



## **Cisco RF Gateway 10 Command Reference Guide**

July 11, 2013

**Cisco Systems, Inc.**

[www.cisco.com](http://www.cisco.com)

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Text Part Number: OL-18700-07

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

*Cisco RF Gateway 10 Command Reference Guide*  
Copyright © 2009-2013, Cisco Systems, Inc.  
All rights reserved.



## **Preface 1v**

Objectives 1v

Audience 1v

Document Organization 1v

New and Modified Commands by Release 1vi

New and Modified Commands in Cisco IOS-XE Release 3.3.0SQ 1vi

New and Modified Commands in Cisco IOS-XE Release 3.2.0SQ 1vii

New and Modified Commands in Cisco IOS Release 12.2(50)SQ4 1ix

New and Modified Commands in Cisco IOS Release 12.2(50)SQ2 1ix

New and Modified Commands in Cisco IOS Release 12.2(50)SQ1 1ix

New and Modified Commands in Cisco IOS Release 12.2(50)SQ 1ix

New and Modified Commands in Cisco IOS Release 12.2(44)SQ2 1x

New and Modified Commands in Cisco IOS Release 12.2(44)SQ1 1x

Document Conventions 1x

Related Documentation 1xi

Obtaining Documentation and Submitting a Service Request 1xi

## **CHAPTER 1**

## **Using the Command-Line Interface in Cisco IOS Software 11**

Initially Configuring a Device 11

Using the CLI 12

Understanding Command Modes 12

Using the Interactive Help Feature 14

Understanding Command Syntax 15

Understanding Enable and Enable Secret Passwords 16

Using the Command History Feature 17

Abbreviating Commands 18

Using Aliases for CLI Commands 18

Using the no and default Forms of Commands 18

Filtering Output Using Output Modifiers 19

Understanding CLI Error Messages 19

Saving Changes to a Configuration 110

Additional Information 110



Cisco RFGW-10 Commands by Functional Group 11

CHAPTER 1

Cisco RFGW-10 Commands 11



## Preface

---

This guide provides information about the Cisco RF Gateway 10 (RFGW-10) command set. This preface contains the following sections:

- [Objectives, page v](#)
- [Audience, page v](#)
- [Document Organization, page v](#)
- [New and Modified Commands by Release, page vi](#)
- [Document Conventions, page x](#)
- [Related Documentation, page xi](#)
- [Obtaining Documentation and Submitting a Service Request, page xi](#)

## Objectives

This guide describes the commands necessary to configure, maintain, and troubleshoot the Cisco RF Gateway 10 Universal Edge Quadrature Amplitude Modulation (RFGW-10 UEQAM) platform.

## Audience

This book is intended for system administrators and support engineers who configure and maintain the Cisco RFGW-10 and cable modem devices.

## Document Organization

This command reference guide is organized as follows:

- Chapter 1—Using the Command-Line Interface in Cisco IOS Software
- Chapter 2—List of Cisco RFGW-10 Commands
- Chapter 3—Cisco RFGW-10 Commands

# New and Modified Commands by Release

This section identifies new and modified commands.

## New and Modified Commands in Cisco IOS-XE Release 3.3.0SQ

New commands in Cisco IOS-XE Release 3.3.0SQ:

- **cable linecard encryption**
- **cable partition**
- **cable qam-group**
- **cable qam-partition**
- **cable qam-replication-group**
- **cable route linecard load-balance-group**
- **cable service-group**
- **cable video encryption-failover-mode**
- **cable video ip udp**
- **cable video ip multicast**
- **cable video pre-encrypted-multicast**
- **clear cable ermi statistics**
- **errp**
- **mac-address**
- **mgmt-ip**
- **pilot-qam**
- **qam-group**
- **qam-partition**
- **replicate-qam**
- **rtsp**
- **show cable ermi errp**
- **show cable ermi rtsp**
- **show cable qam-partition**
- **show\_cable\_qam-replication-group**
- **show\_cable\_service-group**
- **show\_cable\_video\_gqi**

Modified Commands in Cisco IOS-XE Release 3.3.0SQ:

- **active**
- **cable downstream tsid**
- **cable mode**

- **cable video group**
- **cable video labels**
- **cable video multicast uplink**
- **cable video psi-interval**
- **cable video timeout**
- **clear\_cable\_video\_gqi\_statistics**
- **clear cable video packet**
- **clear cable video session**
- **keepalive retry**
- **protocol**
- **server**

Integrated Commands in Cisco IOS-XE Release 3.3.0SQ:

- **mac-address**
- **reset interval**
- **show cable video route**
- **show cable video session**
- **show cable video statistics packet**

## **New and Modified Commands in Cisco IOS-XE Release 3.2.0SQ**

New commands in Cisco IOS-XE Release 3.2.0SQ:

- **block**
- **cable clock auto-revert**
- **cable downstream max-carriers**
- **cable downstream frequency (channel)**
- **cable downstream freq-profile**
- **cable downstream rf-profile**
- **cable downstream start-freq**
- **cable downstream symbol-rate**
- **lane**
- **reserve cardtype**
- **show cable freq-profile**
- **show cable linecard carrier-id-mapping**
- **show cable linecard licenses**
- **show cable linecard load-balancing-group**
- **show cable linecard logical-qamid-mapping**
- **show cable rf-profile**

Modified command in Cisco IOS Release 3.2.0SQ

- **cable depi dest-ip**
- **cable downstream annex**
- **cable downstream interleaver-depth**
- **cable downstream modulation**
- **cable mode**



## New and Modified Commands in Cisco IOS Release 12.2(50)SQ4

New commands in Cisco IOS Release 12.2(50)SQ4:

- **cable midplane ping**

## New and Modified Commands in Cisco IOS Release 12.2(50)SQ2

New commands in Cisco IOS Release 12.2(50)SQ2:

- **depi eqam-stats**
- **protect-tunnel**
- **show cable depi-sessions slot count**
- **show controllers linecard**
- **show depi session**
- **show depi tunnel**

Modified command in Cisco IOS Release 12.2(50)SQ2:

- **show cable video session**

## New and Modified Commands in Cisco IOS Release 12.2(50)SQ1

Modified commands in Cisco IOS Release 12.2(50)SQ1

- **asm**
- **ssm**
- **cable video udp**
- **show cable video label**

## New and Modified Commands in Cisco IOS Release 12.2(50)SQ

New commands in Cisco IOS Release 12.2(50)SQ

- **clear cable video packets**
- **clear cable video server-group**
- **depi-class**
- **dest-ip**
- **depi-tunnel**
- **ip rpc portmapper**
- **l2tp class**
- **mode**
- **keepalive**
- **reset interval**
- **show depi**

Modified commands in Cisco IOS Release 12.2(50)SQ

- **cable mode**
- **cable video servers**
- **show redundancy**

Obsolete commands in Cisco IOS Release 12.2(50)SQ

- **cable image-upgrade download** *slot*

## New and Modified Commands in Cisco IOS Release 12.2(44)SQ2

Modified commands in Cisco IOS Release 12.2(44)SQ2

- **cable image-upgrade download**

## New and Modified Commands in Cisco IOS Release 12.2(44)SQ1

Modified commands in Cisco IOS Release 12.2(44)SQ1

- **show cable line card version**

## Document Conventions

This guide uses the following conventions for command syntax descriptions and textual emphasis:

Convention	Description
<b>boldface</b> font	Commands and keywords are in <b>boldface</b> .
<i>italic</i> font	Arguments for which you supply values are in <i>italics</i> .
[ ]	Elements in square brackets are optional.
{x   y   z}	Alternative, mutually exclusive, keywords are grouped in braces and separated by vertical bars.
[x   y   z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<i>screen</i> font	Terminal sessions and information the system displays are in <i>screen</i> font.
<b>boldface screen</b> font	Information you must enter is in <b>boldface screen</b> font.
<i>italic screen</i> font	Arguments for which you supply values are in <i>italic screen</i> font.
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords, are in angle brackets in contexts where italics are not available.

Convention	Description
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point ( ! ) or a pound sign ( # ) at the beginning of a line of code indicates a comment line.

**Note**

This symbol means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

**Caution**

This symbol means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

This section lists the documents that provide more detailed hardware and software information about the Cisco RFGW-10 documented in this guide. These documents are available on Cisco.com.

For detailed information about the Cisco RFGW-10 platform, see the following documents:

- [Cisco RF Gateway 10 Hardware Installation Guide](#)
- [Cisco RF Gateway 10 Software Feature and Configuration Guide](#)

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.





# Using the Command-Line Interface in Cisco IOS Software

---

This chapter provides basic information about the command-line interface (CLI) in Cisco IOS software and how you can use some of the CLI features. This chapter contains the following sections:

- [Initially Configuring a Device, page 1-1](#)
- [Using the CLI, page 1-2](#)
- [Saving Changes to a Configuration, page 1-10](#)
- [Additional Information, page 1-10](#)

## Initially Configuring a Device

Initially configuring a device varies by platform. For information about performing an initial configuration, see the hardware installation documentation that is provided with the original packaging of the product or go to the Product Support area of Cisco.com at <http://www.cisco.com/cisco/web/support/index.html>

After you have performed the initial configuration and connected the device to your network, you can configure the device by using the console port or a remote access method, such as Telnet or Secure Shell (SSH), to access the CLI or by using the configuration method provided on the device, such as Security Device Manager.

### Changing the Default Settings for a Console or AUX Port

There are only two changes that you can make to a console port and an AUX port:

- Change the port speed with the **config-register 0x** command. Changing the port speed is not recommended. The well-known default speed is 9600.
- Change the behavior of the port; for example, by adding a password or changing the timeout value.

# Using the CLI

This section describes the following topics:

- [Understanding Command Modes, page 1-2](#)
- [Using the Interactive Help Feature, page 1-4](#)
- [Understanding Command Syntax, page 1-5](#)
- [Understanding Enable and Enable Secret Passwords, page 1-6](#)
- [Using the Command History Feature, page 1-7](#)
- [Abbreviating Commands, page 1-8](#)
- [Using Aliases for CLI Commands, page 1-8](#)
- [Using the no and default Forms of Commands, page 1-8](#)
- [Filtering Output Using Output Modifiers, page 1-9](#)
- [Understanding CLI Error Messages, page 1-9](#)

## Understanding Command Modes

The CLI command mode structure is hierarchical, and each mode supports a set of specific commands. This section describes the most common of the many modes that exist.

[Table 1-1](#) lists common command modes with associated CLI prompts, access and exit methods, and a brief description of how each mode is used.

**Table 1-1 CLI Command Modes**

Command Mode	Access Method	Prompt	Exit Method	Mode Usage
User EXEC	Log in.	Router>	Issue the <b>logout</b> or <b>exit</b> command.	<ul style="list-style-type: none"> <li>• Change terminal settings.</li> <li>• Perform basic tests.</li> <li>• Display device status.</li> </ul>
Privileged EXEC	From user EXEC mode, issue the <b>enable</b> command.	Router#	Issue the <b>disable</b> command or the <b>exit</b> command to return to user EXEC mode.	<ul style="list-style-type: none"> <li>• Issue <b>show</b> and <b>debug</b> commands.</li> <li>• Copy images to the device.</li> <li>• Reload the device.</li> <li>• Manage device configuration files.</li> <li>• Manage device file systems.</li> </ul>
Global configuration	From privileged EXEC mode, issue the <b>configure terminal</b> command.	Router(config)#	Issue the <b>exit</b> command or the <b>end</b> command to return to privileged EXEC mode.	Configure the device.

**Table 1-1** CLI Command Modes (continued)

Command Mode	Access Method	Prompt	Exit Method	Mode Usage
Interface configuration	From global configuration mode, issue the <b>interface</b> command.	Router(config-if)#	Issue the <b>exit</b> command to return to global configuration mode or the <b>end</b> command to return to privileged EXEC mode.	Configure individual interfaces.
Line configuration	From global configuration mode, issue the <b>line vty</b> or <b>line console</b> command.	Router(config-line)#	Issue the <b>exit</b> command to return to global configuration mode or the <b>end</b> command to return to privileged EXEC mode.	Configure individual terminal lines.
ROM monitor	From privileged EXEC mode, issue the <b>reload</b> command. Press the <b>Break</b> key during the first 60 seconds while the system is booting.	rommon # >  The # symbol represents the line number and increments at each prompt.	Issue the <b>continue</b> command.	<ul style="list-style-type: none"> <li>Run as the default operating mode when a valid image cannot be loaded.</li> <li>Access the fall-back procedure for loading an image when the device lacks a valid image and cannot be booted.</li> <li>Perform password recovery when a Ctrl-Break sequence is issued within 60 seconds of a power-on or reload event.</li> </ul>

EXEC commands are not saved when the software reboots. Commands that you issue in a configuration mode can be saved to the startup configuration. If you save the running configuration to the startup configuration, these commands will execute when the software is rebooted. Global configuration mode is the highest level of configuration mode. From global configuration mode, you can enter a variety of other configuration modes, including protocol-specific modes.

ROM monitor mode is a separate mode that is used when the software cannot load properly. If a valid software image is not found when the software boots or if the configuration file is corrupted at startup, the software might enter ROM monitor mode. Use the question symbol (?) to view the commands that you can use while the device is in ROM monitor mode.

```
rommon 1 > ?
alias          set and display aliases command
boot           boot up an external process
confreg        configuration register utility
cont           continue executing a downloaded image
context        display the context of a loaded image
cookie         display contents of cookie PROM in hex
.
.
.
rommon 2 >
```

The following example shows how the command prompt changes to indicate a different command mode:

```
Router> enable
Router# configure terminal
Router(config)# interface ethernet 1/1
Router(config-if)# ethernet
Router(config-line)# exit
Router(config)# end
```



**Note** A keyboard alternative to the **end** command is **Ctrl-Z**.

# Using the Interactive Help Feature

The CLI includes an interactive Help feature. [Table 1-2](#) describes how to use the Help feature.

**Table 1-2 CLI Interactive Help Commands**

Command	Purpose
<b>help</b>	Provides a brief description of the help feature in any command mode.
<b>?</b>	Lists all commands available for a particular command mode.
<i>partial command?</i>	Provides a list of commands that begin with the character string (no space between the command and the question mark).
<i>partial command</i> <Tab>	Completes a partial command name (no space between the command and <Tab>).
<i>command ?</i>	Lists the keywords, arguments, or both associated with the command (space between the command and the question mark).
<i>command keyword ?</i>	Lists the arguments that are associated with the keyword (space between the keyword and the question mark).

The following examples show how to use the help commands:

## help

```
Router> help

Help may be requested at any point in a command by entering a question mark '?'. If
nothing matches, the help list will be empty and you must backup until entering a '?'
shows the available options.

Two styles of help are provided:

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?')
and describes each possible argument.

2. Partial help is provided when an abbreviated argument is entered and you want to know
what arguments match the input (e.g. 'show pr?'.)
```



?

Router# ?

Exec commands:

access-enable	Create a temporary access-List entry
access-profile	Apply user-profile to interface
access-template	Create a temporary access-List entry
alps	ALPS exec commands
archive	manage archive files

<snip>

### **partial command?**

Router(config)# zo?

zone zone-pair

### **partial command<Tab>**

Router(config)# we<Tab> webvpn

### **command?**

Router(config-if)# pppoe ?

enable	Enable pppoe
max-sessions	Maximum PPPOE sessions

### **command keyword?**

Router(config-if)# pppoe enable ?

group	attach a BBA group
<cr>	

## Understanding Command Syntax

Command syntax is the format in which a command should be entered in the CLI. Commands include the name of the command, keywords, and arguments. Keywords are alphanumeric strings that are used literally. Arguments are placeholders for values that a user must supply. Keywords and arguments may be required or optional.

Specific conventions convey information about syntax and command elements. [Table 1-3](#) describes these conventions.

**Table 1-3 CLI Syntax Conventions**

Symbol/Text	Function	Notes
< > (angle brackets)	Indicate that the option is an argument.	Sometimes arguments are displayed without angle brackets.
A.B.C.D.	Indicates that you must enter a dotted decimal IP address.	Angle brackets (< >) are not always used to indicate that an IP address is an argument.
WORD (all capital letters)	Indicates that you must enter one word.	Angle brackets (< >) are not always used to indicate that a WORD is an argument.

**Table 1-3 CLI Syntax Conventions (continued)**

Symbol/Text	Function	Notes
LINE (all capital letters)	Indicates that you must enter more than one word.	Angle brackets (< >) are not always used to indicate that a LINE is an argument.
<cr> (carriage return)	Indicates the end of the list of available keywords and arguments, and also indicates when keywords and arguments are optional. When <cr> is the only option, you have reached the end of the branch or the end of the command if the command has only one branch.	—

The following examples show syntax conventions:

```
Router(config)# ethernet cfm domain ?
WORD domain name
Router(config)# ethernet cfm domain dname ?
level
Router(config)# ethernet cfm domain dname level ?
<0-7> maintenance level number
Router(config)# ethernet cfm domain dname level 7 ?
<cr>
Router(config)# snmp-server file-transfer access-group 10 ?
protocol protocol options
<cr>
Router(config)# logging host ?
Hostname or A.B.C.D IP address of the syslog server
ipv6 Configure IPv6 syslog server
Router(config)# snmp-server file-transfer access-group 10 ?
protocol protocol options
<cr>
```

## Understanding Enable and Enable Secret Passwords

Some privileged EXEC commands are used for actions that impact the system, and it is recommended that you set a password for these commands to prevent unauthorized use. Two types of passwords, enable (not encrypted) and enable secret (encrypted), can be set. The following commands set these passwords and are issued in global configuration mode:

- **enable password**
- **enable secret password**

Using an enable secret password is recommended because it is encrypted and more secure than the enable password. When you use an enable secret password, text is encrypted (unreadable) before it is written to the config.text file. When you use an enable password, the text is written as entered (readable) to the config.text file.

Each type of password is case sensitive, can contain from 1 to 25 uppercase and lowercase alphanumeric characters, and can start with a number. Spaces are also valid password characters; for example, “two words” is a valid password. Leading spaces are ignored, but trailing spaces are recognized.

**Note**

Both password commands have numeric keywords that are single integer values. If you choose a number for the first character of your password followed by a space, the system will read the number as if it were the numeric keyword and not as part of your password.

When both passwords are set, the enable secret password takes precedence over the enable password.

To remove a password, use the **no** form of the commands: **no enable password** or **no enable secret password**.

For more information about password recovery procedures for Cisco products, see [http://www.cisco.com/en/US/products/sw/iosswrel/ps1831/products\\_tech\\_note09186a00801746e6.shtml](http://www.cisco.com/en/US/products/sw/iosswrel/ps1831/products_tech_note09186a00801746e6.shtml).

## Using the Command History Feature

The CLI command history feature saves the commands you enter during a session in a command history buffer. The default number of commands saved is 10, but the number is configurable within the range of 0 to 256. This command history feature is particularly useful for recalling long or complex commands.

To change the number of commands saved in the history buffer for a terminal session, issue the **terminal history size** command:

```
Router# terminal history size num
```

A command history buffer is also available in line configuration mode with the same default and configuration options. To set the command history buffer size for a terminal session in line configuration mode, issue the **history** command:

```
Router(config-line)# history [size num]
```

To recall commands from the history buffer, use the following methods:

- Press **Ctrl-P** or the **Up Arrow** key—Recalls commands beginning with the most recent command. Repeat the key sequence to recall successively older commands.
- Press **Ctrl-N** or the **Down Arrow** key—Recalls the most recent commands in the history buffer after they have been recalled using **Ctrl-P** or the **Up Arrow** key. Repeat the key sequence to recall successively more recent commands.

**Note**

The arrow keys function only on ANSI-compatible terminals such as the VT100.

- Issue the **show history** command in user EXEC or privileged EXEC mode—Lists the most recent commands that you entered. The number of commands that are displayed is determined by the setting of the **terminal history size** and **history** commands.

The CLI command history feature is enabled by default. To disable this feature for a terminal session, issue the **terminal no history** command in user EXEC or privileged EXEC mode or the **no history** command in line configuration mode.

## Abbreviating Commands

Typing a complete command name is not always required for the command to execute. The CLI recognizes an abbreviated command when the abbreviation contains enough characters to uniquely identify the command. For example, the **show version** command can be abbreviated as **sh ver**. It cannot be abbreviated as **s ver** because **s** could mean **show**, **set**, or **systat**. The **sh v** abbreviation also is not valid because the **show** command has **vrrp** as a keyword in addition to **version**. (Command and keyword examples from Cisco IOS Release 12.4(13)T.)

## Using Aliases for CLI Commands

To save time and the repetition of entering the same command multiple times, you can use a command alias. An alias can be configured to do anything that can be done at the command line, but an alias cannot move between modes, type in passwords, or perform any interactive functions.

Table 1-4 shows the default command aliases.

**Table 1-4** Default Command Aliases

Command Alias	Original Command
<b>h</b>	help
<b>lo</b>	logout
<b>p</b>	ping
<b>s</b>	show
<b>u</b> or <b>un</b>	undebug
<b>w</b>	where

To create a command alias, issue the **alias** command in global configuration mode. The syntax of the command is **alias mode command-alias original-command**. Following are some examples:

- Router(config)# **alias exec prt partition**—privileged EXEC mode
- Router(config)# **alias configure sb source-bridge**—global configuration mode
- Router(config)# **alias interface rl rate-limit**—interface configuration mode

To view both default and user-created aliases, issue the **show alias** command.

For more information about the **alias** command, see

[http://www.cisco.com/en/US/docs/ios/fundamentals/command/reference/cf\\_book.html](http://www.cisco.com/en/US/docs/ios/fundamentals/command/reference/cf_book.html).

## Using the no and default Forms of Commands

Most configuration commands have a **no** form that is used to reset a command to its default value or disable a feature or function. For example, the **ip routing** command is enabled by default. To disable this command, you would issue the **no ip routing** command. To re-enable IP routing, you would issue the **ip routing** command.

Configuration commands may also have a **default** form, which returns the command settings to their default values. For commands that are disabled by default, using the **default** form has the same effect as using the **no** form of the command. For commands that are enabled by default and have default settings, the **default** form enables the command and returns the settings to their default values.

The **no** and **default** forms of commands are described in the command pages of command references.

## Filtering Output Using Output Modifiers

Many commands produce lengthy output that may use several screens to display. Using output modifiers, you can filter this output to show only the information that you want to see.

Three output modifiers are available and are described as follows:

- **begin *regular expression***—Displays the first line in which a match of the regular expression is found and all lines that follow.
- **include *regular expression***—Displays all lines in which a match of the regular expression is found.
- **exclude *regular expression***—Displays all lines except those in which a match of the regular expression is found.

To use one of these output modifiers, type the command followed by the pipe symbol (`|`), the modifier, and the regular expression that you want to search for or filter. A regular expression is a case-sensitive alphanumeric pattern. It can be a single character or number, a phrase, or a more complex string.

The following example illustrates how to filter output of the **show interface** command to display only lines that include the expression “protocol.”

```
Router# show interface | include protocol
```

```
FastEthernet0/0 is up, line protocol is up
Serial4/0 is up, line protocol is up
Serial4/1 is up, line protocol is up
Serial4/2 is administratively down, line protocol is down
Serial4/3 is administratively down, line protocol is down
```

## Understanding CLI Error Messages

You may encounter some error messages while using the CLI. [Table 1-5](#) shows the common CLI error messages.

**Table 1-5 Common CLI Error Messages**

Error Message	Meaning	How to Get Help
% Ambiguous command: “show con”	You did not enter enough characters for the command to be recognized.	Reenter the command followed by a space and a question mark (?). The keywords that you are allowed to enter for the command appear.

**Table 1-5 Common CLI Error Messages (continued)**

Error Message	Meaning	How to Get Help
% Incomplete command.	You did not enter all the keywords or values required by the command.	Reenter the command followed by a space and a question mark (?). The keywords that you are allowed to enter for the command appear.
% Invalid input detected at “^” marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode. The keywords that you are allowed to enter for the command appear.

## Saving Changes to a Configuration

To save changes that you made to the configuration of a device, you must issue the **copy running-config startup-config** command or the **copy system:running-config nvram:startup-config** command. When you issue these commands, the configuration changes that you made are saved to the startup configuration and saved when the software reloads or power to the device is turned off or interrupted. The following example shows the syntax of the **copy running-config startup-config** command:

```
Router# copy running-config startup-config
Destination filename [startup-config]?
```

You press Enter to accept the startup-config filename (the default), or type a new filename and then press Enter to accept that name. The following output is displayed indicating that the configuration was saved:

```
Building configuration...
[OK]
Router#
```

On most platforms, the configuration is saved to NVRAM. On platforms with a Class A flash file system, the configuration is saved to the location specified by the CONFIG\_FILE environment variable. The CONFIG\_FILE variable defaults to NVRAM.

## Additional Information

- “Using the Cisco IOS Command-Line Interface” section of the *Cisco IOS Configuration Fundamentals Configuration Guide*:  
[http://www.cisco.com/en/US/docs/ios/fundamentals/configuration/guide/cf\\_cli-basics.html](http://www.cisco.com/en/US/docs/ios/fundamentals/configuration/guide/cf_cli-basics.html)
- Cisco Product Support Resources  
<http://www.cisco.com/cisco/web/support/index.html>
- Support area on Cisco.com (also search for documentation by task or product)  
<http://www.cisco.com/en/US/support/index.html>
- *White Paper: Cisco IOS Reference Guide*  
<http://www.cisco.com/web/about/security/intelligence/ios-ref.html>

- Software Download Center (downloads; tools; licensing, registration, advisory, and general information) (requires Cisco.com User ID and password)  
<http://tools.cisco.com/support/downloads/go/Redirect.x?mdfid=278875386>
- Error Message Decoder, a tool to help you research and resolve error messages for Cisco IOS software  
<http://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi>
- Command Lookup Tool, a tool to help you find detailed descriptions of Cisco IOS commands (requires Cisco.com user ID and password)  
<http://tools.cisco.com/Support/CLILookup>
- Output Interpreter, a troubleshooting tool that analyzes command output of supported **show** commands  
<https://www.cisco.com/cgi-bin/Support/OutputInterpreter/home.pl>







## List of Cisco RFGW-10 Commands

This chapter lists Cisco RFGW-10 commands. [Table 2-1](#) contains the commands by functional group.

### Cisco RFGW-10 Commands by Functional Group

The following table lists Cisco RFGW-10 commands by functional category. Each command references the page in Chapter 3 in which the command is described in detail.

[Table 2-1](#) lists commands that relate to the Cisco RFGW-10 platform and not a particular feature or function.

**Table 2-1** *Cisco RFGW-10 Commands by Function*

Command Name	Command Description
<b>Bundled Image Upgrade</b>	
<b>cable image-upgrade disable</b>	Disables the automatic image upgrade of the line card.
<b>show cable image-upgrade bundle</b>	Displays the upgraded images of all the devices on the Supervisor.
<b>show cable image-upgrade status</b>	Displays the upgrade status for a line card.
<b>show cable image-upgrade version</b>	Displays all the upgraded image versions on the line card.
<b>DOCSIS Timing Interface (DTI)</b>	
<b>cable clock auto-revert</b>	Sets the clock in auto-revert mode.
<b>cable clock free-run</b>	Allows the clock to be in free-run mode.
<b>clear cable clock counters</b>	Clears DTI client transition counters of a TCC DTI client and server.
<b>show cable clock</b>	Displays information about displaying Timing, Communication and Control (TCC) card DTI client and server statistic counts.
<b>DOCSIS Timing Interface (DTI) Offset</b>	
<b>cable depi offset</b>	Sets the DOCSIS timing offset on the QAM channel for a line card in DEPI mode.

Table 2-1 Cisco RFGW-10 Commands by Function (continued)

Command Name	Command Description
<b>show cable depi-sessions offset</b>	Displays the DTI timing value on the QAM channels.
<b>Modular Cable Modem Termination System (M-CMTS)</b>	
<b>cable depi dest-ip</b>	Configures Downstream External PHY Interface (DEPI) sessions manually on QAM line cards.
<b>depi class</b>	Creates a template of DEPI control plane configuration settings and enters DEPI class configuration mode.
<b>depi tunnel</b>	Creates a template of DEPI tunnel configuration settings and enters DEPI data session configuration mode.
<b>dest-ip</b>	Assigns an IP address to the EQAM.
<b>depi eqam-stats</b>	Enables debugging information for DEPI EQAM statistics on the Cisco RFGW-10.
<b>l2tp-class</b>	Creates a template of Layer 2 Tunnel Protocol (L2TP) control plane configuration settings and enters L2TP class configuration mode.
<b>protect-tunnel</b>	Configures a DEPI tunnel on the Cisco RFGW-10.
<b>show cable depi-sessions</b>	Displays DEPI sessions configured on the line card.
<b>show cable depi-sessions slot count</b>	Displays the DEPI session count on all QAMs on a line card.
<b>show controllers linecard</b>	Displays information about used bandwidth and total bandwidth on all QAMs on a line card interface.
<b>show depi</b>	Displays DEPI information.
<b>show depi session</b>	Displays DEPI session information.
<b>Platform</b>	
<b>banner lcd</b>	Configures the string on the front panel display.
<b>cable midplane ping</b>	Enables the midplane failure detection between the line card and the Supervisor.
<b>clear cable midplane ping statistics</b>	Clears the midplane ping statistics on the Cisco RFGW-10.
<b>cluster run</b>	Enables clustering on the Cisco RFGW-10
<b>show cable heartbeat</b>	Displays the number of heartbeats received from the line cards.
<b>show cable linecard coreinfo</b>	Copies the core file information from line card flash directory to the bootflash.
<b>show cable linecard cpupload</b>	Displays the CPU utilization information of the line card.
<b>show cable linecard logs</b>	Displays the system log information of the line card at bootup.

**Table 2-1** *Cisco RFGW-10 Commands by Function (continued)*

Command Name	Command Description
<b>show cable linecard process</b>	Displays all the processes running on the line card.
<b>show cable linecard version</b>	Displays image version information of the line card.
<b>show cable midplane ping statistics</b>	Displays the midplane ping statistics on the Cisco RFGW-10.
<b>Redundancy</b>	
<b>auto-sync</b>	Enable automatic synchronization of the configuration files in NVRAM.
<b>class</b>	Configures redundancy class on the line card.
<b>description</b>	Adds a description to the line card group.
<b>linecard-group internal switch</b>	Configures a redundancy line card group.
<b>main-cpu</b>	Enters the main CPU redundancy configuration mode.
<b>member slot</b>	Adds a slot to the line card redundancy group.
<b>mode</b>	Configures the redundancy mode of operation.
<b>redundancy</b>	Enters the redundancy configuration mode.
<b>redundancy force-failover main-cpu</b>	Forces a switchover so that a standby Supervisor module becomes the active Supervisor module.
<b>redundancy force-switchover</b>	Forces the standby Route Processor (RP) or standby Supervisor to assume the role of an active RP or Supervisor.
<b>redundancy linecard-group switchover from slot</b>	Initiates a line card switchover.
<b>redundancy reload</b>	Resets the standby Supervisor to reset both the active and standby Supervisors.
<b>redundancy tcc-group switchover from slot</b>	Initiates a Timing Control Card (TCC) switchover.
<b>reserve cardtype</b>	Configures the reserve line card type in line card redundancy.
<b>show redundancy</b>	Displays the current active and standby Supervisor redundancy status.
<b>show redundancy linecard</b>	Displays information on a line card or line card group redundancy status.
<b>show redundancy tcc</b>	Displays information of the TCC cards redundancy status.
<b>Universal QAM</b>	
<b>cable downstream annex</b>	Sets the MPEG framing format for a downstream port on a line card to Annex A (Europe) or Annex B (North America) or Annex C (Japan).
<b>cable downstream frequency</b>	Sets the center frequency on the line card.

Table 2-1 Cisco RFGW-10 Commands by Function (continued)

Command Name	Command Description
<b>cable downstream if-output</b>	Activates a downstream port on an interface and generates a standard modulated signal or a test signal.
<b>cable downstream interleave-depth</b>	Sets the downstream interleave depth on the line card.
<b>cable downstream interleaver-level</b>	Sets the downstream interleave level on the line card.
<b>cable downstream lock</b>	Locks the downstream port on the QAM interface.
<b>cable downstream modulation</b>	Sets the modulation format for a downstream port on a line card.
<b>cable downstream rf-power</b>	Configures the specified RF output power on the integrated upconverter.
<b>cable downstream rf-shutdown</b>	Enables or disables the RF output from the integrated upconverter.
<b>cable downstream stacking</b>	Configures frequency stacking on the line card.
<b>cable downstream tsid</b>	Configures the TSID value on the QAM subinterface.
<b>cable mode</b>	Sets the mode on the QAM channel.
<b>interface qam</b>	Configures a QAM interface on the line card.
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show interfaces qam</b>	Displays information of the QAM interface.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.
<b>Cisco DS-384 line card RF Port Configuration</b>	
<b>block</b>	Configures the block frequency in the lane for a frequency profile.
<b>cable downstream frequency (channel)</b>	Sets the center frequency on the QAM channel
<b>cable downstream freq-profile</b>	Create the frequency profile at the global level, and applies it to the RF port on the line card.
<b>cable downstream lqam-group</b>	Creates logical QAM groups on the QAM channel.
<b>cable downstream max-carriers</b>	Activates the QAM carrier density on the line card.
<b>cable downstream rf-profile</b>	Creates RF profiles at the global level and applies it across the QAM channel line card.
<b>cable downstream start-freq</b>	Sets the starting frequency on the QAM interface on the line card.
<b>cable downstream symbol-rate</b>	Sets the symbol rate on the line card.
<b>lane</b>	Configures the lane frequency in the frequency profile on the line card.

**Table 2-1** *Cisco RFGW-10 Commands by Function (continued)*

Command Name	Command Description
<b>show cable line card carrier-id-mapping</b>	Displays the carrier-id mapped to the line card.
<b>show cable linecard load-balancing-group</b>	Displays the load balancing groups created on the Cisco RFGW-10.
<b>show cable linecard logical-qamid-mapping</b>	Displays the logical QAM group IDs and QAM carriers mapped to the RF profiles on the Cisco RFGW-10.
<b>show cable rf-profile</b>	Display RF profiles created on the Cisco RFGW-10.
<b>Licensing</b>	
<b>show cable licenses</b>	Displays the license information applied to QAM channels on the Cisco RFGW-10.
<b>Video</b>	
<b>active</b>	Activates the video server group on the line card.
<b>asm</b>	Configures Any Source Multicast (ASM) label definition.
<b>cable linecard encryption</b>	Configures the line card encryption scrambling algorithm.
<b>cable partition</b>	Manages and assigns QAM channels to a QAM partition
<b>cable qam-domain</b>	Configures a QAM domain.
<b>cable qam-group</b>	Configures a QAM group.
<b>cable qam-partition</b>	Configures a QAM partition.
<b>cable qam-replication-group</b>	Configures a QAM replication group.
<b>cable route linecard load-balance-group</b>	Configures a video route on the cable load balancing group and to enter into load balancing group configuration.
<b>cable service-group</b>	Creates a cable service group and enter QAM service group configuration mode
<b>cable video encryption-failover-mode</b>	Enables video encryption failover.
<b>cable video group</b>	Creates a group of unicast video sessions.
<b>cable video ip multicast</b>	Configures the multicast video sessions on a load balancing group.
<b>cable video pre-encrypted-multicast</b>	Configures pre-encrypted Switched Digital Video (SDV) multicast video sessions.
<b>cable video ip udp</b>	Configures unicast video sessions on a load balancing group.
<b>cable video labels</b>	Configures video session labels.
<b>cable video multicast</b>	Configures video multicast sessions on a QAM interface.

Table 2-1 Cisco RFGW-10 Commands by Function (continued)

Command Name	Command Description
<b>cable video multicast uplink</b>	Sets up an uplink port for multicast traffic.
<b>clear cable ermi statistics</b>	Clears the ERMI protocol connection statistics information.
<b>clear cable video packet</b>	Clears all video packet insertions.
<b>clear cable video server-group statistics</b>	Clears all video server-group statistics.
<b>cable video psi-interval</b>	Configures the PSI interval on the QAM subinterface.
<b>cable video servers</b>	Configures server groups for video sessions using external servers.
<b>cable video table</b>	Configures video sessions on a QAM channel using the pre-defined UDP map.
<b>cable video timeout</b>	Configures the video session timeout thresholds.
<b>cable video udp</b>	Configures a unicast video session.
<b>errp</b>	Configures the Edge Resource and Registration protocol (ERRP).
<b>ip</b>	Configures destination IP address for video sessions on a QAM domain.
<b>ip multicast-routing</b>	Enables video multicast routing.
<b>ip rpc portmapper</b>	Establishes a remote procedure call (RPC) connection between an external server and an EQAM.
<b>keepalive retry</b>	Sends keepalive message to a remote client with a specified retry interval.
<b>mac-address</b>	Configures the MAC address for the QAM partition.
<b>mgmt-ip</b>	Configures the IP address of the QAM partition.
<b>mgmt-ip-address mac-address</b>	Configures the management port IP address in a cable video server group.
<b>pilot-qam</b>	Configures the pilot (source) QAM.
<b>protocol</b>	Sets the protocol used by the server in a video server group.
<b>qam-group</b>	Configures a QAM group.
<b>qam-partition</b>	Configures a QAM partition to a load balancing group.
<b>replicate-qam</b>	Configures the replicate (destination) QAM.
<b>reset interval</b>	Sets the reset interval in video server configuration mode
<b>retry interval</b>	Configures the retry time and interval time on the external server.

**Table 2-1** *Cisco RFGW-10 Commands by Function (continued)*

<b>Command Name</b>	<b>Command Description</b>
<b>rtsp</b>	Configures the ERMI Real-time Streaming Protocol (RTSP) on the QAM partition.
<b>server</b>	Configures the external server IP address of video server group.
<b>show cable ermi errp</b>	Displays information on the ERMI Edge Resource and Registration protocol (ERRP) protocol.
<b>show cable ermi rtsp</b>	Displays information on the ERMI Real-time Streaming Protocol (RTSP) protocol.
<b>show cable qam-partition</b>	Displays the QAM partition information on the line card
<b>show_cable_qam-replication-group</b>	Displays the QAM Replication Group (QRG) information on the line card
<b>show_cable_service-group</b>	Display the service group information.
<b>show_cable_video_gqi</b>	Displays all the GQI video sessions information.
<b>show cable video label</b>	Displays the active video labels configured on the chassis.
<b>show cable video multicast uplink</b>	Displays the multicast uplink interfaces configured on the chassis.
<b>show cable video packets</b>	Displays the cable video packets on the QAM interface.
<b>show cable video route</b>	Displays video route information on the chassis.
<b>show cable video server-group</b>	Displays information on a video server group.
<b>show cable video session</b>	Displays the video session information.
<b>show cable video statistics packet</b>	Displays unicast and multicast video packets.
<b>ssm</b>	Configures Specific Source Multicast (SSM) label definition.
<b>video route</b>	Creates video policy routes to redirect traffic to the line cards.







## Cisco RFGW-10 Commands

---

This chapter includes a description of all the Cisco RFGW-10 commands in alphabetical order of the command mnemonic.

For each command, this chapter provides:

- A short description of the purpose of the command
- The command syntax
- The semantics of each parameter in the syntax
- Parameter default values
- Command example or examples
- Related commands

# active

To activate a QAM partition or Video Server Group (VSG), use the **active** command in cable video server configuration mode or QAM partition configuration mode. To deactivate, use the **no** form of this command.

**active**

**no active**

**Syntax Description** This command has no arguments or keywords.

**Command Default** QAM partition is not active.

**Command Modes** QAM partition configuration (config-qp)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated in to Cisco IOS-XE Release 3.3.0SQ.

**Usage Guidelines** Only one video server can be activated. Starting with Cisco IOS-XE Release 3.3.0SQ, the **active** command activates the QAM partition configuration. A reset indication message is sent to the GQI sever for the GQI protocol when the QAM partition is activated. For the Edge Resource Management Interface (ERMI) protocol, a ERMI-1 connection is established and resources are advertised to the Edge Resource Manager (ERM).

When the QAM partition is deactivated (**no** form), the Session Resource Manager (SRM) is closed for the GQI protocol. For ERMI protocol, a notification message is sent and the connection is closed.

**Examples** The following example shows how to activate a QAM partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# protocol gqi
Router(config-qp)# mgmt-ip 1.1.1.1
Router(config-qp)# mac-address 1234.abcd.4e4e
Router(config-qp)# server 192.168.0.10
Router(config-qp)# active
```

## Related Commands

Command	Description
<b>cable qam-partition</b>	Configures the QAM partition for a video server.
<b>mgmt-ip-address mac-address</b>	Configures the management port IP address and MAC address.
<b>protocol</b>	Configures the protocol used by the external server.
<b>server</b>	Configures the IP address of the external server.

## asm

To configure an Any Source Multicast (ASM) definition, use the **asm** command in cable video label configuration mode. To remove the ASM label, use the **no** form of this command.

```
asm label {filter pid pid-list | group IP-address [cbr | GigabitEthernet | TenGigabitEthernet
interface | bitrate bps | jitter ms] }
```

```
no asm label [filter pid {all | pid-list}]
```

### Syntax Description

<i>label</i>	Specifies the name of the session.
<b>filter</b>	Adds or deletes a filter to the video session.
<b>pid</b>	Sets filtering of PIDs for pass-through video sessions.
<i>pid-list</i>	Specifies the PIDs or the range of PIDs or both to be dropped for the video session. The PID range is specified in “ <i>lower_pid</i> - <i>upper_pid</i> ” format. All PIDs must be within 1 to 8190 inclusively.  PIDs and PID ranges are to be separated by commas. A space is required before and after the commas and hyphens.
<b>all</b>	Deletes all filtered PIDs. This keyword is applicable to the <b>no</b> form of the command.
<b>group</b>	Indicates the multicast group.
<i>IP-address</i>	Specifies the destination IP address.
<b>cbr</b>	(Optional) Specifies that the session is supposed to be constant bitrate.
<b>GigabitEthernet</b>	(Optional) Indicates the Gigabit Ethernet interface. Valid slot range is 1 to 12 and port range is 3 through 6, 13 and 14.
<b>TenGigabitEthernet</b>	(Optional) Indicates the 10-Gigabit Ethernet interface. Valid slots and ports are 1 and 2.
<i>interface</i>	Specifies the interface slot and port.
<b>bitrate</b>	(Optional) Sets the bitrate allocated for the session.
<i>bps</i>	(Optional) Specifies the bitrate value. Valid range is 1 to 52000000 bps. Default is 3.75 Mbps
<b>jitter</b>	(Optional) Specifies the amount of jitter allowed in a network.
<i>ms</i>	(Optional) Specifies the jitter value. Valid range is 10 to 200 ms. Default is 200 ms.

### Command Default

This command has no default behavior or values.

### Command Modes

Cable video label configuration (cfg-video-lbl)

**Command History**

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
12.2(50)SQ1	Added the <b>filter</b> keyword to the command to allow filtering of PIDs for pass-through video sessions.

**Usage Guidelines**

The Cisco RFGW-10 supports Any Source Multicast (ASM). An ASM session is identified by the group IP address.

Filtering of PIDs is applicable for pass-through video sessions. It is intended for filtering of unreferenced PIDs. No PMT regeneration will be performed even if PIDs referenced in the PMT are filtered. Up to 32 PIDs can be filtered per session. Up to eight PIDs or PID ranges can be specified in one CLI line. Multiple CLI lines can be used to specify the PID filter.

An ASM video session can be mapped to multiple QAM channels. All cloned sessions of the same video label share the same attributes, including the filtered PID list.

The **no** form of the command with **filter pid** keyword removes the PIDs from the filtered PID set. A subset of the filtered PID set can be removed with this form.

The **no** form of the command without the **filter pid** keyword removes the ASM label and the associated filter PID list if it exists.

**Note**

To avoid oversubscription, ensure that the actual bitrate of the video session does not exceed the allocated bitrate.

**Examples**

The following example shows the ASM configuration on the Cisco RFGW-10:

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# asm asm1 group 233.1.1.1 bitrate 3750000
```

The following example shows an ASM configuration with filtering configured:

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# asm asm1 group 233.1.1.1 bitrate 3750000
Router(cfg-video-lbl)# asm asm1 filter pid 34 , 21 , 40 - 45
Router(cfg-video-lbl)# exit
```

**Related Commands**

Command	Description
<b>cable video labels</b>	Enters the cable video label configuration.
<b>cable video multicast</b>	Configures video multicast sessions on the QAM interface.
<b>show cable video label</b>	Displays the labels configured on the chassis.
<b>ssm</b>	Configures an SSM video session definition.

# auto-sync

To enable automatic synchronization of the configuration files in NVRAM, use the **auto-sync** command in the main CPU redundancy configuration mode. To disable automatic synchronization, use the **no** form of this command.

**auto-sync** { **startup-config** | **config-register** | **bootvar** | **running-config** | **standard** }

**no auto-sync** { **startup-config** | **config-register** | **bootvar** | **standard** }

## Syntax Description

<b>startup-config</b>	Specifies synchronization of the startup configuration files.
<b>config-register</b>	Specifies synchronization of the configuration register values.
<b>bootvar</b>	Specifies synchronization of the following boot variables: <ul style="list-style-type: none"> <li>• <b>BOOT</b>—Set by the <b>boot system</b> <i>device:filename</i> command.</li> <li>• <b>CONFIG_FILE</b>—Set by the <b>boot config</b> <i>device:filename</i> command.</li> <li>• <b>BOOTLDR</b>—Set by the <b>boot bootldr</b> <i>device:filename</i> command.</li> </ul>
<b>running-config</b>	Specifies synchronization of the running configuration files.
<b>standard</b>	Specifies synchronization of all of the system files (startup configuration, boot variables, and running config configuration registers).

## Command Default

At the Cisco RF Gateway 10 chassis level, all the system files are synchronized by default.

## Command Modes

Main CPU redundancy configuration (config-r-mc)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

## Usage Guidelines

We recommend that you use the **auto-sync standard** command to ensure that all system files are synchronized between the two Supervisor modules. The **no auto-sync** command is not used in production plants.

## Examples

The following example shows the synchronization of all system files on the Cisco RFGW-10 chassis:

```
Router#configure terminal
Router(config)#redundancy
Router(config-red)#main-cpu
Router(config-r-mc)#auto-sync standard
Router(config-r-mc)#exit
Router(config-red)#exit
```

Related Commands	Command	Description
	<b>main-cpu</b>	Enters the main CPU redundancy configuration mode.
	<b>redundancy</b>	Enters the redundancy configuration mode.

# banner lcd

To configure the string on the front panel display, use the **banner lcd** command in global configuration mode. To disable the string, use the **no** form of this command.

```
banner lcd text

no banner lcd
```

Syntax Description	<i>text</i> Specifies the information that is displayed on the front panel.
--------------------	---

Command Default	The platform hostname is displayed by default.
-----------------	--

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	You can use this command to specify additional information when identifying the chassis or including extra contact information.
------------------	---

Examples	The following example shows the configuration of the banner on the Cisco RFGW-10:  Router# <b>configure terminal</b> Router(config)# <b>banner lcd This is RFGW-10.</b>
----------	--



# block

To configure the block frequency in the lane for a frequency profile on the Cisco RFGW-10 DS-384 line card, use the **block** command in frequency profile lane configuration mode.

**block** *block-id* **start-freq** *frequency*

## Syntax Description

<i>block_id</i>	Block ID in the lane frequency profile. Valid range is from 1 to 4.
<b>start-freq</b>	Specifies the starting frequency of the block.
<i>frequency</i>	Downstream start frequency of a block in a lane. Valid range is from 48000000 to 999000000 Hz.
<b>Note</b>	The valid range of the block depends on the starting frequency of the parent lane.

## Command Default

The command has no default behavior or values.

## Command Modes

Frequency profile lane configuration mode (config-freq-prof-lane)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

## Usage Guidelines

Cisco IOS Release Cisco IOS-XE Release 3.2.0SQ supports global templates or profiles on the Cisco RFGW-10 DS-384 line card. A wider range of frequency spectrum is supported on the upconverter on the line card. The Supervisor card uses two frequency schemes—static frequency scheme and user-defined frequency scheme—to configure the frequency profiles at the port level.



### Note

The frequency schemes are applicable to Cisco RFGW-10 DS-384 line card only.

The user-defined frequency scheme allows you to define the frequency at the chassis level, and apply the cable downstream frequency spectrum to any port on any Cisco RFGW-10 DS-384 line card.

A frequency profile has four frequency lanes in the 1 GHz spectrum. Each lane has a frequency of 216 MHz. Each lane has 4 blocks of 54 MHz, and each block has 8 carriers. The start frequency assigned to a carrier must be in the frequency range of 216 MHz.



### Note

The channel frequencies cannot overlap with each other. Each lane cannot exceed 32 carriers, and a block cannot exceed the frequency of 54 MHz and 8 carriers.



### Note

This command is applicable on the Cisco RFGW10-DS-384 line card.

Examples

The following example creates the blocks in frequency profile lane configuration mode:

```
Router(config)# cable downstream freq-profile 1
Router(config-freq-prof)# lane 1 start-freq 48000000
Router(config-freq-prof-lane)# block 1 start-freq 48000000
Router(config-freq-prof-lane)# block 2 start-freq 96000000
Router(config-freq-prof-lane)# exit
Router(config-freq-prof)#
```

Related Commands

Command	Description
cable downstream freq-profile	Creates the frequency profile for a Cisco RFGW-10 DS-384 line card.
lane	Creates the lane frequency for the frequency profile.

# cable clock auto-revert

To set the clock in auto-revert mode, use the **cable clock auto-revert** command in global configuration mode. To disable the clock auto-revert mode, use the **no** form of this command.

**cable clock auto-revert prefer** *slot*

**no cable clock auto-revert prefer**

Syntax Description	prefer	Specifies the TCC card that should be made active.
	slot	TCC card slot. Valid slots are 13 and 14.

Command Default	The clock is not in auto-revert mode.
-----------------	---------------------------------------

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	Use the <b>cable clock auto-revert prefer</b> command to choose which TCC card should active, when both the TCC cards are connected to DTI servers, and are in the same clock state.
------------------	--

Examples	The following example shows the auto-revert preference set to TCC card in slot 14: <pre>Router(config)# cable clock auto-revert prefer 14</pre>
----------	--

Related Commands	Command	Description
	<b>clear cable clock counters</b>	Clears DTI client transition counters of a TCC DTI card.
	<b>show cable clock</b>	Displays information on DTI client, and server statistic counts, and path traceability of a TCC card.

# cable clock auto-revert

To set the clock in auto-revert mode, use the **cable clock auto-revert** command in global configuration mode. To disable the clock auto-revert mode, use the **no** form of this command.

**cable clock auto-revert prefer** *slot*

**no cable clock auto-revert prefer**

## Syntax Description

<b>prefer</b>	Specifies the TCC card that should be made active.
<i>slot</i>	TCC card slot. Valid slots are 13 and 14.

## Command Default

The clock is not in auto-revert mode.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

Use the **cable clock auto-revert prefer** command to choose which TCC card should active, when both the TCC cards are connected to DTI servers, and are in the same clock state.

## Examples

The following example shows the auto-revert preference set to TCC card in slot 14:

```
Router(config)# cable clock auto-revert prefer 14
```

## Related Commands

Command	Description
<b>clear cable clock counters</b>	Clears DTI client transition counters of a TCC DTI card.
<b>show cable clock</b>	Displays information on DTI client, and server statistic counts, and path traceability of a TCC card.

# cable clock free-run

To set the clock in free-run mode, use the **cable clock free-run** command in global configuration mode. To disable the clock from free-run mode, use the **no** form of this command.

**cable clock slot free-run**

**no cable clock slot free-run**

<b>Syntax Description</b>	<i>slot</i>	Specifies the slot in the TCC card. Valid slots are 13 and 14.
---------------------------	-------------	--

<b>Command Default</b>	The clock is not in free-run mode.
------------------------	------------------------------------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

<b>Usage Guidelines</b>	We recommend to avoid running free-run mode in a Timing, Communication and Control (TCC) card server and client setup.
-------------------------	--

<b>Examples</b>	The following example shows the configuration of the TCC card in slot 13 in the free-run state:
-----------------	---

```
Router(config)# cable clock 13 free-run
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear cable clock counters</b>	Clears DTI client transition counters of a TCC DTI card.
	<b>show cable clock</b>	Displays information on DTI client, and server statistic counts, and path traceability of a TCC card.

# cable depi dest-ip

To configure Downstream External PHY Interface (DEPI) sessions manually on QAM line cards, use the **cable depi dest-ip** command in the QAM subinterface configuration mode. To remove a session, use the **no** form of this command.

**cable depi dest-ip** *IP address*

**no cable depi dest-ip** *IP address*

## Syntax Description

<i>IP address</i>	IP address of the destination network.
-------------------	--

## Command Default

This command has no default behavior or values.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.2.0SQ	This command was modified. The <b>session-id</b> keyword was removed from the command.

## Usage Guidelines

This command is used to configure DEPI sessions manually instead of signalled remote sessions. When you configure a DEPI session on the QAM channel, a route is established.

## Examples

The following example shows DEPI sessions created manually created on a QAM line card 7 on the Cisco RFGW-10:

```
Router(config)# interface qam-red 7/1.1
Router(config-subif)# cable mode depi local lbg 1
Router(config-subif)# cable depi dest-ip 10.1.1.1
```

## Related Commands

Command	Description
<b>cable depi offset</b>	Sets the DOCSIS Timing Offset (DTI) value for the DEPI session.
<b>cable mode depi</b>	Sets the mode and usage of a QAM channel on a line card.
<b>show cable depi-sessions</b>	Displays the manual and L2TP DEPI sessions configured on the Cisco RFGW-10.

# cable depi offset

To set the DOCSIS timing offset on the QAM channel for a line card in a Downstream External PHY Interface (DEPI), use the **cable depi offset** command in global configuration mode and QAM interface and subinterface configuration mode. To disable the offset, use the **no** form of this command.

**cable depi offset** *ticks*

**no cable depi offset** *ticks*

## Syntax Description

<i>ticks</i>	Specifies the offset value. Valid range is from 0 to 32768 for 1/10.24 MHz. Default is 0.
--------------	---

## Command Default

This command has no default behavior or values.

## Command Modes

Global configuration (config)  
QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

This command sets the DOCSIS timing offset (DTI) for a QAM channel in a DEPI mode. The DTI Offset enables DOCSIS timing offset adjustment per QAM channel. The actual timing offset needs to be measured on each QAM channel.

To configure all the QAM ports to the same timing offset, use the **cable depi offset** command at the port level. However, this sets the offset value on all the QAM channels on that port.

You can also configure the entire chassis with the same timing offset.

## Examples

The following example shows how to configure the timing offset adjustment on slot 7 RF port 3:

```
Router(config)# interface qam 7/3
Router(config-if)# cable depi offset 950
```

The following example shows how to configure the timing offset adjustment on line card slots 3 and 5 RF port range 1 - 12. The timing offset value of line card slots 3 and 5 will be adjusted by 150 ticks.

```
Router(config)# interface range qam 3/1 - 12, qam 5/1 - 12
Router(config-if-range)# cable depi offset 150
```

The following example shows the DTI offset being set to 324 ticks on QAM channels:

```
Router(config)# interface qam-red 3/1.1
Router(config-subif)# cable mode depi local
Router(config-subif)# cable depi offset 324
```

**Related Commands**

Command	Description
<b>cable depi dest-ip</b>	Sets the destination IP address for a DEPI session.
<b>cable mode depi</b>	Sets the mode and usage of a QAM channel on a line card.



# cable downstream annex

To set the Moving Picture Experts Group (MPEG) framing format for a downstream port on a cable interface line card to Annex A (Europe), Annex B (North America), or Annex C (Japan), use the **cable downstream annex** command in RF profile configuration, QAM interface, and subinterface configuration mode.

**cable downstream annex {A | B | C}**

## Syntax Description

<b>A</b>	Annex A: The downstream uses the EuroDOCSIS J.112 standard.
<b>B</b>	Annex B: The DOCSIS-compliant cable plants that support North American channel uses ITU J.83 Annex B downstream radio frequency.
<b>C</b>	Annex C: A variant of DOCSIS 1.1 designed to operate in Japanese cable systems.

## Command Default

Annex B is the default for all Cisco cable interface line cards.

## Command Modes

RF profile configuration (config-rf-prof)  
QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for Cisco RF Gateway 10 was added.
Cisco IOS-XE Release 3.2.0SQ	This command was modified. The annex type can be set globally on the RFGW-10 using the RF profile configuration.

## Usage Guidelines

The Cisco RFGW-10 supports Annex A, Annex B, and Annex C operation.



### Note

If the Annex is changed, the cable modems may go offline.

Annex is configured at the QAM interface (config-if) or QAM subinterface (config-subif) on the Cisco RFGW-10 DS-48 line card.



### Note

Executing port level commands such as **cable downstream annex**, **cable downstream modulation**, **cable downstream stacking**, **cable downstream frequency** and, **cable downstream rf-power** at the QAM channel level modifies all the QAM channels on that port. This is applicable on the Cisco RFGW-10 DS-48 line card.

Annex is a part of RF profile configuration mode for Cisco RFGW-10 DS-384 line card. You can apply Annex only after you create the RF profiles on Cisco RFGW-10 DS-384 channels.

In Cisco IOS-XE Release 3.2.0SQ, RF profiles can be created globally at the chassis level, and applied to any QAM channel on the Cisco RFGW-10 DS-384 line card. The RF profiles are used for grouping QAM channels with same modulation, Annex mode, symbol rate, and interleaver depth.

The **cable downstream rf-profile** command creates the RF profile. The modulation, annex mode, symbol-rate, and interleaver depth are configured in the RF profile configuration mode.

**Note**

RF profiles are supported only on the Cisco RFGW-10 DS-384 line card.

The following example is a sample of a RF profile configuration:

```
Router(config)# cable downstream rf-profile 64qam-B
Router(config-rf-prof)# cable downstream annex B
Router(config-rf-prof)# cable downstream modulation 64
Router(config-rf-prof)# cable downstream interleaver-depth option1 I128-J1 option2 I32-J4
Router(config-rf-prof)# cable downstream symbol-rate 3500000
Router(config-rf-prof)# exit
Router(config)#
```

**Examples**

The following example shows how to set the MPEG framing format to Annex B on a Cisco RFGW-10 DS-48 line card:

```
Router# configure terminal
Router(config)# interface qam 3/1
Router(config-if)# cable downstream annex B
```

The following example shows how to set the annex mode for carriers on Cisco RFGW-10 DS-384 line card. On Cisco RFGW-10 DS-384, the annex modes are configurable only via RF profiles. Once an RF profile with the desired annex mode has been created, use the following commands to configure the QAM channel:

```
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream rf-profile 64qam-B
Router(config-subif)# exit
```

**Related Commands**

Command	Description
<b>cable downstream rf-profile</b>	Creates RF profiles on the RFGW-10.
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream frequency

To set the downstream center frequency in the cable interface line card to reflect the digital carrier frequency of the downstream radio frequency carrier (the channel) for that downstream port, use the **cable downstream frequency** command in QAM interface and subinterface configuration mode. Use the **no** form of this command on the cable interfaces with an integrated upconverter to unset the downstream frequency and to disable the RF output from the integrated upconverter.

**cable downstream frequency** *down-freq-hz*

**no cable downstream frequency**

## Syntax Description

*down-freq-hz* The known center frequency of the downstream carrier in Hertz (the valid range is 57,000,000 to 999,000,000). The usable range depends on whether the downstream is configured for DOCSIS or EuroDOCSIS values:

- DOCSIS = 88,000,000 to 855,000,000 MHz
- Extended frequency range = 70,000,000 to 855,000,000 MHz
- EuroDOCSIS = 112,000,000 to 858,000,000 MHz

Cisco IOS supports a superset of these standards, and setting a frequency value outside these limits violates the DOCSIS or EuroDOCSIS standards. Cisco does not guarantee the conformance of the downstream and upconverter outputs when using frequencies outside the DOCSIS or EuroDOCSIS standards.

## Command Default

The default frequency on the Cisco RF Gateway 10 is 501 Mhz.

## Command Modes

QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

## Usage Guidelines

You must set the downstream frequency of the RF output to match the expected input frequency of the upconverter. To do this, you enter the fixed center frequency of the downstream channel for the downstream port. (You can also select a default that does not set a specific fixed value.) The valid range for a fixed center frequency is 57,000,000 to 999,000,000 Hz. To install an IF-to-RF upconverter in the downstream path, you can use the center frequency to configure an IF-to-RF upconverter.



### Note

The downstream center frequency is set to 501 MHz on all first QAM channels on a port. But, if the QAM channel is in the rf-shut mode, you are required to set the frequency settings on all of the QAM channels on the Cisco RF Gateway 10 before enabling them.

The digital carrier frequency is specified to be the center of a 6.0 MHz channel. For example, EIA channel 95 spans 90.000 to 96.000 MHz. The center frequency is 93.000 MHz, which is the digital carrier frequency that should be configured as the downstream frequency. The typical range for current CATV headends is 88,000,000 to 860,000,000 Hz.



**Note** This command is executed at both the QAM interface as well as the QAM subinterface level. Executing at the subinterface level changes all of the frequencies on that QAM interface. The frequencies are separated by a number determined by the annex.



**Note**

DOCSIS allows downstreams to use any center frequency from 88,000,000 to 855,000,000 MHz. However, when most cable modems are switched on, they scan the downstream frequencies in the NTSC channel plan. If a valid downstream is not found, the cable modems scan the remaining frequencies. For speedy and efficient registration times, we recommend you to configure downstreams to the frequencies specified in the NTSC channel plan.

**Examples**

The following example shows how to set the downstream center frequency display value on a Cisco RFGW-10:

```
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream frequency 520000000
```

**Related Commands**

Command	Description
<b>cable downstream annex</b>	Sets the MPEG framing format for a downstream port on a cable interface line card to Annex A (Europe), Annex B (North America) and Annex C (Japan).
<b>cable downstream rf-power</b>	Configures the specified RF output power on the integrated upconverter.
<b>cable downstream rf-shutdown</b>	Enables or disables the RF output from the integrated upconverter.
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream frequency (channel)

To set the center frequency on the QAM channel, use the **cable downstream frequency** command in QAM subinterface configuration mode. To disable the center frequency, use the **no** form of this command.

**cable downstream frequency** *qam-center-frequency* [**lane** *lane-id* **block** *block-id*]

**no cable downstream frequency** *qam-center-frequency*

## Syntax Description

*frequency*

Sets the center frequency on the QAM subinterface on the Cisco RFGW10-DS-384 line card. Valid ranges in MHz per Annex type are:

- Annex A: 1003-744; default is 259
- Annex B, Annex C: 1002-768; default is 234

## Command Default

By default, QAM channels are not assigned with a default center frequency.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

### Release

### Modification

Cisco IOS-XE Release 3.2.0SQ	This command was introduced.
------------------------------	------------------------------

## Usage Guidelines

The **cable downstream frequency** assigns the lane and block assigned at the QAM interface level to the subinterface on the Cisco RFGW-10 DS-384.



### Note

The center frequency assigned to Cisco RFGW-10 DS-384 QAM channel should be within the frequency range as specified by the freq-profile at the QAM interface (port level).

The Cisco RFGW-10 DS0-384 supports a maximum of 8 QAM channels per block. Thus, while configuring the center frequencies on the QAM channels, ensure that only a maximum of 8 carriers belong to a particular block (as defined by the freq-profile applied at the QAM interface).



### Note

This command is applicable on both the line cards, but **lane** and **block** parameters are only applicable on Cisco RFGW-10 DS-384 line card.

Examples

The following example shows the frequency configuration assigned to the QAM channel:

```
Router(config)# interface qam 9/1.1
Router(config-subif)# cable downstream frequency 714000000 lane 2 block 4
Router(config-if)
```

Related Commands

Command	Description
<b>cable downstream rf-profile</b>	Create RF profiles at the Cisco RFGW-10 chassis level, and apply it across any QAM channel on the Cisco RFGW-10 DS-384 line card.
<b>cable downstream freq-profile</b>	Creates the frequency profile configuration on the Cisco RFGW10.

# cable downstream freq-profile

To create the frequency profile at the Cisco RF Gateway 10 chassis level, and apply it to any RF port on the Cisco RFGW-10 DS-384 line card, use the **cable downstream freq-profile** command in global configuration mode. To disable the frequency profile applied to the RF port, use the **no** form of this command.

**cable downstream freq-profile** *freq-profile-id*

**no cable downstream freq-profile line** *freq-profile-id*

<b>Syntax Description</b>	<i>freq-profile-id</i>	Profile ID applied to the RF port. Default is 1.
---------------------------	------------------------	--

<b>Command Default</b>	Default frequency profile (default-freq-profile) is created.
------------------------	--

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

<b>Usage Guidelines</b>	<p>Cisco IOS-XE Release 3.2.0SQ supports global templates or profiles on the Cisco RFGW-10 DS-384 line card. Each port on the Cisco RFGW10 DS-384 line card provides a frequency range from 45 MHz to 1003 MHz. The Supervisor card uses two frequency schemes—static frequency scheme and the user-defined frequency scheme—to configure the frequency profile at port level.</p> <p>The <b>cable downstream freq-profile</b> command configures the frequency spectrum in a user-defined frequency scheme on the Cisco RFGW-10 chassis. The frequency scheme is applied to any port on the Cisco RFGW10 DS-384 line card. In the frequency profile configuration mode, you can set the lane and block frequency.</p>
-------------------------	--



## Note

This command is applicable only on the Cisco RFGW10-DS-384 line card.



## Tip

Configure the **cable downstream annex** before creating the frequency profile. If the Annex mode is not configured, the default Annex B value is set on the line card.

Examples

The following example creates a frequency profile on the Cisco RFGW-10:

```
Router(config)# cable downstream freq-profile freq-profile1
Router(config-freq-prof)# ?
Frequency Profile subcommands:
  exit  Exit from freq profile config mode
  lane  lane configurations
```

Related Commands

Command	Description
lane	Configures the lane frequency in a frequency profile.
block	Configures the block frequency in a lane in the frequency profile.
show cable freq-profile	Displays all the frequency profiles configured on the Cisco RFGW-10 DS-384 line card.



# cable downstream if-output

To activate a downstream port on a cable interface and to generate a standard modulated signal or a test signal, use the **cable downstream if-output** command in QAM interface and subinterface configuration mode. To disable all signal output on the intermediate frequency (IF) carrier and to shut down the interface, use the **no** form of this command.

**cable downstream if-output [continuous-wave]**

**no cable downstream if-output**

<b>Syntax Description</b>	<b>continuous-wave</b> Displays an unmodulated carrier signal on the downstream, disabling normal data network operations.
---------------------------	--

<b>Command Default</b>	The downstream interface is enabled for normal data use.
------------------------	--

<b>Command Modes</b>	QAM interface and subinterface configuration (config-if and config-subif)
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

<b>Usage Guidelines</b>	You can use the <b>cable downstream if-output</b> command to perform the following actions:
-------------------------	---

- Configure a downstream to relay a modulated signal
- Transmit data over the Hybrid Fiber Coaxial (HFC) cable network
- Test the cable plant
- Disable the interface

**cable downstream if-output continuous-wave**—Generates an unmodulated, continuous sine wave on the downstream interface. You can use a spectrum analyzer to verify the frequency, amplitude, and power of the wave. You can use the **cable downstream if-output** command to test the signal continuity on the downstream until you resume normal modulated operations.

**no cable downstream if-output**—Terminates all signal output and shuts down the downstream interface. The interface is disabled until you reactivate the downstream using the **cable downstream if-output** command.

<b>Examples</b>	The following example shows how to enable downstream on QAM interface 3 on the Cisco RFGW-10:
-----------------	---

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream if-output
```

Related Commands	Command	Description
	<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
	<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream interleaver-depth

To set the downstream interleave depth, use the **cable downstream interleaver-depth** command in RF profile configuration, QAM interface, and subinterface configuration mode. To restore the default setting, use the **no** form of this command.

**cable downstream interleaver-depth** *depth-value*

**no cable downstream interleaver-depth**

<b>Syntax Description</b>	<p><i>depth-value</i></p> <p>Downstream interleave depth values.</p> <ul style="list-style-type: none"> <li>• I12-J17 RFGW_MB_FEC-I-12-J-17</li> <li>• I128-J1 RFGW_MB_FEC-I-128-J-1</li> <li>• I128-J2 RFGW_MB_FEC-I-128-J-2</li> <li>• I128-J3 RFGW_MB_FEC-I-128-J-3</li> <li>• I128-J4 RFGW_MB_FEC-I-128-J-4</li> <li>• I128-J5 RFGW_MB_FEC-I-128-J-5</li> <li>• I128-J6 RFGW_MB_FEC-I-128-J-6</li> <li>• I128-J7 RFGW_MB_FEC-I-128-J-7</li> <li>• I128-J8 RFGW_MB_FEC-I-128-J-8</li> <li>• I16-J8 RFGW_MB_FEC-I-16-J-8</li> <li>• I32-J4 RFGW_MB_FEC-I-32-J-4</li> <li>• I64-J2 RFGW_MB_FEC-I-64-J-2</li> <li>• I8-J16 RFGW_MB_FEC-I-8-J-16</li> </ul>						
<b>Command Default</b>	The default interleave depth value is 5 (I=32, J=4).						
<b>Command Modes</b>	<p>RF profile configuration (config-rf-profile)</p> <p>QAM interface and subinterface configuration (config-subif)</p>						
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>12.2(44)SQ</td><td>This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.</td></tr> <tr> <td>Cisco IOS-XE Release 3.2.0SQ</td><td>This command was modified. The modulation format can be set globally on the Cisco RFGW-10 DS-384 line card using the RF profile configuration.</td></tr> </table>	Release	Modification	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.	Cisco IOS-XE Release 3.2.0SQ	This command was modified. The modulation format can be set globally on the Cisco RFGW-10 DS-384 line card using the RF profile configuration.
Release	Modification						
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.						
Cisco IOS-XE Release 3.2.0SQ	This command was modified. The modulation format can be set globally on the Cisco RFGW-10 DS-384 line card using the RF profile configuration.						

Usage Guidelines

In Cisco IOS Release 3.2.0SQ, RF profiles can be created globally at the chassis level, and applied to any QAM channel on the Cisco RFGW-10 DS-384 line card. The RF profiles are used for grouping QAM channels with same modulation, annex mode, symbol rate, and interleaver depth.

The **cable downstream rf-profile** command creates the RF profile. The modulation, annex mode, symbol-rate, and interleaver depth are configured in the RF profile configuration mode.



Note

RF profiles are supported on the Cisco RFGW-10 DS-384 line card.

The syntax for the Cisco RFGW-10 DS-384 line card at the RF profile configuration level is:

**cable downstream interleaver-depth option1 *depth-value* option2 *depth-value***

**no cable downstream interleaver option1**

<b>option1</b>	Indicates the interleaver-depth FEC I/J values at the RF profile.
<b>option2</b>	Indicates the interleaver-depth FEC I/J values that are available at the subinterface level when the profile in assigned to the QAM subinterface.

Once the RF profile is created with the FEC I/J values, assign the RF profile to the carrier subinterface. The following example is a sample of a RF profile configuration:

```
Router(config)# cable downstream rf-profile 1
Router(config-rf-prof)# cable downstream interleaver depth option1 I12-J17 option2 I12-J17
Router(config-rf-prof)# exit
Router(config)#
```

The FEC I/J values specified in **option2** are applied to the carrier, and are available at the QAM subinterface level. The following is an example of interface 3/1.1 with the FEC I/J values on the Cisco RFGW-10 DS-384 line card:

```
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream interleave-depth I12-J17
Router(config-subif)# exit
```

This command sets the minimum latency of the system. A higher interleave depth relays the bits of each code word over a great transmission time and protects the noise bursts on the hybrid fiber coaxial (HFC) network.

Interleave transmissions do not transmit each code word by itself, but instead relay the bits from multiple code words at the same time. This noise burst affects the minimum number of bits per code word and allows the Forward Error Correction (FEC) algorithm a greater chance of detecting and correcting any transmission errors.

A higher interleave depth transmits bits from a greater number of code words, increasing the efficacy of the FEC algorithm. However, a higher depth also increases downstream latency, which might slow TCP/IP throughput for some configurations, so you need to choose an interleave depth appropriate to the plant’s noise levels and application needs.

If your cable plant is experiencing high noise levels, increase the default value of 32 to 64. For plants with exceptionally high noise levels, increase the interleave value to 128 to secure the cable network from noise bursts.

Low interleave depth values cause some packet loss on HFC networks, because burst noise lasts beyond the error correction block correctable length. However, on cable plants with exceptionally low noise levels, we recommend you to use the default value of 32, and then try an interleave of either 16 or 8 to confirm an increase in performance without increasing the number of errors that result from noise.

Table 3-1 shows interleave characteristics and their relation to one another.

**Table 3-1 DOCSIS Downstream Cable Interleave Descriptions**

I (Number of Taps)	J (Increment)	Burst Protection 64-QAM/256 QAM	Latency 64-QAM/256 QAM
8	16	5.9 microseconds/4.1 milliseconds	0.22 ms/0.15 ms
16	8	12 microseconds/8.2 milliseconds	0.48 ms/0.33 ms
32	4	24 microseconds/16 milliseconds	0.98 ms/0.68 ms
64	2	47 microseconds/33 milliseconds	2.0 ms/1.4 ms
128	1	95 microseconds/66 milliseconds	4.0 ms/2.8 ms



**Note**

Table 3-1 does not apply to EuroDOCSIS cable plants because the interleave depth for EuroDOCSIS cable interfaces is fixed.



**Note**

Executing this command at the QAM channel level (subinterface) changes the interleave level of that subinterface. However, executing the command at the QAM port level (interface), changes the interleaver levels of all QAM channels on that QAM port.

### Examples

The following example shows downstream I/J values to 128/5 on QAM interface 3 on Cisco RFGW-10:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream interleaver-depth I128-J17
```

### Related Commands

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream interleaver-level

To set the downstream interleave level, use the **cable downstream interleaver-level** command in QAM subinterface configuration mode. To restore the default setting, use the **no** form of this command.

**cable downstream interleaver-level {1 | 2}**

**no cable downstream interleaver-level**

## Syntax Description

The following level values are supported on Cisco RF Gateway 10:

<b>1</b>	Indicates the downstream interleaver level. Default is 2.
<b>2</b>	

## Command Default

The default interleaver level is 2.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

This command modifies the interleaver level on the downstream radio frequency carrier on a downstream QAM channel. Interleaver level indicates modifiable FEC I/J values. Level 1 indicates non-modifiable FEC I/J values. The I/J values are set to 128/1. For level 2, there are different FEC I/J values that can be configured.

## Examples

The following example shows the interleaver level value set to 2 on QAM subinterface 3:

```
Router# configure terminal
Router(config)#interface qam 3/1.1
Router(config-subif)#cable downstream interleaver-level 1
```

## Related Commands

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream lock

To lock a downstream port on the cable interface, use the **cable downstream lock** command in QAM interface and subinterface configuration mode. To unlock, use the **no** form of this command.

**cable downstream lock**

**no cable downstream lock**

## Syntax Description

This command has no arguments or keywords.

## Command Default

The lock is not set on QAM interfaces.

## Command Modes

QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

This command is used to set the configuration lock on the downstream QAM interfaces on a Cisco RFGW-10 QAM line card. Setting this lock prohibits the user from modifying any RF parameters on that QAM channel. If the lock is set at the port level, then all the QAM Channels on that port will be locked.

Executing this command at a QAM channel level (subinterface) modifies the only the QAM channel. However, executing the command at a QAM port level (interface) modifies all QAM channels (subinterfaces) on that interface.

## Examples

The following example shows how to set the downstream lock on QAM interface 3 on a Cisco RFGW-10:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream lock
```

## Related Commands

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream lqam-group

To create logical QAM groups on the QAM channel on the Cisco RFGW-10 DS-384 line card, use the **cable downstream lqam-group** command in QAM interface and QAM subinterface configuration mode. To remove the logical QAM group configuration, use the **no** form of this command.

**cable downstream lqam-group** *group\_ID*

**no cable downstream lqam-group** *group\_ID*

## Syntax Description

<i>group_ID</i>	Logical QAM group on QAM interface on the line card. Valid range is from 1 to 48.
-----------------	---

## Command Default

This command is not enabled by default.

## Command Modes

QAM interface configuration (config-if)  
QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

## Usage Guidelines

A logical QAM group is a group of QAMs that share the same RF parameters in an RF profile such as Annex, Modulation format, symbol rate etc. There are 48 groups on Cisco RFGW-10 DS-384 line card. The logical QAM ID uniquely identifies the channels on the Cisco RFGW-10 DS-384 line card. Logical QAM IDs 0 to 7 are assigned to QAM group 1, logical QAM IDs 8 to 15 are assigned to QAM group 2 and so on.



### Note

Logical QAM group configuration is supported only on the Cisco RFGW-10 DS-384 line card.

## Associated Features

The **cable downstream lqam-group** command is used to configure the following:

- [Configuring the Cisco RFGW-10 DS-384 Line Card](#)

## Examples

The following example creates the logical QAM group on the Cisco RFGW-10 DS-384 line card:

```
Router(config-if)# interface qam-red 4/1.2
Router(config-if)# cable downstream lqam-group 2
Router(config)#
```



The following example displays the logical QAM groups on QAM interface 4 on the Cisco RFGW-10 DS-384 line card:

```
Router# show running-config
.
.
.
Interface gam4/2.1
  cable downstream carrier-id 1
  cable downstream lqam-group 40
  cable mode depi remote learn
  cable downstream tsid 42001
  cable depi depi-tunnel tunnel-1
Interface gam4/2.2
  cable downstream carrier-id 2
  cable downstream lqam-group 25
  cable mode depi remote learn
  cable downstream tsid 42002
  cable depi depi-tunnel tunnel-1
Interface gam4/2.3
  cable downstream carrier-id 3
  cable downstream lqam-group 40
  cable mode depi remote learn
  cable downstream tsid 42003
  cable depi depi-tunnel tunnel-1
Interface gam4/5.4
  cable downstream carrier-id 13
  cable downstream lqam-group 40
  cable mode depi remote learn
  cable downstream tsid 42004
  cable depi depi-tunnel tunnel-1
.
.
.
```

#### Related Commands

Command	Description
<b>show cable linecard logical-qamid-mapping</b>	Displays the logical QAM group IDs and QAM carriers mapped to the RF profiles on the Cisco RFGW-10 DS-384 line card.
<b>show controllers qam</b>	Displays information about the downstream configuration on a line card.
<b>show cable rf-profiles</b>	Displays the RF profiles on the line card.
<b>show running-config</b>	Displays the logical QAM groups on a interface.

# cable downstream max-carriers

To create specific number of QAM carriers per RF port, use the **cable downstream max-carriers** on the Cisco RFGW-10 DS-384 command in QAM interface configuration mode. To disable the QAM carriers per port, use the **no** form of this command.

**cable downstream max-carriers** *carriers*

**no cable downstream max-carriers** *carriers*

## Syntax Description

<i>carriers</i>	Number of carriers per port. Valid range is from 1 to 64. Default
-----------------	---

## Command Default

No QAM carriers are created when the line card is inserted in the RFGW-10 chassis.

## Command Modes

QAM interface configuration (config-if)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

## Usage Guidelines

When the Cisco RFGW-10 DS-384 line card is inserted, prior to any configuration, all the physical port interfaces are automatically created in the configuration file, but they are in shutdown mode. The **cable downstream max-carriers** command creates the carriers under each QAM port interface.

Each QAM port on the Cisco RFGW-10 DS-384 line card can have up to a maximum of 64 carriers configured.



### Note

If the port is already configured with max-carriers or sub-interfaces, changing the density will affect the power levels and might bring down the carriers due to the licensing restrictions.



### Note

This command is applicable only on the Cisco RFGW-10 DS-384 line card.

For the Cisco RFGW-10 DS-48 line card, 4 carriers per port are created, and applied to all 12 ports on the line card. To disable QAM interfaces on the Cisco RFGW-10 DS-48 line card, use the **cable downstream stacking** command.

## Examples

The following example configures 64 QAM carriers on QAM interface 3/1 on the Cisco RFGW-10 DS-384 line card:

```
Router(config)# interface qam 3/1
Router(config-if)# cable downstream max-carriers 64
```

**Related Commands**

Command	Description
<b>cable downstream rf-shutdown</b>	Enables or disables the RF output from the integrated upconverter.

# cable downstream modulation

To set the modulation format for a downstream port on a cable interface line card, use the **cable downstream modulation** command in RF profile configuration, QAM interface, and subinterface configuration mode.

**cable downstream modulation { 64 | 256 }**

## Syntax Description

<b>64</b>	Modulation rate is 6 bits per downstream symbol.
<b>256</b>	Modulation rate is 8 bits per downstream symbol.

## Command Default

The default modulation rate is 64 QAM.

## Command Modes

RF profile configuration (config-rf-profile)  
QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.
Cisco IOS-XE Release 3.2.0SQ	This command was modified. The modulation rate can be set globally on the Cisco RFGW-10 using the RF profile configuration.

## Usage Guidelines

Modulation is configured at the QAM interface (config-if) or QAM subinterface (config-subif) on the Cisco RFGW-10 DS-48 line card.



### Note

Executing port level commands such as **cable downstream annex**, **cable downstream modulation**, **cable downstream stacking**, **cable downstream frequency**, and **cable downstream rf-power** at the QAM channel level modifies all the QAM channels on that port. This is applicable on the Cisco RFGW-10 DS-48 line card.

Modulation is a part of RF profile configuration mode for Cisco RFGW-10 DS-384 line card. You can apply Annex mode only after you create the RF profiles on Cisco RFGW-10 DS-384 channels.

In Cisco IOS-XE Release 3.2.0SQ, RF profiles can be created globally at the chassis level, and applied to any QAM channel on the Cisco RFGW-10 DS-384 line card. The RF profiles are used for grouping QAM channels with same modulation, annex mode, symbol rate, and interleaver depth.



### Note

A group of eight logical QAM channels can be assigned to an RF profile.

The **cable downstream rf-profile** command creates the RF profile. The modulation, annex mode, symbol-rate, and interleaver depth are configured in the RF profile configuration mode.

**Note**

RF profiles are supported on the Cisco RFGW-10 DS-384 line card.

The following example is a sample of a RF profile configuration:

```
Router(config)# cable downstream rf-profile rf-profile1
Router(config-rf-prof)# cable downstream annex B
Router(config-rf-prof)# cable downstream modulation 64
Router(config-rf-prof)# cable downstream interleaver depth option1 I128-J1 option2 I32-J4
Router(config-rf-prof)# cable downstream symbol-rate 3500000
Router(config-rf-prof)# exit
Router(config)#
```

**Examples**

The following example shows how to set the downstream modulation to 256 QAM on a Cisco RFGW-10 DS-48 line card:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream modulation 256
```

The following example applies the modulation that was specified in the global RF profile 1 Cisco RFGW-10 DS-384 line card:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream rf-profile 1
```

The following example shows how to set the modulation rate in the RF profile on the Cisco RFGW-10 DS-384 line card:

```
Router(config)# cable downstream rf-profile 1
Router(config-rf-prof)# cable downstream modulation 64
Router(config-rf-prof)# exit
```

**Note**

Changing global RF profile attributes, such as modulation can affect all channels that are currently configured on that RF profile.

**Related Commands**

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.
<b>cable downstream rf-profile</b>	Creates RF profiles on the RFGW-10.

# cable downstream rf-profile

To create RF profiles at the Cisco RF Gateway 10 chassis level and apply them across any QAM channel on the Cisco RFGW-10 DS-384 line card, use the **cable downstream rf-profile** command in global configuration mode, and in QAM subinterface configuration mode. To disable the RF profile configuration, use the **no** form of this command.

```

cable downstream rf-profile rf-profile-id

no cable downstream rf-profile rf-profile-id

```

Syntax Description	rf-profile-id	RF profile ID applied to the QAM channel on the line card.
--------------------	---------------	--

Command Default	Default RF profile (default-rf-profile) is created.
-----------------	---

Command Modes	Global configuration (config) QAM subinterface configuration (config-subif)
---------------	--

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

Usage Guidelines	RF profiles can be created globally at the chassis level, and applied to any QAM channel on the Cisco RFGW-10 DS-384 line card. The RF profiles are used for grouping QAM channels with same modulation, annex mode, symbol rate and interleaver depth.
------------------	---

  
Note

A group of eight logical QAM channels can be assigned to an RF profile.

The **cable downstream rf-profile** command creates the RF profile and enters the RF profile configuration mode. The modulation, annex mode, symbol-rate, and interleaver depth can be configured in the RF profile configuration mode. After the RF profile is created, it can be assigned to any QAM channel on the line card.

  
Note

RF profile configuration is supported only on the Cisco RFGW-10 DS-384 line card.

Examples	<p>The following example creates the RF profile 1 on the Cisco RFGW-10, and enters the RF profile configuration:</p> <pre> Router(config)# cable downstream rf-profile 1 Router(config-rf-prof)# ? RF Profile cable downstream commands:   cable  cable keyword under rf profile config mode </pre>
----------	---

`exit` Exit from the rfprof config mode

The following example is a sample of a RF profile configuration:

```
Router(config)# cable downstream rf-profile 1
Router(config-rf-prof)# cable downstream annex B
Router(config-rf-prof)# cable downstream modulation 64
Router(config-rf-prof)# cable downstream interleaver depth option1 I128-J1 option2 I32-J4
Router(config-rf-prof)# cable downstream symbol-rate 3500000
Router(config-rf-prof)# exit
Router(config)#
```

Related Commands	Command	Description
	<b>cable downstream annex</b>	Sets the MPEG framing format for a downstream port on a cable interface line card to Annex A (Europe), Annex B (North America) and Annex C (Japan).
	<b>cable downstream modulation</b>	Sets the modulation format for a downstream port on the line card
	<b>cable downstream interleaver-depth</b>	Sets the interleaver-depth on the line card.
	<b>cable downstream symbol-rate</b>	Sets the symbol rate on the line card.
	<b>show cable linecard logical-qamid-mapping</b>	Displays the logical QAM group IDs and QAM carriers mapped to the RF profiles on the Cisco RFGW-10 DS-384 line card.

# cable downstream rf-power

To set the RF power output level on the Cisco RF Gateway 10, use the **cable downstream rf-power** command in QAM interface and subinterface configuration mode. To reset the RF output power level to its default value, use the **no** form of this command.

```
cable downstream rf-power {power-level}

no cable downstream rf-power {power-level}
```

Syntax Description	<i>power-level</i> Desired RF output power level in dBmV.
--------------------	---

Command Default	The default values set are as follows for the different stacking levels: 1:1 stacking—44 dBmV 2:1 stacking—47 dBmV 4:1 stacking—40 dBmV
-----------------	--

Command Modes	QAM interface and subinterface configuration (config-if and config-subif)
---------------	---

Command History	Release	Modification
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

Usage Guidelines	The stacking level on Cisco RFGW-10 are as follows: 1:1 stacking—30 dBmV ~ 61 dBmV, default is 44 dBmV 2:1 stacking—30 dBmV ~ 57 dBmV, default is 47 dBmV 4:1 stacking—30 dBmV ~ 53 dBmV, default is 40 dBmV The official range for acceptable power levels in the DOCSIS standard depends on the stacking level. The DOCSIS levels are as follows: 1:1 stacking—52 dBmV ~ 60 dBmV 2:1 stacking—48 dBmV ~ 56 dBmV 4:1 stacking—44 dBmV ~ 52 dBmV
------------------	---



Note

Cisco cable interfaces exceed the DOCSIS standard, but power levels outside the DOCSIS standards should be used only in lab and test environments.



**Note**

Executing port level commands such as **cable downstream annex**, **cable downstream modulation**, **cable downstream stacking**, **cable downstream frequency**, and **cable downstream rf-power** at the QAM channel level modifies all the QAM channels on that port.

**Examples**

The following example shows the integrated upconverter on a Cisco RFGW-10 configured for an RF output power level of 50 dBmV:

```
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream rf-power 50
```

**Related Commands**

Command	Description
<b>cable downstream frequency</b>	Configures the downstream center frequency on the integrated upconverter.
<b>cable downstream rf-shutdown</b>	Enables or disables the RF output from the integrated upconverter.
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream rf-shutdown

To disable the RF output from an integrated upconverter on a Cisco RF Gateway 10, use the **cable downstream rf-shutdown** command in QAM interface and subinterface configuration mode. To enable the RF output on the integrated upconverter, use the **no** form of this command.

**cable downstream rf-shutdown**

**no cable downstream rf-shutdown**

## Syntax Description

This command has no arguments or keywords.

## Command Default

The RF output is disabled on the upconverter.

## Command Modes

QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

## Usage Guidelines

Executing this command at the port level command modifies all the QAM channels on that port. However no channel is affected if the command is executed at the channel level.

## Examples

The following example enables the integrated upconverter on the Cisco RFGW-10:

```
Router(config)#configure terminal
Router(config-if)#interface qam 3/1.1
Router(config-subif)#cable downstream rf-shutdown
```

## Related Commands

Command	Description
<b>cable downstream frequency</b>	Configures the downstream center frequency on the integrated upconverter.
<b>cable downstream rf-power</b>	Configures the desired RF output power on the integrated upconverter.
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.

# cable downstream stacking

To configure frequency stacking, use the **cable downstream stacking** command in QAM interface and subinterface configuration mode.

**cable downstream stacking** *stacking*

## Syntax Description

*stacking* Specifies the stacking level in the RF port. Valid levels are 1, 2 and 4.

## Command Default

The stacking level is set to 1:4 on all RF ports.

## Command Modes

QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

You can configure the stacking level on the RF port and enable the appropriate QAM channels:

- QAM channel 1 is enabled on the specified RF port for stacking level 1.
- QAM channels 1 and 2 are enabled on the specified RF port for stacking level 2.
- QAM channels 1, 2, and 4 are enabled on the specified RF port for stacking level 4.



### Note

Executing port level commands such as **cable downstream annex**, **cable downstream modulation**, **cable downstream stacking**, **cable downstream frequency**, and **cable downstream rf-power** at the QAM channel level modifies all the QAM channels on that port.

## Examples

The following example shows how to configure the downstream channel on the QAM interface for frequency stacking of 4.

```
Router# configure terminal
Router(config)# interface qam 3/1
Router(config-if)# cable downstream stacking 4
Router(config-if)# exit
```

## Related Commands

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable downstream start-freq

To set the starting frequency on the QAM interface, use the **cable downstream start-freq** command in QAM interface configuration mode. To disable the starting frequency, use the **no** form of this command.

```

cable downstream start-freq frequency

no cable downstream start-freq

```


Syntax Description	frequency	Starting frequency on the QAM interface on the Cisco RFGW10 DS-384 line card. Valid ranges in MHz per Annex type are: <ul style="list-style-type: none"> <li>Annex A: 1003-744; default is 259</li> <li>Annex B, Annex C: 1002-768; default is 234</li> </ul>
--------------------	-----------	---

Command Default	This command is disabled by default.
-----------------	--------------------------------------

Command Modes	QAM interface configuration (config-if)
---------------	---

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

Usage Guidelines	The <b>cable downstream start-freq</b> command sets the starting frequency for a QAM port on the Cisco RFGW-10 DS-384 card in the static frequency scheme. In this scheme, the lane and block start frequencies are internally configured for the port by the Supervisor. The carrier frequency can be configured at the carrier.
------------------	---

	
Note	The start-frequency configured at the port has to be such that the entire four lanes are within the valid maximum frequency range of 1003 GHz.

	
Note	This command is applicable only on the Cisco RFGW-10 DS-384 line card.

Examples	<p>The following example shows the starting frequency configuration for a QAM port with Annex B:</p> <pre> Router(config)# interface qam 4/1 Router(config-if)# cable downstream start-freq 234000000 Router(config-if)# </pre>
----------	---

**Related Commands**

Command	Description
<b>cable downstream annex</b>	Sets the MPEG framing format for a downstream port on a cable interface line card to Annex A (Europe), Annex B (North America) and Annex C (Japan).
<b>cable downstream frequency (channel)</b>	Sets the center frequency of the QAM channel.
<b>show cable linecard carrier-id-mapping</b>	Displays the QAM blocks and QAM carriers mapped on a line card.

# cable downstream symbol rate

To set the symbol rate on the line card, use the **cable downstream symbol rate** command in RF profile configuration mode. To disable the symbol rate, use the **no** form of this command.

**cable downstream symbol rate** *symbols*

**no cable downstream symbol rate**

<b>Syntax Description</b>	<i>symbols</i>	Symbol rate of the line card in seconds. Valid range is from 3500000 to 7000000 symbols per second.
---------------------------	----------------	---

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	RF profile configuration (config-rf-profile)
----------------------	--

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

<b>Usage Guidelines</b>	The <b>cable downstream symbol-rate</b> command sets the symbol rate for the Cisco RFGW-10 DS-384 line card.
-------------------------	--



## Note

Symbol rate is set only for Annex A mode carriers. The symbol rate specified at the RF profile configuration is ignored for Annex B carriers.

<b>Examples</b>	The following example shows the symbol rate configured on the Cisco RFGW-10 DS-384 line card:
-----------------	---

```
Router(config)# cable downstream rf-profile 1
Router(config-rf-prof)# cable downstream annex A
Router(config-rf-prof)# cable downstream modulation 256
Router(config-rf-prof)# cable downstream interleaver depth option1 I12-J17 option2 I12-J17
Router(config-rf-prof)# cable downstream symbol-rate 3500000
Router(config-rf-prof)# exit
Router(config)#
```

Related Commands	Command	Description
	<b>cable downstream rf-profile</b>	Creates the RF profile configuration at the RFGW-10 chassis level, and enters the RF profile configuration mode

# cable downstream tsid

To configure the Transport Stream Identifier (TSID) value on the QAM subinterface, use the **cable downstream tsid** command in QAM subinterface configuration mode. To reset the TSID to 0, use the **no** form of this command.

**cable downstream tsid** *id* [**onid** *onid-id*]

**no cable downstream tsid**

## Syntax Description

<i>id</i>	TSID value for the QAM subinterface. Valid TSID values are from 0-65535.
<b>onid</b>	(Optional) Sets the original downstream network ID for a video transport stream.
<i>onid-id</i>	Specifies the downstream original network id (ONID). The valid range is from 1 to 65535. The default value is 0.

## Command Default

The TSID and ONID values are set to 0 on all QAM interfaces.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command was modified to include <b>onid</b> keyword.

## Usage Guidelines

This command ensures that each downstream QAM channel has a unique ID when there are multiple Cisco Cable Modem Termination System (CMTS) routers at a headend facility. This ID uniquely defines the QAM channel in the cable headend.

For DEPI, the TSID value is overwritten with a new value if there are no sessions established on that QAM channel. However, if a session exists with the specified QAM channel, the new TSID value being configured is rejected.

For video, the TSID value is required only for powerkey encrypted video sessions. The TSID value is overwritten with the new value even when a session exists and the system recovers sessions with the new TSID value.

The **no** form of the command resets the TSID value of the QAM channel to 0.



### Note

The ONID configuration is not supported on the Cisco RFGW-10 DS-48 line card.

Examples

The following example configures the downstream channel on the QAM subinterface with a TSID value of 44:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable downstream tsid 44
```

The following example shows how to configure the ONID on the QAM interface on the Cisco RFGW-10 DS-384 line card:

```
Router(config)# configure terminal
Router(config)# interface qam 7/1.1
Router(config)# cable mode video local
Router(config)# cable downstream tsid 1000 onid 65000
Router(config)# cable downstream rf-profile rfprofile_video
Router(config)# cable downstream frequency 325000000
Router(config)# no cable downstream rf-shutdown
Router(config)# cable downstream interleaver-depth I128-J1
Router(config)# exit
```

The following example shows the RF profile configuration on the Cisco RFGW-10 DS-384 line card:

```
Router(config)# show running config
cable downstream rf-profile rfprofile_video
cable downstream annex B
cable downstream modulation 256
cable downstream interleaver-depth option1 I128-J1 option2 I128-J1
cable downstream symbol-rate 5360537
!
```

Related Commands

Command	Description
show controllers qam	Displays cable downstream information configured on the QAM channel and port.
show running-config interface qam	Displays the running configuration of the QAM interface.



# cable downstream tsid-base

To configure the Transport Stream Identifier (TSID) value for all QAM interfaces, use the **cable downstream tsid-base** command in privileged EXEC mode.

**cable downstream tsid-base** *id*

## Syntax Description

<i>id</i>	Specifies the TSID value for the QAM interface. Valid range is from 0 to 65535.
-----------	---

## Command Default

The TSID value is set to 0 on all QAM interfaces.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

This command ensures that each downstream QAM channel has a unique ID when there are multiple Cisco CMTS routers at a headend facility. This ID uniquely defines the QAM channel in the cable headend.

A QAM channel is assigned a TSID value if it is unique. The TSID value is overwritten with a new value if there are no sessions established on that QAM channel. However, if a session exists with the specified QAM channel, the new configured TSID value is rejected.

## Examples

The following example sets the TSID value of 44 on the QAM interfaces:

```
Router#cable downstream tsid-base 44
```

## Related Commands

Command	Description
<b>show controllers qam</b>	Displays cable downstream information configured on the QAM channel and port.
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# cable image-upgrade download

To upgrade all device images on a specific line card, use the **cable image-upgrade download** command in privileged EXEC mode.

**cable image-upgrade download** *slot* [**forced** | **background**]

## Syntax Description

<i>slot</i>	Specifies the slot number of the line card. Valid slot numbers are 3 to 14.
<b>forced</b>	(Optional) Forces an upgrade of all the images on the line card.
<b>background</b>	(Optional) Upgrade to line card occurs in the background and control is immediately returned to the command prompt.

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

The line card must be present in the slot for an upgrade. The line card image is upgraded with the image of the Supervisor card.

The upgrade occurs in the background if the **background** keyword is specified. The control is immediately returned to the CLI prompt.

The line card resets if an image upgrade has occurred. If the latest images are present on the line card, then the line card does not reset.

## Examples

The following example upgrades the image on line card in slot 7:

```
Router# cable image-upgrade download 7
```

The following example forces the upgrade of all images in line card in slot 3:

```
Router# cable image-upgrade download 3 forced
```

## Related Commands

Command	Description
<b>show cable-image upgrade bundle</b>	Displays the upgrade bundle on the supervisor.
<b>show cable-image upgrade status</b>	Displays the upgrade status of an image on the specified line card.
<b>show cable-image upgrade version</b>	Displays all the upgraded image versions on the line card.

# cable image-upgrade disable

To disable the automatic image upgrade of the line card, use the **cable image-upgrade disable** command in global configuration mode. To enable the automatic image upgrade, use the **no** form of this command.

**cable image-upgrade disable**

**no cable image-upgrade disable**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The **no** form of the command is enabled by default.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	15.0(2)SQA	This command was introduced.

**Usage Guidelines** Use the **cable image-upgrade disable** command to disable automatic image upgrade.

**Examples** The following example disables auto image upgrade of the line card:

```
Router(config)# cable image-upgrade disable
Router(config)#
```

**Associated Features** The **cable image-upgrade disable** command is used to configure the following features:

- [Bundled Image Upgrade](#)

Related Commands	Command	Description
	<b>show cable-image upgrade bundle</b>	Displays the upgraded images of all the devices on the Supervisor card.
	<b>show cable-image upgrade version</b>	Displays all the upgraded image versions on the line card.

# cable linecard encryption

To configure the line card encryption scrambling algorithm, use the **cable linecard encryption** command in global configuration mode. To disable line card encryption, use the **no** form of this command.

```
cable linecard slot encryption {pkey scrambler des | clear scrambler none}
```

```
no cable linecard slot encryption pkey scrambler des
```

Syntax Description	<i>slot</i>	Line card slot. The valid range is from 3 to 12.
	<b>pkey</b>	Specifies the encryption type is PowerKEY.
	<b>scrambler</b>	Specifies the encryption scrambling algorithms.
	<b>des</b>	Indicates the scrambling algorithm is Data Encryption Standard (DES).
	<b>clear</b>	Clears the encryption type.
	<b>none</b>	Indicates no scrambling algorithm.

**Command Default** This command is enabled by default.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

**Usage Guidelines** The Cisco RFGW-10 DS-384 DS-384 line card encryption capability is enforced by the software license. At line card insertion, no encryption feature license are available. The Cisco Software Licensing (CSL) and platform CSL layer validate the license present in the line card flash partitions. The line card is licensed for PowerKEY encryption scheme. For more information on Licensing, see [Software License Activation for Cisco RF Gateway 10 Line Cards](#).

The Cisco RFGW-10 DS-384 line card supports two different scrambling algorithms, DES and DVB-CSA. PowerKEY supports the DES algorithm. By default, DES is used for a PowerKEY enabled line card.

To disable linecard encrytion use **no cable linecard slot encryption pkey scrambler des** or **cable linecard slot encryption clear scrambler none**

**Examples** The following example shows how to configure PowerKEY encryption on the line card:

```
Router# configure terminal
Router(config)# cable linecard 6 encryption pkey scrambler des
```

**Related Commands**

Command	Description
<b>show cable licenses</b>	Displays the licenses configured on the Cisco RFGW-10 line card.

# cable linecard license max-carriers

To activate the QAM carrier density on the line card, use the **cable linecard license max carriers** command in global configuration mode. To deactivate the QAM carrier density on the line card, use the **no** form of this command.

```
cable linecard lc-slot license max-carriers carrier_density
```

```
no cable linecard lc-slot license max-carriers
```

Syntax Description	<i>lc_slot</i>	Slot of the line card in the QAM interface. Line card redundancy configured interfaces appear as QAM-red. Valid range is from 3 to 12.
	<i>carrier_density</i>	Maximum carrier density per line card. The carrier densities for the Cisco RFGW-10 DS-384 line card are 48, 96, 192, and 384. The default carrier density is 96.

Command Default	Enabled during line card bootup, provided that a valid QAM carrier license exists on the Cisco RFGW-10 DS-384 line card.
-----------------	--

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	15.0(2)SQ	This command was introduced.

**Usage Guidelines**

The **cable linecard license max-carriers** command sets the QAM carrier density of the line card. Valid configurable licenses are required for the maximum carriers densities per line card. The density specifications are validated by the license on the Supervisor when the max-carriers ports are created.

This command defines the maximum carrier density for a downstream QAM line card. The maximum carriers supported on the Cisco RFGW10-DS-48 line card are 48, and the maximum carriers supported on the Cisco RFGW-10 DS-384 line card are 384.



Note

This command is applicable on the Cisco RFGW-10 DS-384 line card. This command is auto-generated, and cannot be modified for the Cisco RFGW-10 DS-48 line card.

**Examples**

The following example sets the QAM carrier density for the line card in slot 3.

```
Router(config)# cable linecard 3 license max-carriers 96
```

**Related Commands**

Command	Description
<b>cable downstream max-carriers</b>	Creates QAM carriers per RF port on the Cisco RFGW-10.

# cable linecard reset

To partially reset the line card, use the **cable linecard reset** command in privileged EXEC configuration mode.

**cable linecard** *slot* **reset**

<b>Syntax Description</b>	<i>slot</i> Specifies the line card slot. Valid slot numbers are 3 to 12.				
<b>Command Default</b>	This command has no default behavior or values.				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>12.2(44)SQ</td><td>This command was introduced on the Cisco RF Gateway 10.</td></tr> </table>	Release	Modification	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Release	Modification				
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.				
<b>Usage Guidelines</b>	This command partially resets the line card and the CPU. The front panel SFP (small form-factor pluggable) module continues to process the data.				
<b>Examples</b>	<p>The following example shows a partial reset of the line card in slot 3:</p> <pre>Router#<b>cable linecard 3 reset</b></pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>hw-module slot reset</b></td><td>Resets the line card on the chassis.</td></tr> </table>	Command	Description	<b>hw-module slot reset</b>	Resets the line card on the chassis.
Command	Description				
<b>hw-module slot reset</b>	Resets the line card on the chassis.				



# cable midplane ping

To enable the midplane failure detection between the line card and the Supervisor on the Cisco RFGW-10, use the **cable midplane ping** command in global configuration mode. To disable the midplane failure detection, use the **no** form of this command.

```
cable midplane ping interval ping-interval retries retry_num wait wait-interval action {log | none}
```

```
no cable midplane ping interval ping-interval retries retry_num wait wait-interval action {log | none}
```

## Syntax Description

<b>interval</b>	Specifies the frequency of pings sent by the line card.
<i>ping-interval</i>	Length of ping interval, in milliseconds. The valid range is from 10000 to 600000.
<b>retries</b>	Specifies the number of times the line card retries before sending the error message.
<i>retry_num</i>	Number of midplane ping retries. The range is from 10 to 100.
<b>wait</b>	Specifies the time the line card should wait to restart sending the pings after a ping failure has occurred.
<i>wait-interval</i>	Waiting time period, in milliseconds. The range is from 10000 to 600000.
<b>action</b>	Specifies the action taken when ping failure occurs.
<i>log</i>	Messages are written to a system log on ping failure.
<i>none</i>	Action is not taken; pings are disabled.

## Command Default

The midplane failure detection is not configured.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
12.2(50)SQ4	This command was introduced.

## Usage Guidelines

Use the **cable midplane ping** command to enable midplane pings between the line card and the Supervisor. When this command is enabled, the line card periodically sends ping packets to the Supervisor, and receives responses. However, if no responses are received by the line card, an error message is sent to the Supervisor, and the pings are disabled.

The minimum ping interval is 10000 milliseconds with 10 retries. If a ping fails after the number of retries, the line card waits before restarting the pings. This delay interval is configured as the wait parameter.

---

**Examples**

The following example shows how to configure the midplane ping interval for 10000 milliseconds with 10 retry attempts, followed by a wait interval of 10000 milliseconds, and an action to log a message on failure:

```
Router(config)# cable midplane ping interval 10000 retries 10 wait 10000 action log
```

---

**Related Commands**

Command	Description
<b>clear cable midplane ping statistics</b>	Clears the midplane ping statistics on the Cisco RFGW-10.
<b>show cable midplane ping statistics</b>	Displays the midplane ping statistics between the line card and the Supervisor on the Cisco RFGW-10.

# cable mode

To set the mode of the QAM channel, use the **cable mode** command in QAM interface and subinterface configuration mode. To remove this setting, use the **no** form of this command.

**cable mode depi {local lbg lbg-interface | remote [learn]} | video {local | remote encrypt}**

**no cable mode {depi | video} {local | remote}**

Syntax	Description
<b>depi</b>	Specifies the DEPI mode of the QAM channel.
<b>video</b>	Specifies the video mode of the QAM channel.
<b>local</b>	Specifies that the QAM channel is manually configured.
<b>lbg</b>	Specifies the load balancing group. The QAM block or the Ten Gigabit Ethernet is assigned to the QAM-based local DEPI session.  <b>Note</b> 192 carriers are supported on a load balancing group.
<i>lbg-interface</i>	Load balancing group interface. Valid values are 1 and 2.
<b>remote</b>	Specifies that the QAM channel is remotely configured.
<b>learn</b>	(Optional) Specifies that the QAM channel is in learn mode and the RFGW-10 can learn the channel configuration from the M-CMTS. All QAM channels on a single port must be in <b>learn</b> mode for this configuration to work.
<b>encrypt</b>	Sets the mode for encryption based remote video sessions.  Maximum number of video sessions per line card is 3840.  Maximum number of video sessions per chassis is 38400.  Maximum number of encrypted video sessions per line card is 1920.  Number of video QAM carriers per line card is 256 for Annex-B, 192 for Annex-A or mixed.

**Command Default** No cable mode is set on the QAM channel.

**Command Modes** QAM interface and subinterface configuration (config-if and config-subif)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	12.2(50)SQ	This command was modified to add <b>remote</b> and <b>learn</b> keywords.

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was modified to include the <b>lbg</b> keyword for local DEPI sessions, and <b>24-qam-map</b> for local video sessions.  The <b>cable mode depi remote learn</b> command is configurable at the QAM interface level.
Cisco IOS-XE Release 3.3.0SQ	This command was modified to include the <b>encrypt</b> keyword for encryption based remote video sessions and remove <b>24-qam-map</b> keyword for the Cisco DS-384 line card.

### Usage Guidelines

QAM channels on the Cisco RFGW-10 are characterized based on their usage mode and ownership. QAM channels within a QAM port are configured in DEPI and video mode.



#### Note

QAM channels cannot be configured within a QAM port in DEPI or Video mode on the Cisco RF Gateway-10 DS48 line card.



#### Note

Ensure that you configure the same mode on all channels of a port.

Each QAM channel is configured locally via CLI or remotely through a signaling protocol, such as Modular Cable Modem Termination System (M-CMTS) Downstream External PHY Interface (DEPI), Data Network Control Station (DNCS), Generic QAM Interface (GQI), or Edge Resource Manager Interface (ERMI). The DNCS, GQI and ERMI protocols are used for video only. If a QAM channel is used for remote setup, it cannot be configured locally.



#### Note

If other QAM channels on a single port are set to a different mode, the configuration of a QAM channel may fail.



#### Tip

Before changing the existing cable mode of a channel on a port, the **no cable mode** command should be executed.

In Cisco IOS Release Cisco IOS-XE Release 3.2.0SQ, load balancing groups are assigned to QAM channels while configuring local DEPI sessions. Two load balancing groups exist per line card. The QAM channels are equally divided between the two load balancing groups on any line card. Each load balancing group supports 192 carriers or 9.1Gbps.

Effective with Cisco IOS-XE Release 3.3.0SQ, the **24-qam-map** keyword is not supported on the Cisco DS-384 line card.

### Examples

The following example shows the configuration of QAM subinterface 7/1.1 using DEPI mode locally on a Cisco RFGW-10. Load balancing interface 1 is assigned to the QAM channel:

```
Router(config)# interface qam-red7/1.1
Router(config-subif)# cable mode depi local lbg 1
```

The following is an example at the QAM interface 3/1 level with DEPI in **remote learn** mode on a Cisco RFGW-10:

```
Router(config)# interface qam 3/1
Router(config-if)# cable mode depi remote learn
```

The following is an example at the QAM subinterface 6/4.1 level with DEPI in **learn** mode on a Cisco RFGW-10:

```
Router(config)# interface qam 6/4.1
Router(config-subif)# cable mode depi remote learn
```

The following is a sample output to show the total number of video sessions:

```
Router# show cable video session slot 3
Session      QAM      Stream Sess IP      UDP   Out   Input   Input   Output PSI
Ctrl
ID           Port     Type   Type Address    Port  Pgm   Bitrate  State  State  Rdy
State
-----
-----
201459584    3/1.2    Remap  SSM  -            -     1     2500412  ACTIVE OFF  NO  -
201459585    3/1.2    Remap  SSM  -            -     2     2500415  ACTIVE OFF  NO  -
201459586    3/1.2    Remap  SSM  -            -     3     2500420  ACTIVE OFF  NO  -
201459587    3/1.2    Remap  SSM  -            -     4     2500427  ACTIVE OFF  NO  -
201459588    3/1.2    Remap  SSM  -            -     5     2500427  ACTIVE OFF  NO  -
201459589    3/1.2    Remap  SSM  -            -     6     2500427  ACTIVE OFF  NO  -
201459590    3/1.2    Remap  SSM  -            -     7     2500427  ACTIVE OFF  NO  -
201459591    3/1.2    Remap  SSM  -            -     8     2500433  ACTIVE OFF  NO  -
201459592    3/1.2    Remap  SSM  -            -     9     2500436  ACTIVE OFF  NO  -
```

```
RFGW-10#show cable video session slot 3 | inc Total
Total Sessions = 1920
```

The following example shows the output expected while trying to create the 193rd encrypted video session:

```
interface Qam-red3/4.48
cable carrier-id 192
cable mode video remote encrypt
cable downstream lqam-group 27
cable downstream rf-profile default-rf-profile
cable downstream frequency 597000000
no cable downstream rf-shutdown
cable partition 2 external-channel 192

Router(config-subif)# cable mode video remote encrypt
Error: Max encrypted carriers on linecard 3 reached, limit is 192
%ERROR: Failed to enable encryption for Qam3/5.1 - max encrypted carriers reached, only
192 allowed
```

#### Related Commands

Command	Description
<b>show depi tunnel</b>	Displays all active control connections.
<b>show depi session</b>	Displays established DEPI data sessions.
<b>show cable linecard load-balancing-group</b>	Displays the load balancing groups on the Cisco RFGW-10.
<b>show controllers qam</b>	Displays information about downstream configuration on a line card.
<b>show running-config interface qam</b>	Displays the downstream configuration of a QAM channel.

# cable partition

To manage and assign QAM channels to a QAM partition, use the **cable partition** command in QAM subinterface configuration mode. To disable, use the **no** form of this command.

**cable partition** *partition-id* {**external-channel** *channel\_number*}

**no cable partition** *partition-id* {**external-channel** *channel\_number*}

## Syntax Description

<i>partition-id</i>	QAM partition ID. The valid range is from 1 to 50.
<b>external-channel</b>	Specifies the output port number used in ERM to represent a QAM channel.
<i>channel_number</i>	External output port number for GQI protocol QAM partition. The valid range is from 1-2147483647.

## Command Default

This command is not enabled by default.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

Use the **cable partition** command to assign QAM channels to QAM partitions. Ensure that the QAM channel is configured for **cable mode video remote encrypt** and the QAM partition is created before assigning the QAM partition to the QAM channel.



### Note

External channel is applicable to GQI protocol configured QAM partitions.

## Examples

The following example shows how to assign the QAM partition 3 to the QAM channel:

```
Router# configure terminal
Router(config)# interface qam-red 3/1.1
Router(config)# cable mode video remote encrypt
Router(config-subif)# cable partition 3 external-channel 200
Router(config-subif)#
```

## Related Commands

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.

# cable qam-domain

To configure a QAM domain, use the **cable qam-domain** command in global configuration mode.

**cable qam-domain** *qam-domain*

Syntax Description	<i>qam-domain</i> Indicates the QAM domain. Valid range is from 1 to 20.
--------------------	--

Command Default	This command has no default behavior or values.
-----------------	---

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	A QAM domain is a logical grouping of QAM blocks sharing the same IP addresses for their unicast sessions. Only 20 QAM domains can exist on the Cisco RFGW-10. The QAM domains are numbered from 1 to 20. A QAM domain can contain any number of QAM blocks.
------------------	--

**Note**

A QAM block can be present only in one QAM domain.

A QAM domain is configured with a local and a remote IP address. All local unicast sessions in the QAM domain use the local IP address as their destination IP address. All remote unicast sessions use the remote IP address as their destination IP address. The local and the remote IP address can be the same or different. However, in a QAM domain which uses the same IP address, a QAM block cannot be designated as local and remote.

The following conditions must be followed while creating QAM domains:

- A QAM block can belong to only one QAM domain.
- Multiple QAM blocks can belong to a single QAM domain.
- An IP address cannot be configured in more than one QAM domain.
- Removing a QAM domain results in removal of its IP addresses, video routes and sessions.

The **cable qam-domain** command creates groups of QAM channels. In the Cisco RFGW-10, you can configure 20 QAM domains and assign QAM blocks to each domain.

Examples	The following example creates QAM domain 3:
----------	---

```
Router#configure terminal
Router(config)#cable qam-domain 3
```

Related Commands	Command	Description
	<b>ip</b>	Specifies the destination IP address for video or remote sessions on the QAM domain.
	<b>video route</b>	Specifies the route for a local or video session.



# cable qam-group

To configure cable QAM group, use the **cable qam-group** command in qam-interface configuration mode. To remove the cable QAM group from a qam-interface, use the **no** form of this command in that qam-interface.

**cable qam-group** *qam-group-name*

**no cable qam-group** *qam-group-name*

## Syntax Description

<i>qam-group-name</i>	Cable QAM group name.
-----------------------	-----------------------

## Command Default

This command is enabled by default.

## Command Modes

QAM interface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

To configure a cable QAM group, the QAM subinterface must be set to **cable video remote mode**. You can not change or remove a qam-group from the qam-interface when it is advertised to Edge Resource Manager (ERM).

## Examples

The following example shows how to create a cable QAM group:

```
Router# configure terminal
Router(config)# interface qam 3/1.2
Router(config-subif)# cable mode video remote
Router(config-subif)# cable qam-group qg1
```

## Related Commands

Command	Description
<b>cable service-group</b>	Configures the QAM service group.
<b>show cable service-group</b>	Displays the service groups configured on the Cisco RFGW-10.

# cable qam-partition

To create a user-defined QAM partition for a video server, use the **cable qam-partition** command in global configuration mode. To remove the QAM partition, use the **no** form of this command.

**cable qam-partition** *partition-id*

**no cable qam-partition** *partition-id*

<b>Syntax Description</b>	<i>partition-id</i> QAM partition ID. The valid range is from 1 to 50.				
<b>Command Default</b>	This command is enabled by default.				
<b>Command Modes</b>	Global configuration (config)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Cisco IOS-XE Release 3.3.0SQ</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.
Release	Modification				
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.				

<b>Usage Guidelines</b>	<p>QAM partitioning is introduced in on the Cisco RFGW-10 to support the sharing of a Cisco RFGW-10 DS-384 line card or Cisco RFGW-10 chassis among different remote servers such as Digital Network Control System (DNCS), Universal Session Resource Manager (USRM), and Edge Resource Manager (ERM). The line card is partitioned and used by the multiple remote servers. QAM partitioning is used by protocol application such as GQI and ERMI to extend the QAM partition configuration for a given protocol.</p> <p>QAM partitioning configuration provides the ability to divide QAM carriers into logical groups where each partition manages the QAM carriers without interfering with QAM carriers in different groups.</p> <p>Fifty user-defined QAM partitions can be created with <i>partition-id</i> 1 to 50. These are used in remote video sessions.</p> <p>A default QAM partition is a hidden partition (not user-defined) that collects the QAM carriers that are not assigned to any QAM partition. By default, all QAM carriers are in the default QAM partition. Once a QAM carrier is assigned to a partition, the carrier is removed from the default partition. Default partition IDs are used in local video sessions.</p>
-------------------------	---

**Examples**      The following example shows how to create a QAM partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)#
```

**Related Commands**

Command	Description
<b>active</b>	Activates the QAM partition configuration.
<b>mgmt-ip</b>	Configures the management IP address of the QAM partition.
<b>protocol</b>	Configures the control plane protocol of QAM partition.
<b>server</b>	Configures the IP address of the external server.
<b>cable partition</b>	Associates the QAM partition to the QAM interface.

# cable qam-replication-group

To configure qam replication group, use the **cable qam-replication-group** command in global configuration mode. To remove the qam replication group, use the **no** form of this command.

```
cable qam-replication-group {group-id | new}

no cable qam-replication-group {group-id}
```

Syntax Description	<i>groupd-id</i>	QAM replication group ID. The valid range is from 1 to 3840.
	<b>new</b>	Creates a new group and assigns a group number automatically.

**Command Default** This command is enabled by default.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

**Usage Guidelines**

Cisco IOS-XE Release 3.3.0SQ introduces the QAM replication group feature to replicate any single QAM output from one port to another port on the same Cisco RFGW-10 DS-384 line card.

A QAM Replication Group (QRG) contains information about a single source QAM and its corresponding replicated copy or copies. A QRG contains only one pilot and a minimum of one and maximum of seven replicate QAMs. Each group is numbered with an identifier and contains the *slot*, *port* and *channel number* for both the source QAM (pilot-qam) and the destination QAM or QAMs (replicate-qam).

The **cable qam-replication-group** *group-id* command does one of the following:

- When there is no **group** already configured with a matching *group-id*, it creates one and opens it for editing.
- When there is an existing **group** with a matching *group-id*, it opens it for editing.



**Note** QAM replication is supported only within a given line card and not from one line card to another.

**Examples**

The following example shows how to create a user-defined QAM replication group:

```
Router# configure terminal
Router(config)# cable qam-replication-group 1
Router(config)#
```

Related Commands	Command	Description
	<b>pilot-qam</b>	Configures the pilot QAM in the QAM replication group.
	<b>replicate-qam</b>	Configures the replicate QAM in the QAM replication group.

# cable route linecard load-balance-group

To configure a video route on the cable load balancing group and to enter into load balancing group configuration, use the **cable route linecard load-balance-group** command in global configuration mode. To disable a video route, use the **no** form of this command.

**cable route linecard** *lc-slot* **load-balance-group** *group-id*

**no cable route linecard** *lc-slot* **load-balance-group** *group-id*

Syntax Description	<i>lc-slot</i>	Specifies the line card slot. The valid slot numbers are 3 to 12.
	<i>group-id</i>	Specifies the load balancing group number. The valid group IDs are 1 and 2.

**Command Default** This command is enabled on default.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

**Usage Guidelines** A load balance group is used to identify a group of QAM traffic that uses the mid-plane 10 Gigabit Ethernet ports to forward traffic to the QAM carriers. Only 9.1Gbps traffic is allowed on the Cisco DS-384 line card.

On the Cisco RFGW-10, the Cisco RFGW-10 DS-384 line card has internal mid-plane interfaces to forward data traffic between the Supervisor and line card. Two load balancing group represents this mid-plane— first mid-plane is LBG1, and second mid-plane is LBG2.

**Examples** The following example shows how to configure a load balancing group:

```
Router# configure terminal
Router(config)# cable route linecard 3 load-balance-group 1
Router(config-lbg)#?
Cable Load balance Group Configuration Commands:
  exit          Exit from route configuration for load balance
  no            Unconfigure Load Balance Group parameters
  qam-partition QAM Partition
```

Related Commands	Command	Description
	<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
	<b>show cable linecard load-balancing-group</b>	Displays the load balancing groups configured on the QAM partitions.

# cable service-group

To create a cable service group and enter QAM service group configuration mode, use the **cable service-group** command in global configuration mode. To remove the service group, use the **no** form of this command.

**cable service-group** *group-name*

**no cable service-group** *group-name*

## Syntax Description

<i>group-name</i>	Service group name.
-------------------	---------------------

## Command Default

This command is enabled by default.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

A cable service group contains one or multiple QAM groups. A QAM group contains one or more channels.

## Examples

The following example shows how to create a user-defined cable service group:

```
Router# configure terminal
Router(config)# cable service-group 1
Router(config-qsg)#
```

## Related Commands

Command	Description
<b>cable qam-group</b>	Configures the Cable QAM group.
<b>qam-group</b>	Configures the QAM group in a cable service group.
<b>show cable service-group</b>	Displays the service group information.



# cable video encryption-failover-mode

To enable video encryption failover, use the **cable video encryption-failover-mode** command in QAM subinterface configuration mode. To disable video encryption failover, use the **no** form of this command.

**cable video encryption-failover-mode { blackout | clear }**

**no cable video encryption-failover-mode { blackout | clear }**

## Syntax Description

<b>blackout</b>	Indicates a fail to black. The encryption scheduler fails to retrieve and send a valid message for the session. The encrypted session is not played.
<b>clear</b>	Indicates a fail to clear. When failure occurs, the encrypted session is played without being scrambled.

## Command Default

This command is enabled by default. The default failover mode is blackout.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

Each encrypted session can be configured as either **blackout** or **clear** encryption failover.

## Examples

The following example shows how to configure blackout encryption failover:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable video encryption-failover-mode blackout
Router(config-subif)#
```

## Related Commands

Command	Description
<b>cable linecard encryption</b>	Configures the line card encryption scrambling algorithm.

# cable video group

To create a group of unicast video sessions, use the **cable video group** command in global and QAM interface and subinterface configuration mode. To remove the group, use the **no** form of this command.

```
cable video group sessions ip IP-address udp port {increment increment program prog-num |  
  program prog-num} [bitrate bps | increment increment | jitter ms] [repeat | qam(-red) slot  
  /port.channel]
```

```
no cable video group sessions ip IP-address udp port {increment increment program prog-num |  
  program prog-num} [bitrate bps | increment increment | jitter ms] [repeat | qam (-red) slot  
  /port.channel]
```

## Syntax Description

<i>sessions</i>	Specifies the number of sessions in a group. Valid group range is 2 to 30.
<b>ip</b>	Specifies the destination IP address.
<i>IP-address</i>	IP address of the destination.
<b>udp</b>	Specifies UDP as the protocol.
<i>port</i>	Specifies the UDP port used. Valid UDP port range is 1 to 65535.
<b>increment</b>	Adds the increment value to the group UDP sessions.
<i>increment</i>	Specifies the increment value of the UDP port. Valid range is 1 to 10000.
<b>program</b>	Sets the first program.
<i>prog-num</i>	Specifies the program number. Valid range is 1 to 65535.
<b>bitrate</b>	Sets bitrate for group sessions.
<i>bps</i>	Specifies the bitrate value. Valid range is 1 to 52000000 bps.
<b>jitter</b>	(Optional) Sets the jitter for group sessions.
<i>ms</i>	(Optional) Specifies the jitter value. Valid range is between 10 to 200 ms.
<b>repeat</b>	(Optional) Creates cloned video sessions over a range of QAM channels.
<b>qam (-red)</b>	(Optional) Identifies the QAM interface.
<i>slot</i>	(Optional) Specifies the slot on the QAM interface. Valid range is 3 to 12.
<i>port</i>	(Optional) Specifies the port on the slot. Valid port range is 1 to 12.
<i>channel</i>	(Optional) Specifies the channel on the port. Valid range is 1 to 4.

## Command Default

This command has no default behavior or values.

## Command Modes

Global configuration (config)

QAM interface and subinterface configuration (config-if and config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command was integrated in Cisco IOS-XE Release 3.3.0SQ. The keyword <b>ip</b> was added.

**Usage Guidelines**

This command allows you to configure a group of video unicast sessions within a QAM channel and over a range of QAM channels.

**Note**

The QAM subinterface must be set to cable video local mode.

The optional **repeat** keyword is used to indicate whether the program numbers are to be repeated for all QAM channels.

**Note**

If **increment** keyword is not specified, an increment of 1 is added to the group.

**Examples**

The following example shows a configuration of a video group for three video sessions with an increment of one:

```
Router# configure terminal
Router(config)# interface qam 3/1.2
Router(config-subif)# cable mode video local
Router(config-subif)# cable video group 3 ip 10.1.1.1 udp 3 program 2 increment 1 jitter 12
```

The following example configures ten cloned video sessions for all QAM channels on slot 3:

```
Router#configure terminal
Router(config)#cable video group 10 ip 10.2.2.1 udp 3 increment 2 program 3 repeat bitrate 10000 Qam-red 3/1.1 - Qam-red 3/4.1
```

**Related Commands**

Command	Description
<b>show cable video session</b>	Displays the video session on the RF Gateway 10.

# cable video ip multicast

To configure the multicast video sessions on a load balancing group, use the **cable video ip multicast** command in QAM subinterface configuration mode. To disable the multicast sessions, use the **no** form of this command.

**cable video ip** *dest-IP-address* **multicast** *label* {**data** | **passthru** | **program** *prog-num*}

**no cable video ip** *dest-IP-address* **multicast** *label* {**data** | **passthru** | **program** *prog-num*}

## Syntax Description

<i>dest-IP-address</i>	Destination IP address of the video route or GQI ingress port IP address.
<i>label</i>	Specifies the multicast session label definition created for ASM or SSM.
<b>data</b>	Adds a data-piping session to the QAM interface.
<b>passthru</b>	Adds a pass-through session to the QAM interface.
<b>program</b>	Adds a remap session to the QAM interface.
<i>prog-num</i>	Specifies the program number.

## Command Default

Load balancing group is configured.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

Video servers use multiple network paths to reach the Cisco RFGW-10. Traffic enters through one of the multiple ingress ports to the Cisco RFGW-10.

Multiple ports also exist on the Cisco RFGW-10 between the ingress port to the output QAM channel. Each line card receives traffic from the internal ports. Using QAM partitioning, a mapping is specified using QAM partitions input route and the internal port. For example, a QAM partition with 10Gbps of maximum throughput may use one mid-plane 10 Gigabit Ethernet port exclusively or divide the throughput using 5 Gbps to two 10 Gigabit Ethernet port.

When a QAM model has more than one input port, the server determines which input port to use for a video session. For ERMI QAM model, the input IP address is used to signal which input port should be used for a video session. For GQI model, the input port ID is used. This input port determines the route of the QAM partition. For multicast traffic, the internal port and the ingress port are used to join the multicast traffic.

Video routes are organized according to the mid-plane ports. The load balancing group ID indicates which midplane port is used for the sessions.

The input route is configured using the **cable route linecard load-balance-group** command at the global configuration level. For multicast sessions, the input route consists of destination IP address, maximum reserved bandwidth on the mid-plane and source and group IP address of the label using the **cable video label** command.

**Note**

The same load balancing group on the line card can configure video routes for both local and remote sessions, as long as the total bandwidth reserved for each route does not exceed 9.1 Gbps for Cisco RFGW-10 DS-384 line card.

**Note**

The QAM subinterface must be set to **cable mode video local** mode for local video sessions and **cable mode video remote** mode for remote video sessions.

A video session contains input attributes, processing type, and output attributes.

The input attributes include:

- Input type (ASM or SSM)
- Input port information (destination port)
- Allocated bitrate
- Jitter buffer size

The output processing types are as described as follows:

- Data-piping: All the input Program Identifiers (PID)s are preserved to the output. No Program Specific Information (PSI) processing and dejittering is performed.
- Pass-through: All input program numbers and PIDs are preserved to the output. In general, only one pass-through session is present on the QAM channel.
- Remapped: The output program number and PIDs are different from the input. The output program number is configured and output PIDs are selected on the program number.

The output attributes include the output QAM channel and output program number for remapped sessions.

**Examples**

The following example shows how to configure local multicast video sessions:

```
Router# configure terminal
Router(config)# cable route linecard 3 load-balance-group 1
Router(config-lbg)# qam-partition default ip 192.168.10.10 udp 49201 49250 bitrate 250000
Router(config)# interface Qam3/3.48
Router(config-subif)# cable mode video local
Router(config-subif)# cable video ip 192.168.10.10 multicast ssm0 program 100
Router(config-subif)#
```

The following example shows how to configure remote multicast video sessions:

```
Router# configure terminal
Router(config)# cable route linecard 3 load-balance-group 2
Router(config-lbg)# qam-partition 3 ip 192.168.10.10 udp 49201 49250 bitrate 250000
Router(config)# interface Qam3/3.40
Router(config-subif)# cable mode video remote
Router(config-subif)# cable video ip 172.168.10.10 udp 23 multicast ssm0 program 100
Router(config-subif)#
```

Related Commands	Command	Description
	<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
	<b>cable route linecard load-balancing-group</b>	Configure a video route on the cable load balancing group on the line card.
	<b>cable video labels</b>	Enters the cable video label configuration mode.

# cable video ip udp

To configure unicast video sessions on a load balancing group, use the **cable video ip udp** command in QAM subinterface configuration mode. To disable the sessions, use the **no** form of this command.

**cable video ip** *dest-IP-address* **udp** { **data** **bitrate** *bps* | **multicast** *label* { **data** | **passthru** | **program** *prog-num* } | **passthru** | **program** }

**no cable video ip** *dest-IP-address* **udp** { **data** **bitrate** *bps* | **multicast** *label* { **data** | **passthru** | **program** *prog-num* } | **passthru** | **program** }

## Syntax Description

<i>dest-IP-address</i>	Destination IP address of the video route or GQI ingress port IP address.
<b>data</b>	Adds a data-piping session to the QAM interface.
<b>bitrate</b>	Sets the bitrate allocated for the data session.
<i>bps</i>	Bitrate value in bps. The valid range is 1 to 26970350.
<i>label</i>	Specifies the multicast session label definition created for ASM or SSM.
<b>data</b>	Adds a data-piping session to the QAM interface.
<b>passthru</b>	Adds a pass-through session to the QAM interface.
<b>program</b>	Adds a remap session to the QAM interface.
<i>prog-num</i>	Specifies the program number.

## Command Default

This command has no default behavior or values.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced. This command replaces the <b>cable video udp</b> command.

## Usage Guidelines

The cable input route is configured using the **cable route linecard load-balance-group** command at the global configuration level. For unicast sessions, the input route consists of destination IP address, maximum reserved bandwidth on the mid-plane.



### Note

The QAM subinterface must be set to **cable mode video local** mode for local video sessions and **cable mode video remote** for remote video sessions.



### Note

While configuring the video session on, the destination IP address must be same as the one configured on the **cable route linecard load-balance-group** command. For unicast session, UDP port number must be one of the UDP defined in the UDP range.

**Note**

To change the bitrate or jitter value of an existing video session to a higher value, remove the existing video session and reconfigure a new session. To avoid oversubscription, ensure that the actual bitrate of the video session does not exceed the allocated bitrate.

**Examples**

The following example shows how to configure local unicast video sessions:

```
Router(config)# cable route linecard 3 load-balancing-group 1
Router(config-lbg)# qam-partition default ip 192.168.10.10 udp 49201 49250 bitrate 250000
Router(config)# interface Qam3/3.48
Router(config-subif)# cable mode video local
Router(config-subif)# cable video ip 192.168.10.10 udp 49211 program 10 bitrate 3750000
Router(config-subif)#
```

The following example shows how to configure remote unicast video sessions:

```
Router(config)# cable route linecard 3 load-balancing-group 2
Router(config-lbg)# qam-partition 4 ip 192.168.10.10 udp 49201 49250 bitrate 250000
Router(config)# interface Qam3/3.48
Router(config-subif)# cable mode video remote [encrypt]
Router(config-subif)# cable partition 2 external-channel 23
Router(config-subif)#
```

**Related Commands**

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
<b>cable route linecard load-balance-group</b>	Configure a video route on the cable load balancing group on the line card.
<b>cable video labels</b>	Enters the cable video label configuration mode.



# cable video labels

To configure video session labels, use the **cable video labels** command in global configuration mode.

## cable video labels

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated in Cisco IOS-XE Release 3.3.0SQ.

<b>Usage Guidelines</b>	This command is used to set video session configuration labels. Cisco RFGW-10 supports both Any Source Multicast (ASM) and Source Specific Multicast (SSM) video sessions. An ASM session is identified by the destination IP address. An SSM session is identified by the source or group IP address pairs. You can specify a maximum of three multicast address pairs in an SSM multicast session.
-------------------------	--

<b>Examples</b>	The following example shows an ASM label on the Cisco RFGW-10:
-----------------	--

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# asm asm1 group 1.2.2.2 bitrate 42
```

The following example configures an SSM label on the Cisco RFGW-10:

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# ssm ssm1 source 2.2.22.2 group 1.1.11.1 bitrate 34
```

Related Commands	Command	Description
	asm	Configures the Any Source Multicast (ASM) session definition.
	cable video multicast	Configures ASM or SSM video session on the QAM interface.
	ssm	Configures the Source Specific Multicast (SSM) session definition.

# cable video multicast

To configure video multicast sessions on a QAM interface, use the **cable video multicast** command in QAM subinterface configuration mode. To deconfigure the multicast session, use the **no** form of this command.

**cable video multicast** *label* { **data** | **passthru** | **program** *prog-num* }

**no cable video multicast** *label* { **data** | **passthru** | **program** *prog-num* }

## Syntax Description

<i>label</i>	Specifies the multicast session label definition created for ASM or SSM.
<b>data</b>	Adds a data-piping session to the QAM interface.
<b>passthru</b>	Adds a pass-through session to the QAM interface.
<b>program</b>	Adds a VoD session to the QAM interface.
<i>prog-num</i>	Specifies the program number.

## Command Default

ASM and SSM labels are configured on the chassis.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on Cisco RF Gateway 10.

## Usage Guidelines

A video session contains input attributes, processing type, and output attributes.

The input attributes include:

- Input type (ASM or SSM)
- Input port information (destination UDP port or labels)
- Allocated bitrate
- Jitter buffer size

The output processing types are as described as follows:

- Data-piping: All the input Program Identifiers (PID)s are preserved to the output. No Program Specific Information (PSI) processing and dejittering is performed.
- Pass-through: All input program numbers and PIDs are preserved to the output. In general, only one pass-through session is present on the QAM channel.
- Remapped: The output program number and PIDs are different from the input. The output program number is configured and output PIDs are selected on the program number.

The output attributes include the output QAM channel and output program number for remapped sessions.

For unicast sessions, all attributes are configured at the QAM channel level. For multicast sessions, the input attributes are configured at the video session label level.

### Examples

The following example shows the ASM video session configuration on a QAM interface:

```
Router# configure terminal  
Router(config)#interface qam 3/1.1  
Router(config-subif)#cable video multicast asm1 data  
Router(config-subif)# exit
```

### Related Commands

Command	Description
<b>asm</b>	Creates a label for ASM multicast video session.
<b>cable video labels</b>	Enters the cable video label configuration mode.
<b>cable video udp</b>	Configures a unicast video session on QAM interface.
<b>show cable video label</b>	Displays the labels configured on the chassis.
<b>show cable video session</b>	Displays all cable video sessions configured on the Cisco RFGW-10.
<b>ssm</b>	Creates a label for SSM multicast video session.

# cable video multicast uplink

To set an uplink port for multicast traffic, use the **cable video multicast uplink** command in global configuration mode. To remove the configuration, use the **no** form of this command.

**cable video multicast uplink** {GigabitEthernet | TenGigabitEthernet *interface/port*} [**backup** GigabitEthernet | TenGigabitEthernet *interface/port*] [**bandwidth** *kbps*]

**no cable video multicast uplink** {GigabitEthernet | TenGigabitEthernet *interface/port*} [**backup** GigabitEthernet | TenGigabitEthernet *interface/port*] [**bandwidth** *kbps*]

## Syntax Description

<b>GigabitEthernet</b>	Indicates the Gigabit Ethernet interface. Valid slot range is 1 to 12.
<b>TenGigabitEthernet</b>	Indicates the 10 Gigabit Ethernet interface. Valid slots are 1 and 2.
<i>interface/port</i>	Specifies the interface slot and port.
<b>backup</b>	(Optional) Specifies the backup interface.
<b>bandwidth</b>	(Optional) Specifies the bandwidth of the interface.
<i>kbps</i>	(Optional) Specifies the bandwidth in kbps. Valid range is 1 to 1000000.

## Command Default

This command has no default behavior or values.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command was integrated in Cisco IOS-XE Release 3.3.0SQ.

## Usage Guidelines

This command is used to set the Gigabit or Ten Gigabit Ethernet port for multicast routing. The backup interface takes over the primary interface in case of failure.



### Note

Before setting the Gigabit Ethernet or Ten Gigabit Ethernet port for multicast routing, multicast routing must be enabled on the Cisco RFGW-10. The interfaces that would receive the multicast traffic must also be set in multicast mode.

## Examples

The following example configures video multicast on GigabitEthernet interface 1/3 and backup interface 2/3 with 20 kbps bandwidth:

```
Router# configure terminal
Router(config)# ip multicast-routing
Router(config)# cable video multicast uplink GigabitEthernet 1/3 backup GigabitEthernet
2/3 bandwidth 20
```

**Related Commands**

Command	Description
<b>ip multicast-routing</b>	Enables multicast routing on the Cisco RFGW-10.
<b>show cable video multicast uplink</b>	Displays video multicast uplink interfaces.

# cable video pre-encrypted-multicast

To configure pre-encrypted Switched Digital Video (SDV) multicast video sessions, use the **cable video pre-encrypted-multicast** command in QAM subinterface configuration mode. To disable, use the **no** form of this command.

**cable video pre-encrypted-multicast**

**no cable video pre-encrypted-multicast**

## Syntax Description

No keywords or arguments.

## Command Default

Encryption must be enabled on QAM partition.

## Command Modes

QAM subinterface configuration (config-subif)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

The **cable video pre-encrypted-multicast** command is configured for the QAM carrier configured with video remote mode and assigned to a GQI QAM partition.

When this CLI is configured on the QAM carriers, all session creation request received from GQI, which has the encrypted flag set, is ignored.



### Note

This mode setting is only required in a DNCS 5.0 environment and is not required with DNCS 6.0 and later. On a DNCS 6.0, ERMI, or local CLI, it is not mandatory to configure this.

## Examples

The following example shows how to configure the **cable video pre-encrypted-multicast** command:

```
Router# configure terminal
Router(config)# interface Qam-red3/1.1
Router(config-subif)# cable carrier-id 1
Router(config-subif)# cable mode video remote encrypt
Router(config-subif)# cable downstream lqam-group 1
Router(config-subif)# cable downstream tsid 1
Router(config-subif)# cable downstream frequency 125000000
Router(config-subif)# cable downstream rf-shutdown
Router(config-subif)# cable partition 1 external-channel 1
Router(config-subif)# cable video pre-encrypted-multicast
Router(config-subif)# exit
```

**Related Commands**

Command	Description
<b>cable video labels</b>	Enters the cable video label configuration mode.
<b>cable video ip udp</b>	Configures a unicast video session on QAM interface.
<b>show cable video label</b>	Displays the labels configured on the chassis.
<b>show cable video session</b>	Displays all cable video sessions configured on the Cisco RFGW-10.

# cable video psi-interval

To configure the Program Specific Information (PSI) interval, use the **cable video psi-interval** command in QAM subinterface configuration mode. To restore the default value, use the **no** form of this command.

**cable video psi-interval** *ms*

**no cable video psi-interval** *ms*

<b>Syntax Description</b>	<i>ms</i>	Specifies the interval time. Valid range is from 40 to 1000 ms. Default is 100 ms.
---------------------------	-----------	--

<b>Command Default</b>	The default PSI interval value is 100 ms.
------------------------	---

<b>Command Modes</b>	QAM subinterface configuration (config-subif)
----------------------	---

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated in Cisco IOS-XE Release 3.3.0SQ.

<b>Usage Guidelines</b>	The PSI interval is a timer configured on the QAM subinterface.
	Reconfiguring the PSI interval value reschedules all existing and new sessions in the same QAM channel with the new value.
	The <b>no</b> form of this command resets the value to the default value.

<b>Examples</b>	The following example shows the configuration of the PSI timer:
-----------------	---

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable video psi-interval 40
Router(config-subif)# exit
```

Related Commands	Command	Description
	<b>cable video timeout</b>	Configures the video session time-out intervals on the QAM interface.



## cable video servers

To configure server groups for video sessions using external servers, use the **cable video servers** command in global configuration mode. To deconfigure server groups for video sessions, use the **no** form of this command.

**cable video servers** *server-groupname*

**no cable video servers** *server-groupname*

<b>Syntax Description</b>	<i>server-groupname</i> Specifies the name of the video server group.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	12.2(50)SQ	This command was modified. The cable video server group configuration commands were modified.

<b>Usage Guidelines</b>	Server groups are required to set up video sessions when external servers such as the Data Network Control Station (DNCS) are used.
	A server group specifies the properties of protocols used, time-out and reconnect time intervals, IP address of the server, and the management IP address for communication between the server and the Cisco RFGW-10.
	Any number of server groups can be created, but only one of each type can be activated at any point of time.

<b>Examples</b>	The following example shows how to create a server group and lists the properties:
-----------------	--

```
Router(config)#cable video servers servergroup1
Router(config-video-servers)#?
Cable Video Server Group Configuration Commands:
  active          Start using the server-group
  exit            Exit from the Video Server Group mode
  mgmt-ip-address Management IP address
  no              Unconfigure Video Server Group parameters
  protocol        Configure protocols supported by servers in the group
  reset           Configure GQI Reset parameters
  server          IP address of video servers
  keepalive       Configure keepalive parameters
```

**Related Commands**

Command	Description
<b>active</b>	Activates the server.
<b>ip rpc portmapper</b>	Establishes an RPC connection between the external server and EQAM.
<b>keepalive retry</b>	Configures the keepalive retry value on the server.
<b>mgmt-ip-address</b> <b>mac-address</b>	Configures the management IP and MAC address of the server.
<b>protocol</b>	Configures the protocols supported by the server.
<b>reset interval</b>	Configures the reset interval on the server.
<b>server</b>	Configures the IP address of the server.

# cable video table

To configure video sessions on a QAM channel using the pre-defined UDP map, use the **cable video table** command in QAM subinterface configuration mode. To remove the configuration, use the **no** form of this command.

**cable video table 24-qam-map**

**no cable video table 24-qam-map**

Syntax Description	24-qam-map	Specifies the pre-defined port map. This is only applicable to local sessions.
--------------------	------------	--

Command Default	This command has no default values or behavior.
-----------------	---

Command Modes	QAM subinterface configuration (config-subif)
---------------	---

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on Cisco RF Gateway 10.

Usage Guidelines	<p>Local video sessions offer two methods of mapping UDP ports to QAM ports:</p> <ul style="list-style-type: none"> <li>• User-specified UDP ranges: Start and end UDP ports are specified using the <b>cable video udp</b> command.</li> <li>• Table-based: Referred to as <b>24-qam-map</b>. A local session is configured locally on the Cisco RFGW-10 using the <b>cable video table</b> command. The currently supported pre-defined UDP map is the 24-qam-map table.</li> </ul>
------------------	---

Examples	<p>The following example configures 30 (input sessions per QAM channel) re-mapped sessions in a QAM interface channel:</p>
----------	--

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable video table 24-qam-map
Router(config-subif)# exit
```


Related Commands	Command	Description
	<b>cable video udp</b>	Configures a unicast video session on QAM interface.
	<b>show cable video session</b>	Displays all cable video sessions configured on the Cisco RFGW-10.

# cable video timeout

To configure the video session time-out thresholds, use the **cable video timeout** command in global configuration mode. To restore the default value, use the **no** form of this command.

**cable video timeout** { **init-session** *ms* | **idle-session** *ms* | **off-session** *sec* | **low-bitrate-idle-session** *sec* }

**no cable video timeout** { **init-session** *ms* | **idle-session** *ms* | **off-session** *sec* | **low-bitrate-idle-session** *sec* }

Syntax Description	
<b>init-session</b>	Sets the timeout interval during initialization of a video session. Valid range is from 100 ms to 60000 ms. Default is 5000 ms.
<b>idle-session</b>	Sets the idle video session timeout interval. Valid range for idle sessions is 10 0ms to 2000 ms. Default value is 250 ms.
<b>off-session</b>	Sets the timeout interval for an off video session. Valid range for off sessions is 1 second to 4294967295 seconds. Default value is 60 seconds.
<b>low-bitrate-idle-session</b>	Sets the idle session timeout interval.
<b>n</b>	When the low bitrate value is less than or equal to 64000 bps, the default idle timeout value is 5 seconds.
	 <b>Note</b> For video sessions with bitrate value greater than 256000 bps, the idle-session timeout value is 250msec by default or takes the user configured value.
<i>ms</i>	Specifies the time in milliseconds.
<i>sec</i>	Specifies the time in seconds

**Command Default** Newly created sessions are in the init state. The default value is 5000 ms.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated and modified to include the <b>low-bitrate-idle-session</b> keyword.

**Usage Guidelines** A video session is created in the init state. The session enters the idle state when no traffic flows over a time duration specified by the init timer. The state transition is used to trigger a source switchover if a backup source is provided for the session.

When traffic stops in an active video session for a time period longer than the idle timer, the session moves to the idle state.

Similar to the idle state sessions are the off state sessions. Idle video sessions enter the off state when the time period of the idle session is longer than the off timer. The default off timer value is 60 seconds.

Use the **cable video timeout low-bitrate-idle-session** command to separate low bitrate idle sessions for SDV mini-carousel with 64Kbps.

The **no** form of the command resets the timer to the default value.

Reconfiguration of the init timer, idle timer, and the off timer affects only the new video sessions. The existing video sessions remain unchanged.

**Note**

A session always moves from the idle state before moving to the off state.

**Examples**

The following example shows the configuration of the idle session timer to 200 ms and the off session timer to 2 seconds:

```
Router#configure terminal
Router(config)#cable video timeout idle-session 200
Router(config)#cable video timeout off-session 2
Router(config)#exit
```

**Related Commands**

Command	Description
<b>cable video psi-interval</b>	Configures the PSI timer on a QAM interface.

# cable video udp



## Note

Effective with Cisco IOS-XE Release 3.3.0SQ the **cable video udp** command is relaced by the **cable video ip udp** command. See the **cable video ip udp** command for more details.

To configure a unicast video session, use the **cable video udp** command in QAM subinterface configuration mode. To unconfigure the session, use the **no** form of this command.

**cable video udp** *port* { **data** | **filter pid** *pid-list* | **passthru** [**cbr**] | **program** *prog-num* } [**bitrate** *bps* | **jitter** *ms*]

**no cable video udp** *port* { **data** | **filter pid** { **all** | *pid-list* } | **passthru** [**cbr**] | **program** *prog-num* } [**bitrate** *bps* | **jitter** *ms*]

## Syntax Description

<i>port</i>	Specifies the destination UDP port.
<b>data</b>	Adds a data-piping session to the QAM interface.
<b>filter</b>	Adds a filter to the video session.
<b>pid</b>	Sets filtering of PIDs for the pass-through video session.
<i>pid-list</i>	Specifies the PIDs or the range of PIDs or both to be dropped for the video session. The PID range is specified in “ <i>lower_pid</i> - <i>upper_pid</i> ” format. All PIDs must be within 1 to 8190 inclusively.  PIDs and PID ranges are to be separated by commas. A space is required before and after the commas and hyphens.
<b>all</b>	Deletes all filtered PIDs. This keyword is applicable to the <b>no</b> form of the command.
<b>passthru</b>	Adds a pass through session to the QAM interface.
<b>cbr</b>	Specifies that the session is supposed to be constant bitrate.
<b>program</b>	Adds a VoD session to the QAM interface.
<i>prog-num</i>	Specifies the program number.
<b>bitrate</b>	(Optional) Sets the bitrate allocated for the session.
<i>bps</i>	(Optional) Specifies the bitrate value. Valid range is 1 to 52000000 bps. Default is 3.75 Mbps.
<b>jitter</b>	(Optional) Specifies the amount of jitter allowed in a network.
<i>ms</i>	(Optional) Specifies the jitter value. Valid range is 10 to 200 ms. Default is 200 ms.

## Command Default

This command has no default behavior or values.

## Command Modes

QAM subinterface configuration (config-subif)

**Command History**

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
12.2(50)SQ1	Added the <b>filter</b> keyword to allow filtering of PIDs for pass-through video sessions.
Cisco IOS-XE Release 3.3.0SQ	This command is replaced by the <b>cable video ip udp</b> command.

**Usage Guidelines**

A unicast session is identified by its destination IP address and destination UDP port number. The destination IP address of the QAM block is configured in the video route command at the global configuration level. The destination UDP port is specified per unicast session. The UDP port value should be within the specified range and the corresponding configured video policy route.

Filtering of PIDs is applicable for pass-through video sessions. It is intended for filtering of unreferenced PIDs. No PMT regeneration will be performed even if PIDs referenced in the PMT are filtered. Upto 32 PIDs can be filtered per session. Up to eight PIDs or PID ranges can be specified in one CLI line. Multiple commands lines can be used to specify the PID filter.

**Note**

The QAM subinterface must be set to cable video local mode.

**Note**

To change the bitrate or jitter value of an existing video session to a higher value, remove the existing video session and reconfigure a new session. To avoid oversubscription, ensure that the actual bitrate of the video session does not exceed the allocated bitrate.

**Examples**

The following example configures a VoD session on QAM interface 3:

```
Router# configure terminal
Router(config)# interface qam 3/1.1
Router(config-subif)# cable mode video local
Router(config-subif)# cable video udp 1000 program 2 bitrate 3750000
Router(config-subif)# exit
```

The following example shows filtering being configured for unicast sessions. PID 23, 45 and PID range between 40 to 50 are filtered:

```
Router# configure terminal
Router(config)# interface qam-red 3/1.1
Router(config-subif)# cable video udp 10000 passthru 3500000
Router(config-subif)# cable video udp 10000 filter pid 23 , 34 , 40 - 50
Router(config-subif)# exit
```

**Related Commands**

Command	Description
<b>cable video multicast</b>	Configures video multicast session on QAM interface.
<b>show cable video session</b>	Displays the video sessions configured on the chassis.

# class

To select the redundancy class for a line card group, use the **class** command in line card redundancy configuration mode. To disable, use the **no** form of this command.

**class {1:1 | 1:n}**

**no class**

## Syntax Description

<b>1:1   1:n</b>	Specifies the redundancy class of the line card.
• <b>1:1</b>	Supports hot redundancy.
• <b>1:n</b>	Supports warm redundancy.

## Command Default

This command has no default behaviour or values.

## Command Modes

Line card redundancy configuration (config-red-lc)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

This command configures the redundancy class for the line card. The transmission switching between an active line card and a switchover line card is done by setting the class. Classes 1:1 and 1:n imply transmission switching from the active line card to the standby line card on switchover.

1:n redundancy refers to “n” active line cards being protected by one standby line card. The standby can take over for any active that fails, but cannot protect the others until the failed unit is restored and the standby is back in standby mode. 1:1 redundancy is treated as a special case of 1:n with a dedicated standby unit for a single active line card.

## Examples

The following example assigns class 1: 1 on redundancy line card group 2 on the Cisco RFGW-10:

```
Router(config-red)#linecard-group 2 internal-switch
Router(config-red-lc)#class 1:1
```

## Related Commands

Command	Description
<b>description</b>	Adds a description to the line card group.
<b>linecard-group</b> <b>internal-switch</b>	Creates a line card group for the line card.
<b>member slot</b>	Adds a slot to the redundancy group.



Command	Description
<b>redundancy</b>	Enters redundancy configuration mode.
<b>show redundancy linecard</b>	Displays information about a line card or a line card group.

# clear cable clock counters

To clear information about Timing, Communication and Control (TCC) DOCSIS Timing Interface (DTI) client and server counts and path traceability information, use the **clear cable clock counters** command in privileged EXEC mode.

## clear cable clock *slot* counters

Syntax Description	slot	Identifies a TCC interface on the Cisco RF Gateway 10.
--------------------	------	--

Command Default	This command has no default values or behavior.
-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	This command clears the TCC DTI client and server statistic counts and path traceability information.
------------------	---

Examples	The following example shows the counters on the TCC 13 card on the Cisco RF Gateway 10:
----------	---

```
Router#show cable clock 13 counters
TCC Card 13 DTI counters:
-----
Client Normal time           : 0x1EB6
Client Holdover time         : 0x0000
Client Phase Correction       : 0
Client Freq Correction        : 63213
Client EFC Correction         : 61039
Client transition count t3    : 0
Client transition count t4    : 1
Client transition count t6    : 0
Client transition count t7    : 0
Client port switch count     : 1
```

The following command clears the counters on the TCC 13 card on the Cisco RF Gateway 10:

```
Router#clear cable clock 13 counters
The following is a sample output of the TCC 13 card counters after execution of the clear cable clock
counters command on the Cisco RF Gateway 10:

Router#show cable clock 13 counters
TCC Card 13 DTI counters:
-----
Client Normal time           : 0x01B5
Client Holdover time         : 0x0000
Client Phase Correction       : 65535
Client Freq Correction        : 63210
```

```
Client EFC Correction           : 60649
Client transition count t3      : 0
Client transition count t4      : 0
Client transition count t6      : 0
Client transition count t7      : 0
Client port switch count       : 0
```

**Related Commands**

Command	Description
<b>cable clock free-run</b>	Allows the clock to be in free-run mode.
<b>show cable clock</b>	Displays information on TCC DTI client and server statistics counts and path traceability information.

# clear cable depi counters

To clear all Downstream External PHY Interface (DEPI) counters, use the **clear cable depi counters** command in privileged EXEC mode.

```
clear cable depi counters {all | session-id id | slot slot}
```

Syntax Description	all	Clears counters of all DEPI sessions.
	session-id	Clears counters of a particular session.
	id	Specifies the DEPI session.
	slot	Clears the counters of a session on a particular slot.
	slot	Specifies the slot. Valid slot range is from 3 to 12.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** This command clears all the counters on an existing DEPI sessions on the Cisco RFGW-10.

**Examples** The following example shows the clearance of the counters in all the DEPI sessions:  
Router#clear cable depi counters all

Related Commands	Command	Description
	show cable depi-sessions	Displays DEPI session information.

# clear cable ermi statistics

To clear the ERMI protocol connection statistics information, use the **clear cable ermi statistics** command in privileged EXEC mode.

**clear cable ermi { errp | rtsp } statistics**

<b>Syntax Description</b>	<b>errp</b>	Clears the Edge Resource and Registration protocol (ERRP) connection sessions.
	<b>rtsp</b>	Clears Real-time Streaming Protocol (RTSP) connections session.

<b>Command Default</b>	This command is enabled by default.
------------------------	-------------------------------------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

<b>Usage Guidelines</b>	This command clears the ERMI protocol connection information of ERRP and RTSP configured on the QAM partition.
-------------------------	--

<b>Examples</b>	The following example shows how to clear the ERRP statistics:  Router# <b>clear ermi errp statistics</b>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>errp</b>	Configures Edge Resource and Registration protocol (ERRP) on the QAM partition.
	<b>rtsp</b>	Configures Real-time Streaming Protocol (RTSP) on the QAM partition.

# clear cable midplane ping statistics

To clear the midplane ping statistics on the Cisco RFGW-10, use the **clear cable midplane ping statistics** command in privileged EXEC mode.

**clear cable midplane ping statistics** {all | slot *lc\_slot*}

Syntax Description	all	Clears the midplane ping statistics of all line cards.
	slot	Clears the midplane ping statistics of a line card slot.
	<i>lc_slot</i>	Line card slot. The valid range is from 3 to 12.

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(50)SQ4	This command was introduced.

Usage Guidelines	This command clears the midplane ping statistics on the Cisco RFGW-10.
------------------	--

Examples	The following shows how to clear the midplane ping information from all line cards: Router# <b>clear cable midplane ping statistics all</b>
----------	--

Related Commands	Command	Description
	<b>cable midplane ping</b>	Configures the midplane pings between the line card and the Supervisor on the Cisco RFGW-10.
	<b>show cable midplane ping statistics</b>	Displays the midplane ping statistics between the line cards and the Supervisor on the Cisco RFGW-10.

# clear cable video gqi statistics

To clear all video GQI sessions, use the **clear cable video gqi statistics** command in privileged EXEC mode.

**clear cable video gqi statistics**{all | qam-partition *partition-id*}

## Syntax Description

<b>all</b>	Clears all the QAM partitions statistics information configured for GQI on the line card.
<b>qam-partition</b>	Clears statistics information configured for GQI for a specific QAM partition.
<i>partition-id</i>	QAM partition ID. The valid range is from 1 to 50.

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ.

## Usage Guidelines

This command clears all the GQI statistics information on the Cisco RFGW-10.

## Examples

The following example shows the GQI statistics information on the QAM partition 3:

```
Router# show cable video gqi statistic qam 3
```

Qam Partition 3 Statistics:

	Create	Delete	Create	Delete	Insert	Cancel	Switch	Bind
Unbind	Reset	Encryption	Event					
Session	Shell	Shell	Session	Session	Packet	Packet	Source	
	Session	Indication	Discovery	Notification				
Success:	3	4	3	2	2	2	1	1
0	3	1	1					
Error:	4	5	2	3	4	2	2	1
2	0	2	2					
Total:	7	9	5	5	6	4	3	2
2	3	3	3					

The following example shows how to clear GQI statistics on the QAM partition 3:

Router# **clear cable video gqi statistics qam-partition 3**

The following example shows the output for the GQI sessions on QAM interface 3 after executing the **clear cable video gqi statistics** command:

Router# **show cable video gqi statistic qam 3**

Qam Partition 3 Statistics:								
Unbind	Create Reset	Delete Shell	Create Encryption	Delete Event	Insert	Cancel	Switch	Bind
Session	Session	Shell Indication	Session Discovery	Session Notification	Packet	Packet	Source	
-----								
Success:	0	0	0	0	0	0	0	0
0	0	0	0					
Error:	0	0	0	0	0	0	0	0
0	0	0	0					
Total:	0	0	0	0	0	0	0	0
0	0	0	0					

Related Commands

Command	Description
<b>show cable video packet</b>	Displays video packet information.



# clear cable video packet-insertion

To clear all video packet insertions, use the **clear cable video packet-insertion** command in privileged EXEC mode.

```
clear cable video packet-insertion { qam | qam-red slot/port.channel [stream stream-id] | all | slot slot }
```

Syntax Description		
<b>qam</b>		Specifies the QAM interface on the Cisco RFGW-10.
<b>qam-red</b>		Specifies the QAM interface when line card redundancy is configured on the Cisco RFGW-10.
<i>slot</i>		Specifies the slot on the QAM interface. Valid range is from 3 to 12.
<i>port</i>		Specifies the port on the interface. Valid range is from 1 to 12.
<i>channel</i>		(Optional) Specifies the channel on the port. Valid range is from 1 to 4.
<b>stream</b>		(Optional) Specifies packet stream insertion information.
<i>stream-id</i>		(Optional) Specifies the packet stream identifier. Valid range is from 1 to 4294967295.
<b>all</b>		Clears all the video packet insertions on the chassis.
<b>slot</b>		Clears the video packet insertions for a given slot.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ. The command name is changed from <b>clear cable video packet</b> to <b>clear cable video packet-insertion</b> .

**Usage Guidelines** This command clears all the video packet insertions on the Cisco RFGW-10.

**Examples** The following example shows the video packets on QAM interface 3:

```
Router# show cable video packets qam-red 3/1.1
```

Packet Stream ID	Interface	Version	Times Repeat	Actual Repeated	Insert Rate (bps)	Num Pkts Inserted	State
1	Qam3/1.1	1	Continuos	14460	1000	1	ON

The following example shows how to clear the video packet insertions on QAM interface 3:

```
Router#clear cable video packet qam-red 3/1.1 stream 1
```

The following example shows the output for the video packets on QAM interface 3 after executing the **clear cable video packet** command:

```
Router# show cable video packet qam-red 3/1.1
```

Packet			Times	Actual	Insert	Num Pkts	
Stream ID	Interface	Version	Repeat	Repeated	Rate (bps)	Inserted	State
-----							
Total Packets = 0							

Related Commands	Command	Description
	show cable video packet	Displays video packet information.

# clear cable video server-group statistics

To clear all video server-group statistics, use the **clear cable video server-group statistics** command in privileged EXEC mode.

**clear cable video server-group** *group-name* **statistics**

Syntax	Description
<i>group-name</i>	Name of the video server group.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** This command clears all the video server-group statistics on the Cisco RFGW-10.

**Examples** The following example displays information on all server groups configured on the line card:

```
Router# show cable video server-group all
```

```
Server-Group :    gqi1
State :          ACTIVE
Protocol :       GQI Emulation
Emulation Type : 24-qam
Keepalive Timeout Period : 5 seconds
Number of Retry : 3
Reset Timeout Period : 5 seconds
Number of Retry : 0
Server[0] :      1.9.87.2
```

```
Management IP: 1.43.24.61 Port: 938 Mac-Addr: 001d.e5e8.66c0
QAM Interfaces : 3/1.1-3/6.4
```

Server	State	Reset Indication	Pending Requests
1.9.87.2	Connected	In-progress	0

The following example shows how to clear the video server-group statistics:

```
Router# clear cable video server-group gqi1 statistics
```

The following example displays information of the server groups configured on the line card, after executing the **clear cable video server-group statistics** command:

```
Router# show cable video server-group all
```

## ■ clear cable video server-group statistics

```

Server-Group :    gqil
State :          ACTIVE
Protocol :       GQI Emulation
Emulation Type : 24-qam
Keepalive Timeout Period : 5 seconds
Number of Retry : 3
Reset Timeout Period : 5 seconds
Number of Retry : 0
Server[0] :      1.9.87.2

```

```

Management IP: 1.43.24.61 Port: 938 Mac-Addr: 001d.e5e8.66c0
QAM Interfaces : 3/1.1-3/6.4

```

Server	State	Reset Indication	Pending Requests
1.9.87.2	Not Connected	Not Completed	0

## Connection Statistics:

	Create Shell	Delete Shell	Create Session	Delete Session	Insert Packet	Cancel Packet	Send Message
Total:	0	0	0	0	0	0	26455
Success:	0	0	0	0	0	0	0
Error:	0	0	0	0	0	0	26455

```

Management IP: 1.43.24.62 Port: 938 Mac-Addr: 001d.e5e8.66c1
QAM Interfaces : 3/7.1-3/12.4

```

Server	State	Reset Indication	Pending Requests
1.9.87.2	Not Connected	Not Completed	0

## Connection Statistics:

	Create Shell	Delete Shell	Create Session	Delete Session	Insert Packet	Cancel Packet	Send Message
Total:	0	0	0	0	0	0	26453
Success:	0	0	0	0	0	0	0
Error:	0	0	0	0	0	0	26453

## Related Commands

Command	Description
<b>show cable video server-group</b>	Displays information of the server groups configured on a line card.

# clear cable video session

To clear all video session information, use the **clear cable video session** command in privileged EXEC mode.

**clear cable video session** {**qam** | **qam-red** *slot/port.channel* | **all** | **id** *session ID* | **local** | **remote** | **slot** *slot* | **statistics** *slot slot*}

Syntax Description		
<b>qam</b>		Specifies the QAM interface on the Cisco RFGW-10.
<b>qam-red</b>		Specifies the QAM interface when line card redundancy is configured on the Cisco RFGW-10.
<i>slot</i>		Specifies the slot on the QAM interface. Valid range is from 3 to 12.
<i>port</i>		Specifies the port on the interface. Valid range is from 1 to 12.
<i>channel</i>		(Optional) Specifies the channel on the port. Valid range is from 1 to 4.
<b>all</b>		Clears all the video sessions on the chassis.
<b>local</b>		Clears all the local video sessions on the chassis.
<b>remote</b>		Clears all the remote video sessions on the chassis.
<b>statistics</b>		Clears all the video statistics information on the chassis.
<b>slot</b>		Clears the video statistics information for a given slot.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ. The <b>local</b> , <b>remote</b> and <b>statistics</b> keyword are added.

**Usage Guidelines** This command clears all the video session information on the Cisco RFGW-10.

**Examples** The following example shows the video sessions on QAM interface 3:

Router# **show cable video sessions qam 3/1.1**

Session ID	QAM Port	Stream Type	Sess Type	UDP Port	Out Pgm	Input Bitrate	Input State	Output State	PSI Rdy	Ctrl State
1	3/1.1	Remap	UDP	500	10	0	OFF	ON	NO	-
2	3/1.1	Remap	UDP	50000	20	0	OFF	ON	NO	-
3	3/1.1	Remap	UDP	7000	30	0	OFF	ON	NO	-

Total Sessions = 3

The following example shows how to clear the video sessions on QAM interface 3:

```
Router# clear cable video sessions 3/1.1
```

The following example shows the output for the video sessions on QAM interface 3 after executing the **clear cable video session** command:

```
Router# show cable video sessions qam 3/1.1
```

```
Session   QAM      Stream Sess UDP   Out   Input   Input   Output PSI Ctrl
ID         Port    Type  Type Port   Pgm   Bitrate State  State Rdy State
-----
Total Sessions = 0
```

Related Commands	Command	Description
	show cable video session	Displays video session information.

# cluster run

To enable clustering on the Cisco RFGW-10, use the **cluster run** command in global configuration mode. To disable clustering, use the **no** form of this command.

**cluster run**

**no cluster run**

**Syntax Description** This command has no arguments and keywords.

**Command Default** This command is disabled by default.

**Command Modes** Global Configuration (Config)

Command History	Release	Modification
	12.2(50)SQ4	This command was introduced
	Cisco IOS-XE Release 3.2.0SQ	This command was integrated into Cisco IOS-XE Release 3.2.0SQ.

**Usage Guidelines** The **cluster run** command must be configured to:

- Enable DEPI midplane pings between the line card and Supervisor on the Cisco RFGW-10
- Handle DEPI Latency Measurement (DLM) ingress traffic on the Cisco RFGW-10

**Associated Features** The **cluster run** command is enabled to handle DLM traffic and DEPI midplane pings. For more information, see:

- [M-CMTS DEPI](#)

**Examples** The following example shows how to enable cluster run on the Cisco RFGW-10:

```
Router# configure terminal
Router(config)# cluster run
```

Related Commands	Command	Description
	<b>cable midplane ping</b>	Configures the midplane pings between the line card and the Supervisor on the Cisco RFGW-10.

# debug cable clock

To enable the DOCSIS Timing Interface (DTI) debugging, use the **debug cable clock** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug cable clock slot
no debug cable clock slot
```

Syntax Description	slot Specifies the TCC card slot. Valid slots are 13 and 14.
--------------------	--

Command Default	Debugging of the cable clock is not enabled.
-----------------	--

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	This command enables or disables debugging on the DOCSIS Timing Interface (DTI) for the Cisco RF Gateway 10.
------------------	--

Examples

The following example shows the sample output for **debug cable clock** command on TCC slot 13 on the Cisco RF Gateway 10:

Router# debug cable clock 13
00:05:53: rfgw\_dti\_process\_polling\_dti\_state:268 -> Current active TCC slot = 13
, state = 0x220
00:05:53: rfgw\_dti\_get\_tcc:52 -> a given slot 14 is not a TCC card type
00:05:53: rfgw\_tcc\_find\_best\_slot:191 -> TCC on slot 14 is not in service
00:05:53: rfgw\_dti\_process\_polling\_dti\_state:278 -> Unable to find the state for slot 14
00:05:53: rfgw\_dti\_process\_polling\_dti\_state:317 -> Current Slot 13, Best Clock is on slot 13
00:05:54: DTI\_MGMT Trace rfgw\_dti\_mgmt\_process:399
00:05:54: rfgw\_dti\_process\_polling\_dti\_state -> Current Slot = 13
00:05:54: DTI\_MGMT Trace rfgw\_dti\_is\_tcc\_connected:685
00:05:54: rfgw\_dti\_is\_tcc\_connected:695 -> TCC state for slot 13 = 0x7
00:05:54: STATE REPLY: 18

00:05:54: 0x0000: 00 02 00 0D 00 00 00 00 00 02 00 20 02 20 00 01
00:05:54: 0x0010: 01 00
00:05:54:

Related Commands



Command	Description
<b>clear cable clock</b>	Clears DTI client transition counters of a TCC DTI client and server statistics counts.
<b>cable clock polling-interval</b>	Enables the user to tune the polling interval used by the DTI processes on the Supervisor.
<b>cable clock free-run</b>	Allows the clock to be in free-run mode.
<b>show cable clock</b>	Displays information about TCC DTI client.

# depi eqam-stats

To enable debugging information for Downstream External PHY Interface (DEPI) EQAM statistics on the Cisco RF Gateway 10 (RFGW-10), use the **depi eqam-stats** command in global configuration mode. To disable debugging information, use the **no** form of this command.

**depi eqam-stats**

**no depi eqam-stats**

## Syntax Description

This command has no arguments or keywords.

## Command Default

The DEPI EQAM statistics configuration is enabled by default.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
12.2(50)SQ2	This command was introduced.

## Usage Guidelines

Cisco RFGW-10 sends EQAM statistics to the Cisco CMTS router. No other EQAM supports the EQAM statistics feature.

## Examples

The following example shows how to configure DEPI EQAM statistics on a Cisco RFGW-10:

```
Router# configure terminal
Router(config)# depi eqam-stats
```

## Related Commands

Command	Description
show depi session	Displays information about DEPI sessions.

# depi-class

To create a template of Downstream External PHY Interface (DEPI) control plane configuration settings, which different pseudowire classes can inherit, and to enter the DEPI class configuration mode, use the **depi-class** command in global configuration mode. To remove a specific DEPI class configuration, use the **no** form of this command.

**depi-class** *depi-class-name*

**no depi-class** *depi-class-name*

Syntax Description	<i>depi-class-name</i>	Name of the DEPI class. The <i>depi-class-name</i> argument must be specified to configure multiple sets of DEPI control parameters.
--------------------	------------------------	--

Command Default	No DEPI classes are defined.
-----------------	------------------------------

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	12.2(50)SQ	This command was introduced.

Usage Guidelines	<p>The <b>depi-class</b> <i>depi-class-name</i> command allows you to configure a DEPI class template that consists of configuration settings used by different pseudowire classes. The <b>depi-class</b> command enters DEPI class configuration mode, where DEPI control plane parameters are configured.</p> <p>You must use the same DEPI class in the pseudowire configuration at both ends of a Layer 2 control channel.</p>
------------------	--

Examples	<p>The following example shows how to enter DEPI class configuration mode to create a DEPI class configuration template for the class named SPA0:</p>
----------	---

```
Router# configure terminal
Router(config)# depi-class SPA0
Router(config-depi-ctrl SPA0)#
```

Related Commands	Command	Description
	<b>l2tp-class</b>	Creates a template of Layer 2 Tunnel Protocol (L2TP) control plane configuration settings that can be inherited by different pseudowire classes and enters the L2TP class configuration mode.
	<b>depi-tunnel</b>	Creates a template of Downstream External PHY Interface (DEPI) tunnel configuration settings, which different pseudowire classes can inherit, and enters the DEPI data session configuration mode.

Command	Description
<b>show depi tunnel</b>	Displays all active control connections.
<b>show depi session</b>	Displays established DEPI data sessions.

# depi-tunnel

To create a template of Downstream External PHY Interface (DEPI) tunnel configuration settings, which different pseudowire classes can inherit, and to enter the DEPI data session configuration mode, use the **depi-tunnel** command in the global configuration mode or subinterface configuration mode. To remove a configured DEPI tunnel, use the **no** form of this command.

**depi-tunnel** *depi-tunnel-name*

**no depi-tunnel** *depi-tunnel-name*

## Syntax Description

<i>depi-tunnel-name</i>	Name of the DEPI tunnel.
-------------------------	--------------------------

## Command Default

This command has no default behavior or values.

## Command Modes

Global configuration (config)  
Subinterface configuration (config-subif)

## Command History

Release	Modification
12.2(50)SQ	This command was introduced.

## Usage Guidelines

The **depi-tunnel** creates a template of DEPI tunnel configuration settings. The DEPI data session inherits the control plane configuration settings of a depi-control template.

The following depi data session configuration options are available in this mode:

- l2tp-class
- depi-class
- dest-ip
- tos

## Examples

The following example shows how to create a template of DEPI tunnel configuration settings in the global configuration mode and enter the DEPI data session configuration mode:

```
Router# configure terminal
Router(config)# depi-tunnel rf6
Router(config-depi-tunnel)#
```

The following example shows how to create a template of DEPI tunnel configuration settings in the subinterface configuration mode:

```
Router(config)# interface qam 6/4.1
Router(config-subif)# depi-tunnel 0
```

Related Commands	Command	Description
	<b>l2tp-class</b>	Creates a template of Layer 2 Tunnel Protocol (L2TP) control plane configuration settings, which different pseudowire classes can inherit, and enters the L2TP class configuration mode.
	<b>depi-class</b>	Creates a template of Downstream External PHY Interface (DEPI) control plane configuration settings, which different pseudowire classes can inherit, and enters the DEPI class configuration mode.
	<b>dest-ip</b>	Assigns an IP address to the destination network.
	<b>show depi tunnel</b>	Displays all active control connections.
	<b>show depi session</b>	Displays established DEPI data sessions.

# description

To add a description to the line card group, use the **description** command in line card redundancy configuration mode. To remove the description, use the **no** form of this command.

**description** *string*

**no description** *string*

## Syntax Description

<i>string</i>	Specifies a description for the line card group. The maximum length of the string is 127 characters.
---------------	--

## Command Default

Default is LC-GROUP followed by the line card group ID.

## Command Modes

Line card redundancy configuration (config-red-lc)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

The description string has a maximum limit of 127 characters.

## Examples

The following example assigns a description to the redundancy line card group 2 on the Cisco RF Gateway 10:

```
Router(config-red)#linecard-group 2 internal-switch
Router(config-red-lc)#description line card group 2 created.
```

## Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>member slot</b>	Adds a slot to the redundancy group.
<b>linecard-group internal-switch</b>	Configures a redundancy line card group.
<b>redundancy</b>	Configures the redundancy mode.
<b>show redundancy linecard</b>	Displays information about a redundancy line card or a line card group.

# dest-ip

To assign an IP address to the edge quadrature amplitude modulation (EQAM), use the **dest-ip** command in DEPI tunnel configuration mode. To remove a specific destination IP address, use the **no** form of this command.

**dest-ip** *dest-ip-address*

**no dest-ip** *dest-ip-address*

<b>Syntax Description</b>	<i>dest-ip-address</i>	IP address of the EQAM.
---------------------------	------------------------	-------------------------

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	DEPI tunnel configuration
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ	This command was introduced.

<b>Usage Guidelines</b>	The <b>dest-ip</b> <i>dest-ip-address</i> command allows you to configure the IP address of the EQAM.
-------------------------	---

<b>Examples</b>	The following example shows how to assign 1.3.4.155 as the destination IP address:
-----------------	--

```
Router# configure terminal
Router(config)# depi-tunnel rf6
Router(config-depi-tunnel)# dest-ip 1.3.4.155
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>l2tp-class</b>	Creates a template of Layer 2 Tunnel Protocol (L2TP) control plane configuration settings, which different pseudowire classes can inherit, and enters the L2TP class configuration mode.
	<b>depi-class</b>	Creates a template of Downstream External PHY Interface (DEPI) control plane configuration settings, which different pseudowire classes can inherit, and enters the DEPI class configuration mode.
	<b>depi-tunnel</b>	Specifies the name of the depi-tunnel and enters the DEPI tunnel configuration mode.
	<b>show depi tunnel</b>	Displays all active control connections.
	<b>show depi session</b>	Displays established DEPI data sessions.



# errp

To configure Edge Resource and Registration protocol (ERRP), use the **errp** command in QAM partition configuration mode. To disable ERMI registration, use the **no** form of this command.

```
errp { component-name comp-name | connect-retry retry-interval | connect-time connect-seconds
| hold-time hold-seconds | streaming-zone zone-name }
```

```
no errp { component-name com-name | connect-retry retry-interval | connect-time
connect-seconds | hold-time hold-seconds | streaming-zone zone-name }
```

## Syntax Description

<b>component-name</b>	Specifies the ERMI component name for QAM partition.
<i>comp-name</i>	Component name.
<b>connect-retry</b>	Specifies connection retry time.
<i>retry-interval</i>	Connection retry interval in seconds. The valid range is from 1 to 10.
<b>connect-time</b>	Specifies the connection time.
<i>connect-seconds</i>	Connection time in seconds. The valid range is from 10 to 100
<b>hold-time</b>	Specifies the hold time.
<i>hold-seconds</i>	Wait time in seconds. The valid range is from 3 to 240 seocnds.
<b>streaming-zone</b>	Specifies the ERMI streaming zone for QAM partition.
<i>zone-name</i>	Streaming zone name.

## Command Default

This command is not enabled by default.

## Command Modes

QAM partition configuration mode (config-qp)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

ERMI is a protocol for managing EQAM resources both for DOCSIS and video services. It provides video edge device discovery, resource provisioning and signaling protocols for setup and control of video on demand (VOD) and switched digital video (SDV) type video sessions.



### Note

ERMI protocol has to be configured in the QAM partition.

ERMI-1 is a discovery and registration protocol which allows edge resource manager (ERM) to discover and ascertain capacity, operation state, and signaling mechanism for Cisco RFGW-10. On the Cisco RFGW-10, ERMI-1 acts as a client to provide protocol messages.

ERMI-2 is a control protocol which uses Supervisor to perform video session setup and session management requested by the ERM server. On the Cisco RFGW-10, ERMI-2 acts as a server to handle the message types.

Examples

The following example shows how to configure errp on the QAM partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# protocol ermi
Router(config-qp)# errp component-name c1
Router(config-qp)# connect-retry 5
Router(config-qp)# connect-time 10
Router(config-qp)# hold-time 200
Router(config-qp)# streaming-zone zone1
```

Related Commands

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
<b>clear cable ermi statistics</b>	Clears ERMI protocol connection statistics information.
<b>protocol</b>	Assigns the protocol used by the external server.
<b>rtsp</b>	Configures Real-time Streaming Protocol (RTSP) on the QAM partition.

# hw-module module power

To manually power on a cable interface line card, use the **hw-module module power** command in global configuration mode. To power off the cable line card, use the **no** form of this command.

**hw-module module slot power**

**no hw-module module slot power**

<b>Syntax Description</b>	<i>slot</i> Specifies the slot of the line card. Valid slot numbers range from 3 to 12.
---------------------------	---

<b>Command Default</b>	The cable line cards are always powered on when inserted into the chassis slot.
------------------------	---

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

<b>Usage Guidelines</b>	<p>This command is applicable to one line card at a time. This command is not applicable for TCC cards.</p> <p>This command is not used during normal operations, but it can be used for lab, diagnostic, and troubleshooting purposes. For example, use this command to power off and then power on a card, which is equivalent to inserting or removing a line card online.</p>
-------------------------	---

<b>Examples</b>	<p>The following example shows the line card 3 powered on:</p> <pre>Router(config)#hw-module module 3 power</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface qam</b>	Displays the configuration and hardware present on the line card.

# interface qam

To configure a QAM interface, use the **interface qam** command in global configuration mode.

**interface { qam | qam-red } slot/port.[channel]**

## Syntax Description

<i>slot</i>	Specifies the QAM or QAM-red slot on the line card. If line card redundancy is configured on the QAM, the interface is QAM-red. Valid range is from 3 to 12.
<i>port</i>	Specifies the port on the slot. Valid range is from 1 to 12.
<i>channel</i>	(Optional) Specifies the channel on the port. Valid range is from 1 to 4. Enters the QAM sub interface configuration mode when executed.

## Command Default

This command has no default behavior or values.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

Redundancy-configured interfaces (QAM-red) imply that line card redundancy (LCRED) is configured on the chassis.

All downstream commands are configured in the interface and subinterface configuration modes.

## Examples

The following example shows how to configure a QAM interface:

```
Router#configure terminal
Router(config)#interface qam 3/1
```

## Related Commands

Command	Description
<b>show running-config</b>	Displays downstream configuration on the QAM interface.
<b>interface qam</b>	

# ip

To configure a destination IP address for video sessions on a QAM domain, use the **ip** command in QAM domain configuration mode. To remove the assigned IP address, use the **no** form of this command.

**ip** *IP address* [**local** | **remote**]

**no ip** *IP address* [**local** | **remote**]

## Syntax Description

<i>IP address</i>	Specifies the destination IP address for the video sessions.
<b>local</b>	(Optional) Specifies the video services that are configured locally.
<b>remote</b>	(Optional) Specifies remotely configured video sessions.

## Command Default

If local or remote destinations are not specified, then the IP address is used for both local and remote sessions.

## Command Modes

QAM domain configuration (QAM-domain)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

A QAM domain has a local IP address and a remote IP address. The IP address is assigned to destination local or remote video sessions on the QAM domain. You can configure two sets of IP addresses for each session. You can also use the same IP address for both local and remote sessions.



### Note

If you remove an IP address, all its associated video services are also removed.

## Examples

The following example shows the IP address assigned to a video session on the QAM domain in slot 3:

```
Router#configure terminal
Router(config)#cable qam-domain 3
Router(qam-domain)#ip 10.10.10.1 local
Router(qam-domain)#ip 10.10.10.1 remote
Router(qam-domain)#exit
Router(config)#exit
```

## Related Commands

Command	Description
<b>cable qam-domain</b>	Configures the QAM domain.
<b>video route</b>	Specifies the route for a video session.

# ip multicast-routing

To enable video multicast routing, use the **ip multicast-routing** command in global configuration mode. To disable video multicast routing, use the **no** form of this command.

**ip multicast-routing**

**no ip multicast-routing**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

<b>Usage Guidelines</b>	This command enables multicast forwarding on the chassis. To enable video multicast routing, set the interfaces in multicast mode and assign the specific bandwidth.
-------------------------	--

<b>Examples</b>	The following example enables video multicast routing on the Cisco RFGW-10:
-----------------	---

```
Router#configure terminal
Router(config)#ip multicast-routing
```

<b>Related Commands</b>	Command	Description
	<b>cable video multicast</b>	Enables an uplink port for multicast traffic.

# ip rpc portmapper

To establish a remote procedure call (RPC) connection between an external server and an EQAM, use the **ip rpc portmapper** command in global configuration mode.

## ip rpc portmapper

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	Release	Modification
	12.2(50)SQ	This command was introduced on Cisco RF Gateway 10.

<b>Usage Guidelines</b>	The <b>ip rpc portmapper</b> command establishes an RPC connection to enable the DNCS (client) to invoke a program to be executed on the Cisco RFGW-10 EQAM (server).
-------------------------	---

<b>Examples</b>	The following example shows how to establish an RPC connection:
-----------------	---

```
Router# configure terminal
Router(config)# ip rpc portmapper
```

<b>Related Commands</b>	Command	Description
	<b>active</b>	Activates the server.
	<b>cable video servers</b>	Configures the video server group for external servers.
	<b>keepalive retry</b>	Configures the keepalive retry value on the server.
	<b>mgmt-ip-address</b> <b>mac-address</b>	Configures the management IP and MAC address of the server.
	<b>protocol</b>	Configures the protocols supported by the server.
	<b>reset interval</b>	Configures the reset interval on the server.
	<b>server</b>	Configures the IP address of the server.

# keepalive retry

To send keepalive message to a remote client with a specified retry interval, use the **keepalive retry** command in QAM partition configuration mode. To remove the setting, use the **no** form of this command.

**keepalive retry** *seconds*

**no keepalive retry** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Retry interval value. A maximum of three retry attempts are allowed. The valid retry range is from 0 to 10. The default keepalive is 5 seconds.
---------------------------	----------------	---

<b>Command Default</b>	This command is not enabled by default.
------------------------	---

<b>Command Modes</b>	QAM partition configuration (config-qp)
----------------------	---

<b>Command History</b>	Release	Modification
	12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command is integrated into Cisco IOS-XE Release 3.3.0SQ.

<b>Usage Guidelines</b>	Use the <b>keepalive retry</b> command in QAM partition configuration to set the keepalive retry time interval.
-------------------------	---

<b>Examples</b>	The following example shows how to configure a keepalive retry interval value of 4 seconds in a QAM partition configuration:
-----------------	--

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# keepalive retry 4
```

<b>Related Commands</b>	Command	Description
	<b>active</b>	Activates the server.
	<b>cable qam-partition</b>	Configures the QAM partition for a video server.
	<b>ip rpc portmapper</b>	Establishes an RPC connection between the external server and EQAM.
	<b>mgmt-ip-address</b> <b>mac-address</b>	Configures the management IP and MAC address of the server.
	<b>protocol</b>	Configures the protocols supported by the server.



Command	Description
<b>reset interval</b>	Configures the reset interval on the server.
<b>server</b>	Configures the IP address of the server.

# l2tp-class

To create a template of Layer 2 Tunnel Protocol (L2TP) control plane configuration settings, which different pseudowire classes can inherit and to enter L2TP class configuration mode, use the **l2tp-class** command in global configuration mode. To remove a specific L2TP class configuration, use the **no** form of this command.

**l2tp-class** *l2tp-class-name*

**no l2tp-class** *l2tp-class-name*

<b>Syntax Description</b>	<i>l2tp-class-name</i>	Name of the L2TP class. The <i>l2tp-class-name</i> argument must be specified if you want to configure multiple sets of L2TP control parameters.
---------------------------	------------------------	--

<b>Command Default</b>	No L2TP classes are defined.
------------------------	------------------------------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ	This command was introduced.

<b>Usage Guidelines</b>	The <b>l2tp-class</b> <i>l2tp-class-name</i> command allows you to configure an L2TP class template that consists of configuration settings used by different pseudowire classes. An L2TP class includes the following configuration settings:
-------------------------	--

- Hostname of local router used during Layer 2 authentication
- Authentication enabled
- Time interval used for exchange of hello packets
- Password used for control channel authentication
- Packet size of receive window
- Retransmission settings for control packets
- Time allowed to set up a control channel

The **l2tp-class** command enters L2TP class configuration mode, where L2TP control plane parameters are configured.

You must use the same L2TP class in the pseudowire configuration at both ends of a Layer 2 control channel.

<b>Examples</b>	The following example shows how to enter L2TP class configuration mode to create an L2TP class configuration template for the class named ether-pw:
-----------------	---

```
Router(config)# l2tp-class ether-pw
```

```
Router(config-l2tp-class)#
```

**Related Commands**

Command	Description
<b>depi-class</b>	Creates a template of Downstream External PHY Interface (DEPI) control plane configuration settings, which different pseudowire classes can inherit, and enters the DEPI class configuration mode.
<b>depi-tunnel</b>	Specifies the name of the depi-tunnel and enters the DEPI tunnel configuration mode.

# lane

To configure the lane frequency in the frequency profile, use the **lane** command in frequency profile configuration mode.

```
lane lane_id start-freq frequency
```

## Syntax Description

<i>lane_id</i>	Lane ID in the frequency profile. Valid range is from 1 to 4.
<b>start-freq</b>	Specifies the starting frequency of the lane.
<i>frequency</i>	Downstream start frequency of a lane. Valid range is from 48000000 to 999000000 Hz.

## Command Default

The command is disabled by default.

## Command Modes

Frequency profile configuration mode (config-freq-prof)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

## Usage Guidelines

The Supervisor card uses two frequency schemes—static frequency scheme and the user-defined frequency scheme—to configure the frequency profile at port level. Cisco IOS-XE Release 3.2.0SQ supports global templates or profiles on the Cisco RFGW-10 DS-384 line card. A wider range of frequency spectrum is supported on the UPX on the line card.

  
**Note**

The downstream frequency layout schemes are applicable only on the Cisco RFGW-10 DS-384 line card.

In the user-defined frequency layout scheme allows you to define the frequency on a global chassis level, and apply the cable downstream frequency scheme spectrum for any port on any Cisco RFGW-10 DS-384 line card.

A frequency profile has four frequency lanes in the 1GHz spectrum. Each lane has a frequency of 216 MHz. Each lane has 4 blocks of 54 MHz, and each block has 8 carriers. The start frequency assigned to a carrier must be in the frequency range of 216 MHz.

  
**Note**

The channel frequencies cannot overlap with each other. Each lane cannot exceed 32 carriers.

  
**Note**

This command is applicable on the Cisco RFGW10-DS-384 line card.

### Examples

The following example creates the lane in frequency profile, and enters the frequency profile lane configuration mode:

```
Router(config)# cable downstream freq-profile freq-profile-1
Router(config-freq-prof)# lane 1 start-freq 48000000
Router(config-freq-prof-lane)# exit
Router(config-freq-prof)#
```

### Related Commands

Command	Description
<b>cable downstream freq-profile</b>	Creates the frequency profile for a Cisco RFGW-10 DS-384 line card.
<b>block</b>	Creates the block frequency in the lane for the frequency profile.

# linecard-group internal switch

To add a group ID for a line card group and configure line card redundancy, use the **linecard-group internal switch** command in redundancy configuration mode. To remove the line card group, use the **no** form of this command.

**linecard-group** *group-id* **internal switch**

**no linecard-group** *group-id* **internal switch**

## Syntax Description

<i>group-id</i>	Specifies the group ID number. Valid range is from 0 to 5.
-----------------	--

## Command Default

This command has no default behavior or values.

## Command Modes

Redundancy configuration (config-red)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

Before you remove the group, ensure that the configured slot members on the line card are removed.

## Examples

The following example creates a redundancy line card group 2 on the Cisco RFGW-10:

```
Router(config-red)#linecard-group 2 internal-switch
```

## Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>description</b>	Adds a description to the line card group.
<b>member slot</b>	Adds a slot to the line card redundancy group.
<b>redundancy</b>	Enters redundancy configuration mode.
<b>show redundancy linecard</b>	Displays information about a redundant line card or a line card group.

# main-cpu

To configure the synchronization of the active and standby Supervisor cards, use the **main-cpu** command in redundancy configuration mode,.

## main-cpu

**Syntax Description** This command has no keywords or arguments.

**Command Default** This command has no default behavior or values.

**Command Modes** Redundancy configuration (config-red)

Command History	Release	Modification
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

**Usage Guidelines** When you enter the main-CPU redundancy configuration mode, the command prompt changes to:

```
Router(config-r-mc)#
```

After you enter the main-CPU redundancy configuration mode, use the **auto-sync** command to specify which files are synchronized between the active and standby Supervisor cards.

To exit main-CPU redundancy configuration mode and return to the redundancy configuration mode, use the **exit** command.

**Examples** The following example shows how to enter main-CPU redundancy mode, and its associated commands:

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# main-cpu
Router(config-r-mc)# ?
Main CPU redundancy configuration commands:
  auto-sync  Sync elements
  default    Set a command to its defaults
  exit       Exit from main-cpu configuration mode
  no         Negate a command or set its defaults
```

Related Commands	Command	Description
	<b>auto-sync</b>	Configures which files are synchronized between the active and standby Supervisor cards.
	<b>redundancy</b>	Enters redundancy configuration mode.

# mac-address

To configure the MAC address for the QAM partition, use the `mac-address` command in QAM partition configuration mode. To disable the MAC address, use the **no** form of this command.

**mac-address** *mac\_address*

**no mac-address** *mac\_address*

## Syntax Description

<i>mac_address</i>	MAC address of the external server.
--------------------	-------------------------------------

## Command Default

This command has no default behavior or values.

## Command Modes

QAM partition configuration (config-qp)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command is integrated into Cisco IOS-XE Release 3.3.0SQ.

## Usage Guidelines

The GQI protocol uses the Cisco RFGW-10 MAC address in a GQI specific QAM partition configuration.

## Examples

The following example configures the MAC address on the QAM partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# mac-address 192.168.20.20
Router(config-qp)
```

## Related Commands

Command	Description
<b>cable qam-partition</b>	Configures the QAM partition for a video server.
<b>protocol</b>	Configures the protocols supported by the server.



# member slot

To configure the redundancy role of a line card, use the **member slot** command in line card redundancy configuration mode. To remove the role, use the **no** form of this command.

**member slot** *slot* {**primary** | **secondary**}

**no member slot** *slot* {**primary** | **secondary**}

## Syntax Description

<i>slot</i>	Specifies the slot number of the line card. Valid range is from 3 to 12.
<b>primary</b>	Specifies the redundancy role of the active line card.
<b>secondary</b>	Specifies the redundancy role of the standby line card.

## Command Default

This command has no default behavior or values.

## Command Modes

Line card redundancy configuration (config-red-lc)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

Ensure that the following criteria are met prior to configuring the member slots:

- The slot is not configured as a member of another line card group.
- The number of primary members must be less than or equal to the maximum number allowed in a line card group for a line card.
- A primary or secondary member is not configured in a line card group.

## Examples

The following example assigns member slots 7 and 12 as the primary and secondary line cards in the redundancy line card group 2 in the Cisco RFGW-10:

```
Router(config-red)#linecard-group 2 internal-switch
Router(config-red-lc)#class 1:1
Router(config-red-lc)#member slot 7 primary
Router(config-red-lc)#member slot 12 secondary
```

## Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>description</b>	Adds a description to the line card group.
<b>linecard-group</b> <b>internal switch</b>	Creates a line card redundancy group on the line card.

Command	Description
<b>redundancy</b>	Enters redundancy configuration mode.
<b>show redundancy linecard</b>	Displays information about a line card or a line card group.

# mgmt-ip

To configure the IP address of the QAM partition, use the **mgmt-ip** command in QAM partition configuration mode. To disable the IP address on the QAM partition, use the **no** form of this command.

**mgmt-ip** *IP\_address*

**no mgmt-ip** *IP\_address*

Syntax Description	<i>IP_address</i> Specifies the IP address of the QAM partition.							
Command Default	This command is disabled by default.							
Command Modes	QAM partition configuration (config-qp)							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Cisco IOS-XE Release 3.3.0SQ</td><td>This command was introduced.</td></tr></table>		Release	Modification	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.		
Release	Modification							
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.							
Usage Guidelines	The <b>mgmt-ip</b> command sets the IP address of QAM partition. The management IP address of the QAM partition must be unique.							
Examples	<p>The following example configures the management IP address of the QAM partition:</p> <pre>Router# configure terminal Router(config)# cable qam-partition 1 Router(config-qp)# protocol gqi Router(config-qp)# mgmt-ip 1.1.1.1 Router(config-qp)# end</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td><b>cable qam-partition</b></td><td>Configures the QAM partition for a video server.</td></tr><tr><td><b>protocol</b></td><td>Assigns the protocol used by the external server.</td></tr></table>		Command	Description	<b>cable qam-partition</b>	Configures the QAM partition for a video server.	<b>protocol</b>	Assigns the protocol used by the external server.
Command	Description							
<b>cable qam-partition</b>	Configures the QAM partition for a video server.							
<b>protocol</b>	Assigns the protocol used by the external server.							

# mgmt-ip-address mac-address

To configure the management port IP address and MAC address, use the **mgmt-ip-address mac address** command in cable video server configuration mode. To remove the configuration, use the **no** form of this command.

**mgmt-ip-address** *IP address* **mac-address** *MAC address*

**no mgmt-ip-address** *IP address* **mac-address** *MAC address*

<b>Syntax Description</b>	<i>IP address</i>	Specifies the IP address of the management port on the external server.
	<i>MAC address</i>	Specifies the MAC address of the external server.

**Command Default** This command has no default behavior or values.

**Command Modes** Cable video server configuration (config-video-servers)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** Ensure that you configure the protocol used by the external server prior to configuring the IP address and MAC address.

**Examples** The following example shows the configuration of the management port:

```
Router#configure terminal
Router(config)#cable video servers group2
Router(config-video-servers)#protocol gqi
Router(config-video-servers)#mgmt-ip-address 172.16.22.1 mac-address 1234.abcd.4e4e
Router(config-video-servers)#exit
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>cable video servers</b>	Configures the video server group for external servers.
	<b>protocol</b>	Configures the protocol used by the external server.
	<b>server</b>	Configures the IP address of the external server.

# mode

To configure the redundancy mode of operation, use the **mode** command in redundancy configuration mode.

```
mode {rpr | sso}
```

## Syntax Description

<b>rpr</b>	Sets Route Processor Redundancy (RPR) mode on the Supervisor card.
<b>sso</b>	Sets Stateful Switchover (SSO) redundancy mode on the Supervisor card.

## Command Default

The default mode is SSO.

## Command Modes

Redundancy configuration (config-red)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.
12.2(50)SQ	Support for SSO was added.

## Usage Guidelines

The IOS software image on both the active and standby Supervisor cards must be the same.

## Examples

The following example shows how to enter RPR mode on the Cisco RFGW-10:

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# mode rpr
Router(config-red)# main-cpu
Router(config-red-mc)# auto-sync standard
Router(config-red-mc)# exit
Router# write memory
```

The following example shows how to enter SSO redundancy mode:

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# mode sso
Router(config-red)# exit
Router# write memory
```

Related Commands	Command	Description
	<b>redundancy</b>	Enters redundancy configuration mode.
	<b>redundancy force-failover main-cpu</b>	Forces a manual switchover between the active and standby Supervisor cards.
	<b>redundancy force-switchover</b>	Forces the standby Supervisor card to assume the role of the active Supervisor card.

# pilot-qam

To configure the pilot (source) QAM, use the **pilot-qam** command in QAM replication group configuration mode. To remove the pilot QAM, use the **no** form of this command.

**pilot-qam** {qam | qam-red} {qam-interface-number}

**no pilot-qam** {qam | qam-red} {qam-interface-number}

## Syntax Description

*qam-interface-number* Pilot QAM location.

## Command Default

This command is enabled by default.

## Command Modes

QAM replication group configuration (config-qrg)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

Cisco IOS-XE Release 3.3.0SQ introduces the QAM replication group feature to replicate any single QAM output from one port to another port on the same Cisco RFGW-10 DS-384 line card.

A QAM replication group contains information about a single source QAM and its corresponding replicated copy or copies. Each group is numbered with a *group-id* and contains the *slot*, *port* and *channel number* for both the source QAM (pilot-qam) and the destination QAM (replicate-qam).



### Note

QAM replication is supported only within a given line card and not from one line card to another.

## Examples

The following example shows how to create a pilot QAM:

```
Router# configure terminal
Router(config)# cable qam-replication-group 1
Router(config-qrg)# pilot-qam qam-red 3/1.1
```

## Related Commands

Command	Description
<b>cable qam-replication-group</b> <b>p</b>	Configures the QAM replication group.
<b>replicate-qam</b>	Configures the replicate QAM in the QAM replication group.

# protect-tunnel

To configure a Downstream External PHY Interface (DEPI) tunnel on the Cisco RF Gateway 10 (RFGW-10), use the **protect-tunnel** command in global configuration mode. To disable this configuration, use the **no** form of this command.

```
protect-tunnel protect-depi-tunnel-name

no protect-tunnel protect-depi-tunnel-name
```

Syntax Description	protect-depi-tunnel-na    Protect DEPI tunnel with which the depi-tunnel is associated. me
--------------------	---

Command Default	The N+1 DEPI redundancy feature is disabled.
-----------------	--

Command Modes	Global configuration (config)
---------------	-------------------------------

Command History	Release	Modification
	12.2(50)SQ2	This command was introduced.

Usage Guidelines	The protect tunnel must be explicitly configured. The protect tunnel inherits L2TP class and DEPI class parameters from the working tunnel. When you configure the protect tunnel and specify the destination IP address for the protect tunnel, the protect tunnel inherits the QAM channel parameters specified for the working tunnel.
------------------	---

Examples	The following example shows how to configure a DEPI tunnel for the protect cable interface line card on the Cisco RFGW-10.
	<p>Destination IP address of the M-CMTS router must be specified as the endpoint for the protect tunnel:</p> <pre>Router&gt; enable Router# configure terminal Router(config)# depi-tunnel protect1 Router(config-depi-tunnel)# dest-ip 192.0.2.103 Router(config-depi-tunnel)# exit</pre> <p>The protect tunnel is then configured on an existing working DEPI tunnel:</p> <pre>Router(config)# depi-tunnel working1 Router(config-depi-tunnel)# protect-tunnel protect1 Router(config-depi-tunnel)# end</pre>

## Related Commands



Command	Description
<b>depi-tunnel</b>	Specifies a template for DEPI tunnel configuration settings.

# protocol

To set the protocol used by the server, use the **protocol** command in **cable qam-partition** configuration mode QAM partition configuration mode. To remove the protocol configuration, use the **no** form of this command.

```
protocol {ermi | gqi}

no protocol {ermi | gqi }
```

Syntax Description	ermi	Supports Edge Resource Management Interface (ERMI) protocol for video sessions.
	gqi	Supports Generic QAM Interface (GQI) protocol sent to the Data Network Control Station (DNCS) server.

Command Default This command has no default behavior or values.

Command Modes QAM partition configuration (config-qp)

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ.

Usage Guidelines Use the **protocol** command in QAM partition configuration to set the interface used between DNCS/USRM and RFGW-10.

QAM partitioning is used by protocol applications such as GQI and ERMI to extend the QAM partition configuration for a given protocol.

The GQI protocol supports the latest GQI protocol. The QAM partition must be configured before any protocol configuration.

## Examples

The following example shows the configuration of a QAM in emulation mode:

```
Router(config-video-servers)# protocol gqi emulation 24-qam
Router(config-video-servers)# mgmt-ip-address 10.10.1.1 mac-address 1223/.e03f.ffff
Router(config-video-servers)# exit
```

The following example shows the GQI protocol configuration on the cable qam partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-video-servers)# protocol gqi
Router(config-video-servers)# server 10.10.10.1
Router(config-video-servers)# exit
```

The following example sets the QAM partition with the ERMI protocol:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# protocol ermi
```

## Related Commands

Command	Description
<b>mgmt-ip-address</b> <b>mac-address</b>	Configures the management port IP address and MAC address.
<b>server</b>	Configures the IP address of the external server.
<b>cable qam-partition</b>	Configures the QAM partition for a video server.

# qam-group

To configure QAM group, use the **qam-group** command in cable service group configuration mode. To remove the QAM group, use the **no** form of this command.

```
qam-group qam-group-name

no qam-group qam-group-name
```

Syntax Description	qam-group-name      QAM group name.
--------------------	-------------------------------------

Command Default	This command is enabled by default.
-----------------	-------------------------------------

Command Modes	Cable service group configuration (config-qsg)
---------------	--

Command History	Release	Modification
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

Usage Guidelines	A QAM group can contain one or more QAM channels.
------------------	---

Examples

The following example shows how to create a QAM group:

```
Router# configure terminal
Router(config)# cable service-group 1
Router(config-qsg)# qam-group group1
```

Related Commands	Command	Description
	<b>cable service-group</b>	Configures the QAM service group.
	<b>show cable service-group</b>	Displays the service groups configured on the Cisco RFGW-10.

# qam-partition

To assign the QAM partition to the load balancing group, use the **qam-partition** command in load balancing group configuration mode. To disable the QAM partition, use the **no** form of this command.

**qam-partition** {*partition-id* | **default** *dest-IP-address*} **bitrate** *bit-value* **udp** *low-udp high-udp* {**bitrate** *bit-value*}

**no qam-partition** {*partition-id* | **default** *dest-IP-address*} **bitrate** *bit-value* **udp** *low-udp high-udp* {**bitrate** *bit-value*}

## Generic QAM Interface (GQI)

**qam-partition** {*partition-id*} [**ip** *IP-address* **udp** *low-udp high-udp*] [**gqi-ingress-port** *input-port* **bitrate** *bit-value*]

**no qam-partition** {*partition-id*} [**ip** *dest-IP-address* **udp** *low-udp high-udp*] [**gqi-ingress-port** *input-port* **bitrate** *bit-value*]

### Syntax Description

<i>partition-id</i>	QAM partition ID. The valid range is from 1 to 50.
<b>default</b>	Configures the default QAM partition to the load balancing group.
<i>dest-IP-address</i>	IP address of the default QAM partition.
<b>bitrate</b>	Sets the reserved bandwidth to the partition.
<i>bit-value</i>	Specifies the bit value in Kbps. The valid range is from 1 to 9100000.
<b>udp</b>	Sets the UDP port range.
<i>low-udp</i>	Low UDP port value. The valid range is from 1 to 65535.
<i>high-udp</i>	High UDP port value. The valid range is from 1 to 65535.
<b>ip</b>	Specifies the destination IP address.
<b>gqi-ingress-port</b>	Specifies the input port for the GQI interface.
<i>input-port</i>	Input port of GQI. The valid range is from 1 to 100.

### Command Default

This command is enabled by default.

### Command Modes

Load balancing group configuration (config-lbg)

### Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

### Usage Guidelines

Use the **qam-partition** command to assign a QAM partition to the load balancing group.

  
**Note**

The IP address and UDP range in the cable route must be unique, and must be a valid IP address configured on the QAM interface.

  
**Note**

The **gqi-ingress-port** is only used in GQI QAM partitions. This identifies the physical input port for sessions in GQI model.

Examples

The following example shows how to configure the QAM partition on the load balancing group:

```
Router# configure terminal
Router(config)# cable route linecard 3 load-balance-group 1
Router(config-lbg)# qam-partition default 30.0.3.10 udp 1 49260 bitrate 3300
Router(config-lbg)#
```

The following example shows how to configure the GQI QAM partition on the load balancing group:

```
Router# configure terminal
Router(config)# cable route linecard 3 load-balance-group 1
Router(config-lbg)# qam-partition 3 ip 10.1.1.1 gqi 10 bitrate 21
Router(config-lbg)#
```

Related Commands

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
<b>cable route linecard load-balancing-group</b>	Configure a video route on the cable load balancing group on the line card.
<b>show cable linecard load-balancing-group</b>	Displays the load balancing groups configured on the QAM partitions.

# redundancy

To configure redundancy configuration mode, use the **redundancy** command in global configuration mode.

## redundancy

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command has no default behavior or values.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

**Usage Guidelines** At the redundancy configuration mode, you can do the following:

- Set a command to its default mode using the **default** command.
- Exit from a redundancy configuration using the **exit** command.
- Enter the line card group redundancy configuration using the **linecard-group** command.
- Enter main-CPU redundancy configuration mode using the **main-cpu** command, which allows you to specify which files are synchronized between the active and standby Supervisor cards.
- Configure the redundancy mode for the chassis using the **mode** command.
- Enforce a redundancy policy using the **policy** command.

**Examples** The following example shows how to enter redundancy configuration mode and its associated commands on the Cisco RFGW-10 chassis:

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)#?
Redundancy configuration commands:
  default      Set a command to its defaults
  exit         Exit from redundancy configuration mode
  linecard-group Enter linecard redundancy submode
  main-cpu     Enter main-cpu mode
  mode         redundancy mode for this chassis
  no           Negate a command or set its defaults
  policy       redundancy policy enforcement
```

Related Commands	Command	Description
	<b>auto-sync</b>	Enables automatic synchronization of the configuration files in NVRAM.
	<b>main-cpu</b>	Enters main-CPU redundancy configuration mode to synchronize the active and standby Supervisor cards.
	<b>mode (redundancy)</b>	Configures the redundancy mode of operation.
	<b>redundancy force-switchover</b>	Switches control of a router from the active RP to the standby RP.
	<b>show redundancy</b>	Displays information about the current redundant configuration, recent changes in states, current or historical status, and planned or logged handovers.



# redundancy force-failover main-cpu

To force a switchover so that a standby Supervisor card becomes an active Supervisor card, use the **redundancy force-failover main-cpu** command in privileged EXEC mode.

## redundancy force-failover main-cpu

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

<b>Usage Guidelines</b>	The <b>redundancy force-failover main-cpu</b> command initiates a manual switchover so that the standby Supervisor card becomes the active Supervisor card and assumes full responsibilities for router operations. When using this command, ensure that both Supervisor cards have the Cisco IOS software image that supports the Route Processor Redundancy (RPR) feature.
-------------------------	--

**Note**

Though the terms “failover” and “switchover” are interchangeable, “switchover” is the term used across all Cisco platforms.

A manual switchover is performed for the following reasons:

- To upgrade or replace the active Supervisor card.
- To upgrade the Cisco IOS software on the standby Supervisor card and let the standby Supervisor card use the new software image. This also allows you to upgrade the software on the former active Supervisor card without interrupting system operations.
- To test the switchover operation on the system.

A switchover can also be manually initiated by removing the active Supervisor card from the chassis, by using the **redundancy force-failover main-cpu** command to provide a more graceful switchover, without generating hardware alarms.

**Tip**

Do not perform a switchover immediately after you change the configuration and save it to the NVRAM. Instead, wait a few minutes to allow the two Supervisor cards to synchronize with the new configuration, and then perform the switchover.

**Examples**

The following example shows a manually initiated switchover on a Supervisor card on a Cisco RFGW-10 chassis:

```
Router# redundancy force-failover main-cpu
Proceed with switchover to standby Supervisor? [confirm] y
```

**Note**

Press **Enter** or enter **y** to begin the switchover. Pressing any other key aborts the switchover and returns control to the current active Supervisor card.

The following example shows a switchover attempt that has failed, because the standby Supervisor card is either not ready, not available, or not installed on a Cisco RFGW-10 chassis:

```
Switch# redundancy force-failover main-cpu

Proceed with switchover to standby Supervisor? [confirm]
Standby Supervisor not ready, switchover aborted.
```

**Related Commands**

Command	Description
<b>redundancy</b>	Enters the redundancy configuration mode so that the synchronization parameters can be configured.
<b>redundancy reload</b>	Resets the standby Supervisor card to reset both the active and standby Supervisor cards.

# redundancy force-switchover

To force the standby Route Processor (RP) or standby Supervisor card to assume the role of an active RP or Supervisor card, use the **redundancy force-switchover** command in privileged EXEC mode.

## redundancy force-switchover

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

**Usage Guidelines** Use the **redundancy force-switchover** command to switch control of a router from the active Supervisor card to the standby Supervisor card. Install the Cisco IOS image on both the active and standby Supervisor cards to ensure high availability. Configure the Route Processor Redundancy (RPR) mode on both the Supervisor cards before the **redundancy force-switchover** command is used. This command verifies if the standby Supervisor card is ready for system switchover.

When you use the **redundancy force-switchover** command and the current running configuration is different from the startup configuration, the system prompts you to save the running configuration before the switchover is performed.



### Note

All line cards will reset in RPR mode on a switchover.

**Examples** The following example shows how to perform a manual switchover from the active to the standby RP when the running configuration is different from the startup configuration:

```
Router# redundancy force-switchover

System configuration has been modified. Save? [yes/no]:y
Building configuration...
...
...
[OK]
Proceed with switchover to standby NSE? [confirm]y

00:07:35:%SYS-5-SWITCHOVER:Switchover requested
```

The following example shows how to perform a manual switchover from the active to the standby RP when the running configuration is the same as the startup configuration:

```
Router# redundancy force-switchover
```

```
Proceed with switchover to standby NSE? [confirm]
```

```
00:07:35:%SYS-5-SWITCHOVER:Switchover requested
```

#### Related Commands

Command	Description
<b>redundancy</b>	Enters the redundancy configuration mode.
<b>show redundancy</b>	Displays the current active and standby Supervisor card redundancy status.

# redundancy linecard-group switchover from slot

To initiate a line card switchover, use the **redundancy linecard-group switchover from slot** command in privileged EXEC mode.

**redundancy linecard-group switchover from slot** *slot*

<b>Syntax Description</b>	<i>slot</i>	Specifies the line card slot on the chassis. Valid range is from 3 to 12.
---------------------------	-------------	---

<b>Command Default</b>	The switchover of the line card takes place.
------------------------	--

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

<b>Usage Guidelines</b>	This command is used for the line card switchover. Switchover occurs from the current active line card to the standby line card.
-------------------------	--

<b>Examples</b>	The following example shows the switchover of a line card in slot 3:
-----------------	--

```
Router#redundancy linecard-group switchover from slot 3
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show redundancy linecard</b>	Displays information on a line card or line card group redundancy status.

# redundancy reload

To reset the standby Supervisor card to reset both the active and standby Supervisor cards, use the **redundancy reload** command in privileged EXEC mode.

**redundancy reload {peer | shelf}**

## Syntax Description

<b>peer</b>	Reloads only the standby Supervisor card.
<b>shelf</b>	Reloads both the active and standby r Supervisor card.

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was integrated into Cisco IOS Release 12.2(44)SQ. Support for the Cisco RF Gateway 10 was added.

## Usage Guidelines

The **redundancy reload peer** command reloads the Cisco IOS software on the standby Supervisor card which does not have an impact on router operations, assuming a switchover is not required while the standby module is resetting. The **redundancy reload shelf** command reloads the Cisco IOS software on both the active and standby Supervisor cards, which will interrupt services on the router until all the Supervisor cards and line cards initialize and come back online.

## Examples

The following example shows the system response when a standby Supervisor card is not installed in the Cisco RFGW-10:

```
Switch# redundancy reload peer
```

```
System is running in SIMPLEX mode, reload anyway? [confirm] n
Peer reload not performed.
```

The following example shows how to reload both Supervisor cards on the Cisco RFGW-10:

```
Switch# redundancy reload shelf
```

```
Reload the entire shelf [confirm] y
Preparing to reload entire shelf
```



### Note

Pressing **Enter** or **y** confirms the action and begins the reload of both cards. Pressing any other key aborts the reload and returns control to the current active Supervisor card.

## Related Commands

Command	Description
<b>redundancy</b>	Enters redundancy configuration mode so that the synchronization parameters can be configured.
<b>redundancy force-failover main-cpu</b>	Forces a switchover, so that the standby Supervisor card becomes the active Supervisor card.

# redundancy tcc-group switchover from slot

To initiate a Timing, Communication and Control (TCC) card switchover, use the **redundancy tcc-group switchover from slot** command in privileged EXEC mode.

**redundancy tcc-group switchover from slot** *slot*

<b>Syntax Description</b>	<i>slot</i> Specifies the TCC card slot on the chassis. Valid slots are 13 and 14.				
<b>Command Default</b>	This command has no default behavior or values.				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>12.2(44)SQ</td><td>This command was introduced on the Cisco RF Gateway 10.</td></tr> </table>	Release	Modification	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Release	Modification				
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.				
<b>Usage Guidelines</b>	This command is used for TCC card switchover. Switchover occurs from the current active card to the standby TCC card.				
<b>Examples</b>	<p>The following example shows the switchover of a TCC card in slot 13:</p> <pre>Router#redundancy tcc-group switchover from slot 13</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show redundancy tcc</b></td><td>Displays information of the TCC card redundancy status.</td></tr> </table>	Command	Description	<b>show redundancy tcc</b>	Displays information of the TCC card redundancy status.
Command	Description				
<b>show redundancy tcc</b>	Displays information of the TCC card redundancy status.				



# replicate-qam

To configure the replicate (destination) QAM, use the **replicate-qam** command in QAM replication group configuration mode. To remove the replicate QAM, use the **no** form of this command.

**replicate-qam** {qam | qam-red} {qam-interface-number}

**no replicate-qam** {qam | qam-red} {qam-interface-number}

## Syntax Description

*qam-interface-number* Replicate QAM location.

## Command Default

This command is enabled by default.

## Command Modes

QAM replication group configuration (config-qrg)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

Cisco IOS-XE Release 3.3.0SQ introduces the QAM replication group feature to replicate any single QAM output from one port to another port on the same Cisco RFGW-10 DS-384 line card.

A QAM replication group contains information about a single source QAM and its corresponding replicated copy or copies. Each group is numbered with a *group-id* and contains the *slot*, *port* and *channel number* for both the source QAM (pilot-qam) and the destination QAM (replicate-qam).



### Note

QAM replication is supported only within a given line card and not from one line card to another.

## Examples

The following example shows how to create a replicate QAM:

```
Router# configure terminal
Router(config)# cable qam-replication-group 1
Router(config-qrg)# replicate-qam qam-red3/2.1
```

## Related Commands

Command	Description
<b>cable qam replication-group</b>	Configures the QAM replication group.
<b>pilot-qam</b>	Configures the pilot QAM in the QAM replication group.

# reserve cardtype

To configure the reserve line card type in line card redundancy, use the **reserve cardtype** command in line card redundancy configuration mode. To disable the line card type, use the **no** form of this command.

```
reserve cardtype type
no reserve cardtype type
```

Syntax Description	type	Line card type in Hex or Decimal. Valid range is from 0-4294967295.
--------------------	------	---

Command Default	This command is auto-generated when the first primary line card is configured.
-----------------	--

Command Modes	Line card redundancy configuration (config-red-lc)
---------------	--

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Cisco IOS-XE Release 3.2.0SQ</td><td>This command was introduced.</td></tr></table>	Release	Modification	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.
Release	Modification				
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.				


**Usage Guidelines**

The Cisco RFGW-10 DS-48 line card and the Cisco RFGW-10 DS-384 line card have 12 and 8 ports respectively. Thus, these cards cannot exist in the same redundancy group.

Each protection group has a reserve cardtype configuration which can be manually configured before configuring the first primary line card in the group. However, if the reserve cardtype is not configured, it is automatically generated when the first primary line card is configured.

Additional redundancy line cards in a redundancy group are configured only if the card types are compatible with the reserve cardtype. The line card will not be allowed to fully initialize, if the line card is removed from a redundancy group and replaced with a non-compatible line cardtype.

For information on the redundancy group cardtype compatibility, see [1:1 and 1:N Line Card Redundancy](#).

 Note	To determine the cardtype of an existing line card, use the <b>show redundancy linecard slot [slot]</b> command. Use this command even if the line card is a <i>not</i> redundant line card.
---	--

Associated Features	<p>The <b>reserve cardtype</b> command is used to configure the reserve cardtype in a redundancy line card configuration on the Cisco RFGW-10 router. For information on configuring line card redundancy, see</p> <ul style="list-style-type: none"><li><a href="#">1:1 and 1:N Line Card Redundancy</a></li></ul>
---------------------	---

**Examples**

The following example shows the configuration and the output of the automatic generation of the reserve cardtype for a Cisco RFGW-10 line card:

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# linecard-group 0 internal-switch
Router(config-red-lc)# class 1:n
Class set to 1:N for Redundancy group (0)
Router(config-red-lc)# member slot 3 primary
Auto generate reserve card type command
Router(config-red-lc)# end
```

```
Router# show run | beg redundancy
...
redundancy
  linecard-group 0 internal-switch
  class 1:N
  reserve cardtype 0x6011
  member slot 3 primary
  revertive 300
  mode sso
```

The following example manually configures the reserve cardtype for a Cisco RFGW-10 DS-384 line card, and attempts to configure the Cisco RFGW-10 DS-48 line card as a primary line card.

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# linecard-group 0 internal-switch
Router(config-red-lc)# class 1:n
Class set to 1:N for Redundancy group (0)
Router(config-red-lc)# reserve cardtype ?
<0-4294967295> Enter reserve cardtype in Hex or Decimal

Router(config-red-lc)# reserve cardtype 0x6015
Router(config-red-lc)# member slot 3 primary
Reject: Configuration of slot 3 as Primary failed for the above reason
Router(config-red-lc)#
*Apr 20 11:36:13.690: %RFGW-3-CARDTYPE_MISMATCH: Primary card type (ElbCardTypeMossbeach)
in slot (3) is not compatible with Reserve card type (ElbCardTypeBlackbriar)
```

The following example manually configures the reserve cardtype for a Cisco RFGW-10 DS-48 line card, and configure the Cisco RFGW-10 DS-48 line card as a primary line card.

```
Router# configure terminal
Router(config)# redundancy
Router(config-red)# linecard-group 0 internal-switch
Router(config-red-lc)# class 1:n
Class set to 1:N for Redundancy group (0)
Router(config-red-lc)# reserve cardtype 0x6011
Router(config-red-lc)# member slot 3 primary
Router(config-red-lc)# end
Router#
*Apr 20 11:38:27.161: %SYS-5-CONFIG_I: Configured from console by console
```

```
Router# show run | beg redundancy
...
redundancy
  linecard-group 0 internal-switch
  class 1:N
  reserve cardtype 0x6011
  member slot 3 primary
  revertive 300
```

```

mode sso
!

```

The following example shows an attempt to configure an invalid reserve cardtype for the Cisco RFGW-10 line card:

```

Router# configure terminal
Router(config)# redundancy
Router(config-red)# linecard-group 0 internal-switch
Router(config-red-lc)# class 1:n
Class set to 1:N for Redundancy group (0)
Router(config-red-lc)# reserve cardtype 0x6000
Router#
Cardtype is not valid, enter valid card type and try this command again

```

The following example shows an attempt to configure a different reserve cardtype that does not match the existing redundancy members.

```

Router# configure terminal
Router(config)# redundancy
Router(config-red)# linecard-group 0 internal-switch
Router(config-red-lc)# class 1:n
Class set to 1:N for Redundancy group (0)
Router(config-red-lc)# reserve cardtype 0x6011
Router(config-red-lc)# member slot 3 primary
Router(config-red-lc)# reserve cardtype 0x6015
Reserve cardtype cannot be changed while this group
has members. Reserved card type (0x6011 24593)
Router(config-red-lc)#

```

#### Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>linecard-group internal-switch</b>	Adds a group ID for a line card group, and enters line card redundancy configuration mode.
<b>member slot</b>	Adds a slot to the line card redundancy group.
<b>redundancy</b>	Enters the redundancy configuration mode.

# reset interval



## Note

The **reset-interval** command is not available in the Cisco IOS-XE Release 3.3.0SQ and later releases.

To set the reset interval, use the **reset interval** command in video server configuration mode and QAM partition configuration mode. To remove the setting, use the **no** form of this command.

**reset interval** *seconds*

**no reset interval** *seconds*

## Syntax Description

<i>seconds</i>	Reset interval value. The valid interval range is from 1 to 300.
----------------	--

## Command Default

This command is not enabled by default.

## Command Modes

Video server configuration (config-video-servers)QAM partition configuration (config-qp)

## Command History

Release	Modification
12.2(50)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command is removed. It is not available in the Cisco IOS-XE Release 3.3.0SQ and later releases.

## Usage Guidelines

Use the reset interval command in QAM partition configuration to reset the reset interval value.



## Note

Video server configuration is *not* supported in Cisco IOS-XE 3.2.99SQ{X} and later.

## Examples

The following example shows how to configure the reset interval value of 10 seconds in QAM partition configuration:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# reset interval 10
```

The following example shows how to configure the reset interval value of 1 second on a Cisco RFGW-10:

```
Router(config)# cable video servers servergroup1
Router(config-video-servers)# reset interval 1
```

■ reset interval

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>active</b>	Activates the server.
<b>cable qam-partition</b>	Configures the QAM partition for a video server.
<b>cable video servers</b>	Configures server groups for video sessions using external servers.
<b>ip rpc portmapper</b>	Establishes an RPC connection between the external server and EQAM.
<b>keepalive retry</b>	Configures the keepalive retry value on the server.
<b>mgmt-ip-address mac-address</b>	Configures the management IP and MAC address of the server.
<b>protocol</b>	Configures the protocols supported by the server.
<b>server</b>	Configures the IP address of the server.
<b>show cable video server-group</b>	Displays the video server-group information.

# retry interval

To configure the retry time and interval time on the external server, use the **retry interval** command in cable video server configuration mode. To remove the configuration, use the **no** form of this command.

**retry** *seconds interval seconds*

**no retry** *seconds interval seconds*

Syntax Description	<i>seconds</i>	Specifies the time interval. The default retry time is 3 seconds and the default interval time is 5 seconds.
--------------------	----------------	--

Command Default	This command has no default behavior or values.
-----------------	---

Command Modes	Cable video server configuration (config-video-servers)
---------------	---

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	Retry and interval time are optionally configured in the server group for communication between the Cisco RFGW-10 and the external servers.
------------------	---

Examples	The following example shows 10 seconds configured as the retry and interval value on the video server:
----------	--

```
Router#configure terminal
Router(config)#cable video server servergroup1
Router(config-video-servers)#protocol gqi
Router(config-video-servers)#server 10.10.10.1
Router(config-video-servers)#retry 10 interval 10
Router(config-video-servers)#exit
```

Related Commands	Command	Description
	<b>cable video servers</b>	Configures the video server group for external servers.
	<b>mgmt-ip-address</b> <b>mac-address</b>	Configures the management port IP address and MAC address.
	<b>protocol</b>	Configures the protocol used by the external server.
	<b>server</b>	Configures the IP address of the external server.

# rtsp

To configure the ERMI Real-time Streaming Protocol (RTSP) on the QAM partition, use the **rtsp** command in global configuration mode. To disable the protocol, use the **no** form of this command.

```

rtsp {connect-retry retry-interval | connect-time connect-seconds | keepalive
connection-timeout-interval | session-timeout session-timeout-interval}

no rtsp {connect-retry retry-interval | connect-time connect-seconds | keepalive
connection-timeout | session-timeout session-timeout}
```

## Syntax Description

<b>connect-retry</b>	Specifies RTSP connection retry time.
<i>retry-interval</i>	RTSP connection retry interval, The valid range is from 1 to 10.
<b>connect-time</b>	Specifies the RTSP connection time
<i>connect-seconds</i>	RTSP connection time in seconds. The valid range is from 10 to 200.
<b>keepalive</b>	Specifies the keepalive time for the RTSP connection.
<i>connection-timeout-interval</i>	RTSP connection timeout interval. The valid range is from 1 to 300. The default value is 300.
<b>session-timeout</b>	Specifies the RTSP session timeout for the connection.
<i>session-timeout-interval</i>	RTSP session timeout interval. The valid range is from 10800 to 36000.

## Command Default

This command is not enabled by default.

## Command Modes

QAM partition configuration mode (config-qp)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Usage Guidelines

ERMI is a protocol for managing EQAM resources both for DOCSIS and video services. It provides video edge device discovery, resource provisioning and signaling protocols for setup and control of video on demand (VOD) and switched digital video (SDV) type video sessions.



### Note

ERMI protocol has to be configured in the QAM partition.

RTSP protocol is designed to support the setup of multimedia sessions over IP networks. RTSP operates on TCP port and provides primitives for session setup and session management protocol. RTSP is a client server protocol that enables a client application to request streaming media services from a media server.



### Examples

The following example shows how to configure ERMI **rtsp** protocol on the QAM partition 1:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# protocol ermi
Router(config-qp)# rtsp connect-retry 5
Router(config-qp)# rtsp connect-time 10
Router(config-qp)# rtsp keepalive 5
Router(config-qp)# rtsp session-timeout 10800
```

### Related Commands

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
<b>clear cable ermi statistics</b>	Clears ERMI protocol connection statistics information.
<b>errp</b>	Configures Edge Resource and Registration protocol (ERRP) on the QAM partition.
<b>protocol</b>	Assigns the protocol used by the external server.

# server

To configure the external server IP address, use the **server** command in cable video server configuration mode and QAM partition configuration mode. To remove the configuration, use the **no** form of this command.

**server** *IP address*

**no server** *IP address*

## Syntax Description

<i>IP address</i>	Specifies the IP address of the external server.
-------------------	--

## Command Default

This command has no default behavior or values.

## Command Modes

QAM partition configuration (config-qp)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
Cisco IOS-XE Release 3.3.0SQ	This command is integrated Cisco IOS-XE Release 3.3.0SQ.

## Usage Guidelines

Data Network Control Station (DNCS) servers use Generic QAM interface (GQI) protocol. The IP address of the DNCS server must be provided. SDV servers use Switched Digital Video (SDV) protocol and do not require an IP address.

Starting with Cisco IOS-XE Release 3.3.0SQ, the **server** command configures the IP address of the external server that uses the QAM partition.

## Examples

The following example sets the external server IP address in a QAM partition:

```
Router# configure terminal
Router(config)# cable qam-partition 1
Router(config-qp)# protocol gqi
Router(config-qp)# mgmt-ip 1.1.1.1
Router (config-qp)# server 192.168.0.10
```

## Related Commands

Command	Description
<b>cable qam-partition</b>	Configures the QAM partition for a video server.
<b>protocol</b>	Assigns the protocol used by the external server.

# show cable clock

To display information about displaying Timing, Communication and Control (TCC) card DOCSIS Timing Interface (DTI) client and server statistic counts, use the **show cable clock** command in privileged EXEC mode.

**show cable clock** [*slot*] {*client port id* | *server port id* | **counters**}

<b>Syntax Description</b>	<i>slot</i>	(Optional) Identifies a TCC interface on the Cisco RF Gateway 10. Valid TCC slots are 13 and 14.
	<b>client port id</b>	Specifies the DTI client port ID. Valid port values are 1 and 2.
	<b>server port id</b>	Specifies the DTI server port ID. Valid port values are 1 and 2.
	<b>counters</b>	Specifies the DTI client counters.

**Command Default** Information on the TCC DTI client and server is displayed. Counters are not displayed.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was modified in Cisco IOS Release 12.2(44)SQ to support the Cisco RF Gateway 10. The <i>slot</i> , <b>client</b> , <b>server</b> , and <b>counters</b> options were added.

**Examples** The following example shows the TCC DTI client and server statistic counts information:

```
Router# show cable clock
DTI Client status: TCC 13
-----
Client status                : normal
Client clock type            : ITU type 1
Client firmware version      : 7
Client dti version           : 0
Client timestamp             : 657519453
Client phase correction       : 65535
Client normal time           : 65535
Client holdover time         : 0
Client transition t3 count    : 0
Client transition t4 count    : 1
Client transition t6 count    : 0
Client transition t7 count    : 0
Client port switch count      : 1
Client Integral Frequency Term : 64518
Client EFC Value              : 63282

DTI Client Port 1 Status:
-----
Port Status                  : Active
Signal detected               : yes
```

# show cable clock

```

CRC error count      : 2
Frame error rate     : < 2%
Cable advance        : 2560

-- Connected server information ---
Server status        : Active free-run
Root Server clock type : ITU type 3
Root Server source    : none
Server Type          : Root
Client Performance Stable : yes
Client Cable advance Valid : yes

```

## DTI Client Port 2 Status:

```

-----
Port Status          : Inactive
Signal detected      : no
CRC error count      : 66
Frame error rate     : > 5%
Cable advance        : 0

```

## DTI Client status: TCC 14

```

-----
Client status        : normal
Client clock type     : ITU type 1
Client firmware version : 7
Client dti version    : 0
Client timestamp      : 672169320
Client phase correction : 65535
Client normal time    : 65535
Client holdover time  : 0
Client transition t3 count : 0
Client transition t4 count : 1
Client transition t6 count : 0
Client transition t7 count : 0
Client port switch count : 1
Client Integral Frequency Term : 64760
Client EFC Value      : 63832

```

## DTI Client Port 1 Status:

```

-----
Port Status          : Inactive
Signal detected      : no
CRC error count      : 26
Frame error rate     : > 5%
Cable advance        : 0

```

## DTI Client Port 2 Status:

```

-----
Port Status          : Active
Signal detected      : yes
CRC error count      : 2
Frame error rate     : < 2%
Cable advance        : 1792

-- Connected server information ---
Server status        : Active free-run
Root Server clock type : ITU type 3
Root Server source    : none
Server Type          : Root
Client Performance Stable : yes
Client Cable advance Valid : yes

```

The following is sample output of a TCC card in slot 13 on a Cisco RF Gateway 10:

```
Router#show cable clock 13 client 1
DTI Client Port 1 Status:
-----
Port Status           : Inactive
Signal detected       : no
CRC error count       : 63006
Frame error rate      : > 5%
Cable advance         : 0x0000
```

Table 3-2 describes the significant fields shown in the display.

**Table 3-2** *show cable clock client Field Descriptions*

Field	Description
Port status	Indicates the current status of the DTI port on the TCC card.
Signal detected	Indicates whether the DTI signal was detected.
CRC error count	The number of cyclic redundancy check (CRC) errors. It can indicate intermittent upstream, laser clipping, or common-path distortion.

The following example shows the server status of the TCC card in slot 13 on a Cisco RFGW-10:

```
Router#show cable clock 13 server 2
TCC Card 13 port 2 DTI Server status:
-----
Server signal detected : yes
Server status          : free-run
Root Server clock type : ITU type 3
Root Server source     : none
Server Type            : Root
Client Performance Stable : yes
Client Cable advance Valid : yes
TOD Setting Mode       : Short
TOD gpssec             : 902825745
TOD leap seconds       : 14
```

Table 3-3 describes the significant fields shown in the display.

**Table 3-3** *show cable clock server Field Descriptions*

Field	Description
Server signal detected	Indicates whether the server was detected.
Server status	Indicates the state in which the server is functioning. The states are warm-up, free-run state, fast mode, normal, holdover, or bridge mode.
Root server source	The server source such as internal, external, GPS or none.
Root server clock type	The clock type. The types are 1, 2, 3 or ITU Stratum 3 or DTI Min. clock.
TOD setting mode	Displays the time (user time, NTP, GPS) mode such as short or long.

The following is a sample output showing the counters on TCC card 13 on Cisco RFGW-10:

```
Router#show cable clock 13 counters
TCC Card 13 DTI counters:
-----
Client Normal time           : 0x1EB6
Client Holdover time         : 0x0000
Client Phase Correction       : 0
Client Freq Correction        : 63213
Client EFC Correction         : 61039
Client transition count t3    : 0
Client transition count t4    : 1
Client transition count t6    : 0
Client transition count t7    : 0
Client port switch count     : 1
```

Related Commands

Command	Description
cable clock free-run	Allows the clock to be in free-run mode.
clear cable clock counters	Clears DTI client transition counters of a TCC DTI client and server.

# show cable depi-sessions

To display Downstream External PHY Interface (DEPI) sessions configured on the line card, use the **show cable depi-sessions** command in privileged EXEC mode.

**show cable depi-sessions** *mode* {**session-id** | **summary**}

<b>Syntax Description</b>	<b>mode</b>	Specifies the mode of the QAM channel: <ul style="list-style-type: none"> <li>• <b>L2TP</b>—Displays signalled DEPI sessions.</li> <li>• <b>Manual</b>—Displays manually configured DEPI sessions.</li> </ul>
	<b>session-id</b>	Displays detailed information on a specific DEPI session.
	<b>summary</b>	Displays a summary of all DEPI sessions configured

**Command Default** Information on configured DEPI sessions is displayed.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following is sample output for manual DEPI session 1 on the Cisco RF Gateway 10:

```
Router#show cable depi-sessions manual 1
Detailed Info about Session with id# 1:
```

```

Type                : MANUAL_DEPI_OVER_IP
Name                :
State               : IDLE
Remote id           : 0
DestIP addr         : 1.1.1.1
Qam slotid          : 3
Qam portid          : 1
Qam ch id           : 1
Payload type        : DEPI_PW_TYPE_D_MPT
Sync Mode           : ENABLE
Sync Intl           : 100
Up time             : 01:58:34
```

```

<< Session Statistic >>
Session is off      : 0
Broken seq num      : 0
Bad depi header     : 0
Bad MPEG sync byte : 0
In packet rate      : 0 pps
In bit rate         : 0 bps
Out bit rate        : 0 bps
```

■ **show cable depi-sessions**

```

<< Flow Statistic >>
Total packet      : 0
Total byte        : 0
Total segment     : 0
Discards          : 0
Errors            : 0
Bad pyld size     : 0
Cmnd buf ovfw     : 0

```

Table 3-4 describes the significant fields shown in the display.

**Table 3-4** *show cable depi-sessions manual Field Descriptions*

Field	Indicates the
Type	Mode of the DEPI session.
Name	Name given to the session.
State	State of the session.
Remote id	Remote ID of the session.
DestIP addr	Destination IP address of the DEPI.
Qam slotid	Slot on the QAM interface.
Qam portid	Port on the QAM slot.
Qam ch id	Channel on the QAM port.

The following example shows a summary of the manual DEPI sessions configured on a Cisco RF Gateway 10:

```

Router#show cable depi-sessions manual summary
List of the Configured Depi Sessions

```

ID	Type	State	Qam-info	PWtype
x-----	x-----	x-----	x-----	x-----
1	MANUAL_DEPI_OVER_IP	IDLE	Qam3/01.1	DMPT
11012	MANUAL_DEPI_OVER_IP	ACTIVE	Qam3/01.2	DMPT
11013	MANUAL_DEPI_OVER_IP	ACTIVE	Qam3/01.3	DMPT
30011	MANUAL_DEPI_OVER_IP	ACTIVE	Qam5/01.1	DMPT
30012	MANUAL_DEPI_OVER_IP	ACTIVE	Qam5/01.2	DMPT
30013	MANUAL_DEPI_OVER_IP	ACTIVE	Qam5/01.3	DMPT

Table 3-5 describes the significant fields shown in the display.

**Table 3-5** *show cable depi-sessions manual summaryField Descriptions*

Field	Indicates the
ID	ID of the sessions created.
Type	Type of the DEPI session.
State	State of the DEPI session.
Qam-info	Slot, port and channel of a QAM interface.
PW type	Cable mode of the QAM channel.



**Related Commands**

Command	Description
<code>cable mode</code>	Specifies the mode and usage of QAM channels.

# show cable depi-sessions slot count

To display the Downstream External PHY Interface (DEPI) session count on all QAMs on a line card, use the **show cable depi-sessions slot count** command in privileged EXEC mode.

**show cable depi-sessions slot** *slot* **count**

Syntax Description	slot	Displays DEPI sessions information for a slot.
	<i>slot</i>	Specifies the slot on the QAM interface. Valid slot number range is from 3 to 12.
	<b>count</b>	Displays the count of both Manual and L2tp sessions for all QAM channels on the linecard interface.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(50)SQ2	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following is sample output for DEPI session count on the Cisco RF Gateway 10:

```
Router#show cable depi-sessions slot 3 count
      QAM Port          Sessions
x-----x-----
Channel 3/1.1          1
Channel 3/1.2          1
Channel 3/1.3          1
Channel 3/1.4          1
```

[Table 3-4](#) describes the significant fields shown in the display.

**Table 3-6** *show cable depi-sessions slot count* Field Descriptions

Field	Description
QAM Port	Port on the QAM slot.
Sessions	Count of the DEPI sessions on the QAM port.

Related Commands	Command	Description
	<b>cable mode</b>	Specifies the mode and usage of QAM channels.

# show cable depi-sessions offset

To display the DOCSIS Timing Interface (DTI) timing value on the QAM channels, use the **show cable depi-sessions offset** command in privileged EXEC mode.

**show cable depi-sessions offset** [**port** *slot/port* | **slot** *slot*]

## Syntax Description

<b>port</b>	Displays the offset value at the port.
<i>slot/port</i>	Specifies the slot and the port of the line card. Valid slot range is 3 to 12. Valid port range is 1 to 12.
<b>slot</b>	Displays the offset value for the specified slot.
<i>slot</i>	Specifies the slot on the line card. Valid slot range is from 3 to 12.

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Examples

The following is sample output for DTI offset values configured on the chassis:

```
Router# show cable depi-sessions offset
Qam-info Offset
x-----x-----
Qam3/01.1 639
Qam3/01.2 640
Qam3/01.3 641
Qam3/01.4 642
Qam3/02.1 639
Qam3/02.2 640
Qam3/02.3 641
Qam3/02.4 642
```

Table 3-7 describes the significant fields shown in the display.

**Table 3-7** *show cable depi-sessions offset* Field Descriptions

Field	Description
Qam-info	Displays information about the QAM interface.
Offset	Displays the offset value configured.

## Related Commands

Command	Description
<b>cable depi offset</b>	Sets the offset value on the QAM channel for a line card in DEPI mode.

■ show cable depi-sessions offset

# show cable ermi errp

To display information on the ERMI Edge Resource and Registration protocol (ERRP) protocol, use the **show cable ermi errp** command in privileged EXEC mode.

**show cable ermi errp server** {*server-IP-address* | **all** | **resources** {*res-IP-address* | **all**} | **statistics**

## Syntax Description

<b>server</b>	Displays information of a specific ERRP server.
<i>server-IP-address</i>	ERRP server IP address.
<b>all</b>	Displays all information about the ERRP server.
<b>resources</b>	Displays all resources used by the ERRP server.
<i>res-IP-address</i>	Displays information of a particular resource used by the ERRP server.
<b>all</b>	Displays informatin of all resources used by the ERRP server.
<b>statistics</b>	Displays the ERRP statistics information.

## Command Default

This command is enabled by default.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Examples

The following example displays the ERRP server information:

```
Router# show cable ermi errp server all
ERRP Details:
Socket      : 1
Local       : 10.78.179.167:22350
Remote      : 10.78.179.170:6069
Timers      : Hold 90, Keepalive 0, ConnectRetry 10
FSM state   : CONNECT
QAM Partition : 1
Number of QAMs reachable : 0
```

[Table 3-8](#) describes the significant fields shown in the display.

**Table 3-8** *show cable ermi errp Field Descriptions*

Field	Description
Socket	Port connected to the ERRP server.
Local	Local IP address.
Remote	Remote IP address

**Table 3-8** *show cable ermi errp Field Descriptions (continued)*

Field	Description
FSM State	State of server.
QAM Partitoin	QAM Partition used by the protocol.
No of QAMs Reachable	No of QAM interfaces that use the server.

The following example displays the ERRP server statistics:

```
Router# show cable ermi errp statistics
```

ERRP Protocol Statistics:

Packet Type	Received Packets	Received Failed	Received Success	Sent Packets	Sent Failed	Sent Success
-----	-----	-----	-----	-----	-----	-----
OPEN	0	0	0	0	0	0
UPDATE	0	0	0	0	0	0
NOTIFICATION	0	0	0	0	0	0
KEEPALIVE	0	0	0	0	0	0
SOCKET	0	0	0	0	0	0
UNKNOWN	0	0	0	0	0	0

The following example displays the resources used by ERRP server:

```
Router# show cable ermi errp server resources all
```

```
ERRP Connection ID 1
QAM      Carrier
Interface ID
-----Total Resource
: 0
```

#### Related Commands

Command	Description
<b>clear cable ermi statistics</b>	Clears ERMI protocol connection statistics information.
<b>errp</b>	Configures Edge Resource and Registration protocol (ERRP) on the QAM partition.

# show cable ermi rtsp

To display information on the ERMI Real-time Streaming Protocol (RTSP) protocol, use the **show cable ermi rtsp** command in privileged EXEC mode.

**show cable ermi errp server** {*server-IP-address* | **all**} | **session** {*session-id* | **all**} | **statistics**

## Syntax Description

<b>server</b>	Displays RTSP server information
<i>server-IP-address</i>	Server IP address
<b>all</b>	Displays all information about the server.
<b>session</b>	Displays information about a RTSP session ID.
<i>session-id</i>	RTSP session ID. The valid range is from 0 to 4294967295.
<b>all</b>	Displays information about all RTSP sessions.
<b>statistics</b>	Displays the RTSP statistics information.

## Command Default

This command is enabled by default.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Examples

The following example displays all the server information:

```
Router# show cable ermi rtsp server all
```

```
Socket      Mgmt      Server      QP   RTSP   RTSP   Conn   Co
ID          Info      Info      ID   Session Req  Timeout Re
y
-----
-
```

[Table 3-8](#) describes the significant fields shown in the display.

**Table 3-9 show cable ermi errp Field Descriptions**

Field	Description
Socket ID	ID of the socket.
Mgmt Infol	Information about Management port.
Server Info	Information about the Server port.
QP ID	QAM partition ID.
RTSP session	No of RTSP sessions.

**Table 3-9** *show cable ermi errp Field Descriptions (continued)*

Field	Description
RTSP Req	RTSP request.
Conn timeout	Connection timeout interval.
Conn Retry	Connection retry interval.

The following example displays the RTSP server statistics:

```
Router# show cable ermi errp statistics
```

RTSP Protocol Statistics:

Packet Type	Received Packets	Received Failed	Received Success	Sent Packets	Sent Failed	Sent Success
SETUP	0	0	0	0	0	0
TEARDOWN	0	0	0	0	0	0
SET PARAMETER	0	0	0	0	0	0
GET PARAMETER	0	0	0	0	0	0
ANNOUNCE	0	0	0	0	0	0
SOCKET	0	0	0	0	0	0
UNKNOWN	0	0	0	0	0	0

The following example displays the RTSP session information:

```
Router# show cable ermi rtsp session all
```

```

Session      Session QP  QAM      QAM  RTSP  Server      Socket Session Ses
on Client
ID           Type    ID  Port   TSID  State  Addr(Socket)  Id    Index  Gro
Session ID
-----
Total Sessions: 0

```

[Table 3-10](#) describes the significant fields shown in the display.

**Table 3-10** *show cable ermi rtsp Field Descriptions*

Field	Descriptions
Session on Client ID	RTSP Client ID (MAC address).
Session Type	Type of session.
QAM ID	QAM partition ID assigned to server.
QAM Port	QAM port assigned to server.
RTSP State	State of RTSP server.
Server Address (Socket)	IP address of server.
Socket ID	TCP Socket ID.
Session Index	Session Index.
Session Group	Group of sessions.
Session ID	RTSP Session ID.
Total Sessions	Total no. of sessions.



**Related Commands**

Command	Description
<b>clear cable ermi statistics</b>	Clears ERMI protocol connection statistics information.
<b>rtsp</b>	Configures ERMI Real-time Streaming Protocol (RTSP) on the QAM partition.

# show cable freq-profile

To display frequency profiles created on the Cisco RFGW-10, use the **show cable freq-profile** command in privileged EXEC mode.

```
show cable freq-profile [all | freq-profile-id]
```

Syntax Description	all	Displays detailed information of all the frequency profiles on the Cisco RFGW-10.
	freq-profile-id	Displays detailed information of a specific frequency profile.

Command Default	Information on configured frequency profiles are displayed.
-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

Usage Guidelines	Use the <b>show cable freq-profile</b> command find out which frequency segment is occupied by the carriers, which part are not being used, and which portions cannot be used.
------------------	--

Examples	The following example displays the frequency profiles configured on the Cisco RFGW-10:
----------	--

```
Router# show cable freq-profile

Frequency Profile ID default-freq-profile:
  Lane 1 start-freq 88000000hz
    Block 1 start-freq 88000000hz
    Block 2 start-freq 136000000hz
    Block 3 start-freq 184000000hz
    Block 4 start-freq 232000000hz
  Lane 2 start-freq 280000000hz
    Block 1 start-freq 280000000hz
    Block 2 start-freq 328000000hz
    Block 3 start-freq 376000000hz
    Block 4 start-freq 424000000hz
  Lane 3 start-freq 472000000hz
    Block 1 start-freq 472000000hz
    Block 2 start-freq 520000000hz
    Block 3 start-freq 568000000hz
    Block 4 start-freq 616000000hz
  Lane 4 start-freq 664000000hz
    Block 1 start-freq 664000000hz
    Block 2 start-freq 712000000hz
    Block 3 start-freq 760000000hz
    Block 4 start-freq 808000000hz
```

```

Frequency Profile ID 20:
  Lane 1 start-freq 680000000hz
    Block 1 start-freq 680000000hz
    Block 2 start-freq 680000000hz
    Block 3 start-freq 680000000hz
    Block 4 start-freq 680000000hz
  Lane 2 start-freq 780000000hz
    Block 1 start-freq 780000000hz
    Block 2 start-freq 780500000hz
    Block 3 start-freq 780500000hz
    Block 4 start-freq 780099000hz
  Lane 3 start-freq 990000000hz
    Block 1 start-freq 994000000hz
    Block 2 start-freq 993000000hz
    Block 3 start-freq 993400000hz
    Block 4 start-freq 995400000hz
  Lane 4 start-freq 580000000hz
    Block 1 start-freq 679000000hz
    Block 2 start-freq 678000000hz
    Block 3 start-freq 678500000hz
    Block 4 start-freq 679500000hz

```

Table 3-11 describes the significant fields shown in the display.

**Table 3-11** *show cable freq-profile Field Descriptions*

Field	Description
Frequency Profile ID	Indicates the frequency profile ID.
Lane	Indicates the lane ID, and starting frequency of the lane.
Block	Indicates the block ID, and starting frequency of the block.

#### Related Commands

Command	Description
<b>cable downstream freq-profile</b>	Configures the frequency profiles on the Cisco RFGW-10.

# show cable heartbeat

To display the number of heartbeats received from the line cards, use the **show cable heartbeat** command in privileged EXEC mode.

**show cable heartbeat**

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows the heartbeat of the line cards:

Router#**show cable heartbeat**

Slot	Heartbeat Enabled	Heartbeat	Card State
		Received Count	
3	enabled	6183	ready
4	enabled	733519	ready
5	enabled	562516	ready
6	enabled	1423983	ready
7	enabled	1423001	ready
8	enabled	1423984	ready
9	enabled	1424010	ready
10	enabled	1423989	ready
11	enabled	197795	ready
12	enabled	562139	ready
13	enabled	1423949	ready
14	enabled	1423900	ready

Table 3-12 describes the significant fields shown in the display.

Table 3-12 show cable heartbeat Field Descriptions

Field	Specifies the
Slot	Slot on the chassis.
Heartbeat Enabled	Heartbeat enabled status. If no heartbeat is received, it indicates that the line card is reset. Note that heartbeat state must be enabled to receive heartbeats.

**Table 3-12** *show cable heartbeat Field Descriptions (continued)*

Field	Specifies the
Heartbeat Received Count	Number of heartbeats.
Card State	State of the line card.

**Related Commands**

Command	Description
<b>cable linecard reset</b>	Resets the line card on the chassis.

# show cable image-upgrade bundle

To display the upgraded images of all the devices on the Supervisor card, use the **show cable image-upgrade bundle** command in user EXEC or privileged EXEC mode.

## show cable image-upgrade bundle

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command has no default behavior or values.

**Command Modes** User EXEC (>)  
Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows the sample output using the **show cable image-upgrade bundle** command on the Cisco RF Gateway 10:

```
Router# show cable image-upgrade bundle
Image Name                               Id   Date       Time
=====
TCC_APP_00000000_20080811-00144654      00   20080811   00144654
TCC_ROM_00000001_20080317-00170141      01   20080317   00170141
TCC_GEN_00000002_20080612-00140709      02   20080612   00140709
TCC_DTI_00000003_20080428-00094708      03   20080428   00094708
TCC_RST_00000004_20080612-00140712      04   20080612   00140712
RFS_CPL_00000005_20080428-00105357      05   20080428   00105357
MV_APP_00000011_20080811-00144650      11   20080811   00144650
MV_ROM_00000012_20080605-00074654      12   20080605   00074654
MV_DIS_00000013_20080603-00151016      13   20080603   00151016
MV_COB_00000014_20080609-00205712      14   20080609   00205712
MV_YEL_00000015_20080609-00205659      15   20080609   00205659
MV_GWT_00000016_20080717-00162446      16   20080717   00162446
RFGW_GUI_00000017_20080603-00114822     17   20080603   00114822
```

Table 3-13 describes the significant fields shown in the display.

**Table 3-13** show cable image-upgrade bundle Field Descriptions

Field	Indicates the
Image Name	Name of images of all devices on Supervisor card.
Id	ID allotted to the image.
Date	Date when the image was created.
Time	Time when the image was created.

**Related Commands**

Command	Description
<b>cable-image upgrade download</b>	Upgrades the image on the specified line card.
<b>show cable-image upgrade status</b>	Displays the image upgraded status of the line card.
<b>show cable-image upgrade version</b>	Displays all the upgraded image versions on the line card.

# show cable image-upgrade status

To display the upgrade status for a line card, use the **show cable image-upgrade status** command in user EXEC or privileged EXEC mode.

**show cable image-upgrade status** *slot*

## Syntax Description

<i>slot</i>	Specifies the slot number of the line card. Valid ranges are from 3 to 12.
-------------	--

## Command Default

This command has no default behavior or values.

## Command Modes

User EXEC (>)  
Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Examples

The following example displays the upgrade status for the line card:

```
Router# show cable image-upgrade status 12
No current image upgrade is occurring on slot 12
```

## Related Commands

Command	Description
<b>cable-image upgrade download</b>	Upgrades the image on the specified line card.
<b>show cable-image upgrade bundle</b>	Displays the upgraded images of all the devices on the Supervisor card.
<b>show cable-image upgrade version</b>	Displays all the upgraded image versions on the line card.



# show cable image-upgrade version

To display the upgraded images on the line card, use the **show cable image-upgrade version** command in privileged EXEC and user EXEC mode.

**show cable image-upgrade version** *slot*

<b>Syntax Description</b>	<i>slot</i> Specifies the slot number of the line card. Valid slot range is from 3 to 12.
---------------------------	---

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	12.2(44)SQ                      This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows the output from the **show cable image-upgrade version** command:


```
Router# show cable image-upgrade version 3
Image Name                               Id  Date      Time
=====
MV_APP_00000011_20080811-00144650      11  20080811  00144650
MV_ROM_00000012_20080605-00074654      12  20080605  00074654
MV_DIS_00000013_20080603-00151016      13  20080603  00151016
MV_COB_00000014_20080609-00205712      14  20080609  00205712
MV_YEL_00000015_20080609-00205659      15  20080609  00205659
MV_GWT_00000016_20080717-00162446      16  20080717  00162446
```

Table 3-14 describes the significant fields shown in the display.

**Table 3-14**      **show cable image-upgrade version Field Descriptions**

Field	Indicates the
Image Name	Name of the image upgraded.
Id	ID allotted to the image.
Date	Date when image was upgraded.
Time	Time when image upgrade occurred.

## Related Commands

 show cable image-upgrade version

Command	Description
<b>cable-image upgrade download</b>	Upgrades the image on the specified line card.
<b>show cable-image upgrade bundle</b>	Displays the upgraded images of all the devices e on the Supervisor card.
<b>show cable-image upgrade status</b>	Displays the image upgraded status of the line card.

# show cable licenses

To view license information applied to QAM channels on the Cisco RFGW-10, use the **show cable licenses** command in the privileged EXEC mode.

**show cable licenses** [**all** | *lc-slot*]

## Syntax Description

<b>all</b>	Displays detailed information of all licenses Cisco RFGW-10.
<i>lc-slot</i>	Displays detailed information of a specific slot on the line card. Valid line cards are from 3 to 12.

## Command Default

Information on licenses are displayed.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

## Usage Guidelines

Use the **show cable license** command to view the licenses on the line cards on the Cisco RFGW-10 DS-384 line card.

The license on the Cisco RFGW-10 DS-384 line card is a count based license for available QAM channels. The Supervisor enforces the license after ensuring the number of unshut QAM channels in the running configuration does not exceed the license. If there are more QAM channels unshut, then the system shuts down the extra QAM channels. Depending on the running configuration, the first N licensed channels remain unshut, and the rest are shutdown.



### Note

This command does not display the license information for the Cisco RFGW-10 DS-48 line card.

## Examples

The following example displays the license information of all line cards on the Cisco RFGW-10:

```
Router# show cable licenses all

Slot 3 : License Configuration : DS384_384_CLEAR
-----
Feature: Downstream Licenses

Installed: 384 Consumed: 0   Available: 384 Forced-Shut: 0

Router#
```

Table 3-11 describes the significant fields shown in the display.

**Table 3-15** *show cable licenses Field Descriptions*

Field	Description
Slot	Indicates the slot on the Cisco RFGW-10.
License Configuration	Indicates the type of license.
Feature	Indicates whether the license is for downstream or upstream port.
Installed	Displays the currently active license count.
Consumed	Displays the number of un-shut channels used by the license.
Available	Displays the number of available un-shut channels allowed by the license.
Forced-Shut	Displays the number of un-shut channels not allowed by the license during a license downgrade. The channels are un-shut during a license upgrade.

# show cable linecard carrier-id-mapping

To display the carrier-id mapped to the line card, use the **show cable linecard carrier-id-mapping** command in privileged EXEC mode.

**show cable linecard carrier-id-mapping** *slot*

<b>Syntax Description</b>	<i>slot</i>	Specifies the line card on the Cisco RF Gateway 10. Valid range is from 3 to 14.
<b>Command Default</b>	This command has no default behavior or values.	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.
<b>Usage Guidelines</b>	QAM block information, QAM carrier mapped to line card, and maximum carriers assigned to the slot are displayed.	

**Examples**

The following example shows the carrier ID, and the QAM carriers on slot 9 on the Cisco RFGW-10 DS-48 line card:

Router# **show cable linecard carrier-id-mapping 9**

QAM Block 1 ID	Slot: 9 QAM Carrier	Maximum Carriers per Block: 24
1	9/1.1	
2	9/1.2	
3	9/1.3	
4	9/1.4	
5	9/2.1	
6	9/2.2	
7	9/2.3	
8	9/2.4	
9	9/3.1	
10	9/3.2	
11	9/3.3	
12	9/3.4	
13	9/4.1	
14	9/4.2	
15	9/4.3	
16	9/4.4	
17	9/5.1	
18	9/5.2	
19	9/5.3	
20	9/5.4	
21	9/6.1	
22	9/6.2	
23	9/6.3	
24	9/6.4	

QAM Block 2 ID	Slot: 9 QAM Carrier	Maximum Carriers per Block: 24
25	9/7.1	
26	9/7.2	
27	9/7.3	
28	9/7.4	
29	9/8.1	
30	9/8.2	
31	9/8.3	
32	9/8.4	
33	9/9.1	
34	9/9.2	
35	9/9.3	
36	9/9.4	
37	9/10.1	
38	9/10.2	
39	9/10.3	
40	9/10.4	
41	9/11.1	
42	9/11.2	
43	9/11.3	
44	9/11.4	
45	9/12.1	
46	9/12.2	
47	9/12.3	
48	9/12.4	

The following example shows the carrier ID , and the QAM carriers on slot 3 on the Cisco RFGW-10 DS-384 line card:

Router# **show cable linecard carrier-id-mapping 3**

QAM Block 1 ID	Slot: 3 QAM Carrier	Maximum Carriers per Block: 16
1	3/1.1	
2	3/1.2	
3	3/1.3	
4	3/1.4	
5	3/1.5	
6	3/1.6	
7	3/1.7	
8	3/1.8	
9	3/1.9	
10	3/1.10	
11	3/1.11	
12	3/1.12	
13	3/1.13	
14	3/1.14	
15	3/1.15	
16	3/1.16	
17	--	
18	--	
19	--	
20	--	
21	--	
22	--	
23	--	
24	--	
25	--	
26	--	
27	--	
28	--	
29	--	
30	--	
31	--	
32	--	
33	--	
34	--	
35	--	
36	--	
37	--	
38	--	
39	--	
40	--	
41	--	
42	--	
43	--	
44	--	
45	--	
46	--	
47	--	
48	--	
49	--	
50	--	
51	--	
52	--	
53	--	
54	--	
55	--	
56	--	

**show cable linecard carrier-id-mapping**

57	--
58	--
59	--
60	--
61	--
62	--
63	--
64	--
65	--
66	--
67	--
68	--
69	--
70	--
71	--
72	--
73	--
74	--
75	--
76	--
77	--
78	--
79	--
80	--
81	--
82	--
83	--
84	--
85	--
86	--
87	--
88	--
89	--
90	--
91	--
92	--
93	--
94	--
95	--
96	--
97	--
98	--
99	--
100	--
101	--
102	--
103	--
104	--
105	--
106	--
107	--
108	--
109	--
110	--
111	--
112	--
113	--
114	--
115	--
116	--
117	--
118	--
119	--
120	--



121	--
122	--
123	--
124	--
125	--
126	--
127	--
128	--
129	--
130	--
131	--
132	--
133	--
134	--
135	--
136	--
137	--
138	--
139	--
140	--
141	--
142	--
143	--
144	--
145	--
146	--
147	--
148	--
149	--
150	--
151	--
152	--
153	--
154	--
155	--
156	--
157	--
158	--
159	--
160	--
161	--
162	--
163	--
164	--
165	--
166	--
167	--
168	--
169	--
170	--
171	--
172	--
173	--
174	--
175	--
176	--
177	--
178	--
179	--
180	--
181	--
182	--
183	--
184	--

# show cable linecard carrier-id-mapping

```

185    --
186    --
187    --
188    --
189    --
190    --
191    --
192    --

```

```

QAM Block 2      Slot: 3      Maximum Carriers per Block: 0
  ID            QAM Carrier
-----

```

```

193    --
194    --
195    --
196    --
197    --
198    --
199    --
200    --
201    --
202    --
203    --
204    --
205    --
206    --
207    --
208    --
209    --
210    --
211    --
212    --
213    --
214    --
215    --
216    --
217    --
218    --
219    --
220    --
221    --
222    --
223    --
224    --
225    --
226    --
227    --
228    --
229    --
230    --
231    --
232    --
233    --
234    --
235    --
236    --
237    --
238    --
239    --
240    --
241    --
242    --
243    --
244    --

```

```

245      --
246      --
247      --
248      --
249      --
250      --
251      --
252      --
253      --
254      --
255      --
256      --
257      --
258      --
259      --
260      --
261      --
262      --

```

Table 3-16 describes the significant fields shown in the display.

**Table 3-16** *show cable linecard carrier-id mapping Field Descriptions*

Field	Description
QAM Block ID	Indicates the QAM block on the line card. First 24 carriers are QAM 1 for Cisco RFGW-10 DS-48 line card. First 192 carriers are QAM 1 for the Cisco RFGW-10 DS-384 line card.
Slot	Indicates the line card slot.
QAM carrier	Indicates all the carrier IDs associated to the QAM block.
Maximum carriers per block	Indicates the maximum carriers associated to the QAM block.

#### Related Commands

Command	Description
<b>cable linecard license max-carriers</b>	Creates the QAM carriers on the QAM port.
<b>cable carrier-id</b>	Auto-generated when the line card is inserted into to the Cisco RFGW-10 chassis. Applicable to both the Cisco RFGW-10 DS-48 and Cisco RFGW10-DS-384 line cards.

# show cable linecard coreinfo

To copy the core file information from line card flash directory to the bootflash, use the **show cable linecard coreinfo** command in privileged EXEC mode.

**show cable linecard coreinfo** *slot*

Syntax Description	<i>slot</i>	Specifies the line card and TCC card slots. Valid line card range is from 3 to 12 and valid TCC card slots are 13 and 14.
--------------------	-------------	---

Command Default	This command has no default behavior or values.
-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Usage Guidelines	This command copies the core files from line card flash directories to the bootflash with the line card identifier appended as a prefix and file creation time appended as a suffix to the core file information.
------------------	---

Examples	The following example shows the core files from slot 3 being copied onto the bootflash:
----------	---

```
Router#dir bootflash:
Directory of bootflash:/

 1  -rwx   12535060  Apr 12 2007 19:10:18 +00:00  cat4000-i9s-mz.122-25.EWA8.bin
 3  -rw-         5737  Sep 13 2007 12:54:26 +00:00  np_rfgw_run_913.cfg
 6  -rwx   26904132  Oct 23 2007 05:27:07 +00:00  cat4500-entservices-mz
 7  -rw-         6576  Mar 11 2008 02:48:36 +00:00  temp-1.cfg
 8  -rw-         8070  Oct 5 2008 04:28:25 +00:00  np-startup1.cfg
 9  -rw-   236964    Oct 21 2008 23:54:48 +00:00  slogs1

61341696 bytes total (9444684 bytes free)

Router#dir linecard-3-flash:
Directory of linecard-3-flash:/

720958 -rw-   4047732  Sep 29 2008 12:40:49 +00:00  mv_app.lc
720986 -rwx      74    Sep 29 2008 12:48:37 +00:00  update
1704275 -rw-   65536    Jan 1 1970 00:03:00 +00:00  mv_iu.core
2031738 -rw-   232833   Oct 24 2008 19:31:32 +00:00  slog_latest
1245266 -rw-   327881   Nov 3 2008 18:30:16 +00:00  AA
1573181 -rw-   77824    Nov 6 2008 01:29:35 +00:00  mv_video.core
1442197 -rw-   147603   Nov 7 2008 20:57:23 +00:00  AAA
```

```

131273  -rw-      385309  Nov 10 2008 20:54:58 +00:00  slogs1.text
1048865  -rw-      63617   Nov 10 2008 20:57:18 +00:00  slogs2.text
327848  -rw-      385309  Nov 10 2008 20:54:58 +00:00  slogs1_boot.text
458769  -rw-      63617   Nov 10 2008 20:57:18 +00:00  slogs2_boot.text
196793  -rw-      20036   Jan 1 1970 00:00:14 +00:00  slogs1_boot.txt
524465  -rw-      114208   Dec 9 2008 20:33:25 +00:00  slogs1

8126464 bytes total (1719532 bytes free)

Router#show cable linecard coreinfo 3
  Copying core file linecard-3-flash:mv_video.core to
bootflash:LC_3_mv_video.core_012935_6_Nov_2008

  Copying core file linecard-3-flash:mv_iu.core to
bootflash:LC_3_mv_iu.core_000300_1_Jan_1970

Router#dir bootflash:
Directory of bootflash:/

   1  -rwx      12535060  Apr 12 2007 19:10:18 +00:00  cat4000-i9s-mz.122-25.EWA8.bin
   3  -rw-         5737   Sep 13 2007 12:54:26 +00:00  np_rfgw_run_913.cfg
   6  -rwx      26904132  Oct 23 2007 05:27:07 +00:00  cat4500-entservices-mz
   7  -rw-         6576   Mar 11 2008 02:48:36 +00:00  temp-1.cfg
   8  -rw-         8070   Oct 5 2008 04:28:25 +00:00  np-startup1.cfg
   9  -rw-      236964   Oct 21 2008 23:54:48 +00:00  slogs1
  21  -rw-         77824   Dec 9 2008 20:33:51 +00:00  LC_3_mv_video.core_012935_6_Nov_2008
  22  -rw-         65536   Dec 9 2008 20:33:51 +00:00  LC_3_mv_iu.core_000300_1_Jan_1970

61341696 bytes total (9301068 bytes free)

```

Table 3-17 describes the significant fields shown in the display.


**Table 3-17 show cable linecard coreinfo Field Descriptions**

Field	Description
Copying core file line card	Shows the copying of the files to the bootflash directory.

#### Related Commands

Command	Description
<b>show cable linecard version</b>	Displays the version information for a line card.





**Table 3-18 show cable linecard cpuload Field Descriptions**

## Related Commands

Command	Description
<b>cable linecard reset</b>	Resets the line card on the Cisco RF Gateway 10.

# show cable linecard load-balancing-group

To display the load balancing groups created on the Cisco RFGW-10, use the **show cable line card load-balancing-group** command in privileged EXEC mode.

**show cable linecard slot load-balancing-group**

Syntax Description	slotLine card slot on the Cisco RFGW-10. Valid range is from 3 to14.
--------------------	--

Command Default	This command is disabled by default.
-----------------	--------------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

Usage Guidelines	Use the <b>show cable linecard load-balancing group</b> command to view the load balanced groups on the Cisco RFGW-10.
------------------	--

Examples	<p>The following example displays the load balancing groups on line card slot 3 on the Cisco RFGW-10:</p> <pre>Router# show cable linecard 3 load-balancing-group all</pre> <p>Slot : 3Load-balancing Group : 1 Total Bandwidth : 10000000 KBps Available Bandwidth : 10000000 KBps Reserved Bandwidth for QAM Based Sessions : 0 KBps Reserved Bandwidth for IP Based Sessions : 0 KBps</p> <p>Slot : 3Load-balancing Group : 2 Total Bandwidth : 10000000 KBps Available Bandwidth : 10000000 KBps Reserved Bandwidth for QAM Based Sessions : 0 KBps Reserved Bandwidth for IP Based Sessions : 0 KBps</p>
----------	---

Table 3-11describes the significant fields shown in the display.

Table 3-19 show cable linecard load-balancing-group Field Descriptions

Field	Description
Slot	Indicates the line card slot.
Load-balancing Group	Indicates the load balancing group.
Total Bandwidth	Indicates the total bandwidth.



**Table 3-19** *show cable linecard load-balancing-group Field Descriptions (continued)*

Field	Description
Available Bandwidth	Indicates the available bandwidth.
Reserved Bandwidth for QAM Based Sessions	Indicates reserved bandwidth for QAM session.
Reserved Bandwidth for IP Based Sessions	Indicates reserved bandwidth for IP sessions.

**Related Commands**

Command	Description
<b>cable downstream freq-profile</b>	Configures the frequency profiles on the Cisco RFGW-10.

# show cable linecard logical-qamid-mapping

To display the logical QAM group IDs and QAM carriers mapped to the RF profiles on the Cisco RFGW-10, use the **show cable linecard logical-qamid-mapping** command in privileged EXEC mode.

**show cable linecard logical-qamid-mapping** *lc-slot*

Syntax Description	<i>lc-slot</i> Line card slot on the Cisco RFGW-10. Valid range is from 3 to 14.				
Command Default	Information on mapped QAM group IDs and QAM carriers are displayed.				
Command Modes	Privileged EXEC (#)				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Cisco IOS-XE Release 3.2.0SQ</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.
Release	Modification				
Cisco IOS-XE Release 3.2.0SQ	This command was introduced.				

**Usage Guidelines**

Use the **show cable linecard logical-qamid-mapping** command to view the associated logical QAM groups and QAM carrier information.

Logical QAM groups are internally associated to RF profiles when the RF profile configuration is assigned to the QAM interface.

**Examples**

The following example displays the logical QAM IDs and carriers assigned to QAM interface 3 on the Cisco RFGW-10:

```
Router# show cable linecard logical-qamid-mapping 4

Slot: 4, Logical QAM Group ID 1:
  RF Profile ID : Remote-RF-Profile-14
  First Port    : Qam-red4/1
  Associated Qam Carrier ids:
    offset 0 - carrier-id 1 - Qam-red4/1.1
    offset 1 - carrier-id 2 - Qam-red4/1.2
  Second Port   : Qam-red4/2
    offset 4 - carrier-id 49 - Qam-red4/2.1
    offset 5 - carrier-id 50 - Qam-red4/2.2
Slot: 4, Logical QAM Group ID 2:
  RF Profile ID : Remote-RF-Profile-14
  First Port    : Qam-red4/3
  Associated Qam Carrier ids:
    offset 0 - carrier-id 97 - Qam-red4/3.1
    offset 1 - carrier-id 98 - Qam-red4/3.2
  Second Port   : Qam-red4/4
    offset 4 - carrier-id 145 - Qam-red4/4.1
    offset 5 - carrier-id 146 - Qam-red4/4.2
Slot: 4, Logical QAM Group ID 33:
```

```

RF Profile ID : Remote-RF-Profile-14
First Port    : Qam-red4/5
Associated Qam Carrier ids:
    offset 0 - carrier-id 193 - Qam-red4/5.1

```

Table 3-11 describes the significant fields shown in the display.

**Table 3-20 show cable linecard logical-qamid-mapping Field Descriptions**

Field	Description
Slot	Indicates the line card slot.
Logical QAM ID	Indicates the QAM ID.
RF Profile ID	Indicates RF profile ID associated to the logical QAM.
Annex	Indicates annex mode set to the RF profile.
First Port	Indicates the port of the QAM interface.
Associated Qam Carrier IDs	Indicates the QAM carriers associated with the RF profile.
Offset	Indicates the QAM offset within that group for the carrier.
Carrier ID	Indicates the QAM carrier ID.

#### Related Commands

Command	Description
<b>cable downstream rf-profile</b>	Configures the RF profiles on the Cisco RFGW-10.
<b>cable downstream lqam-group</b>	Creates a logical qam group on the Cisco RFGW-10.

# show cable linecard logs

To display the system log information of the line card at bootup, use the **show cable linecard logs** command in privileged EXEC mode.

**show cable linecard logs** *slot* { **all** | **slogs1** | **slogs1-boot** | **slogs2** | **slogs2-boot** }

## Syntax Description

<i>slot</i>	Specifies the line card slot. Valid range is from 3 to 12.
<b>all</b>	Displays log information of all line cards on the chassis.
<b>slogs1</b>	Displays log information of latest system log 1 file.
<b>slogs1-boot</b>	Displays log information of latest system log 1 file at boot up.
<b>slogs2</b>	Displays log information of latest system log 2 file.
<b>slogs2-boot</b>	Displays log information of latest system log 2 file at boot up.

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Usage Guidelines

The command may result in a lengthy output, if **all** option is used.

## Examples

The following example shows the log information for all line cards on the chassis:

```
Router#show cable linecard logs 3 all
More linecard-3-flash:slogs1.txt ...
Time           Sev Major Minor Args
Jan 01 00:00:11 6 10000 0 root >> process is up (restart max 3 times)
Jan 01 00:00:11 6 10000 0 root >> guardian 94217 waiting on source 94216
Jan 01 00:00:11 6 10000 0 root >> thread [tid: 2] child_monitor awaiting
signal
Jan 01 00:00:11 6 10000 0 root >> thread [tid: 3] daemon_monitor awaiting
event
Jan 01 00:00:11 6 10000 0 Active SUP: slot 1, mac 020000000100
Jan 01 00:00:11 5 14 0 tcpip starting
Jan 01 00:00:11 3 14 0 Using pseudo random generator. See "random" op
tion
Jan 01 00:00:13 6 10000 0 NPM: init
Jan 01 00:00:13 6 10000 0 NPM: options seat_id=0x02030000
Jan 01 00:00:13 6 10000 0 NPM: Seat ID 2030000
```

```

Jan 01 00:00:13    6 10000    0 NPM: Cell 2, EndPt 0
Jan 01 00:00:13    6 10000    0 NPM: Start resmgr: No error
Jan 01 00:00:13    6 10000    0 NCM: init
Jan 01 00:00:13    6 10000    0 NCM: Cell 1, EndPt 0
Jan 01 00:00:13    6 10000    0 NPM: Advert: en0, mac 02:00:00:00:03:00, mtu 15
14, cell 1, endPt 0, iface 0
Jan 01 00:00:13    6 10000    0 NCM: Module started
Jan 01 00:00:13    6 10000    0 NCM: Start resmgr: No error
Jan 01 00:00:13    6 10000    0 NCM: ncm_cipc_en: IPC master mac 02:00:00:00:01
:00

```

More linecard-3-flash:slogs2.txt ...

%Error opening linecard-3-flash:slogs2.txt (No such file or directory)

More linecard-3-flash:slogs1\_boot.txt ...

```

Time              Sev Major Minor Args
Jan 01 00:00:11    6 10000    0 root >> process is up (restart max 3 times)
Jan 01 00:00:11    6 10000    0 root >> guardian 94217 waiting on source 94216
Jan 01 00:00:11    6 10000    0 root >> thread [tid: 2] child_monitor awaiting
signal
Jan 01 00:00:11    6 10000    0 root >> thread [tid: 3] daemon_monitor awaiting
event
Jan 01 00:00:11    6 10000    0 Active SUP: slot 1, mac 020000000100
Jan 01 00:00:11    5     14    0 tcpip starting
Jan 01 00:00:11    3     14    0 Using pseudo random generator. See "random" op
tion
Jan 01 00:00:11    6 10000    0 NPM: init
Jan 01 00:00:11    6 10000    0 NPM: options seat_id=0x02030000
Jan 01 00:00:11    6 10000    0 NPM: Seat ID 2030000
Jan 01 00:00:11    6 10000    0 NPM: Cell 2, EndPt 0
Jan 01 00:00:11    6 10000    0 NPM: Start resmgr: No error
Jan 01 00:00:13    6 10000    0 NCM: init
Jan 01 00:00:13    6 10000    0 NCM: Cell 1, EndPt 0
Jan 01 00:00:13    6 10000    0 NPM: Advert: en0, mac 02:00:00:00:03:00, mtu 15
14, cell 1, endPt 0, iface 0
Jan 01 00:00:13    6 10000    0 NCM: Module started
Jan 01 00:00:13    6 10000    0 NCM: Start resmgr: No error
Jan 01 00:00:13    6 10000    0 NCM: ncm_cipc_en: IPC master mac 02:00:00:00:01
:00

```

More linecard-3-flash:slogs2\_boot.txt ...

Table 3-21 describes the significant fields shown in the display.

**Table 3-21** *show cable linecard logs Field Descriptions*

Field	Description
Time	Displays the time during which the log was recorded.
Sev	Indicates the severity of the issue logged.
Major Minor Args	Displays a short description of the issue.

#### Related Commands

Command	Description
<b>show cable linecard version</b>	Displays the version information for a line card.

# show cable linecard process

To display all the processes running on the line card, use the **show cable linecard process** command in privileged EXEC mode.

**show cable linecard process** *slot*

Syntax Description	<i>slot</i>	Specifies the slot on the Cisco RF Gateway 10. Valid range is from 3 to 14.
--------------------	-------------	---

Command Default	This command has no default behavior or values.
-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows the processes running on line card 3:

```
Router#show cable linecard process 3

pid      name                start
=====  =====
45066    io-net                1      Registered,Launched
81934    mv_iu                 1      Registered,Launched
81935    ipc_ping_server       1      Registered,Launched
81936    rfs                   1      Registered,Launched
81937    mv_cpuload            1      Registered,Launched
81938    mv_lcinfo             1      Registered,Launched
81939    mv_lcred              1      Registered,Launched
81940    mv_hw_ctrl            1      Registered,Launched
81941    mv_tsec_ctrl          1      Registered,Launched
81942    mv_depi               1      Registered,Launched
81943    mv_video              1      Registered,Launched
Total number of processes: 11
```

Table 3-22 describes the significant fields shown in the display.

**Table 3-22 show cable linecard process Field Descriptions**

Field	Description
pid	Displays the program identifier.
name	Displays the name of the process.
start counter	Displays how many times a process has been launched.
state	Displays the state of the process.

**Related Commands**

Command	Description
show cable linecard cpuload	Displays the CPU utilization information on the line card.

# show cable linecard version

To display image version information of the line card, use the **show cable linecard version** command in privileged EXEC mode.

**show cable linecard version** *slot*

Syntax Description	<i>slot</i>	Specifies the line card on the Cisco RF Gateway 10. Valid range is from 3 to 14.
--------------------	-------------	--

Command Default	This command has no default behavior or values.
-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Usage Guidelines	Software, hardware version information, and programmed flash image information are displayed for the line card.
------------------	---

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Examples	The following example shows the sample output of the <b>show cable line card version</b> command on a Cisco RF Gateway 10:
----------	--

```
Router#show cable linecard version 4

Application Upgrade Version: 12.2(20100116.00032134): MV_APP_00000011_20100116-0
0032645
Application Permanent Version: MV_APP_00000011_20081112-00144210
Rommon Version: 12.2(12.2.394): MV_ROM_00000012_20081111-00141240
Board rev ID: 0x0000000A

Discus Image version: MV_DIS_00000013_20080603-00151016
Discus FPGA 1st rev ID: 0x00420042
Discus FPGA 2nd rev ID: 0x00420042

Cobia Image version: MV_COB_00000014_20080807-00112745
Cobia FPGA 1st rev ID: 0x02560029
Cobia FPGA 2nd rev ID: 0x00230276

Yellowfin Image version: MV_YEL_00000015_20090319-00124021
Yellowfin FPGA 1st rev ID: 0x02260025
Yellowfin FPGA 2nd rev ID: 0x00240277

UPX Image version: MV_ZMR_00000018_20091217-00145848
Zimmer module: 0
    Cisco S/N:
    Cisco Part Number:
    Cisco PN Number:
```



```

Cisco Mfg Dev:
OEM Name: Vecima Networks Inc
OEM Serial Number: 2469876
OEM Part Number: 00020000
OEM HW Rev: 2
Mfg Test Software Version: S1.0.94.0
Production Status:
UI Version 3885
Zimmer module: 1
Cisco S/N:
Cisco Part Number:
Cisco PN Number:
Cisco Mfg Dev:
OEM Name: Vecima Networks Inc
OEM Serial Number: 2469846
OEM Part Number: 00020000
OEM HW Rev: 2
Mfg Test Software Version: S1.0.81.0
Production Status:
UI Version 3885
Zimmer module: 2
Cisco S/N:
Cisco Part Number:
Cisco PN Number:
Cisco Mfg Dev:
OEM Name: Vecima Networks Inc
OEM Serial Number: 2469854
OEM Part Number: 00020000
OEM HW Rev: 2
Mfg Test Software Version: S1.0.84.0
Production Status:
UI Version 3885

```

Table 3-23 describes the significant fields shown in the display.

**Table 3-23** *show cable linecard version Field Descriptions*

Field	Description
Rommon version	Displays the ROMMON version.

#### Related Commands

Command	Description
<b>show cable linecard cpload</b>	Displays the CPU utilization information.
<b>show cable linecard process</b>	Displays the processes running on the line card.

# show cable midplane ping statistics

To display the midplane ping statistics on the Cisco RFGW-10, use the **show cable midplane ping statistics** command in privileged EXEC mode.

```
show cable midplane ping statistics {all | slot lc_slot}
```

Syntax Description	<b>all</b>	Displays the midplane ping statistics of all line cards.
	<b>slot</b>	Displays the midplane ping statistics of a line card slot.
	<i>lc_slot</i>	Line card slot. The valid range is from 3 to 12.

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ4	This command was introduced.

**Usage Guidelines**

Midplane pings sent and pings received counters are cumulative. The downstream traffic functions normally as the ping received counter increments,

It might also be possible that the ping failed counter may display a non-zero value, though the downstream traffic functions normally.

**Examples**

The following example is a sample output of the **show cable midplane ping statistics all** command that displays the midplane ping information on all line cards:

```
Router# show cable midplane ping statistics all

Slot: 3
  Port   : 0
    Pings sent       : 36841
    Pings received   : 661
    Pings failed     : 36179
  Port   : 1
    Pings sent       : 36841
    Pings received   : 36841
    Pings failed     : 0

Slot: 11
  Port   : 0
    Pings sent       : 0
    Pings received   : 0
    Pings failed     : 0
  Port   : 1
    Pings sent       : 0
    Pings received   : 0
    Pings failed     : 0
```

Table 3-24 describes the significant fields shown in the display.

**Table 3-24** *show cable midplane ping statistics all Field Descriptions*

Field	Description
Slot	Line card slot.
Port	Internal Gigabit Ethernet interface on the line card.
Pings sent	Number of midplane pings sent by the line card.
Pings received	Number of midplane pings received by the Supervisor.
Pings failed	Number of midplane pings lost between the line card and the Supervisor.

#### Related Commands

Command	Description
<b>cable midplane ping</b>	Configures the midplane pings between the line card and the Supervisor on the Cisco RFGW-10.
<b>clear cable midplane ping statistics</b>	Clears the midplane ping statistics on the Cisco RFGW-10.

# show cable qam-partition

To display the QAM partition information on the line card, use the **show cable qam-partition** command in privileged EXEC mode.

```
show cable qam-partition { all | { partition-id | default } } { qam | route | sessions } | protocol { ermi | gqi }
```

## Syntax Description

<i>partition-id</i>	QAM partition ID. The valid range is from 1 to 50.
<b>all</b>	Displays all QAM partitions configured on the line card.
<b>default</b>	Displays the default QAM partitions.
<b>qam</b>	Displays the QAM channels on QAM partition.
<b>route</b>	Displays the input route used for the QAM partition.
<b>session</b>	Displays the video sessions on the QAM partition.
<b>protocol</b>	Displays QAM partitions using the same protocol
<b>ermi</b>	Displays QAM partitions used by the ERMI protocol.
<b>qam</b>	Displays QAM partitions used by the GQI protocol.

## Command Default

This command is enabled by default.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Examples

The following example displays the QAM partition information for Partition ID 3 on the line card:

```
Router# show cable qam-partition 3
```

```
QAM Partition : 3
Management IP address: 10.78.179.187
State :      active
Protocol :    gqi
Keepalive Timeout Period : 5 seconds
Number of Retry : 3
SDV Bindings Service : Not Available
MAC Address : 30e4.db04.8dc0
Reset Timeout Period : 5 seconds
```

```

Server                State
-----
10.78.179.150        disconnected

Total QAM carriers : 34
QAM      Carrier   Logical   External
Interface ID       QAM ID    Channel ID
-----
3/1.1      1           0         1
3/1.2      2           1         2
3/1.3      3           2         3
3/1.4      4           3         4
3/1.5      5           4         5
3/1.6      6           5         6
3/1.7      7           6         7
3/1.8      8           7         8
3/1.9      9           8         9
3/1.10     10          9        10
3/1.11     11          10       11
3/1.12     12          11       12
3/1.13     13          12       13
3/1.14     14          13       14
3/1.15     15          14       15
3/1.16     16          15       16
3/1.17     17          16       17
3/1.18     18          17       18
3/1.19     19          18       19
3/1.20     20          19       20
3/1.21     21          20       21
3/1.22     22          21       22
3/1.23     23          22       23
3/1.24     24          23       24
3/1.25     25          24       25

!

```

! [Table 3-25](#) describes the significant fields shown in the display.

**Table 3-25** *show cable qam-partition Field Descriptions*

Field	Description
QAM partition	QAM partition ID
Management IP address	Management IP address configured on the QAM partition.
State	State of the QAM partition.
Protocol	Protocol used on the QAM partition.
Keepalive Timeout Period	Keepalive time period in seconds
Number of retry	Number of connection retries.
MAC address	Cisco RFGW-10 MAC address in a GQI specific QAM partition.
Reset Timeout Period	Reset time period in seconds.
Server	Server IP address.
State	State of the video server.
Total QAM carriers	No of carriers on the QAM partition.
QAM interface	QAM interface associated with the QAM partition.
Carrier ID	QAM channel.

**Table 3-25** *show cable qam-partition Field Descriptions (continued)*

Field	Description
Logical QAM ID	Logical QAM ID.
External channel ID	External channel number for GQI protocol QAM partition.

The following example displays the default QAM partition information for QAM channels on the line card:

Router# **show cable qam-partition default qam**

```

QAM Partition : 0
Total QAM carriers : 34
QAM      Carrier      Logical
Interface ID          QAM ID
-----
3/3.1      65          64
3/3.2      66          65
3/3.3      67          66
3/3.4      68          67
3/3.5      69          68
3/3.6      70          69
3/3.7      71          70
3/3.8      72          71
3/3.9      73          72
3/3.10     74          73
3/3.11     75          74
3/3.12     76          75
3/3.13     77          76
3/3.14     78          77
3/3.15     79          78
3/3.16     80          79
3/3.17     81          80
3/3.18     82          81

```

The following example displays the default QAM partition information for input routes used by the QAM partition:

Router# **show cable qam-partition default route**

```

QAM Partition : 0
Total Routes : 4
Slot  LBG  Destination      Low   High   Reserved   Bandwidth   Ingress   Numbe
Id    Id    IP                UDP   UDP   Bandwidth  In-Use      Port      Sessi
-----
--
3     1     30.0.3.10         1     49260  1000000    3300        0         2
3     2     1.21.1.2          1     49260  1000000    0           0         0
3     2     40.0.1.10         1     65535  1000000    3300        0         2
7     1     192.168.11.2      1     65535  112500     0           0         0

```

Table 3-26 describes the significant fields shown in the display.

**Table 3-26** *show cable qam-partition default route Field Descriptions*

Field	Description
QAM Partition	Default QAM partition ID.
Total Routes	Routes used by the QAM partition.
Slot ID	Slot on the line card.
LBG ID	Load balancing group ID.
Low UDP	Low UDP value.
High UDP	Hig UDP value.
Reserved Bandwidth	Total bandwidth value.
Bandwidth In-Use	Used bandwidth value.
Ingress Port	Ingress port used by the QAM partition.
Number of Sessions	Total number of video sessions on the QAM partition.

The following example displays the default QAM partition information for video sessions used by the QAM partition:

```
Router# show cable qam-partition default sessions
QAM Partition : default
Total QAM carriers : 34
Slot Carrier QAM Session Session
Id Id Port Id Type
-----
3 65 3/3.1 205586432 VIDEO
3 65 3/3.1 205586433 VIDEO
3 66 3/3.2 205651971 VIDEO
3 66 3/3.2 205651972 VIDEO
```

The following example displays the default QAM partition information for ERMI protocol used by the QAM partition:

```
Router# show cable qam-partition protocol ermi

QAM Partition : 1
Management IP address: 10.78.179.167
State : active
Protocol : ermi
Keepalive Timeout Period : 5 seconds
Number of Retry : 3

ERRP Addr Domain : 0
ERRP Hold Time : 90 Seconds
ERRP Connect Time : 10 Seconds
ERRP Connect Retry : 0
ERRP Keepalive Time : 0 Seconds
ERRP Keepalive Retry : 0

RTSP Connect Time : 200 Seconds
RTSP Connect Retry : 0
RTSP Keepalive Time : 10 Seconds
RTSP Keepalive Retry : 0
RTSP Session Timeout : 10800 Seconds
```

# **show cable qam-partition**

```

Server          State
-----
10.78.179.170   disconnected

Total QAM carriers : 0

```

Table 3-27 describes the significant fields shown in the display.

**Table 3-27** *show cable qam-partition protocol ermi Field Descriptions*

Field	Descriptions
ERRP Hold Time	Hold time in seconds.
ERRP Connect Time	Connection time in seconds.
ERRP Connect Retry	Connection retry interval.
ERRP Keepalive Time	Keepalive time interval in seconds.
ERRP Keepalive Retry	Keepalive retry interval.
RTSP Connect Time	Connection time in seconds.
RTSP Connect Retry	Connection retry interval.
RTSP Keepalive Time	Keepalive time interval in seconds.
RTSP Keepalive Retry	Keepalive retry interval.
RTSP Session Timeout	Session timeout interval.

The following example displays the default QAM partition information for GQI protocol used by the QAM partition:

```
Router# show cable qam-partition protocol gqi
```

```

QAM Partition : 2
Management IP address: 10.78.179.185
State :        active
Protocol :     gqi
Keepalive Timeout Period : 5 seconds
Number of Retry : 3
SDV Bindings Service : Not Available
MAC Address : 30e4.db04.8dc1
Reset Timeout Period : 5 seconds

```

```

Server          State
-----
10.78.179.170   connected

```

```

Total QAM carriers : 32
QAM      Carrier   Logical   External
Interface ID      QAM ID    Channel ID
-----
3/2.1    33           32        1
3/2.2    34           33        2
3/2.3    35           34        3
3/2.4    36           35        4
3/2.5    37           36        5

```



The following example displays the default QAM partition information for all QAM partitions:

```
Router# show cable qam-partition all

QAM Partition : 1
Management IP address: 10.78.179.167
State :      active
Protocol :   ermi
Keepalive Timeout Period : 5 seconds
Number of Retry : 3

ERRP Addr Domain      : 0
ERRP Hold Time        : 90 Seconds
ERRP Connect Time     : 10 Seconds
ERRP Connect Retry    : 0
ERRP Keepalive Time   : 0 Seconds
ERRP Keepalive Retry  : 0

RTSP Connect Time     : 200 Seconds
RTSP Connect Retry    : 0
RTSP Keepalive Time   : 10 Seconds
RTSP Keepalive Retry  : 0
RTSP Session Timeout  : 10800 Seconds

Server                State
-----
10.78.179.170         disconnected

Total QAM carriers : 0

Total Routes: 1
Slot  LBG  Destination      Low   High   Reserved   Bandwidth   Ingress   Numb

Id    Id   IP                  UDP   UDP   Bandwidth  In-Use      Port      Sess
s
-----
--
3     1    1.1.1.1              1     65535  21         0           0         0

QAM Partition : 2
Management IP address: 10.78.179.185
State :      active
Protocol :   gqi
Keepalive Timeout Period : 5 seconds
Number of Retry : 3
SDV Bindings Service : Not Available
MAC Address : 30e4.db04.8dc1
Reset Timeout Period : 5 seconds

Server                State
-----
10.78.179.170         connected

Total QAM carriers : 32
QAM      Carrier   Logical   External
Interface ID      QAM ID    Channel ID
-----
3/2.1    33              32        1
3/2.2    34              33        2
3/2.3    35              34        3
3/2.4    36              35        4
3/2.5    37              36        5
3/2.6    38              37        6
```

# show cable qam-partition

3/2.7	39	38	7
3/2.8	40	39	8
3/2.9	41	40	9
3/2.10	42	41	10
3/2.11	43	42	11
3/2.12	44	43	12
3/2.13	45	44	13
3/2.14	46	45	14
3/2.15	47	46	15
3/2.16	48	47	16
3/2.17	49	48	17
3/2.18	50	49	18
3/2.19	51	50	19
3/2.20	52	51	20
3/2.21	53	52	21
3/2.22	54	53	22
3/2.23	55	54	23
3/2.24	56	55	24
3/2.25	57	56	25
3/2.26	58	57	26
3/2.27	59	58	27
3/2.28	60	59	28
3/2.29	61	60	29
3/2.30	62	61	30
3/2.31	63	62	31
3/2.32	64	63	32

Total Routes: 0  
 QAM Partition : 3  
 Management IP address: 10.78.179.187  
 State : active  
 Protocol : gqi  
 Keepalive Timeout Period : 5 seconds  
 Number of Retry : 3  
 SDV Bindings Service : Not Available  
 MAC Address : 30e4.db04.8dc0  
 Reset Timeout Period : 5 seconds

Server	State
10.78.179.150	disconnected

Total QAM carriers : 34

QAM Interface	Carrier ID	Logical QAM ID	External Channel ID
3/1.1	1	0	1
3/1.2	2	1	2
3/1.3	3	2	3
3/1.4	4	3	4
3/1.5	5	4	5
3/1.6	6	5	6
3/1.7	7	6	7
3/1.8	8	7	8
3/1.9	9	8	9
3/1.10	10	9	10
3/1.11	11	10	11
3/1.12	12	11	12
3/1.13	13	12	13
3/1.14	14	13	14
3/1.15	15	14	15
3/1.16	16	15	16
3/1.17	17	16	17

```

3/1.18      18          17          18
3/1.19      19          18          19
3/1.20      20          19          20
3/1.21      21          20          21
3/1.22      22          21          22
3/1.23      23          22          23
3/1.24      24          23          24
3/1.25      25          24          25
3/1.26      26          25          26
3/1.27      27          26          27
3/1.28      28          27          28
3/1.29      29          28          29
3/1.30      30          29          30
3/1.31      31          30          31
3/1.32      32          31          32
3/5.1       129         128         33
3/5.2       130         129         34

```

Total Routes: 3

Slot	LBG	Destination	Low	High	Reserved	Bandwidth	Ingress	Numb
Id	Id	IP	UDP	UDP	Bandwidth	In-Use	Port	Sess
3	1	0.0.0.0	0	0	34	0	20	0
3	1	10.1.1.1	1	65535	21	0	10	0
3	1	30.0.3.10	49261	65535	1000000	0	1	0

QAM Partition : 4

Management IP address: 10.78.179.184

State : active

Protocol : gqi

Keepalive Timeout Period : 5 seconds

Number of Retry : 3

SDV Bindings Service : Not Available

MAC Address : 30e4.db04.8dc2

Reset Timeout Period : 5 seconds

Server	State
10.78.179.150	disconnected

## Related Commands

Command	Description
<b>cable partition</b>	Associates the QAM partition to the QAM interface.
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.

# show cable qam-replication-group

To display the QAM Replication Group (QRG) information on the line card, use the **show cable qam-replication-group** command in privileged EXEC mode.

```
show cable qam-replication-group {qam-replication-group-id | all | slot slot-id}
```

Syntax Description	<i>qam-replication-group-id</i>	Specifies the QRG group ID. The valid range is from 1 to 3840.
	<b>all</b>	Displays all QRGs configured on the line card.
	<b>slot slot-id</b>	Specifies a slot on the line card.

Command Default	This command is enabled by default.
-----------------	-------------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

**Examples** The following example displays QRG information for group ID 3 on the line card:

```
Router# show cable qam-replication-group 10

QRG      Pilot Qam      Replicate Qams
-----
10       3/1.2                3/6.2, 3/8.2, 3/7.2
```

The following example displays QRG information for slot 8:

```
Router# show cable qam-replication-group slot 8

QRG      Pilot Qam      Replicate Qams
-----
3        8/1.1                8/2.1, 8/3.1
4        8/1.2                8/2.2, 8/3.2
```

The following example displays QRG information for all line cards:

```
Router# show cable qam-replication-group all

QRG      Pilot Qam      Replicate Qams
-----
1        3/1.1                3/6.1, 3/7.1, 3/8.1
3        8/1.1                8/2.1, 8/3.1
4        8/1.2                8/2.2, 8/3.2
10       3/1.2                3/6.2, 3/8.2, 3/7.2
11       3/1.3                3/6.3, 3/7.3, 3/8.3
```

Table 3-25 describes the significant fields shown in the display.

**Table 3-28** *show cable qam-replication-group Field Descriptions*

Field	Description
QRG	QAM replication group number.
Pilot Qam	Pilot Qam information.
Replicate Qams	Replicate Qam information.

#### Related Commands

Command	Description
<code>cable qam-replication-group</code>	Configures QAM Replication Group.

# show cable rf-profile

To display RF profiles created on the Cisco RFGW-10, use the **show cable rf-profile** command in privileged EXEC mode.

```
show cable rf-profile [all | profile-id]
```

Syntax Description	all	Displays information of all the RF profiles on the Cisco RFGW-10.
	profile-id	RF profile ID applied to the QAM channel on the line card.

Command Default	Information on configured RF profiles are displayed.
-----------------	--

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	Cisco IOS-XE Release 3.2.0SQ	This command was introduced.

Usage Guidelines	Use the <b>show cable rf-profile</b> command to view the mapping of the RF profiles with the QAM channels.
------------------	--

**Examples**

The following example displays the RF profiles configured on the Cisco RFGW-10:

```
Router# show cable rf-profile

RF Profile ID default-rf-profile is configured
  annex: B
  modulation: 64
  interleaver-depth options: I32-J4, I32-J4
  srate: 5056941
  remote: 0

RF Profile ID line 1 is configured
  annex: A
  modulation: 64
  interleaver-depth options: I12-J17, I12-J17
  srate: 3500000
  remote: 0

RF Profile ID line 10 is configured
  annex: A
  modulation: 256
  interleaver-depth options: I12-J17, I12-J17
  srate: 3500000
  remote: 0
```

Table 3-11 describes the significant fields shown in the display.

**Table 3-29 show cable rf-profile Field Descriptions**

Field	Description
RF Profile ID	Indicates the RF profile ID.
annex	Indicates the annex for the RF downstream channel.
modulation	Indicates the modulation level of the QAM.
Interleaver-depth options	Indicates the frequency interleaver depth on the QAM.
srate	Indicates the symbol rate configured on the QAM.
remote	Indicates the RF profile is remote.

**Related Commands**

Command	Description
<b>cable downstream rf-profile</b>	Configures the RF profiles on the Cisco RFGW-10.

# show cable service group

To display the service group information, use the **show cable service-group** command in privileged EXEC mode.

**show cable service-group {brief | detail} {all | name}**

## Syntax Description

<b>brief</b>	Displays summarized information about the service group.
<b>detail</b>	Displays detailed information about the service group.
<b>all</b>	Displays information about the all service group configured on the Cisco RFGW-10.
<b>name</b>	Displays information about the a particular service group.

## Command Default

This command has no default behavior or defaults.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

## Examples

The following example shows a summary of all the cable service groups configured on the Cisco RFGW-10:

```
Router# show cable service-group brief all

Service Group : servicegroup1
QAM Group                QAM Carriers
-----
qamgroup1                 4
qamgroup2                 3

Service Group : servicegroup2
QAM Group                QAM Carriers
-----
qamgroup3                 0
qamgroup4                 0

Total Qam Service Groups: 2
```

The following example shows output of the **show cable service-group brief name** command:

```
Router# show cable service-group brief name servicegroup1

QAM Service Group : servicegroup1

QAM Group                QAM Carriers
-----
qamgroup1                 4
```



qamgroup2

3

The following example shows output of the **show cable service-group detail name** command:

Router# **show cable service-group detail name servicegroup1**

Service Group : servicegroup1

Qam Group : qamgroup1

Slot	Carrier ID	Qam Group
3	1	qamgroup1
3	2	qamgroup1
3	3	qamgroup1
3	4	qamgroup1

Total QAM carriers : 4

Qam Group : qamgroup2

Slot	Carrier ID	Qam Group
3	5	qamgroup2
3	6	qamgroup2
3	7	qamgroup2

Total QAM carriers : 3

The following example shows output of the **show cable service-group detail all** command:

Router# **show cable service-group detail all**

Service Group : servicegroup1

Qam Group : qamgroup1

Slot	Carrier ID	Qam Group
3	1	qamgroup1
3	2	qamgroup1
3	3	qamgroup1
3	4	qamgroup1

Total QAM carriers : 4

Qam Group : qamgroup2

Slot	Carrier ID	Qam Group
3	5	qamgroup2
3	6	qamgroup2
3	7	qamgroup2

Total QAM carriers : 3

Service Group : servicegroup2

Qam Group : qamgroup3

Slot	Carrier ID	Qam Group
------	------------	-----------

Total QAM carriers : 0

Qam Group : qamgroup4

Slot	Carrier ID	Qam Group
------	------------	-----------

Total QAM carriers : 0

Router#

Table 3-30 describes the significant fields shown in the display.

**Table 3-30** *show cable service-group Field Descriptions*

Field	Description
Carrier ID	Carrier identifier.
Service Group	Service group name.
QAM group	QAM group name.
QAM carriers	QAM carriers associated to QAM group.

#### Related Commands

Command	Description
<b>cable service-group</b>	Configures a cable service group on the Cisco RFGW-10.
<b>qam-group</b>	Configures the QAM group in a cable service group.

# show cable video gqi

To display all the GQI video sessions information, use the **show cable video gqi** command in privileged EXEC mode.

**show cable video gqi** { **connection** | **sessions** | **statistics** } { **all** | **qam-partition** *partition-id* }

<b>Syntax Description</b>	<b>qam-partition</b> <i>partition-id</i>	QAM partition ID. The valid range is from 1 to 50.
	<b>all</b>	Information for all QAM partitions configured on the line card.
	<b>connection</b>	Connection information for the QAM partition.
	<b>sessions</b>	Session information for the QAM partition.
	<b>statistics</b>	Statistics information for the QAM partition.

**Command Default** This command has no default behavior or defaults.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS-XE Release 3.3.0SQ	This command was introduced.

**Examples** The following example shows all the GQI connection information on the line card:

```
Router# show cable video gqi connections all
```

Management Encryption IP Discovery	Server IP	Protocol Type	QP ID	Connection State	RPC Version	Resp Pending	Event Pending	Reset Indication
10.78.179.185	10.78.179.170	GQI	2	Connected	2	0	0	Acked
-	10.78.179.187	10.78.179.150	GQI	3	Disconnect	0	0	-
-	10.78.179.184	10.78.179.150	GQI	4	Disconnect	0	0	-
-								

Table 3-30 describes the significant fields shown in the display.

**Table 3-31 show cable video gqi connections Field Descriptions**

Field	Description
Management IP	Management IP address.
Server IP	GQI server IP address.

**Table 3-31 show cable video gqi connections Field Descriptions (continued)**

Field	Description
Protocol Type	Protocol on QAM partition.
Connection State	State of connection.
RPC Version	GQI Remote Procedure Call interface version.
Resp Pending	Number of responses that could not be sent to the requestor (USRM or DNCS).
Event Pending	Number of announcement events pending in the system waiting to be sent to the ERM (DNCS or USRM).
Reset indication	Indicates whether an acknowledgement has been received from the peer after the reset indication message is sent to the peer.
Encryption Discovery	Asynchronous message sent to USRM to inform type of encryption currently supported in Cisco RFGW-10.

The following example shows the GQI session information for all QAM partitions on the line card:

```
Router# show cable video gqi sessions all
```

QP Id	GQI Id	SCM Id	Session Type	Encryption Type	Current State
3	00 00 00 00 00 00 00 00 00 00 03	201785344	VOD	None	Clear Mode
3	00 00 00 00 00 00 00 00 00 00 08	201457668	VOD	PowerKey	Encrypted
2	D0 67 E5 F3 6E E7 00 5D 32 95	203489281	SDV	None	Clear Mode

Total Sessions for All QAM Partitions: 3

The following example shows how to create an encrypted session with no CA blob and verify that the session is created, but the gqi state is set to 'Waiting CA':

```
Router# show cable video gqi sessions all
```

QP Id	GQI Id	SCM Id	Session Type	Encryption Type	Current State
1	00 00 00 00 00 00 00 00 00 00 01	201457664	SDV	PowerKey	Waiting CA

Total Sessions: 1

The following example shows how to create a session with override and verify that the session is updated and session is active:

```
Router# show cable video session a
```

```
Slot:11 Lic-Enforcement module sent Simultaneous PKEY_N_DVB encryption to GQI11
Session QAM Stream Sess IP UDP Out Input Input Output PSI
Ctrl
ID Port Type Type Address Port Pgm Bitrate State State Rdy
State
-----
201457664 3/1.2 Remap SSM - - 1 2500320 ACTIVE OFF NO -
Total Sessions = 1
```

```
Router# show cable video gqi sessions all
```

QP Id	GQI Id	SCM Id	Session Type	Encryption Type	Current State
1	00 00 00 00 00 00 00 00 00 00 01	201457664	SDV	PowerKey	Encrypted

Total Sessions: 1

The following example shows the GQI session information on QAM partition ID 3 of the line card:

```
Router# show cable video gqi sessions qam-partition 3
```

QP Id	GQI Id	SCM Id	Session Type	Encryption Type	Current State
3	00 00 00 00 00 00 00 00 00 03	201785344	VOD	None	Clear Mode
3	00 00 00 00 00 00 00 00 00 08	201457668	VOD	PowerKey	Encrypted
Total Sessions for QAM Partition 3: 2					

Table 3-32 describes the significant fields shown in the display.

**Table 3-32** show cable video gqi sessions Field Descriptions

Field	Description
QP ID	QAM partition ID.
GQI ID	GQI session ID.
SCM ID	Session control manager ID.
Session Type	Type of session.
Encryption Type	Encryption type used.
Current State	Current state of session.
Total Sessions	Total number of sessions.

The following example shows the GQI statistics on QAM partition 3 on the line card:

Router# **show cable video gqi statistic qam 3**

Qam Partition 3 Statistics:

Unbind	Create Reset	Delete Shell	Create Encryption Session Indication	Delete Event Discovery	Insert Session Notification	Cancel Packet	Switch Packet	Bind Source
Success:	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0
Error:	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0
Total:	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0

Related Commands

Command	Description
<b>cable qam-partition</b>	Creates a QAM partition for video server on the Cisco RFGW-10 DS-384 line card.
<b>protocol</b>	Sets the control plane protocol of the QAM partition.

# show cable video label

To display the active video labels, use the **show cable video label** command in privileged EXEC mode.

**show cable video label** [*label*]

<b>Syntax Description</b>	<i>label</i> (Optional) Specifies the label name given to the video label.
---------------------------	--

<b>Command Default</b>	This command has no default behavior or values.
------------------------	---

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Usage Guidelines</b>	The command displays all the labels configured on the chassis.
-------------------------	--

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	12.2(50)SQ1	The output of the command is modified to display the filtered PIDs for pass-through video sessions.

**Examples**

The following example shows the video labels configured on the Cisco RFGW-10:

```
Router#show cable video label
```

```
Multicast Label: s1
```

```
Label Type: SSM
```

```
Label Sources: [1]
```

SRC ADDR	DST ADDR	BITRATE	JITTER
162.0.0.10	232.3.1.1	3750000	200

Current Active Src: 0

Label Output Streams: [2]

QAM	Program ID
10/1.1	1
10/7.1	1

```
Multicast Label: s2
```

```
Label Type: SSM
```

```
Label Sources: [1]
```

SRC ADDR	DST ADDR	BITRATE	JITTER
162.0.0.10	232.3.1.2	15000000	200

Current Active Src: 0

Label Output Streams: [2]

QAM	Program ID
10/1.1	2
10/7.1	2

The following example shows the PIDs filtered when filtering is configured for pass-through video sessions:

```
Router#show cable video label
```

```
Multicast Label ID: 2
```

```
Label Name: ssm0
```

```
Label Type: SSM
```

```
Label Sources: [3]
```

SRC ADDR	DST ADDR	BITRATE	JITTER
111.17.1.101	232.2.1.0	25000000	200

SRC ADDR	DST ADDR	BITRATE	JITTER
111.17.1.102	232.2.1.0	25000000	200

SRC ADDR	DST ADDR	BITRATE	JITTER
111.17.1.103	232.2.1.0	25000000	200

```
Filtered PIDs: [25]
```

```
00000101 00000102 00000103 00000104 00000105 00000106 00000107 00000108
00000109 00000110 00000111 00000112 00000113 00000114 00000115 00000116
00000117 00000118 00000119 00000120 00000200 00000201 00000202 00000203
00000800
```

```
MAP: 1
```

```
Current Active Src: 0
```

```
Label Output Streams: [1]
```

QAM	Program ID



3/7.1 -1

Table 3-33 describes the significant fields shown in the display.

**Table 3-33 show cable video label Field Descriptions**

Field	Description
Multicast Label	Name of the label.
Label Type	Whether it is an ASM label or an SSM label.
Label Sources	Source of the label.
SRC ADD	Source IP address.
DST ADDR	Destination IP address.
BITRATE	Amount of bandwidth allotted.
JITTER	Amount of Jitter allotted.
Filtered PIDs	Lists the PIDs that are dropped when PID filtering is configured for pass-through video sessions.
Current Active Src	Name of the active source.
Label Output Stream	Name of the output stream label.
QAM	QAM interface.
Program ID	Program Identifier (PID).

#### Related Commands

Command	Description
<b>asm</b>	Configures ASM video session definition.
<b>cable video labels</b>	Enters the cable video label configuration.
<b>cable video multicast</b>	Configures video multicast sessions on the QAM interface.
<b>ssm</b>	Configures SSM video session definition.

# show cable video multicast uplink

To display the multicast uplink interfaces, use the **show cable video multicast uplink** command in privileged EXEC mode.

```
show cable video multicast uplink [GigabitEthernet | TenGigabitEthernet interface/port]
```

Syntax Description	GigabitEthernet	Indicates the Gigabit Ethernet interface. Valid port range is 3 through 6, 13 and 14.
	TenGigabitEthernet	Indicates the 10 Gigabit Ethernet interface. Valid slots are 1 and 2.
	interface/port	Specifies the interface slot and port.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows all uplink interfaces configured on the Cisco RFGW-10:

```
Router#show cable video multicast uplink
Uplink Interface      Status  Allocated  Maximum    Allocated  Backup Interface
      Backup
                        Streams   Bandwidth  Bandwidth
      Activated
-----
TenGigabitEthernet1/1 UP        240        10000000   30240
```

Table 3-34 describes the significant fields shown in the display.

Table 3-34 show cable video multicast uplink Field Descriptions

Field	Description
Uplink Interface Backup Activated	Displays the status of the Uplink interface such as activated or deactivated.
Status	Displays the status of the interface such as up or down..
Allotted Streams	Specifies the number of allotted streams.
Maximum Bandwidth	Specifies the maximum amount of bandwidth for the specified interface
Allocated Bandwidth	Specifies the bandwidth allocated for that interface.
Backup Interface	Displays the name of the backup interface.

**Related Commands**

Command	Description
<b>cable video multicast uplink</b>	Configures an uplink port for multicast traffic.
<b>ip multicast-routing</b>	Enables multicast routing on the Cisco RFGW-10.

# show cable video packet

To display the video insertion packet information, use the **show cable video packet** command in privileged EXEC mode.

```
show cable video packet {qam | qam-red slot/port.channel [stream stream-id] | all | slot slot}
```

Syntax Description	qam	Specifies the QAM interface on the Cisco RFGW-10.
	qam-red	Specifies the QAM interface when line card redundancy is configured on the Cisco RFGW-10.
	slot	Specifies the slot on the QAM interface. Valid range is from 3 to 12.
	port	Specifies the port on the interface. Valid range is from 1 to 12.
	channel	(Optional) Specifies the channel on the port. Valid range is from 1 to 4.
	stream	(Optional) Specifies packet stream insertion information.
	stream-id	(Optional) Specifies the packet stream identifier. Valid range is from 1 to 4294967295.
	all	Displays a summary of the packet insertion on the chassis.
	slot	Displays packet insertion for a slot.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

Examples

The following example shows the video packets on a QAM interface 3:

```
Router#show cable video packet qam-red 3/1.1
```

Packet	Times	Actual	Insert	Num Pkts		
Stream ID	Interface	Version	Repeat	Repeated	Rate (bps)	Inserted State
1	Qam3/1.1	1	Continuos	14460	1000	1 ON

Table 3-35 describes the significant fields shown in the display.

Table 3-35 show cable video packet Field Descriptions

Field	Description
Packet Stream ID	Packet stream identifiers of the video packets.
Interface	QAM channel or QAM subinterface.
Version	Version of video packets.

**Table 3-35** *show cable video packet Field Descriptions (continued)*

Field	Description
Times Repeat	Packets repetition state such as continuos.
Actual Repeated	The number of times the packets are repeated.
Insert rate	Rate at which packets are inserted.
Num pkts inserted	Number of packets inserted.
State	Displays the status of the packets whether on or off.

# show cable video route

To display video route information, use the **show cable video route** command in privileged EXEC mode.

**show cable video route** { **multicast** | **unicast** } { **all** | **slot** *slot* }

<b>Syntax Description</b>	<b>multicast</b>	Displays information for multicast routes.
	<b>unicast</b>	Displays information for unicast routes.
	<b>all</b>	Displays information on all routes on the chassis.
	<b>slot</b>	Displays information of a slot on the line card.
	<i>slot</i>	Specifies the slot on the line card. Valid range is from 3 to 12.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ. The <b>qam-domain</b> is <i>not</i> supported. The <b>unicast</b> keyword is removed. Use <b>show cable linecard load-balancing group</b> command to view unicast video sessions

**Examples** The following example displays all the multicast routes configured on the chassis:

```
Router#show cable video route multicast all
Source          Group          rx-interface          tx-qamblock          Sessions
-----
162.0.0.10      232.3.1.1      TenGigabitEthernet1/1 qam 10/1-6          1
162.0.0.10      232.3.1.2      TenGigabitEthernet1/1 qam 10/1-6          1
162.0.0.10      232.3.1.3      TenGigabitEthernet1/1 qam 10/1-6          1
162.0.0.10      232.3.1.4      TenGigabitEthernet1/1 qam 10/1-6          1
162.0.0.10      232.3.1.5      TenGigabitEthernet1/1 qam 10/1-6          1
```

[Table 3-33](#) describes the significant fields shown in the display.

**Table 3-36 show cable video route Field Descriptions**

<b>Field</b>	<b>Description</b>
Source	Source IP address.
Group	Group IP address.

**Table 3-36** *show cable video route Field Descriptions (continued)*

Field	Description
rx-interface	Multicast interfaces.
tx-qamblock	QAM block on a slot.
Sessions	Number of sessions.
Route Type	Type of route configured.

**Related Commands**

Command	Description
<b>video route</b>	Configures the video route on the line card.

# show cable video server-group

To display information on a video server group, use the **show cable video server-group** command in privileged EXEC mode.

```
show cable video server-group {all | mapping | name group_name}
```

Syntax Description	<b>all</b>	Displays all the server groups configured on a line card.
	<b>mapping</b>	Displays external and internal session mapping.
	<b>name</b>	Displays the information of a server group.
	<i>group_name</i>	Specifies a server group.

**Command Default** This command has no default values or behavior.

**Command Modes** Privileged EXEC (#)

Command History	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** This command is used to view all the server groups configured on a line card.

**Examples** The following example displays information on all server groups configured on the line card:

```
Router#show cable video server-group all
Server-Group :    gqi1
State :          ACTIVE
Protocol :       GQI
Timeout Period :  5 seconds
Number of Retry  : 3
Server[0] :      172.22.23.161

Management IP :   172.22.22.181   Port : 844   Mac Id : 0017.94fe.a9c0

Server           State           Reset Pending
                Indication       Requests
-----
172.22.23.161   Connected       In-progress       0

Server-Group :    GQI
State :          NON-ACTIVE
Protocol :       GQI Emulation
Emulation Type :  24-qam
Timeout Period :  5 seconds
Number of Retry  : 3
Server[0] :      56.1.1.11
Management IP :   56.1.1.101   Port : 0   Mac Id : 001a.a2ff.0d03
QAM Interfaces :  5/1.1-5/6.4
```



Table 3-37 describes the significant fields shown in the display.

**Table 3-37 show cable video server-group Field Descriptions**

Field	Description
Server-Group	Specifies the name of the server group.
State	Indicates whether the group is active or non-active.
Protocol	Indicates the protocol configured on the server group.
Timeout Period	Indicates the time period for a time out.
Number of Retry	Indicates the number of retries.
Server	Indicates the IP address of the external server. IP address must be configured for the GQI protocol.
Management IP	IP address of the management port of the server configured on the server group.
Port	Specifies the port number.
Mac Id	Specifies the MAC address of the server.
QAM Interfaces	Specifies the QAM interfaces.

#### Related Commands

Command	Description
<b>cable video servers</b>	Configures external control server groups on the line card.

# show cable video session

To display the video session information, use the **show cable video session** command in privileged EXEC mode.

```
show cable video session [{Qam qam-interface-number | Qam-red qam-interface-number | all}
[brief [filter] | summary]] | id session-id-number [in | out] [psi | stats] | local {Qam
qam-interface-number | Qam-red qam-interface-number | all | slot slot} | remote {Qam
qam-interface-number | Qam-red qam-interface-number | all | ermi | gqi | slot slot} | slot [brief
[filter] | count | summary]
```

## Syntax Description

<b>Qam</b>	Displays information on video session configured on a QAM interface.
<b>Qam-red</b>	Displays the video session configured on a QAM interface with line card redundancy.
<i>qam_interface_number</i>	Indicates the interface number of the QAM. <ul style="list-style-type: none"> <li>• <i>slot</i>: Specifies the slot of the QAM interface. Valid range is from 3 to 12.</li> <li>• <i>port</i>: Specifies the port on the slot. Valid range is from 1 to 12.</li> <li>• <i>channel</i>: Specifies the channel on the QAM. Valid range is from 1 to 4</li> </ul>
<b>all</b>	Displays information of all video sessions configured on the chassis.
<b>summary</b>	(Optional) Displays a summary of all the video sessions configured on the chassis.
<b>brief</b>	(Optional) Displays brief video information.
<i>filter</i>	(Optional) Filters the information using the following criteria: <ul style="list-style-type: none"> <li>• <b>active</b>—Shows the active sessions present.</li> <li>• <b>asm</b>—Shows the ASM video sessions.</li> <li>• <b>blocked</b>—Shows blocked video sessions.</li> <li>• <b>data</b>—Shows sessions with the data-piping processing type.</li> <li>• <b>idle</b>—Shows idle sessions.</li> <li>• <b>off</b>—Shows off sessions.</li> <li>• <b>passthru</b>—Shows sessions with the pass-through processing type.</li> <li>• <b>psi</b>—Shows packet stream identifiers of video sessions.</li> <li>• <b>remap</b>—Shows remapped video streams.</li> <li>• <b>shell</b>—shows video sessions in shell.</li> <li>• <b>ssm</b>—Shows SSM video sessions.</li> <li>• <b>udp</b>—Shows the UDP port.</li> </ul>
<b>id</b>	Displays video session information for a session ID.
<i>session-id-number</i>	Specifies the ID of a particular session. Valid session IDs are 1 and 2.
<b>in</b>	(Optional) Displays input session information.
<b>out</b>	(Optional) Displays output session information.
<b>psi</b>	(Optional) Displays detailed Program Specific Information (PSI) video session information with program table.

<b>stats</b>	(Optional) Displays detailed video session
<b>slot</b>	Displays video sessions information for a slot.
<i>slot</i>	Specifies the slot on the QAM interface. Valid slot number range is from 3 to 12.
<b>ermi</b>	Displays video session information for ERMI sessions.
<b>gqi</b>	Displays video session information for GQI sessions.
<b>count</b>	(Optional) Displays the session count for all QAM channels on the line card interface.
<b>local</b>	Displays local video sessions.
<b>remote</b>	Displays remote video sessions.

**Command Default**

This command has no default behavior or values.

**Command Modes**

Privileged EXEC (#)

**Command History**

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
12.2(50)SQ2	This command was modified. The <b>count</b> keyword was added.
Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ. <b>qam-domain</b> is <i>not</i> supported. The <b>local</b> and <b>remote</b> keywords are added.

**Examples**

The following example shows the video sessions configured on 3/1.1 QAM interface:

```
Router# show cable video session qam 3/1.1
```

Session ID	QAM Port	Stream Type	Sess Type	UDP Port	Out Pgm	Input Bitrate	Input State	Output State	PSI Rdy	Ctrl State
1	3/1.1	Remap	UDP	500	10	0	OFF	ON	NO	-
2	3/1.1	Remap	UDP	50000	20	0	OFF	ON	NO	-
3	3/1.1	Remap	UDP	7000	30	0	OFF	ON	NO	-

Total Sessions = 3

The following example shows the video sessions configured on the chassis:

```
Router# show cable video session all
```

Session ID	QAM Port	Stream Type	Sess Type	IP Address	UDP Port	Out Pgm	Input Bitrate	Input State	Output State
201392176	3/3.1	Remap	UDP	192.168.11.254	49152	1	2652807	ACTIVE	ON
YES	-	-	-	-	-	-	-	-	-
201392177	3/3.1	Remap	UDP	192.168.11.254	49153	2	2652777	ACTIVE	ON
YES	-	-	-	-	-	-	-	-	-

### show cable video session

```

201392178 3/3.1 Remap UDP 192.168.11.254 49154 3 2652761 ACTIVE ON
YES -
201392179 3/3.1 Remap UDP 192.168.11.254 49155 4 2652756 ACTIVE ON
YES -
201392180 3/3.1 Remap UDP 192.168.11.254 49156 5 2650350 ACTIVE ON
YES -
201457717 3/3.2 Remap UDP 192.168.11.254 49158 7 2650349 ACTIVE ON
YES -
201457718 3/3.2 Remap UDP 192.168.11.254 49159 8 2650291 ACTIVE ON
YES -
201457719 3/3.2 Remap UDP 192.168.11.254 49160 9 2648961 ACTIVE ON
YES -
201457720 3/3.2 Remap UDP 192.168.11.254 49161 10 2648889 ACTIVE ON
YES -
Total Sessions = 8

```

The following example shows the detailed summary of video sessions configured on the chassis:

Router#**show cable video session all summary**

Video Session Summary for Chassis:

```

Active      : 0      Init       : 0      Idle        : 0
Off         : 3      Blocked    : 0      PSI-Ready   : 0
UDP         : 3      ASM        : 0      SSM         : 0
Remap       : 3      Data       : 0      Passthru    : 0
Shell       : 0      Bound      : 0
Total Sessions: 3
Total Measured Bitrate : 0 bps

```

The following example shows information about video sessions configured on the chassis:

Router# **show cable video session all brief**

Session ID	QAM Port	Stream Type	Sess Type	UDP Port	Out Pgm	Input Bitrate	Input State	Output State	PSI Rdy	Ctrl State
1	3/1.1	Remap	UDP	500	10	0	OFF	ON	NO	-
2	3/1.1	Remap	UDP	50000	20	0	OFF	ON	NO	-
3	3/1.1	Remap	UDP	7000	30	0	OFF	ON	NO	-

Total Sessions = 3

Table 3-38 describes the significant fields shown in the display.

**Table 3-38 show cable video session all Field Descriptions**

Field	Description
Session ID	Represents the internal ID allocated by the chassis to the output stream of the input session.
QAM Port	Indicates the QAM interface or QAM subinterface.
Stream Type	Indicates the transport stream.
IP address	Session IP address
Session Type	Indicates the video session type.
UDP Port	Indicates the UDP port.
Output Program	Indicates the Single ProgramTransport Stream (SPTS) or Multiple ProgramTransport Stream (MPTS) program number.
Input Bitrate	Indicates the actual bitrate measured on the input.

**Table 3-38** *show cable video session all Field Descriptions (continued)*

Field	Description
Input State	Indicates the state on the input.
Output State	Indicates the state on the output.
PSI Rdy	Indicates the PSI ready state.
Ctrl State	Indicates the controller state.

The following example shows the detailed video session configuration on the line card:

Router# **show cable video session id 201392130**

```

INPUT Source      : 201392130
  Created On      : 04:41:10 AM
  Uptime [SUP]    : 04:41:10 AM
  Data State      : ACTIVE, PSI,
  Config Bitrate  : 3000000 bps
  Jitter          : 200 ms
  Stream Type     : SPTS
  Stream Rate     : VBR
  PID Remap       : ENABLED
  Source IP       : 0.0.0.0
  Source UDP      : 0
  Destination IP  : 30.0.3.10
  Destination UDP : 49261
  Idle Timeout    : 250 msec
  Init Timeout    : 1000 msec
  Off Timeout     : 60 seconds

```

PID Filter [0] :

Input PSI Info:

```

PAT Info:
Ver 2, TSID 1, len 16, section 0/0
  Prog 1: pmt 16
PMT Info:
Ver 2, program 1, pcr pid 17, len 32
  Type 2, PID 17, len 0
  Type 129, PID 20, len 6 (desc 10, len 4)

```

```

Elapsed time [LC]: 0 days 17 hours 48 min 52 secs
IP Packets: In: 17879939, Drop: 0
TP Packets: In: 125159573, PCR: 1782371, Non-PCR: 117297535, PSI: 264196, NU
: 5682013, Filtered: 0, Unreferenced: 133458
  Sync-Loss: 0, Dis-continuous: 0, CC Errors: 18, PCR Jump: 826, Id
: 0
Measured Bitrate 2998635 (0 min 3159570 max) bps, stay 169 ms, jitter 34 ms
PCR Bitrate 3000092 (600014 min 0 max) bps, stay 169 ms, jitter 34 ms
Idle Count: 0, Total Idle Time: 0 sec

```

Output Session: 201392130:

```

SPTS PGM Number: 3111
Data State      : PSI,
Control State   : ACTIVE
QAM             : 3/1.1
QAM-partition   : 3

```

Output PSI Info (Carrier ID 1):

PAT Info for Pgm Num 3111:

**show cable video session**

```

Ver 1, TSID 311, len 16, section 0/0
  Prog 3111: pmt 352
PMT Info for Pgm Num 3111:
Ver 0, program 3111, pcr pid 353, len 32
  Type 2, PID 353, len 0
  Type 129, PID 354, len 6 (desc 10, len 4)

Elapsed time [LC]: 0 days 17 hours 48 min 53 secs
TP Packets: PCR: 4, Non-PCR: 215, PSI: 2, New PAT: 1, New PMT: 1
             Drop: 0, Info-Err: 0, Inv-Rate: 0, Output Adjust: 0
             Overruns: 0, Overdue Drop 0, Under-Flow: 0, Over-Flow: 0

```

The following example shows the cable video session information for session ID 2:

```

Router# show cable video session id 2 in psi

Session PAT:  Ver 0, TSID 1, len 16, section 0/0
              Prog 1: pmt 500

Session PMT:  Ver 0, program 1, pcr pid 481, len 43

              Type 3, PID 482, len 6 (desc 10, len 4)
              Type 129, PID 483, len 6 (desc 10, len 4)
              Type 2, PID 481, len 0

```

The following example shows detailed video session statistics:

```

Router# show cable video session id 2 in stats

Elapsed time [LC]: 14142 days 22 hours 52 min 41 secs
IP Packets: In: 0, Drop: 0
TP Packets: In: 0, PCR: 0, Non-PCR: 0, PSI: 0, NULL: 0, Unreferenced: 0
              Sync-Loss: 0, Dis-continuous: 0, CC Errors: 0, PCR Jump: 0, Idle: 0
Measured Bitrate 0 (0 min 0 max) bps, stay 0 ms, jitter 0 ms
PCR Bitrate 0 (0 min 0 max) bps, stay 0 ms, jitter 0 ms
Idle Count: 0, Total Idle Time: 0 sec

```

The following example shows the session count on all QAMs on the line card in slot 9:

```

Router# show cable video session slot 9 count

QAM Port          Sessions
x-----x-----
Channel 9/1.1      2
Channel 9/1.2     10

```

Table 3-39 describes the significant fields shown in the display.

**Table 3-39** *show cable video session id Field Descriptions*

Field	Description
Elapsed time	Indicates the session time elapsed in days, hours, minutes, and seconds.
IP packets	Indicates the number of IP packets used and dropped.
TP packets	Indicates the number of transport packets that are program clock referenced, known and unknown bitrates, unreferenced, discontinuous, and idle.

**Table 3-39** *show cable video session id Field Descriptions*

Field	Description
Measured Bitrate	Indicates the size of the video stream. Standard definition (SD) video programs have bitrates from 62.5 kbps to 15 Mbps, high definition (HD) video programs have bitrates from 6 to 20 Mbps, and music programs have bitrates of 128 to 384 kbps. 32 SD programs, or 4 HD programs per QAM channel.
PCR Bitrate	Indicates the known bitrate size of the video stream.
Idle count	Indicates the number of times the line card is idle. When the input session enters into the IDLE state, an update is sent to the Supervisor card.
QAM Port	Indicates the QAM channel on a linecard.
Sessions	Indicates the session count on a QAM channel.

The following example shows the video sessions configured on QAM domain 1:

Router# **show cable video session qam-domain 1 brief remap**

Session ID	QAM Port	Stream Type	Sess Type	UDP Port	Out Pgm	Input Bitrate	Input State	Output State	PSI Rdy	Ctrl State
1	3/1.1	Remap	UDP	500	10	0	OFF	ON	NO	-
2	3/1.1	Remap	UDP	50000	20	0	OFF	ON	NO	-
3	3/1.1	Remap	UDP	7000	30	0	OFF	ON	NO	-

The following example displays the local sessions on the line card:

Router# **show cable video session local all**

Session ID	QAM Port	Stream Type	Sess Type	IP Address	UDP Port	Out Pgm	Input Bitrate	Input State	Output State
201392176	3/3.1	Remap	UDP	192.168.11.254	49152	1	2643442	ACTIVE	ON
YES -									
201392177	3/3.1	Remap	UDP	192.168.11.254	49153	2	2643398	ACTIVE	ON
YES -									
201392178	3/3.1	Remap	UDP	192.168.11.254	49154	3	2643343	ACTIVE	ON
YES -									
201392179	3/3.1	Remap	UDP	192.168.11.254	49155	4	2643320	ACTIVE	ON
YES -									
201392180	3/3.1	Remap	UDP	192.168.11.254	49156	5	2643286	ACTIVE	ON
YES -									
201457717	3/3.2	Remap	UDP	192.168.11.254	49158	7	2643265	ACTIVE	ON
YES -									
201457718	3/3.2	Remap	UDP	192.168.11.254	49159	8	2643263	ACTIVE	ON
YES -									
201457719	3/3.2	Remap	UDP	192.168.11.254	49160	9	2643254	ACTIVE	ON
YES -									
201457720	3/3.2	Remap	UDP	192.168.11.254	49161	10	2642829	ACTIVE	ON
YES -									

show cable video session

Related Commands

Command	Description
cable qam-partition	Creates a QAM partition on the line card.



# show cable video statistics packet

To display unicast and multicast video packets, use the **show cable video statistics packet** command in privileged EXEC mode.

**show cable video statistics packet** {all | slot *slot-num*} {brief | detail}

<b>Syntax Description</b>	<b>all</b>	Displays video unicast and multicast packets configured on the chassis.
	<b>slot</b>	Displays video unicast and multicast packets for a specified slot.
	<i>slot-num</i>	Specifies the slot on the chassis. Valid range is from 3 to 12.
	<b>brief</b>	Displays the brief information of packets for a given slot.
	<b>detail</b>	Displays detailed summary information of packets for a given slot.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
	Cisco IOS-XE Release 3.3.0SQ	This command was integrated into Cisco IOS-XE Release 3.3.0SQ. The command output is modified to display the load balancing groups.

**Examples** The following example shows the information of all packets on a chassis:

Router# **show cable video statistics packet all brief**

Slot Id	LBG Id	Multicast Groups	Multicast Sessions	Unicast Sessions	Mcast DS Packets	Unicast DS Packets
3	1	0	0	40	17	858851741
3	2	6	48	0	1735875	0
6	1	0	0	0	29	0
6	2	0	0	0	29	0

# show cable video statistics packet

The following example shows the detailed summary information of all packets on a chassis:

```
Router#show cable video statistics packet slot 3 detail
Slot: 3
LBG ID: 1
QAM Range:          gam3/1-6
Multicast Groups:   0
Multicast Sessions: 0
Unicast Sessions:   3
DS BYTES:           135146944
MCAST DS PACKETS:   48
UCAST DS PACKETS:   563833

CRC ALIGN ERROR:    0
COLLISIONS:         0
UNDERSIZE PKTS:     0
FRAGMENTS PKTS:     0
DROPPED BAD PKTS:  0
SYMBOL ERROR:       255
OVERSIZE PKTS:      0
JABBERS:            0

SINGLE COL:          0
LATE COL:            0
MULTI COL:           0
ACCESSIVE COL:       0

DEFERRED COL:        0
FALSE CARRIER:      0
CARRIER SENSE:      0
SEQUENCE ERROR:      255

QAM Range:          gam3/7-12
Multicast Groups:   0
Multicast Sessions: 0
Unicast Sessions:   0
DS BYTES:           20160
MCAST DS PACKETS:   48
UCAST DS PACKETS:   0

CRC ALIGN ERROR:    0
COLLISIONS:         0
UNDERSIZE PKTS:     0
FRAGMENTS PKTS:     0
DROPPED BAD PKTS:  0
SYMBOL ERROR:       255
OVERSIZE PKTS:      0
JABBERS:            0

SINGLE COL:          0
LATE COL:            0
MULTI COL:           0
ACCESSIVE COL:       0

DEFERRED COL:        0
FALSE CARRIER:      0
CARRIER SENSE:      0
SEQUENCE ERROR:      255
```

Table 3-40 describes the significant fields shown in the display.

**Table 3-40 show cable video statistics packet Field Descriptions**

Field	Description
Qam Range	QAM domains configured on the chassis.
LBG ID	Load balancing group ID.
Multicast Groups	Multicast groups configured.
Multicast Sessions	Number of video multicast sessions.
Unicast Sessions	Number of video unicast sessions.
Mcast DS Packets	Multicast downstream packets.
Unicast DS Packets	Unicast downstream packets.
CRC ALIGN ERROR	Number of packets with a CRC align errors.
DROPPED BAD PKTS	Number of bad packets that were dropped.

**Table 3-40** *show cable video statistics packet Field Descriptions (continued)*

Field	Description
COLLISIONS	Number of packet collisions.
SYMBOL ERROR	Number of symbol errors.
UNDERSIZE PKTS	Number of undersized packets.
OVERIZE PKTS	Number of oversized packets
FRAGMENTS PKTS	Number of fragmented packets.
JABBERS	Number of jabber errors.
DEFERRED COL	Number of times the interface has tried to send a frame, but found the carrier busy at the first attempt.
FALSE CARRIER	False carrier counter. It is incremented when a false error is detected in the register.
CARRIER SENSE	Indicates the signal.
SEQUENCE ERROR	Frame check sequence error.

#### Related Commands

Command	Description
<b>cable video group</b>	Creates a group of video sessions.
<b>cable video multicast</b>	Configures multicast sessions on a QAM interface.

# show controllers linecard

To display information about used bandwidth and total bandwidth on all QAMs on a line card interface, use the **show controllers linecard** command in user EXEC or privileged EXEC mode.

**show controllers linecard** *number* **bandwidth**

<b>Syntax Description</b>	<i>linecard</i>	Specifies the slot location of the line card. The valid range is from 3 to 12.
	<b>bandwidth</b>	Displays the used bandwidth and total bandwidth on all QAMs on a line card interface.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ2	This command was introduced.

**Examples** The following is sample output for the **show controllers linecard** command for a line card in slot 3:

```
Router#show controllers linecard 3 bandwidth
      QAM Port      Bandwidth Used(bps)  Bandwidth Total(bps)
-----x-----x-----
Channel 3/1.1      0                      38810000
Channel 3/1.2      0                      38810000
Channel 3/1.3      0                      38810000
Channel 3/1.4      0                      38810000
```

[Table 3-41](#) describes the fields shown in the **show controllers linecard** command display.

**Table 3-41** *show controllers linecard Field Descriptions*

Field	Description
QAM Port	QAM channel on the line card.
Bandwidth Used (bps)	Amount of bandwidth used by the QAM interface.
Bandwidth Total (bps)	Amount of bandwidth allotted to the QAM interface.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# show controllers qam

To display information about downstream configuration on a line card, use the **show controllers qam** command in privileged EXEC mode.

**show controllers qam | qam-red slot/port.channel downstream**

<b>Syntax Description</b>	<i>slot</i>	Specifies the line card in the QAM interface. Line card redundancy configured interfaces appear as QAM -red. Valid range is from 3 to 12.
	<i>port</i>	Specifies the QAM RF port number in the line card. Valid range is from 1 to 12.
	<i>channel</i>	Specifies the QAM channel in the port of the line card. Valid range is from 1 to 4.
	<b>downstream</b>	Specifies the configuration of the QAM interface.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** This command displays the downstream information for a QAM interface. If line card redundancy (LCRED) is configured on the QAM interface, the interface is denoted by **qam-red**.

**Examples** The following example shows the downstream configuration on a redundancy line card:

```
Router#show controllers qam 3/1.1 downstream
  Qam3/1.1 Downstream is up
    Annex B, Stacking set to 4
    Frequency: 279000000 Hz, Power: 50.0 dBmV
    Modulation: 256QAM, TSID: 0, QAM IDB_State: UP
    Bandwidth Reserved for Video: 0 bps
    Bandwidth Used: 8223776 bps
    Bandwidth Total: 38810000 bps
    Transport Mode: QAM_MODE_MPT Qam Owner: LOCAL
    Interleave Level: 2, FEC I: 32 FEC J: 4
```

Table 3-42 describes the significant fields shown in the display.

**Table 3-42** *show controllers qam Field Descriptions*

Field	Description
Downstream	Indicates whether the interface hardware is currently active or disabled by the administrator.
Annex	Indicates the annex for the RF downstream channel.
Stacking	Indicates the stacking level set on the QAM interface.
Modulation	Indicates the modulation level of the QAM.
TSID	Indicates the TSID value set on the QAM.
QAM_IDB_State	Indicates the state of the QAM interface.
Bandwidth Reserved for video	Amount of bandwidth allotted for video.
Bandwidth Used	Amount of bandwidth used by the QAM interface.
Bandwidth Total	Amount of bandwidth allotted to the QAM interface.
Transport Mode	Indicates the mode on the QAM.
Interleave Level	Indicates the frequency interleave level on the QAM.
FEC	Length of the forward error correction in bytes. The range is 0 to 10 bytes; a value of 0 implies no forward error correction.

#### Related Commands

Command	Description
<b>show running-config interface qam</b>	Displays the running configuration of the QAM interface.

# show depi

To display Downstream External PHY Interface (DEPI) tunnel and session information, use the **show depi** command in privileged EXEC mode.

## show depi

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(50)SQ	This command was introduced.

**Examples** The following example shows a sample output of the **show depi** command on a Cisco RF Gateway 10:

Router# **show depi**

DEPI Tunnel and Session Information Total tunnels 3 sessions 12

LocTunID	RemTunID	Remote Name	State	Remote Address	Sessn Count	L2TP Class
555844637	4037701912	RFGW-10-1	est	11.30.14.100	4	test10

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
1252048235	1074332337	555844637	717,	est	1w0d	16	P
1252049362	1074332330	555844637	711,	est	1w0d	15	P
1252005266	1074332288	555844637	699,	est	1w0d	13	P
1252000641	1074332316	555844637	705,	est	1w0d	14	P

LocTunID	RemTunID	Remote Name	State	Remote Address	Sessn Count	L2TP Class
1486289361	1394811300	RFGW-10-1	est	12.30.14.100	4	test10

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
1252014460	1074332279	1486289361	549,	est	1w0d	20	P
1252059306	1074332234	1486289361	531,	est	1w0d	17	P
1252057709	1074332245	1486289361	537,	est	1w0d	18	P
1252006708	1074332262	1486289361	543,	est	1w0d	19	P

LocTunID	RemTunID	Remote Name	State	Remote Address	Sessn Count	L2TP Class
1688275168	1361251901	RFGW-10-1	est	24.30.14.100	4	test10

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
1252018493	1074332252	1688275168	537,	est	1w0d	22	S
1252054974	1074332286	1688275168	549,	est	1w0d	24	S
1252022230	1074332263	1688275168	543,	est	1w0d	23	S
1252059782	1074332236	1688275168	531,	est	1w0d	21	S

Table 3-43 describes the major fields shown in the **show depi** command display:

**Table 3-43** *show depi Field Descriptions*

Field	Description
LocTunID	Identifier of the local tunnel.
RemTunID	Identifier of the remote tunnel.
Remote Name	Name of the remote tunnel.
State	State of the tunnel.
Remote Address	IP address of the remote tunnel.
Session Count	Number of sessions.
LocID	Identifier of the session.
RemID	Identifier of the remote session.
TunID	Identifier of the tunnel.
State	State of the session.
Last Chg	Last state change timestamp.
Uniq ID	Unique identifier of the QAM channel.
Type	Primary or secondary session.

#### Related Commands

Command	Description
<b>depi-tunnel</b>	Creates a template of DEPI tunnel configuration settings that can be inherited by different pseudowire classes.
<b>show depi session</b>	Displays information about DEPI sessions.
<b>show depi tunnel</b>	Displays information about DEPI tunnels.



# show depi session

To display information about Downstream External PHY Interface (DEPI) sessions, use the **show depi session** command in privileged EXEC mode.

**show depi session** [*session-id* **verbose** | **configured** | **name** *session-name* [**verbose**] | **primary** | **secondary** | **tsid** *ts-id*]

<b>Syntax Description</b>	<i>session-id</i>	(Optional) Local session ID value. The allowed range is from 1 to 4294967295.
	<b>verbose</b>	(Optional) Displays detailed DEPI tunnel or session information.
	<b>configured</b>	(Optional) Displays all the DEPI sessions configured and their state. The states are IDLE and ACTIVE.
	<b>name</b> <i>session-name</i>	(Optional) Specifies the name of the DEPI session.
	<b>primary</b>	(Optional) Specifies the primary DEPI session.
	<b>secondary</b>	(Optional) Specifies the backup DEPI session.
	<b>tsid</b> <i>ts-id</i>	(Optional) Specifies the Transport Stream Identifier (TSID).

**Command Default** None

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ	This command was introduced.
	12.2(50)SQ2	This command was modified. The following keywords were added to this command: <ul style="list-style-type: none"> <li>• <b>configured</b></li> <li>• <b>name</b></li> <li>• <b>primary</b></li> <li>• <b>secondary</b></li> <li>• <b>tsid</b></li> </ul>

## Examples

The following example shows sample output of the **show depi session** command for all the established DEPI data sessions in Cisco IOS Release 12.2(50)SQ:

Router# **show depi session**

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
1074004031	1252011014	641420592	514	est	04:19:46	4	P
1074003980	1252043972	641420592	511	est	04:19:46	1	P
1074266112	1252009847	641420592	7711	est	04:19:46	5	P
1074266158	1252028749	641420592	7713	est	04:19:45	7	P
1074004011	1252053945	641420592	513	est	04:19:46	3	P

■ **show depi session**

1074266138	1252065065	641420592	7712	est	04:19:46	6	P
1074003990	1252034268	641420592	512	est	04:19:46	2	P
1074266170	1252049135	641420592	7714	est	04:19:45	8	P
1074332283	1252057764	1102797124	549	est	04:19:46	16	S
1074332237	1252023871	1102797124	531	est	04:19:46	10	S
1074332269	1252060064	1102797124	543	est	04:19:46	14	S
1074332247	1252030448	1102797124	537	est	04:19:46	12	S
1074332254	1252061912	2073848961	537	est	04:19:47	11	P
1074332258	1252020223	2073848961	543	est	04:19:47	13	P
1074332275	1252030759	2073848961	549	est	04:19:47	15	P

The following is sample output of the **show depi session** command for a specific established DEPI data session identified by the *session-id* in Cisco IOS Release 12.2(50)SQ:

Router# **show depi session 1074528558 verbose**

```

Session id 1074528558 is up, tunnel id 3574340018
  Remote session id is 1252003902, remote tunnel id 3815831337
  Remotely initiated session
  Session Type: Secondary
Qam Channel Parameters
  Tsid is 953
  Group Tsid is 76
  Frequency is 435000000
  Modulation is 256qam
  Annex is B
  Interleaver Depth I=32 J=4
  Power is 480
  Qam channel status is 0
  Unique ID is 58
Call serial number is 2504300043
Remote tunnel name is romeo
  Internet address is 1.30.54.1
Local tunnel name is RFGW-10-1
  Internet address is 1.30.54.100
IP protocol 115
  Session is L2TP signaled
  Session state is established, time since change 00:22:48
    0 Packets sent, 0 received
    0 Bytes sent, 0 received
  Last clearing of counters never
  Counters, ignoring last clear:
    0 Packets sent, 0 received
    0 Bytes sent, 0 received
  Receive packets dropped:
    out-of-order:      0
    out-of-order:      0
    total:             0
  Send packets dropped:
    exceeded session MTU: 0
    exceeded session MTU: 0
    total:             0
  DF bit on, ToS reflect enabled, ToS value 0, TTL value 255
  UDP checksums are disabled
  Session PMTU enabled, path MTU is 1518 bytes
  No session cookie information available
  FS cached header information:
    encap size = 28 bytes
    45000014 00004000 FF730CD6 011E3664
    011E3601 4AA0103E 00000000
  Sequencing is on
    Ns 0, Nr 0, 0 out of order packets received
    Packets switched/dropped by secondary path: Tx 0, Rx 0
Peer Session Details

```

```

Peer Session ID : 1073808091
Peer Qam ID : Qam3/12.2
Peer Qam State : ACTIVE
Peer Qam Type : Secondary
Peer Qam Statistics
Total Pkts : 35177
Total Octets : 6613276
Total Discards : 0
Total Errors : 0
Total In Pkt Rate : 0
Bad Sequence Num : 0
Total In DLM Pkts : 0
Conditional debugging is disabled

```

The following is sample output of the **show depi session** command for all the configured DEPI data sessions:

Router# **show depi session configured**

Session Name	State	Reason	Time
Qam5/1.1:0	ACTIVE	-	
Qam5/1.2:0	ACTIVE	-	
Qam5/1.3:0	ACTIVE	-	
Qam5/1.4:0	ACTIVE	-	
Qam7/1.1:0	ACTIVE	-	
Qam7/1.2:0	ACTIVE	-	
Qam7/1.3:0	ACTIVE	-	
Qam7/1.4:0	ACTIVE	-	
Qam7/10.1:0	ACTIVE	-	
Qam7/10.1:1	ACTIVE	-	
Qam7/10.2:0	ACTIVE	-	
Qam7/10.2:1	ACTIVE	-	
Qam7/10.3:0	ACTIVE	-	
Qam7/10.3:1	ACTIVE	-	
Qam7/10.4:0	ACTIVE	-	
Qam7/10.4:1	ACTIVE	-	
Qam7/11.1:0	IDLE		0 00:00:00
Qam7/11.2:0	IDLE		0 00:00:00
Qam7/11.3:0	IDLE		0 00:00:00
Qam7/11.4:0	IDLE		0 00:00:00
Qam9/1.1:0	ACTIVE	-	
Qam12/4.1:0	IDLE		0 00:00:00

The following is a sample output of the **show depi session** command that displays all primary data sessions on the Cisco RFGW-10:

Router# **show depi session primary**

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
1252048235	1074332337	555844637	717,	est	3d09h	16	P
1252049362	1074332330	555844637	711,	est	3d09h	15	P
1252005266	1074332288	555844637	699,	est	3d09h	13	P
1252000641	1074332316	555844637	705,	est	3d09h	14	P
1252014460	1074332279	1486289361	549,	est	3d09h	20	P
1252059306	1074332234	1486289361	531,	est	3d09h	17	P
1252057709	1074332245	1486289361	537,	est	3d09h	18	P
1252006708	1074332262	1486289361	543,	est	3d09h	19	P

The following is a sample output of the **show depi session** command that displays all secondary data sessions on the Cisco RFGW-10:

Router# **show depi session secondary**

LocID	RemID	TunID	Tsid	State	Last Chg	Uniq ID	Type
-------	-------	-------	------	-------	----------	---------	------

■ **show depi session**

```

1252018493 1074332252 1688275168 537,      est  3d09h  22      S
1252054974 1074332286 1688275168 549,      est  3d09h  24      S
1252022230 1074332263 1688275168 543,      est  3d09h  23      S
1252059782 1074332236 1688275168 531,      est  3d09h  21      S

```

The following is a sample output of the **show depi session** command that shows all secondary data sessions on the Cisco RFGW-10:

Router# **show depi session tsid 549**

```

LocID      RemID      TunID      Tsid      State  Last Chg  Uniq ID   Type
1074332275 1252030759 2073848961 549       est    04:30:38  15        P

LocID      RemID      TunID      Tsid      State  Last Chg  Uniq ID   Type
1074332283 1252057764 1102797124 549       est    04:30:37  16        S

```

[Table 3-44](#) describes the major fields shown in the **show depi session** command display:

**Table 3-44** *show depi Field Descriptions*

Field	Description
State	State of the tunnel or the session.
LocID	Identifier of the session.
RemID	Identifier of the remote session.
TunID	Identifier of the tunnel.
Last Chg	Last state change timestamp.
Uniq ID	Unique identifier of the QAM channel.
Session Name	Name of the session.
Reason	Reason for the current state of the session.
Time	Timestamp of the session.
Type	Primary or secondary session.

■ **Related Commands**

Command	Description
<b>cable mode</b>	Sets the mode of the QAM channel.
<b>depi-class</b>	Creates a template of Downstream External PHY Interface (DEPI) control plane configuration settings, which different pseudowire classes can inherit, and enters the DEPI class configuration mode.
<b>depi-tunnel</b>	Creates a template of DEPI tunnel configuration settings that can be inherited by different pseudowire classes.
<b>show depi</b>	Displays information about DEPI sessions and tunnels.
<b>show depi tunnel</b>	Displays information about DEPI tunnels.

# show depi tunnel

To display information about Downstream External PHY Interface (DEPI) tunnels, use the **show depi tunnel** command in privileged EXEC mode.

**show depi tunnel** [*tunnel-id* *verbose*]

<b>Syntax Description</b>	<i>tunnel-id</i>	(Optional) Name of the DEPI tunnel.
	<b>verbose</b>	(Optional) Displays detailed DEPI tunnel or session information.

**Command Default** None

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(50)SQ	This command was introduced.

**Examples** The following example shows a sample output of the **show depi tunnel** command for all the active control connections:

Router# **show depi tunnel**

LocTunID	RemTunID	Remote Name	State	Remote Address	Sessn Count	L2TP Class
555844637	4037701912	RFGW-10-1	est	11.30.14.100	4	classM
1486289361	1394811300	RFGW-10-1	est	12.30.14.100	4	class1
1688275168	1361251901	RFGW-10-1	est	24.30.14.100	4	class1

The following example shows a sample output of the **show depi tunnel** command for a specific active control connection identified by the DEPI tunnel name:

Router# **show depi tunnel 1834727012 verbose**

```
Tunnel id 1834727012 is up, remote id is 3849925733, 1 active sessions
  Locally initiated tunnel
  Tunnel state is established, time since change 04:10:38
  Remote tunnel name is RFGW-10
    Internet Address 1.3.4.155, port 0
  Local tunnel name is myankows_ubr10k
    Internet Address 1.3.4.103, port 0
  L2TP class for tunnel is rf6
  Counters, taking last clear into account:
    0 packets sent, 0 received
    0 bytes sent, 0 received
  Last clearing of counters never
  Counters, ignoring last clear:
    0 packets sent, 0 received
    0 bytes sent, 0 received
  Control Ns 255, Nr 254
  Local RWS 1024 (default), Remote RWS 8192
```

**show depi tunnel**

```

Control channel Congestion Control is enabled
  Congestion Window size, Cwnd 256
  Slow Start threshold, Ssthresh 8192
  Mode of operation is Slow Start
Retransmission time 1, max 1 seconds
Unsent queuesize 0, max 0
Resend queuesize 0, max 2
Total resends 0, ZLB ACKs sent 252
Total peer authentication failures 0
Current no session pak queue check 0 of 5
Retransmit time distribution: 0 0 0 0 0 0 0 0
Control message authentication is disabled

```

Table 3-43 describes the major fields shown in the **show depi tunnel** command display:

**Table 3-45** *show depi Field Descriptions*

Field	Description
LocTunID	Identifier of the local tunnel.
RemTunID	Identifier of the remote tunnel.
Remote Name	Name of the remote tunnel.
State	State of the tunnel.
Remote Address	IP address of the remote tunnel.
Session Count	Number of sessions.
L2TP Class	L2TP class name for the tunnel.

**Related Commands**

Command	Description
<b>depi-tunnel</b>	Creates a template of DEPI tunnel configuration settings that can be inherited by different pseudowire classes.
<b>rf-channel depi-tunnel</b>	Binds the depi-tunnel to an rf-channel on a shared port adapter (SPA).
<b>controller modular-cable</b>	Enters controller configuration mode to configure the SPA controller.
<b>show depi</b>	Displays information about DEPI sessions and tunnels.
<b>show depi session</b>	Displays information about DEPI sessions.

# show interfaces qam

To display the QAM details, use the **show interfaces qam** command in privileged EXEC mode.

**show interfaces qam** [**qam-red** *slot/port.[channel]*] [**cable**] [**psi** | **pat** | **pmt** | **carousel**]

Syntax Description		
<i>slot</i>		Specifies the slot on the QAM interface. Line card redundancy configured interfaces appear as QAM-red. Valid range is from 3 to 12.
<i>port</i>		Specifies the port on the interface. Valid range is from 1 to 12.
<i>channel</i>		(Optional) Specifies the channel on the port. Valid range is from 1 to 4.
<b>cable</b>		(Optional) Displays cable specific information of the QAM interface.
<b>psi</b>		(Optional) Displays the Packet Stream Identifier (PSI) information of the QAM interface such as Program Allocation Table (PAT) information, PMT information of sessions such as elementary streams and PIDs associated.
<b>pat</b>		(Optional) Displays PAT table information of the QAM interface.
<b>pmt</b>		(Optional) Displays PMT information of the QAM interface.
<b>carousel</b>		(Optional) Displays the IDs and the packets of the different packet stream.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** This command displays packet and byte counts and protocol information of the QAM interface. PSI, PMT, and PAT information details are not displayed.

The Program Allocation Table (PAT) is the master table that contains the list of PIDs for all programs on the output stream of the QAM.



**Note**

The **show interfaces qam slot/port.channel psi** and **show interfaces qam slot/port.channel pmt** commands could potentially create a large amount of output and are recommended to be used sparingly.

**Examples**

The following example displays the protocol and byte information on QAM slot 3:

```
Router#show interfaces qam 3/1
Qam3/1 is up, line protocol is up
  Hardware is RFGW-48DS Line Card - QAM Port
  MTU 1464 bytes, BW 107880 Kbit, DLY 0 usec,
    reliability 0/255, txload 1/255, rxload 1/255
  Encapsulation QAM, loopback not set
  Keepalive set (10 sec)
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts (0 IP multicasts)
    0 runs, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  8439807 packets output, 67518456 bytes 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 output buffer failures, 0 output buffers swapped out
```

Table 3-46 describes the significant fields shown in the display.

**Table 3-46 show interfaces qam Field Descriptions**

Field	Description
QAM slot/port	Indicates whether the interface hardware is currently active or taken down by the administrator.
line protocol	Indicates whether the software processes that handle the line protocol believe the interface is usable or if it has been taken down by the administrator.
Hardware	Hardware type and address.
MTU	Maximum transmission unit (MTU) of the interface.
BW	Bandwidth of the interface in kilobits per second.
DLY	Delay of the interface in microseconds.
reliability	Reliability of the interface as a fraction of 255, calculated as an exponential average over 5 minutes. (For example, 255/255 is 100-percent reliability)
txload	Load on the interface as a fraction of 255, calculated as an exponential average over 5 minutes. (For example, 255/255 is complete saturation)
rxload	Load on the interface as a fraction of 255, calculated as an exponential average over 5 minutes. (For example, 255/255 is complete saturation)
Encapsulation	Encapsulation method assigned to this interface.
Keepalive set	Indicates the time for the keep alive set.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface.
output	Number of hours, minutes, and seconds since the last packet was successfully sent by an interface.



**Table 3-46** *show interfaces qam Field Descriptions (continued)*

Field	Description
Last clearing of "show interfaces" counters	Time at which the counters that measure cumulative statistics (such as number of bytes sent and received) were last reset to zero.
Input queue	Number of packets in the input queue. The format of this number is A/B, where A indicates the number of packets in the queue, and B indicates the maximum number of packets allowed in the queue.
Total output drops	Indicates the number of packets dropped because of a full queue.
5 minute input rate 5 minute output rate	<p>Average number of bits and packets sent and received per second in the last five minutes. The five-minute interval is the default time period for statistics collection and can be changed for each individual cable interface using the <b>load-interval</b> command in the interface configuration mode.</p> <p><b>Note</b> These statistics are calculated using a decayed averaging method, where only the average is stored over the interval period, not the individual samples. Every time a sample average is taken, a percentage of the sample and a percentage of the average are added together to create the new average. If traffic stops for a time period, these statistics do not immediately go to zero but drop with a decay rate of about 70 percent per time period.</p> <p>For example, if the interface is passing 1,000 packets per second (pps) before traffic stops, the <b>show interface cable</b> command shows the rate being 300 pps at the end of the first time interval. The rate then drops to 90 pps at the end of the second time interval, and so forth.</p>
packets input	Total number of error-free packets received by the system.
bytes input	Total number of bytes, including data and MAC encapsulation, in the error-free packets received by the system.
no buffer	Number of received packets discarded because there was no buffer space in the main system.
Received broadcast	Total number of broadcast or multicast packets received by the interface.
runts	Number of packets that are discarded because they are smaller than the medium's minimum packet size.

**Table 3-46** *show interfaces qam Field Descriptions (continued)*

Field	Description
giants	<p>Number of packets that are discarded because they are bigger than the standard Ethernet Maximum Transmission Unit (MTU) size. For Ethernet packets, RFC 1757 defines giants as “the total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.”</p> <p><b>Note</b> In addition, to account for the different Ethernet and other packet encapsulations on the network, packets are considered giants when they exceed the configured MTU size plus 114 bytes.</p>
input errors	Total number of errors received on the interface. This count includes runts and giants, as well as other errors, such as no buffers, and CRC, frame, overrun, and ignored counts. This count can also include DOCSIS protocol errors such as an invalid SID in the DOCSIS frame, a bad extended header length, corrupted concatenated packets, and invalid bandwidth requests.
CRC	Indicates the number of times the cyclic redundancy check (CRC) generated by the originating LAN station or far-end device does not match the checksum calculated from the data received.
frame	Number of packets received incorrectly having a CRC error and a non-integer number of octets.
overrun	Number of times the receiver hardware was unable to forward received data to a hardware buffer because the input rate exceeded the receiver’s ability to handle the data.
ignored	Number of received packets ignored by the interface because the interface hardware ran low on internal buffers.
packets output	Total number of messages sent by the system.
bytes	Total number of bytes, including data and MAC encapsulation, sent by the system.
underruns	Number of times the sender has been relaying faster than the receiving device can handle.
output errors	Sum of all errors that prevented the final transmission of packets out of the interface.
collisions	Not applicable.
interface resets	Number of times an interface has been completely reset.
output buffer failures	Number of times the output buffer has failed.
output buffers swapped out	Number of times the output buffer has been swapped out.

**Related Commands**

Command	Description
<b>interface qam</b>	Enters QAM interface configuration mode.

# show redundancy linecard

To display the information pertaining to a redundancy line card or line card group, use the **show redundancy linecard** command privileged EXEC mode.

**show redundancy linecard** {**all** | **slot** *slot* | **group** **all** | *groupID*}

<b>Syntax Description</b>	<b>all</b>	Displays information of all the redundancy line cards.
	<b>slot</b>	Displays information about line cards in the specified slot.
	<i>slot</i>	Specifies the slot number of the line card. Valid range is from 3 to 12.
	<b>group</b>	Displays information about the redundancy line card group:
	<ul style="list-style-type: none"> <li><b>all</b>—Displays information on all groups on the line card</li> <li><i>groupID</i>—Displays information on a specified group.</li> </ul>	

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following example shows the output for the redundancy line card in slot 3:

```
Router#show redundancy linecard slot 3
LC Redundancy Is Configured:
LC Group Number: 0
LC Slot: 3 (idx=3)
LC Card Type: 0xFFFFFFFF , -1
LC Name: 3
LC Mode: Primary
LC Role: None
LC My State: Init
LC Peer State: Init
```

The following example shows the output for all redundancy line cards:

```
Router#show redundancy linecard all
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
3	-	0	Init	Init	11	-	None	Primary
11	-	0	-	-	Multiple	None	None	Secondary
7	-	1	Init	Active	12	-	None	Primary
12	-	1	Active	Init	7	-	Active	Secondary

Table 3-47 describes the significant fields shown in the display.

**Table 3-47** *show redundancy linecard all Field Descriptions*

Field	Description
Slot	The slot of the line card.
LC Group	If a line card group exists in the line card.
My State	The state of the line card.
Peer State	If the peer state is active.
Peer Slot	The peer line card slot.
Role	Whether the line card is active.
Mode	Whether the line card is in primary or secondary mode.

The following example shows the output for redundancy line card group 2:

```
Router#show redundancy linecard group 2
Group Identifier: 2
Group Description: "line card group 2 created."
NON-revertive
Reserved Cardtype: 0x6011 24593
Group Redundancy Type: INTERNAL SWITCH
Group Redundancy Class: 1:1
Group Redundancy Configuration Type: LINECARD GROUP
Primary: 7
Secondary: 12
```

Table 3-48 describes the significant fields shown in the display.

**Table 3-48** *show redundancy linecard group Field Descriptions*

Field	Description
Group Identifier	Indicates the name of the group.
Group Description	Displays the description given to the line card group.
Reserved Cardtype	Displays the reserved card.
Group Redundancy Type	Indicates the type of redundancy group.
Group Redundancy class	Indicates the redundancy class set for the group.
Group Redundancy Configuration Type	Indicates the linecard group.
Primary	Indicates the primary line card.
Secondary	Indicates the secondary line card.

#### Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>description</b>	Adds a description to the line card group.
<b>member slot</b>	Adds a slot to the line card redundancy group.

Command	Description
<b>redundancy</b>	Enters redundancy configuration mode.
<b>show redundancy linecard</b>	Displays information about a line card or a line card group.

# show redundancy linecard

To display the information pertaining to a redundancy line card or line card group, use the **show redundancy linecard** command privileged EXEC mode.

**show redundancy linecard** {**all** | **slot** *slot* | **group** **all** | *groupID*}

## Syntax Description

<b>all</b>	Displays information of all the redundancy line cards.
<b>slot</b>	Displays information about line cards in the specified slot.
<i>slot</i>	Specifies the slot number of the line card. Valid range is from 3 to 12.
<b>group</b>	Displays information about the redundancy line card group: <ul style="list-style-type: none"> <li><b>all</b>—Displays information on all groups on the line card</li> <li><i>groupID</i>—Displays information on a specified group.</li> </ul>

## Command Default

This command has no default behavior or values.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

## Examples

The following example shows the output for the redundancy line card in slot 3:

```
Router#show redundancy linecard slot 3
LC Redundancy Is Configured:
LC Group Number: 0
LC Slot: 3 (idx=3)
LC Card Type: 0xFFFFFFFF , -1
LC Name: 3
LC Mode: Primary
LC Role: None
LC My State: Init
LC Peer State: Init
```

The following example shows the output for all redundancy line cards:

```
Router#show redundancy linecard all
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
3	-	0	Init	Init	11	-	None	Primary
11	-	0	-	-	Multiple	None	None	Secondary
7	-	1	Init	Active	12	-	None	Primary
12	-	1	Active	Init	7	-	Active	Secondary

Table 3-47 describes the significant fields shown in the display.

**Table 3-49** *show redundancy linecard all Field Descriptions*

Field	Description
Slot	The slot of the line card.
LC Group	If a line card group exists in the line card.
My State	The state of the line card.
Peer State	If the peer state is active.
Peer Slot	The peer line card slot.
Role	Whether the line card is active.
Mode	Whether the line card is in primary or secondary mode.

The following example shows the output for redundancy line card group 2:

```
Router#show redundancy linecard group 2
Group Identifier: 2
Group Description: "line card group 2 created."
NON-revertive
Reserved Cardtype: 0x6011 24593
Group Redundancy Type: INTERNAL SWITCH
Group Redundancy Class: 1:1
Group Redundancy Configuration Type: LINECARD GROUP
Primary: 7
Secondary: 12
```

Table 3-48 describes the significant fields shown in the display.

**Table 3-50** *show redundancy linecard group Field Descriptions*

Field	Description
Group Identifier	Indicates the name of the group.
Group Description	Displays the description given to the line card group.
Reserved Cardtype	Displays the reserved card.
Group Redundancy Type	Indicates the type of redundancy group.
Group Redundancy class	Indicates the redundancy class set for the group.
Group Redundancy Configuration Type	Indicates the linecard group.
Primary	Indicates the primary line card.
Secondary	Indicates the secondary line card.

#### Related Commands

Command	Description
<b>class</b>	Configures redundancy class on the line card.
<b>description</b>	Adds a description to the line card group.
<b>member slot</b>	Adds a slot to the line card redundancy group.

Command	Description
<b>redundancy</b>	Enters redundancy configuration mode.
<b>show redundancy linecard</b>	Displays information about a line card or a line card group.



# show redundancy tcc

To display the information pertaining to a redundancy Timing, Communication and Control (TCC) card, use the **show redundancy tcc** command in privileged EXEC mode.

**show redundancy tcc {all | slot slot}**

<b>Syntax Description</b>	<b>all</b>	Displays information about all TCC cards.
	<b>slot</b>	Displays information about TCC cards in the specified slot.
	<i>slot</i>	Specifies the slot number of the TCC card. Valid slots are 13 and 14.

**Command Default** This command has no default behavior or values.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Examples** The following is the sample output for all redundancy TCC cards:

```
Router#show redundancy tcc all
      My      Peer
Slot State    Slot  Role
-----
13    -        14    -
14   Ready     None   Active
```

[Table 3-51](#) describes the significant fields shown in the display.

**Table 3-51** *show redundancy tcc Field Descriptions*

Field	Descriptions
Slot	Indicates the slot of the TCC card.
My State	Indicates the state of the TCC card.
Peer Slot	Indicates the peer TCC card slot.
Role	Indicates whether the TCC card is active.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>redundancy</b>	Enters redundancy configuration mode.

# show running-config interface qam

To display the running configuration of the QAM interfaces, use the **show running-config interface qam** command in privileged EXEC mode.

```
show running-config interface qam | qam-red slot/port.channel
```

Syntax Description	slot	Specifies the line card in the QAM interface. Line card redundancy configured interfaces appear as QAM-red. Valid range is from 3 to 12.
	port	Specifies the QAM RF port number in the line card. Valid range is from 1 to 12.
	channel	Specifies the QAM channel in the port of the line card. Valid range is from 1 to 4.

**Command Default** This command has no default behavior or vlaues.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** If line card redundancy (LCRED) is configured on the QAM interface, then the interface appears as **qam-red**.

**Examples** The following example shows a running configuration of QAM interface 3:

```
Router#show running-config interface qam-red 3/1.1
Load for five secs: 12%/0%; one minute: 14%; five minutes: 15%
Time source is hardware calendar, *00:39:45.193 UTC Fri Nov 28 2008

Building configuration...

Current configuration : 263 bytes
!
interface Qam-red3/1.1
 cable mode depi local
 no cable downstream rf-shutdown
 cable downstream rf-power 50.0
 cable downstream frequency 279000000
 cable downstream modulation 256
 cable depi dest-ip 192.168.201.100 session-id 311
 snmp trap link-status
end
```

Table 3-52 describes the significant fields shown in the display.

**Table 3-52** *show running-config interface qam Field Descriptions*

Field	Description
Current configuration	Displays all the downstream parameters configured on the QAM interface.

#### Related Commands

Command	Description
<b>show controllers qam</b>	Displays downstream information of a QAM interface.

## ssm

To configure a Specific Source Multicast (SSM) definition, use the **ssm** command in cable video label configuration mode. To remove the SSM label, use the **no** form of this command.

```
ssm label {filter pid pid-list | source source-IP-address group group-IP-address [cbr |  
GigabitEthernet | TenGigabitEthernet interface-number | bitrate bps | jitter ms]}
```

```
no ssm label {filter pid {all | pid-list} | source source-IP-address}
```

### Syntax Description

<i>label</i>	Specifies the name of the session.
<b>filter</b>	Adds or deletes a filter to the video session.
<b>pid</b>	Sets PID filtering for pass-through video sessions.
<i>pid-list</i>	Specifies the PIDs or the range of PIDs or both to be dropped for the video session. The PID range is specified in “ <i>lower_pid</i> - <i>upper_pid</i> ” format. All PIDs must be within 1 to 8190 inclusively.  PIDs and PID ranges are to be separated by commas. A space is required before and after the commas and hyphens.
<b>all</b>	Deletes all filtered PIDs. This keyword is applicable to the <b>no</b> form of the command.
<b>source</b>	Indicates the source.
<i>source-IP-address</i>	Specifies the IP address of the source.
<b>group</b>	Indicates the multicast group.
<i>group-IP-address</i>	Specifies the destination IP address.
<b>cbr</b>	Specifies that the session is supposed to be constant bitrate.
<b>GigabitEthernet</b>	(Optional) Indicates the Gigabit Ethernet interface. Valid slot range is 1 to 12 and port range is 3 through 6, 13 and 14.
<b>TenGigabitEthernet</b>	(Optional) Indicates the 10-Gigabit Ethernet interface. Valid slots and ports are 1 and 2.
<i>interface-number</i>	Specifies the interface slot and port.
<b>bitrate</b>	(Optional) Sets the bitrate allocated for the session.
<i>bps</i>	Specifies the bitrate value. Valid range is 1 to 52000000 bps.
<b>jitter</b>	(Optional) Sets the jitter for group sessions.
<i>ms</i>	Specifies the jitter value. Valid range is from 10 to 200 ms.

### Command Default

This command has no default behavior or values.

### Command Modes

Cable video label configuration (cfg-video-lbl)

**Command History**

Release	Modification
12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.
12.2(50)SQ1	Added the <b>filter</b> keyword to the command to allow filtering of PIDs for pass-through video sessions.

**Usage Guidelines**

Cisco RF Gateway 10 supports Source Specific Multicast (SSM) video sessions. An SSM session is identified by the source and group IP address pair. You can specify up to three multicast address pairs for each SSM video session. This can be achieved by reusing the same session label for all the address pairs. The address pairs under the same label must have different source IP addresses. The Cisco RFGW-10 cycles the address pairs to look for a active signal.

These address pairs are redundant sources for the label. Address pairs under the same label must have identical settings for cbr, bitrate, and jitter. If additional address pairs are entered without these parameters, the corresponding values for the first address pair are used. These parameters can be modified by re-entering the first address pair with new parameter settings. The change is propagated to all the address pairs under the same label.

Filtering of PIDs is applicable for pass-through video sessions. It is intended for filtering of unreferenced PIDs. No PMT regeneration will be performed even if PIDs referenced in the PMT are filtered. Up to 32 PIDs can be filtered per session. Up to eight PIDs or PID ranges can be specified in one CLI line. Multiple CLI lines can be used to specify the PID filter. The same PID filter is applied to all the redundant address pairs under the same label.

An SSM video session can be mapped to multiple QAM channels. All cloned sessions of the same video label share the same attributes, including the filtered PID list.

The **no** form with **filter pid** keyword removes the PIDs from the filtered PID set. A subset of the filtered PID set can be removed with this form.

The **no** form without the **filter pid** keyword removes the SSM label with the associated filter PID list if present.

**Note**

The label definition cannot be modified once the label is used in a QAM channel. Address pairs cannot be added or deleted, or any optional parameters cannot be modified. The only exception is the filtered PID list, which can be modified anytime.

**Note**

To avoid oversubscription, ensure that the actual bitrate of the video session does not exceed the allocated bitrate.

**Examples**

The following example shows the SSM configuration on the Cisco RF Gateway 10:

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# ssm ssm1 source 1.1.1.1 group 232.1.1.1 bitrate 3750000
Router(cfg-video-lbl)# ssm ssm1 source 2.2.2.2 group 232.1.1.1 bitrate 3750000
```

The following example shows an SSM configuration with filtering configured:

```
Router# configure terminal
Router(config)# cable video labels
Router(cfg-video-lbl)# ssm ssm1 source 1.1.1.1 group 232.1.1.1 bitrate 3750000
Router(cfg-video-lbl)# ssm ssm1 source 2.2.2.2 group 232.1.1.1 bitrate 3750000
```

```
Router(cfg-video-lbl)# ssm ssm1 filter pid 10 , 15 , 20 - 30 , 35 - 38  
Router(cfg-video-lbl)# exit
```

**Related Commands**

Command	Description
<b>asm</b>	Configures the ASM video session definition.
<b>cable video labels</b>	Enters the cable video label configuration.
<b>cable video multicast</b>	Configures video multicast sessions on the QAM interface.
<b>show cable video label</b>	Displays the labels configured on a chassis.

# video route

To create policy routes to redirect traffic to the line cards, use the **video route** command in QAM domain configuration mode. To remove the policy route, use the **no** form of this command.

**video route** {**local** | **remote**} {**udp** *startport endport* | **table 24-qam-map**} **qam slot** /{**1-6** / **7-12**}

**no video route** {**local** | **remote**} {**udp** *startport endport* | **table 24-qam-map**} **qam slot** /{**1-6** / **7-12**}

Syntax Description		
<b>local</b>		Creates a local video session.
<b>remote</b>		Creates a remote video session.
<b>udp</b>		Specifies UDP mode.
<i>startport</i>		Specifies the start port of the UDP range.
<i>endport</i>		Specifies the end port of the UDP range.
<b>table</b>		Specifies table-based mode. This is only applicable to local sessions.
<b>24-qam-map</b>		Specifies the pre-defined port map. This is only applicable to local sessions.
<b>qam</b>		Specifies the QAM interface.
<i>slot</i>		Specifies the slot on the line card. Valid ranges are from 3 to 12.
<b>1-6</b>		Specifies the first QAM block of channels.
<b>7-12</b>		Specifies the second QAM block of channels.

**Command Default** This commands has no default behavior or values.

**Command Modes** QAM domain configuration (qam-domain)

Command History	Release	Modification
	12.2(44)SQ	This command was introduced on the Cisco RF Gateway 10.

**Usage Guidelines** Video routes are used to direct traffic to the underlying QAM blocks in a QAM domain. A video route specifies a continuous range of UDP ports mapped to a QAM block. For a local route, the UDP ports are taken from the local IP address. For a remote route, the UDP ports are taken from the remote IP address. A pre-defined UDP map also is present for local video routes, where the UDP ports are defined by a map.

Policy routes are used to redirect traffic to line cards. QAM blocks are added to QAM domains using video policy routes. Each video policy route specifies a range of QAM channels. QAM channels are bound to a QAM block in the video route.

In a local configuration, you can configure the QAM channels using the CLI, GUI or SNMP.

In a remote configuration, the video control plane configures the QAM channels using GQI.

The local session offers two methods of mapping UDP ports to QAM ports:

- User- specified UDP ranges: Start and end UDP ports are specified in the CLI. The video route maps a range of UDP destination ports from the local IP address to the QAM block.

- Table-based: referred to as **24-qam-map**. This is a pre-defined range with a default UDP port range of 49152 to 55295. The video route uses the UDP port map defined in the table for the QAM block.



**Note** Only one QAM map is used per QAM domain.

In the remote session, only user-specified UDP range setup is allowed. Data network Control Station (DNCS) and Universal Session and Resource Manager (USRM) controls the session setup.



**Note** No two video routes within a QAM domain can overlap in IP address and UDP range.



**Note** Removing a video route results in removal of all the sessions configured with that video route.

### Examples

The following example shows a video route for a local session on QAM domain 5:

```
Router#configure terminal
Router(config)#cable qam-domain 5
Router(qam-domain)#ip 1.1.1.1 local
Router(qam-domain)#video route local udp 50000 51000 qam 7/1-6
Router(qam-domain)#video route local udp 51001 52000 qam 7/7-12
Router(qam-domain)#exit
Router(config)#exit
```

The following example shows a video route for a remote session on QAM domain 5:

```
Router#configure terminal
Router(config)#cable qam-domain 5
Router(qam-domain)#ip 1.1.1.1 remote
Router(qam-domain)#video route remote udp 20000 21000 qam 7/1-6
Router(qam-domain)#video route remote udp 21001 22000 qam 7/7-12
Router(qam-domain)#exit
Router(config)#exit
```

The following example shows a table-based policy route on QAM domain 5:

```
Router#configure terminal
Router(config)#cable qam-domain 5
Router(qam-domain)#ip 1.1.1.1 local
Router(qam-domain)#video route local table 24-qam-map qam 3/1-6
Router(qam-domain)#exit
```

The following example shows non-overlapping UDP ranges and QAM channel lists:

```
Router(qam-domain)#video route local udp 50001 51000 qam 3/1-6
Router(qam-domain)#video route local udp 51001 52000 qam 3/7-12
Router(qam-domain)#video route local udp 52001 53000 qam 5/1-6
```

### Related Commands

Command	Description
<b>cable qam-domain</b>	Enters QAM domain configuration mode.
<b>ip</b>	Configures the IP address for video and remote sessions.





