

A

account lockout 2-9 Activate Incident VTG button 3-67 Activate VTG button 3-61 activating incident VTG 3-67 policy **3-112** VTG 3-61 Add a Channel pop-up window 3-86 Add a Radio pop-up window 3-92 Add a User pop-up window 3-88 Add a VTG pop-up window 3-90 Add Image pop-up window 3-94 adding channel to incident 3-86 channel to VTG 3-86 image to incident 3-94 incident 3-110 incident resource 3-70 radio to incident 3-92 radio to VTG 3-92 resource to incident **3-86** resource to VTG 3-86

ΙΝΟΕΧ

user to incident 3-88 user to VTG 3-88 video to incident **3-96** VTG 3-108 VTG resource 3-64 VTG to incident 3-90 VTG to VTG 3-90 Add Video pop-up window 3-96 alert configured tones for 3-136 from IPICS Connect 3-44 message 3-151 alert icon 3-7 Alert pop-up window 3-151 alert tone downloading 2-2 select channel for 3-13 select direct dial channel for 3-21 select incident for 3-32 select P25 channel for 3-18 select radio for 3-25 select resource for 3-135, 3-141 select VTG for 3-29 All Mute button 3-134

All role, IPICS Dispatch Console features available to 1-8 All Talk and Patch Controls area location 3-135 audio device for output 3-76 input devices 3-78 master controls 3-134 time received 3-143 volume 3-33, 3-104, 3-135 audio connections options 3-76 audio replay beep tone 3-32 channel 3-12 controls 3-32 description 3-32 direct dial channel 3-20 hiding controls 3-12, 3-17, 3-20, 3-24, 3-28, 3-31, 3-33 incident 3-31 P25 channel 3-17 radio 3-24 save audio 3-33 showing controls 3-12, 3-17, 3-20, 3-24, 3-28, 3-31 VTG 3-28 audio select channel 3-12, 3-21 incident 3-31 P25 channel 3-17

radio **3-24** resource **3-143** VTG **3-28**

В

beep tone, in audio replay 3-32

С

call ending 3-119 placing 3-119 call alert, supplementary service 3-121 Call button 3-117 channel adding to incident 3-86 to VTG 3-86 audio replay 3-12 audio select 3-12, 3-21 icon 3-11 incidents participating in 3-13 latch 3-12 move 3-13 mute 3-12 name **3-11** patch 3-13, 3-144 powered on 3-10

PTT 3-11 receive indicator 3-13 secure 3-10 traffic 3-13 transmit indicator 3-13 Channel Details for P25 Channels tab description 3-55 displaying 3-18, 3-55 Cisco IPICS role, IPICS Dispatch Console features available to 1-8 Cisco IPICS server downloading installation program from 2-3 IP address of 3-86 Cisco Security Agent (CSA) 1-2 client PC audio devices on 3-78 description 1-2 guidelines 1-2 network interface card (NIC) 3-79 time on **3-120** connectivity, guidelines 2-9

D

dark theme 3-76 Deactivate Incident VTG button 3-67 Deactivate VTG button 3-61 deactivating incident VTG 3-67

VTG 3-61 Dial button, in VTG 3-61 dialer-channel audio 3-83 Dialer Patch Manager pop-up window 3-117 dial-out action. in VTG 3-61 Dial Pad and Channel Patch area access to 1-9 displaying 3-112 hiding 3-114 showing 3-114 direct connect number. for IPICS Connect 3-42 direct dial channel audio replay 3-20 icon **3-19** latch 3-20 move 3-21 mute 3-21 name 3-19 patch 3-21 powered on 3-19 PTT 3-20 receive indicator 3-21 traffic 3-21 transmit indicator 3-21 Dispatcher role, IPICS Dispatch Console features available to 1-8 downloading alert tone 2-2 IPICS Dispatch Console 2-3 DTMF button 3-136

Cisco IPICS Dispatch Console User Guide

Е

EF Johnson radio, radio details tab 3-46 emergency mode description 3-146 indications 3-147 IPICS Dispatch Console 3-146 responding to from Cisco IPICS Dispatch Console 3-149 from SRCI 3-149 serial control radio 3-49, 3-57 encryption, for radio 3-37 EndtoEnd P25 3-14 Event Log window description 3-144 displaying 3-144

F

features, available to user 1-8 filtering incident resource 3-70 VTG resource 3-64

G

Gateway P25 **3-14** group alias, for IPICS Connect **3-42**

Η

headset audible hum 2-13 audio settings for 2-14 connecting to client PC 2-13 type 2-13 USB DSP 2-11 hiding Dial Pad and Channel Patch area 3-114 Items Tabs area 3-106 Master Audio Controls area 3-134 P25 Supplementary Services area 3-120 PTT and Patch Controls area 3-135 System Information area 3-119 high availability (HA) description 1-10 operation 1-10 Hld button 3-117 hot keys, assigning 3-80

icon

channel 3-11 direct dial channel 3-19 incident 3-30 P25 channel 3-15 radio 3-22

VTG 3-26 IDC See IPICS Dispatch Console IDC.exe process 1-2 image adding to incident 3-94 in incident 3-68 uploading to Cisco IPICS server 3-98 viewing 3-68 incident active 1-9 adding image to 3-94 radio to 3-92 user to 3-88 video to 3-96 adding channel to 3-86 adding VTG to 3-90 audio replay 3-31 audio select 3-31 creating 3-110 description 1-9, 3-71 icon 3-30 inactive 1-9 journal 3-70 latch **3-30** move **3-31** mute 3-31 name 3-30

overview 1-9 patch 3-31 powered on 3-29 PTT 3-30 receive indicator 3-32 resource adding 3-70 filtering 3-70 removing 3-70 status 3-69 types **3-68** title **3-71** traffic 3-32 transmit indicator 3-32 Incident Details tab displaying 3-31, 3-65, 3-110 Incidents tab access to 1-6 items on 3-108 incident VTG activating 3-67 deactivating 3-67 description 1-9, 3-65 latch 3-67 listen only 3-68 RX mute 3-67 state 3-71 VAD 3-68

installation directories, required privileges 2-2

installation program, downloading 2-3 installing, IPICS Dispatch Console 2-4 **IPICS** Connect alert 3-44 direct connect number 3-42 group alias 3-42 page 3-44 **IPICS** Dispatch Console color theme **3-76** emergency mode 3-146 exiting 1-6 features available by user type 1-8 high availability (HA) 1-10 installation directories 2-2 guidelines 2-2 procedure 2-4 installation program 2-3 installation program, downloading 2-3 keep on top 3-85 license types 1-6 log files 2-7 logging in to 1-4 logging out of 1-6 Main window 3-2 menu bar 3-5 off-line mode 1-7, 3-6 on-line mode 1-7, 3-6

overview 1-1 Platinum user license 1-6 Region tab 3-7 Silver user license 1-6 starting 1-3 themes 3-75 uninstalling 2-6 version 3-6 Items Tabs area description 3-105 hiding 3-106 showing 3-106

J

journal adding to incident **3-66, 3-70** definition **3-70** entry **3-70** in incident **3-71**

Κ

Keep on Top check box **3-85** key assignments **3-80**

L

last call transmit 3-143

operating mode 1-7, 3-6

latch

channel 3-12 direct dial channel 3-20 incident 3-30 incident VTG 3-67 P25 channel 3-17 radio 3-23, 3-36, 3-39, 3-48, 3-56 resource 3-143 VTG 3-27, 3-61 Latch button channel 3-12 direct dial channel 3-20 incident 3-30 P25 channel 3-17 radio 3-23, 3-36, 3-39, 3-48, 3-56 resource 3-143 VTG 3-27 license Platinum 1-6 Silver 1-6 light theme 3-76 listen only incident VTG 3-68 VTG 3-61 log in, to IPICS Dispatch Console 1-4 log out, of IPICS Dispatch Console 1-6

Μ

Main window 3-2 Master Audio Controls area hiding 3-134 location 3-134 showing 3-134 Master Volume slider 3-135 menu bar 3-5 microphone type **2-13** monitor, radio 3-51 monitoring, radio 3-131 move incident 3-31 resource 3-8, 3-10, 3-139, 3-140 mute all 3-134 channel 3-12 direct dial channel 3-21 incident 3-31 P25 channel 3-18 radio **3-24** resource 3-143 VTG 3-28 Mute button channel 3-12 direct dial channel 3-21 global 3-134

incident 3-31 P25 channel 3-18 radio 3-24 resource 3-143 VTG 3-28

Ν

name

incident 3-30 VTG 3-26 network interface card (NIC), selecting 3-79 network settings 3-79 network time protocol (NTP) server 1-2 Nextel radio, radio details tab 3-37 notification action, in VTG 3-60 Notify button 3-60

0

off-line mode **1-7, 3-6** on-line mode **1-7, 3-6**

Ρ

P25

call alert **3-121** radio check **3-123** radio detach **3-124**

radio inhibit 3-126 radio uninhibit 3-132 radio unit monitor 3-131 short message 3-127 status query 3-129 P25 channel audio replay 3-17 audio select 3-17 channel details tab 3-55 EndtoEnd P25 3-14 Gateway P25 3-14 icon 3-15 incidents participating in 3-18 latch 3-17 move 3-18 mute 3-18 name 3-15 patch 3-18 powered on 3-13 PTT 3-16, 3-58 receive indicator 3-18 secure 3-15 status 3-59 talk group 3-14 transmit indicator 3-18 transmit mode 3-58 unit call 3-14 P25 Supplementary Services area hiding 3-120

location 3-120 showing 3-120 page, from IPICS Connect 3-44 password expiration 2-9 patch incident 3-31 in Dial Pad and Channel Patch area 3-119 P25 channel 3-18 radio **3-25** resources 3-136 select channel for 3-13 select direct dial channel for 3-21 select incident for 3-32 select P25 channel for 3-18 select radio for 3-25 select resource for 3-135, 3-141 select VTG for 3-29 VTG 3-28 Patch button 3-136 Platinum user license 1-6 Policies tab 3-111 policy activating 3-112 alert message **3-151** Policy Execution Status tab description 3-71 displaying 3-71 powered-off resource 3-9 powered-on

channel 3-10 direct dial channel 3-19 incident 3-29 P25 channel 3-13 radio 3-21 resource 3-9 VTG 3-25 powering off, resource 3-139 powering on, resource 3-139 power level, radio 3-36, 3-49 primary Cisco IPICS server 1-10 PTT button 3-136 channel 3-11 direct dial channel 3-20 incident 3-30 P25 channel 3-16, 3-58 radio 3-23, 3-37, 3-40, 3-52 resource 3-142 select channel for 3-13 select direct dial channel for 3-21 select incident for 3-32 select P25 channel for 3-18 select radio for 3-25 select resource for 3-135, 3-141 select VTG for 3-29 VTG 3-27 PTT and Patch Controls area hiding 3-135

showing 3-135 PTT button 3-136 push-to-talk See PTT

R

radio adding to incident 3-92 to VTG 3-92 audio replay 3-24 audio select 3-24 icon 3-22 incidents participating in 3-24 latch 3-23, 3-36, 3-39, 3-48, 3-56 monitoring 3-131 move **3-25** mute **3-24** name **3-22** P25 channel 3-18 patch 3-25 powered on 3-21 PTT 3-23 receive indicator 3-25 secure 3-22 serial control emergency mode 3-49, 3-57 monitor 3-51

power level 3-49 PTT 3-40, 3-52 receive indicator 3-39, 3-48 releasing 3-39, 3-48 repeater or talkaround (RTA) 3-51 reserving 3-39, 3-48 scan 3-52 status 3-41, 3-53 traffic 3-39, 3-48, 3-56 transmit indicator 3-39, 3-48 transmit mode 3-50 tone control encryption 3-37 power level 3-36 PTT 3-37 receive indicator 3-35 traffic 3-35 transmit indicator 3-35 traffic 3-25 transmit indicator 3-25 radio check, supplementary service 3-123 radio detach, supplementary service 3-124 Radio Details for EF Johnson Radios tab description 3-46 displaying 3-45 Radio Details for Nextel Radios tab description 3-37 displaying 3-37 Radio Details for Tone Control Radios tab

description 3-34 displaying 3-34 Radio Details tab displaying 3-25 radio inhibit, supplementary service 3-126 radio uninhibit, supplementary service 3-132 radio unit monitor, supplementary service 3-131 receive indicator channel 3-13 direct dial channel 3-21 incident 3-32 P25 channel 3-18, 3-56 radio 3-25, 3-35, 3-39, 3-48 resource 3-140 VTG 3-29 Records per Page field 3-85 region 3-8 **Regions** list collapsed region view 3-139 displaying 3-137 expanded region view 3-139 hiding 3-137, 3-139 moving resources 3-139, 3-140 showing 3-137, 3-139 Region tab 3-7 Release button 3-39, 3-48 releasing, serial control radio 3-39, 3-48 removing incident resource 3-70

VTG resource 3-64 repeater or talkaround (RTA), radio 3-51 replay audio See audio replay Res button 3-117 Reserve button 3-39, 3-48 reserving, serial control radio 3-39, 3-48 resource adding to incident 3-86 to VTG 3-86 adding to incident 3-70 adding to VTG 3-64 audio select 3-143 channel 3-10 direct dial channel 3-19 icons 3-9 incident 3-29 in incident 3-68 in VTG 3-63 latch 3-143 move 3-10, 3-139, 3-140 mute **3-143** P25 channel 3-13 patching 3-136 power off 3-9 on 3-9 powering off 3-139

powering on 3-139 power on 3-9 PTT 3-142 radio 3-21 receive indicator 3-140 removing from incident 3-70 removing from VTG 3-64 transmit indicator 3-144 VTG 3-25 role All 1-8 Dispatcher 1-8 RX mute incident VTG 3-67

VTG 3-61

S

scan 3-52 secondary Cisco IPICS server 1-10 secure channel 3-10 P25 channel 3-15 radio 3-22 select channel, for PTT, patch, alert tone 3-13 direct dial channel, for PTT, patch, alert tone 3-21 incident, for PTT, patch, alert tone 3-32

P25 channel, for PTT, patch, alert tone **3-18** radio, for PTT, patch, alert tone 3-25 resource, for PTT, patch, alert tone 3-135, 3-141 VTG, for PTT, patch, alert tone 3-29 Select check box channel 3-13 direct dial channel 3-21 incident 3-32 radio 3-18, 3-25 resource 3-141 VTG 3-29 Serial Radio Control Interface (SRCI) accessing 3-37, 3-46 emergency mode 3-149 Server Address field 3-86 Settings tab audio connections options 3-76 description 3-73 dialer-channel audio options 3-83 displaying 3-73 key assignments options 3-80 miscellaneous options 3-85 network settings options 3-79 themes options 3-75 short message, supplementary service 3-127 showing Dial Pad and Channel Patch area 3-114 Items Tabs area 3-106

Master Audio Controls area 3-134 P25 Supplementary Services area 3-120 PTT and Patch Controls area 3-135 Regions list 3-137, 3-139 System Information area 3-119 Show Rx Times check box 3-85 Silver user license 1-6 starting, IPICS Dispatch Console 1-3 state, of IPICS Dispatch Console 1-7, 3-6 status of incident resource 3-69 of VTG resource 3-63 P25 channel 3-59 serial control radio 3-41, 3-53 status query, supplementary service 3-129 supplementary services call alert 3-121 P25 3-120 radio check 3-123 radio detach 3-124 radio inhibit 3-126 radio uninhibit 3-132 radio unit monitor 3-131 short message 3-127 status query 3-129 System Information area hiding **3-119** location 3-119 showing 3-119

system message **3-150** System Message pop-up window **3-150**

Т

talk group P25 channel 3-14 themes dark 3-76 light 3-76 options 3-75 time, on client PC 3-120 time stamp, for audio received 3-143 tone control radio DTMF tones 3-136 Radio Details tab 3-34 traffic channel 3-13 direct dial channel **3-21** incident 3-32 P25 channel 3-18 radio 3-25, 3-35, 3-39, 3-48, 3-56 VTG 3-29 transmit indicator channel 3-13 direct dial channel 3-21 incident 3-32 P25 channel 3-18, 3-56 radio 3-25, 3-35, 3-39, 3-48

resource **3-144** VTG **3-29** transmit mode P25 channel **3-58** radio **3-50**

U

uninstalling, IPICS Dispatch Console 2-6 unit call 3-14 Unmute button channel 3-12 direct dial channel 3-21 global 3-134 incident 3-31 P25 channel 3-18 radio 3-24 resource 3-143 VTG 3-28 Unpatch button 3-136 Upload Image pop-up window 3-98 uploading image to Cisco IPICS server 3-98 video to Cisco IPICS server 3-100 Upload Video pop-up window 3-100 USB DSP headset, using with IPICS Dispatch Console 2-11 user adding to incident 3-88 adding to VTG 3-88

user, features available to 1-8

V

VAD in incident VTG 3-68 in VTG 3-62 video adding to incident 3-96 format **3-102** in incident 3-68 type **3-96** uploading to Cisco IPICS server 3-100 viewing 3-68 YouTube 3-102, 3-105 VLC media player 1-2 Voice Activity Detection See VAD voice quality, guidelines 2-13 volume, audio 3-33, 3-104, 3-135 VTG 3-108 activating 3-61 adding channel to 3-86 radio to 3-92 to incident 3-90 to VTG 3-90 user to 3-88 VTG to 3-90

Cisco IPICS Dispatch Console User Guide

audio replay 3-28 audio select 3-28 creating 3-108 deactivating 3-61 description 3-64 dial-out 3-61 icon 3-26 latch 3-27, 3-61 listen only **3-61** move 3-29 mute 3-28 name 3-26 notification 3-60 patch 3-28 powered on 3-25 PTT 3-27 receive indicator 3-29 resource adding 3-64 filtering 3-64 removing 3-64 status 3-63 types **3-63** RX mute 3-61 state 3-64 title **3-64** traffic 3-29 transmit indicator 3-29 VAD 3-62

VTG Details tab displaying 3-28, 3-59, 3-108 features 3-59 VTGs tab access to 1-6 items on 3-106

W

WaveEngine.exe process 1-2
WAVE Engine process description 2-6 status, determining 2-7 trusting 1-2
Wave Engine process status 3-120
Windows time service 1-2

Y

YouTube video source URL for 3-102 viewing 3-105 Index