



mace enable through rtcp-regenerate

- [mace enable, page 4](#)
- [mace monitor waas, page 6](#)
- [map-class frame-relay, page 8](#)
- [map-group, page 10](#)
- [map-list, page 12](#)
- [match fr-de, page 15](#)
- [match protocol \(L2TPv3\), page 17](#)
- [match tcp, page 19](#)
- [max-lsp-lifetime \(OTV\), page 21](#)
- [metadataacache, page 22](#)
- [mls l2tpv3 reserve, page 25](#)
- [monitor l2tun counters tunnel l2tp, page 28](#)
- [neighbor \(L2VPN Pseudowire Switching\), page 30](#)
- [neighbor \(VPLS\), page 32](#)
- [nsf \(OTV\), page 34](#)
- [oam-ac emulation-enable, page 35](#)
- [optimize tfo, page 37](#)
- [otv active-source, page 40](#)
- [otv adjacency-server unicast-only, page 42](#)
- [otv control-group, page 44](#)
- [otv data-group, page 46](#)
- [otv filter-fhrp, page 48](#)
- [otv fragmentation, page 50](#)
- [otv isis authentication, page 52](#)

- [otv isis csnp-interval, page 54](#)
- [otv isis hello-interval, page 55](#)
- [otv isis hello-multiplier, page 56](#)
- [otv isis hello padding, page 57](#)
- [otv isis lsp-interval, page 58](#)
- [otv isis metric, page 59](#)
- [otv isis overlay, page 61](#)
- [otv isis priority, page 62](#)
- [otv isis retransmit-interval, page 63](#)
- [otv isis retransmit-throttle-interval, page 64](#)
- [otv isis site, page 65](#)
- [otv join-interface, page 67](#)
- [otv mac flood, page 69](#)
- [otv site bridge-domain, page 71](#)
- [otv site-identifier, page 72](#)
- [otv suppress arp-nd, page 73](#)
- [otv use-adjacency-server unicast-only, page 74](#)
- [otv vpn-name, page 76](#)
- [packet drop during-authorization, page 77](#)
- [parameter-map type waas, page 78](#)
- [passthrough, page 80](#)
- [password, page 81](#)
- [password \(L2TP\), page 83](#)
- [peer-cert-verify enable, page 85](#)
- [peer-cipherlist, page 87](#)
- [peer-ssl-version, page 89](#)
- [policy-map type mace, page 91](#)
- [policy-map type waas, page 93](#)
- [platform trace runtime process forwarding-manager module mfr, page 95](#)
- [prc-interval \(OTV\), page 98](#)
- [precedence \(Frame Relay VC-bundle-member\), page 99](#)
- [protect \(Frame Relay VC-bundle-member\), page 102](#)
- [protocol \(L2TP\), page 104](#)

- [pseudowire](#), page 106
- [pseudowire-class](#), page 108
- [pvc \(Frame Relay VC-bundle\)](#), page 110
- [read-ahead](#), page 112
- [receive-window](#), page 114
- [retransmit](#), page 116
- [rewrite ingress tag](#), page 118
- [rd \(VPLS\)](#), page 121
- [route-target \(VPLS\)](#), page 123
- [rtcp-regenerate](#), page 125

mace enable

To apply the global Measurement, Aggregation, and Correlation Engine (MACE) policy on an interface, use the **mace enable** command in interface configuration mode. To disable the MACE policy on an interface, use the **no** form of this command.

mace enable

no mace enable

Syntax Description This command has no arguments or keywords.

Command Default No MACE policy is applied on an interface.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	15.1(4)M	This command was introduced.

Usage Guidelines Use the **mace enable** command to apply the global MACE policy on an interface. This command applies the global MACE policy in both directions, ingress and egress, of the interface. The MACE runs on the traffic coming over this interface. MACE policy is limited to targets for which the Wide-Area Application Services (WAAS) policy can be enabled. MACE supports all the interfaces that are supported by WAAS.



Note

MACE does not interoperate with Network Address Translation (NAT) on the ingress (LAN) interface if the **ip nat inside** command is configured on the ingress interface. However, MACE interoperates with NAT on the egress (WAN) interface if the **ip nat outside** command is configured on the egress interface.

Before you enable MACE, you must configure the following:

- Flow record of type MACE
- Flow exporter
- Flow monitor of type MACE
- Class map of type WAAS
- Policy map of type MACE

When you configure the **mace enable** command, the metrics of the matching flows are collected and updated on every packet. When the export timer expires, these metrics are aggregated and exported to various collectors according to the defined configuration. On optimizing the flow by using WAAS, the metrics of both segments, pre-WAAS and post-WAAS, of the flow are exported.

Examples

The following example shows how to enable MACE on Ethernet interface 0/0:

```
Device(config)# interface ethernet0/0  
Device(config-if)# mace enable
```

Related Commands

Command	Description
class-map type waas	Configures a WAAS Express class map.
flow exported	Creates a Flexible NetFlow flow exporter.
flow monitor type mace	Configures a flow monitor for MACE.
flow record type mace	Configures a flow record for MACE.
policy-map type mace	Configures a MACE policy map.

mace monitor waas

To enable the Measurement, Aggregation, and Correlation Engine (MACE) monitoring on Wide Area Application Services (WAAS), use the **mace monitor waas** command in global configuration mode. To disable MACE monitoring, use the **no** form of this command.

mace monitor waas [**all**| **optimized**] [**name**] *monitor-name*

no mace monitor waas [**all**| **optimized**] [**name**] *monitor-name*

Syntax Description

all	(Optional) Enables MACE monitoring for all WAAS flows.
optimized	(Optional) Enables MACE monitoring for WAAS-optimized flows.
name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of the specific flow monitor that is configured using the flow monitor type mace command.

Command Default

No MACE is configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.1(4)M	This command was introduced.

Usage Guidelines

Use the **mace monitor waas** command to enable MACE for all WAAS instances that run on the router.

MACE monitors all the flows on which WAAS is active for optimization.

To enable MACE on WAAS, you must first configure the following:

- A flow record of type MACE
- A flow exporter
- A flow monitor of type MACE

When you use the **mace monitor waas** command along with the **optimized** keyword, MACE monitors all the flows on which WAAS is active for optimization.

When you use this command along with the **all** keyword, MACE monitors all the flows configured in a WAAS policy. This includes the flows that are subject to either WAAS optimization or pass-through actions.

When you use this command without the **all** or **optimized** keyword, MACE monitors all WAAS classes that have the **optimize** keyword configured in them. MACE also exports the flows that are tagged by WAAS as passthrough, even when they match the classes with optimize actions in them.

**Note**

If you wish to choose a subset of WAAS classes, you must create a global MACE policy that includes the desired classes.

Examples

The following example shows how to configure MACE to monitor all the flows that are configured in a WAAS policy:

```
Router(config)# mace monitor waas all  
my-flow-monitor
```

Related Commands

Command	Description
flow exporter	Creates a Flexible NetFlow flow exporter.
flow monitor type mace	Configures a flow monitor for MACE.
flow record type mace	Configures a flow record for MACE.
mace enable	Applies the global MACE policy on an interface.

map-class frame-relay

To specify a map class to define quality of service (QoS) values for a virtual circuit (VC), use the **map-class frame-relay** command in global configuration mode. To remove a map class, use the no form of this command.

map-class frame-relay *map-class-name*

no map-class frame-relay *map-class-name*

Syntax Description

<i>map-class-name</i>	Name of map class.
-----------------------	--------------------

Command Default

A map class is not specified.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

After you specify the named map class, you can specify the QoS parameters--such as incoming and outgoing committed information rate (CIR), committed burst rate, excess burst rate, and the idle timer--for the map class.

To specify the protocol-and-address combination to which the QoS parameters are to be applied, associate this map class with the static maps under a map list.

Examples

The following example specifies a map class "hawaii" and defines three QoS parameters for it. The "hawaii" map class is associated with a protocol-and-address static map defined under the **map-list** command.

```
map-list bermuda source-addr E164 123456 dest-addr E164 654321
ip 10.108.177.100 class hawaii
appletalk 1000.2 class hawaii
map-class frame-relay hawaii
frame-relay cir in 2000000
frame-relay cir out 56000
frame-relay be out 9000
```


Related Commands

Command	Description
frame-relay bc	Specifies the incoming or outgoing Bc for a Frame Relay VC.
frame-relay be	Sets the incoming or outgoing Be for a Frame Relay VC.
frame-relay cir	Specifies the incoming or outgoing CIR for a Frame Relay VC.
frame-relay idle-timer	Specifies the idle timeout interval for an SVC.

map-group

To associate a map list with a specific interface, use the **map-group** command in interface configuration mode.

map-group *group-name*

Syntax Description

<i>group-name</i>	Name used in a map-list command.
-------------------	---

Command Default

A map list is not associated with an interface.

Command Modes

Interface configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

A map-group association with an interface is required for switched virtual circuit (SVC) operation. In addition, a map list must be configured.

The **map-group** command applies to the interface or subinterface on which it is configured. The associated E.164 or X.121 address is defined by the **map-list** command, and the associated protocol addresses are defined by using the **class** command under the **map-list** command.

Examples

The following example configures a physical interface, applies a map group to the physical interface, and then defines the map group:

```
interface serial 0
 ip address 172.10.8.6
 encapsulation frame-relay
 map-group bermuda
 frame-relay lmi-type q933a
 frame-relay svc
 map-list bermuda source-addr E164 123456 dest-addr E164 654321
 ip 10.1.1.1 class hawaii
 appletalk 1000.2 class rainbow
```

Related Commands

Command	Description
class (map-list)	Associates a map class with a protocol-and-address combination.
map-list	Specifies a map group and link it to a local E.164 or X.121 source address and a remote E.164 or X.121 destination address for Frame Relay SVCs.

map-list

To specify a map group or map list and link it to a local E.164 or X.121 source address and a remote E.164 or X.121 destination address for Frame Relay switched virtual circuits (SVCs), use the **map-list** command in global configuration mode. To delete a previous map-group link, use the **no** form of this command.

map-list *map-group-name* **source-addr** {**e164** | **x121**} *source-address* **dest-addr** {**e164** | **x121**} *destination-address* **clps** *number* [**cdps** *number*]

no map-list *map-group-name* **source-addr** {**e164** | **x121**} *source-address* **dest-addr** {**e164** | **x121**} *destination-address* **clps** *number* [**cdps** *number*]

Syntax Description

<i>map-group-name</i>	Name of the map group or map list. This map group or list must be associated with a physical interface.
source-addr { e164 x121 }	Specifies the type of source address.
<i>source-address</i>	Address of the type specified (E.164 or X.121).
dest-addr { e164 x121 }	Specifies the type of destination address.
<i>destination-address</i>	Address of the type specified (E.164 or X.121).
clps <i>number</i>	Specifies the calling party subaddress. The subaddress range is from 1 to 9.
cdps <i>number</i>	(Optional) Specifies the called party subaddress. The subaddress range is from 1 to 9.

Command Default

A map group or map list is not linked to a source and destination address.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Release	Modification
15.0(1)M	This command was modified in a release earlier than Cisco IOS Release 15.0(1)M. The clps number and cdps number keyword and argument pairs were added.

Usage Guidelines

Use the **map-class** command to define quality of service (QoS) parameters--such as incoming and outgoing committed information rate (CIR), committed burst rate, excess burst rate, and the idle timer--for the static maps defined under a map list or map group.

Each SVC needs to use a source and destination number, in much the same way that a public telephone network needs to use source and destination numbers. These numbers allow the network to route calls from a specific source to a specific destination. This specification is done through map lists or map groups.

Depending on switch configuration, addressing can take either of two forms: E.164 or X.121.

An X.121 address number is 14 digits long and has the following form:

Z CC P NNNNNNNNNN

The table below describes the codes in an X.121 address number form.

Table 1: X.121 Address Numbers

Code	Meaning	Value
Z	Zone code	3 for North America
C	Country code	10-16 for the United States
P	Public data network (PDN) code	Provided by the PDN
N	10-digit number	Set by the network for the specific destination

An E.164 number has a variable length; the maximum length is 15 digits. An E.164 number has the fields shown in the figure below and described in the table below.

Table 2: E.164 Address Field Descriptions

Field	Description
Country code	Can be 1, 2, or 3 digits long. Some examples of country code are as follows: <ul style="list-style-type: none"> • Code 1--United States of America • Code 44--United Kingdom • Code 61--Australia

Field	Description
National destination code + subscriber number	Referred to as the National ISDN number; the maximum length is 12, 13, or 14 digits, based on the country code.
ISDN subaddress	Identifies one of many devices at the termination point. An ISDN subaddress is similar to an extension on a PBX.

Examples

In the following SVC example, if IP or AppleTalk triggers the call, the SVC is set up with the QoS parameters defined within the class “example”.

An SVC triggered by either protocol results in two SVC maps, one for IP and one for AppleTalk. Two maps are set up because these protocol-and-address combinations are heading for the same destination, as defined by the **dest-addr** keyword and the values following it in the **map-list** command.

```
map-list test source-addr e164 123456 dest-addr e164 654321 clps 2 cdps 4
ip 10.1.1.1 class example
appletalk 1000.2 class example
```

Related Commands

Command	Description
class (map-list)	Associates a map class with a protocol-and-address combination.
map-class frame-relay	Specifies a map class to define QoS values for an SVC.

match fr-de

To match packets on the basis of the Frame Relay discard eligibility (DE) bit setting, use the **match fr-de** command in class-map configuration or policy inline configuration mode. To remove the match criteria, use the **no** form of this command.

match fr-de

no match fr-de

Syntax Description This command has no arguments or keywords.

Command Default Packets are not matched on the basis of the Frame Relay DE bit setting.

Command Modes Class-map configuration (config-cmap) Policy inline configuration (config-if-spolicy-inline)

Command History	Release	Modification
	12.0(25)S	This command was introduced for the Cisco 7500 series router.
	12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S and implemented on the Cisco 7200 series router.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.
	12.4(15)T2	This command was integrated into Cisco IOS Release 12.4(15)T2.
	12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB and implemented on the Cisco 7300 series router.
	15.1(3)T	This command was integrated into Cisco IOS Release 15.1(3)T for Cisco Performance Monitor. Support was added for policy inline configuration mode.
	12.2(58)SE	This command was integrated into Cisco IOS Release 12.2(58)SE for Cisco Performance Monitor.

Usage Guidelines This command can be used with both Flexible NetFlow and Performance Monitor. These products use different commands to enter the configuration mode in which you issue this command.

Cisco Performance Monitor in Cisco IOS Release 15.1(3)T and 12.2(58)SE

You must first enter the **service-policy type performance-monitor inline** command.

Examples

The following example creates a class named match-fr-de and matches packets on the basis of the Frame Relay DE bit setting.

```
Router(config)# class-map match-fr-de
Router(config-cmap)# match fr-de
```

Examples

The following example shows how to use the policy inline configuration mode to configure a service policy for Performance Monitor. The policy specifies that packets traversing Ethernet interface 0/0 that match the Frame Relay DE bit setting will be monitored based on the parameters specified in the flow monitor configuration named **fm-2**:

```
Router(config)# interface ethernet 0/0
Router(config-if)# service-policy type performance-monitor inline input
Router(config-if-spolicy-inline)# match
fr-de
Router(config-if-spolicy-inline)# flow monitor fm-2
Router(config-if-spolicy-inline)# exit
```

Related Commands

Command	Description
class-map	Creates a class map to be used for matching packets to a specified class.
service-policy type performance-monitor	Associates a Performance Monitor policy with an interface.
set fr-de	Changes the DE bit setting in the address field of a Frame Relay frame to 1 for all traffic leaving an interface.

match protocol (L2TPv3)

To configure protocol demultiplexing, use the **match protocol** command in xconnect configuration mode. To disable protocol demultiplexing, use the **no** form of this command.

match protocol ipv6

no match protocol ipv6

Syntax Description

ipv6	Specifies IPv6 as the protocol to demultiplex.
-------------	--

Command Default

IPv6 protocol demultiplexing is disabled by default.

Command Modes

Xconnect configuration

Command History

Release	Modification
12.0(29)S	This command was introduced.
12.2(27)SBC	Support for this command was integrated into Cisco IOS Release 12.2(27)SBC.
12.4(11)T	This command was integrated into Cisco IOS Release 12.4(11)T.

Usage Guidelines

Protocol demultiplexing is supported only for Ethernet and terminated data-link connection identifier (DLCI) Frame Relay traffic in Cisco IOS Release 12.0(29)S and later releases.

Protocol demultiplexing requires supporting the combination of an IP address and an **xconnect** command configuration on the IPv4 provider edge (PE) interface. This combination of configurations is not allowed without enabling protocol demultiplexing, with the exception of switched Frame Relay permanent virtual circuits (PVCs). If no IP address is configured, the protocol demultiplexing configuration is rejected. If an IP address is configured, the **xconnect** command configuration is rejected unless protocol demultiplexing is enabled in xconnect configuration mode before exiting that mode. If an IP address is configured with an **xconnect** command configuration and protocol demultiplexing enabled, the IP address cannot be removed. To change or remove the configured IP address, the **xconnect** command configuration must first be disabled.

The table below shows the valid combinations of configurations.

Table 3: Support for the ATM Cell Relay Features

Scenario	IP Address	xconnect Configuration	Protocol Demultiplexing Configuration
Routing	Yes	No	--
L2VPN	No	Yes	No
IPv6 Protocol Demultiplexing	Yes	Yes	Yes

Examples

The following example configures IPv6 protocol demultiplexing in an xconnect configuration:

```
xconnect 10.0.3.201 888 pw-class demux
 match protocol ipv6
```

Related Commands

Command	Description
xconnect	Binds an attachment circuit to a Layer 2 pseudowire and enters xconnect configuration mode

match tcp

To match WAAS Express TCP traffic based on the IP address or port options, use the **match tcp** command in QoS class-map configuration mode. To remove the match, use the **no** form of this command.

match tcp {**any**|**destination**|**source**} {**ip** *ip-address* [*inverse mask*]|**port** *start-port-number* [*end-port-number*] }

match tcp {**any**|**destination**|**source**} {**ip** *ip-address* [*inverse mask*]|**port** *start-port-number* [*end-port-number*] }

Syntax Description

any	Matches based on any of TCP traffic.
destination	Matches the traffic based on the destination IP address or port number.
source	Matches the TCP traffic based on the source IP address or port number.
ip <i>ip-address</i> [<i>inverse mask</i>]	(Optional) Matches the TCP traffic based on the source or destination IP address and inverse mask.
port	Matches the TCP traffic based on the port number.
<i>start-port-number</i>	The starting port number.
<i>end-port-number</i>	(Optional) The ending port number.

Command Default

Traffic is matched on all TCP traffic.

Command Modes

QoS class-map configuration (config-cmap)

Command History

Release	Modification
15.1(2)T	This command was introduced.

Usage Guidelines

Use this command to match the TCP traffic based on the IP address or port number of the source or destination. If Network Address Translation (NAT) is used, the IP address refers to the inside local address and outside global address.

**Note**

The class-map type of WAAS combines filters using the match-any logical operator. The match-all logical operator is not supported by the WAAS class map. This means that if one match criterion (filters) matches, the entire class map also matches.

Examples

The following example matches traffic having a destination TCP port number from 7000 to 7009:

```
Router(config)# class-map type waas waas_global
Router(config-cmap)# match tcp destination port 7000 7009
```

The following example matches traffic if the following conditions are matched:

- Destination IP address is in the range 209.165.200.225 and destination TCP port is 80.
- Destination IP address is in the range 209.165.200.225 and destination TCP port is 8080.

```
Router(config)# class-map type waas waas_global
Router(config-cmap)# match tcp destination ip 209.165.200.225 0.0.0.31 port 80 80
Router(config-cmap)# match tcp destination ip 209.165.200.225 0.0.0.31 port 8080 8080
```

Related Commands

Command	Description
class-map type waas	Defines a WAAS Express class map.

max-lsp-lifetime (OTV)

To configure the maximum link-state packets (LSPs) lifetime, use the **max-lsp-lifetime** command in OTV IS-IS instance configuration mode. To return to the default setting, use the **no** form of this command.

max-lsp-lifetime *seconds*

no max-lsp-lifetime

Syntax Description

<i>seconds</i>	Maximum LSP lifetime in seconds. The range is from 1 to 65535.
----------------	--

Command Default

By default, the maximum LSP lifetime is 1200 seconds (20 minutes).

Command Modes

OTV IS-IS instance configuration (config-otv-isis)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to set the maximum time that LSPs persist to 1300 seconds:

```
Router# configure terminal
Router(config)# otv isis overlay 1
Router(config-otv-isis)# max-lsp-lifetime 1300
Router(config-otv-isis)# end
```

Related Commands

Command	Description
otv isis overlay	Creates an OTV overlay interface.
show otv isis	Displays the IS-IS status and configuration.

metadatatcache

To configure HTTP metadata caching, use the **metadatatcache** command in WAAS HTTP configuration mode. To disable metadata caching, use the **no** form of this command.

metadatatcache {**filter-extension** *ext* | **max-age** *seconds* | **min-age** *seconds* | {**https** | **request-ignore-no-cache** | **response-ignore-no-cache** | **conditional-response** | **redirect-response** | **unauthorized-response**} **enable** | **enable**}

no metadatatcache {**filter-extension** *ext* | **max-age** *seconds* | **min-age** *seconds* | {**https** | **request-ignore-no-cache** | **response-ignore-no-cache** | **conditional-response** | **redirect-response** | **unauthorized-response**} **enable** | **enable**}

Syntax Description

filter-extension <i>ext</i>	Specifies file extensions, as a comma separated string, for which the metadata cache needs to be stored. Filter extension is enabled by default. However, it is effective only after metadata caching is enabled. If no file extensions are configured, all file types are cached, which is the default state.
max-age <i>seconds</i>	Specifies the maximum time, in seconds, to retain cache entries in the metadata cache table. Maximum age for metadata cache entries is enabled by default. However, it is effective only after metadata caching is enabled. The range is from 5 to 2592000. The default value is 86400.
min-age <i>seconds</i>	Specifies the minimum time, in seconds, to retain cache entries in the metadata cache table. Minimum age for metadata cache entries is enabled by default. However, it is effective only after metadata caching is enabled. The range is from 5 to 86400. The default value is 60.
https	Enables HTTPS metadata caching. This keyword is enabled by default.
request-ignore-no-cache	Configures the metadata cache to ignore cache-control on requests. This keyword is disabled by default.
response-ignore-no-cache	Configures the metadata cache to ignore cache-control on response. This keyword is disabled by default.
conditional-response	Enables responses for the HTTP conditional requests feature. This keyword is enabled by default.

redirect-response	Enables the HTTP URL redirect feature. If this keyword is configured, the HTTP-Express accelerator responds with local HTTP 301 redirect messages. This keyword is enabled by default.
unauthorized-response	Enables the HTTP authentication-redirect feature. If this keyword is configured, the HTTP-Express accelerator responds with local HTTP 401 'authentication required' messages. This keyword is enabled by default.
enable	Enables HTTP metadata caching.

Command Default Metadata caching is enabled.

Command Modes WAAS HTTP configuration (config-waas-http)

Command History	Release	Modification
	15.2(3)T	This command was introduced.

Usage Guidelines Before you can enable the **metadatatcache** command, use the following commands:

- Use the **parameter-map type waas** command in global configuration mode to enter parameter map configuration mode.
- Use the **accelerator http-express** command in parameter map configuration mode to enter WAAS HTTP configuration mode.

Use the **metadatatcache enable** command to enable metadata caching for other metadata parameters to take effect.

Examples

The following example shows how to enable metadata caching and configure related parameters:

```
Device(config)# parameter-map type waas waas_global
Device(config-profile)# accelerator http-express
Device(config-waas-http)# enable
Device(config-waas-http)# metadatatcache enable
Device(config-waas-http)# metadatatcache max-age 10000
Device(config-waas-http)# metadatatcache min-age 100
Device(config-waas-http)# metadatatcache redirect-response enable
Device(config-waas-http)# metadatatcache conditional-response enable
Device(config-waas-http)# metadatatcache request-ignore-no-cache enable
```

Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
parameter-map type waas	Configures WAAS Express global parameters.
show waas accelerator	Displays information about WAAS Express accelerators.
show waas cache http-express metadatacache	Displays WAAS Express HTTP metadata cache entries.

mls l2tpv3 reserve

To reserve a loopback interface to use as a source for the Layer 2 Tunnel Protocol version 3 (L2TPv3) tunnel for a specific line card and processor pair, use the `mls l2tpv3 reserve` command in interface configuration mode. To cancel the loopback interface reservation, use the `no` form of this command.

mls l2tpv3 reserve {*slot slot-num*| **interface** {**TenGigabitEthernet** *slot_num/slot_unit*| **GigabitEthernet** *slot_num/slot_unit*} **GigabitEthernet** *slot_num/slot_unit*}

no mls l2tpv3 reserve {*slot slot-num*| **interface** {**TenGigabitEthernet** *slot_num/slot_unit*| **GigabitEthernet** *slot_num/slot_unit*} **GigabitEthernet** *slot_num/slot_unit*}

Syntax Description

slot <i>slot_num</i>	Router slot number for a Cisco 7600 series SPA Interface Processor-400 (SIP-400) line card.
interface	Specifies that the interface is for a Cisco 7600 series ES Plus line card.
TenGigabitEthernet	Specifies a 2-Port 10 Gigabit Ethernet or a 4-Port 10 Gigabit Ethernet line card.
GigabitEthernet	Specifies 20-Port Gigabit Ethernet or 40-Port Gigabit Ethernet line cards.
<i>slot_num/slot_unit</i>	Slot number in which the line card is inserted and the slot unit (the line card port number). When using two Gigabit Ethernet interfaces, the slot numbers of the two interfaces must match and can either be 1, 11, 21, or 31. The slot unit of the second Gigabit Ethernet interface must be ten plus the slot number of the first Gigabit Ethernet interface.

Command Default

No loopback interface is configured.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
12.2(33)SRC	This command was introduced on the Cisco 7600 series routers.
12.2(33)SRD	This command was modified to support the Cisco 7600 series ES Plus line cards.

Usage Guidelines

This command also prevents the reserved loopback interface from being used across multiple line cards.

Examples

The following example reserves a loopback interface to use as a source for the L2TPv3 tunnel for a SIP-400 line card:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface Loopback1
Router(config-if)# mls l2tpv3 reserve slot 4
Router(config-if)# end
Router#
*Sep 11 04:03:26.770: %SYS-5-CONFIG I: Configured from console by console
Router# show running interface Loopback1
Building configuration...
Current configuration : 69 bytes
!
interface Loopback1
  no ip address
  mls l2tpv3 reserve slot 4
end
```

The following example reserves a loopback interface to use as a source for the L2TPv3 tunnel for two 40-Port Gigabit Ethernet line cards:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface Loopback1
Router(config-if)# mls l2tpv3 reserve interface GigabitEthernet 3/11 GigabitEthernet 3/20
Router(config-if)# end
Router#
*Sep 10 10:46:01.671: %SYS-5-CONFIG I: Configured from console by console
Router# show running interface Loopback1
Building configuration...
Current configuration : 112 bytes
!
interface Loopback1
  no ip address
  mls l2tpv3 reserve interface GigabitEthernet3/11 GigabitEthernet3/20
end
```

The following example reserves a loopback interface to use as a source for the L2TPv3 tunnel for a 2-Port 10 Gigabit Ethernet line card:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface Loopback2
Router(config-if)# mls l2tpv3 reserve interface TenGigabitEthernet 9/1
Router(config-if)# end
Router#
*Sep 10 10:49:31.451: %SYS-5-CONFIG I: Configured from console by console
Router# show running interface Loopback2
Building configuration...
Current configuration : 112 bytes
!
interface Loopback2
  no ip address
  mls l2tpv3 reserve interface Tengigether 9/1
end
```

Related Commands

Command	Description
show running interface	Verifies the configuration.

monitor l2tun counters tunnel l2tp

To enable or disable the collection of per-tunnel control message statistics for Layer 2 Tunnel Protocol (L2TP) tunnels, use the **monitor l2tun counters tunnel l2tp** command in privileged EXEC mode.

monitor l2tun counters tunnel l2tp id *local-id* {start| stop}

Syntax Description

id <i>local-id</i>	Specifies the local ID of an L2TP tunnel.
start	Specifies that per-tunnel control message statistics will be collected for the tunnel.
stop	Specifies that per-tunnel control message statistics will not be collected for the tunnel. Note Any existing per-tunnel statistics will be lost when the stop keyword is issued.

Command Default

Per-tunnel statistics are not collected for any tunnels.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.

Usage Guidelines

Use the **monitor l2tun counters tunnel l2tp** command to enable or disable the collection of per-tunnel control message statistics. Per-tunnel statistics must be enabled for each tunnel that you want to monitor.

Use the **show l2tun counters tunnel l2tp id *local-id*** command to display per-tunnel statistics for a specific tunnel. Use the **show l2tun counters tunnel l2tp all** command to display per-tunnel statistics for all tunnels that have per-tunnel statistics enabled.

Use the **clear l2tun counters tunnel l2tp id *local-id*** command to clear the per-tunnel statistics for a specific tunnel. Per-tunnel statistics are also cleared when the collection of per-tunnel statistics is disabled.

Examples

The following example enables the collection of per-tunnel control message statistics for the tunnel with the local tunnel ID 4230:

```
monitor l2tun counters tunnel l2tp id 4230 start
```

The following example disables the collection of per-tunnel control message statistics for the tunnel with the local tunnel ID 4230:

```
monitor l2tun counters tunnel l2tp id 4230 stop
```

Related Commands

Command	Description
clear l2tun counters tunnel l2tp	Clears global or per-tunnel control message statistics for L2TP tunnels.
show l2tun counters tunnel l2tp	Displays global or per-tunnel control message statistics for L2TP tunnels.

neighbor (L2VPN Pseudowire Switching)

To specify the routers that should form a point-to-point Layer 2 virtual forwarding interface (VFI) connection, use the **neighbor** command in L2 VFI point-to-point configuration mode. To disconnect the routers, use the **no** form of this command.

neighbor *ip-address vc-id* {**encapsulation** **mpls**| **pw-class** *pw-class-name*}

no neighbor *ip-address vc-id* {**encapsulation** **mpls**| **pw-class** *pw-class-name*}

Syntax Description

<i>ip-address</i>	IP address of the VFI neighbor.
<i>vc-id</i>	Virtual circuit (VC) identifier.
encapsulation mpls	Encapsulation type.
pw-class	Pseudowire type.
<i>pw-class-name</i>	Name of the pseudowire you created when you established the pseudowire class.

Command Default

Routers do not form a point-to-point Layer 2 VFI connection.

Command Modes

L2 VFI point-to-point configuration (config-vfi)

Command History

Release	Modification
12.0(31)S	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.

Usage Guidelines

A maximum of two **neighbor** commands are allowed when you issue an **l2 vfi point-to-point** command.

Examples

The following example is a typical configuration of a Layer 2 VFI connection:

```
Router(config)# l2 vfi atom point-to-point
Router(config-vfi)# neighbor 10.10.10.10 1 encapsulation mpls
```

Related Commands

Command	Description
l2 vfi point-to-point	Establishes a point-to-point Layer 2 VFI between two separate networks.

neighbor (VPLS)

To specify the type of tunnel signaling and encapsulation mechanism for each Virtual Private LAN Service (VPLS) peer, use the **neighbor** command in L2 VFI manual configuration mode. To disable a split horizon, use the **no** form of this command.

neighbor *remote-router-id* *vc-id* {**encapsulation** *encapsulation-type*| **pw-class** *pw-name*} [**no-split-horizon**]
no neighbor *remote-router-id* [*vc-id*]

Syntax Description

<i>remote-router-id</i>	Remote peer router identifier. The remote router ID can be any IP address, as long as it is reachable.
<i>vc-id</i>	32-bit identifier of the virtual circuit between the routers.
encapsulation	Specifies tunnel encapsulation.
<i>encapsulation-type</i>	Specifies the tunnel encapsulation type; valid values are l2tpv3 and mpls .
pw-class	Specifies the pseudowire class configuration from which the data encapsulation type is taken.
<i>pw-name</i>	Name of the pseudowire class.
no-split-horizon	(Optional) Disables the Layer 2 split horizon forwarding in the data path.

Command Default

Split horizon is enabled.

Command Modes

L2 VFI manual configuration (config-vfi)

Command History

Release	Modification
12.2(18)SXF	This command was introduced on the Supervisor Engine 720.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was modified. This command was updated so that the remote router ID need not be the LDP router ID of the peer.
Cisco IOS XE Release XE 3.7S	This command was integrated into Cisco IOS XE Release XE 3.7S.

Usage Guidelines

In a full-mesh VPLS network, keep split horizon enabled to avoid looping.

With the introduction of VPLS Autodiscovery, the remote router ID no longer needs to be the LDP router ID. The address that you specify can be any IP address on the peer, as long as it is reachable. When VPLS Autodiscovery discovers peer routers for the VPLS, the peer router addresses might be any routable address.

Examples

This example shows how to specify the tunnel encapsulation type:

```
Device(config-vfi) # l2 vfi vfi-1 manual
Device(config-vfi) # vpn 1
Device(config-vfi) # neighbor 172.16.10.2 4 encapsulation mpls
```

This example shows how to disable the Layer 2 split horizon in the data path:

```
Device(config-vfi) # l2 vfi vfi-1 manual
Device(config-vfi) # vpn 1
Device(config-vfi) # neighbor 172.16.10.2 4 encapsulation mpls no-split-horizon
```

Related Commands

Command	Description
l2 vfi manual	Creates a Layer 2 VFI.

nsf (OTV)

To enable nonstop forwarding (NSF) operations for Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS), use the **nsf** command in OTV IS-IS instance configuration mode. To disable OTV IS-IS NSF and remove OTV IS-IS NSF configuration, use the **no** form of this command.

nsf {**cisco**|**interval** *minutes*}

nsf {**cisco**|**interval**}

Syntax Description

cisco	Specifies the Cisco proprietary IS-IS NSF method of checkpointing if the active Route Processor (RP) fails over.
interval <i>minutes</i>	Specifies how long to wait after an RP stabilizes before restarting. The range is from 0 to 1440.

Command Default

NSF Cisco is enabled by default on a dual RP platform when an IS-IS overlay instance is created. The default NSF interval is 5 minutes.

Command Modes

OTV IS-IS instance configuration (config-otv-isis)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The **cisco** and **interval** keywords are available only on a dual RP platform.

Examples

The following example shows how to configure an IS-IS NSF interval as 10 minutes:

```
Router# configure terminal
Router(config)# otv isis overlay 1
Router(config-otv-isis)# nsf interval 10
Router(config-otv-isis)# end
```

Related Commands

Command	Description
otv isis overlay	Creates an OTV overlay interface.
show otv isis	Displays IS-IS status and configuration.

oam-ac emulation-enable

To enable Operation, Administration, and Maintenance (OAM) cell emulation on ATM adaptation layer 5 (AAL5) over Multiprotocol Label Switching (MPLS) or Layer 2 Tunnel Protocol Version 3 (L2TPv3), use the **oam-ac emulation-enable** command in the appropriate configuration mode on both provider edge (PE) routers. To disable OAM cell emulation, use the **no** form of this command on both routers.

oam-ac emulation-enable [*seconds*]

no oam-ac emulation-enable

Syntax Description

<i>seconds</i>	(Optional) The rate (in seconds) at which the alarm indication signal (AIS) cells should be sent. The range is 0 to 60 seconds. If you specify 0, no AIS cells are sent. The default is 1 second, which means that one AIS cell is sent every second.
----------------	---

Command Default

OAM cell emulation is disabled.

Command Modes

L2transport PVC configuration--for an ATM PVC VC class configuration mode--for a VC class

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.0(30)S	This command was updated to enable OAM cell emulation as part of a virtual circuit (VC) class.
12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4(11)T	This command was integrated into Cisco IOS Release 12.4(11)T.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.

Release	Modification
15.0(1)S	This command was integrated into Cisco IOS Release 15.0(1)S.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

This command is used with AAL5 over MPLS or L2TPv3 and is not supported with ATM cell relay over MPLS or L2TPv3.

Examples

The following example shows how to enable OAM cell emulation on an ATM permanent virtual circuit (PVC):

```
Router# interface ATM 1/0/0
Router(config-if)# pvc 100 12transport
Router(config-if-atm-l2trans-pvc)# oam-ac emulation-enable
```

The following example shows how to set the rate at which an AIS cell is sent every 30 seconds:

```
Router# interface ATM 1/0/0
Router(config-if)# pvc 100 12transport
Router(config-if-atm-l2trans-pvc)# oam-ac emulation-enable 30
```

The following example configures OAM cell emulation for ATM AAL5 over MPLS in VC class configuration mode. The VC class is then applied to an interface.

```
Router> enable
Router# configure terminal
Router(config)# vc-class atm oamclass
Router(config-vc-class)# encapsulation aal5
Router(config-vc-class)# oam-ac emulation-enable 30
Router(config-vc-class)# oam-pvc manage
Router(config)# interface atm1/0
Router(config-if)# class-int oamclass
Router(config-if)# pvc 100 12transport
Router(config-if-atm-l2trans-pvc)# xconnect 10.13.13.13 100 encapsulation mpls
```

Related Commands

Command	Description
show atm pvc	Displays all ATM PVCs and traffic information.

optimize tfo

To enable WAAS Express Transport Flow Optimization (TFO), use the **optimize tfo** command in QoS policy-map class configuration mode. To disable the WAAS Express TFO optimization, use the **no** form of this command.

optimize tfo [**dre**] [**lz**] **application** *application-name* [**accelerate** {**cifs-express**| **http-express**}]

no optimize tfo [**dre**] [**lz**] **application** *application-name* [**accelerate** {**cifs-express**| **http-express**}]

Syntax Description

dre	Enables Data Redundancy Elimination (DRE) and TFO.
lz	Enables Lempel-Ziv (LZ) and TFO.
application <i>application-name</i>	Specifies the class-map application name.
accelerate	(Optional) Enables the specified accelerator.
cifs-express	(Optional) Enables the Common Internet File System (CIFS)-Express accelerator.
http-express	(Optional) Enables the HTTP-Express accelerator.

Command Default

The default optimization is pass-through.

Command Modes

QoS policy-map class configuration (config-pmap-c)

Command History

Release	Modification
15.1(2)T	This command was introduced.
15.2(3)T	This command was modified. The accelerate , cifs-express , and http-express keywords were added.

Usage Guidelines

Use this command to apply optimizations for WAN traffic.

WAAS Express uses a variety of TFO features to optimize TCP traffic intercepted by WAAS devices. TFO protects communicating clients and servers from negative WAN conditions, such as bandwidth constraints, packet loss, congestion, and retransmission. In addition to TFO, WAAS Express provides acceleration benefits by supporting CIFS-Express, HTTP-Express, and Secure Sockets Layer (SSL)-Express accelerators.

WAAS Express uses the following optimization technologies based on the type of traffic it encounters:

- TFO—A collection of optimization technologies such as automatic windows scaling, increased buffering, and selective acknowledgment that optimize all TCP traffic over your network.
- DRE—A compression technology that reduces the size of transmitted data by removing redundant information before sending the shortened data stream over the WAN. DRE operates on significantly larger streams and maintains a much larger compression history than LZ compression.
- LZ—A compression technology that operates on smaller data streams and keeps limited compression history compared to DRE.
- Accelerator—A collection of individual accelerators for the following traffic types: CIFS, HTTP, and SSL.

**Note**

If you do not use this command, pass-through optimization is applied on the WAN traffic.

You can also use the **accelerator cifs-express** command, the **accelerator http-express** command, and the **accelerator ssl-express** command in parameter map type configuration mode to enable CIFS-Express accelerator, HTTP-Express accelerator, and SSL-Express accelerator, respectively.

Examples

The following example shows how to enable TFO and LZ optimizations:

```
Device(config)# policy-map type waas_global
Device(config-pmap)# class AFS
Device(config-pmap-c)# optimize tfo lz application Filesystem
Device(config-pmap-c)# exit
Device(config-pmap)# exit
```

The following example shows how to enable TFO, DRE, and LZ optimizations on a Web application:

```
Device(config)# policy-map type waas_global
Device(config-pmap)# class Http
Device(config-pmap-c)# optimize tfo dre lz application Web
Device(config-pmap-c)# exit
Device(config-pmap)# exit
```

The following example shows how to enable TFO, DRE, and LZ optimizations on a Web application and also enable HTTP-Express accelerator:

```
Device(config)# policy-map type waas_global
Device(config-pmap)# class Http
Device(config-pmap-c)# optimize tfo dre lz application Web accelerate http-express
Device(config-pmap-c)# exit
Device(config-pmap)# exit
```

Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
class	Associates a map class with a specified DLCI.
passthrough	Allows traffic without optimization.
policy-map type waas	Defines a WAAS Express policy map.

Command	Description
sequence-interval	Assigns sequential numbering to class maps.

otv active-source

To add a static active multicast source address for simulating a stream of multicast traffic emanating from an Overlay Transport Virtualization (OTV) site, use the **otv active-source** command in service instance configuration mode. To return to the default setting, use the **no** form of this command.

otv active-source *source-address group-address*

no otv active-source *source-address group-address*

Syntax Description

<i>source-address</i>	IPv4 or IPv6 unicast address of a multicast source.
<i>group-address</i>	IPv4 or IPv6 multicast address of a multicast group.

Command Default

The static active multicast source is not configured.

Command Modes

Service instance configuration (config-if-srv)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

This command preprovisions a mapping of the configured internal site multicast group to a multicast group in the core, even when no traffic is flowing for that multicast stream. Once the multicast traffic starts flowing, it will be sent over the overlay using the preprovisioned multicast mapping. As with all multicast mappings, a mapping is advertised by Intermediate System-to-Intermediate System (IS-IS) when the edge device is authoritative.

Examples

The following example shows how to add a static active multicast source address:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# service instance 10 ethernet
Router(config-if-srv)# otv active-source 192.0.2.250 232.2.2.20
Router(config-if-srv)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.

Command	Description
service instance ethernet	Configures an Ethernet service instance on an interface.
show otv	Displays information about OTV.

otv adjacency-server unicast-only

To configure a local edge device as an adjacency server in a unicast-core network, use the **otv adjacency-server unicast-only** command in interface configuration mode. To remove the adjacency server configuration from an edge device, use the **no** form of this command.

otv adjacency-server unicast-only

no otv adjacency-server unicast-only

Syntax Description This command has no arguments or keywords.

Command Default An adjacency server is not configured.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 3.9S	This command was introduced.

Usage Guidelines To enable the OTV Adjacency Server feature, use the **otv adjacency-server unicast-only** command to configure an Overlay Transport Virtualization (OTV) edge device as a primary adjacency server and optionally configure another edge device as a secondary adjacency server as a backup. The remaining edge devices in the overlay network are configured to register to the primary and secondary adjacency servers by using the **otv use-adjacency-server unicast-only** command. Configure adjacency servers in a network where the provider core does not support multicast capability. The **otv adjacency-server unicast-only** command specifies that the device is not multicast-capable for the overlay network.

The configuration of multicast-core-specific commands and unicast-core-specific adjacency server commands is mutually exclusive. Therefore, if the **otv control-group** command or the **otv data-group** command is configured, the adjacency server commands are not allowed until the previous commands are disabled. Similarly, after an adjacency server command is configured, the **otv control-group** and **otv data-group** commands return errors until the adjacency server commands have been disabled.

Examples The following example shows how to configure a local edge device as an adjacency server:

```
Device# configure terminal
Device(config)# interface overlay 1
Device(config-if)# otv adjacency-server unicast-only
Device(config-if)# end
```

The following example shows how to remove a local edge device from acting as an adjacency server:

```
Device# configure terminal
Device(config)# interface overlay 1
Device(config-if)# no otv adjacency-server unicast-only
Device(config-if)# end
```

Related Commands

Command	Description
otv control-group	Configures the IP multicast group address for the control and broadcast traffic for the specified OTV network.
otv data-group	Configures one or more ranges of core provider multicast group prefixes for multicast data traffic for the specified OTV network.
otv use-adjacency-server unicast-only	Configures a local edge device to use a remote adjacency server in a unicast-core network.
show otv adjacency-server replication-list	Displays the list of unicast destinations for which multicast traffic is replicated.

otv control-group

To configure the IP multicast group address for the control and broadcast traffic for the specified Overlay Transport Virtualization (OTV) network, use the **otv control-group** command in interface configuration mode. To remove the multicast group address, use the **no** form of this command.

otv control-group *multicast-address*

no otv control-group

Syntax Description

<i>multicast-address</i>	External multicast group address for the OTV overlay network control traffic. The multicast group address is an IPv4 address in dotted decimal notation.
--------------------------	--

Command Default

The multicast group address for the specified OTV network is not configured.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

Use the **otv control-group** command to configure the multicast group address for control traffic for the specified OTV overlay network and for customer broadcast traffic. Intermediate System-to-Intermediate System (IS-IS), broadcast, and other control packets sent toward the overlay are addressed to the specified multicast address to reach all other sites in the VPN.

Performing this command more than once on the same overlay interface will overwrite the existing addresses.



Note

The OTV overlay interface cannot come up if you do not configure this command.

Examples

The following example shows how to configure the multicast group address for the OTV control traffic:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv control-group 232.1.1.1
Router(config-if)# end
```

Related Commands

Command	Description
otv data-group	Configure one or more ranges of core provider multicast group prefixes for multicast data traffic for the specified OTV network.
show otv	Displays information about OTV.

otv data-group

To configure one or more ranges of core provider multicast group prefixes for multicast data traffic for the specified Overlay Transport Virtualization (OTV) network, use the **otv data-group** command in interface configuration mode. To remove the multicast group address, use the **no** form of this command.

otv control-group *multicast-address/mask*

no otv control-group *multicast-address/mask*

Syntax Description

<i>multicast-address/mask</i>	Multicast group range used for multicast data traffic over the overlay network, in IPv4 dotted decimal notation. A subnet mask is used to indicate ranges of addresses. The maximum number of ranges that can be configured is 8.
-------------------------------	---

Command Default

Range of multicast group prefixes for multicast data traffic for the specified OTV network

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

Use the **otv data-group** command to configure a group of multicast addresses used to transmit multicast data across the overlay. Packets from the site that are destined to multicast addresses get mapped to one of these overlay multicast addresses. None of the data-group range addresses may overlap with addresses used by different overlays.

This command may be performed more than once for an overlay, in which case, the addresses will be added to the existing list of data-group addresses.



Note

The OTV overlay interface cannot come up if you do not configure this command.

Examples

The following example shows how to configure multicast group address for the OTV data traffic:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv data-group 232.1.1.0/8
Router(config-if)# end
```

Related Commands

Command	Description
otv control-group	Configures the IP multicast group address for the control and broadcast traffic for the specified OTV network.
show otv	Displays information about OTV.

otv filter-fhrp

To enable filtering of First Hop Redundancy Protocol (FHRP) control packets, such as Hot Standby Router Protocol (HSRP), Virtual Router Redundancy Protocol (VRRP), and Gateway Load Balancing Protocol (GLBP), sent towards an Overlay Transport Virtualization (OTV) overlay network, use the **otv filter-fhrp** command in interface configuration mode. To disable the filtering of these packets, use the **no** form of this command.

otv filter-fhrp

no otv filter-fhrp

Syntax Description This command has no arguments or keywords.

Command Default Filtering is on by default.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines The HSRP/VRRP/GLBP packets being exchanged between routers in the same site are filtered from going over the overlay. This command enables filtering of FHRP control packets so that FHRP devices in different sites do not peer with each other. However, you can use the same virtual IP in multiple sites by performing additional configuration. Perform the following steps to use the same virtual IP in multiple sites:

- 1 Enable the **otv filter-fhrp** command to filter HSRP/VRRP/GLBP protocol data units (PDUs).
- 2 Create a Layer 2 access control list (L2ACL) to filter packets sourced from the FHRP device's virtual MAC address.
- 3 Apply the L2ACL to overlay Ethernet Flow Points (EFPs) in the out direction:

```
! HSRP L2ACL
mac access-list extended filter_hsrp
deny 0000.0c07.ac00 0000.0000.00ff any
permit any any

! GLBP L2ACL
mac access-list extended filter_glbp
deny 0007.b400.0000 0000.00ff.ffff any
permit any any

! VRRP L2ACL
mac access-list extended filter_vrrp
deny 0000.5e00.0100 0000.0000.00ff any
permit any any

interface Overlay1
service instance 120 ethernet
```



```
encapsulation dot1q 120
mac access-group filter_hsrp out
bridge-domain 120
```

- 4 Configure FHRP domains in different sites with different group numbers so that each site uses a unique virtual MAC address. Because the HSRP/VRRP/GLBP group number is included in the virtual MAC address, configuring a unique group in each site will ensure that the virtual MACs are also unique.

HSRP Usage:
standby [group-number] ip [ip-address [secondary]]

GLBP Usage:
glbp group-number ip [ip-address [secondary]]

VRRP Usage:
vrrp group-number ip ip-address

Examples

The following example shows how to enable filtering of HSRP/VRRP/GLBP packets on overlay interface 1:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv filter-fhrp
Router(config-if)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.

otv fragmentation

To allow fragmentation of IP packets sent on an Overlay Transport Virtualization (OTV) overlay network using the specified join interface, use the **otv fragmentation** command in global configuration mode. To disable the fragmentation of IP packets, use the **no** form of this command.

otv fragmentation join-interface *type number*

no otv fragmentation join-interface *type number*

Syntax Description

join-interface	Enables fragmentation of IP packets by using the specified join interface.
<i>type</i>	The type of interface to be configured.
<i>number</i>	Port, connector, or interface card number. The numbers are assigned at the factory at the time of installation or when added to a system; they can be displayed with the show interfaces command.

Command Default

Fragmentation of IP packets is not configured in an overlay network.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The result of configuring the **otv fragmentation** command is that the Don't Fragment (DF) bit in an IP header is set to zero. By default, all packets sent on an overlay are sent with the DF bit set to one.

This command should be used only if all edge devices in the overlay support reassembly in hardware.

Examples

The following example shows how to enable fragmentation of IP packets on join interface 1:

```
Router# configure terminal
Router(config)# otv fragmentation join-interface gigabitethernet 0/0/5
Router(config)# end
```

Related Commands

Command	Description
show otv	Displays information about OTV.

otv isis authentication

To configure the Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) authentication on an overlay interface, use the **otv isis authentication** command in interface configuration mode or OTV site configuration mode. To remove the authentication, use the **no** form of this command.

otv isis authentication {**key-chain** *key-chain-name*| **mode** {**md5**| **text**}| **send-only**}

no otv isis authentication {**key-chain** *key-chain-name*| **mode** {**md5**| **text**}| **send-only**}

Syntax Description

key-chain	Configures the authentication key chain string.
<i>keychain-name</i>	Authentication key chain. The <i>key-chain-name</i> argument is case-sensitive and can be an alphanumeric string of up to 16 characters in length.
mode	Configures the authentication type.
md5	Specifies the message digest algorithm 5 (MD5) authentication method.
text	Specifies the cleartext authentication method.
send-only	Disables the authentication check on incoming hello protocol data units (PDUs) on an overlay interface and allows the sending of only authinfo.

Command Default

No IS-IS authentication is configured by default.

Command Modes

Interface configuration (config-if)
OTV site configuration (config-otv-site)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The **otv isis authentication** command is used to configure authentication for hello PDUs.

Examples

The following example shows how to configure IS-IS authentication on an overlay interface:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis authentication key-chain OTV
Router(config-if)# otv isis authentication mode md5
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis csnp-interval

To configure the interval in seconds between complete sequence number protocol data units (PDUs) (CSNPs) sent on the Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) interface, use the **otv isis csnp-interval** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

otv isis csnp-interval *seconds*

no otv isis csnp-interval *seconds*

Syntax Description

<i>seconds</i>	Interval in seconds. The range is from 0 to 65535.
----------------	--

Command Default

The default CSNP interval is 10 seconds.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The **otv isis csnp-interval** command applies only for the designated router (DR) for a specified interface. The CSNP interval can be configured independently for Level 1. Configuring the CSNP interval does not apply to serial point-to-point interfaces.

Examples

The following example shows how to specify the interval between CSNPs on an interface:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis csnp-interval 100
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis hello-interval

To configure the interval between hello protocol data units (PDUs) sent on the Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) interface, use the **otv isis hello-interval** command in interface configuration mode or OTV site configuration mode. To return to the default setting, use the **no** form of this command.

otv isis hello-interval {*seconds*| **minimal**}

no otv isis hello-interval {*seconds*| **minimal**}

Syntax Description

<i>seconds</i>	Interval in seconds. The range is from 1 to 65535.
minimal	Specifies the minimum interval, which is 1 second by default. The hello interval in this case depends on the hello multiplier.

Command Default

The default hello interval is 10 seconds.

Command Modes

Interface configuration (config-if)
OTV site configuration (config-otv-site)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure the hello interval in seconds:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis hello-interval 30
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis hello-multiplier

To configure a multiplier used to calculate the interval within which hello protocol data units (PDUs) must be received on Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) instance to keep adjacency up, use the **otv isis hello-multiplier** command in interface configuration mode or OTV site configuration mode. To return to the default setting, use the **no** form of this command.

otv isis hello-multiplier *multiplier*

no otv isis hello-multiplier *multiplier*

Syntax Description

<i>multiplier</i>	Hello multiplier value. The range is from 3 to 1000.
-------------------	--

Command Default

The default hello multiplier is 3.

Command Modes

Interface configuration (config-if)
OTV site configuration (config-otv-site)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

Use the **otv isis hello-multiplier** command when hello packets are lost frequently and IS-IS adjacencies are failing. You can raise or lower the hello multiplier (**otv isis hello-multiplier** command) to make the hello protocol more reliable without increasing the time required to detect a link failure.

Examples

The following example shows how to configure a multiplier for a hello holding time:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis hello-multiplier 30
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis hello padding

To enable Overlay Transport Virtualization (OTV) Intermediate-System-to-Intermediate System (IS-IS) hello protocol data unit (PDU) padding, use the **otv isis hello padding** command in interface configuration mode or OTV site configuration mode. To disable IS-IS hello PDU padding, use the **no** form of this command.

otv isis hello padding

no otv isis hello padding

Syntax Description This command has no arguments or keywords.

Command Default OTV IS-IS hello padding is enabled by default.

Command Modes Interface configuration (config-if)
OTV site configuration (config-otv-site)

Command History	Release	Modification
	Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines Padding adds extra characters to the hello packets so that all packets sent out by IS-IS have the maximum sized data payload.

IS-IS hello PDUs are padded to the full maximum transmission unit (MTU) size. Padding IS-IS hellos to the full MTU allows early detection of errors that may result either from transmission problems with large frames or from mismatched MTUs on adjacent interfaces.

You can disable hello padding to avoid wasting network bandwidth if the MTU of both interfaces is the same or for translational bridging. While hello padding is disabled, Cisco routers still send the first five IS-IS hellos padded to the full MTU size to maintain the benefits of discovering MTU mismatches.

Examples The following example shows how to enable OTV IS-IS hello PDU padding:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis hello padding
Router(config-if)# end
```

Related Commands	Command	Description
	show otv isis	Displays the IS-IS status and configuration.

otv isis lsp-interval

To configure the interval between Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) link-state packet (LSP) protocol data units (PDUs) sent on the interface during flooding, use the **otv isis lsp-interval** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

otv isis lsp-interval *milliseconds*

no otv isis lsp-interval *milliseconds*

Syntax Description

<i>milliseconds</i>	LSP transmission interval in milliseconds. The range is from 1 to 4294967295.
---------------------	---

Command Default

The default LSP interval is 33 milliseconds.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure an LSP transmission interval:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis lsp-interval 30
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis metric

To configure the value of an Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) metric on an interface, use the **otv isis metric** command in interface configuration mode. To return to the default metric value, use the **no** form of this command.

otv isis metric {*metric*| **maximum**} [*delay-metric*| *expense-metric*| *error-metric*]

no otv isis metric {*metric*| **maximum**} [*delay-metric*| *expense-metric*| *error-metric*]

Syntax Description

<i>metric</i>	Metric on the interface. The range is from 1 to 16777214.
maximum	Specifies the maximum metric value.
<i>delay-metric</i>	(Optional) Delay metric on the interface. The range is from 1 to 16777214.
<i>expense-metric</i>	(Optional) Expense metric on the interface. The range is from 1 to 16777214.
<i>error-metric</i>	(Optional) Error metric on the interface. The range is from 1 to 16777214.

Command Default

The default IS-IS level 1 metric is 10.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure the metric for an interface:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis metric 30
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis overlay

To create an Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) instance, use the **otv isis overlay** command in global configuration mode. To return the OTV IS-IS instance to its default configuration, use the **no** form of this command.

otv isis overlay *interface*

no otv isis overlay *interface*

Syntax Description

<i>interface</i>	Number that you assign to the overlay interface. The range is from 0 to 512.
------------------	--

Command Default

The IS-IS overlay instance is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

You can also create an overlay instance by using the **interface overlay** command. An IS-IS overlay instance is automatically created when you use either the **interface overlay** command or the **otv isis overlay** command.

The **no otv isis overlay** command does not remove the IS-IS overlay instance; it only returns the IS-IS overlay instance to its default configuration. The **no interface overlay** command removes the IS-IS overlay instance.

Use the **otv isis overlay** command to enter OTV IS-IS instance configuration mode.

Examples

The following example shows how to create an OTV IS-IS overlay instance:

```
Router# configure terminal
Router(config)# otv isis overlay 1
Router(config-otv-isis)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.

otv isis priority

To configure the Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) priority for a Designated Intermediate System (DIS) election on the interface, use the **otv isis priority** command in interface configuration mode or OTV site configuration mode. To return to the default setting, use the **no** form of this command.

otv isis priority *value*

no otv isis priority *value*

Syntax Description

<i>value</i>	Priority value. The range is from 0 to 127.
--------------	---

Command Default

The default IS-IS priority is 64.

Command Modes

Interface configuration (config-if)
OTV site configuration (config-otv-site)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure the OTV priority for a DIS election on an interface:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis priority 1
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis retransmit-interval

To configure the time interval between retransmission of each Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) link-state packet (LSP) on the interface, use the **otv isis retransmit-interval** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

otv isis retransmit-interval *seconds*

no otv isis retransmit-interval

Syntax Description

<i>seconds</i>	Time in seconds between retransmission of the same LSP. The range is from 0 to 65535.
----------------	---

Command Default

The default retransmission interval for an LSP is 5 seconds.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure the retransmission interval as 20 seconds:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis retransmit-interval 20
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis retransmit-throttle-interval

To configure the link-state packet (LSP) retransmission interval, use the **otv isis retransmit-throttle-interval** command in interface configuration mode. To remove the configuration, use the **no** form of this command.

otv isis retransmit-throttle-interval *milliseconds*

no otv isis retransmit-throttle-interval

Syntax Description

<i>milliseconds</i>	Time in milliseconds between retransmitted LSPs. The range is from 0 to 65535.
---------------------	--

Command Default

The default LSP retransmission throttle interval is 0 milliseconds.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example show to configure the LSP retransmission interval:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv isis retransmit-throttle-interval 12
Router(config-if)# end
```

Related Commands

Command	Description
show otv isis	Displays the IS-IS status and configuration.

otv isis site

To create an Overlay Transport Virtualization (OTV) Intermediate System-to-Intermediate System (IS-IS) site instance, use the **otv isis site** command in global configuration mode. To return the OTV IS-IS site instance to its default configuration, use the **no** form of this command.

otv isis site

no otv isis site

Syntax Description This command has no arguments or keywords.

Command Default The IS-IS site instance is not configured.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines An IS-IS site instance is created automatically when one of the following configurations happen:

- An IS-IS overlay instance is created. You can create an overlay instance by using the **interface overlay** command or the **otv isis overlay** command.
- The **otv site-identifier** command is configured.
- The **otv isis site** command is configured.

An IS-IS site instance will be removed in the following scenarios:

- When the last IS-IS overlay instance is removed using the **no interface overlay** command. The IS-IS site instance, in this scenario, is removed only if either of the following is also true:
 - The site identifier configuration is removed using the **no otv site-identifier** command.
 - There is no non-default configuration for the IS-IS site instance.
- When the site identifier configuration is removed using the **no otv site-identifier** command. The IS-IS site instance, in this scenario, is removed only if the following are also true:
 - No IS-IS overlay instance exists.
 - There is no non-default configuration for the IS-IS site instance.
- When there is no IS-IS overlay instance or site identifier, the **no otv isis site** command will remove the IS-IS site instance, irrespective of whether there is a site instance with default configuration. If there is

at least one IS-IS overlay instance or a site identifier configured, the **no otv isis site** command will not remove the IS-IS site instance; instead, the command will return the IS-IS site instance to its default configuration.

The IS-IS site instance does not generate Link State Packets (LSPs) or run Shortest Path First (SPF) computations.

Examples

The following example shows how to create an OTV IS-IS site instance:

```
Router# configure terminal
Router(config)# otv isis site
Router(config-otv-isis)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.
show otv site	Displays the OTV site information .

otv join-interface

To associate an Overlay Transport Virtualization (OTV) overlay interface to an external interface, use the **otv join-interface** command in interface configuration mode. To remove that interface from the overlay interface, use the **no** form of this command.

otv join-interface *type number*

no otv join-interface *type number*

Syntax Description

<i>type</i>	The type of interface to be configured.
<i>number</i>	Port, connector, or interface card number. The numbers are assigned at the factory at the time of installation or when added to a system; they can be displayed with the show interfaces command.

Command Default

The interface is not configured as an overlay interface.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

This command configures the interface over which an overlay is formed. The IP of the specified interface is used as the source address of packets sourced from the edge device. Therefore, you must ensure that the IP address on the physical interface is configured. You can specify only one join interface per overlay.



Note

The OTV overlay interface cannot come up if you do not configure this command.



Note

The join interface must belong to the default VPN routing and forwarding (VRF) instance.

Examples

The following example shows how to associate an external interface on an OTV edge device to the specified overlay interface:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv join-interface gigabitethernet 0/0/5
Router(config-if)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.

otv mac flood

To flood the specified destination MAC address to all other edge devices in the Overlay Transport Virtualization (OTV) overlay network and to all unblocked local ports in the bridge domain, use the **otv mac flood** command in service instance configuration mode. To disable the flooding of the specified MAC address, use the **no** form of this command.

otv mac flood *mac-address*

no otv mac flood *mac-address*

Syntax Description

<i>mac-address</i>	Hexadecimal representation of the MAC address.
--------------------	--

Command Default

Traffic is not flooded with the destination MAC address.

Command Modes

Service instance configuration (config-if-srv)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

This command supports unidirectional MAC forwarding used by technologies such as Microsoft Network Load Balancing (NLB). The specified MAC is not advertised by Intermediate System-to-Intermediate System (IS-IS).

Examples

The following example shows how to flood the specified MAC address to all edge devices in the overlay and to all unblocked local ports in the bridge domain:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# service instance 10 ethernet
Router(config-if-srv)# otv mac flood 0005.9A3C.7810
Router(config-if-srv)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
service instance ethernet	Configures an Ethernet service instance on an interface.
show otv	Displays information about OTV.

otv site bridge-domain

To configure a bridge domain for sending Intermediate System-to-Intermediate System (IS-IS) hellos over site interfaces, use the **otv site bridge-domain** command in global configuration mode. To remove the bridge domain configuration, use the **no** form of this command.

otv site bridge-domain *bridge-domain-ID*

no otv site bridge-domain

Syntax Description

<i>bridge-domain-ID</i>	Bridge domain ID. The range is from 1 to 4096.
-------------------------	--

Command Default

The bridge domain is not configured for a site.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The same site bridge domain is used for all configured overlays. Interfaces facing the site network must be configured with this bridge domain for IS-IS hellos to reach other edge devices in the same site network. This command may be configured even if the specified bridge domain does not yet exist. IS-IS site hellos will not be sent until the specified bridge domain has been configured on one or more access port service instances.

This command needs to be configured before an edge device can become an authoritative edge device (AED).

Examples

The following example shows how to configure a site bridge domain:

```
Router# configure terminal
Router(config)# otv site bridge-domain 1
Router(config-otv-site)# end
```

Related Commands

Command	Description
show otv	Displays information about OTV.

otv site-identifier

To configure a site identifier for an Overlay Transport Virtualization (OTV) site, use the **otv site-identifier** command in global configuration mode. To remove the site-identifier configuration, use the **no** form of this command.

otv site-identifier *{siteID-hex|siteID-mac}*

no otv site-identifier

Syntax Description

<i>siteID-hex</i>	Site ID in hexadecimal format.
<i>siteID-mac</i>	Site ID in MAC format.

Command Default

The site ID is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

All edge devices connected to the same site must have the same site identifier configured. The **otv site-identifier** command needs to be configured before an edge device can become an authoritative edge device (AED).

Examples

The following example shows how to configure a site ID:

```
Router# configure terminal
Router(config)# otv site-identifier 0005.0005.0005
Router(config)# end
```

Related Commands

Command	Description
otv site bridge-domain	Configures a bridge domain for sending IS-IS hellos over site interfaces.
show otv site	Displays OTV site information.

otv suppress arp-nd

To suppress sending IPv4 Address Resolution Protocol (ARP) requests over an overlay network, use the **otv suppress-arp-nd** command in interface configuration mode. To allow sending ARP requests over the overlay network, use the **no** form of this command.

otv suppress arp-nd

no otv suppress arp-nd

Syntax Description This command has no arguments or keywords.

Command Default ARP requests are suppressed by default.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines When sending of ARP requests is suppressed, this command performs caching of Layer 3-to-Layer 2 address mappings by snooping on ARP packets. Broadcast ARP requests received from the site for which a cache entry exists are then responded to by edge devices on the behalf of remote hosts. Because the edge devices respond to ARP requests, the number of broadcast and multicast packets sent on the overlay is significantly reduced.

Examples The following example shows how to allow sending ARP packets on an overlay network:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# no otv suppress arp-nd
Router(config-if)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.

otv use-adjacency-server unicast-only

To configure a local edge device to use a remote adjacency server in a unicast-core network, use the **otv use-adjacency-server unicast-only** command in interface configuration mode. To return to the default settings on the edge device, use the **no** form of this command.

otv use-adjacency-server *primary-address* [*secondary-address*] **unicast-only**

no otv use-adjacency-server *primary-address* [*secondary-address*] **unicast-only**

Syntax Description

<i>primary-address</i>	IP address of the remote adjacency server. The IP address format must be in dotted decimal notation.
<i>secondary-address</i>	(Optional) IP address of the backup adjacency server. The IP address format must be in dotted decimal notation. This address is available only if a backup adjacency server has been configured.

Command Default

An edge device is not configured to use an adjacency server and is assumed to be multicast-capable.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.9S	This command was introduced.

Usage Guidelines

The primary and secondary IP addresses specified in the **otv use-adjacency-server unicast-only** command must match the IP addresses of previously configured adjacency servers. The **otv use-adjacency-server unicast-only** command specifies that the device is not multicast-capable for the overlay network.

Examples

The following example shows how to configure a local edge device to use an adjacency server in a unicast-core network:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv use-adjacency-server 192.0.2.1 unicast-only
Router(config-if)# end
```

Related Commands

Command	Description
otv adjacency-server unicast-only	Configures a local edge device as an adjacency server in a unicast-core network.
show otv adjacency-server replication-list	Displays the list of unicast destinations for which multicast traffic is replicated.

otv vpn-name

To configure the name of the specified Overlay Transport Virtualization (OTV) VPN, use the **otv vpn-name** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

otv vpn-name *name*

no otv vpn-name

Syntax Description

<i>name</i>	Alias for the OTV overlay interface name. The value is case-sensitive and can be up to 20 alphanumeric characters in length.
-------------	--

Command Default

The VPN name of an OTV network is not configured.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Usage Guidelines

The OTV VPN name configured using this command is used as an alias to the overlay interface name in various OTV **show** commands. The VPN name for the specified overlay is locally significant only on the device. You must have different names for different overlay interfaces on the same device.

Examples

The following example shows how to configure a name for OTV interface 1:

```
Router# configure terminal
Router(config)# interface overlay 1
Router(config-if)# otv vpn-name vpn1
Router(config-if)# end
```

Related Commands

Command	Description
interface overlay	Creates an OTV overlay interface.
show otv	Displays information about OTV.

packet drop during-authorization

To specify that packets received from the user during authorization will be dropped, use the **packet drop during-authorization** command in transparent auto-logon configuration mode. To remove the configuration, use the **no** form of this command.

packet drop during-authorization

no packet drop during-authorization

Syntax Description This command has no arguments or keywords.

Command Default Packet drop during authorization is disabled, and packets from the authorizing user are forwarded.

Command Modes Transparent auto-logon configuration

Command History	Release	Modification
	12.3(1a)BW	This command was introduced.
	12.3(3)B	This command was integrated into Cisco IOS Release 12.3(3)B.
	12.3(7)T	This command was integrated into Cisco IOS Release 12.3(7)T.

Usage Guidelines Use this command for configuring data traffic packet drop for users that are waiting for authorization (WA).

Examples The following example specifies that packets received from the user during authorization will be dropped:

```
Router(config-login-transparent)# packet drop during-authorization
```

Related Commands	Command	Description
	ssg login transparent	Enables the SSG Transparent Autologon feature.

parameter-map type waas

To configure WAAS Express global parameters, use the **parameter-map type waas** command in global configuration mode. To remove global parameters, use the **no** form of this command.

parameter-map type waas *parameter-map-name*

no parameter-map type waas *parameter-map-name*

Syntax Description

<i>parameter-map-name</i>	Name of the parameter map.
Note	The only parameter-map type supported is waas_global .

Command Default

Global parameters are not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.1(2)T	This command was introduced.

Usage Guidelines

This command extends the **parameter-map type** command and enters parameter-map configuration mode. The parameter map type of WAAS can be deleted only if WAAS Express is not enabled on any interface.

Examples

The following example shows how to configure global parameters for WAAS Express:

```
Router> enable
Router# configure terminal
Router(config)# parameter-map type waas waas_global
```

Related Commands

Command	Description
class-map type waas	Configures a WAAS Express class map.
cpu-threshold	Sets the CPU threshold limit.
lz entropy-check	Enables entropy checking to turn on LZ compression.
parameter-map type	Creates or modifies a parameter map.

Command	Description
policy-map type waas	Configures WAAS Express policy map.
tfo auto-discovery blacklist	Configures a blacklist with autodiscovery for WAAS Express.
tfo optimize	Configures compression for WAAS Express.
waas config	Restores or removes WAAS Express default configurations.

passthrough

To pass through match traffic and not apply the WAN optimization, use the **passthrough** command in QoS policy-map class configuration mode. To remove the default optimization, use the **no** form of this command.

passthrough application *application-name*

no passthrough application *application-name*

Syntax Description

application <i>application-name</i>	Specifies the class-map application name.
--	---

Command Default

The default optimization is pass-through.

Command Modes

QoS policy-map class configuration (config-pmap-c)

Command History

Release	Modification
15.1(2)T	This command was introduced.

Usage Guidelines

Use this command if you do not want to specify any optimizations such as Transport Flow Optimization (TFO), Data Redundancy Elimination (DRE), and Lempel-Ziv (LZ) for WAN traffic.

Examples

The following example shows how to specify pass-through optimization for Instant-Messaging:

```
Router(config)# policy-map type waas waas_global
Router(config-pmap)# sequence-interval 111
Router(config-pmap-c)# optimize tfo dre lz application File-System
Router(config-pmap-c)# passthrough application Instant-Messaging
Router(config-pmap-c)# exit
```

Related Commands

Command	Description
class	Associates a map class with a specified DLCI.
policy-map type waas	Defines a WAAS Express policy map.
optimize	Applies WAAS optimization.
sequence-interval	Assigns sequential numbering to class maps.

password

To configure the password used by a provider edge (PE) router for Challenge Handshake Authentication Protocol (CHAP) style Layer 2 Tunnel Protocol Version 3 (L2TPv3) authentication, use the **password** command in L2TP class configuration mode. To disable a configured password, use the **no** form of this command.

password [**0** | **7**] *password*

no password

Syntax Description

[0 7]	(Optional) Specifies the input format of the shared secret. <ul style="list-style-type: none"> • 0 --Specifies that a plain-text secret will be entered. • 7 --Specifies that an encrypted secret will be entered. The default value is 0 .
<i>password</i>	The password used for L2TPv3 authentication.

Command Default

If a password is not configured for the L2TP class with the **password** command, the password configured with the **username password** command in global configuration mode is used. The default input format of the shared secret is **0**.

Command Modes

L2TP class configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.
15.2(02)SA	This command was implemented on the Cisco ME 2600X Series Ethernet Access Switches.

Usage Guidelines

The password hierarchy sequence used for a local and remote peer PE for L2TPv3 authentication is as follows:

- The L2TPv3 password (configured with the **password** command) is used first.
- If no L2TPv3 password exists, the globally configured password (configured with the **username password** command) for the router is used.

**Note**

The use of a special character such as \"\\(backslash) and a three or more digit number for the character setting like **password**, results in incorrect translation.

Examples

The following example sets the password named tunnel2 to be used to authenticate an L2TPv3 session between the local and remote peers in L2TPv3 pseudowires configured with the L2TP class configuration named l2tp class1:

```
Router(config)# l2tp-class l2tp-class1
Router(config-l2tp-class)# authentication
Router(config-l2tp-class)# password tunnel2
```

Related Commands

Command	Description
authentication	Enables L2TPv3 CHAP-style authentication.
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.

password (L2TP)

To configure the password used by a provider edge (PE) router for Layer 2 authentication, use the **password** command in L2TP class configuration mode. To disable a configured password, use the **no** form of this command.

password [*encryption-type*] *password*

no password [*encryption-type*] *password*

Syntax Description

<i>encryption-type</i>	(Optional) Specifies the type of encryption to use. The valid values are from 0 to 7. Currently defined encryption types are 0 (no encryption) and 7 (text is encrypted using an algorithm defined by Cisco). The default encryption type is 0.
<i>password</i>	Specifies the password used for L2TPv3 authentication.

Command Default

If a password is not configured for the L2TP class with the **password** command, the password configured with the **username** command in global configuration mode is used.

Command Modes

L2TP class configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

The password that you define with the **password** command is also used for attribute-value pair (AVP) hiding. The password hierarchy sequence used for a local and remote peer PE for L2TPv3 authentication is as follows:

- The L2TPv3 password (configured with the **password** command) is used first.

- If no L2TPv3 password exists, the globally configured password (configured with the **username password** command) for the router is used.

Examples

The following example sets the password named “tunnel2” to be used to authenticate an L2TPv3 session between the local and remote peers in L2TPv3 pseudowires that has been configured with the L2TP class configuration named “l2tp-class1”:

```
Router(config)
# l2tp-class l2tp-class1
Router(config-l2tp-class)
# authentication
Router(config-l2tp-class)
# password tunnel2
```

Related Commands

Command	Description
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.
username	Establishes a username-based authentication system.

peer-cert-verify enable

To enable the verification of the peer certificate, use the **peer-cert-verify enable** command in SSL peering service configuration mode. To disable the verification of the peer certificate, use the **no** form of this command.

peer-cert-verify enable

no peer-cert-verify enable

Syntax Description This command has no arguments or keywords.

Command Default Verification of the peer certificate is disabled.

Command Modes SSL peering service configuration (config-waas-ssl-peering)

Command History	Release	Modification
	15.2(3)T	This command was introduced.

Usage Guidelines SSL peering service configuration parameters control secure communications established by the SSL accelerator between WAAS devices while optimizing SSL connections. If peer certificate verification is enabled, WAAS Express devices that use self-signed certificates will not be able to establish peering connections to each other and, therefore, will not be able to accelerate SSL traffic.

Before you can enable the **peer-cert-verify enable** command, use the following commands:

- Use the **parameter-map type waas waas_global** command in global configuration mode to enter parameter map configuration mode.
- Use the **accelerator ssl-express** command in parameter map configuration mode to enter WAAS SSL configuration mode.
- Use the **services host-service peering** command in WAAS SSL configuration mode to enter SSL peering service configuration mode.

Examples The following example shows how to enable the verification of the peer certificate:

```
Device(config)# parameter-map type waas waas_global
Device(config-profile)# accelerator ssl-express
Device(config-waas-ssl)# enable
Device(config-waas-ssl)# services host-service peering
Device(config-waas-ssl-peering)# peer-cert-verify enable
```

Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
parameter-map type waas	Configures WAAS Express global parameters.
peer-cipherlist	Creates a cipher list to be used for WAN-to-WAN sessions.
peer-ssl-version	Configures the SSL version to be used for WAAS-to-WAAS sessions.
services host-service peering	Configures the SSL-Express accelerator host peering service.
show waas accelerator	Displays information about WAAS Express accelerators.
show waas statistics accelerator	Displays statistical information about WAAS Express accelerators.

peer-cipherlist

To create a cipher list to be used for WAN-to-WAN sessions, use the **peer-cipherlist** command in SSL peering service configuration mode. To disable the use of a cipher list, use the **no** form of this command.

peer-cipherlist *list-name*

no peer-cipherlist

Syntax Description

<i>list-name</i>	Name of the cipher list.
------------------	--------------------------

Command Default

No cipher list is used.

Command Modes

SSL peering service configuration (config-waas-ssl-peering)

Command History

Release	Modification
15.2(3)T	This command was introduced.

Usage Guidelines

A cipher list is customer list of cipher suites that you assign to an SSL connection.

Before you can enable the **peer-cipherlist** command, use the following commands:

- Use the **parameter-map type waas** command in global configuration mode to enter parameter map configuration mode.
- Use the **accelerator ssl-express** command in parameter map configuration mode to enter WAAS SSL configuration mode.
- Use the **services host-service peering** command in WAAS SSL configuration mode to enter SSL peering service configuration mode.

Examples

The following example shows how to create a cipher list for WAN-to-WAN sessions:

```
Device(config)# parameter-map type waas waas_global
Device(config-profile)# accelerator ssl-express
Device(config-waas-ssl)# enable
Device(config-waas-ssl)# services host-service peering
Device(config-waas-ssl-peering)# peer-cipherlist c-list
```

Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
parameter-map type waas	Configures WAAS Express global parameters.
peer-cert-verify enable	Enables the verification of the peer certificate.
peer-ssl-version	Configures the SSL version to be used for WAAS-to-WAAS sessions.
services host-service peering	Configures the SSL-Express accelerator host peering service.
show waas accelerator	Displays information about WAAS Express accelerators.
show waas statistics accelerator	Displays statistical information about WAAS Express accelerators.

peer-ssl-version

To configure the Secure Sockets Layer (SSL) version to be used for Wide-Area Application Services (WAAS)-to-WAAS sessions, use the **peer-ssl-version** command in SSL peering service configuration mode. To toggle to the other SSL version value, use the **no** form of this command.

peer-ssl-version*ssl-tls-version*

no peer-ssl-version

Syntax Description

<i>ssl-tls-version</i>	SSL or Transport Layer Security (TLS) version. Valid values include ssl3 for SSL Version 3.0 and tls1 for TLS Version 1.0.
------------------------	--

Command Default

TLS Version 1.0 is used for WAAS-to-WAAS sessions.

Command Modes

SSL peering service configuration (config-waas-ssl-peering)

Command History

Release	Modification
15.2(3)T	This command was introduced.

Usage Guidelines

Before you can enable the **peer-ssl-version** command, use the following commands:

- Use the **parameter-map type waas** command in global configuration mode to enter parameter map configuration mode.
- Use the **accelerator ssl-express** command in parameter map configuration mode to enter WAAS SSL configuration mode.
- Use the **services host-service peering** command in WAAS SSL configuration mode to enter SSL peering service configuration mode.



Note

You cannot use the **no** form of the **peer-ssl-version** command while SSL-Express accelerator is enabled. Disable SSL-Express accelerator by using the **no enable** command in WAAS SSL configuration mode, and then enter SSL peering service configuration mode to change the SSL version.

Examples

The following example shows how to configure SSL Version 3.0 to be used for WAAS-to-WAAS sessions:

```
Device(config)# parameter-map type waas waas_global
Device(config-profile)# accelerator ssl-express
Device(config-waas-ssl)# enable
Device(config-waas-ssl)# services host-service peering
Device(config-waas-ssl-peering)# peer-ssl-version ssl3
```

Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
parameter-map type waas	Configures WAAS Express global parameters.
peer-cert-verify enable	Enables the verification of the peer certificate.
peer-cipherlist	Creates a cipher list to be used for WAAS-to-WAAS sessions.
services host-service peering	Configures the SSL-Express accelerator host peering service.
show waas accelerator	Displays information about WAAS Express accelerators.
show waas statistics accelerator	Displays statistical information about WAAS Express accelerators.

policy-map type mace

To configure a Measurement, Aggregation, and Correlation Engine (MACE) policy map and enter policy map configuration mode, use the **policy-map type mace** command in global configuration mode. To remove a MACE policy map, use the **no** form of this command.

policy-map type mace *name*

no policy-map type mace *name*

Syntax Description

<i>name</i>	Name of the MACE policy map. The only accepted value for this argument is mace_global .
-------------	--

Command Default

No MACE policy map is configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.1(4)M	This command was introduced.

Usage Guidelines

Use the **policy-map type mace** command to classify session traffic and run MACE on that traffic. Two types of class maps are supported in a MACE policy map:

- A quality of service (QoS) class map (default type class map)
- A Wide Area Application Services (WAAS) class map

The usage of QoS and WAAS class maps in the MACE policy is independent of QoS or WAAS policies being configured on the routers.

Inside a MACE policy map, you can configure a flow monitor name using only the **flow monitor** command. The name of the flow monitor is used to collect the corresponding flow metrics and to export these flow metrics when the cache timeout is updated.



Note

Only one flow monitor can be configured in a class map.

Examples

The following example shows how to configure the MACE policy map, **mace_global**:

```
Router(config)# policy-map type mace mace_global
```

```
Router(config-pmap) # class class1  
Router(config-pmap-c) # flow monitor name my-flow-monitor
```

Related Commands

Command	Description
class (policy-map)	Specifies the name of the class whose policy you want to create or change or specifies the default class (commonly known as the class-default class) before you configure its policy.
flow monitor	Creates or modifies a Flexible NetFlow flow monitor.
policy-map	Enters policy-map configuration mode, and creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy.

policy-map type waas

To configure a WAAS Express policy map, use the **policy-map type waas** command in global configuration mode. To remove a WAAS Express policy-map, use the **no** form of this command.

policy-map type waas *policy-map-name*

no policy-map type waas *policy-map-name*

Syntax Description

<i>policy-map-name</i>	Name of the class map. Note The only policy-map type supported is waas_global .
------------------------	--

Command Default

No WAAS Express policy maps are configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.1(2)T	This command was introduced.

Usage Guidelines

This command extends the **policy-map** command and enters QoS policy-map configuration mode. The policy-map type of WAAS can be deleted only if WAAS Express is not enabled on any interface.

Examples

The following example shows how to configure a WAAS Express policy map:

```
Router> enable
Router# configure terminal
Router(config)# policy-map type waas waas_global
Router(config-pmap)# class waas_global
```

Related Commands

Command	Description
class	Associates a map class with a specified DLCI.
optimize	Applies optimization to WAN network traffic.
parameter-map type waas	Configures WAAS Express global parameters.

Command	Description
passthrough	Sends the network traffic without applying any optimization.
policy-map	Creates or modifies a policy map.
sequence-interval	Assigns sequential numbering to class maps.
waas config	Restores or removes WAAS Express default configurations.

platform trace runtime process forwarding-manager module mfr

To enable Forwarding Manager Route Processor and Embedded Service Processor trace messages for the multilink frame relay, use the **platform trace runtime process forwarding-manager module mfr** command in the global configuration mode. To disable the Forwarding Manager Route Processor and Embedded Service Processor debug messages, use the **no** form of this command.

platform trace runtime slot *slot* bay *bay* process forwarding-manager module mfr level *level*

no platform trace runtime slot *slot* bay *bay* process forwarding-manager module mfr level *level*

Syntax Description

<i>slot</i>	Shared Port Adapter (SPA) Interprocessor, Embedded Service Processor, or Route Processor slot. Valid options are: <ul style="list-style-type: none">• F0—Embedded Service Processor slot 0• R0—Route Processor slot 0• F1—Embedded Service Processor slot 1• R1—Route Processor slot 1
<i>bay</i>	Chassis bay to be configured. Valid options are: <ul style="list-style-type: none">• 0• 1

level <i>level</i>	<p>Selects the trace level. The trace level determines the amount of information that should be stored about a module in the trace buffer or file.</p> <p>Valid options are:</p> <ul style="list-style-type: none"> • debug —Provides debug-level output. • emergency —Provides information about an issue that makes the system unusable. • error —Provides information about a system error. • info —Provides informational messages. • noise —Provides all possible trace messages pertaining to the module. The noise level is always equal to the highest possible tracing level. • notice —Provides information regarding a significant issue, that does not, however, affect the normal functioning of the router. • verbose —Provides all possible tracing messages. • warning —Provides information about a system warning.
---------------------------	--

Command Default

The default tracing level for every module on the Cisco ASR 1000 Series Routers is notice.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.4S	This command was introduced on the Cisco ASR 1000 Series Routers.

Usage Guidelines

Trace-level settings are leveled, that is, every setting contains all the messages from the lower setting plus the messages from its own setting. For instance, setting the trace level to 3 (error) ensures that the trace file contains all the output for the 0 (emergencies), 1 (alerts), 2 (critical), and 3 (error) settings. Setting the trace level to 4 (warning) ensures that all the trace output for a specific module is included in that trace file.

All trace levels cannot be configured by users. Specifically, the alert, critical, and notice tracing levels cannot be set by users. To trace these messages, set the trace level to a higher level, which collects these messages.

When setting the trace levels, it is also important to remember that the setting is not done in a configuration mode. As a result of this, trace level settings are returned to their defaults after every router reload.

**Caution**

Setting the tracing of a module to the debug level or higher can have a negative performance impact. Setting the tracing to the debug level or higher should be done with discretion.

**Caution**

Setting a large number of modules to high tracing levels can severely degrade performance. If a high level of tracing is needed in a specific context, it is almost always preferable to set a single module on a higher tracing level rather than setting multiple modules to high tracing levels.

Examples

In the following example, the trace level of the Forwarding Processor in the Forwarding Manager of the ESP processor in slot 0 is set to the informational tracing level (info):

```
Router(config)# platform trace runtime slot F0 bay 0 process forwarding-manager module mfr  
level info
```

In the following example, the trace level for the Route Processor in the Forwarding Manager of the ESP processor in slot 0 is set to the informational tracing level (info):

```
Router(config)# platform trace runtime slot r0 bay 0 process forwarding-manager module mfr  
level info
```

Related Commands

Command	Description
show platform software trace level	Displays the trace levels for specified modules.
show platform software trace message	Displays trace messages.

prc-interval (OTV)

To configure the minimum interval between Partial Route Calculations (PRC), use the **prc-interval** command in OTV IS-IS instance configuration mode. To remove the configuration for the PRC interval, use the **no** form of this command.

prc-interval *prc-max-wait* [*prc-initial-wait prc-second-wait*]

no prc-interval

Syntax Description

<i>prc-max-wait</i>	Interval in seconds. The range is from 1 to 120.
<i>prc-initial-wait</i>	(Optional) Initial wait interval in milliseconds. The range is from 1 to 120000.
<i>prc-second-wait</i>	(Optional) Interval in milliseconds between the first and second PRC generation. The range is from 1 to 120000.

Command Default

Layer 2 is configured, by default, with PRC generation intervals of 5 seconds, 50 milliseconds, and 200 milliseconds for the *prc-max-wait*, *prc-initial-wait*, and *prc-second-wait* arguments, respectively.

Command Modes

OTV IS-IS instance configuration (config-otv-isis)

Command History

Release	Modification
Cisco IOS XE Release 3.5S	This command was introduced.

Examples

The following example shows how to configure a PRC interval:

```
Router# configure terminal
Router(config)# otv isis overlay 1
Router(config-otv-isis)# prc-interval 4 5 6
Router(config-otv-isis)# end
```

Related Commands

Command	Description
otv isis overlay	Creates an OTV overlay interface.
show otv isis	Displays the IS-IS status and configuration.

precedence (Frame Relay VC-bundle-member)

To configure the precedence levels for a Frame Relay permanent virtual circuit (PVC) bundle member, use the **precedence** command in Frame Relay VC-bundle-member configuration mode. To remove the precedence level configuration from a PVC, use the **no** form of this command.

precedence *{level| other}*

no precedence

Syntax Description

<i>level</i>	<p>The precedence level or levels for the Frame Relay PVC bundle member. The range is from 0 to 7:</p> <ul style="list-style-type: none"> • 0--routine • 1--priority • 2--immediate • 3--flash • 4--flash override • 5--critical • 6--internetwork control • 7--network control <p>A PVC bundle member can be configured with a single precedence level, multiple individual precedence levels, a range of precedence levels, multiple ranges of precedence levels, or a combination of individual precedence levels and ranges. Examples are as follows:</p> <ul style="list-style-type: none"> • 0 • 0,2,3 • 0-2,4-5 • 0,1,2-4,7
other	<p>Specifies that this Frame Relay PVC bundle member will handle all of the remaining precedence levels that are not explicitly configured on any other bundle member PVCs.</p>

Command Default

Precedence levels are not configured.

Command Modes

Frame Relay VC-bundle-member configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines

Assignment of precedence levels to PVC bundle members lets you create differentiated services, because you can distribute the IP precedence levels over the various PVC bundle members. You can map a single precedence level or a range of levels to each discrete PVC in the bundle, which enables PVCs in the bundle to carry packets marked with different precedence levels.

Use the **precedence other** command to indicate that a PVC can carry traffic marked with precedence levels not specifically configured for other PVCs. Only one PVC in the bundle can be configured using the **precedence other** command.

This command is available only when the match type for the PVC bundle is set to precedence by using the **match precedence** command in Frame Relay VC-bundle configuration mode.

You can overwrite the precedence level configuration on a PVC by reentering the **precedence** command with a new level value.

All precedence levels must be accounted for in the PVC bundle configuration, or the bundle will not come up. However, a PVC can be a bundle member without a precedence level associated with it. As long as all valid precedence levels are handled by other PVCs in the bundle, the bundle can come up, but the PVC that has no precedence level configured will not participate in it.

A precedence level can be configured on one PVC bundle member per bundle. If you configure the same precedence level on more than one PVC within a bundle, the following error appears on the console:

```
%Overlapping precedence levels
```

When you use the **mpls ip** command to enable multiprotocol label switching (MPLS) on the interface, MPLS and IP packets can flow across the interface, and PVC bundles that are configured for IP precedence mapping are converted to MPLS EXP mapping. The PVC bundle functionality remains the same with respect to priority levels, bumping, and so on, but the **match precedence** command is replaced by the **match exp** command, and each **precedence** command is replaced by the **exp** command. The result is that a bundle-member PVC previously configured to carry precedence level 1 IP traffic now carries EXP level 1 MPLS traffic.

When MPLS is disabled, the **match precedence** and **match dscp** commands are restored, and the **exp** commands are replaced by **precedence** commands.

When MPLS is enabled or disabled, PVC bundles configured for IP precedence mapping or MPLS EXP mapping will stay up, and traffic will be transmitted over the appropriate bundle-member PVCs.

Examples

The following example shows how to configure Frame Relay PVC bundle member 101 to carry traffic with IP precedence level 5:

```
frame-relay vc-bundle bundle1
match precedence
pvc 101
precedence 5
```

Related Commands

Command	Description
bump	Configures the bumping rules for a specific PVC member of a bundle.
class	Associates a map class with a specified DLCI.
dscp (Frame Relay VC-bundle-member)	Configures the DSCP value or values for a Frame Relay PVC bundle member.
exp	Configures MPLS EXP levels for a Frame Relay PVC bundle member.
match	Specifies which bits of the IP header to use for mapping packet service levels to Frame Relay PVC bundle members.
match dscp	Configures a specific IP differentiated service code point (DSCP) value as a match criterion.
match precedence	Configures IP precedence values as match criteria.
protect (Frame Relay VC-bundle-member)	Configures a Frame Relay PVC bundle member with protected group or protected PVC status.

protect (Frame Relay VC-bundle-member)

To configure a Frame Relay permanent virtual circuit (PVC) bundle member with protected group or protected PVC status, use the **protect** command in Frame Relay VC-bundle-member configuration mode. To remove the protected status from a PVC, use the **no** form of this command.

protect {group| vc}

no protect {group| vc}

Syntax Description

group	Configures the PVC bundle member as part of a collection of protected PVCs within the PVC bundle.
vc	Configures the PVC member as individually protected.

Command Default

The PVC is not in a protected group and is also not individually protected.

Command Modes

Frame Relay VC-bundle-member configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines

When an individually-protected PVC goes down, it takes the bundle down. When all members of a protected group go down, the bundle goes down.

Despite any protection configurations, the PVC bundle will go down if a downed PVC has no PVC to which to bump its traffic or if the last PVC that is up in a PVC bundle goes down.

Examples

The following example configures Frame Relay PVC bundle member 101 as an individually protected PVC:

```
frame-relay vc-bundle new york
pvc 101
protect vc
```

Related Commands

Command	Description
bump	Configures the bumping rules for a specific PVC member of a bundle.
bundle	Creates a bundle or modifies an existing bundle to enter bundle configuration mode.
dscp (Frame Relay VC-bundle-member)	Configures the DSCP value or values for a Frame Relay PVC bundle member.
exp	Configures MPLS EXP levels for a Frame Relay PVC bundle member.
precedence (Frame Relay VC-bundle-member)	Configures the precedence levels for a Frame Relay PVC bundle member.

protocol (L2TP)

To specify the signaling protocol to be used to manage the pseudowires created from a pseudowire class for a Layer 2 session and to cause control plane configuration settings to be taken from a specified L2TP class, use the **protocol** command in pseudowire class configuration mode. To remove the signaling protocol (and the control plane configuration to be used) from a pseudowire class, use the **no** form of this command.

protocol {**l2tpv2**|**l2tpv3**|**none**} [*l2tp-class-name*]

no protocol {**l2tpv2**|**l2tpv3**|**none**} [*l2tp-class-name*]

Syntax Description

l2tpv2	Specifies that the Layer 2 Tunnel Protocol (L2TP) signaling protocol will be used.
l2tpv3	Specifies that the L2TPv3 signaling protocol will be used. This is the default.
none	Specifies that no signaling protocol will be used in L2TPv3 sessions.
<i>l2tp-class-name</i>	(Optional) The name of the L2TP class whose control plane configuration is to be used for pseudowires set up from a specified pseudowire class. If you do not enter a value for the <i>l2tp-class-name</i> argument, the default control plane configuration settings in the L2TP signaling protocol are used.

Command Default

The default protocol is **l2tpv3**.

Command Modes

Pseudowire class configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(27)SBC	Support for this command was integrated into Cisco IOS Release 12.2(27)SBC.

Usage Guidelines

Use the **protocol**(L2TP) command to configure the signaling protocol to use in sessions created from the specified pseudowire class. In addition, you can use this command to specify the L2TP class (see the “Configuring the Xconnect Attachment Circuit” section in the *Layer 2 Tunnel Protocol Version 3* feature document) from which the control plane configuration settings are to be taken.

Use the **protocol none** command to specify that no signaling will be used in L2TPv3 sessions created from the specified pseudowire class. This configuration is required for interoperability with a remote peer running the Universal Tunnel Interface (UTI).

Do not use this command if you want to configure a pseudowire class that will be used to create manual L2TPv3 sessions (see the “Static L2TPv3 Sessions” section in the *Layer 2 Tunnel Protocol Version 3* feature document).

Examples

The following example shows how to enter pseudowire class configuration mode and how to configure L2TPv3 as the signaling protocol. The control plane configuration used in the L2TP class named “class1” will be used to create dynamic L2TPv3 sessions for a VLAN xconnect interface.

```
Router(config)
# pseudowire-class vlan-xconnect
Router(config-pw)
# protocol l2tpv3 class1
```

Related Commands

Command	Description
pseudowire-class	Specifies the name of an L2TP pseudowire class and enters pseudowire class configuration mode.

pseudowire

To bind a virtual circuit to a Layer 2 pseudowire for an xconnect service, use the **pseudowire** command in interface configuration mode. To remove the binding between a virtual circuit and a Layer 2 pseudowire, use the **no** form of this command.

pseudowire *peer-ip-address* *vcid* **pw-class** *pw-class-name* [**sequencing** {**transmit**| **receive**| **both**}]

no pseudowire

Syntax Description

<i>peer-ip-address</i>	IP address of the remote peer.
<i>vcid</i>	32-bit identifier of the virtual circuit between devices at each end of a Layer 2 control channel.
pw-class <i>pw-class-name</i>	Specifies the pseudowire class configuration from which the data encapsulation type is derived.
sequencing	(Optional) Configures sequencing options for xconnect.
transmit	(Optional) Transmits sequence numbers.
receive	(Optional) Receives sequence numbers.
both	(Optional) Transmits and receives sequence numbers.

Command Default

A virtual circuit is not bound to a Layer 2 pseudowire for an xconnect service.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
12.3(2)T	This command was introduced.
15.0(1)S	This command was integrated into Cisco IOS Release 15.0(1)S.
15.2(4)S	This command was modified. The behavior of the no form of this command was modified. A configured pseudowire must be disabled before disabling a virtual-ppp interface.

Usage Guidelines

The combination of the *peer-ip-address* and *vcid* arguments must be unique on a device.

The same *vcid* value that identifies a virtual circuit must be configured by using the **pseudowire** command on local and remote devices at each end of a Layer 2 session. The virtual circuit identifier creates a binding between a pseudowire and a virtual circuit.

The **pw-class** *pw-class-name* binds the pseudowire configuration of a virtual circuit to a specific pseudowire class. The pseudowire class configuration serves as a template that contains settings used by all virtual circuits bound to it by using the **pseudowire** command.

When removing a virtual-PPP interface that has a configured pseudowire, you must first remove the pseudowire by using the **no pseudowire** command.

Examples

The following example shows how to create a virtual-PPP interface, configure PPP on the virtual-PPP interface, and bind a virtual circuit to a Layer 2 pseudowire for an xconnect service for a pseudowire class named *pwclass1*:

```
interface virtual-ppp 1
  ppp authentication chap
  ppp chap hostname peer1
  pseudowire 172.24.13.196 10 pw-class pwclass1
```

The following example shows how to remove a virtual-PPP interface that has a configured pseudowire. You must first remove the configured pseudowire or an error is generated. Note that you can remove the virtual-PPP interface in interface configuration mode as shown below:

```
no interface virtual-ppp 1
% Interface Virtual-PPP1 not removed - Remove the Pseudowire
interface virtual-ppp 1
  no pseudowire
no interface virtual-ppp 1
end
```

Related Commands

Command	Description
interface virtual-ppp	Configures a virtual-PPP interface.
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.
ppp authentication	Enables at least one PPP authentication protocol and specifies the order in which protocols are selected on the interface.
ppp chap hostname	Creates a pool of dialup routers that all appear to be the same host when authenticating with CHAP.
pseudowire-class	Specifies the name of a Layer 2 pseudowire class and enters pseudowire class configuration mode.

pseudowire-class

To specify the name of a Layer 2 pseudowire class and enter pseudowire class configuration mode, use the **pseudowire-class** command in global configuration mode. To remove a pseudowire class configuration, use the **no** form of this command.

pseudowire-class *pw-class-name*

no pseudowire-class *pw-class-name*

Syntax Description

<i>pw-class-name</i>	The name of a Layer 2 pseudowire class.
----------------------	---

Command Default

No pseudowire classes are defined.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
Cisco IOS XE Release 3.4S	This command was integrated into Cisco IOS XE Release 3.4S.
15.3(2)S	This command was implemented on the Cisco ASR 901 Series Aggregation Services Routers.

Command History

12.2(33)SRD	This command was integrated into Cisco IOS Release 12.2(33)SRD.
-------------	---

Usage Guidelines

The **pseudowire-class** command allows you to configure a pseudowire class template that consists of configuration settings used by all attachment circuits bound to the class. A pseudowire class includes the following configuration settings:

- Data encapsulation type
- Control protocol

- Sequencing
- IP address of the local Layer 2 interface
- Type of service (ToS) value in IP headers

The local interface name for each pseudowire class configured between a pair of PE routers can be the same or different.

After you enter the **pseudowire-class** command, the router switches to pseudowire class configuration mode, where pseudowire settings may be configured.

Examples

The following example shows how to enter pseudowire class configuration mode to configure a pseudowire configuration template named "ether-pw":

```
Router(config)
# pseudowire-class ether-pw
Router(config-pw)#
```

The following example shows how to enter pseudowire class configuration mode to configure a pseudowire configuration template named "mpls-ip":

```
Router(config)
# pseudowire-class mpls-ip
```

Related Commands

Command	Description
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.
pseudowire	Binds an attachment circuit to a Layer 2 pseudowire for xconnect service.
xconnect	Binds an attachment circuit to an L2TPv3 pseudowire for xconnect service and enters xconnect configuration mode.

pvc (Frame Relay VC-bundle)

To create a permanent virtual circuit (PVC) that is a Frame Relay PVC bundle member, and to enter Frame Relay VC-bundle-member configuration mode, use the **pvc** command in Frame Relay VC-bundle configuration mode. To delete a PVC from the Frame Relay PVC bundle, use the **no** form of this command.

pvc *dlci* [*vc-name*]

no pvc *dlci* [*vc-name*]

Syntax Description

<i>dlci</i>	Data-link connection identifier (DLCI) number used to identify the PVC.
<i>vc-name</i>	(Optional) Alphanumeric name for the PVC.

Command Default

No PVC is defined.

Command Modes

Frame Relay VC-bundle configuration

Command History

Release	Modification
12.2(13)T	This command was introduced.
12.2(16)BX	This command was integrated into Cisco IOS Release 12.2(16)BX.
12.0(26)S	This command was integrated into Cisco IOS Release 12.0(26)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines

To use this command, you must first create a Frame Relay PVC bundle and enter Frame Relay VC-bundle configuration mode.

A PVC bundle must have at least one PVC for the bundle to come up. A PVC bundle cannot have more than eight PVCs. If you try to configure more than eight PVCs in a bundle, the following message appears on the console:

```
%FR vc-bundle contains 8 members. Cannot add another.
```

Dynamic PVCs can be specified as PVC bundle members; however, if a PVC has already been created by using another configuration command, you cannot add it to a PVC bundle. If you try to do so, the following message appears on the console:

```
%DLCI 200 is not a dynamic PVC. Cannot add to VC-Bundle.
```

If a PVC is already a member of a PVC bundle, any attempt to reuse that same PVC in a command that creates a PVC (for example, **frame-relay interface-dlci** or **frame-relay local-dlci**) causes the following error message:

```
%Command is inapplicable to vc-bundle PVCs.
```

Examples

The following example creates a PVC that has a DLCI number of 101 and that belongs to a Frame Relay PVC bundle named `new_york`:

```
frame-relay vc-bundle new_york
pvc 101
```

Related Commands

Command	Description
dscp (frame-relay vc-bundle-member)	Configures the DSCP value or values for a Frame Relay PVC bundle member.
exp	Configures MPLS EXP levels for a Frame Relay PVC bundle member.
frame-relay vc-bundle	Creates a Frame Relay PVC bundle and enters Frame Relay VC-bundle configuration mode.
match	Specifies which bits of the IP header to use for mapping packet service levels to Frame Relay PVC bundle members
precedence (Frame Relay VC-bundle-member)	Configures the precedence levels for a Frame Relay PVC bundle member.

read-ahead

To configure the read ahead feature of Common Internet File System (CIFS)-Express accelerator, use the **read-ahead** command in WAAS CIFS configuration mode. To disable the read ahead feature, use the **no** form of this command.

read-ahead {**enable**| *size kb*}

no read-ahead {**enable**| *size kb*}

Syntax Description

enable	Enables the read ahead feature.
size <i>kb</i>	Specifies the amount of data, in kilobytes (KB), to read ahead per file. The default read ahead size is 190. The size range is from 32 to 512.

Command Default

The read ahead feature is enabled, and the default read ahead size is 190 KB.

Command Modes

WAAS CIFS configuration (config-waas-cifs)

Command History

Release	Modification
15.2(3)T	This command was introduced.

Usage Guidelines

Before you can enable the **read-ahead** command, use the following commands:

- Use the **parameter-map type waas** command in global configuration mode to enter parameter map configuration mode.
- Use the **accelerator cifs-express** command in parameter map configuration mode to enter WAAS CIFS configuration mode.

To enable the read ahead feature, use the **read-ahead enable** command before configuring the read ahead size.

Examples

The following example shows how to enable read ahead and configure the read ahead size:

```
Device(config)# parameter-map type waas waas_global
Device(config-profile)# accelerator cifs-express
Device(config-waas-cifs)# enable
Device(config-waas-cifs)# read-ahead enable
Device(config-waas-cifs)# read-ahead size 300
```


Related Commands

Command	Description
accelerator	Enters a specific WAAS Express accelerator configuration mode based on the accelerator being configured.
parameter-map type waas	Configures WAAS Express global parameters.
show waas accelerator	Displays information about WAAS Express accelerators.
show waas statistics accelerator	Displays statistical information about WAAS Express accelerators.

receive-window

To configure the packet size of the receive window on the remote provider edge router at the other end of a Layer 2 control channel, use the **receive-window** command in L2TP class configuration mode. To disable the configured value, use the **no** form of this command.

receive-window *number*

no receive-window *number*

Syntax Description

<i>number</i>	The number of packets that can be received by the remote peer before backoff queueing occurs. The valid values range from 1 to the upper limit the peer has for receiving packets. The default value is the upper limit that the remote peer has for receiving packets.
---------------	---

Command Default

The default packet size of the receive window is the upper limit that the remote peer has for receiving packets.

Command Modes

L2TP class configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(27)SBC	Support for this command was integrated into Cisco IOS Release 12.2(27)SBC.

Usage Guidelines

To determine the upper limit for the *number* argument, refer to the platform-specific documentation for the peer router.

Examples

The following example sets a receive window of 30 packets to the remote peer in Layer 2 pseudowires that have been configured with the L2TP class named "l2tp-class1":

```
Router(config)
# l2tp-class l2tp-class1
Router(config-l2tp-class)
# receive-window 30
```

Related Commands

Command	Description
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.

retransmit

To configure the retransmission settings of control packets, use the **retransmit** command in L2TP class configuration mode. To disable the configured values, use the **no** form of this command.

retransmit {**initial retries** *initial-retries* | **retries** *retries* | **timeout** {**max** | **min**} *seconds*}

no retransmit {**initial retries** *initial-retries* | **retries** *retries* | **timeout** {**max** | **min**} *seconds*}

Syntax Description

initial retries <i>initial-retries</i>	Specifies how many start control channel requests (SCCRQs) are re-sent before giving up on the session. Valid values for the <i>initial-retries</i> argument range from 1 to 1000. The default value is 2
retries <i>retries</i>	Specifies how many retransmission cycles occur before determining that the peer provider edge (PE) router does not respond. Valid values for the <i>retries</i> argument range from 1 to 1000. The default value is 15.
timeout max min } <i>seconds</i>	Specifies maximum and minimum retransmission intervals (in seconds) for resending control packets. Valid values for the <i>timeout</i> argument range from 1 to 8. The default maximum interval is 8; the default minimum interval is 1.

Command Default

The default values of the retransmission settings are used.

Command Modes

L2TP class configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(27)SBC	Support for this command was integrated into Cisco IOS Release 12.2(27)SBC.

Usage Guidelines

Use this command to configure the amount of time spent trying to establish or maintain a control channel.

Examples

The following example configures ten retries for sending tunneled packets to a remote peer in Layer 2 pseudowires that have been configured with the Layer 2 Tunnel Protocol (L2TP) class named "l2tp-class1":

```
Router(config)
# l2tp-class l2tp-class1
Router(config-l2tp-class)
# retransmit retries 10
```

Related Commands

Command	Description
l2tp-class	Creates a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes and enters L2TP class configuration mode.

rewrite ingress tag

To specify the encapsulation adjustment to be performed on a frame ingressing a service instance, use the **rewrite ingress tag** command in Ethernet service configuration mode. To delete the encapsulation adjustment, use the **no** form of this command.

```
rewrite ingress tag {pop | {1 | 2} [symmetric]} push {dot1ad vlan-id [dot1q vlan-id] [symmetric] | dot1q
vlan-id [second-dot1q vlan-id] [symmetric]} | translate {1-to-1 {dot1ad vlan-id dot1q vlan-id}
[symmetric]} | 1-to-2 {dot1ad vlan-id dot1q vlan-id} | dot1q vlan-id second-dot1q vlan-id [symmetric] |
2-to-1 {dot1ad vlan-id dot1q vlan-id [symmetric]} | 2-to-2 {dot1q vlan-id second-dot1q vlan-id
[symmetric]}}
```

no rewrite ingress tag

Syntax on the Cisco ASR 1000 Series Aggregation Router

Syntax Description

rewrite ingress tag {pop {1 | 2} [symmetric] | push {dot1ad vlan-id [dot1q vlan-id] [symmetric] | dot1q vlan-id [second-dot1q vlan-id] [symmetric] | vlan-type {0x88a8 | 0x9100 | 0x9200} [second-dot1q vlan-id] [symmetric]} | translate {1-to-1 {dot1ad vlan-id dot1q vlan-id [vlan-type {0x88a8 | 0x9100 | 0x9200}] [symmetric]} | 1-to-2 {dot1ad vlan-id dot1q vlan-id dot1q vlan-id [second-dot1q vlan-id] [vlan-type {0x88a8 | 0x9100 | 0x9200}] second-dot1q vlan-id} [symmetric] | 2-to-1 {dot1ad vlan-id [symmetric] | dot1q vlan-id [vlan-type {0x88a8 | 0x9100 | 0x9200}] [symmetric]} | 2-to-2 {dot1ad vlan-id dot1q vlan-id [symmetric] | dot1q vlan-id [second-dot1q vlan-id] [vlan-type {0x88a8 | 0x9100 | 0x9200}] second-dot1q vlan-id} [symmetric]}}

no rewrite ingress tag

pop	Removes a tag from a packet.
{1 2}	Specifies either the outermost tag or the two outermost tags for removal from a packet.
symmetric	(Optional) Indicates a reciprocal adjustment to be done in the egress direction. For example, if the ingress pops a tag, the egress pushes a tag and if the ingress pushes a tag, the egress pops a tag.
push	Adds a tag.
dot1ad	Specifies an IEEE 802.1ad tag.
<i>vlan-id</i>	Integer in the range 1 to 4094 that identifies the VLAN.
dot1q	Specifies an IEEE 802.1Q tag.
second-dot1q	Specifies a different 802.1Q tag at the ingress service instance.

vlan-type	Specifies the type of VLAN protocol.
0x88a8	Specifies the protocol type 0x88a8.
0x9100	Specifies the protocol type 0x9100.
0x9200	Specifies the protocol type 0x9200.
translate	Translates, by VLAN ID, a tag or a pair of tags defined in the encapsulation command.
1-to-1	Translates a single tag defined by the encapsulation command to a single tag defined in the rewrite ingress tag command.
1-to-2	Translates a single tag defined by the encapsulation command to a pair of tags defined in the rewrite ingress tag command.
2-to-1	Translates, by VLAN ID, a pair of tags defined by the encapsulation command to a single tag defined in the rewrite ingress tag command.
2-to-2	Translates, by VLAN ID, a pair of tags defined by the encapsulation command to a pair of tags defined in the rewrite ingress tag command.

Command Default

The frame is left intact on ingress (the service instance is equivalent to a trunk port).

Command Modes

Ethernet service (config-if-srv)

Command History

Release	Modification
12.2(33)SRB	This command was introduced.
Cisco IOS XE Release 3.2S	This command was integrated into Cisco IOS XE Release 3.2S.
Cisco IOS XE Release 3.5S	This command was implemented on the Cisco ASR 903 Router.
15.1(2)SNH	This command was implemented on the Cisco ASR 901 Series Aggregation Services Router.

Usage Guidelines

The **symmetric** keyword is accepted for all rewrite operations only when a single VLAN is configured in encapsulation. If a list of VLANs or a range of VLANs is configured in encapsulation, the **symmetric** keyword is accepted only for push rewrite operations.

The **pop** keyword assumes the elements being popped are defined by the encapsulation type. The exception case should be drop the packet.

The **translate** keyword assumes the tags being translated from are defined by the encapsulation type. In the 2-to-1 option, the “2” means 2 tags of a type defined by the **encapsulation** command. The translation operation requires at least one “from” tag in the original packet. If the original packet contains more tags than the ones defined in the “from,” the operation should be done beginning on the outer tag. Exception cases should be dropped.

Examples

The following example shows how to specify the encapsulation adjustment to be performed on the frame ingressing the service instance:

```
Device> enable
Device# configure terminal
Device(config) interface gigabitethernet 2/0/0
Device(config-if) # service instance 100 ethernet
Device(config-if-srv) # encapsulation dot1q 100
Device(config-if-srv) # rewrite ingress tag push dot1q 200
```

Related Commands

Command	Description
encapsulation	Sets the encapsulation method used by an interface.

rd (VPLS)

To specify a route distinguisher (RD) to distribute endpoint information in a Virtual Private LAN Service (VPLS) configuration, use the **rd** command in L2 VFI configuration or VFI autodiscovery configuration mode. To remove the manually configured RD and return to the automatically generated RD, use the **no** form of this command.

rd {*autonomous-system-number:nn*|*ip-address:nn*}

no rd {*autonomous-system-number:nn*|*ip-address:nn*}

Syntax Description

<i>autonomous-system-number:nn</i>	Specifies a 16-bit autonomous system number (ASN) and 32-bit arbitrary number. The ASN does not have to match the local autonomous system number.
<i>ip-address:nn</i>	Specifies a 32-bit IP address and a 16-bit arbitrary number. Only IPv4 addresses are supported.

Command Default

VPLS autodiscovery automatically generates a RD using the Border Gateway Protocol (BGP) autonomous system number and the configured virtual forwarding instance (VFI) VPN ID.

Command Modes

L2 VFI configuration (config-vfi)

VFI autodiscovery configuration (config-vfi-autodiscovery)

Command History

Release	Modification
12.2(33)SRB	This command was introduced.
Cisco IOS XE Release 3.7S	This command was modified as part of the MPLS-based Layer 2 VPN (L2VPN) command modifications for cross-OS support. This command was made available in VFI autodiscovery configuration mode.

Usage Guidelines

VPLS autodiscovery automatically generates an RD using the BGP autonomous system number and the configured VFI VPN ID. You can use this command to change the automatically generated RD.

The same RD value cannot be configured in multiple VFIs.

There are two formats for configuring the RD argument. It can be configured in the *autonomous-system-number:network-number* format, or it can be configured in the *ip-address:network-number* format.

An RD is either:

- Autonomous system-related—Composed of an autonomous system number and an arbitrary number.
- IP address-related—Composed of an IP address and an arbitrary number.

You can enter an RD in either of the following formats:

- *16-bit-autonomous-system-number:32-bit-number* —For example, 101:3.
- *32-bit-IP-address:16-bit-number* —For example, 192.168.122.15:1.

Examples

The following example shows a configuration using VPLS autodiscovery that sets the RD to an IP address of 10.4.4.4 and a network address of 70:

```
Device(config)# 12 vfi SP2 autodiscovery
Device(config-vfi)# vpn id 200
Device(config-vfi)# vpls-id 10.4.4.4:70
Device(config-vfi)# rd 10.4.5.5:7
```

The following example shows a configuration using VPLS Autodiscovery that sets the RD to an autonomous system number of 2 and a network address of 3:

```
Device(config)# 12 vfi SP2 autodiscovery
Device(config-vfi)# vpn id 200
Device(config-vfi)# vpls-id 10.4.4.4:70
Device(config-vfi)# rd 2:3
```

The following example shows a configuration using VPLS autodiscovery that sets the RD to an autonomous system number of 2 and a network address of 3 in VFI autodiscovery configuration mode:

```
Device(config)# 12vpn vfi context vfi1
Device(config-vfi)# vpn id 200
Device(config-vfi)# autodiscovery bgp signaling ldp
Device(config-vfi-autodiscovery)# rd 2:3
```

Related Commands

Command	Description
autodiscovery (l2vpn vfi)	Designates VFI as having BGP autodiscovered pseudowire members.
12 vfi autodiscovery	Enables a VPLS PE router to automatically discover other PE routers that are part of the same VPLS domain.

route-target (VPLS)

To specify a route target for a Virtual Private LAN Services (VPLS) virtual forwarding instance (VFI), use the **route-target** command in L2 VFI configuration or VFI auto discovery configuration mode. To revert to the automatically generated route target, use the **no** form of this command.

route-target [**import**| **export**| **both**] {*autonomous-system-number:nn*| *ip-address:nn*}

no route-target {**import**| **export**| **both**} {*autonomous-system-number:nn*| *ip-address:nn*}

Syntax Description

import	(Optional) Imports routing information from the target VPN extended community.
export	(Optional) Exports routing information to the target VPN extended community.
both	(Optional) Imports and exports routing information to the target VPN extended community.
<i>autonomous-system-number:nn</i>	Specifies the autonomous system number (ASN) and a 32-bit number.
<i>ip-address:nn</i>	Specifies the IP address and a 16-bit number.

Command Default

VPLS Autodiscovery automatically generates a route target using the lower six bytes of the route distinguisher (RD) and VPLS ID.

Command Modes

L2 VFI configuration (config-vfi)
VFI autodiscovery configuration (config-vfi-autodiscovery)

Command History

Release	Modification
12.2(33)SRB	This command was introduced.
Cisco IOS XE Release 3.7S	This command was modified as part of the MPLS-based Layer 2 VPN (L2VPN) command modifications for cross-OS support . This command was made available in VFI autodiscovery configuration mode.

Usage Guidelines

The same route target cannot be configured in multiple VFIs.

The route target specifies a target VPN extended community. Like a route distinguisher, an extended community is composed of either an autonomous system number and an arbitrary number or an IP address and an arbitrary number. You can enter the numbers in either of the following formats:

- *16-bit-autonomous-system-number:32-bit-number*—For example, 101:3.
- *32-bit-IP-address:16-bit-number* —For example, 192.168.122.15:1.

Examples

The following example shows how to configure VPLS autodiscovery route-target extended community attributes for VFI SP1:

```
Device(config)# l2 vfi SP1 autodiscovery
Device(config-vfi)# vpn id 100
Device(config-vfi)# vpls-id 5:300
Device(config-vfi)# rd 4:4
Device(config-vfi)# route-target 10.1.1.1:29
```

The following example shows how to configure VPLS autodiscovery route-target extended community attributes for VFI vfi1:

```
Device(config)# l2vpn vfi context vfi1
Device(config-vfi)# vpn id 100
Device(config-vfi)# autodiscovery bgp signaling ldp
Device(config-vfi-autodiscovery)# rd 4:4
Device(config-vfi-autodiscovery)# route-target 10.1.1.1:29
```

Related Commands

Command	Description
autodiscovery (l2vpn vfi)	Designates VFI as having BGP autodiscovered pseudowire members.
auto-route-target	Automatically generates the route target in a VFI.
l2 vfi autodiscovery	Enables a VPLS PE router to automatically discover other PE routers that are part of the same VPLS domain.

rtcp-regenerate

To generate and terminate the RTCP packets on the SPA-DSP, use the **rtcp-regenerate** command in the SBC configuration mode (config-sbc) for the Unified Model, and from the SBC DBE configuration mode (config-sbc-dbe) for the Distributed Model.

rtcp-regenerate

no rtcp-regenerate

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes SBC configuration (config-sbc) for the Unified Model
SBC DBE configuration (config-sbc-dbe) for the Distributed Model

Release	Modification
3.4.0S	This command was introduced.

Usage Guidelines Use this command to generate and terminate the RTCP packets on the SPA-DSP on a Cisco ASR 1000 Series Router.

Examples The following example shows how to generate and terminate the RTCP packets on the SPA-DSP on the Cisco Unified Border Element: Unified Model:

```
Router> enable
Router# config terminal
Router(config)# sbc mySBC
Router(config-sbc)# rtcp-regenerate
```

The following example shows how to generate and terminate the RTCP packets on the SPA-DSP on the Cisco Unified Border Element: Distributed Model:

```
Router> enable
Router# config terminal
Router(config)# sbc mySBC dbe
```

