



Cisco IOS Configuration Fundamentals Command Reference

Release 12.2

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number: DOC-7811740=
Text Part Number: 78-11740-02

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.


AccessPath, AtmDirector, Browse with Me, CCDA, CCDE, CCDP, CCIE, CCNA, CCNP, CCSI, CD-PAC, *CiscoLink*, the Cisco NetWorks logo, the Cisco Powered Network logo, Cisco Systems Networking Academy, the Cisco Systems Networking Academy logo, Fast Step, Follow Me Browsing, FormShare, FrameShare, GigaStack, IGX, Internet Quotient, IP/VC, iQ Breakthrough, iQ Expertise, iQ FastTrack, the iQ Logo, iQ Net Readiness Scorecard, MGX, the Networkers logo, *Packet*, PIX, RateMUX, ScriptBuilder, ScriptShare, SlideCast, SMARTnet, TransPath, Unity, Voice LAN, Wavelength Router, and WebViewer are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, Discover All That's Possible, and Empowering the Internet Generation, are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, the Cisco IOS logo, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Enterprise/Solver, EtherChannel, EtherSwitch, FastHub, FastSwitch, IOS, IP/TV, LightStream, MICA, Network Registrar, Post-Routing, Pre-Routing, Registrar, StrataView Plus, Stratm, SwitchProbe, TeleRouter, and VCO are registered trademarks of Cisco Systems, Inc. or its affiliates in the U.S. and certain other countries.

All other brands, names, or trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0102R)

Cisco IOS Configuration Fundamentals Command Reference

© 2001–2006 Cisco Systems, Inc.

All rights reserved.



About Cisco IOS Software Documentation v

Using Cisco IOS Software xiii

CISCO IOS USER INTERFACE COMMANDS

Basic Command-Line Interface Commands FR-3

The Setup Command FR-45

Terminal Operating Characteristics Commands FR-53

Connection, Menu, and System Banner Commands FR-123

Cisco IOS Web Browser User Interface Commands FR-167

FILE MANAGEMENT COMMANDS

Cisco IOS File System Commands FR-179

Configuration File Management Commands FR-231

System Image and Microcode Commands FR-267

Router Memory Commands FR-293

Bootting Commands FR-311

Basic File Transfer Services Commands FR-343

SYSTEM MANAGEMENT COMMANDS

Basic System Management Commands FR-375

Troubleshooting and Fault Management Commands FR-481

SNMP Commands FR-667

CDP Commands FR-743

RMON Commands FR-767

Cisco Service Assurance Agent Commands FR-805


WCCP Commands FR-895

APPENDIXES

ASCII Character Set and Hex Values FR-919

Cisco 7500 Series Line Card Configuration Commands FR-925

INDEX



About Cisco IOS Software Documentation

This chapter discusses the objectives, audience, organization, and conventions of Cisco IOS software documentation. It also provides sources for obtaining documentation from Cisco Systems.

Documentation Objectives

Cisco IOS software documentation describes the tasks and commands necessary to configure and maintain Cisco networking devices.

Audience

The Cisco IOS software documentation set is intended primarily for users who configure and maintain Cisco networking devices (such as routers and switches) but who may not be familiar with the tasks, the relationship between tasks, or the Cisco IOS software commands necessary to perform particular tasks. The Cisco IOS software documentation set is also intended for those users experienced with Cisco IOS software who need to know about new features, new configuration options, and new software characteristics in the current Cisco IOS software release.

Documentation Organization

The Cisco IOS software documentation set consists of documentation modules and master indexes. In addition to the main documentation set, there are supporting documents and resources.

Documentation Modules

The Cisco IOS documentation modules consist of configuration guides and corresponding command reference publications. Chapters in a configuration guide describe protocols, configuration tasks, and Cisco IOS software functionality and contain comprehensive configuration examples. Chapters in a command reference publication provide complete Cisco IOS command syntax information. Use each configuration guide in conjunction with its corresponding command reference publication.


Figure 1 shows the Cisco IOS software documentation modules.




Note

The abbreviations (for example, FC and FR) next to the book icons are page designators, which are defined in a key in the index of each document to help you with navigation. The bullets under each module list the major technology areas discussed in the corresponding books.


Figure 1 Cisco IOS Software Documentation Modules




47953

**Module DC/DR:**

- Preparing for Dial Access
- Modem and Dial Shelf Configuration and Management
- ISDN Configuration
- Signalling Configuration
- Dial-on-Demand Routing Configuration
- Dial-Backup Configuration
- Dial-Related Addressing Services
- Virtual Templates, Profiles, and Networks
- PPP Configuration
- Callback and Bandwidth Allocation Configuration
- Dial Access Specialized Features
- Dial Access Scenarios

**Module TC/TR:**


- ARA
- LAT
- NAS1
- Telnet
- TN3270
- XRemote
- X.28 PAD
- Protocol Translation

**Module BC/B1R:**


- Transparent Bridging
- SRB
- Token Ring Inter-Switch Link
- Token Ring Route Switch Module
- RSRB
- DLSw+
- Serial Tunnel and Block Serial Tunnel
- LLC2 and SDLC
- IBM Network Media Translation
- SNA Frame Relay Access
- NCIA Client/Server
- Airline Product Set

Module BC/B2R:


- DSPU and SNA Service Point
- SNA Switching Services
- Cisco Transaction Connection
- Cisco Mainframe Channel Connection
- CLAW and TCP/IP Offload
- CSNA, CMPC, and CMPC+
- TN3270 Server

**Module VC/VR:**

- Voice over IP
- Call Control Signalling
- Voice over Frame Relay
- Voice over ATM
- Telephony Applications
- Trunk Management
- Fax, Video, and Modem Support

**Module QC/QR:**

- Packet Classification
- Congestion Management
- Congestion Avoidance
- Policing and Shaping
- Signalling
- Link Efficiency Mechanisms

**Module XC/XR:**

- Cisco IOS Switching Paths
- NetFlow Switching
- Multiprotocol Label Switching
- Multilayer Switching
- Multicast Distributed Switching
- Virtual LANs
- LAN Emulation

47954

Master Indexes

Two master indexes provide indexing information for the Cisco IOS software documentation set: an index for the configuration guides and an index for the command references. Individual books also contain a book-specific index.

The master indexes provide a quick way for you to find a command when you know the command name but not which module contains the command. When you use the online master indexes, you can click the page number for an index entry and go to that page in the online document.

Supporting Documents and Resources

The following documents and resources support the Cisco IOS software documentation set:

- *Cisco IOS Command Summary* (two volumes)—This publication explains the function and syntax of the Cisco IOS software commands. For more information about defaults and usage guidelines, refer to the Cisco IOS command reference publications.
- *Cisco IOS System Error Messages*—This publication lists and describes Cisco IOS system error messages. Not all system error messages indicate problems with your system. Some are purely informational, and others may help diagnose problems with communications lines, internal hardware, or the system software.
- *Cisco IOS Debug Command Reference*—This publication contains an alphabetical listing of the **debug** commands and their descriptions. Documentation for each command includes a brief description of its use, command syntax, usage guidelines, and sample output.
- *Dictionary of Internetworking Terms and Acronyms*—This Cisco publication compiles and defines the terms and acronyms used in the internetworking industry.
- New feature documentation—The Cisco IOS software documentation set documents the mainline release of Cisco IOS software (for example, Cisco IOS Release 12.2). New software features are introduced in early deployment releases (for example, the Cisco IOS “T” release train for 12.2, 12.2(x)T). Documentation for these new features can be found in standalone documents called “feature modules.” Feature module documentation describes new Cisco IOS software and hardware networking functionality and is available on Cisco.com and the Documentation CD-ROM.
- Release notes—This documentation describes system requirements, provides information about new and changed features, and includes other useful information about specific software releases. See the section “Using Software Release Notes” in the chapter “Using Cisco IOS Software” for more information.
- Caveats documentation—This documentation provides information about Cisco IOS software defects in specific software releases.
- RFCs—RFCs are standards documents maintained by the Internet Engineering Task Force (IETF). Cisco IOS software documentation references supported RFCs when applicable. The full text of referenced RFCs may be obtained on the World Wide Web at <http://www.rfc-editor.org/>.
- MIBs—MIBs are used for network monitoring. For lists of supported MIBs by platform and release, and to download MIB files, see the Cisco MIB website on Cisco.com at <http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>.

Document Conventions

Within Cisco IOS software documentation, the term *router* is generally used to refer to a variety of Cisco products (for example, routers, access servers, and switches). Routers, access servers, and other networking devices that support Cisco IOS software are shown interchangeably within examples. These products are used only for illustrative purposes; that is, an example that shows one product does not necessarily indicate that other products are not supported.

The Cisco IOS documentation set uses the following conventions:

Convention	Description
^ or Ctrl	The ^ and Ctrl symbols represent the Control key. For example, the key combination ^D or Ctrl-D means hold down the Control key while you press the D key. Keys are indicated in capital letters but are not case sensitive.
<i>string</i>	A string is a nonquoted set of characters shown in italics. For example, when setting an SNMP community string to public, do not use quotation marks around the string or the string will include the quotation marks.

Command syntax descriptions use the following conventions:

Convention	Description
boldface	Boldface text indicates commands and keywords that you enter literally as shown.
<i>italics</i>	Italic text indicates arguments for which you supply values.
[x]	Square brackets enclose an optional element (keyword or argument).
	A vertical line indicates a choice within an optional or required set of keywords or arguments.
[x y]	Square brackets enclosing keywords or arguments separated by a vertical line indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical line indicate a required choice.

Nested sets of square brackets or braces indicate optional or required choices within optional or required elements. For example:

Convention	Description
[x {y z}]	Braces and a vertical line within square brackets indicate a required choice within an optional element.

Examples use the following conventions:

Convention	Description
<code>screen</code>	Examples of information displayed on the screen are set in Courier font.
<code>boldface screen</code>	Examples of text that you must enter are set in Courier bold font.
< >	Angle brackets enclose text that is not printed to the screen, such as passwords.

Convention	Description
!	An exclamation point at the beginning of a line indicates a comment line. (Exclamation points are also displayed by the Cisco IOS software for certain processes.)
[]	Square brackets enclose default responses to system prompts.

The following conventions are used to attract the attention of the reader:

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.

**Timesaver**

Means the *described action saves time*. You can save time by performing the action described in the paragraph.

Obtaining Documentation

The following sections provide sources for obtaining documentation from Cisco Systems.

World Wide Web

The most current Cisco documentation is available on the World Wide Web at the following website:

<http://www.cisco.com>

Translated documentation is available at the following website:

http://www.cisco.com/public/countries_languages.html

Documentation CD-ROM

Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

Ordering Documentation

Cisco documentation can be ordered in the following ways:

- Registered Cisco Direct Customers can order Cisco product documentation from the Networking Products Marketplace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, in North America, by calling 800 553-NETS(6387).

Documentation Feedback

If you are reading Cisco product documentation on the World Wide Web, you can submit technical comments electronically. Click **Feedback** in the toolbar and select **Documentation**. After you complete the form, click **Submit** to send it to Cisco.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, use the response card behind the front cover of your document, or write to the following address:

Cisco Systems, Inc.
Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools. For Cisco.com registered users, additional troubleshooting tools are available from the TAC website.

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information and resources at anytime, from anywhere in the world. This highly integrated Internet application is a powerful, easy-to-use tool for doing business with Cisco.

Cisco.com provides a broad range of features and services to help customers and partners streamline business processes and improve productivity. Through Cisco.com, you can find information about Cisco and our networking solutions, services, and programs. In addition, you can resolve technical issues with online technical support, download and test software packages, and order Cisco learning materials and merchandise. Valuable online skill assessment, training, and certification programs are also available.

Customers and partners can self-register on Cisco.com to obtain additional personalized information and services. Registered users can order products, check on the status of an order, access technical support, and view benefits specific to their relationships with Cisco.

To access Cisco.com, go to the following website:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC website is available to all customers who need technical assistance with a Cisco product or technology that is under warranty or covered by a maintenance contract.

Contacting TAC by Using the Cisco TAC Website

If you have a priority level 3 (P3) or priority level 4 (P4) problem, contact TAC by going to the TAC website:

<http://www.cisco.com/tac>

P3 and P4 level problems are defined as follows:

- P3—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- P4—You need information or assistance on Cisco product capabilities, product installation, or basic product configuration.

In each of the above cases, use the Cisco TAC website to quickly find answers to your questions.

To register for Cisco.com, go to the following website:

<http://www.cisco.com/register/>

If you cannot resolve your technical issue by using the TAC online resources, Cisco.com registered users can open a case online by using the TAC Case Open tool at the following website:

<http://www.cisco.com/tac/caseopen>


Contacting TAC by Telephone

If you have a priority level 1 (P1) or priority level 2 (P2) problem, contact TAC by telephone and immediately open a case. To obtain a directory of toll-free numbers for your country, go to the following website:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

P1 and P2 level problems are defined as follows:

- P1—Your production network is down, causing a critical impact to business operations if service is not restored quickly. No workaround is available.
- P2—Your production network is severely degraded, affecting significant aspects of your business operations. No workaround is available.



Using Cisco IOS Software

This chapter provides helpful tips for understanding and configuring Cisco IOS software using the command-line interface (CLI). It contains the following sections:

- Understanding Command Modes
- Getting Help
- Using the no and default Forms of Commands
- Saving Configuration Changes
- Filtering Output from the show and more Commands
- Identifying Supported Platforms

For an overview of Cisco IOS software configuration, refer to the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

For information on the conventions used in the Cisco IOS software documentation set, see the previous chapter, “About Cisco IOS Software Documentation.”

Understanding Command Modes

You use the CLI to access Cisco IOS software. Because the CLI is divided into many different modes, the commands available to you at any given time depend on the mode you are currently in. Entering a question mark (?) at the CLI prompt allows you to obtain a list of commands available for each command mode.

When you log in to the CLI, you are in user EXEC mode. User EXEC mode contains only a limited subset of commands. To have access to all commands, you must enter privileged EXEC mode, normally by using a password. From privileged EXEC mode you can issue any EXEC command—user or privileged mode—or you can enter global configuration mode. Most EXEC commands are one-time commands. For example, **show** commands show important status information, and **clear** commands clear counters or interfaces. The EXEC commands are not saved when the software reboots.

Configuration modes allow you to make changes to the running configuration. If you later save the running configuration to the startup configuration, these changed commands are stored when the software is rebooted. To enter specific configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and a variety of other modes, such as protocol-specific modes.

ROM monitor mode is a separate mode used when the Cisco IOS software cannot load properly. If a valid software image is not found when the software boots or if the configuration file is corrupted at startup, the software might enter ROM monitor mode.

Table 1 describes how to access and exit various common command modes of the Cisco IOS software. It also shows examples of the prompts displayed for each mode.

Table 1 Accessing and Exiting Command Modes

Command Mode	Access Method	Prompt	Exit Method
User EXEC	Log in.	Router>	Use the logout command.
Privileged EXEC	From user EXEC mode, use the enable EXEC command.	Router#	To return to user EXEC mode, use the disable command.
Global configuration	From privileged EXEC mode, use the configure terminal privileged EXEC command.	Router(config)#	To return to privileged EXEC mode from global configuration mode, use the exit or end command, or press Ctrl-Z .
Interface configuration	From global configuration mode, specify an interface using an interface command.	Router(config-if)#	To return to global configuration mode, use the exit command. To return to privileged EXEC mode, use the end command, or press Ctrl-Z .
ROM monitor	From privileged EXEC mode, use the reload EXEC command. Press the Break key during the first 60 seconds while the system is booting.	>	To exit ROM monitor mode, use the continue command.

For more information on command modes, refer to the “Using the Command-Line Interface” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Getting Help

Entering a question mark (?) at the CLI prompt displays a list of commands available for each command mode. You can also get a list of keywords and arguments associated with any command by using the context-sensitive help feature.

To get help specific to a command mode, a command, a keyword, or an argument, use one of the following commands:

Command	Purpose
help	Provides a brief description of the help system in any command mode.
<i>abbreviated-command-entry?</i>	Provides a list of commands that begin with a particular character string. (No space between command and question mark.)
<i>abbreviated-command-entry</i> <Tab>	Completes a partial command name.
?	Lists all commands available for a particular command mode.
<i>command ?</i>	Lists the keywords or arguments that you must enter next on the command line. (Space between command and question mark.)

Example: How to Find Command Options

This section provides an example of how to display syntax for a command. The syntax can consist of optional or required keywords and arguments. To display keywords and arguments for a command, enter a question mark (?) at the configuration prompt or after entering part of a command followed by a space. The Cisco IOS software displays a list and brief description of available keywords and arguments. For example, if you were in global configuration mode and wanted to see all the keywords or arguments for the **arap** command, you would type **arap ?**.

The <cr> symbol in command help output stands for “carriage return.” On older keyboards, the carriage return key is the Return key. On most modern keyboards, the carriage return key is the Enter key. The <cr> symbol at the end of command help output indicates that you have the option to press **Enter** to complete the command and that the arguments and keywords in the list preceding the <cr> symbol are optional. The <cr> symbol by itself indicates that no more arguments or keywords are available and that you must press **Enter** to complete the command.

Table 2 shows examples of how you can use the question mark (?) to assist you in entering commands. The table steps you through configuring an IP address on a serial interface on a Cisco 7206 router that is running Cisco IOS Release 12.0(3).

Table 2 *How to Find Command Options*

Command	Comment
Router> enable Password: <password> Router#	Enter the enable command and password to access privileged EXEC commands. You are in privileged EXEC mode when the prompt changes to Router#.
Router# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Router(config)#	Enter the configure terminal privileged EXEC command to enter global configuration mode. You are in global configuration mode when the prompt changes to Router(config)#.
Router(config)# interface serial ? <0-6> Serial interface number Router(config)# interface serial 4 ? / Router(config)# interface serial 4/ ? <0-3> Serial interface number Router(config)# interface serial 4/0 Router(config-if)#	Enter interface configuration mode by specifying the serial interface that you want to configure using the interface serial global configuration command. Enter ? to display what you must enter next on the command line. In this example, you must enter the serial interface slot number and port number, separated by a forward slash. You are in interface configuration mode when the prompt changes to Router(config-if)#.

Table 2 *How to Find Command Options (continued)*

Command	Comment
<pre>Router(config-if)# ? Interface configuration commands: . . . ip Interface Internet Protocol config commands keepalive Enable keepalive lan-name LAN Name command llc2 LLC2 Interface Subcommands load-interval Specify interval for load calculation for an interface locaddr-priority Assign a priority group logging Configure logging for interface loopback Configure internal loopback on an interface mac-address Manually set interface MAC address mls mls router sub/interface commands mpoa MPOA interface configuration commands mtu Set the interface Maximum Transmission Unit (MTU) netbios Use a defined NETBIOS access list or enable name-caching no Negate a command or set its defaults nrzi-encoding Enable use of NRZI encoding ntp Configure NTP . . . Router(config-if)#</pre>	Enter ? to display a list of all the interface configuration commands available for the serial interface. This example shows only some of the available interface configuration commands.
<pre>Router(config-if)# ip ? Interface IP configuration subcommands: access-group Specify access control for packets accounting Enable IP accounting on this interface address Set the IP address of an interface authentication authentication subcommands bandwidth-percent Set EIGRP bandwidth limit broadcast-address Set the broadcast address of an interface cgmp Enable/disable CGMP directed-broadcast Enable forwarding of directed broadcasts dvmrp DVMRP interface commands hello-interval Configures IP-EIGRP hello interval helper-address Specify a destination address for UDP broadcasts hold-time Configures IP-EIGRP hold time . . . Router(config-if)# ip</pre>	Enter the command that you want to configure for the interface. This example uses the ip command. Enter ? to display what you must enter next on the command line. This example shows only some of the available interface IP configuration commands.

Table 2 *How to Find Command Options (continued)*

Command	Comment
Router(config-if)# ip address ? A.B.C.D IP address negotiated IP Address negotiated over PPP Router(config-if)# ip address	Enter the command that you want to configure for the interface. This example uses the ip address command. Enter ? to display what you must enter next on the command line. In this example, you must enter an IP address or the negotiated keyword. A carriage return (<cr>) is not displayed; therefore, you must enter additional keywords or arguments to complete the command.
Router(config-if)# ip address 172.16.0.1 ? A.B.C.D IP subnet mask Router(config-if)# ip address 172.16.0.1	Enter the keyword or argument you want to use. This example uses the 172.16.0.1 IP address. Enter ? to display what you must enter next on the command line. In this example, you must enter an IP subnet mask. A <cr> is not displayed; therefore, you must enter additional keywords or arguments to complete the command.
Router(config-if)# ip address 172.16.0.1 255.255.255.0 ? secondary Make this IP address a secondary address <cr> Router(config-if)# ip address 172.16.0.1 255.255.255.0	Enter the IP subnet mask. This example uses the 255.255.255.0 IP subnet mask. Enter ? to display what you must enter next on the command line. In this example, you can enter the secondary keyword, or you can press Enter. A <cr> is displayed; you can press Enter to complete the command, or you can enter another keyword.
Router(config-if)# ip address 172.16.0.1 255.255.255.0 Router(config-if)#	In this example, Enter is pressed to complete the command.

Using the no and default Forms of Commands

Almost every configuration command has a **no** form. In general, use the **no** form to disable a function. Use the command without the **no** keyword to reenable a disabled function or to enable a function that is disabled by default. For example, IP routing is enabled by default. To disable IP routing, use the **no ip routing** command; to reenable IP routing, use the **ip routing** command. The Cisco IOS software command reference publications provide the complete syntax for the configuration commands and describe what the **no** form of a command does.

Configuration commands also can have a **default** form, which returns the command settings to the default values. Most commands are disabled by default, so in such cases using the **default** form has the same result as using the **no** form of the command. However, some commands are enabled by default and

have variables set to certain default values. In these cases, the **default** form of the command enables the command and sets the variables to their default values. The Cisco IOS software command reference publications describe the effect of the **default** form of a command if the command functions differently than the **no** form.

Saving Configuration Changes

Use the **copy system:running-config nvram:startup-config** command to save your configuration changes to the startup configuration so that the changes will not be lost if the software reloads or a power outage occurs. For example:

```
Router# copy system:running-config nvram:startup-config
Building configuration...
```

It might take a minute or two to save the configuration. After the configuration has been saved, the following output appears:

```
[OK]
Router#
```

On most platforms, this task saves the configuration to NVRAM. On the Class A Flash file system platforms, this task saves the configuration to the location specified by the CONFIG_FILE environment variable. The CONFIG_FILE variable defaults to NVRAM.

Filtering Output from the show and more Commands

In Cisco IOS Release 12.0(1)T and later releases, you can search and filter the output of **show** and **more** commands. This functionality is useful if you need to sort through large amounts of output or if you want to exclude output that you need not see.

To use this functionality, enter a **show** or **more** command followed by the “pipe” character (**|**); one of the keywords **begin**, **include**, or **exclude**; and a regular expression on which you want to search or filter (the expression is case-sensitive):

```
command | {begin | include | exclude} regular-expression
```

The output matches certain lines of information in the configuration file. The following example illustrates how to use output modifiers with the **show interface** command when you want the output to include only lines in which the expression “protocol” appears:

```
Router# show interface | include protocol

FastEthernet0/0 is up, line protocol is up
Serial4/0 is up, line protocol is up
Serial4/1 is up, line protocol is up
Serial4/2 is administratively down, line protocol is down
Serial4/3 is administratively down, line protocol is down
```

For more information on the search and filter functionality, refer to the “Using the Command-Line Interface” chapter in the *Cisco IOS Configuration Fundamentals Configuration Guide*.

Identifying Supported Platforms

Cisco IOS software is packaged in feature sets consisting of software images that support specific platforms. The feature sets available for a specific platform depend on which Cisco IOS software images are included in a release. To identify the set of software images available in a specific release or to find out if a feature is available in a given Cisco IOS software image, see the following sections:

- Using Feature Navigator
- Using Software Release Notes

Using Feature Navigator

Feature Navigator is a web-based tool that enables you to quickly determine which Cisco IOS software images support a particular set of features and which features are supported in a particular Cisco IOS image.

Feature Navigator is available 24 hours a day, 7 days a week. To access Feature Navigator, you must have an account on Cisco.com. If you have forgotten or lost your account information, e-mail the Contact Database Administration group at cdbadmin@cisco.com. If you do not have an account on Cisco.com, go to <http://www.cisco.com/register> and follow the directions to establish an account.

To use Feature Navigator, you must have a JavaScript-enabled web browser such as Netscape 3.0 or later, or Internet Explorer 4.0 or later. Internet Explorer 4.0 always has JavaScript enabled. To enable JavaScript for Netscape 3.x or Netscape 4.x, follow the instructions provided with the web browser. For JavaScript support and enabling instructions for other browsers, check with the browser vendor.

Feature Navigator is updated when major Cisco IOS software releases and technology releases occur. You can access Feature Navigator at the following URL:


<http://www.cisco.com/go/fn>

Using Software Release Notes


Cisco IOS software releases include release notes that provide the following information:

- Platform support information
- Memory recommendations
- Microcode support information
- Feature set tables
- Feature descriptions
- Open and resolved severity 1 and 2 caveats for all platforms

Release notes are intended to be release-specific for the most current release, and the information provided in these documents may not be cumulative in providing information about features that first appeared in previous releases.



Cisco IOS User Interface Commands



Basic Command-Line Interface Commands

This chapter describes the commands used to enter and exit the various Cisco IOS configuration command modes. It provides a description of help features, command-line interface (CLI) navigation commands, and the command history feature.

The CLI allows you to enter partial Cisco IOS configuration commands. The software recognizes a command when you enter enough characters of the command to uniquely identify it.

For user interface task information and examples, see the “Using the Command-Line Interface” chapter of the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

disable

To exit privileged EXEC mode and return to user EXEC mode, or to exit to a lower privilege level, enter the **disable** EXEC command.

disable [*privilege-level*]

Syntax Description

privilege-level (Optional) Specific privilege level (other than user EXEC mode).

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Up to 16 security levels can be configured using Cisco IOS software. If such levels are configured on a system, using this command with the *privilege-level* option allows you to exit to a lower security level. If a level is not specified, the user will exit to the user EXEC mode, which is the default.



Note

Five EXEC commands are associated with privilege level 0: **disable**, **enable**, **exit**, **help**, and **logout**. If you configure a privilege level greater than 0, these five commands will not be included in the command set for that privilege level.

Examples

In the following example, the user enters privileged EXEC mode using the **enable** command, then exits back to user EXEC mode using the **disable** command. Note that the prompt for user EXEC mode is >, and the prompt for privileged EXEC mode is #.

```
Router> enable
Password: <letmein>
Router# disable
Router>
```

Related Commands

Command	Description
enable	Enables higher privilege level access, such as privileged EXEC mode.

editing

To reenable Cisco IOS enhanced editing features for a particular line after they have been disabled, use the **editing** line configuration command. To disable these features, use the **no** form of this command.

editing

no editing

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Enhanced editing features are enabled by default. However, there may be situations in which you need to disable these features. The **no** form of this command disables these enhanced editing features, and the plain form of the command can be used to reenable these features.

[Table 3](#) provides a description of the keys used to enter and edit commands when the editing features are enabled. Ctrl indicates the Control key, which must be pressed simultaneously with its associated letter key. Esc indicates the Escape key, which must be pressed first, followed by its associated letter key. A comma is used in the following table to indicate a key sequence (the comma key should not be pressed). Keys are not case sensitive. Many letters used for CLI navigation and editing were chosen to provide an easy way of remembering their functions. In the following table ([Table 3](#)), characters are bolded in the “Function Summary” column to indicate the relation between the letter used and the function.

Table 3 **Command Editing Keys and Functions**

Keys	Function Summary	Function Details
Tab	Complete command	Completes a partial command name entry. When you enter a unique set of characters and press the Tab key, the system completes the command name. If you enter a set of characters that could indicate more than one command, the system beeps to indicate an error. To view the commands which match the set of characters you have entered, enter a question mark (?) immediately following the partial command (no space). The CLI will then list the commands that begin with that string.
Return (at the command line)	Execute	Executes the command.
Return (at the --More-- prompt)	Continue	Displays the next line of output.
Space Bar (at the --More-- prompt)	Continue	Displays the next screen of output. The amount of output you see will depend on the screen depth setting of your terminal.
Delete or Backspace	Backspace	Erases the character to the left of the cursor.
Left Arrow ¹ or Ctrl-B	Back character	Moves the cursor one character to the left. When you enter a command that extends beyond a single line, you can press the Left Arrow or Ctrl-B keys repeatedly to scroll back toward the system prompt and verify the beginning of the command entry.
Right Arrow ¹ or Ctrl-F	Forward character	Moves the cursor one character to the right.
Esc, B	Back word	Moves the cursor back one word.
Esc, F	Forward word	Moves the cursor forward one word.
Ctrl-A	Beginning of line	Moves the cursor to the beginning of the line.
Ctrl-E	End of line	Moves the cursor to the end of the command line.
Ctrl-D	Delete character	Deletes the character at the cursor.
Esc, D	Delete next word	Deletes from the cursor to the end of the word .
Ctrl-W	Delete previous word	Deletes the word to the left of the cursor.
Ctrl-K	Delete line forward	Deletes all characters from the cursor to the end of the command line.
Ctrl-U or Ctrl-X	Delete line backward	Deletes all characters from the cursor back to the beginning of the command line.
Ctrl-T	Transpose characters	Transposes the character to the left of the cursor with the character located at the cursor.

Table 3 Command Editing Keys and Functions (continued)

Keys	Function Summary	Function Details
Ctrl-R or Ctrl-L	Redisplay line	Redisplays the system prompt and command line.
Ctrl-V or Esc, Q	Ignore editing	Inserts a code to indicate to the system that the keystroke immediately following should be treated as a command entry, <i>not</i> as an editing key.
Up Arrow ¹ or Ctrl-P	Previous command	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Down Arrow ¹ or Ctrl-N (next)	Next command	Returns to more recent commands in the history buffer (after recalling commands with the Up Arrow or Ctrl-P). Repeat the key sequence to recall successively more recent commands.
Ctrl-Y	Recall last deleted command	Recalls the most recent entry in the delete buffer. The delete buffer contains the last ten items you have deleted or cut. Ctrl-Y can be used in conjunction with Esc Y.
Esc, Y	Recall next deleted command	Recalls the next entry in the delete buffer. The delete buffer contains the last ten items you have deleted. Press Ctrl-Y first to recall the most recent entry. Then press Esc Y up to nine times to recall the remaining entries in the buffer. If you bypass an entry, continue to press Esc Y to cycle back to it.
Esc, C	Capitalize word	Capitalizes the word from the cursor to the end of the word.
Esc, U	Make word uppercase	Changes all letters from the cursor to the next space on the line appear in uppercase letters.
Esc, L	Make word lowercase	Changes the word to lowercase from the cursor to the end of the word.

1. The arrow keys function only with ANSI-compatible terminals.

Examples

In the following example, enhanced editing mode is disabled on line 3:

```
Router(config)# line 3
Router(config-line)# no editing
```

Related Commands

Command	Description
terminal editing	Controls CLI enhanced editing feature for the current terminal session.

enable

To enter privileged EXEC mode, or any other security level set by a system administrator, use the **enable** EXEC command.

enable [*privilege-level*]

Syntax Description	<i>privilege-level</i> (Optional) Privilege level at which to log in.				
Defaults	Privilege-level 15 (privileged EXEC)				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>10.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines

Entering privileged EXEC mode enables the use of privileged commands. Because many of the privileged commands set operating parameters, privileged access should be password-protected to prevent unauthorized use. If the system administrator has set a password with the **enable password** global configuration command, you are prompted to enter it before being allowed access to privileged EXEC mode. The password is case sensitive.

If an **enable** password has not been set, enable mode only can be accessed through the console connection.

Security levels can be set by an administrator using the **enable password** and **privilege level** commands. Up to 16 privilege levels can be specified, using the numbers 0 through 15. Using these privilege levels, the administrator can allow or deny access to specific commands. Privilege level 0 is associated with user EXEC mode, and privilege level 15 is associated with privileged EXEC mode.

For more information on defined privilege levels, see the “Passwords and Privileges” chapters of the *Cisco IOS Security Configuration Guide* and the *Cisco IOS Security Command Reference* publications.

If a level is not specified when entering the **enable** command, the user will enter the default mode of privileged EXEC (level 15).

Examples

In the following example, the user enters privileged EXEC mode using the **enable** command. The system prompts the user for a password before allowing access to the privileged EXEC mode. The password is not printed to the screen. The user then exits back to user EXEC mode using the **disable** command. Note that the prompt for user EXEC mode is >, and the prompt for privileged EXEC mode is #.

```
Router> enable
Password: <letmein>
Router# disable
Router>
```

Related Commands

Command	Description
disable	Exits from privileged EXEC mode to user EXEC mode, or, if privilege levels are set, to the specified privilege level.
enable password	Sets a local password to control access to various privilege levels.
privilege level (global)	Sets a privilege level for a command.
privilege level (line)	Sets a privilege level for a command for a specific line.

end

To end the current configuration session and return to privileged EXEC mode, use the **end** global configuration command.

end

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines This command will bring you back to privileged EXEC mode regardless of what configuration mode or configuration submode you are in.



Note This global configuration command can be used in any configuration mode.

Use this command when you are done configuring the system and you want to return to EXEC mode to perform verification steps.

Examples In the following example, the **end** command is used to exit from ALPS ASCU configuration mode and return to privileged EXEC mode. A **show** command is used in privileged EXEC mode to verify the configuration.

```
Router# configure terminal
Router(config)# interface serial 1:1
Router(config-if)# alps ascu 4B
Router(config-alps-ascu)# end
Router# show interface serial 1:1
```

Related Commands	Command	Description
	exit (global)	Exits from the current configuration mode.

exit (EXEC)

To close an active terminal session by logging off the router, use the **exit** command in EXEC mode.

exit

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use the exit (EXEC) command in EXEC mode to exit the active session (log off the device).

Examples	In the following example, the exit (global) command is used to move from global configuration mode to privileged EXEC mode, the disable command is used to move from privileged EXEC mode to user EXEC mode, and the exit (EXEC) command is used to log off (exit the active session):

```
Router(config)# exit
Router# disable
Router> exit
```

Related Commands	Command	Description
	disconnect	Disconnects a line.
	end	Exits configuration mode, or any of the configuration submodes.
	exit (global)	Exits from the current configuration mode to the next highest configuration mode.

exit (global)

To exit any configuration mode to the next highest mode in the CLI mode hierarchy, use the **exit** command in any configuration mode.

exit

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes All configuration modes

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The **exit** command is used in the Cisco IOS CLI to exit from the current command mode to the next highest command mode in the CLI mode hierarchy.

For example, use the exit command in global configuration mode to return to privileged EXEC mode. Use the exit command in interface, line, or router configuration mode to return to global configuration mode. Use the exit command in subinterface configuration mode to return to interface configuration mode. At the highest level, EXEC mode, the exit command will exit the EXEC mode and disconnect from the router interface (see the description of the **exit** (EXEC) command for details).

Examples The following example displays an exit from the subinterface configuration mode to return to the interface configuration mode:

```
Router(config-subif)# exit
Router(config-if)#
```

The following example displays an exit from the interface configuration mode to return to the global configuration mode:

```
Router(config-if)# exit
Router(config)#
```

Related Commands	Command	Description
	disconnect	Disconnects a line.
	end	Exits from any configuration mode to privileged EXEC mode.
	exit (EXEC)	Closes the active terminal session by logging off the router.

full-help

To get help for the full set of user-level commands, use the **full-help** line configuration command.

full-help

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The full-help command enables (or disables) an unprivileged user to see all of the help messages available. It is used with the show ? command.

Examples	In the following example, the show ? command is used first with full-help disabled. Then full-help is enabled for the line, and the show ? command is used again to demonstrate the additional help output that is displayed.

```
Router> show ?
```

```
bootflash  Boot Flash information
calendar   Display the hardware calendar
clock      Display the system clock
context    Show context information
dialer     Dialer parameters and statistics
history    Display the session command history
hosts      IP domain-name, lookup style, nameservers, and host table
isdn       ISDN information
kerberos   Show Kerberos Values
modemcap   Show Modem Capabilities database
ppp        PPP parameters and statistics
rmon       rmon statistics
sessions   Information about Telnet connections
snmp       snmp statistics
terminal   Display terminal configuration parameters
users      Display information about terminal lines
version    System hardware and software status
```

```
Router> enable
Password:<letmein>
```

```
Router# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
```

```

Router(config)# line console 0
Router(config-line)# full-help
Router(config-line)# ^Z
Router#
%SYS-5-CONFIG_I: Configured from console by console
Router# disable
Router> show ?

  access-expression  List access expression
  access-lists       List access lists
  aliases            Display alias commands
  apollo             Apollo network information
  appletalk          AppleTalk information
  arp               ARP table
  async             Information on terminal lines used as router interfaces
  bootflash          Boot Flash information
  bridge            Bridge Forwarding/Filtering Database [verbose]
  bsc               BSC interface information
  bstun             BSTUN interface information
  buffers            Buffer pool statistics
  calendar           Display the hardware calendar
  .
  .
  .
  translate          Protocol translation information
  ttycap            Terminal capability tables
  users             Display information about terminal lines
  version           System hardware and software status
  vines             VINES information
  vlans             Virtual LANs Information
  whoami            Info on current tty line
  x25               X.25 information
  xns               XNS information
  xremote           XRemote statistics

```

Related Commands

Command	Description
help	Displays a brief description of the help system.

help

To display a brief description of the help system, enter the **help** command.

help

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values

Command Modes

All command modes

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The **help** command provides a brief description of the context-sensitive help system, which functions as follows:

- To list all commands available for a particular command mode, enter a question mark (?) at the system prompt.
- To obtain a list of commands that begin with a particular character string, enter the abbreviated command entry immediately followed by a question mark (?). This form of help is called *word help*, because it lists only the keywords or arguments that begin with the abbreviation you entered.
- To list the keywords and arguments associated with a command, enter a question mark (?) in place of a keyword or argument on the command line. This form of help is called *command syntax help*, because it lists the keywords or arguments that apply based on the command, keywords, and arguments you have already entered.

Examples

In the following example, the **help** command is used to display a brief description of the help system:

```
Router# help
```

```
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
```

```
Two styles of help are provided:
```

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show pr?'.)

The following example shows how to use word help to display all the privileged EXEC commands that begin with the letters “co”. The letters entered before the question mark are reprinted on the next command line to allow the user to continue entering the command.

```
Router# co?
configure connect copy
Router# co
```

The following example shows how to use command syntax help to display the next argument of a partially complete **access-list** command. One option is to add a wildcard mask. The <cr> symbol indicates that the other option is to press Return to execute the command without adding any more keywords or arguments. The characters entered before the question mark are reprinted on the next command line to allow the user to continue entering the command or to execute that command as it is.

```
Router(config)# access-list 99 deny 131.108.134.234 ?
A.B.C.D Mask of bits to ignore
<cr>
Router(config)# access-list 99 deny 131.108.134.234
```

Related Commands

Command	Description
full-help	Gets help for the full set of user-level commands.

history

To enable the command history function, use the **history** line configuration command. To disable the command history feature, use the **no** form of this command.

history

no history

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled, ten command lines in buffer

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The command history feature provides a record of EXEC commands that you have entered. This feature is particularly useful for recalling long or complex commands or entries, including access lists.

To change the number of command lines that the system will record in its history buffer, use the **history size** line configuration command.

The **history** command enables the history function with the last buffer size specified or, if there was not a prior setting, with the default of ten lines. The **no history** command disables the history feature.

The **show history** EXEC command will list the commands you have entered, but you can also use your keyboard to display individual commands. [Table 4](#) lists the keys you can use to recall commands from the command history buffer.

Table 4 History Keys

Key(s)	Functions
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals.

Examples

In the following example, line 4 is configured with a history buffer size of 35 lines:

```
Router(config)# line 4
```

```
Router(config-line)# history size 35
```

Related Commands

Command	Description
history size	Sets the command history buffer size for a particular line.
show history	Lists the commands you have entered in the current EXEC session.
terminal history	Enables the command history feature for the current terminal session or changes the size of the command history buffer for the current terminal session.

history size

To change the command history buffer size for a particular line, use the **history size** line configuration command. To reset the command history buffer size to ten lines, use the **no** form of this command.

history size *number-of-lines*

no history size

Syntax Description

<i>number-of-lines</i>	Specifies the number of command lines that the system will record in its history buffer. The range is from 0 to 256. The default is ten.

Defaults

Ten command lines

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The **history size** command should be used in conjunction with the **history** and **show history** commands. The **history** command enables or disables the command history function. The **show history** command lists the commands you have entered in the current EXEC session. The number of commands that the history buffer will show is set by the **history size** command.



Note

The **history size** command only sets the size of the buffer; it does not reenables the history feature. If the **no history** command is used, the **history** command must be used to reenables this feature.

Examples

The following example displays line 4 configured with a history buffer size of 35 lines:

```
Router(config)# line 4
Router(config-line)# history size 35
```

Related Commands

Command	Description
history	Enables or disables the command history function.
show history	Lists the commands you have entered in the current EXEC session.
terminal history size	Enables the command history function for the current terminal session or changes the size of the command history buffer for the current terminal session.

logout

To close an active terminal session by logging off the router, use the **logout** command in user EXEC mode.

logout

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	User EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples	In the following example, the exit (global) command is used to move from global configuration mode to privileged EXEC mode, the disable command is used to move from privileged EXEC mode to user EXEC mode, and the logout command is used to log off (exit from the active session):

```
Router(config)# exit
Router# disable
Router> logout
```

Related Commands	Command	Description
	exit (global)	Exits any configuration mode to the next highest mode in the CLI mode hierarchy.

menu (EXEC)

To display a preconfigured user menu, use the **menu** command in user or privileged EXEC mode.

menu *menu-name*

Syntax Description	<i>menu-name</i>	The name of the menu.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	A user menu is a type of user interface where text descriptions of actions to be performed are displayed to the user. The user can use the menu to select services and functions without having to know the details of command-line interface (CLI) commands.

Menus can be created for users in global configuration mode, using the commands listed in the “Related Commands” section. The description of these commands can be found in the [“Connection, Menu, and System Banner Commands”](#) chapter of this document.

A menu can be invoked at either the user or privileged EXEC level, but if an item in the menu contains a privileged EXEC command, the user must be logged in at the privileged level for the command to succeed.

Examples	The following example invokes a menu named OnRamp:

```
Router> menu OnRamp

Welcome to OnRamp Internet Services

Type a number to select an option;
Type 9 to exit the menu.

1    Read email
2    UNIX Internet access
3    Resume UNIX connection

6    Resume next connection

9    Exit menu system
```

Related Commands	Command	Description
	menu clear-screen	Clears the terminal screen before displaying a menu.
	menu command	Specifies underlying commands for user interface menus.
	menu default	Specifies the menu item to use as the default.
	menu line-mode	Requires the user to press Enter after specifying an option number.
	menu options	Sets options for items in user interface menus.
	menu prompt	Specifies the prompt for a user interface menu.
	menu single-space	Displays menu items single-spaced rather than double-spaced.
	menu status-line	Displays a line of status information about the current user at the top of a menu
	menu text	Specifies the text of a menu item in a user interface menu.
	menu title	Creates a title, or banner, for a user menu.
	no menu	Deletes a specified menu from a menu configuration.

more begin

To search the output of any **more** command, use the **more begin** command in EXEC mode. This command begins unfiltered output of the **more** command with the first line that contains the regular expression you specify.

more *file-url* | **begin** *regular-expression*

Syntax Description	<i>file-url</i>	The Universal Resource Locator (url) of the file to display. More commands are advanced show commands; for details, see the command reference page in this book for the more command.
		A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
	<i>regular-expression</i>	Any regular expression found in more command output.
	/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.
	-	Specifies a filter at a --More-- prompt that only displays output lines that do not contain the regular expression.
	+	Specifies a filter at a --More-- prompt that only displays output lines that contain the regular expression.

Command Modes	EXEC

Command History	Release	Modification
	11.3 AA	The more command was introduced.
	12.0(1)T	This extension of the more command was introduced.

Usage Guidelines The *regular-expression* argument is case sensitive and allows for complex matching requirements.

You can specify a new search at every --More-- prompt.

To search the remaining output of the **more** command, use the following command at the --More-- prompt:

/regular-expression

To filter the remaining output of the **more** command, use one of the following commands at the --More-- prompt:

-regular-expression

+regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-Z**.

**Note**

Once you specify a filter for a **more** command, you cannot specify another filter at a --More-- prompt. The first specified filter remains until the **more** command output finishes or until you interrupt the output. The use of the keyword **begin** does not constitute a filter.

Because prior output is not saved, you cannot search or filter backward through prior output.

Examples

The following is partial sample output of the **more nvram:startup-config | begin ip** command that begins unfiltered output with the first line that contain the regular expression “ip.” At the --More-- prompt, the user specifies a filter to exclude output lines that contain the regular expression “ip.”

```
router# more nvram:startup-config | begin ip

ip subnet-zero
ip domain-name cisco.com
ip name-server 198.92.30.32
ip name-server 171.69.2.132
!
isdn switch-type primary-5ess
.
.
.
interface Ethernet1
 ip address 5.5.5.99 255.255.255.0
--More--
-ip
filtering...
 media-type 10BaseT
!
interface Serial0:23
 encapsulation frame-relay
 no keepalive
 dialer string 4001
 dialer-group 1
 isdn switch-type primary-5ess
 no fair-queue
```

Related Commands

Command	Description
more exclude	Filters more command output so that it excludes lines that contain a particular regular expression.
more include	Filters more command output so that it displays only lines that contain a particular regular expression.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show exclude	Filters show command output so that it excludes lines that contain a particular regular expression.
show include	Filters show command output so that it displays only lines that contain a particular regular expression.

more exclude

To filter **more** command output so that it excludes lines that contain a particular regular expression, use the **more exclude** command in EXEC mode.

more *file-url* | **exclude** *regular-expression*

Syntax Description

<i>file-url</i>	The Universal Resource Locator (url) of the file to display. More commands are advanced show commands; for details, see the command reference page in this book for the more command.
	A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	Any regular expression found in more command output.
/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.

Command Modes

EXEC

Command History

Release	Modification
11.3 AA	The more command was introduced.
12.0(1)T	This extension of the more command was introduced.

Usage Guidelines

The *regular-expression* argument is case sensitive and allows for complex matching requirements.

You can specify a new search at any --More-- prompt. To search the remaining output of the **more** command, use the following command at the --More-- prompt:

/regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-Z**.

Because prior output is not saved, you cannot search or filter backward through prior output.

Examples

The following is partial sample output of the **more nvram:startup-config | exclude service** command. The use of **| exclude service** in the command specifies a filter that excludes lines that contain the regular expression “service.” At the --More-- prompt, the user searches for the regular expression “Dialer1,” which continues filtered output with the first line that contains “Dialer1.”

```
router# more nvram:startup-config | exclude service
!
version 12.0
!
hostname router
!
boot system flash
no logging buffered
!
```

more exclude

```

ip subnet-zero
ip domain-name cisco.com
.
.
.
--More--
/Dialer1
filtering...
interface Dialer1
  no ip address
  no ip directed-broadcast
  dialer in-band
  no cdp enable

```

Related Commands

Command	Description
more begin	Begins unfiltered output of the more command with the first line that contains the regular expression you specify.
more include	Filters more command output so that it displays only lines that contain a particular regular expression.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show exclude	Filters show command output so that it excludes lines that contain a particular regular expression.
show include	Filters show command output so that it displays only lines that contain a particular regular expression.

more include

To filter **more** command output so that it displays only lines that contain a particular regular expression, use the **more include** command in EXEC mode.

more *file-url* | **include** *regular-expression*

Syntax Description

<i>file-url</i>	The Universal Resource Locator (url) of the file to display. More commands are advanced show commands; for details, see the command reference page in this book for the more command.
	A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	Any regular expression found in more command output.
/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.

Command Modes

EXEC

Command History

Release	Modification
11.3 AA	The more command was introduced.
12.0(1)T	This extension of the more command was introduced.

Usage Guidelines

The *regular-expression* argument is case sensitive and allows for complex matching requirements.

You can specify a new search at any --More-- prompt. To search the remaining output of the **more** command, use the following syntax at the --More-- prompt:

/regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-Z**.

Because prior output is not saved, you cannot search or filter backward through prior output.

Examples

The following is partial sample output of the **more nvram:startup-config | include ip** command. It only displays lines that contain the regular expression “ip.”

```
router# more nvram:startup-config | include ip

ip subnet-zero
ip domain-name cisco.com
ip name-server 198.92.30.32
ip name-server 171.69.2.132
description ip address 172.21.53.199 255.255.255.0
ip address 172.21.53.199 255.255.255.0
```

Related Commands

Command	Description
more begin	Begins unfiltered output of the more command with the first line that contains the regular expression you specify.
more exclude	Filters more command output so that it excludes lines that contain a particular regular expression.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show exclude	Filters show command output so that it excludes lines that contain a particular regular expression.
show include	Filters show command output so that it displays only lines that contain a particular regular expression.

show begin

To begin the output of any **show** command from a specified string, use the **show begin** command in EXEC mode.

show *any-command* | **begin** *regular-expression*

Syntax Description

<i>any-command</i>	Any supported show command.
	A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	Any regular expression found in show command output. The show output will begin from the first instance of this string (output prior to this string will not be printed to the screen). The string is case-sensitive. Use parenthesis to indicate a literal use of spaces.
/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.
-	Specifies a filter at a --More-- prompt that only displays output lines that do not contain the regular expression.
+	Specifies a filter at a --More-- prompt that only displays output lines that contain the regular expression.

Command Modes

EXEC

Command History

Release	Modification
8.3	The show command was introduced.
12.0(1)T	This extension of the show command was introduced.

Usage Guidelines

The *regular-expression* argument is case sensitive and allows for complex matching requirements. Use parenthesis to indicate a literal use of spaces. For example, | **begin u** indicates that the show output should begin with any line that contains a u; | **begin (u)** indicates that the show output should begin with any line that contains a space and a u together (line has a word that begins with a lowercase u).

To search the remaining output of the **show** command, use the following command at the --More-- prompt:

/regular-expression

You can specify a filtered search at any --More-- prompt. To filter the remaining output of the **show** command, use one of the following commands at the --More-- prompt:

-regular-expression

+regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-z**.

**Note**

Once you specify a filter for a **show** command, you cannot specify another filter at the next --More-- prompt. The first specified filter remains until the **more** command output finishes or until you interrupt the output. The use of the keyword **begin** does not constitute a filter.

Because prior output is not saved, you cannot search or filter backward through prior output.

**Note**

A few **show** commands that have long output requirements do not require user input at the --More-- prompt to jump to the next table of output; these types of output require you to enter the same number of Ctrl-^ or Ctrl-Z combinations as there are --More-- prompts to completely abort output.

Examples

The following is partial sample output of the **show interface | begin Ethernet** command that begins unfiltered output with the first line that contains the regular expression “Ethernet.” At the --More-- prompt, the user specifies a filter to show only the lines in the remaining output that contain the regular expression “Serial.”

```
router# show interface | begin Ethernet
Ethernet0 is up, line protocol is up
Hardware is Lance, address is 0060.837c.6399 (bia 0060.837c.6399)
  Description: ip address is 172.1.2.14 255.255.255.0
  Internet address is 172.1.2.14/24
.
.
.
      0 lost carrier, 0 no carrier
      0 output buffer failures, 0 output buffers swapped out
--More--
+Serial
filtering...
Serial1 is up, line protocol is up
Serial2 is up, line protocol is up
Serial3 is up, line protocol is down
Serial4 is down, line protocol is down
Serial5 is up, line protocol is up
Serial6 is up, line protocol is up
Serial7 is up, line protocol is up
```

Related Commands

Command	Description
more begin	Begins unfiltered output of the more command with the first line that contains the regular expression you specify.
more exclude	Filters more command output so that it excludes lines that contain a particular regular expression.
more include	Filters more command output so that it displays only lines that contain a particular regular expression.
show exclude	Filters show command output so that it excludes lines that contain a particular regular expression.
show include	Filters show command output so that it displays only lines that contain a particular regular expression.

show exclude

To filter **show** command output so that it excludes lines that contain a particular regular expression, use the **show exclude** command in EXEC mode.

show *any-command* | **exclude** *regular-expression*

Syntax Description

<i>any-command</i>	Any supported show command.
	A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	Any regular expression found in show command output.
/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.

Command Modes

EXEC

Command History

Release	Modification
8.3	The show command was introduced.
12.0(1)T	This extension of the show command was introduced.

Usage Guidelines

The *regular-expression* argument is case sensitive and allows for complex matching requirements.

You can specify a new search at every --More-- prompt. To search the remaining output of the **show** command, use the following syntax at the --More-- prompt:

/regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-Z**.

Because prior output is not saved, you cannot search or filter backward through prior output.



Note

A few **show** commands that have long output requirements do not require user input at the --More-- prompt to jump to the next table of output; these types of output require you to enter the same number of Ctrl-^ or Ctrl-Z combinations as there are --More-- prompts to completely abort output.

Examples

The following is partial sample output of the **show | exclude** command used with the **show buffers** command. It excludes lines that contain the regular expression “0 misses.” At the --More-- prompt, the user searches for the regular expression “Serial0,” which continues the filtered output with the first line that contains “Serial0.”

```
router# show buffers | exclude 0 misses

Buffer elements:
    398 in free list (500 max allowed)
Public buffer pools:
```

■ show exclude

```

Small buffers, 104 bytes (total 50, permanent 50):
    50 in free list (20 min, 150 max allowed)
    551 hits, 3 misses, 0 trims, 0 created
Big buffers, 1524 bytes (total 50, permanent 50):
    49 in free list (5 min, 150 max allowed)
Very Big buffers, 4520 bytes (total 10, permanent 10):
.
.
.
Huge buffers, 18024 bytes (total 0 permanent 0):
    0 in free list (0 min, 4 max allowed)
--More--
/Serial0
filtering...
Serial0 buffers, 1543 bytes (total 64, permanent 64):
    16 in free list (0 min, 64 max allowed)
    48 hits, 0 fallbacks

```

Related Commands

Command	Description
more begin	Begins unfiltered output of the more command with the first line that contains the regular expression you specify.
more exclude	Filters more command output so that it excludes lines that contain a particular regular expression.
more include	Filters more command output so that it displays only lines that contain a particular regular expression.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show include	Filters show command output so that it displays only lines that contain a particular regular expression.

show history

To list the commands you have entered in the current EXEC session, use the **show history** EXEC command.

show history

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The command history feature provides a record of EXEC commands you have entered. The number of commands that the history buffer will record is determined by the **history size** line configuration command or the **terminal history size** EXEC command.

[Table 5](#) lists the keys and functions you can use to recall commands from the command history buffer.

Table 5 History Keys

Key	Function
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals.

Examples The following is sample output from the **show history** command, which lists the commands the user has entered in EXEC mode for this session:

```
Router# show history
  help
  where
  show hosts
  show history
Router#
```

■ show history

Related Commands

Command	Description
history size	Enables the command history function, or changes the command history buffer size for a particular line.
terminal history size	Enables the command history feature for the current terminal session, or changes the size of the command history buffer for the current terminal session.

show include

To filter **show** command output so that it only displays lines that contain a particular regular expression, use the **show include** command in EXEC mode.

show *any-command* | **include** *regular-expression*

Syntax Description

<i>any-command</i>	Any supported show command.
	A vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	Any regular expression found in show command output. Use parenthesis to include spaces in the expression.
/	Specifies a search at a --More-- prompt that begins unfiltered output with the first line that contains the regular expression.

Command Modes

EXEC

Command History

Release	Modification
8.3	The show command was introduced.
12.0(1)T	This extension of the show command was introduced.

Usage Guidelines

The *regular-expression* argument is case sensitive and allows for complex matching requirements.

You can specify a new search at every --More-- prompt. To search the remaining output of the **show** command, use the following syntax at the --More-- prompt:

/regular-expression

When output volume is large, the search can produce long lists of output. To interrupt the output, press **Ctrl-^** (Ctrl-Shift-6) or **Ctrl-Z**.

Because prior output is not saved, you cannot search or filter backward through prior output.



Note

A few **show** commands that have long output requirements do not require user input at the --More-- prompt to jump to the next table of output; these types of output require you to enter the same number of Ctrl-^ or Ctrl-Z combinations as there are --More-- prompts to completely abort output.

Examples

The following is partial sample output of the **show interface | include (is)** command. It displays only lines that contain the regular expression “(is).” The parentheses force the inclusion of the spaces before and after “is.” Use of the parenthesis ensures that only lines containing “is” with a space both before and after it will be included in the output. Lines with words like “disconnect” will be excluded because there are not spaces around the instance of the string “is”.

```
router# show interface | include ( is )
```

show include

```

ATM0 is administratively down, line protocol is down
  Hardware is ATMizer BX-50
Dialer1 is up (spoofing), line protocol is up (spoofing)
  Hardware is Unknown
  DTR is pulsed for 1 seconds on reset
Ethernet0 is up, line protocol is up
  Hardware is Lance, address is 0060.837c.6399 (bia 0060.837c.6399)
  Internet address is 172.21.53.199/24
Ethernet1 is up, line protocol is up
  Hardware is Lance, address is 0060.837c.639c (bia 0060.837c.639c)
  Internet address is 5.5.5.99/24
Serial0:0 is down, line protocol is down
  Hardware is DSX1
.
.
.
--More--

```

At the `--More--` prompt, the user searches for the regular expression “Serial0:13”, which continues filtered output with the first line that contains “Serial0:13.”

```

/Serial0:13
filtering...
Serial0:13 is down, line protocol is down
  Hardware is DSX1
  Internet address is 11.0.0.2/8
    0 output errors, 0 collisions, 2 interface resets
  Timeslot(s) Used:14, Transmitter delay is 0 flags

```

Related Commands

Command	Description
more begin	Begins unfiltered output of the more command with the first line that contains the regular expression you specify.
more exclude	Filters more command output so that it excludes lines that contain a particular regular expression.
more include	Filters more command output so that it displays only lines that contain a particular regular expression.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show exclude	Filters show command output so that it excludes lines that contain a particular regular expression.

terminal editing

To reenable the enhanced editing mode for only the current terminal session, use the **terminal editing** EXEC command. To disable the enhanced editing mode on the current line, use the **no** form of this command.

terminal editing

terminal no editing

Syntax Description	This command has no arguments or keywords.

Defaults	Enabled

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command is identical to the editing EXEC mode command, except that it controls (enables or disables) enhanced editing for only the terminal session you are using. For a description of the available editing keys, see the description of the editing command in this chapter.

Examples	In the following example, enhanced editing mode is reenabled for only the current terminal session: Router> terminal editing

Related Commands	Command	Description
	editing	Controls CLI enhanced editing features for a particular line.

terminal full-help

To get help for the full set of user-level commands, use the **terminal full-help** EXEC mode command.

terminal full-help

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The terminal full-help command enables a user to see all of the help messages available from the terminal. It is used with the show ? command.

Examples	In the following example, the difference between the output of the show ? command before and after using the terminal full-help command is shown:

```
Router> show ?
```

```
bootflash  Boot Flash information
calendar   Display the hardware calendar
clock      Display the system clock
context    Show context information
dialer     Dialer parameters and statistics
history    Display the session command history
hosts      IP domain-name, lookup style, nameservers, and host table
isdn       ISDN information
kerberos   Show Kerberos Values
modemcap   Show Modem Capabilities database
ppp        PPP parameters and statistics
rmon       rmon statistics
sessions   Information about Telnet connections
snmp       snmp statistics
terminal   Display terminal configuration parameters
users      Display information about terminal lines
version    System hardware and software status
```

```
Router> terminal full-help
```

```
Router> show ?
```

```
access-expression  List access expression
access-lists       List access lists
aliases            Display alias commands
apollo             Apollo network information
```

appletalk	AppleTalk information
arp	ARP table
async	Information on terminal lines used as router interfaces
bootflash	Boot Flash information
bridge	Bridge Forwarding/Filtering Database [verbose]
bsc	BSC interface information
bstun	BSTUN interface information
buffers	Buffer pool statistics
calendar	Display the hardware calendar
cdp	CDP information
clns	CLNS network information
clock	Display the system clock
cls	DLC user information
cmns	Connection-Mode networking services (CMNS) information
compress	Show compression statistics.
.	
.	
.	
x25	X.25 information
xns	XNS information
xremote	XRemote statistics

Related Commands

Command	Description
full-help	Gets help for the full set of user-level commands.
help	Displays a brief description of the help system.

terminal history

To enable the command history feature for the current terminal session, use the **terminal history** command in user EXEC mode or privileged EXEC mode. To disable the command history feature, use the **no** form of this command.

terminal history

terminal no history

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled, history buffer of 10 lines

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The history feature provides a record of commands you have entered. This feature is particularly useful for recalling long or complex commands or entries for the purposes of modifying them slightly and reexecuting them.

The **terminal history** command enables the command history feature with the default buffer size or the last buffer size specified using the **terminal history size** command.

[Table 6](#) lists the keys and functions you can use to recall commands from the history buffer.

Table 6 History Keys

Key(s)	Function
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals.

Examples

In the following example, the command history feature is disabled for the current terminal session:

```
Router> terminal no history
```

Related Commands

Command	Description
history	Enables the command history function, or changes the command history buffer size for a particular line.
show history	Lists the commands you have entered in the current EXEC session.
terminal history size	Sets the size of the history buffer for the command history feature for the current terminal session.

terminal history size

To change the size of the command history buffer for the current terminal session, use the **terminal history size** EXEC mode command. To reset the command history buffer to its default size of 10 lines, use the **no** form of this command.

terminal history size *number-of-lines*

terminal no history size

Syntax Description	<i>number-of-lines</i>	Number of command lines that the system will record in its history buffer. The range is from 0 to 256. The default is 10.

Defaults	10 lines of command history

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The history feature provides a record of commands you have entered. This feature is particularly useful for recalling long or complex commands or entries for the purposes of modifying them slightly and reissuing them.

The **terminal history size** command enables the command history feature and sets the command history buffer size. The **terminal no history size** command resets the buffer size to the default of 10 command lines.

[Table 6](#) lists the keys and functions you can use to recall commands from the history buffer. When you use these keys, the commands recalled will be from EXEC mode if you are in EXEC mode, or from all configuration modes if you are in any configuration mode.

Table 7 History Keys

Key	Function
Ctrl-P or Up Arrow ¹	Recalls commands in the history buffer in a backward sequence, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or Down Arrow ¹	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the Up Arrow. Repeat the key sequence to recall successively more recent commands.

1. The arrow keys function only with ANSI-compatible terminals.

In EXEC mode, you can also use the **show history** command to show the contents of the command history buffer.

To check the current settings for the command history feature on your line, use the **show line** command.

Examples

In the following example, the number of command lines recorded is set to 15 for the current terminal session. The user then checks to see what line he/she is connected to using the **show users** command. The user uses this line information to issue the show line command. (In this example, the user uses the **show begin** option in the **show line** command to start the output at the “Editing is enabled/disabled” line.)

```
Router# terminal history size 15
Router# show users
```


```
      Line      User      Host(s)      Idle      Location
* 50 vty 0      admin      idle        00:00:00
! the * symbol indicates the active terminal session for the user (line 50)
```

```
Router# show line 50 | begin Editing
```

```
Editing is enabled.
! the following line shows the history settings for the line
History is enabled, history size is 15.
DNS resolution in show commands is enabled
Full user help is disabled
Allowed transports are telnet. Preferred is none.
No output characters are padded
No special data dispatching characters
```

Related Commands

Command	Description
history	Enables the command history function, or changes the command history buffer size for a particular line.
show begin	Searches the output of any show command and displays the output from the first instance of a specified string.
show history	Lists the commands you have entered in the current EXEC session.
terminal history	Enables the command history feature for the current terminal session.



The Setup Command

The “Using AutoInstall and Setup” chapter of the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide* describes the tasks associated with using the AutoInstall and Setup features.

The AutoInstall process does not require you to use any commands on the new routing device. Therefore, this chapter discusses only the **setup** command, which is used to enter Setup mode.

To locate documentation of other commands that appear in the “Using AutoInstall and Setup” chapter, use the *Cisco IOS Command Reference Master Index* or search online.

Setup is an interactive Cisco IOS software feature that allows you to perform first-time configuration or other basic configuration procedures on all Cisco devices. Setup mode guides you through the configuration process by prompting you for the information required to make the routing device function in the network.

While the use of the **setup** command is a quick way to set up a Cisco device, you can also use it after first-time startup to perform configuration changes. This chapter focuses on using the **setup** command after first-time startup.

Refer to the hardware-specific documentation that came with your platform for details on how to use Setup mode for first-time startup.

setup

To enter Setup mode, use the **setup** privileged EXEC command.

setup

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.

Usage Guidelines

Setup mode gives you the option of configuring your system without using the Cisco IOS CLI. For some tasks, you may find it easier to use Setup than to enter Cisco IOS commands individually. For example, you might want to use Setup to add a protocol suite, to make major addressing scheme changes, or to configure a newly installed interface. Although you can use the CLI to make these changes, Setup provides you with a high-level view of the configuration and guides you through the configuration process.

If you are not familiar with Cisco products and the CLI, Setup is a particularly valuable tool because it prompts you for the specific information required to configure your system.

**Note**

If you use Setup to modify a configuration because you have added or modified the hardware, be sure to verify the physical connections using the **show version** EXEC command. Also, verify the logical port assignments using the **show running-config** EXEC command to ensure that you configure the correct port. Refer to the hardware documentation for your platform for more information on physical and logical port assignments.

Before using Setup, you should have the following information so that you can configure the system properly:

- Which interfaces you want to configure
- Which routing protocols you wish to enable
- Whether the router is to perform bridging
- Network addresses for the protocols being configured
- Password strategy for your environment

When you enter the **setup** EXEC command after first-time startup, an interactive dialog called the *System Configuration Dialog* appears on the system console screen. The System Configuration Dialog guides you through the configuration process. It prompts you first for global parameters and then for interface parameters. The values shown in brackets next to each prompt reflect either the default settings or the last configured setting.

The prompts and the order in which they appear on the screen vary depending on the platform and the interfaces installed in the device.

You must progress through the System Configuration Dialog until you come to the item that you intend to change. To accept default settings for items that you do not want to change, press the **Return** or **Enter** key. The default choice is indicated by square brackets (for example, [yes]) before the prompt colon (:).

To exit Setup and return to privileged EXEC mode without making changes and without progressing through the entire System Configuration Dialog, press **Ctrl-C**.

The facility also provides help text for each prompt. To access help text, press the question mark (?) key at a prompt.

When you complete your changes, the system will automatically display the configuration file that was created during the Setup session. It also asks you if you want to use this configuration. If you answer Yes, the configuration is saved to NVRAM as the startup configuration file. If you answer No, the configuration is not saved and the process begins again. There is no default for this prompt; you must answer either Yes or No.

Examples

The following example displays the **setup** command facility to configure serial interface 0 and to add ARAP and IP/IPX support on the asynchronous interfaces:

```
Router# setup

--- System Configuration Dialog ---

At any point you may enter a question mark '?' for help.
Use ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.

Continue with configuration dialog? [yes]:

First, would you like to see the current interface summary? [yes]:

Interface      IP-Address      OK? Method      Status          Protocol
Ethernet0      172.16.72.2     YES manual        up              up
Serial0        unassigned      YES not set        administratively down down
Serial1        172.16.72.2     YES not set        up              up

Configuring global parameters:

Enter host name [Router]:

The enable secret is a one-way cryptographic secret used
instead of the enable password when it exists.

Enter enable secret [<Use current secret>]:

The enable password is used when there is no enable secret
and when using older software and some boot images.

Enter enable password [ww]:
Enter virtual terminal password [ww]:
Configure SNMP Network Management? [yes]:
Community string [public]:
Configure DECnet? [no]:
Configure AppleTalk? [yes]:
Multizone networks? [no]: yes
Configure IPX? [yes]:
Configure IP? [yes]:
Configure IGRP routing? [yes]:
Your IGRP autonomous system number [15]:
```

```
Configure Async lines? [yes]:
  Async line speed [9600]: 57600
  Configure for HW flow control? [yes]:
  Configure for modems? [yes/no]: yes
    Configure for default chat script? [yes]: no
  Configure for Dial-in IP SLIP/PPP access? [no]: yes
    Configure for Dynamic IP addresses? [yes]: no
    Configure Default IP addresses? [no]: yes
    Configure for TCP Header Compression? [yes]: no
    Configure for routing updates on async links? [no]:
  Configure for Async IPX? [yes]:
  Configure for Appletalk Remote Access? [yes]:
    AppleTalk Network for ARAP clients [1]: 20
    Zone name for ARAP clients [ARA Dialins]:
```

Configuring interface parameters:

```
Configuring interface Ethernet0:
  Is this interface in use? [yes]:
  Configure IP on this interface? [yes]:
    IP address for this interface [172.16.72.2]:
    Number of bits in subnet field [8]:
    Class B network is 172.16.0.0, 8 subnet bits; mask is /24
  Configure AppleTalk on this interface? [yes]:
    Extended AppleTalk network? [yes]:
    AppleTalk starting cable range [1]:
    AppleTalk ending cable range [1]:
    AppleTalk zone name [Sales]:
    AppleTalk additional zone name:
  Configure IPX on this interface? [yes]:
    IPX network number [1]:
```

```
Configuring interface Serial0:
  Is this interface in use? [no]: yes
  Configure IP on this interface? [no]: yes
  Configure IP unnumbered on this interface? [no]: yes
    Assign to which interface [Ethernet0]:
  Configure AppleTalk on this interface? [no]: yes
    Extended AppleTalk network? [yes]:
    AppleTalk starting cable range [2]: 3
    AppleTalk ending cable range [3]: 3
    AppleTalk zone name [myzone]: ZZ Serial
    AppleTalk additional zone name:
  Configure IPX on this interface? [no]: yes
    IPX network number [2]: 3
```

```
Configuring interface Serial1:
  Is this interface in use? [yes]:
  Configure IP on this interface? [yes]:
  Configure IP unnumbered on this interface? [yes]:
    Assign to which interface [Ethernet0]:
  Configure AppleTalk on this interface? [yes]:
    Extended AppleTalk network? [yes]:
    AppleTalk starting cable range [2]:
    AppleTalk ending cable range [2]:
    AppleTalk zone name [ZZ Serial]:
    AppleTalk additional zone name:
  Configure IPX on this interface? [yes]:
    IPX network number [2]:
Configuring interface Async1:
  IPX network number [4]:
  Default client IP address for this interface [none]: 172.16.72.4
Configuring interface Async2:
  IPX network number [5]:
```

```
    Default client IP address for this interface [172.16.72.5]:
Configuring interface Async3:
    IPX network number [6]:
    Default client IP address for this interface [172.16.72.6]:
Configuring interface Async4:
    IPX network number [7]:
    Default client IP address for this interface [172.16.72.7]:
Configuring interface Async5:
    IPX network number [8]:
    Default client IP address for this interface [172.16.72.8]:
Configuring interface Async6:
    IPX network number [9]:
    Default client IP address for this interface [172.16.72.9]:
Configuring interface Async7:
    IPX network number [A]:
    Default client IP address for this interface [172.16.72.10]:
Configuring interface Async8:
    IPX network number [B]:
    Default client IP address for this interface [172.16.72.11]:
Configuring interface Async9:
    IPX network number [C]:
    Default client IP address for this interface [172.16.72.12]:
Configuring interface Async10:
    IPX network number [D]:
    Default client IP address for this interface [172.16.72.13]:
Configuring interface Async11:
    IPX network number [E]:
    Default client IP address for this interface [172.16.72.14]:
Configuring interface Async12:
    IPX network number [F]:
    Default client IP address for this interface [172.16.72.15]:
Configuring interface Async13:
    IPX network number [10]:
    Default client IP address for this interface [172.16.72.16]:
Configuring interface Async14:
    IPX network number [11]:
    Default client IP address for this interface [172.16.72.17]:
Configuring interface Async15:
    IPX network number [12]:
    Default client IP address for this interface [172.16.72.18]:
Configuring interface Async16:
    IPX network number [13]:
    Default client IP address for this interface [172.16.72.19]:
```

The following configuration command script was created:

```
hostname Router
enable secret 5 $1$krIg$semfYm/1OwHVspDuS8Gy0K1
enable password ww
line vty 0 4
password ww
snmp-server community public
!
no decnet routing
appletalk routing
ipx routing
ip routing
!
line 1 16
speed 57600
flowcontrol hardware
modem inout
!
arap network 20 ARA Dialins
```

```

line 1 16
arap enable
autoselect
!
! Turn off IPX to prevent network conflicts.
interface Ethernet0
no ipx network
interface Serial0
no ipx network
interface Serial1
no ipx network
!
interface Ethernet0
ip address 172.16.72.2 255.255.255.0
appletalk cable-range 1-1 1.204
appletalk zone Sales
ipx network 1
no mop enabled
!
interface Serial0
no shutdown
no ip address
ip unnumbered Ethernet0
appletalk cable-range 3-3
appletalk zone ZZ Serial
ipx network 3
no mop enabled
!
interface Serial1
no ip address
ip unnumbered Ethernet0
appletalk cable-range 2-2 2.2
appletalk zone ZZ Serial
ipx network 2
no mop enabled
!
Interface Async1
ipx network 4
ip unnumbered Ethernet0
peer default ip address 172.16.72.4
async mode interactive
!
Interface Async2
ipx network 5
ip unnumbered Ethernet0
peer default ip address 172.16.72.5
async mode interactive
!
Interface Async3
ipx network 6
ip unnumbered Ethernet0
peer default ip address 172.16.72.6
async mode interactive
!
Interface Async4
ipx network 7
ip unnumbered Ethernet0
peer default ip address 172.16.72.7
async mode interactive
async dynamic address
!
Interface Async5
ipx network 8
ip unnumbered Ethernet0

```

```
peer default ip address 172.16.72.8
async mode interactive
!
Interface Async6
ipx network 9
ip unnumbered Ethernet0
peer default ip address 172.16.72.9
async mode interactive
!
Interface Async7
ipx network A
ip unnumbered Ethernet0
peer default ip address 172.16.72.10
async mode interactive
!
Interface Async8
ipx network B
ip unnumbered Ethernet0
peer default ip address 172.16.72.11
async mode interactive
!
Interface Async9
ipx network C
ip unnumbered Ethernet0
peer default ip address 172.16.72.12
async mode interactive
!
Interface Async10
ipx network D
ip unnumbered Ethernet0
peer default ip address 172.16.72.13
async mode interactive
!
Interface Async11
ipx network E
ip unnumbered Ethernet0
peer default ip address 172.16.72.14
async mode interactive
!
Interface Async12
ipx network F
ip unnumbered Ethernet0
peer default ip address 172.16.72.15
async mode interactive
!
Interface Async13
ipx network 10
ip unnumbered Ethernet0
peer default ip address 172.16.72.16
async mode interactive
!
Interface Async14
ipx network 11
ip unnumbered Ethernet0
peer default ip address 172.16.72.17
async mode interactive
!
Interface Async15
ipx network 12
ip unnumbered Ethernet0
peer default ip address 172.16.72.18
async mode interactive
!
Interface Async16
```

```
ipx network 13
ip unnumbered Ethernet0
peer default ip address 172.16.72.19
async mode interactive
!
router igrp 15
network 172.16.0.0
!
end
```

Use this configuration? [yes/no]: **yes**


Building configuration...

Use the enabled mode 'configure' command to modify this configuration.

Router#

Related Commands

Command	Description
erase nvram:	Erases a file system.
show running-config	Displays the running configuration file. Command alias for the more system:running-config command.
show startup-config	Displays the startup configuration file. Command alias for the more system:startup-config command.
show version	Displays the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images.



Terminal Operating Characteristics Commands

This chapter describes the commands used to control terminal operating characteristics.

For terminal operating characteristic task information and examples, refer to the “Configuring Operating Characteristics for Terminals” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

activation-character

To define the character you enter at a vacant terminal to begin a terminal session, use the **activation-character** line configuration command. To make any character activate a terminal, use the **no** form of this command.

activation-character *ascii-number*

no activation-character

Syntax Description	<i>ascii-number</i>	Decimal representation of the activation character.

Defaults	Return (decimal 13)

Command Modes	Line configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines	See the “ASCII Character Set and Hex Values” appendix for a list of ASCII characters.



Note

If you are using the **autoselect** function, set the activation character to the default, Return, and exec-character-bits to 7. If you change these defaults, the application will not recognize the activation request.

Examples	The following example sets the activation character for the console to Delete, which is decimal character 127: <pre>Router(config)# line console Router(config-line)# activation-character 127</pre>

autobaud

To set the line for automatic baud rate detection (autobaud), use the **autobaud** line configuration command. To disable automatic baud detection, use the **no** form of this command.

autobaud

no autobaud

Syntax Description

This command has no arguments or keywords.

Defaults

Autobaud detection disabled. Fixed line speed of 9600 bps.

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The autobaud detection supports a range from 300 to 19200 baud. A line set for autobaud cannot be used for outgoing connections, nor can you set autobaud capability on a line using 19200 baud when the parity bit is set (because of hardware limitations).



Note

Automatic baud rate detection must be disabled by using the **no autobaud** command prior to entering the **rxspeed**, **speed**, or **txspeed** commands.

Examples

In the following example, the auxiliary port is configured for autobaud detection:

```
Router(config)# line aux
Router(config-line)# autobaud
```

buffer-length

To specify the maximum length of the data stream to be forwarded, use the **buffer-length** command in line configuration mode. To restore the default setting, use the **no** form of this command.

```
buffer-length length
no buffer-length
```

Syntax Description	<i>length</i>	Specifies the length of the buffer in bytes. Valid values for the <i>length</i> argument range from 16 to 1536. The default buffer length is 1536 bytes.

Defaults	1536 bytes

Command Modes	Line configuration

Command History	Release	Modification
	12.1	This command was introduced.

Usage Guidelines

The **buffer-length** command configures the size of the forwarded data stream. The higher the value used for the *length* argument is, the longer the delay between data transmissions will be. Configuring a smaller buffer length can prevent connections from timing out inappropriately.

Examples

The following example configures a buffer length of 500 bytes:

```
buffer-length 500
```

databits

To set the number of data bits per character that are interpreted and generated by the router hardware, use the **databits** line configuration command. To restore the default value, use the **no** form of the command.

databits {5 | 6 | 7 | 8}

no databits

Syntax Description

5	Five data bits per character.
6	Six data bits per character.
7	Seven data bits per character.
8	Eight data bits per character.

Defaults

Eight data bits per character

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The **databits** line configuration command can be used to mask the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity generation is in effect, specify 8 data bits per character. The other keywords are supplied for compatibility with older devices and generally are not used.

Examples

The following example sets the number of data bits per character to seven on line 4:

```
Router(config)# line 4  
Router(config-line)# databits 7
```

Related Commands

Command	Description
data-character-bits	Sets the number of data bits per character that are interpreted and generated by the Cisco IOS software.
terminal databits	Changes the number of data bits per character for the current terminal line for this session.
terminal data-character-bits	Sets the number of data bits per character that are interpreted and generated by the Cisco IOS software for the current line and session.

data-character-bits

To set the number of data bits per character that are interpreted and generated by the Cisco IOS software, use the **data-character-bits** line configuration command. To restore the default value, use the **no** form of this command.

data-character-bits { 7 | 8 }

no data-character-bits

Syntax Description	7	Seven data bits per character.
	8	Eight data bits per character. This is the default.

Defaults	Eight data bits per character

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The data-character-bits line configuration command is used primarily to strip parity from X.25 connections on routers with the protocol translation software option. The data-character-bits line configuration command does not work on hard-wired lines.

Examples	The following example sets the number of data bits per character to seven on virtual terminal line 1: Router(config)# line vty 1 Router(config-line)# data-character-bits 7

Related Commands	Command	Description
	terminal data-character-bits	Sets the number of data bits per character that are interpreted and generated by the Cisco IOS software for the current line and session.

default-value exec-character-bits

To define the EXEC character width for either 7 bits or 8 bits, use the **default-value exec-character-bits** global configuration command. To restore the default value, use the **no** form of this command.

default-value exec-character-bits {7 | 8}

no default-value exec-character-bits

Syntax Description	7	Selects the 7-bit ASCII character set. This is the default.
	8	Selects the full 8-bit ASCII character set.
Defaults	7-bit ASCII character set	
Command Modes	Global configuration	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	Configuring the EXEC character width to 8 bits allows you to add graphical and international characters in banners, prompts, and so on. However, setting the EXEC character width to 8 bits can also cause failures. If a user on a terminal that is sending parity enters the help command, an “unrecognized command” message appears because the system is reading all 8 bits, although the eighth bit is not needed for the help command.	
Examples	The following example selects the full 8-bit ASCII character set for EXEC banners and prompts: <pre>Router(config)# default-value exec-character-bits 8</pre>	
Related Commands	Command	Description
	default-value special-character-bits	Configures the flow control default value from a 7-bit width to an 8-bit width.
	exec-character-bits	Configures the character widths of EXEC and configuration command characters.
	length	Sets the terminal screen length.
	terminal exec-character-bits	Locally changes the ASCII character set used in EXEC and configuration command characters for the current session.
	terminal special-character-bits	Changes the ASCII character widths to accept special characters for the current terminal line and session.

default-value special-character-bits

To configure the flow control default value from a 7-bit width to an 8-bit width, use the **default-value special-character-bits** global configuration command. To restore the default value, use the **no** form of this command.

default-value special-character-bits { 7 | 8 }

no default-value special-character-bits

Syntax Description	7	Selects the 7-bit character set. This is the default.
	8	Selects the full 8-bit character set.

Defaults	7-bit character set

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Configuring the special character width to 8 bits allows you to add graphical and international characters in banners, prompts, and so on.

Examples	The following example selects the full 8-bit special character set: <pre>Router(config)# default-value special-character-bits 8</pre>

Related Commands	Command	Description
	default-value exec-character-bits	Defines the EXEC character width for either 7 bits or 8 bits.
	exec-character-bits	Configures the character widths of EXEC and configuration command characters.
	length	Sets the terminal screen length.
	terminal exec-character-bits	Locally changes the ASCII character set used in EXEC and configuration command characters for the current session.
	terminal special-character-bits	Changes the ASCII character widths to accept special characters for the current terminal line and session.

disconnect-character

To define a character to disconnect a session, use the **disconnect-character** line configuration command. To remove the disconnect character, use the **no** form of this command.

disconnect-character *ascii-number*

no disconnect-character

Syntax Description	<i>ascii-number</i>	Decimal representation of the session disconnect character.

Defaults	No disconnect character is defined.

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	See the “ASCII Character Set and Hex Values” appendix for a list of ASCII characters.
	The Break character is represented by zero; NULL cannot be represented.
	To use the session-disconnect character in normal communications, precede it with the escape character.

Examples	The following example defines the disconnect character for virtual terminal line 4 as Escape, which is decimal character 27:

```
Router(config)# line vty 4
Router(config-line)# disconnect-character 27
```

dispatch-character

To define a character that causes a packet to be sent, use the **dispatch-character** line configuration command. To remove the definition of the specified dispatch character, use the **no** form of this command.

dispatch-character *ascii-number1* [*ascii-number2* . . . *ascii-number*]

no dispatch-character *ascii-number1* [*ascii-number2* . . . *ascii-number*]

Syntax Description

<i>ascii-number1</i>	Decimal representation of the desired dispatch character.
<i>ascii-number2</i> . . . <i>ascii-number</i>	(Optional) Additional decimal representations of characters. This syntax indicates that you can define any number of characters as dispatch characters.

Defaults

No dispatch character is defined.

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

See the“[ASCII Character Set and Hex Values](#)” appendix for a list of ASCII characters.

The **dispatch-character** command defines one or more dispatch characters that cause a packet to be sent even if the dispatch timer has not expired. Use of a dispatch character causes the Cisco IOS software to attempt to buffer characters into larger-sized packets for transmission to the remote host.

Enable the **dispatch-character** command from the session that initiates the connection, not from the incoming side of a streaming Telnet session.

This command can take multiple arguments, so you can define any number of characters as dispatch characters.

Examples

The following example defines the Return character (decimal 13) as the dispatch character for vty line 4:

```
Router(config)# line vty 4
Router(config-line)# dispatch-character 13
```

Related Commands

Command	Description
dispatch-machine	Specifies an identifier for a TCP packet dispatch state machine on a particular line.
dispatch-timeout	Sets the character dispatch timer.

Command	Description
state-machine	Specifies the transition criteria for the state of a particular state machine.
terminal dispatch-character	Defines a character that causes a packet to be sent for the current session.

dispatch-machine

To specify an identifier for a TCP packet dispatch state machine on a particular line, use the **dispatch-machine** line configuration command. To disable a state machine on a particular line, use the **no** form of this command.

dispatch-machine *name*

no dispatch-machine

Syntax Description

<i>name</i>	Name of the state machine that determines when to send packets on the asynchronous line.

Defaults

No dispatch state machine identifier is defined.

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

When the **dispatch-timeout** command is specified, a packet being built will be sent when the timer expires, and the state will be reset to zero.

Any dispatch characters specified using the **dispatch-character** command are ignored when a state machine is also specified.

If a packet becomes full, it will be sent regardless of the current state, but the state will not be reset. The packet size depends on the traffic level on the asynchronous line and the dispatch-timeout value. There is always room for 60 data bytes. If the dispatch-timeout value is greater than or equal to 100 milliseconds, a packet size of 536 (data bytes) is allocated.

Examples

The following example specifies the name “linefeed” for the state machine:

```
Router(config)# state-machine linefeed 0 0 9 0
Router(config)# state-machine linefeed 0 11 255 0
Router(config)# state-machine linefeed 0 10 10 transmit
Router(config)# line 1
Router(config-line)# dispatch-machine linefeed
```

Related Commands

Command	Description
dispatch-character	Defines a character that causes a packet to be sent.
dispatch-timeout	Sets the character dispatch timer.
state-machine	Specifies the transition criteria for the state of a particular state machine.

dispatch-timeout

To set the character dispatch timer, use the **dispatch-timeout** line configuration command. To remove the timeout definition, use the **no** form of this command.

dispatch-timeout *milliseconds*

no dispatch-timeout

Syntax Description	<i>milliseconds</i>	Integer that specifies the number of milliseconds (ms) that the Cisco IOS software waits after putting the first character into a packet buffer before sending the packet. During this interval, more characters can be added to the packet, which increases the processing efficiency of the remote host.

Defaults	No dispatch timeout is defined.

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command to increase the processing efficiency for the remote host. The dispatch-timeout line configuration command causes the software to buffer characters into packets for transmission to the remote host. The Cisco IOS software sends a packet a specified amount of time after the first character is put into the buffer. You can use the dispatch-timeout and dispatch-character line configuration commands together. In this case, the software dispatches a packet each time the dispatch character is entered, or after the specified dispatch timeout interval, depending on which condition is met first.

**Note**

The system response time might appear intermittent if the timeout interval is greater than 100 milliseconds and remote echoing is used. For lines with a reverse-Telnet connection, use a dispatch-timeout value less than 10 milliseconds.

Examples	The following example sets the dispatch timer to 80 milliseconds for vty lines 0 through 4:

```
Router(config)# line vty 0 4  
Router(config-line)# dispatch-timeout 80
```

Related Commands	Command	Description
	dispatch-character	Defines a character that causes a packet to be sent.
	dispatch-machine	Specifies an identifier for a TCP packet dispatch state machine on a particular line.
	state-machine	Specifies the transition criteria for the state of a particular state machine.
	terminal dispatch-timeout	Sets the character dispatch timer for the current session.

escape-character

To define a system escape character, use the **escape-character** line configuration command. To set the escape character to Break, use the **no** or **default** form of this command.

escape-character { **break** | *char* | **default** | **none** | **soft** }

no escape-character [**soft**]

default escape-character [**soft**]

Syntax Description

break	Sets the escape character to Break. Note that the Break key should not be used as an escape character on a console terminal.
<i>char</i>	Character (for example, !) or its ASCII decimal representation (integer in the range of 0 to 255) to be used as the escape character.
default	Sets the escape key sequence to the default of Ctrl-^, X.
none	Disables escape entirely.
soft	Sets an escape character that will wait until pending input is processed before it executes.

Defaults

The default escape key sequence is Ctrl-Shift-6 (Ctrl-^) or Ctrl-Shift-6, X (^X). The X is generally only required for modem connections.

The **default escape-character** command sets the escape character to Break (the default setting for Break is Ctrl-C).

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.
11.3	The soft keyword was added.

Usage Guidelines

See the [“ASCII Character Set and Hex Values”](#) appendix for a list of ASCII characters and their numerical representation.

The escape character (or key sequence) suspends any actively running processes and returns you to privileged EXEC mode or, if a menu is being used, to the system menu interface. The escape character is used for interrupting or aborting a process started by previously executed command. Examples of processes from which you can escape include Domain-Name lookup, **ping**, **trace**, and Telnet sessions initiated from the device to which you are connected.

To view the current setting of the escape sequence for a line, use the **show line** command followed by the specific line identifier (for example, **show line 0**, or **show line console**). The default escape sequence for a line is often displayed as ^X. The first caret symbol represents the Control (Ctrl) key, the second caret symbol is literal (Shift-6), and the X is literal (for most systems, the X is not required).

To set the escape key for the active terminal line session, use the **terminal escape-character** command.

The Break key cannot be used as an escape character on a console terminal because the Cisco IOS software interprets Break as an instruction to halt the system. Depending upon the configuration register setting, break commands issued from the console line either will be ignored or cause the server to shut down.

To send an escape sequence over a Telnet connection, press **Ctrl-Shift-6** twice.

The **escape-character soft** form of this command defines a character or character sequence that will cause the system to wait until pending input is processed before suspending the current session. This option allows you to program a key sequence to perform multiple actions, such as using the F1 key to execute a command, then execute the escape function after the first command is executed.

The following restrictions apply when using the **soft** keyword:

- The length of the logout sequence must be 14 characters or fewer.
- The soft escape character cannot be the same as the generic Cisco escape character, Break, or the characters b, d, n, or s.
- The soft escape character should be an ASCII value from 1 to 127. Do not use the number 30.

Examples

The following example sets the escape character for the console line to the keyboard entry Ctrl-P, which is represented by the ASCII decimal value of 16:

```
Router(config)# line console
Router(config-line)# escape-character 16
```

The following example sets the escape character for line 1 to !, which is represented in the configuration file as the ASCII number 33:

```
Router(config)# line 1
Router(config-line)# escape-character !
Router(config-line)# end
Router# show running-config
Building configuration...
.
.
.
line 1
  autoselect during-login
  autoselect ppp
  modem InOut
  transport preferred none
  transport output telnet
  escape-character 33
.
.
.
```

Related Commands

Command	Description
show line	Displays information about the specified line connection, or all the lines.
terminal escape-character	Sets the escape character for the current terminal line for the current session.

exec-character-bits

To configure the character widths of EXEC and configuration command characters, use the **exec-character-bits** line configuration command. To restore the default value, use the **no** form of this command.

exec-character-bits {7 | 8}

no exec-character-bits

Syntax Description

7	Selects the 7-bit character set. This is the default.
8	Selects the full 8-bit character set for use of international and graphical characters in banner messages, prompts, and so on.

Defaults

7-bit ASCII character set

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Setting the EXEC character width to 8 allows you to use special graphical and international characters in banners, prompts, and so on. However, setting the EXEC character width to 8 bits can cause failures. If a user on a terminal that is sending parity enters the **help** command, an “unrecognized command” message appears because the system is reading all 8 bits, and the eighth bit is not needed for the **help** command.



Note

If you are using the **autoselect** function, set the activation character to the default (Return) and the value for **exec-character-bits** to 7. If you change these defaults, the application will not recognize the activation request.

Examples

The following example enables full 8-bit international character sets, except for the console, which is an ASCII terminal. It illustrates use of the **default-value exec-character-bits** global configuration command and the **exec-character-bits** line configuration command.

```
Router(config)# default-value exec-character-bits 8
Router(config)# line 0
Router(config-line)# exec-character-bits 7
```

Related Commands	Command	Description
	default-value exec-character-bits	Defines the EXEC character width for either 7 bits or 8 bits.
	default-value special-character-bits	Configures the flow control default value from a 7-bit width to an 8-bit width.
	length	Sets the terminal screen length.
	terminal exec-character-bits	Locally changes the ASCII character set used in EXEC and configuration command characters for the current session.
	terminal special-character-bits	Changes the ASCII character widths to accept special characters for the current terminal line and session.

hold-character

To define the local hold character used to pause output to the terminal screen, use the **hold-character** line configuration command. To restore the default, use the **no** form of this command.

hold-character *ascii-number*

no hold-character

Syntax Description	<i>ascii-number</i>	ASCII decimal representation of a character or control sequence (for example, Ctrl-P).

Defaults	No hold character is defined.

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The Break character is represented by zero; NULL cannot be represented. To continue the output, enter any character after the hold character. To use the hold character in normal communications, precede it with the escape character. See the “ASCII Character Set” appendix for a list of ASCII characters.

Examples	The following example sets the hold character to Ctrl-S, which is ASCII decimal character 19:

```
Router(config)# line 8
Router(config-line)# hold-character 19
```

Related Commands	Command	Description
	terminal hold-character	Sets or changes the hold character for the current session.

insecure

To configure a line as insecure, use the **insecure** line configuration command. To disable this feature, use the **no** form of this command.

- insecure**
- no insecure**

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Use this command to identify a modem line as insecure for DEC local area transport (LAT) classification.

Examples In the following example, line 10 is configured as an insecure dialup line:

```
Router(config)# line 10
Router(config-line)# insecure
```

length

To set the terminal screen length, use the **length** line configuration command. To restore the default value, use the **no** form of this command.

length *screen-length*

no length

Syntax Description	<i>screen-length</i>	The number of lines on the screen. A value of zero disables pausing between screens of output.

Defaults	Screen length of 24 lines

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The Cisco IOS software uses the value of this command to determine when to pause during multiple-screen output. Not all commands recognize the configured screen length. For example, the show terminal command assumes a screen length of 24 lines or more.

Examples	In the following example, the terminal type is specified and the screen pause function is disabled for the terminal connection on line 6:

```
Router(config)# line 6
Router(config-line)# terminal-type VT220
Router(config-line)# length 0
```

Related Commands	Command	Description
	terminal length	Sets the number of lines on the current terminal screen for the current session.

location

To provide a description of the location of a serial device, use the **location** line configuration command. To remove the description, use the **no** form of this command.

location *text*

no location

Syntax Description	<i>text</i> Location description.

Defaults	No location description provided.

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The location command enters information about the device location and status. Use the show users all EXEC command to display the location information.

Examples	In the following example, the location description for the console line is given as “Building 3, Basement”: <pre>Router(config)# line console Router(config-line)# location Building 3, Basement</pre>

lockable

To enable use of the **lock** EXEC command, use the **lockable** line configuration command. To reinstate the default (the terminal session cannot be locked), use the **no** form of this command.

lockable

no lockable

Syntax Description

This command has no arguments or keywords.

Defaults

Sessions on the line are not lockable (the **lock** EXEC command has no effect).

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command enables use of temporary terminal locking, which is executed using the **lock** EXEC command. Terminal locking allows a user keep the current session open while preventing access by other users.

Examples

In the following example, the terminal connection is configured as lockable, then the current connection is locked:

```
Router# configure terminal
Router(config)# line console 0
Router(config-line)# lockable
Router(config)# ^Z
Router# lock
Password: <password>
Again: <password>

                Locked

Password: <password>
Router#
```

Related Commands

Command	Description
lock	Prevents access to your session by other users by setting a temporary password on your terminal line.

logout-warning

To warn users of an impending forced timeout, use the **logout-warning** line configuration command. To restore the default, use the **no** form of this command.

logout-warning [*seconds*]

logout-warning

Syntax Description	<i>seconds</i>	(Optional) Number of seconds that are counted down before session termination. If no number is specified, the default of 20 seconds is used.

Defaults	No warning is sent to the user.

Command Modes	Line configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	This command notifies the user of an impending forced timeout (set using the absolute-timeout command).

Examples	In the following example, a logout warning is configured on line 5 with a countdown value of 30 seconds: Router(config)# line 5 Router(config-line)# logout-warning 30

Related Commands	Command	Description
	absolute-timeout	Sets the interval for closing user connections on a specific line or port.
	session-timeout	Sets the interval for closing the connection when there is no input or output traffic.

notify

To enable terminal notification about pending output from other Telnet connections, use the **notify** line configuration command. To disable notifications, use the **no** form of this command.

notify

no notify

Syntax Description

This command has no arguments or keywords.

Defaults

Disabled

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command sets a line to inform a user that has multiple, concurrent Telnet connections when output is pending on a connection other than the current one.

Examples

In the following example, notification of pending output from connections is enabled on virtual terminal lines 0 to 4:

```
Router(config)# line vty 0 4
Router(config-line)# notify
```

Related Commands

Command	Description
terminal notify	Configures a line to inform a user that has multiple, concurrent Telnet connections when output is pending on a connection other than the current one.

padding

To set the padding on a specific output character, use the **padding** line configuration command. To remove padding for the specified output character, use the **no padding** form of this command.

padding *ascii-number count*

no padding *ascii-number*

Syntax Description	<i>ascii-number</i>	ASCII decimal representation of the character.
	<i>count</i>	Number of NULL bytes sent after the specified character, up to 255 padding characters in length.

Defaults	No padding

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command when the attached device is an old terminal that requires padding after certain characters (such as ones that scrolled or moved the carriage). See the “ASCII Character Set and Hex Values” appendix for a list of ASCII characters.

Examples	In the following example, the Return (decimal character 13) is padded with 25 NULL bytes on the console line: <pre>Router(config)# line console Router(config-line)# padding 13 25</pre>

Related Commands	Command	Description
	terminal padding	Changes the character padding on a specific output character for the current session.

parity

To define generation of a parity bit, use the **parity** line configuration command. To specify no parity, use the **no** form of this command.

parity { **none** | **even** | **odd** | **space** | **mark** }

no parity

Syntax Description	none	No parity. This is the default.
	even	Even parity.
	odd	Odd parity.
	space	Space parity.
	mark	Mark parity.

Defaults	No parity.

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Communication protocols provided by devices such as terminals and modems will sometimes require a specific parity bit setting. Refer to the documentation for your device to determine required parity settings.

Examples	In the following example even parity is configured for line 34:

```
Router(config)# line 34
Router(config-line)# parity even
```

Related Commands	Command	Description
	terminal parity	Defines the generation of the parity bit for the current for the current session and line.

printer

To configure a printer and assign a server tty line (or lines) to it, use the **printer** global configuration command. To disable printing on a tty line, use the **no** form of this command.

```
printer printer-name {line number | rotary number} [newline-convert | formfeed]

no printer
```

Syntax Description	<i>printer-name</i>	Printer name.
	line number	Assigns a tty line to the printer.
	rotary number	Assigns a rotary group of tty lines to the printer.
	newline-convert	(Optional) Converts newline (linefeed) characters to a two-character sequence “carriage-return, linefeed” (CR+LF).
	formfeed	(Optional) Causes the Cisco IOS software to send a form-feed character (ASCII 0x0C) to the printer tty line immediately following each print job received from the network.

Defaults No printers are defined by default.

Command Modes Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines

This command enables you to configure a printer for operations and assign either a single tty line or a group of tty lines to it. To make multiple printers available through the same printer name, specify the number of a rotary group.

In addition to configuring the printer with the **printer** command, you must modify the file /etc/printcap on your UNIX system to include the definition of the remote printer in the Cisco IOS software. Refer to the *Release 12.2 Cisco IOS Configuration Fundamentals Configuration Guide* for additional information.

Use the optional **newline-convert** keyword in UNIX environments that cannot handle single-character line terminators. This converts newline characters to a carriage-return, linefeed sequence. Use the **formfeed** keyword when using the line printer daemon (lpd) protocol to print and your system is unable to separate individual output jobs with a form feed (page eject). You can enter the **newline-convert** and **formfeed** keywords together and in any order.

Examples

In the following example a printer named printer1 is configured and output is assigned to tty line 4:

```
Router(config)# printer printer1 line 4
```

Related Commands

Command	Description
clear line	Returns a terminal line to idle state.

private

To save user EXEC command changes between terminal sessions, use the **private** line configuration command. To restore the default condition, use the **no** form of this command.

- private
- no private

Syntax Description This command has no arguments or keywords.

Defaults User-set configuration options are cleared with the **exit** EXEC command or when the interval set with the **exec-timeout** line configuration command has passed.

Command Modes Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines This command ensures that the terminal parameters set by the user remain in effect between terminal sessions. This behavior is desirable for terminals in private offices.

Examples In the following example, line 15 (in this example, vty 1) is configured to keep all user-supplied settings at system restarts:

```
Router(config)# line 15
Router(config-line)# private
```

Related Commands	Command	Description
	exec-timeout	Sets the interval that the EXEC command interpreter waits until user input is detected.
	exit	Exits any configuration mode, or closes an active terminal session and terminates the EXEC.

show whoami

To display information about the terminal line of the current user, including host name, line number, line speed, and location, use the **show whoami** EXEC command.

show whoami [*text*]

Syntax Description

<i>text</i>	(Optional) Additional data to print to the screen.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

If text is included as an argument in the command, that text is displayed as part of the additional data about the line.

To prevent the information from being lost if the menu display clears the screen, this command always displays a More prompt before returning. Press the space bar to return to the prompt.

Examples

The following example is sample output from the **show whoami** command:

```
Router> show whoami
```

```
Comm Server "Router", Line 0 at 0bps. Location "Second floor, West"
```

```
--More--
```

```
Router>
```

special-character-bits

To configure the number of data bits per character for special characters such as software flow control characters and escape characters, use the **special-character-bits** line configuration command. To restore the default value, use the **no** form of this command.

special-character-bits {7 | 8}

no special-character-bits

Syntax Description	7	Selects the 7-bit ASCII character set. This is the default.
	8	Selects the full 8-bit character set for special characters.
Defaults	7-bit ASCII character set	
Command Modes	Line configuration	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	Setting the special character bits to 8 allows you to use twice as many special characters as with the 7-bit ASCII character set. The special characters affected by this setting are the escape, hold, stop, start, disconnect, and activation characters.	
Examples	The following example allows the full 8-bit international character set for special characters on line 5: <pre>Router(config)# line 5 Router(config-line)# special-character-bits 8</pre>	
Related Commands	Command	Description
	default-value exec-character-bits	Defines the EXEC character width for either 7 bits or 8 bits.
	default-value special-character-bits	Configures the flow control default value from a 7-bit width to an 8-bit width.
	exec-character-bits	Configures the character widths of EXEC and configuration command characters.
	terminal exec-character-bits	Locally changes the ASCII character set used in EXEC and configuration command characters for the current session.
	terminal special-character-bits	Changes the ASCII character widths to accept special characters for the current terminal line and session.

state-machine

To specify the transition criteria for the state of a particular state machine, use the **state-machine** global configuration command. To remove a particular state machine from the configuration, use the **no** form of this command.

state-machine *name state first-character last-character [nextstate | transmit]*

no state-machine *name*

Syntax Description

<i>name</i>	Name for the state machine (used in the dispatch-machine line configuration command). The user can specify any number of state machines, but each line can have only one state machine associated with it.
<i>state</i>	State being modified. There are a maximum of eight states per state machine. Lines are initialized to state 0 and return to state 0 after a packet is transmitted.
<i>first-character</i> <i>last-character</i>	Specifies a range of characters. Use ASCII numerical values. If the state machine is in the indicated state, and the next character input is within this range, the process goes to the specified next state. Full 8-bit character comparisons are done, so the maximum value is 255. Ensure that the line is configured to strip parity bits (or not generate them), or duplicate the low characters in the upper half of the space.
<i>nextstate</i>	(Optional) State to enter if the character is in the specified range.
transmit	(Optional) Causes the packet to be transmitted and the state machine to be reset to state 0. Recurring characters that have not been explicitly defined to have a particular action return the state machine to state 0.

Defaults

No transition criteria are specified.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command is paired with the **dispatch-machine** line configuration command, which defines the line on which the state machine is effective.

Examples

In the following example a dispatch machine named “function” is configured to ensure that the function key characters on an ANSI terminal are kept in one packet. Because the default in the example is to remain in state 0 without sending anything, normal key signals are sent immediately.

```
Router(config)# line 1 20
Router(config-line)# dispatch-machine function
Router(config-line)# exit
```

Router(config)# **state-machine function 0 0 255 transmit**

Related Commands	Command	Description
	dispatch-character	Defines a character that causes a packet to be sent.
	dispatch-machine	Specifies an identifier for a TCP packet dispatch state machine on a particular line.
	dispatch-timeout	Sets the character dispatch timer.

stopbits

To set the number of the stop bits transmitted per byte, use the **stopbits** line configuration command. To restore the default value, use the **no** form of this command.

stopbits { **1** | **1.5** | **2** }

no stopbits

Syntax Description	1	One stop bit.
	1.5	One and one-half stop bits.
	2	Two stop bits. This is the default.
Defaults	2 stop bits per byte	
Command Modes	Line configuration	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	Communication protocols provided by devices such as terminals and modems often require a specific stop-bit setting.	
Examples	In the following example, the stop bits transmitted per byte are changed from the default of two stop bits to one stop bit as a performance enhancement for line 4:	
	<pre>Router(config)# line 4 Router(config-line)# stopbits 1</pre>	
Related Commands	Command	Description
	terminal stopbits	Changes the number of stop bits sent per byte by the current terminal line during an active session.

terminal databits

To change the number of data bits per character for the current terminal line for this session, use the **terminal databits EXEC** command.

terminal databits {5 | 6 | 7 | 8}

Syntax Description

5	Five data bits per character.
6	Six data bits per character.
7	Seven data bits per character.
8	Eight data bits per character. This is the default.

Defaults

8 data bits per character

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Communication protocols provided by devices such as terminals and modems often require a specific data bit setting. The **terminal databits** command can be used to mask the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity generation is in effect, specify 8 data bits per character. The other keywords (**5** and **6**) are supplied for compatibility with older devices and are generally not used.

Examples

In the following example, the databits per character is changed to seven for the current session:

```
Router# terminal databits 7
```

Related Commands

Command	Description
databits	Sets the number of data bits per character that are interpreted and generated by the router hardware.
terminal parity	Defines the generation of the parity bit for the current terminal line and session.

terminal data-character-bits

To set the number of data bits per character that are interpreted and generated by the Cisco IOS software for the current line and session, use the **terminal data-character-bits** EXEC command.

terminal data-character-bits {7 | 8}

Syntax Description

7	Seven data bits per character.
8	Eight data bits. This is the default.

Defaults

8 data bits per character

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command is used primarily to strip parity from X.25 connections on routers with the protocol translation software option. The **terminal data-character-bits** command does not work on hard-wired lines.

Examples

The following example sets the data bits per character to seven on the current line:

```
Router# terminal data-character-bits 7
```

Related Commands

Command	Description
data-character-bits	Sets the number of data bits per character that are interpreted and generated by the Cisco IOS software.

terminal dispatch-character

To define a character that causes a packet to be sent for the current session, use the **terminal dispatch-character EXEC** command.

```
terminal dispatch-character ascii-number [ascii-number2 . . . ascii-number]
```

Syntax Description

<i>ascii-number</i>	The ASCII decimal representation of the character, such as Return (ASCII character 13) for line-at-a-time transmissions.
<i>ascii-number2</i> . . . <i>ascii-number</i>	(Optional) Additional decimal representations of characters. This syntax indicates that you can define any number of characters as dispatch characters.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

At times, you might want to queue up a string of characters until they fill a complete packet and then transmit the packet to a remote host. This can make more efficient use of a line, because the access server or router normally dispatches each character as it is entered.

Examples

The following example defines the characters Ctrl-D (ASCII decimal character 4) and Ctrl-Y (ASCII decimal character 25) as the dispatch characters:

```
Router# terminal dispatch-character 4 25
```

Related Commands

Command	Description
dispatch-character	Defines a character that causes a packet to be sent.

terminal dispatch-timeout

To set the character dispatch timer for the current terminal line for the current session, use the **terminal dispatch-timeout EXEC** command.

terminal dispatch-timeout *milliseconds*

Syntax Description

milliseconds

Integer that specifies the number of milliseconds that the router waits after it puts the first character into a packet buffer before sending the packet. During this interval, more characters can be added to the packet, which increases the processing efficiency of the remote host.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use this command to increase the processing efficiency of the remote host.

The **dispatch-timeout** line configuration command causes the software to buffer characters into packets for transmission to the remote host. The Cisco IOS software sends a packet a specified amount of time after the first character is put into the buffer. You can use the **terminal dispatch-timeout** and **terminal dispatch-character** line configuration commands together. In this case, the software dispatches a packet each time the dispatch character is entered, or after the specified dispatch timeout interval, depending on which condition is met first.



Note

The router response time might appear intermittent if the timeout interval is greater than 100 milliseconds and remote echoing is used.

Examples

In the following example, the dispatch timeout timer is set to 80 milliseconds:

```
Router# terminal dispatch-timeout 80
```

Related Commands

Command	Description
dispatch-timeout	Sets the character dispatch timer for a specified line or group of lines.

terminal download

To temporarily set the ability of a line to act as a transparent pipe for file transfers for the current session, use the **terminal download EXEC** command.

terminal download

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines You can use this feature to run a program such as KERMIT, XMODEM, or CrossTalk that downloads a file across an access server or router line. This command configures the terminal line to send data and is equivalent to entering all the following commands:

- **terminal telnet transparent**
- **terminal no escape-character** (see **terminal escape-character**)
- **terminal no hold-character** (see **terminal hold-character**)
- **terminal no padding 0** (see **terminal padding**)
- **terminal no padding 128** (see **terminal padding**)
- **terminal parity none**
- **terminal databits 8**

Examples The following example configures a line to act as a transparent pipe:

```
Router# terminal download
```


terminal escape-character

To set the escape character for the current terminal line for the current session, use the **terminal escape-character EXEC** command.

terminal escape-character *ascii-number*

Syntax Description	<i>ascii-number</i>	ASCII decimal representation of the escape character or control sequence (for example, Ctrl-P).

Defaults	Ctrl-^ (Ctrl-Shift-6)

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	See the “ASCII Character Set and Hex Values” appendix for a list of ASCII characters and their numerical representation. This command is useful, for example, if you have the default escape character defined for a different purpose in your keyboard file. Entering the escape character followed by the X key returns you to EXEC mode when you are connected to another computer.

**Note**

The Break key generally cannot be used as an escape character on the console terminal because the operating software interprets the Break command on a console line as an instruction to halt the system.

Examples	In the following example the escape character to Ctrl-P (ASCII decimal character 16) for the current session:

```
Router# terminal escape-character 16
```

Related Commands	Command	Description
	escape-character	Defines a system escape character.

terminal exec-character-bits

To locally change the ASCII character set used in EXEC and configuration command characters for the current session, use the **terminal exec-character-bits** EXEC command.

```
terminal exec-character-bits {7 | 8}
```

Syntax Description	7	Selects the 7-bit ASCII character set. This is the default.
	8	Selects the full 8-bit character set.

Defaults	7-bit ASCII character set (unless set otherwise in global configuration mode)

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

This EXEC command overrides the **default-value exec-character-bits** global configuration command. Configuring the EXEC character width to 8 bits enables you to view special graphical and international characters in banners, prompts, and so on.

When the user exits the session, the character width is reset to the default value established by the **exec-character-bits** global configuration command. However, setting the EXEC character width to 8 bits can also cause failures. For example, if a user on a terminal that is sending parity enters the **help** command, an “unrecognized command” message appears because the system is reading all 8 bits, and the eighth bit is not needed for the **help** command.

Examples

The following example temporarily configures the system to use a full 8-bit user interface for system banners and prompts, allowing the use of additional graphical and international characters:

```
Router# terminal exec-character-bits 8
```

Related Commands	Command	Description
	exec-character-bits	Configures the character widths of EXEC and configuration command characters.

terminal flowcontrol

To set flow control for the current terminal line for the current session, use the **terminal flowcontrol EXEC** command.

terminal flowcontrol { **none** | **software** [**in** | **out**] | **hardware** }

Syntax Description

none	Prevents flow control.
software	Sets software flow control.
in out	(Optional) Specifies the direction of flow control: in causes the router to listen to flow control from the attached device, and out causes the router to send flow control information to the attached device. If you do not specify a direction, both directions are assumed.
hardware	Sets hardware flow control. For information about setting up the EIA/TIA-232 line, see the manual that was shipped with your product.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Flow control enables you to regulate the rate at which data can be transmitted from one point so that it is equal to the rate at which it can be received at another point. Flow control protects against loss of data because the terminal is not capable of receiving data at the rate it is being sent. You can set up data flow control for the current terminal line in one of two ways: software flow control, which you do with control key sequences, and hardware flow control, which you do at the device level.

For software flow control, the default stop and start characters are Ctrl-S and Ctrl-Q (XOFF and XON). You can change them with the **terminal stop-character** and **terminal start-character EXEC** commands.

Examples

In the following example incoming software flow control is set for the current session:

```
Router# terminal flowcontrol software in
```

Related Commands

Command	Description
flowcontrol	Sets the method of data flow control between the terminal or other serial device and the router.

terminal hold-character

To define the hold character for the current session, use the **terminal hold-character** EXEC command. To return the hold character definition to the default, use the **terminal no hold-character** command.

```
terminal hold-character ascii-number

terminal no hold-character
```

Syntax Description	<i>ascii-number</i>	ASCII decimal representation of a character or control sequence (for example, Ctrl-P).

Defaults	The default hold character is defined by the hold-character global configuration command.

Command Modes	EXEC

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines	You can define a local hold character that temporarily suspends the flow of output on the terminal. When information is scrolling too quickly, you can enter the hold character to pause the screen output, then enter any other character to resume the flow of output. You cannot suspend output on the console terminal. To send the hold character to the host, precede it with the escape character.

Examples	In the following example the hold character for the current (local) session is set to Ctrl-P. The show terminal output is included to show the verification of the setting (the value for the hold character is shown in the “Special Characters” listing). <pre>Router# terminal hold-character 16 "^P" is the local hold character Router# show terminal Line 50, Location: "", Type: "VT220" Length: 24 lines, Width: 80 columns Baud rate (TX/RX) is 9600/9600 Status: PSI Enabled, Ready, Active, No Exit Banner, Automore On Capabilities: none Modem state: Ready Group codes: 0 Special Chars: Escape Hold Stop Start Disconnect Activation ^^x ^P - - none Timeouts: Idle EXEC Idle Session Modem Answer Session Dispatch 00:10:00 never none not set Idle Session Disconnect Warning never Login-sequence User Response</pre>

```
00:00:30
Autoselect Initial Wait
not set

Modem type is unknown.
Session limit is not set.
Time since activation: 00:04:13
Editing is enabled.
History is enabled, history size is 10.
.
.
.
```

Related Commands

Command	Description
hold-character	Defines the local hold character used to pause output to the terminal screen.
show terminal	Displays settings for terminal operating characteristics.

terminal keymap-type

To specify the current keyboard type for the current session, use the **terminal keymap-type EXEC** command.

```
terminal keymap-type keymap-name
```

Syntax Description	<i>keymap-name</i> Name defining the current keyboard type.				
Defaults	VT100				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>11.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	11.2	This command was introduced.
Release	Modification				
11.2	This command was introduced.				
Usage Guidelines	You must use this command when you are using a keyboard other than the default of VT100.				
Examples	The following example specifies a VT220 keyboard as the current keyboard type: <pre>Router# terminal keymap-type vt220</pre>				
Related Commands	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>show keymap</td><td>Displays the current keymap settings.</td></tr> </table>	Command	Description	show keymap	Displays the current keymap settings.
Command	Description				
show keymap	Displays the current keymap settings.				

terminal length

To set the number of lines on the current terminal screen for the current session, use the **terminal length** EXEC command.

terminal length *screen-length*

Syntax Description	<i>screen-length</i>	Number of lines on the screen. A value of zero disables pausing between screens of output.

Defaults	24 lines

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The system uses the length value to determine when to pause during multiple-screen output. A value of zero prevents the router from pausing between screens of output. Some types of terminal sessions do not require you to specify the screen length because the screen length specified can be learned by some remote hosts. For example, the rlogin protocol uses the screen length to set up terminal parameters on a remote UNIX host.

Examples	In the following example the system is configured to prevent output from pausing if it exceeds the length of the screen: <pre>Router# terminal length 0</pre>

Related Commands	Command	Description
	length	Sets the terminal screen length.

terminal monitor

To display **debug** command output and system error messages for the current terminal and session, use the **terminal monitor** EXEC command.

terminal monitor

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Remember that all terminal parameter-setting commands are set locally and do not remain in effect after a session is ended.

Examples In the following example the system is configured to display **debug** command output and error messages during the current terminal session:

```
Router# terminal monitor
```


terminal notify

To enable terminal notification about pending output from other Telnet connections for the current session, use the **terminal notify** EXEC command. To disable notifications for the current session, use the **no** form of this command.

terminal notify

terminal no notify

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Enabling notifications may be useful if, for example, you want to know when another connection receives mail, or when a process has been completed.

This command enables or disables notifications for only the current session. To globally set these notifications, use the **notify** line configuration command.

Examples

In the following example notifications will be displayed to inform the user when output is pending on another connection:

```
Router# terminal notify
```

Related Commands

Command	Description
notify	Enables terminal notification about pending output from other Telnet connections.

terminal padding

To change the character padding on a specific output character for the current session, use the **terminal padding** EXEC command.

terminal padding *ascii-number count*

Syntax Description

<i>ascii-number</i>	ASCII decimal representation of the character.
<i>count</i>	Number of NULL bytes sent after the specified character, up to 255 padding characters in length.

Defaults

No padding

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Character padding adds a number of null bytes to the end of the string and can be used to make a string an expected length for conformity.

Use this command when the attached device is an old terminal that requires padding after certain characters (such as ones that scrolled or moved the carriage). See the [“ASCII Character Set and Hex Values”](#) appendix for a list of ASCII characters.

Examples

The following example pads Ctrl-D (ASCII decimal character 4) with 164 NULL bytes:

```
Router# terminal padding 4 164
```

Related Commands

Command	Description
padding	Sets the padding on a specific output character.

terminal parity

To define the generation of the parity bit for the current terminal line and session, use the **terminal parity** EXEC command.

terminal parity {**none** | **even** | **odd** | **space** | **mark**}

Syntax Description

none	No parity. This is the default.
even	Even parity.
odd	Odd parity.
space	Space parity.
mark	Mark parity.

Defaults

No parity.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Communication protocols provided by devices such as terminals and modems will sometimes require a specific parity bit setting. Refer to the documentation for your device to determine required parity settings.

Examples

In the following example odd parity checking is enabled for the current session:

```
Router# terminal parity odd
```

Related Commands

Command	Description
parity	Defines generation of a parity bit for connections on a specified line or lines.

terminal-queue entry-retry-interval

To change the retry interval for a terminal port queue, use the **terminal-queue** global configuration command. To restore the default terminal port queue interval, use the **no** form of this command.

```
terminal-queue entry-retry-interval interval
no terminal-queue entry-retry-interval
```

Syntax Description	<i>interval</i> Number of seconds between terminal port retries.

Defaults	60 seconds

Command Modes	Global configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.1</td><td>This command was introduced.</td></tr></table>	Release	Modification	11.1	This command was introduced.
Release	Modification				
11.1	This command was introduced.				

Usage Guidelines	If a remote device (such as a printer) is busy, the connection attempt is placed in a terminal port queue. If you want to decrease the waiting period between subsequent connection attempts, decrease the default of 60 to an interval of 10 seconds. Decrease the time between subsequent connection attempts when, for example, a printer queue stalls for long periods.

Examples	The following example changes the terminal port queue retry interval from the default of 60 seconds to 10 seconds: <pre>Router# terminal-queue entry-retry-interval 10</pre>

terminal rxspeed

To set the terminal receive speed (how fast information is sent to the terminal) for the current line and session, use the **terminal rxspeed** EXEC command.

terminal rxspeed *bps*

Syntax Description	<i>bps</i> Baud rate in bits per second (bps).

Defaults	9600 bps

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Set the speed to match the baud rate of whatever device you have connected to the port. Some baud rates available on devices connected to the port might not be supported on the system. The system will indicate if the speed you select is not supported.

Examples	The following example sets the current auxiliary line receive speed to 115200 bps: Router# terminal rxspeed 115200

Related Commands	Command	Description
	rxspeed	Sets the terminal receive speed for a specified line or lines.
	terminal rxspeed	Sets the terminal receive speed for the current session.
	terminal txspeed	Sets the terminal transmit speed for a specified line or lines.
	terminal speed	Sets the transmit and receive speeds for the current session.

terminal special-character-bits

To change the ASCII character widths to accept special characters for the current terminal line and session, use the **terminal special-character-bits** EXEC command.

terminal special-character-bits {7 | 8}

Syntax Description	7	Selects the 7-bit ASCII character set. This is the default.
	8	Selects the full 8-bit ASCII character set.

Defaults	7-bit ASCII character set

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

Configuring the width to 8 bits enables you to use twice as many special characters as with the 7-bit setting. This selection enables you to add special graphical and international characters in banners, prompts, and so on.

This command is useful, for example, if you want the router to provide temporary support for international character sets. It overrides the **default-value special-character-bits** global configuration command and is used to compare character sets typed by the user with the special character available during a data connection, which includes software flow control and escape characters.

When you exit the session, character width is reset to the width established by the **default-value exec-character-bits** global configuration command.

Note that setting the EXEC character width to eight bits can cause failures. For example, if a user on a terminal that is sending parity enters the **help** command, an “unrecognized command” message appears because the Cisco IOS software is reading all eight bits, and the eighth bit is not needed for the **help** command.

Examples

The following example temporarily configures a router to use a full 8-bit user interface for system banners and prompts.

```
Router# terminal special-character-bits 8
```

Related Commands

Command	Description
default-value exec-character-bits special-character-bits	Globally defines the character width as 7-bit or 8-bit. Configures the number of data bits per character for special characters such as software flow control characters and escape characters.

terminal speed

To set the transmit and receive speeds of the current terminal line for the current session, use the **terminal speed** EXEC command.

terminal speed *bps*

Syntax Description	<i>bps</i> Baud rate in bits per second (bps).	
Defaults	9600 bps	
Command Modes	EXEC	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	Set the speed to match the transmission rate of whatever device you have connected to the port. Some baud rates available on devices connected to the port might not be supported on the router. The router indicates whether the speed you selected is not supported.	
Examples	The following example restores the transmit and receive speed on the current line to 9600 bps: Router# terminal speed 9600	
Related Commands	Command	Description
	speed	Sets the terminal baud rate.

terminal start-character

To change the flow control start character for the current session, use the **terminal start-character** EXEC command.

terminal start-character *ascii-number*

Syntax Description	<i>ascii-number</i> ASCII decimal representation of the start character.	
Defaults	Ctrl-Q (ASCII decimal character 17)	
Command Modes	EXEC	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	The flow control start character signals the start of data transmission when software flow control is in effect.	
Examples	The following example changes the start character to Ctrl-O (ASCII decimal character 15): <pre>Router# terminal start-character 15</pre>	
Related Commands	Command	Description
	start-character	Sets the flow control start character.

terminal stopbits

To change the number of stop bits sent per byte by the current terminal line during an active session, use the **terminal stopbits** EXEC command.

```
terminal stopbits {1 | 1.5 | 2}
```

Syntax Description	1	One stop bit.
	1.5	One and one-half stop bits.
	2	Two stop bits. This is the default.

Defaults	2 stop bits

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Communication protocols provided by devices such as terminals and modems often require a specific stop-bit setting.

Examples	In the following example the setting for stop bits is changed to one for the current session: Router# terminal stopbits 1

Related Commands	Command	Description
	stopbits	Sets the number of the stop bits sent per byte.

terminal stop-character

To change the flow control stop character for the current session, use the **terminal stop-character** EXEC command.

terminal stop-character *ascii-number*

Syntax Description	<i>ascii-number</i> ASCII decimal representation of the stop character.	
Defaults	Ctrl-S (ASCII character decimal 19)	
Command Modes	EXEC	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	The flow control stop character signals the end of data transmission when software flow control is in effect. See the “ASCII Character Set and Hex Values” appendix for a list of ASCII characters.	
Examples	In the following example the stop character is configured as Ctrl-E (ASCII character decimal 5) for the current session: <pre>Router# terminal stop-character 5</pre>	
Related Commands	Command	Description
	stop-character	Sets the flow control stop character.

terminal telnet break-on-ip

To cause an access server to generate a hardware Break signal when an interrupt-process (ip) command is received, use the **terminal telnet break-on-ip EXEC** command.

terminal telnet break-on-ip

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The hardware Break signal occurs when a Telnet interrupt-process (ip) command is received on that connection. The **terminal telnet break-on-ip** command can be used to control the translation of Telnet interrupt-process commands into X.25 Break indications.



Note In this command, the acronym “ip” indicates “interrupt-process,” not internet protocol (IP).

This command is also a useful workaround in the following situations:

- Several user Telnet programs send an ip command, but cannot send a Telnet Break signal.
- Some Telnet programs implement a Break signal that sends an IP command.

Some EIA/TIA-232 hardware devices use a hardware Break signal for various purposes. A hardware Break signal is generated when a Telnet Break command is received.

You can verify if this command is enabled with the **show terminal EXEC** command. If enabled the following line will appear in the output: Capabilities: Send BREAK on IP.

Examples In the following example, a Break signal is generated for the current connection when an interrupt-process command is issued:

```
Router# terminal telnet break-on-ip
```

Related Commands	Command	Description
	terminal telnet ip-on-break	Configures the system to send an interrupt-process (ip) signal when the Break command is issued.

terminal telnet refuse-negotiations

To configure the current session to refuse to negotiate full-duplex, remote echo options on incoming connections, use the **terminal telnet refuse-negotiations** EXEC command.

terminal telnet refuse-negotiations

Syntax Description

This command has no arguments or keywords.

Defaults

Disabled

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

You can set the line to allow access server to refuse full-duplex, remote echo connection requests from the other end. This command suppresses negotiation of the Telnet Remote Echo and Suppress Go Ahead options.

Examples

In the following example the current session is configured to refuse full-duplex, remote echo requests:

```
Router# terminal telnet refuse-negotiations
```

terminal telnet speed

To allow an access server to negotiate transmission speed for the current terminal line and session, use the **terminal telnet speed** EXEC command.

terminal telnet speed *default-speed maximum-speed*

Syntax Description	<i>default-speed</i>	Line speed, in bits per second (bps), that the access server will use if the device on the other end of the connection has not specified a speed.
	<i>maximum-speed</i>	Maximum line speed in bits per second (bps), that the device on the other end of the connection can use.

Defaults	9600 bps (unless otherwise set using the speed , txspeed or rxspeed line configuration commands)

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

You can match line speeds on remote systems in reverse Telnet, on host machines connected to an access server to access the network, or on a group of console lines connected to the access server when disparate line speeds are in use at the local and remote ends of the connections listed above. Line speed negotiation adheres to the Remote Flow Control option, defined in RFC 1080.


Note

This command applies only to access servers. It is not supported on standalone routers.

Examples

The following example enables the access server to negotiate a bit rate on the line using the Telnet option. If no speed is negotiated, the line will run at 2400 bps. If the remote host requests a speed greater than 9600 bps, then 9600 bps will be used.

```
Router# terminal telnet speed 2400 9600
```

terminal telnet sync-on-break

To cause the access server to send a Telnet Synchronize signal when it receives a Telnet Break signal on the current line and session, use the **terminal telnet sync-on-break EXEC** command.

terminal telnet sync-on-break

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	You can configure the session to cause a reverse Telnet line to send a Telnet Synchronize signal when it receives a Telnet Break signal. The TCP Synchronize signal clears the data path, but still interprets incoming commands.



Note	This command applies only to access servers. It is not supported on standalone routers.

Examples	The following example sets an asynchronous line to cause the access server to send a Telnet Synchronize signal:

```
Router# terminal telnet sync-on-break
```

terminal telnet transparent

To cause the current terminal line to send a Return character (CR) as a CR followed by a NULL instead of a CR followed by a Line Feed (LF) for the current session, use the **terminal telnet transparent EXEC** command.

terminal telnet transparent

Syntax Description This command has no arguments or keywords.

Defaults CR followed by an LF

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The end of each line typed at the terminal is ended with a Return (CR). This command permits interoperability with different interpretations of end-of-line demarcation in the Telnet protocol specification.

**Note**

This command applies only to access servers. It is not supported on stand-alone routers.

Examples In the following example the session is configured to send a CR signal as a CR followed by a NULL:

```
Router# terminal telnet transparent
```


terminal terminal-type

To specify the type of terminal connected to the current line for the current session, use the **terminal terminal-type EXEC** command.

terminal terminal-type *terminal-type*

Syntax Description	<i>terminal-type</i> Defines the terminal name and type, and permits terminal negotiation by hosts that provide that type of service.							
Defaults	VT100							
Command Modes	EXEC							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	10.0	This command was introduced.		
Release	Modification							
10.0	This command was introduced.							
Usage Guidelines	Indicate the terminal type if it is different from the default of VT100. The terminal type name is used by TN3270s for display management and by Telnet and rlogin to inform the remote host of the terminal type.							
Examples	In the following example the terminal type is defined as VT220 for the current session: <pre>Router# terminal terminal-type VT220</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>terminal keymap-type</td><td>Specifies the current keyboard type for the current session.</td></tr><tr><td>terminal-type</td><td>Specifies the type of terminal connected to a line.</td></tr></table>		Command	Description	terminal keymap-type	Specifies the current keyboard type for the current session.	terminal-type	Specifies the type of terminal connected to a line.
Command	Description							
terminal keymap-type	Specifies the current keyboard type for the current session.							
terminal-type	Specifies the type of terminal connected to a line.							

terminal txspeed

To set the terminal transmit speed (how fast the terminal can send information) for the current line and session, use the **terminal txspeed** EXEC command.

terminal txspeed *bps*

Syntax Description	<i>bps</i> Baud rate in bits per second (bps).

Defaults	9600 bps

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples	In the following example the line transmit speed is set to 2400 bps for the current session: Router# terminal txspeed 2400

Related Commands	Command	Description
	rxspeed	Sets the terminal receive speed for a specified line or lines.
	terminal rxspeed	Sets the terminal receive speed for the current line and session.
	terminal terminal-type	Specifies the type of terminal connected to the current line for the current session.
	txspeed	Sets the terminal transmit speed for a specified line or lines.

terminal-type

To specify the type of terminal connected to a line, use the **terminal-type** line configuration command. To remove any information about the type of terminal and reset the line to the default terminal emulation, use the **no** form of this command.

terminal-type {*terminal-name* | *terminal-type*}

no terminal-type

Syntax Description

<i>terminal-name</i>	Terminal name.
<i>terminal-type</i>	Terminal type.

Defaults

VT100

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command records the type of terminal connected to the line. The *terminal-name* argument provides a record of the terminal type and allows terminal negotiation of display management by hosts that provide that type of service.

For TN3270 applications, this command must follow the corresponding ttycap entry in the configuration file.

Examples

The following example defines the terminal on line 7 as a VT220:

```
Router(config)# line 7
Router(config-line)# terminal-type VT220
```

terminal width

To set the number of character columns on the terminal screen for the current line for a session, use the **terminal width** EXEC command.

terminal width *characters*

Syntax Description	<i>characters</i>	Number of character columns displayed on the terminal.

Defaults	80 characters

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	By default, the route provides a screen display width of 80 characters. You can reset this value for the current session if it does not meet the needs of your terminal. The rlogin protocol uses the value of the <i>characters</i> argument to set up terminal parameters on a remote host.

Examples	The following example sets the terminal character columns to 132: <pre>Router# terminal width 132</pre>

Related Commands	Command	Description
	width	Sets the terminal screen width (the number of character columns displayed on the attached terminal).

where

To list the open sessions, use the **where** EXEC command.

where

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command first appeared in a release prior to Cisco IOS Release 10.0.

Usage Guidelines

The **where** command displays all open sessions associated with the current terminal line.

The break (Ctrl-Shift-6, x), **where**, and **resume** commands are available with all supported connection protocols.

Examples

The following is sample output from the **where** command:

```
Router# where
Conn Host                Address          Byte    Idle  Conn Name
  1 MATHOM                192.31.7.21      0       0    MATHOM
* 2 CHAFF                131.108.12.19    0       0    CHAFF
```

The asterisk (*) indicates the current terminal session.

[Table 8](#) describes the significant fields shown in the display.

Table 8 *where* Field Descriptions

Field	Description
Conn	Name or address of the remote host to which the connection is made.
Host	Remote host to which the router is connected through a Telnet session.
Address	IP address of the remote host.
Byte	Number of unread bytes for the user to see on the connection.
Idle	Interval (in minutes) since data was last sent on the line.
Conn Name	Assigned name of the connection.

Related Commands

Command	Description
show line	Displays information about all lines on the system or the specified line.
show sessions	Displays information about open LAT, Telnet, or rlogin connections.

width

To set the terminal screen width, use the **width** line configuration command. To return to the default screen width, use the **no** form of this command.

width *characters*

no width

Syntax Description	<i>characters</i> Number of character columns displayed on the terminal.

Defaults	80 character columns


Command Modes	Line configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>10.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines	By default, the route provides a screen display width of 80 characters. You can reset this value for the current session if it does not meet the needs of your terminal. The rlogin protocol uses the value of the <i>characters</i> argument to set up terminal parameters on a remote host.

Examples	In the following example the location for line 7 is defined as “console terminal” and the display is set to 132 columns wide: <pre>Router(config)# line 7 Router(config-line)# location console terminal Router(config-line)# width 132</pre>

Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>terminal width</td><td>Sets the number of character columns on the terminal screen for the current session.</td></tr></table>	Command	Description	terminal width	Sets the number of character columns on the terminal screen for the current session.
Command	Description				
terminal width	Sets the number of character columns on the terminal screen for the current session.				



Connection, Menu, and System Banner Commands

This chapter describes commands used for connection management, and the commands used to configure user menus and banners.

For connection and system banner task information and examples, refer to the “Managing Connections, Menus, and System Banners” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

banner exec

To specify and enable a message to be displayed when an EXEC process is created (an EXEC banner), use the **banner exec** global configuration command. To delete the existing EXEC banner, use the **no** form of this command.

banner exec *d message d*

no banner exec

Syntax Description	<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
	<i>message</i>	Message text. You can include tokens in the form \$(token) in the message text. Tokens will be replaced with the corresponding configuration variable. Tokens are described in Table 9 .

Defaults Disabled (no EXEC banner is displayed).

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.
	11.3(7.5) AA	Token functionality was introduced.
	12.0(3) T	Token functionality was integrated in the 12.0 T release train.

Usage Guidelines

This command specifies a message to be displayed when an EXEC process is created (a line is activated, or an incoming connection is made to a vty). Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a router, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the router, the EXEC banner or incoming banner will be displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner will be displayed. For all other connections, the router will display the EXEC banner.

To disable the EXEC banner on a particular line or lines, use the **no exec-banner** line configuration command.

To customize the banner, use tokens in the form \$(*token*) in the message text. Tokens will display current Cisco IOS configuration variables, such as the router’s host name and IP address. The tokens are described in [Table 9](#).

Table 9 *banner exec Tokens*

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the router.
\$(domain)	Displays the domain name for the router.
\$(line)	Displays the vty or tty (asynchronous) line number.
\$(line-desc)	Displays the description attached to the line.

Examples

The following example sets an EXEC banner that uses tokens. The percent sign (%) is used as a delimiting character. Notice that the *\$(token)* syntax is replaced by the corresponding configuration variable.

```
Router(config)# banner exec %  
Enter TEXT message. End with the character '%'.  
Session activated on line $(line), $(line-desc). Enter commands at the prompt.  
%
```

When a user logs on to the system, the following output is displayed:

```
User Access Verification
```

```
Username: joeuser  
Password: <password>
```

```
Session activated on line 50, vty default line. Enter commands at the prompt.
```

```
Router>
```

Related Commands

Command	Description
banner incoming	Defines a customized banner to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner login	Defines a customized banner to be displayed before the username and password login prompts.
banner motd	Defines a customized message-of-the-day banner.
banner slip-ppp	Defines a customized banner to be displayed when a Serial-line IP or Point-to-Point connection is made.
exec-banner	Controls (enables or disables) the display of EXEC banners and message-of-the-day banners on a specified line or lines.

banner incoming

To define and enable a banner to be displayed when there is an incoming connection to a terminal line from a host on the network, use the **banner incoming** global configuration command. To delete the incoming connection banner, use the **no** form of this command.

banner incoming *d message d*

no banner incoming

Syntax Description

<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
<i>message</i>	Message text. You can include tokens in the form \$(<i>token</i>) in the message text. Tokens will be replaced with the corresponding configuration variable. Tokens are described in Table 10 .

Defaults

Disabled (no incoming banner is displayed).

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.
11.3(7.5) AA	Token functionality was introduced.
12.0(3) T	Token functionality was integrated in the 12.0 T release train.

Usage Guidelines

Follow the **banner incoming** command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

An *incoming connection* is one initiated from the network side of the router. Incoming connections are also called reverse Telnet sessions. These sessions can display MOTD banners and incoming banners, but they do not display EXEC banners. Use the **no motd-banner** line configuration command to disable the MOTD banner for reverse Telnet sessions on asynchronous lines.

When a user connects to the router, the message-of-the-day (MOTD) banner (if configured) appears first, before the login prompt. After the user successfully logs in to the router, the EXEC banner or incoming banner will be displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner will be displayed. For all other connections, the router will display the EXEC banner.

Incoming banners cannot be suppressed. If you do not want the incoming banner to appear, you must delete it with the **no banner incoming** command.

To customize the banner, use tokens in the form \$(*token*) in the message text. Tokens will display current Cisco IOS configuration variables, such as the router’s host name and IP address. The tokens are described in [Table 10](#).

Table 10 *banner incoming Tokens*

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the router.
\$(domain)	Displays the domain name for the router.
\$(line)	Displays the vty or tty (asynchronous) line number.
\$(line-desc)	Displays the description attached to the line.

Examples

The following example sets an incoming connection banner. The pound sign (#) is used as a delimiting character.

```
Router# banner incoming #  
This is the Reuses router.  
#
```

The following example sets an incoming connection banner that uses several tokens. The percent sign (%) is used as a delimiting character.

```
darkstar(config)# banner incoming %  
Enter TEXT message. End with the character '%'.  
You have entered $(hostname).$(domain) on line $(line) ($(line-desc)) %
```

When the incoming connection banner is executed, the user will see the following banner. Notice that the *\$(token)* syntax is replaced by the corresponding configuration variable.

```
You have entered darkstar.ourdomain.com on line 5 (Dialin Modem)
```

Related Commands

Command	Description
banner exec	Defines a customized banner to be displayed whenever the EXEC process is initiated.
banner login	Defines a customized banner to be displayed before the username and password login prompts.
banner motd	Defines a customized message-of-the-day banner.
banner slip-ppp	Defines a customized banner to be displayed when a Serial-line IP or Point-to-Point connection is made.

banner login

To define and enable a customized banner to be displayed before the username and password login prompts, use the **banner login** global configuration command. To disable the login banner, use **no** form of this command.

banner login *d message d*

no banner login

Syntax Description	<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
	<i>message</i>	Message text. You can include tokens in the form \$(token) in the message text. Tokens will be replaced with the corresponding configuration variable. Tokens are described in Table 11 .

Defaults	Disabled (no login banner is displayed).

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.
	11.3(7.5) AA	Token functionality was introduced.
	12.0(3) T	Token functionality was integrated in the 12.0 T release train.

Usage Guidelines	Follow the banner login command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.
	When a user connects to the router, the message-of-the-day (MOTD) banner (if configured) appears first, followed by the login banner and prompts. After the user successfully logs in to the router, the EXEC banner or incoming banner will be displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner will be displayed. For all other connections, the router will display the EXEC banner.
	To customize the banner, use tokens in the form \$(<i>token</i>) in the message text. Tokens will display current Cisco IOS configuration variables, such as the router’s host name and IP address. The tokens are described in Table 11 .

Table 11 *banner login Tokens*

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the router.
\$(domain)	Displays the domain name for the router.

Table 11 *banner login Tokens (continued)*

Token	Information Displayed in the Banner
\$(line)	Displays the vty or tty (asynchronous) line number.
\$(line-desc)	Displays the description attached to the line.

Examples

The following example sets a login banner. Double quotes (") are used as the delimiting character.

```
Router# banner login " Access for authorized users only. Please enter your username and password. "
```

The following example sets a login banner that uses several tokens. The percent sign (%) is used as the delimiting character.

```
darkstar(config)# banner login %  
Enter TEXT message. End with the character '%'.  
You have entered $(hostname).$(domain) on line $(line) ($(line-desc)) %
```

When the login banner is executed, the user will see the following banner. Notice that the *\$(token)* syntax is replaced by the corresponding configuration variable.

```
You have entered darkstar.ourdomain.com on line 5 (Dialin Modem)
```

Related Commands

Command	Description
banner exec	Defines a customized banner to be displayed whenever the EXEC process is initiated.
banner incoming	Defines a customized message to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner motd	Defines a customized message-of-the-day banner.
banner slip-ppp	Defines a customized banner to be displayed when a Serial-line IP or Point-to-Point connection is made.

banner motd

To define and enable a message-of-the-day (MOTD) banner, use the **banner motd** global configuration command. To delete the MOTD banner, use the **no** form of this command.

```

banner motd d message d

no banner motd

```

Syntax Description	<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
	<i>message</i>	Message text. You can include tokens in the form <i>\$(token)</i> in the message text. Tokens will be replaced with the corresponding configuration variable.

Defaults Disabled (no MOTD banner is displayed).

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.
	11.3(7.5) AA	Token functionality was introduced.
	12.0(3) T	Token functionality was integrated in the 12.0 T release train.

Usage Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

This MOTD banner is displayed to all terminals connected and is useful for sending messages that affect all users (such as impending system shutdowns). Use the **no exec-banner** or **no motd-banner** command to disable the MOTD banner on a line. The **no exec-banner** command also disables the EXEC banner on the line.

When a user connects to the router, the MOTD banner appears before the login prompt. After the user logs in to the router, the EXEC banner or incoming banner will be displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner will be displayed. For all other connections, the router will display the EXEC banner.

To customize the banner, use tokens in the form *\$(token)* in the message text. Tokens will display current Cisco IOS configuration variables, such as the router’s host name and IP address. The tokens are described in [Table 12](#).

Table 12 *banner motd Tokens*

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the router.
\$(domain)	Displays the domain name for the router.
\$(line)	Displays the vty or tty (asynchronous) line number.
\$(line-desc)	Displays the description attached to the line.

Examples

The following example configures an MOTD banner. The pound sign (#) is used as a delimiting character.

```
Router# banner motd # Building power will be off from 7:00 AM until 9:00 AM this coming
Tuesday. #
```

The following example configures an MOTD banner with a token. The percent sign (%) is used as a delimiting character.

```
darkstar(config)# banner motd %
Enter TEXT message. End with the character '%'.
Notice: all routers in $(domain) will be upgraded beginning April 20
%
```

When the MOTD banner is executed, the user will see the following. Notice that the *\$(token)* syntax is replaced by the corresponding configuration variable.

```
Notice: all routers in ourdomain.com will be upgraded beginning April 20
```

Related Commands

Command	Description
banner exec	Defines and enables a customized banner to be displayed whenever the EXEC process is initiated.
banner incoming	Defines and enables a customized message to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner login	Defines and enables a customized banner to be displayed before the username and password login prompts.
banner slip-ppp	Defines and enables a customized banner to be displayed when a Serial-line IP or Point-to-Point connection is made.
exec-banner	Controls (enables or disables) the display of EXEC banners and message-of-the-day banners on a specified line or lines.
motd-banner	Controls (enables or disables) the display of message-of-the-day banners on a specified line or lines.

banner slip-ppp

To customize the banner that is displayed when a SLIP or PPP connection is made, use the **banner slip-ppp** global configuration command. To restore the default SLIP or PPP banner, use the **no** form of this command.

banner slip-ppp *d message d*

no banner slip-ppp

Syntax Description	<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
	<i>message</i>	Message text. You can include tokens in the form \$(token) in the message text. Tokens will be replaced with the corresponding configuration variable.

Defaults

The default SLIP or PPP banner message is:

```
Entering encapsulation mode.
Async interface address is unnumbered (Ethernet0)
Your IP address is 10.000.0.0 MTU is 1500 bytes
```

The banner message when using the **service old-slip-prompt** command is:

```
Entering encapsulation mode.
Your IP address is 10.100.0.0 MTU is 1500 bytes
```

where *encapsulation* is SLIP or PPP.

Command Modes

Global configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

Use this command to define a custom SLIP or PPP connection message. This is useful when legacy client applications require a specialized connection string. To customize the banner, use tokens in the form \$(token) in the message text. Tokens will display current Cisco IOS configuration variables, such as the routers host name, IP address, encapsulation type, and MTU size. The banner tokens are described in [Table 13](#).

Table 13 *banner slip-ppp Tokens*

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name of the router.
\$(domain)	Displays the domain name of the router.
\$(peer-ip)	Displays the IP address of the peer machine.
\$(gate-ip)	Displays the IP address of the gateway machine.
\$(encap)	Displays the encapsulation type (SLIP, PPP, and so on).
\$(encap-alt)	Displays the encapsulation type as SL/IP instead of SLIP.
\$(mtu)	Displays the Maximum Transmission Unit (MTU) size.

Examples

The following example sets the SLIP/PPP banner using several tokens and the percent sign (%) as the delimiting character:

```
Router(config)# banner slip-ppp %
Enter TEXT message. End with the character '%'.
Starting $(encap) connection from $(gate-ip) to $(peer-ip) using a maximum packet size of
$(mtu) bytes... %
```

The new SLIP/PPP banner will now be displayed when the **slip** EXEC command is used. Notice that the \$(token) syntax is replaced by the corresponding configuration variable.

```
Router# slip
Starting SLIP connection from 172.16.69.96 to 192.168.1.200 using a maximum packet size of
1500 bytes...
```

Related Commands

Command	Description
banner exec	Defines and enables a customized banner to be displayed whenever the EXEC process is initiated.
banner incoming	Defines and enables a customized message to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner motd	Defines and enables a customized message-of-the-day banner.
slip	Initiates a connection to a remote host using Serial Line Internet Protocol (SLIP).
ppp	Initiates a connection to a remote host using Point-to-Point Protocol (PPP).

clear tcp

To clear a TCP connection, use the **clear tcp** privileged EXEC command.

clear tcp {**line** *line-number* | **local** *hostname port* **remote** *hostname port* | **tcb** *address*}

Syntax Description	line <i>line-number</i>	Line number of the TCP connection to clear.
	local <i>hostname port</i>	Host name of the local router and port and host name of the remote
	remote <i>hostname port</i>	router and port of the TCP connection to clear.
	tcb <i>address</i>	Transmission Control Block (TCB) address of the TCP connection to clear. The TCB address is an internal identifier for the endpoint.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines

The **clear tcp** command is particularly useful for clearing hung TCP connections.

The **clear tcp line** *line-number* command terminates the TCP connection on the specified tty line. Additionally, all TCP sessions initiated from that tty line are terminated.

The **clear tcp local** *hostname port* **remote** *hostname port* command terminates the specific TCP connection identified by the host name and port pair of the local and remote router.

The **clear tcp tcb** *address* command terminates the specific TCP connection identified by the TCB address.

Examples

The following example clears a TCP connection using its tty line number. The **show tcp** command displays the line number (tty2) that is used in the **clear tcp** command.

```
Router# show tcp

tty2, virtual tty from host router20.cisco.com
Connection state is ESTAB, I/O status: 1, unread input bytes: 0
Local host: 171.69.233.7, Local port: 23
Foreign host: 171.69.61.75, Foreign port: 1058

Enqueued packets for retransmit: 0, input: 0, saved: 0

Event Timers (current time is 0x36144):
Timer           Starts    Wakeups      Next
Retrans         4         0            0x0
TimeWait        0         0            0x0
AckHold         7         4            0x0
SendWnd         0         0            0x0
KeepAlive       0         0            0x0
GiveUp          0         0            0x0
PmtuAger        0         0            0x0
```

```

iss: 4151109680  snduna: 4151109752  sndnxt: 4151109752      sndwnd: 24576
irs: 1249472001  rcvnxt: 1249472032  rcvwnd:          4258  delrcvwnd:   30

```

```

SRTT: 710 ms, RTTO: 4442 ms, RTV: 1511 ms, KRTT: 0 ms
minRTT: 0 ms, maxRTT: 300 ms, ACK hold: 300 ms

```

```

Router# clear tcp line 2
[confirm]
[OK]

```

The following example clears a TCP connection by specifying its local router host name and port and its remote router host name and port. The **show tcp brief** command displays the local (Local Address) and remote (Foreign Address) host names and ports to use in the **clear tcp** command.

```

Router# show tcp brief

TCB          Local Address          Foreign Address      (state)
60A34E9C  router1.cisco.com.23      router20.cisco.1055  ESTAB

Router# clear tcp local router1 23 remote router20 1055
[confirm]
[OK]

```

The following example clears a TCP connection using its TCB address. The **show tcp brief** command displays the TCB address to use in the **clear tcp** command.

```

Router# show tcp brief

TCB          Local Address          Foreign Address      (state)
60B75E48  router1.cisco.com.23      router20.cisco.1054  ESTAB

Router# clear tcp tcb 60B75E48
[confirm]
[OK]

```

Related Commands

Command	Description
show tcp	Displays the status of TCP connections.
show tcp brief	Displays a concise description of TCP connection endpoints.

exec

To allow an EXEC process on a line, use the **exec** line configuration command. To turn off the EXEC process for the specified line, use the **no** form of this command.

exec

no exec

Syntax Description

This command has no arguments or keywords.

Defaults

The EXEC processes start is activated automatically on all lines.

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

When you want to allow an outgoing connection *only* for a line, use the **no exec** command. When a user tries to Telnet to a line with the **no exec** command configured, the user will get no response when pressing the Return key at the login screen.

Examples

The following example turns off the EXEC process on line 7. You might want to do this on the auxiliary port if the attached device (for example, the control port of a rack of modems) sends unsolicited data. If this happens, an EXEC process starts, which makes the line unavailable.

```
line 7
no exec
```

exec-banner

To reenable the display of EXEC and message-of-the-day (MOTD) banners on the specified line or lines, use the **exec-banner** line configuration command. To suppress the banners on the specified line or lines, use the **no** form of this command.

exec-banner

no exec-banner

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled on all lines

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command determines whether the router will display the EXEC banner and the message-of-the-day (MOTD) banner when an EXEC session is created. These banners are defined with the **banner exec** and **banner motd** global configuration commands. By default, these banner are enabled on all lines. Disable the EXEC and MOTD banners using the **no exec-banner** command.

This command has no effect on the incoming banner, which is controlled by the [banner incoming](#) command.

The MOTD banners can also be disabled by the **no motd-banner** line configuration command, which disables MOTD banners on a line. If the **no exec-banner** command is configured on a line, the MOTD banner will be disabled regardless of whether the **motd-banner** command is enabled or disabled.

[Table 14](#) summarizes the effects of the **exec-banner** command and the **motd-banner** command.

Table 14 Banners Displayed Based On exec-banner and motd-banner Combinations

	exec-banner (default)	no exec-banner
motd-banner (default)	MOTD banner	None
	EXEC banner	
no motd-banner	EXEC banner	None

For reverse Telnet connections, the EXEC banner is never displayed. Instead, the incoming banner is displayed. The MOTD banner is displayed by default, but it is disabled if either the **no exec-banner** command or **no motd-banner** command is configured. [Table 15](#) summarizes the effects of the **exec-banner** command and the **motd-banner** command for reverse Telnet connections.

Table 15 *Banners Displayed Based On exec-banner and motd-banner Combinations for Reverse Telnet Sessions to Async Lines*

	exec-banner (default)	no exec-banner
	MOTD banner	Incoming banner
motd-banner (default)	Incoming banner	
no motd-banner	Incoming banner	Incoming banner

Examples

The following example suppresses the EXEC and MOTD banners on virtual terminal lines 0 to 4:

```
line vty 0 4
no exec-banner
```

Related Commands

Command	Description
banner exec	Defines and enables a customized banner to be displayed whenever the EXEC process is initiated.
banner incoming	Defines and enables a customized message to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner motd	Defines and enables a customized message-of-the-day banner.
motd-banner	Controls (enables or disables) the display of message-of-the-day banners on a specified line or lines.

exec-timeout

To set the interval that the EXEC command interpreter waits until user input is detected, use the **exec-timeout** line configuration command. To remove the timeout definition, use the **no** form of this command.

exec-timeout *minutes* [*seconds*]

no exec-timeout

Syntax Description	<i>minutes</i>	Integer that specifies the number of minutes.
	<i>seconds</i>	(Optional) Additional time intervals in seconds.

Defaults	10 minutes

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

If no input is detected during the interval, the EXEC facility resumes the current connection. If no connections exist, the EXEC facility returns the terminal to the idle state and disconnects the incoming session.

To specify no timeout, enter the **exec-timeout 0 0** command.

Examples

The following example sets a time interval of 2 minutes, 30 seconds:

```
line console
exec-timeout 2 30
```

The following example sets a time interval of 10 seconds:

```
line console
exec-timeout 0 10
```

lock

To configure a temporary password on a line, use the **lock** EXEC command.

lock

Syntax Description	This command has no arguments or keywords.	
Defaults	Not locked	
Command Modes	EXEC	
Command History	Release	Modification
	10.0	This command was introduced in a release prior to Cisco IOS Release 10.0.

Usage Guidelines	You can prevent access to your session while keeping your connection open by setting up a temporary password. To lock access to the terminal, perform the following steps:	
Step 1	Enter the lock command. The system prompts you for a password.	
Step 2	Enter a password, which can be any arbitrary string. The system will prompt you to confirm the password. The screen then clears and displays the message “Locked.”	
Step 3	To regain access to your sessions, reenter the password.	

The Cisco IOS software honors session timeouts on a locked lines. You must clear the line to remove this feature. The system administrator must set the line up to allow use of the temporary locking feature by using the **lockable** line configuration command.

Examples	The following example shows configuring the router as lockable, saving the configuration, and then locking the current session for the user: <pre>Router(config-line)# lockable Router(config-line)# ^Z Router# copy system:running-config nvram:startup-config Building configuration... OK Router# lock Password: <password> Again: <password> Locked Password: <password> Router#</pre>	

Related Commands	Command	Description
	lockable	Enables the lock EXEC command.
	login (EXEC)	Enables or changes a login username.

menu clear-screen

To clear the terminal screen before displaying a menu, use the **menu clear-screen** global configuration command.

menu *menu-name* **clear-screen**

Syntax Description

<i>menu-name</i>	Name of the menu this command should be applied to.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command uses a terminal-independent mechanism based on termcap entries defined in the router and the configured terminal type for the user. This command allows the same menu to be used on multiple types of terminals instead of having terminal-specific strings embedded within menu titles. If the termcap entry does not contain a clear string, the menu system enters 24 new lines, causing all existing text to scroll off the top of the terminal screen.

Examples

In the following example, the terminal screen is cleared before displaying the menu named Access1:

```
menu Access1 clear-screen
```

Related Commands

Command	Description
menu (EXEC)	Invokes a user menu.
menu command	Specifies underlying commands for user menus.
menu default	Specifies the menu item to use as the default.
menu line-mode	Requires the user to press Enter after specifying an item.
menu options	Sets options for items in user menus.
menu prompt	Specifies the prompt for a user menu.
menu single-space	Displays menu items single-spaced rather than double-spaced.
menu status-line	Displays a line of status information about the current user at the top of a menu
menu text	Specifies the text of a menu item in a user menu.
menu title	Creates a title, or banner, for a user menu.
no menu	Deletes a specified menu from a menu configuration.

menu command

To specify underlying commands for user menus, use the **menu command** global configuration command.

```
menu menu-name command menu-item {command | menu-exit}
```

Syntax Description	<i>menu-name</i>	Name of the menu. You can specify a maximum of 20 characters.
	<i>menu-item</i>	Number, character, or string used as the key for the item. The key is displayed to the left of the menu item text. You can specify a maximum of 18 menu entries. When the tenth item is added to the menu, the line-mode and single-space options are activated automatically.
	<i>command</i>	Command to issue when the user selects an item.
	menu-exit	Provides a way for menu users to return to a higher-level menu or exit the menu system.

Defaults Disabled

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Use this command to assign actions to items in a menu. Use the **menu text** global configuration command to assign text to items. These commands must use the same menu name and menu selection key.

The **menu command** command has a special keyword for the *command* argument, **menu-exit**, that is available only within menus. It is used to exit a submenu and return to the previous menu level, or to exit the menu altogether and return to the EXEC command prompt.

You can create submenus that are opened by selecting entries in another menu. Use the **menu EXEC** command as the *command* for the submenu item.



Note If you nest too many levels of menus, the system prints an error message on the terminal and returns to the previous menu level.

When a menu allows connections (their normal use), the command for an entry activating the connection should contain a **resume** command, or the line should be configured to prevent users from escaping their sessions with the **escape-char none** command. Otherwise, when they escape from a connection and return to the menu, there will be no way to resume the session and it will sit idle until the user logs out.

Specifying the **resume** command as the action that is performed for a selected menu entry permits a user to resume a named connection or connect using the specified name, if there is no active connection by that name. As an option, you can also supply the connect string needed to connect initially. When you do not supply this connect string, the command uses the specified connection name.

You can also use the **resume/next** command, which resumes the next connection in the user's list of connections. This function allows you to create a single menu entry that steps through all of the user's connections.



Note

A menu should not contain any exit paths that leave users in an unfamiliar interface environment.

When a particular line should always display a menu, that line can be configured with an **autocommand** line configuration command. Menus can be run on a per-user basis by defining a similar **autocommand** command for that local username. For more information about the **autocommand** command, refer to the *Cisco IOS Dial Technologies Configuration Guide*.

Examples

In the following example, the commands to be issued when the menu user selects option 1, 2, or 3 are specified for the menu named Access1:

```
menu Access1 command 1 tn3270 vms.cisco.com
menu Access1 command 2 rlogin unix.cisco.com
menu Access1 command 3 menu-exit
```

The following example allows a menu user to exit a menu by entering **Exit** at the menu prompt:

```
menu Access1 text Exit Exit
menu Access1 command Exit menu-exit
```

Related Commands

Command	Description
autocommand	Configures the Cisco IOS software to automatically execute a command when a user connects to a particular line.
menu (EXEC)	Invokes a user menu.
menu clear-screen	Clears the terminal screen before displaying a menu.
menu default	Specifies the menu item to use as the default.
menu line-mode	Requires the user to press Enter after specifying an item.
menu options	Sets options for items in user menus.
menu prompt	Specifies the prompt for a user menu.
menu single-space	Displays menu items single-spaced rather than double-spaced.
menu status-line	Displays a line of status information about the current user at the top of a menu
menu text	Specifies the text of a menu item in a user menu.
menu title	Creates a title, or banner, for a user menu.

menu default

To specify the menu item to use as the default, use the **menu default** global configuration command.

menu *menu-name* **default** *menu-item*

Syntax Description	<i>menu-name</i>	Name of the menu. You can specify a maximum of 20 characters.
	<i>menu-item</i>	Number, character, or string key of the item to use as the default.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command to specify which menu entry is used when the user presses Enter without specifying an item. The menu entries are defined by the menu command and menu text global configuration commands.

Examples	In the following example, the menu user exits the menu when pressing Enter without selecting an item: <pre>menu Access1 9 text Exit the menu menu Access1 9 command menu-exit menu Access1 default 9</pre>

Related Commands	Command	Description
	menu (EXEC)	Invokes a preconfigured user menu.
	menu command	Specifies underlying commands for user menus.
	menu prompt	Specifies the prompt for a user menu.
	menu text	Specifies the text of a menu item in a user menu.
	menu title	Creates a title, or banner, for a user menu.

menu line-mode

To require the user to press Enter after specifying an item, use the **menu line-mode** global configuration command.

menu *menu-name* **line-mode**

Syntax Description	<i>menu-name</i>	Name of the menu this command should be applied to.

Defaults	Enabled for menus with more than nine items. Disabled for menus with nine or fewer items.	

Command Modes	Global configuration	

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	In a menu of nine or fewer items, you ordinarily select a menu item by entering the item number. In line mode, you select a menu entry by entering the item number and pressing Enter. Line mode allows you to backspace over the selected number and enter another number before pressing Enter to issue the command.	
	This option is activated automatically when more than nine menu items are defined but also can be configured explicitly for menus of nine or fewer items.	
	In order to use strings as keys for items, the menu line-mode command must be configured.	

Examples	In the following example, the line-mode option is enabled for the menu named Access1:	
	<pre>menu Access1 line-mode</pre>	

Related Commands	Command	Description
	menu (EXEC)	Invokes a preconfigured user menu.
	menu clear-screen	Clears the terminal screen before displaying a menu.
	menu command	Specifies underlying commands for a user menu.
	menu default	Specifies the menu item to use as the default.
	menu options	Sets options for items in user menus.
	menu prompt	Specifies the prompt for a user menu.
	menu single-space	Displays menu items single-spaced rather than double-spaced.
	menu status-line	Displays a line of status information about the current user at the top of a menu
	menu text	Specifies the text of a menu item in a user menu.

menu options

To set options for items in user menus, use the **menu options** global configuration command.

menu *menu-name* **options** *menu-item* {**login** | **pause**}

Syntax Description	<i>menu-name</i>	The name of the menu. You can specify a maximum of 20 characters.
	<i>menu-item</i>	Number, character, or string key of the item affected by the option.
	login	Requires a login before issuing the command.
	pause	Pauses after the command is entered before redrawing the menu.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use the menu command and menu text global configuration commands to define a menu entry.

Examples	In the following example, a login is required before issuing the command specified by menu entry 3 of the menu named Access1:

```
menu Access1 options 3 login
```

Related Commands	Command	Description
	menu (EXEC)	Invokes a user menu.
	menu clear-screen	Clears the terminal screen before displaying a menu.
	menu command	Specifies underlying commands for user menus.
	menu default	Specifies the menu item to use as the default.
	menu line-mode	Requires the user to press Enter after specifying an item.
	menu prompt	Specifies the prompt for a user menu.
	menu single-space	Displays menu items single-spaced rather than double-spaced.
	menu status-line	Displays a line of status information about the current user at the top of a menu.
	menu text	Specifies the text of a menu item in a user menu.
	menu title	Creates a title, or banner, for a user menu.

menu prompt

To specify the prompt for a user menu, use the **menu prompt** global configuration command.

```
menu menu-name prompt d prompt d
```

Syntax Description	menu-name	Name of the menu. You can specify a maximum of 20 characters.
	d	A delimiting character that marks the beginning and end of a title. Text delimiters are characters that do not ordinarily appear within the text of a title, such as slash (/), double quote ("), and tilde (~). ^C is reserved for special use and should not be used in the text of the title.
	prompt	Prompt string for the menu.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Press Enter after entering the first delimiter. The router will prompt you for the text of the prompt. Enter the text followed by the delimiter, and press Enter.
	Use the menu command and menu text commands to define the menu selections.

Examples	In the following example, the prompt for the menu named Access1 is configured as “Select an item.”:
	<pre>Router(config)# menu Access1 prompt / Enter TEXT message. End with the character '/'. Select an item. / Router(config)#</pre>

Related Commands	Command	Description
	menu (EXEC)	Invokes a user menu.
	menu command	Specifies underlying commands for user menus.
	menu default	Specifies the menu item to use as the default.
	menu text	Specifies the text of a menu item in a user menu.
	menu title	Creates a title, or banner, for a user menu.

menu single-space

To display menu items single-spaced rather than double-spaced, use the **menu single-space** global configuration command.

menu *menu-name* **single-space**

Syntax Description	<i>menu-name</i>	Name of the menu this command should be applied to.

Defaults	Enabled for menus with more than nine items; disabled for menus with nine or fewer items.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	When more than nine menu items are defined, the menu is displayed single-spaced. To configure the menus with nine or fewer items to display single-spaced, use this command.

Examples	In the following example, single-spaced menu items are displayed for the menu named Access1: <pre>menu Access1 single-space</pre>

Related Commands	Command	Description
	menu (EXEC)	Invokes a user menu.
	menu clear-screen	Clears the terminal screen before displaying a menu.
	menu command	Specifies underlying commands for user menus.
	menu default	Specifies the menu item to use as the default.
	menu line-mode	Requires the user to press Enter after specifying an item.
	menu options	Sets options for items in user menus.
	menu prompt	Specifies the prompt for a user menu.
	menu status-line	Displays a line of status information about the current user at the top of a menu.
	menu text	Specifies the text of a menu item in a user menu.
	menu title	Creates a title, or banner, for a user menu.

menu status-line

To display a line of status information about the current user at the top of a menu, use the **menu status-line** global configuration command.

menu *menu-name* **status-line**

Syntax Description

<i>menu-name</i>	Name of the menu this command should be applied to.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command displays the status information at the top of the screen before the menu title is displayed. This status line includes the router's host name, the user's line number, and the current terminal type and keymap type (if any).

Examples

In the following example, status information is enabled for the menu named Access1:

```
menu Access1 status-line
```

Related Commands

Command	Description
menu (EXEC)	Invokes a user menu.
menu clear-screen	Clears the terminal screen before displaying a menu.
menu command	Specifies underlying commands for user menus.
menu default	Specifies the menu item to use as the default.
menu line-mode	Requires the user to press Enter after specifying an item in a menu.
menu options	Sets options for items in user menus.
menu prompt	Specifies the prompt for a user menu.
menu single-space	Displays menu items single-spaced rather than double-spaced.
menu text	Specifies the text of a menu item in a user menu.
menu title	Creates a title, or banner, for a user menu.

menu text

To specify the text of a menu item in a user menu, use the **menu text** global configuration command.

menu *menu-name* **text** *menu-item* *menu-text*

Syntax Description	<i>menu-name</i>	Name of the menu. You can specify a maximum of 20 characters.
	<i>menu-item</i>	Number, character, or string used as the key for the item. The key is displayed to the left of the menu item text. You can specify a maximum of 18 menu items. When the tenth item is added to the menu, the menu line-mode and menu single-space commands are activated automatically.
	<i>menu-text</i>	Text of the menu item.

Defaults	No text appears for the menu item.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command to assign text to items in a menu. Use the menu command command to assign actions to items. These commands must use the same menu name and menu selection key. You can specify a maximum of 18 items in a menu.

Examples	In the following example, the descriptive text for the three entries is specified for options 1, 2, and 3 in the menu named Access1:

```
menu Access1 text 1 IBM Information Systems
menu Access1 text 2 UNIX Internet Access
menu Access1 text 3 Exit menu system
```

Related Commands	Command	Description
	menu (EXEC)	Invokes a user menu.
	menu clear-screen	Clears the terminal screen before displaying a menu.
	menu command	Specifies underlying commands for user menus.
	menu default	Specifies the menu item to use as the default.
	menu line-mode	Requires the user to press Enter after specifying an item.
	menu options	Sets options for items in user menus.
	menu prompt	Specifies the prompt for a user menu.

■ menu text

Command	Description
menu single-space	Displays menu items single-spaced rather than double-spaced.
menu status-line	Displays a line of status information about the current user at the top of a menu
menu title	Creates a title, or banner, for a user menu.

menu title

To create a title (banner) for a user menu, use the **menu title** global configuration command.

menu *menu-name* **title** *d menu-title d*

Syntax Description	<i>menu-name</i>	Name of the menu. You can specify a maximum of 20 characters.
	<i>d</i>	A delimiting character that marks the beginning and end of a title. Text delimiters are characters that do not ordinarily appear within the text of a title, such as slash (/), double quote ("), and tilde (~). ^C is reserved for special use and should not be used in the text of the title.
	<i>menu-title</i>	Lines of text to appear at the top of the menu.

Defaults The menu does not have a title.

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The **menu title** command must use the same menu name used with the **menu text** and **menu command** commands used to create a menu.

You can position the title of the menu horizontally by preceding the title text with blank characters. You can also add lines of space above and below the title by pressing Enter.

Follow the **title** keyword with one or more blank characters and a delimiting character of your choice. Then enter one or more lines of text, ending the title with the same delimiting character. You cannot use the delimiting character within the text of the message.

When you are configuring from a terminal and are attempting to include special control characters, such as a screen-clearing string, you must use Ctrl-V before the special control characters so that they are accepted as part of the title string. The string ^[[H^[[J is an escape string used by many VT100-compatible terminals to clear the screen. To use a special string, you must enter Ctrl-V before each escape character.

You also can use the **menu clear-screen** global configuration command to clear the screen before displaying menus and submenus, instead of embedding a terminal-specific string in the menu title. The **menu clear-screen** command allows the same menu to be used on different types of terminals.

Examples In the following example, the title that will be displayed is specified when the menu named Access1 is invoked. Press Enter after the second slash (/) to display the prompt.

```
Router(config)# menu Access1 title /^[H^[[J
Enter TEXT message. End with the character '/'.
Welcome to Access1 Internet Services
```

menu title

```

                                Type a number to select an option;
                                Type 9 to exit the menu.
/
Router(config)#
```

Related Commands

Command	Description
menu (EXEC)	Invokes a user menu.
menu clear-screen	Clears the terminal screen before displaying a menu.
menu command	Specifies underlying commands for user menus.
menu default	Specifies the menu item to use as the default.
menu line-mode	Requires the user to press Enter after specifying an item.
menu options	Sets options for items in user menus.
menu prompt	Specifies the prompt for a user menu.
menu single-space	Displays menu items single-spaced rather than double-spaced.
menu status-line	Displays a line of status information about the current user at the top of a menu
menu text	Specifies the text of a menu item in a user menu.

no menu

To delete a user menu from the configuration file, use the **no menu** global configuration command.

no menu *menu-name*

Syntax Description	<i>menu-name</i>	Name of the menu to delete from the configuration file.

Defaults	None

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command to remove any menu commands for a particular menu from the configuration file.
	As with all global configuration commands, this command will only effect the startup configuration file when you save the running configuration using the copy running-config startup-config EXEC command.

Examples	The following example deletes the menu named Access1:
	<pre>no menu Access1</pre>

Related Commands	Command	Description
	menu (EXEC)	Invokes a user menu.
	menu command	Specifies underlying commands for user menus.
	menu prompt	Specifies the prompt for a user menu.
	menu text	Specifies the text of a menu item in a user menu.
	menu title	Creates a title, or banner, for a user menu.

motd-banner

To enable the display of message-of-the-day (MOTD) banners on the specified line or lines, use the **motd-banner** line configuration command. To suppress the MOTD banners on the specified line or lines, use the **no** form of this command.

motd-banner

no motd-banner

Syntax Description	This command has no arguments or keywords.	
Defaults	Enabled on all lines.	
Command Modes	Line configuration	
Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines

This command determines whether the router will display the MOTD banner when an EXEC session is created on the specified line or lines. The MOTD banner is defined with the **banner motd** global configuration command. By default, the MOTD banner is enabled on all lines. Disable the MOTD banner on specific lines using the **no motd-banner** line configuration command.

The MOTD banners can also be disabled by the **no exec-banner** line configuration command, which disables both MOTD banners and EXEC banners on a line. If the **no exec-banner** command is configured on a line, the MOTD banner will be disabled regardless of whether the **motd-banner** command is enabled or disabled. [Table 16](#) summarizes the effects of the **exec-banner** command and the **motd-banner** command.

Table 16 Banners Displayed Based On exec-banner and motd-banner Combinations

	exec-banner (default)	no exec-banner
motd-banner (default)	MOTD banner	None
	EXEC banner	
no motd-banner	EXEC banner	None

For reverse Telnet connections, the EXEC banner is never displayed. Instead, the incoming banner is displayed. The MOTD banner is displayed by default, but it is disabled if either the **no exec-banner** command or **no motd-banner** command is configured. [Table 17](#) summarizes the effects of the **exec-banner** command and the **motd-banner** command for reverse Telnet connections.

Table 17 *Banners Displayed Based On exec-banner and motd-banner Combinations for Reverse Telnet Sessions to Async Lines*

	exec-banner (default)	no exec-banner
motd-banner (default)	MOTD banner	Incoming banner
	Incoming banner	
no motd-banner	Incoming banner	Incoming banner

Examples

The following example suppresses the MOTD banner on vty lines 0 through 4:

```
line vty 0 4
no motd-banner
```

Related Commands

Command	Description
banner exec	Defines and enables a customized banner to be displayed whenever the EXEC process is initiated.
banner incoming	Defines and enables a customized message to be displayed when there is an incoming connection to a terminal line from a host on the network.
banner motd	Defines and enables a customized message-of-the-day banner.
motd-banner	Controls (enables or disables) the display of message-of-the-day banners on a specified line or lines.

name-connection

To assign a logical name to a connection, use the **name-connection** user EXEC command.

name-connection

Syntax Description	This command has no arguments or keywords.	
Defaults	No logical name is defined.	
Command Modes	User EXEC	
Command History	Release	Modification
	10.0	This command was introduced.
Usage Guidelines	This command can be useful for keeping track of multiple connections. You are prompted for the connection number and name to assign. The where command displays a list of the assigned logical connection names.	
Examples	The following example assigns the logical name blue to the connection: <pre>Router> where Conn Host Address Byte Idle Conn Name * 1 doc-2509 172.30.162.131 0 0 doc-2509 Router> name-connection Connection number: 1 Enter logical name: blue Connection 1 to doc-2509 will be named "BLUE" [confirm]</pre>	
Related Commands	Command	Description
	where	Lists open sessions associated with the current terminal line.

refuse-message

To define and enable a line-in-use message, use the **refuse-message** line configuration command. To disable the message, use the **no** form of this command.

```

refuse-message d message d

no refuse-message
    
```

Syntax Description	<i>d</i>	Delimiting character of your choice—a pound sign (#), for example. You cannot use the delimiting character in the message.
	<i>message</i>	Message text.

Defaults	Disabled (no line-in-use message is displayed).

Command Modes	Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character. You cannot use the delimiting character within the text of the message.
	When you define a message using this command, the Cisco IOS software performs the following steps: 1. Accepts the connection. 2. Prints the custom message. 3. Clears the connection.

Examples	In the following example, line 5 is configured with a line-in-use message, and the user is instructed to try again later:
	<pre> line 5 refuse-message /The dial-out modem is currently in use. Please try again later./ </pre>

send

To send messages to one or all terminal lines, use the **send EXEC** command.

send {*line-number* | * | **aux number** | **console number** | **tty number** | **vty number**}

Syntax Description	<i>line-number</i>	Line number to which the message will be sent.
	*	Sends a message to all lines.
	aux number	Sends a message to the specified AUX port.
	console number	Sends a message to the specified console port.
	tty number	Sends a message to the specified asynchronous line.
	vty number	Sends a message to the specified virtual asynchronous line.

Defaults No messages are sent.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines After entering this command, the system prompts for the message to be sent, which can be up to 500 characters long. Enter **Ctrl-Z** to end the message. Enter **Ctrl-C** to abort this command.



Caution

Be aware that in some circumstances text sent using the **send** command may be interpreted as an executable command by the receiving device. For example, if the receiving device is Unix workstation, and the receiving device is in a state (shell) where commands can be executed, the incoming text (if a valid Unix command) will be interpreted as a command. For this reason you should limit your use of any unmonitored connection to a router that uses an interactive shell.

Examples

The following example sends a message to all lines:

```
2509# send *
Enter message, end with CTRL/Z; abort with CTRL/C:
The system 2509 will be shut down in 10 minutes for repairs.^Z
Send message? [confirm]
2509#

***
***
*** Message from tty0 to all terminals:
***
The system 2509 will be shut down in 10 minutes for repairs.
```

2509#

service linenumber

To configure the Cisco IOS software to display line number information after the EXEC or incoming banner, use the **service linenumber** global configuration command. To disable this function, use the **no** form of this command.

- service linenumber**
- no service linenumber**

Syntax Description	This command has no arguments or keywords.				
Defaults	Disabled				
Command Modes	Global configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>10.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	10.0	This command was introduced.
Release	Modification				
10.0	This command was introduced.				

Usage Guidelines

With the **service linenumber** command, you can have the Cisco IOS software display the host name, line number, and location each time an EXEC process is started, or an incoming connection is made. The line number banner appears immediately after the EXEC banner or incoming banner. This feature is useful for tracking problems with modems, because the host and line for the modem connection are listed. Modem type information can also be included.

Examples

In the following example, a user Telnets to Router2 before and after the **service linenumber** command is enabled. The second time, information about the line is displayed after the banner.

```
Router1> telnet Router2

Trying Router2 (172.30.162.131)... Open

Welcome to Router2.

User Access Verification

Password:
Router2> enable
Password:
Router2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router2(config)# service linenumber
Router2(config)# end
Router2# logout

[Connection to Router2 closed by foreign host]
Router1> telnet Router2
```

Trying Router2 (172.30.162.131)... Open

Welcome to Router2.

Router2 line 10

User Access Verification

Password:

Router2>

Related Commands

Command	Description
show users	Displays information about the active lines on the router.

vacant-message

To display an idle terminal message, use the **vacant-message** line configuration command. To remove the default vacant message or any other vacant message that may have been set, use the **no** form of this command.

vacant-message [*d message d*]

no vacant-message

Syntax Description	<i>d</i>	(Optional) Delimiting character that marks the beginning and end of the vacant-message. Text delimiters are characters that do not ordinarily appear within the text of a title, such as slash (/), double quote ("), or tilde (~). ^C is reserved for special use and should not be used in the message.
	<i>message</i>	(Optional) Vacant terminal message.

Defaults The format of the default vacant message is as follows:

```
<blank lines>
hostname tty# is now available
<blank lines>
Press RETURN to get started.
```

This message is generated by the system.

Command Modes Line configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines This command enables the banner to be displayed on the screen of an idle terminal. The **vacant-message** command without any arguments restores the default message.

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.




Note For a rotary group, you need to define only the message for the first line in the group.

Examples The following example turns on the system banner and displays this message:

```
line 0
vacant-message #
                Welcome to Cisco Systems, Inc.
```


Press Return to get started.

■ vacant-message



Cisco IOS Web Browser User Interface Commands

This chapter provides descriptions of the commands used to enable the HTTP server on your router to allow the use of the Cisco IOS Web browser user interface (UI) and ClickStart.

For configuration tasks and examples, refer to the “Using the Cisco Web Browser User Interface” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

international

If you are using Telnet to access a Cisco IOS platform and you want to display 8-bit and multibyte international characters (for example, Kanji) and print the Escape character as a single character instead of as the caret and bracket symbols (^[]), use the **international** line configuration command. To display characters in 7-bit format, use the **no** form of this command.

international

no international

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Line configuration

Command History	Release	Modification
	11.3	This command was introduced.

Usage Guidelines	If you are configuring a Cisco IOS platform using the Cisco Web browser UI, this feature is enabled automatically when you enable the Cisco Web browser UI using the ip http server global configuration command.

Examples	The following example enables a Cisco IOS platform to display 8-bit and multibyte characters and print the Escape character as a single character instead of as the caret and bracket symbols (^[]) when you are using Telnet to access the platform:

```
line vty 4
  international
```

Related Commands	Command	Description
	terminal international	Prints the Escape character as a single character instead of as the caret and bracket symbols (^[]) for a current Telnet session in instances when you are using Telnet to access a Cisco IOS platform and you want to display 8-bit and multibyte international characters (for example, Kanji).

ip http access-class

To assign an access list to the HTTP server used by the Cisco IOS ClickStart software or the Cisco Web browser UI, use the **ip http access-class** global configuration command. To remove the assigned access list, use the **no** form of this command.

ip http access-class {*access-list-number* | *access-list-name*}

no ip http access-class {*access-list-number* | *access-list-name*}

Syntax Description

<i>access-list-number</i>	Standard IP access list number in the range 0 to 99, as configured by the access-list (standard) global configuration command.
<i>access-list-name</i>	Name of a standard IP access list, as configured by the ip access-list command.

Defaults

No access list is applied to the HTTP server.

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

If this command is configured, the specified access list is assigned to the HTTP server. Before the HTTP server accepts a connection, it checks the access list. If the check fails, the HTTP server does not accept the request for a connection.

Examples

The following example assigns the access list named marketing to the HTTP server:

```
ip http access-class marketing
ip access-list standard marketing
 permit 192.168.34.0 0.0.0.255
 permit 172.16.0.0 0.0.255.255
 permit 10.0.0.0 0.255.255.255
! (Note: all other access implicitly denied)
```

Related Commands

Command	Description
ip access-list	Defines an IP access list by name.
ip http server	Enables monitoring or configuring of routers using the Cisco Web browser UI.

ip http authentication

To specify a particular authentication method for HTTP server users, use the **ip http authentication** global configuration command. To disable a configured authentication method, use the **no** form of this command.

ip http authentication {aaa | enable | local | tacacs}

no ip http authentication {aaa | enable | local | tacacs}

Syntax Description

aaa	Indicates that the AAA facility is used for authentication.
enable	Indicates that the enable password method, which is the default method of HTTP server user authentication, is used for authentication.
local	Indicates that the local user database as defined on the Cisco router or access server is used for authentication.
tacacs	Indicates that the TACACS or XTACACS server is used for authentication.

Defaults

The default method of authentication for the HTTP server interface is the enable password method.

Command Modes

Global configuration

Command History

Release	Modification
11.2 F	This command was introduced.

Usage Guidelines

The **ip http authentication** command specifies the authentication method to be used for login when a client connects to the HTTP server. Use of the **ip http authentication aaa** command option is recommended. The **enable**, **local**, and **tacacs** methods should be specified using the **aaa authentication login** command.

The “enable” password method is the default HTTP server authentication method. If the enable password is used as the HTTP server login authentication method, the client connects to the HTTP server with a default privilege level of 15.



Note

When the “enable” password is used as the HTTP server login authentication method, any username entered will be ignored; the server will only verify the “enable” password. This may make it easier for an attacker to access the router. Because a username and password pair is more secure than using only a password for authentication, using only “enable” password for authentication is strongly discouraged. Instead, use of the **local** or **tacacs** authentication options, configured as part of a global Authentication, Authorization, and Accounting (AAA) framework, is recommended.

To configure HTTP access as part of a AAA policy, use the **ip http authentication aaa** command option. The “local”, “tacacs”, or “enable” authentication methods should then be configured using the **aaa authentication login** command.

For information about adding users into the local username database, refer to the [Cisco IOS Security Configuration Guide](#).

Examples

The following example specifies that the method configured for AAA should be used for authentication for HTTP server users. The AAA login method is configured as the “local” username/password authentication method.

```
Router(config)# ip http authentication aaa
Router(config)# aaa authentication login default local
```

Related Commands

Command	Description
ip http server	Enables the HTTP server.
aaa authentication login	Specifies the login authentication method to be used by the authentication, authorization, and accounting (AAA) service.

ip http port

To specify the port to be used by the Cisco IOS ClickStart software or the Cisco Web browser UI, use the **ip http port** global configuration command. To use the default port, use the **no** form of this command.

ip http port *port-number*

no ip http port

Syntax Description

<i>port-number</i>	Port number for use by the HTTP server.

Defaults

The HTTP server uses port 80.

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

Use this command if ClickStart or the Cisco Web browser UI cannot use port 80.

Examples

The following example configures the router so that you can use ClickStart or the Cisco Web browser UI through port 60:

```
ip http server
ip http port 60
```

Related Commands

Command	Description
ip http server	Enables a Cisco 1003, Cisco 1004, or Cisco 1005 router to be configured from a browser using the Cisco IOS ClickStart software, and enables any router to be monitored or have its configuration modified from a browser using the Cisco Web browser UI.

ip http server

To enable the Cisco Web browser UI on a router or access server, use the **ip http server** global configuration command. To disable this feature, use the **no** form of this command.

ip http server

no ip http server

Syntax Description

This command has no arguments or keywords.

Defaults

This feature is automatically enabled on Cisco 1003, Cisco 1004, and Cisco 1005 routers that have not yet been configured. For Cisco 1003, Cisco 1004, and Cisco 1005 routers that have already been configured, and for all other routers, this feature is disabled.

The HTTP server is disabled on the Cisco Catalyst 4000 series switch. The HTTP server is enabled for clustering and on the following Cisco switches: Catalyst 3700 series, Catalyst 3750 series, Catalyst 3550 series, Catalyst 3560 series, and Catalyst 2950 series.

Command History

Release	Modification
11.2	This command was introduced.

Command Modes

Global configuration

Usage Guidelines

This command enables a simple HTTP server on your system. The HTTP server in Cisco IOS software is used primarily for the Cisco Web browser user interface (UI) and ClickStart.

The Cisco Web browser UI allows configuration and monitoring of a router or access server using any web browser. Enabling the Cisco Web browser UI also allows Cisco 1003, Cisco 1004, and Cisco 1005 routers to be configured from a browser using ClickStart.

To view the home page of the router, use a Web browser pointed to `http://x.y.z.t`, where `x.y.z.t` is the IP address of your router or access server, or, if a name has been set, use `http://router-name`. Varying forms of authentication for login can be set using the **ip http authentication** command, but the default login method is entering the **enable** password when prompted.

For information on accessing a router Web page at a privilege level other the default of 15 (privileged EXEC mode), see the “Using the Cisco Web Browser to Issue Commands” section of the *Cisco IOS Configuration Fundamentals Configuration Guide*.

Examples

The following example enables the HTTP server on the router, allowing use of the Cisco Web browser UI to monitor the router and issue commands to it:

```
ip http server
```

Related Commands	Command	Description
	ip http access-class	Assigns an access list to the HTTP server used by the Cisco IOS ClickStart software or the Cisco Web browser UI.
	ip http authentication	Specifies an authentication method for HTTP server users.
	ip http port	Specifies the port to be used by the Cisco IOS ClickStart software or the Cisco Web browser UI.

terminal international

If you are using Telnet to access a Cisco IOS platform and you want to display 8-bit and multibyte international characters (for example, Kanji) and print the Escape character as a single character instead of as the caret and bracket symbols (^[]) for a current Telnet session, use the **terminal international** EXEC command. To display characters in 7-bit format for a current Telnet session, use the **no** form of this command.

terminal international

no terminal international

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	EXEC

Command History	Release	Modification
	11.3	This command was introduced.

Usage Guidelines	If you are configuring a Cisco IOS platform using the Cisco Web browser UI, this feature is enabled automatically when you enable the Cisco Web browser UI using the ip http server global configuration command.

Examples	The following example enables a Cisco IOS platform to display 8-bit and multibyte characters and print the Escape character as a single character instead of as the caret and bracket symbols (^[]) when you are using Telnet to access the platform for the current Telnet session:


```
Router# terminal international
```

Related Commands	Command	Description
	international	Prints the Escape character as a single character instead of as the caret and bracket symbols (^[]) in instances when you are using Telnet to access a Cisco IOS platform and you want to display 8-bit and multibyte international characters (for example, Kanji).

■ terminal international



File Management Commands



Cisco IOS File System Commands

This chapter describes the basic set of commands used to manipulate files on your routing device using the Cisco IOS File System (IFS) in Cisco IOS Release 12.2.

Commands in this chapter use URLs as part of the command syntax. URLs used in the Cisco IFS contain two parts: a file system or network prefix, and a file identification suffix. The following tables list URL keywords that can be used in the *source-url* and *destination-url* arguments for all commands in this chapter. The prefixes listed below can also be used in the *filesystem* arguments in this chapter.

Table 18 lists common URL network prefixes used to indicate a device on the network.

Table 18 Network Prefixes for Cisco IFS URLs

Prefix	Description
ftp:	Specifies a File Transfer Protocol (FTP) network server.
rcp:	Specifies an remote copy protocol (rcp) network server.
tftp:	Specifies a TFTP server.

Table 19 lists the available suffix options (file indentification suffixes) for the URL prefixes used in Table 18.

Table 19 File ID Suffixes for Cisco IFS URLs

Prefix	Suffix Options
ftp:	[[//[username[:password]@]location]/directory]/filename For example: ftp://network-config (<i>prefix://filename</i>) ftp://jeanluc:secret@enterprise.cisco.com/ship-config
rcp:	rcp:[//[username@]location]/directory]/filename
tftp:	tftp:[//[location]/directory]/filename

Table 20 lists common URL prefixes used to indicate memory locations on the system.

Table 20 File System Prefixes for Cisco IFS URLs

Prefix	Description
bootflash:	Bootflash memory.
disk0:	Rotating disk media.
flash: [<i>partition-number</i>]	Flash memory. This prefix is available on most platforms. For platforms that do not have a device named flash: , the prefix flash: is aliased to slot0: . Therefore, you can use the prefix flash: to refer to the main Flash memory storage area on all platforms
flh:	Flash load helper log files.
null:	Null destination for copies. You can copy a remote file to null to determine its size.
nvr:	NVRAM. This is the default location for the running-configuration file.
slavebootflash:	Internal Flash memory on a slave RSP card of a router configured with Dual RSPs.
slavenvr:	NVRAM on a slave RSP card.
slaveslot0:	First PCMCIA card on a slave RSP card.
slaveslot1:	Second PCMCIA card on a slave RSP card.
slot0:	First PCMCIA Flash memory card.
slot1:	Second PCMCIA Flash memory card.
xmodem:	Obtain the file from a network machine using the Xmodem protocol.
ymodem:	Obtain the file from a network machine using the Ymodem protocol.

For details about the Cisco IFS, and for IFS configuration tasks, refer to the “Configuring the Cisco IOS File System” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*. For details about Flash File System types (Class A, B, and C), refer to “PCMCIA Filesystem Compatibility Matrix and Filesystem Information” Tech Note on Cisco.com

cd

To change the default directory or file system, use the **cd** EXEC command.

cd [*filesystem:*]

Syntax Description	<i>filesystem:</i> (Optional) The URL or alias of the directory or file systems followed by a colon.															
Defaults	The initial default file system is flash:. For platforms that do not have a physical device named flash:, the keyword flash: is aliased to the default Flash device. If you do not specify a directory on a file system, the default is the root directory on that file system.															
Command Modes	EXEC															
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	11.0	This command was introduced.										
Release	Modification															
11.0	This command was introduced.															
Usage Guidelines	For all EXEC commands that have an optional <i>filesystem</i> argument, the system uses the file system specified by the cd command when you omit the optional <i>filesystem</i> argument. For example, the dir EXEC command, which displays a list of files on a file system, contain an optional <i>filesystem</i> argument. When you omit this argument, the system lists the files on the file system specified by the cd command.															
Examples	In the following example, the cd command is used to set the default file system to the Flash memory card inserted in slot 0: <pre>Router# pwd bootflash:/ Router# cd slot0: Router# pwd slot0:/</pre>															
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>copy</td><td>Copies any file from a source to a destination.</td></tr><tr><td>delete</td><td>Deletes a file on a Flash memory device.</td></tr><tr><td>dir</td><td>Displays a list of files on a file system.</td></tr><tr><td>pwd</td><td>Displays the current setting of the cd command.</td></tr><tr><td>show file systems</td><td>Lists available file systems and their alias prefix names.</td></tr><tr><td>undelete</td><td>Recovers a file marked “deleted” on a Class A or Class B Flash file system.</td></tr></table>		Command	Description	copy	Copies any file from a source to a destination.	delete	Deletes a file on a Flash memory device.	dir	Displays a list of files on a file system.	pwd	Displays the current setting of the cd command.	show file systems	Lists available file systems and their alias prefix names.	undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.
Command	Description															
copy	Copies any file from a source to a destination.															
delete	Deletes a file on a Flash memory device.															
dir	Displays a list of files on a file system.															
pwd	Displays the current setting of the cd command.															
show file systems	Lists available file systems and their alias prefix names.															
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.															

configure network

The **configure network** command was replaced by the **copy {rcp | tftp} running-config** command in Cisco IOS Release 11.0. To maintain backward compatibility, the **configure network** command continues to function in Cisco IOS Release 12.2 for most systems, but support for this command may be removed in a future release.

The **copy {rcp | tftp} running-config** command was replaced by the **copy {ftp: | rcp: | tftp:}[filename] system:running-config** command in Cisco IOS Release 12.1.

The **copy {ftp: | rcp: | tftp:}[filename] system:running-config** command specifies that a configuration file should be copied from a FTP, rcp, or TFTP source to the running configuration. See the description of the **copy** in this chapter command for more information.

copy

To copy any file from a source to a destination, use the **copy** EXEC command.

copy [/erase] *source-url destination-url*

Syntax Description

/erase	(Optional) Erases the destination file system before copying.
<i>source-url</i>	The location URL or alias of the source file or directory to be copied.
<i>destination-url</i>	The destination URL or alias of the copied file or directory.

The exact format of the source and destination URLs varies according to the file or directory location. You may enter either an alias keyword for a particular file or an alias keyword for a file system type (not a file within a type).



Timesaver

Aliases are used to cut down on the amount of typing you need to perform. For example, it is easier to type **copy run start** (the abbreviated form of the **copy running-config startup-config** command) than it is to type **copy system:r nvram:s** (the abbreviated form of the **copy system:running-config nvram:startup-config** command). These aliases also allow you to continue using some of the common commands used in previous versions of Cisco IOS software.

[Table 21](#) shows two keyword shortcuts to URLs.

Table 21 Common Keyword Aliases to URLs

Keyword	Source or Destination
running-config	(Optional) Keyword alias for the system:running-config URL. The system:running-config keyword represents the current running configuration file. This keyword does not work in more and show file EXEC command syntaxes.
startup-config	(Optional) Keyword alias for the nvram:startup-config URL. The nvram:startup-config keyword represents the configuration file used during initialization (startup). This file is contained in NVRAM for all platforms except the Cisco 7000 family, which uses the CONFIG_FILE environment variable to specify the startup configuration. The Cisco 4500 series cannot use the copy running-config startup-config command. This keyword does not work in more and show file EXEC command syntaxes.

The following tables list aliases by file system type. If you do not specify an alias, the router looks for a file in the current directory.

[Table 22](#) lists URL aliases for Special (opaque) file systems. [Table 23](#) lists them for network file systems, and [Table 24](#) lists them for local writable storage.

Table 22 URL Prefix Aliases for Special File Systems

Alias	Source or Destination
flh:	Source URL for flash load helper log files.
modem:	Destination URL for loading modem firmware on Cisco 5200 and 5300 Series routers.
nvr:	Router NVRAM. You can copy the startup configuration into or from NVRAM. You can also display the size of a private configuration file.
null:	Null destination for copies or files. You can copy a remote file to null to determine its size.
system:	Source or destination URL for system memory, which includes the running configuration.
xmodem:	Source destination for the file from a network machine that uses the Xmodem protocol.
ymodem:	Source destination for the file from a network machine that uses the Xmodem protocol.

Table 23 URL Prefix Aliases for Network File Systems

Alias	Source or Destination
ftp:	Source or destination URL for an File Transfer Protocol (FTP) network server. The syntax for this alias is as follows: ftp: [[[//username [:password]@]location]/directory]/filename.
rcp:	Source or destination URL for a Remote Copy Protocol (rcp) network server. The syntax for this alias is as follows: rcp: [[[//username@]location]/directory]/filename.
tftp:	Source or destination URL for a TFTP network server. The syntax for this alias is tftp: [[[//location]/directory]/filename.

Table 24 URL Prefix Aliases for Local Writable Storage File Systems

Alias	Source or Destination
bootflash:	Source or destination URL for boot flash memory.
disk0: and disk1:	Source or destination URL of rotating media.
flash:	Source or destination URL for Flash memory. This alias is available on all platforms. For platforms that lack a flash: device, note that flash: is aliased to slot0: , allowing you to refer to the main Flash memory storage area on all platforms.
slavebootflash:	Source or destination URL for internal Flash memory on the slave RSP card of a router configured for HSA.
slaveram:	NVRAM on a slave RSP card of a router configured for HSA.
slaveslot0:	Source or destination URL of the first PCMCIA card on a slave RSP card of a router configured for HSA.

Table 24 URL Prefix Aliases for Local Writable Storage File Systems (continued)

Alias	Source or Destination
slaveslot1:	Source or destination URL of the second PCMCIA slot on a slave RSP card of a router configured for HSA.
slot0:	Source or destination URL of the first PCMCIA Flash memory card.
slot1:	Source or destination URL of the second PCMCIA Flash memory card.

Command Modes	EXEC

Command History	<table> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>11.3 T</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	11.3 T	This command was introduced.
Release	Modification				
11.3 T	This command was introduced.				

Usage Guidelines	You can enter on the command line all necessary source- and destination-URL information and the username and password to use, or you can enter the copy command and have the router prompt you for any missing information. If you enter information, choose one of the following three options: running-config, startup-config, or a file system alias (see previous tables.) The location of a file system dictates the format of the source or destination URL. The colon is required after the alias. However, earlier commands not requiring a colon remain supported, but are unavailable in context-sensitive help. The entire copying process may take several minutes and differs from protocol to protocol and from network to network. In the alias syntax for ftp:, rcp:, and tftp:, the location is either an IP address or a host name. The filename is specified relative to the directory used for file transfers. This section contains usage guidelines for the following topics: • Understanding Invalid Combinations of Source and Destination • Understanding Character Descriptions • Understanding Partitions • Using rcp • Using FTP • Storing Images on Servers • Copying from a Server to Flash Memory • Verifying Images • Copying a Configuration File from a Server to the Running Configuration • Copying a Configuration File from a Server to the Startup Configuration • Storing the Running or Startup Configuration on a Server • Saving the Running Configuration to the Startup Configuration

- [Using CONFIG_FILE, BOOT, and BOOTLDR Environment Variables](#)
- [Using the Copy Command with the Dual RSP Feature](#)

Understanding Invalid Combinations of Source and Destination

Some invalid combinations of source and destination exist. Specifically, you cannot copy the following:

- From a running configuration to a running configuration
- From a startup configuration to a startup configuration
- From a device to the same device (for example, the **copy flash: flash:** command is invalid)

Understanding Character Descriptions

[Table 25](#) describes the characters that you may see during processing of the **copy** command.

Table 25 *copy Character Descriptions*

Character	Description
!	For network transfers, an exclamation point indicates that the copy process is taking place. Each exclamation point indicates the successful transfer of ten packets (512 bytes each).
.	For network transfers, a period indicates that the copy process timed out. Many periods in a row typically mean that the copy process may fail.
O	For network transfers, an uppercase O indicates that a packet was received out of order and the copy process may fail.
e	For Flash erasures, a lowercase e indicates that a device is being erased.
E	An uppercase E indicates an error. The copy process may fail.
V	A series of uppercase Vs indicates the progress during the verification of the image checksum.

Understanding Partitions

You cannot copy an image or configuration file to a Flash partition from which you are currently running. For example, if partition 1 is running the current system image, copy the configuration file or image to partition 2. Otherwise, the copy operation will fail.

You can identify the available Flash partitions by entering the **show file system EXEC** command.

Using rcp

The rcp protocol requires a client to send a remote username upon each rcp request to a server. When you copy a configuration file or image between the router and a server using rcp, the Cisco IOS software sends the first valid username it encounters in the following sequence:

1. The remote username specified in the **copy** command, if a username is specified.
2. The username set by the **ip rcmd remote-username** global configuration command, if the command is configured.
3. The remote username associated with the current tty (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the router software sends the Telnet username as the remote username.
4. The router host name.

For the `rcp copy` request to process, an account must be defined on the network server for the remote username. If the network administrator of the destination server did not establish an account for the remote username, this command will not run. If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user name as the remote username.

If you are writing to the server, the `rcp` server must be properly configured to accept the `rcp write` request from the user on the router. For UNIX systems, add an entry to the `.rhosts` file for the remote user on the `rcp` server. Suppose the router contains the following configuration lines:

```
hostname Rtr1
ip rcmd remote-username User0
```

If the router IP address translates to `Router1.company.com`, then the `.rhosts` file for `User0` on the `rcp` server should contain the following line:

```
Router1.company.com Rtr1
```

Refer to the documentation for your `rcp` server for more details.

If you are using a personal computer as a file server, the computer must support the remote shell protocol (`rsh`).

Using FTP

The FTP protocol requires a client to send a remote username and password upon each FTP request to a server. When you copy a configuration file from the router to a server using FTP, the Cisco IOS software sends the first valid username that it encounters in the following sequence:

1. The username specified in the **copy** command, if a username is specified.
2. The username set by the **ip ftp username** command, if the command is configured.
3. Anonymous.

The router sends the first valid password in the following list:

1. The password specified in the **copy** command, if a password is specified.
2. The password set by the **ip ftp password** command, if the command is configured.
3. The router forms a password `username@routename.domain`. The variable `username` is the username associated with the current session, `routename` is the configured host name, and `domain` is the domain of the router.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept the FTP write request from the user on the router.

If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user name as the remote username.

Refer to the documentation for your FTP server for more details.

Use the **ip ftp username** and **ip ftp password** global configuration commands to specify a username and password for all copies. Include the username in the **copy** command if you want to specify a username for that copy operation only.

Storing Images on Servers

Use the **copy flash: destination-url** command (for example, **copy flash: tftp:**) to copy a system image or boot image from Flash memory to a network server. Use the copy of the image as a backup copy. Also, use it to verify that the copy in Flash memory is the same as that in the original file.

Copying from a Server to Flash Memory

Use the **copy destination-url flash:** command (for example, **copy tftp: flash:**) to copy an image from a server to Flash memory.

On Class B file system platforms, the system provides an option to erase existing Flash memory before writing onto it.



Note

Verify the image in Flash memory before booting the image.

Verifying Images

When copying a new image to your router, you should confirm that the image was not corrupted during the copy process. Depending on the destination filesystem type, a checksum for the image file may be displayed when the **copy** command completes. You can verify this checksum by comparing it to the checksum value provided for your image file on Cisco.com.



Caution

If the checksum values do not match, do not reboot the router. Instead, reissue the **copy** command and compare the checksums again. If the checksum is repeatedly wrong, copy the original image back into Flash memory *before* you reboot the router from Flash memory. If you have a corrupted image in Flash memory and try to boot from Flash memory, the router will start the system image contained in ROM (assuming booting from a network server is not configured). If ROM does not contain a fully functional system image, the router might not function and will need to be reconfigured through a direct console port connection.

An alternate method for file verification is to use the UNIX 'diff' command. This method can also be applied to file types other than Cisco IOS images. If you suspect that a file is corrupted, copy the suspect file and the original file to a Unix server. (The file names may need to be modified if you try to save the files in the same directory.) Then run the Unix 'diff' command on the two files. If there is no difference, then the file has not been corrupted.

Copying a Configuration File from a Server to the Running Configuration

Use the **copy {ftp: | rcp: | tftp:} running-config** command to load a configuration file from a network server to the running configuration of the router (note that **running-config** is the alias for the **system:running-config** keyword). The configuration will be added to the running configuration as if the commands were typed in the command-line interface (CLI). Thus, the resulting configuration file will be a combination of the previous running configuration and the loaded configuration file, with the loaded configuration file having precedence.

You can copy either a host configuration file or a network configuration file. Accept the default value of *host* to copy and load a host configuration file containing commands that apply to one network server in particular. Enter *network* to copy and load a network configuration file containing commands that apply to all network servers on a network.

Copying a Configuration File from a Server to the Startup Configuration

Use the **copy {ftp: | rcp: | tftp:} nvram:startup-config** command to copy a configuration file from a network server to the router startup configuration. These commands replace the startup configuration file with the copied configuration file.

Storing the Running or Startup Configuration on a Server

Use the **copy system:running-config {ftp: | rcp: | tftp:}** command to copy the current configuration file to a network server using FTP, rcp, or TFTP. Use the **copy nvram:startup-config {ftp: | rcp: | tftp:}** command to copy the startup configuration file to a network server.

The configuration file copy can serve as a backup copy.

Saving the Running Configuration to the Startup Configuration

Use the **copy system:running-config nvram:startup-config** command to copy the running configuration to the startup configuration.



Note

Some specific commands might not get saved to NVRAM. You will need to enter these commands again if you reboot the machine. These commands are noted in the documentation. We recommend that you keep a listing of these settings so you can quickly reconfigure your router after rebooting.

If you issue the **copy system:running-config nvram:startup-config** command from a bootstrap system image, a warning will instruct you to indicate whether you want your previous NVRAM configuration to be overwritten and configuration commands to be lost. This warning does not appear if NVRAM contains an invalid configuration or if the previous configuration in NVRAM was generated by a bootstrap system image.

On all platforms except Class A file system platforms, the **copy system:running-config nvram:startup-config** command copies the currently running configuration to NVRAM.

On the Class A Flash file system platforms, the **copy system:running-config nvram:startup-config** command copies the currently running configuration to the location specified by the CONFIG_FILE environment variable. This variable specifies the device and configuration file used for initialization. When the CONFIG_FILE environment variable points to NVRAM or when this variable does not exist (such as at first-time startup), the software writes the current configuration to NVRAM. If the current configuration is too large for NVRAM, the software displays a message and stops executing the command.

When the CONFIG_FILE environment variable specifies a valid device other than **nvram:** (that is, **flash:**, **bootflash:**, **slot0:**, or **slot1:**), the software writes the current configuration to the specified device and filename, and stores a distilled version of the configuration in NVRAM. A distilled version is one that does not contain access list information. If NVRAM already contains a copy of a complete configuration, the router prompts you to confirm the copy.

Using CONFIG_FILE, BOOT, and BOOTLDR Environment Variables

For the Class A Flash file system platforms, specifications are as follows:

- The CONFIG_FILE environment variable specifies the configuration file used during router initialization.
- The BOOT environment variable specifies a list of bootable images on various devices.
- The BOOT environment variable specifies a list of bootable images on various devices.
- The BOOTLDR environment variable specifies the Flash device and filename containing the rxboot image that ROM uses for booting.

- Cisco 3600 routers do not use a dedicated boot helper image (rxboot), which many other routers use to help with the boot process. Instead, the BOOTLDR ROM monitor environment variable identifies the Flash memory device and filename that are used as the boot helper; the default is the first system image in Flash memory.

To view the contents of environment variables, use the **show bootvar** EXEC command. To modify the CONFIG_FILE environment variable, use the **boot config** global configuration command. To modify the BOOTLDR environment variable, use the **boot bootldr** global configuration command. To modify the BOOT environment variable, use the **boot system** global configuration command. To save your modifications, use the **copy system:running-config nvram:startup-config** command.

When the destination of a **copy** command is specified by the CONFIG_FILE or BOOTLDR environment variable, the router prompts you for confirmation before proceeding with the copy. When the destination is the only valid image in the BOOT environment variable, the router also prompts you for confirmation before proceeding with the copy.

Using the Copy Command with the Dual RSP Feature

The Dual RSP feature allows you to install two Route/Switch Processor (RSP) cards in a single router on the Cisco 7507 and Cisco 7513 platforms.

On a Cisco 7507 or Cisco 7513 router configured for Dual RSPs, if you copy a file to **nvram:startup-configuration** with automatic synchronization disabled, the system asks if you also want to copy the file to the slave startup configuration. The default answer is **yes**. If automatic synchronization is enabled, the system automatically copies the file to the slave startup configuration each time you use a **copy** command with **nvram:startup-configuration** as the destination.

Examples

The following examples illustrate uses of the **copy** command.

- [Copying an Image from a Server to Flash Memory Examples](#)
- [Saving a Copy of an Image on a Server Examples](#)
- [Copying a Configuration File from a Server to the Running Configuration Example](#)
- [Copying a Configuration File from a Server to the Startup Configuration Example](#)
- [Copying the Running Configuration to a Server Example](#)
- [Copying the Startup Configuration to a Server Example](#)
- [Saving the Current Running Configuration Example](#)
- [Moving Configuration Files to Other Locations Examples](#)
- [Copying an Image from the Master RSP Card to the Slave RSP Card Example](#)

Copying an Image from a Server to Flash Memory Examples

The following three examples use a **copy rcp:**, **copy tftp:**, or **copy ftp:** command to copy an image file from a server to Flash memory:

- [Copying an Image from a Server to Flash Memory Example](#)
- [Copying an Image from a Server to a Flash Memory Using Flash Load Helper Example](#)
- [Copying an Image from a Server to a Flash Memory Card Partition Example](#)

Copying an Image from a Server to Flash Memory Example

This example copies a system image named file1 from the remote rcp server with an IP address of 172.16.101.101 to Flash memory. On Class B file system platforms, the Cisco IOS software allows you to first erase the contents of Flash memory to ensure that enough Flash memory is available to accommodate the system image.

```
Router# copy rcp://netadmin@172.16.101.101/file1 flash:file1
```

```
Destination file name [file1]?
Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101 (via Ethernet0): ! [OK]

Erase flash device before writing? [confirm]
Flash contains files. Are you sure you want to erase? [confirm]

Copy 'file1' from server
  as 'file1' into Flash WITH erase? [yes/no] yes
Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee...erased
Loading file1 from 172.16.101.101 (via Ethernet0): !
[OK - 984/8388608 bytes]

Verifying checksum... OK (0x14B3)
Flash copy took 0:00:01 [hh:mm:ss]
```

Copying an Image from a Server to a Flash Memory Using Flash Load Helper Example

The following example copies a system image into a partition of Flash memory. The system will prompt for a partition number only if there are two or more read/write partitions or one read-only and one read/write partition and dual Flash bank support in boot ROMs. If the partition entered is not valid, the process terminates. You can enter a partition number, a question mark (?) for a directory display of all partitions, or a question mark and a number (?number) for directory display of a particular partition. The default is the first read/write partition. In this case, the partition is read-only and has dual Flash bank support in boot ROM, so the system uses Flash Load Helper.

```
Router# copy tftp: flash:
```

```
System flash partition information:
Partition  Size    Used    Free    Bank-Size    State      Copy-Mode
    1      4096K    2048K    2048K    2048K        Read Only  RXBOOT-FLH
    2      4096K    2048K    2048K    2048K        Read/Write  Direct
```

```
[Type ?<no> for partition directory; ? for full directory; q to abort]
Which partition? [default = 2]
```

```
**** NOTICE ****
```

```
Flash load helper v1.0
This process will accept the copy options and then terminate
the current system image to use the ROM based image for the copy.
Routing functionality will not be available during that time.
If you are logged in via telnet, this connection will terminate.
Users with console access can see the results of the copy operation.
```

```
---- ***** ----
```

```
Proceed? [confirm]
System flash directory, partition 1:
File Length Name/status
  1  3459720 master/igs-bfpx.100-4.3
[3459784 bytes used, 734520 available, 4194304 total]
Address or name of remote host [255.255.255.255]? 172.16.1.1
Source file name? master/igs-bfpx-100.4.3
Destination file name [default = source name]?

Loading master/igs-bfpx.100-4.3 from 172.16.1.111: !
```

```
Erase flash device before writing? [confirm]
Flash contains files. Are you sure? [confirm]
Copy 'master/igs-bfpx.100-4.3' from TFTP server
as 'master/igs-bfpx.100-4.3' into Flash WITH erase? [yes/no] yes
```

Copying an Image from a Server to a Flash Memory Card Partition Example

The following example copies the file c3600-i-mz from the rcp server at IP address 172.23.1.129 to the Flash memory card in slot 0 of a Cisco 3600 series router, which has only one partition. As the operation progresses, the Cisco IOS software asks you to erase the files on the Flash memory PC card to accommodate the incoming file. This entire operation takes 18 seconds to perform, as indicated at the end of the example.

```
Router# copy rcp: slot0:
```

PCMCIA Slot0 flash

Partition	Size	Used	Free	Bank-Size	State	Copy Mode
1	4096K	3068K	1027K	4096K	Read/Write	Direct
2	4096K	1671K	2424K	4096K	Read/Write	Direct
3	4096K	0K	4095K	4096K	Read/Write	Direct
4	4096K	3825K	270K	4096K	Read/Write	Direct

```
[Type ?<no> for partition directory; ? for full directory; q to abort]
Which partition? [default = 1]
```

```
PCMCIA Slot0 flash directory, partition 1:
```

File	Length	Name/status

```
1 3142288 c3600-j-mz.test
```

```
[3142352 bytes used, 1051952 available, 4194304 total]
```

```
Address or name of remote host [172.23.1.129]?
```

```
Source file name? /tftpboot/images/c3600-i-mz
```

Destination file name [/tftpboot/images/c3600-i-mz]?

```
Accessing file '/tftpboot/images/c3600-i-mz' on 172.23.1.129...
```

Connected to 172.23.1.129

Loading 1711088 byte file c3600-i-mz: ! [OK]

Erase flash device before writing? [confirm]

```
Flash contains files. Are you sure you want to erase? [confirm]
```

```
Copy '/tftpboot/images/c3600-i-mz' from server
```

```
as '/tftpboot/images/c3600-i-mz' into Flash WITH erase? [yes/no] yes
```

```
Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee ..erased
```

Connected to 172.23.1.129

```
Loading 1711088 byte file c3600-i-mz:
```

[illegible]

```
Verifying checksum... OK (0xF89A)
```

Flash device copy took 00:00:18 [hh:mm:ss]

Saving a Copy of an Image on a Server Examples

The following four examples use **copy** commands to copy image files to a server for storage:

- [Copy an Image from Flash Memory to an rcp Server Example](#)
- [Copy an Image from a Partition of Flash Memory to a Server Example](#)
- [Copying an Image from a Flash Memory File System to an FTP Server Example](#)
- [Copying an Image from Boot Flash Memory to a TFTP Server Example](#)

Copy an Image from Flash Memory to an rcp Server Example

The following example copies a system image from Flash Memory to an rcp server using the default remote username. Because the rcp server address and filename are not included in the command, the router prompts for it.

```
Router# copy flash: rcp:

IP address of remote host [255.255.255.255]? 172.16.13.110
Name of file to copy? gsxx
writing gsxx - copy complete
```

Copy an Image from a Partition of Flash Memory to a Server Example

The following example copies an image from a particular partition of Flash memory to an rcp server using a remote username of netadmin1.

The system will prompt if there are two or more partitions. If the partition entered is not valid, the process terminates. You have the option to enter a partition number, a question mark (?) for a directory display of all partitions, or a question mark and a number (?number) for a directory display of a particular partition. The default is the first partition.

```
Router# configure terminal
Router# ip rcmd remote-username netadmin1
Router# end
Router# copy flash: rcp:
System flash partition information:
Partition  Size    Used    Free    Bank-Size    State        Copy-Mode
    1         4096K    2048K    2048K    2048K        Read Only    RXBOOT-FLH
    2         4096K    2048K    2048K    2048K        Read/Write    Direct
[Type ?<number> for partition directory; ? for full directory; q to abort]
Which partition? [1] 2

System flash directory, partition 2:
File Length  Name/status
    1  3459720  master/igs-bfpx.100-4.3
[3459784 bytes used, 734520 available, 4194304 total]
Address or name of remote host [ABC.CISCO.COM]?
Source file name? master/igs-bfpx.100-4.3
Destination file name [master/igs-bfpx.100-4.3]?
Verifying checksum for 'master/igs-bfpx.100-4.3' (file # 1)... OK
Copy 'master/igs-bfpx.100-4.3' from Flash to server
as 'master/igs-bfpx.100-4.3'? [yes/no] yes
!!!!...
Upload to server done
Flash copy took 0:00:00 [hh:mm:ss]
```

Copying an Image from a Flash Memory File System to an FTP Server Example

The following example copies the file c3600-i-mz from partition 1 of the Flash memory card in slot 0 to an FTP server at IP address 172.23.1.129.

```
Router# show slot0: partition 1
```

```
PCMCIA Slot0 flash directory, partition 1:
File Length Name/status
 1 1711088 c3600-i-mz
[1711152 bytes used, 2483152 available, 4194304 total]
```

```
Router# copy slot0:1:c3600-i-mz ftp://myuser:mypass@172.23.1.129/c3600-i-mz
Verifying checksum for '/tftpboot/cisco_rules/c3600-i-mz' (file # 1)... OK
Copy '/tftpboot/cisco_rules/c3600-i-mz' from Flash to server
  as 'c3700-i-mz'? [yes/no] yes
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Upload to server done
Flash device copy took 00:00:23 [hh:mm:ss]
```

Copying an Image from Boot Flash Memory to a TFTP Server Example

The following example copies an image from boot Flash memory to a TFTP server:

```
Router# copy bootflash:file1 tftp://192.168.117.23/file1
```

```
Verifying checksum for 'file1' (file # 1)... OK
Copy 'file1' from Flash to server
  as 'file1'? [yes/no] y
!!!!...
Upload to server done
Flash copy took 0:00:00 [hh:mm:ss]
```

Copying a Configuration File from a Server to the Running Configuration Example

The following example copies and runs a configuration filename host1-confg from the netadmin1 directory on the remote server with an IP address of 172.16.101.101:

```
Router# copy rcp://netadmin1@172.16.101.101/host1-confg system:running-config
```

```
Configure using host1-confg from 172.16.101.101? [confirm]
Connected to 172.16.101.101
Loading 1112 byte file host1-confg:![OK]
Router#
%SYS-5-CONFIG: Configured from host1-config by rcp from 172.16.101.101
```

Copying a Configuration File from a Server to the Startup Configuration Example

The following example copies a configuration file host2-confg from a remote FTP server to the startup configuration. The IP address is 172.16.101.101, the remote username is netadmin1, and the remote password is ftppass.

```
Router# copy ftp://netadmin1:ftppass@172.16.101.101/host2-confg nvram:startup-config
Configure using rtr2-confg from 172.16.101.101?[confirm]
Connected to 172.16.101.101
Loading 1112 byte file rtr2-confg:![OK]
[OK]
Router#
%SYS-5-CONFIG_NV:Non-volatile store configured from rtr2-config by
FTP from 172.16.101.101
```

Copying the Running Configuration to a Server Example

The following example specifies a remote username of netadmin1. Then it copies the running configuration file named rtr2-confg to the netadmin1 directory on the remote host with an IP address of 172.16.101.101.

```
Router# configure terminal
Router(config)# ip rcmd remote-username netadmin1
Router(config)# end
Router# copy system:running-config rcp:
Remote host[]? 172.16.101.101

Name of configuration file to write [Rtr2-config]?
Write file rtr2-config on host 172.16.101.101?[confirm]
Building configuration...[OK]
Connected to 172.16.101.101
```

Copying the Startup Configuration to a Server Example

The following example copies the startup configuration to a TFTP server:

```
Router# copy nvram:startup-config tftp:

Remote host[]? 172.16.101.101

Name of configuration file to write [rtr2-config]? <cr>
Write file rtr2-config on host 172.16.101.101?[confirm] <cr>
![OK]
```

Saving the Current Running Configuration Example

The following example copies the running configuration to the startup configuration. On a Class A Flash file system platform, this command copies the running configuration to the startup configuration specified by the CONFIG_FILE variable.

```
copy system:running-config nvram:startup-config
```

The following example shows the warning that the system provides if you try to save configuration information from bootstrap into the system:

```
Router(boot)# copy system:running-config nvram:startup-config

Warning: Attempting to overwrite an NVRAM configuration written
by a full system image. This bootstrap software does not support
the full configuration command set. If you perform this command now,
some configuration commands may be lost.
Overwrite the previous NVRAM configuration?[confirm]
```

Enter **no** to escape writing the configuration information to memory.

Moving Configuration Files to Other Locations Examples

On some routers, you can store copies of configuration files on a Flash memory device. Five examples follow.

Copying the Startup Configuration to a Flash Memory Device Example

The following example copies the startup configuration file (specified by the CONFIG_FILE environment variable) to a Flash memory card inserted in slot 0:

```
copy nvram:startup-config slot0:router-config
```

Copying the Running Configuration to a Flash Memory Device Example

The following example copies the running configuration from the router to the Flash memory PC card in slot 0:

```
Router# copy system:running-config slot0:berlin-cfg

Building configuration...
```

78-11740-02

Copying an Image from the Master RSP Card to the Slave RSP Card Example

The following example copies the router-image file from the Flash memory card inserted in slot 1 of the master RSP card to slot 0 of the slave RSP card in the same router:

```
copy slot1:router-image slaveslot0:
```

Related Commands

Command	Description
boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
boot system	Specifies the system image that the router loads at startup.
cd	Changes the default directory or file system.
copy xmodem: flash:	Copies any file from a source to a destination.
copy ymodem: flash:	Copies any file from a source to a destination.
delete	Deletes a file on a Flash memory device.
dir	Displays a list of files on a file system.
erase	Erases a file system.
ip rcmd remote-username	Configures the remote username to be used when requesting a remote copy using rcp.
reload	Reloads the operating system.
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.
show (Flash file system)	Displays the layout and contents of a Flash memory file system.
slave auto-sync config	Turns on automatic synchronization of configuration files for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Backup.
verify bootflash:	Either of the identical verify bootflash: or verify bootflash commands replaces the copy verify bootflash command. Refer to the verify command for more information.

delete

To delete a file from a Flash memory device or NVRAM, use the **delete** EXEC command.

delete *URL* [/force | /recursive]

Syntax Description	<i>URL</i>	IFS URL of the file to be deleted. Include the filesystem prefix, followed by a colon, and, optionally, the name of a file or directory.
	<i>/force</i>	(Optional) Deletes the specified file or directory with prompting you for verification. Note Use this keyword with caution: the system will not ask you to confirm the file deletion.
	<i>/recursive</i>	(Optional) Deletes all files in the specified directory, as well as the directory itself.

Command Modes	EXEC

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines	If you attempt to delete the configuration file or image specified by the CONFIG_FILE or BOOTLDR environment variable, the system prompts you to confirm the deletion. Also, if you attempt to delete the last valid system image specified in the BOOT environment variable, the system prompts you to confirm the deletion.
	When you delete a file in Flash memory, the software simply marks the file as deleted, but it does not erase the file. To later recover a “deleted” file in Flash memory (Class A only), use the undelete EXEC command. You can delete and undelete a file up to 15 times.
	To permanently delete all files marked “deleted” on a linear Flash memory device, use the squeeze EXEC command.

Examples	The following example deletes the file named “test” from the Flash filesystem:

```
Router# delete flash:test
Delete flash:test? [confirm]
```

Related Commands	Command	Description
	cd	Changes the default directory or file system.
	dir	Displays a list of files on a file system.

Command	Description
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.
squeeze	Permanently deletes Flash files by squeezing a Class A Flash file system.
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.

dir

To display a list of files on a file system, use the **dir** EXEC command.

dir [/all] [filesystem:][file-url]

Syntax Description	/all	(Optional) Lists deleted files, undeleted files, and files with errors.
	filesystem:	(Optional) File system or directory containing the files to list, followed by a colon.
	file-url	(Optional) The name of the files to display on a specified device. The files can be of any type. You can use wildcards in the filename. A wildcard character (*) matches all patterns. Strings after a wildcard are ignored.

Defaults The default file system is specified by the **cd** command. When you omit the **/all** keyword, the Cisco IOS software displays only undeleted files.

Command Modes EXEC

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines Use the **show** (Flash file system) command to display more detail about the files in a particular file system.

Examples The following is sample output from the **dir** command:

```
Router# dir slot0:
```

```
Directory of slot0:/
```

```

 1  -rw-      4720148   Aug 29 1997 17:49:36 hampton/nitro/c7200-j-mz
 2  -rw-      4767328   Oct 01 1997 18:42:53 c7200-js-mz
 5  -rw-         639   Oct 02 1997 12:09:32 rally
 7  -rw-         639   Oct 02 1997 12:37:13 the_time
```

```
20578304 bytes total (3104544 bytes free)
```

```
Router# dir /all slot0:
```

```
Directory of slot0:/
```

```

 1  -rw-      4720148   Aug 29 1997 17:49:36 hampton/nitro/c7200-j-mz
 2  -rw-      4767328   Oct 01 1997 18:42:53 c7200-js-mz
 3  -rw-      7982828   Oct 01 1997 18:48:14 [rsp-jsv-mz]
 4  -rw-         639   Oct 02 1997 12:09:17 [the_time]
```

```

5  -rw-          639   Oct 02 1997 12:09:32  rally
6  -rw-          639   Oct 02 1997 12:37:01  [the_time]
7  -rw-          639   Oct 02 1997 12:37:13  the_time

```

Table 26 describes the significant fields shown in the displays.

Table 26 *dir Field Descriptions*

Field	Description
1	Index number of the file.
-rw-	Permissions. The file can be any or all of the following: • d—directory • r—readable • w—writable • x—executable
4720148	Size of the file.
Aug 29 1997 17:49:36	Last modification date.
hampton/nitro/c7200-j-mz	Filename. Deleted files are indicated by square brackets around the filename.

Related Commands

Command	Description
cd	Changes the default directory or file system.
delete	Deletes a file on a Flash memory device.
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.

erase

To erase a file system, use the **erase EXEC** command. The **erase nvram:** command replaces the **write erase** command and the **erase startup-config** command.

erase filesystem:

Syntax Description

<i>filesystem:</i>	File system name, followed by a colon. For example, flash: or nvram:

Command Modes

EXEC

Command History

Release	Modification
11.0	This command was introduced.

Usage Guidelines

When a file system is erased, none of the files in the file system can be recovered.

The **erase** command can be used on both Class B and Class C Flash file systems only. To reclaim space on Flash file systems after deleting files using the **delete** command, you must use the **erase** command. This command erases all of the files in the Flash file system.

Class A Flash file systems cannot be erased. You can delete individual files using the **delete EXEC** command and then reclaim the space using the **squeeze EXEC** command. You can use the **format EXEC** command to format the Flash file system.

On Class C Flash file systems, space is dynamically reclaimed when you use the **delete** command. You can also use either the **format** or **erase** command to reinitialize a Class C Flash file system.

The **erase nvram:** command erases NVRAM. On Class A file system platforms, if the CONFIG_FILE variable specifies a file in Flash memory, the specified file will be marked “deleted.”

Examples

The following example erases the NVRAM, including the startup configuration located there:

```
erase nvram:
```

The following example erases all of partition 2 in internal Flash memory:

```
Router# erase flash:2
```

```
System flash directory, partition 2:
File Length Name/status
 1 1711088 dirt/images/c3600-i-mz
[1711152 bytes used, 15066064 available, 16777216 total]
```

```
Erase flash device, partition 2? [confirm]
Are you sure? [yes/no]: yes
Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee ...erased
```

The following example erases Flash memory when Flash is partitioned, but no partition is specified in the command:

```
Router# erase flash:
```

```
System flash partition information:
```

Partition	Size	Used	Free	Bank-Size	State	Copy-Mode
1	4096K	2048K	2048K	2048K	Read Only	RXBOOT-FLH
2	4096K	2048K	2048K	2048K	Read/Write	Direct

```
[Type ?<no> for partition directory; ? for full directory; q to abort]
Which partition? [default = 2]
```

The system will prompt only if there are two or more read/write partitions. If the partition entered is not valid or is the read-only partition, the process terminates. You can enter a partition number, a question mark (?) for a directory display of all partitions, or a question mark and a number (?*number*) for directory display of a particular partition. The default is the first read/write partition.

```
System flash directory, partition 2:
```

```
File Length Name/status
  1 3459720 master/igs-bfpx.100-4.3
[3459784 bytes used, 734520 available, 4194304 total]
```

```
Erase flash device, partition 2? [confirm] <Return>
```

Related Commands

Command	Description
boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
delete	Deletes a file on a Flash memory device.
more	Displays the startup configuration file contained in NVRAM or specified by the CONFIG_FILE environment variable.
nvramp:startup-config	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.

erase bootflash

The **erase bootflash:** and **erase bootflash** commands have identical functions. See the description of the **erase** command in this chapter for more information.

file prompt

To specify the level of prompting, use the **file prompt** global configuration command.

file prompt [alert | noisy | quiet]

Syntax Description	alert	(Optional) Prompts only for destructive file operations. This is the default.
	noisy	(Optional) Confirms all file operation parameters.
	quiet	(Optional) Seldom prompts for file operations.
Defaults	alert	
Command Modes	Global configuration	
Command History	Release	Modification
	11.0	This command was introduced.
Usage Guidelines	Use this command to change the amount of confirmation needed for different file operations. This command affects only prompts for confirmation of operations. The router will always prompt for missing information.	
Examples	The following example configures confirmation prompting for all file operations: <pre>file prompt noisy</pre>	

format

To format a Class A or Class C Flash file system, use the **format** EXEC command.

Class C Flash File System

format *filesystem1*:

Class A Flash File System

format [*spare spare-number*] *filesystem1*: [[*filesystem2*:][*monlib-filename*]]



Reserve a certain number of memory sectors as spares, so that if some sectors fail, most of the Flash memory card can still be used. Otherwise, you must reformat the Flash card when some of the sectors fail.

Syntax Description

spare	(Optional) Reserves spare sectors as specified by the <i>spare-number</i> argument when formatting Flash memory.
<i>spare-number</i>	(Optional) Number of the spare sectors to reserve on formatted Flash memory. Valid values are from 0 to 16. The default value is zero.
<i>filesystem1</i> :	Flash memory to format, followed by a colon.
<i>filesystem2</i> :	(Optional) File system containing the monlib file to use for formatting filesystem1 followed by a colon.
<i>monlib-filename</i>	(Optional) Name of the ROM monitor library file (monlib file) to use for formatting the <i>filesystem1</i> argument. The default monlib file is the one bundled with the system software. When used with HSA and you do not specify the <i>monlib-filename</i> argument, the system takes ROM monitor library file from the slave image bundle. If you specify the <i>monlib-filename</i> argument, the system assumes that the files reside on the slave devices.

Defaults

The default monlib file is the one bundled with the system software.
The default number of spare sectors is zero (0).

Command Modes

EXEC

Command History

Release	Modification
11.0	This command was introduced.

Usage Guidelines

Use this command to format Class A or C Flash memory file systems.

In some cases, you might need to insert a new PCMCIA Flash memory card and load images or backup configuration files onto it. Before you can use a new Flash memory card, you must format it.

Sectors in Flash memory cards can fail. Reserve certain Flash memory sectors as “spares” by using the optional *spare* argument on the **format** command to specify 0 to 16 sectors as spares. If you reserve a small number of spare sectors for emergencies, you can still use most of the Flash memory card. If you specify 0 spare sectors and some sectors fail, you must reformat the Flash memory card, thereby erasing all existing data.

The monlib file is the ROM monitor library. The ROM monitor uses this file to access files in the Flash file system. The Cisco IOS system software contains a monlib file.

In the command syntax, *filesystem1*: specifies the device to format and *filesystem2*: specifies the optional device containing the monlib file used to format *filesystem1*:. If you omit the optional *filesystem2*: and *monlib-filename* arguments, the system formats *filesystem1*: using the monlib file already bundled with the system software. If you omit only the optional *filesystem2*: argument, the system formats *filesystem1*: using the monlib file from the device you specified with the **cd** command. If you omit only the optional *monlib-filename* argument, the system formats *filesystem1*: using the *filesystem2*: monlib file. When you specify both arguments—*filesystem2*: and *monlib-filename*—the system formats *filesystem1*: using the monlib file from the specified device. You can specify *filesystem1*:’s own monlib file in this argument. If the system cannot find a monlib file, it terminates its formatting.



Caution

You can read from or write to Flash memory cards formatted for Cisco 7000 series Route Processor (RP) cards in your Cisco 7200 and 7500 series routers, but you cannot boot the Cisco 7200 and 7500 series routers from a Flash memory card formatted for the Cisco 7000 series routers. Similarly, you can read from or write to Flash memory cards formatted for the Cisco 7200 and 7500 series routers in your Cisco 7000 series routers, but you cannot boot the Cisco 7000 series routers from a Flash memory card formatted for the Cisco 7200 and 7500 series routers.

Examples

The following example formats a Flash memory card inserted in slot 0:

```
Router# format slot0:
```

```
Running config file on this device, proceed? [confirm]y
All sectors will be erased, proceed? [confirm]y
Enter volume id (up to 31 characters): <Return>
Formatting sector 1 (erasing)
Format device slot0 completed
```

When the console returns to the EXEC prompt, the new Flash memory card is formatted and ready for use.

Related Commands

Command	Description
cd	Changes the default directory or file system.
copy	Copies any file from a source to a destination.
delete	Deletes a file on a Flash memory device.
show file systems (Flash file system)	Lists available file systems.

Command	Description
squeeze	Permanently deletes Flash files by squeezing a Class A Flash file system.
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.

fsck

To check a Class C Flash file system for damage and repair any problems, use the **fsck** EXEC command.

fsck [/nocrc] *filesystem*:

Syntax Description	/nocrc	(Optional) Omits cyclic redundancy checks (CRCs).
	<i>filesystem</i> :	The file system to check.

Command Modes	EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines	This command is only valid on Class C Flash file systems.

Examples	The following example checks the Flash file system:

```
Router# fsck flash:
```

```
Fsck operation may take a while. Continue? [confirm]
flashfs[4]: 0 files, 2 directories
flashfs[4]: 0 orphaned files, 0 orphaned directories
flashfs[4]: Total bytes: 8128000
flashfs[4]: Bytes used: 1024
flashfs[4]: Bytes available: 8126976
flashfs[4]: flashfs fsck took 23 seconds.
Fsck of flash: complete
```

mkdir

To create a new directory in a Class C Flash file system, use the **mkdir** EXEC command.

mkdir *directory*

Syntax Description

<i>directory</i>	The name of the directory to create.

Command Modes

EXEC

Command History

Release	Modification
11.3 AA	This command was introduced.

Usage Guidelines

This command is only valid on Class C Flash file systems.

If you do not specify the directory name in the command line, the router prompts you for it.

Examples

The following example creates a directory named newdir:

```
Router# mkdir newdir

Mkdir file name [newdir]?
Created dir flash:newdir
Router# dir
Directory of flash:

  2  drwx          0   Mar 13 1993 13:16:21  newdir

8128000 bytes total (8126976 bytes free)
```

Related Commands

Command	Description
dir	Displays a list of files on a file system.
rmdir	Removes an existing directory in a Class C Flash file system.

more

To display a file, use the **more** EXEC command.

more [/ascii | /binary | /ebcdic] *file-url*

Syntax Description	/ascii	(Optional) Displays a binary file in ASCII format.
	/binary	(Optional) Displays a file in hex/text format.
	/ebcdic	(Optional) Displays a binary file in EBCDIC format.
	<i>file-url</i>	The URL of the file to display.

Command Modes	EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines

The **more system:running-config** command displays the same output as the **show running-config** command. The **more nvram:startup-config** command replaces the **show startup-config** command and the **show configuration** command.

You can use this command to display configuration files, as follows:

- The **more nvram:startup-config** command displays the startup configuration file contained in NVRAM or specified by the CONFIG_FILE environment variable. The Cisco IOS software informs you whether the displayed configuration is a complete configuration or a distilled version. A distilled configuration is one that does not contain access lists.
- The **more system:running-config** command displays the running configuration.

These commands show the version number of the software used when you last changed the configuration file.

You can display files on remote systems using the **more** command.

Examples

The following partial sample output displays the configuration file named startup-config in NVRAM:

```
Router# more nvram:startup-config

!
! No configuration change since last restart
! NVRAM config last updated at 02:03:26 PDT Thu Oct 2 1997
!
version 12.1
service timestamps debug uptime
service timestamps log uptime
service password-encryption
service udp-small-servers
service tcp-small-servers
.
```

```
.
.
end
```

The following is partial sample output from the **more nvram:startup-config** command when the configuration file has been compressed:

```
Router# more nvram:startup-config
```

```
Using 21542 out of 65536 bytes, uncompressed size = 142085 bytes
!
version 12.1
service compress-config
!
hostname rose
!
.
.
.
```

The following partial sample output displays the running configuration:

```
Router2# more system:running-config
```

```
Building configuration...

Current configuration:
!
version 12.1
no service udp-small-servers
no service tcp-small-servers
!
hostname Router2
!
.
.
.
!
end
```

Related Commands

Command	Description
boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
service compress-config	Compresses startup configuration files.
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.

pwd

To show the current setting of the **cd** command, use the **pwd** EXEC command.

pwd

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines	Use the pwd command to show which directory or file system is specified as the default by the cd command. For all EXEC commands that have an optional <i>filesystem</i> argument, the system uses the file system specified by the cd command when you omit the optional <i>filesystem</i> argument. For example, the dir command contains an optional <i>filesystem</i> argument and displays a list of files on a particular file system. When you omit this <i>filesystem</i> argument, the system shows a list of the files on the file system specified by the cd command.

Examples	The following example shows that the present working file system specified by the cd command is slot 0:

```
Router> pwd
slot0:/
```

The following example uses the **cd** command to change the present file system to slot 1 and then uses the **pwd** command to display that present working file system:

```
Router> cd slot1:
Router> pwd
slot1:/
```

Related Commands	Command	Description
	cd	Changes the default directory or file system.
	dir	Displays a list of files on a file system.

rename

To rename a file in a Class C Flash file system, use the **rename** EXEC command.

rename *url1 url2*

Syntax Description

<i>url1</i>	The original path and filename.
<i>url2</i>	The new path and filename.

Command Modes

EXEC

Command History

Release	Modification
11.3 AA	This command was introduced.

Usage Guidelines

This command is valid only on Class C Flash file systems.

Examples

In the following example, the file named Karen.1 is renamed test:

```
Router# dir

Directory of disk0:/Karen.dir/

 0  -rw-          0   Jan 21 1998 09:51:29  Karen.1
 0  -rw-          0   Jan 21 1998 09:51:29  Karen.2
 0  -rw-          0   Jan 21 1998 09:51:29  Karen.3
 0  -rw-          0   Jan 21 1998 09:51:31  Karen.4
243 -rw-        165   Jan 21 1998 09:53:17  Karen.cur

340492288 bytes total (328400896 bytes free)

Router# rename disk0:Karen.dir/Karen.1 disk0:Karen.dir/test
Router# dir

Directory of disk0:/Karen.dir/

 0  -rw-          0   Jan 21 1998 09:51:29  Karen.2
 0  -rw-          0   Jan 21 1998 09:51:29  Karen.3
 0  -rw-          0   Jan 21 1998 09:51:31  Karen.4
243 -rw-        165   Jan 21 1998 09:53:17  Karen.cur
 0  -rw-          0   Apr 24 1998 09:49:19  test

340492288 bytes total (328384512 bytes free)
```

rmdir

To remove an existing directory in a Class C Flash file system, use the **rmdir** EXEC command.

rmdir *directory*

Syntax Description	<i>directory</i> Directory to delete.

Command Modes	EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines	This command is valid only on Class C Flash file systems.

Examples	The following example deletes the directory named newdir:

```
Router# dir
Directory of flash:
  2  drwx          0   Mar 13 1993 13:16:21  newdir

8128000 bytes total (8126976 bytes free)
Router# rmdir newdir
Rmdir file name [newdir]?
Delete flash:newdir? [confirm]
Removed dir flash:newdir
Router# dir
Directory of flash:

No files in directory

8128000 bytes total (8126976 bytes free)
```

Related Commands	Command	Description
	dir	Displays a list of files on a file system.
	mkdir	Creates a new directory in a Class C Flash file system.

show configuration

The **show configuration** command is replaced by the **show startup-config** and **more nvram:startup-config** commands. See the description of the **show startup-config** and [more](#) commands for more information.

show file descriptors

To display a list of open file descriptors, use the **show file descriptors** EXEC command.

show file descriptors

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines File descriptors are the internal representations of open files. You can use this command to learn if another user has a file open.

Examples The following is sample output from the **show file descriptors** command:

```
Router# show file descriptors
```

```
File Descriptors:
```

FD	Position	Open	PID	Path
0	187392	0001	2	tftp://dirt/hampton/c4000-i-m.a
1	184320	030A	2	flash:c4000-i-m.a

[Table 27](#) describes the significant fields shown in the display.

Table 27 *show file descriptors Field Descriptions*

Field	Description
FD	File descriptor. The file descriptor is a small integer used to specify the file once it has been opened.
Position	Byte offset from the start of the file.
Open	Flags supplied when opening the file.
PID	Process ID of the process that opened the file.
Path	Location of the file.

show file information

To display information about a file, use the **show file information** EXEC command.

show file information *file-url*

Syntax Description	<i>file-url</i>	The URL of the file to display.
Command Modes	EXEC	
Command History	Release	Modification
	11.3 AA	This command was introduced.

Examples

The following is sample output from the **show file information** command:

```
Router# show file information tftp://dirt/hampton/c2500-j-1.a

tftp://dirt/hampton/c2500-j-1.a:
  type is image (a.out) [relocatable, run from flash]
  file size is 8624596 bytes, run size is 9044940 bytes [8512316+112248+420344]
  Foreign image

Router# show file information slot0:c7200-js-mz

slot0:c7200-js-mz:
  type is image (elf) []
  file size is 4770316 bytes, run size is 4935324 bytes
  Runnable image, entry point 0x80008000, run from ram

Router1# show file information nvram:startup-config

nvram:startup-config:
  type is ascii text
```

[Table 28](#) describes the possible file types.

Table 28 *Possible File Types*

Types	Description
image (a.out)	Runnable image in a.out format.
image (elf)	Runnable image in elf format.
ascii text	Configuration file or other text file.
coff	Runnable image in coff format.
ebedic	Text generated on an IBM mainframe.
lzw compression	Lzw compressed file.
tar	Text archive file used by the Channel Interface Processor (CIP).

show file systems

To list available file systems, use the **show file systems** command in EXEC mode.

show file systems

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines Use this command to learn the alias names (Prefixes) of the file systems your router supports.

Examples The following is sample output from the **show file systems** command:

```
Router# show file systems
```

File Systems:

	Size(b)	Free(b)	Type	Flags	Prefixes
	-	-	opaque	rw	null:
	-	-	opaque	rw	system:
	-	-	opaque	ro	xmodem:
	-	-	opaque	ro	ymodem:
	-	-	network	rw	tftp:
	-	-	network	rw	rcp:
	-	-	network	rw	ftp:
*	4194304	4190616	flash	rw	flash:
	131066	129185	nvr	rw	nvr:
	-	-	opaque	wo	lex:

Table 29 describes the significant fields shown in the display.

Table 29 show file systems Field Descriptions

Type	Description
Size(b)	Amount of memory in the file system (in bytes).
Free(b)	Amount of free memory in the file system (in bytes).
Type	Type of file system.
Flags	Permissions for file system.
Prefixes	Alias for file system.
disk	The file system is for a rotating medium.
flash	The file system is for a Flash memory device.

Table 29 *show file systems Field Descriptions (continued)*

Type	Description
network	The file system is a network file system (TFTP, rcp, FTP, and so on).
nvrn	The file system is for an NVRAM device.
opaque	The file system is a locally generated “pseudo” file system (for example, the “system”) or a download interface, such as brimux.
rom	The file system is for a ROM or EPROM device.
tty	The file system is for a collection of terminal devices.
unknown	The file system is of unknown type.

Table 30 describes file system flags.

Table 30 *Possible File System Flags*

Flag	Description
ro	The file system is Read Only.
wo	The file system is Write Only.
rw	The file system is Read/Write.

squeeze

To permanently erase files tagged as “deleted” or “error” on Class A Flash file systems, use the **squeeze** command in EXEC mode.

squeeze [/nolog] [/quiet] *filesystem:*

Syntax Description	/nolog	(Optional) Disables the squeeze log (recovery data) and accelerates the squeeze process.
	/quiet	(Optional) Disables status messages during the squeeze process.
	<i>filesystem:</i>	The Flash file system, followed by a colon. Typically flash: or slot0: .

Command Modes	EXEC

Command History	Release	Modification
	11.1	This command was introduced.
	12.2(1)	This command was implemented in images for the Cisco 2600 and Cisco 3600 series.
	12.2(4)XL	This command was implemented in images for the Cisco 1700 series.
	12.1(9), 12.0(17)S 12.0(17)ST, 12.2(2), 12.2(2)T, 12.2(2)B, 12.1(9)E	The /nolog and /quiet keywords were added.

Usage Guidelines

When Flash memory is full, you might need to rearrange the files so that the space used by the files marked “deleted” can be reclaimed. (This “squeeze” process is required for linear Flash memory cards to make sectors contiguous; the free memory must be in a “block” to be usable.)

When you enter the **squeeze** command, the router copies all valid files to the beginning of Flash memory and erases all files marked “deleted.” After the squeeze process is completed, you can write to the reclaimed Flash memory space.



Caution

After performing the squeeze process you cannot recover deleted files using the **undelete** EXEC mode command.

In addition to removing deleted files, the **squeeze** command removes any files that the system has marked as “error”. An error file is created when a file write fails (for example, the device is full). To remove error files, you must use the **squeeze** command.

Rewriting Flash memory space during the squeeze operation may take several minutes.

Using the **/nolog** keyword disables the log for the squeeze process. In most cases this will speed up the squeeze process. However, if power is lost or the Flash card is removed during the squeeze process, all the data on the Flash card will be lost, and the device will have to be reformatted.

**Note**

Using the **/nolog** keyword makes the squeeze process uninterruptible.

Using the **/quiet** keyword disables the output of status messages to the console during the squeeze process.

If the optional keywords are not used, the progress of squeeze process will be displayed to the console, a log for the process will be maintained, and the squeeze process is interruptible.

On Cisco 2600 or Cisco 3600 series routers, the entire file system needs to be erased once before the **squeeze** command can be used. After being erased once, the **squeeze** command should operate properly on the Flash file system for the rest of the Flash file system's history.

To erase an entire flash file system on a Cisco 2600 or 3600 series router, perform the following steps:

-
- Step 1** If the Flash file system has multiple partitions, enter the **no partition** command to remove the partitions. The reason for removing partitions is to ensure that the entire Flash file system is erased. The **squeeze** command can be used in a Flash file system with partitions after the Flash file system is erased once.
- Step 2** Enter the **erase** command to erase the Flash file system.
-

Examples

In the following example, the file named "config1" is deleted, and then the **squeeze** command is used to reclaim the space used by that file. The **/nolog** option is used to speed up the squeeze process.

```
Router# delete config1
Delete filename [config1]?
Delete slot0:conf? [confirm]
Router# dir slot0:
! Note that the deleted file name appears in square brackets
Directory of slot0:/

   1  -rw-     4300244   Apr 02 2001 03:18:07  c7200-boot-mz.122-0.14
   2  -rw-         2199   Apr 02 2001 04:45:15  [config1]
   3  -rw-     4300244   Apr 02 2001 04:45:23  image
20578304 bytes total (11975232 bytes free)
!20,578,304 - 4,300,244 - 4,300,244 - 2,199 - 385 = 11975232

Router# squeeze /nolog slot0:
%Warning: Using /nolog option would render squeeze operation uninterruptible.
All deleted files will be removed. Continue? [confirm]
Squeeze operation may take a while. Continue? [confirm]

Squeeze of slot0 completed in 291.832 secs .
Router# dir slot0:
Directory of slot0:/

   1  -rw-     4300244   Apr 02 2001 03:18:07  c7200-boot-mz.122-0.14
   2  -rw-     4300244   Apr 02 2001 04:45:23  image

20578304 bytes total (11977560 bytes free)
!20,578,304 - 4,300,244 - 4,300,244 - 256 = 11977560
```

Related Commands

Command	Description
delete	Deletes a file on a Flash memory device.
dir	Displays a list of files on a file system.
undelete	Recovers a file marked “deleted” on a Class A or Class B Flash file system.

undelete

To recover a file marked “deleted” on a Class A Flash file system, use the **undelete** EXEC command.

undelete *index* [*filesystem:*]

Syntax Description

<i>index</i>	A number that indexes the file in the dir command output.
<i>filesystem:</i>	(Optional) A file system containing the file to undelete, followed by a colon.

Defaults

The default file system is the one specified by the **cd** command.

Command Modes

EXEC

Command History

Release	Modification
11.0	This command was introduced for Class A Flash File Systems (platforms include the Cisco 7500 series and Cisco 12000 series).

Usage Guidelines

For Class A Flash file systems, when you delete a file, the Cisco IOS software simply marks the file as deleted, but it does not erase the file. This command allows you to recover a “deleted” file on a specified Flash memory device. You must undelete a file by its index because you could have multiple deleted files with the same name. For example, the “deleted” list could contain multiple configuration files with the name router-config. You undelete by index to indicate which of the many router-config files from the list to undelete. Use the **dir** command to learn the index number of the file you want to undelete.

You cannot undelete a file if a valid (undeleted) file with the same name exists. Instead, you first delete the existing file and then undelete the file you want. For example, if you had an undeleted version of the router-config file and you wanted to use a previous, deleted version instead, you could not simply undelete the previous version by index. You would first delete the existing router-config file and then undelete the previous router-config file by index. You can delete and undelete a file up to 15 times.

On Class A Flash file systems, if you try to recover the configuration file pointed to by the CONFIG_FILE environment variable, the system prompts you to confirm recovery of the file. This prompt reminds you that the CONFIG_FILE environment variable points to an undeleted file. To permanently delete all files marked “deleted” on a Flash memory device, use the **squeeze** EXEC command.

Examples

The following example recovers the deleted file whose index number is 1 to the Flash memory card inserted in slot 0:

```
undelete 1 slot0:
```

Related Commands

Command	Description
delete	Deletes a file on a Flash memory device.
dir	Displays a list of files on a file system.
squeeze	Permanently deletes Flash files by squeezing a Class A Flash file system.

verify

To verify the checksum of a file on a Flash memory file system, use the **verify** EXEC command.

verify *filesystem:[file-url]*

Syntax Description

<i>filesystem:</i>	Flash memory file system containing the files to list, followed by a colon. Standard file system keywords for this command include flash: , bootflash: , and slot0: .
<i>file-url</i>	(Optional) URL of the file to verify. Generally this consists only of the filename(s), but you may also specify directories (file paths), separated by forward-slashes (/). The files can be of any type. You can use wildcards in the filename. A wildcard character (*) matches all patterns. Strings after a wildcard are ignored.

Defaults

The current working device is the default device.

Command Modes

EXEC

Command History

Release	Modification
11.0	This command was introduced.

Usage Guidelines

This command replaces the **copy verify** and **copy verify flash** commands.

Use the **verify** command to verify the checksum of a file before using it.

Each software image that is distributed on disk uses a single checksum for the entire image. This checksum is displayed only when the image is copied into Flash memory; it is not displayed when the image file is copied from one disk to another.

To display the contents of Flash memory, use the **show flash** command. The Flash contents listing does not include the checksum of individual files. To recompute and verify the image checksum after the image has been copied into Flash memory, use the **verify** command.



Note

The verify command only performs a check on the integrity of the file after it has been saved in the file system. It is possible for a corrupt image to be transferred to the router and saved in the file system without detection.

To verify that a Cisco IOS software image was not corrupted while it was transferred to the router, copy the image from where it is stored on your router to a Unix server. Also copy the same image from CCO (Cisco.com) to the same Unix server. (The name may need to be modified if you try to save the image in the same directory as the image that you copied from the router.) Then run a Unix **diff** command on the two Cisco IOS software images. If there is no difference then the image stored on the router has not been corrupted.

Examples

The following example verifies that the file named c7200-js-mz is on the Flash memory card inserted in slot 0:

```
Router# dir slot0:
Directory of slot0:/

 1  -rw-     4720148   Aug 29 1997 17:49:36  hampton/nitro/c7200-j-mz
 2  -rw-     4767328   Oct 01 1997 18:42:53  c7200-js-mz
 5  -rw-         639   Oct 02 1997 12:09:32  rally
 7  -rw-         639   Oct 02 1997 12:37:13  the_time

20578304 bytes total (3104544 bytes free)
tw3-7200-1# verify slot0:
Verify filename []? c7200-js-mz
Verified slot0:
```

The following example also verifies that the file named c7200-js-mz is on the Flash memory card inserted in slot 0:

```
Router# verify slot0:?
slot0:c7200-js-mz slot0:rally slot0:hampton/nitro/c7200-j-mz slot0:the_time

Router# verify slot0:c7200-js-mz
Verified slot0:c7200-js-mz
```

Related Commands

Command	Description
cd	Changes the default directory or file system.
copy	Copies any file from a source to a destination, use the copy EXEC command.
dir	Displays a list of files on a file system.
pwd	Displays the current setting of the cd command.
show file systems	Lists available file systems.


write erase

The **write erase** command is replaced by the **erase nvram:** command. See the description of the **erase** command in this chapter for more information.

write terminal

The **more system:running-config** command replaces the **write terminal** command. See the description of the **more** command in this chapter for more information.

■ write terminal



Configuration File Management Commands

This chapter provides detailed descriptions of commands used to manage configuration files in Cisco IOS Release 12.2. Configuration files contain the set of commands used to customize the function of the Cisco IOS software.

For configuration information and examples, refer to the “Managing Configuration Files” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Flash Memory File System Types

Cisco platforms generally use one of three different Flash memory file system types. Some commands are supported on only one or two file system types. This chapter notes commands that are not supported on all file system types.

Use [Table 31](#) to determine which Flash memory file system type your platform uses.

Table 31 *Flash Memory File System Types*

Type	Platforms
Class A	Cisco 7000 family, Cisco 12000 series routers, LightStream1010 switch
Class B	Cisco 1003, Cisco 1004, Cisco 1005, Cisco 2500 series, Cisco 3600 series, and Cisco 4000 series routers, and Cisco AS5200 access servers
Class C	Cisco MC3810 multiservice concentrators, disk0 of Cisco SC3640 System Controllers

Replaced Commands

Some commands found in this chapter in previous releases of this book have been replaced. Older commands generally continue to provide the same functionality in the current release, but are no longer documented. Support for the older version of these commands may already be removed on your system, or may be removed in a future Cisco IOS software release.

[Table 32](#) maps the old commands to their replacements.

Table 32 Replaced Commands

Old Command	New Command
configure network	copy ftp: [[[/[username[:password]@]location]/directory]/filename] system:running-config
configure overwrite-network	copy ftp: [[[/[username[:password]@]location]/directory]/filename] nvrn:startup-config
copy rcp running-config	copy rcp: [[[/[username@]location]/directory]/filename] system:running-config
copy running-config rcp	copy system:running-config rcp: [[[/[username@]location]/directory]/filename]
copy running-config startup-config	copy system:running-config nvrn:startup-config Note The copy running-config startup-config command has been replaced by the command shown here. However, the copy running-config startup-config command will continue to be supported as a command alias for the copy system:running-config nvrn:startup-config command.
copy running-config tftp	copy system:running-config tftp: [[[/[location]/directory]/filename]
copy tftp running-config	copy tftp: [[[/[location]/directory]/filename] system:running-config
copy tftp startup-config	copy tftp: [[[/[location]/directory]/filename] nvrn:startup-config
erase startup-config	erase nvrn:
show configuration	more nvrn:startup-config
show file	more
show running-config	more system:running-config Note The show running-config command has been replaced by the command shown here. However, the show running-config command will continue to be supported as a command alias for the more system:running-config command.
show startup-config	more nvrn:startup-config Note The show startup-config command has been replaced by the command shown here. However, the show startup-config command will continue to be supported as a command alias for the more nvrn:startup-config command.
write erase	erase nvrn:
write memory	copy running-config startup-config or copy system:running-config nvrn:startup-config

Table 32 *Replaced Commands (continued)*

Old Command	New Command
write network	copy system:running-config ftp:[[/[username[:password]@][location]/directory]/filename]
write terminal	show running-config or more system:running-config

For more information about these command replacements, see the description of the Cisco IOS File System (IFS) in the “Using the Cisco IOS File System” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

boot buffersize

The **boot buffersize** global configuration command no longer functions.

Executing this command has no effect on the system. Using this command will not generate CLI errors; the **boot buffersize** command syntax is still allowed to be entered at the CLI and in configuration files in order to accommodate existing configuration scripts used by customers.

boot config

To specify the device and filename of the configuration file from which the router configures itself during initialization (startup), use the **boot config** global configuration command. This command is only available on Class A file system platforms. To remove the specification, use the **no** form of this command.

boot config *file-system-prefix*:[*directory*/]*filename*

no boot config

Syntax Description	<i>file-system-prefix</i> :	File system, followed by a colon (for example, nvr am:, flash :, or slot0 :).
	<i>directory</i> /	(Optional) File system directory the configuration file is located in, followed by a forward slash (/).
	<i>filename</i>	Name of the configuration file.

Defaults	NVRAM (nvr am:)

Command Modes	Global configuration

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines

This command is only available on Class A file system platforms.

You set the CONFIG_FILE environment variable in the current running memory when you use the **boot config** command. This variable specifies the configuration file used for initialization (startup). The configuration file must be an ASCII file located in either NVRAM or Flash memory.

**Note**

When you use this global configuration command, you affect only the running configuration. You must save the environment variable setting to your startup configuration to place the information under ROM monitor control and to have the environment variable function as expected. Use the **copy system:running-config nvram:startup-config** command to save the environment variable from your running configuration to your startup configuration.

The software displays an error message and does not update the CONFIG_FILE environment variable in the following situations:

- You specify **nvr**am: as the file system, and it contains only a distilled version of the configuration. (A distilled configuration is one that does not contain access lists.)
- You specify a configuration file in the *filename* argument that does not exist or is not valid.

The router uses the NVRAM configuration during initialization when the CONFIG_FILE environment variable does not exist or when it is null (such as at first-time startup). If the software detects a problem with NVRAM or the configuration it contains, the device enters **setup** mode. See the “Setup Command” chapter in this publication for more information on the **setup** command facility.

When you use the **no** form of this command, the router returns to using the default NVRAM configuration file as the startup configuration.

Examples

In the following example, the first line specifies that the router should use the configuration file named router-config located in internal Flash memory to configure itself during initialization. The third line copies the specification to the startup configuration, ensuring that this specification will take effect upon the next reload.

```
Router(config)# boot config flash:router-config
Router(config)# end
Router# copy system:running-config nvram:startup-config
```

The following example instructs a Cisco 7500 series router to use the configuration file named router-config located on the Flash memory card inserted in the second PCMCIA slot of the RSP card during initialization. The third line copies the specification to the startup configuration, ensuring that this specification will take effect upon the next reload.

```
Router (config)# boot config slot1:router-config
Router (config)# end
Router# copy system:running-config nvram:startup-config
```

Related Commands

Command	Description
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.

boot host

To specify the host-specific configuration file to be used at the next system startup, use the **boot host** global configuration command. To restore the host configuration filename to the default, use the **no** form of this command.

```
boot host remote-url

no boot host remote-url
```

Syntax Description	<i>remote-url</i> Location of the configuration file. Use the following syntax: ftp:[[[//[<i>username</i>[:<i>password</i>]]@]<i>location</i>]/<i>directory</i>]/<i>filename</i>] rcp:[[[//[<i>username</i>@]<i>location</i>]/<i>directory</i>]/<i>filename</i>] tftp:[[[//[<i>location</i>]/<i>directory</i>]/<i>filename</i>]

Defaults	If you do not specify a <i>filename</i> using this command, the router uses its configured host name to request a configuration file from a remote server. To form the configuration filename, the router converts its name to all lowercase letters, removes all domain information, and appends <i>-confg</i> or <i>-config</i>.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command instructs the system to “Boot using network configuration file <i>x</i>,” where <i>x</i> is the filename specified in the <i>remote-url</i> argument. This command specifies the remote location and filename of the network configuration file to be used at the next system startup, as well as the protocol to be used to obtain the file. When booting from a network server, routers ignore routing information, static IP routes, and bridging information. As a result, intermediate routers are responsible for handling FTP, rcp, or TFTP requests. Before booting from a network server, verify that a server is available by using the ping command. Use the service config command to enable the loading of the specified configuration file at reboot time. Without this command, the router ignores the boot network command and uses the configuration information in NVRAM. If the configuration information in NVRAM is invalid or missing, the service config command is enabled automatically. The network server will attempt to load two configuration files from remote hosts. The first is the network configuration file containing commands that apply to all network servers on a network. Use the boot network command to identify the network configuration file. The second is the host configuration file containing commands that apply to one network server in particular. Use the boot host command to identify the host configuration file.

**Note**

In releases prior to Cisco IOS Release 12.3(2)T and 12.3(1)B, the **service config** command is used in conjunction with the **boot host** or **boot network** command. To enable the router to automatically configure the system from the file specified by the **boot host** or **boot network** command you must enter the **service config** command.

With Cisco IOS Release 12.3(2)T, 12.3(1)B, and later, you no longer have to specify the **service config** command for the **boot host** or **boot network** command to be active.

If you specify both the **no service config** command and the **boot host** command, the router attempts to find the specified host configuration file.

The **service config** command can also be used without the **boot host** or **boot network** command. If you do not specify host or network configuration filenames, the router uses the default configuration files. The default network configuration file is *network-config*. The default host configuration file is *host-config*, where *host* is the hostname of the router. If the Cisco IOS software cannot resolve its hostname, the default host configuration file is *router-config*.

Loading a Configuration File Using rcp

The rcp software requires that a client send the remote username on each rcp request to the network server. If the server has a directory structure (such as UNIX systems), the rcp implementation searches for the configuration files starting in the directory associated with the remote username.

When you load a configuration file from a server using rcp, the Cisco IOS software sends the first valid username in the following list:

1. The username specified in the file-URL, if a username is specified.
2. The username set by the **ip rcmd remote-username** command, if the command is configured.
3. The router host name.

**Note**

An account for the username must be defined on the destination server. If the network administrator of the destination server did not establish an account for the username, this command will not execute successfully.

Loading a Configuration File Using FTP

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. The username and password must be associated with an account on the FTP server. If the server has a directory structure, the configuration file or image copied from the directory associated with the username on the server. Refer to the documentation for your FTP server for more details.

When you load a configuration file from a server using FTP, the Cisco IOS software sends the first valid username in the following list:

1. The username specified in the **boot host** command, if a username is specified.
2. The username set by the **ip ftp username** command, if the command is configured.
3. Anonymous.

The router sends the first valid password in the following list:

1. The password specified in the **boot host** command, if a password is specified.
2. The password set by the **ip ftp password** command, if the command is configured.

3. The router forms a password username@routename.domain. The variable username is the username associated with the current session, routename is the configured host name, and domain is the domain of the router.

Examples

The following example sets the host filename to wilma-config at address 192.168.7.19:

```
Router(config)# boot host tftp://192.168.7.19/usr/local/tftpddir/wilma-config
Router(config)# service config
```

Related Commands

Command	Description
boot network	Specifies the remote location and filename of the network configuration file to be used at the next system boot (startup).
service config	Enables autoloading of configuration files from a network server.

boot network

To change the default name of the network configuration file from which to load configuration commands, use the **boot network** global configuration command. To restore the network configuration filename to the default, use the **no** form of this command.

boot network *remote-url*

no boot network *remote-url*

Syntax Description	<i>remote-url</i>	Location of the configuration file. Use the following syntax: ftp:[[[//<i>username[:password]@location]/directory]/filename]</i> rcp:[[[//<i>username@location]/directory]/filename]</i> tftp:[[[//<i>location]/directory]/filename]</i>

Defaults	The default filename is network-config.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command instructs the system to “Boot using network configuration file <i>x</i>,” where <i>x</i> is the filename specified in the <i>remote-url</i> argument. This command specifies the remote location and filename of the network configuration file to be used at the next system startup, as well as the protocol to be used to obtain the file. When booting from a network server, routers ignore routing information, static IP routes, and bridging information. As a result, intermediate routers are responsible for handling FTP, rcp, or TFTP requests. Before booting from a network server, verify that a server is available by using the ping command. Use the service config command to enable the loading of the specified configuration file at reboot time. Without this command, the router ignores the boot network command and uses the configuration information in NVRAM. If the configuration information in NVRAM is invalid or missing, the service config command is enabled automatically. The network server will attempt to load two configuration files from remote hosts. The first is the network configuration file containing commands that apply to all network servers on a network. Use the boot network command to identify the network configuration file. The second is the host configuration file containing commands that apply to one network server in particular. Use the boot host command to identify the host configuration file.

**Note**

In releases prior to Cisco IOS Release 12.3(2)T and 12.3(1)B, the **service config** command is used in conjunction with the **boot host** or **boot network** command. To enable the router to automatically configure the system from the file specified by the **boot host** or **boot network** command you must enter the **service config** command.

With Cisco IOS Release 12.3(2)T, 12.3(1)B, and later, you no longer have to specify the **service config** command for the **boot host** or **boot network** command to be active.

If you specify both the **no service config** command and the **boot host** command, the router attempts to find the specified host configuration file.

The **service config** command can also be used without the **boot host** or **boot network** command. If you do not specify host or network configuration filenames, the router uses the default configuration files. The default network configuration file is *network-conf*. The default host configuration file is *host-conf*, where *host* is the hostname of the router. If the Cisco IOS software cannot resolve its hostname, the default host configuration file is *router-conf*.

Loading a Configuration File Using rcp

The rcp software requires that a client send the remote username on each rcp request to the network server. If the server has a directory structure (such as UNIX systems), the rcp implementation searches for the configuration files starting in the directory associated with the remote username.

When you load a configuration file from a server using rcp, the Cisco IOS software sends the first valid username in the following list:

1. The username specified in the file-URL, if a username is specified.
2. The username set by the **ip rcmd remote-username** command, if the command is configured.
3. The router host name.

**Note**

An account for the username must be defined on the destination server. If the network administrator of the destination server did not establish an account for the username, this command will not execute successfully.

Loading a Configuration File Using FTP

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. The username and password must be associated with an account on the FTP server. If the server has a directory structure, the configuration file or image copied from the directory associated with the username on the server. Refer to the documentation for your FTP server for more details.

When you load a configuration file from a server using FTP, the Cisco IOS software sends the first valid username in the following list:

1. The username specified in the **boot network** command, if a username is specified.
2. The username set by the **ip ftp username** command, if the command is configured.
3. Anonymous.

The router sends the first valid password in the following list:

1. The password specified in the **boot network** command, if a password is specified.
2. The password set by the **ip ftp password** command, if the command is configured.

3. The router forms a password username@routename.domain. The variable username is the username associated with the current session, routename is the configured host name, and domain is the domain of the router.

Examples

The following example changes the network configuration filename to bridge_9.1 and uses the default broadcast address:

```
Router(config)# boot network tftp:bridge_9.1
Router(config)# service config
```

The following example changes the network configuration filename to bridge_9.1, specifies that rcp is to be used as the transport mechanism, and gives 172.16.1.111 as the IP address of the server on which the network configuration file resides:

```
Router(config)# service config
Router(config)# boot network rcp://172.16.1.111/bridge_9.1
```

Related Commands

Command	Description
boot host	Specifies the remote location and filename of the host-specific configuration file to be used at the next system boot (startup).
service config	Enables autoloading of configuration files from a remote host.

clear parser cache

To clear the parse cache entries and hit/miss statistics stored for the Parser Cache feature, use the **clear parser cache** command in privileged EXEC mode.

clear parser cache

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	Privileged EXEC

Command History	Release	Modification
	12.1(5)T	This command was introduced.

Usage Guidelines	The Parser Cache feature optimizes the parsing (translation and execution) of Cisco IOS software configuration command lines by remembering how to parse recently encountered command lines, decreasing the time required to process large configuration files.
	The clear parser cache command will free the system memory used by the Parser Cache feature and will erase the hit/miss statistics stored for the output of the show parser statistics EXEC command. This command is only effective when the Parser Cache feature is enabled.

Examples	The following example shows the clearing of the parser cache:
	<pre>Router# show parser statistics Last configuration file parsed:Number of Commands:1484, Time:820 ms Parser cache:enabled, 1460 hits, 26 misses Router# clear parser cache Router# show parser statistics Last configuration file parsed:Number of Commands:1484, Time:820 ms Parser cache:enabled, 0 hits, 1 misses</pre>

Related Commands	Command	Description
	parser cache	Enables or disables the Parser Cache feature.
	show parser statistics	Displays statistics about the last configuration file parsed and the status of the Parser Cache feature.

configure terminal

To enter global configuration mode or to configure the system from the system memory, use the **configure terminal** privileged EXEC command.

configure terminal

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

Use this command to enter global configuration mode. Note that commands in this mode are written to the running configuration file as soon as you enter them (using the Enter key or Carriage Return).

After you enter the **configure** command, the system prompt changes from <router-name># to <router-name>(config)#, indicating that the router is in global configuration mode. To leave global configuration mode and return to the privileged EXEC prompt, type **end** or press **Ctrl-Z**.

To view the changes to the configuration you have made, use the **more system:running-config** command or **show running-config** command in EXEC mode.

Examples

In the following example, the user enters global configuration mode:

```
Router# configure
```

Configuring from terminal, memory, or network [terminal]?**terminal**
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#

Related Commands	Command	Description
	boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
	copy system:running-config nvram:startup-config	Saves the running configuration as the startup configuration file.
	more system:running-config	Displays the currently running configuration.

configure memory

To configure the system from the system memory, use the **configure memory** privileged EXEC command.

configure memory

Syntax Description	This command has no arguments or keywords.

Command Modes	Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	On all platforms except Class A Flash file system platforms, this command executes the commands located in the configuration file in NVRAM (the “startup configuration file”). On Class A Flash file system platforms, if you specify the configure memory command, the router executes the commands pointed to by the CONFIG_FILE environment variable. The CONFIG_FILE environment variable specifies the location of the configuration file that the router uses to configure itself during initialization. The file can be located in NVRAM or any of the Flash file systems supported by the platform. When the CONFIG_FILE environment variable specifies NVRAM, the router executes the NVRAM configuration only if it is an entire configuration, not a distilled version. A distilled configuration is one that does not contain access lists. To view the contents of the CONFIG_FILE environment variable, use the show bootvar EXEC command. To modify the CONFIG_FILE environment variable, use the boot config command and then save your changes by issuing the copy system:running-config nvram:startup-config command. After you enter the configure terminal command, the system prompt changes from <router-name># to <router-name>(config)#, indicating that the router is in global configuration mode. To leave global configuration mode and return to the privileged EXEC prompt, use the end command.

Examples	In the following example, a router is configured from the configuration file in the memory location pointed to by the CONFIG_FILE environment variable:

```
Router# configure memory
```

Related Commands	Command	Description
	boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).

Command	Description
copy system:running-config nvram:startup-config	Saves the running configuration as the startup configuration file.
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.

configure overwrite-network

The **configure overwrite-network** has been replaced by the **copy** *{ftp-url | rcp-url | tftp-url}* **nvrn:startup-config** command. See the description of the **copy** command in the [“Cisco IOS File System Commands”](#) chapter for more information.

parser cache

To reenable the Cisco IOS software parser cache after disabling it, use the **parser cache** global configuration command. To disable the parser cache, use the **no** form of this command.

parser cache

no parser cache

Syntax Description This command has no arguments or keywords.

Defaults Parser cache is enabled by default.

Command Modes Global configuration

Command History	Release	Modification
	12.1(5)T	This command was introduced.

Usage Guidelines

The Parser Cache feature optimizes the parsing (translation and execution) of Cisco IOS software configuration command lines by remembering how to parse recently encountered command lines, decreasing the time required to process large configuration files.

The parser cache is enabled by default. However, if you wish to disable the parser cache, you may do so using the **no parser cache** command in global configuration mode. To reenable the parser cache after it has been disabled, use the **parser cache** command.

When the **no parser cache** is issued, the command line appears in the running configuration file. However, if the parser cache is reenabled, no command line appears in the running configuration file.

Examples

In the following example, the Cisco IOS software Parser Cache feature is disabled:

```
Router(config)# no parser cache
```

Related Commands	Command	Description
	clear parser cache	Clears the parse cache entries and hit/miss statistics stored for the Parser Cache feature.
	show parser statistics	Displays statistics about the last configuration file parsed and the status of the Parser Cache feature.

service compress-config

To compress startup configuration files, use the **service compress-config** global configuration command. To disable compression, use the **no** form of this command.

service compress-config

no service compress-config

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	After you configure the service compress-config command, the router will compress configuration files every time you save a configuration to the startup configuration. For example, when you enter the copy system:running-config nvram:startup-config command, the running configuration will be compressed before storage in NVRAM.

If the file compression succeeds, the following message is displayed:

```
Compressing configuration from configuration-size to compressed-size
[OK]
```

If the boot ROMs do not recognize a compressed configuration, the following message is displayed:

```
Boot ROMs do not support NVRAM compression Config NOT written to NVRAM
```

If the file compression fails, the following message is displayed:

```
Error trying to compress nvram
```

One way to determine whether a configuration file will be compressed enough to fit into NVRAM is to use a text editor to enter the configuration, then use the UNIX **compress** command to check the compressed size. To get a closer approximation of the compression ratio, use the UNIX **compress -b12** command.

Once the configuration file has been compressed, the router functions normally. At boot time, the system recognizes that the configuration file is compressed, uncompresses it, and proceeds normally. A **partition nvram:startup-config** command uncompresses the configuration before displaying it.

To disable compression of the configuration file, enter configuration mode and specify the **no service compress-config** command. Then, exit global configuration mode and enter the **copy system:running-config nvram:startup-config** command. The router displays an OK message if it is

able to write the uncompressed configuration to NVRAM. Otherwise, the router displays an error message indicating that the configuration is too large to store. If the configuration file is larger than the physical NVRAM, the following message is displayed:

```
##Configuration too large to fit uncompressed in NVRAM Truncate configuration? [confirm]
```

When the file is truncated, commands at the end of the file are erased. Therefore, you will lose part of your configuration. To truncate and save the configuration, type **Y**. To not truncate and not save the configuration, type **N**.

Examples

In the following example, the configuration file is compressed:

```
Router# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)# service compress-config
Router(config)# end
Router#
%SYS-5-CONFIG_I: Configured from console by console
Router# copy system:running-config nvram:startup-config
Building configuration...
Compressing configuration from 1179 bytes to 674 bytes
[OK]
```

Related Commands

Command	Description
partition nvram:startup-config	Separates Flash memory into partitions on Class B file system platforms.

service config

To enable autoloading of configuration files from a network server, use the **service config** global configuration command. To restore the default, use the **no** form of this command.

service config

no service config

Syntax Description

This command has no arguments or keywords.

Defaults

Disabled, except on systems without NVRAM or with invalid or incomplete information in NVRAM. In these cases, autoloading of configuration files from a network server is enabled automatically.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Usually, the **service config** command is used in conjunction with the **boot host** or **boot network** command. You must enter the **service config** command to enable the router to automatically configure the system from the file specified by the **boot host** or **boot network** command.

With IOS software versions 12.3(2)T, 12.3(1)B, and later, you no longer have to specify the **service config** command for the **boot host** or **boot network** command to be active.

If you specify both the **no service config** command and the **boot host** command, the router attempts to find the specified host configuration file. The **service config** command can also be used without the **boot host** or **boot network** command. If you do not specify host or network configuration filenames, the router uses the default configuration files. The default network configuration file is network-config. The default host configuration file is host-config, where host is the hostname of the router. If the Cisco IOS software cannot resolve its hostname, the default host configuration file is router-config.

Examples

In the following example, a router is configured to autoload the default network and host configuration files. Because no **boot host** or **boot network** commands are specified, the router uses the broadcast address to request the files from a TFTP server.

```
Router(config)# service config
```

The following example changes the network configuration filename to bridge_9.1, specifies that rcp is to be used as the transport mechanism, and gives 172.16.1.111 as the IP address of the server on which the network configuration file resides:

```
Router(config)# service config
Router(config)# boot network rcp://172.16.1.111/bridge_9.1
```

Related Commands

Command	Description
boot host	Changes the default name of the host configuration filename from which to load configuration commands.
boot network	Changes the default name of the network configuration file from which to load configuration commands.

show configuration

The **show configuration** command has been replaced by the **show startup-config** and **more nvram:startup-config** commands. See the description of the **more** command in the “Cisco IOS File System Commands” chapter for more information.

show derived-config

To display the composite results of all the configuration commands that apply to an interface, including commands that come from sources such as static templates, dynamic templates, dialer interfaces, and authentication, authorization, and accounting (AAA) per-user attributes, use the **show derived-config** command in privileged EXEC mode.

```
show derived-config [interface type number]
```

Syntax Description	interface type number (Optional) Displays the derived configuration for a specific interface. If you use the interface keyword, you must specify the interface type and the interface number (for example, interface ethernet 0).

Command Modes	Privileged EXEC

Command History	Release	Modification
	12.1	This command was introduced.

Usage Guidelines

Configuration commands can be applied to an interface from sources such as static templates, dynamic templates bound by resource pooling, dialer interfaces, AAA per-user attributes and the configuration of the physical interface. The **show derived-config** command displays all the commands that apply to an interface.

The output for the **show derived-config** command is nearly identical to that of the **show running-config** command. It differs when the configuration for an interface is derived from a template, a dialer interface, or some per-user configuration. In those cases, the commands derived from the template, dialer interface, and so on, will be displayed for the affected interface.

If the same command is configured differently in two different sources that apply to the same interface, the command coming from the source that has the highest precedence will appear in the display.

Examples

The following examples show sample output for the **show running-config** and **show derived-config** commands for serial interface 0:23 and dialer interface 0. The output of the **show running-config** and **show derived-config** commands is the same for dialer interface 0 because none of the commands that apply to that interface are derived from any sources other than the configuration of the dialer interface. The output for the **show running-config** and **show derived-config** commands for serial interface 0:23 differs because some of the commands that apply to serial interface 0:23 come from dialer interface 0.

```
Router# show running-config interface Serial0:23

Building configuration...

Current configuration :296 bytes
!
interface Serial0:23
 description PRI to ADTRAN (#4444150)
 ip unnumbered Loopback0
 encapsulation ppp
```

```
dialer rotary-group 0
isdn switch-type primary-dms100
isdn incoming-voice modem
isdn calling-number 4444150
peer default ip address pool old_pool
end
```

Router# **show running-config interface Dialer0**

Building configuration...

```
Current configuration :257 bytes
!
interface Dialer0
  description Dialin Users
  ip unnumbered Loopback0
  no ip proxy-arp
  encapsulation ppp
  dialer in-band
  dialer idle-timeout 30
  dialer-group 1
  peer default ip address pool new_pool
  ppp authentication pap chap callin
end
```

Router# **show derived-config interface Serial0:23**

Building configuration...

```
Derived configuration :332 bytes
!
interface Serial0:23
  description PRI to ADTRAN (#4444150)
  ip unnumbered Loopback0
  encapsulation ppp
  dialer rotary-group 0
  isdn switch-type primary-dms100
  isdn incoming-voice modem
  isdn calling-number 4444150
  peer default ip address pool new_pool
  ppp authentication pap chap callin
end
```

Router# **show derived-config interface Dialer0**

Building configuration...

```
Derived configuration :257 bytes
!
interface Dialer0
  description Dialin Users
  ip unnumbered Loopback0
  no ip proxy-arp
  encapsulation ppp
  dialer in-band
  dialer idle-timeout 30
  dialer-group 1
  peer default ip address pool new_pool
  ppp authentication pap chap callin
end
```

■ show derived-config

Related Commands

Command	Description
show running-config	Displays the contents of the currently running configuration file or the configuration for a specific interface.

show file

The **show file** command has been replaced by the **more** command. See the description of the [more](#) command in the “[Cisco IOS File System Commands](#)” chapter for more information.

show parser statistics

To displays statistics about the last configuration file parsed and the status of the Parser Cache feature, use the show parser statistics command in privileged EXEC mode.

show parser statistics

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.1(5)T	This command was introduced.

Usage Guidelines The **show parser statistics** command displays two sets of data:

- The number of commands in the configuration file that was last copied into the running configuration, and the time it took for the system to parse them (a configuration file can be loaded into the running configuration at system startup, or by issuing commands such as the **copy source running-config** command).
- The status of the Parser Cache feature (enabled or disabled) and the number of command matches (indicated by hits/misses) since the system was started or since the parser cache was cleared.

The Parser Cache feature optimizes the parsing (translation and execution) of Cisco IOS software configuration command lines by remembering how to parse recently encountered command lines, decreasing the time required to process large configuration files.

Examples The following example shows sample output from the **show parser statistics** command:

```
Router# show parser statistics

Last configuration file parsed: Number of Commands: 1484, Time: 1272 ms

Parser cache: disabled, 0 hits, 2 misses
```

In this example, the Parser Cache feature is disabled, but shows the hit/miss statistics for the two commands issued while the parser cache was last enabled.

Table 33 describes the key output fields:

Table 33 *show parser statistics Output Fields*

Last configuration file parsed:	Displays statistics on the last configuration file copied into the running configuration (at startup or using the copy command).
Number of commands:	The number of command lines in the last configuration file parsed.
Time:	Time (in milliseconds) taken for the system to load the last configuration file.
Parser cache:	Displays whether the Parser Cache feature is enabled or disabled, and the hit/miss statistics related to the feature. Statistics are stored since the initialization of the system, or since the last time the parser cache was cleared.
hits	Number of commands the parser cache was able to parse more efficiently by matching them to similar commands executed previously.
misses	Number of commands the parser cache was unable to match to previously executed commands. The performance enhancement provided by the Parser Cache feature cannot be applied to unmatched commands.

In the following example the **show parser statistics** command is used to compare the parse-time of a large configuration file with the Parser Cache feature disabled and enabled. In this example, a configuration file with 1484 access list commands is loaded into the running configuration.

```
Router# configure terminal
!parser cache is disabled
Router(config)# no parser cache
!configuration file is loaded into the running configuration
Router# copy slot0:acl_list running-config
. . .
Router# show parser statistics
Last configuration file parsed: Number of Commands:1484, Time:1272 ms

Parser cache:disabled, 0 hits, 2 misses

!the parser cache is reenabled
Router(config)# parser cache
!configuration file is loaded into the running configuration
Router# copy slot0:acl_list running-config
. . .
Router# show parser statistics
Last configuration file parsed: Number of Commands:1484, Time:820 ms

Parser cache:enabled, 1460 hits, 26 misses
```

These results show an improvement to the load time for the same configuration file from 1272 milliseconds (ms) to 820 ms when the Parser Cache feature was enabled. As indicated in the “hits” field of the **show** command output, 1460 commands were able to be parsed more efficiently by the parser cache.

show parser statistics

Related Commands

Command	Description
clear parser cache	Clears the parse cache entries and hit/miss statistics stored for the Parser Cache feature.
parser cache	Enables or disables the Parser Cache feature.

show running-config

To display the contents of the currently running configuration file or the configuration for a specific class map, interface, map class, policy map, or virtual circuit (VC) class, use the **show running-config** command in privileged EXEC mode.

show running-config [*options*]

Syntax Description	<i>options</i> (Optional) One of the following options can be entered with the command: • brief—Displays the configuration without certification data. • class-map name—Displays class map information. The linenum keyword can be used with the class-map name option. • full—Displays the full configuration. • interface type number—Displays interface-specific configuration information. If you use the interface keyword, you must specify the interface type and the interface number (for example, interface ethernet 0). Common interfaces include async, ethernet, fastEthernet, group-async, loopback, null, serial, and virtual-template. Use the show run interface ? command to determine the interfaces available on your system. • linenum—Displays line numbers in the output. The brief or full keyword can be used with the linenum keyword. • map-class—Displays map class information. This option is described separately; see the show running-config map-class command page. • policy-map name—Displays policy map information. The linenum keyword can be used with the policy-map name option. • vc-class name—Displays VC class information (display available only on limited routers such as the Cisco 7500 series). The linenum keyword can be used with the vc-class name option. • —Allows addition of output modifiers and is available with all the keywords for this command.						
Defaults	The show running-config command without any arguments or keywords displays the entire contents of the running configuration file.						
Command Modes	Privileged EXEC						
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.0</td><td>This command was introduced.</td></tr><tr><td>12.0</td><td>This command was replaced by the more system:running-config command.</td></tr></table>	Release	Modification	11.0	This command was introduced.	12.0	This command was replaced by the more system:running-config command.
Release	Modification						
11.0	This command was introduced.						
12.0	This command was replaced by the more system:running-config command.						

12.0(1)T	The output modifier (l) was added.
12.2(4)T	The linenum keyword was added.

Usage Guidelines

The **show running-config** command is technically a command alias of the **more system:running-config** command. Although **more** commands are recommended (due to their uniform structure across platforms and their expandable syntax), the **show running-config** command remains enabled to accommodate its widespread use, and to allow typing shortcuts such as **show run**.

The **show running-config interface** command is useful when there are multiple interfaces and you want to look at the configuration of a specific interface.

The **linenum** keyword causes line numbers to be displayed in the output. This option is useful for identifying a particular portion of a very large configuration.

Examples

The following example shows the configuration for serial interface 1:

```
Router# show running-config interface serial 1
```

```
Building configuration...
```

```
Current configuration:
```

```
!
interface Serial1
 no ip address
 no ip directed-broadcast
 no ip route-cache
 no ip mroute-cache
 shutdown
end
```

The following example shows the configuration for Ethernet interface 0/0. Line numbers are displayed in the output.

```
Router# show running-config interface ethernet 0/0 linenum
```

```
Building configuration...
```

```
Current configuration : 104 bytes
```

```
1 : !
2 : interface Ethernet0/0
3 : ip address 10.4.2.63 255.255.255.0
4 : no ip route-cache
5 : no ip mroute-cache
6 : end
```

The following example shows how to set line numbers in the command output, and then use the output modifier to start the display at line 10:

```
Router# show running-config linenum | begin 10
```

```
10 : boot-start-marker
11 : boot-end-marker
12 : !
13 : no logging buffered
14 : enable password #####
15 : !
16 : spe 1/0 1/7
17 : firmware location bootflash:mica-modem-pw.2.7.1.0.bin
```

```

18 : !
19 : !
20 : resource-pool disable
21 : !
22 : no aaa new-model
23 : ip subnet-zero
24 : ip domain name cisco.com
25 : ip name-server 172.16.11.48
26 : ip name-server 172.16.2.133
27 : !
28 : !
29 : isdn switch-type primary-5ess
30 : !
.
.
.
126 : end

```

Related Commands

Command	Description
boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
configure terminal	Enters global configuration mode.
copy running-config startup-config	Copies the running configuration to the startup configuration. (Command alias for the copy system:running-config nvram:startup-config command.)
show running-config map-class	Displays only map-class configuration information from the running configuration file.
show startup-config	Displays the contents of NVRAM (if present and valid) or displays the configuration file pointed to by the CONFIG_FILE environment variable. (Command alias for the more:nvram startup-config command.)

show running-config map-class

To display only map-class configuration information from the running configuration file, use the **show running-config map-class** privileged EXEC command.

```
show running-config map-class [atm [map-class-name] | dialer [map-class-name]| frame-relay [map-class-name]]
```

Syntax Description	atm	(Optional) Displays only ATM map-class configuration lines.
	dialer	(Optional) Displays only dialer map-class configuration lines.
	frame-relay	(Optional) Displays only Frame Relay map-class configuration lines.
	map-class-name	(Optional) Displays only configuration lines for the specified map-class.

Defaults Displays all map-class configuration in the running configuration file.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.1	The map-class extension to the show running-config command was introduced to show only lines pertaining to dialer or Frame Relay map classes.
	12.1(2)T	The atm , dialer , and frame-relay keywords and <i>map-class-name</i> argument were introduced.

Usage Guidelines Use the **show running-config map-class** command to display the following information from the running configuration file:

- All map classes configured on the router .
- Map classes configured specifically for ATM, Frame Relay, or dialer .
- A specific ATM, Frame Relay, or dialer map class.

Examples The following output examples assume that a user has configured 2 Frame Relay map classes named "cir60" and "cir70," 1 ATM map class named "vc100," and 1 dialer map class named "dialer1."

All Map Classes Configured on the Router Example

```
Router# show running-config map-class

Building configuration...
Current configuration:
!
map-class frame-relay cir60
  frame-relay bc 16000
  frame-relay adaptive-shaping becn
```

```
!  
map-class frame-relay cir70  
  no frame-relay adaptive-shaping  
  frame-relay priority-group 2  
!  
map-class atm vc100  
  atm aal5mux  
!  
map-class dialer dialer1  
  dialer idle-timeout 10  
end
```

All Frame Relay Map Classes Example

Router# **show running-config map-class frame-relay**

```
Building configuration...  
Current configuration:  
!  
map-class frame-relay cir60  
  frame-relay bc 16000  
  frame-relay adaptive-shaping becn  
!  
map-class frame-relay cir70  
  no frame-relay adaptive-shaping  
  frame-relay priority-group 2  
end
```

A Specific Map Class Example

Router# **show running-config map-class frame-relay cir60**

```
Building configuration...  
Current configuration:  
!  
map-class frame-relay cir60  
  frame-relay bc 16000  
  frame-relay adaptive-shaping becn  
end
```

Related Commands

Command	Description
map-class atm	Specifies the ATM map class for an SVC.
map-class dialer	Defines a class of shared configuration parameters associated with the dialer map command for outgoing calls from an ISDN interface and for PPP callback.
map-class frame-relay	Specifies a map class to define QoS values for a Frame Relay VC.
more system:running-config	Displays contents of the currently running configuration file (equivalent to the show running-config command.)

show startup-config

To display the contents of the configuration file that will be used at the next system startup, use the **show startup-config** or **more nvram:startup-config** command in Privileged EXEC mode.

```
show startup-config [l {begin | exclude | include} string]
```

Syntax Description	begin <i>string</i>	(Optional) Begin the output from the first line to match the specified string. The pipe () is required.
	exclude <i>string</i>	(Optional) Exclude from the output any line that matches the specified string. The pipe () is required.
	include <i>string</i>	(Optional) Displays only lines that match the specified string. The pipe () is required.

Defaults None.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.0	This command was introduced.


Usage Guidelines

The **show startup-config** command displays the contents of NVRAM (if present and valid) or displays the configuration file pointed to by the CONFIG_FILE environment variable.

As with all **show** commands, you can specify the output you are interested in more precisely using the pipe (|) option combined with the **begin**, **include**, and **exclude** keywords. For more information on these options, see the documentation of the **more begin**, **more exclude**, **more include**, **show begin**, **show exclude**, and **show include** commands.

In Cisco IOS Release 12.0 the **show startup-config** command was deprecated in favor of the **more nvram:startup-config** command. Although **more** commands are recommended (due to their uniform structure across platforms and their expandable syntax), the **show startup-config** command remains enabled to accommodate its widespread use, and to allow typing shortcuts such as **show start**.

Related Commands	Command	Description
	boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
	copy running-config startup-config	Copies the running configuration to the startup configuration. (Command alias for the copy system:running-config nvram:startup-config command.)



System Image and Microcode Commands

This chapter provides detailed descriptions of the commands used to load and copy system images and microcode images. System images contain the system software. Microcode images contain microcode to be downloaded to various hardware devices.

For configuration information and examples, refer to the “Loading and Maintaining System Images” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Flash Memory File System Types

Cisco platforms generally use one of three different Flash memory file system types. Some commands in this chapter are supported on only one or two file system types.

Use [Table 34](#) to determine which Flash memory file system type your platform uses.

Table 34 *Flash Memory File System Types*

Type	Platforms
Class A	Cisco 7000 family, Cisco 12000 series routers, LightStream LS1010 switches
Class B	Cisco 1003, Cisco 1004, Cisco 1005, Cisco 2500 series, Cisco 3600 series, and Cisco 4000 series routers, and Cisco AS5200 access servers
Class C	Cisco MC3810 multiservice concentrators, disk0 of Cisco SC3640 system controllers

Replaced Commands

Some commands found in this chapter in previous releases of this book have been replaced. Older commands generally continue to provide the same functionality in the current release, but are no longer documented. Support for the older version of these commands may already be removed on your system, or may be removed in a future Cisco IOS software release.

[Table 35](#) maps the old commands to their replacements.

Table 35 *Replaced Commands*

Old Command	New Command
copy erase flash	erase flash: (Class B Flash file systems only) format (Class A and C Flash file systems only)
copy verify	verify
copy verify bootflash	verify bootflash:
copy verify flash	verify flash:
copy xmodem	xmodem
copy ymodem	xmodem -y
show flh-log	more flh: logfile
verify bootflash	verify bootflash:
verify flash	verify flash:

For a description of the **copy** and **verify** commands, see the “[Cisco IOS File System Commands](#)” chapter.

copy erase flash

The **copy erase flash** command has been replaced by the **erase flash:**command. See the description of the **erase** command in the “Cisco IOS File System Commands” chapter for more information.

copy verify

The **copy verify** command has been replaced by the **verify** command. See the description of the [verify](#) command in the “Cisco IOS File System Commands” chapter for more information.

copy verify bootflash

The **copy verify bootflash** command has been replaced by the **verify bootflash:** command. See the description of the [verify](#) command in the “Cisco IOS File System Commands” chapter for more information.

copy verify flash

The **copy verify flash** command has been replaced the **verify flash:** command. See the description of the [verify](#) command in the “Cisco IOS File System Commands” chapter for more information.

copy xmodem:

To copy a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Xmodem protocol, use the **copy xmodem:** EXEC command.

copy xmodem: *flash-filesystem:*

Syntax Description	<i>flash-filesystem:</i> Destination of the copied file, followed by a colon.	
Command Modes	EXEC	
Command History	Release	Modification
	11.2 P	This command was introduced.
Usage Guidelines	This command is a form of the copy command. The copy xmodem: and copy xmodem commands are identical. See the description of the copy command for more information. Copying a file using FTP, rcp, or TFTP is much faster than copying a file using Xmodem. Use the copy xmodem: command only if you do not have access to an FTP, TFTP, or rcp server. This copy operation is performed through the console or AUX port. The AUX port, which supports hardware flow control, is recommended. No output is displayed on the port over which the transfer is occurring. You can use the logging buffered command to log all router messages sent to the console port during the file transfer.	
Examples	The following example initiates a file transfer from a local or remote computer to the router's internal Flash memory using the Xmodem protocol: <pre>copy xmodem: flash:</pre>	
Related Commands	Command	Description
	copy copy ymodem:	Copies any file from a source to a destination. Copies a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Ymodem protocol.

copy ymodem:

To copy a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Ymodem protocol, use the **copy ymodem:** EXEC command.

copy ymodem: *flash-filesystem:*

Syntax Description	<i>flash-filesystem:</i> Destination of the copied file, followed by a colon.	
Command Modes	EXEC	
Command History	Release	Modification
	11.2 P	This command was introduced.
Usage Guidelines	The copy ymodem: and copy ymodem commands are identical. See the description of the copy command for more information. Copying a file using FTP, rcp, or TFTP is much faster than copying a file using Ymodem. Use the copy ymodem: command only if you do not have access to an FTP, rcp, or TFTP server. This copy operation is performed through the console or AUX port. The AUX port, which supports hardware flow control, is recommended. No output is displayed on the port over which the transfer is occurring. You can use the logging buffered command to log all router messages sent to the console port during the file transfer.	
Examples	The following example initiates a file transfer from a local or remote computer to the router's internal Flash memory using the Ymodem protocol: <pre>copy ymodem: flash:</pre>	
Related Commands	Command	Description
	copy xmodem:	Copies a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Xmodem protocol.

erase flash:

The **erase flash:** and **erase flash** commands are identical. See the description of the **erase** command in the “Cisco IOS File System Commands” chapter for more information.

microcode (7000/7500)

To specify the location of the microcode that you want to download from Flash memory into the writable control store (WCS) on Cisco 7000 series (including RSP based routers) or Cisco 7500 series routers, use the **microcode** global configuration command. To load the microcode bundled with the system image, use the **no** form of this command.

```
microcode interface-type {flash-filesystem:filename [slot] | rom | system [slot]}

no microcode interface-type {flash-filesystem:filename [slot] | rom | system [slot]}
```

Syntax Description	interface-type One of the following interface processor names: aip, cip, eip, feip, fip, fsip, hip, mip, sip, sp, ssp, trip, vip, or vip2.
	flash-filesystem: Flash file system, followed by a colon. Valid file systems are bootflash, slot0, and slot1. Slave devices such as slaveslot0 are invalid. The slave’s file system is not available during microcode reloads.
	filename Name of the microcode file.
	slot (Optional) Number of the slot. Range is from 0 to 15.
	rom If ROM is specified, the router loads from the onboard ROM microcode.
	system If the system keyword is specified, the router loads the microcode from the microcode bundled into the system image you are running for that interface type.

Defaults

The default is to load from the microcode bundled in the system image.

Command Modes

Global configuration

Command History	Release Modification
	10.3 This command was introduced.

Usage Guidelines

If you do not use the **microcode reload** command after using the **microcode** command, the **microcode reload** command will be written to the configuration file automatically.

When using Dual RSPs for simple hardware backup, ensure that the master and slave RSP card contain the same microcode image in the same location when the router is to load the interface processor microcode from a Flash file system. Thus, if the slave RSP becomes the master, it will be able to find the microcode image and download it to the interface processor.

Examples

In the following example, all FIP cards will be loaded with the microcode found in Flash memory file fip.v141-7 when the system is booted, when a card is inserted or removed, or when the **microcode reload** global configuration command is issued. The configuration is then written to the startup configuration file.


```
Router(config)# microcode fip slot0:fip.v141-7
Router(config)# end
Router# copy system:running-config nvram:startup-config
```

Related Commands

Command	Description
more fh:logfile	Displays the system console output generated during the Flash load helper operation.

microcode (7200)

To configure a default override for the microcode that is downloaded to the hardware on a Cisco 7200 series router, use the **microcode** global configuration command. To revert to the default microcode for the current running version of the Cisco IOS software, use the **no** form of this command.

microcode {**ecpa** | **pcpa**} *location*

no microcode {**ecpa** | **pcpa**}

Syntax Description

ecpa	ESCON Channel Port Adapter (CPA) interface.
pcpa	Parallel CPA interface.
<i>location</i>	Location of microcode, including the device and filename.

Defaults

If the default or **no** form of the command is specified, the driver uses the default microcode for the current running version of the Cisco IOS software.

Command Modes

Global configuration

Command History

Release	Modification
11.3(3)T	This command was introduced.

Usage Guidelines

If there are any default overrides when the configuration is written, then the **microcode reload** command will be written to the configuration automatically. This action enables the configured microcode to be downloaded at system startup.

The CPA microcode image is preloaded on Flash memory cards for Cisco 7200-series routers for Cisco IOS Release 11.3(3)T and later releases. You may be required to copy a new image to Flash memory when a new microcode image becomes available.

For more information on the CPA configuration and maintenance, refer to the “Configuring Cisco Mainframe Channel Connection Adapters” chapter in the Release 12.2 *Cisco IOS Bridging and IBM Networking Configuration Guide*.

Examples

The following example instructs the Cisco IOS software to load the microcode from an individual microcode image that is stored as a file on the Flash card inserted in Flash card slot 0:

```
microcode ecpa slot0:xcpa26-1
```

Related Commands	Command	Description
	microcode reload (7200)	Resets and reloads the specified hardware in a Cisco 7200 series router.
	show microcode	Displays microcode information.

microcode (12000)

To load a Cisco IOS software image on a line card from Flash memory or the GRP card on a Cisco 12000 series Gigabit Switch Router (GSR), use the **microcode** global configuration command. To load the microcode bundled with the GRP system image, use the **no** form of this command.

microcode {**oc12-atm** | **oc12-pos** | **oc3-pos4**} [**flash** *file-id* [*slot*] | **system** [*slot*]]

no microcode {**oc12-atm** | **oc12-pos** | **oc3-pos4**} [**flash** *file-id* [*slot*] | **system** [*slot*]]

Syntax Description

oc12-atm oc12-pos oc3-pos4	Interface name.
flash	Loads the image from the Flash file system.
<i>file-id</i>	Specifies the device and filename of the image file to download from Flash memory. A colon (:) must separate the device and filename (for example, slot0:gsr-p-mz). Valid devices include: • bootflash:—Internal Flash memory. • slot0:—First PCMCIA slot. • slot1:—Second PCMCIA slot.
<i>slot</i>	(Optional) Slot number of the line card that you want to copy the software image to. Slot numbers range from 0 to 11 for the Cisco 12012 router and 0 to 7 for the Cisco 12008 router. If you do not specify a slot number, the Cisco IOS software image is downloaded on all line cards.
system	Loads the image from the software image on the GRP card.

Defaults

The default is to load the image from the GRP card (**system**).

Command Modes

Global configuration

Command History

Release	Modification
11.2 GS	This command was introduced for Cisco 12000 series GSRs.

Usage Guidelines

In addition to the Cisco IOS image that resides on the GRP card, each line card on a Cisco 12000 series has a Cisco IOS image. When the router is reloaded, the specified image is loaded onto the GRP card and then automatically downloaded to all the line cards.

Normally, you want the same Cisco IOS image on the GRP card and all line cards. However, if you want to upgrade a line card with a new version of microcode for testing or to fix a defect, you might need to load a Cisco IOS image that is different from the one on the line card. Additionally, you might need to load a new image on the line card to work around a problem that is affecting only one of the line cards.

To load a Cisco IOS image on a line card, first use the **copy tftp** command to download the Cisco IOS image to a slot on one of the PCMCIA Flash memory cards. Then use the **microcode** command to download the image to the line card, followed by the **microcode reload** command to start the image. Immediately after you enter the **microcode reload** command and press Return, the system reloads all microcode. Global configuration mode remains enabled. After the reloading is complete, enter the **exit** command to return to the EXEC system prompt.

To verify that the correct image is running on the line card, use the **execute-on slot *slot* show version** command.

For additional information on GSR configuration, refer to the documentation specific to your Cisco IOS software release.

Examples

In the following example, the Cisco IOS software image in slot 0 is downloaded to the line card in slot 10. This software image is used when the system is booted, a line card is inserted or removed, or the **microcode reload** global configuration command is issued.

```
microcode oc3-POS-4 flash slot0:fp.v141-7 10
microcode reload 10
```

In this example, the user would issue the **execute-on slot 10 show version** command to verify that the correct version is loaded.

Related Commands

Command	Description
microcode reload (12000)	Reloads microcode on Cisco 12000 series GSRs.

microcode reload (7000/7500)

To reload the processor card on the Cisco 7000 series with RSP7000 or Cisco 7500 series routers, use the **microcode reload** global configuration command.

microcode reload

Syntax Description This command has no arguments or keywords.

Defaults No default behaviors or values.

Command Modes Global configuration

Command History	Release	Modification
	10.3	This command was introduced for Cisco 7500 series routers.

Usage Guidelines This command reloads the microcode without rebooting the router. Immediately after you enter the **microcode reload** command and press Return, the system reloads all microcode. Global configuration mode remains enabled.



Note

If you modify the system configuration to load a microcode image, the **microcode reload** command will be written to the configuration file automatically following the use of a **microcode** command. This action enables the configured microcode to be downloaded at system startup.

Examples In the following example, all controllers are reset, and the microcode specified in the current configuration is loaded:

```
microcode reload
```

Related Commands	Command	Description
	microcode (7000/7500)	Specifies the location from where microcode should be loaded when the microcode reload command is executed on RSP-based routers.

microcode reload (7200)

To reload the Cisco IOS microcode image on an ESCON CPA card in the Cisco 7200 series router, use the **microcode reload** command in privileged EXEC configuration mode.

microcode reload {**all** | **ecpa** [slot *slot#*] | **pcpa** [slot *slot#*]}

Syntax Description

all	Resets and reloads all hardware types that support downloadable microcode.
ecpa	Resets and reloads only those slots that contain hardware type ecpa .
pcpa	Resets and reloads only those slots that contain hardware type pcpa .
slot <i>slot#</i>	(Optional) Resets and reloads only the slot specified, and only if it contains the hardware specified.

Defaults

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.3(3)T	This command was introduced.

Usage Guidelines

Hardware types that do not support downloadable microcode are unaffected by the **microcode reload all** command.

You will be prompted for confirmation before the **microcode reload** command is executed.

Examples

The following example reloads the ESCON CPA microcode in slot 5 with the currently configured microcode:

```
microcode reload ecpa slot 5
```

Related Commands

Command	Description
microcode (7200)	Configures a default override for the microcode that is downloaded to the hardware on a Cisco 7200 series router.
show microcode	Displays the microcode bundled into a Cisco 7000 series with RSP7000, Cisco 7200 series, or Cisco 7500 series router.

microcode reload (12000)

To reload the Cisco IOS image from a line card on Cisco 12000 series routers, use the **microcode reload** global configuration command.

microcode reload [*slot-number*]

Syntax Description

<i>slot-number</i>	(Optional) Slot number of the line card that you want to reload the Cisco IOS software image on. Slot numbers range from 0 to 11 for the Cisco 12012 and from 0 to 7 for the Cisco 12008 router. If you do not specify a slot number, the Cisco IOS software image is reloaded on all line cards.

Command Modes

Global configuration

Command History

Release	Modification
11.2 GS	This command was introduced for Cisco 12000 series GSRs.

Usage Guidelines

In addition to the Cisco IOS image that resides on the GRP card, each line card on Cisco 12000 series routers has a Cisco IOS image. When the router is reloaded, the specified Cisco IOS image is loaded onto the GRP card and automatically downloaded to all the line cards.

Normally, you want the same Cisco IOS image on the GRP card and all line cards. However, if you want to upgrade a line card with a new version of microcode for testing or to fix a defect, you might need to load a different Cisco IOS image. Additionally, you might need to load a new image on the line card to work around a problem affecting only one of the line cards.

To load a Cisco IOS image on a line card, first use the **copy tftp** command to download the Cisco IOS image to a slot on one of the PCMCIA Flash memory cards. Then use the **microcode** command to download the image to the line card, followed by the **microcode reload** command to start the image. To verify that the correct image is running on the line card, use the **execute-on slot slot show version** command.

For additional information on GSR configuration, refer to the “Observing System Startup and Performing a Basic Configuration” chapter in the Cisco 12000 series installation and configuration guides.

The **microcode reload** (12000) command allows you to issue another command immediately.



Note

Issuing a **microcode reload** command on any of the line cards in a Cisco 12000 GSR immediately returns the console command prompt. This allows you to issue a subsequent command immediately to the reloading line card. However, any commands entered at this time will not execute, and often no indication will be given that such a command failed to run. Verify that the microcode has reloaded before issuing new commands.

Examples

In the following example, the Cisco IOS software is reloaded on the line card in slot 10:

```
microcode reload 10
```

Related Commands

Command	Description
microcode (12000)	Loads a Cisco IOS software image on a line card from Flash memory or the GRP card on a Cisco 12000 series GSR.

more flh:logfile

To view the system console output generated during the Flash load helper operation, use the **more flh:logfile** privileged EXEC command.

more flh:logfile

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines If you are a remote Telnet user performing the Flash upgrade without a console connection, this command allows you to retrieve console output when your Telnet connection has terminated due to the switch to the ROM image. The output indicates what happened during the download, and is particularly useful if the download fails.

This command is a form of the **more** command. See the **more** command for more information.

Examples The following is sample output from the **more flh:logfile** command:

```
Router# more flh:logfile

%FLH: abc/igs-kf.914 from 172.16.1.111 to flash...

System flash directory:
File Length Name/status
  1  2251320 abc/igs-kf.914

[2251384 bytes used, 1942920 available, 4194304 total]
Accessing file 'abc/igs-kf.914' on 172.16.1.111...
Loading from 172.16.13.111:

Erasing device..... erased
Loading from 172.16.13.111:
- [OK -
2251320/4194304 bytes]

Verifying checksum... OK (0x97FA)
Flash copy took 79292 msec
%FLH: Re-booting system after download
Loading abc/igs-kf.914 at 0x3000040, size = 2251320 bytes [OK]

F3: 2183364+67924+259584 at 0x3000060
```

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134

Cisco Internetwork Operating System Software
Cisco IOS (tm) GS Software (GS7), Version 11.0
Copyright (c) 1986-1995 by cisco Systems, Inc.
Compiled Tue 06-Dec-94 14:01 by smith
Image text-base: 0x00001000, data-base: 0x005A9C94

cisco 2500 (68030) processor (revision 0x00) with 4092K/2048K bytes of memory.
Processor board serial number 00000000
DDN X.25 software, Version 2.0, NET2 and BFE compliant.
ISDN software, Version 1.0.
Bridging software.
Enterprise software set supported. (0x0)
1 Ethernet/IEEE 802.3 interface.
2 Serial network interfaces.
--More--

1 ISDN Basic Rate interface.
32K bytes of non-volatile configuration memory.

4096K bytes of processor board System flash (Read ONLY)

Related Commands

Command	Description
more	Displays a file.

show flh-log

The **show flh-log** command has been replaced by the **more flh:logfile** command. See the description of the [more flh:logfile](#) command in this chapter for more information.

show microcode

To display microcode image information available on line cards, use the **show microcode EXEC** command.

show microcode

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples The following is sample output from the **show microcode** command:

```
Router# show microcode
```

```
Microcode bundled in system
```

Card Type	Microcode Version	Target Hardware Version	Description
SP	2.3	11.x	SP version 2.3
EIP	1.1	1.x	EIP version 1.1
TRIP	1.2	1.x	TRIP version 1.2
FIP	1.4	2.x	FIP version 1.4
HIP	1.1	1.x	HIP version 1.1
SIP	1.1	1.x	SIP version 1.1
FSIP	1.1	1.x	FSIP version 1.1

In the following example for the Cisco 7200 series router, the output from the **show microcode** command lists the hardware types that support microcode download. For each type, the default microcode image name is displayed. If there is a configured default override, that name also is displayed.

```
router# show microcode
```

```
Microcode images for downloadable hardware
```

HW Type	Microcode image names
ecpa	default slot0:xcpa26-0 configured slot0:xcpa26-2
pcpa	default slot0:xcpa26-4

 show microcode

Related Commands	Command	Description
	microcode (7000/7500)	Specifies where microcode should be loaded from on Cisco 7500/7000RSP routers.
	microcode (7200)	Configures a default override for the microcode that is downloaded to the hardware on a Cisco 7200 series router.

xmodem

To copy a Cisco IOS image to a router using the ROM monitor and the Xmodem or Ymodem protocol, use the **xmodem** ROM monitor command.

xmodem [-c] [-y] [-e] [-f] [-r] [-x] [-s *data-rate*] [*filename*]

Syntax Description	
-c	(Optional) CRC-16 checksumming, which is more sophisticated and thorough than standard checksumming.
-y	(Optional) Uses the Ymodem protocol for higher throughput.
-e	(Optional) Erases the first partition in Flash memory before starting the download. This option is only valid for the Cisco 1600 series.
-f	(Optional) Erases all of Flash memory before starting the download. This option is only valid for the Cisco 1600 series.
-r	(Optional) Downloads the file to DRAM. The default is Flash memory.
-x	(Optional) Do not execute Cisco IOS image on completion of the download.
-s <i>data-rate</i>	(Optional) Sets the console port's data rate during file transfer. Values are 1200, 2400, 4800, 9600, 19200, 38400, and 115200 bps . The default rate is specified in the configuration register. This option is only valid for the Cisco 1600 series.
<i>filename</i>	(Optional) Filename to copy. This argument is ignored when the -r keyword is specified, because only one file can be copied to DRAM. On the Cisco 1600 series routers, files are loaded to the ROM for execution.

Defaults Xmodem protocol with 8-bit CRC, file downloaded into Flash memory and executed on completion.

Command Modes ROM monitor

Command History	Release	Modification
	11.2 P	This command was introduced.

Usage Guidelines The Cisco 3600 series routers does not support XBOOT functionality. If your Cisco IOS image is erased or damaged, you cannot load a new image over the network.

Use the **xmodem** ROM monitor command to download a new system image to your router from a local personal computer (such as a PC, Mac, or UNIX workstation), or a remote computer over a modem connection, to the router's console port. The computer must have a terminal emulation application that supports these protocols.

Cisco 3600 Series Routers

Your router must have enough DRAM to hold the file being transferred, even if you are copying to Flash memory. The image is copied to the first file in internal Flash memory. Any existing files in Flash memory are erased. There is no support for partitions or copying as a second file.

Cisco 1600 Series Routers

If you include the **-r** option, your router must have enough DRAM to hold the file being transferred. To run from Flash, an image must be positioned as the first file in Flash memory. If you are copying a new image to boot from Flash, erase all existing files first.



A modem connection from the telephone network to your console port introduces security issues that you should consider before enabling the connection. For example, remote users can dial in to your modem and access the router's configuration settings.



If the file to be downloaded is not a valid router image, the copy operation is automatically terminated.

Examples

The following example uses the **xmodem -c filename** ROM monitor command to copy the file named new-ios-image from a remote or local computer:


```
rommon > xmodem -c new-ios-image

Do not start the sending program yet...
      File size      Checksum  File name
1738244 bytes (0x1a8604)  0xdd25  george-admin/c3600-i-mz

WARNING: All existing data in bootflash will be lost!
Invoke this application only for disaster recovery.
Do you wish to continue? y/n  [n]:  yes
Ready to receive file new-ios-image ...
```

Related Commands

Command	Description
copy xmodem:	Copies a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Xmodem protocol.
copy ymodem:	Copies a Cisco IOS image from a local or remote computer (such as a PC, Macintosh, or UNIX workstation) to Flash memory on a Cisco 3600 series router using the Ymodem protocol.



Router Memory Commands

This chapter provides detailed descriptions of the commands used to maintain router memory.

For configuration information and examples, refer to the “Maintaining Router Memory” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Flash Memory File System Types

Cisco platforms generally use one of three different Flash memory file system type. Some commands are supported on only one or two file system types.

Use [Table 36](#) to determine which Flash memory file system type your platform uses.

Table 36 *Flash Memory File System Types*

Type	Platforms
Class A	Cisco 7000 family, Cisco 12000 series, LightStream LS1010 series
Class B	Cisco 1003, Cisco 1004, Cisco 1005, Cisco 2500 series, Cisco 3600 series, Cisco 4000 series, Cisco AS5200 access servers
Class C	Cisco MC3810 multiservice concentrators; disk0 and disk1 of Cisco SC3640 system controllers

memory scan

To enable the Memory Scan feature on a Cisco 7500 series router, use the **memory scan** command. To restore the router configuration to the default, use the **no** form of this command.

memory scan

no memory scan

Syntax Description	This command has no arguments or keywords.

Defaults	This command is disabled by default.

Command Modes	Global configuration

Command History	Release	Modification
	12.0(4)XE	This command was introduced.
	12.0(7)T	This command was integrated in Cisco IOS Release 12.0 T.

Usage Guidelines	The Memory Scan feature adds a low-priority background process that searches all installed dynamic random-access memory (DRAM) for possible parity errors. If errors are found in memory areas that are not in use, this feature attempts to scrub (remove) the errors. The time to complete one memory scan and scrub cycle can range from 10 minutes to several hours, depending on the amount of installed memory. The impact of the Memory Scan feature on the central processing unit (CPU) is minimal. To view the status of the memory scan feature on your router, use the show memory scan command in EXEC mode.

Examples	The following example enables the Memory Scan feature on a Cisco 7500 series router:

```
Router(config)# memory scan
```

Related Commands	Command	Description
	show memory scan	Displays the number and type of parity errors on your system (Cisco 7500 series only).

memory-size iomem

To reallocate the percentage of DRAM to use for I/O memory and processor memory on Cisco 3600 series routers, use the **memory-size iomem** global configuration command. To revert to the default memory allocation, use the **no** form of this command.

memory-size iomem *i/o-memory-percentage*

no memory-size iomem *i/o-memory-percentage*

Syntax Description

<i>i/o-memory-percentage</i>	The percentage of DRAM allocated to I/O memory. The values permitted are 10, 15, 20, 25, 30, 40, and 50 . A minimum of 4 MB of memory is required for I/O memory.

Defaults

The default memory allocation is 25 percent I/O memory and 75 percent processor memory.



Note

If the **smartinit** process has been enabled, the default memory allocation of 25% to I/O does not apply. Instead, **smartinit** examines the network modules and then calculates the I/O memory required.

Command Modes

Global configuration

Command History

Release	Modification
11.2 P	This command was introduced.

Usage Guidelines

When you specify the percentage of I/O memory in the command line, processor memory automatically acquires the remaining percentage of DRAM memory.

Examples

The following example allocates 40 percent of the DRAM memory to I/O memory and the remaining 60 percent to processor memory:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# memory-size iomem 40
Router(config)# exit
Router# copy system:running-config nvram:startup-config
Building configuration...
[OK]

Router# reload

rommon 1 > boot
program load complete, entry point: 0x80008000, size: 0x32ea24
```

Self decompressing the image :

```
#####  
#####  
##### [OK]
```

partition

To separate Flash memory into partitions on Class B file system platforms, use the **partition** global configuration command. To undo partitioning and to restore Flash memory to one partition, use the **no** form of this command.

Cisco 1600 Series and Cisco 3600 Series Routers

partition *flash-filesystem:* [*number-of-partitions*][*partition-size*]

no partition *flash-filesystem:*

All Other Class B Platforms

partition flash *partitions* [*size1 size2*]

no partition flash

Syntax Description

<i>flash-filesystem:</i>	One of the following Flash file systems, which must be followed by a colon (:). The Cisco 1600 series can only use the flash: keyword. • flash:—Internal Flash memory • slot0:—Flash memory card in PCMCIA slot 0 • slot1:—Flash memory card in PCMCIA slot 1
<i>number-of-partitions</i>	(Optional) Number of partitions in Flash memory.
<i>partition-size</i>	(Optional) Size of each partition. The number of partition size entries must be equal to the number of specified partitions.
<i>partitions</i>	Number of partitions in Flash memory. Can be 1 or 2.
<i>size1</i>	(Optional) Size of the first partition (in megabytes).
<i>size2</i>	(Optional) Size of the second partition (in megabytes).

Defaults

Flash memory consists of one partition.

If the partition size is not specified, partitions of equal size are created.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

For the Cisco 1600 series and Cisco 3600 series routers, to undo partitioning, use the **partition** *flash-filesystem:1* or **no partition flash-filesystem:** command. For other Class B platforms, use either the **partition flash 1** or **no partition flash** command. If there are files in a partition other than the first, you must use the **erase** *flash-filesystem:partition-number* command to erase the partition before reverting to a single partition.

When creating two partitions, you must not truncate a file or cause a file to spill over into the second partition.

Examples

The following example creates two partitions of 4 MB each in Flash memory:

```
Router(config)# partition flash 2 4 4
```

The following example divides the Flash memory card in slot 0 into two partitions, each 8 MB in size on a Cisco 3600 series router:

```
Router(config)# partition slot0: 2 8 8
```

The following example creates four partitions of equal size in the card on a Cisco 1600 series router:

```
Router(config)# partition flash: 4
```

show (Flash file system)

To display the layout and contents of a Flash memory file system, use the **show EXEC** command.

Class A Flash File Systems

show flash-filesystem: [**all** | **chips** | **filesys**]

Class B Flash File Systems

show flash-filesystem: [**partition number**] [**all** | **chips** | **detailed** | **err** | **summary**]

Class C Flash File Systems

show flash-filesystem:

Syntax Description	
<i>flash-filesystem:</i>	Flash memory file system (bootflash: , flash: , slot0: , slot1: , slavebootflash: , slaveslot0: , or slaveslot1:), followed by a colon.
all	(Optional) On Class B Flash file systems, all keyword displays complete information about Flash memory, including information about the individual ROM devices in Flash memory and the names and sizes of all system image files stored in Flash memory, including those that are invalid. On Class A Flash file systems, the all keyword displays the following information: • The information displayed when no keywords are used. • The information displayed by the filesys keyword. • The information displayed by the chips keyword.
chips	(Optional) Displays information per partition and per chip, including which bank the chip is in, plus its code, size, and name.
filesys	(Optional) Displays the Device Info Block, the Status Info, and the Usage Info.
partition number	(Optional) Displays output for the specified partition number. If you do not specify a partition in the command, the router displays output for all partitions. You can use this keyword only when Flash memory has multiple partitions.
detailed	(Optional) Displays detailed file directory information per partition, including file length, address, name, Flash memory checksum, computer checksum, bytes used, bytes available, total bytes, and bytes of system Flash memory.
err	(Optional) Displays write or erase failures in the form of number of retries.
summary	(Optional) Displays summary information per partition, including the partition size, bank size, state, and method by which files can be copied into a particular partition. You can use this keyword only when Flash memory has multiple partitions.

Command Modes EXEC

Command History	Release	Modification
	11.3 AA	This command was introduced.

Usage Guidelines If Flash memory is partitioned, the command displays the requested output for each partition, unless you use the **partition** keyword.

The command also specifies the location of the current image.

To display the contents of boot Flash memory on Class A or B file systems, use the **show bootflash:** command as follows:

Class A Flash file systems

show bootflash: [all | chips | filesystems]

Class B Flash file systems

show bootflash: [partition *number*] [all | chips | detailed | err]

To display the contents of internal Flash memory on Class A or B file systems, use the **show flash:** command as follows:

Class A Flash file systems

show flash: [all | chips | filesystems]

Class B Flash file systems

show flash: [partition *number*][all | chips | detailed | err | summary]

The [show \(Flash file system\)](#) command replaces the **show flash devices** command.

Examples The output of the **show** command depends on the type of Flash file system you select. Types include **flash:**, **bootflash:**, **slot0:**, **slot1:**, **slavebootflash:**, **slaveslot0:**, and **slaveslot1:**.

Examples of output from the **show flash** command are provided in the following sections:

- [Class A Flash File System](#)
- [Class B Flash File Systems](#)

Although the examples use **flash:** as the Flash file system, you may also use the other Flash file systems listed.

Class A Flash File System

The following three examples show sample output for Class A Flash file systems. [Table 37](#) describes the significant fields shown in the display.

The following is sample output from the **show flash:** command.

```
Router# show flash:

-#- ED --type---crc--- -seek-- nlen -length- -----date/time----- name
1  .. unknown 317FBA1B 4A0694 24 4720148 Aug 29 1997 17:49:36
hampton/nitro/c7200-j-mz
```



```

2  .. unknown 9237F3FF 92C574 11 4767328 Oct 01 1997 18:42:53 c7200-js-mz
3  .D unknown 71AB01F1 10C94E0 10 7982828 Oct 01 1997 18:48:14 rsp-jsv-mz
4  .D unknown 96DACD45 10C97E0 8 639 Oct 02 1997 12:09:17 the_time
5  .. unknown 96DACD45 10C9AE0 3 639 Oct 02 1997 12:09:32 the_time
6  .D unknown 96DACD45 10C9DE0 8 639 Oct 02 1997 12:37:01 the_time
7  .. unknown 96DACD45 10CA0E0 8 639 Oct 02 1997 12:37:13 the_time

```

3104544 bytes available (17473760 bytes used)

Table 37 *show (Class A Flash File System) Field Descriptions*

Field	Description
#	Index number for the file.
ED	Whether the file contains an error (<i>E</i>) or is deleted (<i>D</i>).
type	File <i>type</i> (1 = configuration file, 2 = image file). The software displays these values only when the file type is certain. When the file type is unknown, the system displays “unknown” in this field.
crc	Cyclic redundant check for the file.
seek	Offset into the file system of the next file.
nlen	<i>name length</i> —Length of the filename.
length	Length of the file itself.
date/time	Date and time the file was created.
name	Name of the file.

The following is sample output from the **show flash: chips** command:

```

RouterA# show flash: chips

***** Intel Series 2+ Status/Register Dump *****

ATTRIBUTE MEMORY REGISTERS:
  Config Option Reg (4000): 2
  Config Status Reg (4002): 0
  Card Status Reg (4100): 1
  Write Protect Reg (4104): 4
  Voltage Cntrl Reg (410C): 0
  Rdy/Busy Mode Reg (4140): 2

COMMON MEMORY REGISTERS: Bank 0
  Intelligent ID Code : 8989A0A0
  Compatible Status Reg: 8080
  Global Status Reg: B0B0
  Block Status Regs:
    0 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
    8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
   16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
   24 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

COMMON MEMORY REGISTERS: Bank 1
  Intelligent ID Code : 8989A0A0
  Compatible Status Reg: 8080
  Global Status Reg: B0B0
  Block Status Regs:
    0 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

```

show (Flash file system)

```

      8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
     16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
     24 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

COMMON MEMORY REGISTERS: Bank 2
Intelligent ID Code : 8989A0A0
Compatible Status Reg: 8080
Global      Status Reg: B0B0
Block Status Regs:
  0 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
  8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 24 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

COMMON MEMORY REGISTERS: Bank 3
Intelligent ID Code : 8989A0A0
Compatible Status Reg: 8080
Global      Status Reg: B0B0
Block Status Regs:
  0 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
  8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 24 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

COMMON MEMORY REGISTERS: Bank 4
Intelligent ID Code : 8989A0A0
Compatible Status Reg: 8080
Global      Status Reg: B0B0
Block Status Regs:
  0 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
  8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
 24 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0

```

The following is sample output from the **show flash: filesystem** command:

```

RouterA# show flash: filesystem

----- F I L E   S Y S T E M   S T A T U S -----
Device Number = 0
DEVICE INFO BLOCK:
  Magic Number      = 6887635   File System Vers = 10000   (1.0)
  Length            = 1400000   Sector Size      = 20000
  Programming Algorithm = 4      Erased State     = FFFFFFFF
  File System Offset = 20000     Length = 13A0000
  MONLIB Offset      = 100       Length = C730
  Bad Sector Map Offset = 1FFEC   Length = 14
  Squeeze Log Offset  = 13C0000   Length = 20000
  Squeeze Buffer Offset = 13E0000   Length = 20000
  Num Spare Sectors   = 0
  Spares:
STATUS INFO:
  Writable
  NO File Open for Write
  Complete Stats
  No Unrecovered Errors
  No Squeeze in progress
USAGE INFO:
  Bytes Used      = 10AA0E0   Bytes Available = 2F5F20
  Bad Sectors     = 0         Spared Sectors  = 0
  OK Files        = 4         Bytes = 90C974
  Deleted Files   = 3         Bytes = 79D3EC
  Files w/Errors  = 0         Bytes = 0

```

The following is sample output from the **show flash:** command:

```
RouterB> show flash:
```

```
System flash directory:
File Length Name/status
  1  4137888 c3640-c2is-mz.Feb24
[4137952 bytes used, 12639264 available, 16777216 total]
16384K bytes of processor board System flash (Read/Write)\
```

The following example shows detailed information about the second partition in internal Flash memory:

```
RouterB# show flash: partition 2
```

```
System flash directory, partition 2:
File Length Name/status
  1  1711088 dirt/images/c3600-i-mz
[1711152 bytes used, 15066064 available, 16777216 total]
16384K bytes of processor board System flash (Read/Write)
```

Class B Flash File Systems

Table 38 describes significant fields shown in the displays.

Table 38 *show (Class B Flash File System) all Fields*

Field	Description
addr	Address of the file in Flash memory.
available	Total number of bytes available in Flash memory.
Bank	Bank number.
Bank-Size	Size of bank in bytes.
bytes used	Total number of bytes used in Flash memory.
ccksum	Computed checksum.
Chip	Chip number.
Code	Code number.
Copy-Mode	Method by which the partition can be copied to: • RXBOOT-MANUAL indicates a user can copy manually by reloading to the boot ROM image. • RXBOOT-FLH indicates user can copy via Flash load helper. • Direct indicates user can copy directly into Flash memory. • None indicates that it is not possible to copy into that partition.
fcksum	Checksum recorded in Flash memory.
File	Number of the system image file. If no filename is specified in the boot system flash command, the router boots the system image file with the lowest file number.
Free	Number of bytes free in partition.
Length	Size of the system image file (in bytes).
Name	Name of chip manufacturer and chip type.

Table 38 *show (Class B Flash File System) all Fields (continued)*

Field	Description
Name/status	Filename and status of a system image file. The status [invalidated] appears when a file has been rewritten (recopied) into Flash memory. The first (now invalidated) copy of the file is still present within Flash memory, but it is rendered unusable in favor of the newest version. The [invalidated] status can also indicate an incomplete file that results from the user abnormally terminating the copy process, a network timeout, or a Flash memory overflow.
Partition	Partition number in Flash memory.
Size	Size of partition (in bytes) or size of chip.
State	State of the partition. It can be one of the following values: - Read-Only indicates the partition that is being executed from. - Read/Write is a partition that can be copied to.
System flash directory	Flash directory and its contents.
total	Total size of Flash memory (in bytes).
Used	Number of bytes used in partition.

The following is sample output from the **show flash: all** command:

```
RouterB> show flash: all
Partition   Size      Used      Free      Bank-Size  State      Copy Mode
  1         16384K   4040K     12343K    4096K      Read/Write Direct
```

System flash directory:

```
File Length Name/status
      addr      fcksum ccksum
  1  4137888 c3640-c2is-mz.Feb24
      0x40      0xED65 0xED65
```

[4137952 bytes used, 12639264 available, 16777216 total]

16384K bytes of processor board System flash (Read/Write)

Chip	Bank	Code	Size	Name
1	1	01D5	1024KB	AMD 29F080
2	1	01D5	1024KB	AMD 29F080
3	1	01D5	1024KB	AMD 29F080
4	1	01D5	1024KB	AMD 29F080
1	2	01D5	1024KB	AMD 29F080
2	2	01D5	1024KB	AMD 29F080
3	2	01D5	1024KB	AMD 29F080
4	2	01D5	1024KB	AMD 29F080
1	3	01D5	1024KB	AMD 29F080
2	3	01D5	1024KB	AMD 29F080
3	3	01D5	1024KB	AMD 29F080
4	3	01D5	1024KB	AMD 29F080
1	4	01D5	1024KB	AMD 29F080
2	4	01D5	1024KB	AMD 29F080
3	4	01D5	1024KB	AMD 29F080
4	4	01D5	1024KB	AMD 29F080

The following is sample output from the **show flash: all** command on a router with Flash memory partitioned:

Router# **show flash: all**

System flash partition information:

Partition	Size	Used	Free	Bank-Size	State	Copy-Mode
1	4096K	3459K	637K	4096K	Read Only	RXBOOT-FLH
2	4096K	3224K	872K	4096K	Read/Write	Direct

System flash directory, partition 1:

File	Length	Name/status
	addr	fcksum ccksum
1	3459720	master/igs-bfpx.100-4.3
	0x40	0x3DE1 0x3DE1

[3459784 bytes used, 734520 available, 4194304 total]
4096K bytes of processor board System flash (Read ONLY)

Chip	Bank	Code	Size	Name
1	1	89A2	1024KB	INTEL 28F008SA
2	1	89A2	1024KB	INTEL 28F008SA
3	1	89A2	1024KB	INTEL 28F008SA
4	1	89A2	1024KB	INTEL 28F008SA

Executing current image from System flash [partition 1]

System flash directory, partition2:

File	Length	Name/status
	addr	fcksum ccksum
1	3224008	igs-kf.100
	0x40	0xEE91 0xEE91

[3224072 bytes used, 970232 available, 4194304 total]
4096K bytes of processor board System flash (Read/Write)

Chip	Bank	Code	Size	Name
1	2	89A2	1024KB	INTEL 28F008SA
2	2	89A2	1024KB	INTEL 28F008SA
3	2	89A2	1024KB	INTEL 28F008SA
4	2	89A2	1024KB	INTEL 28F008SA

The following is sample output from the **show flash: chips** command:

RouterB> **show flash: chips**

16384K bytes of processor board System flash (Read/Write)

Chip	Bank	Code	Size	Name
1	1	01D5	1024KB	AMD 29F080
2	1	01D5	1024KB	AMD 29F080
3	1	01D5	1024KB	AMD 29F080
4	1	01D5	1024KB	AMD 29F080
1	2	01D5	1024KB	AMD 29F080
2	2	01D5	1024KB	AMD 29F080
3	2	01D5	1024KB	AMD 29F080
4	2	01D5	1024KB	AMD 29F080
1	3	01D5	1024KB	AMD 29F080
2	3	01D5	1024KB	AMD 29F080
3	3	01D5	1024KB	AMD 29F080
4	3	01D5	1024KB	AMD 29F080
1	4	01D5	1024KB	AMD 29F080
2	4	01D5	1024KB	AMD 29F080
3	4	01D5	1024KB	AMD 29F080
4	4	01D5	1024KB	AMD 29F080

The following is sample output from the **show flash: detailed** command:

■ **show (Flash file system)**

```
RouterB> show flash: detailed
```

```
System flash directory:
File Length Name/status
      addr      fcksum  ccksum
    1  4137888  c3640-c2is-mz.Feb24
      0x40      0xED65  0xED65
[4137952 bytes used, 12639264 available, 16777216 total]
16384K bytes of processor board System flash (Read/Write)
```

The following is sample output from the **show flash: err** command:

```
RouterB> show flash: err
```

```
System flash directory:
File Length Name/status
    1  4137888  c3640-c2is-mz.Feb24
[4137952 bytes used, 12639264 available, 16777216 total]
16384K bytes of processor board System flash (Read/Write)
```

Chip	Bank	Code	Size	Name	erase	write
1	1	01D5	1024KB	AMD 29F080	0	0
2	1	01D5	1024KB	AMD 29F080	0	0
3	1	01D5	1024KB	AMD 29F080	0	0
4	1	01D5	1024KB	AMD 29F080	0	0
1	2	01D5	1024KB	AMD 29F080	0	0
2	2	01D5	1024KB	AMD 29F080	0	0
3	2	01D5	1024KB	AMD 29F080	0	0
4	2	01D5	1024KB	AMD 29F080	0	0
1	3	01D5	1024KB	AMD 29F080	0	0
2	3	01D5	1024KB	AMD 29F080	0	0
3	3	01D5	1024KB	AMD 29F080	0	0
4	3	01D5	1024KB	AMD 29F080	0	0
1	4	01D5	1024KB	AMD 29F080	0	0
2	4	01D5	1024KB	AMD 29F080	0	0
3	4	01D5	1024KB	AMD 29F080	0	0
4	4	01D5	1024KB	AMD 29F080	0	0

See [Table 38](#) for a description of the fields. The **show flash: err** command also displays two extra fields: **erase** and **write**. The **erase** field indicates the number of erase errors. The **write** field indicates the number of write errors.

The following is sample output from the **show flash summary** command on a router with Flash memory partitioned. The partition in the Read Only state is the partition from which the Cisco IOS image is being executed.

```
Router# show flash summary
```

```
System flash partition information:
Partition Size Used Free Bank-Size State Copy-Mode
    1      4096K 2048K 2048K 2048K Read Only RXBOOT-FLH
    2      4096K 2048K 2048K 2048K Read/Write Direct
```

Related Commands

Command	Description
more	Displays the contents of any file in the Cisco IOS File System.

show memory scan

To monitor the number and type of parity (memory) errors on your system, use the **show memory scan** EXEC command.

show memory scan

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values

Command Modes	EXEC

Command History	Release	Modification
	12.0(4)XE	This command was introduced.
	12.0(7)T	This command was implemented in Cisco IOS Release 12.0(7) T.

Examples	The following example shows a result with no memory errors:

```
Router# show memory scan
```

```
Memory scan is on.  
No parity error has been detected.
```

If errors are detected in the system, the **show memory scan** command generates an error report. In the following example, memory scan detected a parity error:

```
Router# show memory scan
```

```
Memory scan is on.  
Total Parity Errors 1.  
AddressBlockPtrBlckSizeDispositRegion Timestamp  
6115ABCD60D5D0909517A4ScrubedLocal 16:57:09 UTC Thu Mar 18
```

[Table 39](#) describes the fields contained in the error report.

Table 39 show memory scan Field Descriptions

Field	Description
Address	The byte address where the error occurred.
BlockPtr	The pointer to the block that contains the error.
BlckSize	The size of the memory block

Table 39 *show memory scan Field Descriptions (continued)*


Field	Description
Disposit	The action taken in response to the error: • BlockInUse—An error was detected in a busy block. • InFieldPrev—An error was detected in the previous field of a block header. • InHeader—An error was detected in a block header. • Linked—A block was linked to a bad list. • MScrubed—The same address was “scrubbed” more than once, and the block was linked to a bad list. • MultiError—Multiple errors have been found in one block. • NoBlkHdr—No block header was found. • NotYet—An error was found; no action has been taken at this time. • Scrubed—An error was “scrubbed.” • SplitLinked—A block was split, and only a small portion was linked to a bad list.
Region	The memory region in which the error was found: • IBSS—image BSS • IData—imagedata • IText—imagetext • local—heap
Timestamp	The time the error occurred.

write memory

The **write memory** command has been replaced by the **copy system:running-config nvram:startup-config** command. See the description of the **copy** command in this [“Cisco IOS File System Commands”](#) chapter for more information.

write network

The **write network** command is replaced by the **copy system:running-config** *destination-url*. See the description of the **copy** command in this “[Cisco IOS File System Commands](#)” chapter for more information.



Booting Commands

This chapter provides detailed descriptions of the commands used to modify the rebooting procedures of the router.

For configuration information and examples, refer to the “Rebooting” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Flash Memory File System Types

Cisco platforms generally use one of three different Flash memory file system types. Some commands are supported on only one or two file system types. This chapter notes commands that are not supported on all file system types.

Use [Table 40](#) to determine which Flash memory file system type your platform uses.

Table 40 *Flash Memory File System Types*

Type	Platforms
Class A	Cisco 7000 family, Cisco 12000 series, LightStreamLS1010
Class B	Cisco 1003, Cisco 1004, Cisco 1005, Cisco 2500 series, Cisco 3600 series, Cisco 4000 series, Cisco AS5200 access servers
Class C	Cisco MC3810 multiservice concentrators, disk0 of Cisco SC3640 system controllers

boot

To boot the router manually, use the **boot** ROM monitor command. The syntax of this command varies according to the platform and ROM monitor version.

```
boot
boot file-url
boot filename [tftp-ip-address]
boot flash [flash-fs:][partition-number:][filename]
```

Cisco 7000 Series, 7200 Series, 7500 Series Routers

```
boot flash-fs:[filename]
```

Cisco 1600 and Cisco 3600 Series Routers

```
boot [flash-fs:][partition-number:][filename]
```

Syntax Description	file-url	URL of the image to boot (for example, boot tftp://172.16.15.112/routerest).
	filename	When used in conjunction with the <i>ip-address</i> argument, the <i>filename</i> argument is the name of the system image file to boot from a network server. The filename is case sensitive. When used in conjunction with the flash keyword, the <i>filename</i> argument is the name of the system image file to boot from Flash memory. On all platforms except the Cisco 1600 series, Cisco 3600 series, and Cisco 7000 family routers, the system obtains the image file from internal Flash memory. On the Cisco 1600 series, Cisco 3600 series and Cisco 7000 family routers, the <i>flash-fs:</i> argument specifies the Flash memory device from which to obtain the system image. (See the <i>flash-fs:</i> argument later in this table for valid device values.) The filename is case sensitive. Without the <i>filename</i> argument, the first valid file in Flash memory is loaded.
	tftp-ip-address	(optional) IP address of the TFTP server on which the system image resides. If omitted, this value defaults to the IP broadcast address of 255.255.255.255.
	flash	Boots the router from Flash memory. Note that this keyword is required in some boot images.

<i>flash-fs:</i>	(Optional) Specifying the Flash file system is optional for all platforms except the Cisco 7500 series routers. Possible file systems are: • flash:—Internal Flash memory on the Cisco 1600 series routers and Cisco 3600 series routers. This is the only valid Flash file system for the Cisco 1600 series routers. • bootflash:—Internal Flash memory on the Cisco 7000 family. • slot0:—Flash memory card in the first PCMCIA slot on the Cisco 7000 family and Cisco 3600 series routers. • slot1:—Flash memory card in the second PCMCIA slot on the Cisco 7000 family and Cisco 3600 series routers.
<i>partition-number:</i>	(Optional) Specifies the partition number of the file system the file should be loaded from. This argument is not available on all platforms.

Defaults

For most platforms, if you enter the **boot** command and press Return, the router boots from ROM by default. However, for some platforms, such as the Cisco 3600 series routers, if you enter the **boot** command and press Return, the router boots the first image in Flash memory. Refer to the documentation for your platform for information about the default image.

If the *partition-number* is not specified, the first partition is used.

If the *filename* is not specified, the first file in the partition or file system is used.

For other defaults, see the “Syntax Description” section.

Command Modes

ROM monitor

Command History

Release	Modification
10.3	The command was introduced.

Usage Guidelines

To determine which form of this command to use, refer to the documentation for your platform or use the CLI help (?) feature.

Use this command only when your router cannot find the boot configuration information needed in NVRAM. To enter ROM monitor mode, use one of the following methods:

- Enter the **reload EXEC** command, then press the **Break** key during the first 60 seconds of startup.
- Set the configuration register bits 0 to 3 to zero (for example, set the configuration register to 0x0) and enter the **reload** command.

The ROM Monitor prompt is either “>” or, for newer platforms, “rommon x>”. Enter only lowercase commands.

These commands work only if there is a valid image to boot. Also, from the ROM monitor prompt, issuing a prior reset command is necessary for the boot to be consistently successful.

Refer to your hardware documentation for information on correct jumper settings for your platform.



For some platforms the **flash** keyword is now required. If your attempts to use the boot command are failing using the older **boot flash:x:[filename]** syntax, try using the **boot flash flash:x:[filename]** syntax.

In the following example, a router is manually booted from ROM:

```
> boot
F3:
(ROM Monitor copyrights)
```

In the following example, a router boots the file named `routertest` from a network server with the IP address `172.16.15.112` using the `file-url` syntax:

```
> boot tftp://172.16.15.112/routertest
F3
(ROM Monitor copyrights)
```

The following example shows the **boot flash** command without the *filename* argument. The first valid file in Flash memory is loaded.

[illegible]

The following example boots from Flash memory using the file named `gs7-k`:

[illegible]

In the following example, the **boot flash flash:** command boots the relocatable image file named `igs-bpx-1` from partition 2 in Flash memory:

```
> boot flash flash:2:igs-bpx-1
F3: 3562264+98228+303632 at 0x30000B4

(ROM Monitor copyrights)
```

In the following command, the Cisco 7000 family router accepts the **flash** keyword for compatibility but ignores it, and boots from slot 0:

```
> boot flash slot0:gs7-k-mz.103-9
F3: 8468+3980384+165008 at 0x1000
```

In the following example, the command did not function because it must be entered in lowercase:

```
rommon 10 > BOOT  
command "BOOT" not found
```

The following example boots the first file in the first partition of internal Flash memory of a Cisco 3600 series router:

```
> boot flash:
```

The following example boots the first image file in the first partition of the Flash memory card in slot 0 of a Cisco 3600 series router:

```
> boot slot0:
```

The following example shows the ROM monitor booting the first file in the first Flash memory partition on a Cisco 1600 series router:

```
> boot flash:
```

Related Commands

Command	Description
continue	Returns to EXEC mode from ROM monitor mode by completing the boot process.

boot bootldr

To specify the location of the boot image that ROM uses for booting, use the **boot bootldr** global configuration command. To remove this boot image specification, use the **no** form of this command.

```
boot bootldr file-url

no boot bootldr
```

Syntax Description	file-url	URL of the boot image on a Flash file system.

Defaults	Refer to your platform documentation for the location of the default boot image.

Command Modes	Global configuration

Command History	Release	Modification
	11.0	The command was introduced.

Usage Guidelines The **boot bootldr** command sets the BOOTLDR variable in the current running configuration. You must specify both the Flash file system and the filename.



Note

When you use this global configuration command, you affect only the running configuration. You must save the variable setting to your startup configuration to place the information under ROM monitor control and to have the variable function as expected. Use the **copy system:running-config nvram:startup-config** command to save the variable from your running configuration to your startup configuration.

The **no** form of the command sets the BOOTLDR variable to a null string. On the Cisco 7000 family routers, a null string causes the first image file in boot flash memory to be used as the boot image that ROM uses for booting.

Use the **show boot** command to display the current value for the BOOTLDR variable.

Examples	In the following example, the internal Flash memory contains the boot image: <pre>boot bootldr bootflash:boot-image</pre> The following example specifies that the Flash memory card inserted in slot 0 contains the boot image: <pre>boot bootldr slot0:boot-image</pre>

Related Commands

Command	Description
copy system:running-config nvram:startup-config	Copies any file from a source to a destination.
show bootvar	Displays the contents of the BOOT variable, the name of the configuration file pointed to by the CONFIG_FILE variable, the contents of the BOOTLDR variable, and the configuration register setting.
show (Flash file system)	Displays the layout and contents of a Flash memory file system.

boot bootstrap

To configure the filename that is used to boot a secondary bootstrap image, use the **boot bootstrap** global configuration command. To disable booting from a secondary bootstrap image, use the **no** form of this command.

```
boot bootstrap file-url
no boot bootstrap file-url
boot bootstrap flash [filename]
no boot bootstrap flash [filename]
boot bootstrap [tftp] filename [ip-address]
no boot bootstrap [tftp] filename [ip-address]
```

Syntax Description	file-url	URL of the bootstrap image.
	flash	Boots the router from Flash memory.
	filename	(Optional with flash) Name of the system image to boot from a network server or from Flash memory. If you omit the filename when booting from Flash memory, the router uses the first system image stored in Flash memory.
	tftp	(Optional) Boots the router from a system image stored on a TFTP server.
	ip-address	(Optional) IP address of the TFTP server on which the system image resides. If omitted, this value defaults to the IP broadcast address of 255.255.255.255.

Defaults No secondary bootstrap

Command Modes Global configuration

Command History	Release	Modification
	10.0	The command was introduced.

Usage Guidelines

The **boot bootstrap** command causes the router to load a secondary bootstrap image over the network. The secondary bootstrap image then loads the specified system image file. See the appropriate hardware installation guide for details on the configuration register and secondary bootstrap filename.

Use this command when you have attempted to load a system image but have run out of memory even after compressing the system image. Secondary bootstrap allows you to load a larger system image through a smaller secondary image.

Examples

In the following example, the system image file named sysimage-2 will be loaded by using a secondary bootstrap image:

```
boot bootstrap bootflash:sysimage-2
```

boot system

To specify the system image that the router loads at startup, use one of the following **boot system** global configuration commands. To remove the startup system image specification, use the **no** form of the command.

boot system *file-url*

no boot system *file-url*

boot system flash [*flash-fs:*][*partition-number:*][*filename*]

no boot system flash [*flash-fs:*][*partition-number:*][*filename*]

boot system mop *filename* [*mac-address*] [*interface*]

no boot system mop *filename* [*mac-address*] [*interface*]

boot system rom

no boot system rom

boot system {*rcp* | *tftp* | *ftp*} *filename* [*ip-address*]

no boot system {*rcp* | *tftp* | *ftp*} *filename* [*ip-address*]

no boot system

Syntax Description

<i>file-url</i>	URL of the system image to load at system startup.
flash	On all platforms except the Cisco 1600 series, Cisco 3600 series, and Cisco 7000 family routers, this keyword boots the router from internal Flash memory. If you omit all arguments that follow this keyword, the system searches internal Flash for the first bootable image. On the Cisco 1600 series, Cisco 3600 series, and Cisco 7000 family routers, this keyword boots the router from a Flash device, as specified by the <i>device:</i> argument. On the Cisco 1600 series and Cisco 3600 series routers, if you omit all optional arguments, the router searches internal Flash memory for the first bootable image. On the Cisco 7000 family routers, when you omit all arguments that follow this keyword, the system searches the PCMCIA slot 0 for the first bootable image.

<i>flash-fs:</i>	(Optional) Flash file system containing the system image to load at startup. The colon is required. Valid file systems are as follows: • flash:—Internal Flash memory on the Cisco 1600 series and Cisco 3600 series routers. For the Cisco 1600 series and Cisco 3600 series routers, this file system is the default if you do not specify a file system. This is the only valid file system for the Cisco 1600 series. • bootflash—Internal Flash memory in the Cisco 7000 family. • slot0—First PCMCIA slot on the Cisco 3600 series and Cisco 7000 family routers. For the Cisco 7000 family routers, this file system is the default if you do not specify a file system. • slot1—Flash memory card in the second PCMCIA slot on the Cisco 3600 series and Cisco 7000 family routers.
<i>partition-number:</i>	(Optional) Number of the Flash memory partition that contains the system image to boot, specified by the optional <i>filename</i> argument. If you do not specify a filename, the router loads the first valid file in the specified partition of Flash memory. This argument is only valid on routers that can be partitioned.
<i>filename</i>	(Optional when used with the boot system flash command) Name of the system image to load at startup. It is case sensitive. If you do not specify a filename, the router loads the first valid file in the specified Flash file system, the specified partition of Flash memory, or the default Flash file system if you also omit the <i>flash-fs:</i> argument.
mop	Boots the router from a system image stored on a Digital MOP server. Do not use this keyword with the Cisco 3600 series or Cisco 7000 family routers.
<i>mac-address</i>	(Optional) MAC address of the MOP server containing the specified system image file. If you do not include the MAC address argument, the router sends a broadcast message to all MOP boot servers. The first MOP server to indicate that it has the specified file is the server from which the router gets the boot image.
<i>interface</i>	(Optional) Interface the router uses to send out MOP requests to the MOP server. The interface options are async , dialer , ethernet , serial , and tunnel . If you do not specify the <i>interface</i> argument, the router sends a request out on all interfaces that have MOP enabled. The interface that receives the first response is the interface the router uses to load the software.
rom	Boots the router from ROM. Do not use this keyword with the Cisco 3600 series or the Cisco 7000 family routers.
rcp	Boots the router from a system image stored on a network server using rcp.
tftp	Boots the router from a system image stored on a TFTP server.
ftp	Boots the router from a system image stored on an FTP server.
<i>ip-address</i>	(Optional) IP address of the server containing the system image file. If omitted, this value defaults to the IP broadcast address of 255.255.255.255.

Defaults

If you configure the router to boot from a network server but do not specify a system image file with the **boot system** command, the router uses the configuration register settings to determine the default system image filename. The router forms the default boot filename by starting with the word *cisco* and then appending the octal equivalent of the boot field number in the configuration register, followed by a hyphen (-) and the processor type name (*cisconn-cpu*). Refer to the appropriate hardware installation guide for details on the configuration register and default filename. See also the **config-register** or **confreg** command. For additional information about defaults, see the preceding “Syntax Description” section.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

For this command to work, the **config-register** command must be set properly.

Enter several **boot system** commands to provide a fail-safe method for booting your router. The router stores and executes the **boot system** commands in the order in which you enter them in the configuration file. If you enter multiple boot commands of the same type—for example, if you enter two commands that instruct the router to boot from different network servers—then the router tries them in the order in which they appear in the configuration file. If a **boot system** command entry in the list specifies an invalid device, the router omits that entry. Use the **boot system rom** command to specify use of the ROM system image as a backup to other **boot** commands in the configuration.

For some platforms, the boot image must be loaded before the system image is loaded. However, on many platforms, the boot image is loaded only if the router is booting from a network server or if the Flash file system is not specified. If the file system is specified, the router will boot faster because it need not load the boot image first.

This section contains the following usage guideline sections:

- [Change the List of Boot System Commands](#)
- [Boot Compressed Images](#)
- [Understand the rcp Protocol](#)
- [Stop Booting and Enter ROM Monitor Mode](#)
- [Cisco 1600 Series, Cisco 3600 Series, and Cisco 7000 Family Notes](#)

Change the List of Boot System Commands

To remove a single entry from the bootable image list, use the **no** form of the command with an argument. For example, to remove the entry that specifies a bootable image on a Flash memory card inserted in the second slot, use the **no boot system flash slot1:[filename]** command. All other entries in the list remain.

To eliminate all entries in the bootable image list, use the **no boot system** command. At this point, you can redefine the list of bootable images using the previous **boot system** commands. Remember to save your changes to your startup configuration by issuing the **copy system:running-config nvram:startup-config** command.

Each time you write a new software image to Flash memory, you must delete the existing filename in the configuration file with the **no boot system flash *filename*** command. Then add a new line in the configuration file with the **boot system flash *filename*** command.

**Note**

If you want to rearrange the order of the entries in the configuration file, you must first issue the **no boot system** command and then redefine the list.

Boot Compressed Images

You can boot the router from a compressed image on a network server. When a network server boots software, both the image being booted and the running image must fit into memory. Use compressed images to ensure that enough memory is available to boot the router. You can compress a software image on any UNIX platform using the **compress** command. Refer to your UNIX platform's documentation for the exact usage of the **compress** command. (You can also uncompress data with the UNIX **uncompress** command.)

Understand the rcp Protocol

The rcp protocol requires a client to send the remote username in an rcp request to a server. When the router executes the **boot system rcp** command, the Cisco IOS software sends the host name as both the remote and local usernames by default. For the rcp protocol to execute properly, an account must be defined on the network server for the remote username configured on the router.

If the server has a directory structure, the rcp software searches for the system image to boot from the remote server relative to the directory of the remote username.

By default, the router software sends host name as the remote username. You can override the default remote username by using the **ip rcmd remote-username** command. For example, if the system image resides in the home directory of a user on the server, you can specify that user's name as the remote username.

Understand TFTP

You need a TFTP server running in order to retrieve the router image from the host.

Understand FTP

You need to an FTP server running in order to fetch the router image from the host. You also need an account on the server or anonymous file access to the server.

Stop Booting and Enter ROM Monitor Mode

During the first 60 seconds of startup, you can force the router to stop booting by pressing the Break key. The router will enter ROM Monitor mode, where you can change the configuration register value or boot the router manually.

Cisco 1600 Series, Cisco 3600 Series, and Cisco 7000 Family Notes

For the Cisco 3600 series and Cisco 7000 family, the **boot system** command modifies the BOOT variable in the running configuration. The BOOT variable specifies a list of bootable images on various devices.

**Note**

When you use the **boot system** global configuration command on the Cisco 1600 series, Cisco 3600 series, and Cisco 7000 family, you affect only the running configuration. You must save the BOOT variable settings to your startup configuration to place the information under ROM monitor control

and to have the variable function as expected. Use the **copy system:running-config nvram:startup-config** EXEC command to save the variable from your running configuration to your startup configuration.

To view the contents of the BOOT variable, use the **show bootenv** EXEC command.

Examples

The following example illustrates a list specifying two possible internetwork locations for a system image, with the ROM software being used as a backup:

```
boot system tftp://192.168.7.24/cs3-rx.90-1
boot system tftp://192.168.7.19/cs3-rx.83-2
boot system rom
```

The following example boots the system boot relocatable image file named igs-bpx-1 from partition 2 of the Flash device:

```
boot system flash:2:igs-bpx-1
```

The following example instructs the router to boot from an image located on the Flash memory card inserted in slot 0 of the Cisco 7000 RSP7000 card, Cisco 7200 NPE card, or Cisco 7500 series RSP card:

```
boot system slot0:new-config
```

The following example specifies the file named new-ios-image as the system image for a Cisco 3600 series router to load at startup. This file is located in the fourth partition of the Flash memory card in slot 0.

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# boot system slot0:4:dirt/images/new-ios-image
```

This example boots from the image file named c1600-y-1 in partition 2 of Flash memory of a Cisco 1600 series router:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# boot system flash:2:c1600-y-1
```

Related Commands

Command	Description
config-register	Changes the configuration register settings.
copy	Copies any file from a source to a destination.
ip rcmd remote username	Configures the remote username to be used when requesting a remote copy using rcp.
show bootvar	Displays the contents of the BOOT variable, the name of the configuration file pointed to by the CONFIG_FILE variable, the contents of the BOOTLDR variable, and the configuration register setting

config-register

To change the configuration register settings, use the **config-register** global configuration command.

config-register *value*

Syntax Description	<i>value</i>	Hexadecimal or decimal value that represents the 16-bit configuration register value that you want to use the next time the router is restarted. The value range is from 0x0 to 0xFFFF (0 to 65535 in decimal).

Defaults	Refer to the documentation for your platform for the default configuration register value. For many newer platforms, the default is 0x2102, which causes the router to boot from Flash memory and the Break key to be ignored.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command applies only to platforms that use a software configuration register. The lowest four bits of the configuration register (bits 3, 2, 1, and 0) form the boot field. The boot field determines if the router boots manually, from ROM, or from Flash or the network. To change the boot field value and leave all other bits set to their default values, follow these guidelines: • If you set the configuration register boot field value to 0x0, you must boot the operating system manually with the boot command. • If you set the configuration register boot field value to 0x1, the router boots using the default ROM software. • If you set the configuration register boot field to any value from 0x2 to 0xF, the router uses the boot field value to form a default boot filename for booting from a network server. For more information about the configuration register bit settings and default filenames, refer to the appropriate router hardware installation guide.

Examples	In the following example, the configuration register is set to boot the system image from Flash memory: <pre>config-register 0x2102</pre>

Related Commands	Command	Description
	boot system	Specifies the system image that the router loads at startup.
	confreg	Changes the configuration register settings while in ROM monitor mode.

Command	Description
o	Lists the value of the boot field (bits 0 to 3) in the configuration register.
show version	Displays the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images.

confreg

To change the configuration register settings while in ROM monitor mode, use the **confreg** ROM monitor command.

confreg [*value*]

Syntax Description

<i>value</i>	(Optional) Hexadecimal value that represents the 16-bit configuration register value that you want to use the next time the router is restarted. The value range is from 0x0 to 0xFFFF.

Defaults

Refer to your platform documentation for the default configuration register value.

Command Modes

ROM monitor

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Not all versions in the ROM monitor support this command. Refer to your platform documentation for more information on ROM monitor mode.

If you use this command without specifying the configuration register value, the router prompts for each bit of the configuration register.

The lowest four bits of the configuration register (bits 3, 2, 1, and 0) form the boot field. The boot field determines if the router boots manually, from ROM, or from Flash or the network.

To change the boot field value and leave all other bits set to their default values, follow these guidelines:

- If you set the configuration register boot field value to 0x0, you must boot the operating system manually with the **boot** command.
- If you set the configuration register boot field value to 0x1, the router boots using the default ROM software.
- If you set the configuration register boot field to any value from 0x2 to 0xF, the router uses the boot field value to form a default boot filename for booting from a network server.

For more information about the configuration register bit settings and default filenames, refer to the appropriate router hardware installation guide.

Examples

In the following example, the configuration register is set to boot the system image from Flash memory:

```
confreg 0x210F
```

In the following example, no configuration value is entered, so the system prompts for each bit in the register:

```
rommon 7 > confreg
```

```

Configuration Summary
enabled are:
console baud: 9600
boot: the ROM Monitor

do you wish to change the configuration? y/n [n]: y
enable "diagnostic mode"? y/n [n]: y
enable "use net in IP bcast address"? y/n [n]:

enable "load rom after netboot fails"? y/n [n]:
enable "use all zero broadcast"? y/n [n]:
enable "break/abort has effect"? y/n [n]:
enable "ignore system config info"? y/n [n]:
change console baud rate? y/n [n]: y
enter rate: 0 = 9600, 1 = 4800, 2 = 1200, 3 = 2400 [0]: 0
change the boot characteristics? y/n [n]: y
enter to boot:
  0 = ROM Monitor
  1 = the boot helper image
  2-15 = boot system
[0]: 0

Configuration Summary
enabled are:
diagnostic mode
console baud: 9600
boot: the ROM Monitor

do you wish to change the configuration? y/n [n]:

You must reset or power cycle for new config to take effect.
rommon 8>

```

continue

To return to EXEC mode from ROM monitor mode, use the **continue** ROM monitor command.

continue

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values

Command Modes	ROM monitor

Command History	Release	Modification
	11.0	The command was introduced.

Usage Guidelines	Use this command to return to EXEC mode from ROM monitor mode, to use the system image instead of reloading. On older platforms, the angle bracket (>) indicates that the router is in ROM monitor mode. On newer platforms, common <i>number></i> is the default ROM monitor prompt. Typically, the router is in ROM monitor mode when you manually load a system image or perform diagnostic tests. Otherwise, the router will most likely never be in this mode.

**Caution**

While in ROM monitor mode, the Cisco IOS system software is suspended until you issue either a reset or the continue command.

Examples	In the following example, the continue command switches the router from ROM monitor to EXEC mode:

```
> continue
Router#
```

Related Commands	Command	Description
	boot	Boots the router manually.

reload

To reload the operating system, use the **reload** EXEC command.

```
reload [text | in [hh:]mm [text] | at hh:mm [month day | day month] [text] | cancel]
```

Syntax Description	<i>text</i>	(Optional) Reason for the reload, 1 to 255 characters long.
	in [hh:]mm	(Optional) Schedule a reload of the software to take effect in the specified minutes or hours and minutes. The reload must take place within approximately 24 days.
	at hh:mm	(Optional) Schedule a reload of the software to take place at the specified time (using a 24-hour clock). If you specify the month and day, the reload is scheduled to take place at the specified time and date. If you do not specify the month and day, the reload takes place at the specified time on the current day (if the specified time is later than the current time), or on the next day (if the specified time is earlier than the current time). Specifying 00:00 schedules the reload for midnight. The reload must take place within approximately 24 days.
	<i>month</i>	(Optional) Name of the month, any number of characters in a unique string.
	<i>day</i>	(Optional) Number of the day in the range from 1 to 31.
	cancel	(Optional) Cancel a scheduled reload.

Command Modes	EXEC

Command History	Release	Modification
	10.0	The command was introduced.

Usage Guidelines

The **reload** command halts the system. If the system is set to restart on error, it reboots itself. Use the **reload** command after configuration information is entered into a file and saved to the startup configuration.

You cannot reload from a virtual terminal if the system is not set up for automatic booting. This prevents the system from dropping to the ROM monitor and thereby taking the system out of the remote user’s control.

If you modify your configuration file, the system prompts you to save the configuration. During a save operation, the system asks you if you want to proceed with the save if the CONFIG_FILE variable points to a startup configuration file that no longer exists. If you say “yes” in this situation, the system goes to setup mode upon reload.

When you schedule a reload to occur at a later time, it must take place within approximately 24 days.

The **at** keyword can be used only if the system clock has be set on the router (either through NTP, the hardware calendar, or manually). The time is relative to the configured time zone on the router. To schedule reloads across several routers to occur simultaneously, the time on each router must be synchronized with NTP.

To display information about a scheduled reload, use the **show reload** EXEC command.

Examples

The following example immediately reloads the software on the router:

```
Router# reload
```

The following example reloads the software on the router in 10 minutes:

```
Router# reload in 10
```

```
Router# Reload scheduled for 11:57:08 PDT Fri Apr 21 1996 (in 10 minutes)
Proceed with reload? [confirm]
Router#
```

The following example reloads the software on the router at 1:00 p.m. today:

```
Router# reload at 13:00
```

```
Router# Reload scheduled for 13:00:00 PDT Fri Apr 21 1996 (in 1 hour and 2 minutes)
Proceed with reload? [confirm]
Router#
```

The following example reloads the software on the router on April 20 at 2:00 a.m.:

```
Router# reload at 02:00 apr 20
```

```
Router# Reload scheduled for 02:00:00 PDT Sat Apr 20 1996 (in 38 hours and 9 minutes)
Proceed with reload? [confirm]
Router#
```

The following example cancels a pending reload:

```
Router# reload cancel
```

```
%Reload cancelled.
```

Related Commands

Command	Description
copy system:running-config nvram:startup-config	Copies any file from a source to a destination.
show reload	Displays the reload status on the router.

show boot

The **show boot** command has been replaced by the **show bootvar** command. See the description of the [show bootvar](#) command in this chapter for more information.

show bootvar

To display the contents of the BOOT variable, the name of the configuration file pointed to by the CONFIG_FILE variable, the contents of the BOOTLDR variable, and the configuration register setting, use the **show bootvar** EXEC command.

show bootvar

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
11.3 AA	This command was introduced.

Usage Guidelines

The **show bootvar** command replaces the **show boot** command.

The **show bootvar** command allows you to view the current settings for the following variables:

- BOOT
- CONFIG_FILE
- BOOTLDR

The BOOT variable specifies a list of bootable images on various devices. The CONFIG_FILE variable specifies the configuration file used during system initialization. The BOOTLDR variable specifies the Flash device and filename containing the rxboot image that ROM uses for booting. You set these variables with the **boot system**, **boot config**, and **boot bootldr** global configuration commands, respectively.

When you use this command on a device with multiple RSP cards (Dual RSPs), this command also shows you the variable settings for both the master and slave RSP card.

Examples

The following is sample output from the **show bootvar** command:

```
Router# show bootvar
```

```
BOOT variable =
CONFIG_FILE variable = nvram:
Current CONFIG_FILE variable = slot0:router-config
BOOTLDR variable not exist
```

```
Configuration register is 0x0
```

```
Router#
```

In the sample output, the BOOT variable contains a null string. That is, a list of bootable images is not specified.

The CONFIG_FILE variable points to the configuration file in NVRAM as the startup (initialization) configuration. The run-time value for the CONFIG_FILE variable points to the router-config file on the Flash memory card inserted in the first slot of the RSP card. That is, during the run-time configuration, you have modified the CONFIG_FILE variable using the **boot config** command, but you have not saved the run-time configuration to the startup configuration. To save your run-time configuration to the startup configuration, use the **copy system:running-config nvram:startup-config** command. If you do not save the run-time configuration to the startup configuration, then the system reverts to the saved CONFIG_FILE variable setting for initialization information upon reload. In this sample, the system reverts to NVRAM for the startup configuration file.

The BOOTLDR variable does not yet exist. That is, you have not created the BOOTLDR variable using the **boot bootldr** global configuration command.

The following example is output from the **show bootvar** command for a Cisco 7513 router configured for HSA:

```
Router# show bootvar

BOOT variable =
CONFIG_FILE variable =
Current CONFIG_FILE variable =
BOOTLDR variable does not exist

Configuration register is 0x0

current slave is in slot 7
BOOT variable =
CONFIG_FILE variable =
BOOTLDR variable does not exist

Configuration register is 0x0

Router#
```

Related Commands

Command	Description
boot bootstrap	Configures the filename that is used to boot a secondary bootstrap image.
boot config	Specifies the device and filename of the configuration file from which the router configures itself during initialization (startup).
boot system	Specifies the system image that the router loads at startup.
show version	Displays the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images.

show reload

To display the reload status on the router, use the **show reload** EXEC command.

show reload

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	You can use the show reload command to display a pending software reload. To cancel the reload, use the reload cancel privileged EXEC command.

Examples	The following sample output from the show reload command shows that a reload is schedule for 12:00 a.m. (midnight) on Saturday, April 20: <pre>Router# show reload Reload scheduled for 00:00:00 PDT Sat April 20 (in 12 hours and 12 minutes) Router#</pre>

Related Commands	Command	Description
	reload	Reloads the operating system.

show version

To display information about the currently loaded software version along with hardware and device information, use the **show version** command in EXEC mode.

show version

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	9.0	This command was introduced.
	12.3(4)T	The output format of this command was updated.
	12.2(25)S	The output format of this command was updated.

Usage Guidelines This command displays information about the Cisco IOS software version currently running on a routing device, the ROM Monitor and Bootflash software versions, and information about the hardware configuration, including the amount of system memory. Because this command displays both software and hardware information, the output of this command is the same as the output of the **show hardware** command. (The **show hardware** command is a command alias for the **show version** command.)

Specifically, the **show version** command provides the following information:

- Software information
 - Main Cisco IOS image version
 - Main Cisco IOS image capabilities (feature set)
 - Location and name of bootfile in ROM
 - Bootflash image version (depending on platform)
- Device-specific information
 - Device name
 - System uptime
 - System reload reason
 - Config-register setting
 - Config-register settings for after the next reload (depending on platform)

- Hardware information
 - Platform type
 - Processor type
 - Processor hardware revision
 - Amount of main (processor) memory installed
 - Amount I/O memory installed
 - Amount of Flash memory installed on different types (depending on platform)
 - Processor board ID

The output of this command uses the following format:

```
Cisco IOS Software, <platform> Software (<image-id>), Version <software-version>,
<software-type>
TAC Support: http://www.cisco.com/tac
Copyright (c) <date-range> by Cisco Systems, Inc.
Compiled <day> <date> <time> by <compiler-id>

ROM: System Bootstrap, Version <software-version>, <software-type>
BOOTLDR: <platform> Software (image-id), Version <software-version>, <software-type>

<router-name> uptime is <w> weeks, <d> days, <h> hours, <m> minutes
System returned to ROM by reload at <time> <day> <date>
System image file is "<filesystem-location>/<software-image-name>"
Last reload reason: <reload-reason>

Cisco <platform-processor-type> processor (revision <processor-revision-id>) with
<free-DRAM-memory>K/<packet-memory>K bytes of memory.
Processor board ID <ID-number>
<CPU-type> CPU at <clock-speed>Mhz, Implementation <number>, Rev <Revision-number>,
<kilobytes-Processor-Cache-Memory>KB <cache-Level> Cache
```

See the Examples section for descriptions of the fields in this output.

Examples

The following is sample output from the **show version** command issued on a Cisco 3660 running Cisco IOS Release 12.3(4)T:

```
Router# show version
Cisco IOS Software, 3600 Software (C3660-I-M), Version 12.3(4)T
TAC Support: http://www.cisco.com/tac
Copyright (c) 1986-2003 by Cisco Systems, Inc.
Compiled Thu 18-Sep-03 15:37 by ccai

ROM: System Bootstrap, Version 12.0(6r)T, RELEASE SOFTWARE (fc1)
ROM:

C3660-1 uptime is 1 week, 3 days, 6 hours, 41 minutes
System returned to ROM by power-on
System image file is "slot0:tftpboot/c3660-i-mz.123-4.T"

Cisco 3660 (R527x) processor (revision 1.0) with 57344K/8192K bytes of memory.
Processor board ID JAB055180FF
R527x CPU at 225Mhz, Implementation 40, Rev 10.0, 2048KB L2 Cache

3660 Chassis type: ENTERPRISE
2 FastEthernet interfaces
4 Serial interfaces
```

```

DRAM configuration is 64 bits wide with parity disabled.
125K bytes of NVRAM.
16384K bytes of processor board System flash (Read/Write)

Flash card inserted. Reading filesystem...done.
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)

Configuration register is 0x2102

```

The following is sample output from the **show version** command issued on a Cisco 7200 router running Cisco IOS Release 12.4(4)T. This output shows the total bandwidth capacity and the bandwidth capacity that is configured on the Cisco 7200. Displaying bandwidth capacity is available in Cisco IOS Release 12.2 and later releases.

```

Router# show version
Cisco IOS Software, 7200 Software (C7200-JS-M), Version 12.4(4)T, RELEASE SOFTWARE
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2005 by Cisco Systems, Inc.
Compiled Thu 27-Oct-05 05:58 by ccai

ROM: System Bootstrap, Version 12.1(20000710:044039) [nlaw-121E_npeb 117], DEVEE
BOOTLDR: 7200 Software (C7200-KBOOT-M), Version 12.3(16), RELEASE SOFTWARE (fc4)

router uptime is 5 days, 18 hours, 2 minutes
System returned to ROM by reload at 02:45:12 UTC Tue Feb 14 2006
System image file is "disk0:c7200-js-mz.124-4.T"
Last reload reason: Reload Command


Cisco 7206VXR (NPE400) processor (revision A) with 491520K/32768K bytes of memo.
Processor board ID 26793934
R7000 CPU at 350MHz, Implementation 39, Rev 3.2, 256KB L2 Cache
6 slot VXR midplane, Version 2.6

Last reset from power-on

PCI bus mb0_mb1 (Slots 0, 1, 3 and 5) has a capacity of 600 bandwidth points.
Current configuration on bus mb0_mb1 has a total of 440 bandwidth points.
This configuration is within the PCI bus capacity and is supported.

PCI bus mb2 (Slots 2, 4, 6) has a capacity of 600 bandwidth points.
Current configuration on bus mb2 has a total of 390 bandwidth points
This configuration is within the PCI bus capacity and is supported.

Please refer to the following document "Cisco 7200 Series Port Adaptor
Hardware Configuration Guidelines" on Cisco.com <http://www.cisco.com>
for c7200 bandwidth points oversubscription and usage guidelines.


4 Ethernet interfaces
2 FastEthernet interfaces
2 ATM interfaces
125K bytes of NVRAM.

62976K bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes).
125952K bytes of ATA PCMCIA card at slot 1 (Sector size 512 bytes).
8192K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x2002

Router#

```

For information about PCI buses and bandwidth calculation, go to http://www.cisco.com/univercd/cc/td/doc/product/core/7206/port_adp/config/3875in.htm#wp1057192. Table 41 describes the significant fields shown in the display.

Table 41 *show version Field Descriptions*

Field	Description
Cisco IOS Software, <platform> Software (<image-id>), Version <software-version>, <release-type> Example: Cisco IOS Software, 7200 Software (C7200-G4JS-M), Version 12.3(4)T	<i>platform</i>—Cisco hardware device name. <i>image-id</i>—The coded software image identifier, in the format <i>platform-features-format</i> (for example, “c7200-g4js-mz”). <i>software-version</i>—The Cisco IOS software release number, in the format <i>x.y(z)A</i>, where <i>x.y</i> is the main release identifier, <i>z</i> is the maintenance release number, and <i>A</i>, where applicable, is the special release train identifier. For example, 12.3(4)T indicates the fourth maintenance release of the 12.3T special technology release train. Note In the full software image filename, 12.3(4)T appears as 123-4.T. In the IOS Upgrade Planner, 12.3(4)T appears as 12.3.4T (ED). <i>release-type</i>—The description of the release type. Possible values include MAINTENANCE [for example, 12.3(3)] or INTERIM [for example, 12.3(3.2)]. Tips Refer to “The ABC’s of Cisco IOS Networking” (available on Cisco.com) for more information on Cisco IOS software release numbering and software versions. Cisco IOS is a registered trademark (R) of Cisco Systems, Inc.
TAC Support: http://www.cisco.com/tac Copyright (c) <date-range> by Cisco Systems, Inc.	The Cisco Technical Assistance Center (TAC) contains more than 30,000 pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content. Cisco IOS software, including the source code, user-help, and documentation, is copyrighted by Cisco Systems, Inc. It is Cisco’s policy to enforce its copyrights against any third party who infringes on its copyright.
ROM: System Bootstrap, Version 12.0(6r)T, RELEASE SOFTWARE (fc1)	The system “bootstrap” software, stored in ROM memory.
BOOTFLASH:	The system “bootflash” software, stored in Flash memory (if applicable).
<device> uptime is ... Example: C3660-1 uptime is 1 week, 3 days, 6 hours, 41 minutes	The amount of time the system has been up and running.

Table 41 *show version Field Descriptions (continued)*

Field	Description
System returned to ROM by <reload-reason> at <time> <day> <date> Example: System returned to ROM by reload at 20:56:53 UTC Tue Nov 4 2003	Shows the last recorded reason for a system reload, and time of last reload.
Last reload reason: <reload-reason> Example: Last reload reason: Reload command	Shows the last recorded reason for a system reload.
Last reset from <reset-reason> Example: Last reset from power-on	Shows the last recorded reason for a system reset. Possible <i>reset-reason</i> values include: • power-on—System was reset with the initial power on or a power cycling of the device. • s/w peripheral—System was reset due to a software peripheral. • s/w nmi—System was reset by a nonmaskable interrupt (NMI) originating in the system software. For example, on some systems, you can configure the device to reset automatically if two or more fans fail. • push-button—System was reset by manual activation of a RESET push-button (also called a hardware NMI). • watchdog—System was reset due to a watchdog process. • unexpected value—May indicate a bus error, such as for an attempt to access a nonexistent address (for example, “System restarted by bus error at PC 0xC4CA, address 0x210C0C0”). (This field was formerly labeled as the “System restarted by” field.)
System image file is "<file-location/file-name>" Example: System image file is "slot0:tftpboot/c3660-i-mz.1 23-3.9.T2"	Displays the file location (local or remote filesystem) and the system image name.

Table 41 *show version Field Descriptions (continued)*


Field	Description
<pre>Cisco <platform> (<processor-type>) processor (revision <processor-revision-id>) with <free-DRAM-memory>K/<packet- memory>K bytes of memory.</pre>	This line can be used to determine how much Dynamic RAM (DRAM) is installed on your system, in order to determine if you meet the “Min. Memory” requirement for a software image. DRAM (including SDRAM) is used for system processing memory and for packet memory. Two values, separated by a slash, are given for DRAM: The first value tells you how DRAM is available for system processing, and the second value tells you how much DRAM is being used for Packet memory. The first value, Main Processor memory, is either: • The amount of DRAM available for the processor, or • The total amount of DRAM installed on the system. The second value, Packet memory, is either: • The total physical input/output (I/O) memory (or “Fast memory”) installed on the router (Cisco 4000, 4500, 4700, and 7500 series), or • The amount of “shared memory” used for packet buffering. In the shared memory scheme (Cisco 2500, 2600, 3600, and 7200 Series), a percentage of DRAM is used for packet buffering by the router’s network interfaces. Note The terms “I/O memory” or “iomem”; “shared memory”; “Fast memory” and “PCI memory” all refer to “Packet Memory”. Packet memory is either separate physical RAM or shared DRAM. Separate DRAM and Packet Memory The 4000, 4500, 4700, and 7500 series routers have separate DRAM and Packet memory, so you only need to look at the first number to determine total DRAM. In the example to the left for the Cisco RSP4, the first value shows that the router has 65536K (65,536 kilobytes, or 64 megabytes) of DRAM. The second value, 8192K, is the Packet memory. Combined DRAM and Packet Memory The 2500, 2600, 3600, and 7200 series routers require a minimum amount of I/O memory to support certain interface processors. The 1600, 2500, 2600, 3600, and 7200 series routers use a fraction of DRAM as Packet memory, so you need to add both numbers to find out the real amount of DRAM. In the example to the left for the Cisco 3660, the router has 57,344 kilobytes (KB) of free DRAM and 8,192 KB dedicated to Packet memory. Adding the two numbers together gives you 57,344K + 8,192K = 65,536K, or 64 megabytes (MB) of DRAM.
Example: Separate DRAM and Packet Memory <pre>Cisco RSP4 (R5000) processor with 65536K/2072K bytes of memory</pre>	
Example: Combined DRAM and Packet Memory <pre>Cisco 3660 (R527x) processor (revision 1.0) with 57344K/8192K bytes of memory.</pre>	

Table 41 *show version Field Descriptions (continued)*

Field	Description
	For more details on memory requirements, see the document “ How to Choose a Cisco IOS® Software Release ” on Cisco.com.
Configuration register is <value>	Shows the current configured hex value of the software configuration register. If the value has been changed with the config-register command, the register value that will be used at the next reload is displayed in parenthesis.
Example: Configuration register is 0x2142 (will be 0x2102 at next reload)	The boot field (final digit) of the software configuration register dictates what the system will do after a reset. For example, when the boot field of the software configuration register is set to 00 (for example, 0x0), and you press the NMI button on a Performance Route Processor (PRP), the user-interface remains at the ROM monitor prompt (rommon>) and waits for a user command to boot the system manually. But if the boot field is set to 01 (for example, 0x1), the system automatically boots the first Cisco IOS image found in the onboard Flash memory SIMM on the PRP. The factory-default setting for the configuration register is 0x2102. This value indicates that the router will attempt to load a Cisco IOS software image from Flash memory and load the startup configuration file.

Related Commands

Command	Description
show inventory	Displays the Cisco Unique Device Identifier information, including the Product ID, the Version ID, and the Serial Number, for the hardware device and hardware components.



Basic File Transfer Services Commands

This chapter provides detailed descriptions of commands used to configure basic file transfer services on a Cisco routing device.

For configuration information and examples, refer to the “Configuring Basic File Transfer Services” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

async-bootp

To configure extended BOOTP requests for asynchronous interfaces as defined in RFC 1084, use the **async-bootp** global configuration command. To restore the default, use the **no** form of this command.

async-bootp *tag* [:*hostname*] *data*

no async-bootp

Syntax Description

<i>tag</i>	Item being requested; expressed as filename, integer, or IP dotted decimal address. See Table 42 for possible keywords.
: <i>hostname</i>	(Optional) This entry applies only to the host specified. The : <i>hostname</i> argument accepts both an IP address and a logical host name.
<i>data</i>	List of IP addresses entered in dotted decimal notation or as logical host names, a number, or a quoted string.

Table 42 *tag* Keyword Options

Keyword	Description
bootfile	Specifies use of a server boot file from which to download the boot program. Use the optional : <i>hostname</i> argument and the <i>data</i> argument to specify the filename.
subnet-mask <i>mask</i>	Dotted decimal address specifying the network and local subnetwork mask (as defined by RFC 950).
time-offset <i>offset</i>	Signed 32-bit integer specifying the time offset of the local subnetwork in seconds from Coordinated Universal Time (UTC).
gateway <i>address</i>	Dotted decimal address specifying the IP addresses of gateways for this subnetwork. A preferred gateway should be listed first.
time-server <i>address</i>	Dotted decimal address specifying the IP address of time servers (as defined by RFC 868).
IEN116-server <i>address</i>	Dotted decimal address specifying the IP address of name servers (as defined by IEN 116).
nbns-server <i>address</i>	Dotted decimal address specifying the IP address of Windows NT servers.
DNS-server <i>address</i>	Dotted decimal address specifying the IP address of domain name servers (as defined by RFC 1034).
log-server <i>address</i>	Dotted decimal address specifying the IP address of an MIT-LCS UDP log server.
quote-server <i>address</i>	Dotted decimal address specifying the IP address of Quote of the Day servers (as defined in RFC 865).
lpr-server <i>address</i>	Dotted decimal address specifying the IP address of Berkeley UNIX Version 4 BSD servers.
impress-server <i>address</i>	Dotted decimal address specifying the IP address of Impress network image servers.

Table 42 *tag Keyword Options (continued)*

Keyword	Description
rlp-server <i>address</i>	Dotted decimal address specifying the IP address of Resource Location Protocol (RLP) servers (as defined in RFC 887).
hostname <i>name</i>	The name of the client, which may or may not be domain qualified, depending upon the site.
bootfile-size <i>value</i>	A two-octet value specifying the number of 512-octet (byte) blocks in the default boot file.

Defaults

If no extended BOOTP commands are entered, the Cisco IOS software generates a gateway and subnet mask appropriate for the local network.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use the **show async-bootp EXEC** command to list the configured parameters. Use the **no async-bootp** command to clear the list.

Examples

The following example illustrates how to specify different boot files: one for a PC, and one for a Macintosh. With this configuration, a BOOTP request from the host on 172.30.1.1 results in a reply listing the boot filename as pcboot. A BOOTP request from the host named mac results in a reply listing the boot filename as macboot.

```
async-bootp bootfile :172.30.1.1 "pcboot"  
async-bootp bootfile :mac "macboot"
```

The following example specifies a subnet mask of 255.255.0.0:

```
async-bootp subnet-mask 255.255.0.0
```

The following example specifies a negative time offset of the local subnetwork of 3600 seconds:

```
async-bootp time-offset -3600
```

The following example specifies the IP address of a time server:

```
async-bootp time-server 172.16.1.1
```

Related Commands

Command	Description
show async bootp	Displays the extended BOOTP request parameters that have been configured for asynchronous interfaces.

ip ftp passive

To configure the router to use only passive File Transfer Protocol (FTP) connections, use the **ip ftp passive** global configuration command. To allow all types of FTP connections, use the **no** form of this command.

ip ftp passive

no ip ftp passive

Syntax Description

This command has no arguments or keywords.

Defaults

All types of FTP connections are allowed.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Examples

The following example configures the router to use only passive FTP connections:

```
ip ftp passive
```

Related Commands

Command	Description
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp source-interface	Specifies the source IP address for FTP connections.
ip ftp username	Configures the username for FTP connections.

ip ftp password

To specify the password to be used for File Transfer Protocol (FTP) connections, use the **ip ftp password** global configuration command. To return the password to its default, use the **no** form of this command.

ip ftp password [*type*] *password*

no ip ftp password

Syntax Description	<i>type</i>	(Optional) Type of encryption to use on the password. A value of 0 disables encryption. A value of 7 indicates proprietary encryption.
	<i>password</i>	Password to use for FTP connections.

Defaults	The router forms a password <i>username@routername.domain</i> . The variable <i>username</i> is the username associated with the current session, <i>routername</i> is the configured host name, and <i>domain</i> is the domain of the router.

Command Modes	Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Examples	The following example configures the router to use the username red and the password blue for FTP connections: <pre>ip ftp username red ip ftp password blue</pre>

Related Commands	Command	Description
	ip ftp password	Specifies the password to be used for FTP connections.
	ip ftp source-interface	Specifies the source IP address for FTP connections.
	ip ftp username	Configures the username for FTP connections.

ip ftp source-interface

To specify the source IP address for File Transfer Protocol (FTP) connections, use the **ip ftp source-interface** global configuration command. To use the address of the interface where the connection is made, use the **no** form of this command.

ip ftp source-interface *interface*

no ip ftp source-interface

Syntax Description

<i>interface</i>	The interface type and number to use to obtain the source address for FTP connections.

Defaults

The FTP source address is the IP address of the interface the FTP packets use to leave the router.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

Use this command to set the same source address for all FTP connections.

Examples

The following example configures the router to use the IP address associated with the Ethernet 0 interface as the source address on all FTP packets, regardless of which interface is actually used to send the packet:

```
ip ftp source-interface ethernet 0
```

Related Commands

Command	Description
ip ftp passive	Configures the router to use only passive FTP connections
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp username	Configures the username for FTP connections.

ip ftp username

To configure the username for File Transfer Protocol (FTP) connections, use the **ip ftp username** global configuration command. To configure the router to attempt anonymous FTP, use the **no** form of this command.

ip ftp username *username*

no ip ftp username

Syntax Description

<i>username</i>	Username for FTP connections.

Defaults

The Cisco IOS software attempts an anonymous FTP.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

The remote username must be associated with an account on the destination server.

Examples

In the following example, the router is configured to use the username “red” and the password “blue” for FTP connections:

```
Router(config)# ip ftp username red
Router(config)# ip ftp password blue
```

Related Commands

Command	Description
ip ftp passive	Configures the router to use only passive FTP connections.
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp source-interface	Specifies the source IP address for FTP connections.

ip rarp-server

To enable the router to act as a Reverse Address Resolution Protocol (RARP) server, use the **ip rarp-server** command in interface configuration mode. To restore the interface to the default of no RARP server support, use the **no** form of this command.

ip rarp-server *ip-address*

no ip rarp-server *ip-address*

Syntax Description

<i>ip-address</i>	IP address that is to be provided in the source protocol address field of the RARP response packet. Normally, this is set to whatever address you configure as the primary address for the interface.

Defaults

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This feature makes diskless booting of clients possible between network subnets where the client and server are on separate subnets.

RARP server support is configurable on a per-interface basis, so that the router does not interfere with RARP traffic on subnets that need no RARP assistance.

The Cisco IOS software answers incoming RARP requests only if both of the following two conditions are met:

- The **ip rarp-server** command has been configured for the interface on which the request was received.
- A static entry is found in the IP ARP table that maps the MAC address contained in the RARP request to an IP address.

Use the **show ip arp** EXEC command to display the contents of the IP ARP cache.

Sun Microsystems, Inc. makes use of RARP and UDP-based network services to facilitate network-based booting of SunOS on its workstations. By bridging RARP packets and using both the **ip helper-address** interface configuration command and the **ip forward-protocol** global configuration command, the Cisco IOS software should be able to perform the necessary packet switching to enable booting of Sun workstations across subnets. Unfortunately, some Sun workstations assume that the sender of the RARP response, in this case the router, is the host that the client can contact to TFTP load the bootstrap image. This causes the workstations to fail to boot.

By using the **ip rarp-server** command, the Cisco IOS software can be configured to answer these RARP requests, and the client machine should be able to reach its server by having its TFTP requests forwarded through the router that acts as the RARP server.

In the case of RARP responses to Sun workstations attempting to diskless boot, the IP address specified in the **ip rarp-server** interface configuration command should be the IP address of the TFTP server. In addition to configuring RARP service, the Cisco IOS software must be configured to forward UDP-based Sun portmapper requests to completely support diskless booting of Sun workstations. This can be accomplished using configuration commands of the following form:

```
ip forward-protocol udp 111
interface interface name
ip helper-address target-address
```

RFC 903 documents the RARP.

Examples

The following partial example configures a router to act as a RARP server. The router is configured to use the primary address of the specified interface in its RARP responses.

```
arp 172.30.2.5 0800.2002.ff5b arpa
interface ethernet 0
ip address 172.30.3.100 255.255.255.0
ip rarp-server 172.30.3.100
```

In the following example, a router is configured to act as a RARP server, with TFTP and portmapper requests forwarded to the Sun server:

```
! Allow the router to forward broadcast portmapper requests
ip forward-protocol udp 111
! Provide the router with the IP address of the diskless sun
arp 172.30.2.5 0800.2002.ff5b arpa
interface ethernet 0
! Configure the router to act as a RARP server, using the Sun Server's IP
! address in the RARP response packet.
ip rarp-server 172.30.3.100
! Portmapper broadcasts from this interface are sent to the Sun Server.
ip helper-address 172.30.3.100
```

Related Commands

Command	Description
ip forward-protocol	Speeds up flooding of UDP datagrams using the spanning-tree algorithm.
ip helper-address	Forwards UDP broadcasts, including BOOTP, received on an interface.

ip rcmd domain-lookup

To reenable the basic DNS security check for rcp and rsh, use the **ip rcmd domain-lookup** global configuration command. To disable the basic DNS security check for rcp and rsh, use the **no** form of this command.

ip rcmd domain-lookup

no ip rcmd domain-lookup

Syntax Description	This command has no arguments or keywords.	
Defaults	Enabled	
Command Modes	Global configuration	
Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines

The abbreviation RCMD (remote command) is used to indicate both rsh and rcp.

DNS lookup for RCMD is enabled by default (provided general DNS services are enabled on the system using the **ip domain-lookup** command).

The **no ip rcmd domain-lookup** command is used to disable the DNS lookup for RCMD. The **ip rcmd domain-lookup** command is used to reenable the DNS lookup for RCMD.

DNS lookup for RCMD is performed as a basic security check. This check is performed using a host authentication process. When enabled, the system records the address of the requesting client. That address is mapped to a host name using DNS. Then a DNS request is made for the IP address for that host name. The IP address received is then checked against the original requesting address. If the address does not match with any of the addresses received from DNS, the RCMD request will not be serviced.

This reverse lookup is intended to help protect against spoofing. However, please note that the process only confirms that the IP address is a valid “routable” address; it is still possible for a hacker to spoof the valid IP address of a known host.

The DNS lookup is done after the TCP handshake but before the router (which is acting as a rsh/rcp server) sends any data to the remote client.

The **no ip rcmd domain-lookup** will turn off DNS lookups for rsh and rcp only. The **no ip domain-lookup** command takes precedence over the **ip rcmd domain-lookup** command. This means that if the **no ip domain-lookup** command is in the current configuration, DNS will be bypassed for rcp and rsh even if the **ip rcmd domain-lookup** command is enabled.

Examples

In the following example, the DNS security check is disabled for RCMD (rsh/rcp):

```
Router(config)# no ip rcmd domain-lookup
```

Related Commands

Command	Description
ip domain-lookup	Enables the IP DNS-based host name-to-address translation.

ip rcmd rcp-enable

To configure the Cisco IOS software to allow remote users to copy files to and from the router using remote copy (rcp), use the **ip rcmd rcp-enable** global configuration command. To disable rcp on the device, use the **no** form of this command.

- ip rcmd rcp-enable**
- no ip rcmd rcp-enable**

Syntax Description This command has no arguments or keywords.

Defaults To ensure security, the router is not enabled for rcp by default.

Command Modes Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines

To allow a remote user to execute rcp commands on the router, you must also create an entry for the remote user in the local authentication database using the **ip rcmd remote-host** command.

The **no ip rcmd rcp-enable** command does not prohibit a local user from using rcp to copy system images and configuration files to and from the router.

To protect against unauthorized users copying the system image or configuration files, the router is not enabled for rcp by default.

Examples

In the following example, the rcp service is enabled on the system, the IP address assigned to the Loopback0 interface is used as the source address for outbound rcp and rsh packets, and access is granted to the user “netadmin3” on the remote host 172.16.101.101:

```
Router(config)# ip rcmd rcp-enable
Router(config)# ip rcmd source-interface Loopback0
Router(config)# ip rcmd remote-host router1 172.16.101.101 netadmin3
```

Related Commands	Command	Description
	ip rcmd remote-host	Creates an entry for the remote user in a local authentication database so that remote users can execute commands on the router using rsh or rcp.

ip rcmd remote-host

To create an entry for the remote user in a local authentication database so that remote users can execute commands on the router using rsh or rcp, use the **ip rcmd remote-host** command in global configuration mode. To remove an entry for a remote user from the local authentication database, use the **no** form of this command.

ip rcmd remote-host *local-username* { *ip-address* | *host-name* } *remote-username* [**enable** [*level*]]

no ip rcmd remote-host *local-username* { *ip-address* | *host-name* } *remote-username* [**enable** [*level*]]

Syntax Description	<i>local-username</i>	Name of the user on the local router. You can specify the router name as the username. This name needs to be communicated to the network administrator or to the user on the remote system. To be allowed to remotely execute commands on the router, the remote user must specify this value correctly.
	<i>ip-address</i>	IP address of the remote host from which the local router will accept remotely executed commands. Either the IP address or the host name is required.
	<i>host-name</i>	Name of the remote host from which the local router will accept remotely executed commands. Either the host name or the IP address is required.
	<i>remote-username</i>	Name of the user on the remote host from which the router will accept remotely executed commands.
	enable [<i>level</i>]	(Optional) Enables the remote user to execute privileged EXEC commands using rsh or to copy files to the router using rcp. The range is from 1 to 15. The default is 15. For information on the enable level, refer to the privilege level global configuration command in the Release 12.2 <i>Cisco IOS Security Command Reference</i> .

Defaults	No entries are in the local authentication database.

Command Modes	Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	A TCP connection to a router is established using an IP address. Using the host name is valid only when you are initiating an rcp or rsh command from a local router. The host name is converted to an IP address using DNS or host-name aliasing.

To allow a remote user to execute rcp or rsh commands on a local router, you must create an entry for the remote user in the local authentication database. You must also enable the router to act as an rsh or rcp server.

To enable the router to act as an rsh server, issue the **ip rcmd rsh-enable** command. To enable the router to act as an rcp server, issue the **ip rcmd rcp-enable** command. The router cannot act as a server for either of these protocols unless you explicitly enable the capacity.

A local authentication database, which is similar to a UNIX .rhosts file, is used to enforce security on the router through access control. Each entry that you configure in the authentication database identifies the local user, the remote host, and the remote user. To permit a remote user of rsh to execute commands in privileged EXEC mode or to permit a remote user of rcp to copy files to the router, specify the **enable** keyword and level. For information on the enable level, refer to the **privilege level** global configuration command in the Release 12.2 *Cisco IOS Security Command Reference*.

An entry that you configure in the authentication database differs from an entry in a UNIX .rhosts file in the following aspect. Because the .rhosts file on a UNIX system resides in the home directory of a local user account, an entry in a UNIX .rhosts file need not include the local username; the local username is determined from the user account. To provide equivalent support on a router, specify the local username along with the remote host and remote username in each authentication database entry that you configure.

For a remote user to be able to execute commands on the router in its capacity as a server, the local username, host address or name, and remote username sent with the remote client request must match values configured in an entry in the local authentication file.

A remote client host should be registered with DNS. The Cisco IOS software uses DNS to authenticate the remote host's name and address. Because DNS can return several valid IP addresses for a host name, the Cisco IOS software checks the address of the requesting client against all of the IP addresses for the named host returned by DNS. If the address sent by the requester is considered invalid, that is, it does not match any address listed with DNS for the host name, then the software will reject the remote-command execution request.

Note that if no DNS servers are configured for the router, then that device cannot authenticate the host in this manner. In this case, the Cisco IOS software sends a broadcast request to attempt to gain access to DNS services on another server. If DNS services are not available, you must use the **no ip domain-lookup** command to disable the attempt to gain access to a DNS server by sending a broadcast request.

If DNS services are not available and, therefore, you bypass the DNS security check, the software will accept the request to remotely execute a command *only if* all three values sent with the request match exactly the values configured for an entry in the local authentication file.

Examples

The following example allows the remote user named netadmin3 on a remote host with the IP address 172.16.101.101 to execute commands on router1 using the rsh or rcp protocol. User netadmin3 is allowed to execute commands in privileged EXEC mode.

```
ip rcmd remote-host router1 172.16.101.101 netadmin3 enable
```

Related Commands

Command	Description
ip rcmd rcp-enable	Configures the Cisco IOS software to allow remote users to copy files to and from the router.

Command	Description
ip rcmd rsh-enable	Configures the router to allow remote users to execute commands on it using the rsh protocol.
ip domain-lookup	Enables the IP DNS-based host name-to-address translation.

ip rcmd remote-username

To configure the remote username to be used when requesting a remote copy using rcp, use the **ip rcmd remote-username** global configuration command. To remove from the configuration the remote username, use the **no** form of this command.

```
ip rcmd remote-username username  
  
no ip rcmd remote-username username
```

Syntax Description	<i>username</i>	Name of the remote user on the server. This name is used for rcp copy requests. All files and images to be copied are searched for or written relative to the directory of the remote user’s account, if the server has a directory structure, for example, as do UNIX systems.

Defaults If you do not issue this command, the Cisco IOS software sends the remote username associated with the current tty process, if that name is valid, for rcp copy commands. For example, if the user is connected to the router through Telnet and the user was authenticated through the **username** command, then the software sends that username as the remote username.

 **Note** The remote username must be associated with an account on the destination server.

If the username for the current tty process is not valid, the Cisco IOS software sends the host name as the remote username. For rcp boot commands, the Cisco IOS software sends the access server host name by default.

 **Note** For Cisco, tty lines are commonly used for access services. The concept of tty originated with UNIX. For UNIX systems, each physical device is represented in the file system. Terminals are called tty devices (tty stands for teletype, the original UNIX terminal).

Command Modes Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines The rcp protocol requires that a client send the remote username on an rcp request to the server. Use this command to specify the remote username to be sent to the server for an rcp copy request. If the server has a directory structure, as do UNIX systems, all files and images to be copied are searched for or written relative to the directory of the remote user’s account.

**Note**

Cisco IOS Release 10.3 added the **ip** keyword to **rcmd** commands. If you are upgrading from Release 10.2 to Release 10.3 or a later release, this keyword is automatically added to any **rcmd** commands you have in your Release 10.2 configuration files.

Examples

The following example configures the remote username to netadmin1:

```
ip rcmd remote-username netadmin1
```

Related Commands

Command	Description
boot network rcp	Changes the default name of the network configuration file from which to load configuration commands.
boot system rcp	Specifies the system image that the router loads at startup.
bridge acquire	Forwards any frames for stations that the system has learned about dynamically.
copy	Copies any file from a source to a destination.

ip rcmd rsh-enable

To configure the router to allow remote users to execute commands on it using rsh, use the **ip rcmd rsh-enable** global configuration command. To disable a router that is enabled for rsh, use the **no** form of this command.

ip rcmd rsh-enable

no ip rcmd rsh-enable

Syntax Description

This command has no arguments or keywords.

Defaults

To ensure security, the router is not enabled for rsh by default.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

Remote Shell (rsh), used as a client process, gives users the ability to remotely get router info (such as status) without the need to connect into the router and then disconnect. This is valuable when looking at many statistics on many different routers.

Use this command to enable the router to receive rsh requests from remote users. In addition to issuing this command, you must create an entry for the remote user in the local authentication database to allow a remote user to execute rsh commands on the router.

The **no ip rcmd rsh-enable** command does not prohibit a local user of the router from executing a command on other routers and UNIX hosts on the network using rsh. The no form of this command only disables remote access to rsh on the router.

Examples

The following example enables a router as an rsh server:

```
ip rcmd rsh-enable
```

Related Commands

Command	Description
ip rcmd remote-host	Creates an entry for the remote user in a local authentication database so that remote users can execute commands on the router using rsh or rcp.

ip rcmd source-interface

To force rcp or rsh to use the IP address of a specified interface for all outgoing rcp/rsh communication packets, use the **ip rcmd source-interface** command in global configuration mode. To disable a previously configured **ip rcmd source-interface** command, use the **no** form of this command.

ip rcmd source-interface *interface-id*

no ip rcmd source-interface *interface-id*

Syntax Description

<i>interface-id</i>	The name and number used to identify the interface. For example, "Loopback2."

Defaults

The address of the interface closest to the destination is used as the source interface for rcp/rsh communications.

Command Modes

Global configuration

Command History

Release	Modification
11.3	This command was introduced.

Usage Guidelines

If this command is not used, or if the interface specified in this command is not available (not up), the Cisco IOS software uses the address of the interface closest to the destination as the source address.

Use this command to force the system to tag all outgoing rcp/rsh packets with the IP address associated with the specified interface. This address is used as the source address as long as the interface is in the up state.

This command is especially useful in cases where the router has many interfaces, and you want to ensure that all rcp and/or rsh packets from this router have the same source IP address. A consistent address is preferred so that the other end of the connection (the rcp/rsh server or client) can maintain a single session. The other benefit of a consistent address is that an access list can be configured on the remote device.

The specified interface must have an IP address associated with it. If the specified interface does not have an IP address or is in a down state, then rcp/rsh reverts to the default. To avoid this, add an IP address to the subinterface or bring the interface to the up state.

Examples

In the following example, the Loopback0 interface is assigned an IP address of 220.144.159.200, and the **ip rcmd source-interface** command is used to specify that the source IP address for all rcp/rsh packets will be the IP address assigned to the Loopback0 interface:

```
interface Loopback0
  description Loopback interface
  ip address 220.144.159.200 255.255.255.255
```

ip rcmd source-interface

```
no ip directed-broadcast
!
. . .
clock timezone GMT 0
ip subnet-zero
no ip source-route
no ip finger
ip rcmd source-interface Loopback0
ip telnet source-interface Loopback0
ip tftp source-interface Loopback0
ip ftp source-interface Loopback0
ip ftp username cisco
ip ftp password shhhhsecret
no ip bootp server
ip domain-name net.galaxy
ip name-server 220.144.159.1
ip name-server 220.144.159.2
ip name-server 219.10.2.1
!
. . .
```

Related Commands

Command	Description
ip rcmd remote-host	Creates an entry for the remote user in a local authentication database so that remote users can execute commands on the router using rsh or rcp.

mop device-code

To identify the type of device sending Maintenance Operation Protocol (MOP) System Identification (sysid) messages and request program messages, use the **mop device-code** global configuration command. To set the identity to the default value, use the **no** form of this command.

mop device-code {cisco | ds200}

no mop device-code {cisco | ds200}

Syntax Description

cisco	Denotes a Cisco device code.
ds200	Denotes a DECserver 200 device code.

Defaults

Cisco device code

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The sysid messages and request program messages use the identity information indicated by this command.

Examples

The following example identifies a DECserver 200 device as sending MOP sysid and request program messages:

```
mop device-code ds200
```

Related Commands

Command	Description
mop sysid	Enables an interface to send out periodic MOP system identification messages.

mop retransmit-timer

To configure the length of time that the Cisco IOS software waits before resending boot requests to a Maintenance Operation Protocol (MOP) server, use the **mop retransmit-timer** global configuration command. To reinstate the default value, use the **no** form of this command.

mop retransmit-timer *seconds*

no mop retransmit-timer

Syntax Description	<i>seconds</i>	Sets the length of time (in seconds) that the software waits before resending a message. The value is a number from 1 to 20.

Defaults	4 seconds

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	By default, when the software sends a request that requires a response from a MOP boot server and the server does not respond, the message is re-sent after 4 seconds. If the MOP boot server and router are separated by a slow serial link, it might take longer than 4 seconds for the software to receive a response to its message. Therefore, you might want to configure the software to wait longer than 4 seconds before resending the message if you are using such a link.

Examples	In the following example, if the MOP boot server does not respond within 10 seconds after the router sends a message, the server will resend the message:

```
mop retransmit-timer 10
```

Related Commands	Command	Description
	mop device-code	Identifies the type of device sending MOP sysid messages and requests program messages.
	mop enabled	Enables an interface to support the MOP.

mop retries

To configure the number of times the Cisco IOS software will resend boot requests to a Maintenance Operation Protocol (MOP) server, use the **mop retries** global configuration command. To reinstate the default value, use the **no** form of this command.

mop retries *count*

no mop retries

Syntax Description	<i>count</i>	Indicates the number of times the software will resend a MOP boot request. The value is a number from 3 to 24.
Defaults	8 times	
Command Modes	Global configuration	
Command History	Release	Modification
	10.0	This command was introduced.
Examples	In the following example, the software will attempt to resend a message to an unresponsive host 11 times before declaring a failure: <pre>mop retries 11</pre>	
Related Commands	Command	Description
	mop device-code	Identifies the type of device sending MOP sysid messages and requests program messages.
	mop enabled	Enables an interface to support the MOP server.
	mop retransmit-timer	Configures the length of time that the Cisco IOS software waits before resending boot requests to a MOP server.

rsh

To execute a command remotely on a remote rsh host, use the **rsh** privileged EXEC command.

```
rsh {ip-address | host} [/user username] remote-command
```

Syntax Description	<i>ip-address</i>	IP address of the remote host on which to execute the rsh command. Either the IP address or the host name is required.
	<i>host</i>	Name of the remote host on which to execute the command. Either the host name or the IP address is required.
	<i>/user username</i>	(Optional) Remote username.
	<i>remote-command</i>	Command to be executed remotely.

Defaults

If you do not specify the **/user username** keyword and argument, the Cisco IOS software sends a default remote username. As the default value of the remote username, the software sends the username associated with the current tty process, if that name is valid. For example, if the user is connected to the router through Telnet and the user was authenticated through the **username** command, then the software sends that username as the remote username. If the tty username is invalid, the software uses the host name as the both the remote and local usernames.



Note

For Cisco, tty lines are commonly used for access services. The concept of tty originated with UNIX. For UNIX systems, each physical device is represented in the file system. Terminals are sometimes called tty devices (tty stands for teletype, the original UNIX terminal).

Command Modes

Privileged EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use the **rsh** command to execute commands remotely. The host on which you remotely execute the command must support the rsh protocol, and the **.rhosts** files on the rsh host must include an entry that permits you to remotely execute commands on that host.

For security reasons, the software does not default to a remote login if no command is specified, as does UNIX. Instead, the router provides Telnet and connect services that you can use rather than rsh.

Examples

The following command specifies that the user named sharon attempts to remotely execute the UNIX **ls** command with the **-a** argument on the remote host named **mysys.cisco.com**. The command output resulting from the remote execution follows the command example:

```
Router1# rsh mysys.cisco.com /user sharon ls -a
.
```

```
..  
.alias  
.cshrc  
.emacs  
.exrc  
.history  
.login  
.mailrc  
.newsrc  
.oldnewsrc  
.rhosts  
.twmrc  
.xsession  
jazz
```

show async bootp

To display the extended BOOTP request parameters that have been configured for asynchronous interfaces, use the **show async bootp** privileged EXEC command.

show async bootp

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples The following is sample output from the **show async bootp** command:

```
Router# show async bootp
```

The following extended data will be sent in BOOTP responses:

```
bootfile (for address 192.168.1.1) "pcboot"
bootfile (for address 172.16.1.111) "dirtboot"
subnet-mask 255.255.0.0
time-offset -3600
time-server 192.168.1.1
```

[Table 43](#) describes the significant fields shown in the display.

Table 43 *show async bootp Field Descriptions*

Field	Description
bootfile... "pcboot"	Boot file for address 192.168.1.1 is named pcboot.
subnet-mask 255.255.0.0	Subnet mask.
time-offset -3600	Local time is one hour (3600 seconds) earlier than UTC time.
time-server 192.168.1.1	Address of the time server for the network.

Related Commands	Command	Description
	async-bootp	Configures extended BOOTP requests for asynchronous interfaces as defined in RFC 1084.

tftp-server

To configure a router or a Flash memory device on the router as a TFTP server, use one of the following **tftp-server** global configuration commands. This command replaces the **tftp-server system** command. To remove a previously defined filename, use the **no tftp-server** command with the appropriate filename.

```
tftp-server flash [partition-number:]filename1 [alias filename2] [access-list-number]
```

```
tftp-server rom alias filename1 [access-list-number]
```

```
no tftp-server { flash [partition-number:]filename1 | rom alias filename2 }
```

Cisco 1600 Series and Cisco 3600 Series Routers

```
tftp-server flash [device:][partition-number:]filename
```

```
no tftp-server flash [device:][partition-number:]filename
```

Cisco 7000 Family Routers

```
tftp-server flash device:filename
```

```
no tftp-server flash device:filename
```

Syntax Description	
flash	Specifies TFTP service of a file in Flash memory.
rom	Specifies TFTP service of a file in ROM.
<i>filename1</i>	Name of a file in Flash or in ROM that the TFTP server uses in answering TFTP Read Requests.
alias	Specifies an alternate name for the file that the TFTP server uses in answering TFTP Read Requests.
<i>filename2</i>	Alternate name of the file that the TFTP server uses in answering TFTP Read Requests. A client of the TFTP server can use this alternate name in its Read Requests.
<i>access-list-number</i>	(Optional) Basic IP access list number. Valid values are from 0 to 99.
<i>partition-number:</i>	(Optional) Specifies TFTP service of a file in the specified partition of Flash memory. If the partition number is not specified, the file in the first partition is used. For the Cisco 1600 series and Cisco 3600 series routers, you must enter a colon after the partition number if a filename follows it.

<i>device:</i>	(Optional) Specifies TFTP service of a file on a Flash memory device in the Cisco 1600 series, Cisco 3600 series, and Cisco 7000 family routers. The colon is required. Valid devices are as follows: • flash—Internal Flash memory on the Cisco 1600 series and Cisco 3600 series routers. This is the only valid device for the Cisco 1600 series routers. • bootflash—Internal Flash memory in the Cisco 7000 family routers. • slot0—First PCMCIA slot on the Cisco 3600 series and Cisco 7000 family routers. • slot1—Second PCMCIA slot on the Cisco 3600 series and Cisco 7000 family. • slavebootflash—Internal Flash memory on the slave RSP card of a Cisco 7507 or Cisco 7513 router configured for HSA. • slaveslot0—First PCMCIA slot of the slave RSP card on a Cisco 7507 or Cisco 7513 router configured for HSA. • slaveslot1—Second PCMCIA slot of the slave RSP card on a Cisco 7507 or Cisco 7513 router configured for HSA.
<i>filename</i>	Name of the file on a Flash memory device that the TFTP server uses in answering a TFTP Read Request. Use this argument only with the Cisco 1600 series, Cisco 3600 series, Cisco 7000 series, or Cisco 7500 series routers.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
11.0	This command was introduced.

Usage Guidelines

You can specify multiple filenames by repeating the **tftp-server** command. The system sends a copy of the system image contained in ROM or one of the system images contained in Flash memory to any client that issues a TFTP Read Request with this filename.

If the specified *filename1* or *filename2* argument exists in Flash memory, a copy of the Flash image is sent. On systems that contain a complete image in ROM, the system sends the ROM image if the specified *filename1* or *filename2* argument is not found in Flash memory.

Images that run from ROM cannot be loaded over the network. Therefore, it does not make sense to use TFTP to offer the ROMs on these images.

On the Cisco 7000 family routers, the system sends a copy of the file contained on one of the Flash memory devices to any client that issues a TFTP Read Request with its filename.

Examples

In the following example, the system uses TFTP to send a copy of the version-10.3 file located in Flash memory in response to a TFTP Read Request for that file. The requesting host is checked against access list 22.

```
tftp-server flash version-10.3 22
```

In the following example, the system uses TFTP to send a copy of the ROM image gs3-k.101 in response to a TFTP Read Request for the gs3-k.101 file:

```
tftp-server rom alias gs3-k.101
```

In the following example, the system uses TFTP to send a copy of the version-11.0 file in response to a TFTP Read Request for that file. The file is located on the Flash memory card inserted in slot 0.

```
tftp-server flash slot0:version-11.0
```

The following example enables a Cisco 3600 series router to operate as a TFTP server. The source file c3640-i-mz is in the second partition of internal Flash memory.

```
Router# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.  
router(config)# tftp-server flash flash:2:dirt/gate/c3640-i-mz
```

In the following example, the source file is in the second partition of the Flash memory PC card in slot 0 on a Cisco 3600 series:

```
Router# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.  
router(config)# tftp-server flash slot0:2:dirt/gate/c3640-j-mz
```

The following example enables a Cisco 1600 series router to operate as a TFTP server. The source file c1600-i-mz is in the second partition of Flash memory:

```
router# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.  
router(config)# tftp-server flash flash:2:dirt/gate/c1600-i-mz
```

Related Commands


Command	Description
access-list	Creates an extended access list.

tftp-server system

The **tftp-server system** command has been replaced by the **tftp-server** command. See the description of the [tftp-server](#) command in this chapter for more information.



System Management Commands



Basic System Management Commands

This chapter describes the commands used to perform basic system management tasks, such as naming the router and setting time services. This documentation is specific to Cisco IOS Release 12.2.

For basic system management configuration tasks and examples, refer to the “Performing Basic System Management” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

absolute

To specify an absolute time when a time range is in effect, use the **absolute** time-range configuration command. To remove the time limitation, use the **no** form of this command.

absolute [*start time date*] [*end time date*]

no absolute

Syntax Description

start time date	(Optional) Absolute time and date that the permit or deny statement of the associated access list starts going into effect. The <i>time</i> is expressed in 24-hour notation, in the form of <i>hours:minutes</i> . For example, 8:00 is 8:00 a.m. and 20:00 is 8:00 p.m. The <i>date</i> is expressed in the format <i>day month year</i> . The minimum start is 00:00 1 January 1993. If no start time and date are specified, the permit or deny statement is in effect immediately.
end time date	(Optional) Absolute time and date that the permit or deny statement of the associated access list is no longer in effect. Same <i>time</i> and <i>date</i> format as described for the start keyword. The end time and date must be after the start time and date. The maximum end time is 23:59 31 December 2035. If no end time and date are specified, the associated permit or deny statement is in effect indefinitely.

Defaults

There is no absolute time when the time range is in effect.

Command Modes

Time-range configuration

Command History

Release	Modification
12.0(1)T	This command was introduced.

Usage Guidelines

Time ranges are used by IP and IPX extended access lists. For more information on using these functions, see the Release 12.2 *Cisco IOS IP Configuration Guide* and the Release 12.2 *Cisco IOS AppleTalk and Novell IPX Configuration Guide*. Time ranges are applied to the **permit** or **deny** statements found in these access lists.

The **absolute** command is one way to specify when a time range is in effect. Another way is to specify a periodic length of time with the **periodic** command. Use either of these commands after the **time-range** command, which enables time-range configuration mode and specifies a name for the time range. Only one **absolute** entry is allowed per **time-range** command.

If a **time-range** command has both **absolute** and **periodic** values specified, then the **periodic** items are evaluated only after the **absolute start** time is reached, and are not further evaluated after the **absolute end** time is reached.



Note

All time specifications are interpreted as local time. To ensure that the time range entries take effect at the desired times, the software clock should be synchronized using the Network Time Protocol (NTP), or some other authoritative time source. For more information, refer to the “Performing Basic System

Management” chapter of the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Examples

The following example configures an access list named northeast, which references a time range named xyz. The access list and time range together permit traffic on Ethernet interface 0 starting at noon on January 1, 2001 and going forever.

```
time-range xyz
  absolute start 12:00 1 January 2001
!
ip access-list extended northeast
  permit ip any any time-range xyz
!
interface ethernet 0
  ip access-group northeast in
```

The following example permits UDP traffic until noon on December 31, 2000. After that time, UDP traffic is no longer allowed out Ethernet interface 0.

```
time-range abc
  absolute end 12:00 31 December 2000
!
ip access-list extended northeast
  permit udp any any time-range abc
!
interface ethernet 0
  ip access-group northeast out
```

The following example permits UDP traffic out Ethernet interface 0 on weekends only, from 8:00 a.m. on January 1, 1999 to 6:00 p.m. on December 31, 2001:

```
time-range test
  absolute start 8:00 1 January 1999 end 18:00 31 December 2001
  periodic weekends 00:00 to 23:59
!
ip access-list extended northeast
  permit udp any any time-range test
!
interface ethernet 0
  ip access-group northeast out
```

Related Commands

Command	Description
deny	Sets conditions under which a packet does not pass a named access list.
periodic	Specifies a recurring (weekly) start and end time for a time range.
permit	Sets conditions under which a packet passes a named access list.
time-range	Enables time-range configuration mode and names a time range definition.

alias

To create a command alias, use the **alias** global configuration command. To delete all aliases in a command mode or to delete a specific alias, and to revert to the original command syntax, use the **no** form of this command.

```
alias mode command-alias original-command
```

```
no alias mode [command-alias]
```

Syntax Description

mode	Command mode of the original and alias commands.
command-alias	Command alias.
original-command	Original command syntax.

Defaults

A set of six basic EXEC mode aliases are enabled by default. See the “Usage Guidelines” section of this command for a list of default aliases.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

You can use simple words or abbreviations as command aliases.
[Table 44](#) lists the basic EXEC mode aliases that are enabled by default.

Table 44 Default Command Aliases

Command Alias	Original Command
h	help
lo	logout
p	ping
r	resume
s	show
w	where

The default aliases in [Table 44](#) are predefined. These default aliases can be disabled with the **no alias exec** command.

Common keyword aliases (which can not be disabled) include **running-config** (keyword alias for **system:running-config**) and **startup-config** (keyword alias for **nvrn:startup-config**). See the description of the **copy** command for more information about these keyword aliases.

Note that aliases can be configured for keywords instead of entire commands. You can create, for example, an alias for the first part of any command and still enter the additional keywords and arguments as normal.

To determine the value for the mode argument, enter the command mode in which you would issue the original command (and in which you will issue the alias) and enter the **?** command. The name of the command mode should appear at the top of the list of commands. For example, the second line in the following sample output shows the name of the command mode as “Interface configuration”:

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interface e0
Router(config-if)#?
Interface configuration commands:
  access-expression      Build a bridge boolean access expression
  .
  .
  .
```

To match the name of the command mode to the acceptable mode keyword for the **alias** command, issue the **alias ?** command. As shown in the following sample output, the keyword needed to create a command alias for the access-expression command is **interface**:

```
Router(config)# alias ?
  accept-dialin          VPDN group accept dialin configuration mode
  accept-dialout         VPDN group accept dialout configuration mode
  address-family         Address Family configuration mode
  call-discriminator     Call Discriminator Configuration
  cascustom              Cas custom configuration mode
  clid-group             CLID group configuration mode
  configure              Global configuration mode
  congestion             Frame Relay congestion configuration mode
  controller             Controller configuration mode
  cptone-set            custom call progress tone configuration mode
  customer-profile       customer profile configuration mode
  dhcp                  DHCP pool configuration mode
  dnis-group             DNIS group configuration mode
  exec                   Exec mode
  flow-cache             Flow aggregation cache config mode
  fr-fr                 FR/FR connection configuration mode
  interface              Interface configuration mode
  .
  .
  .
Router(config)# alias interface express access-expression
```

For a list of command modes with descriptions and references to related documentation, refer to the “Cisco IOS Command Modes” appendix of the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

When you use online help, command aliases are indicated by an asterisk (*), and displayed in the following format:

**command-alias=original-command*

For example, the **lo** command alias is shown here along with other EXEC mode commands that start with “lo”:

```
Router#lo?
*lo=logout  lock  login  logout
```

When you use online help, aliases that contain multiple keyword elements separated by spaces are displayed in quotes, as shown here:

```
Router(config)#alias exec device-mail telnet device.cisco.com 25
Router(config)#end
Router#device-mail?
*device-mail="telnet device.cisco.com 25"
```

To list only commands and omit aliases, begin your input line with a space. In the following example, the alias **td** is not shown, because there is a space before the **t?** command line.

```
Router(config)#alias exec td telnet device
Router(config)#end
Router# t?
telnet terminal test tn3270 trace
```

To circumvent command aliases, use a space before entering the command. In the following example, the command alias **express** is not recognized because a space is used before the command.

```
Router(config-if)#exp?
*express=access-expression
Router(config-if)# express ?
% Unrecognized command
```

As with commands, you can use online help to display the arguments and keywords that can follow a command alias. In the following example, the alias **td** is created to represent the command **telnet device**. The **/debug** and **/line** switches can be added to **telnet device** to modify the command:

```
Router(config)#alias exec td telnet device
Router(config)#end
Router#td ?
    /debug      Enable telnet debugging mode
    /line       Enable telnet line mode
    ...
    whois       Whois port
    <cr>
Router# telnet device
```

You must enter the complete syntax for the command alias. Partial syntax for aliases is not accepted. In the following example, the parser does not recognize the command **t** as indicating the alias **td**:

```
Router#t
% Ambiguous command: "t"
```

Examples

In the following example, the alias **fixmyrt** is configured for the **clear iproute 209.165.201.16 EXEC** mode command:

```
Router(config)# alias exec fixmyrt clear ip route 209.165.201.16
```

In the following example, the alias **express** is configured for the first part of the **access-expression** interface configuration command:

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interface e0
Router(config-if)#?
Interface configuration commands:
    access-expression      Build a bridge boolean access expression
    .
    .
    .
```



```

Router(config-if)#exit
Router(config)#alias ?
  accept-dialin      VPDN group accept dialin configuration mode
  accept-dialout     VPDN group accept dialout configuration mode
  address-family     Address Family configuration mode
  call-discriminator Call Discriminator Configuration
  cascustom          Cas custom configuration mode
  clid-group         CLID group configuration mode
  configure          Global configuration mode
  congestion         Frame Relay congestion configuration mode
  controller         Controller configuration mode
  cptone-set         custom call progress tone configuration mode
  customer-profile   customer profile configuration mode
  dhcp              DHCP pool configuration mode
  dnis-group         DNIS group configuration mode
  exec              Exec mode
  flow-cache        Flow aggregation cache config mode
  fr-fr             FR/FR connection configuration mode
  interface         Interface configuration mode
.
.
.

```

```
Router(config)#alias interface express access-expression
```

```
Router(config)#int e0
```

```
Router(config-if)#exp?
```

```
*express=access-expression
```

```
Router(config-if)#express ?
```

```
  input      Filter input packets
  output     Filter output packets
```

!Note that the true form of the command/keyword alias appears on the screen after issuing !the express ? command.

```
Router(config-if)#access-expression ?
```

```
  input      Filter input packets
  output     Filter output packets
```

```
Router(config-if)#ex?
```

```
*express=access-expression exit
```

!Note that in the following line, a space is used before the ex? command !so the alias is not displayed.

```
Router(config-if)# ex?
exit
```

!Note that in the following line, the alias can not be recognized because !a space is used before the command.

```
Router(config-if)# express ?
```

```
% Unrecognized command
```

```
Router(config-if)#end
```

```
Router#show alias interface
```

```
Interface configuration mode aliases:
  express          access-expression
```

Related Commands

Command	Description
show aliases	Displays command aliases.

buffers

To make adjustments to initial buffer pool settings and to the limits at which temporary buffers are created and destroyed, use the **buffers** global configuration command. To return the buffers to their default size, use the **no** form of this command.

buffers { **small** | **middle** | **big** | **verybig** | **large** | **huge** | *type number* } { **permanent** | **max-free** | **min-free** | **initial** } *number-of-buffers*

no buffers { **small** | **middle** | **big** | **verybig** | **large** | **huge** | *type number* } { **permanent** | **max-free** | **min-free** | **initial** } *number-of-buffers*

Syntax Description

small	Buffer size of this public buffer pool is 104 bytes.
middle	Buffer size of this public buffer pool is 600 bytes.
big	Buffer size of this public buffer pool is 1524 bytes.
verybig	Buffer size of this public buffer pool is 4520 bytes.
large	Buffer size of this public buffer pool is 5024 bytes.
huge	Default buffer size of this public buffer pool is 18024 bytes. This value can be configured with the buffers huge size command.
<i>type number</i>	Interface type and interface number of the interface buffer pool. The <i>type</i> value cannot be fdi .
permanent	Number of permanent buffers that the system tries to create and keep. Permanent buffers are normally not trimmed by the system.
max-free	Maximum number of free or unallocated buffers in a buffer pool. A maximum of 20,480 small buffers can be constructed in the pool.
min-free	Minimum number of free or unallocated buffers in a buffer pool.
initial	Number of additional temporary buffers that are to be allocated when the system is reloaded. This keyword can be used to ensure that the system has necessary buffers immediately after reloading in a high-traffic environment.
<i>number-of-buffers</i>	Number of buffers to be allocated.

Defaults

The default number of buffers in a pool is determined by the hardware configuration and can be displayed with the **show buffers EXEC** command.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Normally you need not adjust these parameters; do so only after consulting with technical support personnel.

**Note**

Improper buffer settings can adversely impact system performance.

You cannot configure FDDI buffers.

Examples**Examples of Public Buffer Pool Tuning**

The following example keeps at least 50 small buffers free in the system:

```
Router(config)# buffers small min-free 50
```

The following example increases the permanent buffer pool allocation for big buffers to 200:

```
Router(config)# buffers big permanent 200
```

Example of Interface Buffer Pool Tuning

A general guideline is to display buffers with the **show buffers** command, observe which buffer pool is depleted, and increase that one.

The following example increases the permanent Ethernet interface 0 buffer pool on a Cisco 4000 router to 96 when the Ethernet 0 buffer pool is depleted:

```
Router(config)# buffers ethernet 0 permanent 96
```

Related Commands

Command	Description
load-interval	Changes the length of time for which data is used to compute load statistics.
show buffers	Displays statistics for the buffer pools on the network server.

buffers huge size

To dynamically resize all huge buffers to the value you specify, use the **buffers huge size** global configuration command. To restore the default buffer values, use the **no** form of this command.

buffers huge size *number-of-bytes*

no buffers huge size *number-of-bytes*

Syntax Description

number-of-bytes Huge buffer size (in bytes).

Defaults

18,024 bytes

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use this command only after consulting with technical support personnel. The buffer size cannot be lowered below the default.



Note

Improper buffer settings can adversely impact system performance.

Examples

The following example resizes huge buffers to 20,000 bytes:

```
Router(config)# buffers huge size 20000
```

Related Commands

Command	Description
buffers	Adjusts the initial buffer pool settings and the limits at which temporary buffers are created and destroyed.
show buffers	Displays statistics for the buffer pools on the network server.

calendar set

To manually set the hardware clock (calendar), use one of the formats of the **calendar set** EXEC command.

calendar set *hh:mm:ss day month year*

calendar set *hh:mm:ss month day year*

Syntax Description

<i>hh:mm:ss</i>	Current time in hours (using 24-hour notation), minutes, and seconds.
<i>day</i>	Current day (by date) in the month.
<i>month</i>	Current month (by name).
<i>year</i>	Current year (no abbreviation).

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Some platforms have a hardware clock that is separate from the software clock. In Cisco IOS software syntax, the hardware clock is called the “calendar.” The hardware clock is a battery-powered chip that runs continuously, even if the router is powered off or rebooted. After you set the hardware clock, the software clock will be automatically set from the hardware clock when the system is restarted or when the **clock read-calendar** EXEC command is issued. The time specified in this command is relative to the configured time zone.

Examples

The following example manually sets the hardware clock to 1:32 p.m. on July 23, 1997:

```
Router# calendar set 13:32:00 23 July 1997
```

Related Commands

Command	Description
clock read-calendar	Performs a one-time update of the software clock from the hardware clock (calendar).
clock set	Sets the software clock.
clock summer-time	Configures the system time to automatically switch to summer time (daylight saving time).
clock timezone	Sets the time zone for display purposes.
clock update-calendar	Performs a one-time update of the hardware clock from the software clock.

clock calendar-valid

To configure a system as an authoritative time source for a network based on its hardware clock (calendar), use the **clock calendar-valid** global configuration command. To specify that the hardware clock is not an authoritative time source, use the **no** form of this command.

clock calendar-valid

no clock calendar-valid

Syntax Description

This command has no arguments or keywords.

Defaults

The router is not configured as a time source.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Some platforms have a hardware clock that is separate from the software clock. The hardware clock runs continuously, even if the router is powered off or rebooted. If no outside time source is available on your network, use this command to make the hardware clock an authoritative time source.

Because the hardware clock is not as accurate as other time sources, you should configure this command only when a more accurate time source (such as NTP) is not available.

Examples

The following example configures a router as the time source for a network based on its hardware clock:

```
Router(config)# clock calendar-valid
```

Related Commands

Command	Description
ntp master	Configures the Cisco IOS software as an NTP master clock to which peers synchronize themselves when an external NTP source is not available.
vines time use-system	Sets VINES network time based on the system time.

clock read-calendar

To manually read the hardware clock (calendar) settings into the software clock, use the **clock read-calendar** EXEC command.

clock read-calendar

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Some platforms have a hardware clock that is separate from the software clock. The hardware clock runs continuously, even if the router is powered off or rebooted. When the router is rebooted, the hardware clock is automatically read into the software clock. However, you may use this command to manually read the hardware clock setting into the software clock. This command is useful if the calendar set command has been used to change the setting of the hardware clock.

Examples	The following example configures the software clock to set its date and time by the hardware clock setting: Router> clock read-calendar

Related Commands	Command	Description
	calendar set	Sets the hardware clock.
	clock set	Manually sets the software clock.
	clock update-calendar	Performs a one-time update of the hardware clock from the software clock.
	ntp update-calendar	Periodically updates the hardware clock from the software clock.

clock set

To manually set the system software clock, use one of the formats of the **clock set** command in privileged EXEC mode.

clock set *hh:mm:ss day month year*

clock set *hh:mm:ss month day year*

Syntax Description

<i>hh:mm:ss</i>	Current time in hours (military format), minutes, and seconds.
<i>day</i>	Current day (by date) in the month.
<i>month</i>	Current month (by name).
<i>year</i>	Current year (no abbreviation).

Command Modes

Privileged EXEC mode

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Generally, if the system is synchronized by a valid outside timing mechanism, such as a Network Time Protocol (NTP) or VINES clock source, or if you have a router with hardware clock, you need not set the software clock. Use this command if no other time sources are available. The time specified in this command is relative to the configured time zone.

Examples

The following example manually sets the software clock to 1:32 p.m. on July 23, 1997:

```
Router# clock set 13:32:00 23 July 1997
```

Related Commands

Command	Description
calendar set	Sets the hardware clock.
clock read-calendar	Performs a one-time update of the software clock from the hardware clock (calendar).
clock summer-time	Configures the system to automatically switch to summer time (daylight saving time).
clock timezone	Sets the time zone for display purposes.

clock summer-time

To configure the system to automatically switch to summer time (daylight saving time), use one of the formats of the **clock summer-time** global configuration command. To configure the Cisco IOS software not to automatically switch to summer time, use the **no** form of this command.

clock summer-time *zone* **recurring** [*week day month hh:mm week day month hh:mm* [*offset*]]

clock summer-time *zone* **date** *date month year hh:mm date month year hh:mm* [*offset*]

clock summer-time *zone* **date** *month date year hh:mm month date year hh:mm* [*offset*]

no clock summer-time

Syntax	Description
<i>zone</i>	Name of the time zone (for example, “PDT” for Pacific Daylight Time) to be displayed when summer time is in effect.
recurring	Indicates that summer time should start and end on the corresponding specified days every year.
date	Indicates that summer time should start on the first specific date listed in the command and end on the second specific date in the command.
<i>week</i>	(Optional) Week of the month (1 to 5 or last).
<i>day</i>	(Optional) Day of the week (Sunday, Monday, and so on).
<i>date</i>	Date of the month (1 to 31).
<i>month</i>	(Optional) Month (January, February, and so on).
<i>year</i>	Year (1993 to 2035).
<i>hh:mm</i>	(Optional) Time (military format) in hours and minutes.
<i>offset</i>	(Optional) Number of minutes to add during summer time (default is 60).

Defaults Summer time is disabled. If the **clock summer-time** *zone* **recurring** command is specified without parameters, the summer time rules default to United States rules. Default of the *offset* argument is 60.

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Use this command if you want to automatically switch to summer time (for display purposes only). Use the **recurring** form of the command if the local summer time rules are of this form. Use the **date** form to specify a start and end date for summer time if you cannot use the **recurring** form.

In both the **date** and **recurring** forms of the command, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is chronologically after the ending month, the system assumes that you are in the southern hemisphere.

Examples

The following example specifies that summer time starts on the first Sunday in April at 2 a.m. and ends on the last Sunday in October at 2 a.m.:

```
Router(config)# clock summer-time PDT recurring 1 Sunday April 2:00 last Sunday October 2:00
```

If you live in a place where summer time does not follow the pattern in the first example, you can specify the exact date and times. In the following example, daylight saving time (summer time) is configured to start on October 12, 1997 at 2 a.m., and end on April 26, 1998 at 2 a.m.:

```
Router(config)# clock summer-time date 12 October 1997 2:00 26 April 1998 2:00
```

Related Commands

Command	Description
calendar set	Sets the hardware clock.
clock timezone	Sets the time zone for display purposes.

clock timezone

To set the time zone for display purposes, use the **clock timezone** global configuration command. To set the time to Coordinated Universal Time (UTC), use the **no** form of this command.

clock timezone *zone* *hours-offset* [*minutes-offset*]

no clock timezone

Syntax Description

<i>zone</i>	Name of the time zone to be displayed when standard time is in effect.
<i>hours-offset</i>	Hours difference from UTC.
<i>minutes-offset</i>	(Optional) Minutes difference from UTC.

Defaults

UTC

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The system internally keeps time in UTC, so this command is used only for display purposes and when the time is manually set.

[Table 45](#) lists common time zone acronyms used for the *zone* argument.

Table 45 Common Time Zone Acronyms

Acronym	Time Zone Name and UTC Offset
Europe	
GMT	Greenwich Mean Time, as UTC
BST	British Summer Time, as UTC + 1 hour
IST	Irish Summer Time, as UTC + 1 hour
WET	Western Europe Time, as UTC
WEST	Western Europe Summer Time, as UTC + 1 hour
CET	Central Europe Time, as UTC + 1
CEST	Central Europe Summer Time, as UTC + 2
EET	Eastern Europe Time, as UTC + 2
EEST	Eastern Europe Summer Time, as UTC + 3
MSK	Moscow Time, as UTC + 3
MSD	Moscow Summer Time, as UTC + 4

Table 45 Common Time Zone Acronyms (continued)

Acronym	Time Zone Name and UTC Offset
United States and Canada	
AST	Atlantic Standard Time, as UTC –4 hours
ADT	Atlantic Daylight Time, as UTC –3 hours
ET	Eastern Time, either as EST or EDT, depending on place and time of year
EST	Eastern Standard Time, as UTC –5 hours
EDT	Eastern Daylight Saving Time, as UTC –4 hours
CT	Central Time, either as CST or CDT, depending on place and time of year
CST	Central Standard Time, as UTC –6 hours
CDT	Central Daylight Saving Time, as UTC –5 hours
MT	Mountain Time, either as MST or MDT, depending on place and time of year
MST	Mountain Standard Time, as UTC –7 hours
MDT	Mountain Daylight Saving Time, as UTC –6 hours
PT	Pacific Time, either as PST or PDT, depending on place and time of year
PST	Pacific Standard Time, as UTC –8 hours
PDT	Pacific Daylight Saving Time, as UTC –7 hours
AKST	Alaska Standard Time, as UTC –9 hours
AKDT	Alaska Standard Daylight Saving Time, as UTC –8 hours
HST	Hawaiian Standard Time, as UTC –10 hours
Australia	
WST	Western Standard Time, as UTC + 8 hours
CST	Central Standard Time, as UTC + 9.5 hours
EST	Eastern Standard/Summer Time, as UTC + 10 hours (+11 hours during summer time)

Table 46 lists an alternative method for referring to time zones, in which single letters are used to refer to the time zone difference from UTC. Using this method, the letter Z is used to indicate the zero meridian, equivalent to UTC, and the letter J (Juliet) is used to refer to the local time zone. Using this method, the International Date Line is between time zones M and Y.

Table 46 Single-Letter Time Zone Designators

Letter Designator	Word Designator	Difference from UTC
Y	Yankee	UTC –12 hours
X	Xray	UTC –11 hours
W	Whiskey	UTC –10 hours

Table 46 *Single-Letter Time Zone Designators (continued)*

Letter Designator	Word Designator	Difference from UTC
Y	Yankee	UTC -12 hours
V	Victor	UTC -9 hours
U	Uniform	UTC -8 hours
T	Tango	UTC -7 hours
S	Sierra	UTC -6 hours
R	Romeo	UTC -5 hours
Q	Quebec	UTC -4 hours
P	Papa	UTC -3 hours
O	Oscar	UTC -2 hours
N	November	UTC -1 hour
Z	Zulu	Same as UTC
A	Alpha	UTC +1 hour
B	Bravo	UTC +2 hours
C	Charlie	UTC +3 hours
D	Delta	UTC +4 hours
E	Echo	UTC +5 hours
F	Foxtrot	UTC +6 hours
G	Golf	UTC +7 hours
H	Hotel	UTC +8 hours
I	India	UTC +9 hours
K	Kilo	UTC +10 hours
L	Lima	UTC +11 hours
M	Mike	UTC +12 hours

The following example sets the time zone to Pacific Standard Time (PST), which is 8 hours behind UTC:

```
Router(config)# clock timezone PST -8
```

The following example sets the time zone to Atlantic Time (AT) for Newfoundland, Canada, which is 3.5 hours behind UTC:

```
Router(config)# clock timezone AT -3 30
```

Related Commands

Command	Description
calendar set	Sets the hardware clock.
clock set	Manually set the software clock.
clock summer-time	Configures the system to automatically switch to summer time (daylight saving time).
show clock	Displays the software clock.

clock update-calendar

To perform a one-time update of the hardware clock (calendar) from the software clock, use the **clock update-calendar** in user or privileged EXEC mode.

clock update-calendar

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Some platforms have a hardware clock (calendar) in addition to a software clock. The hardware clock is battery operated, and runs continuously, even if the router is powered off or rebooted.

If the software clock and hardware clock are not synchronized, and the software clock is more accurate, use this command to update the hardware clock to the correct date and time.

Examples The following example copies the current date and time from the software clock to the hardware clock:

```
Router> clock update-calendar
```

Related Commands	Command	Description
	clock read-calendar	Performs a one-time update of the software clock from the hardware clock (calendar).
	ntp update-calendar	Periodically updates the hardware clock from the software clock.

downward-compatible-config

To generate a configuration that is compatible with an earlier Cisco IOS release, use the **downward-compatible-config** global configuration command. To remove this feature, use the **no** form of this command.

downward-compatible-config *version*

no downward-compatible-config

Syntax Description	<i>version</i> Cisco IOS release number, not earlier than Release 10.2.							
Defaults	Disabled							
Command Modes	Global configuration							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.1</td><td>This command was introduced.</td></tr></table>		Release	Modification	11.1	This command was introduced.		
Release	Modification							
11.1	This command was introduced.							
Usage Guidelines	In Cisco IOS Release 10.3, IP access lists changed format. Use the downward-compatible-config command to regenerate a configuration in a format prior to Release 10.3 if you are going to downgrade from your software version to version 10.2 or 10.3. The earliest <i>version</i> value this command accepts is 10.2. When this command is configured, the router attempts to generate a configuration that is compatible with the specified version. Note that this command affects only IP access lists. Under some circumstances, the software might not be able to generate a fully backward-compatible configuration. In such a case, the software issues a warning message.							
Examples	The following example generates a configuration file compatible with Cisco IOS Release 10.2 access lists: <pre>Router(config)# downward-compatible-config 10.2</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>access-list (extended)</td><td>Provides extended access lists that allow more detailed access lists.</td></tr><tr><td>access-list (standard)</td><td>Defines a standard XNS access list.</td></tr></table>		Command	Description	access-list (extended)	Provides extended access lists that allow more detailed access lists.	access-list (standard)	Defines a standard XNS access list.
Command	Description							
access-list (extended)	Provides extended access lists that allow more detailed access lists.							
access-list (standard)	Defines a standard XNS access list.							

hostname

To specify or modify the host name for the network server, use the **hostname** global configuration command.

hostname *name*

Syntax Description

<i>name</i>	New host name for the network server.

Defaults

The factory-assigned default host name is Router.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The host name is used in prompts and default configuration filenames.

Do not expect case to be preserved. Upper- and lowercase characters look the same to many internet software applications. It may seem appropriate to capitalize a name the same way you might do in English, but conventions dictate that computer names appear all lowercase. For more information, refer to RFC 1178, *Choosing a Name for Your Computer*.

The name must also follow the rules for ARPANET host names. They must start with a letter, end with a letter or digit, and have as interior characters only letters, digits, and hyphens. Names must be 63 characters or fewer. For more information, refer to RFC 1035, *Domain Names—Implementation and Specification*.

Examples

The following example changes the host name to “sandbox”:

```
Router(config)# hostname sandbox
```

Related Commands

Command	Description
setup	Enables you to make major enhancements to your configurations, for example, adding a protocol suit, making major addressing scheme changes, or configuring newly installed interfaces.

ip bootp server

To enable the BOOTP service on your routing device, use the **ip bootp server** global configuration command. To disable BOOTP services, use the **no** form of the command.

ip bootp server

no ip bootp server

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

By default, the BOOTP service is enabled. When disabled, the **no ip bootp server** command will appear in the configuration file.

The integrated Dynamic Host Configuration Protocol (DHCP) server was introduced in Cisco IOS Release 12.0(1)T. Because DHCP is based on BOOTP, both of these services share the “well-known” UDP server port of 67 (per RFC 951, RFC 1534, and RFC 2131). If both the BOOTP server and DHCP server are disabled, and a helper address is not configured, "ICMP port unreachable" messages will be sent in response to incoming requests on port 67, and the original incoming packet will be discarded.



Note

As with all minor services, the async line BOOTP service should be disabled on your system if you do not have a need for it in your network.

Any network device that has UDP, TCP, BOOTP, DHCP or Finger services should be protected by a firewall or have the services disabled to protect against Denial of Service attacks.

Examples

In the following example, BOOTP and DHCP services are disabled on the router:

```
Router(config)# no ip bootp server
Router(config)# no service dhcp
```

Related Commands

Command	Description
service dhcp	Enables the integrated Dynamic Host Configuration Protocol (DHCP) server and relay agent.

ip finger

To configure a system to accept Finger protocol requests (defined in RFC 742), use the **ip finger** global configuration command. To disable this service, use the **no** form of this command.

ip finger [rfc-compliant]

no ip finger

Syntax Description

rfc-compliant	(Optional) Configures the system to wait for “Return” or “/W” input when processing Finger requests. This keyword should not be used for those systems.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
11.3	This command was introduced.
12.1(5), 12.1(5)T	This command was changed from being enabled by default to being disabled by default.

Usage Guidelines

The Finger service allows remote users to view the output equivalent to the **show users [wide]** command.

When **ip finger** is configured, the router will respond to a **telnet a.b.c.d finger** command from a remote host by immediately displaying the output of the **show users** command and then closing the connection.

When the **ip finger rfc-compliant** command is configured, the router will wait for input before displaying anything (as required by RFC 1288). The remote user can then enter the Return key to display the output of the **show users EXEC** command, or enter **/W** to display the output of the **show users wide EXEC** command. After this information is displayed, the connection is closed.



Note

As with all minor services, the Finger service should be disabled on your system if you do not have a need for it in your network.

Any network device that has UDP, TCP, BOOTP, or Finger services should be protected by a firewall or have the services disabled to protect against Denial of Service attacks.

Because of the potential for hung lines, the **rfc-compliant** form of this command should not be configured for devices with more than 20 simultaneous users.

Examples

The following example disables the Finger protocol:

```
Router(config)# no ip finger
```

ip telnet source-interface

To specify the IP address of an interface as the source address for Telnet connections, use the **ip telnet source-interface** global configuration command. To reset the source address to the default for each connection, use the **no** form of this command.

ip telnet source-interface *interface*

no ip telnet source-interface

Syntax Description	<i>interface</i> The interface whose address is to be used as the source for Telnet connections.					
Defaults	The address of the closest interface to the destination as the source address.					
Command Modes	Global configuration					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.1</td><td>This command was introduced.</td></tr></table>		Release	Modification	11.1	This command was introduced.
Release	Modification					
11.1	This command was introduced.					
Usage Guidelines	Use this command to set the IP address of an interface as the source for all Telnet connections. If the specified interface is not up, the Cisco IOS software selects the address of the interface closest to the destination as the source address.					
Examples	The following example forces the IP address for Ethernet interface 1 as the source address for Telnet connections: <pre>Router(config)# ip telnet source-interface Ethernet1</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>ip radius source-interface</td><td>Forces RADIUS to use the IP address of a specified interface for all outgoing RADIUS packets.</td></tr></table>		Command	Description	ip radius source-interface	Forces RADIUS to use the IP address of a specified interface for all outgoing RADIUS packets.
Command	Description					
ip radius source-interface	Forces RADIUS to use the IP address of a specified interface for all outgoing RADIUS packets.					

ip tftp source-interface

To specify the IP address of an interface as the source address for TFTP connections, use the **ip tftp source-interface** global configuration command. To return to the default, use the no form of this command.

ip tftp source-interface *interface*

no ip tftp source-interface

Syntax Description	<i>interface</i> The interface whose address is to be used as the source for TFTP connections.							
Defaults	The address of the closest interface to the destination as the source address.							
Command Modes	Global configuration							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.1</td><td>This command was introduced.</td></tr></table>		Release	Modification	11.1	This command was introduced.		
Release	Modification							
11.1	This command was introduced.							
Usage Guidelines	Use this command to set the IP address of an interface as the source for all TFTP connections. If the specified interface is not up, the Cisco IOS software selects the address of the interface closest to the destination as the source address.							
Examples	In the following example, the IP address assigned to the Loopback0 interface will be used as the source address for TFTP connections: <pre>Router(config)# ip tftp source-interface Loopback0</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>ip ftp source-interface</td><td>Forces outgoing FTP packets to use the IP address of a specified interface as the source address.</td></tr><tr><td>ip radius source-interface</td><td>Forces outgoing RADIUS packets to use the IP address of a specified interface as the source address.</td></tr></table>		Command	Description	ip ftp source-interface	Forces outgoing FTP packets to use the IP address of a specified interface as the source address.	ip radius source-interface	Forces outgoing RADIUS packets to use the IP address of a specified interface as the source address.
Command	Description							
ip ftp source-interface	Forces outgoing FTP packets to use the IP address of a specified interface as the source address.							
ip radius source-interface	Forces outgoing RADIUS packets to use the IP address of a specified interface as the source address.							

load-interval

To change the length of time for which data is used to compute load statistics, use the **load-interval** interface configuration command. To revert to the default setting, use the **no** form of this command.

load-interval *seconds*

no load-interval *seconds*

Syntax Description	<i>seconds</i>	Length of time for which data is used to compute load statistics. A value that is a multiple of 30, from 30 to 600 (30, 60, 90, 120, and so on).

Defaults	300 seconds (5 minutes)

Command Modes	Interface configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	If you want load computations to be more reactive to short bursts of traffic, rather than averaged over 5-minute periods, you can shorten the length of time over which load averages are computed. If the load interval is set to 30 seconds, new data is used for load calculations over a 30-second period. This data is used to compute load statistics, including input rate in bits and packets per second, output rate in bits and packets per second, load, and reliability. Load data is gathered every 5 seconds. This data is used for a weighted average calculation in which more-recent load data has more weight in the computation than older load data. If the load interval is set to 30 seconds, the average is computed for the last 30 seconds of load data. The load-interval command allows you to change the default interval of 5 minutes to a shorter or longer period of time. If you change it to a shorter period of time, the input and output statistics that are displayed when you use the show interface command will be more current, and based on more instantaneous data, rather than reflecting a more average load over a longer period of time. This command is often used for dial backup purposes, to increase or decrease the likelihood of a backup interface being implemented, but it can be used on any interface.

Examples	In the following example, the default 5-minute average is set to a 30-second average. A burst in traffic that would not trigger a dial backup for an interface configured with the default 5-minute interval might trigger a dial backup for this interface that is set for a shorter, 30-second interval. <pre>Router(config)# interface serial 0 Router(config-if)# load-interval 30</pre>

load-interval

Related Commands

Command	Description
show interfaces	Displays statistics for all configured interfaces.

ntp access-group

To control access to the Network Time Protocol (NTP) services on the system, use the **ntp access-group** command in global configuration mode. To remove access control to the NTP services, use the **no** form of this command.

ntp access-group { **query-only** | **serve-only** | **serve** | **peer** } *access-list-number*

no ntp

Syntax Description

query-only	Allows only NTP control queries. See RFC 1305 (NTP version 3).
serve-only	Allows only time requests.
serve	Allows time requests and NTP control queries, but does not allow the system to synchronize to the remote system.
peer	Allows time requests and NTP control queries and allows the system to synchronize to the remote system.
<i>access-list-number</i>	Number (from 1 to 99) of a standard IP access list.

Defaults

No access control (full access granted to all systems)

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The access group options are scanned in the following order from least restrictive to most restrictive:

1. **peer**
2. **serve**
3. **serve-only**
4. **query-only**

Access is granted for the first match that is found. If no access groups are specified, all access is granted to all sources. If any access groups are specified, only the specified access is granted. This facility provides minimal security for the time services of the system. However, it can be circumvented by a determined programmer. If tighter security is desired, use the NTP authentication facility.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp access-group** command and you now want to remove not only the access group, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure a system to allow itself to be synchronized by a peer from access list 99. However, the system restricts access to allow only time requests from access list 42.

```
Router(config)# ntp access-group peer 99
Router(config)# ntp access-group serve-only 42
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
access-list	Configures the access list mechanism for filtering frames by protocol type or vendor code.

ntp authenticate

To enable Network Time Protocol (NTP) authentication, use the **ntp authenticate** command in global configuration mode. To disable the function, use the **no** form of this command.

ntp authenticate

no ntp

Syntax Description	This command has no arguments or keywords.

Defaults	No authentication

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command if you want authentication. If this command is specified, the system will not synchronize to a system unless it carries one of the authentication keys specified in the ntp trusted-key global configuration command.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp authenticate** command and you now want to disable not only the authentication, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples	The following example shows how to configure the system to synchronize only to systems that provide authentication key 42 in their NTP packets:

```
Router(config)# ntp authenticate
Router(config)# ntp authentication-key 42 md5 aNiceKey
Router(config)# ntp trusted-key 42
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authentication-key	Defines an authentication key for NTP.
ntp trusted-key	Authenticates the identity of a system to which NTP will synchronize.

ntp authentication-key

To define an authentication key for Network Time Protocol (NTP), use the **ntp authentication-key** command in global configuration mode. To remove the authentication key for NTP, use the **no** form of this command.

ntp authentication-key *number* **md5** *value*

no ntp

Syntax Description

<i>number</i>	Key number (from 1 to 4294967295).
md5	Authentication key. Message authentication support is provided using the message digest algorithm 5 (MD5) algorithm. The key type md5 is currently the only key type supported.
<i>value</i>	Key value (an arbitrary string of up to eight characters).

Defaults

No authentication key is defined for NTP.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use this command to define authentication keys for use with other NTP commands in order to provide a higher degree of security.



Note

When this command is written to NVRAM, the key is encrypted so that it is not displayed when the configuration is viewed.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the **no** form of **ntp** commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp authentication-key** command and you now want to remove not only the authentication key, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure the system to synchronize only to systems providing authentication key 42 in their NTP packets:

```
Router(config)# ntp authenticate
Router(config)# ntp authentication-key 42 md5 aNiceKey
Router(config)# ntp trusted-key 42
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authenticate	Enables NTP authentication.
ntp peer	Configures the software clock to synchronize a peer or to be synchronized by a peer.
ntp server	Allows the software clock to be synchronized by a time server.
ntp trusted-key	Authenticates the identity of a system to which NTP will synchronize.

ntp broadcast client

To configure the system to receive Network Time Protocol (NTP) broadcast packets on a specified interface, use the **ntp broadcast client** command in interface configuration mode. To disable this capability, use the **no** form of this command.

ntp broadcast client

no ntp

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Interface configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command to allow the system to listen to broadcast packets on an interface-by-interface basis. When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp broadcast client** command and you now want to remove not only the broadcast client capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples	In the following example, the system is configured to receive (listen to) NTP broadcasts on Ethernet interface 1:

```
Router(config)# interface ethernet 1  
Router(config-if)# ntp broadcast client
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp broadcast	Configures the specified interface to send NTP broadcast packets.
ntp broadcastdelay	Sets the estimated round-trip delay between the system and an NTP broadcast server.

ntp broadcast

To configure the system to send Network Time Protocol (NTP) broadcast packets on a specified interface, use the **ntp broadcast** command in interface configuration mode. To disable this capability, use the **no** form of this command.

ntp broadcast [*version number*]

no ntp

Syntax Description

version	(Optional) Indicates that a version is specified.
<i>number</i>	(Optional) Number from 1 to 3 indicating the NTP version.

Defaults

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the **no** form of **ntp** commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp broadcast** command and you now want to remove not only the broadcast capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure Ethernet interface 0 to send NTP version 2 broadcasts:

```
Router(config)# interface ethernet 0  
Router(config-if)# ntp broadcast version 2
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp broadcast client	Allows the system to receive NTP broadcast packets on an interface.
ntp broadcastdelay	Sets the estimated round-trip delay between the Cisco IOS software and an NTP broadcast server.

ntp broadcastdelay

To set the estimated round-trip delay between the Cisco IOS software and a Network Time Protocol (NTP) broadcast server, use the **ntp broadcastdelay** command in global configuration mode. To revert to the default value, use the **no** form of this command.

ntp broadcastdelay *microseconds*

no ntp

Syntax Description	<i>microseconds</i>	Estimated round-trip time (in microseconds) for NTP broadcasts. The range is from 1 to 999999.

Defaults	3000 microseconds

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Use this command when the router is configured as a broadcast client and the round-trip delay on the network is other than 3000 microseconds. When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect. In the no form of ntp commands, all the keywords are optional. When you enter the no ntp command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the no ntp command. To terminate NTP service on a device, you must enter the no ntp command without keywords. For example, if you previously issued the ntp broadcastdelay command and you now want to remove not only the delay setting, but all NTP functions from the device, use the no ntp command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples	The following example shows how to set the estimated round-trip delay between a router and the broadcast client to 5000 microseconds:

```
Router(config)# ntp broadcastdelay 5000
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

ntp broadcastdelay

Related Commands

Command	Description
ntp broadcast	Configures the specified interface to send NTP broadcast packets.
ntp broadcast client	Configures the specified interface to receive NTP broadcast packets.

ntp clock-period

**Caution**

Do not enter this command; it is documented for informational purposes only. The system automatically generates this command as Network Time Protocol (NTP) determines the clock error and compensates.

As NTP compensates for the error in the software clock, it keeps track of the correction factor for this error. The system automatically saves this value into the system configuration when the **ntp clock-period** command is issued in global configuration mode. To revert to the default, use the **no** form of this command.

ntp clock-period *value*

no ntp

Syntax Description

<i>value</i>	Amount of time to add to the software clock for each clock hardware tick (this value is multiplied by 2^{-32}).

Defaults

17179869 2^{-32} seconds (4 milliseconds)

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Do not manually set a value for the NTP clock-period.

If a **copy running-config startup-config** command is entered to save the configuration to NVRAM, the **ntp clock-period** command will automatically be added to the startup configuration. We recommend saving the running configuration to the startup configuration after NTP has been running for a week or so specifically for the purpose of capturing the current setting for the clock-period; performing this task will help NTP synchronize more quickly if the system is restarted.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you want to remove not only the clock period, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows a typical difference between the values of the NTP clock-period setting in the running configuration and in the startup configuration:

```
Router# show startup-config | include clock-period
```

```
ntp clock-period 17180239
```

```
Router# show running-config | include clock-period
```

```
ntp clock-period 17180255
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

ntp disable

To prevent an interface from receiving Network Time Protocol (NTP) packets, use the **ntp disable** command in interface configuration mode. To enable receipt of NTP packets on an interface, use the **no** form of this command.

ntp disable

no ntp

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Interface configuration

Release	Modification
10.0	This command was introduced.

Usage Guidelines This command provides a simple method of access control.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp disable** command and you now want to remove not only this restriction, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples The following example shows how to prevent Ethernet interface 0 from receiving NTP packets:

```
Router(config)# interface ethernet 0
Router(config-if)# ntp disable
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

ntp master

To configure the Cisco IOS software as a Network Time Protocol (NTP) master clock to which peers synchronize themselves when an external NTP source is not available, use the **ntp master** command in global configuration mode. To disable the master clock function, use the **no** form of this command.

ntp master [*stratum*]

no ntp



Use this command with caution. It is very easy to override valid time sources using this command, especially if a low stratum number is configured. Configuring multiple devices in the same network with the **ntp master** command can cause instability in keeping time if the devices do not agree on the time.

Syntax Description

<i>stratum</i>	(Optional) Number from 1 to 15. Indicates the NTP stratum number that the system will claim.

Defaults

By default, the master clock function is disabled. When enabled, the default stratum is 8.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Because the Cisco implementation of NTP does not support directly attached radio or atomic clocks, the router is normally synchronized, directly or indirectly, to an external system that has such a clock. In a network without Internet connectivity, such a time source may not be available. The **ntp master** command is used in such cases.

If the system has **ntp master** configured, and it cannot reach any clock with a lower stratum number, the system will claim to be synchronized at the configured stratum number, and other systems will be willing to synchronize to it via NTP.



The software clock must have been set from some source, including manually, before the **ntp master** command will have any effect. This protects against distributing erroneous time after the system is restarted.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp master** command and you now want to remove not only the master clock function, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure a router as an NTP master clock to which peers may synchronize:

```
Router(config)# ntp master 10
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
clock calendar-valid	Configures the system hardware clock an authoritative time source for the network.

ntp max-associations

To configure the maximum number of Network Time Protocol (NTP) peers and clients for the routing device, use the **ntp max-associations** command in global configuration mode. To return the maximum associations value to the default, use the **no** form of this command.

ntp max-associations *number*

no ntp

Syntax Description	<i>number</i>	Specifies the number of NTP associations. The range is 0 to 4294967295. The default is 100.

Defaults	100 maximum associations.

Command Modes	Global configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>12.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	12.0	This command was introduced.
Release	Modification				
12.0	This command was introduced.				

Usage Guidelines	The router can be configured to define the maximum number of NTP peer and client associations that the router will serve. The ntp max-associations command is used to set this limit. This command is useful for ensuring that the router is not overwhelmed by huge numbers of NTP synchronization requests or, for an NTP master server, to allow large numbers of devices to sync to the router. When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect. In the no form of ntp commands, all the keywords are optional. When you enter the no ntp command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the no ntp command. To terminate NTP service on a device, you must enter the no ntp command without keywords. For example, if you previously issued the ntp max-associations command and you now want to remove not only that maximum value, but all NTP functions from the device, use the no ntp command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

In the following example, the router is configured to act as an NTP server to 200 clients:

```
Router(config)# ntp max-associations 200
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
show ntp associations	Shows all current NTP associations for the device.

ntp multicast client

To configure the system to receive Network Time Protocol (NTP) multicast packets on a specified interface, use the **ntp multicast client** interface configuration command. To disable this capability, use the **no** form of this command.

ntp multicast client [*ip-address*]

no ntp

Syntax Description	<i>ip-address</i> (Optional) IP address of the multicast group. Default address is 224.0.1.1.

Defaults	Disabled

Command Modes	Interface configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>12.1</td><td>This command was introduced.</td></tr></table>	Release	Modification	12.1	This command was introduced.
Release	Modification				
12.1	This command was introduced.				

Usage Guidelines

Use this command to allow the system to listen to multicast packets on an interface-by-interface basis. When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp multicast client** command and you now want to remove not only the multicast client capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

In the following example, the system is configured to receive (listen to) NTP multicast packets on Ethernet interface 1:

```
Router(config)# interface ethernet 1
Router(config-if)# ntp multicast client
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp multicast	Configures the specified interface to send NTP multicast packets.

ntp multicast

To configure a system to send Network Time Protocol (NTP) multicast packets on a specified interface, use the **ntp multicast** interface configuration command. To disable this capability, use the **no** form of this command.

ntp multicast [*ip-address*] [**key** *key-id*] [**ttl** *value*] [**version** *number*]

no ntp

Syntax Description	<i>ip-address</i>	(Optional) IP address of the multicast group. Default address is 224.0.1.1.
	key	(Optional) Defines a multicast authentication key.
	<i>key-id</i>	(Optional) Authentication key number in the range from 1 to 4294967295.
	ttl	(Optional) Defines the time-to-live (TTL) value of a multicast NTP packet.
	<i>value</i>	(Optional) TTL value in the range from 1 to 255. Default TTL value is 16.
	version	(Optional) Defines the NTP version number.
	<i>number</i>	(Optional) NTP version number in the range from 1 to 3. Default version number is 3.

Defaults	Disabled

Command Modes	Interface configuration

Command History	Release	Modification
	12.1	This command was introduced.

Usage Guidelines

The TTL value is used to limit the scope of an audience for multicast routing.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp multicast** command and you now want to remove not only the multicast capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure Ethernet interface 0 to send NTP version 2 broadcasts:

```
Router(config)# interface ethernet 0
Router(config-if)# ntp multicast version 2
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authentication-key	Defines an authentication key for NTP.
ntp multicast client	Allows the system to receive NTP multicast packets on an interface.

ntp peer

To configure the software clock to synchronize a peer or to be synchronized by a peer, use the **ntp peer** command in global configuration mode. To disable this capability, use the **no** form of this command.

```
ntp peer ip-address [normal-sync] [version number] [key key-id] [source interface] [prefer]

no ntp
```

Syntax Description

<i>ip-address</i>	IP address of the peer providing, or being provided, the clock synchronization.
normal-sync	(Optional) Disables the rapid synchronization at startup.
version	(Optional) Defines the Network Time Protocol (NTP) version number.
<i>number</i>	(Optional) NTP version number (1 to 3).
key	(Optional) Defines the authentication key.
<i>keyid</i>	(Optional) Authentication key to use when sending packets to this peer.
source	(Optional) Names the interface.
<i>interface</i>	(Optional) Name of the interface from which to pick the IP source address.
prefer	(Optional) Makes this peer the preferred peer that provides synchronization.

Command Default

No peers are configured.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.
12.3(14)T	The normal-sync keyword was added.

Usage Guidelines

When a peer is configured, the default NTP version number is 3, no authentication key is used, and the source IP address is taken from the outgoing interface.

Use this command to allow a device to synchronize with a peer, or vice versa. Using the **prefer** keyword reduces switching between peers.



Tip

If you are using the default version of 3 and NTP synchronization does not occur, try using NTP version 2 (NTPv2).

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp peer** command and you now want to remove not only the peer, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure a router to allow its software clock to be synchronized with the clock of the peer (or vice versa) at IP address 192.168.22.33 using NTP version 2. The source IP address is the address of Ethernet 0.

```
Router(config)# ntp peer 192.168.22.33 version 2 source ethernet 0
```

The following example shows how to disable rapid synchronization at startup:

```
Router(config)# ntp peer 192.168.22.33 normal-sync
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authentication-key	Defines an authentication key for NTP.
ntp server	Allows the software clock to be synchronized by a time server.
ntp source	Uses a particular source address in NTP packets.

ntp refclock

To configure an external clock source for use with Network Time Protocol (NTP) services, use the **ntp refclock** command in line configuration mode. To disable support of the external time source, use the **no** form of this command.

```
ntp refclock {trimble | telecom-solutions} pps {cts | ri | none} [inverted] [pps-offset number]
[stratum number] [timestamp-offset number]
```

```
no ntp
```

Syntax Description

trimble	Enables the reference clock driver for the Trimble Palisade NTP Synchronization Kit (Cisco 7200 series routers only).
telecom-solutions	Enables the reference clock driver for a Telecom Solutions GPS device.
pps	Pulse per second (PPS) signal line. Indicate PPS pulse reference clock support. Choices are cts , ri , or none .
cts	Pulse per second on CTS.
ri	Pulse per second on RI.
none	No PPS signal available.
inverted	(Optional) PPS signal is inverted.
pps-offset <i>number</i>	(Optional) Offset of PPS pulse. The number is the offset (in milliseconds).
stratum <i>number</i>	(Optional) Number from 0 to 14. Indicates the NTP stratum number that the system will claim.
timestamp-offset <i>number</i>	(Optional) Offset of time stamp. The number is the offset (in milliseconds).

Defaults

This command is disabled by default.

Command Modes

Line configuration

Command History

Release	Modification
12.1	The trimble keyword was added to provide driver activation for a Trimble GPS time source on the Cisco 7200 series router.

Usage Guidelines

To configure a PPS signal as the source for NTP synchronization, use the following form of the **ntp refclock** command:

```
ntp refclock pps {cts | ri} [inverted] [pps-offset number] [stratum number] [timestamp-offset number]
```

To configure a Trimble Palisade NTP Synchronization Kit as the GPS clock source connected to the auxiliary port of a Cisco 7200 router, use the following form of the **ntp refclock** command:

```
ntp refclock trimble pps none [stratum number]
```

To configure a Telecom Solutions product as the GPS clock source, use the **ntp refclock telecom-solutions** form of the command:

ntp refclock telecom-solutions pps cts [**stratum** *number*]

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp refclock** command and you now want to remove not only the external clock source, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows configuration of a Trimble Palisade GPS time source on a Cisco 7200 router:

```
Router(config)# ntp master
Router(config)# ntp update-calendar
Router(config)# line aux 0
Router(config-line)# ntp refclock trimble pps none
```

The following example shows configuration of a Telecom Solutions GPS time source on a Catalyst switch platform:

```
Router(config)# ntp master
Router(config)# ntp update-calendar
Router(config)# line aux 0
Router(config-line)# ntp refclock telecom-solutions pps cts stratum 1
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
show ntp associations	Displays the status of NTP associations configured for your system.

ntp server

To allow the software clock to be synchronized by a Network Time Protocol (NTP) time server, use the **ntp server** command in global configuration mode. To disable this capability, use the **no** form of this command.

ntp server *ip-address* | *hostname* [**version** *number*] [**key** *key-id*] [**source** *interface*] [**prefer**]

no ntp

Syntax Description

<i>ip-address</i>	IP address of the time server providing the clock synchronization.
<i>hostname</i>	Name of the time server providing the clock synchronization.
version	(Optional) Defines the NTP version number.
<i>number</i>	(Optional) NTP version number (1 to 3).
key	(Optional) Defines the authentication key.
<i>key-id</i>	(Optional) Authentication key to use when sending packets to this peer.
source	(Optional) Identifies the interface from which to pick the IP source address.
<i>interface</i>	(Optional) Name of the interface from which to pick the IP source address.
prefer	(Optional) Specifies that the server referenced in this command is preferred over other configured NTP servers.

Defaults

No peers are configured by default. If a peer is configured, the default NTP version number is 3, no authentication key is used, and the source IP address is taken from the outgoing interface.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use this command if you want to allow the system to synchronize with the specified server. The server will not synchronize to this machine.

When you use the *hostname* option, the router does a domain name server (DNS) lookup on that name, and stores the IP address in the configuration. For example, if you enter the command **ntp server host1** and then check the running configuration, the output shows “ntp server 172.16.0.4,” assuming that the router is correctly configured as a DNS client.

Use the **prefer** keyword if you use this command multiple times, and you want to set a preferred server. Using the **prefer** keyword reduces switching between servers.

If you are using the default version of 3 and NTP synchronization does not occur, try NTP version 2. Some NTP servers on the Internet run version 2.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp server** command and you now want to remove not only the server synchronization capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure a router to allow its software clock to be synchronized with the clock by the device at IP address 172.16.22.44 using NTP version 2:

```
Router(config)# ntp server 172.16.22.44 version 2
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authentication-key	Defines an authentication key for NTP.
ntp peer	Configures the software clock to synchronize a peer or to be synchronized by a peer.
ntp source	Uses a particular source address in NTP packets.

ntp source

To use a particular source address in Network Time Protocol (NTP) packets, use the **ntp source** command in global configuration mode. To remove the specified source address, use the **no** form of this command.

ntp source *type number*

no ntp

Syntax Description

<i>type</i>	Type of interface.
<i>number</i>	Number of the interface.

Defaults

Source address is determined by the outgoing interface.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use this command when you want to use a particular source IP address for all NTP packets. The address is taken from the named interface. This command is useful if the address on an interface cannot be used as the destination for reply packets. If the **source** keyword is present on an **ntp server** or **ntp peer** global configuration command, that value overrides the global value set by this command.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp source** command and you now want to remove not only the configured source address, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure a router to use the IP address of Ethernet 0 as the source address of all outgoing NTP packets:

```
Router(config)# ntp source ethernet 0
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands	Command	Description
	ntp peer	Configures the software clock to synchronize a peer or to be synchronized by a peer.
	ntp server	Allows the software clock to be synchronized by a time server.

ntp trusted-key

To authenticate the identity of a system to which Network Time Protocol (NTP) will synchronize, use the **ntp trusted-key** command in global configuration mode. To disable authentication of the identity of the system, use the **no** form of this command.

ntp trusted-key *key-number*

no ntp

Syntax Description

key-number Key number of authentication key to be trusted.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

If authentication is enabled, use this command to define one or more key numbers (corresponding to the keys defined with the **ntp authentication-key** command) that a peer NTP system must provide in its NTP packets, in order for this system to synchronize to it. This function provides protection against accidentally synchronizing the system to a system that is not trusted, because the other system must know the correct authentication key.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the **no** form of **ntp** commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp trusted-key** command and you now want to remove not only the authentication, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure the system to synchronize only to systems providing authentication key 42 in its NTP packets:

```
Router(config)# ntp authenticate
Router(config)# ntp authentication-key 42 md5 aNiceKey
Router(config)# ntp trusted-key 42
```


The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
ntp authenticate	Enables NTP authentication.
ntp authentication-key	Defines an authentication key for NTP.

ntp update-calendar

To periodically update the hardware clock (calendar) from a Network Time Protocol (NTP) time source, use the **ntp update-calendar** command in global configuration mode. To disable the periodic updates, use the **no** form of this command.

ntp update-calendar

no ntp

Syntax Description This command has no arguments or keywords.

Defaults The hardware clock (calendar) is not updated.

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Some platforms have a battery-powered hardware clock, referred to in the command-line interface (CLI) as the “calendar,” in addition to the software based system clock. The hardware clock runs continuously, even if the router is powered off or rebooted.

If the software clock is synchronized to an outside time source via NTP, it is a good practice to periodically update the hardware clock with the time learned from NTP. Otherwise, the hardware clock will tend to gradually lose or gain time (drift), and the software clock and hardware clock may become out of synchronization with each other. The **ntp update-calendar** command will enable the hardware clock to be periodically updated with the time specified by the NTP source. The hardware clock will be updated only if NTP has synchronized to an authoritative time server.

Many lower-end routers (for example, the Cisco 2500 series or the Cisco 2600 series) do not have hardware clocks, so this command is not available on those platforms.

To force a single update of the hardware clock from the software clock, use the **clock update-calendar EXEC** command.

When you configure NTP, you must include at least one of the available keywords; the NTP service is activated and the keyword takes effect.

In the no form of ntp commands, all the keywords are optional. When you enter the **no ntp** command followed by one or more of its keywords, only the functions activated by those keywords are removed from the NTP service. The NTP service itself remains active, along with all functions you have not specified in the **no ntp** command.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords.

For example, if you previously issued the **ntp update-calendar** command and you now want to disable not only the periodic updates, but all NTP functions running on the device, use the **no ntp** command without any keywords. This ensures that all NTP functions are removed and that the NTP service is also terminated.

Examples

The following example shows how to configure the system to periodically update the hardware clock from the NTP time source:

```
Router(config)# ntp update-calendar
```

The following example shows how to remove all the configured NTP options and disable the ntp server:

```
Router(config)# no ntp
```

Related Commands

Command	Description
clock read-calendar	Performs a one-time update of the software clock from the hardware clock (calendar).
clock update-calendar	Performs a one-time update of the hardware clock (calendar) from the software clock.

periodic

To specify a recurring (weekly) time range for functions that support the time-range feature, use the **periodic** time-range configuration command. To remove the time limitation, use the **no** form of this command.

```
periodic days-of-the-week hh:mm to [days-of-the-week] hh:mm

no periodic days-of-the-week hh:mm to [days-of-the-week] hh:mm
```

Syntax Description	days-of-the-week The first occurrence of this argument is the starting day or day of the week that the associated time range is in effect. The second occurrence is the ending day or day of the week the associated statement is in effect. This argument can be any single day or combinations of days: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, and Sunday. Other possible values are: • daily—Monday through Sunday • weekdays—Monday through Friday • weekend—Saturday and Sunday If the ending days of the week are the same as the starting days of the week, they can be omitted.
	hh:mm The first occurrence of this argument is the starting hours:minutes that the associated time range is in effect. The second occurrence is the ending hours:minutes the associated statement is in effect. The hours:minutes are expressed in a 24-hour clock. For example, 8:00 is 8:00 a.m. and 20:00 is 8:00 p.m.
	to Entry of the to keyword is required to complete the range “from start-time to end-time.”

Defaults	No recurring time range is defined.

Command Modes	Time-range configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>12.0(1)T</td><td>This command was introduced.</td></tr></table>	Release	Modification	12.0(1)T	This command was introduced.
Release	Modification				
12.0(1)T	This command was introduced.				

Usage Guidelines	For Cisco IOS Release 12.2, IP and Internetwork Packet Exchange (IPX) extended access lists are the only functions that can use time ranges. For further information on using these functions, refer to the Release 12.2 <i>Cisco IOS IP Configuration Guide</i> and the Release 12.2 <i>Cisco IOS AppleTalk and Novell IPX Configuration Guide</i> .

The **periodic** command is one way to specify when a time range is in effect. Another way is to specify an absolute time period with the **absolute** command. Use either of these commands after the **time-range** global configuration command, which specifies the name of the time range. Multiple **periodic** entries are allowed per **time-range** command.

If the end days-of-the-week value is the same as the start value, they can be omitted.

If a **time-range** command has both **absolute** and **periodic** values specified, then the **periodic** items are evaluated only after the **absolute start** time is reached, and are not further evaluated after the **absolute end** time is reached.

**Note**

All time specifications are taken as local time. To ensure that the time range entries take effect at the desired times, you should synchronize the system software clock using Network Time Protocol (NTP).

Table 47 lists some typical settings for your convenience:

Table 47 Typical Examples of periodic Command Syntax

If you want:	Configure this:
Monday through Friday, 8:00 a.m. to 6:00 p.m. only	periodic weekday 8:00 to 18:00
Every day of the week, from 8:00 a.m. to 6:00 p.m. only	periodic daily 8:00 to 18:00
Every minute from Monday 8:00 a.m. to Friday 8:00 p.m.	periodic monday 8:00 to friday 20:00
All weekend, from Saturday morning through Sunday night	periodic weekend 00:00 to 23:59
Saturdays and Sundays, from noon to midnight	periodic weekend 12:00 to 23:59

Examples

The following example denies HTTP traffic on Monday through Friday from 8:00 a.m. to 6:00 p.m.:

```
time-range no-http
  periodic weekdays 8:00 to 18:00
!
ip access-list extended strict
  deny tcp any any eq http time-range no-http
!
interface ethernet 0
  ip access-group strict in
```

The following example permits Telnet traffic on Mondays, Tuesdays, and Fridays from 9:00 a.m. to 5:00 p.m.:

```
time-range testing
  periodic Monday Tuesday Friday 9:00 to 17:00
!
ip access-list extended legal
  permit tcp any any eq telnet time-range testing
!
interface ethernet 0
  ip access-group legal in
```

Related Commands	Command	Description
	absolute	Specifies an absolute start and end time for a time range.
	access-list (extended)	Defines an extended IP access list.
	deny (IP)	Sets conditions under which a packet does not pass a named IP access list.
	permit (IP)	Sets conditions under which a packet passes a named IP access list.
	time-range	Enables time-range configuration mode and names a time range definition.

process-max-time

To configure the amount of time after which a process should voluntarily yield to another process, use the **process-max-time** command in global configuration mode. To reset this value to the system default, use the **no** form of this command.

process-max-time *milliseconds*

no process-max-time [*milliseconds*]

Syntax Description

<i>milliseconds</i>	Maximum duration (in milliseconds) that a process can run before suspension. The range is from 20-200 milliseconds.

Defaults

Default maximum process time is 200 milliseconds.

Command Modes

Global configuration

Command History

Release	Modification
12.1	This command was introduced.

Usage Guidelines

Lowering the maximum time a process can run is useful in some circumstances to ensure equitable division of CPU time among different tasks.

Only use this command if recommended to do so by the Cisco Technical Assistance Center (TAC).

Examples

The following example limits the time to 100 milliseconds that a process can run without suspending:

```
process-max-time 100
```

prompt

To customize the CLI prompt, use the **prompt** global configuration command. To revert to the default prompt, use the **no** form of this command.

```
prompt string
no prompt [string]
```

Syntax Description	string	Text that will be displayed on screen as the CLI prompt, including any desired prompt variables.

Defaults	The default prompt is either <i>Router</i> or the name defined with the hostname global configuration command, followed by an angle bracket (>) for user EXEC mode or a pound sign (#) for privileged EXEC mode.	

Command Modes	Global configuration	

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	You can include customized variables when specifying the prompt. All prompt variables are preceded by a percent sign (%). Table 48 lists the available prompt variables.	

Table 48 Custom Prompt Variables

Prompt Variable	Interpretation
%h	Host name. This is either <i>Router</i> or the name defined with the hostname global configuration command.
%n	Physical terminal line (tty) number of the EXEC user.
%p	Prompt character itself. It is either an angle bracket (>) for user EXEC mode or a pound sign (#) for privileged EXEC mode.
%s	Space.
%t	Tab.
%%	Percent sign (%)

Issuing the **prompt %h** command has the same effect as issuing the **no prompt** command.

Examples

The following example changes the EXEC prompt to include the tty number, followed by the name and a space:

```
Router(config)# prompt TTY%n@%h%s%p
```

The following are examples of user and privileged EXEC prompts that result from the previous command:

```
TTY17@Router1 > enable  
TTY17@Router1 #
```

Related Commands

Command	Description
hostname	Specifies or modifies the host name for the network server.

scheduler allocate

To guarantee CPU time for processes, use the **scheduler allocate** global configuration command on the Cisco 7200 series and Cisco 7500 series routers. To restore the default, use the **no** form of this command.

scheduler allocate *interrupt-time process-time*

no scheduler allocate

Syntax Description	<i>interrupt-time</i>	Integer (in microseconds) that limits the maximum number of microseconds to spend on fast switching within any one network interrupt context. The range is from 400 to 60000 microseconds. The default is 4000 microseconds.
	<i>process-time</i>	Integer (in microseconds) that guarantees the minimum number of microseconds to spend at the process level when network interrupts are disabled. The range is from 100 to 4000 microseconds. The default is 200 microseconds.

Defaults Approximately 5 percent of the CPU is available for process tasks.

Command Modes Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines This command applies to the Cisco 7200 series and Cisco 7500 series routers.



Note

Changing settings associated with CPU processes can negatively impact system performance.

Examples The following example makes 20 percent of the CPU available for process tasks:

```
Router(config)# scheduler allocate 2000 500
```

Related Commands	Command	Description
	scheduler interval	Controls the maximum amount of time that can elapse without running system processes.

scheduler interval

To control the maximum amount of time that can elapse without running system processes, use the **scheduler interval** global configuration command. To restore the default, use the **no** form of this command.

scheduler interval *milliseconds*

no scheduler interval

Syntax Description	<i>milliseconds</i> Integer that specifies the interval (in milliseconds). The minimum interval that you can specify is 500 milliseconds; there is no maximum value.

Defaults	High-priority operations are allowed to use as much of the CPU as needed.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The normal operation of the network server allows the switching operations to use as much of the central processor as is required. If the network is running unusually heavy loads that do not allow the processor the time to handle the routing protocols, give priority to the system process scheduler. High-priority operations are allowed to use as much of the CPU as needed.

**Note**

Changing settings associated with CPU processes can negatively impact system performance.

On the Cisco 7200 series and Cisco 7500 series, use the **scheduler allocate** global configuration command instead of the **scheduler interval** command.

Examples	The following example changes the low-priority process schedule to an interval of 750 milliseconds: Router(config)# scheduler interval 750

Related Commands	Command	Description
	scheduler allocate	Guarantees CPU time for processes.

service decimal-tty

To specify that line numbers be displayed and interpreted as decimal numbers rather than octal numbers, use the **service decimal-tty** global configuration command. To display octal numbers, use the **no** form of this command.

- service decimal-tty**
- no service decimal-tty**

Syntax Description This command has no arguments or keywords.

Defaults Decimal numbers are displayed.

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Examples The following example displays decimal rather than octal line numbers:
`Router(config)# service decimal-tty`

service exec-wait

To delay the startup of the EXEC on noisy lines, use the **service exec-wait** global configuration command. To disable the delay function, use the **no** form of this command.

service exec-wait

no service exec-wait

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines This command delays startup of the EXEC until the line has been idle (no traffic seen) for 3 seconds. The default is to enable the line immediately on modem activation.

This command is useful on noisy modem lines or when a modem attached to the line is configured to ignore MNP/V.42 negotiations, and MNP/V.42 modems may be dialing in. In these cases, noise or MNP/V.42 packets may be interpreted as usernames and passwords, causing authentication failure before the user has a chance to type a username or password. The command is not useful on nonmodem lines or lines without some kind of login configured.

Examples The following example delays the startup of the EXEC:

```
Router(config)# service exec-wait
```

service finger

The **service finger** command has been replaced by the **ip finger** command. However, the **service finger** and **no service finger** commands continue to function to maintain backward compatibility with older versions of Cisco IOS software. Support for this command may be removed in a future release. See the description of the **ip finger** command in this chapter for more information.

service hide-telnet-address

To hide addresses while trying to establish a Telnet session, use the **service hide-telnet-address** global configuration command. To remove this service, use the **no** form of this command.

service hide-telnet-address

no service hide-telnet-address

Syntax Description	This command has no arguments or keywords.

Defaults	Addresses are displayed.

Command Modes	Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	When you attempt to connect to a device, the router displays addresses and other messages (for example, “Trying router1 (171.69.1.154, 2008)...”). With the hide feature, the router suppresses the display of the address (for example, “Trying router1 address #1...”). The router continues to display all other messages that would normally be displayed during a connection attempt, such as detailed error messages if the connection was not successful.

The hide feature improves the functionality of the busy-message feature. When you configure only the **busy-message** command, the normal messages generated during a connection attempt are not displayed; only the busy-message is displayed. When you use the hide and busy features together you can customize the information displayed during Telnet connection attempts. When you configure the **service hide-telnet-address** command and the **busy-message** command, the router suppresses the address and displays the message specified with the **busy-message** command if the connection attempt is not successful.

Examples	The following example hides Telnet addresses: <pre>Router(config)# service hide-telnet-address</pre>

Related Commands	Command	Description
	busy-message	Creates a “host failed” message that is displayed when a connection fails.

service nagle

To enable the Nagle congestion control algorithm, use the **service nagle** global configuration command. To to disable the algorithm, use the **no** form of this command.

service nagle

no service nagle

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

When using a standard TCP implementation to send keystrokes between machines, TCP tends to send one packet for each keystroke typed. On larger networks, many small packets use up bandwidth and contribute to congestion.

The algorithm developed by John Nagle (RFC 896) helps alleviate the small-packet problem in TCP. In general, it works this way: The first character typed after connection establishment is sent in a single packet, but TCP holds any additional characters typed until the receiver acknowledges the previous packet. Then the second, larger packet is sent, and additional typed characters are saved until the acknowledgment comes back. The effect is to accumulate characters into larger chunks, and pace them out to the network at a rate matching the round-trip time of the given connection. This method is usually effective for all TCP-based traffic. However, do not use the **service nagle** command if you have XRemote users on X Window system sessions.

Examples

The following example enables the Nagle algorithm:

```
Router(config)# service nagle
```


service prompt config

To display the configuration prompt (config), use the **service prompt config** global configuration command. To remove the configuration prompt, use the **no** form of this command.

service prompt config

no service prompt config

Syntax Description

This command has no arguments or keywords.

Defaults

The configuration prompts appear in all configuration modes.

Command Modes

Global configuration

Command History

Release	Modification
11.1	This command was introduced.

Examples

In the following example, the **no service prompt config** command prevents the configuration prompt from being displayed. The prompt is still displayed in EXEC mode. When the **service prompt config** command is entered, the configuration mode prompt reappears.

```
Router# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Router(config)# no service prompt config
```

```
hostname newname  
end
```

```
newname# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
service prompt config
```

```
newname(config)# hostname Router
```

```
Router(config)# end
```

```
Router#
```

Related Commands

Command	Description
hostname	Specifies or modifies the host name for the network server.
prompt	Customizes the prompt.

service tcp-small-servers

To access minor TCP/IP services available from hosts on the network, use the **service tcp-small-servers** command in global configuration mode. To disable these services, use the **no** form of the command.

```
service tcp-small-servers

no service tcp-small-servers
```

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global configuration

Release	Modification
11.1	This command was introduced.

Usage Guidelines By default, the TCP servers for Echo, Discard, Chargen, and Daytime services are disabled. When the minor TCP/IP servers are disabled, access to the Echo, Discard, Chargen, and Daytime ports cause the Cisco IOS software to send a TCP RESET packet to the sender and discard the original incoming packet.

Examples The following example enables minor TCP/ IP services available from the network:

```
Router(config)# service tcp-small-servers
```

service telnet-zero-idle

To set the TCP window to zero (0) when the Telnet connection is idle, use the **service telnet-zero-idle** global configuration command. To disable this service, use the **no** form of this command.

service telnet-zero-idle

no service telnet-zero-idle

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Normally, data sent to noncurrent Telnet connections is accepted and discarded. When the service telnet-zero-idle command is enabled, if a session is suspended (that is, some other connection is made active or the EXEC is sitting in command mode), the TCP window is set to zero. This action prevents the remote host from sending any more data until the connection is resumed. Use this command when it is important that all messages sent by the host be seen by the users and the users are likely to use multiple sessions. Do not use this command if your host will eventually time out and log out a TCP user whose window is zero.

Examples	The following example sets the TCP window to zero when the Telnet connection is idle: <pre>Router(config)# service telnet-zero-idle</pre>

Related Commands	Command	Description
	resume	Switches to another open Telnet, rlogin, LAT, or PAD session.

service udp-small-servers

To access minor User Datagram Protocol (UDP) services available from hosts on the network, use the **service udp-small-servers** global configuration command. To disable these services, use the **no** form of this command.

service udp-small-servers

no service udp-small-servers

Syntax Description	This command has no arguments or keywords.	
Defaults	Disabled	
Command Modes	Global configuration	
Command History	Release	Modification
	11.2	This command was introduced.
Usage Guidelines	By default the UPD servers for Echo, Discard, and Chargen services are disabled. When the servers are disabled, access to Echo, Discard, and Chargen ports causes the Cisco IOS software to send an “ICMP port unreachable” message to the sender and discard the original incoming packet.	
Examples	In the following example minor UDP services are enabled on the router: <pre>Router(config)# service udp-small-servers</pre>	

show aliases

To display all alias commands, or the alias commands in a specified mode, use the **show aliases EXEC** command.

show aliases [*mode*]

Syntax Description	<i>mode</i> (Optional) Command mode.

Command Modes	EXEC

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	When used without the <i>mode</i> argument, this command will display all aliases currently configured on the system. Use the <i>mode</i> argument to display only the aliases configured for the specified command mode.

To display a list of the command mode keywords available for your system, use the **show aliases ?** command. For a list of command modes, refer to the “Cisco IOS Command Modes” appendix in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

Examples	The following is sample output from the show aliases exec commands. The aliases configured for commands in EXEC mode are displayed.

```
Router> show aliases exec
```

```
Exec mode aliases:
```

```
h          help
lo         logout
p          ping
r          resume
s          show
w          where
```

Related Commands	Command	Description
	alias	Creates a command alias.

show buffers

To display statistics for the buffer pools on the network server, use the **show buffers** EXEC command.

```
show buffers [address hex-addr | [all | assigned | failures | free | old [dump | header | packet]]
           | input-interface interface-type identifier | pool pool-name]
```

Syntax Description	address	(Optional) Displays buffers at a specified address.
	<i>hex-addr</i>	Address (in hexadecimal notation) of the buffer to display.
	all	(Optional) Displays all buffers.
	assigned	(Optional) Displays the buffers in use.
	failures	(Optional) Displays buffer allocation failures.
	free	(Optional) Displays the buffers available for use.
	old	(Optional) Displays buffers older than one minute.
	dump	(Optional) Displays the buffer header and all data in the display.
	header	(Optional) Displays the buffer header only in the display.
	packet	(Optional) Displays the buffer header and packet data in the display.
	input-interface	(Optional) Displays interface pool information. If the specified <i>interface-type</i> argument has its own buffer pool, displays information for that pool.
	<i>interface-type</i>	Value of <i>interface-type</i> can be ethernet , fastethernet , loopback , serial , or null .
	<i>identifier</i>	Identifier of the interface specified in <i>interface-type</i> argument.
	pool	(Optional) Displays buffers in a specified buffer pool.
	<i>pool-name</i>	Specifies the name of a buffer pool to use.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

The peak field in the output of the **show buffers** command shows the maximum number of buffers created (highest total) and the time when that peak occurred relative to when you issued the **show buffers** command. Formats include weeks, days, hours, minutes, and seconds. Not all systems report a peak value, which means this field may not display in output.

Examples

The following is sample output from the **show buffers** command with no arguments, showing all buffer pool information:

```
Router> show buffers

Buffer elements:
  398 in free list (500 max allowed)
 1266 hits, 0 misses, 0 created
```

```
Public buffer pools:
Small buffers, 104 bytes (total 50, permanent 50):
    50 in free list (20 min, 150 max allowed)
    551 hits, 0 misses, 0 trims, 0 created
Middle buffers, 600 bytes (total 25, permanent 25):
    25 in free list (10 min, 150 max allowed)
    39 hits, 0 misses, 0 trims, 0 created
Big buffers, 1524 bytes (total 50, permanent 50):
    49 in free list (5 min, 150 max allowed)
    27 hits, 0 misses, 0 trims, 0 created
VeryBig buffers, 4520 bytes (total 10, permanent 10):
    10 in free list (0 min, 100 max allowed)
    0 hits, 0 misses, 0 trims, 0 created
Large buffers, 5024 bytes (total 0, permanent 0):
    0 in free list (0 min, 10 max allowed)
    0 hits, 0 misses, 0 trims, 0 created
Huge buffers, 18024 bytes (total 0, permanent 0):
    0 in free list (0 min, 4 max allowed)
    0 hits, 0 misses, 0 trims, 0 created

Interface buffer pools:
Ethernet0 buffers, 1524 bytes (total 64, permanent 64):
    16 in free list (0 min, 64 max allowed)
    48 hits, 0 fallbacks
    16 max cache size, 16 in cache
Ethernet1 buffers, 1524 bytes (total 64, permanent 64):
    16 in free list (0 min, 64 max allowed)
    48 hits, 0 fallbacks
    16 max cache size, 16 in cache
Serial0 buffers, 1524 bytes (total 64, permanent 64):
    16 in free list (0 min, 64 max allowed)
    48 hits, 0 fallbacks
    16 max cache size, 16 in cache
Serial1 buffers, 1524 bytes (total 64, permanent 64):
    16 in free list (0 min, 64 max allowed)
    48 hits, 0 fallbacks
    16 max cache size, 16 in cache
TokenRing0 buffers, 4516 bytes (total 48, permanent 48):
    0 in free list (0 min, 48 max allowed)
    48 hits, 0 fallbacks
    16 max cache size, 16 in cache
TokenRing1 buffers, 4516 bytes (total 32, permanent 32):
    32 in free list (0 min, 48 max allowed)
    16 hits, 0 fallbacks
    0 failures (0 no memory)
```

The following is sample output from the **show buffers** command with no arguments, showing only buffer pool information for Huge buffers. This output shows a highest total of five Huge buffers created five days and 18 hours before the command was issued.

```
Router> show buffers
```

```
Huge buffers, 18024 bytes (total 5, permanent 0, peak 5 @ 5d18h):
    4 in free list (3 min, 104 max allowed)
    0 hits, 1 misses, 101 trims, 106 created
    0 failures (0 no memory)
```

The following is sample output from the **show buffers** command with no arguments, showing only buffer pool information for Huge buffers. This output shows a highest total of 184 Huge buffers created one hour, one minute, and 15 seconds before the command was issued.

```
Router> show buffers
```

```
Huge buffers, 65280 bytes (total 4, permanent 2, peak 184 @ 01:01:15):
  4 in free list (0 min, 4 max allowed)
  32521 hits, 143636 misses, 14668 trims, 14670 created
  143554 failures (0 no memory)
```

The following is sample output from the **show buffers** command with an interface type and interface number:

```
Router> show buffers Ethernet 0
```

```
Ethernet0 buffers, 1524 bytes (total 64, permanent 64):
  16 in free list (0 min, 64 max allowed)
  48 hits, 0 fallbacks
  16 max cache size, 16 in cache
```

Table 49 describes significant fields shown in the display.

Table 49 *show buffers Field Descriptions*

Field	Description
Buffer elements	Small structures used as placeholders for buffers in internal operating system queues. Used when a buffer may need to be on more than one queue.
free list	Total number of the currently unallocated buffer elements.
max allowed	Maximum number of buffers that are available for allocation.
hits	Count of successful attempts to allocate a buffer when needed.
misses	Count of buffer allocation attempts that resulted in growing the buffer pool to allocate a buffer.
created	Count of new buffers created to satisfy buffer allocation attempts when the available buffers in the pool have already been allocated.
Public buffer pools:	
Small buffers	Buffers that are 104 bytes long.
Middle buffers	Buffers that are 600 bytes long.
Big buffers	Buffers that are 1524 bytes long.
VeryBig buffers	Buffers that are 4520 bytes long.
Large buffers	Buffers that are 5024 bytes long.
Huge buffers	Buffers that are 18024 bytes long.
total	Total number of this type of buffer.
permanent	Number of these buffers that are permanent.
peak	Maximum number of buffers created (highest total) and the time when that peak occurred. Formats include weeks, days, hours, minutes, and seconds. Not all systems report a peak value, which means this field may not display in output.
free list	Number of available or unallocated buffers in that pool.

Table 49 *show buffers Field Descriptions (continued)*

Field	Description
min	Minimum number of free or unallocated buffers in the buffer pool.
max allowed	Maximum number of free or unallocated buffers in the buffer pool.
hits	Count of successful attempts to allocate a buffer when needed.
misses	Count of buffer allocation attempts that resulted in growing the buffer pool in order to allocate a buffer.
trims	Count of buffers released to the system because they were not being used. This field is displayed only for dynamic buffer pools, not interface buffer pools, which are static.
created	Count of new buffers created in response to misses. This field is displayed only for dynamic buffer pools, not interface buffer pools, which are static.
Interface buffer pools:	
total	Total number of this type of buffer.
permanent	Number of these buffers that are permanent.
free list	Number of available or unallocated buffers in that pool.
min	Minimum number of free or unallocated buffers in the buffer pool.
max allowed	Maximum number of free or unallocated buffers in the buffer pool.
hits	Count of successful attempts to allocate a buffer when needed.
fallbacks	Count of buffer allocation attempts that resulted in falling back to the public buffer pool that is the smallest pool at least as big as the interface buffer pool.
max cache size	Maximum number of buffers from the pool of that interface that can be in the buffer pool cache of that interface. Each interface buffer pool has its own cache. These are not additional to the permanent buffers; they come from the buffer pools of the interface. Some interfaces place all of their buffers from the interface pool into the cache. In this case, it is normal for the <i>free list</i> to display 0.
failures	Total number of times a buffer creation failed. The failure may have occurred because of a number of different reasons, such as low processor memory, low IOMEM, or no buffers in the pool when called from interrupt context.
no memory	Number of times there has been low memory during buffer creation. Low or no memory during buffer creation may not necessarily mean that buffer creation failed; memory can be obtained from an alternate resource such as a fallback pool.

show calendar

To display the current time and date setting for the hardware clock, use the **show calendar** EXEC command:

show calendar

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Some platforms have a hardware clock (calendar) which is separate from the software clock. The hardware clock is battery operated, and runs continuously, even if the router is powered off or rebooted. You can compare the time and date shown with this command with the time and date listed via the **show clock** EXEC command to verify that the hardware clock and software clock are synchronized with each other. The time displayed is relative to the configured time zone.

Examples In the following sample display, the hardware clock indicates the time stamp of 12:13:44 p.m. on Friday, July 19, 1996:

```
Router> show calendar
```

```
12:13:44 PST Fri Jul 19 1996
```

Related Commands	Command	Description
	show clock	Displays the time and date from the system software clock.

show clock

To display the time and date from the system software clock, use the **show clock** EXEC command.

show clock [detail]

Syntax Description	detail (Optional) Indicates the clock source (NTP, VINES, hardware clock, and so on) and the current summer-time setting (if any).

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The software clock keeps an “authoritative” flag that indicates whether the time is authoritative (believed to be accurate). If the software clock has been set by a timing source (for example, via NTP), the flag is set. If the time is not authoritative, it will be used only for display purposes. Until the clock is authoritative and the “authoritative” flag is set, the flag prevents peers from synchronizing to the software clock.

The symbol that precedes the **show clock** display indicates the following:

Symbol	Description
*	Time is not authoritative.
(blank)	Time is authoritative.
.	Time is authoritative, but NTP is not synchronized.

**Note**

In general, NTP synchronization takes approximately 15 to 20 minutes.

Examples	The following sample output shows that the current clock is authoritative and that the time source is NTP:

```
Router> show clock detail
```

```
15:29:03.158 PST Mon Mar 3 1999
Time source is NTP
```

The following example shows the current clock is authoritative, but NTP is not yet synchronized:

```
Router> show clock
```

```
.16:42:35.597 UTC Wed Nov 1 1999
```

show clock

Related Commands	Command	Description
	clock set	Manually sets the software clock.
	show calendar	Displays the current time and date setting of the system hardware clock.

show idb

To display information about the status of interface descriptor blocks (IDBs), use the **show idb** command in privileged EXEC mode.

show idb

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	Privileged EXEC

Command History	Release	Modification
	12.1	This command was introduced.
	12.2(15)T	The output of this command was changed to show additional information.

Examples	The following is sample output from the show idb command:

```
Router# show idb
```

```
Maximum number of Software IDBs 8192. In use 17.
```

			HWIDBs	SWIDBs
Active			5	14
Inactive			10	3
Total IDBs			15	17
Size each (bytes)			5784	2576
Total bytes			86760	43792

```
HWIDB#1 1 2 GigabitEthernet0/0 0 5, HW IFINDEX, Ether)
HWIDB#2 2 3 GigabitEthernet9/0 0 5, HW IFINDEX, Ether)
HWIDB#3 3 4 GigabitEthernet9/1 6 5, HW IFINDEX, Ether)
HWIDB#4 4 5 GigabitEthernet9/2 6 5, HW IFINDEX, Ether)
HWIDB#5 13 1 Ethernet0 4 5, HW IFINDEX, Ether)
```

[Table 50](#) describes the significant fields shown in the display.

Table 50 *show idb Field Descriptions*

Field	Description
In use	Total number of software IDBs (SWIDBs) that have been allocated. This number never decreases. SWIDBs are never deallocated.
Active	Total number of hardware IDBs (HWIDBs) and SWIDBs that are allocated and in use.
Inactive	Total number of HWIDBs and SWIDBs that are allocated but not in use.
Total	Total number of HWIDBs and SWIDBs that are allocated.

show ntp associations

To show the status of Network Time Protocol (NTP) associations, use the **show ntp associations** EXEC command.

show ntp associations [detail]

Syntax Description	detail (Optional) Displays detailed information about each NTP association.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples Detailed descriptions of the information displayed by this command can be found in the NTP specification (RFC 1305).

The following is sample output from the **show ntp associations** command:

```
Router> show ntp associations

      address      ref clock      st  when  poll  reach  delay  offset  disp
~172.31.32.2      172.31.32.1      5   29   1024   377    4.2   -8.59   1.6
+~192.168.13.33   192.168.1.111     3   69    128   377    4.1    3.48   2.3
*~192.168.13.57   192.168.1.111     3   32    128   377    7.9   11.18   3.6
* master (syncd), # master (unsyncd), + selected, - candidate, ~ configured
```

Table 51 describes the significant fields shown in the display.

Table 51 show ntp associations Field Descriptions

Field	Description
(leading characters in display lines)	The first characters in a display line can be one or more of the following characters: * —Synchronized to this peer # —Almost synchronized to this peer + —Peer selected for possible synchronization - —Peer is a candidate for selection ~ —Peer is statically configured
address	Address of peer.
ref clock	Address of reference clock of peer.
st	Stratum of peer.
when	Time since last NTP packet was received from peer.
poll	Polling interval (in seconds).

Table 51 *show ntp associations Field Descriptions (continued)*

Field	Description
reach	Peer reachability (bit string, in octal).
delay	Round-trip delay to peer (in milliseconds).
offset	Relative time of peer clock to local clock (in milliseconds).
disp	Dispersion

The following is sample output of the **show ntp associations detail** command:

```
Router> show ntp associations detail
```

```
172.31.32.2 configured, insane, invalid, stratum 5
ref ID 172.31.32.1, time AFE252C1.6DBDDFF2 (00:12:01.428 PDT Mon Jul 5 1993)
our mode active, peer mode active, our poll intvl 1024, peer poll intvl 64
root delay 137.77 msec, root disp 142.75, reach 376, sync dist 215.363
delay 4.23 msec, offset -8.587 msec, dispersion 1.62
precision 2**19, version 3
org time AFE252E2.3AC0E887 (00:12:34.229 PDT Mon Jul 5 1993)
rcv time AFE252E2.3D7E464D (00:12:34.240 PDT Mon Jul 5 1993)
xmt time AFE25301.6F83E753 (00:13:05.435 PDT Mon Jul 5 1993)
filtdelay =      4.23      4.14      2.41      5.95      2.37      2.33      4.26      4.33
filtoffset =     -8.59     -8.82     -9.91     -8.42    -10.51    -10.77    -10.13    -10.11
filtererror =      0.50      1.48      2.46      3.43      4.41      5.39      6.36      7.34

192.168.13.33 configured, selected, sane, valid, stratum 3
ref ID 192.168.1.111, time AFE24F0E.14283000 (23:56:14.078 PDT Sun Jul 4 1993)
our mode client, peer mode server, our poll intvl 128, peer poll intvl 128
root delay 83.72 msec, root disp 217.77, reach 377, sync dist 264.633
delay 4.07 msec, offset 3.483 msec, dispersion 2.33
precision 2**6, version 3
org time AFE252B9.713E9000 (00:11:53.442 PDT Mon Jul 5 1993)
rcv time AFE252B9.7124E14A (00:11:53.441 PDT Mon Jul 5 1993)
xmt time AFE252B9.6F625195 (00:11:53.435 PDT Mon Jul 5 1993)
filtdelay =      6.47      4.07      3.94      3.86      7.31      7.20      9.52      8.71
filtoffset =      3.63      3.48      3.06      2.82      4.51      4.57      4.28      4.59
filtererror =      0.00      1.95      3.91      4.88      5.84      6.82      7.80      8.77

192.168.13.57 configured, our_master, sane, valid, stratum 3
ref ID 192.168.1.111, time AFE252DC.1F2B3000 (00:12:28.121 PDT Mon Jul 5 1993)
our mode client, peer mode server, our poll intvl 128, peer poll intvl 128
root delay 125.50 msec, root disp 115.80, reach 377, sync dist 186.157
delay 7.86 msec, offset 11.176 msec, dispersion 3.62
precision 2**6, version 2
org time AFE252DE.77C29000 (00:12:30.467 PDT Mon Jul 5 1993)
rcv time AFE252DE.7B2AE40B (00:12:30.481 PDT Mon Jul 5 1993)
xmt time AFE252DE.6E6D12E4 (00:12:30.431 PDT Mon Jul 5 1993)
filtdelay =     49.21      7.86      8.18      8.80      4.30      4.24      7.58      6.42
filtoffset =     11.30     11.18     11.13     11.28      8.91      9.09      9.27      9.57
filtererror =      0.00      1.95      3.91      4.88      5.78      6.76      7.74      8.71
```

Table 52 describes the significant fields shown in the display.

Table 52 *show ntp associations detail Field Descriptions*

Field	Descriptions
configured	Peer was statically configured.
dynamic	Peer was dynamically discovered.

Table 52 *show ntp associations detail Field Descriptions (continued)*

Field	Descriptions
our_master	Local machine is synchronized to this peer.
selected	Peer is selected for possible synchronization.
candidate	Peer is a candidate for selection.
sane	Peer passes basic sanity checks.
insane	Peer fails basic sanity checks.
valid	Peer time is believed to be valid.
invalid	Peer time is believed to be invalid.
leap_add	Peer is signalling that a leap second will be added.
leap-sub	Peer is signalling that a leap second will be subtracted.
unsynced	Peer is not synchronized to any other machine.
ref ID	Address of machine peer is synchronized to.
time	Last time stamp peer received from its master.
our mode	Our mode relative to peer (active/passive/client/server/bdcast/bdcast client).
peer mode	Peer's mode relative to us.
our poll intvl	Our poll interval to peer.
peer poll intvl	Peer's poll interval to us.
root delay	Delay along path to root (ultimate stratum 1 time source).
root disp	Dispersion of path to root.
reach	Peer reachability (bit string in octal).
sync dist	Peer synchronization distance.
delay	Round-trip delay to peer.
offset	Offset of peer clock relative to our clock.
dispersion	Dispersion of peer clock.
precision	Precision of peer clock in Hertz.
version	NTP version number that peer is using.
org time	Originate time stamp.
rcv time	Receive time stamp.
xmt time	Transmit time stamp.
filtdelay	Round-trip delay (in milliseconds) of each sample.
filtoffset	Clock offset (in milliseconds) of each sample.
filtererror	Approximate error of each sample.

Related Commands

Command	Description
show ntp status	Displays the status of the NTP.

show ntp status

To show the status of the Network Time Protocol (NTP), use the **show ntp status** EXEC command.

show ntp status

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples	The following is sample output from the show ntp status command:

Router> **show ntp status**

```
Clock is synchronized, stratum 4, reference is 192.168.13.57
nominal freq is 250.0000 Hz, actual freq is 249.9990 Hz, precision is 2**19
reference time is AFE2525E.70597B34 (00:10:22.438 PDT Mon Jul 5 1993)
clock offset is 7.33 msec, root delay is 133.36 msec
root dispersion is 126.28 msec, peer dispersion is 5.98 msec
```

[Table 53](#) describes the significant fields shown in the display.

Table 53 *show ntp status Field Descriptions*

Field	Description
synchronized	System is synchronized to an NTP peer.
unsynchronized	System is not synchronized to any NTP peer.
stratum	NTP stratum of this system.
reference	Address of peer the system is synchronized to.
nominal freq	Nominal frequency of system hardware clock.
actual freq	Measured frequency of system hardware clock.
precision	Precision of the clock of this system (in Hertz).
reference time	Reference time stamp.
clock offset	Offset of the system clock to synchronized peer.
root delay	Total delay along path to root clock.
root dispersion	Dispersion of root path.
peer dispersion	Dispersion of synchronized peer.

■ show ntp status

Related Commands

Command	Description
show ntp associations	Displays the status of the NTP associations.

show registry

To show the function registry information, use the **show registry** EXEC command.

show registry [*registry-name* [*registry-num*]] [**brief** | **statistics**]

Syntax Description	<i>registry-name</i>	(Optional) Name of the registry to examine.
	<i>registry-num</i>	(Optional) Number of the registry to examine.
	brief	(Optional) Displays limited functions and services information.
	statistics	(Optional) Displays function registry statistics.

Defaults	brief

Command Modes	EXEC

Command History	Release	Modification
	11.1	This command was introduced.

Examples The following example is sample output of the **show registry** command using the **brief** argument:

```
Switch> show registry atm 3/0/0 brief
```

```
Registry objects: 1799  bytes: 213412
```

```
--
```

```
Registry 23: ATM Registry
```

```
Service 23/0:
```

```
Service 23/1:
```

```
Service 23/2:
```

```
Service 23/3:
```

```
Service 23/4:
```

```
Service 23/5:
```

```
Service 23/6:
```

```
Service 23/7:
```

```
Service 23/8:
```

```
Service 23/9:
```

```
Service 23/10:
```

```
Service 23/11:
```

```
Service 23/12:
```

```
Service 23/13:
```

```
Service 23/14:
```

```
--
```

```
Registry 25: ATM routing Registry
```

```
Service 25/0:
```

show sntp

To show information about the Simple Network Time Protocol (SNTP), use the **show sntp** EXEC command on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.

show sntp

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Release	Modification
11.2	This command was introduced.

Examples The following is sample output from the **show sntp** command:

```
Router> show sntp

SNTP server      Stratum  Version  Last Receive
171.69.118.9     5        3        00:01:02
172.21.28.34     4        3        00:00:36   Synced  Bcast

Broadcast client mode is enabled.
```

[Table 54](#) describes the significant fields shown in the display.

Table 54 show sntp Field Descriptions

Field	Description
SNTP server	Address of the configured or broadcast NTP server.
Stratum	NTP stratum of the server. The stratum indicates how far away from an authoritative time source the server is.
Version	NTP version of the server.
Last Receive	Time since the last NTP packet was received from the server.
Synced	Indicates the server chosen for synchronization.
Bcast	Indicates a broadcast server.

Related Commands

Command	Description
snmp broadcast client	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNMP to accept NTP traffic from any broadcast server.
snmp server	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNMP to request and accept NTP traffic from a time server.

sntp broadcast client

To use the Simple Network Time Protocol (SNTP) to accept Network Time Protocol (NTP) traffic from any broadcast server, use the **sntp broadcast client** global configuration command to configure a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router. To prevent the router from accepting broadcast traffic, use the **no** form of this command.

- sntp broadcast client**
- no sntp broadcast client**

Syntax Description This command has no arguments or keywords.

Defaults The router does not accept SNTP traffic from broadcast servers.

Command Modes Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines

SNTP is a compact, client-only version of the NTP. SNMP can only receive the time from NTP servers; it cannot be used to provide time services to other systems.

SNTP typically provides time within 100 milliseconds of the accurate time, but it does not provide the complex filtering and statistical mechanisms of NTP. In addition, SNTP does not authenticate traffic, although you can configure extended access lists to provide some protection.

You must configure the router with either this command or the **sntp server** global configuration command to enable SNTP.

Examples

The following example enables the router to accept broadcast NTP packets and shows sample **show sntp** command output:

```
Router(config)# sntp broadcast client
Router(config)# end
Router#
%SYS-5-CONFIG: Configured from console by console
Router# show sntp
```

SNTP server	Stratum	Version	Last Receive	
172.21.28.34	4	3	00:00:36	Synced Bcast

Broadcast client mode is enabled.

Related Commands	Command	Description
	show snTP	Displays information about SNTP on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.
	snTP server	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to request and accept NTP traffic from a time server.

sntp server

To configure a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, Cisco 1750, or Cisco 800 router to use the Simple Network Time Protocol (SNTP) to request and accept Network Time Protocol (NTP) traffic from a stratum 1 time server, use the **sntp server** global configuration command. To remove a server from the list of NTP servers, use the **no** form of this command.

sntp server {*address* | *hostname*} [*version number*]

no sntp server {*address* | *hostname*}

Syntax Description	<i>address</i>	IP address of the time server.
	<i>hostname</i>	Host name of the time server.
	<i>version number</i>	(Optional) Version of NTP to use. The default is 1.

Defaults The router does not accept SNTP traffic from a time server.

Command Modes Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines SNTP is a compact, client-only version of the NTP. SNTP can only receive the time from NTP servers; it cannot be used to provide time services to other systems.

SNTP typically provides time within 100 milliseconds of the accurate time, but it does not provide the complex filtering and statistical mechanisms of NTP. In addition, SNTP does not authenticate traffic, although you can configure extended access lists to provide some protection.

Enter this command once for each NTP server.

You must configure the router with either this command or the **sntp broadcast client** global configuration command in order to enable SNTP.

SNTP time servers should operate only at the root (stratum 1) of the subnet, and then only in configurations where no other source of synchronization other than a reliable radio or modem time service is available. A stratum 2 server cannot be used as an SNTP time server. The use of SNTP rather than NTP in primary servers should be carefully considered.

Examples The following example enables the router to request and accept NTP packets from the server at 172.21.118.9 and displays sample **show sntp** command output:

```
Router(config)# sntp server 172.21.118.9
Router(config)# end
Router#
%SYS-5-CONFIG: Configured from console by console
```


Router# **show sntp**

SNTP server	Stratum	Version	Last Receive
172.21.118.9	5	3	00:01:02 Synced

Related Commands

Command	Description
show sntp	Displays information about SNTP on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.
sntp broadcast client	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to accept NTP traffic from any broadcast server.

time-range

To enable time-range configuration mode and define time ranges for functions (such as extended access lists), use the **time-range** global configuration command. To remove the time limitation, use the **no** form of this command.

```
time-range time-range-name
no time-range time-range-name
```

Syntax Description

time-range-name Desired name for the time range. The name cannot contain a space or quotation mark, and must begin with a letter.

Defaults

None

Command Modes

Global configuration

Command History

Release	Modification
12.0(1)T	This command was introduced.

Usage Guidelines

The **time-range** entries are identified by a name, which is referred to by one or more other configuration commands. Multiple time ranges can occur in a single access list or other feature.



Note

For Cisco IOS Release 12.2, IP and Internetwork Packet Exchange (IPX) extended access lists are the only functions that can use time-ranges. For further information on using these functions, see the Release 12.2 *Cisco IOS IP Configuration Guide* and the Release 12.2 *Cisco IOS AppleTalk and Novell IPX Configuration Guide*.

After the **time-range** command, use the **periodic** time-range configuration command, the **absolute** time-range configuration command, or some combination of them to define when the feature is in effect. Multiple **periodic** commands are allowed in a time range; only one **absolute** command is allowed.



Tip

To avoid confusion, use different names for time ranges and named access lists.

Examples

The following example denies HTTP traffic on Monday through Friday from 8:00 a.m. to 6:00 p.m. The example allows UDP traffic on Saturday and Sunday from noon to midnight only.


```
time-range no-http
  periodic weekdays 8:00 to 18:00
!
time-range udp-yes
  periodic weekend 12:00 to 24:00
```

```
!
ip access-list extended strict
  deny tcp any any eq http time-range no-http
  permit udp any any time-range udp-yes
!
interface ethernet 0
  ip access-group strict in
```

Related Commands

Command	Description
absolute	Specifies an absolute start and end time for a time range.
ip access-list	Defines an IP access list by name.
periodic	Specifies a recurring (weekly) start and end time for a time range.
permit (IP)	Sets conditions under which a packet passes a named IP access list.

time-range



Troubleshooting and Fault Management Commands

Cisco IOS Release 12.2

This chapter describes the commands used to troubleshoot a routing device. To troubleshoot, you need to discover, isolate, and resolve the system problems. You can discover problems with the system monitoring commands, isolate problems with the system test commands (including **debug** commands), and resolve problems by reconfiguring your system with the suite of Cisco IOS software commands.

This chapter describes general fault management commands. For detailed troubleshooting procedures and a variety of scenarios, see the *Cisco IOS Internetwork Troubleshooting Guide* publication. For complete details on all **debug** commands, see the *Cisco IOS Debug Command Reference*.

For troubleshooting tasks and examples, refer to the “Troubleshooting and Fault Management” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

For documentation of commands in Cisco IOS Release 12.2T or 12.3 mainline, see the [Cisco IOS Configuration Fundamentals and Network Management Command Reference, Release 12.3](#).

attach

To connect to a specific line card for the purpose of executing monitoring and maintenance commands on that line card only, use the **attach** privileged EXEC command. To exit from the Cisco IOS software image on the line card and return to the Cisco IOS image on the GRP card, use the **exit** command.

attach *slot-number*

Syntax Description

<i>slot-number</i>	Slot number of the line card you want to connect to. Slot numbers range from 0 to 11 for the Cisco 12012 router and 0 to 7 for the Cisco 12008 router. If the slot number is omitted, you are prompted for the slot number.

Defaults

None

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2 GS	This command was added to support the Cisco 12000 series Gigabit Switch Routers.

Usage Guidelines

You must first use the **attach** privileged EXEC command to access the Cisco IOS software image on a line card before using line card-specific **show** EXEC commands. Alternatively, you can use the **execute-on** privileged EXEC command to execute a **show** command on a specific line card.

After you connect to the Cisco IOS image on the line card using the **attach** command, the prompt changes to LC-Slotx#, where *x* is the slot number of the line card.

The commands executed on the line card use the Cisco IOS image on that line card.

You can also use the **execute-on slot** privileged EXEC command to execute commands on one or all line cards.



Note

Do not execute the **config** EXEC command from the Cisco IOS software image on the line card.

Examples

In the following example, the user connects to the Cisco IOS image running on the line card in slot 9, gets a list of valid **show** commands, and returns the Cisco IOS image running on the GRP:

```
Router# attach 9
```

```
Entering Console for 4 Port Packet Over SONET OC-3c/STM-1 in Slot: 9
Type exit to end this session
```

```
Press RETURN to get started!
```

```
LC-Slot9# show ?
```

```

cef          Cisco Express Forwarding
clock        Display the system clock
context      Show context information about recent crash(s)
history      Display the session command history
hosts        IP domain-name, lookup style, nameservers, and host table
ipc          Interprocess communications commands
location     Display the system location
sessions     Information about Telnet connections
terminal     Display terminal configuration parameters
users        Display information about terminal lines
version      System hardware and software status
    
```

LC-Slot9# **exit**

Disconnecting from slot 9.
 Connection Duration: 00:01:04
 Router#



Note

Because not all statistics are maintained on the line cards, the output from some of the **show** commands might not be consistent.

Related Commands

Command	Description
attach shelf	Connects you to a specific (managed) shelf for the purpose of remotely executing commands on that shelf only.
execute-on slot	Executes commands remotely on a specific line card, or on all line cards simultaneously.

clear logging

To clear messages from the logging buffer, use the **clear logging** privileged EXEC command.

clear logging

Syntax Description	This command has no arguments or keywords.

Command Modes	Privileged EXEC

CommandHistory	Release	Modification
	11.2	This command was introduced.

Examples	In the following example, the logging buffer is cleared:

```
Router# clear logging

Clear logging buffer [confirm]
Router#
```

Related Commands	Command	Description
	logging buffered	Logs messages to an internal buffer.
	show logging	Displays the state of logging (syslog).

diag

To perform field diagnostics on a line card, on the Gigabit Route Processor (GRP), on the Switch Fabric Cards (SFCs), and on the Clock Scheduler Card (CSC) in Cisco 12000 series Gigabit Switch Routers (GSRs), use the **diag** privileged EXEC command. To disable field diagnostics on a line card, use the **no** form of this command.

diag *slot-number* [**halt** | **previous** | **post** | **verbose** [**wait**] | **wait**]

no diag *slot-number*

Syntax Description		
	<i>slot-number</i>	Slot number of the line card you want to test. Slot numbers range from 0 to 11 for the Cisco 12012 and 0 to 7 for the Cisco 12008 router. Slot numbers for the CSC are 16 and 17, and for the FSC are 18, 19, and 20.
	halt	(Optional) Stops the field diagnostic testing on the line card.
	previous	(Optional) Displays previous test results (if any) for the line card.
	post	(Optional) Initiates an EPROM-based extended power-on self-test (EPOST) only. The EPOST test suite is not as comprehensive as the field diagnostics, and a pass/fail message is the only message displayed on the console.
	verbose [wait]	(Optional) Enables the maximum status messages to be displayed on the console. By default, only the minimum status messages are displayed on the console. If you specify the optional wait keyword, the Cisco IOS software is not automatically reloaded on the line card after the test completes.
	wait	(Optional) Stops the automatic reloading of the Cisco IOS software on the line card after the completion of the field diagnostic testing. If you use this keyword, you must use the microcode reload slot global configuration command, or manually remove and insert the line card (to power it up) in the slot so that the GRP will recognize the line card and download the Cisco IOS software image to the line card.

Defaults No field diagnostics tests are performed on the line card.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2 GS	This command was added to support the Cisco 12000 series GSR.

Usage Guidelines

The **diag** command must be executed from the GRP main console port.

Perform diagnostics on the CSC only if a redundant CSC is in the router.

Diagnostics will stop and ask you for confirmation before altering the router's configuration. For example, running diagnostics on a SFC or CSC will cause the fabric to go from full bandwidth to one-fourth bandwidth. Bandwidth is not affected by GRP or line card diagnostics.

The field diagnostic software image is bundled with the Cisco IOS software and is downloaded automatically from the GRP to the target line card prior to testing.

**Caution**

Performing field diagnostics on a line card stops all activity on the line card. Before the **diag EXEC** command begins running diagnostics, you are prompted to confirm the request to perform field diagnostics on the line card.

In normal mode, if a test fails, the title of the failed test is displayed on the console. However, not all tests that are performed are displayed. To view all the tests that are performed, use the **verbose** keyword.

After all diagnostic tests are completed on the line card, a PASSED or TEST FAILURE message is displayed. If the line card sends a PASSED message, the Cisco IOS software image on the line card is automatically reloaded unless the **wait** keyword is specified. If the line card sends a TEST FAILURE message, the Cisco IOS software image on the line card is not automatically reloaded.

If you want to reload the line card after it fails diagnostic testing, use the **microcode reload slot** global configuration command.

**Note**

When you stop the field diagnostic test, the line card remains down (that is, in an unbooted state). In most cases, you stopped the testing because you need to remove the line card or replace the line card. If that is not the case, and you want to bring the line card back up (that is, online), you must use the **microcode reload** global configuration command or power cycle the line card.

If the line card fails the test, the line card is defective and should be replaced. In future releases this might not be the case because DRAM and SDRAM SIMM modules might be field replaceable units. For example, if the DRAM test failed you might only need to replace the DRAM on the line card.

For more information, refer to the Cisco 12000 series installation and configuration guides.

Examples

In the following example, a user is shown the output when field diagnostics are performed on the line card in slot 3. After the line card passes all field diagnostic tests, the Cisco IOS software is automatically reloaded on the card. Before starting the diagnostic tests, you must confirm the request to perform these tests on the line card because all activity on the line card is halted. The total/indiv. timeout set to 600/220 sec. message indicates that 600 seconds are allowed to perform all field diagnostics tests, and that no single test should exceed 220 seconds to complete.

```
Router# diag 3

Running Diags will halt ALL activity on the requested slot. [confirm]
Router#
Launching a Field Diagnostic for slot 3
Running DIAG config check
RUNNING DIAG download to slot 3 (timeout set to 400 sec.)
sending cmd FDIAG-DO ALL to fdiag in slot 3
(total/indiv. timeout set to 600/220 sec.)
Field Diagnostic ****PASSED**** for slot 3
```

```
Field Diag eeprom values: run 159 fial mode 0 (PASS) slot 3
    last test failed was 0, error code 0
sending SHUTDOWN FDIAG_QUIT to fdiag in slot 3

Board will reload
.
.
.
Router#
```

In the following example, a user is shown the output when field diagnostics are performed on the line card in slot 3 in verbose mode:

```
Router# diag 3 verbose

Running Diags will halt ALL activity on the requested slot. [confirm]
Router#
Launching a Field Diagnostic for slot 3
Running DIAG config check
RUNNING DIAG download to slot 3 (timeout set to 400 sec.)
sending cmd FDIAG-DO ALL to fdiag in slot 3
(total/indiv. timeout set to 600/220 sec.)
FDIAG_STAT_IN_PROGRESS: test #1 R5K Internal Cache
FDIAG_STAT_PASS test_num 1
FDIAG_STAT_IN_PROGRESS: test #2 Sunblock Ordering
FDIAG_STAT_PASS test_num 2
FDIAG_STAT_IN_PROGRESS: test #3 Dram Datapins
FDIAG_STAT_PASS test_num 3
.
.
.
Field Diags: FDIAG_STAT_DONE
Field Diagnostic ****PASSED**** for slot 3
Field Diag eeprom values: run 159 fial mode 0 (PASS) slot 3
    last test failed was 0, error code 0
sending SHUTDOWN FDIAG_QUIT to fdiag in slot 3

Board will reload
.
.
.
Router#
```

Related Commands

Command	Description
microcode reload	Reloads the Cisco IOS image on a line card on the Cisco 7000 series with RSP7000, Cisco 7500 series, or Cisco 12000 series routers after all microcode configuration commands have been entered.

exception core-file

To specify the name of the core dump file, use the **exception core-file** global configuration command. To return to the default core filename, use the **no** form of this command.

exception core-file *file-name*

no exception core-file

Syntax Description	<i>file-name</i> Name of the core dump file saved on the server.

Defaults	The core file is named <i>hostname-core</i> , where <i>hostname</i> is the name of the router.

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.2	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

If you use TFTP to dump the core file to a server, the router will only dump the first 16 MB of the core file. If the router's memory is larger than 16 MB, the whole core file will not be copied to the server. Therefore, use rcp or FTP to dump the core file.

Examples

In the following example, a user configures a router to use FTP to dump a core file named dumpfile to the FTP server at 172.17.92.2 when it crashes:

```
ip ftp username red
ip ftp password blue
exception protocol ftp
exception dump 172.17.92.2
exception core-file dumpfile
```

Related Commands

Command	Description
exception dump	Causes the router to dump a core file to a particular server when the router crashes.
exception memory	Causes the router to create a core dump and reboot when certain memory size parameters are violated.
exception spurious-interrupt	Causes the router to create a core dump and reload after a specified number of spurious interrupts.
exception protocol	Configures the protocol used for core dumps.
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp username	Configures the username for FTP connections.

exception dump

To configure the router to dump a core file to a particular server when the router crashes, use the **exception dump** global configuration command. To disable core dumps, use the **no** form of this command.

exception dump *ip-address*

no exception dump

Syntax Description	<i>ip-address</i>	IP address of the server that stores the core dump file.
Defaults	Disabled	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

If you use TFTP to dump the core file to a server, the router will only dump the first 16 MB of the core file. If the router's memory is larger than 16 MB, the whole core file will not be copied to the server. Therefore, use rcp or FTP to dump the core file.

The core dump is written to a file named *hostname-core* on your server, where *hostname* is the name of the router. You can change the name of the core file by configuring the **exception core-file** command.

This procedure can fail for certain types of system crashes. However, if successful, the core dump file will be the size of the memory available on the processor (for example, 16 MB for a CSC/4).

Examples

In the following example, a user configures a router to use FTP to dump a core file to the FTP server at 172.17.92.2 when it crashes:

```
ip ftp username red
ip ftp password blue
exception protocol ftp
exception dump 172.17.92.2
```

Related Commands	Command	Description
	exception core-file	Specifies the name of the core dump file.
	exception memory	Causes the router to create a core dump and reboot when certain memory size parameters are violated.
	exception spurious-interrupt	Causes the router to create a core dump and reload after a specified number of spurious interrupts.
	exception protocol	Configures the protocol used for core dumps.
	ip ftp password	Specifies the password to be used for FTP connections.
	ip ftp username	Configures the username for FTP connections.
	ip rcmd remote-username	Configures the remote username to be used when requesting a remote copy using rcp.

exception linecard

To enable storing of crash information for a line card and optionally specify the type and amount of information stored, use the **exception linecard** global configuration command. To disable the storing of crash information for the line card, use the **no** form of this command.

exception linecard { **all** | **slot** *slot-number* } [**corefile** *filename* | **main-memory** *size* [**k** | **m**] | **queue-ram** *size* [**k** | **m**] | **rx-buffer** *size* [**k** | **m**] | **sqe-register-rx** | **sqe-register-tx** | **tx-buffer** *size* [**k** | **m**]]

no exception linecard

Syntax Description		
all		Stores crash information for all line cards.
slot <i>slot-number</i>		Stores crash information for the line card in the specified slot. Slot numbers range from 0 to 11 for the Cisco 12012 and 0 to 7 for the Cisco 12008 router.
corefile <i>filename</i>		(Optional) Stores the crash information in the specified file in NVRAM. The default filename is <i>hostname-core-slot-number</i> (for example, c12012-core-8).
main-memory <i>size</i>		(Optional) Stores the crash information for the main memory on the line card and specifies the size of the crash information. Size of the memory to store is 0 to 268435456.
queue-ram <i>size</i>		(Optional) Stores the crash information for the queue RAM memory on the line card and specifies the size of the crash information. Size of the memory to store can be from 0 to 1048576.
rx-buffer <i>size</i> tx-buffer <i>size</i>		(Optional) Stores the crash information for the receive and transmit buffer on the line card and specifies the size of the crash information. Size of the memory to store can be from 0 to 67108864.
sqe-register-rx sqe-register-tx		(Optional) Stores crash information for the receive or transmit silicon queueing engine registers on the line card.
k m		(Optional) The k option multiplies the specified <i>size</i> by 1K (1024), and the m option multiplies the specified <i>size</i> by 1M (1024*1024).

Defaults

No crash information is stored for the line card.

If enabled with no options, the default is to store 256 MB of main memory.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.2 GS	This command was introduced.

Usage Guidelines

This command is currently supported only on Cisco 12000 series Gigabit Switch Routers (GSRs).

Use the **exception linecard** global configuration command only when directed by a technical support representative. Only enable options that the technical support representative requests you to enable. Technical support representatives need to be able to look at the crash information from the line card to troubleshoot serious problems on the line card. The crash information contains all the line card memory information including the main memory and transmit and receive buffer information.

**Caution**

Use caution when enabling the **exception linecard** global configuration command. Enabling all options could cause a large amount (150 to 250 MB) of crash information to be sent to the server.

Examples

In the following example, the user enables the storing of crash information for line card 8. By default, 256 MB of main memory is stored.

```
12000(config)# exception linecard slot 8
```

exception memory

To cause the router to create a core dump and reboot when certain memory size parameters are violated, use the **exception memory** global configuration command. To disable the rebooting and core dump, use the **no** form of this command.

exception memory {**fragment** *size* | **minimum** *size*}

no exception memory {**fragment** | **minimum**}

Syntax Description	fragment <i>size</i>	The minimum contiguous block of memory in the free pool, in bytes.
	minimum <i>size</i>	The minimum size of the free memory pool, in bytes.

Defaults Disabled

Command Modes Global configuration (config)

CommandHistory	Release	Modification
	10.3	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

This command is useful to troubleshoot memory leaks.

The size is checked every 60 seconds. If you enter a size that is greater than the free memory, a core dump and router reload is generated after 60 seconds.

The **exception dump** command must be configured in order to generate a core dump file. If the **exception dump** command is not configured, the router reloads without generating a core dump.

Examples

In the following example, the user configures the router to monitor the free memory. If the amount of free memory falls below 250,000 bytes, the router will dump the core file and reload.

```
exception dump 131.108.92.2
exception core-file memory.overrun
exception memory minimum 250000
```

Related Commands	Command	Description
	exception core-file	Specifies the name of the core dump file.
	exception dump	Configures the router to dump a core file to a particular server when the router crashes.
	exception protocol	Configures the protocol used for core dumps.
	exception region-size	Specifies the size of the region for the exception-time memory pool.
	ip ftp password	Specifies the password to be used for FTP connections.
	ip ftp username	Configures the username for FTP connections.

exception protocol

To configure the protocol used for core dumps, use the **exception protocol** global configuration command. To configure the router to use the default protocol, use the **no** form of this command.

```
exception protocol {ftp | rcp | tftp}

no exception protocol
```

Syntax Description	ftp	Uses File Transfer Protocol (FTP) for core dumps.
	rcp	Uses remote copy protocol (rcp) for core dumps.
	tftp	Uses TFTP for core dumps. This is the default.

Defaults	TFTP

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

If you use TFTP to dump the core file to a server, the router will only dump the first 16 MB of the core file. If the router's memory is larger than 16 MB, the whole core file will not be copied to the server. Therefore, use rcpx or FTP to dump the core file.

Examples

In the following example, the user configures a router to use FTP to dump a core file to the FTP server at 172.17.92.2 when it crashes:

```
ip ftp username red
ip ftp password blue
exception protocol ftp
exception dump 172.17.92.2
```

Related Commands

Command	Description
exception core-file	Specifies the name of the core dump file.
exception dump	Causes the router to dump a core file to a particular server when the router crashes.
exception memory	Causes the router to create a core dump and reboot when certain memory size parameters are violated.
exception spurious-interrupt	Causes the router to create a core dump and reload after a specified number of spurious interrupts.
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp username	Configures the username for FTP connections.

exception region-size

To specify the size of the region for the exception-time memory pool, use the **exception region-size** global configuration command. To use the default region size, use the **no** form of this command.

exception region-size *size*

no exception region-size

Syntax Description	<i>size</i>	The size of the region for the exception-time memory pool.

Defaults	16,384 bytes

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

The **exception region-size** command is used to define a small amount of memory to serve as a fallback pool when the processor memory pool is marked corrupt. The **exception memory** command must be used to allocate memory to perform a core dump.

Examples

In the following example, the region size is set at 1024:

```
Router# exception region-size 1024
```

Related Commands

Command	Description
exception core-file	Specifies the name of the core dump file.
exception dump	Configures the router to dump a core file to a particular server when the router crashes.

Command	Description
exception memory	Causes the router to create a core dump and reboot when certain memory size parameters are violated.
exception protocol	Configures the protocol used for core dumps.
ip ftp password	Specifies the password to be used for FTP connections.
ip ftp username	Configures the username for FTP connections.

exception spurious-interrupt

To configure the router to create a core dump and reload after a specified number of spurious interrupts, use the **exception spurious-interrupt** command global configuration command. To disable the core dump and reload, use the **no** form of this command.

exception spurious-interrupt *number*

no exception spurious-interrupt

Syntax Description	<i>number</i>	(Optional) A number from 1 to 4294967295 that indicates the maximum number of spurious interrupts to include in the core dump before reloading.

Defaults	Disabled

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines



Caution

Use the **exception** commands only under the direction of a technical support representative. Creating a core dump while the router is functioning in a network can disrupt network operation. The resulting binary file, which is very large, must be transferred to a TFTP, File Transfer Protocol (FTP), or remote copy protocol (rcp) server and subsequently interpreted by technical personnel that have access to source code and detailed memory maps.

If you use TFTP to dump the core dump file to a server, the router will only dump the first 16 MB of the file. If the router's memory is larger than 16 MB, the whole core file will not be copied to the server. Therefore, use rcp or FTP to dump the core file.

Examples

In the following example, the user configures a router to create a core dump with a limit of two spurious interrupts:

```
Router# exception spurious-interrupt 2
```

Related Commands	Command	Description
	exception core-file	Specifies the name of the core dump file.
	ip ftp password	Specifies the password to be used for FTP connections.
	ip ftp username	Configures the user name for FTP connections.

execute-on

To execute commands on a line card, use the **execute-on** privileged EXEC command.

execute-on {**slot** *slot-number* | **all** | **master**} *command*

Syntax Description	slot <i>slot-number</i>	Executes the command on the line card in the specified slot. Slot numbers can be chosen from the following ranges: • Cisco 12012 router: 0 to 11 • Cisco 12008 access server: 0 to 7 • Cisco AS5800 access server: 0 to 13
	all	Executes the command on all line cards.
	master	(AS5800 only) Executes the designated command on a Dial Shelf Controller (DSC). Do not use this option; it is used for technical support troubleshooting only.
	<i>command</i>	Cisco IOS command to remotely execute on the line card.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.2 GS	This command was introduced to support Cisco 12000 series Gigabit Switch Routers.
	11.3(2)AA	Support for this command was added to the Cisco AS5800 universal access server.

Usage Guidelines Use this command to execute a command on one or all line cards to monitor and maintain information on one or more line cards (for example, a line card in a specified slot on a dial shelf). This allows you to issue commands remotely; that is, to issue commands without needing to log in to the line card directly. The **all** form of the command allows you to issue commands to all the line cards without having to log in to each in turn.

Though this command does not have a **no** form, note that it is possible to use the **no** form of the remotely executed commands used in this command.



Tip

This command is useful when used with **show** EXEC commands (such as **show version**), because you can verify and troubleshoot the features found only on a specific line card. Please note, however, that because not all statistics are maintained on the line cards, the output from some of the **show** commands might not be consistent.

Cisco 12000 GSR Guidelines and Restrictions

You can use the **execute-on** privileged EXEC command only from Cisco IOS software running on the GRP card.

**Timesaver**

Though you can use the **attach** privileged EXEC command to execute commands on a specific line card, using the **execute-on slot** command saves you some steps. For example, first you must use the **attach** command to connect to the Cisco IOS software running on the line card. Next you must issue the command. Finally you must disconnect from the line card to return to the Cisco IOS software running on the GRP card. With the **execute-on slot** command, you can perform three steps with one command. In addition, the **execute-on all** command allows you to perform the same command on all line cards simultaneously.

Cisco AS5800 Guidelines and Restrictions

The purpose of the command is to conveniently enable certain commands to be remotely executed on the dial shelf cards from the router without connecting to each line card. This is the recommended procedure, because it avoids the possibility of adversely affecting a good configuration of a line card in the process. The **execute-on** command does not give access to every Cisco IOS command available on the Cisco AS5800 access server. In general, the purpose of the **execute-on** command is to provide access to statistical reports from line cards without directly connecting to the dial shelf line cards.

**Warning**

Do not use this command to change configurations on dial shelf cards, because such changes will not be reflected in the router shelf.

Using this command makes it possible to accumulate inputs for inclusion in the **show tech-support** command.

The **master** form of the command can run a designated command remotely on the router from the DSC card. However, using the console on the DSC is *not* recommended. It is used for technical support troubleshooting only.

The **show tech-support** command for each dial shelf card is bundled into the router shelf's **show tech-support** command via the **execute-on** facility.

The **execute-on** command also support interactive commands such as the following:

```
router: execute-on slave slot slot ping
```

The **execute-on** command has the same limitations and restrictions as a **vty telnet** client has; that is, it cannot reload DSC using the following command:

```
router: execute-on slave slot slot reload
```

You can use the **execute-on** command to enable remote execution of the commands included in the following partial list:

- **debug dsc clock**
- **show context**
- **show diag**
- **show environment**
- **show dsc clock**
- **show dsi**
- **show dsip**
- **show tech-support**

Examples

In the following example, the user executes the **show controllers** command on the line card in slot 4 of a Cisco 12000 series GSR:

```
Router# execute-on slot 4 show controllers
```

```
===== Line Card (Slot 4) =====
```

```
Interface POS0
Hardware is BFLC POS
lcpos_instance struct    6033A6E0
RX POS ASIC addr space  12000000
TX POS ASIC addr space  12000100
SUNI framer addr space  12000400
SUNI rsop intr status    00
CRC16 enabled, HDLC enc, int clock
no loop
```

```
Interface POS1
Hardware is BFLC POS
lcpos_instance struct    6033CEC0
RX POS ASIC addr space  12000000
TX POS ASIC addr space  12000100
SUNI framer addr space  12000600
SUNI rsop intr status    00
CRC32 enabled, HDLC enc, int clock
no loop
```

```
Interface POS2
Hardware is BFLC POS
lcpos_instance struct    6033F6A0
RX POS ASIC addr space  12000000
TX POS ASIC addr space  12000100
SUNI framer addr space  12000800
SUNI rsop intr status    00
CRC32 enabled, HDLC enc, int clock
no loop
```

```
Interface POS3
Hardware is BFLC POS
lcpos_instance struct    60341E80
RX POS ASIC addr space  12000000
TX POS ASIC addr space  12000100
SUNI framer addr space  12000A00
SUNI rsop intr status    00
CRC32 enabled, HDLC enc, ext clock
no loop
Router#
```

Related Commands

Command	Description
attach	Connects you to a specific line card for the purpose of executing commands using the Cisco IOS software image on that line card.

logging

To log messages to a syslog server host, use the **logging** global configuration command. To delete the syslog server with the specified address from the list of syslogs, use the **no** form of this command.

logging *host-name*

no logging *host-name*

Syntax Description

<i>host-name</i>	Name or IP address of the host to be used as a syslog server.

Defaults

No messages are logged to a syslog server host.

Command Modes

Global configuration (config)

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

This command identifies a syslog server host to receive logging messages. By issuing this command more than once, you build a list of syslog servers that receive logging messages.

Examples

In the following example, messages are logged to a host named john:

```
logging john
```

Related Commands

Command	Description
logging trap	Limits messages logged to the syslog servers based on severity and limits the logging of system messages sent to syslog servers to only those messages at the specified level.

logging buffered

To limit messages logged to an internal buffer based on severity, use the **logging buffered** global configuration command. To cancel the use of the buffer, use the **no** form of this command. The **default** form of this command returns the buffer size to the default size.

logging buffered [*buffer-size* | *level*]

no logging buffered

default logging buffered

Syntax Description	<i>buffer-size</i>	(Optional) Size of the buffer from 4096 to 4,294,967,295 bytes. The default size varies by platform.
	<i>level</i>	(Optional) Limits the logging of messages to the buffer to a specified level. You can enter the level name or level number. See Table 55 for a list of the acceptable level name or level number keywords.

Defaults For most platforms, the Cisco IOS software logs messages to the internal buffer.

Command Modes Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.
	11.1(17)T	The command syntax was changed to include the <i>level</i> argument.

Usage Guidelines

This command copies logging messages to an internal buffer. The buffer is circular in nature, so newer messages overwrite older messages after the buffer is filled.

Specifying a level causes messages at that level and numerically lower levels to be logged in an internal buffer. See [Table 55](#) for a list of level arguments.

Do not make the buffer size too large because the router could run out of memory for other tasks. You can use the **show memory EXEC** command to view the free processor memory on the router; however, this is the maximum available and should not be approached. The **default logging buffered** command resets the buffer size to the default for the platform.

To display the messages that are logged in the buffer, use the **show logging EXEC** command. The first message displayed is the oldest message in the buffer.

The **show logging EXEC** command displays the addresses and levels associated with the current logging setup, and any other logging statistics.

Table 55 System Message Logging Priorities and Corresponding Level Names/Numbers

Level Name	Level Number	Description	Syslog Definition
emergencies	0	System unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING
notifications	5	Normal but significant condition	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

Examples

In the following example, the user enables logging to an internal buffer:

```
logging buffered
```

Related Commands

Command	Description
clear logging	Clears messages from the logging buffer.
show logging	Displays the state of logging (syslog).

logging console

To limit messages logged to the console based on severity, use the **logging console** global configuration command. To disable logging to the console terminal, use the **no** form of this command.

logging console *level*

no logging console

Syntax Description	<i>level</i>	Limits the logging of messages displayed on the console terminal to a specified level. You can enter the level number or level name. See Table 56 for a list of the level arguments.

Defaults	debugging

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Specifying a level causes messages at that level and numerically lower levels to be displayed at the console terminal.
	The show logging EXEC command displays the addresses and levels associated with the current logging setup, and any other logging statistics. See Table 56 .

Table 56 System Message Logging Priorities and Corresponding Level Names/Numbers

Level Arguments	Level	Description	Syslog Definition
emergencies	0	System unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING
notifications	5	Normal but significant condition	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

The effect of the **log** keyword with the IP **access list** (extended) interface configuration command depends on the setting of the **logging console** command. The **log** keyword takes effect only if the logging console level is set to 6 or 7. If you change the default to a level lower than 6 and specify the **log** keyword with the IP **access list** (extended) command, no information is logged or displayed.

Examples

In the following example, the user changes the level of messages displayed to the console terminal to **alerts**, which means alerts and emergencies are displayed:

```
logging console alerts
```

Related Commands

Command	Description
access-list (extended)	Defines an extended XNS access list.
logging facility	Configures the syslog facility in which system messages are sent.

logging facility

To configure the syslog facility in which system messages are sent, use the **logging facility** global configuration command. To revert to the default of **local7**, use the **no** form of this command.

logging facility *facility-type*

no logging facility

Syntax Description	<i>facility-type</i>	Syslog facility. See the Usage Guidelines section of this command reference entry for descriptions of acceptable keywords.

Defaults	local7

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Table 57 describes the acceptable keywords for the <i>facility-type</i> argument.

Table 57 logging facility facility-type Argument

Facility-type keyword	Description
auth	Authorization system
cron	Cron facility
daemon	System daemon
kern	Kernel
local0–7	Reserved for locally defined messages
lpr	Line printer system
mail	Mail system
news	USENET news
sys9	System use
sys10	System use
sys11	System use
sys12	System use
sys13	System use
sys14	System use
syslog	System log

Table 57 *logging facility facility-type Argument (continued)*

Facility-type keyword	Description
user	User process
uucp	UNIX-to-UNIX copy system

Examples

In the following example, the user configures the syslog facility to the kernel facility type:

```
logging facility kern
```

Related Commands

Command	Description
logging console	Limits messages logged to the console based on severity.

logging history

To limit syslog messages sent to the router's history table and the Simple Network Management Protocol (SNMP) network management station based on severity, use the **logging history** global configuration command. To return the logging of syslog messages to the default level, use the **no** form of this command with the previously configured severity level argument.

logging history [*severity-level-name* | *severity-level-number*]

no logging history [*severity-level-name* | *severity-level-number*]

Syntax Description	<i>severity-level-name</i>	Name of the severity level. Specifies the lowest severity level for system error messag logging. See the Usage Guidelines section of this command for available keywords.
	<i>severity-level-number</i>	Number of the severity level. Specifies the lowest severity level for system error messag logging. See the Usage Guidelines section of this command for available keywords.

Defaults	Logging of system messages of severity levels 0 through 4 (emergency, alert, critical, error, and warning levels); in other words, “saving level warnings or higher”

Command Modes	Global configuration (config)

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	Sending syslog messages to the SNMP network management station occurs when you enable syslog traps with the snmp-server enable traps global configuration command. Because SNMP traps are inherently unreliable and much too important to lose, at least one syslog message, the most recent message, is stored in a history table on the router. The history table, which contains table size, message status, and message text data, can be viewed using the show logging history command. The number of messages stored in the table is governed by the logging history size EXEC command. Severity levels are numbered 0 through 7, with 0 being the highest severity level and 7 being the lowest severity level (that is, the lower the number, the more critical the message). Specifying a <i>level</i> causes messages at that severity level and numerically lower levels to be stored in the router's history table and sent to the SNMP network management station. For example, specifying the level critical causes messages as the critical (3), alert (2), and emergency (1) levles to be saved to the logging history table. Table 58 provides a description of logging severity levels, listed from highest severity to lowest severity, and the arguments used inthe logging history command syntax. Note that you can use the level name or the level number as the <i>level</i> argument in this command.

Table 58 System Logging Message Severity Levels

Severity Level Name	Severity Level Number	Description	Syslog Definition
emergencies	0	System unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING
notifications	5	Normal but significant condition	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

Examples

In the following example, the system is initially configured to the default of saving severity level 4 or higher. The **logging history 1** command is used to configure the system to save only level 1 (alert) and level 0 (emergency) messages to the logging history table. The configuration is then confirmed using the show logging history command.

```
Router#show logging history
Syslog History Table:10 maximum table entries,
! The following line shows that system-error-message-logging is set to the
! default level of "warnings" (4).
saving level warnings or higher
23 messages ignored, 0 dropped, 0 recursion drops
1 table entries flushed
SNMP notifications not enabled
  entry number 2 : LINK-3-UPDOWN
    Interface FastEthernet0, changed state to up
    timestamp: 2766
Router#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)#logging history 1
Router(config)#end
Router#
4w0d: %SYS-5-CONFIG_I: Configured from console by console
Router#show logging history
Syslog History Table:1 maximum table entries,
! The following line indicates that 'logging history level 1' is configured.
saving level alerts or higher
18 messages ignored, 0 dropped, 0 recursion drops
1 table entries flushed
SNMP notifications not enabled
  entry number 2 : LINK-3-UPDOWN
    Interface FastEthernet0, changed state to up
    timestamp: 2766
Router#
```

Related Commands	Command	Description
	logging on	Controls (enables or disables) the logging of system messages.
	logging history size	Changes the number of syslog messages stored in the router's history table.
	show logging	Displays the state of logging (syslog).
	show logging history	Displays the state of logging history.
	snmp-server host	Specifies the recipient of an SNMP notification operation.

logging history size

To change the number of syslog messages stored in the router's history table, use the **logging history size** global configuration command. To return the number of messages to the default value, use the **no** form of this command.

logging history size *number*

no logging history size

Syntax Description	<i>number</i>	Number from 1 to 500 that indicates the maximum number of messages stored in the history table.

Defaults	One message

Command Modes	Global configuration (config)

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	When the history table is full (that is, it contains the maximum number of message entries specified with the logging history size command), the oldest message entry is deleted from the table to allow the new message entry to be stored.

Examples	In the following example, the user sets the number of messages stored in the history table to 20: <pre>logging history size 20</pre>

Related Commands	Command	Description
	logging history	Limits syslog messages sent to the router's history table and the SNMP network management station based on severity.
	show logging	Displays the state of logging (syslog).

logging linecard

To log messages to an internal buffer on a line card, use the **logging linecard** global configuration command. To cancel the use of the internal buffer on the line cards, use the **no** form of this command.

logging linecard [*size* | *level*]

no logging linecard

Syntax Description	<i>size</i>	(Optional) Size of the buffer used for each line card. The range is from 4096 to 65,536 bytes. The default is 8 KB.
	<i>level</i>	(Optional) Limits the logging of messages displayed on the console terminal to a specified level. The message level can be one of the following: • alerts—Immediate action needed • critical—Critical conditions • debugging—Debugging messages • emergencies—System is unusable • errors—Error conditions • informational—Informational messages • notifications—Normal but significant conditions • warnings—Warning conditions

Defaults The Cisco IOS software logs messages to the internal buffer on the GRP card.

Command Modes Global configuration (config)

Command History	Release	Modification
	11.2 GS	This command was added to support the Cisco 12000 series Gigabit Switch Routers.

Usage Guidelines Specifying a message level causes messages at that level and numerically lower levels to be stored in the internal buffer on the line cards.

[Table 59](#) lists the message levels and associated numerical level. For example, if you specify a message level of critical, all critical, alert, and emergency messages will be logged.

Table 59 *Message Levels*

Level Keyword	Level
emergencies	0
alerts	1
critical	2
errors	3
warnings	4
notifications	5
informational	6
debugging	7

To display the messages that are logged in the buffer, use the **show logging slot** EXEC command. The first message displayed is the oldest message in the buffer.

Do not make the buffer size too large because the router could run out of memory for other tasks. You can use the **show memory** EXEC command to view the free processor memory on the router; however, this is the maximum available and should not be approached.

Examples

The following example enables logging to an internal buffer on the line cards using the default buffer size and logging warning, error, critical, alert, and emergency messages:

```
(config)# logging linecard warnings
```

Related Commands

Command	Description
clear logging	Clears messages from the logging buffer.
show logging	Displays the state of logging (syslog).

logging monitor

To limit messages logged to the terminal lines (monitors) based on severity, use the **logging monitor** global configuration command. This command limits the logging messages displayed on terminal lines other than the console line to messages with a level at or above the *level* argument. To disable logging to terminal lines other than the console line, use the **no** form of this command.

logging monitor *severity-level*

no logging monitor

Syntax Description	<i>severity-level</i>	Limits the logging of messages logged to the terminal lines (monitors) to a specified level. You can enter the level number or level name. See the Usage Guidelines section for a list of acceptable severity-level keywords.

Defaults	debugging (severity-level 7)

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Specifying a <i>level</i> causes messages at that level and numerically lower levels to be displayed to the monitor.

Table 60 logging monitor System Message Logging Priorities

Level Name	Level Number	Description	Syslog Definition
emergencies	0	System unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING
notifications	5	Normal but significant conditions	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

Examples	In the following example, the user specifies that only messages of the levels errors , critical , alerts , and emergencies be displayed on terminals:

■ logging monitor

```
logging monitor 3
```

Related Commands

Command	Description
terminal monitor	Enables the display of system messages to the terminal connection.

logging on

To control logging of system messages (including error messages or debugging messages), use the **logging on** global configuration command. This command sends system messages to a logging process, which logs messages to designated locations asynchronously to the processes that generated the messages. To disable the logging process, use the **no** form of this command.

logging on

no logging on

Syntax Description

This command has no arguments or keywords.

Defaults

The Cisco IOS software sends messages to the asynchronous logging process.

Command Modes

Global configuration (config)

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The logging process controls the distribution of logging messages to the various destinations, such as the logging buffer, terminal lines, or syslog server. You can turn logging on and off for these destinations individually using the **logging buffered**, **logging monitor**, and **logging** global configuration commands. However, if the **logging on** command is disabled, no messages will be sent to these destinations. Only the console will receive messages.

Additionally, the logging process logs messages to the console and the various destinations after the processes that generated them have completed. When the logging process is disabled, messages are displayed on the console as soon as they are produced, often appearing in the middle of command output.



Caution

Disabling the **logging on** command will substantially slow down the router. Any process generating system messages will wait until the messages have been displayed on the console before continuing.

The **logging synchronous** line configuration command also affects the displaying of messages to the console. When the **logging synchronous** command is enabled, messages will appear only after the user types a carriage return.

Examples

The following example shows command output and message output when logging is enabled. The ping process finishes before any of the logging information is printed to the console (or any other destination).

```
Router(config)# logging on
Router(config)# end
Router#
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router# ping dirt
```

```
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.1.129, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 4/5/8 ms
Router#
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
```

In the following example, logging is disabled. The message output is displayed as messages are generated, causing the debug messages to be interspersed with the message “Type escape sequence to abort.”

```
Router(config)# no logging on
Router(config)# end

%SYS-5-CONFIG_I: Configured from console by console
Router#
Router# ping dirt

IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sendingTyp
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1e
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sending esc
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sendingape
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sendingse
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1
IP: s=172.21.96.41 (local), d=172.16.1.129 (Ethernet1/0), len 100, sendingquen
IP: s=171.69.1.129 (Ethernet1/0), d=172.21.96.41, len 114, rcvd 1ce to abort.
Sending 5, 100-byte ICMP Echos to 172.16.1.129, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 152/152/156 ms
Router#
```

Related Commands

Command	Description
logging	Logs messages to a syslog server host.
logging buffered	Logs messages to an internal buffer.
logging monitor	Limits messages logged to the terminal lines (monitors) based on severity.
logging synchronous	Synchronizes unsolicited messages and debug output with solicited Cisco IOS software output and prompts for a specific console port line, auxiliary port line, or vty.

logging rate-limit

To limit the rate of messages logged per second, use the **logging rate-limit** command in global configuration mode. To disable the limit, use the **no** form of this command.

logging rate-limit { *number* | **all** *number* | **console** { *number* | **all** *number* } } [**except** *severity*]

no logging rate-limit

Syntax Description

<i>number</i>	Maximum number of messages logged per second. The valid values are from 1 to 10000.
all	Sets the rate limit for all error and debug messages displayed at the console and printer.
console	Sets the rate limit for error and debug messages displayed at the console.
except	(Optional) Excludes messages of this severity level or lower. Severity decreases as the number increases. So, severity level 1 is a more serious problem than severity level 3.
<i>severity</i>	(Optional) Sets the logging severity level. The valid levels are from 0 to 7.

Command Default

The default for this command is 10 messages logged per second and exclusion of messages of the errors level or lower.

Command Modes

Global configuration

Command History

Release	Modification
12.1(3)T	This command was introduced.
12.2	This command was integrated in Cisco IOS Release 12.2.
12.3	This command was integrated in Cisco IOS Release 12.3.
12.3T	This command was integrated in Cisco IOS Release 12.3T.
12.4	This command was integrated in Cisco IOS Release 12.4.
12.4T	This command was integrated in Cisco IOS Release 12.4T.

Usage Guidelines

The **logging rate-limit** command controls the output of messages from the system. Use this command if you want to avoid a flood of output messages. You can select the severity of the output messages and output rate by using the **logging rate-limit** command. You can use the **logging rate-limit** command anytime; it will not negatively impact the performance of your system and may improve the system performance by specifying the severities and rates of output messages.

You can use this command with or without the **logging synchronous** line configuration command. For example, if you want to see all severity 0, 1, and 2 messages, use the **no logging synchronous** command and specify **logging rate-limit 10 except 2**. By using the two commands together, you cause all messages of 0, 1, and 2 severity to print and limit the less severe ones (lower than 2) to only 10 per second.

Table 61 compares the error message logging numeric severity level with its equivalent word description.

Table 61 Error Message Logging Severity Level and Equivalent Word Descriptions

Numeric Severity Level	Equivalent Word	Description
0	emergencies	System unusable
1	alerts	Immediate action needed
2	critical	Critical conditions
3	errors	Error conditions
4	warnings	Warning conditions
5	notifications	Normal but significant condition
6	informational	Informational messages only
7	debugging	Debugging messages

Examples

In the following example, the **logging rate-limit** configuration mode command limits message output to 200 per second:

```
Router(config)# logging rate-limit 200
```

Related Commands

Command	Description
logging synchronous	Synchronizes unsolicited messages and debug output with solicited Cisco IOS software output and prompts for a specific console port line, auxiliary port line, or vty.

logging source-interface

To specify the source IP address of syslog packets, use the **logging source-interface** global configuration command. To remove the source designation, use the **no** form of this command.

logging source-interface *interface-type interface-number*

no logging source-interface

Syntax Description	<i>interface-type</i>	Interface type.
	<i>interface-number</i>	Interface number.

Defaults	No interface is specified.

Command Modes	Global configuration (config)

Command History	Release	Modification
	11.2	This command was introduced.

Normally, a syslog message contains the IP address of the interface it uses to leave the router. The **logging source-interface** command specifies that syslog packets contain the IP address of a particular interface, regardless of which interface the packet uses to exit the router.

Examples	In the following example, the user specifies that the IP address for Ethernet interface 0 is the source IP address for all syslog messages:

```
logging source-interface ethernet 0
```

The following example specifies that the IP address for Ethernet interface 2/1 on a Cisco 7000 series router is the source IP address for all syslog messages:

```
logging source-interface ethernet 2/1
```

Related Commands	Command	Description
	logging	Logs messages to a syslog server host.

logging synchronous

To synchronize unsolicited messages and debug output with solicited Cisco IOS software output and prompts for a specific console port line, auxiliary port line, or vty, use the **logging synchronous** line configuration command. To disable synchronization of unsolicited messages and debug output, use the **no** form of this command.

logging synchronous [*level severity-level* | **all**] [*limit number-of-buffers*]

no logging synchronous [*level severity-level* | **all**] [*limit number-of-buffers*]

Syntax Description	level <i>severity-level</i>	(Optional) Specifies the message severity level. Messages with a severity level equal to or higher than this value are printed asynchronously. Low numbers indicate greater severity and high numbers indicate lesser severity. The default value is 2.
	all	(Optional) Specifies that all messages are printed asynchronously, regardless of the severity level.
	limit <i>number-of-buffers</i>	(Optional) Specifies the number of buffers to be queued for the terminal after which new messages are dropped. The default value is 20.

Defaults

This feature is turned off by default.

If you do not specify a severity level, the default value of 2 is assumed.

If you do not specify the maximum number of buffers to be queued, the default value of 20 is assumed.

Command Modes

Line configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

When synchronous logging of unsolicited messages and debug output is turned on, unsolicited Cisco IOS software output is displayed on the console or printed after solicited Cisco IOS software output is displayed or printed. Unsolicited messages and debug output is displayed on the console after the prompt for user input is returned. To keep unsolicited messages and debug output from being interspersed with solicited software output and prompts. After the unsolicited messages are displayed, the console displays the user prompt again.

When specifying a severity level number, consider that for the logging system, low numbers indicate greater severity and high numbers indicate lesser severity.

When a message queue limit of a terminal line is reached, new messages are dropped from the line, although these messages might be displayed on other lines. If messages are dropped, the notice “%SYS-3-MSGLOST *number-of-messages* due to overflow” follows any messages that are displayed. This notice is displayed only on the terminal that lost the messages. It is not sent to any other lines, any logging servers, or the logging buffer.



Caution

By configuring abnormally large message queue limits and setting the terminal to “terminal monitor” on a terminal that is accessible to intruders, you expose yourself to “denial of service” attacks. An intruder could carry out the attack by putting the terminal in synchronous output mode, making a Telnet connection to a remote host, and leaving the connection idle. This could cause large numbers of messages to be generated and queued, and these messages would unlikely consume all available RAM. You should guard against this type of attack through proper configuration.

Examples

In the following example, line 4 is identified and synchronous logging for line 4 is enabled with a severity level of 6. Then another line, line 2, is identified and the synchronous logging for line 2 is enabled with a severity level of 7 and is specified with a maximum number of buffers to be 70,000.

```
line 4
logging synchronous level 6
line 2
logging synchronous level 7 limit 70000
```

Related Commands

Command	Description
line	Identifies a specific line for configuration and starts the line configuration command collection mode.
logging on	Controls logging of system messages and sends debug or error messages to a logging process, which logs messages to designated locations asynchronously to the processes that generated the messages.

logging trap

To limit messages logged to the syslog servers based on severity, use the **logging trap** global configuration command. The command limits the logging of system messages sent to syslog servers to only those messages at the specified level. To disable logging to syslog servers, use the **no** form of this command.

logging trap *level*

no logging trap

Syntax Description	<i>level</i>	Limits the logging of messages to the syslog servers to a specified level. You can enter the level number or level name. See the Usage Guidelines section for a list of acceptable <i>level</i> keywords.

Defaults	informational (level 6)

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The **show logging EXEC** command displays the addresses and levels associated with the current logging setup. The command output also includes ancillary statistics.

Table 1 lists the syslog definitions that correspond to the debugging message levels. Additionally, four categories of messages are generated by the software, as follows:

- Error messages about software or hardware malfunctions at the LOG_ERR level.
- Output for the debug commands at the LOG_WARNING level.
- Interface up/down transitions and system restarts at the LOG_NOTICE level.
- Reload requests and low process stacks at the LOG_INFO level.

Use the **logging** and **logging trap** commands to send messages to a UNIX syslog server.

Table 62 logging trap System Message Logging Priorities

Level Arguments	Level	Description	Syslog Definition
emergencies	0	System unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING

Table 62 *logging trap System Message Logging Priorities (continued)*

Level Arguments	Level	Description	Syslog Definition
notifications	5	Normal but significant condition	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

Examples

In the following example, the messages to a host named john is logged:

```
logging john
logging trap notifications
```

Related Commands

Command	Description
logging	Logs messages to a syslog server host.

ping (privileged)

To diagnose basic network connectivity on Apollo, AppleTalk, Connectionless Network Service (CLNS), DECnet, IP, Novell IPX, VINES, or XNS networks, use the **ping** privileged EXEC command.

ping [*protocol* | **tag**] {*host-name* | *system-address*} [**data** [*hex-data-pattern*] | **df-bit** | **repeat** [*repeat-count*] | **size** [*datagram-size*] | **source** [*source-address* | **async** | **bvi** | **ctunnel** | **dialer** | **ethernet** | **fastEthernet** | **lex** | **loopback** | **multilink** | **null** | **port-channel** | **tunnel** | **vif** | **virtual-template** | **virtual-tokenring** | **xtagatm**] | **timeout** [*seconds*] | **validate**]

Syntax Description

<i>protocol</i>	(Optional) Protocol keyword, one of apollo , appletalk , clns , decnet , ip , ipx , srb , vines , or xns .
tag	(Optional) Specifies a tag encapsulated IP ping.
<i>host-name</i>	Host name of the system to ping.
<i>system-address</i>	Address of the system to ping.
data	(Optional) Specifies the data pattern.
<i>hex-data-pattern</i>	(Optional) Range is from 0 to FFFF.
df-bit	(Optional) Enables the “do-not-fragment” bit in the IP header.
repeat	(Optional) Specifies the number of pings sent. The default is 5.
<i>repeat-count</i>	(Optional) Range is from 1 to 2147483647.
size	(Optional) Specifies the datagram size. Datagram size is the number of bytes in each ping.
<i>datagram-size</i>	(Optional) Range is from 40 to 18024.
source	(Optional) Specifies the source address or name.
<i>source-address</i>	(Optional) Source address or name.
async	(Optional) Asynchronous interface.
bvi	(Optional) Bridge-Group Virtual Interface.
ctunnel	(Optional) CTunnel interface.
dialer	(Optional) Dialer interface.
ethernet	(Optional) Ethernet IEEE 802.3.
fastEthernet	(Optional) FastEthernet IEEE 802.3.
lex	(Optional) Lex interface.
loopback	(Optional) Loopback interface.
multilink	(Optional) Multilink-group interface.
null	(Optional) Null interface.
port-channel	(Optional) Ethernet channel of interfaces.
tunnel	(Optional) Tunnel interface.
vif	(Optional) PGM Multicast Host interface.
virtual-template	(Optional) Virtual Template interface.
virtual-tokenring	(Optional) Virtual TokenRing.
xtagatm	(Optional) Extended Tag ATM interface.
timeout	(Optional) Specifies the timeout interval in seconds. The default is 2 seconds.

<i>seconds</i>	(Optional) Range is from 0 to 3600.
validate	(Optional) Validates the reply data.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	12.0	The data , df-bit , repeat , size , source , timeout , and validate keywords were added.

Usage Guidelines

The **ping** (packet internet groper) command sends ISO CLNS echo packets to test the reachability of a remote router over a connectionless Open System Interconnection (OSI) network.

The **ping** command sends an echo request packet to an address, then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

To abnormally terminate a ping session, type the escape sequence—by default, **Ctrl-^ X**. You type the default by simultaneously pressing and releasing the **Ctrl**, **Shift**, and **6** keys, and then pressing the **X** key.

[Table 63](#) describes the test characters that the ping facility sends.

Table 63 *ping Test Characters*

Character	Description
!	Each exclamation point indicates receipt of a reply.
.	Each period indicates that the network server timed out while waiting for a reply.
U	A destination unreachable error protocol data unit (PDU) was received.
C	A congestion experienced packet was received.
I	User interrupted test.
?	Unknown packet type.
&	Packet lifetime exceeded.



Note

Not all protocols require hosts to support pings. For some protocols, the pings are Cisco-defined and are only answered by another Cisco router.

Examples

After you enter the **ping** command in privileged mode, the system prompts for one of the following keywords: **apollo**, **appletalk**, **clns**, **decnet**, **ip**, **novell**, **vines**, or **xns**. The default protocol is IP.

If you enter a host name or address on the same line as the **ping** command, the default action is taken as appropriate for the protocol type of that name or address.

The optional **data**, **df-bit**, **repeat**, **size**, **source**, **timeout**, and **validate** keywords can be used to avoid extended **ping** command output. You can use as many of these keywords as you need, and you can use them in any order after the *host-name* or *system-address* arguments.

Although the precise dialog varies somewhat from protocol to protocol, all are similar to the ping session using default values shown in the following output:

```
Router# ping

Protocol [ip]:
Target IP address: 192.168.7.27
Repeat count [5]:
Datagram size [100]:
Timeout in seconds [2]:
Extended commands [n]:
Sweep range of sizes [n]:
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.7.27, timeout is 2 seconds:
!!!!
Success rate is 100 percent, round-trip min/avg/max = 1/2/4 ms
```

Table 64 describes the default **ping** fields shown in the display.

Table 64 ping Field Descriptions

Field	Description
Protocol [ip]:	Prompts for a supported protocol. Enter appletalk , clns , ip , novell , apollo , vines , decnet , or xns . The default is IP.
Target IP address:	Prompts for the IP address or host name of the destination node you plan to ping. If you have specified a supported protocol other than IP, enter an appropriate address for that protocol here. The default is none.
Repeat count [5]:	Prompts for the number of ping packets that will be sent to the destination address. The default is 5 packets.
Datagram size [100]:	Prompts for the size of the ping packet (in bytes). The default is 100 bytes.
Timeout in seconds [2]:	Prompts for the timeout interval. The default is 2 seconds.
Extended commands [n]:	Specifies whether a series of additional commands appears.
Sweep range of sizes [n]:	Allows you to vary the sizes of the echo packets being sent. This capability is useful for determining the minimum sizes of the MTUs configured on the nodes along the path to the destination address. Packet fragmentation contributing to performance problems can then be reduced.
!!!!	Each exclamation point (!) indicates receipt of a reply. A period (.) indicates that the network server timed out while waiting for a reply. Other characters may appear in the ping output display, depending on the protocol type.
Success rate is 100 percent	Indicates the percentage of packets successfully echoed back to the router. Anything less than 80 percent is usually considered problematic.
round-trip min/avg/max = 1/2/4 ms	Indicates the round-trip travel time intervals for the protocol echo packets, including minimum/average/maximum (in milliseconds).

Related Commands

Command	Description
ping (user)	Tests the connection to a remote host on the network.
ping vrf	Tests the connection to a remote device in a VPN.

ping (user)

To diagnose basic network connectivity on AppleTalk, Connection Network Service (CLNS), IP, Novell, Apollo, VINES, DECnet, or XNS networks, use the **ping** (packet internet groper) user EXEC command.

ping [*protocol*] {*host-name* | *system-address*}

Syntax Description

<i>protocol</i>	(Optional) Protocol keyword, one of apollo , appletalk , clns , decnet , ip , ipx , vines , or xns .
<i>host-name</i>	Host name of the system to ping.
<i>system-address</i>	Address of the system to ping.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The user-level ping feature provides a basic ping facility for users that do not have system privileges. This feature allows the Cisco IOS software to perform the simple default ping functionality for a number of protocols. Only the terse form of the **ping** command is supported for user-level pings.

If the system cannot map an address for a host name, it returns an “%Unrecognized host or address” error message.

To abnormally terminate a ping session, type the escape sequence—by default, **Ctrl-^ X**. You type the default by simultaneously pressing and releasing the **Ctrl**, **Shift**, and **6** keys, and then pressing the **X** key.

[Table 65](#) describes the test characters that the ping facility sends.

Table 65 ping Test Characters

Character	Description
!	Each exclamation point indicates receipt of a reply.
.	Each period indicates that the network server timed out while waiting for a reply.
U	A destination unreachable error protocol data unit (PDU) was received.
C	A congestion experienced packet was received.
I	User interrupted test.
?	Unknown packet type.
&	Packet lifetime exceeded.

Examples

The following display shows sample ping output when you ping the IP host named donald:

```
Router> ping donald
Type escape sequence to abort.
```

```
Sending 5, 100-byte ICMP Echos to 192.168.7.27, timeout is 2 seconds:
!!!!
Success rate is 100 percent, round-trip min/avg/max = 1/3/4 ms
```

Related Commands

Command	Description
ping (privileged)	Checks host reachability and network connectivity.

service slave-log

To allow slave Versatile Interface Processor (VIP) cards to log important system messages to the console, use the **service slave-log** global configuration command. To disable slave logging, use the **no** form of this command.

service slave-log

no service slave-log

Syntax Description

This command has no arguments or keywords.

Defaults

This command is enabled by default.

Command Modes

Global configuration (config)

Command History

Release	Modification
11.1	This command was introduced.

Usage Guidelines

This command allows slave slots to log system messages of level 2 or higher (critical, alerts, and emergencies).

Examples

In the following example, important messages from the slave cards to the console are logged:

```
service slave-log
```

In the following example sample output is illustrated when this command is enabled:

```
%IPC-5-SLAVELOG: VIP-SLOT2:  
IPC-2-NOMEM: No memory available for IPC system initialization
```

The first line indicates which slot sent the message. The second line contains the system message.

service tcp-keepalives-in

To generate keepalive packets on idle incoming network connections (initiated by the remote host), use the **service tcp-keepalives-in** global configuration command. To disable the keepalives, use the **no** form of this command.

service tcp-keepalives-in

no service tcp-keepalives-in

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global configuration (config)

CommandHistory	Release	Modification
	10.0	This command was introduced.

Examples In the following example, keepalives on incoming TCP connections are generated:

```
service tcp-keepalives-in
```

Related Commands	Command	Description
	service tcp-keepalives-out	Generates keepalive packets on idle outgoing network connections (initiated by a user).

service tcp-keepalives-out

To generate keepalive packets on idle outgoing network connections (initiated by a user), use the **service tcp-keepalives-out** global configuration command. To disable the keepalives, use the **no** form of this command.

service tcp-keepalives-out

no service tcp-keepalives-out

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	Global configuration (config)

Command History	Release	Modification
	10.0	This command was introduced.

Examples	In the following example, keepalives on outgoing TCP connections are generated: service tcp-keepalives-out

Related Commands	Command	Description
	service tcp-keepalives-in	Generates keepalive packets on idle incoming network connections (initiated by the remote host).

service timestamps

To configure the system to time-stamp debugging or logging messages, use one of the **service timestamps** global configuration commands. To disable this service, use the **no** form of this command.

service timestamps [**debug** | **log**] [**uptime** | **datetime** [**msec**] [**localtime**] [**show-timezone**]]

no service timestamps [**debug** | **log**]

Syntax	Description
debug	Indicates timestamping for debugging messages.
log	Indicates timestamping for system logging messages.
uptime	(Optional) Specifies that the time stamp should consist of the time since the system was last rebooted. For example “4w6d” (time since last reboot is 4 weeks and 6 days). - This is the default timestamp format for both debugging messages and logging messages. - The format for uptime varies depending on how much time has elapsed: <i>HHHH:MM:SS</i> (<i>HHHH</i> hours: <i>MM</i> minutes: <i>SS</i> seconds) for the first 24 hours <i>DdHHh</i> (<i>D</i> days <i>HH</i> hours) after the first day <i>WwDd</i> (<i>W</i> weeks <i>D</i> days) after the first week
datetime	(Optional) Specifies that the time stamp should consist of the date and time. - The time stamp format for datetime is <i>MMM DD HH:MM:SS</i>, where <i>MMM</i> is the month, <i>DD</i> is the date, <i>HH</i> is the hour (in 24-hour notation), <i>MM</i> is the minute, and <i>SS</i> is the second. - If the datetime keyword is specified, you can optionally add the msec, localtime, or show-timezone keywords. - If the service timestamps datetime command is used without additional keywords, timestamps will be shown using UTC, without the year, without milliseconds, and without a time zone name.
msec	(Optional) Includes milliseconds in the time stamp, in the format <i>HH:DD:MM:SS.mmm</i> , where <i>.mmm</i> is milliseconds
localtime	(Optional) Time stamp relative to the local time zone.
show-timezone	(Optional) Include the time zone name in the time stamp. Note If the localtime keyword option is not used (or if the local time zone has not been configured using the clock timezone command), time will be displayed in Universal Coordinated Time (UTC).

Defaults

No time-stamping.

If the **service timestamps** command is specified with no arguments or keywords, the default is **service timestamps debug uptime**.

The default for the **service timestamps type datetime** command is to format the time in Coordinated Universal Time (UTC), with no milliseconds and no time zone name.

The **no service timestamps** command by itself disables time stamps for both debug and log messages.

Command Modes

Global configuration (config)

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Time stamps can be added to either debugging or logging messages independently. The **uptime** form of the command adds time stamps in the format HHHH:MM:SS, indicating the time since the system was rebooted. The **datetime** form of the command adds time stamps in the format MMM DD HH:MM:SS, indicating the date and time according to the system clock. If the system clock has not been set, the date and time are preceded by an asterisk (*) to indicate that the date and time are probably not correct.

Examples

In the following example, the user enables time stamps on debugging messages, showing the time since reboot:

```
service timestamps debug uptime
```

In the following example, the user enables time stamps on logging messages, showing the current time and date relative to the local time zone, with the time zone name included:

```
service timestamps log datetime localtime show-timezone
```

Related Commands

Command	Description
clock set	Manually sets the system clock.
ntp	Controls access to the system's NTP services.

show c2600 (2600)

To display information for troubleshooting the Cisco 2600 series router, use the **show c2600** EXEC command.

show c2600

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

CommandHistory	Release	Modification
	11.3 XA	This command was introduced.

Usage Guidelines The **show c2600** command provides complex troubleshooting information that pertains to the platform's shared references rather than to a specific interface.

Examples In the following example, sample output is shown for the **show c2600** EXEC command. See [Table 66](#) for a description of the output display fields.

```
router# show c2600

C2600 Platform Information:
Interrupts:

Assigned Handlers...
Vect  Handler  # of Ints  Name
  00  801F224C  00000000  Xilinx bridge error interrupt
  01  801DE768  0D3EE155  MPC860 TIMER INTERRUPT
  02  801E94E0  0000119E  16552 Con/Aux Interrupt
  04  801F0D94  00000000  PA Network Management Int Handler
  05  801E6C34  00000000  Timebase Reference Interrupt
  06  801F0DE4  00002C1A  PA Network IO Int Handler
  07  801F0EA0  0000015D  MPC860 CPM INTERRUPT
  14  801F224C  00000000  Xilinx bridge error interrupt

IOS Priority Masks...
Level 00 = [ EF020000 ]
Level 01 = [ EC020000 ]
Level 02 = [ E8020000 ]
Level 03 = [ E0020000 ]
Level 04 = [ E0020000 ]
Level 05 = [ E0020000 ]
Level 06 = [ C0020000 ]
Level 07 = [ 00000000 ]

SIU_IRQ_MASK = FFFFFFFF  SIEN   = EF02xxxx  Current Level = 00
Spurious IRQs = 00000000  SIPEND = 0000xxxx

Interrupt Throttling:
```

```
show c2600 (2600)
```

```
Throttle Count = 00000000   Timer Count       = 00000000
Netint usec    = 00000000   Netint Mask usec = 000003E8
Active         =           0   Configured        =           0
Longest IRQ    = 00000000
```

IDMA Status:

```
Requests = 00000349   Drops                = 00000000
Complete = 00000349   Post Coalesce Frames = 00000349
Giant     = 00000000
Available Blocks = 256/256
```

ISP Status:

```
Version string burned in chip: "A986122997"
New version after next program operation: "B018020998"
ISP family type: "2096"
ISP chip ID: 0x0013
Device is programmable
```

Table 66 *show c2600 Field Descriptions*

Field	Description
Interrupts	Denotes that the next section describes the status of the interrupt services.
Assigned Handlers	Denotes a subsection of the Interrupt section that displays data about the interrupt handlers.
Vect	The processor vector number.
Handler	The execution address of the handler assigned to this vector.
# of Ints	The number of times this handler has been called.
Name	The name of the handler assigned to this vector.
IOS Priority Masks	Denotes the subsection of the Interrupt section that displays internal Cisco IOS priorities. Each item in this subsection indicates a Cisco IOS interrupt level and the bit mask used to mask out interrupt sources when that Cisco IOS level is being processed. Used exclusively for debugging.
SIU_IRQ_MASK	For engineering level debug only.
Spurious IRQs	For engineering level debug only.
Interrupt Throttling:	This subsection describes the behavior of the Interrupt Throttling mechanism on the platform.
Throttle Count	Number of times throttle has become active.
Timer Count	Number of times throttle has deactivated because the maximum masked out time for network interrupt level has been reached.
Netint usec	Maximum time network level is allowed to run (in microseconds).
Netint Mask usec	Maximum time network level interrupt is masked out to allow process level code to run (in microseconds).
Active	Indicates that the network level interrupt is masked or that the router is in interrupt throttle state.
Configured	Indicates that throttling is enabled or configured when set to 1.
Longest IRQ	Duration of longest network level interrupt (in microseconds).

Table 66 *show c2600 Field Descriptions (continued)*

Field	Description
IDMA Status	Monitors the activity of the Internal Direct Memory Access (IDMA) hardware and software. Used to coalesce packets (turn partalized packets into non partalized packets) for transfer to the process level switching mechanism.
Requests	Number of times the IDMA engine is asked to coalesce a packet.
Drops	Number of times the coalescing operation was aborted.
Complete	Number of times the operation was successful.
Post Coalesce Frames	Number of Frames completed post coalesce processing.
Giant	Number of packets too large to coalesce.
Available Blocks	Indicates the status of the request queue, in the format N/M where N is the number of empty slots in queue and M is the total number of slots; for example, 2/256 indicates that the queue has 256 entries and can accept two more requests before it is full.
ISP Status	Provides status of In-System-Programmable (ISP) hardware.
Version string burned in chip	Current version of ISP hardware.
New version after next program operation	Version of ISP hardware after next ISP programming operation.
ISP family type	Device family number of ISP hardware.
ISP chip ID	Internal ID of ISP hardware as designated by the chip manufacturer.
Device is programmable	“Yes” or “No.” Indicates if an ISP operation is possible on this board.

Related Commands

Command	Description
show context	Displays information stored in NVRAM when the router crashes.

show c7200 (7200)

To display information about the CPU and midplane for Cisco 7200 series routers, use the **show c7200 EXEC** command.

show c7200

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines You can use the output of this command to determine whether the hardware version level and upgrade is current. The information is generally useful for diagnostic tasks performed by technical support only.

Examples The following is sample output from the **show c7200** command:

Router# **show c7200**

```
C7200 Network IO Interrupt Throttling:
  throttle count=0, timer count=0
  active=0, configured=0
  netint usec=3999, netint mask usec=200
```

```
C7200 Midplane EEPROM:
  Hardware revision 1.2          Board revision A0
  Serial number      2863311530  Part number      170-43690-170
  Test history       0xAA        RMA number         170-170-170
  MAC=0060.3e28.ee00, MAC Size=1024
  EEPROM format version 1, Model=0x6
  EEPROM contents (hex):
    0x20: 01 06 01 02 AA AA AA AA AA AA AA AA 00 60 3E 28
    0x30: EE 00 04 00 AA AA AA AA AA AA AA AA 50 AA AA AA AA
```

```
C7200 CPU EEPROM:
  Hardware revision 2.0          Board revision A0
  Serial number      3509953     Part number      73-1536-02
  Test history       0x0         RMA number         00-00-00
  EEPROM format version 1
  EEPROM contents (hex):
    0x20: 01 15 02 00 00 35 8E C1 49 06 00 02 00 00 00 00
    0x30: 50 00 00 00 FF FF FF FF FF FF FF FF FF FF FF FF
```

show cls

To display the current status of all Cisco link services (CLS) sessions on the router, use the **show cls** EXEC command.

show cls [brief]

Syntax Description	brief (Optional) Displays a brief version of the output.				
Defaults	Without the brief argument, displays complete output.				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>11.0</td><td>This command was introduced in a release prior to Cisco IOS Release 11.0.</td></tr> </table>	Release	Modification	11.0	This command was introduced in a release prior to Cisco IOS Release 11.0.
Release	Modification				
11.0	This command was introduced in a release prior to Cisco IOS Release 11.0.				

Usage Guidelines

The Cisco link service CLS is used as the interface between data link users (DLUs), such as DLSw, LAN Network Manager (LNM), downstream physical unit (DSPU), and SNASw, and their corresponding data link circuits (DLCs) such as Logic Link Control (LLC), VDLC, and Qualified Logic Link Control (QLLC). Each DLU registers a particular service access point (SAP) with CLS, and establishes circuits through CLS over the DLC.

The **show cls** command displays the SAP values associated with the DLU and the circuits established through CLS.

Examples

The following is sample output from the **show cls** command:

```

IBD-4500B# show cls

DLU user:SNASW
  SSap:0x04  VDLC  VDLC650
  DTE:1234.4000.0001 1234.4000.0002 04 04
  T1 timer:0  T2 timer:0  Inact timer:0
  max out:0  max in:0  retry count:10
  XID retry:10  XID timer:5000  I-Frame:0
  flow:0  DataIndQ:0  DataReqQ:0
DLU user:DLSWDLUPEER
DLU user:DLSWDLU
  Bridging  VDLC  VDLC1000
  Bridging  VDLC  VDLC650

```

The following is sample output from the **show cls brief** command:

```

IBD-4500B# show cls brief

DLU user:SNASW
  SSap:0x04  VDLC  VDLC650
  DTE:1234.4000.0001 1234.4000.0002 04 04

```

```
DLU user:DLSWDLUPEER
DLU user:DLSWDLU
  Bridging  VDLC  VDLC1000
  Bridging  VDLC  VDLC650
```

The examples show two DLUs—SNASw and DLSw—active in the router. SNASw uses a SAP value of 0x04, and the associated DLC port is VDLC650. SNASw has a circuit established between MAC addresses 1234.4000.0001 and 1234.4000.0002 using source and destination SAPs 04 and 04. DLSw is a bridging protocol and uses VDLC1000 and VDLC650 ports. There are no circuits in place at this time.

In the output from the **show cls** command (without the **brief** argument), the values of timers and counters applicable to this circuit are displayed.

show context (2600)

To display information stored in NVRAM when an exception occurs, use the **show context EXEC** command.

show context

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines Context information is specific to processors and architectures, whereas software version and uptime information is not specific to architectures. Context information for the Cisco 2600 series router differs from that for other router types because the Cisco 2600 runs with an M860 processor. The display from the **show context** command includes the following information:

- Reason for the system reboot
- Stack trace
- Software version
- The signal number, code, and router uptime information
- All the register contents at the time of the crash

This information is useful only to your technical support representative for analyzing crashes in the field. Use this information when you read the displayed statistics to an engineer over the phone.

Examples The following is sample output from the **show context** command following a system failure on a Cisco 2600 series router. See [Table 67](#) for a description of the fields in this output.

```
router# show context

S/W Version: Cisco Internetwork Operating System Software
IOS (tm) c2600 Software (c2600-JS-M), Released Version 11.3(19980115:184921)
Copyright (c) 1986-1998 by cisco Systems, Inc.
Compiled Thu 15-Jan-98 13:49 by mmagno
Exception occurred at: 00:02:26 UTC Mon Mar 1 1993
Exception type: Data TLB Miss (0x1200)
CPU Register Context:
PC   = 0x80109964  MSR = 0x00009030  CR   = 0x55FFFD35  LR   = 0x80109958
CTR  = 0x800154E4  XER = 0xC000BB6F  DAR  = 0x00000088  DSISR = 0x00000249
DEC  = 0x7FFFDCA  TBU = 0x00000000  TBL  = 0x15433FCF  IMMR  = 0x68010020
R0   = 0x80000000  R1   = 0x80E80BD0  R2   = 0x80000000  R3   = 0x00000000
R4   = 0x80E80BC0  R5   = 0x40800000  R6   = 0x00000001  R7   = 0x68010000
R8   = 0x00000000  R9   = 0x00000060  R10  = 0x00001030  R11  = 0xFFFFFFFF
R12  = 0x00007CE6  R13  = 0xFFFF379E8  R14  = 0x80D50000  R15  = 0x00000000
```

■ **show context (2600)**

```

R16 = 0x00000000  R17 = 0x00000000  R18 = 0x00000000  R19  = 0x00000000
R20 = 0x00000000  R21 = 0x00000001  R22 = 0x00000010  R23  = 0x00000000
R24 = 0x00000000  R25 = 0x80E91348  R26 = 0x01936010  R27  = 0x80E92A80
R28 = 0x00000001  R29 = 0x019BA920  R30 = 0x00000000  R31  = 0x00000018
Stack trace:
Frame 00: SP = 0x80E80BD0      PC = 0x80109958
Frame 01: SP = 0x80E80C28      PC = 0x8010A720
Frame 02: SP = 0x80E80C40      PC = 0x80271010
Frame 03: SP = 0x80E80C50      PC = 0x8025EE64
Frame 04: SP = 0x80DEE548      PC = 0x8026702C
Frame 05: SP = 0x80DEE558      PC = 0x8026702C

```

Table 67 *show context Field Descriptions*

Field	Description
S/W Version	Standard Cisco IOS version string as displayed.
Exception occurred at	Router real time when exception occurred. The router must have the clock time properly configured for this to be accurate.
Exception type	Technical reason for exception. For engineering analysis.
CPU Register Context	Technical processor state information. For engineering analysis.
Stack trace	Technical processor state information. For engineering analysis.

Related Commands

Command	Description
show processes	Displays information about the active processes.
show stacks	Monitors the stack usage of processes and interrupt routines.

show context

To display information stored in NVRAM when the router crashes, use the **show context EXEC** command.

show context summary

show context { **all** | **slot** *slot-number* [*crash-index*] [**all**] [**debug**] }

Syntax Description		
summary		Displays a summary of all the crashes recorded.
all		Displays all crashes for all the slots. When optionally used with the slot keyword, displays crash information for the specified slot.
slot <i>slot-number</i> [<i>crash-index</i>]		Displays information for a particular line card. Slot numbers range from 0 to 11 for the Cisco 12012 router and from 0 to 7 for the Cisco 12008. The index number allows you to look at previous crash contexts. Contexts from the last 24 line card crashes are saved on the GRP card. If the GRP reloads, the last 24 line card crash contexts are lost. For example, show context slot 3 2 shows the second most recent crash for line card in slot 3. Index numbers are displayed by the show context summary command.
debug		(Optional) Displays crash information as a hex record dump in addition to one of the options listed.

Command Modes	EXEC

Command History	Release	Modification
	11.2 GS	This command was modified to add the all , debug , slot , and summary keywords.

Usage Guidelines The display from the **show context** command includes the following information:

- Reason for the system reboot
- Stack trace
- Software version
- The signal number, code, and router uptime information
- All the register contents at the time of the crash



Note

This information is of use only to technical support representatives in analyzing crashes in the field. It is included here in case you need to read the displayed statistics to an engineer over the phone.

Examples The following is sample output from the **show context** command following a system failure:

show context

Router> **show context**

```
System was restarted by error - a Software forced crash, PC 0x60189354
GS Software (RSP-PV-M), Experimental Version 11.1(2033) [ganesh 111]
Compiled Mon 31-Mar-97 13:21 by ganesh
Image text-base: 0x60010900, data-base: 0x6073E000
Stack trace from system failure:
FP: 0x60AEA798, RA: 0x60189354
FP: 0x60AEA798, RA: 0x601853CC
FP: 0x60AEA7C0, RA: 0x6015E98C
FP: 0x60AEA7F8, RA: 0x6011AB3C
FP: 0x60AEA828, RA: 0x601706CC
FP: 0x60AEA878, RA: 0x60116340
FP: 0x60AEA890, RA: 0x6011632C
Fault History Buffer:
GS Software (RSP-PV-M), Experimental Version 11.1(2033) [ganesh 111]
Compiled Mon 31-Mar-97 13:21 by ganesh
Signal = 23, Code = 0x24, Uptime 00:04:19
$0 : 00000000, AT : 60930120, v0 : 00000032, v1 : 00000120
a0 : 60170110, a1 : 6097F22C, a2 : 00000000, a3 : 00000000
t0 : 60AE02A0, t1 : 8000FD80, t2 : 34008F00, t3 : FFFF00FF
t4 : 00000083, t5 : 3E840024, t6 : 00000000, t7 : 11010132
s0 : 00000006, s1 : 607A25F8, s2 : 00000001, s3 : 00000000
s4 : 00000000, s5 : 00000000, s6 : 00000000, s7 : 6097F755
t8 : 600FABBC, t9 : 00000000, k0 : 30408401, k1 : 30410000
gp : 608B9860, sp : 60AEA798, s8 : 00000000, ra : 601853CC
EPC : 60189354, SREG : 3400EF03, Cause : 00000024
Router>
```

The following is sample output from the **show context summary** command on a Cisco 12012 router. The **show context summary** command displays a summary of all the crashes recorded.

Router# **show context summary**

```
CRASH INFO SUMMARY
Slot 0 : 0 crashes
Slot 1 : 0 crashes
Slot 2 : 0 crashes
Slot 3 : 0 crashes
Slot 4 : 0 crashes
Slot 5 : 0 crashes
Slot 6 : 0 crashes
Slot 7 : 2 crashes
    1 - crash at 18:06:41 UTC Tue Nov 5 1996
    2 - crash at 12:14:55 UTC Mon Nov 4 1996
Slot 8 : 0 crashes
Slot 9 : 0 crashes
Slot 10: 0 crashes
Slot 11: 0 crashes
Router#
```

Related Commands

Command	Description
show processes	Displays information about the active processes.
show stacks	Monitors the stack usage of processes and interrupt routines.

show controllers (GRP image)

To display information that is specific to the hardware, use the **show controllers** privileged EXEC command.

show controllers [**atm** *slot-number* | **clock** | **csar** [**register**] | **csc-fpga** | **dp83800** | **fab-clk** | **fia** [**register**] | **pos** [*slot-number*] [**details**] | **queues** [*slot-number*] | **sca** | **xbar**]

Syntax Description	
atm <i>slot-number</i>	(Optional) Displays the ATM controllers. Number is slot-number/port-number (for example, 4/0). Slot numbers range from 0 to 11 for the Cisco 12012 router and from 0 to 7 for the Cisco 12008 router.
clock	(Optional) Displays the clock card configuration.
csar [register]	(Optional) Displays the Cisco Cell Segmentation and Reassembly (CSAR) information. CSAR is the name of the chip on the card that handles traffic between the GRP and the switch fabric interface ASICs.
csc-fpga	(Optional) Displays the clock and scheduler card register information in the field programmable gate array (FPGA).
dp83800	(Optional) Displays the Ethernet information on the GRP card.
fab-clk	(Optional) Display the switch fabric clock register information. The switch fabric clock FPGA is a chip that monitors the incoming fabric clock generated by the switch fabric. This clock is needed by each card connecting to the switch fabric to properly communicate with it. Two switch fabric clocks arrive at each card; only one can be used. The FPGA monitors both clocks and selects which one to use if only one of them is running.
fia [register]	(Optional) Displays the fabric interface ASIC information and optionally displays the register information.
pos [<i>slot-number</i>] [details]	(Optional) Displays the POS framer state and optionally displays all the details for the interface. Number is slot-number/port-number (for example, 4/0). Slot numbers range from 0 to 11 for the Cisco 12012 router and from 0 to 7 for the Cisco 12008 router.
queues [<i>slot-number</i>]	(Optional) Displays the SDRAM buffer carve information and optionally displays the information for a specific line card. The SDRAM buffer carve information displayed is suggested carve information from the GRP card to the line card. Line cards might change the shown percentages based on SDRAM available. Slot numbers range from 0 to 11 for the Cisco 12012 router and from 0 to 7 for the Cisco 12008.
sca	(Optional) Displays the SCA register information. The SCA is an ASIC that arbitrates among the line cards requests to use the switch fabric.
xbar	(Optional) Displays the crossbar register information. The XBAR is an ASIC that switches the data as it passes through the switch fabric.

Command Modes Privileged EXEC

■ **show controllers (GRP image)****Command History**

Release	Modification
11.2 GS	This command was added to support the Cisco 12000 series Internet Routers.

Usage Guidelines

This information provided by this command is intended for use only by technical support representatives in analyzing system failures in the field.

Examples

The following is sample output from the **show controllers pos** command for a Cisco 12012:

```
Router# show controllers pos 7/0

POS7/0
SECTION
  LOF = 2          LOS = 0          BIP(B1) = 5889
  Active Alarms: None
LINE
  AIS = 2          RDI = 2          FEBE = 146          BIP(B2) = 2106453
  Active Alarms: None
PATH
  AIS = 2          RDI = 4          FEBE = 63          BIP(B3) = 3216
  LOP = 0          PSE = 8          NSE = 3          NEWPTR = 2
  Active Alarms: None
APS
  COAPS = 3        PSBF = 2
  State: PSBF_state = False
  Rx(K1/K2): F0/15 Tx(K1/K2): 00/00
  S1S0 = 00, C2 = 64
PATH TRACE BUFFER : STABLE
  Remote hostname : GSR-C
  Remote interface: POS10/0
  Remote IP addr  : 10.201.101.2
  Remote Rx(K1/K2): F0/15 Tx(K1/K2): 00/00
Router#
```

Related Commands

Command	Description
clear controllers	Resets the T1 or E1 controller.
show controllers (line card image)	Displays information that is specific to the hardware on a line card.

show controllers (line card image)

To display information that is specific to the hardware on a line card, use the **attach** privileged EXEC command to connect to the line card and then use the **show controllers** privileged EXEC command or the **execute-on** privileged EXEC command.

show controllers atm [*port-number*] [**all** | **sar** | **summary**]

show controllers fia [**register**]

show controllers {**frfab** | **tofab**} {**bma** {**microcode** | **ms-inst** | **register**} | **qelem** *start-queue-element* [*end-queue-element*] | **qnum** *start-queue-number* [*end-queue-number*] | **queues** | **statistics**}

show controllers io

show controllers l3

show controllers pos {**framers** | **queues** | **registers** | **rxsram** *port-number queue-start-address* [*queue-length*] | **txsram** *port-number queue-start-address* [*queue-length*]}

Syntax Description

atm	Displays the ATM controller information.
<i>port-number</i>	(Optional) Displays request for the physical interface on the ATM card. The range of choices is from 0 to 3.
all	(Optional) Lists all details.
sar	(Optional) Lists SAR interactive command.
summary	(Optional) Lists SAR status summary.
fia	Displays the fabric interface ASIC information.
register	(Optional) Displays the register information.
frfab	(Optional) Displays the "from" (transmit) fabric information.
tofab	(Optional) Displays the "to" (receive) fabric information.
bma	For the frfab or tofab keywords, displays microcode, micro sequencer, or register information for the silicon queuing engine (SQE), also known as the buffer management ASIC (BMA).
microcode	Displays SQE information for the microcode bundled in the line card and currently running version.
mis-inst	Displays SQE information for the micro sequencer instruction.
register	Displays silicon queuing engine (SQE) information for the register.
qelem	For the frfab or tofab keywords, displays the SDRAM buffer pool queue element summary information.
<i>start-queue-element</i>	Specifies the start queue element number from 0 to 65535.
<i>end-queue-element</i>	(Optional) Specifies the end queue element number from 0 to 65535.
qnum	For the frfab or tofab keywords, displays the SDRAM buffer pool queue detail information.

■ show controllers (line card image)

<i>start-queue-number</i>	Specifies the start free queue number (from 0 to 127).
<i>end-queue-number</i>	(Optional) Specifies the end free queue number (from 0 to 127).
queues	For the frfab or tofab keywords, displays the SDRAM buffer pool information.
statistics	For the frfab or tofab keywords, displays the BMA counters.
io	Displays input/output registers.
l3	Displays Layer 3 ASIC information.
pos	Displays packet-over-sonic (POS) information for framer registers, framer queues, and ASIC registers.
framers	Displays the POS framer registers.
queues	Displays the POS framer queue information.
registers	Displays the ASIC registers.
rxsram	Displays the receive queue SRAM.
<i>port-number</i>	Specifies a port number (valid range is from 0 to 3).
<i>queue-start-address</i>	Specifies the queue SRAM logical starting address.
<i>queue-length</i>	(Optional) Specifies the queue SRAM length.
txsram	Displays the transmit queue SRAM.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2 GS	This command was added to support the Cisco 12000 series Gigabit Switch Routers.

Usage Guidelines

This command is intended for use by Cisco technical support.



Note

This information provided by this command is of use only to technical support representatives in analyzing crashes in the field.

Examples

Because you are executing this command on the line card, you must use the **execute-on** command to use the **show** command, or you must connect to the card using the **attach** command. All examples in this section use the **execute-on** command.

The following is partial sample output from the **show controllers atm** command:

```
Router# execute-on slot 4 show controllers atm 0
```

```
TX SAR (Beta 1.0.0) is Operational;
RX SAR (Beta 1.0.0) is Operational;
```

```
Interface Configuration Mode:
```

STS-12c

```
Active Maker Channels: total # 6
VCID  ChnID  Type  OutputInfo  InPkts  InOAMs  MacString
  1    0888   UBR   0C010010      0        0  08882000AAAA030000000800
  2    0988   VBR   04010020      0        0  09882000
  3    8BC8   UBR   0C010030      0        0  8BC82000AAAA030000000800
  4    0E08   UBR   0C010040      0        0  0E082000AAAA030000000800
 10   1288   VBR   040100A0      0        0  12882000
 11   8BE8   VBR   0C0100B0      0        0  8BE82000AAAA030000000800
```

```
SAR Total Counters:
total_tx_idle_cells 215267  total_tx_paks 0  total_tx_abort_paks 0
total_rx_paks 0  total_rx_drop_paks 0  total_rx_discard_cells 15
```

```
Switching Code Counters:
total_rx_crc_err_paks 0  total_rx_giant_paks 0
total_rx_abort_paks 0  total_rx_crc10_cells 0
total_rx_tmout_paks 0  total_rx_unknown_paks 0
total_rx_out_buf_paks 0  total_rx_unknown_vc_paks 0
```

```
BATMAN Asic Register Values:
hi_addr_reg 0x8000, lo_addr_reg 0x000C, boot_msk_addr 0x0780,
rmcell_msk_addr 0x0724, rmcnt_msk_addr 0x07C2, txbuf_msk_addr 0x070C,
```

.

```
CM622 SAR Boot Configuration:
txind_q_addr 0x14000 txcmd_q_addr 0x20000
```

.

```
SUNI-622 Framer Register Values:
Master Rst and Ident/Load Meters Reg (#0x0): 0x10
Master Configuration Reg (#0x1): 0x1F
Master Interrupt Status Reg (#0x2): 0x00
PISO Interrupt Reg (#0x3): 0x04
Master Auto Alarm Reg (#0x4): 0x03
Master Auto Alarm Reg (#0x5): 0x07
Parallel Output Port Reg (#0x6): 0x02
```

.

```
BERM Line BIP Threshold LSB Reg (#0x74): 0x00
BERM Line BIP Threshold MSB Reg (#0x75): 0x00
Router#
```

The following is partial sample output from the **show controllers** command:

```
Router# execute-on slot 6 show controllers
```

```
Interface POS0
Hardware is BFLC POS
lcpos_instance struct 60311B40
RX POS ASIC addr space 12000000
TX POS ASIC addr space 12000100
SUNI framer addr space 12000400
SUNI rsop intr status 00
CRC32 enabled, HDLC enc, int clock
no loop
```

```
Interface POS1
Hardware is BFLC POS
lcpos_instance struct 603142E0
RX POS ASIC addr space 12000000
```

■ show controllers (line card image)

```
TX POS ASIC addr space 12000100
SUNI framer addr space 12000600
SUNI rsop intr status 00
CRC32 enabled, HDLC enc, int clock
no loop
.
.
.
Router#
```

The following is partial sample output from the **show controllers pos framers** command:

```
Router# execute-on slot 6 show controllers pos framers
```

```
Framer 0, addr=0x12000400:
master reset          C0
master config         1F          rrate sts3c trate sts3c fixptr
master control        00
clock rcv cntrl       D0
RACP control          84
RACP gfc control      0F
TACP control status   04          hcsadd
RACP intr enable      04
RSOP cntrl intr enable 00
RSOP intr status      00
TPOP path sig lbl (c2) 13
SPTB control          04          tnull
SPTB status           00

Framer 1, addr=0x12000600:
master reset          C0
master config         1F          rrate sts3c trate sts3c fixptr
master control        00
clock rcv cntrl       D0
RACP control          84
RACP gfc control      0F
TACP control status   04          hcsadd
RACP intr enable      04
RSOP cntrl intr enable 00
RSOP intr status      00
TPOP path sig lbl (c2) 13
SPTB control          04          tnull
SPTB status           00

Framer 2, addr=0x12000800:
master reset          C0
master config         1F          rrate sts3c trate sts3c fixptr
master control        00
clock rcv cntrl       D0
RACP control          84
RACP gfc control      0F
TACP control status   04          hcsadd
RACP intr enable      04
RSOP cntrl intr enable 00
RSOP intr status      00
TPOP path sig lbl (c2) 13
SPTB control          04          tnull
SPTB status           00
.
.
.
Router#
```

The following is partial sample output from the **show controllers fia** command:


```

Router# execute-on slot 7 show controllers fia

===== Line Card (Slot 7) =====

Fabric configuration: Full bandwidth redundant
Master Scheduler: Slot 17

From Fabric FIA Errors
-----
redund fifo parity 0          redund overflow 0          cell drops 0
crc32 lkup parity 0          cell parity 0          crc32      0
              0              1              2              3              4
-----
los      0              0              0              0              0
crc16    0              0              0              0              0

To Fabric FIA Errors
-----
sca not pres 0          req error      0          uni fifo overflow 0
grant parity 0          multi req      0          uni fifo undrflow 0
cntrl parity 0          uni req        0          crc32 lkup parity 0
multi fifo  0          empty dst req 0          handshake error  0
    
```

Related Commands

Command	Description
clear controllers	Resets the T1 or E1 controller.

show controllers logging

To display logging information about a Versatile Interface Processor (VIP) card, use the **show controllers logging** privileged EXEC command.

show controllers vip *slot-number* logging

Syntax Description

vip <i>slot-number</i>	VIP slot number.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

This command displays the state of syslog error and event logging, including host addresses, and whether console logging is enabled.

Examples

The following is sample output from the **show controllers logging** command:

```
Router# show controllers vip 4 logging

Syslog logging: enabled
  Console logging: disabled
  Monitor logging: level debugging, 266 messages logged.
  Trap logging: level informational, 266 messages logged.
  Logging to 192.180.2.238
```

[Table 68](#) describes the significant fields shown in the display.

Table 68 *show controllers logging Field Descriptions*

Field	Description
Syslog logging	When enabled, system logging messages are sent to a UNIX host that acts as a syslog server; that is, it captures and saves the messages.
Console logging	If enabled, states the level; otherwise, this field displays disabled.
Monitor logging	Minimum level of severity required for a log message to be sent to a monitor terminal (not the console).
Trap logging	Minimum level of severity required for a log message to be sent to a syslog server.

Related Commands

Command	Description
show logging	Displays the state of system logging (syslog).

show controllers tech-support

To display general information about a Versatile Interface Processor (VIP) card when reporting a problem, use the **show controllers tech-support** privileged EXEC command.

show controllers vip *slot-number* tech-support

Syntax Description	vip <i>slot-number</i> VIP slot number.

Command Modes	Privileged EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines Use this command to help collect general information about a VIP card when you are reporting a problem. This command displays the equivalent of the following **show** commands for the VIP card:

- **more system:running-config**
- **show buffers**
- **show controllers**
- **show interfaces**
- **show processes cpu**
- **show processes memory**
- **show stacks**
- **show version**

For a sample display of the **show controllers tech-support** command output, refer to these **show** commands.

Related Commands	Command	Description
	more system:running-config	Displays the running configuration.
	show buffers	Displays statistics for the buffer pools on the network server.
	show controllers	Displays information that is specific to the hardware.
	show interfaces	Uses the show interfaces EXEC command to display ALC information.
	show processes	Displays information about the active processes.
	show processes memory	Displays memory used.
	show stacks	Monitors the stack usage of processes and interrupt routines.

Command	Description
show tech-support	Displays general information about the router when reporting a problem.
show version	Displays the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images.

show debugging

To display information about the types of debugging that are enabled for your router, use the **show debugging** privileged EXEC command.

show debugging

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.

Examples

The following is sample output from the **show debugging** command. In this example, three types of CDP debugging are enabled.

```
Router# show debugging
```

```
CDP:
```

```
  CDP packet info debugging is on
  CDP events debugging is on
  CDP neighbor info debugging is on
```

Related Commands

Command	Description
debug <feature>	Begin message logging for the specified debug command

show diag

To display hardware information including DRAM and static RAM (SRAM) on line cards, use the **show diag** command in privileged EXEC mode.

show diag [*slot-number*] [**details**] [**summary**]

Syntax Description

<i>slot-number</i>	(Optional) Slot number of the interface.
details	(Optional) Displays more details than the normal show diag output.
summary	(Optional) Displays a summary (one line per slot) of the chassis.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1 CA	This command was introduced.
11.2	This command was introduced.
11.2 P	This command was modified to show information for PA-12E/2FE, PA-E3, and PA-T3 port adapters.
11.2 GS	This command was made available on Cisco 12000 series Gigabit Switch Routers (GSRs).
11.3 XA	This command was integrated in Cisco IOS Release 11.3 XA.
12.0(5)XQ	This command was enhanced and made available on Cisco 1750 routers.
12.0(7)T	This command was integrated in Cisco IOS Release 12.0T.

Usage Guidelines

Use this command to determine the type of hardware installed in your router. This command applies line cards in Cisco Universal Access Servers; Cisco 1750, 7200, and 7500 series routers; and Cisco 12000 series GSRs.



Note

The enhancement to display the field replaceable unit (FRU) number in **show diag** command output is not available in all Cisco IOS releases and not all Cisco devices and Cisco network modules will display their FRU numbers.

Examples of output showing the FRU number are included in the Examples section.

Cisco 7304 Router Usage Guidelines

For the Cisco 7304 router, this command applies to NSEs, line cards, MSCs, and SPAs.

- To display hardware information for an NSE, line card, or MSC in the specified slot, use the *slot-number* argument. For MSCs, information about the MSC and each of its installed SPAs is displayed.
- To display hardware information about the backplane, power supplies, and fan modules, use the **chassis** keyword.

Shared Port Adapter Usage Guidelines

- To display hardware information for an MSC or SIP only in a specified slot, use the *slot-number* argument.
- To display hardware information for a SPA only, use the **show diag subslot** *slot/subslot* version of this command.

Examples

Example for a 1-Port T3 Serial Port Adapter on the Cisco 7200 Series Router

The following is sample output from the **show diag** command for a 1-port T3 serial port adapter in chassis slot 1 on a Cisco 7200 series router:

```
Router# show diag 1

Slot 1:
  Physical slot 1, ~physical slot 0xE, logical slot 1, CBus 0
  Microcode Status 0x4
  Master Enable, LED, WCS Loaded
  Board is analyzed
  Pending I/O Status: None
  EEPROM format version 1
  VIP2 controller, HW rev 2.4, board revision D0
  Serial number: 04372053 Part number: 73-1684-03
  Test history: 0x00 RMA number: 00-00-00
  Flags: cisco 7000 board; 7500 compatible

  EEPROM contents (hex):
    0x20: 01 15 02 04 00 42 B6 55 49 06 94 03 00 00 00 00
    0x30: 68 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

  Slot database information:
  Flags: 0x4 Insertion time: 0x14A8 (5d02h ago)

  Controller Memory Size: 16 MBytes DRAM, 1024 KBytes SRAM

  PA Bay 0 Information:
    T3 Serial PA, 1 ports
    EEPROM format version 1
    HW rev FF.FF, Board revision UNKNOWN
    Serial number: 4294967295 Part number: 255-65535-255
```

Example Output from a Cisco 7200 Showing the FRU Number

The following is sample output from the **show diag** command on a Cisco 7200 series router showing the FRU number:

```
Router# show diag

Slot 0:
  Dual FastEthernet (RJ-45) I/O Card Port adapter, 2 ports
  Port adapter is analyzed
  Port adapter insertion time 6d02h ago
  EEPROM contents at hardware discovery:
  Hardware Revision      : 2.1
  Top Assy. Part Number  : 800-07114-06
  Part Number           : 73-5003-06
  Board Revision        : B0
  PCB Serial Number     : 31558694
  RMA History           : 00
  Fab Version           : 03
  Fab Part Number       : 28-3455-03
  Product (FRU) Number  : C7200-I/O-2FE/E
  Deviation Number      : 0-0
```

```

EEPROM format version 4
EEPROM contents (hex):
  0x00: 04 FF 40 02 15 41 02 01 C0 46 03 20 00 1B CA 06
  0x10: 82 49 13 8B 06 42 42 30 C1 8B 33 31 35 35 38 36
  0x20: 39 34 00 00 00 04 00 02 03 85 1C 0D 7F 03 CB 8F
  0x30: 43 37 32 30 30 2D 49 2F 4F 2D 32 46 45 2F 45 80
  0x40: 00 00 00 00 FF FF FF FF FF FF FF FF FF FF FF FF
  0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
Router#

```

Examples for a Cisco 12000 Series Internet Router

The following is sample output from the **show diag** command on a Cisco 12000 series Internet router:

```

Router# show diag 3

SLOT 3  (RP/LC 3 ): 4 Port Packet Over SONET OC-3c/STM-1 Multi Mode
  MAIN: type 33,  00-0000-00 rev 70 dev 0
      HW config: 0x01      SW key: 00-00-00
  PCA:  73-2147-02 rev 94 ver 2
      HW version 1.0  S/N 04499695
  MBUS: MBUS Agent (1)  73-2146-05 rev 73 dev 0
      HW version 1.1  S/N 04494882
      Test hist: 0x00      RMA#: 00-00-00      RMA hist: 0x00
  DIAG: Test count: 0x05000001      Test results: 0x00000000
  MBUS Agent Software version 01.27 (RAM) using CAN Bus A
  ROM Monitor version 00.0D
  Fabric Downloader version used 00.0D (ROM version is 00.0D)
  Board is analyzed
  Board State is Line Card Enabled (IOS  RUN )
  Insertion time: 00:00:10 (00:04:51 ago)
  DRAM size: 33554432 bytes
  FrFab SDRAM size: 67108864 bytes
  ToFab SDRAM size: 16777216 bytes

```

The following is sample output from the **show diag** command with the **summary** keyword:

```

Router# show diag summary

SLOT 0  (RP/LC 0 ): Route Processor
SLOT 2  (RP/LC 2 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 4  (RP/LC 4 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 7  (RP/LC 7 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 9  (RP/LC 9 ): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 11 (RP/LC 11): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
SLOT 16 (CSC 0  ): Clock Scheduler Card
SLOT 17 (CSC 1  ): Clock Scheduler Card
SLOT 18 (SFC 0  ): Switch Fabric Card
SLOT 19 (SFC 1  ): Switch Fabric Card
SLOT 20 (SFC 2  ): Switch Fabric Card
SLOT 24 (PS A1  ): AC Power Supply
SLOT 26 (PS B1  ): AC Power Supply
SLOT 28 (TOP FAN ): Blower Module
SLOT 29 (BOT FAN ): Blower Module

```

The following is sample output from the **show diag** command with the **details** keyword:

```

Router# show diag 4 details

SLOT 4  (RP/LC 4): 4 Port Packet Over SONET OC-3c/STM-1 Single Mode
  MAIN: type 33,  800-2389-01 rev 71 dev 16777215
      HW config: 0x00      SW key: FF-FF-FF
  PCA:  73-2275-03 rev 75 ver 3

```



```

HW version 1.1 S/N 04529465
MBUS: MBUS Agent (1) 73-2146-06 rev 73 dev 0
HW version 1.1 S/N 04541395
Test hist: 0xFF RMA#: FF-FF-FF RMA hist: 0xFF
DIAG: Test count: 0x05000001 Test results: 0x00000000
EEPROM contents (hex):
00: 01 00 01 00 49 00 08 62 06 03 00 00 00 FF FF FF
10: 30 34 35 34 31 33 39 35 FF FF FF FF FF FF FF FF
20: 01 01 00 00 00 00 00 FF FF FF FF FF FF FF FF
30: A5 FF A5 A5 A5 A5 FF A5 A5 A5 A5 A5 A5 A5 A5
40: 00 21 01 01 00 49 00 08 E3 03 05 03 00 01 FF FF
50: 03 20 00 09 55 01 01 FF FF FF 00 FF FF FF FF FF
60: 30 34 35 32 39 34 36 35 FF FF FF FF FF FF FF FF
70: FF FF FF FF FF FF FF FF 05 00 00 01 00 00 00 00
MBUS Agent Software version 01.24 (RAM)
Fabric Downloader version 00.0D
Board is analyzed
Flags: 0x4
Board State is Line Card Enabled (IOS RUN)
Insertion time: 00:00:10 (00:04:51 ago)
DRAM size: 33554432 bytes
FrFab SDRAM size: 67108864 bytes
ToFab SDRAM size: 16777216 bytes

```

Example for an ATM SAR AIM in a Cisco 3660

The following is sample output from the **show diag** command for one ATM Segmentation and Reassembly (SAR) AIM in a Cisco 3660 router:

```

Router# show diag 0

3660 Chassis type: ENTERPRISE

c3600 Backplane EEPROM:
  Hardware Revision      : 1.0
  Top Assy. Part Number  : 800-04740-02
.
.
.
ATM AIM: 1
  ATM AIM module with SAR only (no DSPs)
  Hardware Revision      : 1.0
  Top Assy. Part Number  : 800-03700-01
  Board Revision         : A0
  Deviation Number       : 0-0
  Fab Version            : 02
  PCB Serial Number      : JAB9801ABCD

```

Example Output from a Cisco 3660 Showing the FRU Number

The following is sample output from the **show diag** command on a Cisco 3660 router that shows the FRU numbers for slots 0 and 1:

```

Router# show diag
3660 Chassis type: ENTERPRISE
3660 Backplane EEPROM:
  Hardware Revision      : 1.0
  Top Assy. Part Number  : 800-04740-02
  Board Revision         : C0
  Deviation Number       : 0-0
  Fab Version            : 02
  PCB Serial Number      : HAD04471U36
  RMA Test History       : 00
  RMA Number             : 0-0-0-0

```

■ show diag

```

RMA History                : 00
Chassis Serial Number      : JAB055180FF
Chassis MAC Address        : 0007.ebea.4460
MAC Address block size     : 112
Manufacturing Test Data    : 00 00 00 00 00 00 00 00
Fab Part Number            : 28-2651-02
Number of Slots            : 6
EEPROM format version 4
EEPROM contents (hex):
  0x00: 04 FF 40 00 C8 41 01 00 C0 46 03 20 00 12 84 02
  0x10: 42 43 30 80 00 00 00 00 02 02 C1 8B 48 41 44 30
  0x20: 34 34 37 31 55 33 36 03 00 81 00 00 00 00 04 00
  0x30: C2 8B 4A 41 42 30 35 35 31 38 30 46 46 C3 06 00
  0x40: 07 EB EA 44 60 43 00 70 C4 08 00 00 00 00 00 00
  0x50: 00 00 85 1C 0A 5B 02 01 06 FF FF FF FF FF FF FF
  0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Slot 0:

```

C3600 Mother board 2FE(TX) Port adapter, 2 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
PCB Serial Number          : JAB05460CSV
Processor type             : 34
Top Assy. Part Number      : 800-04737-04
Board Revision             : C0
Fab Part Number            : 28-3234-02
Deviation Number           : 65535-65535
Manufacturing Test Data    : FF FF FF FF FF FF FF FF
RMA Number                 : 255-255-255-255
RMA Test History           : FF
RMA History                : FF
Field Diagnostics Data     : FF FF FF FF FF FF FF FF
Product (FRU) Number       : Leopard-2FE
EEPROM format version 4
EEPROM contents (hex):
  0x00: 04 FF C1 8B 4A 41 42 30 35 34 36 30 43 53 56 09
  0x10: 34 40 00 B3 C0 46 03 20 00 12 81 04 42 43 30 85
  0x20: 1C 0C A2 02 80 FF FF FF FF C4 08 FF FF FF FF FF
  0x30: FF FF FF 81 FF FF FF FF 03 FF 04 FF C5 08 FF FF
  0x40: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
  0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Slot 1:

```

Mueslix-4T Port adapter, 4 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
Hardware revision 1.1      Board revision D0
Serial number 17202570     Part number 800-02314-02
FRU Part Number: NM-4T=

Test history 0x0          RMA number 00-00-00
EEPROM format version 1
EEPROM contents (hex):
  0x00: 01 54 01 01 01 06 7D 8A 50 09 0A 02 00 00 00 00
  0x10: 68 00 00 00 99 11 21 00 00 05 FF FF FF FF FF FF

```

Router#

Example for an NM-AIC-64 Installed in a Cisco 2611

The following is sample output from the **show diag** command for a Cisco 2611 router with the NM-AIC-64 installed.

```
Router# show diag

Slot 0:
C2611 2E Mainboard Port adapter, 2 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
Hardware Revision : 2.3
PCB Serial Number : JAD044808SG (1090473337)
Part Number : 73-2840-13
RMA History : 00
RMA Number : 0-0-0-0
Board Revision : C0
Deviation Number : 0-0
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 00 92 41 02 03 C1 18 4A 41 44 30 34 34
0x10: 38 30 38 53 47 20 28 31 30 39 30 34 37 33 33 33
0x20: 37 29 82 49 0B 18 0D 04 00 81 00 00 00 00 42 43
0x30: 30 80 00 00 00 00 FF FF FF FF FF FF FF FF FF
0x40: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

Slot 1:
NM_AIC_64 Port adapter, 3 ports
Port adapter is analyzed
Port adapter insertion time unknown
EEPROM contents at hardware discovery:
Hardware Revision : 1.0
Part Number : 74-1923-01
Board Revision : 02
PCB Serial Number : DAN05060012
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 02 55 41 01 00 82 4A 07 83 01 42 30 32
0x10: C1 8B 44 41 4E 30 35 30 36 30 30 31 32 FF FF FF
0x20: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x30: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x40: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
```

Table 69 describes significant fields shown in the display.

Table 69 *show diag (AIC) Field Descriptions*

Field	Description
C2611 2E Mainboard Port adapter, 2 ports	Line card type; number of ports available.
Port adapter is analyzed	The system has identified the port adapter.
Port adapter insertion time	Elapsed time since insertion.
Hardware Revision	Version number of the port adapter.

Table 69 *show diag (AIC) Field Descriptions*

Field	Description
PCB Serial Number	Serial number of the printed circuit board.
Part Number	Part number of the port adapter.
RMA History	Counter that indicates how many times the port adapter has been returned and repaired.
RMA Number	Return material authorization number, which is an administrative number assigned if the port adapter needs to be returned for repair.
Board Revision	Revision number (signifying a minor revision) of the port adapter.
Deviation Number	Revision number (signifying a minor deviation) of the port adapter.
EEPROM format version	Version number of the EEPROM format.
EEPROM contents (hex)	Dumps of EEPROM programmed data.

Example for an AIM-VPN in a Cisco 2611XM

The following example shows how to obtain hardware information about an installed AIM-VPN on the Cisco 2611XM router.

```
Router# show diag 0
```

```
Encryption AIM 1:
```

```

Hardware Revision      :1.0
Top Assy. Part Number  :800-03700-01
Board Revision         :A0
Deviation Number       :0-0
Fab Version            :02
PCB Serial Number      :JAB9801ABCD
RMA Test History       :00
RMA Number             :0-0-0-0
RMA History            :00
EEPROM format version 4
EEPROM contents (hex):
0x00:04 FF 40 03 0B 41 01 00 C0 46 03 20 00 0E 74 01
0x10:42 41 30 80 00 00 00 00 02 02 C1 8B 4A 41 42 39
0x20:38 30 31 41 42 43 44 03 00 81 00 00 00 00 04 00
0x30:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x40:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x50:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70:FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
```

Table 70 describes significant fields shown in the display.

Table 70 *show diag (AIM-VPN) Field Descriptions*

Field	Description
Hardware Revision	Version number of the port adapter.
Top Assy. Part Number	Part number of the port adapter.
Board Revision	Revision number (signifying a minor revision) of the port adapter.
Deviation Number	Revision number (signifying a minor deviation) of the port adapter.
PCB Serial Number	Serial number of the printed circuit board.
RMA Number	Return material authorization number, which is an administrative number assigned if the port adapter needs to be returned for repair.
RMA History	Counter that indicates how many times the port adapter has been returned and repaired.
EEPROM format version	Version number of the EEPROM format.
EEPROM contents (hex)	Dumps of EEPROM programmed data.

Example for an MSC-100 on the Cisco 7304 Router

The following is sample output from the **show diag slot-number** version of the command for an MSC-100 located in slot number 4 on a Cisco 7304 router. Information about the MSC is followed by information for its associated SPAs:

```
Router# show diag 4
Slot 4:
  7304-MSC-100 SPA Carrier Card Line Card
  Line Card state: Active
  Insertion time: 00:08:49 ago
  Bandwidth points: 4000000
  EEPROM contents at hardware discovery:
  Hardware Revision      : 0.18
  Boot Time out          : 0000
  PCB Serial Number      : CSJ07288905
  Part Number            : 73-8789-01
  Board Revision         : A0
  Fab Version            : 02
  RMA Test History       : 00
  RMA Number             : 0-0-0-0
  RMA History            : 00
  Deviation Number       : 0-0
  Product Number         : 7304-MSC-100
  Top Assy. Part Number   : 68-1163-04
  Manufacturing Test Data : 00 00 00 00 00 00 00 00
  Field Diagnostics Data  : 00 00 00 00 00 00 00 00
  Calibration Data       : Minimum: 0 dBmV, Maximum: 0 dBmV
    Calibration values :
  EEPROM format version 4
  EEPROM contents (hex):
    0x00: 04 FF 40 04 50 41 00 12 46 00 00 C1 8B 43 53 4A
    0x10: 30 37 32 38 38 39 30 35 82 49 22 55 01 42 41 30
    0x20: 02 02 03 00 81 00 00 00 00 04 00 80 00 00 00 00
    0x30: CB 94 37 33 30 34 2D 4D 53 43 2D 31 30 30 20 20
    0x40: 20 20 20 20 20 20 87 44 04 8B 04 C4 08 00 00 00
    0x50: 00 00 00 00 00 C5 08 00 00 00 00 00 00 00 C8
    0x60: 09 00 00 00 00 00 00 00 00 00 C7 7C F6 44 3F 30
    0x70: 00 00 00 00 00 00 00 00 00 00 00 00 02 EE FF C8
```

```

0x80: C8 37 26 05 DC 64 28 1E 37 26 09 C4 64 32 28 32
0x90: DD 0C E4 64 32 28 43 24 2E E0 AA 82 64 F4 24 00
0xA0: 00 00 00 00 00 00 F0 2E FF FF FF FF FF FF FF
0xB0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xC0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xD0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xE0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0xF0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x100: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x110: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x120: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x130: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x140: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x160: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x170: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x180: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x190: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1A0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1B0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1C0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1D0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1E0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x1F0: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
FPGA information:
  Current FPGA version      : 00.23
  IOS bundled FPGA version  : 00.23
  CPLD version              : 01.02

```

Subslot 4/1:

```

Shared port adapter: SPA-4FE-7304, 4 ports
State: ok
Insertion time: 00:15:13 ago
Bandwidth: 400000 kbps
EEPROM contents:

```

Examples for Shared Port Adapters on the Cisco 7304 Router

The following is sample output from the **show diag subslot** command for a 4-Port 10/100 Fast Ethernet SPA located in the bottom subslot (1) of the MSC that is installed in slot 4 on a Cisco 7304 router:

Router# **show diag subslot 4/1**

Subslot 4/1:

```

Shared port adapter: SPA-4FE-7304, 4 ports
Info: hw-ver=0x100, sw-ver=0x0 fpga-ver=0x0
State: ok
Insertion time: 23:20:42 ago
Bandwidth: 400000 kbps
EEPROM contents:
Hardware Revision      : 1.0
Boot Time out          : 0190
PCB Serial Number      : JAB073204G5
Part Number            : 73-8717-03
73/68 Level Revision   : 01
Fab Version            : 02
RMA Test History       : 00
RMA Number             : 0-0-0-0
RMA History            : 00
Deviation Number       : 0
Product Number         : SPA-4FE-7304
Product Version Id     : V01
Top Assy. Part Number  : 68-2181-01
73/68 Level Revision   : A0
CLEI Code              : CNS9420AAA

```

```

Base MAC Address      : 0000.0000.0000
MAC Address block size : 1024
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00
Calibration Data      : Minimum: 0 dBmV, Maximum: 0 dBmV
  Calibration values :
Power Consumption      : 160000mW max
  Mode 1 : 0mW
  Mode 2 : 0mW
  Mode 3 : 0mW
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 35 41 01 00 46 01 90 C1 8B 4A 41 42
0x10: 30 37 33 32 30 34 47 35 82 49 22 0D 03 8A 30 31
0x20: 20 20 02 02 03 00 81 00 00 00 00 04 00 88 00 00
0x30: 00 00 CB 94 53 50 41 2D 34 46 45 2D 37 33 30 34
0x40: 20 20 20 20 20 20 20 20 89 56 30 31 20 87 44 08
0x50: 85 01 8A 41 30 20 20 C6 8A 43 4E 53 39 34 32 30
0x60: 41 41 41 CF 06 00 00 00 00 00 00 00 43 04 00 C4 08
0x70: 00 00 00 00 00 00 00 00 C5 08 00 00 00 00 00 00
0x80: 00 00 F4 00 64 00 00 00 00 00 00 00 00 00 00 00
0x90: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xA0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xB0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xC0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xD0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xE0: 00 00 00 00 00 00 00 00 00 00 C8 09 00 00 00 00
0xF0: 00 00 00 00 D7 08 3E 80 00 00 00 00 00 00 F3 00
0x100: 41 01 08 F6 48 43 34 F6 49 44 35 02 31 04 B0 B4
0x110: A0 8C 00 00 05 DC 64 46 32 00 00 07 08 64 46 32
0x120: 00 00 09 C4 64 46 32 00 00 0C E4 64 46 32 00 00
0x130: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 FE 02
0x140: F2 A6 FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: CC A0 00 00 00 00 00 00 00 00 00 00 00 00 00
0x160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x170: 00 00 D4 A0 00 00 00 00 00 00 00 00 00 00 00
0x180: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x190: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1A0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1B0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1C0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1D0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1E0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1F0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
FPGA version:
  Software version : 04.17
  Hardware version : 04.17

```

The following is sample output from the **show diag subslot** command for a 2-Port 10/100/1000 Gigabit Ethernet SPA located in the top subslot (0) of the MSC that is installed in slot 4 on a Cisco 7304 router:

```
Router# show diag subslot 4/0
Subslot 4/0:
  Shared port adapter: SPA-2GE-7304, 2 ports
  Info: hw-ver=0x17, sw-ver=0x0 fpga-ver=0x0
  State: ok
  Insertion time: 00:08:47 ago
  Bandwidth: 2000000 kbps
  EEPROM contents:
    Hardware Revision      : 0.23
    Boot Time out          : 0190
    PCB Serial Number      : JAB073406YH
    Part Number            : 73-8792-02
    73/68 Level Revision   : 01
    Fab Version            : 02
    RMA Test History       : 00
    RMA Number             : 0-0-0-0
    RMA History            : 00
    Deviation Number       : 0
    Product Number         : SPA-2GE-7304
    Product Version Id     : V01
    Top Assy. Part Number  : 68-2181-01
    73/68 Level Revision   : A0
    CLEI Code              : CNS9420AAA
    Base MAC Address       : 0000.0000.0000
    MAC Address block size : 1024
    Manufacturing Test Data : 00 00 00 00 00 00 00 00 00
    Field Diagnostics Data  : 00 00 00 00 00 00 00 00 00
    Field Diagnostics Data  : 00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00 00 00 00 00 00
                           00 00 00 00
  Calibration Data        : Minimum: 0 dBmV, Maximum: 0 dBmV
    Calibration values :
  Power Consumption       : 160000mW max
    Mode 1 : 0mW
    Mode 2 : 0mW
    Mode 3 : 0mW
  EEPROM format version 4
  EEPROM contents (hex):
    0x00: 04 FF 40 04 36 41 00 17 46 01 90 C1 8B 4A 41 42
    0x10: 30 37 33 34 30 36 59 48 82 49 22 58 02 8A 30 31
    0x20: 20 20 02 02 03 00 81 00 00 00 00 04 00 88 00 00
    0x30: 00 00 CB 94 53 50 41 2D 32 47 45 2D 37 33 30 34
    0x40: 20 20 20 20 20 20 20 20 89 56 30 31 20 87 44 08
    0x50: 85 01 8A 41 30 20 20 C6 8A 43 4E 53 39 34 32 30
    0x60: 41 41 41 CF 06 00 00 00 00 00 00 43 04 00 C4 08
    0x70: 00 00 00 00 00 00 00 00 C5 08 00 00 00 00 00 00
    0x80: 00 00 F4 00 64 00 00 00 00 00 00 00 00 00 00 00
    0x90: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
    0xA0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
    0xB0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
    0xC0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```



```

0xD0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0xE0: 00 00 00 00 00 00 00 00 00 00 C8 09 00 00 00 00
0xF0: 00 00 00 00 D7 08 3E 80 00 00 00 00 00 00 F3 00
0x100: 41 01 08 F6 48 43 34 F6 49 44 35 02 31 03 E8 B4
0x110: A0 8C 37 26 05 DC 64 46 32 37 26 07 08 64 46 32
0x120: 37 26 09 C4 64 46 32 32 DD 0C E4 64 46 32 43 24
0x130: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 FE 02
0x140: EF E2 FF FF FF FF FF FF FF FF FF FF FF FF FF
0x150: CC A0 00 00 00 00 00 00 00 00 00 00 00 00 00
0x160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x170: 00 00 D4 A0 00 00 00 00 00 00 00 00 00 00 00
0x180: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x190: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1A0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1B0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1C0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1D0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1E0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x1F0: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
FPGA version:
Software version : 04.17
Hardware version : 04.17

```

Examples for a Shared Port Adapter on a Cisco 12000 Series Router

The following is sample output from the **show diag subslot** command for the 1-Port OC-192c/STM-64c POS/RPR XFP SPA in subslot 1 of the SIP located in chassis slot 1 on a Cisco 12000 series router:

```

Router# show diag subslot 1/1
SUBSLOT 1/1 (SPA-OC192POS-XFP): 1-port OC192/STM64 POS/RPR XFP Optics Shared Port Adapter
Product Identifier (PID) : SPA-OC192POS-XFP
Version Identifier (VID) : V01
PCB Serial Number       : PRTA1304061
Top Assy. Part Number   : 68-2190-01
Top Assy. Revision      : A0
Hardware Revision       : 2.0
CLEI Code               : UNASSIGNED
Insertion Time          : 00:00:10 (13:14:17 ago)
Operational Status      : ok

```

Table 71 describes the significant fields shown in the display.

Table 71 *show diag subslot Field Descriptions*

Field	Description
Product Identifier (PID)	Product number of the SPA.
Version Identifier (VID)	Version number of the SPA.
PCB Serial Number	Serial number of the printed circuit board.
Top Assy. Part Number	Part number of the SPA.
Top Assy. Revision	Revision number (signifying a minor revision) of the SPA.
Hardware Revision	Revision number (signifying a minor revision) of the SPA hardware.
CLEI Code	Common Language Equipment Identification number.

Table 71 *show diag subslot Field Descriptions (continued)*

Field	Description
Insertion Time	Time when the SPA was installed, and elapsed time between that insertion time and the current time.
Operational Status	Current status of the SPA. For more information about the status field descriptions, refer to the show hw-module subslot oir command.

The following is sample output from the **show diag subslot details** command for the 1-Port OC-192c/STM-64c POS/RPR XFP SPA in subslot 1 of the SIP located in chassis slot 1 on a Cisco 12000 series router:

```
Router# show diag subslot 1/1 details
SUBSLOT 1/1 (SPA-OC192POS-XFP): 1-port OC192/STM64 POS/RPR XFP Optics Shared Port Adapter
EEPROM version           : 4
Compatible Type          : 0xFF
Controller Type          : 1100
Hardware Revision        : 2.0
Boot Timeout             : 400 msecs
PCB Serial Number        : PRTA1304061
PCB Part Number          : 73-8546-01
PCB Revision             : A0          Fab Version           : 01
RMA Test History         : 00
RMA Number               : 0-0-0-0
RMA History              : 00
Deviation Number         : 0
Product Identifier (PID) : SPA-OC192POS-XFP
Version Identifier (VID) : V01
Top Assy. Part Number    : 68-2190-01
Top Assy. Revision       : A0          IDPROM Format Revision : 36
System Clock Frequency   : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00
CLEI Code                : UNASSIGNED
Base MAC Address         : 00 00 00 00 00 00
MAC Address block size   : 0
Manufacturing Test Data  : 00 00 00 00 00 00 00 00
Field Diagnostics Data   : 00 00 00 00 00 00 00 00
Calibration Data         : Minimum: 0 dBmV, Maximum: 0 dBmV
    Calibration values   :
Power Consumption        : 11000 mWatts (Maximum)
Environment Monitor Data : 03 30 04 B0 46 32 07 08
                          : 46 32 09 C4 46 32 0C E4
                          : 46 32 13 88 46 32 07 08
                          : 46 32 EB B0 50 3C 00 00
                          : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00 00 00
                          : 00 00 FE 02 F6 AC
Processor Label          : 00 00 00 00 00 00 00 00
Platform features        : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00 00 00
                          : 00 00 00 00 00 00 00 00
Asset ID                 :
Asset Alias              :
Insertion Time           : 00:00:10 (13:14:24 ago)
Operational Status       : ok
```

Example for a SPA Interface Processor on a Cisco 12000 Series Router

The following is sample output from the **show diag** command for a SIP located in chassis slot 2 on a Cisco 12000 series router:

Router# **show diag 2**

```
SLOT 2 (RP/LC 2 ): Modular 10G SPA Interface Card
  MAIN: type 149, 800-26270-01 rev 84
        Deviation: 0
        HW config: 0x00 SW key: 00-00-00
  PCA: 73-9607-01 rev 91 ver 1
        Design Release 1.0 S/N SAD08460678
  MBUS: Embedded Agent
        Test hist: 0x00 RMA#: 00-00-00 RMA hist: 0x00
  DIAG: Test count: 0x00000000 Test results: 0x00000000
  FRU: Linecard/Module: 12000-SIP-650
  FRU: Linecard/Module: 12000-SIP-650
        Processor Memory: MEM-LC5-1024=(Non-Replaceable)
        Packet Memory: MEM-LC5-PKT-256=(Non-Replaceable)
  L3 Engine: 5 - ISE OC192 (10 Gbps)
  MBUS Agent Software version 1.114 (RAM) (ROM version is 3.4)
  ROM Monitor version 255.255
  Fabric Downloader version used 3.7 (ROM version is 255.255)
  Primary clock is CSC 1
  Board is analyzed
  Board State is Line Card Enabled (IOS RUN )
  Insertion time: 1d00h (2d08h ago)
  Processor Memory size: 1073741824 bytes
  TX Packet Memory size: 268435456 bytes, Packet Memory pagesize: 32768 bytes
  RX Packet Memory size: 268435456 bytes, Packet Memory pagesize: 32768 bytes
  0 crashes since restart

SPA Information:
  subslot 2/0: SPA-OC192POS-XFP (0x44C), status is ok
  subslot 2/1: Empty
  subslot 2/2: Empty
  subslot 2/3: Empty
```

Example for ADSL HWICs

The following is sample output from the **show diag** command for a Cisco 2811 router with HWIC-1ADSL installed in slot 1 and HWIC-1ADSLI installed in slot 2. Each HWIC has a daughtercard as part of its assembly. The command results below give the output from the HWIC followed by the output from its daughtercard.

Router# **show diag 0**

```
Slot 0:
C2811 Motherboard with 2FE and integrated VPN Port adapter, 2 ports
  Port adapter is analyzed
  Port adapter insertion time unknown
  Onboard VPN : v2.2.0
  EEPROM contents at hardware discovery:
  PCB Serial Number : FOC09052HHA
  Hardware Revision : 2.0
  Top Assy. Part Number : 800-21849-02
  Board Revision : B0
  Deviation Number : 0
  Fab Version : 06
  RMA Test History : 00
  RMA Number : 0-0-0-0
  RMA History : 00
  Processor type : 87
```

■ show diag

```

Hardware date code       : 20050205
Chassis Serial Number    : FTX0908A0B0
Chassis MAC Address      : 0013.1ac2.2848
MAC Address block size   : 24
CLEI Code                : CNMJ7N0BRA
Product (FRU) Number     : CISCO2811
Part Number              : 73-7214-09
Version Identifier       : NA
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF C1 8B 46 4F 43 30 39 30 35 32 48 48 41 40
0x10: 03 E7 41 02 00 C0 46 03 20 00 55 59 02 42 42 30
0x20: 88 00 00 00 00 02 06 03 00 81 00 00 00 00 04 00
0x30: 09 87 83 01 31 F1 1D C2 8B 46 54 58 30 39 30 38
0x40: 41 30 42 30 C3 06 00 13 1A C2 28 48 43 00 18 C6
0x50: 8A 43 4E 4D 4A 37 4E 30 42 52 41 CB 8F 43 49 53
0x60: 43 4F 32 38 31 31 20 20 20 20 20 20 82 49 1C 2E
0x70: 09 89 20 20 4E 41 D9 02 40 C1 FF FF FF FF FF FF

```

WIC Slot 1:

```

ADSL over POTS
Hardware Revision        : 7.0
Top Assy. Part Number    : 800-26247-01
Board Revision           : 01
Deviation Number         : 0
Fab Version              : 07
PCB Serial Number        : FHH093600D4
RMA Test History         : 00
RMA Number               : 0-0-0-0
RMA History              : 00
Product (FRU) Number     : HWIC-1ADSL
Version Identifier       : V01
CLEI Code                :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 C8 41 07 00 C0 46 03 20 00 66 87 01
0x10: 42 30 31 88 00 00 00 00 02 07 C1 8B 46 48 48 30
0x20: 39 33 36 30 30 44 34 03 00 81 00 00 00 00 04 00
0x30: CB 94 48 57 49 43 2D 31 41 44 53 4C 20 20 20 20
0x40: 20 20 20 20 20 20 89 56 30 31 20 D9 02 40 C1 C6
0x50: 8A FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

EM Slot 0:

```

ADSL over POTS non-removable daughtercard
Hardware Revision        : 5.0
Part Number              : 73-9307-05
Board Revision           : 03
Deviation Number         : 0
Fab Version              : 05
PCB Serial Number        : FHH0936006E
RMA Test History         : 00
RMA Number               : 0-0-0-0
RMA History              : 00
Fab Part Number          : 28-6607-05
Manufacturing Test Data   : 00 00 00 00 00 00 00 00 00
Field Diagnostics Data    : 00 00 00 00 00 00 00 00 00
Connector Type           : 01
Version Identifier       : V01
Product (FRU) Number     :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 7A 41 05 00 82 49 24 5B 05 42 30 33

```

```

0x10: 88 00 00 00 00 02 05 C1 8B 46 48 48 30 39 33 36
0x20: 30 30 36 45 03 00 81 00 00 00 00 04 00 85 1C 19
0x30: CF 05 C4 08 00 00 00 00 00 00 00 00 C5 08 00 00
0x40: 00 00 00 00 00 00 05 01 89 56 30 31 20 FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

WIC Slot 2:
ADSL over ISDN
Hardware Revision      : 7.0
Top Assy. Part Number  : 800-26248-01
Board Revision         : 01
Deviation Number       : 0
Fab Version            : 07
PCB Serial Number      : FHH093600DA
RMA Test History       : 00
RMA Number             : 0-0-0-0
RMA History            : 00
Product (FRU) Number   : HWIC-1ADSLI
Version Identifier     : V01
CLEI Code              :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 C9 41 07 00 C0 46 03 20 00 66 88 01
0x10: 42 30 31 88 00 00 00 00 02 07 C1 8B 46 48 48 30
0x20: 39 33 36 30 30 44 41 03 00 81 00 00 00 00 04 00
0x30: CB 94 48 57 49 43 2D 31 41 44 53 4C 49 20 20 20
0x40: 20 20 20 20 20 20 89 56 30 31 20 D9 02 40 C1 C6
0x50: 8A FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

EM Slot 0:
ADSL over ISDN non-removable daughtercard
Hardware Revision      : 5.0
Part Number           : 73-9308-05
Board Revision         : 03
Deviation Number       : 0
Fab Version            : 05
PCB Serial Number      : FHH0936008M
RMA Test History       : 00
RMA Number             : 0-0-0-0
RMA History            : 00
Fab Part Number        : 28-6607-05
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data  : 00 00 00 00 00 00 00 00
Connector Type         : 01
Version Identifier     : V01
Product (FRU) Number   :
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 04 7B 41 05 00 82 49 24 5C 05 42 30 33
0x10: 88 00 00 00 00 02 05 C1 8B 46 48 48 30 39 33 36
0x20: 30 30 38 4D 03 00 81 00 00 00 00 04 00 85 1C 19
0x30: CF 05 C4 08 00 00 00 00 00 00 00 00 00 C5 08 00
0x40: 00 00 00 00 00 00 05 01 89 56 30 31 20 FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

The following sample output from a Cisco 6500 series switch shows the FRU number:

```

Router# show diag

Slot 4: Logical_index 8
2 port adapter FlexWAN controller
Board is analyzed ipc ready
HW rev 1.5, board revision A0
Serial Number: SAD062404C8 Part number: 73-3869-08

Slot database information:
Flags: 0x2004 Insertion time: 0x20960 (1d04h ago)

Controller Memory Size:
112 MBytes CPU Memory
16 MBytes Packet Memory
128 MBytes Total on Board SDRAM
IOS (tm) cwlc Software (cwpa-DW-M), Version 12.2(18)SXF2, RELEASE SOFTW

PA Bay 0 Information:
ENHANCED ATM OC3 MM PA, 1 ports, FRU: PA-A3-OC3-MM
EEPROM format version 1
HW rev 2.00, Board revision A0
Serial number: 29360940 Part number: 73-2430-04

Slot 4: Logical_index 9
2 port adapter FlexWAN controller
Board is analyzed ipc ready
HW rev 1.5, board revision A0
Serial Number: SAD062404C8 Part number: 73-3869-08

Slot database information:
Flags: 0x2004 Insertion time: 0x20D10 (1d04h ago)

Controller Memory Size:
112 MBytes CPU Memory
16 MBytes Packet Memory
128 MBytes Total on Board SDRAM
IOS (tm) cwlc Software (cwpa-DW-M), Version 12.2(18)SXF2, RELEASE SOFTW

PA Bay 1 Information:
Mx Serial PA, 4 ports
EEPROM format version 1
HW rev 1.00, Board revision A0
Serial number: 04387628 Part number: 73-1577-04

Router#

```

The following sample output from a Cisco 7600 series router shows the FRU number:

```

Router#show diag

Slot 2: Logical_index 4
2 port adapter Enhanced FlexWAN controller
Board is analyzed ipc ready
HW rev 2.1, board revision A0
Serial Number: JAE0940MH7Z Part number: 73-9539-04

Slot database information:
Flags: 0x2004 Insertion time: 0x256BC (1d01h ago)

Controller Memory Size:
384 MBytes CPU Memory
127 MBytes Packet Memory
511 MBytes Total on Board SDRAM
IOS (tm) cwlc Software (cwpa2-DW-M), Version 12.2(18)SXF2, RELEASE SOFTW

PA Bay 0 Information:

```

```

      ENHANCED ATM OC3 MM PA, 1 ports, FRU: PA-A3-OC3-MM
      EEPROM format version 4
      HW rev 2.00, Board revision A0
      Serial number: JAE0937KUPX Part number: 73-8728-01
Slot 2: Logical_index 5
      2 port adapter Enhanced FlexWAN controller
      Board is analyzed ipc ready
      HW rev 2.1, board revision A0
      Serial Number: JAE0940MH7Z Part number: 73-9539-04

Slot database information:
Flags: 0x2004 Insertion time: 0x22C34 (1d01h ago)

Controller Memory Size:
      384 MBytes CPU Memory
      127 MBytes Packet Memory
      511 MBytes Total on Board SDRAM
IOS (tm) cwlw Software (cwpa2-DW-M), Version 12.2(18)SXF2, RELEASE SOFT)

PA Bay 1 Information:
      Mx Serial PA, 4 ports
      EEPROM format version 1
      HW rev 1.14, Board revision D0
      Serial number: 33929508 Part number: 73-1577-07
Router#

```

Related Commands

Command	Description
dsl operating-mode (ADSL)	Modifies the operating mode of the digital subscriber line for an ATM interface.
show dsl interface atm	Shows all of the ADSL-specific information for a specified ATM interface.
show controllers fastethernet	Displays Fast Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.
show controllers gigabitethernet	Displays Gigabit Ethernet interface information, transmission statistics and errors, and applicable MAC destination address and VLAN filtering tables.

show disk0:

To display flash or file system information for a disk located in slot 0, use the **show disk** command in user EXEC or privileged EXEC mode.

show disk0: [all | fileys]

Syntax Description

all	(Optional) The all keyword displays complete information about flash memory, including information about the individual devices in flash memory and the names and sizes of all system image files stored in flash memory, including those that are invalid.
fileys	(Optional) Displays the device information block, the status information, and the usage information.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3AA	This command was introduced.
12.2	This command was incorporated into Cisco IOS Release 12.2.
12.3(7)T	This command was enhanced to display information about the ATA ROM monitor library (monlib) file.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

The **show disk0:** command is supported only on platforms that have a disk file system located in slot 0. Use the **show disk0:** command to display details about the files in a particular ATA PCMCIA flash disk memory card.

For more information regarding file systems and flash cards, access the *PCMCIA Filesystem Compatibility Matrix and Filesystem Information* document at the following URL:

http://www.cisco.com/en/US/partner/products/hw/routers/ps341/products_tech_note09186a00800a7515.shtml



Note

The name of the ATA monlib file may contain a platform name that does not match the platform that you are using. Different platforms may have a similar name or the same name for their ATA monlib file.

Examples

The following examples show displays of information about the flash disks or file system information for a disk. The output is self-explanatory.

```
c7200# show disk0:
```

```
-#- --length-- -----date/time----- path
1      29505176 Feb 27 2006 17:56:52 +00:00 c7200-jk9o3s-mz.124-6.T
2          32768 Feb 24 2006 13:30:30 +00:00 file1.log
```

```
34738176 bytes available (29540352 bytes used)
```

```
c7200# show disk0: all
```

```
-#- --length-- -----date/time----- path
1      29505176 Feb 27 2006 17:56:52 +00:00 c7200-jk9o3s-mz.124-6.T
2          32768 Feb 24 2006 13:30:30 +00:00 file1.log
```

```
34738176 bytes available (29540352 bytes used)
```

```
***** ATA Flash Card Geometry/Format Info *****
```

```
ATA CARD GEOMETRY
```

```
Number of Heads:      4
Number of Cylinders   984
Sectors per Cylinder  32
Sector Size           512
Total Sectors         125952
```

```
ATA CARD FORMAT
```

```
Number of FAT Sectors 62
Sectors Per Cluster   8
Number of Clusters    15693
Number of Data Sectors 125812
Base Root Sector      232
Base FAT Sector        108
Base Data Sector       264
```

```
ATA MONLIB INFO
```

```
Image Monlib size = 73048
Disk monlib size = 55296
Name = NA
Monlib end sector = NA
Monlib Start sector = NA
Monlib updated by = NA
Monlib version = NA
```

```
c7200# show disk0: fileys
```

```
***** ATA Flash Card Geometry/Format Info *****
```

```
ATA CARD GEOMETRY
```

```
Number of Heads:      4
Number of Cylinders   984
Sectors per Cylinder  32
Sector Size           512
Total Sectors         125952
```

```
ATA CARD FORMAT
```

```
Number of FAT Sectors 62
Sectors Per Cluster   8
Number of Clusters    15693
Number of Data Sectors 125812
Base Root Sector      232
```

 **show disk0:**

```
Base FAT Sector      108
Base Data Sector     264
```

```
ATA MONLIB INFO
Image Monlib size = 73048
Disk monlib size = 55296
Name = NA
Monlib end sector = NA
Monlib Start sector = NA
Monlib updated by = NA
Monlib version = NA
```

Related Commands

Command	Description
dir disk0:	Displays a directory listing of files on an ATA PCMCIA flash disk card located in slot 0.
dir disk1:	Displays a directory listing of files on an ATA PCMCIA flash disk card located in slot 1.
show disk1:	Displays flash or file system information for a disk located in slot 1.

show disk1:

To display flash or file system information for a disk located in slot 1, use the **show disk1:** command in user EXEC or privileged EXEC mode.

show disk1: [**all** | **filesystems**]

Syntax Description

all	(Optional) The all keyword displays complete information about flash memory, including information about the individual devices in flash memory and the names and sizes of all system image files stored in flash memory, including those that are invalid.
filesystems	(Optional) Displays the device information block, the status information, and the usage information.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.3AA	This command was introduced.
12.2	This command was incorporated into Cisco IOS Release 12.2.
12.3(7)T	This command was enhanced to display information about the ATA ROM monitor library (monlib) file.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.

Usage Guidelines

The **show disk1:** command is supported only on platforms that have a disk file system. Use the **show disk01:** command to display details about the files in a particular ATA PCMCIA flash disk memory card located in slot 1.

For more information regarding file systems and flash cards, access the *PCMCIA Filesystem Compatibility Matrix and Filesystem Information* document at the following URL:

http://www.cisco.com/en/US/partner/products/hw/routers/ps341/products_tech_note09186a00800a7515.shtml



Note

The name of the ATA monlib file may contain a platform name that does not match the platform that you are using. Different platforms may have a similar name or the same name for their ATA monlib file.

■ **show disk1:**

Examples

The following examples show displays of information about the flash disks or file system information for a disk. The output is self-explanatory.

c7200# **show disk1:**

```
-#- --length-- -----date/time----- path
1      29505176 Feb 27 2006 17:56:52 +00:00 c7200-jk9o3s-mz.124-6.T
2          32768 Feb 24 2006 13:30:30 +00:00 file1.log
```

34738176 bytes available (29540352 bytes used)

c7200# **show disk1: all**

```
-#- --length-- -----date/time----- path
1      29505176 Feb 27 2006 17:56:52 +00:00 c7200-jk9o3s-mz.124-6.T
2          32768 Feb 24 2006 13:30:30 +00:00 file1.log
```

34738176 bytes available (29540352 bytes used)

***** ATA Flash Card Geometry/Format Info *****

ATA CARD GEOMETRY

```
Number of Heads:      4
Number of Cylinders   984
Sectors per Cylinder  32
Sector Size           512
Total Sectors         125952
```

ATA CARD FORMAT

```
Number of FAT Sectors 62
Sectors Per Cluster   8
Number of Clusters    15693
Number of Data Sectors 125812
Base Root Sector      232
Base FAT Sector        108
Base Data Sector      264
```

ATA MONLIB INFO

```
Image Monlib size = 73048
Disk monlib size = 55296
Name = NA
Monlib end sector = NA
Monlib Start sector = NA
Monlib updated by = NA
Monlib version = NA
```

c7200# **show disk1: filesys**

***** ATA Flash Card Geometry/Format Info *****

ATA CARD GEOMETRY

```
Number of Heads:      4
Number of Cylinders   984
Sectors per Cylinder  32
Sector Size           512
Total Sectors         125952
```

ATA CARD FORMAT

```
Number of FAT Sectors 62
Sectors Per Cluster   8
Number of Clusters    15693
Number of Data Sectors 125812
Base Root Sector      232
```

```
Base FAT Sector      108
Base Data Sector     264
```

```
ATA MONLIB INFO
Image Monlib size = 73048
Disk monlib size = 55296
Name = NA
Monlib end sector = NA
Monlib Start sector = NA
Monlib updated by = NA
Monlib version = NA
```

Related Commands

Command	Description
dir disk0:	Displays a directory listing of files on an ATA PCMCIA flash disk card located in slot 0.
dir disk1:	Displays a directory listing of files on an ATA PCMCIA flash disk card located in slot 1.
show disk0:	Displays flash or file system information for a disk located in slot 0.

show environment

To display temperature, voltage, and blower information on the Cisco 7000 series, Cisco 7200 series, Cisco 7500 series routers, Cisco AS5300 series Access Servers, and Cisco 12000 series Gigabit Switch Routers (GSRs), use the **show environment** privileged EXEC command.

show environment [**alarms** | **all** | **fans** | **hardware** | **last** | **leds** | **power-supply** | **table** | **temperatures** | **voltages**]



Note

The availability of keywords will depend on your system.

Syntax Description

alarms	(Optional) Displays the alarm contact information.
all	(Optional) Displays a detailed listing of all environmental monitor parameters (for example, the power supplies, temperature readings, voltage readings, and blower speeds). This is the default.
fans	(Optional) Displays blower and fan information.
hardware	(Optional) Displays hardware-specific information.
last	(Optional) Displays information on the last measurement made.
leds	(Optional) Displays the status of the MBus LEDs on the clock and scheduler cards and switch fabric cards.
power-supply	(Optional) Displays power supply voltage and current information. If applicable, displays the status of the Redundant Power Supply (RPS).
table	(Optional) Displays the temperature, voltage, and blower ranges and thresholds.
temperature	(Optional) Displays temperature information.
voltages	(Optional) Displays voltage information.

Defaults

If no options are specified, the default is **all**.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.0	This command was introduced.
11.2 GS	The alarms , fans , hardware , leds , power-supply , table temperature , and voltages keywords were added for Cisco 12000 series GSRs.
11.3(6)AA	This command was expanded to monitor the RPS and board temperature for the Cisco AS5300 platform, Cisco 3600 Series routers, Cisco 7200 series routers, and the Cisco 12000 series routers.

Usage Guidelines

Once a minute a routine is run that gets environmental measurements from sensors and stores the output into a buffer. This buffer is displayed on the console when the **show environment** command is entered.

If a measurement exceeds desired margins, but has not exceeded fatal margins, a warning message is printed to the system console. The system software queries the sensors for measurements once a minute, but warnings for a given test point are printed at most once every hour for sensor readings in the warning range and once every 5 minutes for sensor readings in the critical range. If a measurement is out of line within these time segments, an automatic warning message appears on the console. As noted, you can query the environmental status with the **show environment** command at any time to determine whether a measurement is at the warning or critical tolerance.

If a shutdown occurs because of detection of fatal environmental margins, the last measured value from each sensor is stored in internal nonvolatile memory.

For environmental specifications, refer to the hardware installation and configuration publication for your individual chassis.

If the Cisco 12000 series exceeds environmental conditions, a message similar to the following is displayed on the console:

```
%GSR_ENV-2-WARNING: Slot 3 Hot Sensor Temperature exceeds 40 deg C;  
Check cooling systems
```



Note

Blower temperatures that exceed environmental conditions do not generate a warning message.

You can also enable Simple Network Management Protocol (SNMP) notifications (traps or informs) to alert a network management system (NMS) when environmental thresholds are reached using the **snmp-server enable traps envmon** and **snmp-server host** global configuration commands.

Whenever Cisco IOS software detects a failure or recovery event from the DRPS unit, it sends an SNMP trap to the configured SNMP server. Unlike console messages, only one SNMP trap is sent when the failure event is first detected. Another trap is sent when the recovery is detected.

Cisco AS5300 DRPS software reuses the MIB attributes and traps defined in CISCO-ENVMON-MIB and CISCO-ACCESS-ENVMON-MIB. CISCO-ENVMON-MIB is supported by all Cisco routers with RPS units, and CISCO-ACCESS-ENVMON-MIB is supported by the Cisco 3600 series routers.

A power supply trap defined in CISCO-ENVMON-MIB is sent when a failure is detected and when a failure recovery occurs for the following events: input voltage fail, DC output voltage fail, thermal fail, and multiple failure events.

A fan failure trap defined in CISCO-ENVMON-MIB is sent when a fan failure or recovery event is detected by Cisco IOS software.

A temperature trap defined in CISCO-ACCESS-ENVMON-MIB is sent when a board overtemperature condition is detected by Cisco IOS software.

CISCO-ACCESS-ENVMON-MIB also defines an overvoltage trap. A similar trap is defined in CISCO-ENVMON-MIB, but it requires the `ciscoEnvMonVoltageStatusValue` in varbinds. This value indicates the current value of the voltage in the RPS. With Cisco AS5300 RPS units, the current voltage value is not sent to the motherboard.

CISCO-ENVMON-MIB is extended to add a new enumerated value, `internalRedundant(5)`, for MIB attribute `ciscoEnvMonSupplySource`. This is used to identify a RPS unit.

Examples

In the following example, the typical **show environment** display is shown when no warning conditions are in the system for the Cisco 7000 series and Cisco 7200 series routers. This information may vary slightly depending on the platform you are using. The date and time of the query are displayed, along with the data refresh information and a message indicating that there are no warning conditions.

```
Router> show environment

Environmental Statistics
  Environmental status as of 13:17:39 UTC Thu Jun 6 1996
  Data is 7 second(s) old, refresh in 53 second(s)

All Environmental Measurements are within specifications
```

Table 72 describes the significant fields shown in the display.

Table 72 *show environment Field Descriptions*

Field	Description
Environmental status as of...	Current date and time.
Data is..., refresh in...	Environmental measurements are output into a buffer every 60 seconds, unless other higher-priority processes are running.
Status message	If environmental measurements are not within specification, warning messages are displayed.

Cisco 7000 Series Routers

The following are examples of messages that display on the system console when a measurement has exceeded an acceptable margin:

```
ENVIRONMENTAL WARNING: Air flow appears marginal.
ENVIRONMENTAL WARNING: Internal temperature measured 41.3(C)
ENVIRONMENTAL WARNING: +5 volt testpoint measured 5.310(V)
```

The system displays the following message if voltage or temperature exceed maximum margins:

```
SHUTDOWN: air flow problem
```

In the following example, there have been two intermittent power failures since a router was turned on, and the lower power supply is not functioning. The last intermittent power failure occurred on Monday, June 10, 1996, at 11:07 p.m.

```
7000# show environment all

Environmental Statistics
  Environmental status as of 23:19:47 UTC Wed Jun 12 1996
  Data is 6 second(s) old, refresh in 54 second(s)

WARNING: Lower Power Supply is NON-OPERATIONAL

Lower Power Supply:700W, OFF      Upper Power Supply: 700W, ON

Intermittent Powerfail(s): 2      Last on 23:07:05 UTC Mon Jun 10 1996

+12 volts measured at 12.05(V)
+5 volts measured at 4.96(V)
-12 volts measured at -12.05(V)
+24 volts measured at 23.80(V)

Airflow temperature measured at 38(C)
Inlet temperature measured at 25(C)
```


Table 73 describes the significant fields shown in the display.

Table 73 *show environment all Field Descriptions for the Cisco 7000*

Field	Description
Environmental status as of...	Date and time of last query.
Data is..., refresh in...	Environmental measurements are output into a buffer every 60 seconds, unless other higher-priority processes are running.
WARNING:	If environmental measurements are not within specification, warning messages are displayed.
Lower Power Supply	Type of power supply installed and its status (On or Off).
Upper Power Supply	Type of power supply installed and its status (On or Off).
Intermittent Powerfail(s)	Number of power hits (not resulting in shutdown) since the system was last booted.
voltage specifications	System voltage measurements.
Airflow and inlet temperature	Temperature of air coming in and going out.

The following example is for the Cisco 7000 series router. The router retrieves the environmental statistics at the time of the last shutdown. In this example, the last shutdown was Friday, May 19, 1995, at 12:40 p.m., so the environmental statistics at that time are displayed.

```
Router# show environment last

Environmental Statistics
  Environmental status as of 14:47:00 UTC Sun May 21 1995
  Data is 6 second(s) old, refresh in 54 second(s)

  WARNING: Upper Power Supply is NON-OPERATIONAL

LAST Environmental Statistics
  Environmental status as of 12:40:00 UTC Fri May 19 1995
  Lower Power Supply: 700W, ON      Upper Power Supply: 700W, OFF

  No Intermittent Powerfails

  +12 volts measured at 12.05(V)
  +5 volts measured at 4.98(V)
  -12 volts measured at -12.00(V)
  +24 volts measured at 23.80(V)

  Airflow temperature measured at 30(C)
  Inlet temperature measured at 23(C)
```

Table 74 describes the significant fields shown in the display.

Table 74 *show environment last Field Descriptions for the Cisco 7000*

Field	Description
Environmental status as of...	Current date and time.
Data is..., refresh in...	Environmental measurements are output into a buffer every 60 seconds, unless other higher-priority processes are running.

Table 74 *show environment last Field Descriptions for the Cisco 7000 (continued)*

Field	Description
WARNING:	If environmental measurements are not within specification, warning messages are displayed.
LAST Environmental Statistics	Displays test point values at time of the last environmental shutdown.
Lower Power Supply: Upper Power Supply:	For the Cisco 7000 router, indicates the status of the two 700W power supplies. For the Cisco 7010 router, indicates the status of the single 600W power supply.

In the following example, shows sample output for the current environmental status in tables that list voltage and temperature parameters. There are three warning messages: one each about the lower power supply, the airflow temperature, and the inlet temperature. In this example, voltage parameters are shown to be in the normal range, airflow temperature is at a critical level, and inlet temperature is at the warning level.

```
Router> show environment table
```

Environmental Statistics

```
Environmental status as of Mon 11-2-1992 17:43:36
Data is 52 second(s) old, refresh in 8 second(s)
```

```
WARNING: Lower Power Supply is NON-OPERATIONAL
WARNING: Airflow temperature has reached CRITICAL level at 73(C)
WARNING: Inlet temperature has reached WARNING level at 41(C)
```

Voltage Parameters:

SENSE	CRITICAL	NORMAL	CRITICAL
-----	-----	-----	-----
+12 (V)	10.20	12.05 (V)	13.80
+5 (V)	4.74	4.98 (V)	5.26
-12 (V)	-10.20	-12.05 (V)	-13.80
+24 (V)	20.00	24.00 (V)	28.00

Temperature Parameters:

SENSE	WARNING	NORMAL	WARNING	CRITICAL	SHUTDOWN
-----	-----	-----	-----	-----	-----
Airflow	10	60	70	73 (C)	88
Inlet	10	39	41 (C)	46	64

Table 75 describes the significant fields shown in the display.

Table 75 *show environment Field Descriptions for the Cisco 7000 Series Router*

Field	Description
SENSE (Voltage Parameters)	Voltage specification for a DC line.
SENSE (Temperature Parameters)	Air being measured. Inlet measures the air coming in, and Airflow measures the temperature of the air inside the chassis.
WARNING	System is approaching an out-of-tolerance condition.

Table 75 *show environment Field Descriptions for the Cisco 7000 (continued)Series Router*

Field	Description
NORMAL	All monitored conditions meet normal requirements.
CRITICAL	Out-of-tolerance condition exists.
SHUTDOWN	Processor has detected condition that could cause physical damage to the system.

Cisco 7200 Series Routers

The system displays the following message if the voltage or temperature enters the “Warning” range:

```
%ENVM-4-ENVWARN: Chassis outlet 3 measured at 55C/131F
```

The system displays the following message if the voltage or temperature enters the “Critical” range:

```
%ENVM-2-ENVCRT: +3.45 V measured at +3.65 V
```

The system displays the following message if the voltage or temperature exceeds the maximum margins:

```
%ENVM-0-SHUTDOWN: Environmental Monitor initiated shutdown
```

The following message is sent to the console if a power supply has been inserted or removed from the system. This message relates only to systems that have two power supplies.

```
%ENVM-6-PSCHANGE: Power Supply 1 changed from ZyteK AC Power Supply to removed
```

The following message is sent to the console if a power supply has been powered on or off. In the case of the power supply being shut off, this message can be due to the user shutting off the power supply or to a failed power supply. This message relates only to systems that have two power supplies.

```
%ENVM-6-PSLEV: Power Supply 1 state changed from normal to shutdown
```

The following is sample output from the **show environment all** command on the Cisco 7200 series router when there is a voltage warning condition in the system:

```
7200# show environment all
```

```
Power Supplies:
```

```
Power supply 1 is unknown. Unit is off.
```

```
Power supply 2 is ZyteK AC Power Supply. Unit is on.
```

```
Temperature readings:
```

```
chassis inlet measured at 25C/77F
```

```
chassis outlet 1 measured at 29C/84F
```

```
chassis outlet 2 measured at 36C/96F
```

```
chassis outlet 3 measured at 44C/111F
```

```
Voltage readings:
```

```
+3.45 V measured at +3.83 V:Voltage in Warning range!
```

```
+5.15 V measured at +5.09 V
```

```
+12.15 measured at +12.42 V
```

```
-11.95 measured at -12.10 V
```

Table 76 describes the significant fields shown in the display.

Table 76 *show environment all Field Descriptions for the Cisco 7200 Series Router*

Field	Description
Power Supplies:	Current condition of the power supplies including the type and whether the power supply is on or off.
Temperature readings:	Current measurements of the chassis temperature at the inlet and outlet locations.
Voltage readings:	Current measurement of the power supply test points.

The following example is for the Cisco 7200 series router. This example shows the measurements immediately before the last shutdown and the reason for the last shutdown (if appropriate).

```
7200# show environment last
```

```

chassis inlet      previously measured at 27C/80F
chassis outlet 1   previously measured at 31C/87F
chassis outlet 2   previously measured at 37C/98F
chassis outlet 3   previously measured at 45C/113F
+3.3 V            previously measured at 4.02
+5.0 V            previously measured at 4.92
+12.0 V           previously measured at 12.65
-12.0 V           previously measured at 11.71

```

```
last shutdown reason - power supply shutdown
```

Table 77 describes the significant fields shown in the display.

Table 77 *show environment last Field Descriptions for the Cisco 7200 Series Router*

Field	Description
chassis inlet	Temperature measurements at the inlet area of the chassis.
chassis outlet	Temperature measurements at the outlet areas of the chassis.
voltages	Power supply test point measurements.
last shutdown reason	Possible shutdown reasons are power supply shutdown, critical temperature, and critical voltage.

The following example is for the Cisco 7200 series router. This information lists the temperature and voltage shutdown thresholds for each sensor.

```
7200# show environment table
```

```

Sample Point      LowCritical    LowWarning      HighWarning      HighCritical
chassis inlet      40C/104F      50C/122F
chassis outlet 1   43C/109F      53C/127F
chassis outlet 2   75C/167F      75C/167F
chassis outlet 3   55C/131F      65C/149F
+3.45 V           +2.76         +3.10           +3.80           +4.14
+5.15 V           +4.10         +4.61           +5.67           +6.17
+12.15 V          +9.72         +10.91          +13.37          +14.60
-11.95 V          -8.37         -9.57           -14.34          -15.53
Shutdown system at 70C/158F

```

Table 78 describes the significant fields shown in the display.

Table 78 *show environment table Field Descriptions for the Cisco 7200 Series Router*

Field	Description
Sample Point	Area for which measurements are taken.
LowCritical	Level at which a critical message is issued for an out-of-tolerance voltage condition. The system continues to operate; however, the system is approaching shutdown.
LowWarning	Level at which a warning message is issued for an out-of-tolerance voltage condition. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighWarning	Level at which a warning message is issued. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighCritical	Level at which a critical message is issued. For the chassis, the router is shut down. For the power supply, the power supply is shut down.
Shutdown system at	The system is shut down if the specified temperature is met.

Cisco 7500 Series Router

The sample output for the Cisco 7500 series routers may vary depending on the specific model (for example, the Cisco 7513 router). The following is sample output from the **show environment all** command on the Cisco 7500 series router:

```
7500# show environment all
```

```
Arbiter type 1, backplane type 7513 (id 2)
Power supply #1 is 1200W AC (id 1), power supply #2 is removed (id 7)
Active fault conditions: none
Fan transfer point: 100%
Active trip points: Restart_Inhibit
15 of 15 soft shutdowns remaining before hard shutdown
```

```

1
0123456789012
Dbus slots:  X    XX    X

card      inlet    hotpoint    exhaust
RSP(6)    35C/95F    47C/116F    40C/104F
RSP(7)    35C/95F    43C/109F    39C/102F
```

```
Shutdown temperature source is 'hotpoint' on RSP(6), requested RSP(6)
```

```
+12V measured at 12.31
+5V measured at 5.21
-12V measured at -12.07
+24V measured at 22.08
+2.5 reference is 2.49
```

```
PS1 +5V Current      measured at 59.61 A (capacity 200 A)
PS1 +12V Current     measured at 5.08 A (capacity 35 A)
PS1 -12V Current     measured at 0.42 A (capacity 3 A)
PS1 output is 378 W
```

Table 79 describes the significant fields shown in the display.

Table 79 *show environment all Field Descriptions for the Cisco 7500*

Field	Description
Arbiter type 1	Numbers indicating the arbiter type and backplane type.
Power supply	Number and type of power supply installed in the chassis.
Active fault conditions:	Lists any fault conditions that exist (such as power supply failure, fan failure, and temperature too high).
Fan transfer point:	Software controlled fan speed. If the router is operating below its automatic restart temperature, the transfer point is reduced by 10 percent of the full range each minute. If the router is at or above its automatic restart temperature, the transfer point is increased in the same way.
Active trip points:	Compares temperature sensor against the values displayed at the bottom of the show environment table command output.
15 of 15 soft shutdowns remaining	When the temperature increases above the “board shutdown” level, a soft shutdown occurs (that is, the cards are shut down, and the power supplies, fans, and CI continue to operate). When the system cools to the restart level, the system restarts. The system counts the number of times this occurs and keeps the up/down cycle from continuing forever. When the counter reaches zero, the system performs a hard shutdown, which requires a power cycle to recover. The soft shutdown counter is reset to its maximum value after the system has been up for 6 hours.
Dbus slots:	Indicates which chassis slots are occupied.
card, inlet, hotpoint, exhaust	Temperature measurements at the inlet, hotpoint, and exhaust areas of the card. The (6) and (7) indicate the slot numbers. Dual-Route/Switch Processor (RSP) chassis can show two RSPs.
Shutdown temperature source	Indicates which of the three temperature sources is selected for comparison against the “shutdown” levels listed with the show environment table command.
Voltages (+12V, +5V, -12V, +24V, +2.5)	Voltages measured on the backplane.
PS1	Current measured on the power supply.

The following example is for the Cisco 7500 series router. This example shows the measurements immediately before the last shutdown.

```
7500# show environment last
```

```

RSP(4) Inlet      previously measured at 37C/98F
RSP(4) Hotpoint   previously measured at 46C/114F
RSP(4) Exhaust    previously measured at 52C/125F
+12 Voltage       previously measured at 12.26
+5 Voltage        previously measured at 5.17
-12 Voltage       previously measured at -12.03
+24 Voltage       previously measured at 23.78
```

Table 80 describes the significant fields shown in the display.

Table 80 *show environment last Field Descriptions for the Cisco 7500 Series Router*

Field	Description
RSP(4) Inlet, Hotpoint, Exhaust	Temperature measurements at the inlet, hotpoint, and exhaust areas of the card.
Voltages	Voltages measured on the backplane.

The following example is for the Cisco 7500 series router. This information lists the temperature and voltage thresholds for each sensor. These thresholds indicate when system messages occur. There are two level of messages: warning and critical.

```
7500# show environment table
```

Sample Point	LowCritical	LowWarning	HighWarning	HighCritical
RSP(4) Inlet			44C/111F	50C/122F
RSP(4) Hotpoint			54C/129F	60C/140F
RSP(4) Exhaust				
+12 Voltage	10.90	11.61	12.82	13.38
+5 Voltage	4.61	4.94	5.46	5.70
-12 Voltage	-10.15	-10.76	-13.25	-13.86
+24 Voltage	20.38	21.51	26.42	27.65
2.5 Reference		2.43	2.51	
Shutdown boards at		70C/158F		
Shutdown power supplies at		76C/168F		
Restart after shutdown below		40C/104F		

Table 81 describes the significant fields shown in the display.

Table 81 *show environment table Field Descriptions for the Cisco 7500 Series Router*

Field	Description
Sample Point	Area for which measurements are taken.
LowCritical	Level at which a critical message is issued for an out-of-tolerance voltage condition. The system continues to operate; however, the system is approaching shutdown.
LowWarning	Level at which a warning message is issued for an out-of-tolerance voltage condition. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighWarning	Level at which a warning message is issued. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
HighCritical	Level at which a critical message is issued. For the chassis, the router is shut down. For the power supply, the power supply is shut down.
Shutdown boards at	The card is shut down if the specified temperature is met.
Shutdown power supplies at	The system is shut down if the specified temperature is met.
Restart after shutdown	The system will restart when the specified temperature is met.

Cisco AS5300 Series Access Servers

In the following example, how keywords and options are limited according to the physical characteristics of the system is shown:

```
as5300# show environment ?

all      All environmental monitor parameters
last     Last environmental monitor parameters
table    Temperature and voltage ranges
|        Output modifiers
<cr>

as5300# show environment table

%This option not available on this platform
```

Cisco 12000 Series GSR

The following examples are for the Cisco 12000 series GSRs.

The following is sample output from the **show environment** command for a Cisco 12012 router. Slots 0 through 11 are the line cards, slots 16 and 17 are the clock and scheduler cards, slots 18 through 20 are the switch fabric cards, slots 24 through 26 are the power supplies, and slots 28 and 29 are the blowers. An “NA” in the table means that no values were returned. In some cases it is because the equipment is not supported for that environmental parameter (for example, the power supply and blowers in slots 24, 26, 28, and 29 do not have a 3V power supply, so an NA is displayed).

```
Router# show environment

Slot #   3V          5V          MBUS 5V Hot Sensor      Inlet Sensor
         (mv)       (mv)       (mv)      (deg C)      (deg C)
0        3300      4992      5040      42.0         37.0
2        3296      4976      5136      40.0         33.0
4        3280      4992      5120      38.5         31.5
7        3280      4984      5136      42.0         32.0
9        3292      4968      5160      39.5         31.5
11       3288      4992      5152      40.0         30.5
16       3308      NA        5056      42.5         38.0
17       3292      NA        5056      40.5         36.5
18       3304      NA        5176      36.5         35.0
19       3300      NA        5184      37.5         33.5
20       3304      NA        5168      36.5         34.0
24       NA        5536      5120      NA           31.5
26       NA        5544      5128      NA           31.5
28       NA        NA        5128      NA           NA
29       NA        NA        5104      NA           NA

Slot #   48V      AMP_48
         (Volt)   (Amp)
24       46       12
26       46       19

Slot #   Fan 0    Fan 1    Fan 2
         (RPM)    (RPM)    (RPM)
28       2160    2190    2160
29       2130    2190    2070
Router#
```

[Table 82](#) describes the significant fields shown and lists the equipment supported by each environmental parameter. “NA” indicates that the reading could not be obtained, so the command should be again.

Table 82 *show environment Field Descriptions for the Cisco 12000 Series Routers*

Field	Description
Slot #	Slot number of the equipment. On the Cisco 12012 router, slots 0 through 11 are the line cards, slots 16 and 17 are the clock and scheduler cards, slots 18 through 20 are the switch fabric cards, slots 24 through 27 are the power supplies, and slots 28 and 29 are the blowers.
3V (mv)	Measures the 3v power supply on the card. The 3v power supply is on the line cards, GRP card, clock and scheduler cards, and switch fabric cards.
5V (mv)	Measures the 5v power supply on the card. The 5v power supply is on the line cards, GRP card, and power supplies.
MBUS 5V (mv)	Measures the 5v MBus on the card. The 5v MBus is on all equipment.
Hot Sensor (deg C)	Measures the temperature at the hot sensor on the card. The hot sensor is on the line cards, GRP card, clock and scheduler cards, switch fabric cards, and blowers.
Inlet Sensor (deg C)	Measures the current inlet temperature on the card. The inlet sensor is on the line cards, GRP card, clock and scheduler cards, switch fabric cards, and power supplies.
48V (Volt)	Measures the DC power supplies.
AMP_48 (Amp)	Measures the AC power supplies.
Fan 0, Fan 1, Fan 2	Measures the fan speed in rotations per minute.

The following is sample output from the **show environment all** command for the Cisco 12008 router. Slots 0 through 7 are the line cards, slots 16 and 17 are the clock scheduler cards (the clock scheduler cards control the fans), slots 18 through 20 are the switch fabric cards, and slots 24 and 26 are the power supplies. The Cisco 12008 router does not support slots 25, 27, 28, and 29. An “NA” in the table means that no values were returned. In some cases it is because the equipment is not supported for that environmental parameter (for example, the power supplies in slots 24 and 26 do not have a hot sensor, so an NA is displayed).

Router# **show environment all**

```

Slot #   Hot Sensor      Inlet Sensor
         (deg C)         (deg C)
2         31.0           22.0
5         33.5           26.5
16        25.5           21.5
18        22.0           21.0
19        22.5           21.0
24        NA            29.5
26        NA            24.5

Slot #   3V      5V      MBUS 5V
         (mv)    (mv)    (mv)
2        3292    5008    5136
5        3292    5000    5128
16       3272    NA      5128
18       3300    NA      5128
19       3316    NA      5128

Slot #   5V      MBUS 5V 48V      AMP_48
         (mv)    (mv)    (Volt) (Amp)

```

■ **show environment**

```

24      0      5096      3      0
26     5544     5144     47      3

```

Slot # Fan Information

```
16      Voltage 16V Speed slow: Main Fans Ok Power Supply fans Ok
```

Alarm Indicators

No alarms

Slot # Card Specific Leds

```

16      Mbus OK SFCs Failed
18      Mbus OK
19      Mbus OK
24      Input Failed
26      Input Ok

```

The following is sample output from the **show environment table** command for a Cisco 12012 router. The **show environment table** command lists the warning, critical, and shutdown limits on your system and includes the GRP card and line cards (slots 0 to 15), clock and scheduler cards (slots 16 and 17), switch fabric cards (slots 18 to 20), and blowers.

Router# **show environment table**

Hot Sensor Temperature Limits (deg C):

	Warning	Critical	Shutdown
GRP/GLC (Slots 0-15)	40	46	57
CSC (Slots 16-17)	46	51	65
SFC (Slots 18-20)	41	46	60

Inlet Sensor Temperature Limits (deg C):

	Warning	Critical	Shutdown
GRP/GLC (Slots 0-15)	35	40	52
CSC (Slots 16-17)	40	45	59
SFC (Slots 18-20)	37	42	54

3V Ranges (mv):

	Warning		Critical		Shutdown	
	Below	Above	Below	Above	Below	Above
GRP/GLC (Slots 0-15)	3200	3400	3100	3500	3050	3550
CSC (Slots 16-17)	3200	3400	3100	3500	3050	3550
SFC (Slots 18-20)	3200	3400	3100	3500	3050	3550

5V Ranges (mv):

	Warning		Critical		Shutdown	
	Below	Above	Below	Above	Below	Above
GRP/GLC (Slots 0-15)	4850	5150	4750	5250	4680	5320

MBUS_5V Ranges (mv):

	Warning		Critical		Shutdown	
	Below	Above	Below	Above	Below	Above
GRP/GLC (Slots 0-15)	5000	5250	4900	5350	4750	5450
CSC (Slots 16-17)	4820	5150	4720	5250	4750	5450
SFC (Slots 17-20)	5000	5250	4900	5350	4750	5450

Blower Operational Range (RPM):

Top Blower:

	Warning	Critical
	Below	Below
Fan 0	1000	750
Fan 1	1000	750
Fan 2	1000	750

```

Bottom Blower:
                Warning    Critical
                Below      Below
Fan 0           1000       750
Fan 1           1000       750
Fan 2           1000       750
    
```

The following is sample output from the **show environment leds** command for a Cisco 12012 router. The **show environment leds** command lists the status of the MBus LEDs on the clock, scheduler, and the switch fabric cards.

```
Router# show environment leds
```

```

16 leds Mbus OK
18 leds Mbus OK
19 leds Mbus OK
20 leds Mbus OK
    
```

Related Commands

Command	Description
snmp-server enable traps envmon	Controls (enables or disables) environmental monitoring SNMP notifications.
snmp-server host	Specifies how SNMP notifications should be sent (as traps or informs), the version of SNMP to use, the security level of the notifications (for SNMPv3), and the recipient (host) of the notifications.

show gsr

To display hardware information on the Cisco 12000 series Gigabit Switch Routers (GSRs), use the **show gsr** EXEC command.

show gsr [chassis-info [details]]

Syntax Description	chassis-info	(Optional) Displays backplane NVRAM information.
	details	(Optional) In addition to the information displayed, this option includes hexadecimal output of the backplane NVRAM information.

Command Modes	EXEC

Command History	Release	Modification
	11.2 GS	This command was added to support the Cisco 12000 series GSRs.

Usage Guidelines	Use this command to determine the type of hardware installed in your Cisco 12000 series GSR router.

Examples	The following is sample output from the show gsr command for a Cisco 12012 router. This command shows the type and state of the card installed in the slot.

```
Router# show gsr
```

```
Slot 0  type  = Route Processor
        state = IOS Running  MASTER
Slot 7  type  = 1 Port Packet Over SONET OC-12c/STM-4c
        state = Card Powered
Slot 16 type  = Clock Scheduler Card
        state = Card Powered  PRIMARY CLOCK
```

The following is sample output from the **show gsr chassis-info** command for a Cisco 12012 router:

```
Router# show gsr chassis-info
```

```
Backplane NVRAM [version 0x20] Contents -
Chassis: type 12012 Fab Ver: 1
Chassis S/N: ZQ24CS3WT86MGVHL
PCA: 800-3015-1 rev: A0 dev: 257 HW ver: 1.0
Backplane S/N: A109EXPR75FUNYJK
MAC Addr: base 0000.EAB2.34FF block size: 1024
RMA Number: 0x5F-0x2D-0x44 code: 0x01 hist: 0x1A
```

show gt64010 (7200)

To display all GT64010 internal registers and interrupt status on the Cisco 7200 series routers, use the **show gt64010** EXEC command.

show gt64010

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

CommandHistory	Release	Modification
	11.2	This command was introduced.

Usage Guidelines This command displays information about the CPU interface, DRAM/device address space, device parameters, direct memory access (DMA) channels, timers and counters, and protocol control information (PCI) internal registers. The information is generally useful for diagnostic tasks performed by technical support only.

Examples The following is a partial sample output for the **show gt64010** command:

```
Router# show gt64010

GT64010 Channel 0 DMA:
dma_list=0x6088C3EC, dma_ring=0x4B018480, dma_entries=256
dma_free=0x6088CECC, dma_reqt=0x6088CECC, dma_done=0x6088CECC
thread=0x6088CEAC, thread_end=0x6088CEAC
backup_thread=0x0, backup_thread_end=0x0
dma_working=0, dma_complete=6231, post_coalesce_frames=6231
exhausted_dma_entries=0, post_coalesce_callback=6231

GT64010 Register Dump: Registers at 0xB4000000

CPU Interface:
cpu_interface_conf : 0x80030000 (b/s 0x00000380)
addr_decode_err   : 0xFFFFFFFF (b/s 0xFFFFFFFF)
Processor Address Space :
ras10_low         : 0x00000000 (b/s 0x00000000)
ras10_high        : 0x07000000 (b/s 0x00000007)
ras32_low         : 0x08000000 (b/s 0x00000008)
ras32_high        : 0x0F000000 (b/s 0x0000000F)
cs20_low          : 0xD0000000 (b/s 0x000000D0)
cs20_high         : 0x74000000 (b/s 0x00000074)
cs3_boot_low      : 0xF8000000 (b/s 0x000000F8)
cs3_boot_high     : 0x7E000000 (b/s 0x0000007E)
pci_io_low        : 0x00080000 (b/s 0x00000800)
pci_io_high       : 0x00000000 (b/s 0x00000000)
pci_mem_low       : 0x00020000 (b/s 0x00000200)
pci_mem_high      : 0x7F000000 (b/s 0x0000007F)
```

 show gt64010 (7200)

```
internal_spc_decode   : 0xA0000000 (b/s 0x000000A0)

bus_err_low           : 0x00000000 (b/s 0x00000000)
bus_err_high          : 0x00000000 (b/s 0x00000000)
.
.
.
```

show logging

To display the state of system logging (syslog) and the contents of the standard system logging message buffer,, use the **show logging** privileged EXEC command.

show logging [*slot slot-number* | **summary**]

Syntax Description	slot <i>slot-number</i>	(Optional) Displays information in the syslog history table for a specific line card. Slot numbers range from 0 to 11 for the Cisco 12012 router and 0 to 7 for the Cisco 12008 router.
	summary	(Optional) Displays counts of messages by type for each line card.

Command Modes	Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	11.2 GS	The slot and summary keywords were added for the Cisco 12000 family.

Usage Guidelines This command displays the state of syslog error and event logging, including host addresses, and whether console logging is enabled. This command also displays Simple Network Management Protocol (SNMP) configuration parameters and protocol activity.



Note

Within the context of the CLI, “syslog” is an abbreviation for the system message logging process in Cisco IOS software. “Syslog” is also used to identify the messages generated, as in "syslog messages." Technically, the term "syslog" refers only to the process of logging messages to a remote host or hosts, but is commonly used to refer to all Cisco IOS system logging processes.

Examples The following is sample output from the **show logging** command:

```
Router# show logging

Syslog logging: enabled
  Console logging: disabled
  Monitor logging: level debugging, 266 messages logged.
  Trap logging: level informational, 266 messages logged.
  Logging to 192.180.2.238

SNMP logging: disabled, retransmission after 30 seconds
  0 messages logged
Router#
```

[Table 83](#) describes the significant fields shown in the display.

Table 83 *show logging in Field Descriptions*

Field	Description
Syslog logging	When enabled, system logging messages are sent to a UNIX host that acts as a syslog server; that is, syslog messages are saved to the specified server.
Console logging	Minimum level of severity required for a log message to be sent to the console. If disabled, the word “disabled” is displayed.
Monitor logging	Minimum level of severity required for a log message to be sent to a monitor terminal (not the console).
Trap logging	Minimum level of severity required for a log message to be sent to a syslog server.
SNMP logging	Displays whether SNMP logging is enabled, the number of messages logged, and the retransmission interval.

The following is sample output from the **show logging summary** command for the Cisco 12012 router. A number in the column indicates that the syslog contains that many messages for the line card. For example, line card in slot 9 has 1 system message, 4 warning messages, and 47 notification messages.

Router# **show logging summary**

SLOT	EMERG	ALERT	CRIT	ERROR	WARNING	NOTICE	INFO	DEBUG
* 0*	.	.	.	.	.	.	.	.
1								
2				1	4	45		
3								
4				5	4	54		
5								
6								
7				17	4	48		
8								
9				1	4	47		
10								
11				12	4	65		

Router#

[Table 84](#) describes the logging level fields shown in the display.

Table 84 *show logging summary Field Descriptions*

Field	Description
SLOT	Indicates the slot number of the line card. An asterisk next to the slot number indicates the GRP card whose error message counts are not displayed. For information on the GRP card, use the show logging command.
EMERG	Indicates that the system is unusable.
ALERT	Indicates that immediate action is needed.
CRIT	Indicates a critical condition.
ERROR	Indicates an error condition.
WARNING	Indicates a warning condition.

Table 84 *show logging summary Field Descriptions (continued) (continued)*

Field	Description
NOTIFICE	Indicates a normal but significant condition.
INFO	Indicates an informational message only.
DEBUG	Indicates a debugging message.

Related Commands	Command	Description
	clear logging	Clears messages from the logging buffer.
	logging history size	Changes the number of syslog messages stored in the history table of the router.
	logging linecard	Logs messages to an internal buffer on a line card and limits the logging messages displayed on terminal lines other than the console line to messages with a level at or above level.
	show logging history	Displays information about the configuration of the syslog history table.

show logging history

To display information about the state of the syslog history table, use the **show logging history** privileged EXEC command.

show logging history

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

CommandHistory	Release	Modification
	10.0	This command was introduced.

Usage Guidelines This command displays information about the syslog history table, such as the table size, the status of messages, and text of messages stored in the table. Messages stored in the table are governed by the **logging history** global configuration command.

Examples The following example shows sample output from the **show logging history** command. In this example, notifications of severity level 5 (notifications) through severity level 0 (emergencies) are configured to be written to the logging history table.

```
Router# show logging history

Syslog History Table: 1 maximum table entries,
saving level notifications or higher
0 messages ignored, 0 dropped, 15 table entries flushed,
SNMP notifications not enabled
  entry number 16: SYS-5-CONFIG_I
  Configured from console by console
  timestamp: 1110

Router#
```

[Table 85](#) describes the significant fields shown in the output.

Table 85 *show logging history Field Descriptions*

Field	Description
maximum table entry	Number of messages that can be stored in the history table. Set with the logging history size command.
saving level notifications <x> or higher	Level of messages that are stored in the history table and sent to the SNMP server (if SNMP notification is enabled). The severity level can be configured with the logging history command.

Table 85 *show logging history Field Descriptions (continued)*

Field	Description
messages ignored	Number of messages not stored in the history table because the severity level is greater than that specified with the logging history command.
dropped	Number of messages that could not be processed due to lack of system resources. Dropped messages do not appear in the history table and are not sent to the SNMP server.
table entries flushed	Number of messages that have been removed from the history table to make room for newer messages.
SNMP notifications	Whether syslog traps of the appropriate level are sent to the SNMP server. The sending of syslog traps are enabled or disabled through the snmp-server enable traps syslog command.
entry number:	Number of the message entry in the history table. In the example above, the message "SYS-5-CONFIG_I Configured from console by console" indicates a syslog message consisting of the facility name (SYS), which indicates where the message came from, the severity level (5) of the message, the message name (CONFIG_I), and the message text.
timestamp	Time, based on the up time of the router, that the message was generated.

Related Commands

Command	Description
clear logging	Clears messages from the logging buffer.
logging history	Limits syslog messages sent to the router's history table to a specified severity level.
logging history size	Changes the number of syslog messages that can be stored in the history table.
logging linecard	Logs messages to an internal buffer on a line card. This command limits the logging messages displayed on terminal lines other than the console line to messages with a level at or above level.
snmp-server enable traps	The [no] snmp-server enable traps syslog form of this command controls (enables or disables) the sending of system-logging messages to a network management station.

show memory

To display memory utilization statistics, use the **show memory** command in User or Privileged EXEC mode.

show memory [*start-address* [*end-address*]] [**processor** | **io** | **multibus**] [**free**] **summary**]

Syntax Description

<i>start-address</i> [<i>end-address</i>]	(Optional) Display memory utilization statistics starting at the specified memory block address and, optionally, ending at the specified memory block address.
processor	(Optional) Displays only processor (fast) memory.
io	(Optional) Displays only Input/Output memory.
multibus	(Optional) Displays only multibus memory. (Limited platform support. Originally supported on the Cisco 7000 series.)
free	(Optional) Displays only free memory statistics for the specified memory type.
summary	(Optional) Summarizes the statistics by grouping them together by Allocating Process Call (Alloc PC).

Defaults

If a memory address is not specified, statistics for all memory addresses are displayed.

If a memory type (**processor** | **io** | **multibus**) is not specified, statistics for all memory types present are displayed.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced, using the following syntax: <pre>show memory { <start_address> [end_address] {[processor io sram multibus] [free]} }</pre>

Usage Guidelines

This command prints detailed memory information to the screen. This information is intended for use by Cisco technical support personnel.



Tip

This command can generate a large amount of output. Use the Break key sequence (often Crtl+z) at the --More-- prompt to return to the CLI prompt.

This command first displays how much memory is being used on the router by memory pool (processor, shared I/O memory, and, potentially, SRAM). Then this command displays, for each memory pool, a complete list of all blocks.

Examples

The following is sample output from the **show memory** command:

Router# **show memory**

```

      Head   Total(b)   Used(b)   Free(b)   Lowest(b)   Largest(b)
Processor   B0EE38     5181896     2210036     2971860     2692456     2845368

      Processor memory
Address  Bytes Prev.   Next   Ref  PrevF  NextF  Alloc PC  What
B0EE38   1056 0       B0F280  1          18F132  List Elements
B0F280   2656 B0EE38   B0FD08  1          18F132  List Headers
B0FD08   2520 B0F280   B10708  1         141384  TTY data
B10708   2000 B0FD08   B10F00  1         14353C  TTY Input Buf
B10F00    512 B10708   B11128  1         14356C  TTY Output Buf
B11128   2000 B10F00   B11920  1         1A110E  Interrupt Stack
B11920    44 B11128   B11974  1         970DE8  *Init*
B11974   1056 B11920   B11DBC  1         18F132  messages
B11DBC    84 B11974   B11E38  1         19ABCE  Watched Boolean
B11E38    84 B11DBC   B11EB4  1         19ABCE  Watched Boolean
B11EB4    84 B11E38   B11F30  1         19ABCE  Watched Boolean
B11F30    84 B11EB4   B11FAC  1         19ABCE  Watched Boolean
Router#
```

The following is sample output from the **show memory free** command:

Router# **show memory free**

```

      Head   Total(b)   Used(b)   Free(b)   Lowest(b)   Largest(b)
Processor   B0EE38     5181896     2210076     2971820     2692456     2845368

      Processor memory
Address  Bytes Prev.   Next   Ref  PrevF  NextF  Alloc PC  What
      24   Free list 1
CEB844   32 CEB7A4   CEB88C  0  0       0       96B894  SSE Manager
      52   Free list 2
      72   Free list 3
      76   Free list 4
      80   Free list 5
D35ED4   80 D35E30   D35F4C  0  0       D27AE8  96B894  SSE Manager
D27AE8   80 D27A48   D27B60  0  D35ED4  0       22585E  SSE Manager
      88   Free list 6
      100  Free list 7
D0A8F4   100 D0A8B0   D0A980  0  0       0       2258DA  SSE Manager
      104  Free list 8
B59EF0   108 B59E8C   B59F84  0  0       0       2258DA  (fragment)
```

The display of **show memory free** contains the same types of information as the **show memory** display, except that only free memory is displayed, and the information is displayed in order for each free list.

The first section of the display includes summary statistics about the activities of the system memory allocator. [Table 86](#) describes the significant fields shown in the first section of the display.

Table 86 *show memory Field Descriptions—First Section*

Field	Description
Head	Hexadecimal address of the head of the memory allocation chain.
Total(b)	Sum of used bytes plus free bytes.
Used(b)	Amount of memory in use.
Free(b)	Amount of memory not in use.

Table 86 *show memory Field Descriptions—First Section (continued)*

Field	Description
Lowest(b)	Smallest amount of free memory since last boot.
Largest(b)	Size of largest available free block.

The second section of the display is a block-by-block listing of memory use. [Table 87](#) describes the significant fields shown in the second section of the display.

Table 87 *Characteristics of Each Block of Memory—Second Section*

Field	Description
Address	Hexadecimal address of block.
Bytes	Size of block (in bytes).
Prev.	Address of previous block (should match Address on previous line).
Next	Address of next block (should match address on next line).
Ref	Reference count for that memory block, indicating how many different processes are using that block of memory.
PrevF	Address of previous free block (if free).
NextF	Address of next free block (if free).
Alloc PC	“Allocating Process Call” — Address of the system call that allocated the block.
What	Name of process that owns the block, or “(fragment)” if the block is a fragment, or “(coalesced)” if the block was coalesced from adjacent free blocks.

The **show memory io** command displays the free I/O memory blocks.

The following is sample output from the **show memory io** command:

```
Router# show memory io
```

```

Address  Bytes Prev.  Next  Ref  PrevF  NextF  Alloc PC  What
6132DA0  59264 6132664 6141520 0    0      600DDEC 3FCF0  *Packet Buffer*
600DDEC    500 600DA4C 600DFE0 0    6132DA0 600FE68 0
600FE68    376 600FAC8 600FFE0 0    600DDEC 6011D54 0
6011D54    652 60119B4 6011FEO 0    600FE68 6013D54 0
614FCA0    832 614F564 614FFE0 0    601FD54 6177640 0
6177640 2657056 6172E90 0      0    614FCA0 0      0
Total: 2723244
```

The **show memory summary** command displays a summary of all memory pools and memory usage per Alloc PC (address of the system call that allocated the block).

The following is partial sample output from the **show memory summary** command.

“Size” is the number of bytes in each block. “Bytes” is the total size for all blocks (“Bytes” equals the “Size” value multiplied by the “Blocks” value). For a description of the other fields, see [Table 20](#) and [Table 21](#).

```
Router# show memory summary
```

```

          Head  Total(b)  Used(b)  Free(b)  Lowest(b)  Largest(b)
Processor 8404A580 64102816 10509276 53593540 52101448 51007568
I/O      7C53000 3854336 2138224 1716112 1708432 1716064
```

```

Processor memory
Alloc PC      Size      Blocks      Bytes      What
0x2AB2        192         1          192      IDB: Serial Info
0x70EC         92         2          184      Init
0xC916        128        50         6400     RIF Cache
0x76ADE       4500         1          4500     XDI data
0x76E84       4464         1          4464     XDI data
0x76EAC        692         1           692     XDI data
0x77764        408         1           408     Init
0x77776        116         1           116     Init
0x777A2        408         1           408     Init
0x777B2        116         1           116     Init
0xA4600        24          3           72     List
0xD9B5C        52          1           52     SSE Manager
.....
0x0            0          3413      2072576   Pool Summary
0x0            0           28      2971680   Pool Summary (Free Blocks)
0x0           40          3441      137640    Pool Summary (All Block Headers)
0x0            0          3413      2072576   Memory Summary
0x0            0           28      2971680   Memory Summary (Free Blocks)

```

Related Commands

Command	Description
show processes memory	Displays a summary of how much memory is being allocated and freed by each process on the router.

show memory ecc

To display single-bit Error Code Correction (ECC) error logset data, use the **show memory ecc** command in privileged EXEC mode.

show memory ecc

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	11.1(30)CC	This command was introduced in Cisco IOS Release 11.1(30)CC.
	12.0(4)XE	This command was integrated into Cisco IOS Release 12.0(4)XE.
	12.0(6)S	This command was integrated into Cisco IOS Release 12.0(6)S.
	12.1(13)	This command was integrated into Cisco IOS Release 12.1(13).

Usage Guidelines Use this command to determine if the router has experienced single-bit parity errors.

Examples The following is sample output from the **show memory ecc** command from a 12000-series router running Cisco IOS Release 12.0(23)S:

```
Router# show memory ecc
ECC Single Bit error log
-----
Single Bit error detected and corrected at 0x574F3640
- Occured 1 time(s)
- Whether a scrub was attempted at this address: Yes
- Syndrome of the last error at this address: 0xE9
- Error detected on a read-modify-write cycle ? No
- Address region classification: Unknown
- Address media classification : Read/Write Single Bit error detected and corrected at
0x56AB3760
- Occured 1 time(s)
- Whether a scrub was attempted at this address: Yes
- Syndrome of the last error at this address: 0x68
- Error detected on a read-modify-write cycle ? No
- Address region classification: Unknown
- Address media classification : Read/Write

Total Single Bit error(s) thus far: 2
```


Table 86 describes the significant fields shown in the first section of the display.

Table 88 *show memory ecc Field Descriptions*

Field	Description
Occured <i>n</i> time(s)	Number of single-bit errors that has occurred.
Whether a scrub was attempted at this address:	Indicates whether a scrub has been performed.
Syndrome of the last error at this address:	Describes the syndrome of last error.
Error detected on a read-modify-write cycle ?	Indicates whether an error has occurred.
Address region classification:	Describes the region of the error.
Address media classification :	Describes the media of the error and correction.

Related Commands

Command	Description
show memory	Displays statistics about memory, including memory-free pool statistics.

show memory fast

To display fast memory details for the router, use the **show memory fast** command.

show memory fast [**allocating-process** [totals] | **dead** [totals] | **free** [totals]]

Syntax Description

allocating-process	(Optional) Include allocating process names with the standard output.
dead	(Optional) Display only memory owned by dead processes.
free	(Optional) Display only memory not allocated to a process.
totals	(Optional) Summarizes the statistics for allocating processes, dead memory, or free memory.

Command Modes

Exec

Command History

Release	Modification
12.1	This command was introduced in a release prior to 12.1.

Usage Guidelines

The **show memory fast** command displays the statistics for the fast memory. “Fast memory” is another name for “processor memory,” and is also known as “cache memory.” Cache memory is called fast memory because the processor can generally access the local cache (traditionally stored on SRAM positioned close to the processor) much more quickly than main (primary) memory.

Cache = fast memory closest to processor = “processor memory”

Primary Memory = the main memory below cache.



Note

The **show memory fast** command is a command alias for the **show memory processor** command. These commands will generate the same output on most platforms.

Examples

The following example shows sample output from the **show memory fast** and the **show memory processor** commands:

```
Router>show memory fast
```

```
Processor memory
```

```

Address      Bytes      Prev      Next Ref      PrevF      NextF Alloc PC  what
8404A580 0001493284 00000000 841B6ECC 000 0      84BADF88 815219D8 (coalesced)
841B6ECC 0000020004 8404A580 841BBD18 001 ----- ----- 815DB094 Managed Chunk Queue
Elements
841BBD18 0000001504 841B6ECC 841BC320 001 ----- ----- 8159EAC4 List Elements
841BC320 0000005004 841BBD18 841BD6D4 001 ----- ----- 8159EB04 List Headers
841BD6D4 0000000048 841BC320 841BD72C 001 ----- ----- 81F2A614 *Init*
841BD72C 0000001504 841BD6D4 841BDD34 001 ----- ----- 815A9514 messages
841BDD34 0000001504 841BD72C 841BE33C 001 ----- ----- 815A9540 Watched messages
841BE33C 0000001504 841BDD34 841BE944 001 ----- ----- 815A95E4 Watched Semaphore
```

```

841BE944 0000000504 841BE33C 841BEB64 001 ----- 815A9630 Watched Message
Queue
841BEB64 0000001504 841BE944 841BF16C 001 ----- 815A9658 Watcher Message
Queue
841BF16C 0000001036 841BEB64 841BF5A0 001 ----- 815A2B24 Process Array
-- More --
<Ctrl+z>

Router>show memory processor

Processor memory

Address      Bytes      Prev      Next Ref      PrevF      NextF Alloc PC  what
8404A580 0001493284 00000000 841B6ECC 000 0      84BADF88 815219D8 (coalesced)
841B6ECC 0000020004 8404A580 841BBD18 001 ----- 815DB094 Managed Chunk Queue
Elements
841BBD18 0000001504 841B6ECC 841BC320 001 ----- 8159EAC4 List Elements
841BC320 0000005004 841BBD18 841BD6D4 001 ----- 8159EB04 List Headers
841BD6D4 0000000048 841BC320 841BD72C 001 ----- 81F2A614 *Init*
841BD72C 0000001504 841BD6D4 841BDD34 001 ----- 815A9514 messages
841BDD34 0000001504 841BD72C 841BE33C 001 ----- 815A9540 Watched messages
841BE33C 0000001504 841BDD34 841BE944 001 ----- 815A95E4 Watched Semaphore
841BE944 0000000504 841BE33C 841BEB64 001 ----- 815A9630 Watched Message
Queue
841BEB64 0000001504 841BE944 841BF16C 001 ----- 815A9658 Watcher Message
Queue
841BF16C 0000001036 841BEB64 841BF5A0 001 ----- 815A2B24 Process Array
-- More --
<Ctrl+z>

Router>
    
```

The following example shows sample output from the **show memory fast allocating-process** command, followed by sample output from the **show memory fast allocating-process totals** command:

```

Router#show memory fast allocating-process

Processor memory

Address      Bytes      Prev      Next Ref      Alloc Proc      Alloc PC  What
8404A580 0001493284 00000000 841B6ECC 000      815219D8 (coalesced)
841B6ECC 0000020004 8404A580 841BBD18 001 *Init*      815DB094 Managed Chunk Queue
Elements
841BBD18 0000001504 841B6ECC 841BC320 001 *Init*      8159EAC4 List Elements
841BC320 0000005004 841BBD18 841BD6D4 001 *Init*      8159EB04 List Headers
841BD6D4 0000000048 841BC320 841BD72C 001 *Init*      81F2A614 *Init*
841BD72C 0000001504 841BD6D4 841BDD34 001 *Init*      815A9514 messages
841BDD34 0000001504 841BD72C 841BE33C 001 *Init*      815A9540 Watched messages
841BE33C 0000001504 841BDD34 841BE944 001 *Init*      815A95E4 Watched Semaphore
841BE944 0000000504 841BE33C 841BEB64 001 *Init*      815A9630 Watched Message Queue
841BEB64 0000001504 841BE944 841BF16C 001 *Init*      815A9658 Watcher Message Queue
841BF16C 0000001036 841BEB64 841BF5A0 001 *Init*      815A2B24 Process Array
--More--
<Ctrl+z>

c2600-1#show memory fast allocating-process totals

Allocator PC Summary for: Processor

PC      Total      Count      Name
0x815C085C 1194600      150      Process Stack
0x815B6C28 948680      5      pak subblock chunk
    
```

■ **show memory fast**

```

0x819F1DE4      524640      8  BGP (0) update
0x815C4FD4      393480      6  MallocLite
0x815B5FDC      351528     30  TW Buckets
0x819F14DC      327900      5  connected
0x81A1E838      327900      5  IPv4 Unicast net-chunk(8)
0x8153DFB8      248136    294  *Packet Header*
0x82142438      133192      4  CEF: 16 path chunk pool
0x82151E0C      131116      1  Init
0x819F1C8C      118480      4  BGP (0) attr
0x815A4858      100048    148  Process
0x8083DA44       97248     17

```

```

--More--
<Ctrl+z>

```

The following example shows sample output from the **show memory fast dead** command:

```
Router#show memory fast dead
```

```
Processor memory
```

```

Address      Bytes      Prev      Next Ref      PrevF      NextF Alloc PC  what
8498FC20 0000000028 8498FB90 8498FC64 001  -----  ----- 81472B24 AAA MI SG NAME
-----

```

```
68
```

```
Router#show memory fast dead totals
```

```
Dead Proc Summary for: Processor
```

```

PC          Total      Count      Name
0x81472B24      68          1  AAA MI SG NAME

```

```
Router#
```

show memory scan

To monitor the number and type of parity (memory) errors on your system, use the **show memory scan** command in Exec mode.

show memory scan

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	12.0(4)XE	This command was introduced for the Cisco 7500 series.
	12.0(7)T	This command was implemented in Cisco IOS Release 12.0T for the Cisco 7500 series.
	12.0(6)S	This command was implemented in Cisco IOS Release 12.0S for the Cisco 7500 series.
	12.1(1)E	This command was implemented in Cisco IOS Release 12.1E for the Cisco 7500 series.

Usage Guidelines For the **show memory scan** command to function, the memory scan feature must be enabled on the RSP using the **memory scan** global configuraiton mode command.

Examples The following example shows a result with no memory errors:

```
Router# show memory scan
```

```
Memory scan is on.
No parity error has been detected.
```

If errors are detected in the system, the **show memory scan** command generates an error report. In the following example, memory scan detected a parity error:

```
Router# show memory scan
```

```
Memory scan is on.
Total Parity Errors 1.
Address   BlockPtr  BlckSize  Disposit  Region Timestamp
6115ABCD  60D5D090  9517A4    Scrubed   Local 16:57:09 UTC Thu Mar 18
```

Table 89 describes the fields contained in the error report.

Table 89 *show memory scan Field Descriptions*

Field	Description
Address	The byte address where the error occurred.
BlockPtr	The pointer to the block that contains the error.
BlkSize	The size of the memory block
Disposit	The action taken in response to the error: - BlockInUse—An error was detected in a busy block. - InFieldPrev—An error was detected in the previous field of a block header. - InHeader—An error was detected in a block header. - Linked—A block was linked to a bad list. - MScrubed—The same address was “scrubbed” more than once, and the block was linked to a bad list. - MultiError—Multiple errors have been found in one block. - NoBlkHdr—No block header was found. - NotYet—An error was found; no action has been taken at this time. - Scrubed—An error was “scrubbed.” - SplitLinked—A block was split, and only a small portion was linked to a bad list.
Region	The memory region in which the error was found: - IBSS—image BSS - IData—imagedata - IText—imagetext - local—heap
Timestamp	The time the error occurred.

Related Commands

Command	Description
memory scan	Controls (enables or disables) the memory scan feature.

show pci

To display information about the peripheral component interconnect (PCI) hardware registers or bridge registers for the Cisco 7200 series routers, use the **show pci** EXEC command.

show pci {**hardware** | **bridge** [*register*]}

Syntax Description	hardware	Displays PCI hardware registers.
	bridge	Displays PCI bridge registers.
	<i>register</i>	(Optional) Number of a specific bridge register in the range from 0 to 7. If not specified, this command displays information about all registers.

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines The output of this command is generally useful for diagnostic tasks performed by technical support only.



Note

The **show pci hardware** EXEC command displays a substantial amount of information.

Examples The following is sample output for the PCI bridge register 1 on a Cisco 7200 series router:

```
Router# show pci bridge 1

Bridge 4, Port Adaptor 1, Handle=1
DEC21050 bridge chip, config=0x0
(0x00): cfid = 0x00011011
(0x04): cfcs = 0x02800147
(0x08): cfccid = 0x06040002
(0x0C): cfpmlt = 0x00010010

(0x18): cfsmlt = 0x18050504
(0x1C): cfsis = 0x22805050
(0x20): cfmla = 0x48F04880
(0x24): cfpmla = 0x00004880

(0x3C): cfbc = 0x00000000
(0x40): cfseed = 0x00100000
(0x44): cfstwt = 0x00008020
```

The following is partial sample output for the PCI hardware register, which also includes information on all the PCI bridge registers on a Cisco 7200 series router:

```
Router# show pci hardware
```

■ show pci

```

GT64010 External PCI Configuration registers:
Vendor / Device ID   : 0xAB114601 (b/s 0x014611AB)
Status / Command    : 0x17018002 (b/s 0x02800117)
Class / Revision     : 0x00000006 (b/s 0x06000000)
Latency              : 0x0F000000 (b/s 0x0000000F)
RAS[1:0] Base        : 0x00000000 (b/s 0x00000000)
RAS[3:2] Base        : 0x00000001 (b/s 0x01000000)
CS[2:0] Base         : 0x00000000 (b/s 0x00000000)
CS[3] Base           : 0x00000000 (b/s 0x00000000)
Mem Map Base         : 0x00000014 (b/s 0x14000000)
IO Map Base          : 0x01000014 (b/s 0x14000001)
Int Pin / Line       : 0x00010000 (b/s 0x00000100)

```

Bridge 0, Downstream MB0 to MB1, Handle=0

DEC21050 bridge chip, config=0x0

(0x00): cfid = 0x00011011

(0x04): cfcs = 0x02800143

(0x08): cfccid = 0x06040002

(0x0C): cfpmlt = 0x00011810

(0x18): cfsmlt = 0x18000100

(0x1C): cfsis = 0x02809050

(0x20): cfmla = 0x4AF04880

(0x24): cfpmla = 0x4BF04B00

(0x3C): cfbc = 0x00000000

(0x40): cfseed = 0x00100000

(0x44): cfstwt = 0x00008020

.

.

.

show pci hardware

To display information about the Host-PCI bridge, use the **show pci hardware** EXEC command.

show pci hardware

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

CommandHistory	Release	Modification
	11.2	This command was introduced.

Usage Guidelines The output of this command is generally useful for diagnostic tasks performed by technical support only:

```
router# show pci hardware
```

```
hardware PCI hardware registers
```

Each device on the PCI bus is assigned a PCI device number. For the C2600, device numbers are as follows:

Device	Device number
0	First LAN device
1	Second LAN device
2	AIM device (if present)
3	Not presently used
4	Port module - first PCI device
5	Port module - second PCI device
6	Port module - third PCI device
7	Port module - fourth PCI device
8-14	Not presently used
15	Xilinx PCI bridge

Examples The following is partial sample output for the PCI hardware register, which also includes information on all the PCI bridge registers. [Table 90](#) describes the significant fields shown in the display.

```
router# show pci hardware
```

```
XILINX Host-PCI Bridge Registers:
Vendor / Device ID: 0x401310EE
Status / Command: 0x040001C6
PCI Slave Base Reg 0: 0x00000000
PCI Slave Base Reg 1: 0x04000000
```

Table 90 *show pci hardware Field Descriptions*

Field	Description
Device/Vendor ID	Identifies the PCI vendor and device. The value 0x401310EE identifies the device as the Xilinx-based Host-PCI bridge for the Cisco 2600 router.
Status/Command	Provides status of the Host-PCI bridge. Refer to the PCI Specification for more information.
PCI Slave Base Reg 0	The base address of PCI Target Region 0 for the Host-PCI bridge. This region is used for Big-Endian transfers between PCI devices and memory.
PCI Slave Base Reg 1	The base address of PCI Target Region 1 for the Host-PCI bridge. This region is used for Little-Endian transfers between PCI devices and memory.

show processes

To display information about the active processes, use the **show processes** command in EXEC mode.

show processes [history]

Syntax Description	history (Optional) Displays the process history in an ordered format.

Command Modes	Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(2)T	The history keyword was added.

Examples The following is sample output from the **show processes** command:

Router# **show processes**

```
CPU utilization for five seconds: 21%/0%; one minute: 2%; five minutes: 2%
PID QTy      PC Runtime (ms)  Invoked  uSecs   Stacks   TTY   Process
  1 Mwe  2FEA4E          1808      464    3896   1796/3000  0   IP-EIGRP Router
  2 Lst  11682     10236      109   93908   1828/2000  0   Check heaps
  3 Mst  3AE9C           0      280     0    1768/2000  0   Timers
  4 Lwe  74AD2           0       12     0    1492/2000  0   ARP Input
  5.ME  912E4           0        2     0    1892/2000  0   IPC Zone Manager
  6.ME  91264           0        1     0    1936/2000  0   IPC Realm Manager
  7.ME  91066           0       30     0    1784/2000  0   IPC Seat Manager
  8.ME  133368          0        1     0    1928/2000  0   CXBus hot stall
  9.ME  1462EE          0        1     0    1940/2000  0   Microcode load
 10 Msi 127538           4       76    52    1608/2000  0   Env Mon
 11.ME 160CF4           0        1     0    1932/2000  0   MIP Mailbox
 12 Mwe 125D7C           4      280    14    1588/2000  0   SMT input
 13 Lwe AFD0E           0        1     0    1772/2000  0   Probe Input
 14 Mwe AF662           0        1     0    1784/2000  0   RARP Input
 15 Hwe A1F9A        228     549   415    3240/4000  0   IP Input
 16 Msa C86A0           0      114     0    1864/2000  0   TCP Timer
 17 Lwe CA700           0        1     0    1756/2000  0   TCP Protocols
 18.ME CCE7C           0        1     0    1940/2000  0   TCP Listener
 19 Mwe AC49E           0        1     0    1592/2000  0   BOOTP Server
 20 Mwe 10CD84        24       77   311    1652/2000  0   CDP Protocol
 21 Mwe 27BF82           0        2     0    1776/2000  0   ATMSIG Input
```

The following is sample output from the **show processes history** command:

Router# **show process history**

```
PID Exectime(ms) Caller PC Process Name
  3          12 0x0      Exec
 16           0 0x603F4DEC GraphIt
 21           0 0x603CFEF4 TTY Background
 22           0 0x6042FD7C Per-Second Jobs
 67           0 0x6015CD38 SMT input
 39           0 0x60178804 FBM Timer
```

■ show processes

```

16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
67          0 0x6015CD38 SMT input
39          0 0x60178804 FBM Timer
24          0 0x60425070 Compute load avgs
11          0 0x605210A8 ARP Input
69          0 0x605FDAF4 DHCPD Database
69          0 0x605FD568 DHCPD Database
51          0 0x60670B3C IP Cache Ager
69          0 0x605FD568 DHCPD Database
36          0 0x606E96DC SSS Test Client
69          0 0x605FD568 DHCPD Database
--More--
PID Exectime(ms) Caller PC Process Name
16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
34          0 0x60679D74 CDP Protocol
19          0 0x6041FBA4 Net Background
36          0 0x606E97AC SSS Test Client
12          0 0x60722A40 HC Counter Timers
69          0 0x605FD568 DHCPD Database
44          0 0x6031AD14 Adj Manager
65          4 0x60BC5BE0 SAA Event Processor
25          8 0x6042FD7C Per-minute Jobs
16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
67          0 0x6015CD38 SMT input
39          0 0x60178804 FBM Timer
2          0 0x60496768 Load Meter
16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
16          0 0x603F4DEC GraphIt
21          0 0x603CFEF4 TTY Background
22          0 0x6042FD7C Per-Second Jobs
--More--
. . .

```

Table 91 describes the significant fields shown in the displays.

Table 91 *show processes Field Descriptions*

Field	Description
CPU utilization for five seconds	CPU utilization for the last 5 seconds. The second number indicates the percent of CPU time spent at the interrupt level.
one minute	CPU utilization for the last minute.
five minutes	CPU utilization for the last 5 minutes.
PID	Process ID.
Q	Process queue priority. Possible values: C (critical), H (high), M (medium), L (low).

Table 91 *show processes Field Descriptions (continued)*

Field	Description
Ty	Scheduler test. Possible values: * (currently running), E (waiting for an event), S (ready to run, voluntarily relinquished processor), rd (ready to run, wakeup conditions have occurred), we (waiting for an event), sa (sleeping until an absolute time), si (sleeping for a time interval), sp (sleeping for a time interval (alternate call), st (sleeping until a timer expires), hg (hung; the process will never execute again), xx (dead: the process has terminated, but has not yet been deleted.).
PC	Current program counter.
Runtime (ms)	CPU time the process has used (in milliseconds).
Invoked	Number of times the process has been invoked.
uSecs	Microseconds of CPU time for each process invocation.
Stacks	Low water mark/Total stack space available (in bytes).
TTY	Terminal that controls the process.
Process	Name of the process.
5Sec	CPU utilization by task in the last 5 seconds.
1Min	CPU utilization by task in the last minute.
5Min	CPU utilization by task in the last 5 minutes.



Note

Because the network server has a 4-millisecond clock resolution, run times are considered reliable only after a large number of invocations or a reasonable, measured run time.

For a list of process descriptions, see http://www.cisco.com/warp/public/63/showproc_cpu.html.

Related Commands

Command	Description
show processes memory	Displays amount of system memory used per system process.

show processes cpu

To display CPU utilization information about the active processes in a device, use the **show processes cpu** command in privileged EXEC mode.

show processes cpu [history | sorted]

Syntax Description

history	(Optional) Displays CPU history in a graph format.
sorted	(Optional) Displays CPU utilization sorted by percentage.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0	This command was introduced.
12.2(2)T	The history keyword was added.
12.3(8)T	This command was enhanced to display Address Resolution Protocol (ARP) output.

Usage Guidelines

When you use the optional **history** keyword, output shows (in ASCII graphical form) the total CPU usage on the device over a period of time. Time periods are one minute, one hour, and 72 hours, displayed in increments of one second, one minute, and one hour, respectively. Maximum usage is measured and recorded every second; average usage is calculated on periods of more than one second.

Consistently high CPU utilization over an extended period of time indicates a problem and using the **show processes cpu** command is useful for troubleshooting. Also, you can use the output of this command in the Cisco [Output Interpreter](#) tool to display potential issues and fixes. Output Interpreter is available to registered users of Cisco.com who are logged in and have Java Script enabled.

For a list of system processes, go to http://www.cisco.com/warp/public/63/showproc_cpu.html.

Examples

The following is sample output from the **show processes cpu** command without keywords:

Router# **show processes cpu**

```
CPU utilization for five seconds: 5%/2%; one minute: 3%; five minutes: 2%
  PID  Runtime (ms)   Invoked  uSecs   5Sec   1Min   5Min   TTY   Process
    1         1736        58    29931     0%     0%     0%    0   Check heaps
    2          68       585     116    1.00%   1.00%     0%    0   IP Input
    3           0      744       0     0%     0%     0%    0   TCP Timer
    4           0         2       0     0%     0%     0%    0   TCP Protocols
    5           0         1       0     0%     0%     0%    0   BOOTP Server
    6          16      130     123     0%     0%     0%    0   ARP Input
    7           0         1       0     0%     0%     0%    0   Probe Input
    8           0         7       0     0%     0%     0%    0   MOP Protocols
    9           0         2       0     0%     0%     0%    0   Timers
   10        692         64    10812     0%     0%     0%    0   Net Background
   11           0         5       0     0%     0%     0%    0   Logger
   12           0        38       0     0%     0%     0%    0   BGP Open
```

13	0	1	0	0%	0%	0%	0	Net Input
14	540	3466	155	0%	0%	0%	0	TTY Background
15	0	1	0	0%	0%	0%	0	BGP I/O
16	5100	1367	3730	0%	0%	0%	0	IGRP Router
17	88	4232	20	0.20%	1.00%	0%	0	BGP Router
18	152	14650	10	0%	0%	0%	0	BGP Scanner
19	224	99	2262	0%	0%	1.00%	0	Exec

The following is sample output of the one-hour portion of the output. The Y-axis of the graph is the CPU utilization. The X-axis of the graph is the increment within the time period displayed in the graph. This example shows the individual minutes during the previous hour. The most recent measurement is on the left of the X-axis.

router# **show processes cpu history**

!--- One minute output omitted

```

6665776865756676676666667667677676766666766767767666566667
6378016198993513709771991443732358689932740858269643922613
100
90
80      *  *
70  * *  * * * * *  * *  * * * * *  * *  * * * * *  * *
60  #####
50  #####
40  #####
30  #####
20  #####
10  #####
  0...5...1...1...2...2...3...3...4...4...5...5...
    0    5    0    5    0    5    0    5    0    5
      CPU% per minute (last 60 minutes)
      * = maximum CPU% # = average CPU%

```

!--- 72-hour output omitted

The top two rows, read vertically, display the highest percentage of CPU utilization recorded during the time increment. In this example, the CPU utilization for the last minute recorded is 66 percent. The device may have reached 66 percent only once during that minute, or it may have reached 66 percent multiple times. The device records only the peak reached during the time increment and the average over the course of that increment.

The following is sample output from the **show processes cpu** command that shows an ARP probe process:

Router# **show processes cpu | include ARP**

17	38140	389690	97	0.00%	0.00%	0.00%	0	ARP Input
36	0	1	0	0.00%	0.00%	0.00%	0	IP ARP Probe
40	0	1	0	0.00%	0.00%	0.00%	0	ATM ARP INPUT
80	0	1	0	0.00%	0.00%	0.00%	0	RARP Input
114	0	1	0	0.00%	0.00%	0.00%	0	FR ARP

Table 92 describes the fields shown in the output.

■ `show processes cpu`

Table 92 *show processes cpu Field Descriptions*

Field	Description
CPU utilization for five seconds	CPU utilization for the last 5 seconds and the percent of CPU time spent at the interrupt level.
one minute	CPU utilization for the last minute and the percent of CPU time spent at the interrupt level.
five minutes	CPU utilization for the last 5 minutes and the percent of CPU time spent at the interrupt level.
PID	Process ID.
Runtime (ms)	CPU time the process has used (in milliseconds).
Invoked	Number of times the process has been invoked.
uSecs	Microseconds of CPU time for each process invocation.
5Sec	CPU utilization by task in the last 5 seconds.
1Min	CPU utilization by task in the last minute.
5Min	CPU utilization by task in the last 5 minutes.
TTY	Terminal that controls the process.
Process	Name of the process.



Note

Because platforms have a 4- to 8-millisecond clock resolution, run times are considered reliable only after several invocations or a reasonable, measured run time.

Related Commands

Command	Description
<code>show processes memory</code>	Displays the amount of system memory used per system process.

show processes memory

To show memory used, use the **show processes memory** command in EXEC mode.

show processes memory [*pid* | *sorted*]

Syntax Description	<i>pid</i>	(Optional) Process ID number of a specific process. This keyword shows detail for only the specified process.
	sorted	(Optional) Displays CPU history sorted by percentage of utilization.

Command Modes	Privileged EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples The following is sample output from the **show processes memory** command:

Router# **show processes memory**

Total: 5611448, Used: 2307548, Free: 3303900

PID	TTY	Allocated	Freed	Holding	Getbufs	Retbufs	Process
0	0	199592	1236	1907220	0	0	*Init*
0	0	400	76928	400	0	0	*Sched*
0	0	5431176	3340052	140760	349780	0	*Dead*
1	0	256	256	1724	0	0	Load Meter
2	0	264	0	5032	0	0	Exec
3	0	0	0	2724	0	0	Check heaps
4	0	97932	0	2852	32760	0	Pool Manager
5	0	256	256	2724	0	0	Timers
6	0	92	0	2816	0	0	CXBus hot stall
7	0	0	0	2724	0	0	IPC Zone Manager
8	0	0	0	2724	0	0	IPC Realm Manager
9	0	0	0	2724	0	0	IPC Seat Manager
10	0	892	476	3256	0	0	ARP Input
11	0	92	0	2816	0	0	SERIAL A'detect
12	0	216	0	2940	0	0	Microcode Loader
13	0	0	0	2724	0	0	RFSS watchdog
14	0	15659136	15658584	3276	0	0	Env Mon
.							
.							
.							
77	0	116	0	2844	0	0	IPX-EIGRP Hello
				2307224	Total		

Table 93 describes the significant fields shown in the display.

Table 93 *show processes memory Field Descriptions*

Field	Description
Total:	Total amount of memory held.
Used:	Total amount of used memory.
Free:	Total amount of free memory.
PID	Process ID.
TTY	Terminal that controls the process.
Allocated	Bytes of memory allocated by the process.
Freed	Bytes of memory freed by the process, regardless of who originally allocated it.
Holding	Amount of memory currently allocated to the process.
Getbufs	Number of times the process has requested a packet buffer.
Retbufs	Number of times the process has relinquished a packet buffer.
Process	Process name.
Init	System initialization.
Sched	The scheduler.
Dead	Processes as a group that are now dead.
Total	Total amount of memory held by all processes.

The following is sample output from the show process memory command when a PID is specified:

```
Router# show process memory 1

Proc Memory Summary for pid = 1
Holding = 6844

pc = 0x6049B900, size = 000006044, count = 0001
pc = 0x60480650, size = 000000612, count = 0001
pc = 0x6048254C, size = 000000188, count = 0001

Router#
```

Related Commands

Command	Description
show memory	Displays statistics about memory, including memory-free pool statistics.
show processes	Displays information about the active processes.

show protocols

To display the configured protocols, use the **show protocols** EXEC command.

This command shows the global and interface-specific status of any configured Level 3 protocol; for example, IP, DECnet, IPX, AppleTalk, and so on.

show protocols

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples The following is sample output from the **show protocols** command:

```
Router# show protocols

Global values:
  Internet Protocol routing is enabled
  DECNET routing is enabled
  XNS routing is enabled
  Appletalk routing is enabled
  X.25 routing is enabled
Ethernet 0 is up, line protocol is up
  Internet address is 192.168.1.1, subnet mask is 255.255.255.0
  Decnet cost is 5
  XNS address is 2001.AA00.0400.06CC
  AppleTalk address is 4.129, zone Twilight
Serial 0 is up, line protocol is up
  Internet address is 192.168.7.49, subnet mask is 255.255.255.240
Ethernet 1 is up, line protocol is up
  Internet address is 192.168.2.1, subnet mask is 255.255.255.0
  Decnet cost is 5
  XNS address is 2002.AA00.0400.06CC
  AppleTalk address is 254.132, zone Twilight
Serial 1 is down, line protocol is down
  Internet address is 192.168.7.177, subnet mask is 255.255.255.240
  AppleTalk address is 999.1, zone Magnolia Estates
```

For more information on the parameters or protocols shown in this sample output, see the *Cisco IOS Network Protocols Configuration Guide, Part 1*, *Network Protocols Configuration Guide, Part 2*, and *Network Protocols Configuration Guide, Part 3*.

show slot

To display information about the PCMCIA flash memory cards file system, use the **show slot** command in user EXEC or privileged EXEC mode.

show slot [**all** | **chips** | **fileSYS**]

Syntax Description

all	(Optional) Displays all possible flash system information for all PCMCIA flash cards in the system.
chips	(Optional) Displays flash chip information.
fileSYS	(Optional) Displays file system information.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0	This command was introduced.

Usage Guidelines

Use the **show slot** command to display details about the files in a particular linear PCMCIA flash memory card of less than 20 MB and some 32 MB linear PCMCIA cards.



Note

Use the **show disk** command for ATA PCMCIA cards. Other forms of this commands are **show disk0:** and **show disk1:**.

For more information regarding file systems and flash cards, access the *PCMCIA Filesystem Compatibility Matrix and Filesystem Information* document at the following URL:

http://www.cisco.com/en/US/partner/products/hw/routers/ps341/products_tech_note09186a00800a7515.shtml

To see which flash cards are used in your router, use the **show version** command and look at the bottom portion of the output.

The following display indicates an ATA PCMCIA flash disk.

```
Router# show version
```

```
.  
.
.
```

```
46976K bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes).
```

The following display indicates a linear PCMCIA flash card with 20480K bytes of flash memory in card at slot 1 with a sector size of 128K.

```
Router# show version
```

```
.  
.
.
```

```
20480K bytes of Flash PCMCIA card at slot 1 (Sector size 128K).
```


Note

In some cases the **show slot** command will not display the file systems, use **show slot0:** or **show slot1:**.

Examples

The following example displays information about slot 0. The output is self-explanatory.

```
Router# show slot
```

```
PCMCIA Slot0 flash directory:
```

```
File Length Name/status
```

```
1 11081464 c3660-bin-mz.123-9.3.PI5b
```

```
[11081528 bytes used, 9627844 available, 20709372 total]
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

The following example shows all possible flash system information for all PCMCIA flash cards in the system.

```
Router# show slot all
```

Partition	Size	Used	Free	Bank-Size	State	Copy Mode
1	20223K	10821K	9402K	4096K	Read/Write	Direct

```
PCMCIA Slot0 flash directory:
```

```
File Length Name/status
```

```
addr fcksum ccksum
```

```
1 11081464 c3660-bin-mz.123-9.3.PI5b
```

```
0x40 0x5EA3 0x5EA3
```

```
[11081528 bytes used, 9627844 available, 20709372 total]
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

The following example shows flash chip information

```
Router# show slot chips
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

Related Commands

Command	Description
dir slot0:	Directory listing of files on a PCMCIA Flash card located in slot0.
dir slot1:	Directory listing of files on a PCMCIA Flash card located in slot1.
show slot0:	Displays information about the PCMCIA flash memory card's file system located in slot 0.
show slot1:	Displays information about the PCMCIA flash memory card's file system located in slot 1.

show slot0:

To display information about the PCMCIA flash memory card's file system located in slot 0, use the **show slot0:** command in user EXEC or privileged EXEC mode.

show slot0: [all | chips | filesystems]

Syntax Description	all	(Optional) Displays all possible flash system information for all PCMCIA flash cards in the system.
	chips	(Optional) Displays flash chip information.
	filesystems	(Optional) Displays file system information.

Command Modes	User EXEC
	Privileged EXEC

Command History	Release	Modification
	12.0	This command was introduced.

Usage Guidelines Use the **show slot0:** command to display details about the files in a particular linear PCMCIA flash memory card of less than 20 MB and some 32 MB linear PCMCIA cards.



Note

Use the **show disk** command for ATA PCMCIA cards. Other forms of this commands are **show disk0:** and **show disk1:**.

For more information regarding file systems and flash cards, access the *PCMCIA Filesystem Compatibility Matrix and Filesystem Information* document at the following URL:

http://www.cisco.com/en/US/partner/products/hw/routers/ps341/products_tech_note09186a00800a7515.shtml

To see which flash cards are used in your router, use the **show version** command and look at the bottom portion of the output.

The following display indicates an ATA PCMCIA flash disk.

Router# **show version**

```
.
.
.
46976K bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes).
```

The following display indicates a linear PCMCIA flash card with 20480K bytes of flash memory in card at slot 1 with a sector size of 128K.

Router# **show version**

```
.
.
.
20480K bytes of Flash PCMCIA card at slot 1 (Sector size 128K).
```

show slot0:

Examples

The following example displays information about slot 0. The output is self-explanatory.

```
Router# show slot0:
```

```
PCMCIA Slot0 flash directory:
```

```
File Length Name/status
```

```
1 11081464 c3660-bin-mz.123-9.3.PI5b
```

```
[11081528 bytes used, 9627844 available, 20709372 total]
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

```
Router# show slot0: all
```

Partition	Size	Used	Free	Bank-Size	State	Copy Mode
1	20223K	10821K	9402K	4096K	Read/Write	Direct

```
PCMCIA Slot0 flash directory:
```

```
File Length Name/status
```

```
addr fcksum ccksum
```

```
1 11081464 c3660-bin-mz.123-9.3.PI5b
```

```
0x40 0x5EA3 0x5EA3
```

```
[11081528 bytes used, 9627844 available, 20709372 total]
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

The following example shows flash chip information.

```
Router# show slot0: chips
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

Related Commands

Command	Description
dir slot0:	Directory listing of files on a PCMCIA Flash card located in slot0.
dir slot1:	Directory listing of files on a PCMCIA Flash card located in slot1.
show slot1:	Displays information about the PCMCIA flash memory card's file system located in slot 1.
show slot	Displays information about the PCMCIA flash memory cards.

show slot1:

To display information about the PCMCIA flash memory card's file system located in slot 1, use the **show slot1:** command in user EXEC or privileged EXEC mode.

show slot1: [all | chips | filesystems]

Syntax Description	all	(Optional) Shows all possible flash system information for all PCMCIA flash cards in the system.
	chips	(Optional) Shows flash chip information.
	filesystems	(Optional) Shows file system information.

Command Modes	User EXEC
	Privileged EXEC

Command History	Release	Modification
	12.0	This command was introduced.

Usage Guidelines Use the **show slot1:** command to display details about the files in a particular linear PCMCIA flash memory card of less than 20 MB and some 32 MB linear PCMCIA cards located in slot 1.



Note

Use the **show disk** command for ATA PCMCIA cards. Other forms of this commands are **show disk0:** and **show disk1:**.

For more information regarding file systems and flash cards, access the *PCMCIA Filesystem Compatibility Matrix and Filesystem Information* document at the following URL:

http://www.cisco.com/en/US/partner/products/hw/routers/ps341/products_tech_note09186a00800a7515.shtml

To see which flash cards are used in your router, use the **show version** command and look at the bottom portion of the output.

The following display indicates an ATA PCMCIA flash disk.

```
Router# show version
```

```
.
.
.
```

```
46976K bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes).
```

The following display indicates a linear PCMCIA flash card with 20480K bytes of flash memory in card at slot 1 with a sector size of 128K.

```
Router# show version
```

```
.
.
.
```

```
20480K bytes of Flash PCMCIA card at slot 1 (Sector size 128K).
```

show slot1:

Examples

The following example displays information about slot 0 using the **slot0:** command form. The output is self-explanatory.

```
Router# show slot1:
```

```
PCMCIA Slot1 flash directory:
```

```
File Length Name/status
```

```
1 10907068 c3660-bin-mz.123-7.9.PI4
```

```
[10907132 bytes used, 5739008 available, 16646140 total]
```

```
16384K bytes of processor board PCMCIA Slot1 flash (Read/Write)
```

```
Router# show slot1: all
```

Partition	Size	Used	Free	Bank-Size	State	Copy Mode
1	20223K	10821K	9402K	4096K	Read/Write	Direct

```
PCMCIA Slot0 flash directory:
```

```
File Length Name/status
```

```
addr fcksum ccksum
```

```
1 11081464 c3660-bin-mz.123-9.3.PI5b
```

```
0x40 0x5EA3 0x5EA3
```

```
[11081528 bytes used, 9627844 available, 20709372 total]
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

The following example shows flash chip information.

```
Router# show slot1: chips
```

```
20480K bytes of processor board PCMCIA Slot0 flash (Read/Write)
```

Chip	Bank	Code	Size	Name
1	1	89A0	2048KB	INTEL 28F016SA
2	1	89A0	2048KB	INTEL 28F016SA
1	2	89A0	2048KB	INTEL 28F016SA
2	2	89A0	2048KB	INTEL 28F016SA
1	3	89A0	2048KB	INTEL 28F016SA
2	3	89A0	2048KB	INTEL 28F016SA
1	4	89A0	2048KB	INTEL 28F016SA
2	4	89A0	2048KB	INTEL 28F016SA
1	5	89A0	2048KB	INTEL 28F016SA
2	5	89A0	2048KB	INTEL 28F016SA

Related Commands

Command	Description
dir slot0:	Directory listing of files on a PCMCIA Flash card located in slot0.
dir slot1:	Directory listing of files on a PCMCIA Flash card located in slot1.
show slot0:	Displays information about the PCMCIA flash memory card's file system located in slot 0.
show slot	Displays information about the PCMCIA flash memory cards.

show stacks

To monitor the stack usage of processes and interrupt routines, use the **show stacks** EXEC command.

show stacks

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The display from this command includes the reason for the last system reboot. If the system was reloaded because of a system failure, a saved system stack trace is displayed. This information is of use only to your technical support representative in analyzing crashes in the field. It is included here in case you need to read the displayed statistics to an engineer over the phone.

Examples The following is sample output from the **show stacks** command following a system failure:

```
Router# show stacks

Minimum process stacks:
Free/Size  Name
652/1000   Router Init
726/1000   Init
744/1000   BGP Open
686/1200   Virtual Exec

Interrupt level stacks:
Level      Called Free/Size  Name
1           0 1000/1000  env-flash
3          738 900/1000  Multiport Communications Interfaces
5          178 970/1000  Console UART

System was restarted by bus error at PC 0xAD1F4, address 0xD0D0D1A
GS Software (GS3), Version 9.1(0.16), BETA TEST SOFTWARE
Compiled Tue 11-Aug-92 13:27 by jthomas
Stack trace from system failure:
FP: 0x29C158, RA: 0xACFD4
FP: 0x29C184, RA: 0xAD20C
FP: 0x29C1B0, RA: 0xACFD4
FP: 0x29C1DC, RA: 0xAD304
FP: 0x29C1F8, RA: 0xAF774
FP: 0x29C214, RA: 0xAF83E
FP: 0x29C228, RA: 0x3E0CA
FP: 0x29C244, RA: 0x3BD3C
```

Related Commands

Command	Description
show processes	Displays information about the active processes.

show subsys

To display the subsystem information, use the **show subsys** privileged EXEC command.

show subsys [**class** *class* | **name** *name*]

Syntax Description

class <i>class</i>	(Optional) Displays the subsystems of the specified class. Valid classes are driver , kernel , library , management , protocol , and registry .
name <i>name</i>	(Optional) Displays the specified subsystem. Use the asterisk character (*) as a wildcard at the end of the name to list all subsystems, starting with the specified characters.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	This command was introduced.

Usage Guidelines

Use the **show subsys** command to confirm that all required features are in the running image.

Examples

In the following example, partial sample output is shown from the **show subsys** command:

Router# **show subsys**

	Class	Version
static_map	Kernel	1.000.001
arp	Kernel	1.000.001
ether	Kernel	1.000.001
compress	Kernel	1.000.001
alignment	Kernel	1.000.002
monvar	Kernel	1.000.001
slot	Kernel	1.000.001
oir	Kernel	1.000.001
atm	Kernel	1.000.001
ip_addrpool_sys	Library	1.000.001
chat	Library	1.000.001
dialer	Library	1.000.001
flash_services	Library	1.000.001
ip_localpool_sys	Library	1.000.001
nvramp_common	Driver	1.000.001
ASP	Driver	1.000.001
sonict	Driver	1.000.001
oc3suni	Driver	1.000.001
oc12suni	Driver	1.000.001
ds3suni	Driver	1.000.001
.		
.		
.		

Table 94 describes the significant fields shown in the display.

Table 94 *show subsys Field Descriptions*

Field	Description
static_map	Name of the subsystem.
Class	Class of the subsystem. Possible classes include Kernel, Library, Driver, Protocol, Management, Registry, and SystemInit.
Version	Version of the subsystem.

show tcp

To display the status of TCP connections, use the **show tcp** EXEC command.

show tcp [*line-number*]

Syntax Description	<i>line-number</i>	(Optional) Absolute line number of the line for which you want to display Telnet connection status.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Examples

The following is sample output from the **show tcp** command:

```
Router# show tcp

tty0, connection 1 to host cider
Connection state is ESTAB, I/O status: 1, unread input bytes: 0
Local host: 172.31.232.17, Local port: 11184
Foreign host: 172.31.1.137, Foreign port: 23

Enqueued packets for retransmit: 0, input: 0, saved: 0

Event Timers (current time is 67341276):
Timer:          Retrans  TimeWait   AckHold    SendWnd   KeepAlive   GiveUp     PmtuAger
Starts:           30         0         32         0         0         0         0
Wakeups:           1         0         14         0         0         0         0
Next:             0         0         0         0         0         0         0

iss: 67317172 snduna: 67317228 sndnxt: 67317228 sndwnd: 4096
irs: 1064896000 rcvnxt: 1064897597 rcvwnd: 2144 delrcvwnd: 0

SRTT: 317 ms, RTTO: 900 ms, RTV: 133 ms, KRTT: 0 ms
minRTT: 4 ms, maxRTT: 300 ms, ACK hold: 300 ms
Flags: higher precedence, idle user, retransmission timeout

Datagrams (max data segment is 536 bytes):
Rcvd: 41 (out of order: 0), with data: 34, total data bytes: 1596
Sent: 57 (retransmit: 1), with data: 35, total data bytes: 55
```

[Table 95](#) describes the first five lines of output shown in the display.

Table 95 *show tcp* Field Descriptions—First Section of Output

Field	Description
tty0	Identifying number of the line.
connection 1	Number identifying the TCP connection.

Table 95 *show tcp Field Descriptions—First Section of Output (continued)*

Field	Description
to host xxx	Name of the remote host to which the connection has been made.
Connection state is ESTAB	A connection progresses through a series of states during its lifetime. These states follow in the order in which a connection progresses through them. • LISTEN—Waiting for a connection request from any remote TCP and port. • SYNSENT—Waiting for a matching connection request after having sent a connection request. • SYNRCVD—Waiting for a confirming connection request acknowledgment after having both received and sent a connection request. • ESTAB—Indicates an open connection; data received can be delivered to the user. This is the normal state for the data transfer phase of the connection. • FINWAIT1—Waiting for a connection termination request from the remote TCP or an acknowledgment of the connection termination request previously sent. • FINWAIT2—Waiting for a connection termination request from the remote TCP host. • CLOSEWAIT—Waiting for a connection termination request from the local user. • CLOSING—Waiting for a connection termination request acknowledgment from the remote TCP host. • LASTACK—Waiting for an acknowledgment of the connection termination request previously sent to the remote TCP host. • TIMEWAIT—Waiting for enough time to pass to be sure the remote TCP host has received the acknowledgment of its connection termination request. • CLOSED—Indicates no connection state at all. For more information, see RFC 793, <i>Transmission Control Protocol Functional Specification</i>.
I/O status:	Number describing the current internal status of the connection.
unread input bytes:	Number of bytes that the lower-level TCP processes have read, but the higher-level TCP processes have not yet processed.
Local host:	IP address of the network server.
Local port:	Local port number, as derived from the following equation: <i>line-number + (512 * random-number)</i> . (The line number uses the lower nine bits; the other bits are random.)
Foreign host:	IP address of the remote host to which the TCP connection has been made.
Foreign port:	Destination port for the remote host.

Table 95 *show tcp Field Descriptions—First Section of Output (continued)*

Field	Description
Enqueued packets for retransmit:	Number of packets waiting on the retransmit queue. These are packets on this TCP connection that have been sent but have not yet been acknowledged by the remote TCP host.
input:	Number of packets that are waiting on the input queue to be read by the user.
saved:	Number of received out-of-order packets that are waiting for all packets comprising the message to be received before they enter the input queue. For example, if packets 1, 2, 4, 5, and 6 have been received, packets 1 and 2 would enter the input queue, and packets 4, 5, and 6 would enter the saved queue.

The following line of output shows the current time according to the system clock of the local host:

```
Event Timers (current time is 67341276):
```

The time shown is the number of milliseconds since the system started.

The following lines of output display the number of times that various local TCP timeout values were reached during this connection. In this example, the local host re-sent data 30 times because it received no response from the remote host, and it sent an acknowledgment many more times because there was no data on which to piggyback.

```

Timer:      Retrans   TimeWait   AckHold    SendWnd    KeepAlive   GiveUp      PmtuAger
Starts:      30         0          32         0           0           0           0
Wakeups:      1         0          14         0           0           0           0
Next:        0         0           0         0           0           0           0

```

Table 96 describes the fields in the preceding lines of output.

Table 96 *show tcp Field Descriptions—Second Section of Output*

Field	Description
Timer:	The names of the timers in the display.
Starts:	The number of times the timer has been started during this connection.
Wakeups:	Number of keepalives sent without receiving any response. (This field is reset to zero when a response is received.)
Next:	The system clock setting that will trigger the next time this timer will go off.
Retrans	The Retransmission timer is used to time TCP packets that have not been acknowledged and are waiting for retransmission.
TimeWait	The TimeWait timer is used to ensure that the remote system receives a request to disconnect a session.
AckHold	The Acknowledgment timer is used to delay the sending of acknowledgments to the remote TCP in an attempt to reduce network use.
SendWnd	The Send Window is used to ensure that there is no closed window due to a lost TCP acknowledgment.
KeepAlive	The KeepAlive timer is used to control the transmission of test messages to the remote TCP to ensure that the link has not been broken without the local TCP's knowledge.

Table 96 *show tcp Field Descriptions—Second Section of Output (continued)*

Field	Description
GiveUp	The GiveUp timer determines the amount of time a local host will wait for an acknowledgement (or other appropriate reply) of a transmitted message after the the maximum number of retransmissions has been reached. If the timer expires, the local host gives up retransmission attempts and declares the connection dead.
PmtuAger	The PMTU age timer is a time interval for how often TCP reestimates the path MTU with a larger maximum segment size (MSS). When the age timer is used, TCP path MTU becomes a dynamic process. If the MSS is smaller than what the peer connection can manage, a larger MSS is tried every time the age timer expires. The discovery process stops when the send MSS is as large as the peer negotiated or the timer has been manually disabled by setting it to infinite.

The following lines of output display the sequence numbers that TCP uses to ensure sequenced, reliable transport of data. The local host and remote host each use these sequence numbers for flow control and to acknowledge receipt of datagrams. [Table 97](#) describes the significant fields shown in the display.

```
iss: 67317172 snduna: 67317228 sndnxt: 67317228 sndwnd: 4096
irs: 1064896000 rcvnxt: 1064897597 rcvwnd: 2144 delrcvwnd: 0
```

Table 97 *show tcp Field Descriptions—Sequence Number*

Field	Description
iss:	Initial send sequence number.
snduna:	Last send sequence number that the local host sent but has not received an acknowledgment for.
sndnxt:	Sequence number the local host will send next.
sndwnd:	TCP window size of the remote host.
irs:	Initial receive sequence number.
rcvnxt:	Last receive sequence number that the local host has acknowledged.
rcvwnd:	TCP window size of the local host.
delrcvwnd:	Delayed receive window—data the local host has read from the connection, but has not yet subtracted from the receive window the host has advertised to the remote host. The value in this field gradually increases until it is larger than a full-sized packet, at which point it is applied to the rcvwnd field.

The following lines of output display values that the local host uses to keep track of transmission times so that TCP can adjust to the network it is using.

[Table 98](#) describes the significant fields shown in the display.

```
SRTT: 317 ms, RTTO: 900 ms, RTV: 133 ms, KRTT: 0 ms
minRTT: 4 ms, maxRTT: 300 ms, ACK hold: 300 ms
Flags: higher precedence, idle user, retransmission timeout
```

Table 98 *show tcp Field Descriptions—Line Beginning with “SRTT”*

Field	Description
SRTT:	A calculated smoothed round-trip timeout.
RTTO:	Round-trip timeout.
RTV:	Variance of the round-trip time.
KRTT:	New round-trip timeout (using the Karn algorithm). This field separately tracks the round-trip time of packets that have been re-sent.
minRTT:	Smallest recorded round-trip timeout (hard-wire value used for calculation).
maxRTT:	Largest recorded round-trip timeout.
ACK hold:	Time the local host will delay an acknowledgment in order to piggyback data on it.
Flags:	Properties of the connection.

For more information on these fields, refer to *Round Trip Time Estimation*, P. Karn & C. Partridge, ACM SIGCOMM-87, August 1987.

Table 99 describes the significant fields shown in the display.

```
Datagrams (max data segment is 536 bytes):
Rcvd: 41 (out of order: 0), with data: 34, total data bytes: 1596
Sent: 57 (retransmit: 1), with data: 35, total data bytes: 55
```

Table 99 *show tcp Field Descriptions—Last Section of Output*

Field	Description
Rcvd:	Number of datagrams the local host has received during this connection (and the number of these datagrams that were out of order).
with data:	Number of these datagrams that contained data.
total data bytes:	Total number of bytes of data in these datagrams.
Sent:	Number of datagrams the local host sent during this connection (and the number of these datagrams that needed to be re-sent).
with data:	Number of these datagrams that contained data.
total data bytes:	Total number of bytes of data in these datagrams.

Related Commands

Command	Description
show tcp brief	Displays a concise description of TCP connection endpoints.

show tcp brief

To display a concise description of TCP connection endpoints, use the **show tcp brief** EXEC command.

show tcp brief [all]

Syntax Description	all (Optional) Displays status for all endpoints. Without this keyword, endpoints in the LISTEN state are not shown.

Command Modes	EXEC

Command History	Release Modification
	11.2 This command was introduced.

Examples The following is sample output from the **show tcp brief** command while a user has connected into the system via Telnet:

Router> **show tcp brief**

```
TCB      Local Address      Foreign Address      (state)
609789AC Router.cisco.com.23    cider.cisco.com.3733 ESTAB
```

[Table 100](#) describes the significant fields shown in the display.

Table 100 show tcp brief Field Descriptions

Field	Description
TCB	An internal identifier for the endpoint.
Local Address	The local IP address and port.
Foreign Address	The foreign IP address and port (at the opposite end of the connection).
(state)	The state of the connection. States are described in the syntax description of the show tcp command.

Related Commands	Command Description
	show tcp Displays the status of TCP connections.

show tdm connections

To display a snapshot of the time-division multiplexing (TDM) bus connection memory in a Cisco AS5200 access server, use the **show tdm connections** EXEC command.

show tdm connections [**motherboard** | **slot** *slot-number*]

Syntax Description

motherboard	(Optional) Motherboard in the Cisco AS5200 access server.
slot <i>slot-number</i>	(Optional) Slot number.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

The **show tdm connections** command shows the connection memory for all TDM bus connections in the access server if you do not limit the display to the motherboard or a slot.

Examples

In the following example, source stream 3 (ST3) channel 2 switched out of stream 6 (ST6) channel 2 is shown:

```
AS5200# show tdm connections motherboard
```

```
MT8980 motherboard unit 0, Control Register = 0x1F, ODE Register = 0x06
Connection Memory for ST6:
Ch0: 0x62, Ch1: 0x00, Ch2: 0x00, Ch3: 0x00
Ch4: 0x00, Ch5: 0x00, Ch6: 0x00, Ch7: 0x00
Ch8: 0x00, Ch9: 0x00, Ch10: 0x00, Ch11: 0x00
Ch12: 0x00, Ch13: 0x00, Ch14: 0x00, Ch15: 0x00
Ch16: 0x00, Ch17: 0x00, Ch18: 0x00, Ch19: 0x00
Ch20: 0x00, Ch21: 0x00, Ch22: 0x00, Ch23: 0x00
Ch24: 0x00, Ch25: 0x00, Ch26: 0x00, Ch27: 0x00
Ch28: 0x00, Ch29: 0x00, Ch30: 0x00, Ch31: 0x00
```

To interpret the hexadecimal number 0x62 into meaningful information, you must translate it into binary code. These two hexadecimal numbers represent a connection from any stream and a channel on any stream. The number 6 translates into the binary code 0110, which represents the third-source stream. The number 2 translates into the binary code 0010, which represents the second-source channel.

Stream 6 (ST6) channel 0 is the destination for ST3 channel 2 in this example.

Related Commands

Command	Description
show tcp	Displays the status of TCP connections.

show tdm data

To display a snapshot of the time-division multiplexing (TDM) bus data memory in a Cisco AS5200 access server, use the **show tdm data** EXEC command.

show tdm data [**motherboard** | **slot** *slot-number*]

Syntax Description	motherboard	(Optional) Motherboard in the Cisco AS5200 access server.
	slot <i>slot-number</i>	(Optional) Slot number.

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	The data memory for all TDM bus connections in the access server is displayed if you do not specify a motherboard or slot.

Examples	In the following example, a snapshot of TDM memory is shown where the normal ISDN idle pattern (0x7E) is present on all channels of the TDM device resident on the motherboard:

```
AS5200# show tdm data motherboard

MT8980 motherboard unit 0, Control Register = 0x1F, ODE Register = 0x06
Data Memory for ST0:
Ch0:  0x7E, Ch1:  0x7E, Ch2:  0x7E, Ch3:  0x7E
Ch4:  0x7E, Ch5:  0x7E, Ch6:  0x7E, Ch7:  0x7E
Ch8:  0x7E, Ch9:  0x7E, Ch10: 0x7E, Ch11: 0x7E
Ch12: 0x7E, Ch13: 0x7E, Ch14: 0x7E, Ch15: 0x7E
Ch16: 0x7E, Ch17: 0x7E, Ch18: 0x7E, Ch19: 0x7E
Ch20: 0x7E, Ch21: 0x7E, Ch22: 0x7E, Ch23: 0x7E
Ch24: 0x7E, Ch25: 0x7E, Ch26: 0x7E, Ch27: 0x7E
Ch28: 0x7E, Ch29: 0x7E, Ch30: 0x7E, Ch31: 0x7E
Data Memory for ST1:
Ch0:  0x7E, Ch1:  0x7E, Ch2:  0x7E, Ch3:  0x7E
Ch4:  0x7E, Ch5:  0x7E, Ch6:  0x7E, Ch7:  0x7E
Ch8:  0x7E, Ch9:  0x7E, Ch10: 0x7E, Ch11: 0x7E
Ch12: 0x7E, Ch13: 0x7E, Ch14: 0x7E, Ch15: 0x7E
Ch16: 0x7E, Ch17: 0x7E, Ch18: 0x7E, Ch19: 0x7E
Ch20: 0x7E, Ch21: 0x7E, Ch22: 0x7E, Ch23: 0x7E
Ch24: 0x7E, Ch25: 0x7E, Ch26: 0x7E, Ch27: 0x7E
Ch28: 0x7E, Ch29: 0x7E, Ch30: 0x7E, Ch31: 0x7E
```

Related Commands	Command	Description
	show tdm connections	Displays data about the TDM bus connection memory in a Cisco AS5200 access server.

show tech-support

To display general information about the router when reporting a problem, use the **show tech-support** privileged EXEC command.

```
show tech-support [page] [password] [cef | ipmulticast | isis | mpls | ospf [process-ID | detail] |
                  rsvp]
```

Syntax Description

page	(Optional) Causes the output to display a page of information at a time. Use the return key to display the next line of output or use the space bar to display the next page of information. If not used, the output scrolls (that is, does not stop for page breaks).
password	(Optional) Leaves passwords and other security information in the output. If not used, passwords and other security-sensitive information in the output are replaced with the label "<removed>" (this is the default).
cef	(Optional) Displays show command output specific to Cisco Express Forwarding (CEF).
ipc	(Optional) Displays show command output specific to Inter-Process Communications (IPC).
ipmulticast	(Optional) Displays show command output related to the IP Multicast configuration, including Protocol Independent Multicast (PIM) information, Internet Group Management Protocol (IGMP) information, and Distance Vector Multicast Routing Protocol (DVMRP) information.
isis	(Optional) Displays show command output specific to Connectionless Network Service (CLNS) and Intermediate System-to-Intermediate System Protocol (ISIS).
mpls	(Optional) Displays show command output specific to Multilayer Switching Protocol (MPLS) forwarding and applications.
ospf [<i>process-ID</i> <i>detail</i>]	(Optional) Displays show command output specific to Open Shortest Path First Protocol (OSPF) networking.
rsvp	(Optional) Displays show command output specific to Resource Reservation Protocol (RSVP) networking.

Defaults

The output scrolls without page breaks.
Passwords and other security information are removed from the output.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.2	This command was introduced.
11.3(7), 11.2(16)	The output for this command was expanded to show additional information for boot , bootflash , context , and traffic for all enabled protocols. (CSCdj06229)

Release	Modification
11.3(7)T	This command was integrated into Cisco IOS Release 11.3(7)T.
12.0	The following keyword extensions were added: • cef • ipmulticast • isis • mpls • ospf

Usage Guidelines

The **show tech-support** command is useful for collecting a large amount of information about your routing device for troubleshooting purposes. The output of this command can be provided to technical support representatives when reporting a problem.

The **show tech-support** command displays the output of a number of show commands at once. The output from this command will vary depending on your platform and configuration. For example, Access Servers will display voice-related show output. Additionally, the **show protocol traffic** commands will be displayed for only the protocols enabled on your device. The output of the **show tech-support** command can include the output of the following commands:

- **show apollo traffic**
- **show appletalk traffic**
- **show bootflash**
- **show bootvar**
- **show buffers**
- **show cdp neighbors**
- **show cef**
- **show clns traffic**
- **show context**
- **show controllers**
- **show decnet traffic**
- **show interfaces**
- **show ip cef**
- **show ip interface**
- **show ip traffic**
- **show isis**
- **show mpls**
- **show novell traffic**
- **show processes cpu**
- **show processes memory**
- **show running-config**
- **show stacks**

- **show version**
- **show vines traffic**
- **show xns traffic**
- **show file systems**
- **dir nvram:**
- **show disk0: all**
- **show process cpu**
- **show pci controller**

Use of the optional **cef**, **ipmulticast**, **ipc**, **isis**, **mpls**, **ospf**, or **rsvp** keywords provides a way to display a number of show commands specific to a particular protocol or process in addition to the **show** commands listed previously.

For example, if your TAC support representative suspects that you may have a problem in your Cisco Express Forwarding (CEF) configuration, you may be asked to provide the output of the **show tech-support cef** command. The **show tech-support [page] [password] cef** command will display the output from the following commands in addition to the output for the standard **show tech-support** command:

- **show ip cef summary**
- **show adjacency summary**
- **show ip cef events summary**
- **show ip cef inconsistency records detail**
- **show cef interface**
- **show cef events**
- **show cef timers**
- **show interfaces stats**
- **show cef drop**
- **show cef not-cef-switched**

Examples

For a sample display of the output from the **show tech-support** command, refer to the documentation for the **show** commands listed in the “Usage Guidelines” section.

Related Commands

Command	Description
show apollo traffic	Displays information about the number and type of Apollo Domain packets transmitted and received by the Cisco IOS software.
show appletalk traffic	Displays statistics about AppleTalk traffic, including MacIP traffic.
show bootflash	Displays the contents of boot Flash memory.
show bootvar	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.
show buffers	Displays statistics for the buffer pools on the network server.

Command	Description
show clns traffic	Displays a list of the CLNS packets this router has seen.
show context	Displays context data.
show controllers	Displays information that is specific to the hardware.
show controllers tech-support	Displays general information about a VIP card when reporting a problem.
show decnet traffic	Displays the DECnet traffic statistics (including datagrams sent, received, and forwarded).
show interfaces	Displays ALC information.
show ip traffic	Displays statistics about IP traffic.
show novell traffic	Displays information about the number and type of IPX packets transmitted and received.
show processes cpu	Displays information about the active processes.
show processes memory	Shows the amount of memory used.
show running-config	Displays the current configuration of your routing device.
show stacks	Displays the stack usage of processes and interrupt routines.
show version	Displays the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images.
show vines traffic	Displays the statistics maintained about VINES protocol traffic.
show xns traffic	Displays information about the number and type of XNS packets transmitted and received by the Cisco IOS software.

test flash

To test Flash memory on MCI and envm Flash EPROM interfaces, use the **test flash** EXEC command.

test flash

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Examples

In the following example, the Flash memory is tested:

```
test flash
```

Related Commands

Command	Description
test interfaces	Tests the system interfaces on the modular router.
test memory	Performs a test of Multibus memory (including nonvolatile memory) on the modular router.

test interfaces

To test the system interfaces on the modular router, use the **test interfaces** EXEC command.

test interfaces

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The **test interfaces** EXEC command is intended for the factory checkout of network interfaces. It is not intended for diagnosing problems with an operational router. The **test interfaces** output does not report correct results if the router is attached to a “live” network. For each network interface that has an IP address that can be tested in loopback (MCI and ciscoBus Ethernet and all serial interfaces), the **test interfaces** command sends a series of ICMP echoes. Error counters are examined to determine the operational status of the interface.

Examples In the following example, the system interfaces are tested:

```
test interfaces
```

Related Commands	Command	Description
	test flash	Tests Flash memory on MCI and envm Flash EPROM interfaces.
	test memory	Performs a test of Multibus memory (including nonvolatile memory) on the modular router.

test memory

To perform a test of Multibus memory (including nonvolatile memory) on the modular router, use the **test memory** EXEC command. The memory test overwrites memory.

test memory

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The memory test overwrites memory. If you use the **test memory** command, you will need to rewrite nonvolatile memory. For example, if you test Multibus memory, which is the memory used by the CSC-R 4-Mbps Token Ring interfaces, you will need to reload the system before the network interfaces will operate properly. The **test memory** command is intended primarily for use by Cisco personnel.

Examples

In the following example, the memory is tested:

```
test memory
```

Related Commands

Command	Description
test flash	Tests Flash memory on MCI and envm Flash EPROM interfaces.
test interfaces	Tests the system interfaces on the modular router.

trace (privileged)

To discover the routes that packets will actually take when traveling to their destination, use the **trace** privileged EXEC command.

trace [*protocol*] [*destination*]

Syntax Description

<i>protocol</i>	(Optional) Protocols that can be used are appletalk , clns , ip and vines .
<i>destination</i>	(Optional) Destination address or host name on the command line. The default parameters for the appropriate protocol are assumed and the tracing action begins.

Defaults

The *protocol* argument is based on the Cisco IOS software examination of the format of the *destination* argument. For example, if the software finds a *destination* argument in IP format, the *protocol* value defaults to **ip**.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The **trace** command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.

The **trace** command starts by sending probe datagrams with a TTL value of one. This causes the first router to discard the probe datagram and send back an error message. The **trace** command sends several probes at each TTL level and displays the round-trip time for each.

The **trace** command sends out one probe at a time. Each outgoing packet may result in one or two error messages. A “time exceeded” error message indicates that an intermediate router has seen and discarded the probe. A “destination unreachable” error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the **trace** command prints an asterisk (*).

The **trace** command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with the escape sequence. By default, to invoke the escape sequence, type **Ctrl-^ X** by simultaneously pressing and releasing the **Ctrl**, **Shift**, and **6** keys, and then pressing the **X** key.

To use nondefault parameters and invoke an extended **trace** test, enter the command without a *destination* argument. You will be stepped through a dialog to select the desired parameters.

Common Trace Problems

Due to bugs in the IP implementation of various hosts and routers, the IP **trace** command may behave in unexpected ways.

Not all destinations will respond correctly to a probe message by sending back an “ICMP port unreachable” message. A long sequence of TTL levels with only asterisks, terminating only when the maximum TTL has been reached, may indicate this problem.

There is a known problem with the way some hosts handle an “ICMP TTL exceeded” message. Some hosts generate an “ICMP” message but they reuse the TTL of the incoming packet. Because this is zero, the ICMP packets do not make it back. When you trace the path to such a host, you may see a set of TTL values with asterisks (*). Eventually the TTL gets high enough that the *ICMP* message can get back. For example, if the host is six hops away, the **trace** command will time out on responses 6 through 11.

Trace IP Routes

The following display shows sample IP **trace** output when a destination host name has been specified:

```
Router# trace ABA.NYC.mil

Type escape sequence to abort.
Tracing the route to ABA.NYC.mil (26.0.0.73)
 0  DEBRIS.CISCO.COM (192.180.1.6)  1000 msec  8 msec  4 msec
 1  BARNET-GW.CISCO.COM (192.180.16.2)  8 msec  8 msec  8 msec
 2  EXTERNAL-A-GATEWAY.STANFORD.EDU (192.42.110.225)  8 msec  4 msec  4 msec
 3  BB2.SU.BARNET.NET (192.200.254.6)  8 msec  8 msec  8 msec
 4  SU.ARC.BARNET.NET (192.200.3.8)  12 msec  12 msec  8 msec
 5  MOFFETT-FLD-MB.in.MIL (192.52.195.1)  216 msec  120 msec  132 msec
 6  ABA.NYC.mil (26.0.0.73)  412 msec  628 msec  664 msec
```

Table 101 describes the significant fields shown in the display.

Table 101 trace Field Descriptions

Field	Description
1	Indicates the sequence number of the router in the path to the host.
DEBRIS.CISCO.COM	Host name of this router.
192.180.1.6	Internet address of this router.
1000 msec 8 msec 4 msec	Round-trip time for each of the three probes that are sent.

Extended IP Trace Dialog

The following display shows a sample **trace** session involving the extended dialog of the **trace** command:

```
Router# trace

Protocol [ip]:
Target IP address: mit.edu
Source address:
Numeric display [n]:
Timeout in seconds [3]:
Probe count [3]:
Minimum Time to Live [1]:
Maximum Time to Live [30]:
Port Number [33434]:
Loose, Strict, Record, Timestamp, Verbose[none]:
Type escape sequence to abort.
Tracing the route to MIT.EDU (18.72.2.1)
 0  ICM-DC-2-V1.ICP.NET (192.108.209.17)  72 msec  72 msec  88 msec
 1  ICM-FIX-E-H0-T3.ICP.NET (192.157.65.122)  80 msec  128 msec  80 msec
 2  192.203.229.246  540 msec  88 msec  84 msec
 3  T3-2.WASHINGTON-DC-CNSS58.T3.ANS.NET (140.222.58.3)  84 msec  116 msec  88 msec
```



```

5 T3-3.WASHINGTON-DC-CNSS56.T3.ANS.NET (140.222.56.4) 80 msec 132 msec 88 msec
6 T3-0.NEW-YORK-CNSS32.T3.ANS.NET (140.222.32.1) 92 msec 132 msec 88 msec
7 T3-0.HARTFORD-CNSS48.T3.ANS.NET (140.222.48.1) 88 msec 88 msec 88 msec
8 T3-0.HARTFORD-CNSS49.T3.ANS.NET (140.222.49.1) 96 msec 104 msec 96 msec
9 T3-0.ENSS134.T3.ANS.NET (140.222.134.1) 92 msec 128 msec 92 msec
10 W91-CISCO-EXTERNAL-FDDI.MIT.EDU (192.233.33.1) 92 msec 92 msec 112 msec
11 E40-RTR-FDDI.MIT.EDU (18.168.0.2) 92 msec 120 msec 96 msec
12 MIT.EDU (18.72.2.1) 96 msec 92 msec 96 msec

```

Table 102 describes the fields that are unique to the extended trace sequence, as shown in the display.

Table 102 trace Field Descriptions

Field	Description
Target IP address	You must enter a host name or an IP address. There is no default.
Source address	One of the interface addresses of the router to use as a source address for the probes. The router will normally pick what it feels is the best source address to use.
Numeric display	The default is to have both a symbolic and numeric display; however, you can suppress the symbolic display.
Timeout in seconds	The number of seconds to wait for a response to a probe packet. The default is 3 seconds.
Probe count	The number of probes to be sent at each TTL level. The default count is 3.
Minimum Time to Live [1]	The TTL value for the first probes. The default is 1, but it can be set to a higher value to suppress the display of known hops.
Maximum Time to Live [30]	The largest TTL value that can be used. The default is 30. The trace command terminates when the destination is reached or when this value is reached.
Port Number	The destination port used by the User Datagram Protocol (UDP) probe messages. The default is 33434.
Loose, Strict, Record, Timestamp, Verbose	IP header options. You can specify any combination. The trace command issues prompts for the required fields. Note that the trace command will place the requested options in each probe; however, there is no guarantee that all routers (or end nodes) will process the options.
Loose	Allows you to specify a list of nodes that must be traversed when going to the destination.
Strict	Allows you to specify a list of nodes that must be the only nodes traversed when going to the destination.
Record	Allows you to specify the number of hops to leave room for.
Timestamp	Allows you to specify the number of time stamps to leave room for.
Verbose	If you select any option, the verbose mode is automatically selected and the trace command prints the contents of the option field in any incoming packets. You can prevent verbose mode by selecting it again, toggling its current setting.

Table 103 describes the characters that can appear in **trace** command output.

Table 103 *ip trace Text Characters*

Char	Description
<i>nn msec</i>	For each node, the round-trip time (in milliseconds) for the specified number of probes.
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
U	Port unreachable.

Related Commands

Command	Description
trace (user)	Discovers the CLNS routes that packets will actually take when traveling to their destination.

trace (user)

To discover the IP routes that packets will actually take when traveling to their destination, use the **trace** EXEC command.

trace [*protocol*] [*destination*]

Syntax Description	<i>protocol</i>	(Optional) Protocols that can be used are appletalk , clns , ip and vines .
	<i>destination</i>	(Optional) Destination address or host name on the command line. The default parameters for the appropriate protocol are assumed and the tracing action begins.

Defaults	The <i>protocol</i> argument is based on the Cisco IOS software examination of the format of the <i>destination</i> argument. For example, if the software finds a <i>destination</i> argument in IP format, the <i>protocol</i> defaults to ip .

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	The trace command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.
	The trace command starts by sending probe datagrams with a TTL value of one. This causes the first router to discard the probe datagram and send back a system message. The trace command sends several probes at each TTL level and displays the round-trip time for each.
	The trace command sends out one probe at a time. Each outgoing packet may result in one or two system messages. A “time exceeded” system message indicates that an intermediate router has seen and discarded the probe. A “destination unreachable” system message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, trace prints an asterisk (*).
	The trace command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with the escape sequence. By default, to invoke the escape sequence, type Ctrl-^ X by simultaneously pressing and releasing the Ctrl , Shift , and 6 keys, and then pressing the X key.

Common Trace Problems

Due to bugs in the IP implementation of various hosts and routers, the IP **trace** command may behave in unexpected ways.

Not all destinations will respond correctly to a probe message by sending back an “ICMP port unreachable” message. A long sequence of TTL levels with only asterisks, terminating only when the maximum TTL has been reached, may indicate this problem.

There is a known problem with the way some hosts handle an “ICMP TTL exceeded” message. Some hosts generate an *ICMP* message but they reuse the TTL of the incoming packet. Since this is zero, the ICMP packets do not make it back. When you trace the path to such a host, you may see a set of TTL values with asterisks (*). Eventually the TTL gets high enough that the “ICMP” message can get back. For example, if the host is six hops away, **trace** will time out on responses 6 through 11.

Trace IP Routes

The following display shows sample IP **trace** output when a destination host name has been specified:

```
Router# trace ip ABA.NYC.mil
```

Type escape sequence to abort.

Tracing the route to ABA.NYC.mil (26.0.0.73)

```
 1 DEBRIS.CISCO.COM (192.180.1.6) 1000 msec 8 msec 4 msec
 2 BARRNET-GW.CISCO.COM (192.180.16.2) 8 msec 8 msec 8 msec
 3 EXTERNAL-A-GATEWAY.STANFORD.EDU (192.42.110.225) 8 msec 4 msec 4 msec
 4 BB2.SU.BARRNET.NET (192.200.254.6) 8 msec 8 msec 8 msec
 5 SU.ARC.BARRNET.NET (192.200.3.8) 12 msec 12 msec 8 msec
 6 MOFFETT-FLD-MB.in.MIL (192.52.195.1) 216 msec 120 msec 132 msec
 7 ABA.NYC.mil (26.0.0.73) 412 msec 628 msec 664 msec
```

Table 104 describes the significant fields shown in the display.

Table 104 trace Field Descriptions

Field	Description
1	Indicates the sequence number of the router in the path to the host.
DEBRIS.CISCO.COM	Host name of this router.
192.180.1.61	Internet address of this router.
1000 msec 8 msec 4 msec	Round-trip time for each of the three probes that are sent.

Table 105 describes the characters that can appear in **trace** output.


Table 105 ip trace Text Characters

Char	Description
<i>nn</i> msec	For each node, the round-trip time (in milliseconds) for the specified number of probes.
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
U	Port unreachable.

Related Commands

Command	Description
trace (privileged)	Probes the routes that packets follow when traveling to their destination from the router.

■ trace (user)



SNMP Commands

This chapter describes Cisco IOS Release 12.2 commands used to configure Simple Network Management Protocol (SNMP) on your routers for the purposes of network monitoring and management.

For SNMP configuration tasks and examples, refer to the “[Configuring SNMP Support](#)” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

no snmp-server

To disable Simple Network Management Protocol (SNMP) agent operation, use the **no snmp-server** global configuration command.

no snmp-server

Syntax Description	This command has no arguments or keywords.

Defaults	None

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command disables all running versions of SNMP (SNMPv1, SNMPv2C, and SNMPv3) on the device.

Examples	The following example disables the current running version of SNMP:

```
Router(config)# no snmp-server
```


show management event

To display the Simple Network Management Protocol (SNMP) Event values that have been configured on your routing device through the use of the Event MIB, use the **show management event** command in privileged EXEC mode.

show management event

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	Privileged EXEC

Command History	Release	Modification
	12.1(3)T	This command was introduced.

Usage Guidelines	The Event MIB allows you to configure your own traps, informs, or set operations through the use of an external network management application. The show management event command is used to display the values for the Events configured on your system. There are no Cisco IOS CLI commands for configuring Event MIB values. For information on Event MIB functionality, see RFC 2981, available at http://www.ietf.org .

Examples	The following example shows sample output of the show management event command:

```
Router# show management event

Mgmt Triggers:
(1): Owner: aseem
    (1): 01, Comment: TestEvent, Sample: Abs, Freq: 120
        Test: Existence Threshold Boolean
        ObjectOwner: aseem, Object: sethi
        OID: ifEntry.10.3, Enabled 1, Row Status 1
        Existence Entry: , Absent, Changed
        StartUp: Present, Absent
        ObjOwn: , Obj: , EveOwn: aseem, Eve: 09
        Boolean Entry:
            Value: 10, Cmp: 1, Start: 1
            ObjOwn: , Obj: , EveOwn: aseem, Eve: 09
        Threshold Entry:
            Rising: 50000, Falling: 20000
            ObjOwn: ase, Obj: 01 RisEveOwn: ase, RisEve: 09 , FallEveOwn: ase, FallEve: 09

Delta Value Table:
(0): Thresh: Rising, Exis: 1, Read: 0, OID: ifEntry.10.3 , val: 69356097

Mgmt Events:
```

■ show management event

```
(1): Owner: aseem
(1)Name: 09 , Comment: , Action: Set, Notify, Enabled: 1 Status: 1
  Notification Entry:
    ObjOwn: , Obj: , OID: ifEntry.10.1
  Set:
    OID: ciscoSyslogMIB.1.2.1.0, SetValue: 199, Wildcard: 2 TAG: , ContextName:

Object Table:
(1): Owner: aseem
(1)Name: sethi, Index: 1, OID: ifEntry.10.1, Wild: 1, Status: 1
```

Related Commands

Command	Description
debug management event	Allows real-time monitoring of Event MIB activities for the purposes of debugging.

show snmp

To check the status of Simple Network Management Protocol (SNMP) communications, use the **show snmp** EXEC command.

show snmp

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command provides counter information for SNMP operations. It also displays the chassis ID string defined with the snmp-server chassis-id global configuration command.

Examples	The following is sample output from the show snmp command:

```
Router# show snmp

Chassis: 01506199
37 SNMP packets input
  0 Bad SNMP version errors
  4 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  24 Number of requested variables
  0 Number of altered variables
  0 Get-request PDUs
  28 Get-next PDUs
  0 Set-request PDUs
78 SNMP packets output
  0 Too big errors (Maximum packet size 1500)
  0 No such name errors
  0 Bad values errors
  0 General errors
  24 Response PDUs
  13 Trap PDUs

SNMP logging: enabled
  Logging to 171.69.58.33.162, 0/10, 13 sent, 0 dropped.

SNMP Manager-role output packets
  4 Get-request PDUs
  4 Get-next PDUs
  6 Get-bulk PDUs
  4 Set-request PDUs
  23 Inform-request PDUs
  30 Timeouts
```

```

    0 Drops
SNMP Manager-role input packets
    0 Inform response PDUs
    2 Trap PDUs
    7 Response PDUs
    1 Responses with errors

SNMP informs: enabled
  Informs in flight 0/25 (current/max)
  Logging to 171.69.217.141.162
    4 sent, 0 in-flight, 1 retries, 0 failed, 0 dropped
  Logging to 171.69.58.33.162
    0 sent, 0 in-flight, 0 retries, 0 failed, 0 dropped

```

Table 106 describes the fields shown in the display.

Table 106 *show snmp Field Descriptions*

Field	Description
Chassis	Chassis ID string.
SNMP packets input	Total number of SNMP packets input.
Bad SNMP version errors	Number of packets with an invalid SNMP version.
Unknown community name	Number of SNMP packets with an unknown community name.
Illegal operation for community name supplied	Number of packets requesting an operation not allowed for that community.
Encoding errors	Number of SNMP packets that were improperly encoded.
Number of requested variables	Number of variables requested by SNMP managers.
Number of altered variables	Number of variables altered by SNMP managers.
Get-request PDUs	Number of get requests received.
Get-next PDUs	Number of get-next requests received.
Set-request PDUs	Number of set requests received.
SNMP packets output	Total number of SNMP packets sent by the router.
Too big errors	Number of SNMP packets which were larger than the maximum packet size.
Maximum packet size	Maximum size of SNMP packets.
No such name errors	Number of SNMP requests that specified a MIB object that does not exist.
Bad values errors	Number of SNMP set requests that specified an invalid value for a MIB object.
General errors	Number of SNMP set requests that failed due to some other error. (It was not a noSuchName error, badValue error, or any of the other specific errors.)
Response PDUs	Number of responses sent in reply to requests.
Trap PDUs	Number of SNMP traps sent.
SNMP logging	Indicates whether logging is enabled or disabled.
sent	Number of traps sent.

Table 106 *show snmp Field Descriptions (continued)*

Field	Description
dropped	Number of traps dropped. Traps are dropped when the trap queue for a destination exceeds the maximum length of the queue, as set by the snmp-server queue-length global configuration command.
SNMP Manager-role output packets	Information related to packets sent by the router as an SNMP manager.
Get-request PDUs	Number of get requests sent.
Get-next PDUs	Number of get-next requests sent.
Get-bulk PDUs	Number of get-bulk requests sent.
Set-request PDUs	Number of set requests sent.
Inform-request PDUs	Number of inform requests sent.
Timeouts	Number of request timeouts.
Drops	Number of requests dropped. Reasons for drops include no memory, a bad destination address, or an unreasonable destination address.
SNMP Manager-role input packets	Information related to packets received by the router as an SNMP manager.
Inform response PDUs	Number of inform request responses received.
Trap PDUs	Number of SNMP traps received.
Response PDUs	Number of responses received.
Responses with errors	Number of responses containing errors.
SNMP informs	Indicates whether SNMP informs are enabled.
Informs in flight	Current and maximum possible number of informs waiting to be acknowledged.
Logging to	Destination of the following informs.
sent	Number of informs sent to this host.
in-flight	Number of informs currently waiting to be acknowledged.
retries	Number of inform retries sent.
failed	Number of informs that were never acknowledged.
dropped	Number of unacknowledged informs that were discarded to make room for new informs.

Related Commands

Command	Description
show snmp pending	Displays the current set of pending SNMP requests.
show snmp sessions	Displays the current SNMP sessions.
snmp-server chassis-id	Provides a message line identifying the SNMP server serial number.
snmp-server manager	Starts the SNMP manager process.
snmp-server manager session-timeout	Sets the amount of time before a nonactive session is destroyed.
snmp-server queue-length	Establishes the message queue length for each trap host.

show snmp engineID

To display the identification of the local Simple Network Management Protocol (SNMP) engine and all remote engines that have been configured on the router, use the **show snmp engineID** EXEC command.

show snmp engineID

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

An SNMP engine is a copy of SNMP that can reside on a local or remote device.

Examples

The following example specifies 00000009020000000C025808 as the local engineID and 123456789ABCDEF000000000 as the remote engine ID, 171.69.37.61 as the IP address of the remote engine (copy of SNMP) and 162 as the port from which the remote device is connected to the local device:

```
router# show snmp engineID
```

```
Local SNMP engineID: 00000009020000000C025808
Remote Engine ID      IP-addr      Port
123456789ABCDEF000000000  171.69.37.61    162
```

[Table 107](#) describes the fields shown in the example.

Table 107 show snmp engineID Field Descriptions

Field	Definition
Local SNMP engine ID	A string that identifies the copy of SNMP on the local device.
Remote Engine ID	A string that identifies the copy of SNMP on the remote device.
IP-addr	The IP address of the remote device.
Port	The port number on the local device to which the remote device is connected.

Related Commands

Command	Description
snmp-server engineID	Configures a name for either the local or remote SNMP engine on the router.

show snmp group

To display the names of groups on the router and the security model, the status of the different views, and the storage type of each group, use the **show snmp group** EXEC command.

show snmp group

Syntax Description	This command has no keywords or arguments.

Command Modes	EXEC

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Examples	The following example specifies the group name as public, the security model as v1, the read view name as vldefault, the notify view name as *tv.FFFFFFFFFF, and the storage type as volatile:

```
router# show snmp group

groupname: public      security model:v1
readview:vldefault
writeview: no writeview specified
notifyview: *tv.FFFFFFFFFF
storage-type: volatile
```

Table 108 describes the fields shown in the example.

Table 108 show snmp group Field Descriptions

Field	Definition
groupname	The name of the SNMP group, or collection of users that have a common access policy.
security model	The security model used by the group, either v1, v2c, or v3.
readview	A string identifying the read view of the group.
writeview	A string identifying the write view of the group.
notifyview	A string identifying the notify view of the group.
storage-type	Indicates whether the settings have been set in volatile or temporary memory on the device, or in nonvolatile or persistent memory where settings will remain after the device has been turned off and on again.

Related Commands	Command	Description
	snmp-server group	Configures a new SNMP group or a table that maps SNMP users to SNMP views.

show snmp pending

To display the current set of pending Simple Network Management Protocol (SNMP) requests, use the **show snmp pending** EXEC command.

show snmp pending

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.3 T	This command was introduced.

Usage Guidelines After the SNMP manager sends a request, the request is “pending” until the manager receives a response or the request timeout expires.

Examples The following is sample output from the **show snmp pending** command:

```
Router# show snmp pending
```

```
req id: 47, dest: 171.69.58.33.161, V2C community: public, Expires in 5 secs
req id: 49, dest: 171.69.58.33.161, V2C community: public, Expires in 6 secs
req id: 51, dest: 171.69.58.33.161, V2C community: public, Expires in 6 secs
req id: 53, dest: 171.69.58.33.161, V2C community: public, Expires in 8 secs
```

[Table 109](#) describes the fields shown in the display.

Table 109 show snmp pending Field Descriptions

Field	Description
req id	ID number of the pending request.
dest	IP address of the intended receiver of the request.
V2C community	SNMP version 2C community string sent with the request.
Expires in	Remaining time before request timeout expires.

Related Commands	Command	Description
	show snmp	Checks the status of SNMP communications.
	show snmp sessions	Displays the current SNMP sessions.
	snmp-server manager	Starts the SNMP manager process.
	snmp-server manager session-timeout	Sets the amount of time before a nonactive session is destroyed.

show snmp sessions

To display the current Simple Network Management Protocol (SNMP) sessions, use the **show snmp sessions** EXEC command.

show snmp sessions [brief]

Syntax Description	brief (Optional) Displays a list of sessions only. Does not display session statistics.

Command Modes	EXEC

Command History	Release	Modification
	11.3 T	This command was introduced.

Usage Guidelines	Sessions are created when the SNMP manager in the router sends SNMP requests, such as inform requests, to a host or receives SNMP notifications from a host. One session is created for each destination host. If there is no further communication between the router and host within the session timeout period, the corresponding session will be deleted.

Examples	The following is sample output from the show snmp sessions command:

```
Router# show snmp sessions

Destination: 171.69.58.33.162, V2C community: public
Round-trip-times: 0/0/0 (min/max/last)
packets output
  0 Gets, 0 GetNexts, 0 GetBulks, 0 Sets, 4 Informs
  0 Timeouts, 0 Drops
packets input
  0 Traps, 0 Informs, 0 Responses (0 errors)
Destination: 171.69.217.141.162, V2C community: public, Expires in 575 secs
Round-trip-times: 1/1/1 (min/max/last)
packets output
  0 Gets, 0 GetNexts, 0 GetBulks, 0 Sets, 4 Informs
  0 Timeouts, 0 Drops
packets input
  0 Traps, 0 Informs, 4 Responses (0 errors)
```

The following is sample output from the **show snmp sessions brief** command:

```
Router# show snmp sessions brief

Destination: 171.69.58.33.161, V2C community: public, Expires in 55 secs
```

[Table 110](#) describes the fields shown in these displays.

Table 110 *show snmp sessions Field Descriptions*

Field	Description
Destination	IP address of the remote agent.
V2C community	SNMP version 2C community string used to communicate with the remote agent.
Expires in	Remaining time before the session timeout expires.
Round-trip-times	Minimum, maximum, and the last round-trip time to the agent.
packets output	Packets sent by the router.
Gets	Number of get requests sent.
GetNexts	Number of get-next requests sent.
GetBulks	Number of get-bulk requests sent.
Sets	Number of set requests sent.
Informs	Number of inform requests sent.
Timeouts	Number of request timeouts.
Drops	Number of packets that could not be sent.
packets input	Packets received by the router.
Traps	Number of traps received.
Informs	Number of inform responses received.
Responses	Number of request responses received.
errors	Number of responses that contained an SNMP error code.

Related Commands

Command	Description
show snmp	Checks the status of SNMP communications.
show snmp pending	Displays the current set of pending SNMP requests.
snmp-server manager	Starts the SNMP manager process.
snmp-server manager session-timeout	Sets the amount of time before a nonactive session is destroyed.

show snmp user

To display information on each Simple Network Management Protocol (SNMP) username in the group username table, use the **show snmp user** EXEC command.

show snmp user

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines An SNMP user is a remote user for which an SNMP management operation is performed. For example, inform operations can be sent to a user on a remote SNMP engine. The user is designated using the **snmp-server user** command.

Examples The following example specifies the username as authuser, the engine ID string as 0000000902000000C025808, and the storage-type as nonvolatile:

```
router# show snmp user
```

```
User name: authuser
Engine ID: 0000000902000000C025808
storage-type: nonvolatile
```

[Table 111](#) describes fields shown in the example.

Table 111 *show snmp user Field Descriptions*

Field	Definition
User name	A string identifying the name of the SNMP user.
Engine ID	A string identifying the name of the copy of SNMP on the device.
storage-type	Indicates whether the settings have been set in volatile or temporary memory on the device, or in nonvolatile or persistent memory where settings will remain after the device has been turned off and on again.

Related Commands	Command	Description
	snmp-server user	Configures a new user to an SNMP group.

snmp-server access-policy

This command is no longer valid. The functionality provided by this command has been removed from the Cisco IOS software.

snmp-server chassis-id

To provide a message line identifying the Simple Network Management Protocol (SNMP) server serial number, use the **snmp-server chassis-id** global configuration command. To restore the default value, if any, use the **no** form of this command.

snmp-server chassis-id *text*

no snmp-server chassis-id

Syntax Description

<i>text</i>	Message you want to enter to identify the chassis serial number.

Defaults

On hardware platforms where the serial number can be machine read, the default is the serial number. For example, a Cisco 7000 router has a default chassis-id value of its serial number.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The Cisco MIB provides a chassis MIB variable that enables the SNMP manager to gather data on system card descriptions, chassis type, chassis hardware version, chassis ID string, software version of ROM monitor, software version of system image in ROM, bytes of processor RAM installed, bytes of NVRAM installed, bytes of NVRAM in use, current configuration register setting, and the value of the configuration register at the next reload. The following installed card information is provided: type of card, serial number, hardware version, software version, and chassis slot number.

The chassis ID message can be seen with the [show snmp](#) command.

Examples

In the following example, the chassis serial number specified is 1234456:

```
Router(config)# snmp-server chassis-id 1234456
```

Related Commands

Command	Description
show snmp	Checks the status of SNMP communications.

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** global configuration command. To remove the specified community string, use the **no** form of this command.

snmp-server community *string* [**view** *view-name*] [**ro** | **rw**] [*number*]

no snmp-server community *string*

Syntax Description

<i>string</i>	Community string that acts like a password and permits access to the SNMP protocol.
view <i>view-name</i>	(Optional) Name of a previously defined view. The view defines the objects available to the community.
ro	(Optional) Specifies read-only access. Authorized management stations are only able to retrieve MIB objects.
rw	(Optional) Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects.
<i>number</i>	(Optional) Integer from 1 to 99 that specifies an access list of IP addresses that are allowed to use the community string to gain access to the SNMP agent.

Defaults

By default, an SNMP community string permits read-only access to all objects.



Note

If the **snmp-server community** command is not used during the SNMP configuration session, it will automatically be added to the configuration after the **snmp host** command is used. In this case, the default password (*string*) for the **snmp-server community** will be taken from the **snmp host** command.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

The **no snmp-server** command disables all versions of SNMP (SNMPv1, SNMPv2C, SNMPv3). The first **snmp-server** command that you enter enables all versions of SNMP.

Examples

The following example assigns the string comaccess to SNMP allowing read-only access and specifies that IP access list 4 can use the community string:

```
Router(config)# snmp-server community comaccess ro 4
```

The following example assigns the string `mgr` to SNMP allowing read-write access to the objects in the restricted view:

```
Router(config)# snmp-server community mgr view restricted rw
```

The following example removes the community `comaccess`:

```
Router(config)# no snmp-server community comaccess
```

The following example disables all versions of SNMP:

```
Router(config)# no snmp-server
```

Related Commands

Command	Description
<code>access-list</code>	Configures the access list mechanism for filtering frames by protocol type or vendor code.
snmp-server view	Creates or updates a view entry.

snmp-server contact

To set the system contact (sysContact) string, use the **snmp-server contact** global configuration command. To remove the system contact information, use the **no** form of this command.

snmp-server contact *text*

no snmp-server contact

Syntax Description	<i>text</i>	String that describes the system contact information.

Defaults	No system contact string is set.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Examples	The following is an example of a system contact string: Router(config)# snmp-server contact Dial System Operator at beeper # 27345

Related Commands	Command	Description
	snmp-server location	Sets the system location string.

snmp-server context

This command is no longer valid. The functionality provided by this command has been removed from the Cisco IOS software.

snmp-server enable informs

This command has no functionality. To enable the sending of Simple Network Management Protocol (SNMP) inform notifications, use one of the **snmp-server enable traps** *notification-type* global configuration commands combined with the **snmp-server host** *host-addr* **informs** global configuration command.

snmp-server enable traps

To enable all Simple Network Management Protocol (SNMP) notifications (traps or informs) available on your system, use the **snmp-server enable traps** global configuration command. To disable all available SNMP notifications, use the **no** form of this command.

snmp-server enable traps [*notification-type*]

no snmp-server enable traps [*notification-type*]

Syntax Description

notification-type

(Optional) Type of notification (trap or inform) to enable or disable. If no type is specified, all notifications available on your device are enabled or disabled. The notification type can be one of the following keywords:

- **config**—Controls configuration notifications, as defined in the CISCO-CONFIG-MAN-MIB (enterprise 1.3.6.1.4.1.9.9.43.2). The notification type is: (1) ciscoConfigManEvent.
- **dls** [**circuit** | **tconn**]—Controls DLSw notifications, as defined in the CISCO-DLSW-MIB (enterprise 1.3.6.1.4.1.9.10.9.1.7). When the dls keyword is used, you can specify the specific notification types you wish to enable or disable. If no keyword is used, all DLSw notification types are enabled. The option can be one of the following keywords:
 - **circuit**—Enables DLSw circuit traps:
 - (5) ciscoDlsTrapCircuitUp
 - (6) ciscoDlsTrapCircuitDown
 - **tconn**—Enables DLSw peer transport connection traps:
 - (1) ciscoDlsTrapTConnPartnerReject
 - (2) ciscoDlsTrapTConnProtViolation
 - (3) ciscoDlsTrapTConnUp
 - (4) ciscoDlsTrapTConnDown
- **ds0-busyout**—Sends notification whenever the busyout of a DS0 interface changes state (Cisco AS5300 platform only). This is from the CISCO-POP-MGMT-MIB (enterprise 1.3.6.1.4.1.9.10.19.2) and the notification type is: (1) cpmDS0BusyoutNotification
- **ds1-loopback**—Sends notification whenever the DS1 interface goes into loopback mode (Cisco AS5300 platform only). This notification type is defined in the CISCO-POP-MGMT-MIB (enterprise 1.3.6.1.4.1.9.10.19.2) as: (2) cpmDS1LoopbackNotification.
- **entity**—Controls Entity MIB modification notifications. This notification type is defined in the ENTITY-MIB (enterprise 1.3.6.1.2.1.47.2) as: (1) entConfigChange.
- **hsrp**—Controls Hot Standby Routing Protocol (HSRP) notifications, as defined in the CISCO-HSRP-MIB (enterprise 1.3.6.1.4.1.9.9.106.2). The notification type is: (1) cHsrpStateChange.

-
- **ipmulticast**—Controls IP Multicast notifications.
 - **modem-health**—Controls modem-health notifications.
 - **rsvp**—Controls Resource Reservation Protocol (RSVP) notifications.
 - **rtr**—Controls Service Assurance Agent / Response Time Reporter (RTR) notifications.
 - **syslog**—Controls error message notifications (Cisco Syslog MIB). Specify the level of messages to be sent with the **logging history level** command.
 - **xgcp**—Sends External Media Gateway Control Protocol (XGCP) notifications. This notification is from the XGCP-MIB-V1SMI.my and the notifications are: enterprise 1.3.6.1.3.90.2 (1) xgcpUpDownNotification
-

Defaults

This command is disabled by default. Most notification types are disabled. However, some notification types cannot be controlled with this command.

If you enter this command with no *notification-type* keywords, the default is to enable all notification types controlled by this command.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced with the frame-relay , isdn , and envmon trap types.
12.0(2)T	The rsvp keyword was added.
12.0(3)T	The hsrp keyword was added.

Usage Guidelines

For additional notification types, see the Related Commands table for this command.

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. To specify whether the notifications should be sent as traps or informs, use the **snmp-server host [traps | informs]** command.

If you do not enter an **snmp-server enable traps** command, no notifications controlled by this command are sent. In order to configure the router to send these SNMP notifications, you must enter at least one **snmp-server enable traps** command. If you enter the command with no keywords, all notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled. In order to enable multiple types of notifications, you must issue a separate **snmp-server enable traps** command for each notification type and notification option.

The **snmp-server enable traps** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to send all traps to the host specified by the name myhost.cisco.com, using the community string defined as public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com public
```

The following example enables the router to send Frame Relay and environmental monitor traps to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps frame-relay
Router(config)# snmp-server enable traps envmon temperature
Router(config)# snmp-server host myhost.cisco.com public
```

The following example will not send traps to any host. The BGP traps are enabled for all hosts, but the only traps enabled to be sent to a host are ISDN traps (which are not enabled in this example).

```
Router(config)# snmp-server enable traps bgp
Router(config)# snmp-server host bob public isdn
```

The following example enables the router to send all inform requests to the host at the address myhost.cisco.com, using the community string defined as public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

The following example sends HSRP MIB traps to the host myhost.cisco.com using the community string public.

```
Router(config)# snmp-server enable traps hsrp
Router(config)# snmp-server host myhost.cisco.com traps version 2c public hsrp
```

Related Commands

Command	Description
snmp-server enable traps atm pvc	Controls (enables or disables) ATM PVC SNMP notifications.
snmp-server enable traps bgp	Controls (enables or disables) BGP server state change SNMP notifications.
snmp-server enable traps calltracker	Controls (enables or disables) Call Tracker callSetup and callTerminate SNMP notifications.
snmp-server enable traps envmon	Controls (enables or disables) environmental monitor SNMP notifications.
snmp-server enable traps frame-relay	Controls (enables or disables) Frame Relay DLCI link status change SNMP notifications.
snmp-server enable traps isdn	Controls (enables or disables) ISDN SNMP notifications.
snmp-server enable traps snmp	Controls (enables or disables) RFC 1157 SNMP notifications.
snmp-server enable traps repeater	Controls (enables or disables) RFC 1516 Hub notifications.
snmp-server host	Specifies whether you want the SNMP notifications sent as traps or informs, the version of SNMP to use, the security level of the notifications (for SNMPv3), and the recipient (host) of the notifications.
snmp-server informs	Specifies inform request options.

Command	Description
snmp-server trap-source	Specifies the interface (and hence the corresponding IP address) that an SNMP trap should originate from.
snmp trap illegal-address	Issues an SNMP trap when a MAC address violation is detected on an Ethernet hub port of a Cisco 2505, Cisco 2507, or Cisco 2516 router.

snmp-server enable traps aaa_server

To enable authentication, authorization, and accounting (AAA) server state-change Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps aaa_server** global configuration command. To disable AAA sever state-change SNMP notifications, use the **no** form of this command.

snmp-server enable traps aaa_server

no snmp-server enable traps aaa_server

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP notifications are disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(3)T	This command was introduced for the Cisco AS5300 and Cisco AS5800.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) AAA Server state change (casServerStateChange) notifications. ServerStateChange notifications, when enabled, will be sent when the server moves from an “up” to “dead” state or when a server moves from a “dead” to “up” state.

The Cisco AAA Server State is defined by the casState object in the Cisco AAA Server MIB. The possible values are as follows:

- up(1)—Server is responding to requests.
- dead(2)—Server failed to respond to requests.

A server is marked "dead" if it does not respond after maximum retransmissions. A server is marked "up" again either after a waiting period or if some response is received from it. The initial value of casState is "up(1)" at system startup. This will only transition to "dead(2)" if an attempt to communicate fails.

For a complete description of this notification and additional MIB functions, see the CISCO-AAA-SERVER-MIB.my file, available on Cisco.com at <http://www.cisco.com/public/mibs/v2/>.

The **snmp-server enable traps aaa_sever** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to send AAA Server up/down informs to the host at the address myhost.cisco.com using the community string defined as public:

snmp-server enable traps aaa_server

```
Router(config)# snmp-server enable traps aaa_server
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

Related Commands

Command	Description
aaa session-mib disconnect	Allows a remote network management system to perform Set operations and disconnect users on the configured device using SNMP.
show caller	Displays caller information for Async, Dialer, and Serial interfaces.
show radius statistics	Displays AAA Server MIB statistics for AAA functions.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps atm pvc

To enable the sending of ATM permanent virtual circuit (PVC) Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps atm pvc** global configuration command. To disable ATM PVC-specific SNMP notifications, use the **no** form of this command.

snmp-server enable traps atm pvc [*interval seconds*] [*fail-interval seconds*]

no snmp-server enable traps atm pvc

Syntax Description

interval <i>seconds</i>	(Optional) Minimum period between successive traps, in the range from 1 to 3600. Generation of PVC traps is dampened by the notification interval in order to prevent trap storms. No traps are sent until the interval lapses.
fail-interval <i>seconds</i>	(Optional) Minimum period for storing the failed time stamp, in the range from 0 to 3600.

Defaults

SNMP notifications are disabled by default.

The default **interval** is 30.

The default **fail-interval** is 0.

Command Modes

Global configuration

Command History

Release	Modification
12.0(1)T	This command was introduced for those platforms that support ATM PVC Management.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. ATM notifications are defined in the CISCO-IETF-ATM2-PVCTRAP-MIB.my file, available from the Cisco FTP site at <ftp://www.cisco.com/public/mibs/v2/>.

ATM PVC failure notification are sent when a PVC on an ATM interface fails or leaves the UP operational state. Only one trap is generated per hardware interface, within the specified interval defined by the **interval** keyword (stored as the atmIntfPvcNotificationInterval in the MIB). If other PVCs on the same interface go DOWN during this interval, traps are generated and held until the **fail-interval** has elapsed. Once the interval has elapsed, the traps are sent if the PVCs are still DOWN.

No notifications are generated when a PVC returns to the UP state after having been in the DOWN state. If you need to detect the recovery of PVCs, you must use the SNMP management application to regularly poll your router.

The **snmp-server enable traps atm pvc** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.

Examples

The following example shows the enabling of ATM PVC traps on a router, so that if PVC 0/1 goes down, host 172.16.61.90 will receive the notifications:

```
!For ATM PVC Trap Support to work on your router, you must first have SNMP support and
!an IP routing protocol configured on your router:
Router(config)# snmp-server community public ro
Router(config)# snmp-server host 172.16.61.90 public
Router(config)# ip routing
Router(config)# router igrp 109
Router(config-router)# network 172.16.0.0
!
!Enable ATM PVC Trap Support and OAM management:
Router(config)# snmp-server enable traps atm pvc interval 40 fail-interval 10
Router(config)# interface atm 1/0.1
Router(config-if)# pvc 0/1
Router(config-if-atm-vc)# oam-pvc manage
```

Related Commands

Command	Description
show atm pvc	Displays all ATM permanent virtual circuits (PVCs) and traffic information.
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps bgp

To enable Border Gateway Protocol (BGP) state-change Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps bgp** global configuration command. To disable BGP state-change SNMP notifications, use the no form of this command.

snmp-server enable traps bgp

no snmp-server enable traps bgp

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP notifications are disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(3)T	This command was introduced for the Cisco AS5300 and Cisco AS5800.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) Border Gateway Protocol server state change notifications, as defined in the BGP4-MIB (enterprise 1.3.6.1.2.1.15.7). The notifications types are:

- (1) bgpEstablished
- (2) bgpBackwardTransition.

The BGP notifications are defined in the BGP-4 MIB as follows:

```
bgpTraps                                OBJECT IDENTIFIER ::= { bgp 7 }

bgpEstablished NOTIFICATION-TYPE
    OBJECTS { bgpPeerLastError,
              bgpPeerState          }
    STATUS current
    DESCRIPTION
        "The BGP Established event is generated when
         the BGP FSM enters the ESTABLISHED state."
    ::= { bgpTraps 1 }

bgpBackwardTransition NOTIFICATION-TYPE
    OBJECTS { bgpPeerLastError,
              bgpPeerState          }
    STATUS current
    DESCRIPTION
        "The BGPBackwardTransition Event is generated
         when the BGP FSM moves from a higher numbered
         state to a lower numbered state."
    ::= { bgpTraps 2 }
```

For a complete description of these notifications and additional MIB functions, see the BGP4-MIB.my file, available through the Cisco FTP site at <ftp://www.cisco.com/public/mibs/v2/>.

**Note**

You may notice incorrect BGP trap OID output when using the SNMP version 1 BGP4-MIB that is available for download at <ftp://ftp.cisco.com/pub/mibs/v1/BGP4-MIB-V1SML.my>. When a router sends out BGP traps (notifications) about state changes on an SNMP version 1 monitored BGP peer, the enterprise OID is incorrectly displayed as .1.3.6.1.2.1.15 (bgp) instead of .1.3.6.1.2.1.15.7 (bgpTraps). The problem is not due to any error with Cisco IOS software. This problem occurs because the BGP4-MIB does not follow RFC 1908 rules regarding version 1 and version 2 trap compliance. This MIB is controlled by IANA under the guidance of the IETF, and work is currently in progress by the IETF to replace this MIB with a new version that represents the current state of the BGP protocol. In the meantime, we recommend that you use the SNMP version 2 BGP4-MIB or the CISCO-BGP4-MIB to avoid an incorrect trap OID.

The **snmp-server enable traps bgp** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to send BGP state change informs to the host at the address myhost.cisco.com using the community string defined as public:

```
Router(config)# snmp-server enable traps bgp
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

Related Commands

Command	Description
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps calltracker

To enable Call Tracker CallSetup and Call Terminate Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps calltracker** global configuration command. To disable Call Tracker SNMP notifications, use the **no** form of this command.

snmp-server enable traps calltracker

no snmp-server enable traps calltracker

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP notifications are disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(3)T	This command was introduced for the Cisco AS5300 and Cisco AS580 access servers.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) Call Tracker CallSetup and CallTerminate notifications. CallSetup notifications are generated at the start of each call, when an entry is created in the active table (cctActiveTable), and CallTerminate notifications are generated at the end of each call, when an entry is created in the history table (cctHistoryTable).

For a complete description of these notifications and additional MIB functions, refer to the CISCO-CALL-TRACKER-MIB.my file, available on Cisco.com at <http://www.cisco.com/public/mibs/v2/>.

The **snmp-server enable traps calltracker** command is used in conjunction with the **snmp-server host** global configuration command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to send call-start and call-stop informs to the host at the address myhost.cisco.com using the community string defined as public:

```
Router(config)# snmp-server enable traps calltracker
Router(config)# snmp-server host myhost.cisco.com informs version 2c public calltracker
```

Related Commands

Command	Description
calltracker call-record	Enables call record SYSLOG generation for the purpose of debugging, monitoring, or externally saving detailed call record information.
calltracker enable	Enables the Call Tracker feature on an access server.
isdn snmp busyout b-channel	Enables PRI B channels to be busied out via SNMP.
show call calltracker	Displays Call Tracker activity and configuration information such as the number of active calls and the history table attributes.
show modem calltracker	Displays all of the information stored within the Call Tracker Active or History Database for the latest call assigned to specified modem.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps envmon

To enable Environmental Monitor Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps envmon** global configuration command. To disable environmental monitor SNMP notifications, use the **no** form of this command.

snmp-server enable traps envmon [shutdown] [voltage] [temperature] [fan] [supply]

no snmp-server enable traps envmon [shutdown] [voltage] [temperature] [fan] [supply]

Syntax Description	
shutdown	(Optional) Controls shutdown notifications. A ciscoEnvMonShutdownNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.13.3.1) is sent if the environmental monitor detects a testpoint reaching a critical state and is about to initiate a shutdown.
voltage	(Optional) Controls voltage notifications. A ciscoEnvMonVoltageNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.13.3.2) is sent if the voltage measured at a given testpoint is outside the normal range for the testpoint (i.e. is at the warning, critical, or shutdown stage). For access servers, this notification is defined as the caemVoltageNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.61.2.2).
temperature	(Optional) Controls temperature notifications. A ciscoEnvMonTemperatureNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.13.3.3) is sent if the temperature measured at a given testpoint is outside the normal range for the testpoint (i.e. is at the warning, critical, or shutdown stage). For access servers, this notification is defined as the caemTemperatureNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.61.2.1).
fan	(Optional) Controls fan failure notifications. A ciscoEnvMonFanNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.13.3.4) is sent if any one of the fans in a fan array fails.
supply	(Optional) Controls Redundant Power Supply (RPS) failure notifications. A ciscoEnvMonRedundantSupplyNotification (enterprise MIB OID 1.3.6.1.4.1.9.9.13.2.5) is sent if a redundant power supply fails.

Defaults	SNMP notifications are disabled by default.

Command Modes	Global configuration

Command History	Release	Modification
	10.3	This command was introduced.
	11.3(6)AA	Support for this command was introduced for the Cisco AS5300 access server.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) Environmental Monitor (EnvMon) status notifications for supported systems. Cisco enterprise EnvMon notifications are triggered when an environmental threshold is exceeded. If none of the optional keywords are specified, all available environmental notifications are enabled.

For a complete description of these notifications and additional MIB functions, see the CISCO-ENVMON-MIB.my and CISCO-ACCESS-ENVMON-MIB.my files, available on Cisco.com at <http://www.cisco.com/public/mibs/v2/>.

Status of the Environmental Monitor can be viewed using the **show environment** command.

The **snmp-server enable traps envmon** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables a Cisco 12000 GSR to send environmental failure informs to the host at the address myhost.cisco.com using the community string defined as public:

```
Router(config)# snmp-server enable traps envmon
Router(config)# snmp-server host myhost.cisco.com informs version 2c public envmon
```

Related Commands

Command	Description
show environment	Displays environmental conditions on the system.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps frame-relay

To enable Frame Relay DLCI link status Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps frame-relay** global configuration command. To disable Frame Relay link status SNMP notifications, use the **no** form of this command.

snmp-server enable traps frame-relay

no snmp-server enable traps frame-relay

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP notifications are disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) Data Link Connection Identifier (DLCI) Frame Relay notifications, as defined in the RFC1315-MIB (enterprise 1.3.6.1.2.1.10.32).

The notification type is frDLCIStatusChange (1). This trap indicates that the indicated Virtual Circuit (VC) has changed state, meaning that the VC has either been created or invalidated, or has toggled between the active and inactive states.



Note

For large scale configurations (systems containing hundreds of Frame Relay point-to-point subinterfaces), note that having Frame Relay notifications enabled could potentially have a negative impact on network performance when there are line status changes.

For a complete description of this notification and additional MIB functions, see the RFC1315-MIB.my file and the CISCO-FRAME-RELAY-MIB.my file, available in the “v1” and “v2” directories, respectively, at the Cisco.com MIB web site at <http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>.

The **snmp-server enable traps frame-relay** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

In the following example the router is configured to send Frame Relay DLCI state change informs to the host at the address myhost.cisco.com using the community string defined as public:

■ snmp-server enable traps frame-relay

```
Router(config)# snmp-server enable traps frame-relay
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

Related Commands

Command	Description
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps isdn

To enable the sending of Integrated Services Digital Network (ISDN) specific Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps isdn** global configuration command. To disable ISDN-specific SNMP notifications, use the **no** form of this command.

snmp-server enable traps isdn [**call-information**] [**chan-not-avail**] [**isdnu-interface**] [**layer2**]

no snmp-server enable traps isdn [**call-information**] [**chan-not-avail**] [**isdnu-interface**] [**layer2**]

Syntax Description	
call-information	(Optional) Controls SNMP ISDN call information notifications, as defined in the CISCO-ISDN-MIB (enterprise 1.3.6.1.4.1.9.9.26.2). Notification types are: • demandNbrCallInformation (1) This notification is sent to the manager whenever a successful call clears, or a failed call attempt is determined to have ultimately failed. In the event that call retry is active, then this is after all retry attempts have failed. However, only one such notification is sent in between successful call attempts; subsequent call attempts do not generate notifications of this type. • demandNbrCallDetails (2) This notification is sent to the manager whenever a call connects, or clears, or a failed call attempt is determined to have ultimately failed. In the event that call retry is active, then this is after all retry attempts have failed. However, only one such notification is sent in between successful call attempts; subsequent call attempts do not generate notifications of this type.
chan-not-avail	(Optional) Controls SNMP ISDN channel-not-available notifications. ISDN PRI channel-not-available traps are generated when a requested DS-0 channel is not available, or when there is no modem available to take the incoming call. These notifications are available only for ISDN PRI interfaces.
isdnu-interface	(Optional) Controls SNMP ISDN U interface notifications.
layer2	(Optional) Controls SNMP ISDN layer2 transition notifications.

Defaults

SNMP notifications are disabled by default.

If you enter this command with none of the optional keywords, all available notifications are enabled.

Command Modes

Global configuration

Command History

Release	Modification
10.3	The snmp-server enable traps isdn command was introduced.
11.3	The call-information and isdnu-interface keywords were added for the Cisco 1600 series router.

Release	Modification
12.0	Support for the call-information and isdnu-interface keywords was introduced for most voice platforms.
12.1(5)T	Support for the isdn chan-not-available option was added for the Cisco AS5300, Cisco AS5400, and Cisco AS5800 access servers only.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. ISDN notifications are defined in the CISCO-ISDN-MIB.my and CISCO-ISDNU-IF-MIB.my files, available on Cisco.com at <http://www.cisco.com/public/mibs/v2/>.

Availability of notifications will depend on your platform. To see what notifications are available, use the **snmp-server enable traps isdn ?** command.

If you do not enter an **snmp-server enable traps isdn** command, no notifications controlled by this command are sent. In order to configure the router to send these SNMP notifications, you must enter at least one **snmp-server enable traps isdn** command. If you enter the command with no keywords, all notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled.

The **snmp-server enable traps snmp** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example shows the checking of what notification types are available on a Cisco AS5300, and the enabling of channel-not-available and layer2 informs:

```
NAS(config)#snmp-server enable traps isdn ?
  call-information  Enable SNMP isdn call information traps
  chan-not-avail    Enable SNMP isdn channel not avail traps
  layer2            Enable SNMP isdn layer2 transition traps
  <cr>

NAS(config)#snmp-server enable traps isdn chan-not-avail layer2
NAS(config)#snmp-server host myhost.cisco.com informs version 2c public isdn
```

Related Commands

Command	Description
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server informs	Specifies inform request options.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps snmp

To enable the sending of RFC 1157 Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps snmp** global configuration command. To disable RFC 1157 SNMP notifications, use the **no** form of this command.

snmp-server enable traps snmp [authentication] [linkup] [linkdown] [coldstart] [warmstart]

no snmp-server enable traps snmp [authentication] [linkup] [linkdown] [coldstart]
[warmstart]

Syntax Description	
authentication	(Optional) Controls the sending of SNMP authentication failure notifications. An authenticationFailure(4) trap signifies that the sending device is the addressee of a protocol message that is not properly authenticated. The authentication method depends on the version of SNMP being used. For SNMPv1 or SNMPv2c, authentication failure occurs for packets with an incorrect community string. For SNMPv3, authentication failure occurs for packets with an incorrect SHA/MD5 authentication key or for a packet that is outside of the authoritative SNMP engine's window (for example, falls outside of configured access lists or time ranges).
linkup	(Optional) Controls the sending of SNMP linkUp notifications. A linkUp(3) trap signifies that the sending device recognizes that one of the communication links represented in the agent's configuration has come up.
linkdown	(Optional) Controls the sending of SNMP linkDown notifications. A linkDown(2) trap signifies that the sending device recognizes a failure in one of the communication links represented in the agent's configuration.
coldstart	(Optional) Controls the sending of SNMP coldStart notifications. A coldStart(0) trap signifies that the sending device is reinitializing itself such that the agent's configuration or the protocol entity implementation may be altered.
warmstart	(Optional) Controls the sending of SNMP warmStart notifications. A warmStart(1) trap signifies that the sending device is reinitializing itself such that neither the agent configuration nor the protocol entity implementation is altered.

Defaults

SNMP notifications are disabled by default.

If you enter this command with none of the optional keywords, all RFC 1157 SNMP notifications are enabled (or disabled, if using the **no** form).

Command Modes

Global configuration

Command History

Release	Modification
11.3	The snmp-server enable traps snmp authentication command was introduced. This command replaced the snmp-server trap-authentication command.
12.1(3)T	The following keywords were added: • linkup • linkdown • coldstart
12.1(5)T	The warmstart keyword was added.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types.

If you do not enter an **snmp-server enable traps snmp** command, no notifications controlled by this command are sent. In order to configure the router to send these SNMP notifications, you must enter at least one **snmp-server enable traps snmp** command. If you enter the command with no keywords, all notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled.

The **snmp-server enable traps snmp** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.

For a host to receive a notification controlled by this command, both the **snmp-server enable traps** command and the **snmp-server host** command for that host must be enabled. If the notification type is not controlled by this command, just the appropriate **snmp-server host** command must be enabled.

The **snmp-server enable traps snmp [linkup] [linkdown]** form of this command globally enables or disables SNMP linkUp and linkDown traps. After enabling either of these traps globally, you can disable these traps on specific interfaces using the **no snmp trap link-status** command in interface configuration mode. Note that on the interface level, linkUp and linkDown traps are enabled by default. This means that you do not have to enable these notifications on a per-interface basis. However, linkUp and linkDown notifications will not be sent unless you enable them globally using the **snmp-server enable traps snmp** command.

Examples

The following example enables the router to send all traps to the host `myhost.cisco.com`, using the community string defined as `public`:

```
Router(config)# snmp-server enable traps snmp
Router(config)# snmp-server host myhost.cisco.com public snmp
```

The following example enables the router to send all inform notifications to the host `myhost.cisco.com` using the community string defined as `public`:

```
Router(config)# snmp-server enable traps snmp
Router(config)# snmp-server host myhost.cisco.com informs version 2c public snmp
```

The following example shows the enabling all SNMP trap types, then the disabling of only the linkUp and linkDown traps.

```
Router> enable
Password:
Router# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# snmp-server enable traps snmp
Router(config)# end
Router# more system:running-config | include traps snmp
snmp-server enable traps snmp authentication linkup linkdown coldstart warmstart

Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# no snmp-server enable traps snmp linkup linkdown
Router(config)# end
Router# more system:running-config | include traps snmp
snmp-server enable traps snmp authentication coldstart warmstart
```

Related Commands

Command	Description
snmp-server enable traps	Enables all available SNMP notifications on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server informs	Specifies inform request options.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps repeater

To enable or disable standard repeater (hub) Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps repeater** global configuration command. To disable repeater notifications, use the **no** form of this command.

snmp-server enable traps repeater [health] [reset]

no snmp-server enable traps repeater [health] [reset]

Syntax Description	health	(Optional) The rptrHealth trap conveys information related to the operational status of the repeater. This trap is sent either when the value of rptrOperStatus changes, or upon completion of a non-disruptive test. The rptrOperStatus object indicates the operational state of the repeater. Status values are as follows: - other(1)—undefined or unknown status - ok(2)—no known failures - rpترFailure(3)—repeater-related failure - groupFailure(4)—group-related failure - portFailure(5)—port-related failure - generalFailure(6)—failure, unspecified type
	reset	(Optional) The rpترResetEvent trap is sent on completion of a repeater reset action (triggered by the transition to a START state by a manual command). The rpترResetEvent trap is not sent when the agent restarts and sends an SNMP coldStart or warmStart trap.

Defaults	SNMP notifications are disabled by default. If no keywords are specified, all repeater notifications available on your system are enabled or disabled.

Command Modes	Global configuration

Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines	SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests. This command controls (enables or disables) Repeater MIB notifications, as defined in RFC 1516. RFC 1516 defines objects for managing IEEE 802.3 10 Mbps baseband repeaters, also known as hubs.

There are two sets of notifications available for this command. The following notification is defined in the CISCO-REPEATER-MIB (enterprise 1.3.6.1.4.1.9.9.22.3):

- 1 ciscoRptrIllegalSrcAddrTrap (illegal source address trap)

The following notifications are defined in the CISCO-REPEATER-MIB-V1SMI (enterprise 1.3.6.1.2.1.22):

- 1 rpтрHealth
- 2 rpтрGroupChange
- 3 rpтрResetEvent

For a complete description of the repeater notifications and additional MIB functions, refer to the CISCO-REPEATER-MIB.my and CISCO-REPEATER-MIB-V1SMI.my files, available on Cisco.com at <http://www.cisco.com/public/mibs/>.

The **snmp-server enable traps repeater** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to send repeater inform notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
Router(config)# snmp-server enable traps repeater
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

Related Commands

Command	Description
snmp-server host	Specifies the recipient of an SNMP notification operation.
snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server enable traps voice poor-qov

To enable poor quality of voice Simple Network Management Protocol (SNMP) notifications, use the **snmp-server enable traps voice poor-qov** global configuration command. To disable poor quality of voice SNMP notifications, use the **no** form of this command.

snmp-server enable traps voice poor-qov

no snmp-server enable traps voice poor-qov

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP notifications are disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(3)T	This command was introduced for the Cisco AS5300 and Cisco AS5800.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests.

This command controls (enables or disables) poor-quality-of-voice notifications. The poor-quality-of-voice notification is defined in CISCO-VOICE-DIAL-CONTROL-MIB as follows:

enterprise 1.3.6.1.4.1.9.9.63.2

(1) cvdcPoorQoVNotification

For a complete description of this notification and additional MIB functions, see the CISCO-VOICE-DIAL-CONTROL-MIB.my file, available on Cisco.com at <http://www.cisco.com/public/mibs/v2/>.

The **snmp-server enable traps voice poor-qov** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send SNMP notifications, you must configure at least one **snmp-server host** command.

Examples

The following example enables the router to poor-quality-of-voice informs to the host at the address myhost.cisco.com using the community string defined as public:

```
Router(config)# snmp-server enable traps voice poor-qov
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

Related Commands	Command	Description
	snmp-server host	Specifies the recipient of an SNMP notification operation.
	snmp-server trap-source	Specifies the interface that an SNMP trap should originate from.

snmp-server engineID

To configure a name for either the local or remote Simple Network Management Protocol (SNMP) engine on the router, use the **snmp-server engineID** global configuration command. To remove the configured engine ID, use the **no** form of this command.

```
snmp-server engineID {local engineid-string |  
remote ip-address [udp-port port] engineid-string}
```

```
no snmp-server engineID
```

Syntax Description

local	Specifies the local copy of SNMP on the router. (You must specify either local or remote .)
<i>engineid-string</i>	The name of a copy of SNMP.
remote	Specifies the remote copy of SNMP on the router. (You must specify either local or remote .)
<i>ip-address</i>	The IP address of the device that contains the remote copy of SNMP.
udp-port	(Optional) Specifies a UDP port of the host to use.
<i>port</i>	(Optional) The socket number on the remote device that contains the remote copy of SNMP.

Defaults

An SNMP engine ID is generated automatically but is not displayed or stored in the running configuration. You can display the default or configured engine ID by using the **show snmp engineID EXEC** command.

The default **udp-port** for remote engines is 161.

Command Modes

Global configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

Note that you need not specify the entire 24-character engine ID if it contains trailing zeros. Specify only the portion of the Engine ID up until the point where only zeros remain in the value. To configure an engine ID of 123400000000000000000000, you can specify the value 1234, for example, **snmp-server engineID local 1234**.

Changing the value of snmpEngineID has important side-effects. A user's password (entered on the command line) is converted to an MD5 or SHA security digest. This digest is based on both the password and the local engine ID. The command line password is then destroyed, as required by RFC 2274. Because of this deletion, if the local value of engineID changes, the security digests of SNMPv3 users will be invalid, and the users will have to be reconfigured.

Similar restrictions require the reconfiguration of community strings when the engine ID changes. A remote engine ID is required when an SNMPv3 inform is configured. The remote engine ID is used to compute the security digest for authenticating and encrypting packets sent to a user on the remote host. Please refer to the examples in the Configuring Informs section in the [snmp-server host](#) command reference page.

Related Commands

Command	Description
show snmp engineID	Displays the identification of the local SNMP engine and all remote engines that have been configured on the router.
snmp-server host	Specifies the recipient (SNMP manager) of an SNMP trap notification.

snmp-server group

To configure a new Simple Network Management Protocol (SNMP) group, or a table that maps SNMP users to SNMP views, use the **snmp-server group** global configuration command. To remove a specified SNMP group, use the **no** form of this command.

```
snmp-server group groupname { v1 | v2c | v3 { auth | noauth | priv } } [read readview]
[write writeview] [notify notifyview] [access access-list]
```

```
no snmp-server group
```

Syntax Description

<i>groupname</i>	The name of the group.
v1	The least secure of the possible security models.
v2c	The second least secure of the possible security models. It allows for the transmission of informs and counter 64, which allows for integers twice the width of what is normally allowed.
v3	The most secure of the possible security models.
auth	Specifies authentication of a packet without encrypting it.
noauth	Specifies no authentication of a packet.
priv	Specifies authentication of a packet with encryption.
read	(Optional) The option that allows you to specify a read view.
<i>readview</i>	A string (not to exceed 64 characters) that is the name of the view that enables you only to view the contents of the agent.
write	(Optional) The option that allows you to specify a write view.
<i>writeview</i>	A string (not to exceed 64 characters) that is the name of the view that enables you to enter data and configure the contents of the agent.
notify	(Optional) The option that allows you to specify a notify view
<i>notifyview</i>	A string (not to exceed 64 characters) that is the name of the view that enables you to specify a notify, inform, or trap.
access	(Optional) The option that enables you to specify an access list.
<i>access-list</i>	A string (not to exceed 64 characters) that is the name of the access list.

Defaults

Table 112 describes default values for the different views.

Table 112 snmp-server group Default Descriptions

Default	Definition
<i>readview</i>	Assumed to be every object belonging to the Internet (1.3.6.1) OID space, unless the user uses the read option to override this state.

Table 112 *snmp-server group Default Descriptions (continued)*

Default	Definition
<i>writeview</i>	Nothing is defined for the write view (that is, the null OID). You must configure write access.
<i>notifyview</i>	Nothing is defined for the notify view (that is, the null OID). If a view is specified, any notifications in that view that are generated will be sent to all users associated with the group (provided an SNMP server host configuration exists for the user).

Command Modes Global configuration

Command History	Release	Modification
	11.(3)T	This command was introduced.

Usage Guidelines When a community string is configured internally, two groups with the name public are autogenerated, one for the v1 security model and the other for the v2c security model. Similarly, deleting a community string will delete a v1 group with the name public and a v2c group with the name public.

Configuring Notify Views

Do not specify a notify view when configuring an SNMP group for the following reasons:

- The **snmp-server host** command autogenerates a notify view for the user, and then adds it to the group associated with that user.
- Modifying the group's notify view will affect all users associated with that group.

The *notifyview* option is available for two reasons:

- If a group has a notify view that is set using SNMP, you may need to change the notify view.
- The **snmp-server host** command may have been configured before the **snmp-server group** command. In this case, you must either reconfigure the **snmp-server host** command, or specify the appropriate notify view.

Instead of specifying the notify view for a group as part of the **snmp-server group** command, use the following commands in global configuration mode:

Step	Command	Purpose
1.	snmp-server user	Configures an SNMP user.
2.	snmp-server group	Configures an SNMP group, without adding a notify view.
3.	snmp-server host	Autogenerates the notify view by specifying the recipient of a trap operation.

Working with Passwords and Digests

No default values exist for authentication or privacy algorithms when you configure the command. Also, no default passwords exist. The minimum length for a password is one character, although Cisco recommends using eight characters for security. If you forget a password, you cannot recover it and will need to reconfigure the user. You can specify either a plain-text password or a localized MD5 digest.

The following example shows how to enter a plain-text password for the string `arizona2` for user `John` in group `Johngroup`, type the following command line:

```
snmp-server user John Johngroup v3 auth md5 arizona2
```

When you enter a **show running-config** command, you will not see a line for this user. To see if this user has been added to the configuration, type the **show snmp user** command.

If you have the localized MD5 or SHA digest, you can specify that string instead of the plain-text password. The digest should be formatted as `aa:bb:cc:dd` where `aa`, `bb`, and `cc` are hex values. Also, the digest should be exactly 16 octets long.

The following example shows how to specify the command with a digest name of `00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF`:

```
Router(config)# snmp-server user John Johngroup v3 encrypted auth md5  
00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF
```

Related Commands

Command	Description
show snmp group	Displays the names of groups on the router and the security model, the status of the different views, and the storage type of each group.

snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command. To remove the specified host, use the **no** form of this command.

```
snmp-server host host-addr [traps | informs] [version { 1 | 2c | 3 [auth | noauth | priv] } ]
community-string [udp-port port] [notification-type]
```

```
no snmp-server host host [traps | informs]
```

Syntax Description	
<i>host-addr</i>	Name or Internet address of the host (the targeted recipient).
traps	(Optional) Sends SNMP traps to this host. This is the default.
informs	(Optional) Sends SNMP informs to this host.
version	(Optional) Version of the SNMP used to send the traps. Version 3 is the most secure model, because it allows packet encryption with the priv keyword. If you use the version keyword, one of the following must be specified: • 1—SNMPv1. This option is not available with informs. • 2c—SNMPv2C. • 3—SNMPv3. The following three optional keywords can follow the version 3 keyword: – auth (Optional). Enables Message Digest 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication – noauth (Default). The noAuthNoPriv security level. This is the default if the [auth noauth priv] keyword choice is not specified. – priv (Optional). Enables Data Encryption Standard (DES) packet encryption (also called “privacy”).
<i>community-string</i>	Password-like community string sent with the notification operation. Though you can set this string using the snmp-server host command by itself, we recommend you define this string using the snmp-server community command prior to using the snmp-server host command.
udp-port <i>port</i>	(Optional) UDP port of the host to use. The default is 162.

<i>notification-type</i>	(Optional) Type of notification to be sent to the host. If no type is specified, all notifications are sent. The notification type can be one or more of the following keywords: • bgp—Sends Border Gateway Protocol (BGP) state change notifications. • calltracker—Sends Call Tracker call-start/call-end notifications. • config—Sends configuration notifications. • dspu—Sends downstream physical unit (DSPU) notifications. • entity—Sends Entity MIB modification notifications. • envmon—Sends Cisco enterprise-specific environmental monitor notifications when an environmental threshold is exceeded. • frame-relay—Sends Frame Relay notifications. • hsrp—Sends Hot Standby Routing Protocol (HSRP) notifications. • isdn—Sends Integrated Services Digital Network (ISDN) notifications. • llc2—Sends Logical Link Control, type 2 (LLC2) notifications. • repeater—Sends standard repeater (hub) notifications. • rsrb—Sends remote source-route bridging (RSRB) notifications. • rsvp—Sends Resource Reservation Protocol (RSVP) notifications. • rtr—Sends SA Agent (RTR) notifications. • sdlc—Sends Synchronous Data Link Control (SDLC) notifications. • sdllc—Sends SDLLC notifications. • snmp—Sends any enabled RFC 1157 SNMP linkUp, linkDown, authenticationFailure, warmStart, and coldStart notifications. • stun—Sends serial tunnel (STUN) notifications. • syslog—Sends error message notifications (Cisco Syslog MIB). Specify the level of messages to be sent with the logging history level command. • tty—Sends Cisco enterprise-specific notifications when a Transmission Control Protocol (TCP) connection closes. • voice—Sends SNMP poor quality of voice traps, when used with the snmp enable peer-trap poor gov command. • x25—Sends X.25 event notifications.

Defaults

This command is disabled by default. No notifications are sent.

If you enter this command with no keywords, the default is to send all trap types to the host. No informs will be sent to this host.

If no **version** keyword is present, the default is version 1. The **no snmp-server host** command with no keywords will disable traps, but not informs, to the host. In order to disable informs, use the **no snmp-server host informs** command.

**Note**

If the *community-string* is not defined using the **snmp-server community** command prior to using this command, the default form of the **snmp-server community** command will automatically be inserted into the configuration. The password (*community-string*) used for this automatic configuration of the **snmp-server community** will be the same as specified in the **snmp-server host** command. This is the default behavior for Cisco IOS Release 12.0(3) and later.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.
12.0(3)T	The following keywords were added: • version 3 [auth noauth priv] • hsrp
11.3(1) MA, 12.0(3)T	The voice notification-type keyword was added.
12.1(3)T	The calltracker notification-type keyword was added for the Cisco AS5300 and AS5800 platforms.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response PDU. If the sender never receives the response, the inform request can be sent again. Thus, informs are more likely to reach their intended destination.

However, informs consume more resources in the agent and in the network. Unlike a trap, which is discarded as soon as it is sent, an inform request must be held in memory until a response is received or the request times out. Also, traps are sent only once, while an inform may be retried several times. The retries increase traffic and contribute to a higher overhead on the network.

If you do not enter an **snmp-server host** command, no notifications are sent. In order to configure the router to send SNMP notifications, you must enter at least one **snmp-server host** command. If you enter the command with no keywords, all trap types are enabled for the host.

In order to enable multiple hosts, you must issue a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command will be in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command will replace the first.

The **snmp-server host** command is used in conjunction with the **snmp-server enable** command. Use the **snmp-server enable** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable** command and the **snmp-server host** command for that host must be enabled.

However, some notification types cannot be controlled with the **snmp-server enable** command. For example, some notification types are always enabled. Other notification types are enabled by a different command. For example, the linkUpDown notifications are controlled by the **snmp trap link-status** command. These notification types do not require an **snmp-server enable** command.

A notification-type option's availability depends on the router type and Cisco IOS software features supported on the router. For example, the **envmon** notification-type is available only if the environmental monitor is part of the system. To see what notification types are available on your system, use the command **help ?** at the end of the **snmp-server host** command.

Examples

If you want to configure a unique snmp community string for traps, but you want to prevent snmp polling access with this string, the configuration should include an access-list. In the following example, the community string is named "comaccess" and the access list is numbered 10:

```
Router(config)# snmp-server community comaccess ro 10
Router(config)# snmp-server host 172.20.2.160 comaccess
Router(config)# access-list 10 deny any
```

The following example sends RFC 1157 SNMP traps to the host specified by the name myhost.cisco.com. Other traps are enabled, but only SNMP traps are sent because only **snmp** is specified in the **snmp-server host** command. The community string is defined as comaccess.

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com comaccess snmp
```

The following example sends the SNMP and Cisco environmental monitor enterprise-specific traps to address 172.30.2.160:

```
Router(config)# snmp-server enable traps snmp
Router(config)# snmp-server enable traps envmon
Router(config)# snmp-server host 172.30.2.160 public snmp envmon
```

The following example enables the router to send all traps to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com public
```

The following example will not send traps to any host. The BGP traps are enabled for all hosts, but only the ISDN traps are enabled to be sent to a host.

```
Router(config)# snmp-server enable traps bgp
Router(config)# snmp-server host bob public isdn
```

The following example enables the router to send all inform requests to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

The following example sends HSRP MIB informs to the host specified by the name myhost.cisco.com. The community string is defined as public.

```
Router(config)# snmp-server enable traps hsrp
Router(config)# snmp-server host myhost.cisco.com informs version 2c public hsrp
```

Related Commands

Command	Description
snmp-server enable peer-trap peer qov	Enable poor quality of voice notifications for applicable calls associated with a specific voice dial peer.
snmp-server enable traps	Enables SNMP notifications (traps and informs).
snmp-server informs	Specifies inform request options.
snmp-server trap-source	Specifies the interface (and hence the corresponding IP address) that an SNMP trap should originate from.
snmp-server trap-timeout	Defines how often to try resending trap messages on the retransmission queue.

snmp-server informs

To specify inform request options, use the **snmp-server informs** global configuration command. To return the settings to the defaults, use the **no** form of this command.

snmp-server informs [*retries retries*] [*timeout seconds*] [*pending pending*]

no snmp-server informs [*retries retries*] [*timeout seconds*] [*pending pending*]

Syntax Description

retries <i>retries</i>	(Optional) Maximum number of times to resend an inform request. The default is 3.
timeout <i>seconds</i>	(Optional) Number of seconds to wait for an acknowledgment before resending. The default is 30 seconds.
pending <i>pending</i>	(Optional) Maximum number of informs waiting for acknowledgments at any one time. When the maximum is reached, older pending informs are discarded. The default is 25.

Defaults

Inform requests are resent three times. Informs are resent after 30 seconds if no response is received. The maximum number of informs waiting for acknowledgments at any one time is 25.

Command Modes

Global configuration

Command History

Release	Modification
11.3 T	This command was introduced.

Examples

The following example increases the pending queue size if you are seeing a large number of inform drops:

```
snmp-server informs pending 50
```

The following example increases the default timeout if you are sending informs over slow network links. Because informs will be sitting in the queue for a longer period of time, you may also need to increase the pending queue size.

```
snmp-server informs timeout 60 pending 40
```

The following example decreases the default timeout if you are sending informs over very fast links:

```
snmp-server informs timeout 5
```

The following example increases the retry count if you are sending informs over unreliable links. Because informs will be sitting in the queue for a longer period of time, you may need to increase the pending queue size.

```
snmp-server informs retries 10 pending 45
```

Related Commands

Command	Description
snmp-server enable traps	Enables a router to send SNMP traps and informs.

snmp-server location

To set the system location string, use the **snmp-server location** global configuration command. To remove the location string, use the **no** form of this command.

snmp-server location *text*

no snmp-server location

Syntax Description

<i>text</i>	String that describes the system location information.

Defaults

No system location string is set.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Examples

The following example illustrates a system location string:

```
snmp-server location Building 3/Room 214
```

Related Commands

Command	Description
snmp-server contact	Sets the system contact (sysContact) string.

snmp-server manager

To start the Simple Network Management Protocol (SNMP) manager process, use the **snmp-server manager** global configuration command. To stop the SNMP manager process, use the **no** form of this command.

snmp-server manager

no snmp-server manager

Syntax Description

This command has no arguments or keywords.

Defaults

Disabled

Command Modes

Global configuration

Command History

Release	Modification
11.3 T	This command was introduced.

Usage Guidelines

The SNMP manager process sends SNMP requests to agents and receives SNMP responses and notifications from agents. When the SNMP manager process is enabled, the router can query other SNMP agents and process incoming SNMP traps.

Most network security policies assume that routers will be accepting SNMP requests, sending SNMP responses, and sending SNMP notifications. With the SNMP manager functionality enabled, the router may also be sending SNMP requests, receiving SNMP responses, and receiving SNMP notifications. The security policy implementation may need to be updated prior to enabling this functionality.

SNMP requests are typically sent to UDP port 161. SNMP responses are typically sent from UDP port 161. SNMP notifications are typically sent to UDP port 162.

Examples

The following example enables the SNMP manager process:

```
snmp-server manager
```

Related Commands

Command	Description
show snmp	Checks the status of SNMP communications.
show snmp pending	Displays the current set of pending SNMP requests.
show snmp sessions	Displays the current SNMP sessions.
snmp-server manager session-timeout	Sets the amount of time before a nonactive session is destroyed.

snmp-server manager session-timeout

To set the amount of time before a nonactive session is destroyed, use the **snmp-server manager session-timeout** global configuration command. To return the value to its default, use the **no** form of this command.

snmp-server manager session-timeout *seconds*

no snmp-server manager session-timeout

Syntax Description	<i>seconds</i>	Number of seconds before an idle session is timed out. The default is 600 seconds.

Defaults	Idle sessions time out after 600 seconds (10 minutes).

Command Modes	Global configuration

Command History	Release	Modification
	11.3 T	This command was introduced.

Usage Guidelines	Sessions are created when the SNMP manager in the router sends SNMP requests, such as inform requests, to a host or receives SNMP notifications from a host. One session is created for each destination host. If there is no further communication between the router and host within the session timeout period, the session will be deleted.
	The router tracks statistics, such as the average round-trip time required to reach the host, for each session. Using the statistics for a session, the SNMP manager in the router can set reasonable timeout periods for future requests, such as informs, for that host. If the session is deleted, all statistics are lost. If another session with the same host is later created, the request timeout value for replies will return to the default value.
	However, sessions consume memory. A reasonable session timeout value should be large enough such that regularly used sessions are not prematurely deleted, yet small enough such that irregularly used, or one-shot sessions, are purged expeditiously.

Examples	The following example sets the session timeout to a larger value than the default:

```
snmp-server manager
snmp-server manager session-timeout 1000
```

Related Commands

Command	Description
show snmp pending	Displays the current set of pending SNMP requests.
show snmp sessions	Displays the current SNMP sessions.
snmp-server manager	Starts the SNMP manager process.

snmp-server packetsize

To establish control over the largest Simple Network Management Protocol (SNMP) packet size permitted when the SNMP server is receiving a request or generating a reply, use the **snmp-server packetsize** global configuration command. To restore the default value, use the **no** form of this command.

snmp-server packetsize *byte-count*

no snmp-server packetsize

Syntax Description	<i>byte-count</i> Integer byte count from 484 to 8192. The default is 1500 bytes.	
Defaults	1500 bytes	
Command Modes	Global configuration	
Command History	Release	Modification
	10.0	This command was introduced.
Examples	The following example establishes a packet filtering of a maximum size of 1024 bytes: <pre>snmp-server packetsize 1024</pre>	
Related Commands	Command	Description
	snmp-server queue-length	Establishes the message queue length for each trap host.

snmp-server queue-length

To establish the message queue length for each trap host, use the **snmp-server queue-length** global configuration command.

snmp-server queue-length *length*

Syntax Description	<i>length</i>	Integer that specifies the number of trap events that can be held before the queue must be emptied.

Defaults	10 events

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	This command defines the length of the message queue for each trap host. Once a trap message is successfully transmitted, software will continue to empty the queue, but never faster than at a rate of four trap messages per second. During device bootup, there is a possibility that some traps could be dropped because of trap queue overflow on the device. If you suspect this is occurring, you can increase the size of the trap queue (for example, to 100) to determine if traps are then able to be sent during bootup.

Examples	In the following example, the SNMP notification queue is increased to 50 events: <pre>Router(config)# snmp-server queue-length 50</pre>

Related Commands	Command	Description
	snmp-server packetsize	Establishes control over the largest SNMP packet size permitted when the SNMP server is receiving a request or generating a reply.

snmp-server system-shutdown

To use the Simple Network Management Protocol (SNMP) message reload feature, the router configuration must include the **snmp-server system-shutdown** global configuration command. To prevent an SNMP system-shutdown request (from an SNMP manager) from resetting the Cisco agent, use the **no** form of this command.

snmp-server system-shutdown

no snmp-server system-shutdown

Syntax Description	This command has no arguments or keywords.

Defaults	This command is not included in the configuration file.

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Examples	The following example enables the SNMP message reload feature: <pre>snmp-server system-shutdown</pre>

snmp-server tftp-server-list

To limit the TFTP servers used via Simple Network Management Protocol (SNMP) controlled TFTP operations (saving and loading configuration files) to the servers specified in an access list, use the **snmp-server tftp-server-list** global configuration command. To disable this feature, use the **no** form of this command.

snmp-server tftp-server-list *number*

no snmp-server tftp-server-list

Syntax Description	<i>number</i>	Standard IP access list number from 1 to 99.

Defaults	Disabled

Command Modes	Global configuration

Command History	Release	Modification
	10.2	This command was introduced.

Examples	The following example limits the TFTP servers that can be used for configuration file copies via SNMP to the servers in access list 44:

```
snmp-server tftp-server-list 44
```

snmp-server trap-authentication

The **snmp-server trap-authentication** command has been replaced by the **snmp-server enable traps snmp authentication** command. See the description of the **snmp-server enable traps snmp** command in this chapter for more information.

snmp-server trap link

To enable linkUp/linkDown Simple Network Management Protocol (SNMP) traps which are compliant with RFC2233, use the **snmp-server trap link** command in global configuration mode. To disable IETF compliant functionality and revert to the default Cisco implementation of linkUp/linkDown traps, use the **no** form of this command.

snmp-server trap link ietf

no snmp-server trap link ietf

Syntax Description

ietf	This required keyword indicates to the command parser that you would like to link functionality of SNMP linkUp/linkDown traps to the Internet Engineering Task Force (IETF) standard (as opposed to the previous Cisco implementation).

Defaults

This command is disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
12.1(2)T	This command was introduced.

Usage Guidelines

The **snmp-server trap link ietf** command is used to configure your router to use the RFC2233 IETF standards-based implementation of linkUp/linkDown traps. This command is disabled by default to allow you to continue using the earlier Cisco implementation of linkUp/linkDown traps if you so choose.

However, please note that when using the default Cisco object definitions, linkUp/linkDown traps are not generated correctly for sub-interfaces. In the default implementation an arbitrary value is used for the *locIfReason* object in linkUp/linkDown traps for sub-interfaces, which may give you unintended results. This is because the *locIfReason* object is not defined for sub-interfaces in the current Cisco implementation, which uses OLD-CISCO-INTERFACES-MIB.my.

If you do not enable this functionality, the link trap varbind list will consist of {ifIndex, ifDescr, ifType, locIfReason}. After you enable this functionality with the **snmp-server trap link ietf** command, the varbind list will consist of {inIndex, ifAdminStatus,ifOperStatus, if Descr, ifType}. The *locIfReason* object will also be conditionally included in this list depending on whether meaningful information can be retrieved for that object. A configured sub-interface will generate retrievable information. On non-HWIDB interfaces, there will be no defined value for *locIfReason*, so it will be omitted from the trap message.

Examples

The following example shows the enabling of the RFC 2233 linkUp/linkDown traps, starting in privileged EXEC mode:

```
Router# config term
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)# snmp-server trap link ietf
Router(config)# end
Router# more system:running config
.
.
.
!
snmp-server engineID local 000000090000000A1616C2056
snmp-server community public RO
snmp-server community private RW
snmp-server trap link ietf
!
.
.
.
```

Related Commands

Command	Description
debug snmp packets	Displays information about every SNMP packet sent or received by the router for the purposes of troubleshooting.

snmp-server trap-source

To specify the interface (and hence the corresponding IP address) that an Simple Network Management Protocol (SNMP) trap should originate from, use the **snmp-server trap-source** global configuration command. To remove the source designation, use the **no** form of the command.

snmp-server trap-source *interface*

no snmp-server trap-source

Syntax Description

<i>interface</i>	Interface from which the SNMP trap originates. The argument includes the interface type and number in platform-specific syntax (for example, <i>type/slot/port</i>).

Defaults

No interface is specified.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

When an SNMP trap or inform is sent from a Cisco SNMP server, it has a notification address of whatever interface it happened to go out of at that time. Use this command monitor notifications from a particular interface.

Examples

The following example specifies that the IP address for interface Ethernet 0 is the source for all SNMP notifications:

```
Router(config)# snmp-server trap-source ethernet 0
```

The following example specifies that the IP address for the ethernet interface in slot2, port 1 is the source for all SNMP notifications:

```
Router(config)# snmp-server trap-source ethernet 2/1
```

Related Commands

Command	Description
snmp-server enable traps	Enables a router to send SNMP traps and informs.
snmp-server host	Specifies the recipient of an SNMP notification operation.

snmp-server trap-timeout

To define how often to try resending trap messages on the retransmission queue, use the **snmp-server trap-timeout** global configuration command.

snmp-server trap-timeout *seconds*

Syntax Description	<i>seconds</i>	Integer that sets the interval (in seconds) for resending the messages.

Defaults	30 seconds

Command Modes	Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	Before the Cisco IOS software tries to send a trap, it looks for a route to the destination address. If there is no known route, the trap is saved in a retransmission queue. The server trap-timeout command determines the number of seconds between retransmission attempts.

Examples	The following example sets an interval of 20 seconds to try resending trap messages on the retransmission queue: <pre>snmp-server trap-timeout 20</pre>

Related Commands	Command	Description
	snmp-server host	Specifies the recipient of an SNMP notification operation.
	snmp-server queue-length	Establishes the message queue length for each trap host.

snmp-server user

To configure a new user to a Simple Network Management Protocol (SNMP) group, use the **snmp-server user** global configuration command. To remove a user from an SNMP group, use the **no** form of the command.

```
snmp-server user username groupname [remote host [udp-port port]]
                { v1 | v2c | v3 [encrypted] [auth { md5 | sha } auth-password] } [access access-list]
```

```
no snmp-server user
```

Syntax Description	
<i>username</i>	The name of the user on the host that connects to the agent.
<i>groupname</i>	The name of the group to which the user belongs.
remote <i>host</i>	(Optional) Specifies a remote SNMP entity to which the user belongs, and the hostname or IP address of that entity.
udp-port <i>port</i>	(Optional) Specifies the UDP port number of the remote host. The default is UDP port 162.
v1	Specifies that SNMPv1 should be used.
v2c	Specifies that SNMPv2c should be used.
v3	Specifies that the SNMPv3 security model should be used. Allows the use of the encrypted and/or auth keywords.
encrypted	(Optional) Specifies whether the password appears in encrypted format (a series of digits, masking the true characters of the string).
auth	(Optional) Specifies which authentication level should be used.
md5	The HMAC-MD5-96 authentication level.
sha	The HMAC-SHA-96 authentication level.
<i>auth-password</i>	A string (not to exceed 64 characters) that enables the agent to receive packets from the host.
access <i>access-list</i>	(Optional) Specifies an access list to be associated with this SNMP user. The <i>access-list</i> argument represents a value from 1 to 99 that is the identifier of the standard IP access list.

Defaults

[Table 113](#) describes default behaviors for encryption, passwords and access lists.

Table 113 *snmp-server user Default Descriptions*

Characteristic	Default
encryption	Not present by default. The encrypted keyword is used to specify that the auth and priv passwords are MD5 digests and not text passwords.
passwords	Assumed to be text strings.
access lists	Access from all IP access lists is permitted.
remote users	All users are assumed to be local to this SNMP engine unless you specify they are remote with the remote keyword.

Command Modes Global configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines

To configure a remote user, specify the IP address or port number for the remote SNMP agent of the device where the user resides. Also, before you configure remote users for a particular agent, configure the SNMP engine ID, using the command **snmp-server engineID** with the **remote** option. The remote agent's SNMP engine ID is needed when computing the authentication/privacy digests from the password. If the remote engine ID is not configured first, the configuration command will fail.

SNMP passwords are localized using the SNMP engine ID of the authoritative SNMP engine. For informs, the authoritative SNMP agent is the remote agent. You need to configure the remote agent's SNMP engine ID in the SNMP database before you can send proxy requests or informs to it.

Related Commands	Command	Description
	show snmp user	Displays information on each SNMP username in the group username table.

snmp-server view

To create or update a view entry, use the **snmp-server view** global configuration command. To remove the specified Simple Network Management Protocol (SNMP) server view entry, use the **no** form of this command.

snmp-server view *view-name oid-tree* {**included** | **excluded**}

no snmp-server view *view-name*

Syntax Description

<i>view-name</i>	Label for the view record that you are updating or creating. The name is used to reference the record.
<i>oid-tree</i>	Object identifier of the ASN.1 subtree to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as <i>1.3.6.2.4</i> , or a word, such as <i>system</i> . Replace a single subidentifier with the asterisk (*) wildcard to specify a subtree family; for example <i>1.3.*.4</i> .
included excluded	Type of view. You must specify either included or excluded .

Defaults

No view entry exists.

Command Modes

Global configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Other SNMP commands require a view as an argument. You use this command to create a view to be used as arguments for other commands that create records including a view.

Two standard predefined views can be used when a view is required, instead of defining a view. One is *everything*, which indicates that the user can see all objects. The other is *restricted*, which indicates that the user can see three groups: system, snmpStats, and snmpParties. The predefined views are described in RFC 1447.

The first **snmp-server** command that you enter enables both versions of SNMP.

Examples

The following example creates a view that includes all objects in the MIB-II subtree:

```
snmp-server view mib2 mib-2 included
```

The following example creates a view that includes all objects in the MIB-II system group and all objects in the Cisco enterprise MIB:

```
snmp-server view phred system included
snmp-server view phred cisco included
```

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group:

```
snmp-server view agon system included
snmp-server view agon system.7 excluded
snmp-server view agon ifEntry.*.1 included
```

Related Commands

Command	Description
snmp-server community	Sets up the community access string to permit access to the SNMP protocol.

snmp trap link-status

To enable Simple Network Management Protocol (SNMP) link trap generation, use the **snmp trap link-status** interface configuration command. To disable SNMP link traps, use the **no** form of this command.

snmp trap link-status

no snmp trap link-status

Syntax Description

This command has no arguments or keywords.

Defaults

SNMP link traps are sent when an interface goes up or down.

Command Modes

Interface configuration

Command History

Release	Modification
10.0	This command was introduced.


Usage Guidelines

By default, SNMP link traps are sent when an interface goes up or down. For interfaces expected to go up and down during normal usage, such as ISDN interfaces, the output generated by these traps may not be useful. The **no** form of this command disables these traps.

Examples

The following example disables the sending of SNMP link traps related to the ISDN BRI 0 interface:

```
interface bri 0
 no snmp trap link-status
```

CDP Commands

This chapter describes commands used to monitor the router and network using Cisco Discovery Protocol (CDP).

For system management configuration tasks and examples, refer to the “[Configuring Cisco Discovery Protocol](#)” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

cdp advertise-v2

To enable Cisco Discovery Protocol Version 2 (CDPv2) advertising functionality on a device, use the **cdp advertise-v2** global configuration command. To disable advertising CDPv2 functionality, use the **no** form of the command.

cdp advertise-v2

no cdp advertise-v2

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Global configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

CDP Version 2 has three additional type-length values (TLVs): they are VTP Management Domain Name, Native VLAN, and full/half-Duplex.

Examples

In the following example, CDP Version 2 advertisements are disabled on the router:

```
Router#show cdp
Global CDP information:
    Sending CDP packets every 60 seconds
    Sending a holdtime value of 180 seconds
    Sending CDPv2 advertisements is enabled
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#no cdp advertise-v2
Router(config)#end
Router#show cdp
Global CDP information:
    Sending CDP packets every 60 seconds
    Sending a holdtime value of 180 seconds
    Sending CDPv2 advertisements is not enabled
Router#
```

Related Commands

Command	Description
cdp enable	Enables CDP on a supported interface.
cdp run	Reenables CDP on a Cisco device.

cdp enable

To enable Cisco Discovery Protocol (CDP) on an interface, use the **cdp enable** interface configuration command. To disable CDP on an interface, use the **no** form of this command.

cdp enable

no cdp enable

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled at the global level and on all supported interfaces.

Command Modes

Interface configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

CDP is enabled by default at the global level and on each supported interface in order to send or receive CDP information. However, some interfaces, such as ATM interfaces, do not support CDP.



Note

The **cdp enable**, **cdp timer**, and **cdp run** commands affect the operation of the IP on demand routing feature (that is, the **router odr** global configuration command). For more information on the **router odr** command, see the “On-Demand Routing Commands” chapter in the *Cisco IOS IP and IP Routing Command Reference*.

Examples

In the following example, CDP is disabled on the Ethernet 0 interface only:

```
Router#show cdp
Global CDP information:
  Sending CDP packets every 60 seconds
  Sending a holdtime value of 180 seconds
  Sending CDPv2 advertisements is enabled
Router#config terminal
Router(config)#interface ethernet 0
Router(config-if)#no cdp enable
```

Related Commands

Command	Description
cdp run	Reenables CDP on a Cisco device.
cdp timer	Specifies how often the Cisco IOS software sends CDP updates.
router odr	Enables on-demand routing on a hub router.

cdp holdtime

To specify the amount of time the receiving device should hold a Cisco Discovery Protocol (CDP) packet from your router before discarding it, use the **cdp holdtime** global configuration command. To revert to the default setting, use the **no** form of this command.

cdp holdtime *seconds*

no cdp holdtime

Syntax Description	<i>seconds</i>	Specifies the hold time to be sent in the CDP update packets.

Defaults	180 seconds

Command Modes	Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	CDP packets are sent with a time to live, or hold time, value. The receiving device will discard the CDP information in the CDP packet after the hold time has elapsed. You can set the hold time lower than the default setting of 180 seconds if you want the receiving devices to update their CDP info more rapidly. The CDP hold time must be set to a higher number of seconds than the time between CDP transmissions, which is set using the cdp timer command.

Examples	In the following example, the CDP packets being sent from the router are configured with a hold time of 60 seconds.

```
Router(config)#cdp holdtime 60
```

Related Commands	Command	Description
	cdp timer	Specifies how often the Cisco IOS software sends CDP updates.
	show cdp	Displays global CDP information, including timer and hold-time information.

cdp log mismatch duplex

To display the log of duplex mismatches generated by the Cisco Discovery Protocol (CDP) on Ethernet interfaces on a router, use the **cdp log mismatch duplex** command in global configuration or interface configuration mode. To disable the display of duplex messages on all Ethernet interfaces, use the **no** form of this command.

cdp log mismatch duplex

no cdp log mismatch duplex

Syntax Description

This command has no arguments or keywords.

Defaults

The router reports duplex mismatches from all Ethernet interfaces.

Command Modes

Global configuration
Interface configuration

Command History

Release	Modification
12.0	This command was introduced.

Usage Guidelines

When you enter the **cdp log mismatch duplex** command in global configuration mode, duplex mismatches are displayed on all Ethernet interfaces on the router. When you enter this command in interface configuration mode, only duplex mismatches for the specified Ethernet interface are displayed.

If the **cdp log mismatch duplex** command is disabled in global configuration mode, it cannot be configured per interface using interface configuration mode.

Duplex mismatch can occur only on Ethernet interfaces.

Examples

The following example of the **cdp log mismatch duplex** command in global configuration mode enables the display of duplex messages from all Ethernet interfaces on the router:

```
Router(config)# cdp log mismatch duplex
```

The following example of the **cdp log mismatch duplex** command in interface configuration mode enables only the display of duplex messages that may be generated from Ethernet interface 2/1:

```
Router(config-if)# interface ethernet2/1
```

```
Router(config-if)# cdp log mismatch duplex
```

The following is sample output from the **show running-config** command. The bold text shows that the **cdp log mismatch duplex** command is disabled globally.

```
Router# show running-config
```

```
Building configuration...
```

■ cdp log mismatch duplex

```
Current configuration : 1395 bytes
!
version 12.2
!
hostname 7200_C
!
!
interface Ethernet2/1
  no ip address
  duplex half
  no cdp log mismatch duplex
!
!
!
!
!
no cdp log mismatch duplex
cdp timer 5
!
!
!
!
line con 0
line aux 0
line vty 0 4
  password lab
```

Related Commands

Command	Description
show running-config	Displays the contents of the currently running configuration file.

cdp run

To enable Cisco Discovery Protocol (CDP), use the **cdp run** global configuration command. To disable CDP, use the **no** form of this command.

cdp run

no cdp run

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Global configuration

Command History

Release	Modification
10.3	This command was introduced.

Usage Guidelines

CDP is enabled on your router by default, which means the Cisco IOS software will receive CDP information. CDP also is enabled on supported interfaces by default. To disable CDP on an interface, use the **no cdp enable** interface configuration command.



Note

Because ODR (on demand routing) uses CDP, the **cdp enable**, **cdp timer**, and **cdp run** commands affect the operation of the **router odr** global configuration command. For more information on the **router odr** command, see the Release 12.2 *Cisco IOS IP Command Reference, Volume 2 of 3: Routing Protocols* document.

Examples

In the following example, CDP is disabled globally, then the user attempts to enable CDP on the Ethernet 0 interface:

```
Router(config)#no cdp run
Router(config)#end
Router#show cdp
% CDP is not enabled
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int eth0
Router(config-if)#cdp enable
% Cannot enable CDP on this interface, since CDP is not running
Router(config-if)#
```

Related Commands	Command	Description
	cdp enable	Enables CDP on a supported interface.
	cdp timer	Specifies how often the Cisco IOS software sends CDP updates.
	router odr	Enables ODR on the hub router.

cdp timer

To specify how often the Cisco IOS software sends Cisco Discovery Protocol (CDP) updates, use the **cdp timer** global configuration command. To revert to the default setting, use the **no** form of this command.

cdp timer *seconds*

no cdp timer

Syntax Description	<i>seconds</i>	Specifies how often the Cisco IOS software sends CDP updates.

Defaults	60 seconds

Command Modes	Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines	The trade-off with sending more frequent transmissions is providing up-to-date information versus using bandwidth more often.

**Note**

The **cdp enable**, **cdp timer**, and **cdp run** commands affect the operation of the IP on demand routing feature (that is, the **router odr** global configuration command). For more information on the **router odr** command, see the “On-Demand Routing Commands” chapter in the *Cisco IOS IP and IP Routing Command Reference*.

Examples	In the following example, CDP updates are sent every 80 seconds, less frequently than the default setting of 60 seconds. You might want to make this change if you are concerned about preserving bandwidth. cdp timer 80

Related Commands	Command	Description
	cdp enable	Enables CDP on a supported interface.
	cdp holdtime	Specifies the amount of time the receiving device should hold a CDP packet from your router before discarding it.
	cdp timer	Specifies how often the Cisco IOS software sends CDP updates.

Command	Description
router odr	Enables ODR on the hub router.
show cdp	Displays global CDP information, including timer and hold-time information.

clear cdp counters

To reset Cisco Discovery Protocol (CDP) traffic counters to zero, use the **clear cdp counters** privileged EXEC command.

clear cdp counters

Syntax Description	This command has no arguments or keywords.

Command Modes	Privileged EXEC

Command History	Release	Modification
	10.3	This command was introduced.

Examples	The following example clears the CDP counters. The show cdp traffic output shows that all of the traffic counters have been reset to zero.

```
Router# clear cdp counters
Router# show cdp traffic

CDP counters:
  Packets output: 0, Input: 0
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Fragmented: 0
```

Related Commands	Command	Description
	clear cdp table	Clears the table that contains CDP information about neighbors.
	show cdp traffic	Displays traffic information from the CDP table.

clear cdp table

To clear the table that contains Cisco Discovery Protocol (CDP) information about neighbors, use the **clear cdp table** privileged EXEC command.

clear cdp table

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.3	This command was introduced.

Examples The following example clears the CDP table. The output of the [show cdp neighbors](#) command shows that all information has been deleted from the table.

```
Router# clear cdp table
```

```
CDP-AD: Deleted table entry for neon.cisco.com, interface Ethernet0
CDP-AD: Deleted table entry for neon.cisco.com, interface Serial0
```

```
Router# show cdp neighbors
```

```
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP
```

```
Device ID      Local Intrfce    Holdtme    Capability  Platform  Port ID
```

Related Commands	Command	Description
	show cdp neighbors	Displays information about neighbors.

show cdp

To display global Cisco Discovery Protocol (CDP) information, including timer and hold-time information, use the **show cdp** privileged EXEC command.

show cdp

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.3	This command was introduced.
12.0(3)T	The output of this command was modified to include CDP Version 2 information.

Examples

The following example shows that the current router is sending CDP advertisements every 1 minute (the default setting for the **cdp timer** global configuration command). Also shown is that the current router directs its neighbors to hold its CDP advertisements for 3 minutes (the default for the **cdp holdtime** global configuration command), and that the router is enabled to send CDP Version 2 advertisements:

```
router# show cdp
```

```
Global CDP information:
Sending CDP packets every 60 seconds
Sending a holdtime value of 180 seconds
Sending CDPv2 advertisements is enabled
```

[Table 114](#) describes the significant fields shown in the display.

Table 114 *show cdp Field Descriptions*

Field	Definition
Sending CDP packets every XX seconds	The interval (in seconds) between transmissions of CDP advertisements. This field is controlled by the cdp timer command.
Sending a holdtime value of XX seconds	The amount of time (in seconds) the device directs the neighbor to hold a CDP advertisement before discarding it. This field is controlled by the cdp holdtime command.
Sending CDPv2 advertisements is XX	The state of whether CDP Version-2 type advertisements are enabled to be sent. Possible states are enabled or disabled. This field is controlled by the cdp advertise v2 global configuration command.

Related Commands

Command	Description
cdp advertise-v2	Enables CDP Version 2 advertising functionality on a device.
cdp holdtime	Specifies the amount of time the receiving device should hold a CDP packet from your router before discarding it.
cdp timer	Specifies how often the Cisco IOS software sends CDP updates.
show cdp entry	Displays information about a specific neighbor device listed in the CDP table.
show cdp interface	Displays information about the interfaces on which CDP is enabled.
show cdp neighbors	Displays detailed information about neighboring devices discovered using CDP.
show cdp traffic	Displays information about traffic between devices gathered using CDP.

show cdp entry

To display information about a specific neighboring device discovered using Cisco Discovery Protocol (CDP), use the **show cdp entry** privileged EXEC command.

show cdp entry { * | *device-name* [*] [**protocol** | **version**] }

Syntax Description

*	Displays all of the CDP neighbors.
<i>device-name</i>	Name of the neighbor about which you want information.
<i>device-name</i> *	You can enter an asterisk (*) at the end of an <i>entry-name</i> as a wildcard. For example, entering show cdp entry dev* will match all entries which begin with dev .
protocol	(Optional) Limits the display to information about the protocols enabled on a router.
version	(Optional) Limits the display to information about the version of software running on the router.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.3	This command was introduced.

Examples

The following is sample output from the **show cdp entry** command with no limits. Information about the neighbor device.cisco.com is displayed, including device ID, address and protocol, platform, interface, hold time, and version.

```
Router# show cdp entry device.cisco.com
```

```
-----
Device ID: device.cisco.com
Entry address(es):
  IP address: 192.168.68.18
  CLNS address: 490001.1111.1111.1111.00
  DECnet address: 10.1
Platform: cisco 4500, Capabilities: Router
Interface: Ethernet0/1, Port ID (outgoing port): Ethernet0
Holdtime : 125 sec

Version :
Cisco IOS Software
Cisco IOS (tm) 4500 Software (C4500-J-M), Version 12.1(2)
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Mon 07-Apr-00 19:51 by joeuser
```

The following is sample output from the **show cdp entry protocol** command. Only information about the protocols enabled on device.cisco.com is displayed.

```
Router# show cdp entry device.cisco.com protocol
```

```
Protocol information for device.cisco.com:
  IP address: 192.168.68.18
  CLNS address: 490001.1111.1111.1111.00
  DECnet address: 10.1
```

The following is sample output from the **show cdp entry version** command. Only information about the version of software running on device.cisco.com is displayed.

```
Router# show cdp entry device.cisco.com version
```

```
Version information for device.cisco.com:
  Cisco IOS Software
  Cisco IOS (tm) 4500 Software (C4500-J-M), Version 12.1(2)
  Copyright (c) 1986-2000 by cisco Systems, Inc.
  Compiled Mon 07-Apr-00 19:51 by joeuser
```

Related Commands

Command	Description
show cdp	Displays global CDP information, including timer and hold-time information.
show cdp interface	Displays information about the interfaces on which CDP is enabled.
show cdp neighbors	Displays detailed information about neighboring devices discovered using CDP.
show cdp traffic	Displays traffic information from the CDP table.

show cdp interface

To display information about the interfaces on which Cisco Discovery Protocol (CDP) is enabled, use the **show cdp interface** privileged EXEC command.

show cdp interface [*type number*]

Syntax Description

<i>type</i>	(Optional) Type of interface about which you want information.
<i>number</i>	(Optional) Number of the interface about which you want information.

Command Modes

Privileged EXEC

Command History

Release	Modification
10.3	This command was introduced.

Examples

The following is sample output from the **show cdp interface** command. Status information and information about CDP timer and hold-time settings is displayed for all interfaces on which CDP is enabled.

```
Router# show cdp interface
```

```
Serial0 is up, line protocol is up, encapsulation is SMDS
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
Ethernet0 is up, line protocol is up, encapsulation is ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

The following is sample output from the **show cdp interface** command with an interface specified. Status information and information about CDP timer and hold-time settings is displayed for Ethernet interface 0 only.

```
Router# show cdp interface ethernet 0
```

```
Ethernet0 is up, line protocol is up, encapsulation is ARPA
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

Related Commands

Command	Description
show cdp	Displays global CDP information, including timer and hold-time information.
show cdp entry	Displays information about a specific neighbor device or all neighboring devices discovered using CDP.

Command	Description
show cdp neighbors	Displays detailed information about neighboring devices discovered using CDP.
show cdp traffic	Displays traffic information from the CDP table.

show cdp neighbors

To display detailed information about neighboring devices discovered using Cisco Discovery Protocol (CDP), use the **show cdp neighbors** privileged EXEC command.

show cdp neighbors [*type number*] [**detail**]

Syntax Description	<i>type</i>	(Optional) Type of the interface connected to the neighbors about which you want information.
	<i>number</i>	(Optional) Number of the interface connected to the neighbors about which you want information.
	detail	(Optional) Displays detailed information about a neighbor (or neighbors) including network address, enabled protocols, hold time, and software version.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.3	This command was introduced.
	12.0(3)T	The output for the detail form of this command was expanded to include CDP Version 2 information.

Examples The following is sample output for the **show cdp neighbors** command:

Router#**show cdp neighbors**

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
S - Switch, H - Host, I - IGMP, r - Repeater

Device ID	Local Intrfce	Holdtme	Capability	Platform	Port ID
lab-7206	Eth 0	157	R	7206VXR	Fas 0/0/0
lab-as5300-1	Eth 0	163	R	AS5300	Fas 0
lab-as5300-2	Eth 0	159	R	AS5300	Eth 0
lab-as5300-3	Eth 0	122	R	AS5300	Eth 0
lab-as5300-4	Eth 0	132	R	AS5300	Fas 0/0
lab-3621	Eth 0	140	R S	3631-telco	Fas 0/0
008024 2758E0	Eth 0	132	T	CAT3000	1/2

[Table 115](#) describes the fields shown in this example.

Table 115 *show cdp neighbors Field Descriptions*

Field	Definition
Device ID	The configured ID (name), MAC address, or serial number of the neighbor device.
Local Intrfce	(Local Interface) The protocol being used by the connectivity media.
Holdtme	(Holdtime) The remaining amount of time, in seconds, the current device will hold the CDP advertisement from a transmitting router before discarding it.
Capability	The capability code discovered on the device. This is the type of the device listed in the CDP Neighbors table. Possible values are: R—Router T—Transparent bridge B—Source-routing bridge S—Switch H—Host I—IGMP device r—Repeater
Platform	The product number of the device.
Port ID	The protocol and port number of the device.

The following is sample output for the **show cdp neighbors detail** command.

```

router#show cdp neighbors detail
-----
Device ID: lab-7206
Entry address(es):
  IP address: 172.19.169.83
Platform: cisco 7206VXR, Capabilities: Router
Interface: Ethernet0, Port ID (outgoing port): FastEthernet0/0/0
Holdtime : 123 sec

Version :
Cisco Internetwork Operating System Software
IOS (tm) 5800 Software (C5800-P4-M), Version 12.1(2)
Copyright (c) 1986-2002 by Cisco Systems, Inc.

advertisement version: 2
Duplex: half

-----
Device ID: lab-as5300-1
Entry address(es):
  IP address: 172.19.169.87
Platform: cisco AS5300, Capabilities: Router
--More--
.
.
.

```

Table 116 describes the fields displayed in the **show cdp neighbors** output.

Table 116 *show cdp neighbors detail Field Descriptions*

Field	Definition
Device ID	The name of the neighbor device and either the MAC address or the serial number of this device.
Entry address(es)	A list of network addresses of neighbor devices.
[network protocol] address	The network address of the neighbor device. The address can be in IP, IPX, AppleTalk, DECnet, or CLNS protocol conventions.
Platform	The product name and number of the neighbor device.
Capabilities	The device type of the neighbor. This device can be a router, a bridge, a transparent bridge, a source-routing bridge, a switch, a host, an IGMP device, or a repeater.
Interface	The protocol and port number of the port on the current device.
Holdtime	The remaining amount of time, in seconds, the current device will hold the CDP advertisement from a transmitting router before discarding it.
Version:	The software version running on the neighbor device.
advertisement version:	The version of CDP being used for CDP advertisements.
Duplex:	The duplex state of connection between the current device and the neighbor device.
Native VLAN	The ID number of the VLAN on the neighbor device.
VTP Management Domain	A string that is the name of the collective group of VLANs associated with the neighbor device.

Related Commands

Command	Description
show cdp	Displays global CDP information, including timer and hold-time information.
show cdp entry	Displays information about a specific neighbor device listed in the CDP table.
show cdp interface	Displays information about the interfaces on which CDP is enabled.
show cdp traffic	Displays information about traffic between devices gathered using CDP.

show cdp traffic

To display information about traffic between devices gathered using Cisco Discovery Protocol (CDP), use the **show cdp traffic** privileged EXEC command.

show cdp traffic

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	10.3	This command was introduced.

Examples The following example specifies information associated with the **show cdp traffic** command:

```
router# show cdp traffic

Total packets output: 543, Input: 333
Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
No memory: 0, Invalid: 0, Fragmented: 0
CDP version 1 advertisements output: 191, Input: 187
CDP version 2 advertisements output: 352, Input: 146
```

[Table 117](#) describes the significant fields shown in the display.

Table 117 show cdp traffic Field Descriptions

Field	Definition
Total packets output	The number of CDP advertisements sent by the local device. Note that this value is the sum of the CDP Version 1 advertisements output and CDP Version 2 advertisements output fields.
Input	The number of CDP advertisements received by the local device. Note that this value is the sum of the CDP Version 1 advertisements input and CDP Version 2 advertisements input fields.
Hdr syntax	The number of CDP advertisements with bad headers, received by the local device.
Chksum error	The number of times the checksum (verifying) operation failed on incoming CDP advertisements.
Encaps failed	The number of times CDP failed to send advertisements on an interface because of a failure caused by the bridge port of the local device.


Table 117 *show cdp traffic Field Descriptions (continued)*

Field	Definition
No memory	The number of times the local device did not have enough memory to store the CDP advertisements in the advertisement cache table when the device was attempting to assemble advertisement packets for transmission and parse them when receiving them.
Invalid	The number of invalid CDP advertisements received and sent by the local device.
Fragmented	The number of times fragments or portions of a single CDP advertisement were received by the local device instead of the complete advertisement.
CDP version 1 advertisements output	The number of CDP Version 1 advertisements sent by the local device.
Input	The number of CDP Version 1 advertisements received by the local device.
CDP version 2 advertisements output	The number of CDP Version 2 advertisements sent by the local device.
Input	The number of CDP Version 2 advertisements received by the local device.

Related Commands

Command	Description
show cdp	Displays global CDP information, including timer and hold-time information.
show cdp entry	Displays information about a specific neighbor device listed in the CDP table.
show cdp interface	Displays information about the interfaces on which CDP is enabled.
show cdp neighbors	Displays detailed information about neighboring devices discovered using CDP.

■ show cdp traffic



RMON Commands

This chapter describes commands used to monitor the router and network Remote Monitoring (RMON). For system management configuration tasks and examples, refer to the “Configuring RMON Support” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

rmon

To enable Remote Monitoring (RMON) on an Ethernet interface, use the **rmon** interface configuration command. To disable RMON on the interface, use the **no** form of this command.

```
rmon {native | promiscuous}

no rmon
```

Syntax Description

native	Enables RMON on the Ethernet interface. In native mode, the router processes only packets destined for this interface.
promiscuous	Enables RMON on the Ethernet interface. In promiscuous mode, the router examines every packet.

Defaults

RMON is disabled on the interface.

Command Modes

Interface configuration

Command History

Release	Modification
11.1	This command was introduced.

Usage Guidelines

This command enables RMON on Ethernet interfaces. A generic RMON console application is recommended in order to use the RMON network management capabilities. SNMP must also be configured. RMON provides visibility of individual nodal activity and allows you to monitor all nodes and their interaction on a LAN segment. When the **rmon** command is issued, the router automatically installs an Ethernet statistics study for the associated interface.



Note

RMON can be very data and processor intensive. Users should measure usage effects to ensure that router performance is not degraded and to minimize excessive management traffic overhead. Native mode is less intensive than promiscuous mode.

All Cisco IOS software feature sets support RMON alarm and event groups. Additional RMON groups are supported in certain feature sets. Refer to the Release Notes for feature set descriptions. As a security precaution, support for the packet capture group allows capture of packet header information only; data payloads are not captured.

The RMON MIB is described in RFC 1757.

Examples

The following example enables RMON on Ethernet interface 0 and allows the router to examine only packets destined for the interface:

```
interface ethernet 0
 rmon native
```

Related Commands	Command	Description
	rmon alarm	Sets an alarm on any MIB object.
	rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
	rmon queuesize	Changes the size of the queue that holds packets for analysis by the RMON process.
	show rmon	Displays the current RMON agent status on the router.

rmon alarm

To set an alarm on any MIB object, use the **rmon alarm** global configuration command. To disable the alarm, use the **no** form of this command.

rmon alarm *number variable interval {delta | absolute} rising-threshold value [event-number] falling-threshold value [event-number] [owner string]*

no rmon alarm *number*

Syntax Description		
<i>number</i>		Alarm number, which is identical to the alarmIndex in the alarmTable in the Remote Monitoring (RMON) MIB.
<i>variable</i>		MIB object to monitor, which translates into the alarmVariable used in the alarmTable of the RMON MIB.
<i>interval</i>		Time in seconds the alarm monitors the MIB variable, which is identical to the alarmInterval used in the alarmTable of the RMON MIB.
delta		Tests the change between MIB variables, which affects the alarmSampleType in the alarmTable of the RMON MIB.
absolute		Tests each MIB variable directly, which affects the alarmSampleType in the alarmTable of the RMON MIB.
rising-threshold <i>value</i>		Value at which the alarm is triggered.
<i>event-number</i>		(Optional) Event number to trigger when the rising or falling threshold exceeds its limit. This value is identical to the alarmRisingEventIndex or the alarmFallingEventIndex in the alarmTable of the RMON MIB.
falling-threshold <i>value</i>		Value at which the alarm is reset.
owner <i>string</i>		(Optional) Specifies an owner for the alarm, which is identical to the alarmOwner in the alarmTable of the RMON MIB.

Defaults No alarms configured

Command Modes Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines The MIB object must be specified as a dotted decimal value after the entry sequence (for example, ifEntry.10.1). You cannot specify the variable name and the instance (for example, ifInOctets.1) or the entire dotted decimal notation. The variable must be of the form entry.integer.instance.

To disable the RMON alarms, you must use the **no** form of the command on each configured alarm. For example, enter **no rmon alarm 1**, where the 1 identifies which alarm is to be removed.

See RFC 1757 for more information about the RMON alarm group.

Examples

The following example configures an RMON alarm using the **rmon alarm** command:

```
rmon alarm 10 ifEntry.20.1 20 delta rising-threshold 15 1 falling-threshold 0
owner jjohnson
```

This example configures RMON alarm number 10. The alarm monitors the MIB variable *ifEntry.20.1* once every 20 seconds until the alarm is disabled, and checks the change in the variable's rise or fall. If the *ifEntry.20.1* value shows a MIB counter increase of 15 or more, such as from 100000 to 100015, the alarm is triggered. The alarm in turn triggers event number 1, which is configured with the **rmon event** command. Possible events include a log entry or a SNMP trap. If the *ifEntry.20.1* value changes by 0 (falling-threshold 0), the alarm is reset and can be triggered again.

Related Commands

Command	Description
rmon	Enables Remote Network Monitoring (RMON) on an Ethernet interface
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

rmon capture-userdata

To disable the packet zeroing feature that initializes the user payload portion of each Remote Monitoring (RMON) MIB packet, use the **rmon capture-userdata** global configuration command. To enable packet zeroing, use the **no** form of this command.

rmon capture-userdata

no rmon capture-userdata

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

Use the **show rmon matrix** command to display RMON statistics.

Examples

The following command disables the packet zeroing feature:

```
rmon capture-userdata
```

Related Commands

Command	Description
rmon collection matrix	Enables a RMON MIB matrix group of statistics on an interface.

rmon collection history

To enable Remote Monitoring (RMON) MIB history group of statistics on an interface, use the **rmon collection history** interface configuration command. To remove a specified RMON history group of statistics, use the **no** form of this command.

rmon collection history { **controlEntry** *integer* } [**owner** *ownername*] [**buckets** *bucket-number*] [**interval** *seconds*]

no rmon collection history { **controlEntry** *integer* } [**owner** *ownername*] [**buckets** *bucket-number*] [**interval** *seconds*]

Syntax Description		
controlEntry		Specifies the RMON group of statistics using a value.
<i>integer</i>		A value from 1 to 65535 that identifies the RMON group of statistics and matches the index value returned for Simple Network Management Protocol (SNMP) requests.
owner		(Optional) Specifies the name of the owner of the RMON group of statistics.
<i>ownername</i>		(Optional) Records the name of the owner of the RMON group of statistics.
buckets		(Optional) Specifies the maximum number of buckets desired for the RMON collection history group of statistics.
<i>bucket-number</i>		(Optional) A value associated with the number of buckets specified for the RMON collection history group of statistics.
interval		(Optional) Specifies the number of seconds in each polling cycle.
<i>seconds</i>		(Optional) The number of seconds in each polling cycle.

Defaults No default behavior or values.

Command Modes Interface configuration

Command History	Release	Modification
	12.0(5)T	This command was introduced.

Usage Guidelines Use the **show rmon capture** and **show rmon matrix** commands to display RMON statistics.

Examples The following command enables an RMON MIB collection history group of statistics with an ID number of 20 and an owner of john:

```
rmon collection history controlEntry 20 owner john
```

Related Commands

Command	Description
show rmon capture	Displays the contents of the RMON capture table of the router.
show rmon matrix	Displays the RMON MIB matrix table.

rmon collection host

To enable a Remote Monitoring (RMON) MIB host collection group of statistics on the interface, use the **rmon collection host** interface configuration command. To remove the specified RMON host collection, use the **no** form of the command.

rmon collection host {**controlEntry** *integer*} [**owner** *ownername*]

no rmon collection host {**controlEntry** *integer*} [**owner** *ownername*]

Syntax Description

controlEntry	Specifies the RMON group of statistics using a value.
<i>integer</i>	A value from 1 to 65535 that identifies the RMON group of statistics and matches the index value returned for Simple Network Management Protocol (SNMP) requests.
owner	(Optional) Specifies the name of the owner of the RMON group of statistics.
<i>ownername</i>	(Optional) Records the name of the owner of the RMON group of statistics

Defaults

No default behavior or values.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

Use the **show rmon hosts** and **show rmon matrix** commands to display RMON statistics.

Examples

The following command enables an RMON collection host group of statistics with an ID number of 20 and an owner of john:

```
rmon collection host controlEntry 20 owner john
```

Related Commands

Command	Description
show rmon hosts	Displays the RMON MIB hosts table.
show rmon matrix	Displays the RMON MIB matrix table.

rmon collection matrix

To enable a Remote Monitoring (RMON) MIB matrix group of statistics on an interface, use the **rmon collection matrix** interface configuration command. To remove a specified RMON matrix group of statistics, use the **no** form of the command.

rmon collection matrix {**controlEntry** *integer*} [**owner** *ownername*]

no rmon collection matrix {**controlEntry** *integer*} [**owner** *ownername*]

Syntax Description

controlEntry	Specifies the RMON group of statistics using a value.
<i>integer</i>	A value between 1 and 65535 that identifies the RMON group of statistics and matches the index value returned for Simple Network Management Protocol (SNMP) requests.
owner	(Optional) Specifies the name of the owner of the RMON group of statistics.
<i>ownername</i>	(Optional) Records the name of the owner of the RMON group of statistics.

Defaults

No default behavior or values.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

Use the **show rmon matrix** command to display RMON statistics.

Examples

The following command enables the RMON collection matrix group of statistics with an ID number of 20 and an owner of john:

```
rmon collection matrix controlEntry 20 owner john
```

Related Commands

Command	Description
show rmon matrix	Displays the RMON MIB matrix table.

rmon collection rmon1

To enable all possible autoconfigurable Remote Monitoring (RMON) MIB statistic collections on the interface, use the **rmon collection rmon1** command in interface configuration mode. To disable these statistic collections on the interface, use the **no** form of the command.

rmon collection rmon1 {**controlEntry** *integer*} [**owner** *ownername*]

no rmon collection rmon1 {**controlEntry** *integer*} [**owner** *ownername*]

Syntax Description

controlEntry	Specifies the RMON group of statistics using a value.
<i>integer</i>	A value from 1 to 65535 that identifies the RMON group of statistics and matches the index value returned for Simple Network Management Protocol (SNMP) requests.
owner	(Optional) Specifies the name of the owner of the RMON group of statistics.
<i>ownername</i>	(Optional) Records the name of the owner of the RMON group of statistics.

Defaults

No default behavior or values.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

Use the **show rmon matrix** command to display RMON statistics.

Examples

The following command enables the RMON collection rmon1 group of statistics with an ID of 20 and an owner of john:

```
rmon collection rmon1 controlEntry 20 owner john
```

Related Commands

Command	Description
show rmon matrix	Displays the RMON MIB matrix table.

rmon event

To add or remove an event in the RMON event table that is associated with an RMON event number, use the **rmon event** global configuration command. To disable RMON on the interface, use the **no** form of this command.

rmon event *number* [**log**] [**trap** *community*] [**description** *string*] [**owner** *string*]

no rmon event *number*

Syntax Description

<i>number</i>	Assigned event number, which is identical to the eventIndex in the eventTable in the RMON MIB.
log	(Optional) Generates an RMON log entry when the event is triggered and sets the eventType in the RMON MIB to log or log-and-trap.
trap <i>community</i>	(Optional) SNMP community string used for this trap. Configures the setting of the eventType in the RMON MIB for this row as either snmp-trap or log-and-trap. This value is identical to the eventCommunityValue in the eventTable in the RMON MIB.
description <i>string</i>	(Optional) Specifies a description of the event, which is identical to the event description in the eventTable of the RMON MIB.
owner <i>string</i>	(Optional) Owner of this event, which is identical to the eventOwner in the eventTable of the RMON MIB.

Defaults

No events configured

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

This command applies only to the Cisco 2500 series and Cisco AS5200 series. See RFC 1757 for more information about the RMON MIB.

Examples

The following example enables the **rmon event** command:

```
rmon event 1 log trap eventtrap description "High ifOutErrors" owner sdurham
```

This example configuration creates RMON event number 1, which is defined as High ifOutErrors, and generates a log entry when the event is triggered by an alarm. The user sdurham owns the row that is created in the event table by this command. This configuration also generates a Simple Network Management Protocol (SNMP) trap when the event is triggered.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
show rmon	Displays the current RMON agent status on the router.

rmon queue-size

To change the size of the queue that holds packets for analysis by the Remote Monitoring (RMON) process, use the **rmon queue-size** global configuration command. To restore the default value, use the **no** form of this command.

rmon queue-size *size*

no rmon queue-size

Syntax Description	<i>size</i>	Number of packets allowed in the queue awaiting RMON analysis. Default queue size is 64 packets.

Defaults	64 packets

Command Modes	Global configuration

Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines	This command applies to the RMON function, which is available on Ethernet interfaces of Cisco 2500 series and Cisco AS5200 series routers only.
	You might want to increase the queue size if the RMON function indicates it is dropping packets. You can determine this from the output of the show rmon command or from the etherStatsDropEvents object in the etherStats table. A feasible maximum queue size depends on the amount of memory available in the router and the configuration of the buffer pool.

Examples	The following example configures the RMON queue size to be 128 packets:

```
rmon queue-size 128
```

Related Commands	Command	Description
	show rmon	Displays the current RMON agent status on the router.

show rmon

To display the current RMON agent status on the router, use the **show rmon** EXEC command.

show rmon [**alarms** | **capture** | **events** | **filter** | **history** | **hosts** | **matrix** | **statistics** | **task** | **topn**]

Syntax Description	
alarms	(Optional) Displays the RMON alarm table.
capture	(Optional) Displays the RMON buffer capture table. Available on Cisco 2500 series and Cisco AS5200 series only.
events	(Optional) Displays the RMON event table.
filter	(Optional) Displays the RMON filter table. Available on Cisco 2500 series and Cisco AS5200 series only.
history	(Optional) Displays the RMON history table. Available on Cisco 2500 series and Cisco AS5200 series only.
hosts	(Optional) Displays the RMON hosts table. Available on Cisco 2500 series and Cisco AS5200 series only.
matrix	(Optional) Displays the RMON matrix table. Available on Cisco 2500 series and Cisco AS5200 series only.
statistics	(Optional) Displays the RMON statistics table. Available on Cisco 2500 series and Cisco AS5200 series only.
task	(Optional) Displays general RMON statistics. This is the default.
topn	(Optional) Displays the RMON top-n hosts table. Available on Cisco 2500 series and Cisco AS5200 series only.

Defaults If no option is specified, the **task** option is displayed.

Command Modes EXEC

Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines Refer to the specific **show rmon** command for an example and description of the fields.
For additional information, refer to the RMON MIB described in RFC 1757.

Examples The following is sample output from the **show rmon** command. All counters are from the time the router was initialized.

```
Router# show rmon
```

```
145678 packets input (34562 promiscuous), 0 drops
145678 packets processed, 0 on queue, queue utilization 15/64
```

Table 118 describes the fields shown in the display.

Table 118 *show rmon Field Descriptions*

Field	Description
<i>x</i> packets input	Number of packets received on RMON-enabled interfaces.
<i>x</i> promiscuous	Number of input packets that were seen by the router only because RMON placed the interface in promiscuous mode.
<i>x</i> drops	Number of input packets that could not be processed because the RMON queue overflowed.
<i>x</i> packets processed	Number of input packets actually processed by the RMON task.
<i>x</i> on queue	Number of input packets that are sitting on the RMON queue, waiting to be processed.
queue utilization <i>x/y</i>	<i>y</i> is the maximum size of the RMON queue; <i>x</i> is the largest number of packets that were ever on the queue at a particular time.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
rmon queuesize	Changes the size of the queue that holds packets for analysis by the RMON process.
show rmon alarms	Displays the contents of the router's RMON alarm table.
show rmon capture	Displays the contents of the router's RMON capture table.
show rmon events	Displays the contents of the router's RMON event table.
show rmon filter	Displays the contents of the router's RMON filter table.
show rmon history	Displays the contents of the router's RMON history table.
show rmon hosts	Displays the contents of the router's RMON hosts table.
show rmon matrix	Displays the contents of the router's RMON matrix table.
show rmon statistics	Displays the contents of the router's RMON statistics table.
show rmon topn	Displays the contents of the router's RMON p-N host table.

show rmon alarms

To display the contents of the RMON alarm table of the router, use the **show rmon alarms** EXEC command.

show rmon alarms

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON alarms to display alarm information with the **show rmon alarms** command.

Examples

The following is sample output from the **show rmon alarms** command:

```
Router# show rmon alarms
```

```
Alarm 2 is active, owned by manager1
Monitors ifEntry.1.1 every 30 seconds
Taking delta samples, last value was 0
Rising threshold is 15, assigned to event 12
Falling threshold is 0, assigned to event 0
On startup enable rising or falling alarm
```

[Table 119](#) describes the fields shown in the display.

Table 119 show rmon alarms Field Descriptions

Field	Description
Alarm 2 is active, owned by manager1	Unique index into the alarmTable, showing the alarm status is active, and the owner of this row, as defined in the alarmTable of RMON.
Monitors ifEntry.1.1	Object identifier of the particular variable to be sampled. Equivalent to alarmVariable in RMON.
every 30 seconds	Interval in seconds over which the data is sampled and compared with the rising and falling thresholds. Equivalent to alarmInterval in RMON.
Taking delta samples	Method of sampling the selected variable and calculating the value to be compared against the thresholds. Equivalent to alarmSampleType in RMON.

Table 119 *show rmon alarms Field Descriptions (continued)*

Field	Description
last value was	Value of the statistic during the last sampling period. Equivalent to alarmValue in RMON.
Rising threshold is	Threshold for the sampled statistic. Equivalent to alarmRisingThreshold in RMON.
assigned to event	Index of the eventEntry that is used when a rising threshold is crossed. Equivalent to alarmRisingEventIndex in RMON.
Falling threshold is	Threshold for the sampled statistic. Equivalent to alarmFallingThreshold in RMON.
assigned to event	Index of the eventEntry that is used when a falling threshold is crossed. Equivalent to alarmFallingEventIndex in RMON.
On startup enable rising or falling alarm	Alarm that may be sent when this entry is first set to valid. Equivalent to alarmStartupAlarm in RMON.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
show rmon	Displays the current RMON agent status on the router.

show rmon capture

To display the contents of the router's RMON capture table, use the **show rmon capture** EXEC command.

show rmon capture

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon capture** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

Examples The following is sample output from the **show rmon capture** command:

```
Router# show rmon capture

Buffer 4096 is active, owned by manager1
Captured data is from channel 4096
Slice size is 128, download size is 128
Download offset is 0
Full Status is spaceAvailable, full action is lockWhenFull
Granted 65536 octets out of 65536 requested
Buffer has been on since 00:01:16, and has captured 1 packets
Current capture buffer entries:
  Packet 1 was captured 416 ms since buffer was turned on
  Its length is 326 octets and has a status type of 0
  Packet ID is 634, and contains the following data:
00 00 0c 03 12 ce 00 00 0c 08 9d 4e 08 00 45 00
01 34 01 42 00 00 1d 11 e3 01 ab 45 30 15 ac 15
31 06 05 98 00 a1 01 20 9f a8 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00
```

[Table 120](#) describes the fields shown in the display.

Table 120 *show rmon capture Field Descriptions*

Field	Description
Buffer 4096 is active	Equates to bufferControlIndex in the bufferControlTable of RMON. Uniquely identifies a valid (active) row in this table.
owned by manager1	Denotes the owner of this row. Equates to bufferControlOwner in the bufferControlTable of RMON.
Captured data is from channel	Equates to the bufferControlChannelIndex and identifies which RMON channel is the source of these packets.
Slice size is	Identifies the maximum number of octets of each packet that will be saved in this capture buffer. Equates to bufferControlCaptureSliceSize of RMON.
download size is	Identifies the maximum number of octets of each packet in this capture buffer that will be returned in an SNMP retrieval of that packet. Equates to bufferControlDownloadSliceSize in RMON.
Download offset is	Offset of the first octet of each packet in this capture buffer that will be returned in an SNMP retrieval of that packet. Equates to bufferControlDownloadOffset in RMON.
Full Status is spaceAvailable	Shows whether the buffer is full or has room to accept new packets. Equates to bufferControlFullStatus in RMON.
full action is lockWhenFull	Controls the action of the buffer when it reaches full status. Equates to bufferControlFullAction in RMON.
Granted 65536 octets	Actual maximum number of octets that can be saved in this capture buffer. Equates to bufferControlMaxOctetsGranted in RMON.
out of 65536 requested	Requested maximum number of octets to be saved in this capture buffer. Equates to bufferControlMaxOctetsRequested in RMON.
Buffer has been on since	Indicates how long the buffer has been available.
and has captured 1 packets	Number of packets captured since buffer was turned on. Equates to bufferControlCapturedPackets in RMON.
Current capture buffer entries:	Lists each packet captured.
Packet 1 was captured 416 ms since buffer was turned on Its length is 326 octets and has a status type of 0	Zero indicates the error status of this packet. Equates to captureBufferPacketStatus in RMON, where its value options are documented.
Packet ID is	Index that describes the order of packets received on a particular interface. Equates to captureBufferPacketID in RMON.
and contains the following data:	Data inside the packet, starting at the beginning of the packet.

Related Commands	Command	Description
	rmon	Enables RMON on an Ethernet interface.
	rmon alarm	Sets an alarm on any MIB object.
	rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
	show rmon	Displays the current RMON agent status on the router.

show rmon events

To display the contents of the router's RMON event table, use the **show rmon events** EXEC command.

show rmon events

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON events to display alarm information with the **show rmon events** command.

Examples The following is sample output from the **show rmon events** command:

```
Router# show rmon events

Event 12 is active, owned by manager1
Description is interface-errors
Event firing causes log and trap to community rmonTrap, last fired 00:00:00
```

[Table 121](#) describes the fields shown in the display.

Table 121 show rmon events Field Descriptions

Field	Description
Event 12 is active, owned by manager1	Unique index into the eventTable, showing the event status is active, and the owner of this row, as defined in the eventTable of RMON.
Description is interface-errors	Type of event, in this case an interface error.
Event firing causes log and trap	Type of notification that the router will make about this event. Equivalent to eventType in RMON.
community rmonTrap	If an SNMP trap is to be sent, it will be sent to the SNMP community specified by this octet string. Equivalent to eventCommunity in RMON.
last fired	Last time the event was generated.

Related Commands	Command	Description
	rmon	Enables RMON on an Ethernet interface.
	rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
	show rmon	Displays the current RMON agent status on the router.

show rmon filter

To display the contents of the router's RMON filter table, use the **show rmon filter** EXEC command.

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon filter** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

Examples

The following is sample output from the **show rmon filter** command:

```
Router# show rmon filter

Filter 4096 is active, and owned by manager1
Data offset is 12, with
Data of 08 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ab 45 30 15 ac 15 31 06
Data Mask is ff ff 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ff ff ff ff ff ff ff ff
Data Not Mask is 0
Pkt status is 0, status mask is 0, not mask is 0
Associated channel 4096 is active, and owned by manager1
Type of channel is acceptFailed, data control is off
Generate event index 0
Event status is eventFired, # of matches is 1482
Turn on event index is 0, turn off event index is 0
Description:
```

[Table 122](#) describes the fields shown in the display.

Table 122 show rmon filter Field Descriptions

Field	Description
Filter <i>x</i> is active, and owned by <i>y</i>	Unique index of the filter, its current state, and the owner, as defined in the filterTable of RMON.
Data offset is	Offset from the beginning of each packet where a match of packet data will be attempted. Equivalent to filterPktDataOffset in RMON.
Data of	Data that is to be matched with the input packet. Equivalent to filterPktData in RMON.

Table 122 show rmon filter Field Descriptions (continued)

Field	Description
Data Mask is	Mask that is applied to the match process. Equivalent to filterPktDataMask in RMON.
Data Not Mask is	Inversion mask that is applied to the match process. Equivalent to filterPktDataNotMask in RMON.
Pkt status is	Status that is to be matched with the input packet. Equivalent to filterPktStatus in RMON.
status mask is	Mask that is applied to the status match process. Equivalent to filterPktStatusMask in RMON.
not mask is	Inversion mask that is applied to the status match process. Equivalent to filterPktStatusNotMask in RMON.
Associated channel <i>x</i> is active, and owned by <i>y</i>	Unique index of the channel, its current state, and the owner, as defined in the channelTable of RMON.
Type of channel is {acceptMatched acceptFailed}	This object controls the action of the filters associated with this channel. Equivalent to channelAcceptType of RMON.
data control is {off on }	This object controls the flow of data through this channel. Equivalent to channelDataControl in RMON.
Generate event index 0	Value of this object identifies the event that is configured to be generated when the associated channelDataControl is on and a packet is matched. Equivalent to channelEventIndex in RMON.
Event status is eventFired	When the channel is configured to generate events when packets are matched, this message indicates the means of controlling the flow of those events. Equivalent to channelEventStatus in RMON.
# of matches is	Number of times this channel has matched a packet. Equivalent to channelMatches in RMON.
Turn on event index is	Value of this object identifies the event that is configured to turn the associated channelDataControl from off to on when the event is generated. Equivalent to channelTurnOnEventIndex in RMON.
Turn off event index is	Value of this object identifies the event that is configured to turn the associated channelDataControl from on to off when the event is generated. Equivalent to channelTurnOffEventIndex in RMON.
Description:	Comment describing this channel.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

show rmon history

To display the contents of the router's RMON history table, use the **show rmon history** EXEC command.

show rmon history

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines

For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon history** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

Examples The following is sample output from the **show rmon history** command:

```
Router# show rmon history

Entry 1 is active, and owned by manager1
Monitors ifEntry.1.1 every 30 seconds
Requested # of time intervals, ie buckets, is 5
Granted # of time intervals, ie buckets, is 5
Sample # 14 began measuring at 00:11:00
  Received 38346 octets, 216 packets,
    0 broadcast and 80 multicast packets,
    0 undersized and 0 oversized packets,
    0 fragments and 0 jabbers,
    0 CRC alignment errors and 0 collisions.
  # of dropped packet events is 0
  Network utilization is estimated at 10
```

[Table 123](#) describes the fields shown in the display.

Table 123 show rmon history Field Descriptions

Field	Description
Entry 1 is active, and owned by manager1	Unique index of the history entry, its current state, and the owner as defined in the historyControlTable of RMON.
Monitors ifEntry.1.1	This object identifies the source of the data for which historical data was collected and placed in a media-specific table. Equivalent to historyControlDataSource in RMON.

Table 123 *show rmon history Field Descriptions (continued)*

Field	Description
every 30 seconds	Interval in seconds over which the data is sampled for each bucket in the part of the media-specific table associated with this historyControlEntry. Equivalent to historyControlInterval in RMON.
Requested # of time intervals, ie buckets, is	Requested number of discrete time intervals over which data is to be saved in the part of the media-specific table associated with this historyControlEntry. Equivalent to historyControlBucketsRequested in RMON.
Granted # of time intervals, ie buckets, is	Actual number of discrete time intervals over which data is to be saved in the part of the media-specific table associated with this historyControlEntry. Equivalent to historyControlBucketsGranted in RMON.
Sample # 14 began measuring at	Time at the start of the interval over which this sample was measured.
Received 38346 octets	Total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). Equivalent to etherHistoryOctets in RMON.
x packets	Number of packets (including bad packets) received during this sampling interval. Equivalent to etherHistoryPkts in RMON.
x broadcast	Number of good packets received during this sampling interval that were directed to the broadcast address. Equivalent to etherHistoryBroadcastPkts in RMON.
x multicast packets	Number of good packets received during this sampling interval that were directed to a multicast address. Equivalent to etherHistoryMulticastPkts in RMON.
x undersized	Number of packets received during this sampling interval that were fewer than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed. Equivalent to etherHistoryUndersizedPkts in RMON.
x oversized packets	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed. Equivalent to etherHistoryOversizePkts in RMON.
x fragments	Total number of packets received during this sampling interval that were fewer than 64 octets in length (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Equivalent to etherHistoryFragments in RMON.

Table 123 *show rmon history Field Descriptions (continued)*

Field	Description
x jabbers	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). Equivalent to etherHistoryJabbers in RMON.
x CRC alignment errors	Number of packets received during this sampling interval that had a length (excluding framing bits but including FCS octets) from 64 to 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Equivalent to etherHistoryCRCAlignErrors in RMON.
x collisions	Best estimate of the total number of collisions on this Ethernet segment during this sampling interval. Equivalent to etherHistoryCollisions in RMON.
# of dropped packet events is	Total number of events in which packets were dropped by the operation because of resources during this sampling interval. Note that this number is not necessarily the number of packets dropped, it is just the number of times this condition has been detected. Equivalent to etherHistoryDropEvents in RMON.
Network utilization is estimated at	Best estimate of the mean physical-layer network usage on this interface during this sampling interval, in hundredths of a percent. Equivalent to etherHistoryUtilization in RMON.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

show rmon hosts

To display the contents of the router's RMON hosts table, use the **show rmon hosts** EXEC command.

show rmon hosts

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon hosts** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

For additional information, refer to the RMON MIB described in RFC 1757.

Examples The following is sample output from the **show rmon hosts** command:

```
Router# show rmon hosts
```

```
Host Control Entry 1 is active, and owned by manager1
Monitors host ifEntry.1.1
Table size is 51, last time an entry was deleted was 00:00:00
Creation Order number is 1
Physical address is 0000.0c02.5808
Packets: rcvd 6963, transmitted 7041
Octets: rcvd 784062, transmitted 858530
# of packets transmitted: broadcast 28, multicast 48
# of bad packets transmitted is 0
```

[Table 124](#) describes the fields shown in the display.

Table 124 show rmon hosts Field Descriptions

Field	Description
Host Control Entry 1 is active, and owned by manager1	Unique index of the host entry, its current state, and the owner as defined in the hostControlTable of RMON.
Monitors host ifEntry.1.1	This object identifies the source of the data for this instance of the host function. Equivalent to hostControlDataSource in RMON.
Table size is	Number of hostEntries in the hostTable and the hostTimeTable associated with this hostControlEntry. Equivalent to hostControlTableSize in RMON.

Table 124 *show rmon hosts Field Descriptions (continued)*

Field	Description
last time an entry was deleted was	Time when the last entry was deleted from the hostTable.
Creation Order number is	Index that defines the relative ordering of the creation time of hosts captured for a particular hostControlEntry. Equivalent to hostCreationOrder in RMON.
Physical address is	Physical address of this host. Equivalent to hostAddress in RMON.
Packets: rcvd	Number of good packets transmitted to this address. Equivalent to hostInPkts in RMON.
transmitted	Number of packets, including bad packets transmitted by this address. Equivalent to hostOutPkts in RMON.
Octets: rcvd	Number of octets transmitted to this address since it was added to the hostTable (excluding framing bits but including FCS octets), except for those octets in bad packets. Equivalent to hostInOctets in RMON.
transmitted	Number of octets transmitted by this address since it was added to the hostTable (excluding framing bits but including FCS octets), including those octets in bad packets. Equivalent to hostOutOctets in RMON.
# of packets transmitted:	Number of good packets transmitted by this address that were broadcast or multicast.
# of bad packets transmitted is	Number of bad packets transmitted by this address.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

show rmon matrix

To display the contents of the router's RMON matrix table, use the **show rmon matrix EXEC** command.

show rmon matrix

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon matrix** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

For additional information, refer to the RMON MIB described in RFC 1757.

Examples The following is sample output from the **show rmon matrix** command:

```
Router# show rmon matrix

Matrix 1 is active, and owned by manager1
Monitors ifEntry.1.1
Table size is 451, last time an entry was deleted was at 00:00:00
```

[Table 125](#) describes the fields shown in the display.

Table 125 show rmon matrix Field Descriptions

Field	Description
Matrix 1 is active, and owned by manager1	Unique index of the matrix entry, its current state, and the owner as defined in the matrixControlTable of RMON.
Monitors ifEntry.1.1	This object identifies the source of the data for this instance of the matrix function. Equivalent to matrixControlDataSource in RMON.
Table size is 451, last time an entry was deleted was at	Size of the matrix table and the time that the last entry was deleted.

Related Commands	Command	Description
	rmon	Enables RMON on an Ethernet interface.
	rmon alarm	Sets an alarm on any MIB object.

Command	Description
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

show rmon statistics

To display the contents of the router's RMON statistics table, use the **show rmon statistics EXEC** command.

show rmon statistics

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON alarms and events to display alarm information with the **show rmon statistics** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

Examples The following is sample output from the **show rmon statistics** command:

```
Router# show rmon statistics
```

```
Interface 1 is active, and owned by config
Monitors ifEntry.1.1 which has
Received 60739740 octets, 201157 packets,
1721 broadcast and 9185 multicast packets,
0 undersized and 0 oversized packets,
0 fragments and 0 jabbers,
0 CRC alignment errors and 32 collisions.
# of dropped packet events (due to lack of resources): 511
# of packets received of length (in octets):
64: 92955, 65-127: 14204, 128-255: 1116,
256-511: 4479, 512-1023: 85856, 1024-1518:2547
```

[Table 126](#) describes the fields shown in the display.

Table 126 show rmon statistics Field Descriptions

Field	Description
Interface 1 is active, and owned by config	Unique index of the statistics entry, its current state, and the owner as defined in the etherStatsTable of RMON.
Monitors ifEntry.1.1	This object identifies the source of the data that this etherStats entry is configured to analyze. Equivalent to etherStatsDataSource in RMON.

Table 126 *show rmon statistics Field Descriptions (continued)*

Field	Description
Received 60739740 octets	Total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). Equivalent to etherStatsOctets in RMON.
<i>x</i> packets	Number of packets (including bad packets) received. Equivalent to etherStatsPkts in RMON.
<i>x</i> broadcast	Number of good packets received that were directed to the broadcast address. Equivalent to etherStatsBroadcastPkts in RMON.
<i>x</i> multicast packets	Number of good packets received that were directed to a multicast address. Equivalent to etherStatsMulticastPkts in RMON.
<i>x</i> undersized	Number of packets received that were fewer than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed. Equivalent to etherStatsUndersizedPkts in RMON.
<i>x</i> oversized packets	Number of packets received that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed. Equivalent to etherStatsOversizePkts in RMON.
<i>x</i> fragments	Total number of packets received that were fewer than 64 octets in length (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Equivalent to etherStatsFragments in RMON.
<i>x</i> jabbers	Number of packets received that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). Equivalent to etherStatsJabbers in RMON.
<i>x</i> CRC alignment errors	Number of packets received that had a length (excluding framing bits but including FCS octets) from 64 to 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). Equivalent to etherStatsCRCAlignErrors in RMON.
<i>x</i> collisions	Best estimate of the total number of collisions on this Ethernet segment. Equivalent to etherHistoryCollisions in RMON.

Table 126 *show rmon statistics Field Descriptions (continued)*

Field	Description
# of dropped packet events (due to lack of resources):	Total number of events in which packets were dropped by the operation because of a lack of resources. Note that this number is not necessarily the number of packets dropped, it is just the number of times this condition has been detected. Equivalent to etherStatsDropEvents in RMON.
# of packets received of length (in octets):	Separates the received packets (good and bad) by packet size in the given ranges (64, 65 to 127, 128 to 255, 256 to 511, 512 to 1023, 1024 to 1516).

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

show rmon topn

To display the contents of the router's RMON Top-N host table, use the **show rmon topn EXEC** command.

show rmon topn

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

For additional information, refer to the RMON MIB described in RFC 1757.

You must have first enabled RMON on the interface, and configured RMON events to display alarm information with the **show rmon events** command.

This command is available on the Cisco 2500 series and Cisco AS5200 series only.

Examples

The following is sample output from the **show rmon topn** command:

```
Router# show rmon topn
```

```
Host Entry 1 of report 1 is active, owned by manager1
The rate of change is based on hostTopNInPkts
This report was last started at 00:00:00
Time remaining in this report is 0 out of 0
Hosts physical address is 00ad.beef.002b
Requested # of hosts: 10, # of hosts granted: 10
Report # 1 of Top N hosts entry 1 is recording
Host 0000.0c02.5808 at a rate of 12
```

[Table 127](#) describes the fields shown in the display.

Table 127 show rmon topn Field Descriptions

Field	Description
Host Entry 1 of report 1 is active, owned by manager1	Unique index of the hostTopN entry, its current state, and the owner as defined in the hostTopNControlTable of RMON.
The rate of change is based on hostTopNInPkts	Variable for each host that the hostTopNRate variable is based on.
This report was last started at	Time the report was started.


Table 127 show rmon topn Field Descriptions (continued)

Field	Description
Time remaining in this report is	Number of seconds left in the report currently being collected. Equivalent to hostTopNTimeRemaining in RMON.
out of	Number of seconds that this report has collected during the last sampling interval, or if this report is currently being collected, the number of seconds that this report is being collected during this sampling interval. Equivalent to hostTopNDuration in RMON.
Hosts physical address is	Host address.
Requested # of hosts:	Maximum number of hosts requested for the Top-N table. Equivalent to hostTopNRequestedSize in RMON.
# of hosts granted:	Maximum number of hosts granted for the Top-N table. Equivalent to hostTopNGrantedSiz in RMON.
Report # 1 of Top N hosts entry 1 is recording	Report number and entry.
Host 0000.0c02.5808 at a rate of	Physical address of the host, and the amount of change in the selected variable during this sampling interval. Equivalent to hostTopNAddress and hostTopNRate in RMON.

Related Commands

Command	Description
rmon	Enables RMON on an Ethernet interface.
rmon alarm	Sets an alarm on any MIB object.
rmon event	Adds or removes an event in the RMON event table that is associated with an RMON event number.
show rmon	Displays the current RMON agent status on the router.

■ show rmon topn



Cisco Service Assurance Agent Commands

This chapter describes the commands used to monitor network performance using Cisco Service Assurance Agent (SAA) in Cisco IOS Release 12.2.

For SAA configuration tasks and examples, see the “Network Monitoring Using Cisco Service Assurance Agent” chapter in the *Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.2*.

buckets-of-history-kept

To set the number of history buckets that are kept during the operation lifetime of the SAA, use the **buckets-of-history-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

buckets-of-history-kept *size*

no buckets-of-history-kept

Syntax Description	<i>size</i>	Number of history buckets kept during the lifetime of the operation. The default is 50 buckets.

Defaults	50 buckets

Command Modes	SAA RTR configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.2</td><td>This command was introduced.</td></tr></table>	Release	Modification	11.2	This command was introduced.
Release	Modification				
11.2	This command was introduced.				

Usage Guidelines History collection and statistics capturing is enabled for the following SAA operations: ICMP Echo, SNA Echo, ICMP PathEcho, UDP Echo, TcpConnect, DNS, and DLSW. History collection is not supported for HTTP and Jitter (UDP+) operations.

By default, history is not collected. When a problem arises where history is useful (for example, a large number of timeouts are occurring), you can configure the **lives-of-history-kept** SAA RTR configuration command to collect history. You can optionally adjust the **buckets-of-history-kept**, **filter-for-history**, and **samples-of-history-kept** SAA RTR configuration commands.

When the number of buckets reaches the size specified, no further history for this life is stored.



Note

Collecting history increases the RAM usage. Only collect history when you think there is a problem in the network. For general network response time information, use the statistics gathering feature of SAA.

If history is collected, each bucket contains one or more history entries from the operation. When the operation type is **pathEcho**, an entry is created for each hop along the path that the operation takes to reach its destination. The type of entry stored in the history table is controlled by the **filter-for-history** SAA RTR configuration command. The total number of entries stored in the history table is controlled by the combination of **samples-of-history-kept**, **buckets-of-history-kept**, and **lives-of-history-kept** SAA RTR configuration commands.

Each time the SAA starts an operation, a new bucket is created until the number of history buckets matches the specified size or the operation's lifetime expires. History buckets do not wrap. The operation's lifetime is defined by the **rtr schedule** global configuration command. The operation starts an SAA operation based on the seconds specified by the **frequency** SAA RTR configuration command.

Examples

The following example configures operation 1 to keep 25 history buckets during the lifetime of the operation lifetime:

```
Router(config)# rtr 1  
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.161.21  
Router(config-rtr)# buckets-of-history-kept 25  
Router(config-rtr)# lives-of-history-kept 1
```

Related Commands

Command	Description
filter-for-history	Defines the type of information kept in the history table for the SA Agent operation.
lives-of-history-kept	Sets the number of lives maintained in the history table for the SA Agent operation.
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
rtr schedule	Configures the time parameters for an SAA operation.
samples-of-history-kept	Sets the number of entries kept in the history table per bucket for the SA Agent operation.

data-pattern

To specify the data pattern in an SAA udpEcho operation to test for data corruption, use the **data pattern** SAA RTR configuration mode command. To remove the data pattern specification, use the **no** form of this command.

data-pattern *hex-pattern*

no data-pattern *hex-pattern*

Syntax Description

<i>hex-pattern</i>	Hexadecimal sting to use for monitoring the specified operation.

Defaults

The default *hex-pattern* is ABCD.

Command Modes

SAA RTR configuration

Command History

Release	Modification
12.1(1)T	This command was introduced.

Usage Guidelines

The **data-pattern** command allows users to specify a alphanumeric character string to verify that operation payload does not get corrupted in either direction (source-to-destination (SD) or destination-to-source (DS)).

For Cisco IOS Release 12.2, the **data-pattern** command is applicable to the udpEcho operation only. This command also applies to the Frame Relay operation in 12.2(1)T and later T releases.

Examples

The following example specifies 1234ABCD5678 as the data pattern:

```
Router(config)# rtr 1
Router(config-rtr)# type udpEcho dest-ipaddr 10.0.54.205 dest-port 101
Router(config-rtr)# data-pattern 1234ABCD5678
```

Related Commands

Command	Description
show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.
show rtr collection-statistics	Displays statistical errors for all SAA operations or the specified operation.

distributions-of-statistics-kept

To set the number of statistic distributions kept per hop during the lifetime operation of the SAA, use the **distributions-of-statistics-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

distributions-of-statistics-kept *size*

no distributions-of-statistics-kept

Syntax Description	<i>size</i>	Number of statistic distributions kept per hop. The default is 1 distribution.

Defaults	1 distribution

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	In most situations, you do not need to change the statistic distribution size for the SAA. Only change the size when distributions are needed (for example, when performing statistical modeling of your network).

**Note**

Increasing the distributions also increases the RAM usage. The total number of statistics distributions captured will be: the value of **distributions-of-statistics-kept** times the value of **hops-of-statistics-kept** times the value of **paths-of-statistics-kept** times the value of **hours-of-statistics-kept**.

When the number of distributions reaches the size specified, no further distribution information is stored.

Examples	The following example sets the distribution to 5 and the distribution interval to 10 ms. This setting means that the first distribution will contain statistics from 0 to 9 ms, the second distribution will contain statistics from 10 to 19 ms, the third distribution will contain statistics from 20 to 29 ms, the fourth distribution will contain statistics from 30 to 39 ms, and the fifth distribution will contain statistics from 40 ms to infinity.

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.161.21
Router(config-rtr)# distributions-of-statistics-kept 5
Router(config-rtr)# statistics-distribution-interval 10
```

Related Commands

Command	Description
hops-of-statistics-kept	Sets the number of hops for which statistics are maintained per path for the SAA operation.
hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for the SAA operation.
paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for the SAA operation.
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
statistics-distribution-interval	Sets the time interval for each statistics distribution kept for the SA Agent.

filter-for-history

To define the type of information kept in the history table for an SAA operation, use the **filter-for-history** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

filter-for-history { **none** | **all** | **overThreshold** | **failures** }

no filter-for-history { **none** | **all** | **overThreshold** | **failures** }

Syntax Description

none	No history kept. This is the default.
all	All operation operations attempted are kept in the history table.
overThreshold	Only packets that are over the threshold are kept in the history table.
failures	Only packets that fail for any reason are kept in the history table.

Defaults

No SAA history is kept for an operation.

Command Modes

SAA RTR configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

Use the **filter-for-history** command to control what gets stored in the history table for the SAA. To control how much history gets saved in the history table, use the **lives-of-history-kept**, **buckets-of-history-kept**, and the **samples-of-history-kept** SAA RTR configuration commands.

An operation can collect history and capture statistics. By default, history is not collected. When a problem arises where history is useful (for example, a large number of timeouts are occurring), you can configure the **lives-of-history-kept** command to collect history.



Note

Collecting history increases the RAM usage. Only collect history when you think there is a problem. For general network response time information, use statistics.

Examples

In the following example, only operation packets that fail are kept in the history table:

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.161.21
Router(config-rtr)# lives-of-history-kept 1
Router(config-rtr)# filter-for-history failures
```

Related Commands	Command	Description
	buckets-of-history-kept	Sets the number of history buckets that are kept during the lifetime of the SAA.
	lives-of-history-kept	Sets the number of lives maintained in the history table for the SAA operation.
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	samples-of-history-kept	Sets the number of entries kept in the history table per bucket for the SAA operation.

frequency

To set the rate at which a specified SAA operation is sent into the network, use the **frequency** SAA RTR configuration command. To return to the default value, use the no form of this command.

frequency *seconds*

no frequency

Syntax Description	<i>seconds</i> Number of seconds between the SAA probe operations.	
Defaults	60 seconds	
Command Modes	SAA RTR configuration	
Command History	Release	Modification
	11.2	This command was introduced.
Usage Guidelines	If an individual SAA operational probe takes longer to execute than the specified frequency value, a statistics counter called “busy” is incremented rather than sending a second probe. Note We recommend that you do not set the frequency value to less than 60 seconds for the following reasons: It is not needed when keeping statistics (the default), and it can slow down the WAN because of the potential overhead that numerous operations can cause. The value specified for the frequency command cannot be less than the value specified for the timeout SAA RTR configuration command.	
Examples	The following example configures SAA IP/ICMP Echo operation 1 to send a probe every 90 seconds: <pre>Router(config)# rtr 1 Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176 Router(config-rtr)# frequency 90</pre>	
Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	timeout	Sets the amount of time the SAA operation waits for a response from its request packet.

hops-of-statistics-kept

To set the number of hops for which statistics are maintained per path for the SAA operation, use the **hops-of-statistics-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

hops-of-statistics-kept *size*

no hops-of-statistics-kept

Syntax Description	<i>size</i>	Number of hops for which statistics are maintained per path. The default is 16 hops for type pathEcho and 1 hop for type echo .

Defaults	16 hops for type pathEcho 1 hop for type echo

Command Modes	SAA RTR configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.2</td><td>This command was introduced.</td></tr></table>	Release	Modification	11.2	This command was introduced.
Release	Modification				
11.2	This command was introduced.				

Usage Guidelines	One hop is the passage of a timed packet from this router to another network device. The other network device is assumed to be a device along the path to the destination (including the destination) when the operation type is pathEcho, or just the destination when the type is echo. When the number of hops reaches the size specified, no further hop information is stored.

Examples	The following example monitors the statistics of operation 2 for only 10 hops: <pre>Router(config)# rtr 2 Router(config-rtr)# type pathecho protocol ipIcmpEcho 172.16.1.177 Router(config-rtr)# hops-of-statistics-kept 10</pre>

Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>distributions-of-statistics-kept</td><td>Sets the number of statistic distributions kept per hop during the lifetime of the SAA.</td></tr><tr><td>hours-of-statistics-kept</td><td>Sets the number of hours for which statistics are maintained for the SAA operation.</td></tr><tr><td>paths-of-statistics-kept</td><td>Sets the number of paths for which statistics are maintained per hour for the SAA operation.</td></tr></table>	Command	Description	distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during the lifetime of the SAA.	hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for the SAA operation.	paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for the SAA operation.
Command	Description								
distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during the lifetime of the SAA.								
hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for the SAA operation.								
paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for the SAA operation.								

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
statistics-distribution-interval	Sets the time interval for each statistics distribution kept for the SAA.

http-raw-request

To explicitly specify the options for a GET request for an SAA HTTP operation, use the **http-raw-request** command in SAA RTR configuration mode.

http-raw-request

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes SAA RTR configuration

Command History	Release	Modification
	12.0(5)T	This command was introduced.

Usage Guidelines

Using the **http-raw-request** command puts you in HTTP Raw Request configuration mode, indicated by the (config-rtr-http) router prompt.

The **http-raw-request** command should follow the **type http operation raw** command. Use the raw-request option when you wish to explicitly specify the content of an HTTP request. Use HTTP 1.0 commands in HTTP Raw Request configuration mode.

The SAA will specify the content of an HTTP request for you if you use the **type http operation get** command. SA Agent will send the HTTP request, receive the reply, and report RTT statistics (including the size of the page returned).

Examples

In the following example, SAA operation 6 is created and configured as an HTTP operation. The HTTP GET command is explicitly specified:

```
Router(config)# rtr 6
Router(config-rtr)# type http operation raw url http://www.cisco.com
Router(config-rtr)# http-raw-request
Router(config-rtr-http)# GET /index.html HTTP/1.0\r\n
Router(config-rtr-http)# \r\n
Router(config-rtr-http)# exit
Router(config)# rtr schedule 6 start-time now
```

Related Commands	Command	Description
	type http	Configures an HTTP SAA operation.

hours-of-statistics-kept

To set the number of hours for which statistics are maintained for the SAA operation, use the **hours-of-statistics-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

hours-of-statistics-kept *hours*

no hours-of-statistics-kept

Syntax Description	<i>hours</i> Number of hours that the router maintains statistics. The default is 2 hours.

Defaults	2 hours

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	When the number of hours exceeds the specified value, the statistics table wraps (that is, the oldest information is replaced by newer information). This command sets the amount of time statistics are kept for use by the show rtr collection-statistics command and show rtr distribution command.

Examples	The following example maintains 3 hours of statistics for SAA operation 2:

```
Router(config)# rtr 2  
Router(config-rtr)# type pathecho protocol ipIcmpEcho 172.16.1.177  
Router(config-rtr)# hours-of-statistics-kept 3
```

Related Commands	Command	Description
	distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during the lifetime of the SAA.
	hops-of-statistics-kept	Sets the number of hops for which statistics are maintained per path for the SAA operation.
	paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for the SAA operation.
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	statistics-distribution-interval	Sets the time interval for each statistic distribution kept for the SA Agent.

lives-of-history-kept

To set the number of lives maintained in the history table for the SAA operation, use the **lives-of-history-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

lives-of-history-kept *lives*

no lives-of-history-kept

Syntax Description	<i>lives</i>	Number of lives maintained in the history table for the operation. If you specify 0 lives, history is not collected for the operation.

Defaults	0 lives

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines

The number of lives you can specify is dependent on the type of operation you are configuring. Use the **lives-of-history-kept ?** command to determine the available options.

The default value of 0 lives means that history is not collected for the operation.

To disable history collection, use **no lives-of-history-kept** command rather than the **filter-for-history none** SAA RTR configuration command. The **no lives-of-history-kept** command disables history collection before an operation is attempted, while the **filter-for-history** command causes the SAA to check for history inclusion after the operation attempt is made.

When the number of lives exceeds the specified value, the history table wraps (that is, the oldest information is replaced by newer information).

When an operation makes a transition from pending to active, a life starts. When the life of an operation ends, the operation makes a transition from active to pending.

Examples

The following example maintains the history for 5 lives of operation 1:

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176
Router(config-rtr)# lives-of-history-kept 5
```

Related Commands

Command	Description
buckets-of-history-kept	Sets the number of history buckets that are kept during the lifetime of the SAA.
filter-for-history	Defines the type of information kept in the history table for the SAA operation.
rtr	Enters SAA RTR configuration mode.
samples-of-history-kept	Sets the number of entries kept in the history table per bucket for the SA Agent operation.

lsr-path

To define a loose source routing (LSR) path for a Cisco SAA IP echo operation, use the **lsr-path** SAA RTR configuration command. To remove the definition, use the **no** form of this command.

```
lsr-path {hostname | ip-address} [{hostname | ip-address} ...]

no lsr-path
```

Syntax Description	{hostname ip-address}	Hostname or IP address of the first hop in the LSR path.
	[{hostname ip-address} ...]	(Optional) Indicates that you can continue specifying host destinations until you specify the final host target. Each hostname or ip-address specified indicates another hop on the path. The maximum number of hops you can specify is eight. Do not enter the dots (...).

Defaults LSR path is disabled.

Command Modes SAA RTR configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines The maximum number of hops available is eight when an LSR path is configured.

Examples In the following example, the LSR path is defined for SAA echo operation 1. The target destination for the operation is at 172.16.1.176. The first hop on the LSR path is 172.18.4.149. The second hop on the LSR path is 172.18.16.155.

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176
Router(config-rtr)# lsr-path 172.18.4.149 172.18.26.155
```

Related Commands	Command	Description
	rtr	Specifies an identification for an SAA operation and enters SAA RTR configuration mode.

owner

To configure the Simple Network Management Protocol (SNMP) owner of an SAA operation, use the **owner** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

owner *text*

no owner

Syntax Description	<i>text</i>	Name of the SNMP owner from 0 to 255 ASCII characters. The default is none.

Defaults	No owner is specified.

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	The owner name contains one or more of the following: ASCII form of the network management station's transport address, network management station name (that is, the domain name), and network management personnel's name, location, or phone number. In some cases, the agent itself will be the owner of the operation. In these cases, the name can begin with "agent."

Examples	The following example sets the owner of operation 1 to 172.16.1.189 cwb.cisco.com John Doe RTP 555-1212:

```
Router(config)# rtr 1  
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176  
Router(config-rtr)# owner 172.16.1.189 cwb.cisco.com John Doe RTP 555-1212
```

Related Commands	Command	Description
	rtr	Enters SAA RTR configuration mode.

paths-of-statistics-kept

To set the number of paths for which statistics are maintained per hour for the SAA operation, use the **paths-of-statistics-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

paths-of-statistics-kept *size*

no paths-of-statistics-kept

Syntax Description

size Number of paths for which statistics are maintained per hour. The default is 5 paths for **type pathEcho** and 1 path for **type echo**.

Defaults

5 paths for **type pathEcho**

1 path for **type echo**

Command Modes

SAA RTR configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

A path is the route the request packet of the operation takes through the network to get to its destination. The operation may take a different path to reach its destination for each SAA operation.

When the number of paths reaches the size specified, no further path information is stored.

Examples

The following example maintains statistics for only 3 paths for operation 2:

```
Router(config)# rtr 2
Router(config-rtr)# type pathEcho protocol ipIcmpEcho 172.16.1.177
Router(config-rtr)# paths-of-statistics-kept 3
```

Related Commands

Command	Description
distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during the lifetime of the SA.
hops-of-statistics-kept	Sets the number of hops for which statistics are maintained per path for the SAA operation.
hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for the SAA operation.

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
statistics-distribution-interval	Sets the time interval for each statistics distribution kept for the SAA.

request-data-size

To set the protocol data size in the payload of the SAA operation’s request packet, use the **request-data-size** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

request-data-size *byte*

no request-data-size

Syntax Description	<i>byte</i>	Size of the protocol data in the payload of the request packet of the operation. Range is 0 to the maximum of the protocol. The default is 1 byte.

Defaults	1 byte

Command Modes	SAA RTR configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.2</td><td>This command was introduced.</td></tr></table>	Release	Modification	11.2	This command was introduced.
Release	Modification				
11.2	This command was introduced.				

Usage Guidelines	When the protocol name has the suffix “appl,” the packet uses both a request and respond data size (see the response-data-size SAA RTR configuration command), and the data size is 12 bytes smaller than the normal payload size (this 12 bytes is the ARR Header used to control send and data response sizes).

Examples	The following example sets the request packet size to 40 bytes for operation 3: <pre>Router(config)# rtr 3 Router(config-rtr)# type echo protocol snalu0echoappl cwbc0a Router(config-rtr)# request-data-size 40</pre>

Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>response-data-size</td><td>Sets the protocol data size in the payload of the SAA operation’s response packet.</td></tr><tr><td>rtr</td><td>Specifies an SAA operation and enters SAA RTR configuration mode.</td></tr></table>	Command	Description	response-data-size	Sets the protocol data size in the payload of the SAA operation’s response packet.	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
Command	Description						
response-data-size	Sets the protocol data size in the payload of the SAA operation’s response packet.						
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.						

response-data-size

To set the protocol data size in the payload of an SAA operation's response packet, use the **response-data-size** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

response-data-size *byte*

no response-data-size

Syntax Description	<i>byte</i>	Size of the protocol data in the payload in the operation's response packet. For "appl" protocols, the default is 0 bytes. For all others, the default is the same value as the request-data-size .

Defaults	0 bytes

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines The **response-data-size** command is only applicable for the following operations:

- type echo protocol snaLU0EchoAppl
- type echo protocol snaLU2EchoAppl
- type pathEcho protocol snaLU0EchoAppl
- type pathEcho protocol snaLU2EchoAppl

Note that these protocols are defined with the **type** command that end in "appl" (for example, **snaLU0echoappl**). When the protocol ends in "appl," the response data size is 12 bytes smaller than normal payload size.

Examples The following example configures the response packet size of snaLU0 Echo operation 3 to 1440 bytes:

```
Router(config)# rtr 3
Router(config-rtr)# type echo protocol snaLU0echoappl cwbc0a
Router(config-rtr)# response-data-size 1440
```

Related Commands	Command	Description
	request-data-size	Sets the protocol data size in the payload of the SAA operation's request packet.
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

rtr

To begin configuring an SAA operation by entering SAA RTR configuration mode, use the **rtr** command in global configuration mode. To remove all configuration information for an operation, including the schedule of the operation, reaction configuration, and reaction triggers, use the **no** form of this command.

rtr *op-number*

no rtr *op-number*

Syntax Description

<i>op-number</i>	Operation number used for the identification of the SAA operation you wish to configure.

Defaults

None

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2(11)T	The maximum number of operations was increased from 500 to 2000.

Usage Guidelines

The **rtr** command is used to configure Cisco Service Assurance Agent (SAA) operations. Use this command to specify an identification number for the operation you are about to configure. After you enter this command, you will enter the SAA RTR configuration mode, indicated by the (config-rtr) router prompt. The “Related Commands” table lists the commands you can use in SAA RTR configuration mode.

For detailed information on the configuration of the Cisco SAA feature, see the “Network Monitoring Using Cisco Service Assurance Agent” chapter in the *Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.2*.

SAA allows a maximum of 500 operations.

Debugging is supported only on the first 32 operation numbers.

After you configure a operation, you must schedule the operation. For information on scheduling a operation, refer to the **rtr schedule** global configuration command. You can also optionally set reaction triggers for the operation. For information on reaction triggers, refer to the **rtr reaction-configuration** and **rtr reaction-trigger** global configuration commands.



Note

After you schedule an operation with the **rtr schedule** global configuration command, you cannot modify the configuration of the operation. To modify the configuration of the operation after it is scheduled, use the **no rtr** command. You can now reenter the operation’s configuration with the **rtr** command.

To display the current configuration settings of the operation, use the **show rtr configuration EXEC** command.

Examples

In the following example, operation 1 is configured to perform end-to-end response time operations using an SNA LU Type 0 connection with the host name cwbc0a. Only the **type SAA RTR** configuration command is required; all others are optional.

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol snalu0echoappl cwbc0a
Router(config-rtr)# request-data-size 40
Router(config-rtr)# response-data-size 1440
Router(config-rtr)# exit
Router(config)#
```



Note

If operation 1 already existed and it has not been scheduled, you are placed into SAA RTR configuration command mode. If the operation already exists and has been scheduled, this command will fail.

Related Commands

Command	Description
buckets-of-history-kept	Sets the number of history buckets that are kept during an SAA operation's lifetime.
distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during an SAA operation's lifetime.
filter-for-history	Defines the types of information to be kept in the history table for SAA operations.
frequency	Sets the frequency at which the operation should execute.
hops-of-statistics-kept	Sets the number of hops for which statistics are maintained per path for the SAA operation.
hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for SAA operations.
lives-of-history-kept	Sets the number of lives maintained in the history table for an SAA operation.
lsr path	Specifies the path on which to measure the ICMP Echo response time.
owner	Configures the SNMP owner of an SAA operation.
paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for an SAA operation.
request-data-size	Sets the protocol data size in the payload of an operation's request packet.
response-data-size	Sets the protocol data size in the payload of an operation's response packet.
samples-of-history-kept	Sets the number of entries kept in the history table for an SAA operation.
statistics-distribution-interval	Sets the time interval for each statistical distribution.
tag	Logically links SAA operations together in a group.

Command	Description
threshold	Sets the rising threshold (hysteresis) that generates a reaction event and stores history information for the probe.
timeout	Sets the amount of time an SAA operation waits for a response from its request packet.
tos	Defines the IP type of service for request packets of SAA operations.
type dls	Configures an SAA DLSw operation.
type tcpConnect	Defines an SAA TCP Connect operation.
verify-data	Checks each SAA operation response for corruption.

rtr key-chain

To enable SAA control message authentication and specify an MD5 key chain, use the **rtr key-chain** global configuration command. To remove control message authentication, use the **no** form of this command.

rtr key-chain *name*

no rtr key-chain

Syntax Description	<i>name</i> Name of MD5 key chain.	
Defaults	None	
Command Modes	Global configuration	
Command History	Release	Modification
	12.0(3)T	This command was introduced.
Usage Guidelines	The authentication configuration on the SAA collector and SAA Responder must be the same. Both sides must configure the same key chain or both sides must not use authentication.	
Examples	In the following example, the SAA control message uses MD5 authentication, and the key chain name is CSAA: Router(config)# rtr key-chain csaa	
Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

rtr low-memory

To specify how much unused memory must be available to allow SAA configuration, use the **rtr low-memory** global configuration command. To remove the type configuration for the operation, use the **no** form of this command.

rtr low-memory *value*

no rtr low-memory

Syntax Description

<i>value</i>	Specifies amount of memory, in bytes, that must be available to configure SAA (RTR). The range is from 0 to the maximum amount of free memory bytes available.

Defaults

The default *value* is 25 percent of the memory available on the system.

Command Modes

Global configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

The **rtr low-memory** command allows the user to specify the amount of memory that the SAA can use. If the amount of available free memory falls below the value specified in the **rtr low-memory** command, then the SAA will not allow new operations to be configured. If this command is not used, the default low-memory value is 25 percent. This means that if 75 percent of system memory has been utilized you will not be able to configure any SAA characteristics.

The value of the **rtr low-memory** command should not exceed the amount of free memory available on the system. To determine the amount of free memory available on the system, use the **show memory EXEC** command.

Examples

In the following example, the router is configured so that no less than 2 MB of memory will be free for RTR configuration:

```
Router(config)# rtr low-memory 2000000
```

Related Commands

Command	Description
rtr	Specifies an identification number for an operation and enters SAA RTR configuration mode.
show memory	Displays statistics about memory, including memory-free pool statistics.

rtr reaction-configuration

To configure certain actions to occur based on events under the control of the SAA, use the **rtr reaction-configuration** global configuration command. To return to the default values of the operation, use the **no** form of this command.

```
rtr reaction-configuration operation-number [verify-error-enable] [connection-loss-enable]
[timeout-enable] [threshold-falling milliseconds] [threshold-type option] [action-type
option]
```

```
no rtr reaction-configuration operation-number
```

Syntax Description

<i>operation-number</i>	Number of the SAA operation to configure.
verify-error-enable	(Optional) Enables error verification. The default is disabled.
connection-loss-enable	(Optional) Enables checking for connection loss in connection-oriented protocols. Disabled by default.
timeout-enable	(Optional) Enables checking for response time reporting operation timeouts based on the timeout value configured for the operation with the timeout SAA RTR configuration command. The default is disabled.
threshold-falling <i>milliseconds</i>	(Optional) Sets the falling threshold (standard RMON-type hysteresis mechanism) in milliseconds. When the falling threshold is met, generate a resolution reaction event. The rising of the operation over threshold is set with the threshold SAA RTR configuration command. The default value is 3000 ms.
threshold-type <i>option</i>	(Optional) Specify the algorithm used by the SAA to calculate over and falling threshold violations. The value for <i>option</i> can be one of the following keywords: never—Do not calculate threshold violations (the default). immediate—When the response time exceeds the rising over threshold or drops below the falling threshold, immediately perform the action defined by action-type. consecutive [<i>occurrences</i>]—When the response time exceeds the rising threshold consecutively five times or drops below the falling threshold consecutively five times, perform the action defined by action-type. Optionally specify the number of consecutive occurrences. The default is 5. xofy [<i>x-value y-value</i>]—When the response time exceeds the rising threshold five out of the last five times or drops below the falling threshold five out of the last five times, perform the action defined by action-type. Optionally specify the number of violations that must occur and the number that must occur within a specified number. The default is 5 for both x-value and y-value.

	• average [<i>attempts</i>]—When the average of the last five response times exceeds the rising threshold or when the average of the last five response times drops below the falling threshold, perform the action defined by action-type. Optionally specify the number of operations to average. The default is the average of the last five response time operations. For example: if the threshold of the operation is 5000 ms and the last three attempts results of the operation are 6000, 6000, and 5000 ms, the average would be $6000 + 6000 + 5000 = 17000 / 3 > 5000$, thus violating the 5000-ms threshold.
action-type option	(Optional) Specify what action or combination of actions the operation performs when you configure connection-loss-enable or timeout-enable, or threshold events occur. For the action-type to occur for threshold events, the threshold-type must be defined to anything other than never. Option can be one of the following keywords: • none—No action is taken. • trapOnly—Send an SNMP trap on both over and falling threshold violations. • nmvtOnly—Send an SNA NMVT Alert on over threshold violation and an SNA NMVT Resolution on falling threshold violations. • triggerOnly—Have one or more target operation's operational state make the transition from "pending" to "active" on over (and falling) threshold violations. The target operations are defined with the rtr reaction-trigger command. A target operation will continue until its life expires as specified by the target operation's life value configured with the rtr schedule global configuration command. A triggered target operation must finish its life before it can be triggered again. • trapAndNmvt—Send a combination of trapOnly and nmvtOnly. • trapAndTrigger—Send a combination of trapOnly and triggerOnly. • nmvtAndTrigger—Send a combination of nmvtOnly and triggerOnly. • trapNmvtAndTrigger—Send a combination of trapOnly, nmvtOnly, and triggerOnly.

Defaults

No reactions are generated.
 Error verification is disabled.
 Connection loss is disabled.
 Checking the timeout is disabled.
 The falling threshold value is 3000 ms.
 The algorithm threshold is **never**.

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.
12.1(1)T	The verify-error-enable optional keyword was added.

Usage Guidelines

Triggers are used for diagnostics purposes and are not used in normal operation.

You can use triggers to assist you in determining where delays are happening in the network when excessive delays are being seen on an end-to-end basis.

The reaction applies only to attempts to the target (that is, attempts to any hops along the path in **pathEcho** do not generate reactions).



Note

Keywords are not case sensitive and are shown in mixed case for readability only.


Examples

In the following example, operation 19 sends an SNMP trap when there is an over or falling threshold violation:

```
Router(config)# rtr reaction-configuration 19 threshold-type immediate action-type trapOnly
```

Figure 2 shows that an alert (rising trap) would be issued immediately when the response time exceeds the rising threshold and a resolution (falling trap) would be issued immediately when the response time drops below the falling threshold.

Figure 2 Example of Rising and Falling Thresholds



S4793

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
rtr reaction-trigger	Defines a second SAA operation to make the transition from a pending state to an active state when one of the trigger action-type options are defined with the rtr reaction-configuration global configuration command.
threshold	Sets the rising threshold (hysteresis) that generates a reaction event and stores history information for the SAA operation.
timeout	Sets the amount of time the SAA operation waits for a response from its request packet.

rtr reaction-trigger

To define a second SAA operation to make the transition from a pending state to an active state when one of the trigger action-type options are defined with the **rtr reaction-configuration** global configuration command, use the **rtr reaction-trigger** global configuration command. To remove the trigger combination, use the **no** form of this command.

```
rtr reaction-trigger operation-number target-operation

no rtr reaction-trigger operation
```

Syntax Description	operation-number	Number of the operation in the active state that has the action-type set with the rtr reaction-configuration global configuration command.
	target-operation	Number of the operation in the pending state that is waiting to be triggered with the rtr global configuration command.

Defaults No trigger combination is defined.

Command Modes Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines Triggers are usually used for diagnostics purposes and are not used in normal operation.

Examples In the following example, the state of operation 1 is changed from pending state to active state when **action-type** of operation 2 occurs:

```
Router(config)# rtr reaction-trigger 2 1
```

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	rtr reaction-configuration	Configures certain actions to occur based on events under the control of the SAA.
	rtr schedule	Configures the time parameters for an SAA operation.

rtr reset

To perform a shutdown and restart of the SAA, use the **rtr reset** global configuration command.

rtr reset

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	Global configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines



Caution

Use the **rtr reset** command only in extreme situations such as the incorrect configuration of a number of operations.

The **rtr reset** command stops all operations, clears SAA RTR configuration information, and returns the SAA feature to the startup condition. This command does not reread the SAA RTR configuration stored in startup-config in NVRAM. You must retype the configuration or perform a **config memory** command.

Examples	The following example resets the SAA feature:

```
Router(config)# rtr reset
```

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

rtr responder

To enable the SAA Responder feature, use the **rtr responder** global configuration command. To disable the SAA Responder, use the **no** form of this command.

rtr responder [**type** {**udpEcho** | **tcpConnect**} [**ipaddress** *ipaddr*] **port** *port*]

no rtr responder [**type** {**udpEcho** | **tcpConnect**} [**ipaddress** *ipaddr*] **port** *port*]

Syntax Description

type udpEcho	(Optional) Specifies that the responder will accept and return udpEcho operation packets. Note You should use type udpEcho keyword combination for Jitter (UDP Echo +) operations as well.
type tcpConnect	(Optional) Specifies that the responder will accept and return tcpConnect operation packets.
ipaddress <i>ipaddr</i>	(Optional) Specifies the IP address that the operation will be received at.
port <i>port</i>	(Optional) Specifies the port number that the operation will be received on.

Defaults

None

Command Modes

Global configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.
12.1(1)T	The type , ipaddr , and port keywords were added.

Usage Guidelines

This command is used on the destination device for SAA operations to enable UDP Echo, TCP Connect, and Jitter (UDP+) operations on non-native interfaces.

The **type**, **ipaddr**, and **port** keywords enable the SAA Responder to respond to probe packets without receiving Control Protocol packets. The applicable protocols are Jitter, udpEcho, and tcpConnect. However, note that if you use these keywords, packet loss statistics will not be able to be generated for the operation, because the Responder will not be able to determine the order of the received packets.

Examples

The following example enables the SAA Responder:

```
Router(config)# rtr responder
```


Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

rtr restart

To restart an SAA operation, use the **rtr restart** global configuration command.

rtr restart *operation-number*

Syntax Description	<i>operation-number</i>	Number of the SAA operation to restart. SAA allows a maximum of 500 operations.

Defaults	No default behavior or values.

Command Modes	Global configuration.

Command History	Release	Modification
	12.1(1)T	This command was introduced.

Usage Guidelines	To restart an operation, the operation should be in an “active” state (as defined in the rtr reaction-configuration command).
	SAA allows a maximum of 500 operations.
	This command does not have a no form.

Examples	The following example restarts operation 12:
	Router(config)# rtr restart 12

rtr schedule

To configure the time parameters for an SAA operation, use the **rtr schedule** global configuration command. To stop the operation and place it in the default state (**pending**), use the **no** form of this command.

```
rtr schedule operation-number [life {forever | seconds}] [start-time
{hh:mm[:ss] [month day | day month] | pending | now | after hh:mm:ss}] [ageout seconds]
```

```
no rtr schedule operation-number
```

Syntax Description	
<i>operation-number</i>	(Required) Number of the SAA operation to schedule.
life <i>seconds</i>	(Optional) Number of seconds the operation actively collects information. The default is 3600 seconds (one hour).
life forever	(Optional) Schedules the operation to run indefinitely.
start-time	(Optional) Time when the operation starts collecting information. If the start-time is not specified, no information is collected until the start-time is configured or a trigger occurs that performs a start-time now .
start-time <i>hh:mm[:ss]</i>	(Optional) Specifies an absolute start time using hour, minute, and (optionally) second. Use the 24-hour clock notation. For example, start-time 01:02 means “start at 1:02 a.m.,” and start-time 13:01:30 means “start at 1:01 p.m. and 30 seconds.” The current day is implied unless you specify a <i>month</i> and <i>day</i> .
<i>month</i>	(Optional) Name of the month to start the operation in. If month is not specified, the current month is used. Use of this argument requires that a day be specified as well. You can specify the month with the full english name, or using the first three letters of the month.
<i>day</i>	(Optional) Number of the day (in the range 1 to 31) to start the operation on. If a day is not specified, the current day is used. Use of this argument requires that a month be specified as well.
start-time pending	(Optional) No information is collected. This is the default value.
start-time now	(Optional) Indicates that the operation should start immediately.
start-time after <i>hh:mm:ss</i>	(Optional) Indicates that the operation should start <i>hh</i> hours, <i>mm</i> minutes, and <i>ss</i> seconds after this command was entered.
ageout <i>seconds</i>	(Optional) Number of seconds to keep the operation in memory when it is not actively collecting information. The default is 0 seconds (never ages out).

Defaults

The operation is placed in a **pending** state (that is, the operation is enabled but not actively collecting information).

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.
12.1(1)T	The after and forever keywords were added.

Usage Guidelines

After you schedule the operation with the **rtr schedule** command, you cannot change the configuration of the operation. To change the configuration of the operation, use the **no** form of the **rtr** global configuration command and reenter the configuration information.

If the operation is in a pending state, you can define the conditions under which the operation makes the transition from pending to active with the **rtr reaction-trigger** and **rtr reaction-configuration** global configuration commands. When the operation is in an active state, it immediately begins collecting information.

The following time line shows the age-out process of the operation:

W-----X-----Y-----Z

where:

- W is the time the operation was configured with the **rtr** global configuration command.
- X is the start time or start of life of the operation (that is, when the operation became “active”).
- Y is the end of life as configured with the **rtr schedule** global configuration command (life seconds have counted down to zero).
- Z is the age out of the operation.

Age out starts counting down at W and Y, is suspended between X and Y, and is reset to its configured size at Y.

It is possible for the operation to age out before it executes (that is, Z can occur before X). To ensure that this does not happen, the difference between the operation’s configuration time and start time (X and W) must be less than the age-out seconds.

**Note**

The total RAM required to hold the history and statistics tables is allocated at this time. This is to prevent router memory problems when the router gets heavily loaded and to lower the amount of overhead the feature causes on a router when it is active.

Examples

In the following example, operation 25 begins actively collecting data at 3:00 p.m. on April 5. This operation will age out after 12 hours of inactivity, which can be before it starts or after it has finished with its life. When this operation ages out, all configuration information for the operation is removed (that is, the configuration information is no longer in the running-config in RAM).

```
Router(config)# rtr schedule 25 life 43200 start-time 15:00 apr 5 ageout 43200
```

In the following example, operation 1 begins collecting data after a 5 minute delay:

```
Router(config)# rtr schedule 1 start after 00:05:00
```

In the following example, operation 3 begins collecting data immediately and is scheduled to run indefinitely:

```
Router(config)# rtr schedule 3 start-time now life forever
```

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	rtr reaction-configuration	Configures certain actions to occur based on events under the control of the SAA.
	rtr reaction-trigger	Defines a second SAA operation to make the transition from a pending state to an active state when one of the trigger action-type options is defined with the rtr reaction-configuration global configuration command.

samples-of-history-kept

To set the number of entries kept in the history table per bucket for the SAA operation, use the **samples-of-history-kept** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

samples-of-history-kept *samples*

no samples-of-history-kept

Syntax Description	<i>samples</i>	Number of entries kept in the history table per bucket. The default is 16 entries for type pathEcho and 1 entry for type echo .

Defaults	16 entries for type pathEcho 1 entry for type echo

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	Use the samples-of-history-kept command to control how many entries are saved in the history table. To control the type of information that gets saved in the history table, use the filter-for-history command. To set how many buckets get created in the history table, use the buckets-of-history-kept command. An operation can collect history and capture statistics. By default, history is not collected. When a problem arises where history is useful (for example, a large number of timeouts are occurring), you can configure the lives-of-history-kept SAA RTR configuration command to collect history.



Note	Collecting history increases the usage of RAM. Only collect history when you think there is a problem. For general network response time information, use statistics.

Examples	In the following example, ten entries are kept in the history table for each of the lives of operation 3: <pre>Router(config)# rtr 1 Router(config-rtr)# type pathecho protocol ipIcmpEcho 172.16.1.176 Router(config-rtr)# lives-of-history-kept 3 Router(config-rtr)# samples-of-history-kept 10</pre>

Related Commands

Command	Description
buckets-of-history-kept	Sets the number of history buckets that are kept during the lifetime of the SAA.
filter-for-history	Defines the type of information kept in the history table for the SAA operation.
lives-of-history-kept	Sets the number of lives maintained in the history table for the SAA operation.
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

show rtr application

To display global information about the SAA feature, use the **show rtr application** EXEC command.

show rtr application [**tabular** | **full**]

Syntax Description	tabular	(Optional) Displays information in a column format reducing the number of screens required to display the information.
	full	(Optional) Displays all information using identifiers next to each displayed value. This is the default.

Defaults	Full format

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	Use the show rtr application command to display information such as supported operation types and supported protocols.

Examples	The following is sample output from the show rtr application command in full format:

```
router#show rtr application

      Response Time Reporter
Version: 2.2.0 Round Trip Time MIB
Max Packet Data Size (ARR and Data): 16384
Time of Last Change in Whole RTR: 03:34:44.000 UTC Sun Feb 11 2001
System Max Number of Entries: 500

Number of Entries configured:5
    Number of active Entries:5
    Number of pending Entries:0
    Number of inactive Entries:0
      Supported Operation Types
Type of Operation to Perform:  echo
Type of Operation to Perform:  pathEcho
Type of Operation to Perform:  udpEcho
Type of Operation to Perform:  tcpConnect
Type of Operation to Perform:  http
Type of Operation to Perform:  dns
Type of Operation to Perform:  jitter
Type of Operation to Perform:  dlsw
Type of Operation to Perform:  dhcp
Type of Operation to Perform:  ftp
```



```
Supported Protocols
Protocol Type: ipIcmpEcho
Protocol Type: ipUdpEchoAppl
Protocol Type: snaRUEcho
Protocol Type: snaLU0EchoAppl
Protocol Type: snaLU2EchoAppl
Protocol Type: ipTcpConn
Protocol Type: httpAppl
Protocol Type: dnsAppl
Protocol Type: jitterAppl
Protocol Type: dlsr
Protocol Type: dhcp
Protocol Type: ftpAppl

Number of configurable probe is 490
```

Related Commands

Command	Description
show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.

show rtr authentication

To display SAA RTR authentication information, use the **show rtr authentication** EXEC command.

show rtr authentication

Syntax Description This command has no arguments or keywords.

Command Modes EXEC

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines Use the **show rtr authentication** command to display information such as supported operation types and supported protocols.

Examples The following is sample output from the **show rtr application** command:

```
Router# show rtr authentication

RTR control message uses MD5 authentication, key chain name is: rtr
```

Related Commands	Command	Description
	show rtr configuration	Displays configuration values for RTR operations (probes).

show rtr collection-statistics



Note

Effective with Cisco IOS Release 12.3(14)T, the **show rtr collection-statistics** command is replaced by the **show ip sla monitor collection-statistics** command. See the **show ip sla monitor collection-statistics** command for more information.

To display statistical errors for all Cisco IOS IP Service Level Agreements (IP SLAs) operations or a specified operation, use the **show rtr collection-statistics** command in EXEC mode.

show rtr collection-statistics [*operation-number*]

Syntax Description

operation-number (Optional) Number of the IP SLAs operation to display.

Defaults

Shows statistics for the past two hours.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.0(5)T	The output for this command was expanded to show information for Jitter operations.
12.1	The tabular and full keywords were removed.
12.1(1)T	The output for this command was expanded to show information for the FTP operation type and for One Way Delay Jitter operations.
12.2(8)T, 12.2(8)S	Output for “NumOfJitterSamples” was added (CSCdv30022).
12.2(11)T	The SAA Engine II was implemented. The maximum number of operations was increased from 500 to 2000.
12.3(4)T	Output (MOS and ICPIF scores) for the Jitter (codec) operation type was added.
12.3(7)T	Decimal granularity for MOS scores was added.
12.3(14)T	This command was replaced by the show ip sla monitor collection-statistics command.

Usage Guidelines

Use the **show rtr collection-statistics** command to display information such as the number of failed operations and the failure reason. You can also use the **show rtr distribution-statistics** and **show rtr totals-statistics** commands to display additional statistical information.

This command shows information collected over the past two hours, unless you specify a different amount of time using the **hours-of-statistics-kept** command.

For One Way Delay Jitter operations, the clocks on each device must be synchronized using NTP (or GPS systems). If the clocks are not synchronized, one way measurements are discarded. (If the sum of the source to destination (SD) and the destination to source (DS) values is not within 10 percent of the round trip time, the one way measurement values are assumed to be faulty, and are discarded.)

**Note**

This command does not support the IP SLAs ICMP path jitter operation.

Examples

The following shows sample output from the **show rtr collection-statistics** command in full format.

```
Router# show rtr collection-statistics 1

      Collected Statistics
Entry Number: 1
Start Time Index: *17:15:41.000 UTC Thu May 16 1996
Path Index: 1
Hop in Path Index: 1
Number of Failed Operations due to a Disconnect: 0
Number of Failed Operations due to a Timeout: 0
Number of Failed Operations due to a Busy: 0
Number of Failed Operations due to a No Connection: 0
Number of Failed Operations due to an Internal Error: 0
Number of Failed Operations due to a Sequence Error: 0
Number of Failed Operations due to a Verify Error: 0
Target Address: 172.16.1.176
```

Output for HTTP Operations

The following example shows output from the **show rtr collection-statistics** command when the specified operation is an HTTP operation:

```
Router# show rtr collection-statistics 2

      Collected Statistics

Entry Number:2
HTTP URL:http://172.20.150.200
Start Time:*00:01:16.000 UTC Mon Nov 1 2003

      Comps:1           RTTMin:343
      OvrTh:0           RTTMax:343
      DNSTimeOut:0       RTTSum:343
      TCPTimeOut:0       RTTSum2:117649
      TraTimeOut:0       DNSRTT:0
      DNSError:0         TCPConRTT:13
      HTTPError:0        TransRTT:330
      IntError:0         MesgSize:1771
      Busies:0
```

Output for Jitter Operations

The following is sample output from the **show rtr collection-statistics** command, where operation 2 is a Jitter operation that includes One Way statistics:

```
Router# show rtr collection-statistics

      Collected Statistics

Entry Number: 2
```

```

Target Address: 5.0.0.1, Port Number:99
Start Time: 11:12:03.000 UTC Thu Jul 1 1999
RTT Values:
NumOfRTT: 600 RTTSum: 3789 RTTSum2: 138665
Packet Loss Values:
PacketLossSD: 0 PacketLossDS: 0
PacketOutOfSequence: 0 PacketMIA: 0 PacketLateArrival: 0
InternalError: 0 Busies: 0
Jitter Values:
MinOfPositivesSD: 1 MaxOfPositivesSD: 2
NumOfPositivesSD: 26 SumOfPositivesSD: 31 Sum2PositivesSD: 41
MinOfNegativesSD: 1 MaxOfNegativesSD: 4
NumOfNegativesSD: 56 SumOfNegativesSD: 73 Sum2NegativesSD: 133
MinOfPositivesDS: 1 MaxOfPositivesDS: 338
NumOfPositivesDS: 58 SumOfPositivesDS: 409 Sum2PositivesDS: 114347
MinOfNegativesDS: 1 MaxOfNegativesDS: 338
NumOfNegativesDS: 48 SumOfNegativesDS: 396 Sum2NegativesDS: 114332
One Way Values:
NumOfOW: 440
OWMinSD: 2 OWMaxSD: 6 OWSumSD: 1273 OWSum2SD: 4021
OWMinDS: 2 OWMaxDS: 341 OWSumDS: 1643 OWSum2DS: 120295

```

The values shown indicate the aggregated values for the current hour. RTT stands for Round-Trip-Time. SD stands for Source-to-Destination. DS stands for Destination-to-Source. OW stands for One Way. [Table 128](#) describes the significant fields shown in this output.

Output for Jitter (codec) Operations

The following is sample output from the **show rtr collection-statistics** command, where operation 10 is a Jitter (codec) operation:

```

Router# show rtr collection-statistics 10
Entry number: 10
Start Time Index: 13:18:49.904 PST Mon Jun 24 2002
Number of successful operations: 2
Number of operations over threshold: 0
Number of failed operations due to a Disconnect: 0
Number of failed operations due to a Timeout: 0
Number of failed operations due to a Busy: 0
Number of failed operations due to a No Connection: 0
Number of failed operations due to an Internal Error: 0
Number of failed operations due to a Sequence Error: 0
Number of failed operations due to a Verify Error: 0
Voice Scores:
MinOfICPIF: 0 MaxOfICPIF: 0 MinOfMOS: 0 MaxOfMOS: 0
RTT Values:
NumOfRTT: 122 RTTAvg: 2 RTTMin: 2 RTTMax: 3
RTTSum: 247 RTTSum2: 503
Packet Loss Values:
PacketLossSD: 0 PacketLossDS: 0
PacketOutOfSequence: 0 PacketMIA: 0 PacketLateArrival: 0
InternalError: 0 Busies: 0 PacketSkipped: 78 <<<<<=====
Jitter Values:
MinOfPositivesSD: 1 MaxOfPositivesSD: 1
NumOfPositivesSD: 9 SumOfPositivesSD: 9 Sum2PositivesSD: 9
MinOfNegativesSD: 1 MaxOfNegativesSD: 1
NumOfNegativesSD: 8 SumOfNegativesSD: 8 Sum2NegativesSD: 8
MinOfPositivesDS: 1 MaxOfPositivesDS: 1
NumOfPositivesDS: 6 SumOfPositivesDS: 6 Sum2PositivesDS: 6
MinOfNegativesDS: 1 MaxOfNegativesDS: 1
NumOfNegativesDS: 7 SumOfNegativesDS: 7 Sum2NegativesDS: 7
Interarrival jitterout: 0 Interarrival jitterin: 0
One Way Values:

```

```

NumOfOW: 0
OWMinSD: 0      OWMaxSD: 0      OWSumSD: 0      OWSum2SD: 0
OWMinDS: 0      OWMaxDS: 0      OWSumDS: 0      OWSum2DS: 0

```

Table 128 *show rtr collection-statistics Field Descriptions*

Field	Description
Voice Scores:	Indicates that Voice over IP statistics appear on the following lines. Voice score data is computed when the operation type is configured as type jitter (codec) .
ICPIF	The Calculated Planning Impairment Factor (ICPIF) value for the operation. The ICPIF value is computed by IP SLAs using the formula $Icpif = Io + Iq + Idte + Idd + Ie - A$, where - the values for <i>Io</i>, <i>Iq</i>, and <i>Idte</i> are set to zero, - the value <i>Idd</i> is computed based on the measured one way delay, - the value <i>Ie</i> is computed based on the measured packet loss, - and the value of <i>A</i> is specified by the user. ICPIF values are expressed in a typical range of 5 (very low impairment) to 55 (very high impairment). ICPIF values numerically less than 20 are generally considered “adequate.” Note This value is intended only for relative comparisons, and may not match ICPIF values generated using alternate methods.
MinOfICPIF:	The lowest (minimum) ICPIF value computed for the collected statistics.
MaxOfICPIF:	The highest (maximum) ICPIF value computed for the collected statistics.
Mos	The estimated Mean Opinion Score (Conversational Quality, Estimated) for the latest iteration of the operation. The MOS-CQE is computed by IP SLAs as a function of the ICPIF. MOS values are expressed as a number from 1 (1.00) to 5 (5.00), with 5 being the highest level of quality, and 1 being the lowest level of quality. A MOS value of 0 (zero) indicates that MOS data could not be generated for the operation.
MinOfMos:	The lowest (minimum) MOS value computed for the collected statistics.
MaxOfMos:	The highest (maximum) ICPIF value computed for the collected statistics.
RTT Values:	Indicates that Round-Trip-Time statistics appear on the following lines.
NumOfRTT	The number of successful round trips.
RTTSum	The sum of all successful round trip values (in milliseconds).
RTTSum2	The sum of squares of those round trip values (in milliseconds).
PacketLossSD	The number of packets lost from source to destination.

Table 128 *show rtr collection-statistics Field Descriptions (continued)*

Field	Description
PacketLossDS	The number of packets lost from destination to source.
PacketOutOfSequence	The number of packets returned out of order.
PacketMIA	The number of packets lost where the direction (SD/DS) cannot be determined.
PacketLateArrival	The number of packets that arrived after the timeout.
PacketSkipped	The number of packets that are not sent during the IP SLAs jitter operation.
InternalError	The number of times an operation could not be started due to other internal failures.
Busies	The number of times this operation could not be started because the previously scheduled run was not finished.
Jitter Values:	Indicates that Jitter statistics appear on the following lines. Jitter is inter-packet delay variance.
NumOfJitterSamples:	The number of jitter samples collected. This is the number of samples that are used to calculate the following jitter statistics.
MinOfPositivesSD MaxOfPositivesSD	The minimum and maximum positive jitter values from source to destination, in milliseconds.
NumOfPositivesSD	The number of jitter values from source to destination that are positive (i.e., network latency increases for two consecutive test packets).
SumOfPositivesSD	The sum of those positive values (in milliseconds).
Sum2PositivesSD	The sum of squares of those positive values.
MinOfNegativesSD MaxOfNegativesSD	The minimum and maximum negative jitter values from source to destination. The absolute value is given.
NumOfNegativesSD	The number of jitter values from source to destination that are negative (i.e., network latency decreases for two consecutive test packets).
SumOfNegativesSD	The sum of those values.
Sum2NegativesSD	The sum of the squares of those values.
Interarrival jitterout:	The source to destination(SD) jitter value calculation, as defined in RFC 1889.
Interarrival jitterin:	The destination to source (DS) jitter value calculation, as defined in RFC 1889.
One Way Values	Indicates that one way measurement statistics appear on the following lines. One Way (OW) Values are the amount of time it took the packet to travel from the source router to the target router (SD) or from the target router to the source router (DS).

Table 128 *show rtr collection-statistics Field Descriptions (continued)*

Field	Description
NumOfOW	Number of successful one way time measurements.
OWMinSD	Minimum time from the source to the destination.
OWMaxSD	Maximum time from the source to the destination.
OWSumSD	Sum of the OWMinSD and OWMaxSD values.
OWSum2SD	Sum of the squares of the OWMinSD and OWMaxSD values.

The DS values show the same information as above for Destination-to-Source Jitter values.

Related Commands

Command	Description
show ntp status	Displays the status of the Network Time Protocol configuration on your system.
show rtr configuration	Displays configuration values including all defaults for all IP SLAs operations or the specified operation.
show rtr distributions-statistics	Displays statistic distribution information (captured response times) for all IP SLAs operations or the specified operation.
show rtr totals-statistics	Displays the total statistical values (accumulation of error counts and completions) for all IP SLAs operations or the specified operation.

show rtr configuration

To display configuration values including all defaults for all SAA operations or the specified operation, use the **show rtr configuration** EXEC command.

show rtr configuration [*operation*] [**tabular** | **full**]

Syntax Description	<i>operation</i>	(Optional) Number of the SAA operation to display.
	tabular	(Optional) Display information in a column format reducing the number of screens required to display the information.
	full	(Optional) Display all information using identifiers next to each displayed value. This is the default.

Defaults	Full format for all operations

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Examples The following is sample output from the **show rtr configuration** command in full format:

```
Router# show rtr configuration 1

      Complete Configuration Table (includes defaults)
Entry Number: 1
Owner: "Sample Owner"
Tag: "Sample Tag Group"
Type of Operation to Perform: echo
Reaction and History Threshold (milliseconds): 5000
Operation Frequency (seconds): 60
Operation Timeout (milliseconds): 5000
Verify Data: FALSE
Status of Entry (SNMP RowStatus): active
Protocol Type: ipIcmpEcho
Target Address: 172.16.1.176
Request Size (ARR data portion): 1
Response Size (ARR data portion): 1
Life (seconds): 3600
Next Start Time: Start Time already passed
Entry Ageout (seconds): 3600
Connection Loss Reaction Enabled: FALSE
Timeout Reaction Enabled: FALSE
Threshold Reaction Type: never
Threshold Falling (milliseconds): 3000
Threshold Count: 5
Threshold Count2: 5
Reaction Type: none
Number of Statistic Hours kept: 2
```

show rtr configuration

```

Number of Statistic Paths kept: 1
Number of Statistic Hops kept: 1
Number of Statistic Distribution Buckets kept: 1
Number of Statistic Distribution Intervals (milliseconds): 20
Number of History Lives kept: 0
Number of History Buckets kept: 50
Number of History Samples kept: 1
History Filter Type: none

```

The following example verifies the configuration of an HTTP operation:

```

router# show rtr configuration

Complete Configuration Table (includes defaults)
Entry Number:3
Owner:Joe
Tag:AppleTree
Type of Operation to Perform:http
Reaction and History Threshold (milliseconds):5000
Operation Frequency (seconds):60
Operation Timeout (milliseconds):5000
Verify Data:FALSE
Status of Entry (SNMP RowStatus):active
Protocol Type:httpAppl
Target Address:
Source Address:0.0.0.0
Target Port:0
Source Port:0
Request Size (ARR data portion):1
Response Size (ARR data portion):1
Control Packets:enabled
Loose Source Routing:disabled
LSR Path:
Type of Service Parameters:0x0
HTTP Operation:get
HTTP Server Version:1.0
URL:http://www.cisco.com
Cache Control:enabled
Life (seconds):3600
Next Scheduled Start Time:Start Time already passed
Entry Ageout:never
Connection Loss Reaction Enabled:FALSE
Timeout Reaction Enabled:FALSE
Threshold Reaction Type:never
Threshold Falling (milliseconds):3000
Threshold Count:5
Threshold Count2:5
Reaction Type:none
Number of Statistic Hours kept:2
Number of Statistic Paths kept:1
Number of Statistic Hops kept:1
Number of Statistic Distribution Buckets kept:1
Statistic Distribution Interval (milliseconds):20
Number of History Lives kept:0
Number of History Buckets kept:15
Number of History Samples kept:1
History Filter Type:none

```

Related Commands

Command	Description
show rtr application	Displays global information about the SAA feature.
show rtr collection-statistics	Displays statistical errors for all SAA operations or the specified operation.
show rtr distributions-statistics	Displays statistic distribution information (captured response times) for all SAA operations or the specified operation.
show rtr history	Displays history collected for all SAA operations or the specified operation.
show rtr operational-state	Displays the operational state of all SAA operations or the specified operation.
show rtr reaction-trigger	Displays the reaction trigger information for all SAA operations or the specified operation.
show rtr totals-statistics	Displays the total statistical values (accumulation of error counts and completions) for all SAA operations or the specified operation.

show rtr distributions-statistics

To display statistic distribution information (captured response times) for all SAA operations or the specified operation, use the **show rtr distributions-statistics** EXEC command.

```
show rtr distributions-statistics [operation] [tabular | full]
```

Syntax Description

<i>operation</i>	(Optional) Number of the SAA operation to display.
tabular	(Optional) Displays information in a column format reducing the number of screens required to display the information. This is the default.
full	(Optional) Displays all information using identifiers next to each displayed value.

Defaults

Tabular format for all operations

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

The distributions statistics consist of the following:

- The sum of completion times (used to calculate the mean)
- The sum of the completions times squared (used to calculate standard deviation)
- The maximum and minimum completion time
- The number of completed attempts

You can also use the [show rtr collection-statistics](#) and **show rtr totals-statistics** commands to display additional statistical information.

Examples

The following is sample output from the **show rtr distributions-statistics** command in tabular format:

```
Router# show rtr distributions-statistics

Captured Statistics
Multiple Lines per Entry

Line 1
Entry      = Entry Number
StartT     = Start Time of Entry (hundredths of seconds)
Pth        = Path Index
Hop        = Hop in Path Index
Dst        = Time Distribution Index
Comps      = Operations Completed
OvrTh      = Operations Completed Over Thresholds
SumCmp     = Sum of Completion Times (milliseconds)
```

```

Line 2
SumCmp2L = Sum of Completion Times Squared Low 32 Bits (milliseconds)
SumCmp2H = Sum of Completion Times Squared High 32 Bits (milliseconds)
TMax     = Completion Time Maximum (milliseconds)
TMin     = Completion Time Minimum (milliseconds)
Entry StartT      Pth Hop Dst Comps      OvrTh      SumCmp
  SumCmp2L      SumCmp2H      TMax      TMin
1      17417068      1      1      1      2      0      128
      8192      0      64      64

```

Related Commands

Command	Description
show rtr collection-statistics	Displays statistical errors for all SAA operations or the specified operation.
show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.
show rtr totals-statistics	Displays the total statistical values (accumulation of error counts and completions) for all SAA operations or the specified operation.

show rtr history

To display history collected for all SAA operations or for a specified operation, use the **show rtr history EXEC** command.

```
show rtr history [operation-number] [tabular | full]
```

Syntax Description

<i>operation-number</i>	(Optional) Displays history for only the specified operation.
tabular	(Optional) Displays information in a column format reducing the number of screens required to display the information. This is the default.
full	(Optional) Displays all information using identifiers next to each displayed value.

Defaults

Tabular format, history for all operations is displayed

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

[Table 129](#) lists the Response Return values used in the output of the **show rtr history** command. If the default (**tabular**) format is used, the Response Return description is displayed as a code in the Sense column. If the full format is used, the Response Return is displayed as indicated in the Description column.

Table 129 Response Return (Sense Column) Codes

Code	Description
1	Okay.
2	Disconnected.
3	Over threshold.
4	Timeout.
5	Busy.
6	Not connected.
7	Dropped.
8	Sequence error.
9	Verify error.
10	Application specific.

Examples

The following is sample output from the **show rtr history** command in tabular format:

```
Router# show rtr history

Point by point History
Multiple Lines per Entry
Line 1
Entry      = Entry Number
LifeI      = Life Index
BucketI    = Bucket Index
SampleI    = Sample Index
SampleT    = Sample Start Time
CompT      = Completion Time (milliseconds)
Sense      = Response Return Code
Line 2 has the Target Address
Entry LifeI      BucketI    SampleI    SampleT    CompT      Sense
2      1          1          1          17436548    16          1
  AB 45 A0 16
2      1          2          1          17436551    4           1
  AC 12 7  29
2      1          2          2          17436551    1           1
  AC 12 5  22
2      1          2          3          17436552    4           1
  AB 45 A7 22
2      1          2          4          17436552    4           1
  AB 45 A0 16
```

Related Commands

Command	Description
show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.

show rtr operational-state



Note

Effective with Cisco IOS Release 12.3(14)T, the **show rtr operational-state** command is replaced by the **show ip sla monitor statistics** command. See the **show ip sla monitor statistics** command for more information.

To display the operational state of all Cisco IOS IP Service Level Agreements (IP SLAs) operations or a specified operation, use the **show rtr operational-state** command in EXEC mode.

show rtr operational-state [*operation-number*]

Syntax Description

operation-number (Optional) ID number of the IP SLAs operation to display.

Defaults

Displays output for all running IP SLAs operations.

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.
12.0(5)T	Output for the Jitter operation type was added.
12.1	The tabular and full keywords were removed.
12.2(8)T	Output for “NumOfJitterSamples” was added (CSCdv30022).
12.2(8)S	Output for “NumOfJitterSamples” was added (CSCdv30022).
12.3(4)T	Output (MOS and ICPIF scores) for the Jitter (codec) operation type was added.
12.3(7)T	Decimal granularity for MOS scores was added.
12.3(14)T	This command was replaced by the show ip sla monitor statistics command.

Usage Guidelines

Use the **show rtr operational-state** command to display the current state of IP SLAs operations, including how much life the operation has left, whether the operation is active, and the completion time. The output will also include the monitoring data returned for the last (most recently completed) operation.

Examples

The following example shows basic sample output from the **show rtr operational-state** command:

```
Router# show rtr operational-state
      Current Operational State
Entry Number: 3
Modification Time: *22:15:43.000 UTC Sun Feb 11 2001
Diagnostics Text:
Last Time this Entry was Reset: Never
Number of Octets in use by this Entry: 1332
```



```

Number of Operations Attempted: 2
Current Seconds Left in Life: 3511
Operational State of Entry: active
Latest Completion Time (milliseconds): 544
Latest Operation Start Time: *22:16:43.000 UTC Sun Feb 11 2001
Latest Oper Sense: ok
Latest Sense Description: 200 OK
Total RTT: 544
DNS RTT: 12
TCP Connection RTT: 28
HTTP Transaction RTT: 504
HTTP Message Size: 9707

```

The following example shows sample output from the **show rtr operational-state** command when the specified operation is a Jitter (codec) operation:

```

Router# show rtr operational-state 1
Entry number: 1
Modification time: 13:18:38.012 PST Mon Jun 24 2002
Number of Octets Used by this Entry: 10392
Number of operations attempted: 2
Number of operations skipped: 0
Current seconds left in Life: Forever
Operational state of entry: Active
Last time this entry was reset: Never
Connection loss occurred: FALSE
Timeout occurred: FALSE
Over thresholds occurred: FALSE
Latest RTT (milliseconds): 2
Latest operation start time: *13:18:42.896 PST Mon Jun 24 2002
Latest operation return code: OK
Voice Scores:
ICPIF Value: 0 MOS score: 0
RTT Values:
NumOfRTT: 61 RTTAvg: 2 RTTMin: 2 RTTMax: 3
RTTSum: 123 RTTSum2: 249
Packet Loss Values:
PacketLossSD: 0 PacketLossDS: 0
PacketOutOfSequence: 0 PacketMIA: 0 PacketLateArrival: 0
InternalError: 0 Busies: 0 PacketSkipped: 39 <<<<<=====
Jitter Values:
MinOfPositivesSD: 1 MaxOfPositivesSD: 1
NumOfPositivesSD: 1 SumOfPositivesSD: 1 Sum2PositivesSD: 1
MinOfNegativesSD: 1 MaxOfNegativesSD: 1
NumOfNegativesSD: 1 SumOfNegativesSD: 1 Sum2NegativesSD: 1
MinOfPositivesDS: 0 MaxOfPositivesDS: 0
NumOfPositivesDS: 0 SumOfPositivesDS: 0 Sum2PositivesDS: 0
MinOfNegativesDS: 0 MaxOfNegativesDS: 0
NumOfNegativesDS: 0 SumOfNegativesDS: 0 Sum2NegativesDS: 0
Interarrival jitterout: 0 Interarrival jitterin: 0
One Way Values:
NumOfOW: 0
OWMinSD: 0 OWMaxSD: 0 OWSumSD: 0 OWSum2SD: 0
OWMinDS: 0 OWMaxDS: 0 OWSumDS: 0 OWSum2DS: 0

```

The values shown indicate the values for the last IP SLAs operation. RTT stands for Round-Trip-Time. SD stands for Source-to-Destination. DS stands for Destination-to-Source. OW stands for One Way. The * symbol in front of the time stamps indicates the time is synchronized using NTP or SNTP. [Table 130](#) describes the significant fields shown in this output.

Table 130 show rtr operational-state Field Descriptions

Field	Description
Voice Scores:	Indicates that Voice over IP statistics appear on the following lines. Voice score data is computed when the operation type is configured as type jitter (codec) .
ICPIF:	The Calculated Planning Impairment Factor (ICPIF) value for the latest iteration of the operation. The ICPIF value is computed by IP SLAs using the formula $Icpif = Io + Iq + Idte + Idd + Ie - A$, where - the values for <i>Io</i>, <i>Iq</i>, and <i>Idte</i> are set to zero, - the value <i>Idd</i> is computed based on the measured one way delay, - the value <i>Ie</i> is computed based on the measured packet loss, - and the value of <i>A</i> is specified by the user. ICPIF values are expressed in a typical range of 5 (very low impairment) to 55 (very high impairment). ICPIF values numerically less than 20 are generally considered “adequate.” Note This value is intended only for relative comparisons, and may not match ICPIF values generated using alternate methods.
MOS:	The estimated Mean Opinion Score (Conversational Quality, Estimated) for the latest iteration of the operation. The MOS-CQE is computed by IP SLAs as a function of the ICPIF. MOS values are expressed as a number from 1 (1.00) to 5 (5.00), with 5 being the highest level of quality, and 1 being the lowest level of quality. A MOS value of 0 (zero) indicates that MOS data could not be generated for the operation.
RTT Values:	Indicates that Round-Trip-Time statistics appear on the following lines.
NumOfRTT	The number of successful round trips.
RTTSum	The sum of those round trip values (in milliseconds).
RTTSum2	The sum of squares of those round trip values (in milliseconds).
Packet Loss Values:	Indicates that Packet Loss statistics appear on the following lines.
PacketLossSD	The number of packets lost from source to destination.
PacketLossDS	The number of packets lost from destination to source.
PacketOutOfSequence	The number of packets returned out of order.
PacketMIA	The number of packets lost where the direction (SD or DS) cannot be determined (MIA: “missing in action”).
PacketLateArrival	The number of packets that arrived after the timeout.
PacketSkipped	The number of packets that are not sent during the IP SLAs jitter operation.

Table 130 *show rtr operational-state Field Descriptions (continued)*

Field	Description
InternalError	The number of times an operation could not be started due to other internal failures.
Busies	The number of times this operation could not be started because the previously scheduled run was not finished.
Jitter Values:	Indicates that jitter operation statistics appear on the following lines. Jitter is inter-packet delay variance.
NumOfJitterSamples:	The number of jitter samples collected. This is the number of samples that are used to calculate the following jitter statistics.
MinOfPositivesSD MaxOfPositivesSD	The minimum and maximum positive jitter values from source to destination, in milliseconds.
NumOfPositivesSD	The number of jitter values from source to destination that are positive (i.e., network latency increases for two consecutive test packets).
SumOfPositivesSD	The sum of those positive values (in milliseconds).
Sum2PositivesSD	The sum of squares of those positive values.
MinOfNegativesSD MaxOfNegativesSD	The minimum and maximum negative jitter values from source to destination. The absolute value is given.
NumOfNegativesSD	The number of jitter values from source to destination that are negative (i.e., network latency decreases for two consecutive test packets).
SumOfNegativesSD	The sum of those values.
Sum2NegativesSD	The sum of the squares of those values.
Interarrival jitterout:	The source to destination(SD) jitter value calculation, as defined in RFC 1889.
Interarrival jitterin:	The destination to source (DS) jitter value calculation, as defined in RFC 1889.
One Way Values	Indicates that One Way measurement statistics appear on the following lines. One Way (OW) Values are the amount of time it took the packet to travel from the source router to the target router (SD) or from the target router to the source router (DS).
NumOfOW	Number of successful one way time measurements.
OWMinSD	Minimum time from the source to the destination.
OWMaxSD	Maximum time from the source to the destination.
OWSumSD	Sum of the OWMinSD and OWMaxSD values.
OWSum2SD	Sum of the squares of the OWMinSD and OWMaxSD values.

show rtr operational-state

Related Commands

Command	Description
show rtr configuration	Displays configuration values including all defaults for all IP SLAs operations or the specified operation.

show rtr reaction-trigger

To display the reaction trigger information for all SAA operations or the specified operation, use the **show rtr reaction-trigger EXEC** command.

show rtr reaction-trigger [*operation-number*] [**tabular** | **full**]

Syntax Description

<i>operation-number</i>	(Optional) Number of the SAA operation to display.
tabular	(Optional) Display information in a column format reducing the number of screens required to display the information.
full	(Optional) Display all information using identifiers next to each displayed value. This is the default.

Defaults

Full format for all operations

Command Modes

EXEC

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

Use the **show rtr reaction-trigger** command to display the configuration status and operational state of target operations that will be triggered as defined with the **rtr reaction-configuration** global command.

Examples

The following is sample output from the **show rtr reaction-trigger** command in full format:

```
Router# show rtr reaction-trigger 1

      Reaction Table
Entry Number: 1
Target Entry Number: 2
Status of Entry (SNMP RowStatus): active
Operational State: pending
```

Related Commands

Command	Description
show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.

show rtr responder

To display SAA RTR Responder information, use the **show rtr responder** EXEC command.

show rtr responder

Syntax Description	This command has no arguments or keywords.

Command Modes	EXEC

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines	Use the show rtr responder command to display information about recent sources of SAA control messages, such as who has sent recent control messages and who has sent invalid control messages.

Examples	The following is sample output from the show rtr responder command: <pre>Router# show rtr responder RTR Responder is: Enabled Number of control message received: 19 Number of errors: 1 Recent sources: 4.0.0.1 [19:11:49.035 UTC Sat Dec 2 1995] 4.0.0.1 [19:10:49.023 UTC Sat Dec 2 1995] 4.0.0.1 [19:09:48.707 UTC Sat Dec 2 1995] 4.0.0.1 [19:08:48.687 UTC Sat Dec 2 1995] 4.0.0.1 [19:07:48.671 UTC Sat Dec 2 1995] Recent error sources: 4.0.0.1 [19:10:49.023 UTC Sat Dec 2 1995] RTT_AUTH_FAIL</pre>

Related Commands	Command	Description
	show rtr configuration	Displays configuration values for SAA operations.

show rtr totals-statistics

To display the total statistical values (accumulation of error counts and completions) for all SAA operations or the specified operation, use the **show rtr totals-statistics EXEC** command.

show rtr totals-statistics [*number*] [**tabular** | **full**]

Syntax Description	<i>number</i>	(Optional) Number of the SAA operation to display.
	tabular	(Optional) Display information in a column format reducing the number of screens required to display the information.
	full	(Optional) Display all information using identifiers next to each displayed value. This is the default.

Defaults	Full format for all operations

Command Modes	EXEC

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	The total statistics consist of the following items: • The operation number • The start time of the current hour of statistics • The age of the current hour of statistics • The number of attempted operations
	You can also use the show rtr distributions-statistics and show rtr collection-statistics commands to display additional statistical information.

Examples	The following is sample output from the show rtr totals-statistics command in full format:

```
Router# show rtr totals-statistics

Statistic Totals
Entry Number: 1
Start Time Index: *17:15:41.000 UTC Thu May 16 1996
Age of Statistics Entry (hundredths of seconds): 48252
Number of Initiations: 10
```

Related Commands	Command	Description
	show rtr collection-statistics	Displays statistical errors for all SAA operations or the specified operation.
	show rtr configuration	Displays configuration values including all defaults for all SAA operations or the specified operation.
	show rtr distributions-statistics	Displays statistic distribution information (captured response times) for all SAA operations or the specified operation.

statistics-distribution-interval

To set the time interval for each statistics distribution kept for the SAA, use the **statistics-distribution-interval** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

statistics-distribution-interval *milliseconds*

no statistics-distribution-interval

Syntax Description	<i>milliseconds</i>	Number of milliseconds (ms) used for each statistics distribution kept. The default is 20 ms.

Defaults	20 ms

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	In most situations, you do not need to change the statistical distribution interval or size. Only change the interval or size when distributions are needed, for example, when performing statistical modeling of your network. To set the statistical distributions size, use the distributions-of-statistics-kept SAA RTR configuration command.

Examples	In the following example, the distribution is set to five and the distribution interval is set to 10 ms. This means that the first distribution will contain statistics from 0 to 9 ms, the second distribution will contain statistics from 10 to 19 ms, the third distribution will contain statistics from 20 to 29 ms, the fourth distribution will contain statistics from 30 to 39 ms, and the fifth distribution will contain statistics from 40 ms to infinity.

```
Router(config)# rtr 1  
Router(config-rtr)# type echo protocol ipIcmpEcho 172.28.161.21  
Router(config-rtr)# distribution-of-statistics-kept 5  
Router(config-rtr)# statistics-distribution-interval 10
```

Related Commands	Command	Description
	distributions-of-statistics-kept	Sets the number of statistic distributions kept per hop during the SAA operation's lifetime.
	hops-of-statistics-kept	Set the number of hops for which statistics are maintained per path for the SAA operation.

Command	Description
hours-of-statistics-kept	Sets the number of hours for which statistics are maintained for the SAA operation.
paths-of-statistics-kept	Sets the number of paths for which statistics are maintained per hour for the SAA operation.
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

tag

To create a user-specified identifier for an SAA operation, use the **tag** SAA RTR configuration command. To remove a tag from a operation, use the **no** form of this command.

tag *text*

no tag

Syntax Description	<i>text</i>	Name of a group that this operation belongs to. From 0 to 16 ASCII characters.
Defaults	No operations are tagged.	
Command Modes	SAA RTR configuration	
Command History	Release	Modification
	11.2	This command was introduced.
Usage Guidelines	An operation tag is normally used to logically link operations in a group Tags can be used to support automation (for example, by using the same tag for two different operations on two different routers echoing the same target).	
Examples	In the following example, operation 1 is tagged with the label bluebell: Router(config)# rtr 1 Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176 Router(config-rtr)# tag bluebell	
Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

threshold

To set the rising threshold (hysteresis) that generates a reaction event and stores history information for the SAA operation, use the **threshold** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

threshold *milliseconds*

no threshold

Syntax Description	<i>milliseconds</i>	Number of milliseconds required for a rising threshold to be declared. The default value is 5000 ms.

Defaults	5000 ms

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines The value specified for the **threshold** command must not exceed the value specified for the **timeout** SAA RTR configuration command.

The threshold value is used by the **rtr reaction-configuration** and **filter-for-history** commands.

Examples In the following example, the threshold of operation 1 is set to 2500 ms:

```
Router(config)# rtr 1
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176
Router(config-rtr)# threshold 2500
```

Related Commands	Command	Description
	filter-for-history	Defines the type of information kept in the history table for the SAA operation.
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	rtr reaction-configuration	Configures certain actions to occur based on events under the control of the SAA.

timeout

To set the amount of time the SAA operation waits for a response from its request packet, use the **timeout** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

timeout *milliseconds*

no timeout

Syntax Description	<i>milliseconds</i>	Number of milliseconds (ms) the operation waits to receive a response from its request packet.

Defaults	The default timeout values vary by operation. Per the RTTMON-MIB, the defaults are: DLSw+ (type dlsw) and FTP (type ftp) operations - 30000 ms DNS (type dns) operations - 9 seconds (as defined by multiplying the MAX_DNS_WAITTIME value by the MAXDNSTRIES value) TCP Connection (type tcpConnect) and HTTP (type http) operations - 60 seconds (as defined by multiplying the MAXALIVETRIES value by the MAXSYNTRYTICKS value)

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	Use the timeout command to set how long the operation waits to receive a response, and use the frequency SAA RTR configuration command to set the rate at which the SAA starts an operation. The value specified for the timeout command cannot be greater than the value specified for the frequency command.

Examples	In the following example, the timeout for the IP/ICMP Echo operation 1 is set for 2500 ms: Router(config)# rtr 1 Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176 Router(config-rtr)# timeout 2500

Related Commands	Command	Description
	frequency	Sets the rate at which the SAA operation starts a response time operation.
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

tos

To define a type of service (ToS) byte in the IP header of SAA operations, use the **tos** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

```
tos number

no tos
```

Syntax Description	number	Service type byte in the IP header. The range is 0 to 255. The default is 0.

Defaults	The default type-of-service value is 0.

Command Modes	SAA RTR configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines	The type-of-service (ToS) value is an 8-bit field in IP headers. This field contains information such as precedence and TOS. This is useful for policy-routing as well as features like CAR (Committed Access Rate), where routers examine for TOS values. When the type-of-service is defined for an operation, the SAA Responder will reflect the ToS value it receives.

Examples	In the following example, SAA operation 1 is configured as an echo probe using the IP/ICMP Echo protocol and the destination IP address 172.16.1.175. The ToS value is set to 0x80. Router(config)# rtr 1 Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.176 Router(config-rtr)# tos 0x80

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

type dhcp

To configure a Dynamic Host Configuration Protocol SAA operation, use the **type dhcp** SAA RTR configuration command. To disable a DHCP SAA operation, use the **no** form of this command.

type dhcp [**source-ipaddr** *source-ipaddr*] [**dest-ipaddr** *dest-ipaddr*] [**option** *decimal-option* [**circuit-id** *circuit-id*] [**remote-id** *remote-id*] [**subnet-mask** *subnet-mask*]]

no type dhcp

Syntax Description

source-ipaddr <i>source-ipaddr</i>	(Optional) Source name or IP address.
dest-ipaddr <i>dest-ipaddr</i>	(Optional) Destination name or IP address.
option <i>decimal-option</i>	(Optional) Option number. The only currently valid value is 82. DHCP option 82 allows you to specify the circuit-id, remote-id, and/or the subnet-mask for the destination DHCP server.
circuit-id <i>circuit-id</i>	(Optional) Circuit ID in hexadecimal.
remote-id <i>remote-id</i>	(Optional) Remote ID in hexadecimal.
subnet-mask <i>subnet-mask</i>	(Optional) Subnet mask IP address. The default value is 255.255.255.0.

Defaults

The *subnet-mask* value is 255.255.255.0.

Command Modes

SAA RTR configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.
12.1(1)T	The following keywords were added: • source-ipaddr • dest-ipaddr • option 82

Usage Guidelines

You must configure the type of operation before you can configure any of the other characteristics of the operation.

If the source IP address is configured, then packets will be sent with that source address.

You may configure the **ip dhcp-server** command to identify the DHCP server that the DHCP operation will measure.

If the target IP address is configured, then only that device will be measured.

If the **ip dhcp-server** command is not configured and the target IP address is not configured, then DHCP discover packets will be sent on every available IP interface.

Option 82 is called the Relay Agent Information option and is inserted by the DHCP relay agent when forwarding client-originated DHCP packets to a DHCP server. Servers recognizing the Relay Agent Information option may use the information to implement IP address or other parameter assignment policies. The DHCP Server echoes the option back verbatim to the relay agent in server-to-client replies, and the relay agent strips the option before forwarding the reply to the client.

The Relay Agent Information option is organized as a single DHCP option that contains one or more suboptions that convey information known by the relay agent. The initial sub-options are defined for a relay agent that is co-located in a public circuit access unit. These suboptions are as follows: a **circuit-id** for the incoming circuit, a **remote-id** which provides a trusted identifier for the remote high-speed modem, and a **subnet-mask** designation for the logical IP subnet from which the relay agent received the client DHCP packet.

If an odd number of characters are specified for the **circuit-id**, a zero will be added to the end of the string.

Examples

In the following example, SAA operation number 4 is configured as a DHCP operation enabled for DHCP server 172.16.20.3:

```
Router(config)# rtr 4
Router(config-rtr)# type dhcp option 82 circuit-id 10005A6F1234
Router(config-rtr)# exit
Router(config)# ip dhcp-server 172.16.20.3
```

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
ip dhcp-server	Specifies which DHCP servers to use on a network, and specifies the IP address of one or more DHCP servers available on the network.

type dlsw

To configure a data-link switching (DLSw) SAA operation, use the **type dlsw** SAA RTR configuration command. To remove the type configuration for the operation, use the **no** form of this command.

type dlsw peer-ipaddr *ipaddr*

no type dlsw peer-ipaddr *ipaddr*

Syntax Description	peer-ipaddr	Peer destination.
	<i>ipaddr</i>	IP address.

Defaults	None.

Command Modes	SAA RTR configuration

Command History	Release	Modification
	12.0(5)T	This command was introduced.

Usage Guidelines	In order to configure a DLSw operation, the DLSw feature must be configured on the local and target routers.
	You must configure the type of operation before you can configure any of the other characteristics of the operation.
	The default for the optional characteristic request-data-size for a DLSw SAA operation is 0 bytes.
	The default for the optional characteristic timeout for a DLSw SAA operation is 30 seconds.

Examples	In the following example, SAA operation number 4 is configured as a DLSw operation enabled for remote peer IP address 172.21.27.11. The data size is 15 bytes.

```
Router(config)# rtr 4  
Router(config-rtr)# type dlsw peer-ipaddr 172.21.27.11  
Router(config-rtr)# request-data-size 15
```

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
	request-data-size	Sets the protocol data size in the payload of the SAA operation's request packet.
	show dlsw peers	Displays DLSw peer information.

type dns

To configure a Domain Name System (DNS) SAA operation, use the **type dns** SAA RTR configuration command. To remove the type configuration for the operation, use the **no** form of this command.

type dns target-addr {*ip-address* | *hostname*} **name-server** *ip-address*

no type dns target-addr {*ip-address* | *hostname*} **name-server** *ip-address*

Syntax Description	target-addr { <i>ip-address</i> <i>hostname</i> }	Target (destination) IP address or hostname.
	name-server <i>ip-address</i>	IP address of the Domain Name Server.
Defaults	No default behavior or values.	
Command Modes	SAA RTR configuration	
Command History	Release	Modification
	12.0(5)T	This command was introduced.
Usage Guidelines	You must configure the type of operation before you can configure any of the other characteristics of the operation.	
Examples	In the following example, SAA operation 7 is created and configured as a DNS operation using the target IP address 172.20.2.132: <pre>Router(config)# rtr 7 Router(config-rtr)# type dns target-addr lethe name-server 172.20.2.132</pre>	
Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

type echo

To configure an SAA end-to-end echo response time probe operation, use the **type echo** SAA RTR configuration command. To remove the operation from the configuration, use the **no** form of this command.

```
type echo protocol protocol-type target [source-ipaddr ip-address]

no type echo protocol protocol-type target [source-ipaddr ip-address]
```

Syntax Description	protocol <i>protocol-type</i> <i>target</i> Protocol used by the operation. The <i>protocol-type target</i> argument combination must take one of the following forms: ipIcmpEcho {<i>ip-address</i> <i>hostname</i>}—IP/ICMP Echo. Requires a destination IP address or IP host name. snaRUEcho <i>sna-hostname</i>—SNA’s SSCP Native Echo. Requires the host name defined for the SNA’s PU connection to VTAM. snaLU0EchoAppl <i>sna-hostname</i> [<i>sna-application</i>] [<i>sna-mode</i>]—SNA LU type 0 connection to Cisco’s NSPECHO host application that requires the host name defined for the SNA’s PU connection to VTAM. Optionally, specify the host application name (the default is NSPECHO) and SNA mode to access the application. snaLU2EchoAppl <i>sna-hostname</i> [<i>sna-application</i>] [<i>sna-mode</i>]—SNA LU type 2 connection to Cisco’s NSPECHO host application that requires the host name defined for the SNA’s PU connection to VTAM. Optionally, specify the host application name (the default is NSPECHO) and SNA mode to access the application. source-ipaddr <i>ipaddr</i> (Optional) Specifies an IP address as the source for the operation.

Defaults	The default SNA host <i>sna-application</i> name for a SNA LU type echo is NSPEcho. The default data size for a IP/ICMP echo operation is 28 bytes.

Command Modes	SAA RTR configuration

Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>11.2</td><td>This command was introduced.</td></tr> <tr> <td>12.0(5)T</td><td>The source-ipaddr ipaddr keyword/argument combination was added to support the specification of an IP source for the operation.</td></tr> </table>	Release	Modification	11.2	This command was introduced.	12.0(5)T	The source-ipaddr ipaddr keyword/argument combination was added to support the specification of an IP source for the operation.
Release	Modification						
11.2	This command was introduced.						
12.0(5)T	The source-ipaddr ipaddr keyword/argument combination was added to support the specification of an IP source for the operation.						

Usage Guidelines	Support of echo to a protocol and pathEcho to a protocol is dependent on the protocol type and implementation. In general most protocols support echo and few protocols support pathEcho.

**Note**

Keywords are not case sensitive and are shown in mixed case for readability only.

Prior to sending a operation packet to the responder, the SAA sends a control message to the Responder to enable the destination port.

The default for the optional characteristic **request-data-size** for a ipIcmpEcho operation is 28 bytes. This is the payload portion of the Icmp packet, which makes a 64 byte IP packet.

Examples

In the following example, operation 10 is created and configured as an echo probe using the IP/ICMP Echo protocol and the destination IP address 172.16.1.175:

```
Router(config)# rtr 10  
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.175
```

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
show rtr configuration	Displays configuration values for RTR operations.

type ftp

To configure an FTP operation, use the **type ftp** SAA RTR configuration command. To remove the type configuration for the operation, use the **no** form of this command.

type ftp operation get url *url* [**source-ipaddr** *source-ipaddr*] [**mode** {**passive** | **active**}]

no type ftp operation get url *url* [**source-ipaddr** *source-ipaddr*] [**mode** {**passive** | **active**}]

Syntax Description

operation get	Specifies an FTP GET operation. (Support for other FTP operation types may be added in future releases.)
url <i>url</i>	Location information for the file to retrieve.
source-ipaddr <i>source-ipaddr</i>	(Optional) Source address of the operation.
mode	(Optional) Specifies mode, either active or passive.
passive	FTP passive transfer mode. This mode is the default.
active	FTP active transfer mode.

Defaults

The default FTP transfer mode is passive.

Command Modes

SAA RTR configuration

Command History

Release	Modification
12.1(1)T	This command was introduced.

Usage Guidelines

GET is the only valid operation value. The URL must be in one of the following formats:

- ftp://user:password@host/filename
- ftp://host/filename

If the user and password keywords are not specified, the defaults are anonymous and test, respectively.

Examples

In the following example, an FTP operation is configured. Joe is the user and Young is the password. zxq is the host and test is the file name.

```
Router(config)# rtr 3
Router(config-rtr)# type ftp operation get ftp://joe:young@zxq/test
```

Related Commands

Command	Description
show rtr collection-statistics	Displays statistical errors for all SAA operations or the specified operation.
show rtr operational-state	Displays the operational state of all SAA operations or the specified operation.

type http

To configure a Hypertext Transfer Protocol (HTTP) SAA operation, use the **type http** SAA RTR configuration command. To remove the type configuration for the operation, use the **no** form of this command.

```
type http operation {get | raw} url url [name-server ipaddress] [version version number]
[source-ipaddr {name | ipaddr}] [source-port port number] [cache {enable | disable}]
[proxy proxy-url]
```

```
no type http operation {get | raw} url url [name-server ipaddress] [version version number]
[source-ipaddr {name | ipaddr}] [source-port port number] [cache {enable | disable}]
[proxy proxy-url]
```

Syntax Description

operation get	Specifies an HTTP GET operation.
operation raw	Specifies an HTTP RAW operation.
url <i>url</i>	Specifies the URL of destination HTTP server.
name-server	(Optional) Specifies name of destination Domain Name Server.
<i>ipaddress</i>	(Optional) IP address of Domain Name Server.
version	(Optional) Specifies version number.
<i>version number</i>	(Optional) Version number.
source-ipaddr	(Optional) Specifies source name or IP address.
<i>name</i>	Source name.
<i>ipaddr</i>	Source IP address.
source-port	(Optional) Specifies source port.
<i>port number</i>	(Optional) Source port number.
cache	(Optional) Enables or disables download of cached HTTP page.
enable	Enables downloads of cached HTTP page.
disable	Disables download of cached HTTP page.
proxy	(Optional) Proxy information.
<i>proxy-url</i>	(Optional) Proxy information or URL.

Defaults

No default behavior or values.

Command Modes

SAA RTR configuration

Command History

Release	Modification
12.0(5)T	This command was introduced.

Usage Guidelines

You must configure the type of operation before you can configure any of the other characteristics of the operation.

Examples**HTTP GET operation**

In this example operation 5 is created and configured as an HTTP GET operation. The destination URL is `http://www.cisco.com`.

```
Router(config)# rtr 5
Router(config-rtr)# type http operation get url http://www.cisco.com
Router(config-rtr)# exit
Router(config)# rtr schedule 5 start-time now
```

HTTP RAW operation using RAW submode

In this example operation 6 is created and configured as an HTTP RAW operation. To use the raw request commands, HTTP-RAW submode is entered using the `http-raw-request` command. The RTR HTTP-RAW submode is indicated by the `(config-rtr-http)` router prompt.

```
Router(config)# rtr 6
Router(config-rtr)# type http operation raw url http://www.cisco.com
Router(config-rtr)# http-raw-request
Router(config-rtr-http)# GET /index.html HTTP/1.0\r\n
Router(config-rtr-http)# \r\n
Router(config-rtr-http)# exit
Router(config)# rtr schedule 6 start-time now
```

HTTP RAW operation through a Proxy Server

In this example `http://www.proxy.cisco.com` is the proxy server and `http://www.yahoo.com` is the HTTP Server:

```
Router(config)# rtr 6
Router(config-rtr)# type http operation raw url http://www.proxy.cisco.com
Router(config-rtr)# http-raw-request
Router(config-rtr-http)# GET http://www.example.com HTTP/1.0\r\n
Router(config-rtr-http)# \r\n
Router(config-rtr-http)# exit
Router(config)# rtr schedule 6 start-time now
```

Related Commands

Command	Description
<code>rtr</code>	Specifies an SAA operation and enters SAA RTR configuration mode.

type jitter

To configure a jitter SAA operation, use the **type jitter** SAA RTR configuration command. To disable a jitter operation, use the **no** form of this command.

type jitter dest-ipaddr {*name* | *ipaddr*} **dest-port** *port-number* [**source-ipaddr** {*name* | *ipaddr*}] [**source-port** *port-number*] [**control** {**enable** | **disable**}] [**num-packets** *number-of-packets*] [**interval** *inter-packet-interval*]

no type jitter dest-ipaddr {*name* | *ipaddr*} **dest-port** *port-number* [**source-ipaddr** {*name* | *ipaddr*}] [**source-port** *port-number*] [**control** {**enable** | **disable**}] [**num-packets** *number-of-packets*] [**interval** *inter-packet-interval*]

Syntax Description		
dest-ipaddr		Destination for the operation.
<i>name</i>		Destination IP host name.
<i>ipaddr</i>		Destination IP address.
dest-port		Destination port.
<i>port-number</i>		Port number of the destination port.
source-ipaddr		(Optional) Source IP address.
<i>name</i>		IP host name.
<i>ipaddr</i>		IP address.
source-port		(Optional) Source port.
<i>port-number</i>		Port number of the source.
control		(Optional) Combined with the enable or disable keyword, enables or disables sending a control message to the destination port.
enable		Enables the SAA to send a control message to the destination port prior to sending a probe packet. This is the default value.
disable		Disables sending of control messages to the responder prior to sending a probe packet.
num-packets		(Optional) Number of packets, as specified by the number argument. The default value is 10.
<i>number-of-packets</i>		
interval		(Optional) Interpacket interval in milliseconds. The default value of the <i>inter-packet-interval</i> argument is 20 ms.
<i>inter-packet-interval</i>		

Defaults The default for the optional characteristic **request-data-size** for a SAA Jitter operation is 32 bytes of UDP data.

Command Modes SAA RTR configuration

Command History	Release	Modification
	12.0(5)T	This command was introduced.

Usage Guidelines

The **type jitter** command configures a UDP Plus SAA operation. The UDP Plus operation is a superset of the UDP echo operation. In addition to measuring UDP round trip time, the UDP Plus operation measures per-direction packet-loss and Jitter. Jitter is inter-packet delay variance. Packet loss is a critical element in SLAs, and Jitter statistics are useful for analyzing traffic in a VoIP network.

You must enable the SAA Responder on the target router before you can configure a Jitter operation. Prior to sending a operation packet to the responder, the SAA sends a control message to the SA Agent Responder to enable the destination port.

You must configure the type of operation before you can configure any of the other characteristics of the operation.

Examples

In the following example, operation 6 is created and configured as a UDP+ Jitter operation using the destination IP address 172.30.125.15, the destination port number 2000, 20 packets, and an interval of 20:

```
Router(config)# rtr 6  
Router(config-rtr)# type jitter dest-ip 172.30.125.15 dest-port 2000 num-packets 20  
interval 20
```

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
request-data-size	Sets the payload size for SAA operation requests.

type pathEcho

To configure an IP/ICMP Path Echo SAA operation, use the **type pathEcho** SAA RTR configuration command. To remove the operation from the configuration, use the **no** form of this command.

```
type pathEcho protocol ipIcmpEcho {ip-address | ip-hostname}

no type pathEcho protocol ipIcmpEcho {ip-address | ip-hostname}
```

Syntax Description

protocol ipIcmpEcho	Specifies an IP/ICMP Echo operation. This is currently the only protocol type supported for the SAA Path Echo operation.
ip-address	Specifies the IP address of the target device.
ip-hostname	Specifies the designated IP name of the target device.

Defaults

None

Command Modes

SAA RTR configuration

Command History

Release	Modification
11.2	This command was introduced.

Usage Guidelines

Keywords are not case sensitive and are shown in mixed case for readability only.

Examples

In the following example, SAA operation 10 is created and configured as pathEcho probe using the IP/ICMP Echo protocol and the destination IP address 172.16.1.175:

```
Router(config)# rtr 10
Router(config-rtr)# type pathEcho protocol ipIcmpEcho 172.16.1.175
```

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
show rtr configuration	Displays configuration values for RTR operations (probes).

type tcpConnect

To define a tcpConnect probe, use the **type tcpConnect** SAA RTR configuration command. To remove the type configuration for the probe, use the **no** form of this command.

type tcpConnect dest-ipaddr {*name* | *ipaddr*} **dest-port** *port-number* [**source-ipaddr** {*name* | *ipaddr*} **source-port** *port-number*] [**control** {**enable** | **disable**}]

no type tcpConnect dest-ipaddr {*name* | *ipaddr*} **dest-port** *port-number*

Syntax Description	
dest-ipaddr <i>name</i> <i>ipaddr</i>	Destination of tcpConnect probe. <i>name</i> indicates IP host name. <i>ipaddr</i> indicates IP address.
dest-port <i>port-number</i>	Destination port number.
source-ipaddr <i>name</i> <i>ipaddr</i>	(Optional) Source IP host name or IP address.
source-port <i>port-number</i>	(Optional) Port number of the source. When a port number is not specified, SAA picks the best IP address (nearest to the target) and available UDP port.
control	(Optional) Specifies that the SAA control protocol should be used when running this probe. The control protocol is required when the probe's target is a Cisco router that does not natively provide the service (TCP service in this case). Combined with the enable or disable keyword, enables or disables sending a control message to the destination port. The default is that the control protocol is enabled. When enabled, the SAA sends a control message to the SAA Responder (if available) to enable the destination port prior to sending a probe packet.
enable	Enables the SAA collector to send a control message to the destination port prior to sending a probe packet.
disable	Disables the SAA from sending a control message to the target prior to sending a probe packet.

Defaults The control protocol is enabled.

Command Modes SAA RTR configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines You must configure an SAA operation type before you can configure any of the other characteristics of the operation.

The Transmission Control Protocol (TCP) Connection operation is used to discover the time it takes to connect to the target device. This operation can be used to test virtual circuit availability or application availability. If the target is a Cisco router, then SA Agent makes a TCP connection to any port number specified by the user. If the destination is a non-Cisco IP host, then the user must specify a known target port number (for example, 21 for FTP, 23 for Telnet, or 80 for HTTP Server). This operation is useful in testing Telnet or HTTP connection times.

Examples

In the following example, SAA operation 11 is created and configured as a tcpConnect probe using the destination IP address 172.16.1.175, and the destination port 2400:

```
Router(config)# rtr 11
Router(config-rtr)# type tcpConnect dest-ipaddr 172.16.1.175 dest-port 2400
```

Related Commands

Command	Description
rtr	Specifies an SAA operation begins configuration for that operation.
show rtr configuration	Displays configuration values for SAA operations.

type udpEcho

To define a udpEcho probe, use the **type udpEcho** SAA RTR configuration command. To remove the type configuration for the probe, use the **no** form of this command.

```
type udpEcho dest-ipaddr {name | ipaddr} dest-port port-number [source-ipaddr {name | ipaddr} source-port port-number] [control {enable | disable}]
```

```
no type udpEcho dest-ipaddr {name | ipaddr} dest-port port-number
```

Syntax Description		
dest-ipaddr <i>name</i> <i>ipaddr</i>		Destination of the udpEcho probe. Use an IP host name or IP address.
dest-port <i>port-number</i>		Destination port number. The range of port numbers is from 1 to 65,535.
source-ipaddr <i>name</i> <i>ipaddr</i>	(Optional)	Source IP host name or IP address.
source-port <i>port-number</i>	(Optional)	Port number of the source. When a port number is not specified, SAA picks the best IP address (nearest to the target) and available UDP port
control	(Optional)	Specifies that the SAA RTR control protocol should be used when running this probe. The control protocol is required when the probe's target is a Cisco router that does not natively provide the service (UDP service in this case). Combined with the enable or disable keyword, enables or disables sending of a control message to the destination port. The default is that the control protocol is enabled.
enable		Enable the SAA collector to send a control message to the destination port prior to sending a probe packet.
disable		Disable the SAA from sending a control message to the responder prior to sending a probe packet.

Defaults The control protocol is enabled. Prior to sending a probe packet to the Responder, the SAA collector sends a control message to the Responder to enable the destination port.

Command Modes SAA RTR configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines You must configure an operation type before you can configure any of the other characteristics of the operation.

The source IP address and port number are optional. If they are not specified, SAA selects the IP address nearest to the target and an available UDP port.

Examples

In the following example, SAA operation 12 is created and configured as udpEcho probe using the destination IP address 172.16.1.175 and destination port 2400:

```
Router# configure terminal
Router(config)# rtr 12
Router(config-rtr)# type udpEcho dest-ipaddr 172.16.1.175 dest-port 2400
```

Related Commands

Command	Description
rtr	Specifies an SAA operation and enters SAA RTR configuration mode.
show rtr configuration	Displays configuration values for SAA operations.

verify-data

To cause the SAA operation to check each response for corruption, use the **verify-data** SAA RTR configuration command. To return to the default value, use the **no** form of this command.

verify-data

no verify-data

Syntax Description	This command has no arguments or keywords.

Defaults	Disabled

Command Modes	SAA RTR configuration

Command History	Release	Modification
	11.2	This command was introduced.

Usage Guidelines	Only use the verify-data command when corruption may be an issue.

**Caution**


Do not enable this feature during normal operation because it causes unnecessary overhead.

Examples	In the following example, operation 5 is configured to verify the data for each response:

```
Router(config)# rtr 5
Router(config-rtr)# type echo protocol ipIcmpEcho 172.16.1.174
Router(config-rtr)# response-data-size 2
Router(config-rtr)# verify-data
```

Related Commands	Command	Description
	rtr	Specifies an SAA operation and enters SAA RTR configuration mode.

■ verify-data



WCCP Commands

This chapter provides detailed descriptions of the commands used to configure Web Cache Communication Protocol Version 1 (WCCPv1) and Version 2 (WCCPv2) on your routing device.

For configuration tasks and examples, refer to the “Network Management Using WCCP” chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Configuration Guide*.

[Table 131](#) lists those commands that have been replaced since Cisco IOS Release 12.0.

Table 131 Replaced WCCP Commands

Command in Cisco IOS Release 12.0:	Replaced by or Integrated into:
<code>ip wccp enable</code>	<code>ip wccp</code>
<code>ip wccp redirect-list</code>	<code>ip wccp</code>
<code>ip web-cache redirect</code>	<code>ip wccp web-cache redirect out</code> (see the <code>ip wccp <service> redirect</code> command)
<code>show ip wccp web-caches</code>	<code>show ip wccp web-cache detail</code> (see the <code>show ip wccp</code> command)



Note

Cisco IOS Release 12.2 allows you to enable either WCCPv1 functionality or WCCPv2 functionality on your router using the `ip wccp version` command. However, you must use the commands introduced with WCCPv2 to configure WCCPv1. The original WCCPv1 configuration commands that have been replaced (see [Table 131](#)) will no longer function.

clear ip wccp

To remove Web Cache Communication Protocol (WCCP) statistics (counts) maintained on the router for a particular service, use the **clear ip wccp** EXEC command.

clear ip wccp { **web-cache** | *service-number* }

Syntax Description

web-cache	Directs the router to remove statistics for the web cache service.
<i>service-number</i>	Directs the router to remove statistics for a specified cache service. The number can be from 0 to 99.

Defaults

No default behavior or values.

Command Modes

EXEC

Command History

Release	Modification
11.1 CA	This command was introduced for Cisco 7200 and 7500 platforms.
11.2 P	Support for this command was added to a variety of Cisco platforms.
12.0(3)T	This command was expanded to be explicit about service using the web-cache keyword and the <i>service-number</i> argument.

Usage Guidelines

Use the **show ip wccp** and **show ip wccp detail** commands to display WCCP statistics. If Cisco Cache Engines are used in your service group, the reverse proxy service is indicated by a value of 99.

Examples

In the following example, all statistics associated with the web cache service are removed:

```
Router# clear ip wccp web-cache
```

Related Commands

Command	Description
ip wccp	Directs a router to enable or disable the support for a cache engine service group.
show ip wccp	Displays global statistics related to the WCCP.

ip wccp

To direct a router to enable or disable the support for a cache engine service group, use the **ip wccp** global configuration command. To remove the ability of a router to control support for a service group, use the **no** form of this command.

ip wccp { **web-cache** | *service-number* } [**group-address** *multicast-address*] [**redirect-list** *access-list*] [**group-list** *access-list*] [**password** *password* [**0** | **7**]]

no ip wccp { **web-cache** | *service-number* } [**group-address** *multicast-address*] [**redirect-list** *access-list*] [**group-list** *access-list*] [**password** *password* [**0** | **7**]]

Syntax Description

web-cache	Enables the web cache service.
<i>service-number</i>	Enables the specified Web Cache Communication Protocol (WCCP) service. Services are identified using a number from 0 to 99. If Cisco Cache Engines are being used in your service group, the reverse-proxy service is indicated by a value of 99.
group-address <i>multicast-address</i>	(Optional) Directs the router to use a specified multicast IP address for communication with the WCCP service group. The <i>multicast-address</i> argument requires a multicast address, which is used by the router to determine which cache engine should receive redirected messages.
redirect-list <i>access-list</i>	(Optional) Directs the router to use an access list to control traffic redirected to this service group. The <i>access-list</i> argument should consist of a string of no more than 64 characters (name or number) that specifies the access list.
group-list <i>access-list</i>	(Optional) Directs the router to use an access list to determine which cache engines are allowed to participate in the service group. The <i>access-list</i> argument should consist of a string of no more than 64 characters (name or number) that specifies the access list.
password <i>password</i>	(Optional) Directs the router to apply Message Digest 5 (MD5) authentication to messages received from the service group. Messages that are not accepted by the authentication are discarded. The password can be up to seven characters in length.
0 7	(Optional) Indicates the HMAC MD5 algorithm that is used to encrypt the password. The value is generated when an encrypted password is created for a cache engine.

Defaults

WCCP services are not enabled on the router.

Command Modes

Global configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

This configuration command instructs a router to enable or disable the support for the Service Group specified by the service name given. A service name may be either one of the provided standard keyword definitions or a number representing a cache engine dynamically defined definition. Once the service is enabled, the router can participate in the establishment of a Service Group.

Currently the only provided keyword definition to be used as a service name is **web-cache**. This keyword is used to describe the existing WCCP version 1 functionality.

When the **ip wccp** global configuration command is issued, it instructs the router to allocate space and enable support of the specified WCCP service for participation in a Service Group.

When the **no ip wccp** global configuration command is issued, it instructs the router to terminate participation in the Service Group, deallocate space if none of the interfaces still have the service configured, and terminate the WCCP task if no other services are configured.

**Note**

The **ip wccp** command has replaced the **ip wccp enable**, **ip wccp redirect-list**, and **ip wccp group-list** commands from the version 1 implementation of WCCP.

The keywords following the service name are optional and may be specified in any order, but only may be specified once. The following sections outline the specific usage of each of the optional forms of this command.

ip wccp { web-cache | service-number } group-address multicast-address

A WCCP group address can be configured to set up a multicast address that cooperating routers and web caches can use to exchange WCCP protocol messages. If such an address is used, **ip** multicast routing must be enabled so that the messages using the configured group (multicast) addresses are received correctly. To enable **ip** multicast routing, use the **ip multicast-routing** command.

This option instructs the router to use the specified multicast IP address to coalesce the I See You responses for the Here I Am messages that it has received on this group address. The response is sent to the group address as well. The default is for no group address to be configured, in which case all Here I Am messages are responded to with a unicast reply.

ip wccp { web-cache | service-number } redirect-list access-list

The option instructs the router to use an access list to control the traffic that is redirected to the cache engines of the Service Group specified by the service name given. The *access-list-name* argument specifies either a number from 1 to 99 to represent a standard or extended access list number, or a name to represent a named standard or extended access list. The access list itself specifies which traffic is permitted to be redirected. The default is for no redirect list to be configured (all traffic is redirected).

WCCP requires that the following protocol and ports are not filtered by any access lists:

- User Datagram Protocol (UDP) (protocol type 17) port 2048. This port is used for control signalling. Blocking this type of traffic will prevent WCCP from establishing a connection between the router and cache engines.
- Generic routing encapsulation (GRE) encapsulated (protocol type 47) frames. Blocking this type of traffic will prevent the cache engines from ever seeing the packets intercepted.

ip wccp { web-cache | service-number } group-list access-list

The option instructs the router to use an access list to control the cache engines allowed to participate in the specified Service Group. The *access-list* parameter specifies either a number from 1 to 99 to represent a standard access list number, or a name to represent a named standard access list. The access list itself specifies which cache engines are permitted to participate in the Service Group. The default is for no group list to be configured, in which case all cache engines may participate in the Service Group.

**Note**

The **ip wccp {web-cache | service-number} group-list** command syntax resembles the **ip wccp {web-cache | service-number} group-listen** command, but these are entirely different commands. Note that the **ip wccp group-listen** command is an interface configuration command, used to configure an interface to listen for multicast notifications from a cache cluster. See the description of the **ip wccp <service> group-listen** command in this chapter for more information.

ip wccp {web-cache | service-number} password password

The option instructs the router to use MD5 authentication on the messages received from the Service Group specified by the service name given. Use this form of the command to set the password on the router. You must also configure the same password separately on each cache engine. The password can be up to a maximum of seven characters. Messages that do not authenticate when authentication is enabled on the Router are discarded. The default is for no authentication password to be configured and authentication to be disabled.

Examples

In the following example, a user configures a router to run WCCP reverse proxy service, using the multicast address of 224.1.1.1:

```
Router# configure terminal
Router(config)# ip wccp 99 group-address 224.1.1.1
Router(config)# interface ethernet 0
Router(config-if)# ip wccp web-cache group-list
```

In the following example, a user configures a router to redirect web-related packets without a destination of 192.168.196.51 to the cache engine:

```
Router# configure terminal
Router(config)# access-list 100 deny ip any host 192.168.196.51
Router(config)# access-list 100 permit ip any any
Router(config)# ip wccp redirect-list 100
Router(config)# interface Ethernet 0
Router(config-if)# ip web-cache redirect-list
Router(config-if)# end
Router#
```

Related Commands

Command	Description
ip wccp version	Specifies which version of WCCP you wish to use on your router.

ip wccp enable

The **ip wccp enable** has been replaced by the **ip wccp** command. See the description of the [ip wccp](#) command in this chapter for more information.

ip wccp <service> group-listen

To configure an interface on a router to enable or disable the reception of IP multicast packets for the Web Cache Communication Protocol (WCCP) feature, use the **ip wccp group-listen** interface configuration command. To remove control of the reception of IP multicast packets for the WCCP feature, use the **no** form of this command.

ip wccp {web-cache | service-number} group-listen

no ip wccp {web-cache | service-number} group-listen

Syntax Description	web-cache	Directs the router to send packets to the web cache service.
	service-number	The identification number of the cache engine service group being controlled by a router. The number can be from 0 to 99.

Defaults	This command is disabled by default.

Command Modes	Interface configuration

Command History	Release	Modification
	12.0(3)T	This command was introduced.

Usage Guidelines	On routers that are to be members of a Service Group when IP multicast is used, the following configuration is required: • The IP multicast address for use by the WCCP Service Group must be configured. • The interfaces on which the router wishes to receive the IP multicast address to be configured with the ip wccp {web-cache service-number} group-listen interface configuration command.

Examples	In the following example, a user enables the multicast packets for a web cache with a multicast address of 224.1.1.100.

```
router# configure terminal
router(config)# ip wccp web-cache group-address 224.1.1.100
router(config)# interface ethernet 0
router(config-if)# ip wccp web-cache group listen
```

 `ip wccp <service> group-listen`**Related Commands**

Command	Description
<code>ip wccp</code>	Directs a router to enable or disable the support for a WCCP cache engine service group.
<code>ip wccp <service> redirect</code>	Enables WCCP redirection on an interface.

ip wccp redirect exclude in

To configure an interface to exclude packets received on an interface from being checked for redirection, use the **ip wccp redirect exclude in** interface configuration command. To disable the ability of a router to exclude packets from redirection checks, use the **no** form of this command.

ip wccp redirect exclude in

no ip wccp redirect exclude in

Syntax Description

This command has no arguments or keywords.

Defaults

Redirection exclusion is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.

Usage Guidelines

This configuration command instructs the interface to exclude inbound packets from any redirection check that may occur at the outbound interface. Note that the command is global to all the services and should be applied to any inbound interface that you wish to exclude from redirection.

This command is intended to be used to accelerate the flow of packets from a cache engine to the internet as well as allow for the use of the WCCPv2 Packet Return feature.

Examples

In the following example, packets arriving on Ethernet interface 0 are excluded from all WCCP redirection checks:

```
Router(config)# interface ethernet 0  
Router(config-if)# ip wccp redirect exclude in
```

Related Commands

Command	Description
ip wccp	Directs a router to enable or disable the support for a cache engine service group.
ip wccp redirect out	Configures an interface to enable the ability of a router to verify that appropriate packets are being redirected to a cache engine.

ip wccp redirect-list

This command is now documented as part of the **ip wccp {web-cache | service-number}** command. See the description of the **ip wccp** command in this chapter for more information.

ip wccp <service> redirect

To enable packet redirection on an outbound or inbound interface using Web Cache Communication Protocol (WCCP), use the **ip wccp service redirect** interface configuration command. To disable WCCP redirection, use the **no** form of this command.

ip wccp service redirect {out | in}

no ip wccp service redirect {out | in}

Syntax Description

<i>service</i>	Specifies the service group. You can specify the web-cache keyword, or you can specify the identification number(from 0 to 99) of the service.
redirect	Enables packet redirection checking on an outbound or inbound interface.
out	Specifies packet redirection on an outbound interface.
in	Specifies packet redirection on an inbound interface.

Defaults

Redirection checking on the interface is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
12.0(3) T	This command was introduced.
12.0(11)S	The in keyword was added to the 12.0 S release train.
12.1(3)T	The in keyword was added to the 12.1 T release train.

Usage Guidelines

The **ip wccp service redirect in** command allows you to configure WCCP redirection on an interface receiving inbound network traffic. When the command is applied to an interface, all packets arriving at that interface will be compared against the criteria defined by the specified WCCP service. If the packets match the criteria, they will be redirected.

Likewise, the **ip wccp service redirect out** command allows you to configure the WCCP redirection check at an outbound interface.



Tips

Be careful not to confuse the **ip wccp service redirect {out | in}** interface configuration command with the **ip wccp redirect exclude in** interface configuration command.



Note

This command has the potential to effect the **ip wccp redirect exclude in** command. (These commands have opposite functions.) If you have **ip wccp redirect exclude in** set on an interface and you subsequently configure the **ip wccp service redirect in** command, the “exclude in” command will be overridden. The opposite is also true: configuring the “exclude in” command will override the “redirect in” command.

Examples

In the following example, the user configures a session in which reverse proxy packets on Ethernet interface 0 are being checked for redirection and redirected to a Cisco Cache Engine:

```
Router# configure terminal
Router(config)# ip wccp 99
Router(config)# interface ethernet 0
Router(config-if)# ip wccp 99 redirect ?
    in   Redirect to a Cache Engine appropriate inbound packets
    out  Redirect to a Cache Engine appropriate outbound packets
Router(config-if)# ip wccp 99 redirect out
```

In the following example, the user configures a session in which HTTP traffic arriving on Ethernet interface 0/1 will be redirected to a Cisco Cache Engine:

```
Router# configure terminal
Router(config)# ip wccp web-cache
Router(config)# interface ethernet 0/1
Router(config-if)# ip wccp web-cache redirect in
```

Related Commands

Command	Description
ip wccp redirect exclude in	Enables redirection exclusion on an interface.

ip wccp version

To specify which version of Web Cache Communication Protocol (WCCP) you wish to configure on your router, use the **ip wccp version** global configuration command.

ip wccp version { 1 | 2 }

Syntax Description	1	Web Cache Communication Protocol Version 1 (WCCPv1).
	2	Web Cache Communication Protocol Version 2 (WCCPv2).

Defaults WCCPv2

Command Modes Global configuration

Command History	Release	Modification
	12.0(5)T	This command was introduced.

Examples In the following example, the user changes the WCCP version from the default of WCCPv2 to WCCPv1, starting in privileged EXEC mode:

```
router# show ip wccp
% WCCP version 2 is not enabled
router# configure terminal
router(config)# ip wccp version 1
router(config)# end
router# show ip wccp
% WCCP version 1 is not enabled
```

ip web-cache redirect

The **ip web-cache redirect** interface configuration command has been replaced by the **ip wccp <service> redirect** interface configuration command. The **ip web-cache redirect** command is no longer supported. See the description of the **ip wccp <service> redirect** command in this chapter for more information.

show ip wccp

To display global statistics related to Web Cache Communication Protocol (WCCP), use the **show ip wccp** command in privileged EXEC mode.

show ip wccp [*service-number* | **web-cache**] [**detail** | **view**]

Syntax Description

<i>service-number</i>	(Optional) Identification number of the web-cache service group being controlled by the cache. The number can be from 0 to 256. For web caches using Cisco Cache Engines, the reverse proxy service is indicated by a value of 99.
web-cache	(Optional) Statistics for the web-cache service.
detail	(Optional) Information about the router and all web caches.
view	(Optional) Other members of a particular service group have or have not been detected.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1CA	This command was introduced for Cisco 7200 and 7500 platforms.
11.2P	Support for this command was added to a variety of Cisco platforms.
12.0(3)T	The detail and view keywords were added.
12.3(7)T	The output was enhanced to display the bypass counters (process, fast, and Cisco Express Forwarding) when WCCP is enabled.
12.2(14)SX	Support for this command was introduced on the Supervisor Engine 720.
12.2(17d)SXB	Support for this command on the Supervisor Engine 2 was extended to Cisco IOS Release 12.2(17d)SXB.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.3(14)T	The output was enhanced to display the maximum number of service groups.
12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

Use the **clear ip wccp** command to reset the counter for the “Packets Redirected” information.

Use the **show ip wccp service-number** command to provide the “Total Packets Redirected” count. The “Total Packets Redirected” count is the number of flows, or sessions, that are redirected.

Use the **show ip wccp service-number detail** command to provide the “Packets Redirected” count. The “Packets Redirected” count is the number of flows, or sessions, that are redirected.

Use the **show ip wccp web-cache detail** command to provide an indication of how many flows, rather than packets, are using Layer 2 redirection.

For cache-engine clusters using Cisco cache engines, the reverse proxy *service-number* is indicated by a value of 99.

For additional information on the IP WCCP commands, refer to the “Configuring Web Cache Services Using WCCP” section in the *Cisco IOS Configuration Fundamentals Configuration Guide*.

Examples

This section contains examples and field descriptions for the following forms of this command:

- **show ip wccp web-cache**
- **show ip wccp service-number view**
- **show ip wccp service-number detail**
- **show ip wccp web-cache detail**
- **show ip wccp web-cache detail** (bypass counters displayed)

show ip wccp web-cache

The following is sample output from the **show ip wccp web-cache** command:

```
Router# show ip wccp web-cache
```

```
Global WCCP Information:
Service Name: web-cache:
Number of Cache Engines:      1
Number of Routers:           1
Total Packets Redirected:     213
Redirect access-list:         no_linux
Total Packets Denied Redirect: 88
Total Packets Unassigned:     -none-
Group access-list:            0
Total Messages Denied to Group: 0
Total Authentication failures: 0
```

Table 132 describes the significant fields shown in the display.

Table 132 show ip wccp web-cache Field Descriptions

Field	Description
Service Name	Indicates which service is detailed.
Number of Cache Engines	Number of Cisco cache engines using the router as their home router.
Number of Routers	The number of routers in the service group.
Total Packets Redirected	Total number of packets redirected by the router.
Redirect access-list	The name or number of the access list that determines which packets will be redirected.
Total Packets Denied Redirect	Total number of packets that were not redirected because they did not match the access list.
Total Packets Unassigned	Number of packets that were not redirected because they were not assigned to any cache engine. Packets may not be assigned during initial discovery of cache engines or when a cache is dropped from a cluster.
Group access-list	Indicates which cache engine is allowed to connect to the router.

Table 132 *show ip wccp web-cache Field Descriptions (continued)*

Field	Description
Total Messages Denied to Group	Indicates the number of packets denied by the <i>group-list</i> access list.
Total Authentication failures	The number of instances where a password did not match.

show ip wccp *service-number* view

The following is sample output from the **show ip wccp 1 view** command:

```
Router# show ip wccp 1 view
```

WCCP Router Informed of:

10.168.88.10

10.168.88.20

WCCP Cache Engines Visible

10.168.88.11

10.168.88.12

WCCP Cache Engines Not Visible:

-none-



Note

The number of maximum service groups that can be configured is 256.

If any web cache is displayed under the WCCP Cache Engines Not Visible field, the router needs to be reconfigured to map the web cache that is not visible to it.

Table 133 describes the significant fields shown in the display.

Table 133 *show ip wccp service-number* **view Field Descriptions**

Field	Description
WCCP Router Informed of	A list of routers detected by the current router.
WCCP Clients Visible	A list of clients that are visible to the router and other clients in the service group.
WCCP Clients Not Visible	A list of clients in the service group that are not visible to the router and other clients in the service group.

show ip wccp *service-number* **detail**

The following example displays WCCP client information and WCCP router statistics that include the type of services:

```
Router# show ip wccp 91 detail
```

WCCP Client information:

```
WCCP Client ID: 10.1.1.14
```

Protocol Version: 2.0

State: Usable

Redirection: GRE

Packet Return: GRE

Assignment: HASH

[illegible][illegible]

Hash Allotment: 256 (100.00%)

```

Packets Redirected: 0
Connect Time: 00:01:56
Bypassed Packets
Process: 0
CEF: 0

```

show ip wccp web-cache detail

The following example displays web-cache engine information and WCCP router statistics for a particular service group:

```
Router# show ip wccp web-cache detail
```

```

WCCP Router information:
  IP Address           10.168.88.10
  Protocol Version:    2.0

WCCP Client Information
  IP Address:          10.168.88.11
  Protocol Version:    2.0
  State:               Usable
  Initial Hash Info:   AAAAAAAAAAAAAAAAAAAAAAAAAA
                      AAAAAAAAAAAAAAAAAAAAAAAAAA
  Assigned Hash Info:  FFFFFFFFFFFFFFFFFFFFFFFF
                      FFFFFFFFFFFFFFFFFFFFFFFF
  Hash Allotment:      256 (100.00%)
  Packets Redirected:  21345
  Connect Time:        00:13:46

```

Table 134 describes the significant fields shown in the display.

Table 134 show ip wccp web-cache detail Field Descriptions

Field	Description
WCCP Router information	The header for the area that contains fields for the IP address and version of WCCP associated with the router connected to the cache engine in the service group.
IP Address	The IP address of the router connected to the cache engine in the service group.
Protocol Version	The version of WCCP being used by the router in the service group.
WCCP Client Information	The header for the area that contains fields for information on clients.
IP Address	The IP address of the cache engine in the service group.
Protocol Version	The version of WCCP being used by the cache engine in the service group.
State	Indicates whether the cache engine is operating properly and can be contacted by a router and other cache engines in the service group.
Initial Hash Info	The initial state of the hash bucket assignment. The values show the state of each of the 256 hash buckets. Hexadecimal digits are used as shorthand for binary numbers with F representing 1111, four bits set to one. If a set of four bits is F, then that hash bucket is allocated to the client with the displayed ID. If a set of bits is 0, then it is not allocated to the client with the displayed ID.

Table 134 *show ip wccp web-cache detail Field Descriptions (continued)*

Field	Description
Assigned Hash Info	The current state of the hash bucket assignment. The values show the state of each of the 256 hash buckets. If F is displayed, then that hash bucket is allocated to the client with the displayed ID. If a bit is 0 then it is not allocated to the client with the displayed ID. In this output all the bits in the assigned field are F, indicating that all traffic goes to that client. All 1's in the assigned field indicates there is only one client in the service group. If there were two clients in the group, half of the bits would have a value of F and the other half would have a value of 0 for each client, indicating that redirected traffic is divided equally between the two clients.
Hash Allotment	The percent of buckets assigned to the current cache engine. Both a value and a percent figure are displayed.
Packets Redirected	The number of packets that have been redirected to the cache engine.
Connect Time	The amount of time the cache engine has been connected to the router.

show ip wccp web-cache detail (Bypass Counters)

The following example displays web-cache engine information and WCCP router statistics that include the bypass counters:

```
Router# show ip wccp web-cache detail
```

```
WCCP Router information:
  IP Address:10.168.88.10
  Protocol Version:2.0

WCCP Client Information
  IP Address:10.168.88.11
  Protocol Version:2.0
  State:Usable
  Initial Hash Info:AAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
  Assigned Hash Info:FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
  Hash Allotment:256 (100.00%)
  Packets Redirected:21345
  Connect Time:00:13:46
  Bypassed Packets
    Process:          0
    Fast:             0
    CEF:              250
```

[Table 135](#) describes the significant fields shown in the display.

Table 135 *show ip wccp web-cache detail Field Descriptions*

Field	Description
WCCP Router information	The header for the area that contains fields for the IP address and the version of WCCP associated with the router connected to the cache engine in the service group.
IP Address	The IP address of the router connected to the cache engine in the service group.
Protocol Version	The version of WCCP that is being used by the router in the service group.
WCCP Client Information	The header for the area that contains fields for information on clients.
IP Address	The IP address of the cache engine in the service group.
Protocol Version	The version of WCCP that is being used by the cache engine in the service group.
State	Indicates whether the cache engine is operating properly and can be contacted by a router and other cache engines in the service group.
Initial Hash Info	The initial state of the hash bucket assignment.
Assigned Hash Info	The current state of the hash bucket assignment.
Hash Allotment	The percent of buckets assigned to the current cache engine. Both a value and a percent figure are displayed.
Packets Redirected	The number of packets that have been redirected to the cache engine.
Connect Time	The amount of time the cache engine has been connected to the router.
Bypassed Packets	The number of packets that have been bypassed. Process, fast, and Cisco Express Forwarding (CEF) are switching paths within Cisco IOS software.

Related Commands

Command	Description
clear ip wccp	Clears the counter for packets redirected using WCCP.
ip wccp	Enables WCCP on a router and specifies the type of services to be used.
ip wccp redirect	Enables packet redirection on an outbound or inbound interface using WCCP.
ip wccp web-cache accelerated	Enables the hardware acceleration for WCCP version 1.
show ip interface	Lists a summary of the IP information and status of an interface.

show ip wccp web-caches

The **show ip wccp web-caches** command has been replaced by the **show ip wccp web-cache detail** command. See the description of the [show ip wccp](#) command in this chapter for more information.


Command History

Release	Modification
11.2P, 11.1CA, 12.0	This command was introduced.
12.1	This command was replaced by the show ip wccp command.

■ show ip wccp web-caches



Appendixes



ASCII Character Set and Hex Values

Some commands described in the Cisco IOS documentation set, such as the **escape-character** line configuration command, require that you enter the decimal representation of an ASCII character. Other commands, such as the **snmp-server group** command, make use of hexadecimal representations.

[Table 136](#) provides code translations from the decimal numbers to their hexadecimal and ASCII equivalents. It also provides the keyword entry for each ASCII character. For example, the ASCII carriage return (CR) is decimal 13. Entering Ctrl-M at your terminal generates decimal 13, which is interpreted as a CR.

Table 136 ASCII Translation Table

Numeric Values		ASCII Character	Meaning	Keyboard Entry
Decimal	Hex			
0	00	NUL	Null	Ctrl-@
1	01	SOH	Start of heading	Ctrl-A
2	02	STX	Start of text	Ctrl-B
3	03	ETX	Break/end of text	Ctrl-C
4	04	EOT	End of transmission	Ctrl-D
5	05	ENQ	Enquiry	Ctrl-E
6	06	ACK	Positive acknowledgment	Ctrl-F
7	07	BEL	Bell	Ctrl-G
8	08	BS	Backspace	Ctrl-H
9	09	HT	Horizontal tab	Ctrl-I
10	0A	LF	Line feed	Ctrl-J
11	0B	VT	Vertical tab	Ctrl-K
12	0C	FF	Form feed	Ctrl-L
13	0D	CR	Carriage return (Equivalent to the Enter or Return key)	Ctrl-M
14	0E	SO	Shift out	Ctrl-N
15	0F	SI	Shift in/XON (resume output)	Ctrl-O
16	10	DLE	Data link escape	Ctrl-P

Table 136 ASCII Translation Table (continued)

Numeric Values		ASCII Character	Meaning	Keyboard Entry
Decimal	Hex			
17	11	DC1	Device control character 1	Ctrl-Q
18	12	DC2	Device control character 2	Ctrl-R
19	13	DC3	Device control character 3	Ctrl-S
20	14	DC4	Device control character 4	Ctrl-T
21	15	NAK	Negative acknowledgment	Ctrl-U
22	16	SYN	Synchronous idle	Ctrl-V
23	17	ETB	End of transmission block	Ctrl-W
24	18	CAN	Cancel	Ctrl-X
25	19	EM	End of medium	Ctrl-Y
26	1A	SUB	Substitute/end of file	Ctrl-Z
27	1B	ESC	Escape	Ctrl-[
28	1C	FS	File separator	Ctrl-\
29	1D	GS	Group separator	Ctrl-]
30	1E	RS	Record separator	Ctrl-^
31	1F	US	Unit separator	Ctrl-_
32	20	SP	Space	Space
33	21	!	!	!
34	22	"	"	"
35	23	#	#	#
36	24	\$	\$	\$
37	25	%	%	%
38	26	&	&	&
39	27	,	,	,
40	28	(	(	(
41	29	)	)	)
42	2A	*	*	*
43	2B	+	+	+
44	2C	,	,	,
45	2D	-	-	-
46	2E	.	.	.
47	2F	/	/	/
48	30	0	Zero	0
49	31	1	One	1
50	32	2	Two	2
51	33	3	Three	3

Table 136 ASCII Translation Table (continued)


Numeric Values		ASCII		
Decimal	Hex	Character	Meaning	Keyboard Entry
52	34	4	Four	4
53	35	5	Five	5
54	36	6	Six	6
55	37	7	Seven	7
56	38	8	Eight	8
57	39	9	Nine	9
58	3A	:	:	:
59	3B	;	;	;
60	3C	<	<	<
61	3D	=	=	=
62	3E	>	>	>
63	3F	?	?	?
64	40	@	@	@
65	41	A	A	A
66	42	B	B	B
67	43	C	C	C
68	44	D	D	D
69	45	E	E	E
70	46	F	F	F
71	47	G	G	G
72	48	H	H	H
73	49	I	I	I
74	4A	J	J	J
75	4B	K	K	K
76	4C	L	L	L
77	4D	M	M	M
78	4E	N	N	N
79	4F	O	O	O
80	50	P	P	P
81	51	Q	Q	Q
82	52	R	R	R
83	53	S	S	S
84	54	T	T	T
85	55	U	U	U
86	56	V	V	V

Table 136 ASCII Translation Table (continued)

Numeric Values		ASCII Character	Meaning	Keyboard Entry
Decimal	Hex			
87	57	W	W	W
88	58	X	X	X
89	59	Y	Y	Y
90	5A	Z	Z	Z
91	5B	[	[	[
92	5C	\	\	\
93	5D	]	]	]
94	5E	^	^	^
95	5F	_	_	_
96	60	`	`	`
97	61	a	a	a
98	62	b	b	b
99	63	c	c	c
100	64	d	d	d
101	65	e	e	e
102	66	f	f	f
103	67	g	g	g
104	68	h	h	h
105	69	i	i	i
106	6A	j	j	j
107	6B	k	k	k
108	6C	l	l	l
109	6D	m	m	m
110	6E	n	n	n
111	6F	o	o	o
112	70	p	p	p
113	71	q	q	q
114	72	r	r	r
115	73	s	s	s
116	74	t	t	t
117	75	u	u	u
118	76	v	v	v
119	77	w	w	w
120	78	x	x	x
121	79	y	y	y

Table 136 *ASCII Translation Table (continued)*

Numeric Values		ASCII		
Decimal	Hex	Character	Meaning	Keyboard Entry
122	7A	z	z	z
123	7B	{	{	{
124	7C			
125	7D	}	}	}
126	7E	~	Tilde	~
127	7F	DEL	Delete	Del



Cisco 7500 Series Line Card Configuration Commands

This chapter contains Cisco IOS software commands used to configure characteristics for Cisco 7500 series line cards. Line cards are any I/O card that can be inserted in a modular chassis (including the Cisco 7500 RSP cards).

For more information on Cisco 7000 series hardware configuration, see the Core/High-End Routers documentation section of Cisco.com at <http://www.cisco.com/univercd/cc/td/doc/product/core/index.htm> or on the Documentum CD-ROM.

service single-slot-reload-enable

To enable single line card reloading for all line cards in a Cisco 7500 series router, use the **service single-slot-reload-enable** global configuration command. To disable single line card reloading for the line cards, use the **no** form of this command.

service single-slot-reload-enable

no service single-slot-reload-enable

Syntax Description This command has no arguments or keywords.

Defaults Single line card reloading is disabled by default.

Command Modes Global configuration mode

Command History	Release	Modification
	12.0(13)S	This command was introduced.
	12.1(5)T	This command was integrated in Cisco IOS Release 12.1 T.

Usage Guidelines Before the introduction of this command, the only method of correcting a line card hardware failure or a severe software error for one line card on a Cisco 7500 series router required the execution of a Cbus Complex, a process that reloaded every line card on the network backplane. The time taken to complete the Cbus Complex was often inconvenient, and no network traffic could be routed or switched during the Cbus Complex process.

The **service single-slot-reload-enable command** allows users to correct a line card failure on a Cisco 7500 series router by reloading the failed line card without reloading any other line cards on the network backplane. During the single line card reload process, all physical lines and routing protocols on the other line cards of the network backplane remain active. A single line card reload is also substantially faster than the Cbus Complex process.

Examples In the following example, single line card reloading is enabled for all lines cards on a Cisco 7513 router:

```
c7513(config)# service single-slot-reload-enable
```

Related Commands	Command	Description
	show diag	Displays hardware information on line cards.
	show running-config	Displays configuration information.

slave auto-sync config

To turn on automatic synchronization of configuration files for a Cisco 7507 or Cisco 7513 router that is configured for High System Availability (HSA) using Dual RSP Cards, use the **slave auto-sync config** global configuration command. To turn off automatic synchronization, use the **no** form of the command.

slave auto-sync config

no slave auto-sync config

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Global configuration

Command History

Release	Modification
11.1	The command was introduced.

Usage Guidelines

Use this command for a Cisco 7507 or Cisco 7513 router that is configured for dual RSP cards. On the Cisco 7507 and Cisco 7513 router, you can install two RSP cards in a single router to improve system availability. Dual RSP Cards is a High System Availability (HSA) feature.

In automatic synchronization mode, when you issue a **copy EXEC** command that specifies the master's startup configuration (**nvram:startup-config**) as the target, the master also copies the same file to the slave's startup configuration (**slavenvram:startup-config**). Use this command when implementing HSA for simple hardware backup or for software error protection to ensure that the master and slave RSP contain the same configuration files.

Examples

The following example turns on automatic configuration file synchronization. When the **copy system:running-config nvram:startup-config** command is entered, the running configuration is saved to the startup configurations of both the master RSP and the slave RSP.

```
Router(config)# slave auto-sync config
Router(config)# end
Router# copy system:running-config nvram:startup-config
```

Related Commands

Command	Description
show controller cbus	Displays detailed information on the cards connected to the CBus controller.
show stacks	Displays the stack trace and version information of the master and slave RSP cards.

Command	Description
show version	Displays the software version running on the master and slave RSP cards.
slave sync config	Manually synchronizes configuration files on the master and slave RSP cards of a Cisco 7507 or Cisco 7513 router.

slave default-slot

To specify the default slave Route Switch Processor (RSP) card on a Cisco 7507 or Cisco 7513 router, use the **slave default-slot** global configuration command.

slave default-slot *processor-slot-number*

Syntax Description	<i>processor-slot-number</i>	Number of a processor slot that contains the default slave RSP. On the Cisco 7507 router, valid values are 2 or 3. On the Cisco 7513 router, valid values are 6 or 7. The default is the higher number processor slot.

Defaults	The default slave is the RSP card located in the higher number processor slot. On the Cisco 7507 router, processor slot 3 contains the default slave RSP. On the Cisco 7513 router, processor slot 7 contains the default slave RSP.

Command Modes	Global configuration

Command History	Release	Modification
	11.1	The command was introduced.

Usage Guidelines	Use this command for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Cards. On the Cisco 7507 and Cisco 7513 router, you can install two RSP cards in a single router to improve system availability. Dual RSP Cards is a High System Availability (HSA) feature.

The router uses the default slave information when booting as follows:

- If a system boot is due to powering up the router or using the **reload** EXEC command, then the specified default slave will be the slave RSP.
- If a system boot is due to a system crash or hardware failure, then the system ignores the default slave designation, and makes the crashed or faulty RSP card the slave RSP.

Examples	In the following example, the user sets the default slave RSP to processor slot 2 on a Cisco 7507 router: c7507(config)# slave default-slot 2

Related Commands	Command	Description
	reload	Reloads the operating system.
	show controller cbus	Displays detailed information on the cards connected to the CBus controller.
	show stacks	Displays the stack trace and version information of the master and slave RSP cards.
	show version	Displays the software version running on the master and slave RSP cards.

slave image

To specify the image that the slave Route Switch Processor (RSP) runs on a Cisco 7507 or Cisco 7513 router, use the **slave image** global configuration command.

slave image {**system** | *file-url*}

Syntax Description

system	Loads the slave image that is bundled with the master system image. This is the default.
<i>file-url</i>	Loads the slave image from the specified file in a Flash file system. If you do not specify a filename, the first file on the specified Flash file system is the default file.

Defaults

The default is to load the image from the system bundle.

Command Modes

Global configuration

Command History

Release	Modification
11.1	This command was introduced.

Usage Guidelines

Use this command for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Cards. On the Cisco 7507 and Cisco 7513 router, you can install two RSP cards in a single router to improve system availability. Dual RSP Cards is a High System Availability (HSA) feature.

Use the **slave image** command to override the slave image that is bundled with the master image.

When using HSA for simple hardware backup, ensure that the slave image is in the same location on the master and the slave RSP card. Thus, if the slave RSP card becomes the master, it will be able to find the slave image and download it to the new slave.

Examples

In the following example, the slave RSP is specified to run the `rsp-dw-mz.ucode.111-3.2` image from slot 0:

```
c7507(config)# slave image slot0:rsp-dw-mz.ucode.111-3.2
```

Related Commands

Command	Description
show controller cbus	Displays detailed information on the cards connected to the CBus controller.
show stacks	Displays the stack trace and version information of the master and slave RSP cards.
show version	Displays the software version running on the master and slave RSP cards.
slave reload	Forces a reload of the image that the slave RSP card is running on a Cisco 7507 or Cisco 7513 router.

slave reload

To force a reload of the image that the slave Route Switch Processor (RSP) card is running on a Cisco 7507 or Cisco 7513 router, use the **slave reload** global configuration command.

slave reload

Syntax Description	This command has no arguments or keywords.

Defaults	No default behavior or values.

Command Modes	Global configuration

Command History	Release	Modification
	11.1	The command was introduced.

Usage Guidelines	Use this command for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Cards. On the Cisco 7507 and Cisco 7513 router, you can install two RSP cards in a single router to improve system availability. Dual RSP Cards is a High System Availability (HSA) feature.

After using the **slave image** global configuration command to specify the image that the slave RSP runs on a Cisco 7507 or Cisco 7513 router, use the **slave reload** command to reload the slave with the new image. The **slave reload** command can also be used to force the slave to reboot its existing image.

Examples	In the following example, an inactive slave RSP card is reloaded. If the slave reloads, it will return to an active slave state. If the master RSP fails, the slave RSP will become the master.

```
c7507(config)# slave reload
```

Related Commands	Command	Description
	show controller cbus	Displays detailed information on the cards connected to the CBus controller.
	show stacks	Displays the stack trace and version information of the master and slave RSP cards.
	show version	Displays the software version running on the master and slave RSP cards.
	slave image	Specifies the image that the slave RSP runs on a Cisco 7507 or Cisco 7513 router.

slave sync config

To manually synchronize configuration files on the master and slave Route Switch Processor (RSP) cards of a Cisco 7507 or Cisco 7513 router, use the **slave sync config** privileged EXEC command.

slave sync config

Syntax Description

This command has no arguments or keywords.

Defaults

Automatic synchronization is turned on.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1	The command was introduced.

Usage Guidelines

Use this command for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Cards. On the Cisco 7507 and Cisco 7513 router, you can install two RSP cards in a single router to improve system availability. Dual RSP Cards is a High System Availability (HSA) feature.

This command allows you to synchronize the configuration files of the master and slave RSP cards on a case-by-case basis when you do not have automatic synchronization turned on. This command copies the master's configuration file to the slave RSP card.



Note

You *must* use this command when you insert a new slave RSP card into a Cisco 7507 or Cisco 7513 router for the first time to ensure that the new slave is configured consistently with the master.

Examples

In the following example, the configuration files on the master and slave RSP card are synchronized:

```
c7507(config)# slave sync config
```

Related Commands

Command	Description
show controller cbus	Displays detailed information on the cards connected to the CBus controller.
show stacks	Displays the stack trace and version information of the master and slave RSP cards.
show version	Displays the software version running on the master and slave RSP cards.
slave auto-sync config	Turns on automatic synchronization of configuration files for a Cisco 7507 or Cisco 7513 router that is configured for HSA.

slave terminal

To enable access to the slave Route Switch Processor (RSP) console, use the **slave terminal** global configuration command. To disable access to the slave RSP console, use the **no** form of this command.

slave terminal

no slave terminal

Syntax Description	This command has no arguments or keywords.

Defaults	Enabled

Command Modes	Global configuration

Command History	Release	Modification
	11.1	The command was introduced.

Usage Guidelines	The slave console does not have enable password protection. Thus, an individual connected to the slave console port can enter privileged EXEC mode and view or erase the configuration of the router. Use the no slave terminal command to disable slave console access and prevent security problems. When the slave console is disabled, users cannot enter commands.

If slave console access is disabled, the following message appears periodically on the slave console:

```
%%Slave terminal access is disabled. Use "slave terminal" command in master RSP configuration mode to enable it.
```

Examples	In the following example, the user disables console access to the slave RSP:


```
c7507(config)# no slave terminal
```

Related Commands	Command	Description
	show controller cbus	Displays detailed information on the cards connected to the CBus controller.
	show stacks	Displays the stack trace and version information of the master and slave RSP cards.
	show version	Displays the software version running on the master and slave RSP cards.
	slave auto-sync config	Turns on automatic synchronization of configuration files for a Cisco 7507 or Cisco 7513 router that is configured for Dual RSP Cards.

■ slave terminal



Index



Symbols

! character
 ping command output [FR-532](#)

character (privileged EXEC mode prompt) [FR-9](#)

. character
 ping command output [FR-532](#)

/etc/printcap file
 modifying for printing [FR-80](#)

<cr> [xv](#)

> prompt [FR-313](#)

? command [xiv](#)

Numerics

7-bit character set
 session, changing for a [FR-106](#)
 standard U.S. characters [FR-106](#)

8-bit character set
 EXEC and configuration commands
 default value, setting [FR-59](#)
 line, configuring on a [FR-69](#)
 session, changing for a [FR-94](#)

hardware databits
 line, configuring for a [FR-57](#)
 session, changing for a [FR-88](#)

software character bits
 line, setting for a [FR-58](#)
 session, changing for a [FR-89](#)

special character width
 default value, setting [FR-60](#)
 line, configuring on a [FR-84](#)
 session, changing for a [FR-106](#)

A

absolute command [FR-376](#)

absolute-timeout command
 use with logout-warning [FR-76](#)

access lists
 IP, time-based [FR-376, FR-440](#)
 IPX, time ranges [FR-478](#)

activation character, setting [FR-54, FR-545](#)

activation-character command [FR-54, FR-545](#)

alias command [FR-378](#)

aliases
 commands, creating for [FR-378](#)
 displaying [FR-457](#)

ASCII
 character set (table) [FR-919](#)
 character widths, changing [FR-84, FR-106](#)
 disconnect character [FR-61](#)
 dispatch character [FR-62, FR-90](#)
 escape character [FR-67, FR-93](#)
 hold character [FR-71](#)
 padding [FR-78, FR-102](#)
 start character [FR-109](#)
 stop character [FR-111](#)

async-bootp command [FR-344](#)

attach command [FR-482](#)

autobaud command [FR-55](#)

B

banner exec command [FR-124](#)

banner incoming command [FR-126](#)

banner login command [FR-128](#)

- banner motd command [FR-130](#)
 - banners
 - EXEC, displaying [FR-124](#)
 - incoming message [FR-126](#)
 - line
 - disabling on a [FR-124, FR-128, FR-156](#)
 - enabling on a [FR-124, FR-128, FR-156](#)
 - line number [FR-162](#)
 - login [FR-128](#)
 - MOTD [FR-130](#)
 - reverse Telnet lines [FR-126](#)
 - system shutdown, using to announce [FR-130](#)
 - See also* messages
 - baud rates
 - receive, changing for session [FR-105](#)
 - See also* line speed
 - boot bootldr command [FR-316](#)
 - boot bootstrap command [FR-318](#)
 - boot buffersize command [FR-234](#)
 - boot command [FR-312](#)
 - boot config command [FR-235](#)
 - BOOT environment variable
 - order of entries, rearranging [FR-323](#)
 - specifying [FR-320, FR-323](#)
 - boot fields
 - default values, changing [FR-325, FR-327](#)
 - boot flash command [FR-312](#)
 - boot host command [FR-237](#)
 - booting
 - from Flash [FR-320](#)
 - from Flash manually [FR-312](#)
 - from network server [FR-312](#)
 - (example) [FR-314](#)
 - system software, configuration register [FR-325, FR-327](#)
 - BOOTLDR environment variable, specifying [FR-316](#)
 - boot network command [FR-240](#)
 - boot registers [FR-325, FR-327](#)
 - bootstrap image
 - backing up on a server [FR-188](#)
 - secondary [FR-318](#)
 - boot system command [FR-320](#)
 - Break key [FR-323](#)
 - buckets-of-history-kept command [FR-806](#)
 - buffer-length command [FR-56](#)
 - buffers
 - command history
 - line, configuring for a [FR-17, FR-19](#)
 - session, changing for a [FR-40, FR-42](#)
 - interface buffer pool tuning [FR-383](#)
 - management parameters [FR-382, FR-384](#)
 - public buffer pool tuning [FR-383](#)
 - size, setting [FR-382, FR-384](#)
 - statistics, displaying [FR-458](#)
 - buffers command [FR-382](#)
 - buffers huge size command [FR-384](#)
-
- ## C
-
- calendar set command [FR-385](#)
 - Call Tracker, MIB notifications [FR-697](#)
 - carriage return (<cr>) [xv](#)
 - ASCII value [FR-919](#)
 - cautions, usage in text [x](#)
 - cd command [FR-181](#)
 - CDP (Cisco Discovery Protocol)
 - global information, displaying [FR-755](#)
 - interface status information, displaying [FR-759](#)
 - neighbor
 - device, displaying information [FR-757](#)
 - information, displaying [FR-761](#)
 - table, clearing [FR-754](#)
 - routing device
 - disabling [FR-749](#)
 - enabling [FR-749](#)
 - traffic counters, clearing [FR-753](#)
 - traffic information, displaying [FR-764](#)
 - transmission hold time, configuring [FR-746](#)
 - transmission timer, setting [FR-751](#)

- Version-2, enabling [FR-744](#)
- cdp advertise-v2 command [FR-744](#)
- cdp enable command [FR-745](#)
- cdp holdtime command [FR-746](#)
- cdp log mismatch duplex command [FR-747](#)
- cdp run command [FR-749](#)
- cdp timer command [FR-751](#)
- character data bits
 - line, setting for a [FR-58](#)
 - session, changing for a [FR-89](#)
- character padding
 - line, configuring for a [FR-78](#)
 - session, changing for a [FR-102](#)
- character set
 - 7-bit
 - See* 7-bit character set
 - 8-bit
 - See* 8-bit character set
- character width
 - EXEC process
 - default, defining the [FR-59](#)
 - line, configuring for a [FR-69](#)
 - session, changing for a [FR-94](#)
 - special characters
 - default, defining the [FR-60](#)
 - line, configuring for a [FR-84](#)
 - session, changing for a [FR-106](#)
- checksums
 - system images, verifying [FR-188](#)
- Cisco AAA Server MIB, notifications [FR-691](#)
- Cisco IOS configuration changes, saving [xviii](#)
- Cisco Repeater MIB notifications [FR-708](#)
- clear cdp counters command [FR-753](#)
- clear cdp table command [FR-754](#)
- clear ip wccp command [FR-896](#)
- clear logging command [FR-484](#)
- clear parser cache command [FR-243](#)
- clear tcp command [FR-134](#)
- CLI (command line interface), privilege levels [FR-8](#)
- CLI prompts
 - customizing [FR-444](#)
- clock calendar-valid command [FR-386](#)
- clock read-calendar command [FR-387](#)
- clock set command [FR-388](#)
- clock summer-time command [FR-389](#)
- clock timezone command [FR-391](#)
- clock update-calendar command [FR-395](#)
- command alias
 - See* aliases
- command history
 - buffer size
 - line, configuring for a [FR-17, FR-19](#)
 - session, changing for a [FR-40, FR-42](#)
- commands
 - displaying previous [FR-33](#)
 - recalling [FR-33](#)
- command modes
 - exiting [FR-11, FR-12](#)
 - global configuration [FR-244](#)
 - privileged EXEC [FR-8](#)
- command modes, understanding [xiii to xiv](#)
- commands
 - context-sensitive help for abbreviating [xiv, FR-3](#)
 - default form, using [xvii](#)
 - history
 - See* command history
 - mapping old to new (table) [FR-232, FR-268](#)
 - no form, using [xvii](#)
- command syntax
 - conventions [ix](#)
 - displaying (example) [xv](#)
 - help [FR-15](#)
- community string
 - SNMP, setting [FR-682](#)
- compressed system images [FR-323](#)
- CONFIG_FILE environment variable, specifying [FR-235](#)
- config-register command [FR-325](#)
- configuration files

- active, displaying [FR-261](#)
- compressing [FR-249](#)
- CONFIG_FILE environment variable, storing in [FR-189](#)
- host
 - default filename [FR-251](#)
 - loading from a server [FR-251](#)
- loading from a server [FR-237](#)
- load time, displaying [FR-258](#)
- network
 - default filename [FR-251](#)
 - loading from a server [FR-251](#)
- network server, storing on [FR-189](#)
- NVRAM
 - displaying file [FR-211](#)
 - storing in [FR-189](#)
- rcp, copying using [FR-186, FR-187, FR-238, FR-241](#)
- reloading at boot time [FR-237, FR-240](#)
- running, backing up on the server [FR-189](#)
- specifying boot file [FR-237](#)
- configuration modes, exiting [FR-10](#)
- configurations, saving [xviii](#)
- configuration sessions, ending [FR-10](#)
- configure command [FR-244](#)
- configure memory command [FR-245](#)
- configure network command [FR-182](#)
- configure overwrite-network command [FR-247](#)
- configure terminal command [FR-244](#)
- confreg command [FR-327](#)
- connections
 - full duplex, refusing [FR-113](#)
 - incoming, definition [FR-126](#)
 - naming [FR-158](#)
 - open, displaying [FR-121](#)
- consoles
 - debug messages, displaying [FR-100](#)
 - logging messages [FR-509](#)
- contact string, setting for SNMP [FR-684](#)
- continue command [FR-329](#)
- copy [FR-226](#)
- copy bootflash rcp command [FR-194](#)
- copy command [FR-183](#)
- copy erase flash command
 - See* erase flash command
- copy flash rcp command [FR-193](#)
- copy rcp flash command
 - (example) [FR-191](#)
- copy rcp running-config command [FR-194](#)
- copy rcp startup-config command [FR-194](#)
- copy running-config startup-config command [FR-183](#)
- copy startup-config running-config command [FR-183](#)
- copy tftp flash command
 - (example) [FR-191](#)
- copy verify bootflash command [FR-271](#)
- copy verify command
 - See* verify command
- copy verify flash command [FR-272](#)
 - See* verify command
- copy xmodem command [FR-273](#)
- copy ymodem command [FR-274](#)
- CPA (Channel Port Adapter)
 - microcode image
 - loading [FR-278](#)
 - reloading [FR-283](#)
- CSAA
 - See* SA Agent

D

- data bits
 - character, changing for a [FR-89](#)
 - session, setting for a [FR-58](#)
- databits command [FR-57](#)
- data-character-bits command [FR-58](#)
- data flow control, setting [FR-95](#)
- data-pattern command [FR-808](#)
- debug command output, displaying [FR-100](#)
- debug messages, displaying enabled [FR-561](#)

default-value exec-character-bits command [FR-59](#)
 default-value special-character-bits command [FR-60](#)
 delete command [FR-198](#)
 diag command [FR-485](#)
 dir command [FR-200](#)
 directory
 print working [FR-213](#)
 remove [FR-215](#)
 disable command [FR-4](#)
 disconnect character, setting [FR-61](#)
 disconnect-character command [FR-61](#)
 diskless boot, configuring [FR-351](#)
 dispatch-character command [FR-62](#)
 dispatch characters
 line, configuring for a [FR-62](#)
 packet transmission using a [FR-62, FR-65, FR-91](#)
 session, changing for a [FR-90](#)
 dispatch-machine command [FR-64](#)
 dispatch-timeout command [FR-65](#)
 distributions-of-statistics-kept command [FR-809](#)
 DNS (Domain Name System)
 rcp, enabling on [FR-352](#)
 rsh, enabling on [FR-352](#)
 documentation
 conventions [ix](#)
 feedback, providing [xi](#)
 modules [v to vii](#)
 online, accessing [x](#)
 ordering [xi](#)
 Documentation CD-ROM [x](#)
 documents and resources, supporting [viii](#)
 downward-compatible-config command [FR-396](#)
 Dual RSPs
 reload slave RSP card [FR-931](#)
 slave image
 reloading [FR-931](#)
 specifying [FR-930](#)
 synchronizing configurations manually [FR-932](#)

E

editing command [FR-5](#)
 editors
 enhanced mode
 disabling for a line [FR-5](#)
 disabling for session [FR-37](#)
 enabling for a line [FR-5](#)
 enabling for session [FR-37](#)
 enable command [FR-8](#)
 enable password command [FR-8](#)
 end command [FR-10](#)
 end-of-line characters, changing [FR-116](#)
 enhanced editing mode
 See editors, enhanced mode
 environmental conditions
 at last shutdown [FR-587](#)
 table of measurements within specification [FR-590](#)
 temperature and voltage [FR-587](#)
 environment variables
 BOOT, specifying [FR-320](#)
 BOOTLDR, specifying [FR-316](#)
 CONFIG_FILE, specifying [FR-235](#)
 erase bootflash command
 See erase command
 erase command [FR-202](#)
 erase flash command [FR-275](#)
 erase start-up config command
 See erase command
 error messages
 logging priorities (table) [FR-508, FR-519, FR-528, FR-604](#)
 redirecting [FR-521](#)
 escape-character command [FR-67](#)
 escape characters
 line, defining the [FR-67](#)
 session, changing for a [FR-93](#)
 Event MIB, monitoring [FR-669](#)
 exception core-file command [FR-489](#)
 exception dump command [FR-491](#)

exception linecard command [FR-493](#)
 exception memory command [FR-495](#)
 exception protocol command [FR-497](#)
 exception region-size [FR-499](#)
 exception spurious-interrupt command [FR-501](#)

EXEC

mode, default aliases [FR-378](#)
 process
 delaying startup of [FR-449](#)
 disabling on a line [FR-136](#)
 displaying messages upon creation [FR-124](#)
 enabling on a line [FR-136](#)
 timeout interval, setting for the [FR-139](#)
 exec-banner command [FR-124, FR-128](#)
 exec-character-bits command [FR-69](#)
 exec command [FR-136](#)
 exec-timeout command [FR-139](#)
 execute-on command [FR-501, FR-503](#)
 exit command [FR-11, FR-12](#)

F

Feature Navigator

See platforms, supported

file compression [FR-249](#)
 file prompt command [FR-205](#)
 files
 contents, displaying [FR-211](#)
 download mode [FR-92](#)
 file systems
 default, setting [FR-181](#)
 erase [FR-202](#)
 list [FR-200](#)
 filter-for-history command [FR-811](#)
 filtering output, show and more commands [xviii](#)
 Finger protocol, enabling [FR-399](#)
 Flash file system

 check and repair [FR-209](#)
 deleting files [FR-221](#)

format [FR-207](#)
 make directory [FR-210](#)
 recover deleted file [FR-224](#)
 remove directory [FR-215](#)
 rename file [FR-214](#)
 verifying files [FR-226](#)

Flash load helper, monitoring [FR-286](#)

Flash memory

 booting automatically [FR-320](#)
 devices, deleting a file [FR-198](#)
 formatting [FR-206](#)
 partitioning [FR-297](#)
 verifying checksum [FR-188, FR-226](#)

flow control

 end transmission [FR-111](#)
 session, changing for a [FR-95](#)
 start character [FR-109](#)
 stop character [FR-111](#)

format command [FR-206](#)

frequency (RTR) command [FR-813](#)

fsck command [FR-209](#)

full-help command [FR-13](#)

G

get command

See type http command

global configuration mode

 entering [FR-244](#)

global configuration mode,summary of [xiv](#)

H

hardware break signal [FR-112](#)

hardware flow control [FR-95](#)

hardware platforms

See platforms, supported

help, user-level commands [FR-13](#)

help command [xiv](#), [FR-15](#)
 history command [FR-17](#)
 history size command [FR-19](#)
 hold character
 line, configuring for a [FR-71](#)
 session, changing for a [FR-96](#)
 hold-character command [FR-71](#)
 hops-of-statistics-kept command [FR-814](#)
 host configuration files
 copying from a server using rcp [FR-188](#)
 (example) [FR-194](#)
 default filename [FR-251](#)
 loading from a server [FR-237](#), [FR-251](#)
 hostname command [FR-397](#)
 host names, router [FR-397](#)
 hours-of-statistics-kept command [FR-817](#)
 HTTP Raw configuration submode [FR-885](#)
 http-raw-request command [FR-816](#)

idle-terminal message, enabling [FR-164](#)
 incoming connections, definition [FR-126](#)
 indexes, master [viii](#)
 informs, enabling [FR-687](#)
 insecure command [FR-72](#)
 interface configuration mode, summary of [xiv](#)
 international character sets
 supporting [FR-106](#)
 See also 8-bit character set
 international command [FR-168](#)
 invalidated system images [FR-304](#)
 IP
 access lists, time-based [FR-376](#), [FR-440](#)
 routing, interface status [FR-676](#)
 ip bootp server command [FR-398](#)
 ip finger command [FR-399](#)
 ip ftp passive command [FR-346](#)
 ip ftp password command [FR-347](#)

ip ftp source-interface command [FR-348](#)
 ip ftp username command [FR-349](#)
 ip http access-class command [FR-169](#)
 ip http authentication command [FR-170](#)
 ip http port command [FR-172](#)
 ip http server command [FR-173](#)
 ip rarp-server command [FR-350](#)
 ip rcmd domain-lookup command [FR-352](#)
 ip rcmd rcp-enable command [FR-354](#), [FR-360](#)
 ip rcmd remote-host command [FR-355](#)
 ip rcmd remote-username command [FR-358](#)
 ip rcmd rsh-enable command [FR-360](#)
 ip rcmd source-interface command [FR-361](#)
 ip telnet source-interface command [FR-401](#)
 ip tftp source-interface command [FR-402](#)
 ip wccp command [FR-897](#)
 ip wccp enable command
 See the ip wccp command
 ip wccp group-address command [FR-897](#)
 ip wccp group-list command [FR-897](#)
 ip wccp group-listen command [FR-901](#)
 ip wccp password command [FR-897](#), [FR-899](#)
 ip wccp redirect command [FR-905](#)
 ip wccp redirect exclude in command [FR-903](#)
 ip wccp redirect-list command [FR-897](#)
 ip wccp service redirect command [FR-905](#)
 ip wccp version command [FR-907](#)
 ip wccp web-cache redirect command [FR-905](#)
 ip web-cache redirect command [FR-908](#)
 IPX (Internet Packet Exchange)
 access lists, time ranges [FR-478](#)

K

keepalive packets, generating [FR-537](#), [FR-538](#)
 keymaps, specifying for session [FR-98](#)

L

length command [FR-73](#)

line cards, executing specific show commands on [FR-482](#)

lines

- messages, sending [FR-160](#)

line speeds

- receive speed, changing session [FR-105](#)
- transmit and receive speed, changing session [FR-108](#)
- transmit speed, changing session [FR-118](#)

link traps, disabling [FR-741](#)

linkUp/linkDown traps [FR-733](#)

lives-of-history-kept command [FR-818](#)

load-interval command [FR-403](#)

load statistics interval [FR-403](#)

location command [FR-74](#)

location string, setting [FR-724](#)

lockable command [FR-75](#)

lock command [FR-140](#)

logging buffer, clearing [FR-484](#)

logging buffered command [FR-507](#)

logging command [FR-506](#)

logging console command [FR-509](#)

logging facility command [FR-511](#)

- facility-type keywords (table) [FR-511](#)

logging history command [FR-513](#)

logging history size command [FR-516](#)

logging linecard command [FR-517](#)

logging messages

- See* message logging

logging monitor command [FR-519](#)

logging on command [FR-521](#)

logging rate-limit command [FR-523](#)

logging source-interface command [FR-525](#)

logging synchronous command [FR-526](#)

logging trap command [FR-528](#)

logout, warning users of impending [FR-76](#)

logout command [FR-20](#)

logout-warning command [FR-76](#)

LPD (line printer daemon), configuring [FR-80](#)

lsr-path command [FR-820](#)

M

MAC addresses

- mapping to IP address [FR-350](#)

manual booting

- from Flash [FR-312](#)
- from ROM [FR-312](#)

memory scan command [FR-294](#)

memory-size iomem command [FR-295](#)

menu (EXEC) command [FR-21](#)

menu clear-screen command [FR-142](#)

menu command [FR-143](#)

- resume [FR-144](#)

menu default command [FR-145](#)

menu line-mode command [FR-146](#)

menu options command [FR-147](#)

menu prompt command [FR-148](#)

menu single-space command [FR-149](#)

menu status-line command [FR-150](#)

menu text command [FR-151](#)

menu title command [FR-153](#)

message logging

- console [FR-509](#)
- enabling [FR-521](#)
- history table size [FR-516](#)
- monitor [FR-519](#)
- syslog SNMP traps [FR-513](#)
- UNIX syslog server [FR-506](#)

message queue length, SNMP [FR-729](#)

messages

- buffering [FR-507](#)
- busy [FR-159](#)
- debug, displaying [FR-100](#)
- line activation, displaying [FR-124](#)
- line-in-use [FR-159](#)
- sending to other terminals [FR-160](#)

system error, redirecting [FR-521](#)
 vacant terminal [FR-164](#)
See also banners
MIB
 Cisco Round-Trip Time Monitor [FR-826](#)
 RMON [FR-768, FR-778](#)
 MIB, descriptions online [viii](#)
 microcode
 loading Cisco IOS image [FR-280](#)
 loading from Flash memory [FR-276](#)
 reloading [FR-284](#)
 microcode (12000) command [FR-280](#)
 microcode (7000/7500) command [FR-276](#)
 microcode (7200) command [FR-278](#)
 microcode reload (12000) command [FR-284](#)
 microcode reload (7000/7500) command [FR-282](#)
 microcode reload (7200) command [FR-283](#)
 mkdir command [FR-210](#)
 modes
 See command modes
 monitors, message logging to [FR-519](#)
 MOP (Maintenance Operation Protocol)
 server
 booting automatically [FR-320](#)
 forwarding boot requests [FR-364](#)
 mop device-code command [FR-363](#)
 mop retransmit-timer command [FR-364](#)
 more begin command [FR-23](#)
 more command [FR-211](#)
 more exclude command [FR-25](#)
 more flh:logfile command [FR-286](#)
 more include command [FR-27](#)
 more system
 running-config command [FR-262, FR-266](#)
 MOTD (message-of-the-day) banner, configuring [FR-130](#)
 motd-banner command [FR-156](#)

N

name-connection command [FR-158](#)
 network configuration files [FR-237, FR-240](#)
 copying from a server using rcp [FR-188](#)
 (example) [FR-194](#)
 default filename [FR-251](#)
 changing [FR-240](#)
 loading from a server [FR-251](#)
 network services, tailoring use of [FR-537, FR-538](#)
 no menu command [FR-155](#)
 nonvolatile RAM file compression [FR-249](#)
 no snmp-server command [FR-668](#)
 notes, usage in text [x](#)
 ntp access-group command [FR-405](#)
 ntp authenticate command [FR-407](#)
 ntp authentication-key command [FR-409](#)
 ntp broadcast client command [FR-411](#)
 ntp broadcast command [FR-413](#)
 ntp broadcastdelay command [FR-415](#)
 ntp clock-period command [FR-417](#)
 ntp disable command [FR-419](#)
 ntp master command [FR-420](#)
 ntp multicast client command [FR-424](#)
 ntp multicast command [FR-426](#)
 ntp peer command [FR-428](#)
 ntp refclock command [FR-430](#)
 ntp server command [FR-432](#)
 ntp source command [FR-434](#)
 ntp trusted-key command [FR-436](#)
 ntp update-calendar command [FR-438](#)
 null bytes, end of string [FR-78, FR-102](#)
 NVRAM file compression [FR-249](#)

O

operating system, reloading [FR-330](#)
 output notifications
 line, setting for a [FR-77](#)

session, configuring for a [FR-101](#)
 owner command [FR-821](#)

P

packet dispatch characters
 line, setting [FR-62](#)
 session, changing [FR-90](#)
 packets
 maximum size, establishing [FR-728](#)
 SNMP, filtering [FR-728](#)
 padding
 line, configuring for a [FR-78](#)
 session, changing for a [FR-102](#)
 padding command [FR-78](#)
 parity
 line, setting for a [FR-79](#)
 session, changing for a [FR-103](#)
 parity command [FR-79](#)
 parser cache command [FR-248](#)
 partition command [FR-297](#)
 partition flash command [FR-297](#)
 paths-of-statistics-kept command [FR-822](#)
 period (.) character, ping command output [FR-532](#)
 periodic command [FR-440](#)
 ping (privileged) command [FR-530](#)
 ping (user) command [FR-534](#)
 ping command
 test characters (table) [FR-531, FR-534](#)
 test connectivity [FR-530, FR-534](#)
 platforms, supported
 Feature Navigator, identify using [xix](#)
 release notes, identify using [xix](#)
 port queue, retry interval [FR-104](#)
 printer command [FR-80](#)
 private command [FR-82](#)
 privileged EXEC command mode
 entering [FR-8](#)
 summary of [xiv](#)

privilege level command [FR-8](#)
 privilege levels [FR-8](#)
 probes
 See also SA Agent operation
 process-max-time command [FR-443](#)
 prompt command [FR-440, FR-444](#)
 prompts
 customizing [FR-444](#)
 system [xiv](#)
 pwd command [FR-213](#)

Q

question mark (?) command [xiv](#)
 queues
 length, SNMP trap queues [FR-729](#)

R

RARP (Reverse Address Resolution Protocol)
 router, configuring as server [FR-350](#)
 rcp (remote copy protocol)
 configuring [FR-355, FR-359](#)
 copying files [FR-354](#)
 DNS, enabling security [FR-352](#)
 remote username [FR-323](#)
 refuse-message command [FR-159](#)
 release notes
 See platforms, supported
 reload command [FR-330](#)
 remote shell
 See rsh server
 remote username, rcp requests
 default values [FR-323](#)
 overriding default value [FR-323](#)
 rename command [FR-214](#)
 request-data-size command [FR-824](#)
 response-data-size command [FR-825](#)

resume command [FR-144](#)
 retry interval, terminal port queue [FR-104](#)
 RFC
 full text, obtaining [viii](#)
 RFC 742, Finger protocol [FR-399](#)
 RFC 865, Quote of the Day servers [FR-344](#)
 RFC 868, time servers [FR-344](#)
 RFC 887, RLP servers [FR-345](#)
 RFC 903, RARP [FR-351](#)
 RFC 950, subnet masks [FR-344](#)
 RFC 1034, domain name servers [FR-344](#)
 RFC 1035, domain names [FR-397](#)
 RFC 1084, BOOTP requests for asynchronous interfaces [FR-344](#)
 RFC 1178, choosing a name for your computer [FR-397](#)
 RFC 1447, predefined SNMP views [FR-739](#)
 RFC 1757, RMON alarm group [FR-771](#)
 RFC 1757, RMON MIB [FR-768](#), [FR-778](#)
 rmdir command [FR-215](#)
 RMON (Remote Monitoring)
 agent status, displaying [FR-781](#)
 alarms, enabling [FR-770](#)
 enabling [FR-780](#)
 event table [FR-778](#)
 interface, enabling [FR-768](#)
 rmon alarm command [FR-770](#)
 rmon capture-userdata command [FR-772](#)
 rmon collection history command [FR-773](#)
 rmon collection host command [FR-775](#)
 rmon collection matrix command [FR-776](#)
 rmon collection rmon1 [FR-777](#)
 rmon command [FR-768](#)
 rmon event command [FR-778](#)
 rmon queuesize command [FR-780](#)
 ROM, booting automatically [FR-320](#)
 ROM monitor mode, summary of [xiv](#)
 rotary groups, in-use message [FR-164](#)
 router, host name [FR-397](#)
 rsh command [FR-366](#)

rsh server
 (example) [FR-366](#)
 access, granting [FR-355](#)
 commands, executing [FR-360](#), [FR-366](#)
 DNS, enabling security [FR-352](#)
 RTR (Response Time Reporter)
 See SA Agent (Service Assurance Agent)
 rtr command [FR-826](#)
 rtr configuration mode, entering [FR-826](#)
 rtr key-chain command [FR-829](#)
 rtr low memory command [FR-830](#)
 rtr reaction-configuration command [FR-831](#)
 rtr reaction-trigger command [FR-834](#)
 rtr reset command [FR-835](#)
 rtr responder command [FR-836](#)
 rtr schedule command [FR-839](#)
 running configuration file, copying to the server
 (example) [FR-195](#)

S

SA (Service Assurance) Agent
 history statistics, displaying [FR-858](#)
 SA Agent (Service Assurance Agent)
 application information, displaying [FR-844](#)
 authentication information, displaying [FR-846](#)
 configuration information, displaying [FR-853](#)
 configuring [FR-826](#)
 history
 collection [FR-806](#)
 filters [FR-811](#)
 lives kept [FR-818](#)
 samples kept [FR-842](#)
 operations
 setting frequency of [FR-813](#)
 operations, configuring [FR-875 to FR-892](#)
 probe
 owner [FR-821](#)
 scheduling [FR-840](#)

- reaction trigger
 - configuring [FR-833, FR-834](#)
 - displaying [FR-865](#)
- request data size [FR-824](#)
- resetting [FR-835](#)
- responder information, displaying [FR-866](#)
- response data size [FR-825](#)
- statistics
 - displaying [FR-856, FR-869](#)
 - hops kept [FR-814](#)
 - paths kept [FR-822](#)
- statistics, setting hours kept [FR-817](#)
- tags [FR-871](#)
- threshold [FR-872](#)
- timeout [FR-873](#)
- verify data [FR-893](#)
- samples-of-history-kept command [FR-842](#)
- scheduler allocate command [FR-446](#)
- scheduler-interval command [FR-447](#)
- screen
 - length
 - line, setting for a [FR-73](#)
 - session, changing for a [FR-99](#)
 - output, pausing [FR-71](#)
 - width
 - line, setting for a [FR-122](#)
 - session, changing for a [FR-120](#)
- security levels
 - See* privilege levels
- send command [FR-160](#)
- serial device
 - location, setting [FR-74](#)
- service compress-config command [FR-249](#)
- service config command [FR-251](#)
- service decimal-tty command [FR-448](#)
- service exec-wait command [FR-449](#)
- service finger command [FR-450](#)
- service hide-telnet-address command [FR-451](#)
- service linenummer command [FR-162](#)
- service nagle command [FR-452](#)
- service prompt config command [FR-453](#)
- service single-slot-reload-enable command [FR-926](#)
- service slave-log command [FR-536](#)
- service tcp-keepalives-in command [FR-537](#)
- service tcp-keepalives-out command [FR-538](#)
- service tcp-small-servers command [FR-454](#)
- service telnet-zero-idle command [FR-455](#)
- service udp-small-servers command [FR-456](#)
- setup command [FR-46](#)
- setup command facility
 - asynchronous interfaces
 - configuration (examples) [FR-48 to FR-49](#)
 - default client IP address (examples) [FR-48 to FR-49](#)
 - configuration (example) [FR-47 to FR-52](#)
 - configuration command script (example) [FR-49](#)
 - configuration file, saving [FR-52](#)
 - global parameters configuration (example) [FR-47 to FR-48](#)
 - interface parameters configuration (example) [FR-48 to FR-52](#)
 - interface summary, viewing [FR-47](#)
 - sample configuration [FR-47 to FR-52](#)
- System Configuration Dialog
 - (example) [FR-47](#)
 - returning to privileged EXEC prompt [FR-47](#)
 - terminating the configuration [FR-47](#)
- show (Flash file system) command [FR-299](#)
- show aliases command [FR-457](#)
- show async-bootp command [FR-368](#)
- show begin command [FR-29](#)
- show boot command [FR-332](#)
- show bootflash command [FR-300](#)
- show bootvar command [FR-333](#)
- show buffers command [FR-382](#)
- show c2600 command [FR-541](#)
- show c7200 command [FR-544](#)
- show calendar command [FR-462](#)
- show cdp command [FR-755](#)

show cdp entry command [FR-757](#)
show cdp interface command [FR-759](#)
show cdp neighbors command [FR-761](#)
show cdp traffic command [FR-764](#)
show clock command [FR-463](#)
show cls [FR-545](#)
show configuration command [FR-216](#), [FR-253](#)
show context command [FR-549](#)
show context command (2600) [FR-547](#)
show controllers (GRP image) command [FR-551](#)
show controllers (line card image) command [FR-553](#)
show controllers logging command [FR-558](#)
show controllers tech-support command [FR-559](#)
show debugging command [FR-561](#)
show derived-config command [FR-254](#)
show diag command [FR-562](#)
show disk command [FR-580](#), [FR-583](#)
show environment command [FR-586](#)
show exclude command [FR-31](#)
show file command [FR-257](#)
show file descriptors command [FR-217](#)
show file information command [FR-218](#)
show file systems command [FR-219](#)
show flash chips command [FR-299](#)
show flash command [FR-299](#)
show flash fileys command [FR-299](#)
show flash summary command [FR-306](#)
show flh-log command [FR-288](#)
show gsr command [FR-600](#)
show gt64010 command [FR-601](#)
show history command [FR-33](#)
show idb command [FR-465](#)
show include command [FR-35](#)
show ip wccp command [FR-909](#)
show ip wccp detail command [FR-909](#)
show ip wccp view command [FR-909](#)
show ip wccp web-caches command [FR-915](#)
show logging command [FR-507](#), [FR-509](#), [FR-528](#), [FR-603](#)
show logging history command [FR-606](#)
show management event command [FR-669](#)
show memory command [FR-608](#)
show memory ecc [FR-612](#)
show memory fast command [FR-614](#)
show microcode command [FR-289](#)
show ntp associations command [FR-466](#)
show ntp status command [FR-469](#)
show parser statistics command [FR-258](#)
show pci command [FR-619](#)
show pci hardware command [FR-621](#)
show processes command [FR-623](#)
show processes cpu command [FR-626](#)
show processes memory command [FR-629](#)
show protocols command [FR-631](#)
show registry command [FR-471](#)
show reload command [FR-335](#)
show rmon alarms command [FR-783](#)
show rmon capture command [FR-785](#)
show rmon command [FR-781](#)
show rmon events command [FR-788](#)
show rmon filter command [FR-790](#)
show rmon history command [FR-792](#)
show rmon hosts command [FR-795](#)
show rmon matrix command [FR-797](#)
show rmon statistics command [FR-799](#)
show rmon topn command [FR-802](#)
show rtr application command [FR-844](#)
show rtr authentication command [FR-846](#)
show rtr collection-statistics command [FR-847](#)
show rtr configuration command [FR-853](#)
show rtr distribution-statistics command [FR-856](#)
show rtr history command [FR-858](#)
show rtr operational-state command [FR-860](#)
show rtr reaction-trigger command [FR-865](#)
show rtr responder command [FR-866](#)
show rtr totals-statistics command [FR-867](#)
show running-config command [FR-261](#)
show running-config map-class command [FR-264](#)
show slot command [FR-632](#), [FR-635](#), [FR-637](#)

- show snmp command [FR-671](#)
- show snmp engineID command [FR-674](#)
- show snmp group command [FR-675](#)
- show snmp pending command [FR-676](#)
- show snmp sessions command [FR-677](#)
- show snmp user command [FR-679](#)
- show snmp command [FR-472](#)
- show stacks command [FR-640](#)
- show startup-config command [FR-266](#)
- show subsys command [FR-642](#)
- show tcp brief command [FR-649](#)
- show tcp command [FR-644](#)
- show tdm connections command [FR-650](#)
- show tdm connections motherboard command
 - channel output, interpreting [FR-650](#)
- show tdm data command [FR-651](#)
- show tech-support command [FR-652](#)
- show version command [FR-336](#)
- show whoami command [FR-83](#)
- shutdown
 - SNMP, enabling with [FR-730](#)
- slave auto-sync config command [FR-927](#)
- slave default-slot command [FR-929](#)
- slave image command [FR-930](#)
- slave reload command [FR-931](#)
- slave sync config command [FR-932](#)
- slave terminal command [FR-933](#)
- SNMP (Simple Network Management Protocol)
 - community access string, setting [FR-682](#)
 - configuration parameters, displaying [FR-603](#)
 - informs, enabling [FR-687](#)
 - packet filtering [FR-728](#)
 - system contact, setting [FR-684](#)
 - system location, setting [FR-724](#)
 - system shutdown, enabling [FR-668, FR-730](#)
 - trap message
 - source, setting [FR-735](#)
 - timeout [FR-736](#)
 - traps, enabling [FR-687](#)
 - versions, disabling all [FR-668](#)
- SNMP server
 - system location, setting [FR-717](#)
 - trap operation
 - recipient [FR-717](#)
- snmp-server access-policy command [FR-680](#)
- snmp-server chassis-id command [FR-681](#)
- snmp-server community command [FR-682](#)
- snmp-server contact command [FR-684](#)
- snmp-server context command [FR-685](#)
- snmp-server enable informs command [FR-686](#)
- snmp-server enable traps aaa_server command [FR-691](#)
- snmp-server enable traps atm command [FR-693](#)
- snmp-server enable traps bgp command [FR-695](#)
- snmp-server enable traps calltracker command [FR-697](#)
- snmp-server enable traps command [FR-687](#)
- snmp-server enable traps envmon command [FR-699](#)
- snmp-server enable traps frame-relay command [FR-701](#)
- snmp-server enable traps isdn command [FR-703](#)
- snmp-server enable traps repeater command [FR-708](#)
- snmp-server enable traps snmp command [FR-705](#)
- snmp-server enable traps voice poor-qov
 - command [FR-710](#)
- snmp-server engineID command [FR-712](#)
- snmp-server group command [FR-714](#)
- snmp-server host command [FR-717](#)
- snmp-server informs command [FR-722](#)
- snmp-server location command [FR-724](#)
- snmp-server manager command [FR-725](#)
- snmp-server manager session-timeout command [FR-726](#)
- snmp-server packet-size command [FR-728](#)
- snmp-server queue-length command [FR-729](#)
- snmp-server system-shutdown command [FR-730](#)
- snmp-server tftp-server-list command [FR-731](#)
- snmp-server trap-authentication command [FR-732](#)
- snmp-server trap link command [FR-733](#)
- snmp-server trap-source command [FR-735](#)
- snmp-server trap-timeout command [FR-736](#)
- snmp-server user command [FR-737](#)

- snmp-server view command [FR-739](#)
 - snmp trap link-status command [FR-741](#)
 - sntp broadcast client command [FR-474](#)
 - sntp server command [FR-476](#)
 - software configuration boot register [FR-325, FR-327](#)
 - software flow control
 - session, changing for a [FR-95](#)
 - start character, changing the [FR-109](#)
 - special-character-bits command [FR-84](#)
 - special characters
 - activation character [FR-54, FR-545](#)
 - character width
 - default, defining the [FR-60](#)
 - line, configuring for a [FR-84](#)
 - session, changing for a [FR-106](#)
 - disconnect character [FR-61](#)
 - dispatch character, setting for line [FR-62](#)
 - escape character
 - line, configuring for a [FR-67](#)
 - session, changing for a [FR-93](#)
 - hold character
 - line, configuring for a [FR-71](#)
 - session, changing for a [FR-96](#)
 - session, changing for a [FR-90](#)
 - speeds
 - See* line speeds
 - squeeze command [FR-221](#)
 - start characters
 - flow control, changing [FR-109](#)
 - session, changing for a [FR-109](#)
 - startup configuration file [FR-195](#)
 - state-machine command [FR-85](#)
 - statistics-distribution-interval command [FR-869](#)
 - stop bits
 - line, configuring for a [FR-87](#)
 - session, changing for a [FR-110](#)
 - stopbits command [FR-87](#)
 - stop characters
 - flow control, changing [FR-111](#)
 - session, changing for a [FR-111](#)
 - strings
 - system contact, setting [FR-684](#)
 - system location, setting [FR-717, FR-724](#)
 - Symmetricon GPS device, enabling [FR-430](#)
 - system buffers
 - See* buffers
 - System Configuration Dialog [FR-46](#)
 - system contact string, setting [FR-684](#)
 - system error messages, redirecting [FR-521](#)
 - system image file
 - copying from server to Flash (example) [FR-191](#)
 - system images
 - checksum, verifying [FR-226](#)
 - compressing [FR-323](#)
 - copying from a server using rcp [FR-323](#)
 - copying using Xmodem [FR-291](#)
 - copying using Ymodem [FR-291](#)
 - default filename [FR-322](#)
 - invalidated [FR-304](#)
 - system location string, setting [FR-724](#)
 - system shutdown, enabling using SNMP [FR-668, FR-730](#)
 - system software
 - booting [FR-320, FR-322](#)
 - displaying version of [FR-336](#)
-
- ## T
- Tab key, command completion [xiv](#)
 - tag command [FR-871](#)
 - TCP
 - connections, clearing [FR-134](#)
 - keepalive protocol, activating [FR-538](#)
 - packet dispatch state machine [FR-64](#)
 - technical support information
 - displaying [FR-652](#)
 - Telnet
 - addresses, suppressing [FR-451](#)
 - end-of-line characters, changing [FR-116](#)

- Remote Echo option [FR-113](#)
- Suppress Go Ahead option [FR-113](#)
- terminal databits command [FR-88](#)
- terminal data-character-bits command [FR-89](#)
- terminal dispatch-character command [FR-90](#)
- terminal dispatch-timeout command [FR-91](#)
- terminal download command [FR-92](#)
- terminal editing command [FR-37](#)
- terminal escape-character command [FR-93](#)
- terminal exec-character-bits command [FR-94](#)
- terminal flowcontrol command [FR-95](#)
- terminal full-help command [FR-38](#)
- terminal history command [FR-40](#)
- terminal hold-character command [FR-96](#)
- terminal international command [FR-175](#)
- terminal keymap-type command [FR-98](#)
- terminal length command [FR-99](#)
- terminal monitor command [FR-100](#)
- terminal notify command [FR-101](#)
- terminal padding command [FR-102](#)
- terminal parity command [FR-103](#)
- terminal port queue, retry interval [FR-104](#)
- terminal-queue command [FR-104](#)
- terminal rxspeed command [FR-105, FR-118](#)
- terminals
 - activation character, setting [FR-54, FR-545](#)
 - character padding
 - line, configuring for a [FR-78](#)
 - debug messages, displaying [FR-100](#)
 - end-of-line character [FR-116](#)
 - escape character
 - line, defining for a [FR-67](#)
 - session, defining for a [FR-93](#)
 - file download mode [FR-92](#)
 - flow control [FR-95](#)
 - line speed [FR-108, FR-118](#)
 - line speed, changing [FR-108](#)
 - location, recording [FR-74](#)
 - lock access [FR-140](#)
 - locking [FR-75](#)
 - packet dispatch character [FR-90](#)
 - parity bit [FR-103](#)
 - pausing output to screen [FR-71](#)
 - port queue [FR-104](#)
 - receive speed [FR-105](#)
 - screen length
 - line, configuring for a [FR-73](#)
 - session, changing for a [FR-99](#)
 - screen width
 - line, configuring for a [FR-122](#)
 - session, changing for a [FR-120](#)
 - settings, saving [FR-82](#)
 - start character [FR-109](#)
 - stop character, changing [FR-111](#)
 - type
 - line connection, specifying for a [FR-119](#)
 - session, specifying for a [FR-117](#)
- terminal sessions, closing [FR-11, FR-12](#)
- terminal special-character-bits command [FR-106](#)
- terminal speed command [FR-108](#)
- terminal start-character command [FR-109](#)
- terminal stopbits command [FR-110](#)
- terminal stop-character command [FR-111](#)
- terminal telnet break-on-ip command [FR-112](#)
- terminal telnet refuse-negotiations command [FR-113](#)
- terminal telnet speed command [FR-114](#)
- terminal telnet sync-on-break command [FR-115](#)
- terminal telnet transparent command [FR-116](#)
- terminal terminal-type command [FR-117](#)
- terminal txspeed command [FR-118](#)
- terminal-type command [FR-119](#)
- terminal width command [FR-120](#)
- test flash command [FR-656](#)
- test interfaces command [FR-657](#)
- test memory command [FR-658](#)
- TFTP (Trivial File Transfer Protocol)
 - server
 - booting automatically [FR-320](#)

- router, configuring to function as [FR-369](#)
- tftp-server command [FR-369](#)
- tftp-server system command
 - See* tftp-server command
- threshold command [FR-872](#)
- timeout command [FR-873](#)
- timeout interval [FR-91](#)
 - EXEC process, setting for the [FR-139](#)
 - terminal character dispatch [FR-65](#)
 - trap message [FR-736](#)
- time-range command [FR-478](#)
- ToS (type of service)
 - SA Agent operations, defining for [FR-874](#)
- tos command [FR-874](#)
- trace
 - common problems [FR-663](#)
 - terminating [FR-663](#)
 - tracing IP routes [FR-664](#)
- trace (privileged) command [FR-659](#)
- trace (user) command [FR-663](#)
- trace command
 - common problems [FR-659](#)
 - extended test [FR-659](#)
 - IP routes [FR-660](#)
 - privileged, overview [FR-659](#)
 - terminating [FR-659](#)
 - user, overview [FR-663](#)
- traps
 - host, setting message queue length [FR-729](#)
 - message
 - establishing timeout [FR-736](#)
 - source interface [FR-735](#)
 - recipient, specifying [FR-717](#)
- traps, enabling [FR-687](#)
- Trimble GPS device, enabling [FR-430](#)
- type dhcp command [FR-875](#)
- type dlsw command [FR-877](#)
- type dns command [FR-879](#)
- type echo command [FR-880](#)

- type ftp command [FR-882](#)
- type http command [FR-884](#)
- type jitter command [FR-886](#)
- type pathEcho command [FR-888](#)
- type tcpConnect command [FR-889](#)
- type udpEcho command [FR-891](#)

U

- undelete command [FR-224](#)
- UNIX operating system
 - compress command [FR-323](#)
 - Syslog Serve, message logging to [FR-506](#)
 - uncompress command [FR-323](#)
- unrecognized command message
 - help command [FR-69](#)
- user EXEC mode, summary of [xiv](#)

V

- vacant-message command [FR-164](#)
- verify command [FR-226](#)
- verify-data command [FR-893](#)
- views, predefined as described in RFC 1447 [FR-739](#)

W

- where command [FR-121](#)
- width command [FR-122](#)
- word help, description [FR-15](#)
- write erase command
 - See* erase nvram command
- write memory command [FR-309](#)
- write network command [FR-310](#)
- write terminal command
 - See* show running-config command

X

xmodem command [FR-291](#)