

# Managing Connections, Menus, and System Banners

This chapter describes how to manage connections to other hosts, set banner messages for router users, and create menus of specific user tasks.

For a complete description of the connections, menu, and system banner commands in this chapter, refer to the "Connection, Menu, and System Banner Commands" chapter in the Release 12.2 *Cisco IOS Configuration Fundamentals Command Reference*. To locate documentation of other commands that appear in this chapter, use the *Cisco IOS Command Reference Master Index* or search online

To identify hardware or software image support for a specific feature, use Feature Navigator on Cisco.com to search for information about the feature or refer to the software release notes for a specific release. For more information, see the "Identifying Platform Support for Cisco IOS Software Features" section in the "About Cisco IOS Software Documentation" chapter.

# **Managing Connections, Menus, and System Banners Task List**

To manage connections, configure messages and banners, and create user menus, perform any of the tasks described in the following sections, as needed. All tasks in this chapter are optional.

- Managing Connections
- Configuring Terminal Messages
- Configuring Terminal Banners
- Creating Menus

Examples for these sections can be found at the end of the chapter in the "Connection Management, System Banner, and User Menu Configuration Examples" section.

# **Managing Connections**

To configure connection-management activities that apply to all supported connection protocols, perform the tasks described in the following sections. All tasks are optional.

- Displaying Current Terminal Characteristics
- Escaping Terminal Sessions and Switching to Other Connections
- Assigning a Logical Name to a Connection
- Changing a Login Name
- Locking Access to a Terminal
- Sending Messages to Other Terminals
- Clearing TCP Connections
- Exiting a Session Started from a Router
- Logging Out of a Router
- Disconnecting a Line

# **Displaying Current Terminal Characteristics**

To display the current settings for the terminal line connection, use the following command in EXEC mode:

Command	Purpose
Router# show terminal	Displays current settings for the terminal.

The following example shows sample output:

AccessServer1> show terminal

```
Line 2, Location: "", Type: "VT220"
Length: 24 lines, Width: 80 columns
Baud rate (TX/RX) is 9600/9600
Status: PSI Enabled, Ready, Active, No Exit Banner
Capabilities: none
Modem state: Ready
Group codes: 0
Special Chars: Escape Hold Stop Start Disconnect Activation
              ^^x none
                            _
                                  -
                                         none
Timeouts:
              Idle EXEC Idle Session Modem Answer Session Dispatch
              00:10:00
                            never
                                                        none
                                                                 not set
                          Idle Session Disconnect Warning
                            never
                           Login-sequence User Response
                           00:00:30
                          Autoselect Initial Wait
                            not set
Modem type is unknown.
Session limit is not set.
Time since activation: 00:01:07
Editing is enabled.
History is enabled, history size is 10.
DNS resolution in show commands is enabled
```

```
Full user help is disabled
Allowed transports are lat pad v120 mop telnet rlogin nasi. Preferred is lat.
No output characters are padded
No special data dispatching characters
```

### **Escaping Terminal Sessions and Switching to Other Connections**

After you have started a connection, you can escape out of the current terminal session by using the escape key sequence (Ctrl-Shift-6 then X by default). You can type the command character as you hold down the Ctrl key or with the Ctrl key released; you can type either uppercase or lowercase letters.

Note

In screen output examples that show two caret (^^) symbols together, the first caret represents the Control key (Ctrl) and the second caret represents the key sequence Shift-6. The double-caret combination (^^) means hold down the Ctrl key while you press the Shift and the 6 key.

By default, the escape key sequence is Ctrl-Shift-6, X. However, the escape key sequence can be changed using the **escape-character** line configuration command. To determine the current setting for the escape character, use the **show terminal** EXEC command.

You can have several concurrent sessions open and switch back and forth between them.

The number of sessions that can be open at one time is defined by the session-limit command.

To switch between sessions by escaping one session and resuming a previously opened session, perform the following steps:

- **Step 1** Escape out of the current session by pressing the escape key sequence (Ctrl-Shift-6 then X [Ctrl<sup>^</sup>, X] by default) and return to the EXEC prompt.
- **Step 2** Enter the where command to list the open sessions. All open sessions associated with the current terminal line are displayed.
- **Step 3** Enter the **resume** command and the session number to make the connection.

You also can resume the previous session by pressing the Return key.

The Ctrl<sup>^</sup>, X key combination and the **where** and **resume** EXEC commands are available with all supported connection protocols (for example, Telnet).

### Assigning a Logical Name to a Connection

To assign a logical name to a connection, use the following command in EXEC mode:

Command	Purpose
Router# name-connection	Assigns a logical name to a connection.

The logical name can be useful for keeping track of multiple connections.

You are prompted for the connection number and name to assign. The **where** EXEC command displays a list of the assigned logical connection names.

### **Changing a Login Name**

You can change your login username if you must match outgoing access list requirements or other login prompt requirements. A login server must be running and available to use this command. To change a login username, use the following command in user EXEC mode:

Command	Purpose
Router> login	Allows you to log in to the system a second time for the
	purposes of changing your login name.

When you enter this command, the system prompts you for a username and password. Enter the new username and the original password. If the username does not match, but the password does, the Cisco IOS software updates the session with the new username used by the **login** command attempt. For example, assume that a user logged in as user1 needs to change the login name to user2:

```
Router> login
Username: user2
Password: <letmein>
Router>
```

In this example, the password letmein is the same password used at the initial login. (The angle brackets in the example indicate that the password is not displayed on the screen when entered.) At the second Router> prompt, the user is now logged in as user2.

If no username and password prompts appear, the network administrator did not specify that a username and password be required at login time. If both the username and password are entered correctly, the session becomes associated with the specified username.

To access a system with Terminal Access Controller Access Control System (TACACS) security, enter your login name or specify a TACACS server by using the *user@tacacs-server* syntax when the "Username:" prompt appears, as shown in the following steps:

	Command	Purpose
Step 1	Router> login	Allows you to log in to the system a second time for the purposes of changing your login name.
Step 2	Username: user@tacacs-server	Specifies the new username and authenticates the name with the server specified with the <i>tacacs-server</i> argument.
Step 3	Password: <password></password>	Specifies the TACACS password for the username specified in Step 2.

Only the specified host (tacacs-server) is accessed for user authentication information.

In the following example, user2 specifies the TACACS host host1 to authenticate the password:

```
Router> login
Username: user2@host1
Translating "HOST1"...domain server (131.108.1.111) [OK]
Password: <letmein2>
```

If you do not specify a host, the router tries each of the TACACS servers in the list until it receives a response. If you specify a host that does not respond, no other TACACS server will be queried. The router either will deny access or function, according to the action specified by the **tacacs-server** 

**last-resort** global configuration command, if it is configured. If you specified a TACACS server host with the *user@tacacs-server* argument, the TACACS server specified is used for all subsequent authentication or notification queries, with the possible exception of Serial Line Internet Protocol (SLIP) address queries.

For more information on configuring TACACS, refer to the **tacacs-server host** global configuration command in the "TACACS, Extended TACACS, and TACACS+ Commands" chapter of the *Cisco IOS Security Command Reference*.

For an example of changing a login name, see the "Changing a Login Name Example" section at the end of this chapter.

### **Locking Access to a Terminal**

You can prevent access to your terminal session while keeping your connection open by setting a temporary password. For this temporary locking feature to work, the line must first be configured to allow locking (using the **lockable** line-configuration mode command). To lock access to the terminal, perform the following steps:

**Step 1** Issue the **lock** command in user or privileged EXEC mode.

When you issue this command, the system will prompt you for a password.

- **Step 2** Enter a password, which can be any arbitrary string. The system will prompt you to confirm the password. The screen then is cleared, and the message "Locked" is displayed.
- **Step 3** To regain access to your session, reenter the password.

Locked

The Cisco IOS software honors session timeouts on locked lines. You must clear the line to remove this feature.

The following is an example of the prompts displayed after the **lock** command is entered. Note that the entered password does not appear on screen.

Router# **lock** Password: Again: Password: Router#

### **Sending Messages to Other Terminals**

You can send messages to one or all terminal lines. A common reason for doing this is to inform users of an impending shutdown. To send a message to other terminals, use the following command in EXEC mode:

Command	Purpose
Router# <b>send</b> {line-number   *}	Sends a message to other terminals.

The system prompts for the message, which can be up to 500 characters long. Press **Ctrl-Z** to end the message. Press **Ctrl-C** to abort the command.

### **Clearing TCP Connections**

To clear a Transmission Control Protocol (TCP) connection, use the following command in privileged EXEC mode:

Command	Purpose	
Router# clear tcp {line line-number   local host-name port	Clears a TCP connection.	
<pre>remote host-name port   tcb tcb-address}</pre>		

The clear tcp command is particularly useful for clearing hung TCP connections.

The **clear tcp line** *line-number* command terminates the TCP connection on the specified tty line. All TCP sessions initiated from that tty line are also terminated.

The **clear tcp local** *host-name port* **remote** *host-name port* command terminates the specific TCP connection identified by the host name/port pair of the local and remote router.

# **Exiting a Session Started from a Router**

The protocol used to initiate a session determines how you exit that session.

To exit from SLIP and PPP connections, you must hang up the dial-in connection, usually with a command that your dial-in software supports.

To exit a local area transport (LAT), Telnet, rlogin, TN3270, or X.3 packet assembler/disassembler (PAD) session begun from the router to a remote device, press the escape key sequence (Ctrl-Shift-6 then X [Ctrl^X] by default for some systems, Ctrl-Z by default for other systems) and enter the **disconnect** command at the EXEC prompt. You can also log out of the remote system.

You can use either the exit or logout command in EXEC mode to terminate an active terminal session.

To exit a Telnet session to a router, see the "Logging Out of a Router" section, which follows.

### Logging Out of a Router

The method you use to disconnect from a router depends on where you are located in relation to the router, and the port on the router to which you log in.

If your terminal or computer running a terminal-emulation application is remotely connected to the console port of the router, you disconnect by issuing the command or key sequence used by your terminal-emulation package. For example, if you are on a Macintosh computer running the application TCP/Connect from InterCon Corporation, you would press Ctrl-] at the user or privileged EXEC prompt to disconnect.

If you are on a remote terminal and connect to a vty through a synchronous interface on the router, you can issue one of the following commands in EXEC mode to log out:

- exit
- logout

## **Disconnecting a Line**

Note

Avoid disconnecting a line to end a session. Instead, log out of the host to allow the router to clear the connection. You should disconnect a line only if you cannot log out of an active session (for example, if the line is stuck or frozen).

To disconnect a line, use the following command in EXEC mode:

Command	Purpose
Router# <b>disconnect</b> [connection]	Disconnects a line.

If your terminal or computer running a terminal-emulation application is connected physically to the console port of the router, you can also disconnect from the router by physically disconnecting the cable from the console port of the router.

# **Configuring Terminal Messages**

To configure messages that can be displayed to terminal users that connect to the system, perform any of the tasks found in the following sections. All tasks are optional.

- Configuring an Idle Terminal Message
- Configuring a "Line in Use" Message
- Configuring a "Host Failed" Message

### **Configuring an Idle Terminal Message**

You can configure the system to display a message when a console or terminal not in use. Also called a *vacant message*, this message is different from the banner message displayed when a user logs in to the system. To enable the idle terminal message, use the following command in line configuration mode:

Command	Purpose
Router(config-line) # <b>vacant-message</b> [ <i>d message d</i> ]	Configures the system to display an idle terminal message. The argument $d$ indicates any delimiting character.

<u>P</u> Tips

Commands requiring a delimiting character (the *d* argument) are used throughout this chapter. Any character can be used as the delimiting character, but we recommend the use of the quote sign ("), because this character is unlikely to be needed within the message itself. Other commonly used delimiting characters include the percent sign (%) or the forward slash (/), but because these characters have meanings within certain Cisco IOS commands, they are not recommended. For example, to set the vacant message to This terminal is idle you would enter the command vacant-message "This terminal is idle ".

## Configuring a "Line in Use" Message

To configure the system to display a "line in use" message when an incoming connection is attempted and all rotary group or other lines are in use, use the following command in line configuration mode:

Command	Purpose
Router(config-line)# <b>refuse-message</b> <i>d</i> message <i>d</i>	Configures the system to display a "line in use" message. The argument $d$ indicates any delimiting character.

If you do not define such a message, the user receives a system-generated error message when all lines are in use. You also can use this message to provide the user with further instructions.

## Configuring a "Host Failed" Message

To configure the system to display a "host failed" message when a Telnet connection with a specific host fails, use the following command in line configuration mode:

Command	Purpose	
Router(config-line)# <b>busy-message</b> hostname d message d	Configures the system to display a "host failed" message. The argument <i>d</i> indicates any delimiting character.	

# **Configuring Terminal Banners**

Banners are informational messages that can be displayed to users. To enable terminal banners, perform any of the tasks in the following sections. All tasks are optional.

- Configuring a Message-of-the-Day Banner
- Configuring a Login Banner
- Configuring an EXEC Banner
- Configuring an Incoming Banner
- Configuring a SLIP-PPP Banner Message
- Enabling or Disabling the Display of Banners

For an example of displaying terminal banner messages, see the "Configuring Banners Example" section at the end of this chapter.

# **Using Banner Tokens**

Banners can be customized with the use of banner tokens. Tokens are keywords in the form \$(*token*) that, when used in a banner message, display the currently configured value of the token argument (for example, the router host name, domain name, or IP address). Using these tokens, you can design your own banners that will display current Cisco IOS configuration variables. Only Cisco IOS supported tokens may be used. There is no facility for you to define your own tokens.

Table 10 lists the tokens supported by the different **banner** commands.

Token	Description	motd banner	login banner	exec banner	incoming banner	slip-ppp banner
\$(hostname)	Router Host Name	Yes	Yes	Yes	Yes	Yes
\$(domain)	Router Domain Name	Yes	Yes	Yes	Yes	Yes
\$(peer-ip)	IP Address of the Peer Machine	No	No	No	No	Yes
\$(gate-ip)	IP Address of the Gateway Machine	No	No	No	No	Yes
\$(encap)	Encapsulation Type (SLIP or PPP)	No	No	No	No	Yes
\$(encap-alt)	Encapsulation Type Displayed as SL/IP instead of SLIP	No	No	No	No	Yes
\$(mtu)	Maximum Transmission Unit Size	No	No	No	No	Yes
\$(line)	vty or tty (async) Line Number	Yes	Yes	Yes	Yes	No
\$(line-desc)	User-specified description of the Line	Yes	Yes	Yes	Yes	No

Table 10 Tokens Allowed by Banner Type

### **Configuring a Message-of-the-Day Banner**

You can configure a message-of-the-day (MOTD) banner to be displayed on all connected terminals. This banner is displayed at login and is useful for sending messages that affect all network users (such as impending system shutdowns). To do so, use the following command in global configuration mode:

Command	Purpose		
Router(config)# <b>banner motd</b> <i>d</i> message <i>d</i>	Configures the system to display a message-of-the-day banner. The argument $d$ indicates any delimiting character.		

# **Configuring a Login Banner**

You can configure a login banner to be displayed on all connected terminals. This banner is displayed after the MOTD banner appears and before the login prompts.

To configure a login banner, use the following command in global configuration mode:

Command	Purpose
Router(config)# <b>banner login</b> <i>d</i> message <i>d</i>	Configures the system to display a banner before the username and password login prompts. The argument $d$ indicates any delimiting character.

The login banner cannot be disabled on a per-line basis. To globally disable the login banner, you must delete the login banner with the **no banner login** command.

# **Configuring an EXEC Banner**

You can configure a banner to be displayed whenever a EXEC process is initiated. For example, this banner will be displayed to a user Telneting to the system after entering their username and password, but before the user EXEC mode prompt is displayed. To configure an EXEC banner, use the following command in global configuration mode:

Command	Purpose
Router(config) <b># banner exec</b> <i>d</i> message <i>d</i>	Configures the system to display a banner whenever an EXEC process is initiated. The argument $d$ indicates any delimiting character.

# **Configuring an Incoming Banner**

You can configure a banner to be displayed on terminals connected to reverse Telnet lines. This banner is useful for providing instructions to users of these types of connections. Reverse Telnet connections are described in more detail in the "Configuring and Managing External Modems" chapter of the Release 12.2 *Cisco IOS Dial Technologies Configuration Guide*.

To configure a banner that is sent on incoming connections, use the following command in global configuration mode:

Command	Purpose
Router(config) <b># banner incoming</b> <i>d</i> message <i>d</i>	Configures the system to display a banner when there is an incoming connection to a terminal line from a host on the network. The argument <i>d</i> indicates any delimiting character.

### **Configuring a SLIP-PPP Banner Message**

Default banner messages have been known to cause connectivity problems in some non-Cisco SLIP and PPP dialup software. You can now customize the SLIP-PPP banner message to make Cisco SLIP and PPP compatible with non-Cisco dialup software. To configure a SLIP-PPP banner message, use the following command in global configuration mode:

Command	Purpose
Router(config)# <b>banner slip-ppp</b> <i>d</i> message <i>d</i>	Configures a SLIP-PPP banner to display a customized message. The argument $d$ indicates any delimiting character.

### **Enabling or Disabling the Display of Banners**

You can control display of the MOTD and line-activation (EXEC) banners. By default, these banners are displayed on all lines. To suppress or reinstate the display of such banners, use the following commands in line configuration mode, as needed:

Command	Purpose
Router(config-line)# no exec-banner	Suppresses the display of MOTD and EXEC banners.
Router(config-line)# exec-banner	Reinstates the display of the EXEC or MOTD banners.
Router(config-line)# no motd-banner	Suppresses the display of MOTD banners.
Router(config-line)# motd-banner	Reinstates the display of the MOTD banners.

These commands determine whether the router will display the EXEC banner and the MOTD banner when an EXEC session is created. These banners are defined with the **banner motd** and **banner exec** global configuration commands. By default, the MOTD banner and the EXEC banner are enabled on all lines.

Disable the EXEC and MOTD banners using the no exec-banner command.

The MOTD banners can also be disabled by the **no motd-banner** line configuration command, which disables MOTD banners on a line. If the **no exec-banner** command is configured on a line, the MOTD banner will be disabled regardless of whether the **motd-banner** command is enabled or disabled. Table 11 summarizes the effects of the combination of the **exec-banner** command and the **motd-banner** command.

	exec-banner (default)	no exec-banner
	MOTD banner	None
motd-banner (default)	EXEC banner	
no motd-banner	EXEC banner	None

For reverse Telnet connections, the EXEC banner is never displayed. Instead, the incoming banner is displayed. The MOTD banner is displayed by default, but it is disabled if either the **no exec-banner** command or **no motd-banner** command is configured. Table 12 summarizes the effects of the combination of the **exec-banner** command and the **motd-banner** command for reverse Telnet connections.

#### Table 12 Banners Displayed Based On exec-banner and motd-banner Command Combinations for Reverse Telnet Sessions to Async Lines

	exec-banner (default)	no exec-banner
	MOTD banner	Incoming banner
motd-banner (default)	Incoming banner	
no motd-banner	Incoming banner	Incoming banner

# **Creating Menus**

A menu is a displayed list of actions from which a user can select without needing to know anything about the underlying command-level details. A menu system (also known as a user menu) effectively controls the functions a user can access. Figure 6 illustrates the parts that make up a typical menu.

#### Figure 6 Typical Menu Example

	Welcome	to OnRamp Internet Services		
	Туре а	number to select an option: Type 9 to exit the menu.	}	Menu title and banner (multiline)
Item —	- 1	Read email	)	
numbers	2	UNIX INTERNET access		
	3	Resume UNIX connection		Menu selection items
	6	Resume next connection		
	8	Set terminal type		
	9	Exit menu system	J	
	Item			
	sele	ction	128	
	text		ŝ	

Any user that can enter configuration mode can create menus. Remember the following guidelines when you create menus:

- Each menu item represents a single user command.
- The menu system default is a standard "dumb" terminal that only displays text in a 24-line-by-80-column format.
- A menu can have no more than 18 menu items. Menus containing more than 9 menu items are automatically configured as single-spaced menus; menus containing 9 or fewer menu items are automatically configured as double-spaced menus, but can be configured as single-spaced menus using the **menu single-space** global configuration command. (For more information about menu display configuration options, see the section "Specifying Menu Display Configuration Options" later in this chapter.)
- Item keys can be numbers, letters, or strings. If you use strings, you must configure the **menu line-mode** global configuration command.
- When you construct a menu, always specify how a user exits a menu and where the user goes. If you do not provide an exit from a menu—such as with the **menu-exit** command (described in the section "Specifying the Underlying Command for the Menu Item" later in this chapter), the user will be trapped.

The **exec-timeout** line configuration command can be used to close and clean up an idle menu; the **session-timeout** command can be used to clean up a menu with an open connection.

### **Creating a Menu Task List**

To create menus, perform the tasks described in the following sections:

- Specifying the Menu Title (Required)
- Specifying the Menu Prompt (Optional)
- Specifying the Menu Item Text (Required)
- Specifying the Underlying Command for the Menu Item (Required)
- Specifying the Default Command for the Menu (Required)
- Creating a Submenu (Optional)
- Creating Hidden Menu Entries (Optional)
- Specifying Menu Display Configuration Options (Optional)
- Specifying per-Item Menu Options (Optional)
- Invoking the Menu (Required)
- Deleting the Menu from the Configuration (Optional)

# **Specifying the Menu Title**

You can specify an identifying title for the menu. To specify the menu title, use the following command in global configuration mode:

Command	Purpose	
Router(config)# menu menu-name title d title d	Specifies the title for the menu. The argument d	
	indicates any delimiting character.	

The following example specifies the title that is displayed when the OnRamp menu is selected. The following four main elements create the title:

- The menu title command
- Delimiter characters that open and close the title text
- Escape characters to clear the screen (optional)
- Title text

The following example shows the command used to create the title for the menu shown in Figure 6:

```
Router(config)# menu OnRamp title %^[[H^[[J
Enter TEXT message. End with the character '%'.
Welcome to OnRamp Internet Services
Type a number to select an option;
Type 9 to exit the menu.
```

```
Router(config)#
```

You can position the title of the menu horizontally by preceding the title text with blank characters. You can also add lines of space above and below the title by pressing Enter.

In this example, the title text consists of the following elements:

- One-line title
- Space
- Two-line menu instruction banner

Title text must be enclosed within text delimiter characters—the percent sign character (%) in this example. Title text delimiters are characters that do not ordinarily appear within the text of a title, such as slash (/), double quote ("), or tilde ( $\sim$ ). You can use any character that is not likely to be used within the text of the title as delimiter characters. Ctrl-C is reserved for special use and should not be used in the text of the title.

This title text example also includes an escape character sequence to clear the screen before displaying the menu. In this case the string ^[[H^[[J] is an escape string used by many VT100-compatible terminals to clear the screen. To enter it, you must enter Ctrl-V before each escape character (^[]).

You can also use the **menu clear-screen** global configuration command to clear the screen before displaying menus and submenus, instead of embedding a terminal-specific string in the menu title. This option uses a terminal-independent mechanism based on termcap entries defined in the router and the terminal type configured for the user terminal. The **menu clear-screen** command allows the same menu to be used on multiple types of terminals instead of terminal-specific strings being embedded within menu titles. If the termcap entry does not contain a clear string, the menu system inserts 24 new lines, causing all existing text to scroll off the top of the terminal screen.

To clear the screen before displaying the menu, use the following command in global configuration mode:

Command	Purpose
Router(config) # menu menu-name clear-screen	Specifies screen clearing before displaying menus and submenus.

The following example clears the screen before displacing the OnRamp menu or a submenu: Router(config)# menu OnRamp clear-screen

### **Specifying the Menu Prompt**

To specify a menu prompt, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name prompt d prompt d	Specifies the prompt for the menu. The argument $d$ indicates any delimiting character.

### Specifying the Menu Item Text

Each displayed menu entry consists of the selection key (number, letter, or string) and the text describing the action to be performed. You can specify descriptive text for a maximum number of 18 menu items. Because each menu entry represents a single user interface command, you must specify the menu item text one entry at a time. To specify the menu item text, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name text menu-item menu-text	Specifies the text for the menu item.

The following example specifies the text that is displayed for the three entries in the OnRamp menu:

```
Router(config)# menu OnRamp text 1 Read email
Router(config)# menu OnRamp text 2 UNIX Internet Access
Router(config)# menu OnRamp text 9 Exit menu system
```

You can provide access to context-sensitive help by creating a "help server" host and using a menu entry to make a connection to that host.

Menu selection keys need not be contiguous. You can provide consistency across menus by assigning a particular number, letter, or string to a special function—such as Help or Exit—regardless of the number of menu entries in a given menu. For example, menu entry H could be reserved for help across all menus.

When more than nine menu items are defined in a menu, the **menu line-mode** and **menu single-space** global configuration commands are activated automatically. The commands can be configured explicitly for menus of nine items or fewer. For more information on these commands, see the section "Specifying Menu Display Configuration Options" later in this chapter.

### Specifying the Underlying Command for the Menu Item

Each displayed menu entry issues a user interface command when the user enters its key. Each menu entry can have only a single command associated with it. To specify the underlying menu item command, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name command menu-item command	Specifies the command to be performed when the menu item is selected.

The following example specifies the commands that are associated with the three entries in the OnRamp menu:

```
Router(config)# menu OnRamp command 1 rlogin mailsys
Router(config)# menu OnRamp command 2 rlogin unix.cisco.com
Router(config)# menu OnRamp command 9 menu-exit
```

The **menu-exit** command is available only from within menus. This command provides a way to return to a higher-level menu or to exit the menu system.

When a menu item allows you to make a connection, the menu item should also contain entries that can be used to resume connections; otherwise, when you try to escape from a connection and return to the menu, there is no way to resume the session. It will sit idle until you log out. You can build the **resume connection** EXEC command into a menu entry so that the user can resume a connection, or you can configure the line using the **escape-char none** command to prevent users from escaping their sessions.

To specify connection resumption as part of the menu item command, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name command menu-item resume [connection] /connect [connect string]	Specifies that the <b>resume</b> command will be performed when the menu item is selected.

Embedding the **resume** command within the **menu** command permits a user to resume the named connection or make another connection using the specified name, if there is no active connection by that name. As an option, you can also supply the connect string needed to connect initially. When you do not supply this connect string, the command uses the specified connection name.

You can use the resume command in the following menu entries:

- Embedded in a menu entry
- As a separate, specific menu entry
- As a "rotary" menu entry that steps through several connections

In the following example, the **resume** command is embedded in the **menu** command so that selecting the menu item either starts the specified connection session (if one is not already open) or resumes the session (if one is already open):

Router(config) # menu Duluth text 1 Read email Router(config) # menu Duluth command 1 resume mailsys /connect rlogin mailsys In the following example, the resume command is used in a separate menu entry (entry 3) to resume a specific connection:

Router(config) # menu Duluth text 3 Resume UNIX Internet Access Router(config) # menu Duluth command 3 resume unix.cisco.com

You use the **resume/next** command to resume the next open connection in the user list of connections. This command allows you to create a single menu entry that advances through all of the user connections. To specify **resume/next** connection resumption as part of the menu item command, use the following command in global configuration mode:

Command	Purpose
Router(config)# <b>menu</b> menu-name <b>command</b> menu-item	Specifies resume/next connection resumption.
resume/next	

The following example shows a menu entry (entry 6) created to advance through all of the user connections:

Router(config)# menu Duluth text 6 Resume next connection
Router(config)# menu Duluth command 6 resume/next

### Specifying the Default Command for the Menu

When a user presses Enter without specifying an item, the router performs the command for the default item. To specify the default item, use the following command in global configuration mode:

Command	Purpose
Router(config) # menu menu-name default menu-item	Specifies the command to be performed when the menu
	users does not select a menu item.

### **Creating a Submenu**

To create submenus that are opened by selecting a higher-level menu entry, use the **menu** command to invoke a menu in a line menu entry. To specify a submenu item command, use the following commands in global configuration mode:

	Command	Purpose
Step 1	Router(config)# <b>menu</b> menu-name <b>text</b> menu-item menu-text	Specifies the menu item that invokes the submenu.
Step 2	Router(config)# <b>menu</b> menu-name <b>command</b> menu-item <b>menu</b> menu-name2	Specifies the command to be used when the menu item is selected.
Step 3	Router(config)# <b>menu</b> menu-name <b>title</b> delimiter menu-title delimiter	Specifies the title for the submenu.
Step 4	Router(config)# <b>menu</b> menu-name <b>text</b> menu-item menu-text	Specifies the submenu item.
Step 5	Router(config)# <b>menu</b> menu-name <b>command</b> menu-item command	Specifies the command to be used when the submenu item is selected. Repeat this command as needed.

The following example specifies that the menu item (entry 8) activates the submenu in the OnRamp menu:

Router(config) # menu OnRamp text 8 Set terminal type

The following example specifies the command that is performed when the menu item (entry 8) is selected in the OnRamp menu:

Router(config) # menu OnRamp command 8 menu Terminals

The following example specifies the title for the Terminals submenu:

```
Router(config)# menu Terminals title /
Supported Terminal Types
```

Type a number to select an option; Type 9 to return to the previous menu.

The following example specifies the submenu items for the Terminals submenu:

```
Router(config)# menu Terminals text 1 DEC VT420 or similar
Router(config)# menu Terminals text 2 Heath H-19
Router(config)# menu Terminals text 3 IBM 3051 or equivalent
Router(config)# menu Terminals text 4 Macintosh with gterm emulator
Router(config)# menu Terminals text 9 Return to previous menu
```

The following example specifies the commands associated with the items in the Terminals submenu:

```
Router(config) # menu Terminals command 1 term terminal-type vt420
Router(config) # menu Terminals command 2 term terminal-type h19
Router(config) # menu Terminals command 3 term terminal-type ibm3051
Router(config) # menu Terminals command 4 term terminal-type gterm
Router(config) # menu Terminals command 9 menu-exit
```

When you select entry 8 on the main menu, the following Terminals submenu appears:

Supported Terminal Types Type a number to select an option; Type 9 to return to the previous menu. 1 DEC VT420 or similar 2 Heath H-19 3 IBM 3051 or equivalent 4 Macintosh with gterm emulator

```
9 Return to previous menu
```

Note

If you nest too many levels of menus, the system displays an error message on the terminal and returns to the previous menu level.

### **Creating Hidden Menu Entries**

A hidden menu entry is a menu item that contains a selection key but no associated text describing the action to be performed. Include this type of menu entry to aid system administrators that provide help to users. The normal procedure is to specify a menu command but omit specifying any text for the item. To specify a hidden menu item, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name command menu-item command	Specifies the command to be used when the hidden menu entry is selected.

The following example shows the command associated with the submenu entry in the OnRamp menu:

Router(config) # menu OnRamp command 7 show whoami

If additional text is appended to the **show whoami** command, that text is displayed as part of the data about the line. For example, the hidden menu entry created by the command

Router(config) # menu OnRamp command 7 show whoami Terminals submenu of OnRamp Internet Access menu

will display information similar to the following:

Comm Server "cs101", Line 0 at 0 bps. Location "Second floor, West" Additional data: Terminals submenu of OnRamp Internet Access menu

To prevent the information from being lost if the menu display clears the screen, this command always displays a --More-- prompt before returning.

### **Specifying Menu Display Configuration Options**

In addition to the **menu clear-screen** global configuration command (described in the "Specifying the Menu Title" section) the following are the three other **menu** commands that define menu functions:

- menu line-mode
- menu single-space
- menu status-line

#### **Using Line Mode in Menus**

In a menu of nine or fewer items, you ordinarily select a menu item by entering the item number or a letter. In line mode, you select a menu entry by entering the item key and pressing Enter. The line mode allows you to backspace over the selection and enter another before pressing Enter to issue the command. This function allows you to change the selection before you invoke the command.

To configure the menu to operate in line mode, use the following command in global configuration mode:

Command	Purpose
Router(config) # menu menu-name line-mode	Configures the menu to use line mode for entering menu items.

The line-mode option is invoked automatically when more than nine menu items are defined, but it can also be configured explicitly for menus of nine items or fewer.

In order to use strings as selection keys, you must enable the **menu line-mode** command.

#### **Displaying Single-Spaced Menus**

If there are nine or fewer menu items, the Cisco IOS software ordinarily displays the menu items double-spaced. In a menu of more than nine items, the **single-space** option is activated automatically to fit the menu into a normal 24-line terminal screen. However, the single-space option also can be configured explicitly for menus of nine or fewer items.

To invoke the **single-space** option, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name single-space	Configures the specified menu to display single-spaced.

#### **Displaying an Informational Status Line**

The **status-line** option displays a line of status information about the current user at the top of the terminal screen before the menu title is displayed. This status line includes the router host name, the user line number, and the current terminal type and keymap type (if any).

L

To display the status-line option, use the following command in global configuration mode:

Command	Purpose
Router(config)# menu menu-name status-line	Configures the specified menu to display a status line.

# **Specifying per-Item Menu Options**

To configure per-item options, use the following commands in global configuration mode, as needed:

Command	Purpose
Router(config)# menu menu-name options menu-item pause	Configures the system to pause after the specified menu item is selected by the user. Enter this command once for each menu item that pauses.
Router(config)# menu menu-name options menu-item login	Configures the specified menu item to require a login before executing the command. Enter this command once for each menu item that requires a login.

# **Invoking the Menu**

To invoke (access) a configured menu, use the following command in EXEC mode:

Command	Purpose
Router# menu-name	Invokes a preconfigured user menu.

You can define menus containing privileged EXEC commands, but users must have privileged access when they start up the menu.

To ensure that a menu is automatically invoked on a line, make sure the menu does not have any exit paths that leave users in an interface they cannot operate, then configure that line with the **autocommand menu** *menu-name* line configuration command. (The **autocommand menu** *menu-name* command configures the line to automatically execute the **menu** *menu-name* command when a user initiates a connection over that line.)

Menus also can be invoked on a per-user basis by defining an **autocommand** command for that local username.

In the following example, the OnRamp menu is invoked:

```
Router# menu OnRamp
Welcome to OnRamp Internet Services
Type a number to select an option;
Type 9 to exit the menu.
Read email
UNIX Internet access
Resume UNIX connection
Resume next connection
Exit menu system
```

### **Deleting the Menu from the Configuration**

To delete the menu from the configuration, use the following command in global configuration mode:

Command	Purpose
Router(config)# <b>no menu</b> menu-name	Deletes the menu by specifying the menu name.

In order to use the menu again, you must reconfigure the entire menu.

The following example deletes the OnRamp menu from the configuration:

Router(config) # no menu OnRamp

# **Connection Management, System Banner, and User Menu Configuration Examples**

This section provides the following examples:

- Changing a Login Name Example
- Sending Messages to Other Terminals Example
- Clearing a TCP/IP Connection Example
- Configuring Banners Example
- Setting a SLIP-PPP Banner with Banner Tokens Example
- Configuring a Menu Example

L

I

The following example shows how login usernames and passwords can be changed. In this example, a user currently logged in under the username user1 attempts to change that login name to user2. After entering the **login** command, the user enters the new username, but enters an incorrect password. Because the password does not match the original password, the system rejects the attempt to change the username.

Router> login Username: user2 Password: % Access denied Still logged in as "user1"

Next, the user attempts the login change again, with the username user2, but enters the correct (original) password. This time the password matches the current login information, the login username is changed to user2, and the user is allowed access to the EXEC at the user-level.

Router> **login** Username: **user2** Password: Router>

### **Sending Messages to Other Terminals Example**

The following example shows the process of sending a message to all terminal connections on the router:

```
Router# send *
Enter message, end with CTRL/Z; abort with CTRL/C:
this is a message^Z
Send message? [confirm]
Router#
***
****
**** Message from tty50 to all terminals:
***
this is a message
```

Router#

### **Clearing a TCP/IP Connection Example**

The following example clears a TCP connection using its tty line number. The **show tcp** EXEC command displays the line number (tty2) that is used in the **clear tcp** EXEC command.

Router# show tcp

```
tty2, virtual tty from host router20.cisco.com
   Connection state is ESTAB, I/O status: 1, unread input bytes: 0
   Local host: 171.69.233.7, Local port: 23
   Foreign host: 171.69.61.75, Foreign port: 1058
    Enqueued packets for retransmit: 0, input: 0, saved: 0
    Event Timers (current time is 0x36144):
   Timer Starts Wakeups
                                                Next
   Retrans40TimeWait00AckHold74SendWnd00KeepAlive00GiveUp00PmtuAger00
                                                0x0
                                               0x0
                                               0x0
                                               0x0
                                               0x0
                                                0 \times 0
                                                 0x0
    iss: 4151109680 snduna: 4151109752 sndnxt: 4151109752
                                                             sndwnd: 24576
   irs: 1249472001 rcvnxt: 1249472032 rcvwnd: 4258 delrcvwnd: 30
   SRTT: 710 ms, RTTO: 4442 ms, RTV: 1511 ms, KRTT: 0 ms
   minRTT: 0 ms, maxRTT: 300 ms, ACK hold: 300 ms
Router# clear tcp line 2
   [confirm]
     [OK]
```

The following example clears a TCP connection by specifying its local router host name and port and its remote router host name and port. The **show tcp brief** EXEC command displays the local (Local Address) and remote (Foreign Address) host names and ports to use in the **clear tcp** EXEC command.

```
Router# show tcp brief

TCB Local Address Foreign Address (state)

60A34E9C router1.cisco.com.23 router20.cisco.1055 ESTAB

Router# clear tcp local router1 23 remote router20 1055

[confirm]

[OK]
```

The following example clears a TCP connection using its TCB address. The **show tcp brief** EXEC command displays the TCB address to use in the **clear tcp** EXEC command.

```
Router# show tcp brief

TCB Local Address Foreign Address (state)

60B75E48 router1.cisco.com.23 router20.cisco.1054 ESTAB

Router# clear tcp tcb 60B75E48

[confirm]

[OK]
```

The following example shows how to use the **banner** global configuration commands to notify your users that the server will be reloaded with new software. The **no exec-banner** line configuration command is used to disable EXEC banners and message-of-the-day banners on the vty lines.

```
!
line vty 0 4
no exec-banner
1
banner exec /
This is Cisco Systems training group router.
Unauthorized access prohibited.
 /
!
banner incoming /
You are connected to a Hayes-compatible modem.
Enter the appropriate AT commands.
Remember to reset anything you have changed before disconnecting.
 /
!
banner motd /
The router will go down at 6pm today for a software upgrade
 /
```

When someone connects to the router, the MOTD banner appears before the login prompt. After the user logs in to the router, the router will display the EXEC banner or incoming banner, depending on the type of connection. For a reverse Telnet login, the router will display the incoming banner. For all other connections, the router will display the EXEC banner.

### Setting a SLIP-PPP Banner with Banner Tokens Example

The following example sets the SLIP-PPP banner using several tokens and the percent sign (%) as the delimiting character:

```
Router(config)# banner slip-ppp %
Enter TEXT message. End with the character '%'.
Starting $(encap) connection from $(gate-ip) to $(peer-ip) using a maximum packet size of
$(mtu) bytes... %
```

When a user enters the **slip** command, that user will see the following banner. Notice that the **\$**(*token*) syntax is replaced by the corresponding configuration variable.

Starting SLIP connection from 192.168.69.96 to 172.16.80.8 using a maximum packet size of 1500 bytes...

### **Configuring a Menu Example**

The following example allows menu users to use Telnet to access one of three different machines. The user also can view the output of the **show user** EXEC command and exit the menu. One hidden menu item (configured as menu new command here show version) allows system administrators to display the current software version.

menu new title ^C

Telnet Menu

^C menu new prompt ^C

```
Please enter your selection: ^C
menu new text 1 telnet system1
menu new command 1 telnet system1
menu new options 1 pause
menu new text 2 telnet system2
menu new command 2 telnet system2
menu new options 2 pause
menu new text b telnet systemblue
menu new command b telnet systemblue
menu new options b pause
menu new text me show user
menu new command me show user
menu new options me pause
menu new command here show version
menu new text Exit Exit
menu new command Exit menu-exit
menu new clear-screen
menu new status-line
menu new default me
menu new line-mode
1
```