

sntp broadcast client

To use the Simple Network Time Protocol (SNTP) to accept Network Time Protocol (NTP) traffic from any broadcast server, use the **sntp broadcast client** command in global configuration mode to configure a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router. To prevent the router from accepting broadcast traffic, use the **no** form of this command.

sntp broadcast client

no sntp broadcast client

Syntax Description

This command has no arguments or keywords.

Defaults

The router does not accept SNTP traffic from broadcast servers.

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

SNTP is a compact, client-only version of the NTP. SNTP can only receive the time from NTP servers; it cannot be used to provide time services to other systems.

SNTP typically provides time within 100 milliseconds of the accurate time, but it does not provide the complex filtering and statistical mechanisms of NTP. In addition, SNTP does not authenticate traffic, although you can configure extended access lists to provide some protection.

You must configure the router with either this command or the **sntp server** global configuration command to enable SNTP.

Examples

The following example enables the router to accept broadcast NTP packets and shows sample **show sntp** command output:

```
Router(config)# sntp broadcast client
Router(config)# end
Router#
%SYS-5-CONFIG: Configured from console by console
Router# show sntp
SNTP server      Stratum    Version    Last Receive
172.21.28.34     4          3          00:00:36    Synced    Bcast

Broadcast client mode is enabled.
```

Related Commands	Command	Description
	show sntp	Displays information about SNTP on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.
	sntp server	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to request and accept NTP traffic from a time server.

sntp logging

To enable Simple Network Time Protocol (SNTP) message logging, use the **sntp logging** command in global configuration mode. To disable SNTP logging, use the **no** form of this command.

sntp logging

no sntp logging

Syntax Description This command has no arguments or keywords.

Defaults SNTP message logging is disabled.

Command Modes Global configuration

Command History	Release	Modification
	12.3(7)T	This command was introduced.

Usage Guidelines Use the **sntp logging** command to control the display of SNTP logging messages.

SNTP is a compact, client-only version of Network Time Protocol (NTP). SNTP can be used only to receive the time from NTP servers; SNTP cannot be used to provide time services to other systems. You should consider carefully the use of SNTP rather than NTP in primary servers.

Examples The following example shows how to enable SNTP message logging, configure the IP address of the SNTP server as 10.107.166.3, and verify that SNTP logging is enabled:

```
Router# configure terminal

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)# sntp logging

Router(config)# sntp server 10.107.166.3

Router(config)# end

Router#
04:02:54: %SYS-5-CONFIG_I: Configured from console by console
Router#

Router# show running-config | include ntp

sntp logging
sntp server 10.107.166.3
```

The “sntp logging” entry in the configuration file verifies that SNTP message logging is enabled.

The following example shows how to disable SNTP message logging and verify that it is disabled:

```
Router# configure terminal

Enter configuration commands, one per line.  End with CNTL/Z.

Router(config)# no sntp logging

Router(config)# end

Router#
04:04:34: %SYS-5-CONFIG_I: Configured from console by console

Router# show running-config | include ntp

sntp server 10.107.166.3
```

The “sntp logging” entry no longer appears in the configuration file, which verifies that SNTP message logging is disabled.

Related Commands

Command	Description
show sntp	Displays information about SNTP on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.
sntp broadcast client	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to accept NTP traffic from any broadcast server.
sntp server	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to request and accept NTP traffic from a time server.

sntp server

To configure a Cisco 800, Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use the Simple Network Time Protocol (SNTP) to request and accept Network Time Protocol (NTP) traffic from a stratum 1 time server, use the **sntp server** command in global configuration mode. To remove a server from the list of NTP servers, use the **no** form of this command.

sntp server {*address* | *hostname*} [**version** *number*]

no sntp server {*address* | *hostname*}

Syntax Description

<i>address</i>	IP address of the time server.
<i>hostname</i>	Host name of the time server.
version <i>number</i>	(Optional) Version of NTP to use. The default is 1.

Defaults

The router does not accept SNTP traffic from a time server.

Command Modes

Global configuration

Command History

Release	Modification
11.2	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

SNTP is a compact, client-only version of the NTP. SNTP can only receive the time from NTP servers; it cannot be used to provide time services to other systems.

SNTP typically provides time within 100 milliseconds of the accurate time, but it does not provide the complex filtering and statistical mechanisms of NTP. In addition, SNTP does not authenticate traffic, although you can configure extended access lists to provide some protection.

Enter this command once for each NTP server.

You must configure the router with either this command or the **sntp broadcast client** global configuration command in order to enable SNTP.

SNTP time servers should operate only at the root (stratum 1) of the subnet, and then only in configurations where no other source of synchronization other than a reliable radio or modem time service is available. A stratum 2 server cannot be used as an SNTP time server. The use of SNTP rather than NTP in primary servers should be carefully considered.

Examples

The following example enables the router to request and accept NTP packets from the server at 172.21.118.9 and displays sample **show sntp** command output:

```
Router(config)# sntp server 172.21.118.9
Router(config)# end
Router#
%SYS-5-CONFIG: Configured from console by console
Router# show sntp

SNTP server      Stratum   Version   Last Receive
172.21.118.9     5         3         00:01:02   Synced
```

Related Commands

Command	Description
show sntp	Displays information about SNTP on a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router.
sntp broadcast client	Configures a Cisco 1003, Cisco 1004, Cisco 1005, Cisco 1600, Cisco 1720, or Cisco 1750 router to use SNTP to accept NTP traffic from any broadcast server.

sntp source-interface

To use a particular source address in Simple Network Time Protocol (SNTP) packets, use the **sntp source-interface** command in global configuration mode. To remove the specified source address, use the **no** form of this command.

sntp source-interface *type number*

no sntp source-interface

Syntax Description	<i>type</i>	Type of interface.
	<i>number</i>	Number of the interface.

Command Default The source address is determined by the outgoing interface.

Command Modes Global configuration

Command History	Release	Modification
	12.4(10)	This command was introduced.

Usage Guidelines Use this command to specify a particular source IP address for all SNTP packets. The address is taken from the named interface. This command is useful if the address on an interface cannot be used as the destination for reply packets. The **no** form of the command only replaces the default; that is, the source address of the SNTP request sent is determined by the outgoing interface.

If this command is the last one issued and you then remove it, the SNTP process stops.

Examples The following example shows how to configure a router to use the IP address of interface Ethernet 0 as the source address for all outgoing SNTP packets:

```
Router(config)# sntp source-interface ethernet 0
```

The following example shows how to remove a configured SNTP option:

```
Router(config)# no sntp source-interface
```

spec-file install add-entry

To copy a spec file entry (SFE) from a remote location and add it to the local spec file, use the **spec-file install add-entry** command in privileged EXEC mode.

```
spec-file install [force] location:local-filename add-entry url:remote-filename command
```

Syntax Description	force	(Optional) Performs the action without prompting.
	<i>location:local-filename</i>	Spec filename, which must be on a local file system. Valid locations are bootflash: , flash: , nvram: , and any valid disk or slot number (such as disk0: or slot1:). Spec files have a .odm suffix. You will be prompted to confirm adding the SFE, unless the optional force keyword is used.
	<i>url:remote-filename</i>	Location (URL) and filename of the remote spec file. Valid URLs are archive: , bootflash: , cns: , flash: , ftp: , http: , null: , nvram: , pram: , rcp: , scp: , system: , tar: , tftp: , tmpsys: , and any valid disk or slot number (such as disk0: or slot1:).
	<i>command</i>	Command SFE to be added to the spec file.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.

Usage Guidelines

Use the **spec-file install add-entry** command to add an SFE to a spec file. A check is performed on the loaded SFE to ensure that the command is not already present in the spec file, and that the SFE can be parsed correctly in Extensible Markup Language (XML).

If the spec file does not exist, you will be prompted before the file is created. If the command SFE already exists in the spec file, you will be prompted before the command SFE is replaced. A backup copy of the local spec file is created before the remote SFE is added.

Examples

The following example adds the **show arp** command SFE from the remote show_arp.odm file at location “tftp://system1/user1” to the local file:

```
Router# spec-file install slot0:spec_file.odm add-entry tftp://system1/user1/show_arp.odm show arp
```

Unless you add the **force** keyword to the command string, you will be prompted as follows:

```
create new spec file? [yes]:
```


CLI exists, delete it? [**yes**]:

Pressing the **Enter** key is the same as typing **yes**. Type **no** and press **Enter** to stop either process.

Related Commands

Command	Description
spec-file install built-in	Replaces the current spec file with the built-in spec file.
spec-file install file	Replaces a local spec file with a remote spec file.
spec-file install remove-entry	Removes an SFE from a spec file.
spec-file install restore	Restores a spec file to its previous contents using a backup file.

spec-file install built-in

To replace the current spec file with the built-in spec file, use the **spec-file install built-in** command in privileged EXEC mode.

spec-file install [**force**] *location:local-filename* **built-in**

Syntax Description	
force	(Optional) Performs the action without prompting.
<i>location:local-filename</i>	Spec filename, which must be on a local file system. Valid locations are bootflash: , flash: , nvr: , and any valid disk or slot number (such as disk0: or slot1:). Spec files have a .odm suffix. If <i>local-filename</i> exists, you will be prompted for a yes or no response before the file is replaced, unless the optional force keyword is used.

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.

Usage Guidelines	Use the spec-file install built-in command to replace the current spec file with the built-in spec file. You will be prompted before the current file is replaced and <i>filename.bak</i> will be created.
------------------	---

Examples	The following example shows how to start the process to replace the current spec file with the built-in spec file:
----------	--

```
Router# spec-file install slot0:spec_file.odm built-in
```

Unless you add the **force** keyword to the command string, you will be prompted as follows:

```
Replace existing file? [yes]:
```

Press the **Enter** key to make a backup copy of the current file and then replace it with the built-in spec file. Type **no** and press **Enter** to stop the process.

Related Commands	Command	Description
	spec-file install add-entry	Copies an SFE from a remote location and adds it to a local spec file.
	spec-file install file	Replaces a local spec file with a remote spec file.

Command	Description
spec-file install remove-entry	Removes an SFE from a spec file.
spec-file install restore	Restores a spec file to its previous contents using a backup file.

spec-file install file

To replace a local spec file with a remote spec file, use the **spec-file install file** command in privileged EXEC mode.

spec-file install [**force**] *location:local-filename* **file** *url:remote-filename*

Syntax Description	force	(Optional) Performs the action without prompting.
	<i>location:local-filename</i>	Spec filename, which must be on a local file system. Valid locations are bootflash: , flash: , nvr: , and any valid disk or slot number (such as disk0: or slot1:). Spec files have a .odm suffix. When <i>local-filename</i> exists, you will be prompted for a yes or no response before the file is copied, unless the optional force keyword is used.
	<i>url:remote-filename</i>	Location (URL) and filename of the remote spec file. Valid URLs are archive: , bootflash: , cns: , flash: , ftp: , http: , null: , nvr: , pram: , rcp: , scp: , system: , tar: , tftp: , tmpsys: , and any valid disk or slot number (such as disk0: or slot1:).

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.

Usage Guidelines	Use the spec-file install file command to copy a remote spec file to a local spec file. A check of the loaded file is performed to ensure that each specified command is included only once, and that the spec file entry (SFE) can be parsed correctly in Extensible Markup Language (XML).
------------------	---

Examples	<p>The following example shows how to copy a remote spec file on “tftp://system1/user1” to the local file:</p> <pre>Router# spec-file install slot0:spec_file.odm file tftp://system1/user1/spec_file.odm</pre> <p>Unless you add the force keyword to the command string, you will be prompted as follows:</p> <pre>Replace existing file? [yes]:</pre> <p>Press the Enter key to complete the command. Type no and press Enter to stop the process.</p>
----------	---

Related Commands

Command	Description
spec-file install add-entry	Copies an SFE from a remote location and adds it to a local spec file.
spec-file install built-in	Replaces the current spec file with the built-in spec file.
spec-file install remove-entry	Removes an SFE from a spec file.
spec-file install restore	Restores a spec file to its previous contents using a backup file.

spec-file install remove-entry

To remove a spec file entry (SFE) from a spec file, use the **spec-file install remove-entry** command in privileged EXEC mode.

spec-file install [**force**] *location:local-filename* **remove-entry** *command*

Syntax Description

force	(Optional) Performs the action without prompting.
<i>location:local-filename</i>	Spec filename, which must be on a local file system. Valid locations are bootflash: , flash: , nvr am:, and any valid disk or slot number (such as disk0: or slot1:). Spec files have a .odm suffix.
<i>command</i>	Command SFE to be removed from the spec file.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.

Usage Guidelines

Use the **spec-file install remove-entry** command to remove a command SFE from a spec file. A check is performed to ensure that the command SFE is present in the spec file. If the spec file does not exist, this command fails. A backup copy of the spec file is created before the SFE is removed.

Examples

The following example shows how to remove the **show arp** command SFE from the remote show_arp.odm file to the local spec_file.odm file:

```
Router# spec-file install slot0:spec_file.odm remove-entry show arp
```

Related Commands

Command	Description
spec-file install add-entry	Copies an SFE from a remote location and adds it to a local spec file.
spec-file install built-in	Replaces the current spec file with the built-in spec file.
spec-file install file	Replaces a local spec file with a remote spec file.
spec-file install restore	Restores a spec file to its previous contents using a backup file.

spec-file install restore

To restore a spec file to its previous contents using a backup file, use the **spec-file install restore** command in privileged EXEC mode.

spec-file install [**force**] *location:local-filename* **restore**

Syntax Description	force	(Optional) Performs the action without prompting.
	<i>location:local-filename</i>	Spec filename, which must be on a local file system. Valid locations are bootflash: , flash: , nvr am:, and any valid disk or slot number (such as disk0: or slot1:). Spec files have a .odm suffix.

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was modified. It was integrated into Cisco IOS Release 12.2(33)SRE.
	12.2(54)SG	This command was integrated into Cisco IOS Release 12.2(54)SG.

Usage Guidelines	Use the spec-file install restore command to revert a spec file to its original contents using a backup (.bak) file. If the .bak file does not exist, this command fails.
-------------------------	--

Examples	The following example shows how to restore the spec file using the backup file:
-----------------	---

```
Router# spec-file install slot0:spec_file.odm restore
```

Related Commands	Command	Description
	spec-file install add-entry	Copies an SFE from a remote location and adds it to a local spec file.
	spec-file install built-in	Replaces the current spec file with the built-in spec file.
	spec-file install file	Replaces a local spec file with a remote spec file.
	spec-file install remove-entry	Removes an SFE from a spec file.

startup (test boolean)

To specify whether an event can be triggered for the Boolean trigger test, use the **startup** command in event trigger boolean configuration mode. To disable the configured settings, use the **no** form of this command.

startup

no startup

Syntax Description

This command has no arguments or keywords.

Command Default

The startup event is enabled when the Boolean trigger test is enabled.

Command Modes

Event trigger boolean configuration (config-event-trigger-boolean)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

The **startup** command triggers an event when the conditions specified for the Boolean trigger test are met.

Examples

The following example shows how to specify startup for the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)# startup
Router(config-event-trigger-boolean)#
```

Related Commands

Command	Description
test	Enables a trigger test.

startup (test existence)

To specify whether an event can be triggered for the existence trigger test, use the **startup** command in event trigger existence configuration mode. To disable the configured settings, use the **no** form of this command.

startup {present | absent}

no startup {present | absent}

Syntax Description	present	Triggers the present startup test when the existence trigger conditions are met.
	absent	Triggers the absent startup test when the existence trigger conditions are met.

Command Default By default, both present and absent startup tests are triggered.

Command Modes Event trigger existence configuration (config-event-trigger-existence)

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines The **startup** command triggers an event when the conditions specified for the existence trigger test are met.

Examples The following example shows how to specify startup for the existence trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)# startup
Router(config-event-trigger-existence)#
```

Related Commands	Command	Description
	test	Enables a trigger test.

startup (test threshold)

To specify whether an event can be triggered for the threshold trigger test, use the **startup** command in the threshold test configuration mode. To disable the configured settings, use the **no** form of this command.

startup { **rising** | **falling** | **rise-or-falling** }

no startup

Syntax Description

rising	Specifies the rising threshold value to check against the set value during startup when the trigger type is threshold.
falling	Specifies the falling threshold value to check against the set value during startup when the trigger type is threshold.
rise-or-falling	Specifies the rising or falling threshold value to check against the set value during startup when the trigger type is threshold. This is the default value.

Command Default

The rising or falling threshold value is checked against the set value during startup when the trigger type is threshold.

Command Modes

Event trigger threshold configuration mode (config-event-trigger-threshold)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

The **startup** command starts an event when the conditions for threshold trigger test are met.

Examples

The following example shows how to specify startup for the threshold trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test threshold
Router(config-event-trigger-threshold)# startup rising
Router(config-event-trigger-threshold)#
```

Related Commands

Command	Description
test	Enables a trigger test.

stealth

To disable the Web Services Management Agent (WSMA) profile from sending Simple Object Access Protocol (SOAP) faults, use the **stealth** command in WSMA listener configuration mode or WSMA initiator configuration mode. To enable WSMA to send the SOAP faults, use the **no** form of this command.

stealth

no stealth

Syntax Description This command has no arguments or keywords.

Command Default Stealth is disabled; that is, SOAP faults are sent.

Command Modes WSMA initiator configuration (config-wsma-init)
WSMA listener configuration (config-wsma-listen)

Command History	Release	Modification
	12.4(24)T	This command was introduced.
	15.1(1)T	This command was modified. Support was added for the WSMA initiator configuration mode.

Usage Guidelines Use this command from the WSMA listener configuration mode. To enter this mode, use the **wsma profile listener** command in global configuration mode.

Examples The following example shows how to enable the **stealth** command to stop sending the SOAP faults:

```
Router(config)# wsma profile listener prof1
Router(config-wsma-listen)# stealth
Router(config-wsma-listen)#
```

Related Commands	Command	Description
	acl	Enables access control lists for restricting addresses that can connect to a WSMA profile.
	idle-timeout	Sets a time for the WSMA profile to disconnect the session when there is no network traffic.
	max-message	Sets the maximum size limit for incoming messages.
	transport	Defines a transport configuration for a WSMA profile.

Command	Description
wsma profile listener	Configures and enables a WSMA listener profile.
wsse	Enables the WSSE for a WSMA profile.

system (ERM policy)

To configure system level resource owners (ROs), use the **system** command in Embedded Resource Manager (ERM) policy configuration mode.

system

Syntax Description This command has no arguments or keywords.

Command Default No system level ROs are configured.

Command Modes ERM policy configuration

Command History	Release	Modification
	12.3(14)T	This command was introduced.
	12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.

Examples The following example shows how to configure system level ROs:

```
Router(config-erm-policy) # system
```

Related Commands	Command	Description
	buffer public	Enters the buffer owner configuration mode and sets thresholds for buffer usage.
	cpu interrupt	Enters the CPU owner configuration mode and sets thresholds for interrupt level CPU utilization.
	cpu process	Enters the CPU owner configuration mode and sets thresholds for processor level CPU utilization.
	cpu total	Enters the CPU owner configuration mode and sets thresholds for total CPU utilization.
	critical rising	Sets the critical level threshold values for the buffer, CPU, and memory ROs.
	major rising	Sets the major level threshold values for the buffer, CPU, and memory ROs.
	memory io	Enters the memory owner configuration mode and sets threshold values for I/O memory.
	memory processor	Enters the memory owner configuration mode and sets threshold values for processor memory.
	minor rising	Sets the minor level threshold values for the buffer, CPU, and memory ROs.
	policy (ERM)	Configures an ERM resource policy.
	resource policy	Enters ERM configuration mode.
	show resource all	Displays all the resource details.

tclquit

To quit the interactive Tool Command Language (Tcl) shell, use the **tclquit** command in privileged EXEC mode.

tclquit

Syntax Description

This command has no arguments or keywords.

Defaults

The Tcl shell is disabled.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(2)T	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.

Examples

The following example shows how to disable the interactive Tcl shell:

```
Router# tclsh
Router(tcl)#
Router(tcl)# tclquit
Router#
```

Related Commands

Command	Description
tclsh	Enables the interactive Tcl shell.
tclsafe	Enables the interactive Tcl shell untrusted safe mode.

tclsafe

To enable the interactive Tool Command Language (Tcl) shell untrusted safe mode, use the **tclsafe** command in privileged EXEC mode. To exit from the safe mode, use the **exit** or the **tclquit** command.

tclsafe

exit | tclquit

Syntax Description This command has no arguments or keywords.

Command Default The Tcl shell untrusted safe mode is disabled.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.4(15)T	This command was introduced.

Usage Guidelines Use the **tclsafe** command when you want to manually run Tcl commands from the Cisco IOS command-line interface (CLI) in untrusted safe mode. When you use the **tclsafe** command and enter the interactive Tcl shell safe mode, you can explore the safe mode Tcl commands that are available. When a script fails the signature check for a configured trustpoint name, it is determined to be untrusted. Untrusted Tcl scripts execute in limited safe mode, if **scripting tcl trustpoint untrusted safe-execute** command is configured. In order to get a better understanding of what is available in this limited safe mode, use the **tclsafe** Exec command to explore the options.

After Tcl commands are entered they are sent to a Tcl interpreter. If the commands are recognized as valid Tcl commands, the command is executed and the result is sent to the tty. If a command is not a recognized Tcl command, it is sent to the Cisco IOS CLI parser. If the command is not a Tcl or Cisco IOS command, two error messages are displayed.

A predefined Tcl script can be created outside of Cisco IOS software, transferred to flash or disk memory, and run within Cisco IOS software. It is also possible to create a Tcl script and precompile the code before running it under Cisco IOS software. To exit from this mode, use the **exit** or the **tclquit** command to disable the use of the Tcl shell and return to privileged EXEC mode.

You can also use the **tclsafe** command with a script name such as **tclsafe disk0:hello.tcl**. The script **hello.tcl** executes immediately and allows you to exit from the untrusted safe mode and return to privileged EXEC mode.

Examples The following example shows how to enable the Tcl shell untrusted safe mode and run **info** commands:

```
Router# tclsafe
Router(safe)(tcl)# info commands
info commands
```

```
tell socket subst open eof glob list pid time eval lrange tcl_trace fblocked lsearch gets
case lappend proc break variable llength return linsert error catch clock info split array
if fconfigure concat join lreplace source fcopy global switch update close cd for file
append format read package set binary namespace scan seek while flush after vwait uplevel
continue hostname foreach rename fileevent regexp upvar unset encoding expr load regsub
interp history puts incr lindex lsort string
```

The following example shows how to execute the script **hello.tcl** to exit from the untrusted safe mode and return to privileged EXEC mode.

```
Router# tclsafe disk0:hello.tcl
```

Related Commands

Command	Description
scripting tcl trustpoint untrusted	Allows the interactive Tcl scripts to run regardless of the scripts failing the signature check.
tclquit	Quits Tcl shell.
tclsh	Enables the interactive Tcl shell and enters Tcl configuration mode.

tclsh

To enable the interactive Tool Command Language (Tcl) shell, use the **tclsh** command in privileged EXEC mode.

tclsh

Syntax Description This command has no arguments or keywords.

Defaults The Tcl shell is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.3(2)T	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.

Usage Guidelines Use the **tclsh** command when you want to run Tcl commands from the Cisco IOS command-line interface (CLI). When the interactive Tcl shell is enabled and Tcl configuration mode is entered, Tcl commands can be entered line by line or a predefined Tcl script can be run. After Tcl commands are entered they are sent to a Tcl interpreter. If the commands are recognized as valid Tcl commands, the command is executed and the result is sent to the tty. If a command is not a recognized Tcl command, it is sent to the Cisco IOS CLI parser. If the command is not a Tcl or Cisco IOS command, two error messages will be displayed.

A predefined Tcl script can be created outside of Cisco IOS software, transferred to Flash or disk memory, and run within Cisco IOS software. It is also possible to create a Tcl script and precompile the code before running it under Cisco IOS.

Use the **exit** or the **tclquit** command to disable the use of the Tcl shell and return to privileged EXEC mode.

Examples The following example shows how to enable the Tcl interactive shell:

```
Router# tclsh
Router(tcl)#
```

template (cns)

To specify a list of Cisco Networking Services (CNS) connect templates within a CNS connect profile to be applied to a router’s configuration, use the **template** command in CNS connect configuration mode. To disable this CNS connect template, use the **no** form of this command.

template *name* [...*name*]

no template *name* [...*name*]

Syntax Description	<i>name</i>	Name of the CNS connect template to be applied to a router’s configuration.
	[... <i>name</i>]	Multiple <i>name</i> arguments, which are delimited by a single space. The ellipsis (...) in the command syntax indicates that the command input can include multiple names.

Command Default	No CNS connect templates are specified.
-----------------	---

Command Modes	CNS connect configuration
---------------	---------------------------

Command History	Release	Modification
	12.3(2)XF	This command was introduced.
	12.3(8)T	This command was integrated into Cisco IOS Release 12.3(8)T.
	12.3(9)	This command was integrated into Cisco IOS Release 12.3(9).

Usage Guidelines First use the **cns connect** command to enter CNS connect configuration mode and define the parameters of a CNS connect profile for connecting to the CNS configuration engine. Then use the following CNS connect commands to create a CNS connect profile:

- **discover**
- **template**

A CNS connect profile specifies the **discover** commands and associated **template** commands that are to be applied to a router’s configuration. The **template** command specifies the list of CNS connect templates that is to be applied to a router’s configuration. The templates in the list are applied one at a time. That is, when the **template** command is processed, the first template in the list is applied to the router’s configuration. The router then tries to ping the CNS configuration engine. If the ping fails, then the first template in the list is removed from the router’s configuration and the second template in the list is applied and so on.

The configuration mode in which the CNS connect templates are applied is specified by the immediately preceding **discover** command. (If there are no preceding **discover** commands, the templates are applied in global configuration mode.) When multiple **discover** and **template** commands are configured in a CNS connect profile, they are processed in the order in which they are entered.

Examples

The following example shows how to create a CNS connect profile named profile-1:

```
Router(config)# cns connect profile-1
Router(config-cns-conn)# discover interface Serial
Router(config-cns-conn)# template temp-A1 temp-A2
Router(config-cns-conn)# template temp-B1 temp-B2
Router(config-cns-conn)# exit
Router(config)#
```

In this example, the following sequence of events occur for all serial interfaces when the **cns connect profile-1** command is processed. Assume all ping attempts to the CNS configuration engine are unsuccessful.

1. Enter interface configuration mode and apply all commands in the temp-A1 template to the router's configuration.
2. Enter interface configuration mode and apply all commands in the temp-B1 template to the router's configuration.
3. Try to ping the CNS configuration engine.
4. Enter interface configuration mode and remove all commands in the temp-B1 template from the router's configuration.
5. Enter interface configuration mode and apply all commands in the temp-B2 template to the router's configuration.
6. Try to ping the CNS configuration engine.
7. Enter interface configuration mode and remove all commands in the temp-B2 template from the router's configuration.
8. Enter interface configuration mode and remove all commands in the temp-A1 template from the router's configuration.
9. Enter interface configuration mode and apply all commands in the temp-A2 template to the router's configuration.
10. Enter interface configuration mode and apply all commands in the temp-B1 template to the router's configuration.
11. Try to ping the CNS configuration engine.
12. Enter interface configuration mode and remove all commands in the temp-B1 template from the router's configuration.
13. Enter interface configuration mode and apply all commands in the temp-B2 template to the router's configuration.
14. Try to ping the CNS configuration engine.
15. Enter interface configuration mode and remove all commands in the temp-B2 template from the router's configuration.
16. Enter interface configuration mode and remove all commands in the temp-A2 template from the router's configuration.

Related Commands

Command	Description
cli (cns)	Specifies the command lines of a CNS connect template.
cns connect	Enters CNS connect configuration mode and defines the parameters of a CNS connect profile for connecting to the CNS configuration engine.

Command	Description
cns template connect	Enters CNS template connect configuration mode and defines the name of a CNS connect template.
discover (cns)	Defines the interface parameters within a CNS connect profile for connecting to the CNS configuration engine.

terminal shell

To enable Cisco IOS Shell (IOS.sh) functions on the router use the **terminal shell** command in privileged EXEC mode. To disable Cisco IOS.sh functions, use the **no** form of this command.

terminal shell [trace]

terminal no shell

Syntax Description

trace	Turns on the trace feature on the shell functions that prints the CLI as they are applied.
--------------	--

Add trace if it is available [If the trace option is given, it will turn on the trace on the shell functions that prints the CLI as they are applied.]

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.1(4)M	This command was introduced.
15.1(2)S	This command was integrated into Cisco IOS Release 15.1(2)S.

Usage Guidelines

You can turn shell processing on the terminal by using the **terminal shell** command. However shell processing feature is only on while the terminal is running. Once the terminal is turned off, shell processing is off. When the **terminal shell** command is used, shell processing is not visible in the running configuration because it is only on the terminal level and is not in the configuration level. It is convenient to use the **terminal shell** command at the terminal level to quickly access the Cisco IOS.sh man commands. To enable shell processing in the configuration, it is recommended that you use the **shell processing full** command.

Examples

The following examples shows how to enable Cisco IOS.sh functions on the router and enable the trace feature:

```
Router# terminal shell
Router# terminal shell
Router# terminal shell trace
```

The following examples shows how to disable Cisco IOS.sh functions on the router:

```
Router# terminal no shell
```

test (event trigger)

Command	Description
shell processing full	Enables Cisco IOS.sh processing on the router in global configuration mode.
To specify the type of test to perform during an event trigger, use the test command in event trigger configuration mode. To disable the trigger test configuration settings, use the no form of this command.	
test {existence boolean threshold}	
no test {existence boolean threshold}	

Syntax Description	existence	Description
	existence	Enables the existence trigger test.
	boolean	Enables the Boolean trigger test. Boolean test is the default trigger test performed during event triggers.
	threshold	Enables the threshold trigger test.

Command Default	The Boolean trigger test is enabled by default.
-----------------	---

Command Modes	Event trigger configuration (config-event-trigger)
---------------	--

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines	<p>The trigger table in the Event MIB has supplementary tables for additional objects that are configured based on the type of test performed for the trigger. For each trigger entry type such as existence, threshold, or Boolean, the corresponding tables (existence, threshold, and Boolean tables) are populated with the information required to perform the test. You can set event triggers based on existence, threshold, and Boolean trigger types.</p>
------------------	--

The existence trigger tests are performed based on the following parameters:

- Absent
- Present
- Changed

The Boolean tests are comparison tests that are performed based on one of the following parameters:

- Unequal
- Equal
- Less
- Less Or Equal
- Greater

- Greater Or Equal

The threshold tests are performed based on the following parameters:

- Rising
- Falling
- Rising or Falling

Examples

The following example shows how to enable the existence trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)#
```

The following example shows how to enable the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)#
```

The following example shows how to enable the threshold trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test threshold
Router(config-event-trigger-threshold)#
```

Related Commands

Command	Description
comparison	Specifies the type of Boolean test comparison to perform.
event owner	Specifies an owner for event trigger.
object list owner	Specifies an owner for the list of objects configured for an event.
startup	Specifies whether an event can be triggered during a trigger test.
value	Sets a value to the object.

test snmp trap auth-framework sec-violation

To test CISCO-AUTH-FRAMEWORK-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap auth-framework sec-violation** command in privileged EXEC mode.

test snmp trap auth-framework sec-violation

Syntax Description This command has no keywords or arguments.

Command Default This command has no default setting.

Command Modes Privileged EXEC mode

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.

Examples This example shows the output of the SNMP camSecurityViolationNotif trap when it is not configured:

```
Router# test snmp trap auth-framework sec-violation
cafSecurityViolationNotif was disabled.
Router#
```

This example shows the output of the SNMP camSecurityViolationNotif trap when it is configured:

```
Router# test snmp trap auth-framework sec-violation
cafSecurityViolationNotif was sent.
Router#
```


test snmp trap bridge

To test BRIDGE-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap bridge** command in privileged EXEC mode.

test snmp trap bridge {newroot | topologychange}

Syntax Description	newroot	Tests SNMP newRoot notifications.
	topologychange	Tests SNMP topologyChange notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of **test snmp trap bridge newroot** when snmp-server enable traps bridge newroot is not configured:

```
Router# test snmp trap bridge newroot
newRoot notification is disabled.
Router#
```

This example shows the output of **test snmp trap bridge newroot** when snmp-server enable traps bridge newroot is configured:

```
Router# test snmp trap bridge newroot
newRoot notification was sent.
Router#
```

Related Commands	Command	Description
	snmp-server enable traps bridge	Enables the SNMP BRIDGE-MIB notifications.

test snmp trap c6kxbar

To test CISCO-CAT6K-CROSSBAR-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap c6kxbar** command in priveleged EXEC mode.

```
test snmp trap c6kxbar { flowctrl-bus | intbus-crcvrd | intbus-crcexcd | swbus |
tm-channel-above | tm-channel-below | tm-swbus-above | tm-swbus-below }
```

Syntax Description	flowctrl-bus	Tests SNMP cc6kxbarFlowCtrlBusThrExcdNotif notifications.
	intbus-crcvrd	Tests SNMP cc6kxbarIntBusCRCErrRcvrdNotif notifications.
	intbus-crcexcd	Tests SNMP cc6kxbarIntBusCRCErrExcdNotif notifications.
	swbus	Tests SNMP cc6kxbarSwBusStatusChangeNotif notifications.
	tm-channel-above	Tests cc6kxbarTMChUtilAboveNotif notifications.
	tm-channel-below	Tests cc6kxbarTMChUtilBelowNotif notifications.
	tm-swbus-above	Tests cc6kxbarTMSwBusUtilAboveNotif notifications.
	tm-swbus-below	Tests cc6kxbarTMSwBusUtilBelowNotif notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.
	12.2(33)SX15	Added tm-channel-above , tm-channel-below and tm-swbus-above , tm-channel-below keywords.

Usage Guidelines The **flowctrl-bus** keyword is supported on the Supervisor Engine 32 only.
The **tm-channel-above** and **tm-channel-below** keywords are not supported on Supervisor Engine 32.

Examples This example shows the output of the SNMP cc6kxbarFlowCtrlBusThrExcdNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar flowctrl-bus
cc6kxbarFlowCtrlBusThrExcdNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarFlowCtrlBusThrExcdNotif notification when it is configured:

```
Router# test snmp trap c6kxbar flowctrl-bus
cc6kxbarFlowCtrlBusThrExcdNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarIntBusCRCErrExcdNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar intbus-crcexcd
cc6kxbarIntBusCRCErrExcdNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarIntBusCRCErrExcdNotif notification when it is configured:

```
Router# test snmp trap c6kxbar intbus-crcexcd
cc6kxbarIntBusCRCErrExcdNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarIntBusCRCErrRcvrdNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar intbus-crcvrd
cc6kxbarIntBusCRCErrExcdNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarIntBusCRCErrRcvrdNotif notification when it is configured:

```
Router# test snmp trap c6kxbar intbus-crcvrd
cc6kxbarIntBusCRCErrExcdNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarSwBusStatusChangeNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar swbus
cc6kxbarSwBusStatusChangeNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarSwBusStatusChangeNotif notification when it is configured:

```
Router# test snmp trap c6kxbar swbus
cc6kxbarSwBusStatusChangeNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarTMChUtilAboveNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar tm-channel-above
cc6kxbarTMChUtilAboveNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarTMChUtilAboveNotif notification when it is configured:

```
Router# test snmp trap c6kxbar tm-channel-above
cc6kxbarTMChUtilAboveNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarTMChUtilBelowNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar tm-channel-below
cc6kxbarTMChUtilBelowNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarTMChUtilBelowNotif notification when it is configured:

```
Router# test snmp trap c6kxbar tm-channel-below
cc6kxbarTMChUtilBelowNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarTMSwBusUtilAboveNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar tm-swbus-above
cc6kxbarTMSwBusUtilAboveNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarTMSwBusUtilAboveNotif notification when it is configured:

```
Router# test snmp trap c6kxbar tm-swbus-above
cc6kxbarTMSwBusUtilAboveNotif notification was sent.
Router#
```

This example shows the output of the SNMP cc6kxbarTMSwBusUtilBelowNotif notification when it is not configured:

```
Router# test snmp trap c6kxbar tm-swbus-below
cc6kxbarTMSwBusUtilBelowNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cc6kxbarTMSwBusUtilBelowNotif notification when it is configured:

```
Router# test snmp trap c6kxbar tm-swbus-below
cc6kxbarTMSwBusUtilBelowNotif notification was sent.
Router#
```

Related Commands

Command	Description
snmp-server enable traps c6kxbar	Enables the SNMP c6kxbar notification traps.

test snmp trap call-home

To test CISCO-CALLHOME-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap call-home** command in privileged EXEC mode.

test snmp trap call-home {message-send-fail | server-fail}

Syntax Description	message-send-fail	Tests SNMP ccmSmtplibMsgSendFailNotif notifications.
	server-fail	Tests SNMP ccmSmtplibServerFailNotif notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.

Examples

This example shows the output of the SNMP ccmSmtplibMsgSendFailNotif notification when it is not configured:

```
Router# test snmp trap call-home message-send-fail
ccmSmtplibMsgSendFailNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ccmSmtplibMsgSendFailNotif notification when it is configured:

```
Router# test snmp trap call-home message-send-fail
ccmSmtplibMsgSendFailNotif notification was sent.
Router#
```

This example shows the output of the SNMP ccmSmtplibServerFailNotif notification when it is not configured:

```
Router# test snmp trap call-home server-fail
ccmSmtplibServerFailNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ccmSmtplibServerFailNotif notification when it is configured:

```
Router# test snmp trap call-home server-fail
ccmSmtplibServerFailNotif notification was sent.
Router#
```

test snmp trap config-copy

To verify the reception of config-copy notifications by the Network Management System (NMS) or the Simple Network Management Protocol (SNMP) manager in a simulated scenario, use the **test snmp trap config-copy** command in privileged EXEC mode.

test snmp trap config-copy

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines The Config-Copy MIB facilitates the copying of SNMP agent configuration files to the startup configuration or the local Cisco IOS file system, and vice versa. The config-copy notifications are sent to the NMS or the SNMP manager to indicate the successful completion of config-copy operation to or from the SNMP agent.

Examples The following example shows how to simulate the verification of config-copy traps:

```
Router# test snmp trap config-copy

Generating CONFIG-COPY-MIB trap

00:20:44: SNMP: Queuing packet to 10.2.14.2
00:20:44: SNMP: V2 Trap, reqid 2, errstat 0, erridx 0
sysUpTime.0 = 124470
snmpTrapOID.0 = ccCopyMIBTraps.1
ccCopyTable.1.5.2 = 10.10.10.10
ccCopyTable.1.6.2 =
ccCopyTable.1.10.2 = 3
ccCopyTable.1.11.2 = 124470
ccCopyTable.1.12.2 = 124470
Router#
```

Related Commands	Command	Description
	debug snmp packet	Displays information about every SNMP packet sent or received by the router.
	snmp-server enable traps	Enables all SNMP notification types that are available on your system.
	snmp-server host	Specifies the recipient of an SNMP notification operation.

test snmp trap dhcp bindings

To test the cdsBindingsNotification trap, use the **test snmp trap dhcp bindings** EXEC command.

test snmp trap dhcp bindings

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Defaults	This command has no default settings.
-----------------	---------------------------------------

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(33)SXI	Support for this command was introduced on the Catalyst 6500 series switch.

Examples	This example shows how to test the cdsBindingsNotification traps:
-----------------	---

```
Router# test snmp trap dhcp bindings
cdsBindingsNotification notification is disabled.
```

test snmp trap dhcp-snooping bindings

To test the cdsBindingsNotification trap, use the **test snmp trap dhcp-snooping bindings** privileged EXEC command.

test snmp trap dhcp-snooping bindings

Syntax Description This command has no keywords or arguments.

Defaults This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SX14	Support for this command was introduced on the Catalyst 6500 series.

Examples This example shows how to test the cdsBindingsNotification trap:

```
Router# test snmp trap dhcp-snooping bindings
cdsBindingsNotification notification is disabled.
```


test snmp trap dot1x

To test CISCO-PAE-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap dot1x** command in privileged EXEC mode.

test snmp trap dot1x {auth-fail-vlan | guest-vlan | no-auth-fail-vlan | no-guest-vlan}

Syntax Description	auth-fail-vlan	Tests SNMP cpaeAuthFailVlanNotif notifications.
	guest-vlan	Tests SNMP cpaeGuestVlanNotif notifications.
	no-auth-fail-vlan	Tests SNMP cpaeNoAuthFailedVlanNotif notifications.
	no-guest-vlan	Tests SNMP cpaeNoGuestVlanNotif notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.

Examples

This example shows the output of the SNMP cpaeAuthFailVlanNotif notification when it is not configured:

```
Router# test snmp trap dot1x auth-fail-vlan
cpaeAuthFailVlanNotif notification was disabled.
Router#
```

This example shows the output of the SNMP cpaeAuthFailVlanNotif notification when it is configured:

```
Router# test snmp trap dot1x auth-fail-vlan
cpaeAuthFailVlanNotif notification was sent.
Router#
```

test snmp trap entity-diag

To test CISCO-ENTITY-DIAG-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap c6kxbar** command in privileged EXEC mode.

```
test snmp trap entity-diag { boot-up-fail | hm-test-recover | hm-thresh-reached |
                             scheduled-test-fail }
```

Syntax Description	boot-up-fail	Tests SNMP ceDiagBootUpFailedNotif notifications.
	hm-test-recover	Tests SNMP ceDiagHMTTestRecoverNotif notifications.
	hm-thresh-reached	Tests SNMP ceDiagHMThresholdReachedNotif notifications.
	scheduled-test-fail	Tests SNMP ceDiagScheduledTestFailedNotif notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.

Examples This example shows the output of the SNMP ceDiagBootupFailedNotif notification when it is not configured:

```
Router# test snmp trap entity-diag boot-up-fail
ceDiagBootupFailedNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ceDiagBootupFailedNotif notification when it is configured:

```
Router# test snmp trap entity-diag boot-up-fail
ceDiagBootupFailedNotif notification was sent.
Router#
```

This example shows the output of the SNMP ceDiagHMTTestRecoverNotif notification when it is not configured:

```
Router# test snmp trap dot1x hm-test-recover
ceDiagHMTTestRecoverNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ceDiagHMTTestRecoverNotif notification when it is configured:

```
Router# test snmp trap dot1x hm-test-recover
ceDiagHMTTestRecoverNotif notification was sent.
Router#
```

This example shows the output of the SNMP ceDiagHMThresholdReachedNotif notification when it is not configured:

```
Router# test snmp trap entity-diag hm-thresh-reached
ceDiagHMThresholdReachedNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ceDiagHMThresholdReachedNotif notification when it is configured:

```
Router# test snmp trap entity-diag hm-thresh-reached
ceDiagHMThresholdReachedNotif notification was sent.
Router#
```

This example shows the output of the SNMP ceDiagScheduledTestFailedNotif notification when it is not configured:

```
Router# test snmp trap entity-diag scheduled-test-fail
ceDiagHMThresholdReachedNotif notification is disabled.
Router#
```

This example shows the output of the SNMP ceDiagScheduledTestFailedNotif notification when it is configured:

```
Router# test snmp trap entity-diag scheduled-test-fail
ceDiagHMThresholdReachedNotif notification was sent.
Router#
```

test snmp trap errdisable ifevent

To test CISCO-ERR-DISABLE-MIB cErrDisableInterfaceEventRev1 Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap errdisable ifevent** command in privileged EXEC mode.

test snmp trap errdisable ifevent

Syntax Description This command has no keywords or arguments.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SX14	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of **test snmp trap errdisable ifevent** when snmp-server enable traps errdisable is not configured:

```
Router# test snmp trap errdisable ifevent
cErrDisableInterfaceEventRev1 notification is disabled.
Router#
```

This example shows the output of **test snmp trap errdisable ifevent** when snmp-server enable traps errdisable is configured:

```
Router# test snmp trap errdisable ifevent
cErrDisableInterfaceEventRev1 notification was sent.
Router#
```

Related Commands	Command	Description
	snmp-server enable traps errdisable	Enables SNMP errdisable notifications.

test snmp trap flex-links status

To test CISCO-FLEX-LINKS-MIB cflIfStatusChangeNotif traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap flex-links status** command in privileged EXEC mode.

test snmp trap flex-links status

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	This command has no default settings.
------------------------	---------------------------------------

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples	This example shows the output of the SNMP cflIfStatusChangeNotif trap when it is not configured:
-----------------	--

```
Router# test snmp trap flex-links status
cflIfStatusChangeNotifnotification is disabled.
Router#
```

This example shows the output of the SNMP cflIfStatusChangeNotif trap when it is configured:

```
Router# test snmp trap flex-links status
cflIfStatusChangeNotif notification was sent.
Router#
```

test snmp trap fru-ctrl

To test CISCO-ENTITY-FRU-CONTROL-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap fru-ctrl** command in privileged EXEC mode.

test snmp trap fru-ctrl {insert | module-status | power-status | ps-out-change | remove}

Syntax Description	insert	Tests SNMP cefcFRUInserted notifications.
	module-status	Tests SNMP cefcModuleStatusChange notifications.
	power-status	Tests SNMP cefcPowerStatusChange notifications.
	ps-out-change	Tests SNMP cefcPowerSupplyOutputChange notifications.
	remove	Tests SNMP cefcFRURemoved notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the test SNMP cefcFRUInserted trap when it is not configured:

```
Router# test snmp trap fru-ctrl insert
cefcFRUInserted notification is disabled.
Router#
```

This example shows the output of the SNMP cefcFRUInserted trap when it is configured:

```
Router# test snmp trap fru-ctrl insert
cefcFRUInserted notification was sent.
Router#
```

test snmp trap l2-control vlan

To test CISCO-ENTITY-FRU-CONTROL-MIB clcVLANMacLimitNotif traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap l2-control vlan** command in privileged EXEC mode.

test snmp trap l2-control vlan

Syntax Description This command has no keywords or arguments.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the clcVLANMacLimitNotif trap when it is not configured:

```
Router# test snmp trap l2-control vlan
clcVLANMacLimitNotif notification is disabled.
Router#
```

This example shows the output of the SNMP clcVLANMacLimitNotif trap when it is configured:

```
Router# test snmp trap l2-control vlan
clcVLANMacLimitNotif notification was sent.
Router#
```

test snmp trap l2tc

To test CISCO-L2-TUNNEL-CONFIG-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap l2tc** command in privileged EXEC mode.

test snmp trap l2tc {drop | shutdown | sys-threshold}

Syntax Description	drop	Tests SNMP cltcTunnelDropThresholdExceeded notifications.
	shutdown	Tests SNMP cltcTunnelShutdwonThresholdExceeded notifications.
	sys-threshold	Tests SNMP cltcTunnelSysDropThresholdExceeded notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the cltcTunnelDropThresholdExceeded trap when it is not configured:

```
Router# test snmp trap l2tc drop
cltcTunnelDropThresholdExceeded notification is disabled.
Router#
```

This example shows the output of the SNMP cltcTunnelDropThresholdExceeded trap when it is configured:

```
Router# test snmp trap l2tc drop
cltcTunnelDropThresholdExceeded notification was sent.
Router#
```


test snmp trap mac-notification

To test CISCO-MAC-NOTIFICATION-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap mac-notification** command in privileged EXEC mode.

test snmp trap mac-notification { change | move | threshold }

Syntax Description	change	Tests SNMP cmnMacChangeNotification notifications.
	move	Tests SNMP cmnMacMoveNotification notifications.
	threshold	Tests SNMP cmnMacThresholdExceedNotif notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the SNMP cmnMacChangeNotification trap when it is not configured:

```
Router# test snmp trap mac-notification change
cmnMacChangeNotification notification is disabled.
Router#
```

This example shows the output of the SNMP cmnMacChangeNotification trap when it is configured:

```
Router# test snmp trap mac-notification change
cmnMacChangeNotification notification was sent.
Router#
```

test snmp trap module-auto-shutdown

To test CISCO-MODULE-AUTO-SHUTDOWN-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap module-auto-shutdown** command in privileged EXEC mode.

```
test snmp trap module-auto-shutdown { auto-shutdown | sys-action }
```

Syntax Description	auto-shutdown	Tests SNMP cmasModuleAutoShutdown notifications.
	sys-action	Tests SNMP cmasModuleSysActionNotif notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples

This example shows the output of the SNMP cmasModuleAutoShutdown trap when it is not configured:

```
Router# test snmp trap module-auto-shutdown auto-shutdown
cmasModuleAutoShutdown notification is disabled.
Router#
```

This example shows the output of the SNMP cmasModuleAutoShutdown trap when it is configured:

```
Router# test snmp trap module-auto-shutdown auto-shutdown
cmasModuleAutoShutdown notification is sent.
Router#
```

test snmp trap port-security

To test CISCO-PORT-SECURITY-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap port-security** command in privileged EXEC mode.

test snmp trap port-security {ifvlan-mac | mac}

Syntax Description	ifvlan-mac	Tests SNMP cpsIfVlanSecureMacAddrViolation notifications.
	mac	Tests SNMP cpsSecureMacAddrViolation notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the SNMP cpsIfVlanSecureMacAddrViolation trap when it is not configured:

```
Router# test snmp trap port-security ifvlan-mac
cpsIfVlanSecureMacAddrViolation notification is disabled.
Router#
```

This example shows the output of the SNMP cpsIfVlanSecureMacAddrViolation trap when it is configured:

```
Router# test snmp trap port-security ifvlan-mac
cpsIfVlanSecureMacAddrViolation notification was sent.
Router#
```

test snmp trap power-ethernet port-on-off

To test POWER-ETHERNET-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap power-ethernet** command in privileged EXEC mode.

test snmp trap power-ethernet port-on-off

Syntax Description

This command has no keywords or arguments.

Command Default

This command has no default settings.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples

This example shows the output of the SNMP pethPsePortOnOffNotification trap when it is not configured:

```
Router# test snmp trap power-ethernet port-on-off
pethPsePortOnOffNotification notification is disabled.
Router#
```

This example shows the output of the SNMP pethPsePortOnOffNotification trap when it is configured:

```
Router# test snmp trap power-ethernet port-on-off
pethPsePortOnOffNotification notification was sent.
Router#
```

test snmp trap snmp

To verify the reception of Simple Network Management Protocol (SNMP) notifications by the Network Management System (NMS) or the SNMP manager in a simulated scenario, use the **test snmp trap snmp** command in privileged EXEC mode.

test snmp trap snmp {authentication | coldstart | linkup | linkdown | warmstart}

Syntax Description		
authentication		Verifies the generation and reception of the SNMP authentication failure notification by the SNMP manager. The authentication failure trap indicates that the SNMP agent has received a protocol message from the SNMP manager that is not properly authenticated.
coldstart		Verifies the generation and reception of the SNMP coldStart notifications by the SNMP manager. A coldStart trap indicates that the SNMP agent is reinitializing and its configuration may have changed.
linkup		Verifies the generation and reception of the SNMP linkUp notifications by the SNMP manager. A linkUp trap indicates if a communication link represented in the agent's configuration is activated.
linkdown		Verifies the generation and reception of the SNMP linkDown notifications by the SNMP manager. A linkDown trap indicates if a communication link represented in the agent's configuration fails.
warmstart		Verifies the generation and reception of the SNMP warmStart notifications by the SNMP manager. A warmStart trap indicates that the SNMP agent is reinitializing and its configuration is not modified.

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(33)SXI	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

SNMP traps or notifications provide information about improper user authentication, restarts, closing of a connection, loss of connection to a neighbor router, or other significant events to the NMS.

Before testing the SNMP traps, configure the SNMP manager for the device and enable SNMP traps.

Examples

The following example shows how to simulate the verification of the authentication failure trap:

```
Router# test snmp trap snmp authentication
```

```
Generating Authentication failure trap
```

```
Sep 12 08:37:49.935: SNMP: Queuing packet to 10.4.9.2
```

```
Sep 12 08:37:49.935: SNMP: V1 Trap, ent snmpTraps, addr 192.168.0.1, gentrap 4  
lsystem.5.0 = 10.10.10.10
```

```
ciscoMgmt.412.1.1.1.0 = 1
ciscoMgmt.412.1.1.2.0 = 10.10.10.10
Sep 12 08:38:55.995: SNMP: Packet sent via UDP to 10.4.9.2
Sep 12 08:38:56.263: SNMP: Packet sent via UDP to 10.4.9.2
```

Related Commands

Command	Description
debug snmp packet	Displays information about every SNMP packet sent or received by the router.
snmp-server enable traps	Enables all SNMP notification types that are available on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.

test snmp trap stack

To test CISCO-STACK-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap stack** command in privileged EXEC mode.

test snmp trap stack { chassis-off | chassis-on | module-down | module-up }

Syntax Description	chassis-off	Test SNMP chassisAlarmOff notifications.
	chassis-on	Tests SNMP chassisAlarmOn notifications.
	module-down	Tests SNMP moduleDown notifications.
	module-up	Tests SNMP moduleUp notifications.

Command Default	This command has no default settings.
-----------------	---------------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples	This example shows the output of the SNMP chassisAlarmOff trap when it is not configured:
----------	---

```
Router# test snmp trap stack chassis-off
chassisAlarmOff notification is disabled.
Router#
```

This example shows the output of the SNMP chassisAlarmOff trap when it is configured:

```
Router# test snmp trap stack chassis-off
chassisAlarmOff notification was sent.
Router#
```

test snmp trap storm-control

To test the Simple Network Management Protocol (SNMP) CISCO-PORT-STORM-CONTROL-MIB traps, use the **test snmp trap storm-control** command in privileged EXEC mode.

test snmp trap storm-control {event-rev1}

Syntax Description	event-rev1	Tests the cpscEventRev1 trap.
---------------------------	-------------------	-------------------------------

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(33)SXJ	This command was introduced.

Usage Guidelines	SNMP traps or notifications provide information about storm-control events.
-------------------------	---

Examples	<p>The following example shows how to test the SNMP CISCO-PORT-STORM-CONTROL-MIB trap:</p> <pre>Router# test snmp trap storm-control event-rev1 cpscEventRev1 notification was sent. Router#</pre>
-----------------	--

Related Commands	Command	Description
	snmp-server enable traps storm-control	Enables SNMP storm-control trap notifications.
	snmp-server host	Specifies the recipient of an SNMP notification operation.

test snmp trap stpx

To test CISCO-STP-EXTENSIONS-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap stpx** command in privileged EXEC mode.

test snmp trap stpx {inconsistency | loop-inconsistency | root-inconsistency}

Syntax Description	inconsistency	Tests SNMP stpxInconsistencyUpdate notifications.
	loop-inconsistency	Tests SNMP stpxLoopInconsistencyUpdate notifications.
	root-inconsistency	Tests SNMP stpxRootInconsistencyUpdate notifications.

Command Default This command has no default settings.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the SNMP stpxInconsistencyUpdate trap when it is not configured:

```
Router# test snmp trap stpx inconsistency
stpxInconsistencyUpdate notification is disabled.
Router#
```

This example shows the output of the SNMP stpxInconsistencyUpdate trap when it is configured:

```
Router# test snmp trap stpx inconsistency
stpxInconsistencyUpdate notification was sent.
Router#
```

test snmp trap syslog

To verify the reception of the system logging message Simple Network Management Protocol (SNMP) notifications by the SNMP manager in a simulated scenario, use the **test snmp trap syslog** command in privileged EXEC mode.

test snmp trap syslog

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SXI	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines System logging messages are status notification messages that are generated by the routing device during operation. These messages are typically logged to a destination such as the terminal screen, or to a remote syslog host.

Examples The following example shows how to replicate a syslog trap and its reception by the NMS:

```
Router# test snmp trap syslog

Generating SYSLOG-MIB Trap

00:07:25: SNMP: Queuing packet to 10.4.9.2
00:07:25: SNMP: V1 Trap, ent ciscoSyslogMIB.2, addr 192.16.12.8, gentrap 6, spectra
clogHistoryEntry.2.1 = TEST
clogHistoryEntry.3.1 = 5
clogHistoryEntry.4.1 = 1.3.6.1.4.1.9.9.10.1
clogHistoryEntry.5.1 = Syslog test trap
clogHistoryEntry.6.1 = 44596
00:07:25: SNMP: Queuing packet to 10.4.9.2
00:07:25: SNMP: V2 Trap, reqid 4, errstat 0, erridx 0
sysUpTime.0 = 44596
snmpTrapOID.0 = ciscoSyslogMIB.2.0.1
clogHistoryEntry.2.1 = TEST
clogHistoryEntry.3.1 = 5
clogHistoryEntry.4.1 = 1.3.6.1.4.1.9.9.10.1
clogHistoryEntry.5.1 = Syslog test trap
clogHistoryEntry.6.1 = 44596
```

Related Commands

Command	Description
debug snmp packet	Displays information about every SNMP packet sent or received by the router.
snmp-server enable traps	Enables all SNMP notification types that are available on your system.
snmp-server host	Specifies the recipient of an SNMP notification operation.

test snmp trap udld

To test CISCO-UDLD-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap udld** command in privileged EXEC mode.

test snmp trap udld {link-fail-rpt | status-change}

Syntax Description	link-fail-rpt	Tests SNMP cudldpFastHelloLinkFailRptNotification notifications.
	status-change	Tests SNMP cudldFastHelloStatusChangeNotification notifications.

Command Default This command has no default setting.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SX14	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples This example shows the output of the SNMP cudldpFastHelloLinkFailRptNotification notification when it is not configured:

```
Router# test snmp trap udld link-fail-rpt
cudldpFastHelloLinkFailRptNotification notification is disabled.
Router#
```

This example shows the output of the SNMP cudldpFastHelloLinkFailRptNotification notification when it is configured:

```
Router# test snmp trap udld link-fail-rpt
cudldpFastHelloLinkFailRptNotification notification was sent.
Router#
```

test snmp trap vswitch vsl

To test CISCO-VIRTUAL-SWITCH-MIB Simple Network Management Protocol (SNMP) notifications (traps and informs), use the **test snmp trap vswitch vsl** command in privileged EXEC mode.

test snmp trap vswitch vsl

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	This command has no default setting.
------------------------	--------------------------------------

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	12.2(33)SXI	This command was introduced on the Supervisor Engine 720.

Examples	<p>This example shows the output of the SNMP cvsVSLConnectionChangeNotif notification when it is not configured:</p>
-----------------	--

```
Router# test snmp trap vswitch vsl
cvsVSLConnectionChangeNotif notification is disabled.
Router#
```

This example shows the output of the SNMP cvsVSLConnectionChangeNotif notification when it is configured:

```
Router# test snmp trap vswitch vsl
cvsVSLConnectionChangeNotif notification was sent.
Router#
```

test snmp trap vtp

To test CISCO-VTP-MIB traps Simple Network Management Protocol (SNMP) traps and informs, use the **test snmp trap vtp** command in privileged EXEC mode.

test snmp trap vtp {digest-error | mode-change | port-status | pruning-change | rev-error | server-disable | v1-detected | version-change | vlan-create | vlan-delete}

Syntax Description

digest-error	Tests SNMP vtpConfigDigestError notifications.
mode-change	Tests SNMP vtpLocalModeChange notifications.
port-status	Tests SNMP vlanTrunkPortDynamicStatusChange notifications.
pruning-change	Tests SNMP vtpPruningStateOperChange notifications.
rev-error	Tests SNMP vtpConfigRevNumberError notifications.
server-disable	Tests SNMP vtpServerDisabled notifications.
v1-detected	Tests SNMP vtpVersionOneDeviceDetected notifications.
version-change	Tests SNMP vtpVersionInUseChanged notifications.
vlan-create	Tests SNMP vtpVlanCreated notifications.
vlan-delete	Tests SNMP vtpVlanDeleted notifications.

Command Default

This command has no default settings.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(33)SXI	This command was introduced on the Supervisor Engine 720 and Supervisor Engine 32.

Examples

This example shows the output of the SNMP vtpConfigDigestError trap when it is not configured:

```
Router# test snmp trap vtp digest-error
vtpConfigDigestError notification is disabled.
Router#
```

This example shows the output of the SNMP vtpConfigDigestError trap when it is configured:

```
Router# test snmp trap vtp digest-error
vtpConfigDigestError notification was sent.
Router#
```

test snmp trap vtp pruning-change

To test the vtpPruningStateOperChange trap, use the **test snmp trap vtp pruning-change** EXEC command.

test snmp trap vtp pruning-change

Syntax Description This command has no keywords or arguments.

Defaults This command has no default settings.

Command Modes EXEC mode

Command History	Release	Modification
	12.2(33)SX14	Support for this command was introduced on the Catalyst 6500 series.

Examples This example shows that testing the vtpPruningStateOperChange cannot occur without first enabling SNMP VTP traps:

```
Router# test snmp trap vtp pruning-change
vtpPruningStateOperChange notification is disabled.
```

This example shows how to test the vtpPruningStateOperChange:

```
Router# test snmp trap vtp pruning-change
vtpPruningStateOperChange notification is sent.
```

Related Commands	Command	Description
	snmp-server enable traps vtp	Enables SNMP VTP traps.

time-period

To set the time increment for automatically saving an archive file of the current running configuration in the Cisco IOS configuration archive, use the **time-period** command in archive configuration mode. To disable this function, use the **no** form of this command.

```
time-period minutes

no time-period minutes
```

Syntax Description	minutes	Specifies how often, in minutes, to automatically save an archive file of the current running configuration in the Cisco IOS configuration archive.
--------------------	---------	---

Command Default	By default, no time increment is set.
-----------------	---------------------------------------

Command Modes	Archive configuration
---------------	-----------------------

Command History	Release	Modification
	12.3(7)T	This command was introduced.
	12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2(31)SB2	This command was implemented on the Cisco 10000 series router.
	12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines



Note Before using this command, you must configure the **path** command to specify the location and filename prefix for the files in the Cisco IOS configuration archive.

If this command is configured, an archive file of the current running configuration is automatically saved after the given time specified by the *minutes* argument. Archive files continue to be automatically saved at this given time increment until this function is disabled. Use the **maximum** command to set the maximum number of archive files of the running configuration to be saved.



Note This command saves the current running configuration to the configuration archive whether or not the running configuration has been modified since the last archive file was saved.

Examples

In the following example, a value of 20 minutes is set as the time increment for which to automatically save an archive file of the current running configuration in the Cisco IOS configuration archive:

```
Router# configure terminal
!
Router(config)# archive
Router(config-archive)# path disk0:myconfig
Router(config-archive)# time-period 20
Router(config-archive)# end
```

Related Commands

Command	Description
archive config	Saves a copy of the current running configuration to the Cisco IOS configuration archive.
configure confirm	Confirms replacement of the current running configuration with a saved Cisco IOS configuration file.
configure replace	Replaces the current running configuration with a saved Cisco IOS configuration file.
maximum	Sets the maximum number of archive files of the running configuration to be saved in the Cisco IOS configuration archive.
path	Specifies the location and filename prefix for the files in the Cisco IOS configuration archive.
show archive	Displays information about the files saved in the Cisco IOS configuration archive.

time-range

To enable time-range configuration mode and define time ranges for functions (such as extended access lists), use the **time-range** command in global configuration or webvpn context configuration mode. To remove the time limitation, use the **no** form of this command.

time-range *time-range-name*

no time-range *time-range-name*

Syntax Description

time-range-name Desired name for the time range. The name cannot contain either a space or quotation mark, and it must begin with a letter.

Command Default

None

Command Modes

Global configuration
Webvpn context configuration

Command History

Release	Modification
12.0(1)T	This command was introduced.
12.2(17a)SX	Support for this command was implemented on the Cisco 7600 series routers.
12.2(17d)SXB	Support for this command on the Supervisor Engine 2 was integrated into Cisco IOS Release 12.2(17d)SXB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4(11)T	This command was available in webvpn context configuration mode.

Usage Guidelines

The **time-range** entries are identified by a name, which is referred to by one or more other configuration commands. Multiple time ranges can occur in a single access list or other feature.



Note

In Cisco IOS 12.2SX releases, IP and IPX-extended access lists are the only types of access lists that can use time ranges.

After the **time-range** command, use the **periodic** time-range configuration command, the **absolute** time-range configuration command, or some combination of them to define when the feature is in effect. Multiple **periodic** commands are allowed in a time range; only one **absolute** command is allowed.



Tip

To avoid confusion, use different names for time ranges and named access lists.

Examples

The following example denies HTTP traffic on Monday through Friday from 8:00 a.m. to 6:00 p.m. The example allows UDP traffic on Saturday and Sunday from noon to midnight only.

```
time-range no-http
  periodic weekdays 8:00 to 18:00
!
time-range udp-yes
  periodic weekend 12:00 to 24:00
!
ip access-list extended strict
  deny tcp any any eq http time-range no-http
  permit udp any any time-range udp-yes
!
interface ethernet 0
  ip access-group strict in
```

Related Commands

Command	Description
absolute	Specifies an absolute start and end time for a time range.
ip access-list	Defines an IP access list by name.
periodic	Specifies a recurring (weekly) start and end time for a time range.
permit (IP)	Sets conditions under which a packet passes a named IP access list.

track stub-object

To create a stub object that can be tracked by Embedded Event Manager (EEM) and to enter tracking configuration mode, use the **track stub-object** command in global configuration mode. To remove the stub object, use the **no** form of this command.

track *object-number* **stub-object**

no track *object-number* **stub-object**

Syntax Description	<i>object-number</i>	Object number that represents the object to be tracked. The range is from 1 to 1000.
---------------------------	----------------------	--

Command Default	No stub objects are created.
------------------------	------------------------------

Command Modes	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	12.4(2)T	This command was introduced.
	12.2(31)SB3	This command was integrated into Cisco IOS Release 12.2(31)SB3.
	12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
	12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
	15.1(3)T	This command was modified. The valid range of the <i>object-number</i> argument increased to 1000.
	15.1(1)S	This command was modified. The valid range for the <i>object-number</i> argument increased to 1000.

Usage Guidelines	Use the track stub-object command to create a stub object, which is an object that can be tracked and manipulated by an external process, EEM. After the stub object is created, the default-state command can be used to set the default state of the stub object.
-------------------------	---

EEM is a distributed, scalable, and customized approach to event detection and recovery offered directly in a Cisco IOS device. EEM offers the ability to monitor events and take informational or corrective action when the monitored events occur or when a threshold is reached. An EEM policy is an entity that defines an event and the actions to be taken when that event occurs.

As of Cisco IOS Release 15.1(3)T, a maximum of 1000 objects can be tracked. Although 1000 tracked objects can be configured, each tracked object uses CPU resources. The amount of available CPU resources on a router is dependent upon variables such as traffic load and how other protocols are configured and run. The ability to use 1000 tracked objects is dependent upon the available CPU. Testing should be conducted on site to ensure that the service works under the specific site traffic conditions.

Examples

The following example shows how to create and configure stub object 1 with a default state of up:

```
Router(config)# track 1 stub-object
Router(config-track)# default-state up
```

Related Commands

Command	Description
default-state	Sets the default state for a stub object.
show track	Displays tracking information.

transfer-interval

To configure how long bulk statistics should be collected before a bulk statistics transfer is initiated, use the **transfer-interval** command in Bulk Statistics Transfer configuration mode. To remove a previously configured interval from a bulk statistics configuration, use the **no** form of this command.

transfer-interval *minutes*

no transfer-interval

Syntax Description

<i>minutes</i>	Length of time, in minutes, that the system should collect MIB data before attempting the transfer operation. The valid range is from 1 to 2147483647. The default is 30.
----------------	---

Command Default

Bulk statistics file transfer operations start 30 minutes after the **enable** (bulkstat) command is used.

Command Modes

Bulk Statistics Transfer configuration (config-bulk-tr)

Command History

Release	Modification
12.0(24)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS Release XE 2.1.

Usage Guidelines

Bulk statistics data is collected into a new file when a transfer attempt begins, which means that this command also configures the collection interval.

If the maximum buffer size for a bulk statistics file is reached before the transfer interval time expires, the transfer operation will still be initiated, and bulk statistics MIB data will be collected into a new file in the system buffer.

Examples

The following example shows how to configure a transfer interval of 20 minutes for the bulk statistics configuration bulkstat1:

```
Router(config)# snmp mib bulkstat transfer bulkstat1
Router(config-bulk-tr)# transfer-interval 20
```

Related Commands

Command	Description
snmp mib bulkstat transfer	Names a bulk statistics transfer configuration and enters Bulk Statistics Transfer configuration mode.

transport (WSMA initiator)

To define a transport configuration for a Web Services Management Agent (WSMA) initiator profile, use the **transport** command in WSMA initiator configuration mode. To disable the transport configuration, use the **no** form of this command.

```
[backup] transport {http | https | ssh remote-host [initiator-port-number] path pathname [user
username [0 | 6] password] } | tls remote-host [initiator-port-number] [localcert
trustpoint-name] [remotecert trustpoint-name] [source source-interface]}
```

no [backup] transport

Syntax Description		
backup		Specifies that you are defining a backup transport connection. The backup connection is used only if the primary connection becomes unresponsive or is not configured.
http		Specifies HTTP (plain text) as the transport method for the WSMA profile and enables the profile to initiate connections from the device to the HTTP port on the remote HTTP server.
https		Specifies HTTPS (encrypted) as the transport method for the WSMA profile and enables the profile to initiate connections from the device to the HTTPS port on the remote HTTP server.
ssh		Specifies Secure Shell (SSH) as the transport method for the WSMA profile and enables the profile to initiate connections from the device to the SSH port on the remote SSH server.
<i>remote-host</i>		The name or IP address of the WSMA application host.
<i>initiator-port-number</i>		The port number that the remote WSMA application host is listening on. By default, the client attempts to connect to the port for the transport protocol being used (port 13000 for TLS). This value should be set to the same value as the WSMA application listener port.
path		When the transport method selected is HTTP or HTTPS, this keyword defines the path to the HTTP server. When the transport method selected is SSH, this keyword defines the path to the remote command to be invoked.
<i>pathname</i>		When the transport method selected is HTTP or HTTPS, this is the pathname for the HTTP or HTTPS path. When the transport method selected is SSH Version 2 (SSHv2), this is the path to the remote command to be invoked.
user		Specifies the username for the remote application.
<i>username</i>		The username to connect to the remote application.
0		Specifies that the following password is unencrypted.
6		Specifies that the following password is encrypted.
<i>password</i>		The password for the specified user.
tls		Specifies the Transport Layer Service (TLS) protocol as the transport method for the WSMA profile, and enables the profile to initiate connections from the device, to the TLS port on the remote TLS server.

localcert	Specifies the trustpoint used for client-side authentication during the TLS handshake. The Cisco IOS device presents the certificate supplied by this trustpoint to the WSMA host on the remote side. By default, the primary crypto trustpoint in the global configuration is used.
------------------	--

**Note**

Note - This configuration is needed only if the WSMA application is configured for TLS Client authentication.

<i>trustpoint-name</i>	The name of the client or server trustpoint.
remotecert	Specifies the trustpoint used for server certificate validation. This trustpoint specifies the Certificate Authority (CA) server that validates the certificates presented by the remote WSMA application host. By default, all trustpoints in the global configuration are used to validate the remote WSMA application host certificate.
source	Specifies the source interface for the outgoing connection.
<i>source-interface</i>	The source interface to use for the outgoing connection.

Command Default

The transport is not configured.

Command Modes

WSMA initiator configuration (config-wsma-init)

Command History

Release	Modification
15.1(1)T	This command was introduced.

Usage Guidelines

You can use the **transport** command to define the transport termination points for a WSMA profile.

Defining the transport configuration in WSMA initiator mode enables the Cisco IOS device to initiate connections to the remote management application over trusted and untrusted networks.

To enter the WSMA initiator configuration mode, use the **wsma profile listener** command in global configuration mode.

Examples

The following example shows how to define a transport configuration for an initiator profile using the TLS protocol:

```
Router(config)# wsma profile initiator prof2
Router(config-wsma-init)# transport tls 10.23.23.2
Router(config-wsma-init)#
```

Related Commands

Command	Description
acl	Enables access control lists for restricting addresses that can connect to a WSMA profile.
backup excluded	Sets the time that the WSMA profile must wait after a connection is lost before attempting to connect to the backup transport configuration.
backup hold	Sets the time that the WSMA profile remains connected to the backup transport configuration.
encap	Configures an encapsulation for a WSMA profile.
idle-timeout	Sets a time for the WSMA profile to keep the session alive in the absence of any data traffic.
keepalive	Enables keepalive messages and configures interval and retry values for a WSMA profile.
max-message	Sets the maximum size limit for incoming messages.
reconnect	Specifies the time to wait before attempting to reconnect after a connection is lost.
stealth	Disables WSMA from sending SOAP faults.
wsma profile listener	Configures and enables a WSMA listener profile.
wsma profile initiator	Configures and enables a WSMA initiator profile.
wsse	Enables the WSSE for a WSMA profile.

transport (WSMA listener)

To define a transport configuration for a Web Services Management Agent (WSMA) listener profile, use the **transport** command in WSMA listener configuration mode. To disable the transport configuration, use the **no** form of this command.

```
transport { http | https [path pathname] | ssh [subsys subsys-name] | tls [listener-port-number]
[localcert trustpoint-name] [disable-remotecert-validation | remotecert trustpoint-name] }
```

```
no transport
```

Syntax Description		
http		Specifies HTTP (plain text) as the transport method for the WSMA profile and enables the profile to listen on the HTTP port (port 80 or the port configured by the ip http port command).
https		Specifies HTTPS (encrypted) as the transport method for the WSMA profile and enables the profile to listen on the HTTPS port (port 443 or the port configured by the ip https secure-port command).
path		Defines the HTTP or HTTPS path to use.
<i>pathname</i>		The pathname for the HTTP or HTTPS path. The pathname must begin with a /. By default, /wsma is used as the pathname.
ssh		Specifies Secure Shell (SSH) version 2 as the transport method for the WSMA profile and enables the profile to listen on the SSHv2 port (port 22 or the port configured by the ip ssh port command).
subsys		Defines the SSH subsystem to use.
<i>subsys-name</i>		The name for the SSH subsystem. By default, wsma is used as the subsystem name.
tls		Specifies the Transport Layer Service (TLS) protocol as the transport method for the WSMA profile, and enables the profile to listen on the TLS port. By default the TLS port is set to 13000. This value can be changed using the transport command.
<i>listener-port-number</i>		The port number for the TLS listener. By default, the TLS listener uses port 13000. The port number can be set to any unused port between 1025 and 65535.
localcert		In WSMA listener mode, this specifies the trustpoint used for server-side authentication during the TLS handshake process. The Cisco IOS device presents the certificate supplied by this trustpoint to the remote side. By default, the primary crypto trustpoint in the global configuration is used.
<i>trustpoint-name</i>		The name of the localcert or remotecert trustpoint.

disable-remotecert-validation	<p>Disables the validation of the remote application host's certificate. This option is used when the Cisco IOS device that acts as the TLS server needs to turn off the validation of the remote applications host's certificate. By default, TLS remote host certificate validation is enabled.</p> <p>This keyword cannot be used with the remotecert keyword.</p>
remotecert	<p>Specifies the trustpoint used for client certificate validation. This trustpoint specifies the Certificate Authority (CA) server that validates the certificates presented by the remote WSMA application host.</p> <p>By default, all trustpoints in the global configuration are used to validate the remote WSMA application host certificate.</p>

Command Default

The transport is not configured.

Command Modes

WSMA listener configuration (config-wsma-listen)

Command History

Release	Modification
12.4(24)T	This command was introduced.
15.1(1)T	This command was modified. Support was added for the tls keyword.

Usage Guidelines

You can use the **transport** command to define the transport termination points for a WSMA profile.

Defining the transport configuration in WSMA listener configuration mode leads to the opening of a listening socket for listeners on the router. Opening the listening sockets enables the WSMA to start listening to messages.

Secure Shell version 2 (SSHv2), HTTP, HTTPS, and Transport Layer Service (TLS) are the types of transport configuration available for a WSMA profile.

To enter the WSMA listener configuration mode, use the **wsma profile listener** command in global configuration mode.

Examples

The following example shows how to define a transport configuration for a WSMA listener profile using the SSHv2 protocol:

```
Router(config)# wsma profile listener prof1
Router(config-wsma-listen)# transport ssh subsys wsma
Router(config-wsma-listen)#
```

The following example shows how to define a transport configuration for a WSMA listener profile using the TLS protocol:

```
Router(config)# wsma profile listener prof2
Router(config-wsma-listen)# transport tls 65534
Router(config-wsma-listen)#
```

Related Commands

Command	Description
acl	Enables access control lists for restricting addresses that can connect to a WSMA profile.
backup excluded	Sets the time that the WSMA profile must wait after a connection is lost before attempting to connect to the backup transport configuration.
backup hold	Sets the time that the WSMA profile remains connected to the backup transport configuration.
encap	Configures an encapsulation for a WSMA profile.
idle-timeout	Sets a time for the WSMA profile to keep the session alive in the absence of any data traffic.
keepalive	Enables keepalive messages and configures interval and retry values for a WSMA profile.
max-message	Sets the maximum size limit for incoming messages.
reconnect	Specifies the time to wait before attempting to reconnect after a connection is lost.
stealth	Disables WSMA from sending SOAP faults.
wsma profile listener	Configures and enables a WSMA listener profile.
wsma profile initiator	Configures and enables a WSMA initiator profile.
wsse	Enables the WSSE for a WSMA profile.

transport event

To specify that inventory events are sent out by the CNS inventory agent, use the **transport event** command in CNS inventory configuration mode. To disable the transport of inventory events, use the **no** form of this command.

transport event

no transport event

Syntax Description

This command has no arguments or keywords.

Command Default

This command is enabled by default.

Command Modes

CNS inventory configuration (cns_inv)

Command History

Release	Modification
12.3(1)	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
15.1(2)T	The command was modified. The command default was changed to enabled in Cisco IOS Release 15.1(2)T and later releases.

Usage Guidelines

Use this command to send out inventory requests with each CNS inventory agent message. When configured, the routing device will respond to queries from the CNS event bus. Online insertion and removal (OIR) events on the routing device will be reported to the CNS event bus.

Examples

The following example shows how to enable the CNS inventory agent and configure it to send out inventory events:

```
Router> enable
Router# configure terminal
Router(config)# cns inventory
Router(cns_inv)# end
```

Related Commands

Command	Description
cns inventory	Enables the CNS inventory agent and enters CNS inventory configuration mode.

trigger (EEM)

To enter trigger applet configuration mode and specify the multiple event configuration statements for an Embedded Event Manager (EEM) applet, use the **trigger** command in applet configuration mode. To disable the multiple event configuration statements, use the **no** form of this command.

trigger [**occurs** *occurs-value*] [**period** *period-value*] [**period-start** *period-start-value*] [**delay** *delay-value*]

no trigger [**occurs** *occurs-value*] [**period** *period-value*] [**period-start** *period-start-value*] [**delay** *delay-value*]

Syntax Description	
occurs	(Optional) Specifies the number of times the total correlation occurs before an EEM event is raised. When a number is not specified, an EEM event is raised on the first occurrence.
<i>occurs-value</i>	(Optional) Number in the range from 1 to 4294967295.
period	(Optional) Specifies the time interval during which the one or more occurrences must take place. If not specified, the time-period check is not applied.
<i>period-value</i>	(Optional) Number that represents seconds and optional milliseconds in the format ssssssss[.mmm]. The range for seconds is from 0 to 4294967295. The range for milliseconds is from 0 to 999. If using milliseconds only, specify the milliseconds in the format 0.mmm.
period-start	(Optional) Specifies the start of an event correlation window. If not specified, event monitoring is enabled after the first CRON period occurs.
<i>period-start-value</i>	(Optional) String that specifies the beginning of an event correlation window.
delay	(Optional) Specifies the number of seconds after which an event will be raised if all the conditions are true. If not specified, the event will be raised immediately.
<i>delay-value</i>	(Optional) Number that represents seconds and optional milliseconds in the format ssssssss[.mmm]. The range for seconds is from 0 to 4294967295. The range for milliseconds is from 0 to 999. If using milliseconds only, specify the milliseconds in the format 0.mmm.

Command Default Disabled.

Command Modes Applet configuration (config-applet)

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

The **trigger** command relates multiple event statements using the optional **tag** keyword with the *event-tag* argument specified in each event statement.

Examples

The following example shows how to use the **trigger** command to enter trigger applet configuration mode and specify multiple event configuration statements for an EEM applet. In this example, the applet is run when the **show bgp all** command and any syslog message that contains the string "COUNT" occurs within a period of 60 seconds.

```
Router(config)# event manager applet delay_50
Router(config-applet)# event tag 1.0 cli pattern "show bgp all" sync yes occurs 32 period
60 maxrun 60
Router(config-applet)# event tag 2.0 syslog pattern "COUNT"
Router(config-applet)# trigger occurs 1 delay 50
Router(config-applet-trigger)# correlate event 1.0 or event 2.0
Router(config-applet-trigger)# attribute tag 1.0 occurs 1
Router(config-applet-trigger)# attribute tag 2.0 occurs 1
Router(config-applet-trigger)# action 1.0 cli command "show memory"
Router(config-applet)# action 2.0 cli command "enable"
Router(config-applet)# action 3.0 cli command "config terminal"
Router(config-applet)# action 4.0 cli command " ip route 192.0.2.0 255.255.255.224
192.0.2.12"
Router(config-applet)# action 91.0 cli command "exit"
Router(config-applet)# action 99.0 cli command "show ip route | incl 192.0.2.5"
```

Related Commands

Command	Description
attribute (EEM)	Specifies a complex event for an EEM applet.
correlate	Builds a single complex event.
event manager applet	Registers an event applet with the Embedded Event Manager and enters applet configuration mode.

ttl dns

To configure the number of seconds for which an answer received from the boomerang client will be cached by the Domain Name System (DNS) client, use the **ttl dns** command in boomerang configuration mode. To remove this command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

ttl dns *seconds*

no ttl dns *seconds*

Syntax Description	<i>seconds</i>	Integer in the range from 10 to 2147483647 that specifies the number of seconds for which an answer received from the boomerang client will be cached by the DNS client.
---------------------------	----------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Boomerang configuration
----------------------	-------------------------

Command History	Release	Modification
	12.2(8)T	This command was introduced.

Usage Guidelines	The ttl dns command can be used only on a Director Response Protocol (DRP) agent. The boomerang client is the DRP agent.
	The ttl dns command configures the number of seconds for which the DNS client can cache a boomerang reply from a boomerang client.

Examples	In the following example, the number of seconds for which the DNS client can cache a boomerang reply from a boomerang client is configured as 10:
-----------------	---

```
Router(config)# ip drp domain www.boom1.com
Router(config-boomerang)# ttl dns 10
```

```
Router# show running-config
.
.
.
ip drp domain www.boom1.com
dns-ttl 10
```

Related Commands

Command	Description
alias (boomerang configuration)	Configures an alias name for a specified domain.
ip drp domain	Adds a new domain to the DistributedDirector client or configures an existing domain and puts the client in boomerang configuration mode.
server (boomerang configuration)	Configures the server address for a specified boomerang domain.
show ip drp	Displays DRP statistics on DistributedDirector or a DRP server agent.
show ip drp boomerang	Displays boomerang information on the DRP agent.
ttl ip	Configures the IP TTL value for the boomerang response packets sent from the boomerang client to the DNS client in number of hops.

ttl ip

To configure the IP time-to-live (TTL) value for the boomerang response packets sent from the boomerang client to the DNS client, use the **ttl ip** command in boomerang configuration mode. To remove this command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

ttl ip *hops*

no ttl ip *hops*

Syntax Description	<i>hops</i>	Integer in the range from 1 to 255 that specifies the number of hops that occur between the boomerang client and the DNS client before the boomerang response packet fails.
---------------------------	-------------	---

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Boomerang configuration
----------------------	-------------------------

Command History	Release	Modification
	12.2(8)T	This command was introduced.

Usage Guidelines	The ttl ip command can be used only on a Director Response Protocol (DRP) agent. The boomerang client is the DRP agent.
	The ttl ip command configures the maximum number of hops allowed between the boomerang client and the DNS client, after which the boomerang response packet fails. If the user wants to restrict the contending proxies only to nearby ones, the value of the ttl ip command can be set to a specific number within the allowed range. Any proxy outside of this range will be automatically disqualified in the boomerang race because its replies will never reach the DNS client. Because the ttl ip command specifies the number of hops for which a response from a client will live, it allows faraway proxies to avoid wasting bandwidth.

Examples	In the following example, the number of hops that occur between the boomerang client and the DNS client before the boomerang response packet fails is configured as 2:
-----------------	--

```
Router(config)# ip drp domain www.boom1.com
Router(config-boomerang)# ttl ip 2

Router# show running-config
.
.
.
ip drp domain www.boom1.com
ip-ttl 2
```

Related Commands	Command	Description
	alias (boomerang)	Configures an alias name for a specified domain.
	ip drp domain	Adds a new domain to the DistributedDirector client or configures an existing domain and puts the client in boomerang configuration mode.
	server (boomerang)	Configures the server address for a specified boomerang domain.
	show ip drp	Displays DRP statistics on DistributedDirector or a DRP server agent.
	show ip drp boomerang	Displays boomerang information on the DRP agent.
	ttl dns	Configures the number of seconds for which an answer received from the boomerang client will be cached by the DNS client.

type (test existence)

To specify the type of existence trigger test to perform, use the **type** command in event trigger existence configuration mode. To disable the specified trigger test type, use the **no** form of this command.

type {**present** | **absent** | **changed**}

no type {**present** | **absent** | **changed**}

Syntax Description	present	Specifies whether the trigger conditions for the existence test are present.
	absent	Specifies whether the trigger conditions for the existence test are absent.
	changed	Specifies whether the trigger conditions for the existence test are changed.

Command Default By default, both present and absent tests are performed.

Command Modes Event trigger existence configuration (config-event-trigger-existence)

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines The existence trigger tests are performed based on the following parameters:

- Absent
- Present
- Changed

When the test type is not specified, both present and absent tests are performed.

Examples The following example shows how to specify the existence trigger test as present:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)# type present
Router(config-event-trigger-existence)#
```

Related Commands	Command	Description
	test	Enables a trigger test.

url (bulkstat)

To specify the host to which bulk statistics files should be transferred, use the **url** command in Bulk Statistics Transfer configuration mode. To remove a previously configured destination host, use the **no** form of this command.

url { **primary** | **secondary** } *url*

no url { **primary** | **secondary** }

Syntax Description

primary	Specifies the URL to be used first for bulk statistics transfer attempts.
secondary	Specifies the URL to be used for bulk statistics transfer attempts if the transfer to the primary URL is not successful.
<i>url</i>	Destination URL address for the bulk statistics file transfer. Use FTP, RCP, or TFTP. The Cisco IOS File System (IFS) syntax for these URLs is as follows: <ul style="list-style-type: none"> • ftp:<code>[[//username [:password]@]location]/directory]/filename</code> • rtp:<code>[[//username@]location]/directory]/filename</code> • tftp:<code>[[//location]/directory]/filename</code> The <i>location</i> argument is typically an IP address.

Command Default

No host is specified.

Command Modes

Bulk Statistics Transfer configuration (config-bulk-tr)

Command History

Release	Modification
12.0(24)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS Release XE 2.1.

Usage Guidelines

For bulk statistics transfer retry attempts, a single retry consists of an attempt to send first to the primary URL, and then to the secondary URL.

Examples

In the following example, an FTP server is used as the primary destination for the bulk statistics file. If a transfer to that address fails, an attempt is made to send the file to the TFTP server at 192.168.10.5. No retry command is specified, which means that only one attempt to each destination will be made.

```
Router(config)# snmp mib bulkstat transfer ifMibTesting
Router(config-bulk-tr)# schema carMibTesting1
Router(config-bulk-tr)# schema carMibTesting2
Router(config-bulk-tr)# format bulkBinary
Router(config-bulk-tr)# transfer-interval 60
Router(config-bulk-tr)# buffer-size 10000
Router(config-bulk-tr)# url primary ftp://user2:pswd@192.168.10.5/functionality/
Router(config-bulk-tr)# url secondary tftp://user2@192.168.10.8/tftpboot/
Router(config-bulk-tr)# buffer-size 2500000
Router(config-bulk-tr)# enable
Router(config-bulk-tr)# exit
```

Related Commands

Command	Description
retry (bulkstat)	Configures the number of retries that should be attempted for sending bulk statistics files.
snmp mib bulkstat transfer	Names a bulk statistics transfer configuration and enters Bulk Statistics Transfer configuration mode.

user (ERM)

To apply a global policy, create a resource group, or add resource users (RUs) to a resource group, use the **user** command in Embedded Resource Manager (ERM) configuration mode. To disable applying the policy, use the **no** form of this command.

```
user { resource-instance-name resource-user-type resource-policy-name | global
      global-policy-name | group [resource-group-name type resource-user-type] }

no user { resource-instance-name | global global-policy-name | group [resource-group-name] }
```

Syntax Description

<i>resource-instance-name</i>	Name of the RU to which you are applying a policy.
<i>resource-user-type</i>	Name of the RU type.
<i>resource-policy-name</i>	Name of the policy you are applying to the specified RU.
global	Applies a global policy.
<i>global-policy-name</i>	Name of the global policy you are applying.
group	Specifies a resource group to which the policy is being applied.
<i>resource-group-name</i>	(Optional) Name of the resource group to which the policy is being applied.
type	(Optional) Specifies the type of RU to which the policy is being applied.
<i>resource-user-type</i>	(Optional) Name of the RU type to which the policy is being applied.

Command Default

No policy is configured.

Command Modes

ERM configuration (config-erm)

Command History

Release	Modification
12.3(14)T	This command was introduced.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.

Usage Guidelines

This command helps you to apply the various policies (system global, per-user local, and user global) to resource owners (ROs), RUs, or a group of RUs.

Use the **user** *resource-instance-name* *resource-user-type* *resource-policy-name* command to apply a specified policy to an RU. This policy is also known as a per-user local policy or per-user template.

Use the **user global** *global-policy-name* command to apply a global thresholding policy to all the users.

Use the **user group** *resource-group-name* **type** *resource-user-type* command to create a resource group and to enter resource group configuration mode. After you create the resource group, you can add RUs using the **instance** *instance-name* command and apply the same thresholding policy to all the RUs against the resource group using the **policy** *policy-name* command in resource group configuration mode.

For example, you created a resource group named `lowPrioUsers` with a type of `iosprocess`. You have low-priority RUs or tasks such as HTTP and Simple Network Management Protocol (SNMP), and you want to set a threshold for all the low-priority RUs as a group. You must add the RUs to the resource group using the **instance** *instance-name* command and then apply a resource policy. If the resource policy you apply sets a minor rising threshold value of 10 percent for the resource group, when the accumulated usage of both HTTP and SNMP RUs crosses the 10 percent mark, a notification is sent to the RUs in the resource group `lowPrioUsers`. That is, if HTTP usage is 4 percent and SNMP usage is 7 percent, a notification is sent to `lowPrioUsers`.

Examples

The following example shows how to apply a per-user thresholding policy for the resource instance `EXEC`, resource user type `iosprocess`, and resource policy name `policy-test1`:

```
Router(config-erm)# user EXEC iosprocess policy-test1
```

The following example shows how to apply a global thresholding policy with policy name `global-global-test1`:

```
Router(config-erm)# user global global-global-test1
```

The following example shows how to create a resource group with the resource group name `lowPrioUsers` and RU type as `iosprocess`, and how to add the RU HTTP to the resource group and apply a thresholding policy `group-policy1`:

```
Router(config-erm)# user group lowPrioUsers type iosprocess
```

```
Router(config-res-group)# instance http
```

```
Router(config-res-group)# policy group-policy1
```

Related Commands

Command	Description
instance (resource group)	Adds RUs to a resource group.
policy (ERM)	Configures an ERM resource policy.
policy (resource group)	Applies the same policy to all the RUs in a resource group.
resource policy	Enters ERM configuration mode.
show resource all	Displays resource details for all RUs.

value (action set)

To set a value to the object, use the **value** command in event action set configuration mode. To disable the configured settings, use the **no** form of this command.

value *integer-value*

no value

Syntax Description	<i>integer-value</i>	Numerical value to set for the object.
---------------------------	----------------------	--

Command Default	By default, no value is set for the object.	
------------------------	---	--

Command Modes	Event action set configuration (config-event-action-set)	
----------------------	--	--

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
	Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines	The value command sets the value for the object associated with the event for which actions are set by using the action set command.	
-------------------------	--	--

Examples	<p>The following example shows how to set a value of 2 to the object:</p> <pre>Router(config)# snmp mib event owner owner1 name EventA Router(config-event)# action set Router(config-event-action-set)# value 2 Router(config-event-action-set)#</pre>	
-----------------	---	--

Related Commands	Command	Description
	action	Sets an action for an event.

value (test boolean)

To set a value for the Boolean trigger test, use the **value** command in event trigger boolean configuration mode. To disable the configured settings, use the **no** form of this command.

value *integer-value*

no value

Syntax Description

<i>integer-value</i>	Numerical value to set for the Boolean test. The default is 0.
----------------------	--

Command Default

The Boolean trigger test value is set to 0.

Command Modes

Event trigger boolean configuration (config-event-trigger-boolean)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

The **value** command specifies the value to set for the Boolean trigger test.

Examples

The following example shows how to set a value for the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)# value 10
Router(config-event-trigger-boolean)
```

Related Commands

Command	Description
test	Enables a trigger test.

value type

To specify the type of expression to use during object sampling, use the **value type** command in expression configuration mode. To disable the specified value type, use the **no** form of this command.

value type { **counter32** | **unsigned32** | **timeticks** | **integer32** | **ipaddress** | **octetstring** | **objectid** | **counter64** }

no value type

Syntax Description	
counter32	(Optional) Specifies a counter32 value. Counter32 specifies a value that represents a count. The value ranges from 0 to 4294967295.
unsigned32	(Optional) Specifies an unsigned integer value. Unsigned32 specifies a value that includes only non-negative integers. The value ranges from 0 to 4294967295.
timeticks	(Optional) Specifies a value based on timeticks. Timeticks represents a non-negative integer value that specifies the elapsed time between two events, in units of hundredth of a second. When objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1), the description of the object type identifies this reference period.
integer32	(Optional) Specifies an integer32 value. The Integer32 represents 32-bit signed integer values for Simple Network Management Protocol (SNMP). The value range includes both negative and positive numbers.
ipaddress	(Optional) Specifies a value based on the IP address. The IP address is a string of four octets. The IP address value type is generally an IPv4 address. This value is encoded as four bytes in the network byte order.
octetstring	(Optional) Specifies a value based on octetstring. The octetstring specifies octets of binary or textual information. The octet string length ranges from 0 to 65535 octets.
objectid	(Optional) Specifies a value based on the object identifier of an object. Each object type in a MIB is identified by an object identifier value assigned by the administrator. The object identifier identifies the value type that has an assigned object identifier value.
counter64	(Optional) Specifies a counter64 value. Counter64, like counter32, specifies a value that represents a count. However, the counter64 value ranges from 0 to 18446744073709551615. This value type is used when a 32-bit counter rollover occurs in less than an hour.

Command Default The default value type is counter32.

Command Modes Expression configuration mode (config-expression)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

The **value type** command specifies a value for expression evaluation.

Examples

The following example shows how to specify the counter32 value type:

```
Router(config)# snmp mib expression owner owner1 name ExpressionA
Router(config-expression)# value type counter32
Router(config-expression)#
```

Related Commands

Command	Description
snmp mib expression owner	Specifies the owner for an expression.

wildcard

To specify whether the object identifier needs to be wildcarded, use the **wildcard** command in event object list, event action set, or expression object configuration mode. To disable the configured settings, use the **no** form of this command.

wildcard

no wildcard

Syntax Description

This command has no arguments or keywords.

Command Default

Objects are fully specified by default.

Command Modes

Event object list configuration (config-event-objlist)

Event action set configuration (config-action-set)

Expression object configuration (config-expression-object)

Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Usage Guidelines

The **wildcard** indicates whether an object identifier needs to be wildcarded or fully specified. By default, the objects are based on instances and are not wildcarded.

Examples

The following example shows how to specify wildcard for an object instance during object list configuration:

```
Router(config)# snmp mib event object list owner owner1 name objectA 10
Router(config-event-objlist)# wildcard
Router(config-event-objlist)#
```

The following example shows how to specify wildcard for an object instance during action set configuration:

```
Router(config)# snmp mib event owner owner1 name EventA
Router(config-event)# action set
Router(config-event-action-set)# wildcard
Router(config-event-action-set)#
```

The following example shows how to specify wildcard for an object instance during expression configuration:

```
Router(config)# snmp mib expression owner owner1 name ExpressionA
Router(config-expression)# object 10
Router(config-expression-object)# wildcard
Router(config-expression-object)#
```

Related Commands

Command	Description
object id	Specifies the object identifier of an object.
snmp mib event object list	Configures a list of objects for events, event triggers, and trigger tests.
snmp mib expression owner	Specifies the owner for an expression.

write mib-data

To save MIB data to system memory (NVRAM) for MIB Data Persistence, use the **write mib-data** command in EXEC mode.

write mib-data

Syntax Description This command has no arguments or keywords.

Command Modes Exec

Command History	Release	Modification
	12.2(2)T	This command was introduced as part of the “Circuit Interface Identification Persistence for SNMP” feature.
	12.2(4)T	MIB Data Persistence for the Event and Expression MIBs was introduced as part of the “Distributed Management Event and Expression MIB Persistence” feature.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Usage Guidelines The MIB Data Persistence feature allows the SNMP data of a MIB to be persistent across reloads; that is, the values of certain MIB objects are retained even if your networking device reboots.

To determine which MIBs support “MIB Persistence” in your release, use the **snmp mib persist ?** command in global configuration mode.

Any modified MIB data must be written to NVRAM memory using the **write mib-data** command. If the **write mib-data** command is not used, modified MIB data is not saved automatically, even if MIB Persistence is enabled. Executing the **write mib-data** command saves only the current MIB data; if the MIB object values are changed, you should reenter the **write mib-data** command to ensure that those values are persistent across reboots.

Examples In the following example, Event MIB Persistence and Circuit MIB persistence are enabled, and any currently set object values for those MIBs are saved to NVRAM:

```
Router# configure terminal
Router(config)# snmp mib persist circuit
Router(config)# snmp mib persist event
Router(config)# end
Router# write mib-data
```

Related Commands	Command	Description
	snmp mib persist	Enables MIB data persistence.

wsma agent

To enable a specific Web Services Management Agent (WSMA) and associate it with a profile, use the **wsma agent** command in global configuration mode. To disable the WSMA agent and its associations with a profile, use the **no** form of this command.

wsma agent { **config** | **exec** | **filesys** | **notify** } **profile** *profile-name*

no wsma agent { **config** | **exec** | **filesys** | **notify** }

Syntax Description

config	Starts the WSMA config agent.
exec	Starts the WSMA exec agent.
filesys	Starts the WSMA filesys agent.
notify	Starts the WSMA notify agent.
profile <i>profile-name</i>	Defines the profile name to use.

Command Default

By default, WSMA agents are disabled and are not associated with profiles.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.4(24)T	This command was introduced.

Examples

The following example shows how to enable a WSMA agent and associate with a profile:

```
Router(config)# wsma agent config profile wsma1
Router(config)#
```

Related Commands

Command	Description
wsma id	Assigns unique WSMA IDs to Cisco IOS devices.
wsma profile listener	Configures and enables a WSMA listener profile.

wsma id

To assign unique Web Services Management Agent (WSMA) IDs to IOS devices, use the **wsma id** command in global configuration mode. To disable the WSMA IDs assigned to Cisco IOS devices, use the **no** form of this command.

wsma id { **hardware-serial** | **hostname** | **ip-address** *interface-type* | **mac-address** *interface-type* | **string** *value* }

no wsma id

Syntax Description

hardware-serial	Assigns the hardware serial number as a unique ID.
hostname	Assigns the host name as a unique ID.
ip-address	Assigns the IP address of the specified interface as unique ID.
<i>interface-type</i>	Specifies the interface type.
mac-address	Assigns the IP address of the specified interface as unique ID.
string <i>value</i>	Defines a string value to be assigned as unique ID.

Command Default

By default, unique WSMA IDs are not assigned to Cisco IOS devices.

Command Modes

Global configuration (config)

Command History

Release	Modification
12.4(24)T	This command was introduced.

Usage Guidelines

Use this command to assign unique IDs to Cisco IOS devices. Unique IDs can also be configured by specifying required parameters.

Whenever the WSMA ID changes, all WSMA sessions are terminated. This is done in order to protect the management applications from not having to deal with synchronizing states dynamically.

Examples

The following example shows how to assign WSMA IDs:

```
Router(config)# wsma id ip-address fastethernet 0/1
Router(config)#
```

Related Commands

Command	Description
wsma agent	Enables a specific WSMA and associates it with a profile.
wsma profile listener	Configures and enables a WSMA listener profile.

wsma profile initiator

To configure and enable a Web Services Management Agent (WSMA) initiator profile and to enter WSMA initiator configuration mode, use the **wsma profile initiator** command in global configuration mode. To disable a WSMA initiator profile, use the **no** form of this command.

wsma profile initiator *profile-name*

no wsma profile initiator *profile-name*

Syntax Description	initiator	Enables the WSMA initiator profile for the specified profile name.
	<i>profile-name</i>	Defines the name of the initiator profile to be enabled.

Command Default No WSMA profiles are configured.

Command Modes Global configuration (config)

Command History	Release	Modification
	15.1(1)T	This command was introduced.

Usage Guidelines You can use the **wsma profile initiator** command to configure and enable a WSMA profile. A WSMA profile associated with a specific WSMA constitutes an operational embedded agent.

WSMA profiles work as a transport termination point, and allows transport and XML encapsulation parameters to be configured.

- The configurable encapsulations for WSMA are Simple Object Access Protocol (SOAP) 1.1 and SOAP 1.2.
- The transportation mechanisms for WSMA include Secure Shell (SSH), HTTP, HTTPS, and Transport Layer Security (TLS).

The WSMA initiator mode allows Cisco IOS devices to initiate connections to management applications over trusted and untrusted networks. You can configure various parameters for a WSMA profile in WSMA initiator configuration mode.

Examples The following example shows how to enable a WSMA initiator profile:

```
Router(config)# wsma profile initiator prof1
Router(config-wsma-init)#
```

Related Commands

Command	Description
backup excluded	Sets the time that the WSMA profile must wait after a connection is lost before attempting to connect to the backup transport configuration.
backup hold	Sets the time that the WSMA profile remains connected to the backup transport configuration.
encap	Configures an encapsulation for a WSMA profile.
idle-timeout	Sets a time for the WSMA profile to keep the session alive in the absence of any data traffic.
keepalive	Enables keepalive messages and configures interval and retry values for a WSMA profile.
max-message	Sets the maximum size limit for incoming messages.
reconnect	Specifies the time for the WSMA initiator profile to wait before attempting to reconnect a session.
stealth	Disables WSMA profiles from sending SOAP faults.
transport	Defines a transport configuration for a WSMA profile.
wsma agent	Enables a specific WSMA and associates it with a profile.
wsma dhcp	Enables the configuration of WSMA profiles and services using DHCP Option 43 message as part of Zero Touch Deployment.
wsma id	Assigns unique WSMA IDs to Cisco IOS networking devices.
wsma profile listener	Configures and enables a WSMA listener profile and enters WSMA listener configuration mode.
wsse	Enables the WSSE for a WSMA profile.

wsma profile listener

To configure and enable a Web Services Management Agent (WSMA) listener profile and to enter WSMA listener configuration mode, use the **wsma profile listener** command in global configuration mode. To disable a WSMA listener profile, use the **no** form of this command.

wsma profile listener *profile-name*

no wsma profile listener *profile-name*

Syntax Description	listener	Enables the WSMA listener profile for the specified profile name.
	<i>profile-name</i>	Defines the name of the listener profile to be enabled.

Command Default No WSMA profiles are configured.

Command Modes Global configuration (config)

Command History	Release	Modification
	12.4(24)T	This command was introduced.

Usage Guidelines You can use the **wsma profile listener** command to configure and enable a WSMA profile. A WSMA profile associated with a specific WSMA constitutes an operational embedded agent.

WSMA profiles work as transport termination points, and allow transport and XML encapsulation parameters to be configured.

- The configurable encapsulations for WSMA are Simple Object Access Protocol (SOAP) 1.1 and SOAP 1.2.
- The transportation mechanisms for WSMA include Secure Shell Version (SSH), HTTP, HTTPS, and Transport Layer Security (TLS). The transport mechanisms open listening sockets for listeners on the router.

The **wsma profile listener** command creates a passive listening socket on the Cisco IOS device. The profile receives incoming messages provided they match the configured Access Control List (ACL) requirements. You can configure various parameters for a WSMA profile in WSMA listener configuration mode.

Examples The following example shows how to enable a WSMA listener profile:

```
Router(config)# wsma profile listener prof1
Router(config-wsma-listen)#
```

Related Commands

Command	Description
acl	Enables ACLs for restricting addresses that can connect to a WSMA profile.
encap	Configures an encapsulation for a WSMA profile.
idle-timeout	Sets a time for the WSMA profile to keep the session alive in the absence of any data traffic.
keepalive	Enables keepalive messages and configures interval and retry values for a WSMA profile.
max-message	Sets the maximum size limit for incoming messages.
stealth	Disables WSMA from sending SOAP faults.
transport	Defines a transport configuration for a WSMA profile.
wsma agent	Enables a specific WSMA and associates it with a profile.
wsma dhcp	Enables the configuration of WSMA profiles and services using DHCP Option 43 message as part of Zero Touch Deployment.
wsma id	Assigns unique WSMA IDs to Cisco IOS networking devices.
wsma profile initiator	Configures and enables a WSMA initiator profile and enters WSMA initiator configuration mode.
wsse	Enables the WSSE for a WSMA profile.

WSSE

To enable the Web Services Security (WSSE) Header for a Web Services Management Agent (WSMA), use the **wsse** command in WSMA listener configuration mode or WSMA initiator configuration mode. To disable the security header, use the **no** form of this command.

wsse

no wsse [**authorization level** *level*]

Syntax Description

authorization level	Specifies the authorization level parameters to use when WSSE is disabled.
<i>level</i>	The privilege or authorization level assigned to the requests executed using this profile. The range is from 1 to 15. the default is 1.

Command Default

WSSE is enabled. When WSSE is disabled the default authorization level is set to 1 (the lowest level).

Command Modes

WSMA initiator configuration (config-wsma-init)
WSMA listener configuration (config-wsma-listen)

Command History

Release	Modification
12.4(24)T	This command was introduced.
15.1(1)T	This command was modified. Support was added for the authorization level keyword, and for the WSMA initiator configuration mode.

Usage Guidelines

You can use the **wsse** command to enable the WSSE for a WSMA profile. When enabled, the WSSE username and password are required in the Simple Object Access Protocol (SOAP) header. By default, this command is enabled and the nonvolatile generation (NVGEN) operation does not take place. Specifying the **no wsse** command enables the NVGEN operation.

The username in the WSSE header is authenticated and authorized using the authentication method set in the global configuration. If Authentication, Authorization, and Accounting (AAA) is enabled on the router then the AAA settings are used. If AAA is not enabled, the username and password in the WSSE header is compared to the username and password configured on the router.

When the WSSE SOAP header is disabled for a WSMA listener or initiator profile, the **authorization level** keyword can be used to select an authorization level for commands executed using the profile.

When the WSSE SOAP header is disabled for a WSMA profile, the authorization level assigned to requests over the configured connections is determined as follows:

- For HTTP, HTTPs, or Secure Shell (SSH) listener connections, the user details are extracted from the transport user's credentials. The authorization level used for the request is the lesser of the authenticated user's privilege level and the level configured using the **no wsse authorization level** *level* command.

- For the TLS listener connections, no user is associated with the connection because the protocol does not require user and password based authentication. Authentication is performed using certificates. The authorization level used for the request is the lesser of privilege 15 and the level configured using the **no wsse authorization level level** command.
- For HTTP, HTTPS, SSH or TLS initiator connections, no user is associated with the connection because these are outgoing connections. If no user information is available, the authorization level set using the **no wsse authorization level level** command is used for all agents associated with the profile.
- If no authorization level is set, the default privilege level is used. The default privilege level is set to 1 (the minimum level).

Use this command from the WSMA listener configuration mode or WSMA initiator configuration mode. To enter WSMA listener configuration mode, enter the **wsma profile listener** command in global configuration mode. To enter WSMA initiator configuration mode, use the **wsma profile initiator** command in global configuration mode.

Examples

The following example shows how to enable WSSE on a WSMA listener profile:

```
Router(config)# wsma profile listener prof1
Router(config-wsma-listen)# wsse
Router(config-wsma-listen)#
```

The following example shows how to specify the authorization level parameters to use when WSSE is disabled on a WSMA initiator profile:

```
Router(config)# wsma profile initiator prof2
Router(config-wsma-init)# no wsse authorization level 3
Router(config-wsma-init)#
```

Related Commands

Command	Description
acl	Enables access control lists for restricting addresses that can connect to a WSMA profile.
backup excluded	Sets the time that the WSMA profile must wait after a connection is lost before attempting to connect to the backup transport configuration.
backup hold	Sets the time that the WSMA profile remains connected to the backup transport configuration.
encap	Configures an encapsulation for a WSMA profile.
idle-timeout	Sets a time for the WSMA profile to keep the session alive in the absence of any data traffic.
keepalive	Enables keepalive messages and configures interval and retry values for a WSMA profile.
max-message	Sets the maximum size limit for incoming messages.
reconnect	Specifies the time for the WSMA initiator profile to wait before attempting to reconnect a session.
stealth	Disables WSMA from sending SOAP faults.
transport	Defines a transport configuration for a WSMA profile.
wsma profile initiator	Configures and enables a WSMA initiator profile.
wsma profile listener	Configures and enables a WSMA listener profile.

xsm

To enable XML Subscription Manager (XSM) client access to the device, use the **xsm** command in global configuration mode. To disable XSM client access to the device, use the **no** form of this command.

xsm

no xsm

Syntax Description

This command has no arguments or keywords.

Command Default

XSM client access to the device is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.1(6)E	This command was introduced.
12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command requires that the **ip http server** command is enabled. Enabling the **xsm** command also enables the **xsm vdm** and **xsm edm** commands. This command must be enabled for the XSM client (such as VPN Device Manager [VDM]) to operate.

Examples

In the following example, access by remote XSM clients to XSM data on the device is disabled:

```
Router# no xsm
```

Related Commands

Command	Description
ip http server	Enables a device to be reconfigured through the Cisco browser interface.
show xsm status	Displays information and status about clients subscribed to the XSM server.
show xsm xrd-list	Displays all XRDs for clients subscribed to the XSM server.
xsm dvdm	Grants access to switch operations.

Command	Description
xsm edm	Grants access to EDM monitoring and configuration data.
xsm vdm	Grants access to VPN-specific monitoring and configuration data.

xsm dvdm

To enable switch-specific configuration data (for example, configuring switch ports and VLANs) when running VPN Device Manager (VDM) on a switch, use the **xsm dvdm** command in global configuration mode. To disable switch-specific configuration data for VDM, use the **no** form of this command.

xsm dvdm

no xsm dvdm

Syntax Description

This command has no arguments or keywords.

Command Default

Access to switch-specific configuration data is enabled when XSM is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.2(9)YO1	This command was introduced.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.

Usage Guidelines

Access to switch-specific configuration data (dVDM) is enabled by default when XSM is enabled.

The **no xsm dvdm** command allows you to disable only switch-specific XSM data. Note however that disabling dVDM will prevent the VDM application from communicating properly with the device (switch). There is minimal performance impact associated with leaving dVDM enabled.

Examples

In the following example, access to switch-specific configuration data is disabled in XSM:

```
Router(config)# no xsm dvdm
```

Related Commands

Command	Description
xsm	Enables XSM client access to the router.
xsm edm	Grants access to EDM monitoring and configuration data.
xsm history vdm	Enables specific VPN statistics collection on the XSM server.
xsm vdm	Grants access to VPN-specific monitoring and configuration data.

xsm edm

To grant access to Embedded Device Manager (EDM) monitoring and configuration data, use the **xsm edm** command in global configuration mode. To cancel access to EDM monitoring and configuration data, use the **no** form of this command.

xsm edm

no xsm edm

Syntax Description

This command has no arguments or keywords.

Command Default

Access to EDM monitoring and configuration data is granted by default if XSM is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.1(6)E	This command was introduced.
12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command exists to allow you to disable EDM using the **no xsm edm** form of the command. EDM is enabled by default when XSM is enabled.

EDM provides the following generic information to the VPN Device Manager (VDM):

- Relevant interfaces
- IP routing
- Access-list details
- Basic device health

Note that disabling EDM prevents XSM clients (such as VDM) from working properly and also disables the **xsm history edm** command. There is minimal performance impact associated with leaving EDM enabled.

Examples

In the following example, access to EDM data is disabled:

```
Router(config)# xsm  
Router(config)# no xsm edm
```

Related Commands

Command	Description
xsm	Enables XSM client access to the router.
xsm dvdm	Grants access to switch operations.
xsm history edm	Enables statistics collection for the EDM on the XSM server.
xsm vdm	Grants access to VPN-specific monitoring and configuration data.

xsm history edm

To enable statistics collection for the Embedded Device Manager (EDM) on the XML Subscription Manager (XSM) server, use the **xsm history edm** command in global configuration mode. To disable statistics collection for the EDM on the XSM server, use the **no** form of this command.

xsm history edm

no xsm history edm

Syntax Description This command has no arguments or keywords.

Command Default EDM statistics collection is disabled.

Command Modes Global configuration

Command History

Release	Modification
12.1(6)E	This command was introduced.
12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to save up to five days of data. Historical information on items such as RAM and CPU utilization is gathered and made available, thus enabling XSM clients (such as VPN Device Manager [VDM]) to display charts and data. Use of this command consumes resources on the device. Disabling this command clears all your historical data, as the XSM server does not save this data between reloads.

Examples

In the following example, statistics collection for the EDM is enabled on the XSM server:

```
Router(config)# xsm
Router(config)# xsm history edm
```

Related Commands

Command	Description
xsm	Enables XSM client access to the router.

Command	Description
xsm edm	Grants access to EDM monitoring and configuration data.
xsm history vdm	Enables specific VPN statistics collection on the XSM server.

xsm history vdm

To enable specific VPN statistics collection on the XML Subscription Manager (XSM) server, use the **xsm history vdm** command in global configuration mode. To disable collection of specific selected VPN statistics on the XSM server, use the **no** form of this command.

xsm history vdm

no xsm history vdm

Syntax Description This command has no arguments or keywords.

Command Default VPN statistics collecting is disabled.

Command Modes Global configuration

Command History	Release	Modification
	12.1(6)E	This command was introduced.
	12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
	12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines With this command enabled, you can save up to five days of data. Historical information on items such as the number of active IKE tunnels, IPsec tunnels, total crypto throughput, and total throughput is gathered and made available, thus enabling XSM clients (such as VPN Device Manager [VDM]) to display charts and data. Use of this command consumes resources on the device. Disabling this command clears all your historical data. The XSM server does not save history data across reloads.

Examples The following example shows how to enable specific VPN statistics collection on the XSM server:

```
Router(config)# xsm
Router(config)# xsm history vdm
```


Related Commands

Command	Description
xsm	Enables XSM client access to the router.
xsm history edm	Enables statistics collection for the EDM on the XSM server.
xsm vdm	Grants access to VPN-specific monitoring and configuration data.

xsm privilege configuration level

To enable the XML Subscription Manager (XSM) configuration privilege level required to subscribe to XML Request Descriptors (XRDs), use the **xsm privilege configuration level** command in global configuration mode. To remove a previously configured XSM configuration privilege level, use the **no** form of this command.

xsm privilege configuration level *number*

no xsm privilege configuration level *number*

Syntax Description	<i>number</i>	Integer in the range from 1 to 15 that identifies the privilege level. The default is 15.
---------------------------	---------------	---

Command Default	The default level is 15.
------------------------	--------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	12.1(6)E	This command was introduced.
	12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
	12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines	The privilege level for the xsm privilege configuration level command must be greater than or equal to the privilege level for the xsm privilege monitor level command. For example, if the xsm privilege configuration 7 command is enabled, you need a minimum privilege level of 7 to subscribe to configuration XRDs. The higher the number the higher the privilege level. Trying to set a conflicting range of privilege settings will force the Cisco device to display the following message:
-------------------------	--

Attempt to set monitor privilege greater than configuration. Privilege denied.

You can check the XSM privilege level settings by using the **show xsm status** command. Use the **show xsm xrd-list** command to check which privilege level is required for each XRD.

**Note**

The initial login set by your system administrator determines whether you have the necessary IOS privilege level for actually configuring the Cisco router. Ask your system administrator for more information about privilege levels.

Examples

The following example shows how to set a configuration privilege level of 15, and a monitor privilege level of 11 for subscription to XRDs. Users with a privilege level below 11 are denied access.

```
Router(config)# xsm privilege configuration level 15
Router(config)# xsm privilege monitor level 11
```

Related Commands

Command	Description
privilege	Configures IOS privilege parameters.
xsm privilege monitor level	Enables monitor privilege level to subscribe to XRDs.

xsm privilege monitor level

To enable the XML Subscription Manager (XSM) monitoring privilege level required to subscribe to XML Request Descriptors (XRDs), use the **xsm privilege monitor level** command in global configuration mode. To remove a previously configured XSM monitoring privilege level, use the **no** form of this command.

xsm privilege monitor level *number*

no xsm privilege monitor level *number*

Syntax Description

<i>number</i>	Integer in the range from 1 to 15 that identifies the privilege level. The default is 15.
---------------	---

Command History

The default is level 1.

Command Modes

Global configuration

Command History

Release	Modification
12.1(6)E	This command was introduced.
12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

The privilege level for the **xsm privilege monitor level** command must be less than or equal to the privilege level for the **xsm privilege configuration level** command. For example, if the **xsm privilege monitor 7** command is enabled, you need a minimum privilege level of 7 to subscribe to monitor XRDs. The higher the number the higher the privilege level. Trying to set a conflicting range of privilege settings will force the Cisco device to display the following message:

```
Attempt to set monitor privilege greater than configuration. Privilege denied.
```

You can check the XSM privilege level settings by using the **show xsm status** command. Use the **show xsm xrd-list** command to check which privilege level is required for each XRD.



Note

The initial login set by your system administrator determines whether you have the necessary IOS privilege level for actually configuring the Cisco router. Ask your system administrator for more information about privilege levels.

Examples

The following example shows how to set a configuration privilege level of 15 and a monitor privilege level of 11 for subscription to XRDs. Users with a privilege level below 11 are denied access.

```
Router(config)# xsm privilege configuration level 15
Router(config)# xsm privilege monitor level 11
```

Related Commands

Command	Description
privilege	Configures IOS privilege parameters.
xsm privilege configuration level	Enables configuration privilege level to subscribe to XRDs.

xsm vdm

To grant access to VPN-specific monitoring and configuration data for the VPN Device Manager (VDM), use the **xsm vdm** command in global configuration mode. To cancel access to VPN-specific monitoring and configuration data for VDM, use the **no** form of this command.

xsm vdm

no xsm vdm

Syntax Description This command has no arguments or keywords.

Command Default Enabled (Access to VPN-specific monitoring and configuration data for the VDM is granted when XSM is enabled.)

Command Modes Global configuration

Command History	Release	Modification
	12.1(6)E	This command was introduced.
	12.2(9)YE	This command was integrated into Cisco IOS Release 12.2(9)YE.
	12.2(9)YO1	This command was integrated into Cisco IOS Release 12.2(9)YO1.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines This command enables access to the following VPN-specific information:

- IPSec
- IKE
- Tunneling
- Encryption
- Keys and certificates

If XSM is enabled, this command is enabled by default. Access to VPN-specific monitoring and configuration data within XSM can be disabled by using the **no** form of the command. However, disabling this command will prevent VDM from working properly and will also disable the **xsm history vdm** command. Leaving this command enabled has minimal performance impact.

Examples In the following example, access to VPN-specific monitoring and configuration data is disabled:

```
Router(config)# xsm
Router(config)# no xsm vdm
```

Related Commands

Command	Description
xsm	Enables XSM client access to the router.
xsm dydm	Grants access to switch operations.
xsm edm	Grants access to EDM monitoring and configuration data.
xsm history vdm	Enables specific VPN statistics collection on the XSM server.

