



Viewing VPN Properties In Service View

This chapter describes viewing the properties of the various business elements, as follows:

- Viewing VPN Properties, page 4-1—Describes how to view VPN properties.
- Viewing Site Properties, page 4-2—Describes how to view Site properties.
- Viewing a Virtual Router's Properties, page 4-2—Describes how to view a Virtual Router's properties. In addition, it describes the VRF table and displaying the VRF egress and ingress adjacents.
- Viewing VRF Properties In the Inventory Window, page 4-6—Describes viewing VRF and PWE3 Tunnels VPN specific logical inventory items.
- Working With the VPN Service Overlay, page 4-8—Describes how to select and display an overlay, how to display or hide a previously defined overlay, and how to display or hide the callouts for every link in the map pane.

Viewing VPN Properties

Cisco ANA enables the user to view the properties of the VPN business element.

To view VPN properties:

Step 1Right-click on the VPN in the Cisco ANA NetworkVision window's tree pane or map pane to display
the shortcut menu. Select **Properties**. The VPN Properties dialog box for the selected VPN is displayed.

The following field is displayed in the VPN Properties dialog box:

• Name—The name of the VPN.



The name of the VPN can be changed using the **Rename** shortcut menu option.

- ID—The unique key automatically assigned to the VPN.
- **Step 2** Click to close the VPN Properties dialog box.

Viewing Site Properties

Cisco ANA enables the user to view the properties of a Site, including the interfaces that are configured on the PE. The properties that are displayed reflect the configuration that is automatically discovered from the device.

Note

The user can also add a business tag to the interface. For more information about business tags see the *Cisco Active Network Abstraction NetworkVision User Guide*.

To view Site properties:

Step 1 Right-click on a Site in the Cisco ANA NetworkVision window's tree pane or map pane to display the shortcut menu. Select **Properties**. The Router IP Interface Properties dialog box for the selected Site is displayed.

The following fields are displayed in the Router IP Interface Properties dialog box:

- Name—The name of the Site, for example, ATM4/0.100(10.0.0.1) is a combination of the interface name and IP address used to reach the Site.
- Mask—The mask of the specific network.
- Sending Alarms—Whether the alarm for the required port has been enabled (true) or disabled (false).
- IP Address—The IP address of the interface.
- State—The state of the interface, namely, Up or Down.

The **Addresses** table displays the details of the IP interfaces on the PE-side. The **Subnet** column is a combination of the IP address and the subnet mask.

Step 2 Click to close the Router IP Interface Properties dialog box.

Viewing a Virtual Router's Properties

Cisco ANA NetworkVision enables the user to view the route distinguisher, and the import and export policies for each VRF.

To view a Virtual Router's properties:

Step 1 Right-click on a Virtual Router in the Cisco ANA NetworkVision window's tree pane or map pane to display the shortcut menu. Select Properties. The VRF Properties dialog box for the Virtual Router is displayed.

Black@PE_Sou	th - VRF Prop	erties						
Route Distinguisher : 64000:18								
Name : Black								
Export Route Targets								
124:124 1000:1000 124:124								
Sites VRF Table								
Find:								
Name 🕹 🛆	IP Address	Mask	State	Description	Input Access List	Output Access List	Rate Limits	IP Sec Map Name
FastEthernet1/0.14	10.10.10.25	255.255.255.252	Up				-	
FastEthernet1/0.18	10.10.10.21	255.255.255.252	Up				-	
FastEthernet1/0.222	25.25.25.25	255.255.255.252	Up				-	
Loopback100	9.9.9.9	255.255.255.255	Up				-	
<			Ш					>
								Line 1 (Size 4)
~ *						Memory:	12%	Connected

Figure 4-1 VRF Properties Dialog Box

The following field is displayed at the top of the VRF Properties dialog box:

• Route Distinguisher—The route distinguisher configured in the VRF.

The **Export/Import Route Targets** areas displayed in the VRF Properties dialog box specify separately the export and import policies for each VRF.

The VRF Properties dialog box is divided into two tabs, namely, the **Sites** and **VRF Table** tabs. The **Sites** tab displays the interfaces connected to the VRF and the configuration of the interfaces. The following columns are displayed in the **Sites** tab:

- Interface—A hyperlink that displays the Inventory window for the IP interface linked to the Site on the PE side.
- Name—The name of the Site, for example, ATM4/0.100(10.0.0.1) is a combination of the interface name and IP address used to reach the Site.
- IP Address—The IP address of the interface.
- Mask—The details of the dotted decimal mask.
- State—The state of the sub-interface, namely, Up or Down.
- Description—A description of the interface.
- Input Access List—The access list applied to the inbound traffic of the interface.



This parameter is only relevant for Cisco IOS devices.

• **Output Access List**—The access list applied to the outbound traffic of the interface.



This parameter is only relevant for Cisco IOS devices.

• **Rate Limits**—Measures traffic for the IP interfaces on Cisco devices, including the average rate, normal burst size, excess burst size, conform-action and exceed action.



• Site Name—The name of the business element to which the interface is attached.

The VRF Table tab is displayed below.

Figure 4-2 VRF Table Tab

🔽 Black@PE_South - VRF Properties										
Route Distinguisher : 64000:18										
Name : Black										
Export Route Targets						Import Route Targets				
124:124					1000:1000					
					124:124					
Sites VRF Table										
Deatherting D.V.	March							Deuties Destaurt	Constitute Alarma	
Destination +++	Mask	Next Hop	BGP Next Hop	VRF Out Label	VRF IN Label	MPLS Laber	Type	Routing Protocol	Sending Alarms	
192.168.100.0	255.255		80.80.80.62	5/		30	Indirect	BGP		
192.168.2.0	255.255		80.80.80.62	55		36	Indirect	BGP		
1921681.0	255 255		80.80.80.62	54		36	Indirect	BGP	E	
150,150,150,150	255.255		80.80.80.62	53		36	Indirect	BGP		
60.60.60.160	255.255	10.10.10.22			82		Indirect	Local		
60.60.60.87	255.255	10.10.10.26			81		Indirect	OSPF		
50.50.50.50	255.255		80.80.80.64	1024		37	Indirect	BGP		
43.43.43.0	255.255		80.80.80.60	48		34	Indirect	BGP		
30.30.30.0	255.255	10.10.10.26			83		Indirect	OSPF	~	
Line 1 (Size 20)										
							Memory	12%	Connected	
1							wembry.	12.90	Ponnecied	

VRF Table tab contains the VRF routing table for the device, namely, a collection of routes that are available or reachable to all the destinations or networks in this VRF. In addition, the forwarding table also contains MPLS encapsulation information.

The following columns are displayed in the **VRF Table** tab:

- **Destination**—The destination of the specific network.
- Mask—The mask of the specific network.
- **Next Hop**—The CE address from where to continue to get to a specific address. This field is empty when the routing entry goes to the PE.
- **BGP Next Hop**—The PE address from where to continue to get to a specific address. This field is empty when the routing entry goes to the CE.
- VRF Out Label—The label sent with MPLS traffic.
- VRF In Label—The label that is expected when MPLS traffic is received.
- MPLS Label—The MPLS label.

- Type—The type can be direct (local) or indirect
- **Routing Protocol**—The routing protocol used to communicate with the other Sites/VRFs, namely, BGP or local.
- **Outgoing Int. Name**—The name of the outgoing interface is displayed if the Routing Protocol type is local.
- **Step 2** Click to close the VRF Properties dialog box.

Opening the VRF Table

The user can view the VRF table for a Virtual Router.

To open the VRF Table:

Step 1 Right-click on the Virtual Router in the Cisco ANA NetworkVision window's tree pane or map pane to display the shortcut menu. Select Open VRF Table. The VRF Table dialog box is displayed.

For more information about the columns displayed in the VRF Table dialog box, see Viewing a Virtual Router's Properties, page 4-2.

Step 2 Click to close the VRF Table dialog box.

Displaying the VRF Egress/Ingress Adjacents

Cisco ANA enables the user to view the exporting and importing neighbors by displaying the VRF egress and ingress adjacents. In addition, the user can view the connectivity between the VRFs regarding the route targets and view all their properties.

For example, if VRF A retrieved route target import X then the user will be able to view all the VRFs in the system that are exporting X as a route target whether its in the same VPN or in another VPN.

To display the VRF egress/ingress adjacents:

Step 1 Right-click on the Virtual Routefr in the Cisco ANA NetworkVision window's tree pane or map pane to display the shortcut menu. Select Show VRF Egress Adjacents/Show VRF Ingress Adjacents. The Adjacents dialog box is displayed.

The adjacents displayed are according to the route targets. The following columns are displayed in the table on the right side of the dialog box (properties pane) when the top branch is selected in the tree pane:

- Name—The name of the VRF as it appears in the device.
- Route Distinguisher—The route distinguisher configured in the VRF.

Selecting a specific VRF in the Cisco ANA NetworkVision window's tree pane the displays the properties of the VRF. For more information, see Viewing a Virtual Router's Properties, page 4-2.

Step 2 Click to close the Adjacents dialog box.

Viewing VRF Properties In the Inventory Window

This section describes viewing only the following VPN specific logical inventory items, namely, VRF and **PWE3** Tunnels.

<u>Note</u>

In addition to opening the Inventory window from a device, you can also open and view logical inventory information for a specific Virtual Router directly by right clicking on the Virtual Router to display the shortcut menu and selecting **Inventory**.

For details on viewing the following VPN MPLS specific logical inventory items, namely, BGP Neighbor, MP BGP information, LSEs, and MPLS TE tunnels, and MPLS Black Holes, see Chapter 4, "Viewing VPN Properties In Service View".

To open the Inventory window:

- **Step 1** Right-click on a device in the Cisco ANA NetworkVision window's tree pane or map pane to display the shortcut menu.
- **Step 2** Select **Inventory**. The Inventory window for the selected device is displayed.



Figure 4-3 Inventory Window

1	Tree pane
2	Properties pane including tabs

3	Device view panel
4	Status bar
5	Hidden ticket pane

The tree pane displays a tree and branch representation of the logical and physical inventory. The heading of the window and the root of the tree pane display the name of the selected router.

The properties pane displays physical and logical inventory information relating to the properties of the item selected in the tree pane.



Note The properties of the item selected in the tree pane or the row selected in the properties pane can be displayed by double-clicking it or by right-clicking the line and selecting **Properties** from the shortcut menu.

Step 3 Click to close the Inventory window.

You can view Inventory properties in the properties pane and/or properties pane tab tables, or view selected properties in separate window (Properties window).

Clicking on a sub-branch tree pane option in the Inventory window, displays the properties in the properties pane of the Inventory window:

Double-clicking a sub-branch tree pane option in the Inventory window, displays properties in a window.

Viewing Cross VRF Routing Entries

Cross VRF Routing entries are displayed by double-clicking on an entry in the MP BGP properties pane. The **Cross VRF Routing Entries** table displays routing information learned from the BGP neighbors (BGP knowledge base). The parameters of the cross VRF routing entries are displayed in the Cross VRF MP BGP Properties window tab, an example of which is displayed.

The following information is displayed in the Cross VRF Routing Entries table:

- Destination—The destination of the specific network.
- Mask—The mask of the specific network.
- Next Hop—The PE address from where to continue to get to a specific address.
- **Out Going VRF**—The VRF routing entry that points to the other VRF in the same PE. The Out Going VRF is the VRF that is pointed to by the Cross VRF entry.
- **Out Tag**—The MPLS label inserted in the MPLS label stack by this PE router in order to reach the destination address that is connected to the other VRF.
- In Tag—The MPLS label used by this router in order to identify traffic arriving at the destination address, it was advertised by this PE router and is inserted in the MPLS label stack by the PE from where the traffic originated.

Working With the VPN Service Overlay

In addition to Network and Service View maps the user can select and display an overlay of a specific VPN on top of the devices displayed on the Network map in the map pane. The overlay is a snapshot of the network which visualizes the flows between the Sites and tunnel peers When one of the VPNs in the network is selected (in the Network map), the provider edge routers, MPLS routers and physical links that carry the LSP that is being used by the VPN are highlighted in the Network map and all the devices and links that are not part of the VPN are grayed out.

This enables the user to isolate the parts of a network that are being used by a particular service and this information can then be used for troubleshooting. For example, the overlay can highlight configuration or design problems when a bottleneck exists and all the Site interconnections using the same link.

Note

If the routing information changes after the overlay is run, then the current view will not reflect this change.

Cisco ANA NetworkVision enables you to view overlays of specific VPNs on top of the devices displayed in physical Network maps. In addition, it enables you to view selected callouts for the links displayed on the Network map when the overlay is applied.

This section describes the following overlay functionality information:

- Selecting an Overlay, page 4-8—Describes how to select and display an overlay of a specific VPN on top of the devices displayed on the physical Network map.
- Displaying or Hiding Overlays, page 4-9—Describes how to display or hide a previously defined overlay of a specific VPN on top of the physical devices displayed on the physical Network map.
- Displaying or Hiding Callouts, page 4-9—Describes how to display or hide the callouts for every link in the map pane in order to display related information.

Selecting an Overlay

The user may select and display an overlay of a specific VPN on top of the devices displayed on the physical Network map displayed in the map pane.

To select an overlay:

- **Step 1** Select and display the required Network map in the Cisco ANA NetworkVision window.
- Step 2 On the toolbar, click Choose Overlay. The Choose Overlay dialog box is displayed.

The Choose Overlay dialog box displays a list of the available VPNs in the network.

- **Step 3** Select the required VPN from the list.
- **Step 4** Click **OK**. The provider edge routers, MPLS routers and physical links that are being used by the selected VPN are highlighted in the Network map and the VPN name is displayed in the title of the window.



The overlay is a snapshot taken at a specific point in time and in order to update the overlay the user must select and run it again.

You can choose to hide previously defined VPN network information in the map pane using the appropriate toolbar buttons:

- Overlay information, such as link and layer details
- Callouts for the VPN network

Displaying or Hiding Overlays

The user can quickly and easily display or hide a previously defined overlay of a specific VPN on top of the physical devices displayed on the Network map in the map pane.

Note

The **Show Overlay** button on the toolbar toggles when selected (displays the overlay) or deselected (hides the overlay).

To show or hide the overlay:

Step 1 Select and display the required Network map in the Cisco ANA NetworkVision window.

Step 2 On the toolbar, click **Show Overlay**. The overlay is displayed in the Network map,

or

On the toolbar, click **Show Overlay**. The overlay is hidden from view in the Network map.

Displaying or Hiding Callouts

The user can display or hide the callouts for the links displayed in the map pane in order to show the details of the sites that are interconnected through the selected links.



Multiple callouts can be opened at the same time.

The Callouts dialog box enables the user to view the VPN traffic connections for a specific link (either bi-directional or uni-directional).

In the example below, P-North - > PE-West, the table displays the traffic connections from one Site/LCP to another.



1	Details of the link and the direction. In this example from P-North to PE-West
2	Details of the sites using the link and interconnections. In this example Site PE-88 is connected to Site PE-West
3	Details of the sites using the link and interconnections. In this example Site PE-West is connected to all these Sites on PE-South
4	Details of the link and the direction. In this example from PE-West to P-North

The user can hide the callouts displayed in the map pane.

To view the callouts:

- **Step 1** Select and display the required Network map with an overlay of the specific VPN in the map pane of the Cisco ANA NetworkVision window.
- **Step 2** Right-click on the required link in the map pane to display the shortcut menu and select **Show Callouts**. The Callouts label is displayed.

To hide the callouts:

- **Step 1** Right-click on the link in the map pane that has the attached callout. The right-click shortcut menu is displayed.
- **Step 2** Select **Hide Callouts**. The callouts are no longer displayed in the map pane of the Cisco ANA NetworkVision window.