



CHAPTER 5

Working with Prime Network Vision Maps

The topological map is the main tool used by Cisco Prime Network Vision (Prime Network Vision) to display the links and relationships between the network elements and aggregations. The following topics describe how to work with the topological maps displayed in the content pane of the Prime Network Vision window:

- [User Roles Required for Working with Prime Network Vision Maps, page 5-2](#)
- [Opening and Closing Maps, page 5-5](#)
- [Creating and Deleting Maps, page 5-6](#)
- [Adding and Removing NEs from Maps, page 5-9](#)
- [Managing Maps, page 5-11](#)
- [Finding NEs, Services, and Links, and Elements Affected by Tickets, page 5-15](#)
- [Working with Aggregations, page 5-16](#)
- [Working with Overlays, page 5-21](#)
- [Filtering Links in a Map, page 5-25](#)
- [Opening the CPU Usage Graph, page 5-27](#)
- [Communicating with Devices Using Ping and Telnet, page 5-28](#)

You can also perform the following functions from the map and list views if they are configured for your client:

- Launch external applications or tools, such as an SSH client.
- Launch available scripts and commands, depending on the NE device type, OS, supported technologies, and so forth. Those commands are documented throughout this guide (for example, [Configuring and Viewing NEs using Basic Management Commands, page 3-37](#)). This also includes commands you create using Command Builder. These scripts can be launched against multiple network elements at the same time.

For more information on these functions, see the [Cisco Prime Network 3.10 Customization Guide](#).

User Roles Required for Working with Prime Network Vision Maps

This topic identifies the roles that are required to work with Prime Network Vision maps. Prime Network determines whether you are authorized to perform a task as follows:

- For GUI-based tasks (tasks that do not affect elements), authorization is based on the default permission that is assigned to your user account.
- For element-based tasks (tasks that do affect elements), authorization is based on the default permission that is assigned to your account. That is, whether the element is in one of your assigned scopes and whether you meet the minimum security level for that scope.

For more information on user authorization, see the [Cisco Prime Network 3.10 Administrator Guide](#).

The following tables identify the tasks that you can perform:

- [Table 5-1](#) identifies the tasks that you can perform if a selected element **is not in** one of your assigned scopes.
- [Table 5-2](#) identifies the tasks that you can perform if a selected element **is in** one of your assigned scopes.

By default, users with the Administrator role have access to all managed elements. To change the Administrator user scope, see the topic on device scopes in the [Cisco Prime Network 3.10 Administrator Guide](#).

Table 5-1 Default Permission/Security Level Required for Working with Prime Network Vision Maps - Element Not in User's Scope

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
Map-Related Tasks					
Apply a background image	—	—	—	X	X
Create maps	—	—	X	X	X
Define a map layout	X	X	X	X	X
Delete maps	—	—	X	X	X
Open maps	X	X	X	X	X
Preview and print maps	X	X	X	X	X
Rename maps	—	—	X	X	X
Save as a new map	—	—	X	X	X
Save as an image	X	X	X	X	X
Save map appearance	—	—	X	X	X
Select viewing options	X	X	X	X	X
Use Overview window	X	X	X	X	X
View maps	X	X	X	X	X

Table 5-1 *Default Permission/Security Level Required for Working with Prime Network Vision Maps - Element Not in User's Scope (continued)*

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
Element-Related Tasks					
Add elements to a map	—	—	X	X	X
Remove elements from a map	—	—	X	X	X
Resize elements in a map	X	X	X	X	X
Aggregation-Related Tasks					
Group and ungroup aggregations	—	—	X	X	X
Rename aggregations	X	X	X	X	X
View aggregation thumbnails	X	X	X	X	X
Finding Items in Maps					
Find affected elements	—	—	—	—	X
Find an element or service	X	X	X	X	X
Find and select a link in a map ¹	X	X	X	X	X
Link-Related Task					
Filter links	X	X	X	X	X
Overlay-Related Tasks					
Apply an overlay	X	X	X	X	X
Hide or view an overlay	X	X	X	X	X
Remove an overlay	X	X	X	X	X
Other Tasks					
Open the CPU Usage Graph	—	—	—	—	X
Use Ping and Telnet to communicate with elements	—	—	—	—	X

1. This applies to links within the selected context, and not links identified as network links.

Table 5-2 *Default Permission/Security Level Required for Working with Prime Network Vision Maps - Element in User's Scope*

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
Map-Related Tasks					
Apply a background image	—	—	—	X	X
Create maps	—	—	X	X	X
Define a map layout	X	X	X	X	X
Delete maps	—	—	X	X	X
Open maps	X	X	X	X	X
Preview and print maps	X	X	X	X	X
Rename maps	—	—	X	X	X
Save as a new map	—	—	X	X	X
Save as an image	X	X	X	X	X
Save map appearance	—	—	X	X	X
Select viewing options	X	X	X	X	X
Use Overview window	X	X	X	X	X
View maps	X	X	X	X	X
Element-Related Tasks					
Add elements to a map	—	—	X	X	X
Remove elements from a map	—	—	X	X	X
Resize elements in a map	X	X	X	X	X
Aggregation-Related Tasks					
Group and ungroup aggregations	—	—	X	X	X
Rename aggregations	X	X	X	X	X
View aggregation thumbnails	X	X	X	X	X
Finding Items in Maps					
Find affected elements	X	X	X	X	X
Find an element or service	X	X	X	X	X
Find and select a link in a map ¹	X	X	X	X	X

Table 5-2 *Default Permission/Security Level Required for Working with Prime Network Vision Maps - Element in User's Scope (continued)*

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
Link-Related Task					
Filter links	X	X	X	X	X
Overlay-Related Tasks					
Apply an overlay	X	X	X	X	X
Hide or view an overlay	X	X	X	X	X
Remove an overlay	X	X	X	X	X
Other Tasks					
Open the CPU Usage Graph	—	—	X	X	X
Use Ping and Telnet to communicate with devices	—	—	—	X	X

1. This applies to links within the selected context, and not links identified as network links.

Opening and Closing Maps

Whenever you open a map, the network information is automatically refreshed. For example, if a device was up the last time that the map was saved and closed, and then the device is moved to maintenance, the next time you open the map the management status of the device is updated accordingly and the device displays a maintenance status.

When you first log in, Prime Network Vision lists the maps you recently viewed but did not close when you exited the session. You can also open other maps by choosing **File > Open**, which displays the Open Map dialog.

By default, you can view and work on a maximum of five maps at any given time (per client instance) in the Prime Network Vision window. To change this default setting, contact your Cisco account representative. To create a new map or select a new map, close the required number of maps.

You can save maps as images or print them, if desired.

To close a map, choose **File > Close**. Prime Network Vision saves basic map information whether or not you manually save the map. This default information includes device and link additions, device and link removals, aggregations, and disaggregations. If you made any changes that will not be saved, Prime Network Vision prompts you to save the map.

Creating and Deleting Maps

You can create maps that cover specific network segments, customer networks, or any other mix of network elements required. Network maps provide a graphic display of active faults and alarms, and serve as access points for activating services. When you create a map, it is saved in the database and made available to other users if they have sufficient access and security privileges. When you delete a map, it is removed from the database. See these topics for more information:

- [Creating New Maps, page 5-6](#)
- [Deleting Maps from the Database, page 5-8](#)


Creating New Maps

To create a new map, choose **File > New Map** in the main menu. The following figures give examples of how you can create and manipulate maps. To add NEs to maps, see [Adding and Removing NEs from Maps, page 5-9](#).

Link Filters

Link filters let you choose the links in which you are interested, and then build a map that only displays NEs using those link types. Examples are physical links, data links, MPLS, VLANs, and so forth. When you open the New Map dialog, click the Advanced button and choose the types you want to display.

Figure 5-1 Map with Link Filter




To create a map with link filters, see [Figure 5-13](#).

Aggregations

Aggregations are user-defined groups of elements. An aggregation can contain network elements, services, other aggregations, and so forth. [Figure 5-2](#) shows an example of an aggregation.

Figure 5-2 Map with Aggregation (Thumbnail View)




When you delete an aggregation, the member devices are not deleted from Prime Network; only the aggregation definition is deleted. To create an aggregation, see [Working with Aggregations, page 5-16](#).

Overlays

Overlays isolate the parts of a network that are being used by a specific service, such as an ethernet service or network clock. [Figure 5-3](#) shows an example of an Ethernet Service overlay, where the ethernet link is using the service.

Figure 5-3 Map with Overlay



To create an overlay, see [Working with Overlays](#), page 5-21.

Deleting Maps from the Database

If another client is using a map that you are deleting, Prime Network Vision displays a message to those clients advising them that the map is being closed and deleted from the database.

To delete a map from Prime Network Vision and the Prime Network Vision database:

- Step 1** Open the Open Map dialog by choosing **File > Open**.
- Step 2** In the Open Map dialog box, complete the following steps:
 - a. Select the map you want to delete.
 - b. In the toolbar, click **Delete Map**. A confirmation message is displayed.
 - c. Click **Yes**. The selected map is deleted from the Open Map dialog box, the Prime Network Vision window, and the database. If the map is open when you click **Yes**, a message is displayed, stating that the map will be closed.
 - d. Click **OK** to acknowledge that the map can be closed.
 - e. Click **Cancel** to close the Open Map dialog box.

Adding and Removing NEs from Maps

When you add an element to a map, the map is automatically saved in the Prime Network Vision database.


If the element you want to add is outside of your scope, it is not displayed if you enter a search string. You can display all NEs by selecting **Show All** in [Step 2](#), but devices outside your scope will be displayed with a lock icon.

To add an element to a map:

Step 1 Choose **File > Add to Map > element**.

[Figure 5-4](#) shows the type of elements you can add to maps.


Figure 5-4 Available Elements to Add to Maps



If you choose to add a new VPN, the Create VPN dialog box is displayed. For information on creating a VPN, see [Creating a VPN, page 19-21](#).

In all other instances, the Add *element* to map dialog box is displayed, as shown in [Figure 5-5](#).

Figure 5-5 Add Element Dialog Box



Step 2 In the Add *element* dialog box, do one of the following:

If you are working with a very large number of network elements, keep these items in mind:

- Search for the elements you want to add to the map. For example, you can search Ethernet Services by the system name, NEs element type, pseudowires by their role, and so forth.



Note

If you are working with a large number of NEs, using the search filter Otherwise, it may take some time for all of the NEs to be listed.

- To view all available elements, choose **Show All**.

The available elements are displayed in the Add *element* dialog box in table format. The dialog box also displays the date and time at which the list was generated. To update the list, click **Refresh**.

If a network element is not included in your scope, it is displayed with the locked device icon.

Step 3 In the Add *element* dialog box, select the elements that you want to add. You can select and add multiple elements by pressing **Ctrl** while selecting individual network elements or by pressing **Ctrl + Shift** to select a group of elements.

- Step 4** Click **OK**. If you selected a large number of elements (for example, more than 25 VLANs or VPLS instances), the action may take a while to complete.
- The NEs are added to the map and are displayed in the navigation pane and content area. In addition, any associated tickets are displayed in the ticket pane.
-

Removing Elements from a Map

When you delete an element or aggregation from a map, it is removed from the map in the database, but the elements are still managed by Prime Network Vision.



Note

Based on the security level and access permissions assigned, this option might not be available to all users.

To remove a network element or aggregation from a map:

- Step 1** In the navigation pane or map, select the element or aggregation that you want to delete.
- Step 2** Right-click to display the right-click menu and choose **Remove from Map**. The selected element or aggregation is removed from the map.
-

The element is removed from the map in the database, but is still managed by Prime Network Vision and can be added again.

Managing Maps






The following topics describe how to manage maps in Prime Network Vision:

- [Selecting Map Viewing Options, page 5-12](#)
- [Applying a Background Image, page 5-12](#)
- [Using the Overview Window, page 5-14](#)
- [Saving Maps, page 5-15](#)

Selecting Map Viewing Options

Table 5-3 describes the tools that you can use to view and manipulate maps in the Prime Network Vision map pane.

Table 5-3 Prime Network Vision Map Viewing Options

Button	Name	Function
	Layout Map	Defines how a topology should be displayed: Circular, hierarchical, orthogonal, or symmetric. The default is circular. When you choose a map layout, the elements align accordingly, using animation by default. Related characteristics, such as the speed of the animation and whether an expanded node causes sibling nodes to move aside, are also configured by settings in the registry.
	Fit in Window	Fits an entire aggregation or map in the map pane.
	Normal Selection Mode	Activates normal selection mode.
	Zoom Selection Mode	Activates the zoom selection mode, which enables you to select an area in the map pane to enlarge by clicking and dragging the zoom mode cursor.
	Pan Mode	Activates the pan mode, which enables you to move around in the map pane by clicking and dragging the pan mode cursor.

Applying a Background Image

Prime Network Vision allows you to apply a background image to the map view. You can also choose the same background image or different images for other subordinate windows, such as detailed views of aggregations, VLANs, and VPNs.


The supported file formats are GIF, JPG/JPEG, and PNG.



Note Background images are not supported in thumbnail views.

To apply a background image to a map:

- Step 1** Navigate to the required map in Prime Network Vision. The map can reside at the top level or in a subordinate window.
- Step 2** Right-click the map background and choose **Set Map Background**.
The Manage Map Background dialog box is displayed, as shown in [Figure 5-6](#).

Figure 5-6 Manage Map Background Dialog Box

Step 3 Enter the required information as described in [Table 5-4](#).

Table 5-4 Manage Map Background Options

Field	Description
Select Image	Applies the selected image to the current map background: <ol style="list-style-type: none"> 1. Choose Select Image. 2. Click Browse. 3. In the Open dialog box, select the desired image and click OK. The name of the selected image is displayed in the Manage Map Background dialog box. 4. Click OK. The selected image is displayed as the map background.
Use Image From Upper Level	Indicates whether the selected subordinate map should use the same image as the parent map or a different image: <ul style="list-style-type: none"> • To use the same image that is used by the parent map, choose Use Image from Upper Level. The name of the image used by the parent map is displayed by default. • To use a different image than that used by the parent map, choose Select Image and complete the steps described for that option.
Remove Image	Removes the current image from the map background. To remove an image from the current map, click Remove Image .

Step 4 Click **OK**. The current map background is updated as specified.

Step 5 To retain the background image for subsequent logins, do one of the following:

- Click **Save** in the toolbar.
- Choose **File > Save**.

Using the Overview Window


The Prime Network Vision Overview window enables you to display the entire network map or any part of the map that you require in the map pane. The Overview window also enables you to see all the changes and alarms taking place in the network.

To open the network Overview window do either of the following:

- Click **Overview** in the main toolbar.
- Choose **View > Overview** from the main menu.

Figure 5-7 shows an example of the Overview window.

Figure 5-7 Overview Window



The Overview window can contain the following components:

- Dot—Indicates an element. The dot color indicates the severity of an associated alarm.
- Line—Indicates a link. The line color indicates the severity of an associated alarm.
- Blue rectangle—Indicates the selection area. The area within the rectangle is displayed in the map pane. Handles on the corners enable you to resize the selection area.
- Pan mode cursor—Displayed within the selection area. Use this cursor to move the selection area, and thereby view different elements in the map pane.
- Zoom mode cursor—Displayed outside the selection area. Use this cursor to define a new selection area or to zoom in on an existing selection area.

Click the upper right corner to close the Overview window.

Saving Maps

By default, Prime Network Vision saves basic map information whether or not you manually save the map. This default information includes element additions and removals, link additions and removals, aggregations, and disaggregations. However, you must use the Save Map option if you want to retain the following information in the database:

- Device location on the map
- Thumbnails
- Icon size

To save these changes, do one of the following:

- Click **Save Map Appearance** in the main toolbar.
- Choose **File > Save Map**.

Step 6 Click **OK**. The map is saved as an image in the directory you specified.

Finding NEs, Services, and Links, and Elements Affected by Tickets

The following topics describe how to find network elements, services, links, or elements affected by a ticket in Prime Network Vision maps.

Table 5-5 *Aggregation Thumbnail Options*

If you want to find...	Do this...
An NE or service	From the Prime Network Vision main menu, choose Edit > Find in Map . Enter an element or service (such as a VPN or VLAN) by entering any part of its name or device IP address. If you want your search to include aggregations, check the Search all map levels check box.
A link	From the Links view, right-click the link and choose Find Link in Map . The link is highlighted in the map pane. If two or more lines represent the same link (such as a VRF link), you can choose the appropriate one. If more than one edge device contains the same link in the same map or context, all related edge devices are selected in the map.
Which NEs are affected by a ticket	In the ticket pane, right-click the required ticket and choose Find Affected Elements . If only one element is affected, the affected element is selected in the navigation pane and the content area; if a link is affected, the affected link is selected in the links view. If two or more elements are affected, the affected elements are displayed in the Affected Elements window.

Working with Aggregations

Prime Network Vision enables you to group network elements and display them as an aggregation. Aggregations can contain network elements, services, other aggregations, and so forth.

**Note**

You cannot aggregate service entities that exist within a service. For example, you cannot aggregate VRFs that exist within a VLAN.


For more information on working with aggregations, see the following topics:

- [Grouping Network Elements into Aggregations, page 5-16](#)
- [Adding Elements to an Existing Aggregation, page 5-18](#)
- [Viewing an Aggregation Thumbnail, page 5-16](#)
- [Ungrouping Aggregations, page 5-19](#)
- [Viewing Multi Chassis Devices, page 5-19](#)

Grouping Network Elements into Aggregations

To aggregate network elements:

- Step 1** Select the network elements. To select multiple items, press **Ctrl**.
- Step 2** Aggregate the network elements by choosing **Node > Aggregate**.
- Step 3** In the Aggregation dialog box, enter a unique name for the aggregation and click **OK**. The aggregation is displayed in the navigation pane and the map pane. Aggregations are displayed as a single entity with the Aggregation icon and a plus sign, as in the following examples:



The aggregation icon changes color according to the alarm severity. For more information about severity colors, see [Alarm Indicators, page 2-11](#).


Viewing an Aggregation Thumbnail

You can view a thumbnail of a selected aggregation in the map pane, including all aggregated elements and any nested aggregations.

To display an aggregation thumbnail:

- Step 1** Select the existing aggregation in the map pane.
- Step 2** Open the thumbnail by right-clicking the aggregation, and choosing **Show Thumbnail**.
- The thumbnail is displayed in the map pane as shown in [Figure 5-8](#).

Figure 5-8 Aggregation Thumbnail



When a thumbnail is opened, neighboring nodes are moved aside by default to allow room for the thumbnail to expand. Similarly, when a thumbnail is closed, the neighboring nodes usually return to their original locations. This behavior of the neighboring nodes when a thumbnail is opened and closed is configured in the registry, and can be disabled, if required.

A dashed gray border around an icon indicates that the element resides within a thumbnail and not at the current map level.

Table 5-6 describes the options available when working with aggregation thumbnails.

Table 5-6 **Aggregation Thumbnail Options**

If you want to...	Do this...
Rearrange the icons in the thumbnail	Click and drag the required icons to arrange them as needed.
Resize an icon	Select the icon to be resized, and then either click and drag the gray border or right-click a selected icon and choose Resize . The right-click Resize option allows you to resize multiple selected icons at the same time.
Resize the thumbnail frame	Click and drag one or more icons. If you drag an icon beyond the thumbnail frame, Prime Network Vision adjusts the thumbnail size automatically.
View a nested aggregation	Click the nested aggregation plus sign.
View only the aggregation in the map pane	Double-click the thumbnail frame.
View the next higher level in the map pane	Double-click the current map background.
Zoom in or out in the thumbnail	Position your mouse cursor in the map and use the mouse scroll wheel to zoom in or out.

Step 3 To close the aggregation thumbnail, right-click the thumbnail frame and choose **Show As Aggregation**.

Adding Elements to an Existing Aggregation

You can add elements to an existing aggregation at any time. When adding elements to an aggregation, keep in mind that certain restrictions exist. For example, you cannot add an EVC to a VLAN.

To add elements to an existing aggregation:

- Step 1** Select the existing aggregation in the map pane.
- Step 2** Open the thumbnail by right-clicking the aggregation, and choosing **Show Thumbnail**.
- Step 3** Double-click the thumbnail frame to view the aggregation at the map level.
- Step 4** Click **Add to Map** to add the required element to the aggregation.
- Step 5** Return to the map by double-clicking the map background.

Ungrouping Aggregations

Aggregations can be ungrouped. If the aggregation that you ungroup contains nested aggregations, the nested aggregations move up one level, and the original aggregation is removed.

If an element in the aggregation that you ungroup also exists at the parent level, the element is represented only once after the aggregation is ungrouped. As a result, no elements are represented twice at the same level.

To ungroup an aggregation:

-
- | | |
|---------------|--|
| Step 1 | Select the required aggregation in Prime Network Vision. |
| Step 2 | Ungroup the node by selecting the aggregation in the map pane and choosing Node > Disaggregate .


If the aggregation contains elements that already exist at the parent level, a confirmation message is displayed, stating that any duplicate elements will be removed. |
| Step 3 | Confirm the disaggregation. The node is disaggregated. Any aggregations in the selected node move up one level, and the original aggregation is removed. |
-

Viewing Multi Chassis Devices

Using Prime Network Vision, you can view the physical layout and topology among the multi-chassis devices on the map. The multi chassis devices are grouped as an aggregation and are displayed as a single entity with a plus sign on the map as show in [Figure 5-9](#). The plus sign can be expanded to display the devices under the group as shown in [Figure 5-10](#).


You can see the multichassis grouping in the map view for network elements such as Cisco Aggregation Service Router (ASR) 9000 series network element and Cisco Unified Computing System (UCS). If satellites are configured for a Cisco ASR 9000 series network element, you can view the satellites grouped with the other chassis. For more information on how to view satellite properties, see [Viewing Satellite Properties, page 3-22](#).

The physical ethernet links used for connecting the multi chassis devices are ICL (Inter Chassis Link) and IRL (Inter Rack Link). For more information on when each of these links are used, see [Viewing Inter Rack Links, page 5-20](#) and [Viewing Inter Chassis Links, page 5-20](#).

Figure 5-9 Multichassis Devices in Map View

Viewing Inter Rack Links

Inter Rack Links (IRLs) are used to represent connectivity between the cluster hosts, Cisco ASR 9000 network elements.


Figure 5-10 Multiple Chassis in a Cluster

To view the cluster IRLs:

- Step 1** In Prime Network Vision, double-click the cluster device to open the Inventory Window for the device.
- Step 2** Choose the **Cluster IRL** container in the logical inventory of the cluster device. The content pane displays a list of cluster IRLs with the following details:
 - A End Point—Device or site that is the source of the link, hyperlinked to the inventory of the device or site.
 - Z End Point—Device or site that is the destination of the link, hyperlinked to the relevant entry in the inventory.

Viewing Inter Chassis Links

Inter Chassis Links (ICLs) are used to represent the connectivity between the host Cisco ASR 9000 network element and the satellites. One or more satellites are connected to the host Cisco ASR 9000 series network element by using the ICLs. [Figure 5-11](#) shows an ICL in the map view.

Figure 5-11 ICL Connecting a Satellite with a Chassis

To view the satellite ICLs:

- Step 1** In Prime Network Vision, double-click the satellite device to open the Inventory Window for the device.
- Step 2** Choose the **Satellite ICL** container in the logical inventory of the cluster device. The content pane displays a list of Satellite ICLs with the following details:

Table 5-7 Satellite ICL Properties

Field	Description
Host Interface	Interface by which satellite is configured on the host network element. Click the hyperlink to view the interface properties in the physical inventory.
Satellite IC Interface	Inter-chassis interface used by the satellite. Click the hyperlink to view the satellite interface properties in the physical inventory.
Satellite ID	Satellite ID. Click the hyperlink to view the satellite properties in the physical inventory.
Satellite Port Range	Port associated with the satellite.
Satellite Status	Connection status of the satellite: Connected or Disconnected.
Fabric Link Status	Status of the fabric link connected to the satellite.

Working with Overlays

When you apply an overlay to a map, you can isolate the parts of a network that are being used by a specific service.

The following topics discuss the overlay options in more detail:

- [Applying an Overlay, page 5-22](#)
- [Hiding and Viewing Overlays, and Removing Overlays from a Map, page 5-25](#)

Applying an Overlay


To apply an overlay:

- Step 1** In Prime Network Vision, choose the map in which you want to apply an overlay.
- Step 2** From the toolbar, choose **Choose Overlay Type** > *overlay-type* where *overlay-type* is one of the following options:

Overlay Option	Description
Ethernet Service	Applies an Ethernet service overlay to the map.
MPLS-TP Tunnel	Applies and MPLS-TP tunnel overlay to the map.
Network Clock	Applies a network clock overlay to the map.
None	Removes any existing overlays on the map.
Pseudowire	Applies a pseudowire overlay to the map.
VLAN	Applies a VLAN overlay to the map.
VPLS	Applies a VPLS instance overlay to the map.
VPN	Applies a VPN overlay to the map.

With the exception of the None option, a dialog box is displayed that allows you to select the specific overlay to apply.

Figure 5-12 shows an example of the Select Pseudowire Overlay dialog box.

Figure 5-12 Select Pseudowire Overlay Dialog Box

Each overlay type allows you to search for specific overlays. [Table 5-8](#) identifies the search fields available for each overlay type.

Table 5-8 Overlay Type Search Fields

Overlay Type	Search Fields
Ethernet Service	<ul style="list-style-type: none"> EVC Terminating EFPs Name System Name
MPLS-TP Tunnel	<ul style="list-style-type: none"> Description Name System Name
Network Clock	<ul style="list-style-type: none"> Name
Pseudowire	<ul style="list-style-type: none"> Description Is Multisegment Pseudowire Name Pseudowire Role Pseudowire Type System Name

Table 5-8 **Overlay Type Search Fields (continued)**

Overlay Type	Search Fields
VLAN	<ul style="list-style-type: none">• EFD Name• EFD System Name• ID• Name• System Name
VPLS	<ul style="list-style-type: none">• Name• System Defined Name• VPN ID
VPN	<ul style="list-style-type: none">• Description• Name

Step 3 In the Select Overlay dialog box, do either of the following:

- To search for specific overlays:
 - a. Choose **Search**.
 - b. In the Search field, choose a search category.
 - c. Enter a search string to narrow the display to a range of overlays or to a specific overlay. [Table 5-8](#) identifies the search categories available for each type of overlay.
 - d. Click **Go**.


Search strings are case-insensitive. If you choose Name and enter **NET**, the overlays that contain “net” in their names are displayed. If you choose System Name and enter **System123**, only the overlay with the system named System123 is displayed.

- To view all available overlays, choose **Show All**.

The available overlays that meet the specified search criteria are displayed in the Select Overlay dialog box in table format. The dialog box also displays the date and time at which the list was generated. To update the list, click **Refresh**.

Step 4 Select the overlay that you want to apply to the map.

The elements and links that are used by the overlay are displayed in the map, and the overlay name and date are displayed in the toolbar, as shown in [Figure 5-13](#).

Figure 5-13 Overlay Example**Note**

The overlay is a snapshot taken at a specific point in time and does not reflect changes that occur in the service. As a result, the information in an overlay can become stale. To update the overlay, click **Refresh Overlay** in the toolbar.

Hiding and Viewing Overlays, and Removing Overlays from a Map

When an overlay is applied to a map, the Show Overlay/Hide Overlay button becomes active in the toolbar. To hide and view the overlay, click **Hide Overlay/Show Overlay** in the toolbar. The button toggles depending on whether the overlay is currently displayed or hidden.

To remove an overlay, choose **Choose Overlay Type > None**. The overlay is removed from the map.

Filtering Links in a Map

The links filter enables you to filter the links displayed in the map view and the links view. You can quickly select the types of links to be filtered by selecting from a predefined set of link types in the list, or by manually configuring a customized set of link types.

To filter links, do either of the following:

- Create a new map, select a filter, and then add the devices to the map. This filter is applied to the new map and only the required link types are visible in the map view and the links view. For more information, see [Filtering Links During Map Creation](#), page 5-26.
- Create a map and add the devices with all links enabled and visible in the map view and links view. You can then filter (display or hide) the different types of links as required. For more information, see [Filtering Links in an Existing Map](#), page 5-27.

The links filter applies to all aspects of Prime Network Vision: the map view, links view, ticket pane, severity calculation, and other items, such as memory consumption and thresholds. Prime Network Vision holds only the links that are relevant to the filter and synchronizes the links with the gateway according to that filter.


For more information about links in Prime Network Vision, see [Chapter 6, “Working with Links.”](#)

Filtering Links During Map Creation

To filter links while creating a map:

- Step 1** Open the Create Map dialog box by choosing **File > New Map** from the main menu. The Create Map dialog box is displayed. For more information, see [Creating and Deleting Maps, page 5-6](#).
- Step 2** Click **Advanced**. The Link Filter dialog box is displayed.

Figure 5-14 Link Filter Dialog Box



The Link Filter dialog box displays a list of all the types of links that you can filter in the map view and links view.



Note By default all link types are selected in the Link Filter dialog box. That is, all links are displayed in the map view and links view.

- Step 3** Select the required option from the Group drop-down list:
 - All—All the links are displayed in the map view and links view.
 - Custom—Only the links defined for the customized filter are displayed in the map view and links view.

- **Data Link**—The data link layer class of links (ATM and Frame Relay) is displayed in the map view and links view.
- **None**—None of the links are displayed in the map view and links view.
- **Physical**—Only the physical links are displayed in the map view and links view.
- **VPN**—Only VPN-related links (GRE, Pseudowire, VPN, and VPN IPv6) are displayed in the map view and links view.

**Note**

You can customize the Group drop-down list options by selecting an option and adding or removing the required link types. The next time the Link Filter dialog box is opened, the Custom option is displayed with the specified link types.

- Step 4** Click **Apply** to apply the defined link filter settings and continue with more selections.
- Step 5** Click **OK** when you have completed your selections.
- Step 6** In the Create Map dialog box, enter a name for the new map and click **OK**. An empty new map is displayed in the navigation pane and content area, and the Link Filter Applied button is displayed in the to indicate that the links have been filtered.
- Step 7** Add the required elements to the map. For more information, see [Creating and Deleting Maps, page 5-6](#). The links are displayed in the map view and links view according to your selections.

Filtering Links in an Existing Map

You can also create a map, add elements with all links enabled and visible in the map view and links view, and then filter (display or hide) the different types of links as required.

To filter links in an existing map:

- Step 1** Click **Link Filter** in the main toolbar.
- Step 2** In the Link Filter dialog box, uncheck the check boxes for the links that you do not want to display in the map view and links view.
- Step 3** Click **Apply** to apply the defined link filter settings and continue with more selections.
- Step 4** Click **OK** when you have completed your selections.
- The links are displayed in the map view and links view according to the defined filter, and the Link Filter Applied button is displayed in the to indicate that the links are filtered.

Opening the CPU Usage Graph

Prime Network Vision enables you to display memory and CPU usage information for a device or network element, including its history.

To open the CPU usage graph:

-
- Step 1** Right-click a network element in the navigation tree and choose **Tools > CPU Usage**.
The CPU Usage dialog box displays the following information:
- CPU Usage—The CPU usage rate as a percentage.
 - CPU Usage History—The CPU usage rate history is graphically displayed.
 - Memory Usage—The memory usage rate as a percentage.
 - Memory Usage History—The memory usage rate history is graphically displayed.
- Step 2** If desired, click **Save to CSV File** to export the displayed data.
- Step 3** Click the upper right corner to close the CPU Usage dialog box.
-

Communicating with Devices Using Ping and Telnet

Prime Network Vision enables you to communicate with devices in the following ways:

- [Pinging a Device, page 5-28](#)
- [Telnetting a Device, page 5-28](#)

Pinging a Device

Prime Network Vision enables you to ping a device to verify that the device is responding.

The ping is performed from the client to the device, and not from the Prime Network Vision unit hosting the VNE to the device.

To ping a device, right-click a device in the navigation tree or map, and choose **Tools > Ping**.

The results are displayed in a new window.

Telnetting a Device

Prime Network Vision enables you to communicate with a device using the Telnet window.

The Telnet session is performed from the client to the device, and not from the Prime Network Vision unit hosting the VNE to the device.



Note

If you are using a Windows 7 system, you must enable the Windows Telnet Client before you can use the Prime Network Telnet option.

- For Windows 7 32-bit systems, enable the Windows Telnet Client to use the Prime Network Telnet option.

- For Windows 7 64-bit systems, a solution is available on the Cisco Developer Network at http://developer.cisco.com/web/prime-network/forums/-/message_boards/message/2780108.

To telnet a device:

-
- Step 1** Right-click a device in the navigation tree or map, and choose **Tools > Telnet**. A terminal window opens.
- Step 2** Log in and use the Telnet window as needed.
-

