



Generic Routing Encapsulation Tunnel IP Source and Destination VRF Membership

Last Updated: April, 2007

The Generic Routing Encapsulation Tunnel IP Source and Destination VRF Membership feature allows you to configure the source and destination of a tunnel to belong to any virtual private network (VPN) routing and forwarding (VRF) table.

Finding Feature Information in This Module

Your Cisco IOS software release may not support all of the features documented in this module. To reach links to specific feature documentation in this module and to see a list of the releases in which each feature is supported, use the “[Feature Information for GRE Tunnel IP Source and Destination VRF Membership](#)” section on page 7.

Finding Support Information for Platforms and Cisco IOS Software Images

Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

Contents

- [Restrictions for GRE Tunnel IP Source and Destination VRF Membership, page 2](#)
- [Restrictions for GRE Tunnel IP Source and Destination VRF Membership, page 2](#)
- [Information About GRE Tunnel IP Source and Destination VRF Membership, page 2](#)
- [How to Configure GRE Tunnel IP Source and Destination VRF Membership, page 2](#)
- [Configuration Example for GRE Tunnel IP Source and Destination VRF Membership, page 4](#)
- [Additional References, page 4](#)
- [Command Reference, page 5](#)
- [Feature Information for GRE Tunnel IP Source and Destination VRF Membership, page 7](#)



- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page 8](#)

Restrictions for GRE Tunnel IP Source and Destination VRF Membership

Cisco 10000 Series Routers

- Both ends of the tunnel must reside within the same VRF.
- The VRF associated with the **tunnel vrf** command is the same as the VRF associated with the physical interface over which the tunnel sends packets (outer IP packet routing).
- The VRF associated with the tunnel by using the **ip vrf forwarding** command is the VRF that the packets are to be forwarded in as the packets exit the tunnel (inner IP packet routing).
- The Cisco 10000 series router does not support the fragmentation of multicast packets passing through a multicast tunnel.

Information About GRE Tunnel IP Source and Destination VRF Membership

This feature allows you to configure the source and destination of a tunnel to belong to any Virtual Private Network (VPN) routing and forwarding (VRF) table. A VRF table stores routing data for each VPN. The VRF table defines the VPN membership of a customer site attached to the network access server (NAS). Each VRF table comprises an IP routing table, a derived Cisco Express Forwarding (CEF) table, and guidelines and routing protocol parameters that control the information that is included in the routing table.

Previously, GRE IP tunnels required the IP tunnel destination to be in the global routing table. The implementation of this feature allows you to configure a tunnel source and destination to belong to any VRF. As with existing GRE tunnels, the tunnel becomes disabled if no route to the tunnel destination is defined.

How to Configure GRE Tunnel IP Source and Destination VRF Membership

SUMMARY STEPS

1. **enable**
2. **configure** {*terminal* | *memory* | *network*}
3. **interface** *tunnel number*
4. **ip vrf forwarding** *vrf-name*
5. **ip address** *ip-address subnet-mask*
6. **tunnel source** (*ip-address* | *type number*)
7. **tunnel destination** *ip-address* {*hostname* | *ip-address*}


8. **tunnel vrf** *vrf-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables higher privilege levels, such as privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	interface tunnel <i>number</i> Example: Router(config)# interface tunnel 0	Enters interface configuration mode for the specified interface. <i>number</i> is the number associated with the tunnel interface.
Step 4	ip vrf forwarding <i>vrf-name</i> Example: Router(config-if)# ip vrf forwarding green	Associates a virtual private network (VPN) routing and forwarding (VRF) instance with an interface or subinterface. <i>vrf-name</i> is the name assigned to a VRF.
Step 5	ip address <i>ip-address</i> <i>subnet-mask</i> Example: Router(config-if)# ip address 10.7.7.7 255.255.255.255	Specifies the interface IP address and subnet mask. <i>ip-address</i> specifies the IP address of the interface. <i>subnet-mask</i> specifies the subnet mask of the interface.
Step 6	tunnel source { <i>ip-address</i> <i>type number</i> } Example: Router(config-if)# tunnel source loop 0	Specifies the source of the tunnel interface. <i>ip-address</i> specifies the IP address to use as the source address for packets in the tunnel. <i>type</i> specifies the interface type (for example, serial). <i>number</i> specifies the port, connector, or interface card number. The numbers are assigned at the factory at the time of installation or when added to a system, and can be displayed using the show interfaces command.
Step 7	Router(config-if)# tunnel destination { <i>hostname</i> <i>ip-address</i> } Example: Router(config-if)# tunnel destination 10.5.5.5	Defines the tunnel destination. <i>hostname</i> specifies the name of the host destination. <i>ip-address</i> specifies the IP address of the host destination.
Step 8	Router(config-if)# tunnel vrf <i>vrf-name</i> Example: Router(config-if)# tunnel vrf financial	Associates a VPN routing and forwarding (VRF) instance with a specific tunnel destination. <i>vrf-name</i> is the name assigned to a VRF.

Configuration Example for GRE Tunnel IP Source and Destination VRF Membership

In this example, packets received on interface e0 using VRF green are forwarded out of the tunnel through interface e1 using VRF blue.



```
ip vrf blue
rd 1:1

ip vrf green
rd 1:2

interface loop0
ip vrf forwarding blue
ip address 10.7.7.7 255.255.255.255

interface tunnel0
ip vrf forwarding green
ip address 10.3.3.3 255.255.255.0
tunnel source loop 0
tunnel destination 10.5.5.5
tunnel vrf blue

interface ethernet0
ip vrf forwarding green
ip address 10.1.1.1 255.255.255.0

interface ethernet1
ip vrf forwarding blue
ip address 10.2.2.2 255.255.255.0

ip route vrf blue 10.5.5.5 255.255.255.0 ethernet 1
```

Additional References

Related Documents

Related Topic	Document Title
VRF tables	"Configuring Multiprotocol Label Switching" chapter of the <i>Cisco IOS Switching Services Configuration Guide</i> , Release 12.2
Tunnels	<i>Cisco IOS Interface Configuration Guide</i> , Release 12.2

Standards

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature	—

MIBs

MIB	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFC	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	—

Technical Assistance

Description	Link
The Cisco Technical Support & Documentation website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/techsupport

Command Reference

This section documents the new command. All other commands used with this feature are documented in the Cisco IOS Release 12.2 command reference publications.

- [tunnel vrf](#)

tunnel vrf

To associate a VPN routing and forwarding (VRF) instance with a specific tunnel destination, interface or subinterface, use the **tunnel vrf** command in global configuration mode or interface configuration mode. To disassociate a VRF from the tunnel destination, use the **no** form of this command.

tunnel vrf *vrf-name*

no tunnel vrf *vrf-name*

Syntax Description

<i>vrf-name</i>	Name assigned to a VRF.
-----------------	-------------------------

Defaults

The default destination is determined by the global routing table.

Command Modes

Global configuration
Interface configuration

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB5	This command was integrated into Cisco IOS Release 12.2(31)SB5.

Usage Guidelines

The tunnel source and destination must be in the same VRF.

Either the IP VRF or the tunnel VRF can be set to the global routing table (using the **no ip vrf forwarding** *vrf* command or the **no tunnel vrf** *vrf* command).

The tunnel is disabled if no route to the tunnel destination is defined. If the tunnel VRF is set, there must be a route to that destination in the VRF.

Cisco 10000 Series Router

The VRF associated with the **tunnel vrf** command is the same as the VRF associated with the physical interface over which the tunnel sends packets (outer IP packet routing).

Examples

The following example shows how to associate a VRF with a tunnel destination. The router looks up the tunnel endpoint, 10.5.5.5, in the blue VRF.

```
interface tunnel0
 ip vrf forwarding green
 ip address 10.3.3.3 255.255.255.0
 tunnel source loop 0
 tunnel destination 10.5.5.5
 tunnel vrf blue
```

Related Commands	Command	Description
	ip route vrf	Establishes static routes for a VRF.
	ip vrf	Configures a VRF routing table.
	ip vrf forwarding	Associates a VPN VRF instance with an interface or subinterface.
	tunnel destination	Specifies the destination for a tunnel interface.
	tunnel source	Sets the source address for a tunnel interface.

Feature Information for GRE Tunnel IP Source and Destination VRF Membership

Table 1 lists the release history for this feature.

Not all commands may be available in your Cisco IOS software release. For release information about a specific command, see the command reference documentation.

Cisco IOS software images are specific to a Cisco IOS software release, a feature set, and a platform. Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.



Note

Table 1 lists only the Cisco IOS software release that introduced support for a given feature in a given Cisco IOS software release train. Unless noted otherwise, subsequent releases of that Cisco IOS software release train also support that feature.

Table 1 Feature Information for GRE Tunnel IP Source and Destination VRF Membership

Feature Name	Releases	Feature Information
GRE Tunnel IP Source and Destination VRF Membership	12.0(23)S 12.2(31)SB5	Allows you to configure the source and destination of a tunnel to belong to any VPN VRF table. In 12.0(23)S, this feature was introduced. In 12.2(31)SB5, support was added for the Cisco 10000 series router for the PRE2 and PRE3. The following command was introduced by this feature: tunnel vrf.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

CCVP, the Cisco Logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, *Packet*, PIX, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0704R)

Copyright © 2007 Cisco Systems, Inc. All rights reserved.