



INDEX

Symbols

? (help) command **B-2**

Numerics

100 Mbps LED **1-7**

A

AC power connection **3-15**

ACTIVITY LED **1-4**

ACT LED **1-7**

AIMs, installing **1-8**

asynchronous serial baud rates **2-12**

auxiliary port

connecting to **3-21 to 3-22**

description of **2-7 to 2-8**

B

baud rate

of modem **3-21**

setting for console terminal **1-4**

boot command **B-4**

boothelper **B-4**

booting from Flash memory **1-5**

bracket attachment

rack-mount **3-5 to 3-10**

wall-mount **3-11**

C

cables, provided **2-6**

Caution symbol, meaning of **ix**

chassis

desktop installation **3-3**

grounding **3-13**

rack-mounting **3-4**

wall-mounting **3-11**

Cisco IOS software

locating documentation **xv**

recovering images **B-8**

commands

? (help) **B-2**

boot **B-4**

configuration register **B-7**

confreg **B-7, B-8**

context **B-6**

debugging **B-6**

dev **B-5**

dir **B-5**

frame **B-6**

help **B-2, B-5**

i (Initialize) **B-6**

meminfo **B-5, B-6**

reload **B-1, B-2**

reset **B-6, B-10**

ROM monitor **B-1 to B-12**

stack **B-6**

sysret **B-7**

tftpdnld **B-6, B-8, B-10**

xmodem **B-8, B-9**

compact Flash memory card **1-2**

compliance **1-12**
configuration, site **2-4**
configuration register
 boot field **1-4**
 changing settings **B-7, 1-2**
 enabling booting from Flash memory **1-5**
confreg command **B-7, B-8**
connections
 AC power **3-15**
 asynchronous/synchronous serial **2-12**
 auxiliary port **2-8**
 console port **2-7**
 console terminal **3-20**
 DCE **2-10**
 DC power **3-16 to 3-17**
 DSU/CSU **2-13**
 DTE **2-10**
 Ethernet **2-9**
 ISDN BRI **2-12**
 modem **3-20**
 network **2-8**
 serial **2-10**
 Token Ring **2-9**
console port
 connecting to **3-20 to 3-21**
 description of **2-7**
console speed, setting **B-10**
context command **B-6**
cooling recommendations **2-4**

D

DCE connections **2-10**
DC power connections **3-16 to 3-17**
debugging commands **B-6**
desktop installation **3-3**
dev command **B-5**
dimensions, chassis **1-11, 1-12**
dir command **B-5**

documentation
 Cisco IOS software **xv**
 on CD-ROM **xiv**
 on the WEB **xiv**
 related **xiv**
DRAM **1-2**
DSU/CSU connections **2-13**
DTE connections **2-10**
dynamic random-access memory
 See DRAM.

E

electrical safety guidelines **2-1**
electrostatic discharge damage
 See ESD
error messages **A-4**
ESD **2-2**
Ethernet cable types **2-9**

F

FDX LED **1-7**
feet, installing **3-3**
Figures
 auxiliary port connection **3-22**
 bracket attachment for rack-mounting **3-6 to 3-10**
 bracket attachment for wall-mounting **3-12**
 brackets, rack mounting **3-4, 3-5**
 chassis views **1-2, 1-3**
 console terminal connection **3-21**
 DC power connections **3-17**
 ground lug attachment **3-14, 3-15**
 LEDs on front panel **1-3**
 LEDs on rear panel **1-5, 1-6, 1-7, 1-8**
 modem connection **3-22**
 mounting brackets **3-4, 3-5**
 rollover cable, identifying **3-22**

rubber feet, locations **3-4**
 wall-mounting the chassis **3-13**

Flash memory
 booting from **1-5**
 description of **1-2**
 frame command **B-6**

G

grounding the chassis **3-13**

H

help command **B-2, B-5**
 high temperature, troubleshooting **A-2**
 humidity, specifications **1-11, 1-12**

I

i (initialize) command **B-6**

installation
 checklist **2-4**
 desktop **3-3**
 rack-mounting **3-4**
 site requirements **2-3**
 tools required **2-6**
 wall-mounting **3-11, 3-13**

interface numbering **1-9, 1-11**
 WAN interface cards **1-9**

IOS software
 locating documentation **xv**
 recovering images **B-8**

ISDN BRI **2-12 to 2-13**

L

LAN
 connections **3-18 to 3-19**

interface types **2-9**
 LEDs
 100 Mbps, in 1-RU chassis **1-7**
 100 Mbps, in Cisco 2691 **1-8**
 ACT, in 1-RU chassis **1-7**
 ACT, in Cisco 2691 **1-8**
 ACTIVITY, in 1-RU chassis **1-4**
 ACTIVITY, in Cisco 2691 **1-4**
 CF1, in Cisco 2691 **1-8**
 FDX, in 1-RU chassis **1-7**
 front panel **1-3 to 1-4**
 interpretation of **A-2**
 LINK, in 1-RU chassis **1-7**
 LINK, in Cisco 2691 **1-8**
 Power, in 1-RU chassis **1-3**
 Power, in Cisco 2691 **1-4**
 rear panel **1-5 to 1-8**
 RPS, in 1-RU chassis **1-4**
 SYS/RPS, in Cisco 2691 **1-4**
 lightning safety **2-2**
 LINK LED **1-7**

M

meminfo command **B-5, B-6**
 memory **1-2 to 1-9**
 modem connection **3-21**

N

netboot **B-4**
 network connections **2-8**
 network modules, installing **1-8**
 nonvolatile random-access memory
 See NVRAM.

NVRAM **1-2**

P

packing list **2-6**
port numbering **1-9**
power
 requirements **2-3**
 specifications **1-11 to 1-12**
power supply connections **3-15 to 3-17**
power supply LED **1-3 to 1-4**

R

rack-mounting the chassis **3-4 to 3-11**
racks, equipment **2-4**
record keeping, site log **2-5**
regulatory compliance **1-12**
reload command **B-1, B-2**
reset command **B-6, B-10**
rollover cable, identifying **3-22**
ROM monitor
 commands **B-2 to B-12**
 syntax **B-3**
 using **B-1**
rubber feet, installing **3-3**

S

safety
 guidelines **2-1 to 2-2**
 warnings, translations of **ix**
SDRAM **1-2**
serial connections, considerations **2-10**
serial port specifications **2-11**
shared memory **1-2**
show hardware command **B-5**
show version command **B-5**
site
 configuration **2-4**
 environment **2-3**

log, record keeping **2-5**
requirements **2-3**
slot numbering **1-11**
software image recovery procedure **B-8**
specifications
 Cisco 261x, Cisco 262x, Cisco 265x **1-11**
 Cisco 2691 **1-12**
 serial ports **2-11**
 system **1-11**
stack command **B-6**
static electricity damage **2-2**
synchronous dynamic random-access memory
 See SDRAM.
sysret command **B-7**

T

Tables
cable specifications **3-18**
configuration register bits **1-1**
configuration register settings for boot field **1-3**
configuration register settings for broadcast address **1-4**
configuration register settings for console terminal baud rate **1-5**
DC wiring requirements **3-16**
documents **xv**
DTE and DCE devices **2-11**
ISDN-BRI cable specifications **2-13**
LAN connections **2-9, 3-18**
LAN interfaces, summary **1-1**
LEDs on front panel **1-3, 1-4**
LEDs on rear panel **1-7, 1-8**
power requirements **2-3**
related documents **xv**
serial signal transmission specifications **2-12**
specifications, system **1-11, 1-12**
voice connections **3-18**
WAN connections **3-18**
telephone jacks, safety during installation **2-2**

temperature, operating **1-11, 1-12**

tftpdnld command **B-6, B-8, B-10**

Token Ring connections **2-9**

tools required for installation **2-6**

troubleshooting

cables **A-3**

connections **A-3**

cooling system **A-2**

error messages **A-4**

front panel LEDs **1-3**

high temperature **A-2**

modules **A-3**

power system **A-2**

rear panel LEDs **1-5**

wiring

power supplies **3-15 to 3-17**

telephone **2-2**

X

xmodem command **B-8, B-9**

V

ventilation **2-4**

VICs

See voice interface cards.

voice interface cards, installing **1-8**

W

wall-mounting the chassis **3-11**

wall-mounting the router **3-12**

WAN interface cards, installing **1-8**

Warnings

installation **2-1**

lightning activity **3-15, 3-18**

main disconnection **3-23**

secure power cabling **3-17**

SELV circuit **2-8**

TN power systems **2-3**

translations of **ix**

WAN port voltages **2-12**

WICs

See WAN interface cards

