



Verifying Basic Setup



Note

The information herein applies to the Cisco AS5350, Cisco AS5400, and Cisco AS5400HPX universal gateways. Note that the latter requires use of Cisco IOS release 12.2(2)XB or later.

This chapter details the tasks required to verify that your basic system components are functioning normally:

- [Analyzing the System Boot Dialog, page 2-1](#)
- [Checking the Initial Running Configuration, page 2-5](#)
- [Investigating Memory Usage, page 2-7](#)
- [Inspecting CPU Utilization, page 2-8](#)

Analyzing the System Boot Dialog

The Cisco AS5350 and Cisco AS5400 have a specific boot sequence. To view the boot sequence through a terminal session, you must have a console connection to the gateway before it powers up.



Note

If you observe no messages on the console port, check that the baud rate is configured correctly. The Cisco AS5350 and Cisco AS5400 console port can support a baud rate up to 115200.

The following boot sequence occurs. Step numbers and comments are inserted in the example to describe the boot sequence.

Step 1

In the following segment, the gateway decompresses the system boot image, tests the NVRAM for validity, and decompresses the Cisco IOS image.

```
System Bootstrap, Version 12.0(20000106:234457) [tombnyg-rommon_1_6 106],  
SOFTWARE REV 1.6  
Copyright (c) 1994-2000 by cisco Systems, Inc.  
AS5350 platform with 131072 Kbytes of main memory
```

```
Self decompressing the image : #####  
##### [OK]  
Self decompressing the image : #####  
##### [OK]
```

Step 2 Cisco IOS release, available memory, hardware interfaces, and modem lines are displayed:



Note If a card type is not recognized, verify that you are running the optimum version of Cisco IOS software. Refer to the hardware-software compatibility matrix, available online at <http://cco-sj-1.cisco.com/cgi-bin/front.x/Support/HWSWmatrix/hwswwmatrix.cgi>

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706

```
Cisco Internetwork Operating System Software
IOS (tm) 5350 Software (C5350-JS-M), Version 12.1(3)T,  RELEASE SOFTWARE (fc1)
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Thu 20-Jul-00 03:02 by ccai
Image text-base: 0x60008968, data-base: 0x61000000
cisco AS5400 (R7K) processor (revision 0) with 131072K/65536K bytes of memory.
Processor board ID JAB0351040G
R7000 CPU at 250Mhz, Implementation 39, Rev 1.0, 256KB L2, 2048KB L3 Cache
Last reset from IOS reload
Bridging software.
X.25 software, Version 3.0.0.
SuperLAT software (copyright 1990 by Meridian Technology Corp).
TN3270 Emulation software.
Primary Rate ISDN software, Version 1.1.
Manufacture Cookie Info:
  EEPROM Type 0x0001, EEPROM Version 0x01, Board ID 0x31,
  Board Hardware Version 3.21, Item Number 800-5171-01,
  Board Revision 017, Serial Number JAB0351040G,
  PLD/ISP Version 1.0, Manufacture Date 6-Jan-2000.
Processor 0xFF, MAC Address 0x03096F818
Backplane HW Revision FF.FF, Flash Type 5V
2 FastEthernet/IEEE 802.3 interface(s)
2 Serial network interface(s)
108 terminal line(s)
8 Channelized T1/PRI port(s)
512K bytes of non-volatile configuration memory.
32768K bytes of processor board System flash (Read/Write)
8192K bytes of processor board Boot flash (Read/Write)
```

Step 3 Because the gateway has never been configured, it cannot find a startup-config file. Therefore, the software asks, “Would you like to enter the initial configuration dialog? [yes/no]”

Enter **no**. In this example, the Cisco IOS software is configured manually. The automatic setup script is not used. Configuring the Cisco IOS software manually develops your expertise.

Enter **yes** to terminate autoinstall.

```
--- System Configuration Dialog ---
```

```
Would you like to enter the initial configuration dialog? [yes/no]: no
```

```
Would you like to terminate autoinstall? [yes]: yes
```

Step 4 This example shows the LAN interfaces and the slots in which port cards are not inserted. The universal-port-card (formerly called NextPort) module firmware version is displayed (version 1.1.6.81). The gateway attempts to switch to a better clock source but does not find a suitable source because the T1s are not yet configured.

```

00:00:03: %NP_MD-6-SLOT_INSERTED: Slot 1 (108 ports max) inserted
00:00:16: %CARRIER-3-NO_DFC: DFC is not present - DFC 3
00:00:16: %CARRIER-3-NO_DFC: DFC is not present - DFC 4
00:00:16: %CARRIER-3-NO_DFC: DFC is not present - DFC 5
00:00:16: %CARRIER-3-NO_DFC: DFC is not present - DFC 6
00:00:16: %CARRIER-3-NO_DFC: DFC is not present - DFC 7
00:00:19: %LINK-3-UPDOWN: Interface FastEthernet0/0, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface FastEthernet0/1, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Serial0/0, changed state to down
00:00:19: %LINK-3-UPDOWN: Interface Serial0/1, changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state
to up
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed state
to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0, changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/1, changed state to down
00:00:23: %NP_BS-6-MODULE_STARTED: NextPort module 1/0/0 Started - 1.1.6.81
00:00:26: %NP_BS-6-MODULE_STARTED: NextPort module 1/0/1 Started - 1.1.6.81
00:00:30: %NP_MD-6-MODULE_UP: NextPort module 1/0/0 up
00:00:30: %NP_BS-6-MODULE_STARTED: NextPort module 1/0/2 Started - 1.1.6.81
00:00:33: %NP_MD-6-MODULE_UP: NextPort module 1/0/1 up
00:00:37: %NP_MD-6-MODULE_UP: NextPort module 1/0/2 up
00:01:05: %LINK-5-CHANGED: Interface Serial0/0, changed state to administratively down
00:01:05: %LINK-5-CHANGED: Interface FastEthernet0/0, changed state to administratively
down
00:01:05: %LINK-5-CHANGED: Interface FastEthernet0/1, changed state to administratively
down
00:01:05: %LINK-5-CHANGED: Interface Serial0/1, changed state to administratively down
00:01:06: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state
to down
00:01:10: %SYS-5-RESTART: System restarted --
Cisco Internetwork Operating System Software
IOS (tm) 5350 Software (C5350-JS-M), Version 12.1(1)XD1, EARLY DEPLOYMENT RELEASE SOFTWARE
(fc2)
TAC:Home:SW:IOS:Specials for info
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Sun 09-Jul-00 07:06 by beliu
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 1 priority 205 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 2 priority 204 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 3 priority 205 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 4 priority 204 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 5 priority 205 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 6 priority 204 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-SWITCH: Switching to the clock on slot 2 port 7 priority 205 as
the current primary has gone bad
00:01:10: %TRUNK_CLOCK-6-BAD_CLOCKS: There are no good clocks in the system. Remain in
HOLDOVER mode
00:01:10: %TRUNK_CLOCK-6-BAD_CLOCKS: There are no good clocks in the system. Remain in
HOLDOVER mode
00:01:10: %TRUNK_CLOCK-6-BAD_CLOCKS: There are no good clocks in the system. Remain in
HOLDOVER mode

```

```
00:01:10: %TRUNK_CLOCK-6-BAD_CLOCKS: There are no good clocks in the system. Remain in
HOLDOVER mode
00:01:10: %TRUNK_CLOCK-6-BAD_CLOCKS: There are no good clocks in the system. Remain in
HOLDOVER mode
```

Step 5 Enter the **show version** command to check the system hardware, Cisco IOS image name, uptime, and restart reason:

```
Router> show version

Cisco Internetwork Operating System Software
IOS (tm) 5350 Software (C5350-JS-M), Version 12.1(20001028:174051)
Copyright (c) 1986-2001 by cisco Systems, Inc.
Compiled Mon 19-Feb-01 04:10 by
Image text-base: 0x60008968, data-base: 0x61180000

ROM: System Bootstrap, Version 12.0(19991122:230447)
BOOTFLASH: 5350 Software (C5350-BOOT-M), Version 12.0(19991112:131]

AS5400 uptime is 1 day, 4 hours, 29 minutes
System returned to ROM by reload at 12:34:33 UTC Tue Nov 30 1999
System image file is "flash:c5350-js-mz.xm.Feb19"

cisco AS5400 (R7K) processor (revision L) with 131072K/65536K bytes of memory.
Processor board ID 99290068
R7000 CPU at 250Mhz, Implementation 39, Rev 1.0, 256KB L2, 2048KB L3 Cache
Last reset from warm-reset
Bridging software.
X.25 software, Version 3.0.0.
SuperLAT software (copyright 1990 by Meridian Technology Corp).
TN3270 Emulation software.
Primary Rate ISDN software, Version 1.1.
Manufacture Cookie Info:
  EEPROM Type 0x0001, EEPROM Version 0x01, Board ID 0x31,
  Board Hardware Version 1.21, Item Number 800-5171-01,
  Board Revision 011, Serial Number 99290068,
  PLD/ISP Version 0.0, Manufacture Date 2-Aug-1999.
Processor 0xFF, MAC Address 0x0503EFF5F4C
Backplane HW Revision FF.FF, Flash Type 5V
2 FastEthernet/IEEE 802.3 interface(s)
2 Serial network interface(s)
108 terminal line(s)
8 Channelized T1/PRI port(s)
512K bytes of non-volatile configuration memory.
16384K bytes of processor board System flash (Read/Write)
8192K bytes of processor board Boot flash (Read/Write)

Configuration register is 0x2102
```

[Table 2-1](#) describes the significant output fields in the previous example.

Table 2-1 Show Version Command Field Descriptions

Field	Description
AS5400 uptime is....	Watch for unscheduled reloads by inspecting this field.
System returned to ROM by reload at....	Tells you why the gateway last reloaded. If the field displays “power-on,” a power interruption caused the reload.
System image file is....	The gateway booted from this image location.

Checking the Initial Running Configuration

The Cisco IOS software creates an initial running configuration. Inspect the configuration to get familiar with the default settings. User input is shown in boldface type.

```

Router> enable
Password:
Router# show running-config

Building configuration...

Current configuration : 7653 bytes
!
version 12.1
no service single-slot-reload-enable
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname Router
!
no boot startup-test
logging rate-limit console 10 except errors
!
!
resource-pool disable
!
!
voice-fastpath enable
ip subnet-zero
no ip routing
no ip finger
ip name-server 172.16.11.48
ip name-server 172.16.2.132
ip name-server 172.16.2.133
!
call rsvp-sync
!
!
fax interface-type modem
mta receive maximum-recipients 0
!
!
controller T1 1/0
!
controller T1 1/1

```

```

!
controller T1 1/2
!
controller T1 1/3
!
controller T1 1/4
!
controller T1 1/5
!
controller T1 1/6
!
controller T1 1/7
!
!
interface FastEthernet0/0
 ip address 172.21.101.21 255.255.255.0
 no ip route-cache
 no ip mroute-cache
 duplex auto
 speed 100
 no mop enabled
!
interface FastEthernet0/1
 no ip address
 no ip route-cache
 no ip mroute-cache
 shutdown
 duplex auto
 speed auto
!
interface Serial0/0
 no ip address
 no ip route-cache
 no ip mroute-cache
 shutdown
 fair-queue
 clockrate 2000000
!
interface Serial0/1
 no ip address
 no ip route-cache
 no ip mroute-cache
 shutdown
 clockrate 2000000
!
interface Async4/00
 no ip address
 no ip route-cache
!
interface Async4/01
 no ip address
 no ip route-cache
!
interface Async4/02
 no ip address
 no ip route-cache
.
.
.
interface Async4/107
 no ip address
 no ip route-cache
!

```

```

interface Group-Async0
  no ip address
  no ip route-cache
  no group-range
  !
ip kerberos source-interface any
ip classless
no ip http server
!
!
line con 0
  logging synchronous
  transport input none
line aux 0
  logging synchronous
line vty 0 4
  password cisco
  login
line 4/00 4/107
  no flush-at-activation
  modem InOut
!
scheduler allocate 10000 400
end

```

The Cisco AS5350 or Cisco AS5400 displays every asynchronous interface it recognizes. Therefore, if your system has a large number of asynchronous interfaces, the running-configuration will be very long. To aggregate the asynchronous interfaces, you must assign them to a Group-Async Interface using the command **group-range**. See the [“Configuring the Asynchronous Group Interface” section on page 3-7](#).

Group-async interfaces are templates used to control the configuration of multiple asynchronous interfaces on the gateway. Each asynchronous interface corresponds to one of the modem lines and uses the same number as its corresponding line. Configuring the asynchronous interfaces as a group-async saves you time and configuration file size.

Investigating Memory Usage

Use the **show memory summary** command to:

- Understand how memory is used for different processor and I/O memory processes.
- Identify memory fragmentation and memory leaks.
 - Memory leak—Memory that is not released back to the processor. Memory leaks are indicated by steady decreases of free memory. However, the preferred way to track memory leaks is to monitor the FreeMem variable in the OID MIB (object-identifier management information base).
 - Memory fragmentation—Indicated by the largest block of memory not being equal to the lowest block. Fragmentation increases as the numbers grow further apart.

Router# **show memory summary**

	Head	Total (b)	Used (b)	Free (b)	Lowest (b)	Largest (b)
Processor	61952B00	107664640	24210716	83453924	82827184	82866768
I/O	40000000	67108880	28952352	38156528	38156528	38156412
.						
.						
.						

The sum of the used and free memory equals the total memory. Most of the **show memory summary** command output has been removed for brevity.

**Note**

Do not enter the **show memory summary** command with the **terminal length 0** command enabled. If you do, many screens of output might interrupt your session.

**Note**

To learn more about management information bases (MIBs), see the online references at <http://www.cisco.com/univercd/cc/td/doc/product/software/>. Select your Cisco IOS release and search under new feature documentation.

Inspecting CPU Utilization

Enter the **show process cpu** command and then the **show process cpu history** command to investigate high CPU utilization. High utilization causes network performance problems. For example, knowing when the router is running at over 50% utilization is critical. The router might start dropping packets if an unexpected traffic burst comes through or if Open Shortest Path First (OSPF) is recalculated. Fast switching can also be used to reduce CPU utilization.

Router# **show process cpu**

```

CPU utilization for five seconds: 0%/0%; one minute: 1%; five minutes: 1%
  PID  Runtime(ms)   Invoked  uSecs   5Sec   1Min   5Min  TTY Process
    1         0      20232     0    0.00%  0.00%  0.00%  0 Load Meter
    2         0         12     0    0.00%  0.00%  0.00%  0 EST msg processing
    3    305688     23808  12839   0.00%  0.39%  0.29%  0 Check heaps
    4         0         1     0    0.00%  0.00%  0.00%  0 Chunk Manager
    5         4        10    400   0.00%  0.00%  0.00%  0 Pool Manager
    6         0         2     0    0.00%  0.00%  0.00%  0 Timers
    7        112     20205     5    0.00%  0.00%  0.00%  0 ALARM_TRIGGER_SC
    8         0         2     0    0.00%  0.00%  0.00%  0 Serial Background
    9         0         1     0    0.00%  0.00%  0.00%  0 RM PROCESS
   10         0         1     0    0.00%  0.00%  0.00%  0 RM PROCESS
   11         0         1     0    0.00%  0.00%  0.00%  0 RM PROCESS
   12         0         1     0    0.00%  0.00%  0.00%  0 RM PROCESS
   13         0         2     0    0.00%  0.00%  0.00%  0 CAS Process
   14        220     2803    78   0.00%  0.00%  0.00%  0 ARP Input
   15         0     5058     0   0.00%  0.00%  0.00%  0 HC Counter Timer
   16         0         2     0   0.00%  0.00%  0.00%  0 DDR Timers
   17         0         2     0   0.00%  0.00%  0.00%  0 Dialer event
   18         4         2   2000   0.00%  0.00%  0.00%  0 Entity MIB API
   19         0         1     0   0.00%  0.00%  0.00%  0 SERIAL A'detect
   20         0         1     0   0.00%  0.00%  0.00%  0 Critical Background
   21         72    13826     5   0.00%  0.00%  0.00%  0 Net Background
  PID  Runtime(ms)   Invoked  uSecs   5Sec   1Min   5Min  TTY Process
  43         0         3     0   0.00%  0.00%  0.00%  0 AAA Accounting
  .
  .
  .

```


If you see high utilization numbers in the top line of the output, for example over 50%, inspect the columns 5Sec, 1Min, and 5Min. Find the process that uses the most CPU power.

Where to Go Next

At this point you should go to:

- [Chapter 3, “Basic Configuration Using the Command-Line Interface”](#) to commission your Cisco AS5350 or Cisco AS5400 universal gateway.



Tip

The following publications are available on the Documentation CD-ROM that shipped with your gateway, or on the World Wide Web from the Cisco home page.

- For additional basic configuration information, refer to *Cisco IOS Dial Technologies Configuration Guide* and *Cisco IOS Dial Technologies Command Reference*, available online at <http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122cgcr/index.htm>. For more advanced configuration topics, refer to the Cisco IOS software configuration guide, feature modules, and command reference publications that pertain to your Cisco IOS software release.
- Check *Configuring Selected 12.1 Cisco IOS Software Features*, available online at http://www.cisco.com/univercd/cc/td/doc/product/access/acs_serv/as5400/index.htm
- For troubleshooting information, refer to the *System Error Messages* and *Debug Command Reference* publications.

