



Overview

The Cisco 600W Redundant Power System (RPS) provides power system redundancy to external devices such as routers, switches, and hubs. The system includes two fully redundant AC input power modules and four DC output power modules for connection to external devices. The Cisco RPS supports quasi-redundant, fully redundant, or redundant-with-reboot configurations, depending upon the external device.

This chapter provides an overview of the Cisco RPS features, including the supported external devices and power configurations, in the following sections:

- [Features, page 1-1](#)
- [Supported Devices and Configurations, page 1-2](#)
- [Front and Rear Panel Descriptions, page 1-8](#)
- [Safety Recommendations, page 1-11](#)

Features

The following features are standard:

- Two AC input power cords
- Two fully redundant AC input power modules
- Four 150W DC output power modules
- Rack-mountable chassis (19-inch rack-mount brackets included)
- Redundant cooling fans

- LEDs for AC, DC, fans, and temperature status
- Simple Network Management Protocol (SNMP) support of error messages for Cisco 2600 series and Cisco 3620/3640 series routers. (There is no SNMP support for error messages in the Cisco 1516M hub, FastHub 400 series hub, Catalyst 1900 series switches, Catalyst 2820 series switches, Catalyst 2900 and Catalyst 3500 series XL switches, Cisco 2500 and 4000 series routers, and the Cisco MC3810 multiservice concentrator.)

The Cisco RPS ships in either of the following configurations:

- With cables (Cisco RPS number PWR600-AC-RPS-CAB)—Includes four one-to-one (22-pin to 18-pin) cables for connecting to hubs and switches or for quasi-redundant support for Cisco 2600 series routers; Cisco 3620, Cisco 3640, and Cisco 3725 routers; and Cisco 4000 series routers.
- Without cables (Cisco RPS number PWR600-AC-RPS-NCAB)—Cables must be ordered separately:
 - One-to-one (22-pin to 18-pin) cables for connecting to hubs and switches or for quasi-redundant support for Cisco 2600 series routers; Cisco 3620, Cisco 3640, and Cisco 3725 routers; and Cisco 4000 series routers
 - One-to-one (22-pin to 8-pin) cables for quasi-redundant support for Cisco 2500 series routers and access servers and Cisco MC3810 multiservice concentrators
 - Two-to-one Y cables (22-pin to 18-pin or 22-pin to 8-pin) for fully redundant support only for routers or concentrators



Note

Refer to [Table 3-1 on page 3-5](#) for cable descriptions and order numbers.

Supported Devices and Configurations

[Table 1-1](#) lists the supported external devices and power configurations. The power configurations are described in the following subsections.

Table 1-1 Cisco RPS-Supported External Devices and Power Configurations

External Device	Quasi-Redundant ¹	Fully Redundant	Redundant with Reboot ²
FastHub 400 series hubs ³	Yes	No	Yes
Cisco 1516M hub (HP 10BASE-T Hub-16M)	Yes	No	No
Catalyst 1900 series switches	Yes	No	Yes
Catalyst 2820 series switches	Yes	No	Yes
Catalyst 2900 series XL switches	Yes	No	Yes
Catalyst 3500 series XL switches ⁴	Yes	No	Yes
Cisco 2500 series routers and access servers ⁵	Yes	Yes	No
Cisco 2600 series routers	Yes	Yes	No
Cisco 3620 and Cisco 3640 routers	Yes	Yes	No
Cisco 3725 routers	Yes	Yes	No
Cisco MC3810 multiservice concentrators	Yes	Yes	No
Cisco 4000 series routers	Yes	Yes	No

1. The Cisco RPS has a demonstrated mean time between failures (MTBF) of greater than 500,000 hours in this mode.
2. The redundant-with-reboot configuration is not recommended because of the reboot and downtime; if you use this configuration, always power up the switch *before* you power up the Cisco RPS to ensure correct operation.
3. The Cisco RPS can also be used with the older FastHub 100, 200, and 300 series hubs.
4. If you are using a Cisco RPS with a revision level lower than Z3 with a Catalyst 3508G or a Catalyst 3548 XL switch, the switch RPS LED and the RPS DC LED might display amber (normally indicating RPS malfunction) even when the Cisco RPS is functioning properly. The LEDs display correctly for Cisco RPS revision level Z3 or later revision. The label on the bottom of the Cisco RPS shows the revision level.
5. For simplicity, Cisco 2500 series access servers, such as the Cisco 2509 or the Cisco 2511, are referred to as Cisco 2500 series routers throughout this guide.

**Note**

You might need to order a power adapter plate for your router or concentrator to make it compatible with the Cisco RPS. [Table 3-1 on page 3-6](#) lists adapter plates and order numbers.


Quasi-Redundant Configuration

The Cisco RPS provides a quasi-redundant power source for four external devices that use up to 150W DC each. This configuration is allowed for all supported devices. You can use a one-to-one cable (one connector at each cable end) to connect four external devices to the four DC output power modules, as shown in [Figure 1-1](#). The power source is quasi-redundant because there are two AC input power modules for the Cisco RPS and one DC output power module for each external device. The AC input to the Cisco RPS is fully redundant, but the DC output to the external devices is not.


Note

This is the only *recommended* configuration for Cisco switches and hubs.

Figure 1-1 Quasi-Redundant Configuration



Fully Redundant Configuration


The Cisco RPS can provide a fully redundant power source for two of the supported routers or concentrators. You can use a two-to-one cable (ordered separately) to connect two external devices to the four DC output power modules, as shown in [Figure 1-2](#). The two-to-one cable is a Y-shaped cable with two connectors at one end and one connector at the other end.

In this configuration, the connectors at one end of the Y-shaped cable connect to two Cisco RPS DC output power modules; the single connector on the other end of the cable connects to one external device. The power source is fully redundant, because there are two AC input modules and two DC output power modules connected to each external device. If any power module fails, there is a full backup.

**Note**

This configuration is not supported for switches and hubs.

Figure 1-2 Fully Redundant Configuration




Redundant with Reboot

By using a mode of operation called redundant with reboot, you can connect more hubs and switches to the Cisco RPS and thereby extend its capacity or provide additional redundancy. Redundancy with reboot works for the following devices only: FastHub 400 series hubs, Catalyst 1900 series and Catalyst 2820 switches, and Catalyst 2900 series and Catalyst 3500 series XL switches. However, this configuration is *not* generally recommended, because a power supply failure will cause an interruption while the hub or switch reboots.

The redundant-with-reboot configuration is shown in [Figure 1-3](#), where a straight-through one-to-one cable connects an external switch or hub to the Cisco RPS while the device is powered by its own internal power supply (the device AC power plug is connected).

Figure 1-3 Redundant-With-Reboot Configuration



In this configuration, one Cisco RPS can support four devices. The Cisco RPS and the external device internal power supply are both connected.

**Note**

If you use this configuration, always power up the external device *before* powering up the Cisco RPS to ensure correct operation. If the Cisco RPS powers up first, the LEDs might not indicate the actual state.

After power up, a sense circuit in the Cisco RPS reads that the device has its AC power connected and shuts the Cisco RPS output off, preventing competition between the power supplies.

Normally, the external device internal power supply always provides power. If the internal power system of the hub or switch fails, the device powers down briefly (for approximately 30 seconds) until the Cisco RPS begins supplying power. When the device comes back up, the Cisco RPS is the main power source.

In this configuration, if the Cisco RPS fails or is disconnected, the external device does not power cycle, because its internal power supply has not been disturbed. When both the Cisco RPS and internal power supply are powered, the RPS LED on the external device blinks green, and the LED on the Cisco RPS front panel is off because the Cisco RPS is not supplying power.

Despite 30 seconds of downtime that occur when using redundancy with reboot, this configuration does provide additional redundancy and extends the capacity of the Cisco RPS.


**Note**

Cisco recommends that you do not use the redundant-with-reboot configuration with the hub or switch connected to both the Cisco RPS and to the AC power plug, because of the 30-second reboot and downtime. If you do use the redundant-with-reboot configuration, always power up the external device before you power up the Cisco RPS to ensure correct operation. When the Cisco RPS powers up first, the LEDs might not indicate the actual state.

Quasi- and Fully Redundant Mixed Configuration

You can mix quasi-redundant and fully redundant configurations for supported devices. For example, two devices can be in quasi-redundant mode while one is in fully redundant mode (see [Figure 1-4](#)).


Figure 1-4 Mixed Configuration



Front and Rear Panel Descriptions


The LEDs on the Cisco RPS front panel show the Cisco RPS operational status. [Figure 1-5](#) shows the front panel of the Cisco RPS.

Figure 1-5 Cisco RPS Front Panel



The Cisco RPS rear panel has two AC power connectors, each with an on/off switch, and four DC connectors for connecting to devices. [Figure 1-6](#) shows the rear panel. See [Chapter 3, “Connection Requirements,”](#) for information about required cables and connectors.

Figure 1-6 Cisco RPS Rear Panel



LEDs

The LEDs on the front panel of the Cisco RPS display the current operating condition of the Cisco RPS:

- AC STATUS LEDs—Two on the left side of the front panel.
- DC STATUS LEDs—Four on the center of the front panel.
- FAN and TEMP LEDs—Both on the right side of the front panel.

When the Cisco RPS is working properly, all LEDs on its front panel are solid green.



Note

Some external devices also include LEDs that show the operating condition of the Cisco RPS. Refer to the installation guide that accompanied the device for detailed information about the device LEDs.

Figure 1-7 shows the Cisco RPS front panel LEDs, and Table 1-2 explains the meaning of the colors.

Figure 1-7 Cisco RPS LEDs




Table 1-2 LED Descriptions

LED Name	Color/State	Description
AC STATUS	Off	AC power is not being supplied to the Cisco RPS, or it is switched off.
	Amber	AC power is being supplied to the Cisco RPS, but the designated AC-input power module has failed.
	Green	The AC-input power module is on and operating correctly.
DC STATUS	Note	The DC status LEDs are numbered to correspond to the DC-output connectors on the Cisco RPS rear panel.
	Off	The DC output is powered down at the external device, AC power is not being supplied to the Cisco RPS, or there is no output cable attached to the DC output module.

Table 1-2 LED Descriptions (continued)

LED Name	Color/State	Description
	Amber	The DC output power module has failed. Note The DC status LED is amber for 10 to 15 seconds after the DC output power module has been connected and the external device has been powered up before it turns green to indicate correct operation. Note If you are using a Cisco RPS with a revision level lower than Z3 with a Catalyst 3508G or a Catalyst 3548 XL switch, the switch RPS LED and the RPS DC LED of the connector for the switch might display amber (normally indicating a Cisco RPS malfunction) even when the Cisco RPS is functioning properly. The LEDs display correctly for Cisco RPS revision level Z3 or later revision. The label on the bottom of the Cisco RPS shows the revision.
	Green	The DC output power module is on and operating correctly.
	Off	AC power is not being supplied to the Cisco RPS.
FAN	Amber	One or more cooling fans has failed.
	Green	All cooling fans are functioning correctly.
TEMP	Off	AC power is not being supplied to the Cisco RPS.
	Amber	The Cisco RPS internal temperature is exceeding the operating range.
	Green	The Cisco RPS internal temperature is within the operating range.

Safety Recommendations

Follow these guidelines to guarantee general safety:

- Keep the chassis area clear and dust-free during and after installation.
- Keep tools and chassis components away from walk areas where you or others could fall over them.
- Do not wear loose clothing that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.

- Wear safety glasses when working under conditions that might be hazardous to your eyes.
- Do not perform any action that creates a hazard to people or makes the equipment unsafe.

Safety Warnings

Safety warnings appear throughout this guide in procedures that, if performed incorrectly, might harm you. A warning symbol precedes each warning statement. (For information on safety warnings and translations, see the [“Notes, Cautions, and Warnings”](#) section on page xi.)

Safety with Electricity



Warning

Read the installation instructions before you connect the system to its power source. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.



Warning

The device is designed to work with TN power systems. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.



Warning

Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

**Warning**

This product relies on the building's installation for short-circuit (overcurrent) protection. Make sure that a fuse or circuit breaker is no larger than 120 VAC, 15A U.S. (240 VAC, 10A international) is used on the phase conductors (all current-carrying conductors). To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

**Warning**

This equipment is intended to be grounded. Make sure that the host is connected to earth ground during normal use. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

**Warning**

Ultimate disposal of this product should be handled according to all national laws and regulations. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

Follow these guidelines when working on equipment powered by electricity:

- Locate the emergency power-off switch in the room in which you are working. Then, if an electrical accident occurs, you can quickly shut the power off.
- Look carefully for possible hazards in your work area, such as moist floors, ungrounded power extension cables, and missing safety grounds.
- If an electrical accident occurs, proceed as follows:
 - Use caution; do not become a victim yourself.
 - Turn off power to the Cisco RPS.
 - If possible, send another person to get medical aid. Otherwise, determine the condition of the victim and then call for help.
 - Determine if the person needs rescue breathing or external cardiac compressions; then take appropriate action.

