



CHAPTER 25

Configuring Multicast Routing

This chapter describes how to configure the adaptive security appliance to use the multicast routing protocol and includes the following sections:

- [Information About Multicast Routing, page 25-1](#)
- [Licensing Requirements for Multicast Routing, page 25-2](#)
- [Guidelines and Limitations, page 25-3](#)
- [Enabling Multicast Routing, page 25-3](#)
- [Customizing Multicast Routing, page 25-4](#)
- [Configuration Example for Multicast Routing, page 25-14](#)
- [Additional References, page 25-15](#)
- [Feature History for Multicast Routing, page 25-15](#)

Information About Multicast Routing

Multicast routing is a bandwidth-conserving technology that reduces traffic by simultaneously delivering a single stream of information to thousands of corporate recipients and homes. Applications that take advantage of multicast routing include videoconferencing, corporate communications, distance learning, and distribution of software, stock quotes, and news.

Multicast routing protocols delivers source traffic to multiple receivers without adding any additional burden on the source or the receivers while using the least network bandwidth of any competing technology. Multicast packets are replicated in the network by Cisco routers enabled with Protocol Independent Multicast (PIM) and other supporting multicast protocols resulting in the most efficient delivery of data to multiple receivers possible.

The adaptive security appliance supports both stub multicast routing and PIM multicast routing. However, you cannot configure both concurrently on a single adaptive security appliance.



Note

The UDP and non-UDP transports are both supported for multicast routing. However, the non-UDP transport has no FastPath optimization.

Stub Multicast Routing

Stub multicast routing provides dynamic host registration and facilitates multicast routing. When configured for stub multicast routing, the adaptive security appliance acts as an IGMP proxy agent. Instead of fully participating in multicast routing, the adaptive security appliance forwards IGMP messages to an upstream multicast router, which sets up delivery of the multicast data. When configured for stub multicast routing, the adaptive security appliance cannot be configured for PIM.

The adaptive security appliance supports both PIM-SM and bi-directional PIM. PIM-SM is a multicast routing protocol that uses the underlying unicast routing information base or a separate multicast-capable routing information base. It builds unidirectional shared trees rooted at a single Rendezvous Point per multicast group and optionally creates shortest-path trees per multicast source.

PIM Multicast Routing

Bi-directional PIM is a variant of PIM-SM that builds bi-directional shared trees connecting multicast sources and receivers. Bi-directional trees are built using a DF election process operating on each link of the multicast topology. With the assistance of the DF, multicast data is forwarded from sources to the Rendezvous Point, and therefore along the shared tree to receivers, without requiring source-specific state. The DF election takes place during Rendezvous Point discovery and provides a default route to the Rendezvous Point.

**Note**

If the adaptive security appliance is the PIM RP, use the untranslated outside address of the adaptive security appliance as the RP address.

Multicast Group Concept

Multicast is based on the concept of a group. An arbitrary group of receivers expresses an interest in receiving a particular data stream. This group does not have any physical or geographical boundaries—the hosts can be located anywhere on the Internet. Hosts that are interested in receiving data flowing to a particular group must join the group using IGMP. Hosts must be a member of the group to receive the data stream.

Multicast Addresses

Multicast addresses specify an arbitrary group of IP hosts that have joined the group and want to receive traffic sent to this group.

Licensing Requirements for Multicast Routing

Model	License Requirement
All models	Base License.

Guidelines and Limitations

This section includes the guidelines and limitations for this feature.

Context Mode Guidelines

Supported in single context mode. In multiple context mode, unshared interfaces and shared interfaces are not supported.

Firewall Mode Guidelines

Supported only in routed mode. Transparent mode is not supported.

IPv6 Guidelines

Does not support IPv6.

Enabling Multicast Routing

Enabling multicast routing lets you enable multicast routing on the adaptive security appliance. Enabling multicast routing enables IGMP and PIM on all interfaces by default. IGMP is used to learn whether members of a group are present on directly attached subnets. Hosts join multicast groups by sending IGMP report messages. PIM is used to maintain forwarding tables to forward multicast datagrams.



Note

Only the UDP transport layer is supported for multicast routing.

To enable multicast routing, enter the following command:

Command	Purpose
multicast-routing	Enables multicast routing.
Example: hostname(config)# multicast-routing	The number of entries in the multicast routing tables are limited by the amount of RAM on the adaptive security appliance.

Table 25-1 lists the maximum number of entries for specific multicast tables based on the amount of RAM on the adaptive security appliance. Once these limits are reached, any new entries are discarded.

Table 25-1 Entry Limits for Multicast Tables

Table	16 MB	128 MB	128+ MB
MFIB	1000	3000	5000
IGMP Groups	1000	3000	5000
PIM Routes	3000	7000	12000

Customizing Multicast Routing

This section describes how to customize multicast routing and includes the following topics:

- [Configuring Stub Multicast Routing, page 25-4](#)
- [Configuring a Static Multicast Route, page 25-4](#)
- [Configuring IGMP Features, page 25-5](#)
- [Configuring PIM Features, page 25-9](#)
- [Configuring a Bidirectional Neighbor Filter, page 25-13](#)
- [Configuring a Multicast Boundary, page 25-14](#)

Configuring Stub Multicast Routing

**Note**

Stub multicast routing and PIM are not supported concurrently.

An adaptive security appliance acting as the gateway to the stub area does not need to participate in PIM. Instead, you can configure it to act as an IGMP proxy agent and forward IGMP messages from hosts connected on one interface to an upstream multicast router on another. To configure the adaptive security appliance as an IGMP proxy agent, forward the host join and leave messages from the stub area interface to an upstream interface.

To forward the host join and leave messages, enter the following command from the interface attached to the stub area:

Command	Purpose
<code>igmp forward interface <i>if_name</i></code>	Configures stub multicast routing.
Example: <code>hostname(config-if)# igmp forward interface <i>interface1</i></code>	

Configuring a Static Multicast Route

Configuring static multicast routes lets you separate multicast traffic from unicast traffic. For example, when a path between a source and destination does not support multicast routing, the solution is to configure two multicast devices with a GRE tunnel between them and to send the multicast packets over the tunnel.

When using PIM, the adaptive security appliance expects to receive packets on the same interface where it sends unicast packets back to the source. In some cases, such as bypassing a route that does not support multicast routing, you may want unicast packets to take one path and multicast packets to take another.

Static multicast routes are not advertised or redistributed.

To configure a static multicast route or a static multicast route for a stub area, enter one of the following commands:

Command	Purpose
mroute <i>src_ip src_mask {input_if_name rpf_neighbor} [distance]</i> Example: hostname(config)# mroute <i>src_ip src_mask {input_if_name rpf_neighbor} [distance]</i>	Configures a static multicast route.
mroute <i>src_ip src_mask input_if_name [dense output_if_name] [distance]</i> Example: hostname(config)# mroute <i>src_ip src_mask input_if_name [dense output_if_name] [distance]</i>	Configures a static multicast route for a stub area. The dense output_if_name keyword and argument pair is only supported for stub multicast routing.

Configuring IGMP Features

IP hosts use Internet Group Management Protocol, or IGMP, to report their group memberships to directly connected multicast routers.

IGMP is used to dynamically register individual hosts in a multicast group on a particular LAN. Hosts identify group memberships by sending IGMP messages to their local multicast router. Under IGMP, routers listen to IGMP messages and periodically send out queries to discover which groups are active or inactive on a particular subnet.

IGMP uses group addresses (Class D IP address) as group identifiers. Host group address can be in the range 224.0.0.0 to 239.255.255.255. The address 224.0.0.0 is never assigned to any group. The address 224.0.0.1 is assigned to all systems on a subnet. The address 224.0.0.2 is assigned to all routers on a subnet.

When you enable multicast routing on the adaptive security appliance, IGMP Version 2 is automatically enabled on all interfaces.



Note

Only the **no igmp** command appears in the interface configuration when you use the **show run** command. If the **multicast-routing** command appears in the device configuration, then IGMP is automatically enabled on all interfaces.

This section describes how to configure optional IGMP setting on a per-interface basis and includes the following topics:

- [Disabling IGMP on an Interface, page 25-6](#)
- [Configuring IGMP Group Membership, page 25-6](#)
- [Configuring a Statically Joined IGMP Group, page 25-6](#)
- [Controlling Access to Multicast Groups, page 25-7](#)
- [Limiting the Number of IGMP States on an Interface, page 25-7](#)
- [Modifying the Query Messages to Multicast Groups, page 25-8](#)

- [Changing the IGMP Version, page 25-9](#)

Disabling IGMP on an Interface

You can disable IGMP on specific interfaces. This is useful if you know that you do not have any multicast hosts on a specific interface and you want to prevent the adaptive security appliance from sending host query messages on that interface.

To disable IGMP on an interface, enter the following command:

Command	Purpose
<code>no igmp</code>	Disables IGMP on an interface. To reenable IGMP on an interface, use the igmp command.
Example: <code>hostname(config-if)# no igmp</code>	

**Note**

Only the **no igmp** command appears in the interface configuration.

Configuring IGMP Group Membership

You can configure the adaptive security appliance to be a member of a multicast group. Configuring the adaptive security appliance to join a multicast group causes upstream routers to maintain multicast routing table information for that group and keep the paths for that group active.

**Note**

If you want to forward multicast packets for a specific group to an interface without the adaptive security appliance accepting those packets as part of the group, see the [“Configuring a Statically Joined IGMP Group” section on page 25-6](#).

To have the adaptive security appliance join a multicast group, enter the following command:

Command	Purpose
<code>igmp join-group group-address</code>	Configures the adaptive security appliance to be a member of a multicast group.
Example: <code>hostname(config-if)# igmp join-group mcast-group</code>	The <i>group-address</i> is the IP address of the group.

Configuring a Statically Joined IGMP Group

Sometimes a group member cannot report its membership in the group because of some configuration, or there may be no members of a group on the network segment. However, you still want multicast traffic for that group to be sent to that network segment. You can have multicast traffic for that group sent to the segment by configuring a statically joined IGMP group.

From the command line, use the **igmp static-group** command. The adaptive security appliance does not accept the multicast packets but rather forwards them to the specified interface.

To configure a statically joined multicast group on an interface, enter the following command

Command	Purpose
igmp static-group	Configures the adaptive security appliance statically join a multicast group on an interface.
Example: hostname(config-if)# igmp static-group <i>group-address</i>	The <i>group-address</i> is the IP address of the group.

Controlling Access to Multicast Groups

To control the multicast groups that hosts on the adaptive security appliance interface can join, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	Do one of the following to create a standard or extended access list.	
	access-list <i>name</i> standard [permit deny] <i>ip_addr mask</i>	Creates a standard access list for the multicast traffic. You can create more than one entry for a single access list. You can use extended or standard access lists. The <i>ip_addr mask</i> argument is the IP address of the multicast group being permitted or denied.
	Example: hostname(config)# access-list <i>acl1</i> standard permit <i>192.52.662.25</i>	
	access-list <i>name</i> extended [permit deny] <i>protocol src_ip_addr src_mask dst_ip_addr</i> <i>dst_mask</i>	Creates an extended access list. The <i>dst_ip_addr</i> argument is the IP address of the multicast group being permitted or denied.
	Example: hostname(config)# access-list <i>acl2</i> extended permit <i>protocol src_ip_addr</i> <i>src_mask dst_ip_addr dst_mask</i>	
Step 2	igmp access-group <i>acl</i>	Applies the access list to an interface. The <i>acl</i> argument is the name of a standard or extended IP access list.
	Example: hostname(config-if)# igmp access-group <i>acl</i>	

Limiting the Number of IGMP States on an Interface

You can limit the number of IGMP states resulting from IGMP membership reports on a per-interface basis. Membership reports exceeding the configured limits are not entered in the IGMP cache and traffic for the excess membership reports is not forwarded.

To limit the number of IGMP states on an interface, enter the following command:

Command	Purpose
igmp limit <i>number</i>	Limits the number of IGMP states on an interface.
Example: hostname(config-if)# igmp limit 50	Valid values range from 0 to 500, with 500 being the default value. Setting this value to 0 prevents learned groups from being added, but manually defined memberships (using the igmp join-group and igmp static-group commands) are still permitted. The no form of this command restores the default value.

Modifying the Query Messages to Multicast Groups



Note

The **igmp query-timeout** and **igmp query-interval** commands require IGMP Version 2.

The adaptive security appliance sends query messages to discover which multicast groups have members on the networks attached to the interfaces. Members respond with IGMP report messages indicating that they want to receive multicast packets for specific groups. Query messages are addressed to the all-systems multicast group, which has an address of 224.0.0.1, with a time-to-live value of 1.

These messages are sent periodically to refresh the membership information stored on the adaptive security appliance. If the adaptive security appliance discovers that there are no local members of a multicast group still attached to an interface, it stops forwarding multicast packet for that group to the attached network and it sends a prune message back to the source of the packets.

By default, the PIM designated router on the subnet is responsible for sending the query messages. By default, they are sent once every 125 seconds.

When changing the query response time, by default, the maximum query response time advertised in IGMP queries is 10 seconds. If the adaptive security appliance does not receive a response to a host query within this amount of time, it deletes the group.

To change the query interval, query response time, and query timeout value, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	igmp query-interval <i>seconds</i>	Sets the query interval time in seconds.
	Example: hostname(config-if)# igmp query-interval 30	Valid values range from 0 to 500; 125 is the default value. If the adaptive security appliance does not hear a query message on an interface for the specified timeout value (by default, 255 seconds), then the adaptive security appliance becomes the designated router and starts sending the query messages.

	Command	Purpose
Step 2	<code>igmp query-timeout seconds</code> Example: <code>hostname(config-if)# igmp query-timeout 30</code>	Changes the timeout value of the query. Valid values range from 0 to 500, with 225 being the default value.
Step 3	<code>igmp query-max-response-time seconds</code> Example: <code>hostname(config-if)# igmp query-max-response-time 30</code>	Changes the maximum query response time.

Changing the IGMP Version

By default, the adaptive security appliance runs IGMP Version 2, which enables several additional features such as the `igmp query-timeout` and `igmp query-interval` commands.

All multicast routers on a subnet must support the same version of IGMP. The adaptive security appliance does not automatically detect version 1 routers and switch to version 1. However, a mix of IGMP Version 1 and 2 hosts on the subnet works; the adaptive security appliance running IGMP Version 2 works correctly when IGMP Version 1 hosts are present.

To control which version of IGMP is running on an interface, enter the following command:

Command	Purpose
<code>igmp version {1 2}</code> Example: <code>hostname(config-if)# igmp version 2</code>	Controls which version of IGMP that you want to run on the interface.

Configuring PIM Features

Routers use PIM to maintain forwarding tables for forwarding multicast diagrams. When you enable multicast routing on the adaptive security appliance, PIM and IGMP are automatically enabled on all interfaces.



Note

PIM is not supported with PAT. The PIM protocol does not use ports and PAT only works with protocols that use ports.

This section describes how to configure optional PIM settings and includes the following topics:

- [Enabling and Disabling PIM on an Interface, page 25-10](#)
- [Configuring a Static Rendezvous Point Address, page 25-10](#)
- [Configuring the Designated Router Priority, page 25-11](#)
- [Configuring and Filtering PIM Register Messages, page 25-11](#)
- [Configuring PIM Message Intervals, page 25-12](#)
- [Filtering PIM Neighbors, page 25-12](#)

Enabling and Disabling PIM on an Interface

You can enable or disable PIM on specific interfaces. To enable or disable PIM on an interface, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	pim Example: hostname(config-if)# pim	Enables or reenables PIM on a specific interface.
Step 2	no pim Example: hostname(config-if)# no pim	Disables PIM on a specific interface.



Note

Only the **no pim** command appears in the interface configuration.

Configuring a Static Rendezvous Point Address

All routers within a common PIM sparse mode or bidir domain require knowledge of the PIM RP address. The address is statically configured using the **pim rp-address** command.



Note

The adaptive security appliance does not support Auto-RP or PIM BSR. You must use the **pim rp-address** command to specify the RP address.

You can configure the adaptive security appliance to serve as RP to more than one group. The group range specified in the access list determines the PIM RP group mapping. If an access list is not specified, then the RP for the group is applied to the entire multicast group range (224.0.0.0/4).

To configure the address of the PIM PR, enter the following command:

Command	Purpose
pim rp-address <i>ip_address</i> [<i>acl</i>] [bidir] Example: hostname(config)# pim rp-address 10.86.75.23 [acl1] [bidir]	Enables or reenables PIM on a specific interface. The <i>ip_address</i> argument is the unicast IP address of the router to be a PIM RP. The <i>acl</i> argument is the name or number of a standard access list that defines which multicast groups the RP should be used with. Do not use a host ACL with this command. Excluding the bidir keyword causes the groups to operate in PIM sparse mode.

**Note**

The adaptive security appliance always advertises the bidirectional capability in the PIM hello messages regardless of the actual bidirectional configuration.

Configuring the Designated Router Priority

The DR is responsible for sending PIM register, join, and prune messages to the RP. When there is more than one multicast router on a network segment, there is an election process to select the DR based on DR priority. If multiple devices have the same DR priority, then the device with the highest IP address becomes the DR.

By default, the adaptive security appliance has a DR priority of 1. To change this value, enter the following command:

Command	Purpose
pim dr-priority <i>num</i>	Changes the designated router priority. The <i>num</i> argument can be any number from 1 to 4294967294.
Example: <pre>hostname(config-if)# pim dr-priority 500</pre>	

Configuring and Filtering PIM Register Messages

When the adaptive security appliance is acting as an RP, you can restrict specific multicast sources from registering with it. This prevents unauthorized sources from registering with the RP. The Request Filter pane lets you define the multicast sources from which the adaptive security appliance will accept PIM register messages.

To filter PIM register messages, enter the following command:

Command	Purpose
pim accept-register { list <i>acl</i> route-map <i>map-name</i> }	Configures the adaptive security appliance to filter PIM register messages. In this example, the adaptive security appliance filters PIM register messages <i>acl1</i> and route map <i>map2</i> .
Example: <pre>hostname(config)# pim accept-register {list acl1 route-map map2}</pre>	

Configuring PIM Message Intervals

Router query messages are used to select the PIM DR. The PIM DR is responsible for sending router query messages. By default, router query messages are sent every 30 seconds. Additionally, every 60 seconds, the adaptive security appliance sends PIM join/prune messages.

To change these intervals, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	pim hello-interval <i>seconds</i> Example: hostname(config-if)# pim hello-interval 60	Sends router query messages. Valid values for the <i>seconds</i> argument range from 1 to 3600 seconds.
Step 2	pim join-prune-interval <i>seconds</i> Example: hostname(config-if)# pim join-prune-interval 60	Changes the amount of time (in seconds) that the adaptive security appliance sends PIM join/prune messages. Valid values for the <i>seconds</i> argument range from 10 to 600 seconds.

Filtering PIM Neighbors

You can define the routers that can become PIM neighbors. By filtering the routers that can become PIM neighbors, you can do the following:

- Prevent unauthorized routers from becoming PIM neighbors.
- Prevent attached stub routers from participating in PIM.

To define the neighbors that can become a PIM neighbor, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	access-list pim_nbr deny <i>router-IP_addr</i> <i>PIM neighbor</i> Example: hostname(config)# access-list pim_nbr deny 10.1.1.1 255.255.255.255	Uses a standard access list to define the routers that you want to have participate in PIM. In this example, the following access list, when used with the pim neighbor-filter command, prevents the 10.1.1.1 router from becoming a PIM neighbor:
Step 2	pim neighbor-filter pim_nbr Example: hostname(config)# interface GigabitEthernet0/3 hostname(config-if)# pim neighbor-filter pim_nbr	Filters neighbor routers. In this example, the 10.1.1.1 router is prevented from becoming a PIM neighbor on interface GigabitEthernet0/3.

Configuring a Bidirectional Neighbor Filter

The Bidirectional Neighbor Filter pane shows the PIM bidirectional neighbor filters, if any, that are configured on the adaptive security appliance. A PIM bidirectional neighbor filter is an ACL that defines the neighbor devices that can participate in the DF election. If a PIM bidirectional neighbor filter is not configured for an interface, then there are no restrictions. If a PIM bidirectional neighbor filter is configured, only those neighbors permitted by the ACL can participate in DF election process.

When a PIM bidirectional neighbor filter configuration is applied to the adaptive security appliance, an ACL appears in the running configuration with the name *interface-name_multicast*, to which the *interface-name* is the name of the interface the multicast boundary filter is applied. If an ACL with that name already exists, a number is appended to the name, for example *inside_multicast_1*. This ACL defines which devices can become PIM neighbors of the adaptive security appliance.

Bidirectional PIM allows multicast routers to keep reduced state information. All of the multicast routers in a segment must be bidirectionally enabled for bidir to elect a DF.

The PIM bidirectional neighbor filters enable the transition from a sparse-mode-only network to a bidir network by letting you specify the routers that should participate in DF election while still allowing all routers to participate in the sparse-mode domain. The bidir-enabled routers can elect a DF from among themselves, even when there are non-bidir routers on the segment. Multicast boundaries on the non-bidir routers prevent PIM messages and data from the bidir groups from leaking in or out of the bidir subset cloud.

When a PIM bidirectional neighbor filter is enabled, the routers that are permitted by the ACL are considered to be bidirectionally capable. Therefore:

- If a permitted neighbor does not support bidir, the DF election does not occur.
- If a denied neighbor supports bidir, then DF election does not occur.
- If a denied neighbor does not support bidir, the DF election can occur.

To define the neighbors that can become a PIM bidirectional neighbor filter, perform the following steps:

Detailed Steps

	Command	Purpose
Step 1	access-list pim_nbr deny router-IP_addr PIM neighbor Example: hostname(config)# access-list pim_nbr deny 10.1.1.1 255.255.255.255	Uses a standard access list to define the routers that you want to have participate in PIM. In this example, the following access list, when used with the pim neighbor-filter command, prevents the 10.1.1.1 router from becoming a PIM neighbor.
Step 2	pim bidirectional-neighbor-filter pim_nbr Example: hostname(config)# interface GigabitEthernet0/3 hostname(config-if)# pim bidirectional neighbor-filter pim_nbr	Filters neighbor routers. In this example, the 10.1.1.1 router is prevented from becoming a PIM bidirectional neighbor on interface GigabitEthernet0/3.

The PIM Bidirectional Neighbor Filter table contains the following entries. Double-click an entry to open the Edit Bidirectional Neighbor Filter Entry dialog box for that entry.

The Add/Edit/Insert Bidirectional Neighbor Filter Entry dialog box lets you create ACL entries for the PIM bidirectional neighbor filter ACL.

Select the interface for which you are configuring the PIM bidirectional neighbor filter ACL entry. Choose **Permit** to allow the specified devices to participate in the DF election process. Choose **Deny** to prevent the specified devices from participating in the DF election process.

Configuring a Multicast Boundary

Address scoping defines domain boundaries so that domains with RPs that have the same IP address do not leak into each other. Scoping is performed on the subnet boundaries within large domains and on the boundaries between the domain and the Internet.

You can set up an administratively scoped boundary on an interface for multicast group addresses using the **multicast boundary** command. IANA has designated the multicast address range 239.0.0.0 to 239.255.255.255 as the administratively scoped addresses. This range of addresses can be reused in domains administered by different organizations. They would be considered local, not globally unique.

A standard ACL defines the range of addresses affected. When a boundary is set up, no multicast data packets are allowed to flow across the boundary from either direction. The boundary allows the same multicast group address to be reused in different administrative domains.

You can configure the **filter-autorp** keyword to examine, and filter Auto-RP discovery and announcement messages at the administratively scoped boundary. Any Auto-RP group range announcements from the Auto-RP packets that are denied by the boundary access control list (ACL) are removed. An Auto-RP group range announcement is permitted and passed by the boundary only if all addresses in the Auto-RP group range are permitted by the boundary ACL. If any address is not permitted, the entire group range is filtered and removed from the Auto-RP message before the Auto-RP message is forwarded.

To configure a multicast boundary, enter the following command:

Command	Purpose
multicast boundary <i>acl</i> [filter-autorp]	Configures a multicast boundary.
Example: <pre>hostname(config-if)# multicast boundary acl1 [filter-autorp]</pre>	

Configuration Example for Multicast Routing

The following example shows how to enable and configure multicast routing with various optional processes:

Step 1 Enable multicast routing:

```
hostname(config)# multicast-routing
```

Step 2 Configure a static multicast route:

```
hostname(config)# mroute src_ip src_mask {input_if_name | rpf_neighbor} [distance]
hostname(config)# exit
```

Step 3 Configure the adaptive security appliance to be a member of a multicast group:

```
hostname(config) # interface
hostname(config-if) # igmp join-group group-address
```

Additional References

For additional information related to routing, see the following sections:

- [Related Documents, page 25-15](#)
- [RFCs, page 25-15](#)

Related Documents

Related Topic	Document Title
Technical details about the IGMP and multicast routing standards used for implementing the SMR feature	IETF draft-ietf-idmr-igmp-proxy-01.txt

RFCs

RFC	Title
RFC 2113	IP Router Alert Option
RFC 2236	IGMPv2
RFC 2362	PIM-SM
RFC 2588	IP Multicast and Firewalls

Feature History for Multicast Routing

[Table 25-2](#) lists each feature change and the platform release in which it was implemented.

Table 25-2 Feature History for Multicast Routing

Feature Name	Platform Releases	Feature Information
Multicast routing support	7.0(1)	Support for multicast route data, perform authentication, redistribute and monitor routing information, using the multicast routing protocol was added. The multicast-routing command was introduced. The multicast-routing command was introduced to route data, perform authentication, redistribute and monitor routing information, using the multicast routing protocol.

