



Configuring Multiple Context Mode

This chapter describes how to configure multiple security contexts on the ASA and includes the following sections:

- [Information About Security Contexts, page 5-1](#)
- [Licensing Requirements for Multiple Context Mode, page 5-13](#)
- [Guidelines and Limitations, page 5-14](#)
- [Default Settings, page 5-15](#)
- [Configuring Multiple Contexts, page 5-15](#)
- [Changing Between Contexts and the System Execution Space, page 5-25](#)
- [Managing Security Contexts, page 5-26](#)
- [Monitoring Security Contexts, page 5-30](#)
- [Feature History for Multiple Context Mode, page 5-33](#)

Information About Security Contexts

You can partition a single ASA into multiple virtual devices, known as security contexts. Each context acts as an independent device, with its own security policy, interfaces, and administrators. Multiple contexts are similar to having multiple standalone devices. For unsupported features in multiple context mode, see the [“Guidelines and Limitations” section on page 5-14](#).

This section provides an overview of security contexts and includes the following topics:

- [Common Uses for Security Contexts, page 5-2](#)
- [Context Configuration Files, page 5-2](#)
- [How the ASA Classifies Packets, page 5-3](#)
- [Cascading Security Contexts, page 5-6](#)
- [Management Access to Security Contexts, page 5-7](#)
- [Information About Resource Management, page 5-8](#)
- [Information About MAC Addresses, page 5-11](#)

Common Uses for Security Contexts

You might want to use multiple security contexts in the following situations:

- You are a service provider and want to sell security services to many customers. By enabling multiple security contexts on the ASA, you can implement a cost-effective, space-saving solution that keeps all customer traffic separate and secure, and also eases configuration.
- You are a large enterprise or a college campus and want to keep departments completely separate.
- You are an enterprise that wants to provide distinct security policies to different departments.
- You have any network that requires more than one ASA.

Context Configuration Files

This section describes how the ASA implements multiple context mode configurations and includes the following topics:

- [Context Configurations, page 5-2](#)
- [System Configuration, page 5-2](#)
- [Admin Context Configuration, page 5-2](#)

Context Configurations

For each context, the ASA includes a configuration that identifies the security policy, interfaces, and all the options you can configure on a standalone device. You can store context configurations in flash memory, or you can download them from a TFTP, FTP, or HTTP(S) server.

System Configuration

The system administrator adds and manages contexts by configuring each context configuration location, allocated interfaces, and other context operating parameters in the system configuration, which, like a single mode configuration, is the startup configuration. The system configuration identifies basic settings for the ASA. The system configuration does not include any network interfaces or network settings for itself; rather, when the system needs to access network resources (such as downloading the contexts from the server), it uses one of the contexts that is designated as the *admin context*. The system configuration does include a specialized failover interface for failover traffic only.

Admin Context Configuration

The admin context is just like any other context, except that when a user logs in to the admin context, then that user has system administrator rights and can access the system and all other contexts. The admin context is not restricted in any way, and can be used as a regular context. However, because logging into the admin context grants you administrator privileges over all contexts, you might need to restrict access to the admin context to appropriate users. The admin context must reside on flash memory, and not remotely.

If your system is already in multiple context mode, or if you convert from single mode, the admin context is created automatically as a file on the internal flash memory called `admin.cfg`. This context is named “admin.” If you do not want to use `admin.cfg` as the admin context, you can change the admin context.

How the ASA Classifies Packets

Each packet that enters the ASA must be classified, so that the ASA can determine to which context to send a packet. This section includes the following topics:

- [Valid Classifier Criteria, page 5-3](#)
- [Classification Examples, page 5-4](#)

**Note**

If the destination MAC address is a multicast or broadcast MAC address, the packet is duplicated and delivered to each context.

Valid Classifier Criteria

This section describes the criteria used by the classifier and includes the following topics:

- [Unique Interfaces, page 5-3](#)
- [Unique MAC Addresses, page 5-3](#)
- [NAT Configuration, page 5-3](#)

**Note**

For management traffic destined for an interface, the interface IP address is used for classification.

The routing table is not used for packet classification.

Unique Interfaces

If only one context is associated with the ingress interface, the ASA classifies the packet into that context. In transparent firewall mode, unique interfaces for contexts are required, so this method is used to classify packets at all times.

Unique MAC Addresses

If multiple contexts share an interface, then the classifier uses unique MAC addresses assigned to the interface in each context. An upstream router cannot route directly to a context without unique MAC addresses. By default, auto-generation of MAC addresses is enabled. You can also set the MAC addresses manually when you configure each interface.


NAT Configuration

If you disable use of unique MAC addresses, then the ASA uses the mapped addresses in your NAT configuration to classify packets. We recommend using MAC addresses instead of NAT, so that traffic classification can occur regardless of the completeness of the NAT configuration.

Classification Examples


Figure 5-1 shows multiple contexts sharing an outside interface. The classifier assigns the packet to Context B because Context B includes the MAC address to which the router sends the packet.

Figure 5-1 Packet Classification with a Shared Interface Using MAC Addresses




Note that all new incoming traffic must be classified, even from inside networks. [Figure 5-2](#) shows a host on the Context B inside network accessing the Internet. The classifier assigns the packet to Context B because the ingress interface is Gigabit Ethernet 0/1.3, which is assigned to Context B.

Figure 5-2 Incoming Traffic from Inside Networks



For transparent firewalls, you must use unique interfaces. [Figure 5-3](#) shows a packet destined to a host on the Context B inside network from the Internet. The classifier assigns the packet to Context B because the ingress interface is Gigabit Ethernet 1/0.3, which is assigned to Context B.

Figure 5-3 Transparent Firewall Contexts



Cascading Security Contexts

Placing a context directly in front of another context is called *cascading contexts*; the outside interface of one context is the same interface as the inside interface of another context. You might want to cascade contexts if you want to simplify the configuration of some contexts by configuring shared parameters in the top context.




Note

Cascading contexts requires unique MAC addresses for each context interface (the default setting). Because of the limitations of classifying packets on shared interfaces without MAC addresses, we do not recommend using cascading contexts without unique MAC addresses.

Figure 5-4 shows a gateway context with two contexts behind the gateway.

Figure 5-4 Cascading Contexts



Management Access to Security Contexts

The ASA provides system administrator access in multiple context mode as well as access for individual context administrators. The following sections describe logging in as a system administrator or as a context administrator:

- [System Administrator Access, page 5-7](#)
- [Context Administrator Access, page 5-8](#)

System Administrator Access

You can access the ASA as a system administrator in two ways:

- Access the ASA console.
From the console, you access the *system execution space*, which means that any commands you enter affect only the system configuration or the running of the system (for run-time commands).
- Access the admin context using Telnet, SSH, or ASDM.

See [Chapter 42, “Configuring Management Access,”](#) to enable Telnet, SSH, and ASDM access.

As the system administrator, you can access all contexts.

When you change to a context from admin or the system, your username changes to the default “enable_15” username. If you configured command authorization in that context, you need to either configure authorization privileges for the “enable_15” user, or you can log in as a different name for which you provide sufficient privileges. To log in with a new username, enter the **login** command. For

example, you log in to the admin context with the username “admin.” The admin context does not have any command authorization configuration, but all other contexts include command authorization. For convenience, each context configuration includes a user “admin” with maximum privileges. When you change from the admin context to context A, your username is altered to enable_15, so you must log in again as “admin” by entering the **login** command. When you change to context B, you must again enter the **login** command to log in as “admin.”

The system execution space does not support any AAA commands, but you can configure its own enable password, as well as usernames in the local database to provide individual logins.

Context Administrator Access

You can access a context using Telnet, SSH, or ASDM. If you log in to a non-admin context, you can only access the configuration for that context. You can provide individual logins to the context. See [Chapter 42, “Configuring Management Access,”](#) to enable Telnet, SSH, and ASDM access and to configure management authentication.

Information About Resource Management

By default, all security contexts have unlimited access to the resources of the ASA, except where maximum limits per context are enforced; the only exception is VPN resources, which are disabled by default. If you find that one or more contexts use too many resources, and they cause other contexts to be denied connections, for example, then you can configure resource management to limit the use of resources per context. For VPN resources, you must configure resource management to allow any VPN tunnels.

This section includes the following topics:

- [Resource Classes, page 5-8](#)
- [Resource Limits, page 5-8](#)
- [Default Class, page 5-9](#)
- [Using Oversubscribed Resources, page 5-10](#)
- [Using Unlimited Resources, page 5-11](#)

Resource Classes

The ASA manages resources by assigning contexts to resource classes. Each context uses the resource limits set by the class. To use the settings of a class, assign the context to the class when you define the context. All contexts belong to the default class if they are not assigned to another class; you do not have to actively assign a context to default. You can only assign a context to one resource class. The exception to this rule is that limits that are undefined in the member class are inherited from the default class; so in effect, a context could be a member of default plus another class.

Resource Limits

You can set the limit for individual resources as a percentage (if there is a hard system limit) or as an absolute value.

For most resources, the ASA does not set aside a portion of the resources for each context assigned to the class; rather, the ASA sets the maximum limit for a context. If you oversubscribe resources, or allow some resources to be unlimited, a few contexts can “use up” those resources, potentially affecting service

to other contexts. The exception is VPN resource types, which you cannot oversubscribe, so the resources assigned to each context are guaranteed. To accommodate temporary bursts of VPN sessions beyond the amount assigned, the ASA supports a “burst” VPN resource type, which is equal to the remaining unassigned VPN sessions. The burst sessions *can* be oversubscribed, and are available to contexts on a first-come, first-served basis.

Default Class

All contexts belong to the default class if they are not assigned to another class; you do not have to actively assign a context to the default class.


If a context belongs to a class other than the default class, those class settings always override the default class settings. However, if the other class has any settings that are not defined, then the member context uses the default class for those limits. For example, if you create a class with a 2 percent limit for all concurrent connections, but no other limits, then all other limits are inherited from the default class. Conversely, if you create a class with a limit for all resources, the class uses no settings from the default class.

For most resources, the default class provides unlimited access to resources for all contexts, except for the following limits:

- Telnet sessions—5 sessions. (The maximum per context.)
- SSH sessions—5 sessions. (The maximum per context.)
- IPsec sessions—5 sessions. (The maximum per context.)
- MAC addresses—65,535 entries. (The maximum per context.)
- VPN site-to-site tunnels—0 sessions. (You must manually configure the class to allow any VPN sessions.)

Figure 5-5 shows the relationship between the default class and other classes. Contexts A and C belong to classes with some limits set; other limits are inherited from the default class. Context B inherits no limits from default because all limits are set in its class, the Gold class. Context D was not assigned to a class, and is by default a member of the default class.

Figure 5-5 Resource Classes




104689

Using Oversubscribed Resources

You can oversubscribe the ASA by assigning more than 100 percent of a resource across all contexts (with the exception of non-burst VPN resources). For example, you can set the Bronze class to limit connections to 20 percent per context, and then assign 10 contexts to the class for a total of 200 percent. If contexts concurrently use more than the system limit, then each context gets less than the 20 percent you intended. (See Figure 5-6.)

Figure 5-6 Resource Oversubscription




104895

Using Unlimited Resources

The ASA lets you assign unlimited access to one or more resources in a class, instead of a percentage or absolute number. When a resource is unlimited, contexts can use as much of the resource as the system has available. For example, Context A, B, and C are in the Silver Class, which limits each class member to 1 percent of the connections, for a total of 3 percent; but the three contexts are currently only using 2 percent combined. Gold Class has unlimited access to connections. The contexts in the Gold Class can use more than the 97 percent of “unassigned” connections; they can also use the 1 percent of connections not currently in use by Context A, B, and C, even if that means that Context A, B, and C are unable to reach their 3 percent combined limit. (See [Figure 5-7](#).) Setting unlimited access is similar to oversubscribing the ASA, except that you have less control over how much you oversubscribe the system.

Figure 5-7 *Unlimited Resources*



153211

Information About MAC Addresses

To allow contexts to share interfaces, you should assign unique MAC addresses to each shared context interface.

The MAC address is used to classify packets within a context. If you share an interface, but do not have unique MAC addresses for the interface in each context, then other classification methods are attempted that might not provide full coverage. See the [“How the ASA Classifies Packets”](#) section on page 5-3 for information about classifying packets.

In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, you can manually set the MAC address for the interface within the context. See the [“Configuring the MAC Address and MTU”](#) section on page 17-13 to manually set the MAC address.

This section includes the following topics:

- [Default MAC Address, page 5-12](#)
- [Interaction with Manual MAC Addresses, page 5-12](#)
- [Failover MAC Addresses, page 5-12](#)
- [MAC Address Format, page 5-12](#)

Default MAC Address

If you disable MAC address generation, see the following default MAC addresses:

- For the ASA 5500 series appliances—The physical interface uses the burned-in MAC address, and all subinterfaces of a physical interface use the same burned-in MAC address.
- For the ASASM—All VLAN interfaces use the same MAC address, derived from the backplane MAC address.

See the following sections for your release for additional information about automatic MAC address generation. See also the [“MAC Address Format” section on page 5-12](#).

8.6(1) and Later

Automatic MAC address generation is enabled—Uses an autogenerated prefix. The ASA autogenerates the prefix based on the last two bytes of the interface (ASA 5500) or backplane (ASASM) MAC address. You cannot use the legacy auto-generation method (without a prefix).



Note

To maintain hitless upgrade for failover pairs, the ASA does not convert an existing auto-generation configuration upon a reload if failover is enabled. However, we strongly recommend that you manually change to the prefix method of generation when using failover, especially for the ASASM. Without the prefix method, ASASMs installed in different slot numbers experience a MAC address change upon failover, and can experience traffic interruption. After upgrading, to use the prefix method of MAC address generation, reenable MAC address autogeneration to use a prefix.

8.5(1) (ASASM only)

Automatic MAC address generation is enabled—Uses the legacy auto-generation method (without a prefix).

Earlier Releases

Automatic MAC address generation is disabled.

Interaction with Manual MAC Addresses

If you manually assign a MAC address and also enable auto-generation, then the manually assigned MAC address is used. If you later remove the manual MAC address, the auto-generated address is used.

Because auto-generated addresses (when using a prefix) start with A2, you cannot start manual MAC addresses with A2 if you also want to use auto-generation.

Failover MAC Addresses

For use with failover, the ASA generates both an active and standby MAC address for each interface. If the active unit fails over and the standby unit becomes active, the new active unit starts using the active MAC addresses to minimize network disruption. See the [“MAC Address Format” section on page 5-12](#) section for more information.

MAC Address Format

The MAC address format without a prefix is a legacy version not supported on newer ASA versions.

MAC Address Format Using a Prefix

The ASA generates the MAC address using the following format:

A2xx.yyzz.zzzz

Where xx.yy is a user-defined prefix or an autogenerated prefix based on the last two bytes of the interface (ASA 5500) or backplane (ASASM) MAC address, and zz.zzzz is an internal counter generated by the ASA. For the standby MAC address, the address is identical except that the internal counter is increased by 1.

For an example of how the prefix is used, if you set a prefix of 77, then the ASA converts 77 into the hexadecimal value 004D (yyxx). When used in the MAC address, the prefix is reversed (xxyy) to match the ASA native form:

A24D.00zz.zzzz

For a prefix of 1009 (03F1), the MAC address is:

A2F1.03zz.zzzz

MAC Address Format Without a Prefix (Legacy Method; Not Available in 8.6(1) and Later)

Without a prefix, the MAC address is generated using the following format:

- Active unit MAC address: 12_slot.port_subid.contextid.
- Standby unit MAC address: 02_slot.port_subid.contextid.

For platforms with no interface slots, the slot is always 0. The *port* is the interface port. The *subid* is an internal ID for the subinterface, which is not viewable. The *contextid* is an internal ID for the context, viewable with the **show context detail** command. For example, the interface GigabitEthernet 0/1.200 in the context with the ID 1 has the following generated MAC addresses, where the internal ID for subinterface 200 is 31:

- Active: 1200.0131.0001
- Standby: 0200.0131.0001

This MAC address generation method does not allow for persistent MAC addresses across reloads, does not allow for multiple ASAs on the same network segment (because unique MAC addresses are not guaranteed), and does not prevent overlapping MAC addresses with manually assigned MAC addresses. We recommend using a prefix with the MAC address generation to avoid these issues.

Licensing Requirements for Multiple Context Mode

Model	License Requirement
ASA 5505	No support.
ASA 5510	<ul style="list-style-type: none"> • Base License: No support. • Security Plus License: 2 contexts. <i>Optional license: 5 contexts.</i>
ASA 5520	Base License: 2 contexts. <i>Optional licenses: 5, 10, or 20 contexts.</i>

Model	License Requirement
ASA 5540	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, or 50 contexts.</i>
ASA 5550	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, or 100 contexts.</i>
ASA 5580	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, 100, or 250 contexts.</i>
ASA 5512-X	<ul style="list-style-type: none"> Base License: No support. Security Plus License: 2 contexts. <i>Optional license: 5 contexts.</i>
ASA 5515-X	Base License: 2 contexts. <i>Optional license: 5 contexts.</i>
ASA 5525-X	Base License: 2 contexts. <i>Optional licenses: 5, 10, or 20 contexts.</i>
ASA 5545-X	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, or 50 contexts.</i>
ASA 5555-X	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, or 100 contexts.</i>
ASA 5585-X with SSP-10	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, or 100 contexts.</i>
ASA 5585-X with SSP-20, -40, and -60	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, 100, or 250 contexts.</i>
ASASM	Base License: 2 contexts. <i>Optional licenses: 5, 10, 20, 50, 100, or 250 contexts.</i>

Prerequisites

After you are in multiple context mode, connect to the admin context to access the system configuration. You cannot configure the system from a non-admin context. By default, after you enable multiple context mode, you can connect to the admin context by using the default management IP address. See [Chapter 2, “Getting Started,”](#) for more information about connecting to the ASA.

Guidelines and Limitations

This section includes the guidelines and limitations for this feature.

Firewall Mode Guidelines

Supported in routed and transparent firewall mode; set the firewall mode per context.

Failover Guidelines

Active/Active mode failover is only supported in multiple context mode.

IPv6 Guidelines

Supports IPv6.

Model Guidelines

Does not support the ASA 5505.

Unsupported Features

Multiple context mode does not support the following features:

- RIP
- OSPFv3. (OSPFv2 is supported.)
- Multicast routing
- Threat Detection
- Unified Communications
- QoS
- Remote access VPN. (Site-to-site VPN is supported.)

Additional Guidelines

- The context mode (single or multiple) is not stored in the configuration file, even though it does endure reboots. If you need to copy your configuration to another device, set the mode on the new device to match.
- If you store context configurations in the root directory of flash memory, on some models you might run out of room in that directory, even though there is available memory. In this case, create a subdirectory for your configuration files. Background: some models, such as the ASA 5585-X, use the FAT 16 file system for internal flash memory, and if you do not use 8.3-compliant short names, or use uppercase characters, then fewer than 512 files and folders can be stored because the file system uses up slots to store long file names (see <http://support.microsoft.com/kb/120138/en-us>).

Default Settings

- By default, the ASA is in single context mode.
- See the “Default Class” section on page 5-9.
- See the “Default MAC Address” section on page 5-12.

Configuring Multiple Contexts

This section describes how to configure multiple context mode and includes the following topics:

- [Task Flow for Configuring Multiple Context Mode, page 5-16](#)
- [Enabling or Disabling Multiple Context Mode, page 5-16](#)
- [Configuring a Class for Resource Management, page 5-17](#)

- [Configuring a Security Context, page 5-20](#)
- [Automatically Assigning MAC Addresses to Context Interfaces, page 5-24](#)

Task Flow for Configuring Multiple Context Mode

To configure multiple context mode, perform the following steps:

-
- | | |
|---------------|--|
| Step 1 | Enable multiple context mode. See the “Enabling or Disabling Multiple Context Mode” section on page 5-16 . |
| Step 2 | (Optional) Configure classes for resource management. See the “Configuring a Class for Resource Management” section on page 5-17 . |
| Step 3 | Configure interfaces in the system execution space. <ul style="list-style-type: none">• ASA 5500—Chapter 10, “Starting Interface Configuration (ASA 5510 and Higher).”• ASASM—Chapter 2, “Configuring the Switch for Use with the ASA Services Module.” |
| Step 4 | Configure security contexts. See the “Configuring a Security Context” section on page 5-20 . |
| Step 5 | (Optional) Customize MAC address assignments. See the “Automatically Assigning MAC Addresses to Context Interfaces” section on page 5-24 . |
| Step 6 | Complete interface configuration in the context. See Chapter 17, “Completing Interface Configuration (Routed Mode),” or Chapter 18, “Completing Interface Configuration (Transparent Mode, 8.4 and Later).” |
-

Enabling or Disabling Multiple Context Mode

Your ASA might already be configured for multiple security contexts depending on how you ordered it from Cisco. If you need to convert from single mode to multiple mode, follow the procedures in this section.

ASDM supports changing modes from single to multiple mode if you use the High Availability and Scalability Wizard and you enable Active/Active failover. See [Chapter 13, “Configuring Active/Active Failover,”](#) for more information. If you do not want to use Active/Active failover or want to change back to single mode, you must change modes using the CLI; because changing modes requires confirmation, you cannot use the Command Line Interface tool. This section describes changing modes at the CLI.

This section includes the following topics:

- [Enabling Multiple Context Mode, page 5-16](#)
- [Restoring Single Context Mode, page 5-17](#)

Enabling Multiple Context Mode

When you convert from single mode to multiple mode, the ASA converts the running configuration into two files: a new startup configuration that comprises the system configuration, and admin.cfg that comprises the admin context (in the root directory of the internal flash memory). The original running configuration is saved as old_running.cfg (in the root directory of the internal flash memory). The original startup configuration is not saved. The ASA automatically adds an entry for the admin context to the system configuration with the name “admin.”

Prerequisites

Back up your startup configuration. When you convert from single mode to multiple mode, the ASA converts the running configuration into two files. The original startup configuration is not saved. See the [“Managing Files” section on page 84-14](#).

Detailed Steps

Command	Purpose
<code>mode multiple</code>	Changes to multiple context mode. You are prompted to reboot the ASA.
Example: <code>hostname(config)# mode multiple</code>	

Restoring Single Context Mode

To copy the old running configuration to the startup configuration and to change the mode to single mode, perform the following steps.

Prerequisites

Perform this procedure in the system execution space.

Detailed Steps

	Command	Purpose
Step 1	<code>copy disk0:old_running.cfg startup-config</code> Example: <code>hostname(config)# copy disk0:old_running.cfg startup-config</code>	Copies the backup version of your original running configuration to the current startup configuration.
Step 2	<code>mode single</code> Example: <code>hostname(config)# mode single</code>	Sets the mode to single mode. You are prompted to reboot the ASA.

Configuring a Class for Resource Management

To configure a class in the system configuration, perform the following steps. You can change the value of a particular resource limit by reentering the command with a new value.

Prerequisites

Perform this procedure in the system execution space.

Guidelines

Table 5-1 lists the resource types and the limits.

Table 5-1 Resource Names and Limits

Resource Name	Rate or Concurrent	Minimum and Maximum Number per Context	System Limit ¹	Description
ASDM Sessions	Concurrent	1 minimum 5 maximum	32	ASDM management sessions. Note ASDM sessions use two HTTPS connections: one for monitoring that is always present, and one for making configuration changes that is present only when you make changes. For example, the system limit of 32 ASDM sessions represents a limit of 64 HTTPS sessions.
Connections Conns/sec ²	Concurrent or Rate	N/A	Concurrent connections: See the “Supported Feature Licenses Per Model” section on page 3-1 for the connection limit available for your model. Rate: N/A	TCP or UDP connections between any two hosts, including connections between one host and multiple other hosts.
Hosts	Concurrent	N/A	N/A	Hosts that can connect through the ASA.
Inspects/sec	Rate	N/A	N/A	Application inspections per second.
MAC Entries	Concurrent	N/A	65,535	For transparent firewall mode, the number of MAC addresses allowed in the MAC address table.
Routes	Concurrent	N/A	N/A	Dynamic routes.
Site-to-Site VPN Burst	Concurrent	N/A	The Other VPN session amount for your model minus the sum of the sessions assigned to all contexts for Site-to-Site VPN.	The number of site-to-site VPN sessions allowed beyond the amount assigned to a context with Site-to-Site VPN. For example, if your model supports 5000 sessions, and you assign 4000 sessions across all contexts with Site-to-Site VPN, then the remaining 1000 sessions are available for Site-to-Site VPN Burst. Unlike Site-to-Site VPN, which guarantees the sessions to the context, Site-to-Site VPN Burst can be oversubscribed; the burst pool is available to all contexts on a first-come, first-served basis.

Table 5-1 **Resource Names and Limits (continued)**

Resource Name	Rate or Concurrent	Minimum and Maximum Number per Context	System Limit ¹	Description
Site-to-Site VPN	Concurrent	N/A	See the “Supported Feature Licenses Per Model” section on page 3-1 for the Other VPN sessions available for your model.	Site-to-site VPN sessions. You cannot oversubscribe this resource; all context assignments combined cannot exceed the model limit. The sessions you assign for this resource are guaranteed to the context.
SSH	Concurrent	1 minimum 5 maximum	100	SSH sessions.
Syslogs/sec	Rate	N/A	N/A	Syslog messages per second.
Telnet	Concurrent	1 minimum 5 maximum	100	Telnet sessions.
xlates ²	Concurrent	N/A	N/A	Network address translations.

1. If this column value is N/A, then you cannot set a percentage of the resource because there is no hard system limit for the resource.
2. Syslog messages are generated for whichever limit is lower xlates or conns. For example, if you set the xlates limit to 7 and the conns to 9, then the ASA only generates syslog message 321001 (“Resource 'xlates' limit of 7 reached for context 'ctx1'”) and not 321002 (“Resource 'conn rate' limit of 5 reached for context 'ctx1'”).

Detailed Steps

- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Context Management > Resource Class**, and click **Add**.
The Add Resource Class dialog box appears.

Step 3 In the Resource Class field, enter a class name up to 20 characters in length.

Step 4 In the Count Limited Resources area, set the concurrent limits for resources.

See the [Table 5-1 on page 5-18](#) for a description of each resource type.

For resources that do not have a system limit, you cannot set the percentage; you can only set an absolute value. If you do not set a limit, the limit is inherited from the default class. If the default class does not set a limit, then the resource is unlimited, or the system limit if available. For most resources, 0 sets the limit to unlimited. For VPN types, 0 sets the limit none.

Step 5 In the Rate Limited Resources area, set the rate limit for resources.

See the [Table 5-1 on page 5-18](#) for a description of each resource type.

If you do not set a limit, the limit is inherited from the default class. If the default class does not set a limit, then it is unlimited by default. 0 sets the limit to unlimited

Step 6 Click **OK**.

Configuring a Security Context

The security context definition in the system configuration identifies the context name, configuration file URL, interfaces that a context can use, and other settings.

Prerequisites

- Perform this procedure in the system execution space.
- For the ASASM, assign VLANs to the ASASM on the switch according to [Chapter 2, “Configuring the Switch for Use with the ASA Services Module.”](#)

- For the ASA 5500, configure physical interface parameters, VLAN subinterfaces, EtherChannels, and redundant interfaces according to [Chapter 10, “Starting Interface Configuration \(ASA 5510 and Higher\).”](#)


Detailed Steps

- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Context Management > Security Contexts**, and click **Add**. The Add Context dialog box appears.

The screenshot shows the 'Add Context' dialog box. It contains the following elements:

- Security Context:** A text input field.
- Interface Allocation:** A table with columns 'Interface', 'Aliased Name', and 'Visible'. To the right are 'Add', 'Edit', and 'Delete' buttons.
- IPS Sensor Allocation:** A table with columns 'Sensor Name' and 'Mapped Sensor Name'. To the right are 'Add' and 'Delete' buttons. Below the table is a 'Default Sensor' dropdown.
- Resource Assignment:** A 'Resource Class' dropdown (currently set to 'default') and 'Edit...' and 'New...' buttons.
- Config URL:** A dropdown menu and a 'Login...' button.
- Failover Group:** A dropdown menu (currently set to '-- None Available --').
- Firewall Mode:** A dropdown menu (currently set to 'Routed').
- ScanSafe:** An 'Enable' checkbox and a 'License' text field.
- Description:** A large text area.
- Buttons:** 'Help', 'Cancel', and 'OK' at the bottom.

- Step 3** In the Security Context field, enter the context name as a string up to 32 characters long. This name is case sensitive, so you can have two contexts named “customerA” and “CustomerA,” for example. “System” or “Null” (in upper or lower case letters) are reserved names, and cannot be used.
- Step 4** In the Interface Allocation area, click the **Add** button to assign an interface to the context.



- a. From the Interfaces > Physical Interface drop-down list, choose an interface.

You can assign the main interface, in which case you leave the subinterface ID blank, or you can assign a subinterface or a range of subinterfaces associated with this interface. In transparent firewall mode, only interfaces that have not been allocated to other contexts are shown. If the main interface was already assigned to another context, then you must choose a subinterface.

- b. (Optional) In the Interfaces > Subinterface Range (optional) drop-down list, choose a subinterface ID.

For a range of subinterface IDs, choose the ending ID in the second drop-down list, if available.

In transparent firewall mode, only subinterfaces that have not been allocated to other contexts are shown.

- a. (Optional) In the Aliased Names area, check **Use Aliased Name in Context** to set an aliased name for this interface to be used in the context configuration instead of the interface ID.

- In the Name field, sets the aliased name.

An aliased name must start with a letter, end with a letter, and have as interior characters only letters, digits, or an underscore. This field lets you specify a name that ends with a letter or underscore; to add an optional digit after the name, set the digit in the Range field.

- (Optional) In the Range field, set the numeric suffix for the aliased name.

If you have a range of subinterfaces, you can enter a range of digits to be appended to the name.

- b. (Optional) To enable context users to see physical interface properties even if you set an aliased name, check **Show Hardware Properties in Context**.

- c. Click **OK** to return to the Add Context dialog box.

Step 5 (Optional) If you use IPS virtual sensors, then assign a sensor to the context in the IPS Sensor Allocation area.

For detailed information about IPS and virtual sensors, see [Chapter 81, “Configuring the ASA IPS Module.”](#)

Step 6 (Optional) To assign this context to a resource class, choose a class name from the Resource Assignment > Resource Class drop-down list.

You can add or edit a resource class directly from this area. See the “[Configuring a Class for Resource Management](#)” section on page 5-17 for more information.

- Step 7** To set the context configuration location, identify the URL by choosing a file system type from the Config URL drop-down list and entering a path in the field.
- For example, the combined URL for FTP has the following format:
- ```
ftp://server.example.com/configs/admin.cfg
```
- a. (Optional) For external file systems, set the username and password by clicking **Login**.
- Step 8** (Optional) To set the failover group for Active/Active failover, choose the group name in the Failover Group drop-down list.
- Step 9** (Optional) To enable ScanSafe inspection in this context, click **Enable**. To override the license set in the system configuration, enter a license in the License field.
- Step 10** (Optional) Add a description in the Description field.
- Step 11** Click **OK** to return to the Security Contexts pane.

Configuration > Context Management > Security Contexts

Create, edit or delete security contexts.

| Context | Mode   | Interfaces                                                                            | Primary... | Seconda... | Resou... | Config...  | Group | Description |
|---------|--------|---------------------------------------------------------------------------------------|------------|------------|----------|------------|-------|-------------|
| admin   | Routed | Management0/0<br>Port-channel33                                                       |            |            | default  | disk0:/... |       |             |
| c10     | Routed |                                                                                       |            |            | default  | disk0:/... |       |             |
| c2      | Routed | GigabitEthernet0/1.2-6<br>Management0/0                                               |            |            | default  | disk0:/... |       |             |
| c3      | Routed | GigabitEthernet0/2.1<br>GigabitEthernet0/2.3<br>GigabitEthernet0/2.5<br>Management0/0 |            |            | default  | disk0:/... |       |             |
| c4      | Routed | GigabitEthernet0/2.2<br>GigabitEthernet0/2.4<br>GigabitEthernet0/2.6<br>Management0/0 |            |            | default  | disk0:/... |       |             |
| c5      | Routed |                                                                                       |            |            | default  | disk0:/... |       |             |
| c6      | Routed |                                                                                       |            |            | default  | disk0:/... |       |             |
| c7      | Routed |                                                                                       |            |            | default  | disk0:/... |       |             |

☐ Enable auto-generation of MAC addresses for context interfaces that share a system interface


☐ Specify Pref...

Maximum TLS Sessions

☐ Specify the maximum number of TLS Proxy sessions that the ASA needs to support. By default, ASA supports 300 sessions.

Maximum Number of Sessions:

- Step 12** (Optional) To set the firewall mode to transparent, select the context and click **Change Firewall Mode**. You see the following confirmation dialog box:



If this is a new context, there is no configuration to erase. Click **Change Mode** to change to transparent firewall mode.

If this is an existing context, then be sure to back up the configuration before you change the mode.

**Step 13** To customize auto-generation of MAC addresses, see the [“Automatically Assigning MAC Addresses to Context Interfaces”](#) section on page 5-24.

**Step 14** To specify the maximum TLS Proxy sessions for the device, check the **Specify the maximum number of TLS Proxy sessions that the ASA needs to support** check box. For more information about TLS proxy, see [Chapter 66, “Configuring the TLS Proxy for Encrypted Voice Inspection.”](#)

## Automatically Assigning MAC Addresses to Context Interfaces

This section describes how to configure auto-generation of MAC addresses.

The MAC address is used to classify packets within a context. See the [“Information About MAC Addresses”](#) section on page 5-11 for more information, especially if you are upgrading from an earlier ASA version. See also the [“Viewing Assigned MAC Addresses”](#) section on page 5-32.

### Guidelines

- When you configure a name for the interface in a context, the new MAC address is generated immediately. If you enable this feature after you configure context interfaces, then MAC addresses are generated for all interfaces immediately after you enable it. If you disable this feature, the MAC address for each interface reverts to the default MAC address. For example, subinterfaces of GigabitEthernet 0/1 revert to using the MAC address of GigabitEthernet 0/1.
- In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, you can manually set the MAC address for the interface within the context. See the [“Configuring the MAC Address and MTU”](#) section on page 17-13 to manually set the MAC address.

### Detailed Steps




- 
- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Context Management > Security Contexts**, and check **Mac-Address auto**. If you do not enter a prefix, then the ASA autogenerates the prefix based on the last two bytes of the interface (ASA 5500) or backplane (ASASM) MAC address.
- Step 3** (Optional) Check the **Prefix** check box, and in the field, enter a decimal value between 0 and 65535. This prefix is converted to a four-digit hexadecimal number, and used as part of the MAC address. See the [“MAC Address Format” section on page 5-12](#) section for more information about how the prefix is used.
- 

## Changing Between Contexts and the System Execution Space


If you log in to the system execution space (or the admin context), you can change between contexts and perform configuration and monitoring tasks within each context. The running configuration that you edit in a configuration mode depends on your location. When you are in the system execution space, the running configuration consists only of the system configuration; when you are in a context, the running configuration consists only of that context.

### Detailed Steps

- 
- Step 1** To configure the System, in the Device List pane, double-click **System** under the active device IP address.



- Step 2** To configure a context, in the Device List pane, double-click the context name under the active device IP address.



## Managing Security Contexts

This section describes how to manage security contexts and includes the following topics:

- [Removing a Security Context, page 5-26](#)
- [Changing the Admin Context, page 5-27](#)
- [Changing the Security Context URL, page 5-28](#)
- [Reloading a Security Context, page 5-29](#)

## Removing a Security Context

You cannot remove the current admin context.



### Note

If you use failover, there is a delay between when you remove the context on the active unit and when the context is removed on the standby unit.

### Prerequisites

Perform this procedure in the system execution space.

### Detailed Steps

- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Context Management > Security Contexts**.
- Step 3** Select the context you want to delete, and click **Delete**.  
The Delete Context dialog box appears.



**Step 4** If you might want to re-add this context later, and want to keep the configuration file for future use, uncheck the **Also delete config URL file from the disk** check box.

If you want to delete the configuration file, then leave the check box checked.

**Step 5** Click **Yes**.

## Changing the Admin Context

The system configuration does not include any network interfaces or network settings for itself; rather, when the system needs to access network resources (such as downloading the contexts from the server), it uses one of the contexts that is designated as the admin context.

The admin context is just like any other context, except that when a user logs in to the admin context, then that user has system administrator rights and can access the system and all other contexts. The admin context is not restricted in any way, and can be used as a regular context. However, because logging into the admin context grants you administrator privileges over all contexts, you might need to restrict access to the admin context to appropriate users.



### Note

For ASDM, you cannot change the admin context within ASDM because your ASDM session would disconnect. You can perform this procedure using the Command Line Interface tool noting that you will have to reconnect to the new admin context.

### Guidelines

You can set any context to be the admin context, as long as the configuration file is stored in the internal flash memory.

### Prerequisites


Perform this procedure in the system execution space.

### Detailed Steps

**Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.

**Step 2** Choose **Tools > Command Line Interface**.

The Command Line Interface dialog box appears.



**Step 3** Enter the following command:

```
admin-context context_name
```

**Step 4** Click **Send**.

Any remote management sessions, such as Telnet, SSH, or HTTPS (ASDM), that are connected to the admin context are terminated. You must reconnect to the new admin context.



**Note**

A few system configuration commands, including **ntp server**, identify an interface name that belongs to the admin context. If you change the admin context, and that interface name does not exist in the new admin context, be sure to update any system commands that refer to the interface.

## Changing the Security Context URL

This section describes how to change the context URL.

### Guidelines


- You cannot change the security context URL without reloading the configuration from the new URL. The ASA merges the new configuration with the current running configuration.
- Reentering the same URL also merges the saved configuration with the running configuration.
- A merge adds any new commands from the new configuration to the running configuration.
  - If the configurations are the same, no changes occur.
  - If commands conflict or if commands affect the running of the context, then the effect of the merge depends on the command. You might get errors, or you might have unexpected results. If the running configuration is blank (for example, if the server was unavailable and the configuration was never downloaded), then the new configuration is used.
- If you do not want to merge the configurations, you can clear the running configuration, which disrupts any communications through the context, and then reload the configuration from the new URL.

### Prerequisites

Perform this procedure in the system execution space.

## Detailed Steps

- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Context Management > Security Contexts**.
- Step 3** Select the context you want to edit, and click **Edit**.  
The Edit Context dialog box appears.



- Step 4** Enter a new URL in the Config URL field, and click **OK**.  
The system immediately loads the context so that it is running.

## Reloading a Security Context

You can reload the context in two ways:

- Clear the running configuration and then import the startup configuration.  
This action clears most attributes associated with the context, such as connections and NAT tables.
- Remove the context from the system configuration.  
This action clears additional attributes, such as memory allocation, which might be useful for troubleshooting. However, to add the context back to the system requires you to respecify the URL and interfaces.

This section includes the following topics:


- [Reloading by Clearing the Configuration, page 5-29](#)
- [Reloading by Removing and Re-adding the Context, page 5-30](#)

### Reloading by Clearing the Configuration


To reload the context by clearing the context configuration and reloading the configuration from the URL, perform the following steps.

#### Detailed Steps

- Step 1** In the Device List pane, double-click the context name under the active device IP address.
- Step 2** Choose **Tools > Command Line Interface**.  
The Command Line Interface dialog box appears.



- Step 3** Enter the following command:
- ```
clear configure all
```
- Step 4** Click **Send**.
- The context configuration is cleared.
- Step 5** Choose **Tools > Command Line Interface** again.
- The Command Line Interface dialog box appears.



- Step 6** Enter the following command:
- ```
copy startup-config running-config
```
- Step 7** Click **Send**.
- The ASA reloads the configuration. The ASA copies the configuration from the URL specified in the system configuration. You cannot change the URL from within a context.

## Reloading by Removing and Re-adding the Context

To reload the context by removing the context and then re-adding it, perform the steps in the following sections:

1. [“Removing a Security Context” section on page 5-26](#). Be sure to uncheck the **Also delete config URL file from the disk** check box.
2. [“Configuring a Security Context” section on page 5-20](#)

## Monitoring Security Contexts

This section describes how to view and monitor context information and includes the following topics:

- [Monitoring Context Resource Usage, page 5-31](#)
- [Viewing Assigned MAC Addresses, page 5-32](#)

## Monitoring Context Resource Usage

To monitor resource usage of all contexts from the system execution space, perform the following steps:

- 
- Step 1** If you are not already in the System mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Click the **Monitoring** button on the toolbar.
- Step 3** Click **Context Resource Usage**.

Click each resource type to view the resource usage for all contexts:

- **ASDM/Telnet/SSH**—Shows the usage of ASDM, Telnet, and SSH connections.
  - Context—Shows the name of each context.

For each access method, see the following usage statistics:

- Existing Connections (#)—Shows the number of existing connections.
  - Existing Connections (%)—Shows the connections used by this context as a percentage of the total number of connections used by all contexts.
  - Peak Connections (#)—Shows the peak number of connections since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.
- **Routes**—Shows the usage of dynamic routes.
    - Context—Shows the name of each context.
    - Existing Connections (#)—Shows the number of existing connections.
    - Existing Connections (%)—Shows the connections used by this context as a percentage of the total number of connections used by all contexts.
    - Peak Connections (#)—Shows the peak number of connections since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.
  - **Xlates**—Shows the usage of network address translations.
    - Context—Shows the name of each context.
    - Xlates (#)—Shows the number of current xlates.
    - Xlates (%)—Shows the xlates used by this context as a percentage of the total number of xlates used by all contexts.
    - Peak (#)—Shows the peak number of xlates since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.
  - **NATs**—Shows the number of NAT rules.
    - Context—Shows the name of each context.
    - NATs (#)—Shows the current number of NAT rules.
    - NATs (%)—Shows the NAT rules used by this context as a percentage of the total number of NAT rules used by all contexts.
    - Peak NATs (#)—Shows the peak number of NAT rules since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.

- **Syslogs**—Shows the rate of system log messages.
  - Context—Shows the name of each context.
  - Syslog Rate (#/sec)—Shows the current rate of system log messages.
  - Syslog Rate (%)—Shows the system log messages generated by this context as a percentage of the total number of system log messages generated by all contexts.
  - Peak Syslog Rate (#/sec)—Shows the peak rate of system log messages since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.
- **VPN**—Shows the usage of VPN site-to-site tunnels.
  - Context—Shows the name of each context.
  - VPN Connections—Shows usage of guaranteed VPN sessions.
  - VPN Burst Connections—Shows usage of burst VPN sessions.
  - Existing (#)—Shows the number of existing tunnels.
  - Peak (#)—Shows the peak number of tunnels since the statistics were last cleared, either using the **clear resource usage** command or because the device rebooted.

**Step 4** Click **Refresh** to refresh the view.

---

## Viewing Assigned MAC Addresses

You can view auto-generated MAC addresses within the system configuration or within the context. This section includes the following topics:

- [Viewing MAC Addresses in the System Configuration, page 5-32](#)
- [Viewing MAC Addresses Within a Context, page 5-33](#)

## Viewing MAC Addresses in the System Configuration

This section describes how to view MAC addresses in the system configuration.

### Guidelines

If you manually assign a MAC address to an interface, but also have auto-generation enabled, the auto-generated address continues to show in the configuration even though the manual MAC address is the one that is in use. If you later remove the manual MAC address, the auto-generated one shown will be used.

### Detailed Steps

- 
- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.



- Step 2** Choose **Configuration > Context Management > Security Contexts**, and view the Primary MAC and Secondary MAC columns.

## Viewing MAC Addresses Within a Context

This section describes how to view MAC addresses within a context.

### Detailed Steps

- Step 1** If you are not already in the System configuration mode, in the Device List pane, double-click **System** under the active device IP address.
- Step 2** Choose **Configuration > Interfaces**, and view the MAC Address address column.
- This table shows the MAC address in use; if you manually assign a MAC address and also have auto-generation enabled, then you can only view the unused auto-generated address from within the system configuration.

## Feature History for Multiple Context Mode

Table 5-2 lists each feature change and the platform release in which it was implemented. ASDM is backwards-compatible with multiple platform releases, so the specific ASDM release in which support was added is not listed.

**Table 5-2** Feature History for Multiple Context Mode

| Feature Name                     | Platform Releases | Feature Information                                                                                                                                                    |
|----------------------------------|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Multiple security contexts       | 7.0(1)            | Multiple context mode was introduced.<br>We introduced the following screens: Configuration > Context Management.                                                      |
| Automatic MAC address assignment | 7.2(1)            | Automatic assignment of MAC address to context interfaces was introduced.<br>We modified the following screen: Configuration > Context Management > Security Contexts. |
| Resource management              | 7.2(1)            | Resource management was introduced.<br>We introduced the following screen: Configuration > Context Management > Resource Management.                                   |

**Table 5-2** *Feature History for Multiple Context Mode (continued)*

| Feature Name                                         | Platform Releases | Feature Information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Virtual sensors for IPS                              | 8.0(2)            | <p>The AIP SSM running IPS software Version 6.0 and above can run multiple virtual sensors, which means you can configure multiple security policies on the AIP SSM. You can assign each context or single mode ASA to one or more virtual sensors, or you can assign multiple security contexts to the same virtual sensor.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Security Contexts.</p>                                                                                             |
| Automatic MAC address assignment enhancements        | 8.0(5)/8.2(2)     | <p>The MAC address format was changed to use a prefix, to use a fixed starting value (A2), and to use a different scheme for the primary and secondary unit MAC addresses in a failover pair. The MAC addresses are also now persistent across reloads. The command parser now checks if auto-generation is enabled; if you want to also manually assign a MAC address, you cannot start the manual MAC address with A2.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Security Contexts.</p> |
| Maximum contexts increased for the ASA 5550 and 5580 | 8.4(1)            | <p>The maximum security contexts for the ASA 5550 was increased from 50 to 100. The maximum for the ASA 5580 was increased from 50 to 250.</p>                                                                                                                                                                                                                                                                                                                                                                                      |
| Automatic MAC address assignment enabled by default  | 8.5(1)            | <p>Automatic MAC address assignment is now enabled by default.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Security Contexts.</p>                                                                                                                                                                                                                                                                                                                                                           |

Table 5-2 Feature History for Multiple Context Mode (continued)

| Feature Name                                   | Platform Releases | Feature Information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Automatic generation of a MAC address prefix   | 8.6(1)            | <p>In multiple context mode, the ASA now converts the automatic MAC address generation configuration to use a default prefix. The ASA auto-generates the prefix based on the last two bytes of the interface (ASA 5500) or backplane (ASASM) MAC address. This conversion happens automatically when you reload, or if you reenables MAC address generation. The prefix method of generation provides many benefits, including a better guarantee of unique MAC addresses on a segment. If you want to change the prefix, you can reconfigure the feature with a custom prefix. The legacy method of MAC address generation is no longer available.</p> <p><b>Note</b> To maintain hitless upgrade for failover pairs, the ASA does <i>not</i> convert the MAC address method in an existing configuration upon a reload if failover is enabled. However, we strongly recommend that you manually change to the prefix method of generation when using failover, especially for the ASASM. Without the prefix method, ASASMs installed in different slot numbers experience a MAC address change upon failover, and can experience traffic interruption. After upgrading, to use the prefix method of MAC address generation, reenables MAC address generation to use the default prefix.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Security Contexts</p> |
| Dynamic routing in Security Contexts           | 9.0(1)            | EIGRP and OSPFv2 dynamic routing protocols are now supported in multiple context mode. OSPFv3, RIP, and multicast routing are not supported.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| New resource type for routing table entries    | 9.0(1)            | <p>A new resource type, routes, was created to set the maximum number of routing table entries in each context.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Resource Class &gt; Add Resource Class</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Site-to-Site VPN in multiple context mode      | 9.0(1)            | Site-to-site VPN tunnels are now supported in multiple context mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| New resource type for site-to-site VPN tunnels | 9.0(1)            | <p>New resource types, vpn other and vpn burst other, were created to set the maximum number of site-to-site VPN tunnels in each context.</p> <p>We modified the following screen: Configuration &gt; Context Management &gt; Resource Class &gt; Add Resource Class</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

