



Cisco SFS 7000 Series Product Family Command Reference Guide

Release 2.7.0

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Customer Order Number:
Text Part Number: OL-9163-02



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0601R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco SFS 7000 Series Product Family Command Reference Guide
© 2006 Cisco Systems, Inc. All rights reserved.



Preface **xi**

Audience	xi
Organization	xi
Conventions	xii
Related Documentation	xiii
Obtaining Documentation	xiii
Cisco.com	xiii
Product Documentation DVD	xiii
Ordering Documentation	xiv
Documentation Feedback	xiv
Cisco Product Security Overview	xiv
Reporting Security Problems in Cisco Products	xv
Obtaining Technical Assistance	xv
Cisco Technical Support & Documentation Website	xvi
Submitting a Service Request	xvi
Definitions of Service Request Severity	xvi
Obtaining Additional Publications and Information	xvii

CHAPTER 1

Using the CLI **1-1**

Setting up the Switch	1-1
Starting A CLI Session	1-2
Logging In	1-3
Authentication	1-3
Customizing the Login Prompt	1-4
Entering CLI Modes	1-4
Using User Execute Mode	1-5
Using Privileged Execute Mode	1-5
Using Global Configuration Mode	1-5
Exiting CLI Modes	1-6
Quick Help	1-6
Command Abbreviation	1-7
Editing the CLI	1-7
Exiting the CLI Session	1-8

Specifying Modules and Ports	1-9
Slot#/Port# Pairs	1-9
Ranges	1-9
Lists	1-9
The “all” Keyword	1-10
Using the Documentation	1-10
Synopsis	1-10
Syntax	1-10
Platform Availability	1-10
Command Modes	1-11
Privilege Level	1-11
Usage Guidelines	1-11
Examples	1-11
Defaults	1-11
Related Commands	1-11

CHAPTER 2
Administrative Commands 2-1

action	2-3
addr-option	2-5
authentication	2-6
auto-negotiate	2-8
boot-config	2-10
broadcast	2-11
card	2-12
cdp advertise-v2	2-13
cdp holdtime	2-15
cdp run	2-16
cdp timer	2-18
clear cdp counters	2-19
clear cdp table	2-20
clock set	2-21
config TACACS-server host	2-22
configure terminal	2-24
copy	2-26
delete	2-29
dir	2-31
disable	2-33

enable	2-34
exec	2-35
exit	2-36
ftp-server enable	2-37
gateway	2-38
help	2-39
history	2-40
hostname	2-41
install	2-42
ip http	2-44
link-trap	2-46
location	2-47
logging	2-48
login	2-49
logout	2-50
more	2-51
mtu	2-53
name	2-54
ntp	2-55
ping	2-56
power-supply	2-57
radius-server	2-58
reload	2-60
save-log	2-62
shutdown	2-63
snmp-server	2-66
speed	2-69
system-mode	2-71
system ib-counter-reset	2-72
telnet	2-73
terminal	2-74
trace	2-76
type	2-78
username	2-80
who	2-83

write 2-84

CHAPTER 3

Fibre Channel Commands 3-1

fc srp initiator 3-2
 fc srp initiator-wwpn 3-5
 fc srp it 3-7
 fc srp itl 3-9
 fc srp lu 3-13
 fc srp target 3-17
 fc srp-global gateway-portmask-policy restricted 3-18
 fc srp-global itl 3-19
 fc srp-global lun-policy restricted 3-23

CHAPTER 4

InfiniBand Commands 4-1

ib sm db-sync 4-2
 ib pm 4-4
 ib sm 4-8
 ib sm multicast 4-12
 ib-agent 4-14

CHAPTER 5

IP Commands 5-1

arp ethernet 5-2
 bridge-group 5-3
 distribution-type 5-5
 half-duplex 5-7
 ip 5-8
 redundancy-group 5-11
 trunk-group 5-12

CHAPTER 6

Show Commands 6-1

show arp ethernet 6-4
 show authentication 6-6
 show backplane 6-8
 show boot-config 6-10
 show bridge-forwarding 6-12
 show bridge-group 6-14

show bridge-subnets	6-16
show card	6-17
show card-inventory	6-22
show cdp	6-25
show cdp entry	6-27
show cdp neighbors	6-28
show clock	6-29
show config	6-30
show diagnostic	6-32
show diagnostic card	6-33
show diagnostic chassis	6-35
show diagnostic fan	6-36
show diagnostic fru-error	6-38
show diagnostic interface ethernet	6-40
show diagnostic interface fc	6-42
show diagnostic interface ib	6-44
show diagnostic post	6-46
show diagnostic power-supply	6-48
show diagnostic rack-locator	6-50
show fan	6-52
show fc srp initiator	6-54
show fc srp initiator-wwpn-view	6-57
show fc srp it	6-59
show fc srp itl	6-61
show fc srp itl-statistics	6-64
show fc srp lu	6-66
show fc srp statistics	6-69
show fc srp target	6-71
show fc srp-global	6-73
show host	6-74
show ib dm ioc	6-76
show ib dm iou	6-79
show ib pm config	6-81
show ib pm connection counter	6-83
show ib pm connection monitor	6-86

show ib pm port counter config	6-88
show ib pm port counter	6-89
show ib pm port monitor	6-91
show ib pm threshold	6-94
show ib sm configuration	6-96
show ib sm db-sync	6-99
show ib sm lft	6-101
show ib sm mft	6-103
show ib sm sm-info	6-105
show ib sm multicast	6-106
show ib sm neighbor	6-108
show ib sm node	6-110
show ib sm partition	6-113
show ib sm port	6-115
show ib sm service	6-122
show ib sm subscription	6-125
show ib sm switch	6-127
show ib sm switch-elem-route	6-130
show ib sm switch-route	6-132
show ib-agent channel-adapter	6-134
show ib-agent summary	6-136
show ib-agent switch	6-138
show interface ethernet	6-148
show interface fc	6-156
show interface gateway	6-162
show interface ib	6-167
show interface mgmt-ethernet	6-177
show interface mgmt-ib	6-179
show interface mgmt-serial	6-180
show inventory	6-181
show ip	6-183
show ip http	6-185
show ip http server secure	6-187
show location	6-189
show logging	6-190

[show ntp](#) 6-192
[show power-supply](#) 6-193
[show redundancy-group](#) 6-195
[show running-status](#) 6-197
[show sensor](#) 6-199
[show snmp](#) 6-201
[show system](#) 6-203
[show system-mode](#) 6-204
[show system-services](#) 6-205
[show terminal](#) 6-207
[show trace](#) 6-208
[show trunk](#) 6-209
[show user](#) 6-210
[show version](#) 6-212

CHAPTER 7
Diagnostic Commands 215

[Running Diagnostic Tests](#) 215
[diagnostic](#) 217
[data-pattern](#) 219
[data-size](#) 220
[iterations](#) 221
[source-wwpn](#) 222
[start](#) 223
[stop](#) 224
[target-wwpn](#) 225
[test](#) 226
[validate](#) 227

INDEX



Preface

This document is a guide to the Server Switch OS Command Line Interface, or CLI. This document explains how to use the Server Switch OS CLI and provides a categorized, alphabetical list of all available CLI commands.

Audience

Cisco provides this document for administrators who install, configure, and manage Cisco equipment. This document assumes that administrators have prior Ethernet, Fibre Channel, and network administration experience.

Organization

This publication is organized as follows:

Chapter	Title	Description
Chapter 1	Using the CLI	Describes CLI fundamentals.
Chapter 2	Administrative Commands	Describes administration commands used to configure your device.
Chapter 3	Fibre Channel Commands	Lists the Fibre Channel configuration commands.
Chapter 4	InfiniBand Commands	Lists the InfiniBand configuration commands.
Chapter 5	IP Commands	Lists the IP configuration commands.
Chapter 6	Show Commands	Lists the Show commands used to display information about the configuration.

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands, command options, and keywords are in boldface . Bold text indicates Chassis Manager elements or text that you must enter as it appears.
<i>italic font</i>	Arguments in commands for which you supply values are in <i>italics</i> . Italic font that is not used in commands indicates emphasis.
Menu1 > Menu2 > Item...	Series indicate a pop-up menu sequence to open a form or execute a desired function.
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars. Braces can also be used to group keywords and/or arguments; for example, { interface <i>interface</i> type }.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string because the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments for which you supply values are in <i>italic screen font</i> .
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Notes use the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Cautions use the following conventions:

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

- For additional information about Cisco SFS 7000P series switches, refer to the following:
 - *Release Notes for Cisco SFS 7000P Series Switch Software Release 2.5.0*
 - *Cisco SFS 7000 Series Product Family Element Manager User Guide*
 - *Cisco SFS 7000 Series Product Family Chassis Manager User Guide*
- For detailed hardware configuration and maintenance procedures, see these hardware guides:
 - *Cisco SFS 7000P Switch Installation and Configuration Note*
 - *Cisco SFS 7008P Switch Installation and Configuration Note*
 - *Cisco SFS 7000P Hardware Installation Guide*
 - *Cisco SFS 7008P Hardware Installation Guide*

Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

Cisco.com

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/techsupport>

You can access the Cisco website at this URL:

<http://www.cisco.com>

You can access international Cisco websites at this URL:

http://www.cisco.com/public/countries_languages.shtml

Product Documentation DVD

The Product Documentation DVD is a comprehensive library of technical product documentation on a portable medium. The DVD enables you to access multiple versions of installation, configuration, and command guides for Cisco hardware and software products. With the DVD, you have access to the same HTML documentation that is found on the Cisco website without being connected to the Internet. Certain products also have PDF versions of the documentation available.

The Product Documentation DVD is available as a single unit or as a subscription. Registered Cisco.com users (Cisco direct customers) can order a Product Documentation DVD (product number DOC-DOCDVD= or DOC-DOCDVD=SUB) from Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

Ordering Documentation

Registered Cisco.com users may order Cisco documentation at the Product Documentation Store in the Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

Nonregistered Cisco.com users can order technical documentation from 8:00 a.m. to 5:00 p.m. (0800 to 1700) PDT by calling 1 866 463-3487 in the United States and Canada, or elsewhere by calling 011 408 519-5055. You can also order documentation by e-mail at tech-doc-store-mkpl@external.cisco.com or by fax at 1 408 519-5001 in the United States and Canada, or elsewhere at 011 408 519-5001.

Documentation Feedback

You can rate and provide feedback about Cisco technical documents by completing the online feedback form that appears with the technical documents on Cisco.com.

You can submit comments about Cisco documentation by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Customer Document Ordering
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Cisco Product Security Overview

Cisco provides a free online Security Vulnerability Policy portal at this URL:

http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html

From this site, you will find information about how to:

- Report security vulnerabilities in Cisco products.
- Obtain assistance with security incidents that involve Cisco products.
- Register to receive security information from Cisco.

A current list of security advisories, security notices, and security responses for Cisco products is available at this URL:

<http://www.cisco.com/go/psirt>

To see security advisories, security notices, and security responses as they are updated in real time, you can subscribe to the Product Security Incident Response Team Really Simple Syndication (PSIRT RSS) feed. Information about how to subscribe to the PSIRT RSS feed is found at this URL:

http://www.cisco.com/en/US/products/products_psirt_rss_feed.html

Reporting Security Problems in Cisco Products

Cisco is committed to delivering secure products. We test our products internally before we release them, and we strive to correct all vulnerabilities quickly. If you think that you have identified a vulnerability in a Cisco product, contact PSIRT:

- For Emergencies only—security-alert@cisco.com

An emergency is either a condition in which a system is under active attack or a condition for which a severe and urgent security vulnerability should be reported. All other conditions are considered non-emergencies.

- For Non-emergencies—psirt@cisco.com

In an emergency, you can also reach PSIRT by telephone:

- 1 877 228-7302
- 1 408 525-6532



We encourage you to use Pretty Good Privacy (PGP) or a compatible product (for example, GnuPG) to encrypt any sensitive information that you send to Cisco. PSIRT can work with information that has been encrypted with PGP versions 2.x through 9.x.

Never use a revoked or an expired encryption key. The correct public key to use in your correspondence with PSIRT is the one linked in the Contact Summary section of the Security Vulnerability Policy page at this URL:

http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html

The link on this page has the current PGP key ID in use.

If you do not have or use PGP, contact PSIRT at the aforementioned e-mail addresses or phone numbers before sending any sensitive material to find other means of encrypting the data.

Obtaining Technical Assistance

Cisco Technical Support provides 24-hour-a-day award-winning technical assistance. The Cisco Technical Support & Documentation website on Cisco.com features extensive online support resources. In addition, if you have a valid Cisco service contract, Cisco Technical Assistance Center (TAC) engineers provide telephone support. If you do not have a valid Cisco service contract, contact your reseller.

Cisco Technical Support & Documentation Website

The Cisco Technical Support & Documentation website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The web site is available 24 hours a day, at this URL:

<http://www.cisco.com/techsupport>

Access to all tools on the Cisco Technical Support & Documentation web site requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register at this URL:

<http://tools.cisco.com/RPF/register/register.do>



Use the Cisco Product Identification (CPI) tool to locate your product serial number before submitting a web or phone request for service. You can access the CPI tool from the Cisco Technical Support & Documentation web site by clicking the **Tools & Resources** link under Documentation & Tools. Choose **Cisco Product Identification Tool** from the Alphabetical Index drop-down list, or click the **Cisco Product Identification Tool** link under Alerts & RMAs. The CPI tool offers three search options: by product ID or model name; by tree view; or for certain products, by copying and pasting **show** command output. Search results show an illustration of your product with the serial number label location highlighted. Locate the serial number label on your product and record the information before placing a service call.

Submitting a Service Request

Using the online TAC Service Request Tool is the fastest way to open S3 and S4 service requests. (S3 and S4 service requests are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Service Request Tool provides recommended solutions. If your issue is not resolved using the recommended resources, your service request is assigned to a Cisco engineer. The TAC Service Request Tool is located at this URL:

<http://www.cisco.com/techsupport/servicerequest>

For S1 or S2 service requests, or if you do not have Internet access, contact the Cisco TAC by telephone. (S1 or S2 service requests are those in which your production network is down or severely degraded.) Cisco engineers are assigned immediately to S1 and S2 service requests to help keep your business operations running smoothly.

To open a service request by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553-2447

For a complete list of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/techsupport/contacts>

Definitions of Service Request Severity

To ensure that all service requests are reported in a standard format, Cisco has established severity definitions.

Severity 1 (S1)—An existing network is down, or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Severity 2 (S2)—Operation of an existing network is severely degraded, or significant aspects of your business operations are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

Severity 3 (S3)—Operational performance of the network is impaired, while most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

Severity 4 (S4)—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- The *Cisco Product Quick Reference Guide* is a handy, compact reference tool that includes brief product overviews, key features, sample part numbers, and abbreviated technical specifications for many Cisco products that are sold through channel partners. It is updated twice a year and includes the latest Cisco offerings. To order and find out more about the Cisco Product Quick Reference Guide, go to this URL:

<http://www.cisco.com/go/guide>

- Cisco Marketplace provides a variety of Cisco books, reference guides, documentation, and logo merchandise. Visit Cisco Marketplace, the company store, at this URL:

<http://www.cisco.com/go/marketplace/>

- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco Systems technical user magazine for maximizing Internet and networking investments. Each quarter, Packet delivers coverage of the latest industry trends, technology breakthroughs, and Cisco products and solutions, as well as network deployment and troubleshooting tips, configuration examples, customer case studies, certification and training information, and links to scores of in-depth online resources. You can access Packet magazine at this URL:

<http://www.cisco.com/packet>

- *iQ Magazine* is the quarterly publication from Cisco Systems designed to help growing companies learn how they can use technology to increase revenue, streamline their business, and expand services. The publication identifies the challenges facing these companies and the technologies to help solve them, using real-world case studies and business strategies to help readers make sound technology investment decisions. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

or view the digital edition at this URL:

<http://ciscoiq.texterity.com/ciscoiq/sample/>

- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:

<http://www.cisco.com/ipj>

- Networking products offered by Cisco Systems, as well as customer support services, can be obtained at this URL:

<http://www.cisco.com/en/US/products/index.html>

- Networking Professionals Connection is an interactive web site for networking professionals to share questions, suggestions, and information about networking products and technologies with Cisco experts and other networking professionals. Join a discussion at this URL:

<http://www.cisco.com/discuss/networking>

- World-class networking training is available from Cisco. You can view current offerings at this URL:

<http://www.cisco.com/en/US/learning/index.html>



Using the CLI

This chapter provides a general overview of the Cisco Server Switch command line interface (CLI). It describes how to start a CLI session, how to enter commands, and how to view online help. Details about individual commands appear later in this document.

The following sections appear in this chapter:

- [Setting up the Switch, page 1-1](#)
- [Starting A CLI Session, page 1-2](#)
- [Entering CLI Modes, page 1-4](#)
- [Exiting CLI Modes, page 1-6](#)
- [Quick Help, page 1-6](#)
- [Editing the CLI, page 1-7](#)
- [Exiting the CLI Session, page 1-8](#)
- [Specifying Modules and Ports, page 1-9](#)
- [Using the Documentation, page 1-10](#)

Setting up the Switch

The first time that you access your Server Switch, you must connect a management station, such as a PC or Linux terminal, to the Serial Console port on your Server Switch. After you establish this connection, you can configure the management ports on your Server Switch so that you can perform configuration tasks with a telnet session, Element Manager, or Chassis Manager.



Note

SFS Server Switch product configurations with TopspinOS release 2.3.x and higher use a 128-bit MD5-based hashing scheme to store passwords.

To configure a Server Switch through the Serial Console port, perform the following steps:

-
- Step 1** Connect a PC or terminal to the Serial Console port. For detailed instructions, see the appropriate hardware guide for your Server Switch model.
- Step 2** Open a terminal emulation program (such as HyperTerminal for Windows), and configure session parameters as follows:
- Baud: 9600 b/s
 - Data Bits: 8
 - Parity: None
 - Stop Bits: 1
 - Flow control: None
- Step 3** Attach both power plugs to the Server Switch chassis to power up the Server Switch. The CLI login prompt appears on the management station terminal.
-

Starting A CLI Session

The CLI login prompt automatically appears in a terminal window when you connect the serial port of a computer to the Serial Console port. It also appears when you launch a telnet session to an Ethernet Management port. The user account that you use to log in determines your level of access. By default, you can log in as “super,” “admin,” or “guest.” [Table 1-1](#) lists and describes user login privileges.

Table 1-1 *Privilege Levels*

User Log-in	Privileges
super	The super user has unrestricted privileges. Use this account for initial configuration. This user may view and modify a configuration, as well as administer user accounts and access privileges. This user configures the console and management ports for initial Server Switch setup. This login uses "super" as the default password.
admin	The admin user has general read-write privileges. This user may view and modify the current configuration. However, the admin user can change only its own user information, such as the admin password. This login uses “admin” as the default password.
guest	The guest user has read-only privileges. This user may only view the current configuration. The guest user cannot make any changes during the CLI session. When you first bring up your Server Switch, you must enable this login. (See the “username” section on page 2-80). This login uses “guest” as the default password.

In addition to the default user accounts described above, there are administrative *roles* that may be assigned to individual user accounts. Roles allow granular levels of privileges. For example, you can create separate FibreChannel, Ethernet, or InfiniBand administrators, who only need access to specific subsystems. The Server Switch combines multiple roles with read and read-write access for flexible control.

**Note**

If a user does not have access to particular functionality, that functionality will not appear in the CLI, on-line help, or any GUI management windows.

The unrestricted (super) administrator assigns these roles. [Table 1-2](#) lists and describes these access levels.

Table 1-2 Access Levels

Role	Description
ib-ro	InfiniBand read-only access.
ib-rw	InfiniBand read-write access.
ip-ethernet-ro	Ethernet read-only access.
ip-ethernet-rw	Ethernet read-write access.
fc-ro	FibreChannel read-only access.
fc-rw	FibreChannel read-write access.
unrestricted-rw	Read-write access to all network configuration commands.

To configure accounts, see the **username** command in the [“username” section on page 2-80](#).

Logging In

At the CLI prompt, enter the appropriate username and password to log in as the super user.

```
Login: super
Password: xxxxx
SFS-7000P>
```

You are now logged in as an administrator and can view and configure the CLI configuration.

**Note**

Server Switches support up to three concurrent CLI sessions.

Authentication

You can use any of the authentication methods shown in [Table 1-3](#).

Table 1-3 Authentication Methods for Logging In

Authentication	How it Works
local	Verifies against the chassis database.
local and then RADIUS	Verifies against the chassis database then checks the RADIUS server.
RADIUS and then local	Checks the RADIUS server and then verifies against the chassis database.

Authentication	How it Works
local and then TACAS	Verifies against the chassis database then checks the TACAS client.
TACAS and then local	Checks the TACAS client and then verifies against the chassis database.

When local authentication is in effect and a user logs in, the user must be configured as a CLI user. The login username and password are verified against the local CLI user database. If a match is found, the login succeeds, and the user is assigned a pre-configured privilege level.

When TACACS+ authentication is in effect, the login username and password are passed to the TACACS+ server for verification. The TACACS+ server verifies the login username and password, and it sends back a reply. No TACACS+ user information is stored locally. The **show user all** command shows local users only.

The **config TACACS-server host** command (see [config TACACS-server host, page 2-22](#)) configures the IP address of TACACS+ servers. There can be three TACACS+ servers configured. The first server is queried, the second server is queried if the first server is not reachable, and the third server is queried if the both of the other servers are not reachable.

Cisco supports only TACACS+ authentication; therefore, no privilege level is verified against the TACACS+ server. All users authenticated by the TACACS+ server are given unrestricted rights. If a TACACS+ user makes changes to system configuration, the log will include the TACACS+ username and the config information, just as it does for a local user.

Like RADIUS users, the TACACS+ users do not have associating SNMP community strings. There are no SNMP logins for TACACS+ users.

**Note**

The following are limitations to TACACS+ authentication:

- TACACS+ authorization and accounting are not supported.
- TACACS+ single-connection not supported. Each login authentication makes its own connection to the TACACS+ server.
- TACACS+ user privilege level is always unrestricted.

Customizing the Login Prompt

The CLI checks the file **login-banner** for customized text to include in the prompt. Use the copy command to place a file named **login-banner** in the config directory of the switch. You can do this with FTP:

```
copy ftp://user:xxx.x.x.x/my-banner config:login-banner
```

Entering CLI Modes

The CLI uses the following three command modes:

- User Execute mode
- Privileged Execute mode
- Global Configuration mode

**Note**

Global Configuration mode includes a number of submodes.

The commands that you can execute depend upon the current command mode and your user login. You may enter a question mark (?) at the CLI prompt to list the commands available to the current user identity in the current mode.

Using User Execute Mode

All CLI sessions begin in *User Execute* mode. This mode provides commands for viewing some of the system configuration and some user information. Guest users may only work in User Exec mode. From User Exec mode, authorized users can access Privileged Execute mode.

Using Privileged Execute Mode

When you enter the **enable** command in User Execute mode, you enter *Privileged Execute* mode. From Privileged Exec mode, you can view the entire system configuration and all user information. From this mode, you can perform certain high-level administrative tasks, such as save the current configuration and set the system clock. You can also access Global Configuration mode. You must enter Privileged Execute mode before you can enter Global Configuration mode. Only administrative and unrestricted users may enter Privileged Exec mode.

```
# telnet SFS-7000P
Login: super
Password: xxxx
SFS-7000P> enable
SFS-7000P#
```

Mode changes are reflected in changes to the CLI prompt. When you transition from User Exec mode to Privileged Exec mode, the prompt changes from SFS-7000P> to SFS-7000P#.

Using Global Configuration Mode

You enter Global Configuration mode from Privileged Exec mode. Global Configuration (config) mode configures system-level attributes, such as SNMP, SNMP agents, and networks. To enter config mode, enter either the **configure terminal** or the **configure** command in Privileged Exec mode.

```
SFS-7000P# configure terminal
SFS-7000P(config)#
```

When you transition from Privileged Execute to Global Configuration mode, the prompt changes from SFS-7000P# to SFS-7000P(config)#.

To configure particular elements of the Server Switch, you must enter a configuration submode specific to that element. All Ethernet, FibreChannel, and InfiniBand configuration occurs in submodes. In submodes, you can assign IP addresses to interface gateway ports, set connection speeds, set connection types, and so on.

To enter the Ethernet Interface Configuration (config-if-ether) submode from Global Configuration mode, enter the **interface** command, specify the interface type, and specify the port(s) to configure.

```
SFS-7000P(config)# interface ethernet 4/1-4/4
SFS-7000P(config-if-ether-4/1-4/4)#
```

The commands that you enter in a configuration submode apply to the specified modules and ports. The Ethernet Management port, however, does not require you to specify a port number because there is only one active Ethernet Management port during a system session.

```
SFS-7000P(config)# interface mgmt-ethernet
SFS-7000P(config-if-mgmt-ethernet)#
```

Exiting CLI Modes

Most commands are mode-dependent. For example, you can configure clock settings in Global Configuration mode only. To configure the system, you must enter and exit CLI modes. The **exit** command returns you to the previous mode.

```
SFS-90(config-if-fc-5/1)# exit
SFS-90(config)# exit
SFS-90#
```



Note

If you enter the **exit** command in User Exec mode or Privileged Exec mode, your telnet session ends.

You may also enter the **exit** command with the **all** keyword to return to User Exec mode in one step.

```
SFS-90(config-if-fc-5/1)# exit all
SFS-90>
```

To return to User Exec mode from Privileged Exec mode, enter the **disable** command.

```
SFS-90# disable
SFS-90>
```

Quick Help

You can enter the question mark (?) at the CLI prompt to display one of three types of user information.

Step 1

Enter a question mark (?) at the CLI prompt at any time to display the commands that you can enter. Only those commands that are appropriate to the current mode and user login appear.

```
SFS-7000P> ?
Exec Commands:
broadcast      - Write message to all users logged in
enable        - Turn on privileged commands
exit           - Exit current mode
help           - Show command help
history        - Show command history
login          - Login as a different user
logout         - Logout of this system
ping           - Send echo messages
show           - Show running system information
terminal       - Set terminal line parameters
who            - Display users currently logged in
write          - Write text to another user
```


- Step 2** Enter part of a command string, and end it with a question mark (?) to display options that you can use to complete the string.

```
SFS-7000P> b?
broadcast
```

- Step 3** Enter a command (or enough of a command for the CLI to uniquely identify it), and then enter a space and a question mark (?) to display available arguments to follow the command.

```
SFS-7000P> broadcast ?
String                - Message to broadcast. Enclose multi-word strings within
                        double-quotes.
```

```
SFS-7000P> broadcast
```

After the CLI displays the help information, the Server Switch prints the command string up to the question mark on the input line and waits for you to complete the string. You do not have to retype the string.

Command Abbreviation

To facilitate command entry, you do not need to enter CLI commands in their entirety. You may enter just enough of each command or argument to make it uniquely identifiable.

When enough characters have been entered to uniquely identify a command or keyword in a command string, you may leave the partially-typed command or keyword, enter a space, and then add additional keywords or arguments, or you can press the **Tab** key to complete the commands or keywords to improve readability.

```
SFS-7000P(config)# fc ?
srp                    - Configure FC SRP
srp-global             - Configure FC SRP-global parameters
SFS-7000P(config)# fc srp- ?
enable                - Enable FC SRP
gateway-portmask-pol  - Configure FC SRP-global gateway-portmask-policy
itl                   - Configure FC SRP-global ITL
lun-policy             - Configure FC SRP-global lun-policy
target-portmask-poli  - Configure FC SRP-global target portmask policy
SFS-7000P(config)# fc srp- gate ?
restricted            - Configure FC SRP gateway-portmask-policy restricted
SFS-7000P(config)# fc srp- gate res ?
<cr>
SFS-7000P(config)# fc srp- gate res
```

In the preceding example, **srp-** is short for **srp-global**, **gate** is short for **gateway-portmask-policy**, and **res** is short for **restricted**.

Editing the CLI

Command-line editing lets you modify a command line command that you have just entered or a command line that you entered previously in the CLI session. The CLI supports a variety of ways to move about and edit the currently displayed command line. [Table 1-4](#) lists and describes these options.

Table 1-4 **Key Stroke Shortcuts**

Key Strokes	Description
Ctrl-a	Moves the cursor to the beginning of the line.
Ctrl-b	Moves the cursor left (back) one character.
Ctrl-d	Deletes the current character.
Ctrl-e	Moves the cursor to the end of the line.
Ctrl-f	Moves the cursor to the right (forward) one character.
Ctrl-k	Deletes text from cursor to the end of the line.
Ctrl-l	Refreshes the input line.
Ctrl-n	Displays the next command in the history queue.
Ctrl-p	Displays the previous command in the history queue.
Ctrl-q	Returns to User Exec mode. Note If a command is entered on the command line, execute the command before returning to User Execute mode.
Ctrl-t	Transposes the current and previous characters.
Ctrl-u	Deletes all text to the left of the cursor.
Ctrl-w	Deletes the text of a word up to cursor.
Ctrl-z	Returns you to Privileged Exec mode.
Esc-b	Moves the cursor left (back) one word.
Esc-c	Converts characters, from the cursor to the end of the word, to upper case.
Esc-d	Deletes characters from the cursor through remainder of the word.
Esc-f	Moves the cursor right (forward) one word.
Esc-l	Converts characters, from the cursor to the end of the word, to lower case.
down-arrow	Displays the next command in the history queue.
up-arrow	Displays the previous command in the history queue.
left-arrow	Moves the cursor left (back) one character.
right-arrow	Moves the cursor right (forward) one character.

Exiting the CLI Session

To exit the CLI session, return to User Exec mode or Privileged Exec mode, and enter the **logout** command or the **exit** command. The CLI session ends.

```
SFS-90(config-if-fc-5/1)# exit all
SFS-90> logout
Login:
```



Note

If you use Telnet or SSH to run a remote CLI session, the connection closes when you log out. Conversely, when you terminate a telnet or SSH session, you log out of the Server Switch.

Specifying Modules and Ports

To configure one or more ports on one or more modules, specify the ports when you enter the configuration submode. Many CLI commands allow you to enter the following:

- A slot#/port# pair.
- A range of pairs.
- A list of pairs.
- The **all** keyword.

Slot#/Port# Pairs

A slot#/port# pair (sometimes referred to as the card#/port# pair) is a slash-separated (/) pair of numbers. The first number indicates the slot in which the interface module resides, and the second number represents a port on that module. See your hardware documentation to identify slot numbers and port numbers.

**Note**

With hardware platforms with no removable modules, such as the Cisco 4x InfiniBand Switch Module for IBM BladeCenter, or the Cisco SFS 7000, the slot number defaults to 1.

Ranges

A range is a dash-separated (-) set of two slot#/port# pairs. A range may span multiple modules of the same interface type. Module and port numbers in a range must both appear in ascending order. That is, specify the lower module and port number in the first slot#/port# pair and the higher module and port number in the second slot#/port# pair.

**Note**

Do not insert spaces between elements in the range.

The range 3/2-4/3 indicates all ports starting with module 3, port 2, up to and including module 4, and port 3. (This example assumes that modules 3 and 4 are of the same interface type.)

Lists

A list is a comma-separated (,) series of slot#/port# pairs and/or ranges. Sequencing of pairs in the list is not important. You may specify pairs in any order you wish; however, the data returned is displayed in numerical sequence with the lowest slot#/port# pair first. Do not insert spaces between elements in the list. For example, 3/1,3/3,4/3 indicates ports 1 and 3 on interface module 3 and port 3 on interface module 4. (This example assumes that modules 3 and 4 are of the same interface type.) You can include ranges in lists.

3/1,4/1-4/4,5/1

The preceding example assumes that modules 3, 4, and 5 are of the same interface type.

The “all” Keyword

The **all** keyword indicates all the ports of all the modules of a specific type of interface. That is, all Ethernet, FibreChannel, or InfiniBand interface modules. The subsequent prompt will appear as though you entered the ports as a list.

Using the Documentation

The command descriptions in this book provide quick access to the information about each command. This book divides each command description into subsections, so you can go directly to the desired information.

Synopsis

The Synopsis subsection provides a brief, high-level description of the command.

Syntax

The Syntax subsection provides the command syntax. The following conventions apply:

- Text in **bold** font represents text that you enter exactly as it appears.
- Text in *italicized* font represents variables that you replace with actual values when you enter a command at the command line.
- Square brackets ([,]) enclose optional syntax. Do not enter square brackets in the CLI.
- Braces ({,}) enclose required syntax choices. Do not enter braces in the CLI.
- The pipe character (|) delineates between selections in syntax. That is, if command X requires argument Y *or* argument Z, but not both at the same time, the syntax will appear as follows:

X {Y | Z}

A table that describes all syntax arguments follows the syntax line(s).



Note

Input strings, such as device names and descriptions, must be contiguous without any intervening spaces or blanks. In the event that you wish to enter a multi-word string, enclose the string within double-quotes (“,”); otherwise the CLI parses each word as a separate argument, which results in a syntax violation.

Platform Availability

The platform subsection indicates the platform or platforms (such as Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, InfiniBand Switch Module for IBM BladeCenter) on which you may execute the command.

Command Modes

The Command Modes subsection indicates the command mode or submode that you must enter to execute the command.

Privilege Level

The Privilege Level subsection indicates the user permissions that are required to execute the command. For example, there are commands that only an unrestricted read-write user (for example, a super user) can execute that a user with general read-write permissions (admin) cannot.

Usage Guidelines

The Usage Guidelines subsection supplies additional information and details to help you use a command to its full potential.

Examples

The examples subsection shows actual command entry and CLI output.

```
SFS-7000P# show interface gateway 5
=====Gateway Information=====
      gateway : 5
        name  : 5/0
        type   : fc-gateway
        desc   : 5/0 (320)
last-change  : none
      mtu     : 0
admin-status : up
oper-status  : up
SFS-7000P#
```

Defaults

The Defaults subsection lists command default behavior or values.

Related Commands

The Related Commands subsection provides hypertext links to related CLI commands.



Administrative Commands

This chapter documents the following commands:

- [action](#), page 2-3
- [addr-option](#), page 2-5
- [authentication](#), page 2-6
- [auto-negotiate](#), page 2-8
- [boot-config](#), page 2-10
- [broadcast](#), page 2-11
- [card](#), page 2-12
- [cdp advertise-v2](#), page 2-13
- [cdp holdtime](#), page 2-15
- [cdp run](#), page 2-16
- [cdp timer](#), page 2-18
- [clear cdp counters](#), page 2-19
- [clear cdp table](#), page 2-20
- [clock set](#), page 2-21
- [config TACACS-server host](#), page 2-22
- [config TACACS-server host](#), page 2-22
- [copy](#), page 2-26
- [delete](#), page 2-29
- [dir](#), page 2-31
- [disable](#), page 2-33
- [enable](#), page 2-34
- [exec](#), page 2-35
- [exit](#), page 2-36
- [ftp-server enable](#), page 2-37
- [gateway](#), page 2-38
- [help](#), page 2-39
- [history](#), page 2-40

- [hostname, page 2-41](#)
- [install, page 2-42](#)
- [ip http, page 2-44](#)
- [link-trap, page 2-46](#)
- [location, page 2-47](#)
- [logging, page 2-48](#)
- [login, page 2-49](#)
- [logout, page 2-50](#)
- [more, page 2-51](#)
- [mtu, page 2-53](#)
- [name, page 2-54](#)
- [ntp, page 2-55](#)
- [ping, page 2-56](#)
- [power-supply, page 2-57](#)
- [radius-server, page 2-58](#)
- [reload, page 2-60](#)
- [save-log, page 2-62](#)
- [shutdown, page 2-63](#)
- [snmp-server, page 2-66](#)
- [speed, page 2-69](#)
- [system-mode, page 2-71](#)
- [system ib-counter-reset, page 2-72](#)
- [telnet, page 2-73](#)
- [terminal, page 2-74](#)
- [trace, page 2-76](#)
- [type, page 2-78](#)
- [username, page 2-80](#)
- [who, page 2-83](#)
- [write, page 2-84](#)

action

To execute predefined administrative functions on expansion modules (gateway cards), enter the **action** command in Card Configuration submode.

action { **delete-inactive-image** | **reset** }

Syntax Description

delete-inactive-image	Removes the inactive image from interface cards. Use the action command with the delete-inactive-image keyword after the boot-config command when you upgrade the system image on your Server Switch to clear the inactive image from the card(s) after a reboot.
reset	Resets the card(s) that you specify in a Cisco SFS 7008.

Command Modes

Card Configuration (config-card) mode.

Defaults

This command has no default settings.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted or card-specific read-write user.

Currently, you can execute only one predefined administrative function on all platforms except the Cisco SFS 7008. The function (delete-inactive-image) deletes inactive images from one or more cards to provide more available memory on the card.

Before you use the **action** command with the **delete-inactive-images** keyword, enter the **boot-config** command with the **primary-image-source** keyword to install and activate the proper image on the card. When you execute this command, the previously-active image becomes inactive. You can now execute the **action** command to clear the inactive image from your card.

To execute this command, you must have read-write administrative permission for the type(s) of card(s) that you want to clear.

Examples

The following example deletes inactive images from the card that resides in slot 2:

```
SFS-7000P(config-card-2)# action delete-inactive-images
```

The following example resets a management I/O card on a Cisco SFS 7008:

```
SFS-270(config-card-15)# action reset
```

 action

Related Commands

[boot-config](#)
[copy](#)
[install](#)
[show card](#)
[shutdown](#)

addr-option

To configure the Ethernet Management port to

- use a static IP address,
- obtain an IP address from a DHCP server,
- automatically obtain an IP address from a hardware-designated controller,

enter the **addr-option** command in Ethernet Management Configuration submode.

addr-option { auto | dhcp | static }

Syntax Description

auto	Applies an IP address from an outside controller to the Ethernet Management port.
dhcp	Uses DHCP to configure the address for the Ethernet Management port.
static	Changes the address of the Ethernet management port from the DHCP address to the static address that you configure with the ip command.

Defaults

This command has no default settings.

Command Modes

Ethernet Management Configuration (config-mgmt-ethernet) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Ethernet read-write user.

If you use the **static** keyword, configure the IP address of the Ethernet Management port with the [“ip” section on page 5-8](#).

Examples

The following example configures the Ethernet Management port to obtain an IP address from a DHCP server:

```
SFS-270 (config-if-mgmt-ethernet) # addr-option dhcp
```

Related Commands

[ip](#)

authentication

Authentication can be configured five ways, as shown in [Table 2-1](#)

Table 2-1 Authentication Methods for Logging In

Authentication	How it Works
local	Verifies against the chassis database
local and then RADIUS	Verifies against the chassis database then checks the RADIUS server
RADIUS and then local	Checks the RADIUS server and then verifies against the chassis database
local and then TACACS+	Verifies against the chassis database then checks the TACACS+ client
TACACS+ and then local	Checks the TACACS+ client and then verifies against the chassis database

For more information, see the [“Authentication” section on page 1-3](#).

```
authentication login [default {local [radius|tacacs] | [radius|tacacs] local}]
```

Syntax Description

login	Enables local login authentication. Note When you enter authentication login , the command behaves as though you had entered authentication login default local .
default	(Optional) Configures where and in what order your Server Switch authenticates logins.
local	(Optional) Authenticates the login with the local CLI user database.
radius	(Optional) Authenticates the login with the RADIUS server.
tacacs	(Optional) Authenticates the login with the TACACS+ server.

Defaults

Authentication defaults to **local**.

Command Modes

Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.

Use the **configure authentication** command to indicate the user login authorization sources and the sequence in which to check them.

Examples

The following example configures the Server Switch to authenticate to the RADIUS server, then to the local database if server authentication fails:

```
SFS-7000P(config)# authentication login default radius local
```

The following example configures the Server Switch to authenticate to the TACACS+ server then to the local database if server authentication fails:

```
SFS-7000P(config)# authentication login default tacacs local
```

The following example configures the Server Switch to authenticate to the local database, then to the RADIUS server if server authentication fails:

```
SFS-7000P(config)# authentication login default local radius
```

The following example configures the Server Switch to authenticate to the local database, then to the TACACS+ server if server authentication fails:

```
SFS-7000P(config)# authentication login default local tacacs
```

Related Commands

[config TACACS-server host](#)
[radius-server](#)
[show authentication](#)
[config TACACS-server host](#)
[config TACACS-server host](#)

auto-negotiate

To configure your Server Switch to

- dynamically determine the connection speed of direct-attached Fibre Channel devices,
- dynamically determine the connection speed of direct-attached Ethernet devices,
- dynamically determine the connection speed of direct-attached InfiniBand devices,

enter the **auto-negotiate** command in the appropriate Interface Configuration submode. To disable auto-negotiation, use the **no** form of this command.

auto-negotiate

no auto-negotiate

Syntax Description

This command has no arguments or keywords

Defaults

Fibre Channel and Ethernet ports auto-negotiate connection speeds by default.

Command Modes

Fibre Channel Interface Configuration (config-if-fc) submode, Ethernet Interface Configuration (config-if-ether) submode, InfiniBand Interface Configuration (config-if-ib) submode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Fibre Channel read-write user (for FC ports), Ethernet read-write user (for Ethernet ports), InfiniBand read-write user (for InfiniBand ports).

Fibre Channel:

Before you configure your FC port to auto-negotiate speed, follow these steps to verify that the attached Fibre Channel device supports auto-negotiation:

Step 1

Enter the **show interface fc** command in User Exec mode or Privileged Exec mode.

Step 2

Verify that the **auto-negotiate-supported** field of the command output displays **yes**. If the field displays **no**, you must manually configure the connection speed of the port.



Note

If you disable auto-negotiation in the CLI but leave it active on the attached Fibre Channel devices, the port manager for the Fibre Channel interface on your device does not negotiate speed and mode with the FC devices. The FC devices may choose a different duplex setting than the port manager and produce unexpected results.

Ethernet:

Before you enable auto-negotiation, follow these steps to verify that the Ethernet host supports auto-negotiation:

-
- | | |
|---------------|---|
| Step 1 | Enter the show interface ethernet command in User Exec mode or Privileged Exec mode. |
| Step 2 | Verify that the auto-negotiate-supported field displays yes . If the field displays no , you must manually configure the connection speed of the port. |
-

InfiniBand:

Before you enable auto-negotiation, follow these steps to verify that the InfiniBand host supports auto-negotiation:

-
- | | |
|---------------|---|
| Step 1 | Enter the show interface ib command in User Exec mode or Privileged Exec mode. |
| Step 2 | Verify that the auto-negotiate-supported field displays yes . If the field displays no , you must manually configure the connection speed of the port. |
-

Examples

The following example disables auto-negotiation on ports 1 through 2 on Fibre Channel card 5. The result of this command appears in the **auto-negotiate** field of the **show interface fc** command:

```
SFS-7000P(config-if-fc-5/1-5/2)# no auto-negotiate
```

The following example disables auto-negotiation on ports 1 through 4 on Ethernet card 4. The result of this command appears in the **auto-negotiate-supported** field of the **show interface ethernet** command:

```
SFS-7000P(config-if-ether-4/1-4/4)# no auto-negotiate
```

The following example enables auto-negotiation on port 1 on a Cisco SFS 7000. The result of this command appears in the **auto-negotiate-supported** field of the **show interface ib** command:

```
SFS-120(config-if-ib-1/1)# auto-negotiate
```

Related Commands

[link-trap](#)
[name](#)
[show fc srp initiator](#)
[show interface ethernet](#)
[show interface fc](#)
[show interface ib](#)
[shutdown](#)
[speed](#)

boot-config

To specify the system image to run when your Server Switch boots, enter the **boot-config** command in Global Configuration mode.

boot-config primary-image-source *dir*

Syntax Description

primary-image-source	Specifies that you want to configure the boot image.
<i>dir</i>	Directory that contains the boot image.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.

Specify an image *directory* as a boot image. Do not specify image files that end in “.img” since these are compressed archives that must be installed first.



Note

Use the **dir** command with the image keyword to view a list of images on your device.

Examples

The following example configures the Server Switch controller to use the sfsOS-1.1.0/build460 directory when the Server Switch boots. Without this directory, the system cannot boot successfully.

```
SFS-7000P(config)# boot-config primary-image-source sfsOS-1.1.0/build460
```

Related Commands

- [dir](#)
- [install](#)
- [radius-server](#)
- [reload](#)
- [show boot-config](#)
- [show card](#)
- [show card-inventory](#)

broadcast

To send text messages to all other CLI users, enter the **broadcast** command in User Exec mode or Privileged Exec mode.

broadcast *message*

Syntax Description

message

Message to broadcast. This message may consist of one or more words and may include any alphanumeric character or symbol (except for quotation marks).

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Multi-word messages must begin and end with quotation marks (“,”). Single-word messages do not require quotation marks.

You can broadcast a message to warn other CLI users about events that may impact their sessions, such as a network outage or major configuration change. A broadcast message appears on every active CLI session on the Server Switch, including the user who sends the message.

Examples

The following example prints “FC card 5 going down in 10 minutes” to the terminal screens of all users on the Server Switch:

```
SFS-7000P# broadcast "FC card 5 going down in 10 minutes."
```

Related Commands

[reload](#)
[who](#)
[write](#)

card

To enter Card Configuration submode, enter the **card** command in Global Configuration mode.

card { *slot-list* | **all** | *digit* | *digit,digit* | *digit-digit* }

Syntax Description	<i>slot-list</i>	Card, list of cards, or range of cards to configure.
	all	Configures all cards in the chassis.
	<i>digit</i> <i>digit,digit</i>	Specifies the slot numbers for cards you want to configure in the chassis.

Defaults This command has no default settings.

Command Modes Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Card-specific read-write user

Enter Card Configuration submode to enable, disable, configure, and reinitialize cards in your Server Switch.

Examples

The following example enters Card Configuration submode for all cards on the Server Switch. Any commands that execute in this mode apply to all of the cards in the chassis.

```
SFS-7000P(config)# card all
SFS-7000P(config-card-1,6,11,15-16)#
```

Related Commands

clock set
delete
install
show card
show card-inventory
shutdown

cdp advertise-v2

To enable Cisco Discovery Protocol Version 2 (CDPv2) advertising functionality on a device, use the **cdp advertise-v2** command in global configuration mode. To disable advertising CDPv2 functionality, use the **no** form of the command.

cdp advertise-v2

no cdp advertise-v2

Syntax Description

This command has no arguments or keywords

Defaults

Enabled. CDP is running on chassis boot.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

Each device configured for CDP sends periodic messages, known as advertisements, to a multicast address. Each device advertises at least one address at which it can receive SNMP messages. The advertisements also contain time-to-live, or holdtime, information, which indicates the length of time a receiving device should hold CDP information before discarding it. Each device also listens to the periodic CDP messages sent by others in order to learn about neighboring devices and determine when their interfaces to the media go up or down.

CDP Version 2 is the most recent release of the protocol. With CDP Version-2, detailed information is provided on the VLAN Trunking Protocol (VTP) management domain and duplex modes of neighbor devices, CDP-related counters, and VLAN IDs of connecting ports. This can help the Ethernet gateway configuration. CDP is run on server switches over management-Ethernet interfaces. CDP Version 2 has three additional type-length values (TLVs): VTP Management Domain Name, Native VLAN, and full/half-Duplex.



Note

CDP runs by default when a chassis boots up, but CDP is only learning in this mode. If any neighbors are advertising, CDP will identify them.

Examples

The following example sets the CDP advertisement for CDP Version 2:

```
SFS-7000P(config)# cdp advertise-v2
```

Related Commands

[cdp holdtime](#)
[cdp timer](#)
[show cdp](#)
[show cdp entry](#)
[show cdp neighbors](#)
[show clock](#)

cdp holdtime

To set the Cisco Discovery Protocol (CDP) transmission holdtime, enter the **cdp holdtime** command in Global Configuration mode.

cdp holdtime *seconds*

Syntax Description

<i>seconds</i>	Sets the number of seconds for transmission holdtime.
----------------	---

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

CDP packets are sent with a time to live, or hold time, value. The receiving device will discard the CDP information in the CDP packet after the hold time has elapsed. You can set the hold time lower than the default setting of 180 seconds if you want the receiving devices to update their CDP information more rapidly. The CDP hold time must be set to a higher number of seconds than the time between CDP transmissions, which is set using the **cdp timer** command.

Examples

The following example sets the CDP holdtime:

```
SFS-7000P(config)# cdp holdtime 120
```

Related Commands



[cdp advertise-v2](#)
[cdp timer](#)
[show cdp](#)
[show cdp entry](#)
[show cdp neighbors](#)
[show clock](#)

cdp run

To enable Cisco Discovery Protocol (CDP), use the **cdp run** command in global configuration mode. To disable CDP, use the **no** form of this command.

cdp run

no cdp run

Syntax Description	This command has no arguments or keywords.
Defaults	Disabled
Command Modes	Global Configuration (config) mode.
Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted and general read-write user.</p> <p>CDP is enabled by default, which means the Cisco IOS software will receive CDP information. CDP also is enabled on supported interfaces by default. To disable CDP on an interface, use the no cdp run interface configuration command.</p>
 Note	Because ODR (o- demand routing) uses CDP, the cdp enable , cdp timer , and cdp run commands affect the operation of the router odr global configuration command. For more information on the router odr command, see the Cisco IOS IP Command Reference, Volume 2 of 3: Routing Protocols document.
 Note	CDP runs by default when a chassis boots, but CDP is only learning in this mode. If any neighbors are advertising, CDP will identify them.

Examples	<p>The following example starts CDP advertising on your chassis:</p> <pre>SFS-7000P(config)# cdp run</pre> <p>The following example starts CDP advertising on your chassis and specifies the CDP timer interval:</p> <pre>SFS-7000P# configure SFS-7000P(config)# cdp run SFS-7000P(config)# cdp timer 10</pre>
----------	---

Related Commands

[cdp advertise-v2](#)
[cdp holdtime](#)
[cdp timer](#)
[show cdp](#)
[show cdp entry](#)
[show cdp neighbors](#)
[show clock](#)

cdp timer

To specify how often the Cisco IOS software sends Cisco Discovery Protocol (CDP) updates, use the **cdp timer** command in global configuration mode. To revert to the default setting, use the **no** form of this command.

```
cdp timer seconds

no cdp timer
```

Syntax Description	secondsSets the number of seconds for the transmission timer.
Defaults	80 seconds
Command Modes	Global Configuration (config) mode.
Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted and general read-write user.</p> <p>The trade-off with sending more frequent CDP updates to provide up-to-date information is that bandwidth is used more often.</p>
Note	The cdp timer , and cdp run commands affect the operation of the IP on demand routing feature (that is, the router odr global configuration command). For more information on the router odr command, see the "On-Demand Routing Commands" chapter in the Cisco IOS IP Command Reference, Volume 2 of 3: Routing Protocols document.
Examples	<p>The following example sets the CDP timer:</p> <pre>SFS-7000P(config)# cdp timer 120</pre>
Related Commands	<p>cdp advertise-v2</p> <p>cdp holdtime</p> <p>cdp run</p> <p>show cdp</p> <p>show cdp entry</p> <p>show cdp neighbors</p> <p>show clock</p>

clear cdp counters

To reset Cisco Discovery Protocol (CDP) traffic counters to zero, use the **clear cdp counters** command in privileged EXEC mode.

clear cdp counters

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Privileged EXEC mode.

Examples

The following example sets the CDP counters to zero:

```
SFS-7000P(config)# clear cdp counters
```

Related Commands

[cdp advertise-v2](#)
[cdp holdtime](#)
[cdp run](#)
[clear cdp table](#)
[show cdp](#)
[show cdp entry](#)
[show cdp neighbors](#)
[show clock](#)

clear cdp table

To clear the table that contains Cisco Discovery Protocol (CDP) information about neighbors, use the **clear cdp table** command in privileged EXEC mode.

clear cdp table

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Privileged EXEC mode

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

Examples

The following example sets the CDP counters to zero:

```
SFS-7000P(config)# clear cdp counters
```

Related Commands

[cdp advertise-v2](#)
[cdp holdtime](#)
[cdp run](#)
[clear cdp counters](#)
[show cdp](#)
[show cdp entry](#)
[show cdp neighbors](#)
[show clock](#)

clock set

To manually configure the time and date of the on-board Server Switch clock, enter the **clock set** command in Privileged Exec mode.

clock set *hh:mm:ss dd mm yy*

Syntax Description

<i>hh</i>	Hour to assign.
<i>mm</i>	Minute to assign.
<i>ss</i>	Second to assign.
<i>dd</i>	Day to assign.
<i>mm</i>	Month to assign.
<i>yy</i>	Year to assign.

Defaults

This command has no default settings.

Command Modes

Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

Your Server Switch uses one of the following means to maintain system time:

- an on-board system clock
- an external NTP server (recommended)

When you first power on your Server Switch, factory-default system clock settings run. To ensure accurate synchronization, we recommend that you use an external NTP server, as it will synchronize log dates with other management systems. To configure NTP servers, refer to the [“ntp” section on page 2-55](#).

Examples

The following example sets the clock time to 7:22 PM and 10 seconds on the 25th of May, 2015:

```
SFS-7000P# clock set 19:22:10 25 05 15
```

Related Commands

[card](#)
[ntp](#)
[radius-server](#)
[show clock](#)

config TACACS-server host

To configure a TACACS+ server, use the **config tacacs-server host** command.

```
tacacs-server host <ip-addr> [port <port>] [timeout <seconds>] [retransmit <retransmit>] [key
    <server-client key>

no tacacs-server host <ip-addr>    // delete entry

tacacs-server host <ip-addr> key ""    // to remove the key
```

Syntax Description

<i>ip-addr</i>	IP address.
<i>port</i>	TACACS+ host authentication port, defaults to 49.
<i>seconds</i>	Login request times out if no reply is received from the server within this period. Default is 5 seconds.
<i>retransmit</i>	Number of retries (timeouts).
<i>server-client key</i>	Secret key used between TACACS+ server and client.

Defaults

The TACACS+ host authentication **port** defaults to 49. **Seconds** defaults to 5.

Command Modes

Unrestricted and general read-write user.
Use the the **config tacacs-server host** command to identify a host as a TACACS+ server.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-write user.

Examples

The following example changes to executive mode, changes to configuration mode, and then identifies 164.28.299.30 as a TACACS+ server:

```
SFS-7000>enable
SFS-7000P# configure
SFS-7000P(config)# tacacs-server host 164.28.299.30
```

Related Commands

[authentication](#)
[boot-config](#)
[clock set](#)

```
show authentication  
snmp-server  
radius-server
```

configure terminal

To enter Global Configuration mode, enter the **configure terminal** command in Privileged Exec mode.

configure terminal

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted and general read-write user.

Use the **configure terminal** command to enter Global Configuration mode. From this mode, you can configure gateway and switch cards, subnet management, IP addressing, and various aspects of your Server Switch.

Examples The following example enters Global Configuration mode:

```
SFS-7000P# configure terminal
SFS-7000P(config)#
```

Related Commands

- [arp ethernet authentication](#)
- [boot-config](#)
- [bridge-group](#)
- [card](#)
- [show diagnostic](#)
- [exit](#)
- [fc srp initiator](#)
- [fc srp initiator-wwpn](#)
- [fc srp it](#)
- [fc srp itl](#)
- [fc srp lu](#)
- [fc srp target](#)
- [fc srp-global gateway-portmask-policy restricted](#)
- [fc srp-global itl](#)
- [fc srp-global lun-policy restricted](#)

ftp-server enable
help
history
hostname
ib sm
ib-agent
ip
location
logging
ntp
radius-server
redundancy-group
snmp-server
telnet
trace
trunk-group
username

copy

To copy files

- to your Server Switch from a remote location,
- from your Server Switch to a remote location,
- from one directory on your Server Switch to another,

enter the **copy** command in Privileged Exec mode.

copy ftp://user-id:password@host[/path]/file-name [slot-number:]file-system[:file-name]

Downloads a file from a FTP server.

copy scp://user-id:password@host[/path]/file-name [slot-number:]file-system[:file-name]

Securely transfers files from a remote server to the chassis.

copy tftp://remote-system[/path]/file-name [slot-number:]file-system[:file-name]

Downloads a file from a remote TFTP server.

copy {[slot-number:]file-system:file-name | **startup-config** | **running-config**}
ftp://user-id:password@host[/path]/[file-name]

Uploads a file to a FTP server.

copy running-config startup-config

Saves the running configuration as the startup configuration.

copy [slot-number:]file-system:file-name **running-config**

Executes a configuration file without a system reboot.

Syntax Description

ftp	Identifies a remote system that runs file transfer protocol (FTP).
scp	Securely transfers files from a remote server to the chassis.
tftp	Identifies a remote system that runs trivial file transfer protocol (TFTP).
remote-system	IP address (or DNS name, if appropriate) of the remote host.
running-config	Refers to the active configuration running on your Server Switch.
startup-config	Refers to the configuration that your Server Switch runs when it boots.
<i>user-id</i>	User ID that you use to log in to the FTP server.
<i>password</i>	Password that you use to log in to the FTP server.
<i>host</i>	FTP server domain name or IP address.
<i>path</i>	(Optional) Directory path on the host from which or to which you want to copy a file.
<i>slot-number</i>	(Optional) Slot of the controller card (1 on the Cisco SFS 3001, Cisco SFS 7000, and Cisco 4x InfiniBand Switch Module for IBM BladeCenter; 1 or 14 on the Cisco SFS 3012; 11 or 12 on the Cisco SFS 7008).

<i>file-name</i>	(Optional) Name of the file that you want to copy.
<i>file-system</i>	File system on your Server Switch.

Defaults

This command has no default settings.

Command Modes

Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Use the **copy** command to save a running configuration as a boot-up configuration, to download image files to install, or to upload configurations that you want to propagate to other Server Switches. The **copy** command copies image data, configuration data, and log data locally as well as onto and off of the system chassis.

**Note**

If an administrator has configured the system-mode to VFrame, the Server Switch does not apply SRP configuration changes to the startup configuration. For more information, refer to this command: [system-mode, page 2-71](#).

The **copy** command can also copy the contents of a configuration file.

**Note**

Configuration files that you upload from your Server Switch to a remote host contain plain text that you can read with any word processor. Log files also appear in plain text.

You may download image and configuration files from an FTP server to the system chassis. You may also upload log and configuration files from the system chassis to an FTP server.

Download image files to your Server Switch to upgrade system firmware. Download configuration files to quickly replicate a desired configuration. Upload configuration and log files to maintain back-up files and to troubleshoot your Server Switch.

Image files require additional processing. Your Server Switch can run an image only after you install the image file. For more information about how to install an image, refer to this command: [install, page 2-42](#).

After you download a configuration file to your Server Switch, you can use the **boot-config** command to configure your Server Switch to load that configuration when you reboot the Server Switch.

The **copy** command recognizes **Ctrl-c** as a command to terminate a file transfer. Use **Ctrl-c** to cancel a transfer if the network hangs.

**Note**

You can download image and configuration files only. Log files cannot be downloaded. You can upload configuration files and log files only. System image data cannot be uploaded.

Examples

The following example downloads an image file from a remote host to the Server Switch:

```
SFS-7000P# copy ftp://bob:mypassword@10.0.0.5/SFS-7000P-sfsOS-2.3.0-build497.img
image:SFS-7000P-2.3.0-build497.img
```

```
sfsOS-2.3.0-build497.img
operation completed successfully
```

The following example saves the running configuration as the startup configuration so the current configuration executes when the Server Switch reboots:

```
SFS-7000P# copy running-config startup-config
operation completed successfully
```

```
SFS-7000P
```

The following example copies the startup configuration image from the controller card in slot 1 on a Cisco SFS 3012 to the controller card in slot 14:

```
SFS-7000P# copy 1:config:startup-config 14:config:save.cfg
** operation completed successfully
```

Related Commands

[action](#)
[boot-config](#)
[delete](#)
[dir](#)
[exec](#)
[ftp-server enable](#)
[history](#)
[install](#)
[show boot-config](#)
[show fan](#)

delete

To remove image, configuration, or log files from your Server Switch, enter the **delete** command in Privileged Exec mode.

delete [*slot-number*:]*file-system:file*

Syntax Description

<i>file-system</i>	Server Switch file system. Your Server Switch displays this internal directory by name only. The file systems are config, images, and syslog. The specified file system must be appropriate to the type of file that you want to delete. For example, if you attempt to delete a configuration file from the syslog file system, an error occurs because the name of the file does not match the file system. A colon (:) always follows the file-system specification.
	Note The startup configuration maps to config:startup-config. Therefore, you do not need to specify the file system at the CLI.
<i>slot-number</i>	(Optional) Slot of the controller card (1 on the Cisco SFS 3001 and Cisco SFS 7000, 1 or 14 on the Cisco SFS 3012).
<i>file</i>	Name of the configuration file, image file, or log file that you want to delete.

Defaults

This command has no default settings.

Command Modes

Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

You cannot delete an active image. To deactivate an active system image in order to delete it, install a new image using this command: ([install](#), [page 2-42](#)) and configure your Server Switch to boot that image using this command: ([boot-config](#), [page 2-10](#)), then delete the old image.

Examples

The following example deletes the delete-me.cfg file from the controller card in slot 1 of a Cisco SFS 3012:

```
SFS-7000P# delete 1:config:delete-me.cfg
Delete file 1:delete-me.cfg? [yes(default) | no] yes
*****
```

The following example deletes an image file from the controller card in slot 14 of a Cisco SFS 3012:

```
SFS-7000P# delete 14:image:sfs360-sfsOS-2.0.0-build488.img
Delete file 14:sfs360-sfsOS-2.0.0-build488.img? [yes(default) | no] yes
*****
```

Related Commands

[boot-config](#)
[copy](#)
[dir](#)
[install](#)

dir

To list the configuration files, log files, and system image files on your Server Switch, enter the **dir** command in Privileged Exec mode.

```
dir [slot-number:]{config | image | syslog}
```

Syntax Description	<i>slot-number</i>	(Optional) Slot of the controller card (1 on the Cisco SFS 3001 and Cisco SFS 7000, 1 or 14 on the Cisco SFS 3012, 11 or 12 on the Cisco SFS 7008).
	config	Lists all configuration files in the config directory.
	image	Lists the current image files and system images in the image directory. Image files end with a .img extension. Installed system images look like path names. Note You must unpack and install image files before they can boot the system. For more information, refer to this command: install , page 2-42.
	syslog	Lists the log files in the syslog directory.

Defaults This command has no default settings.

Command Modes Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use this command to list the files on your Server Switch. This command requires one of three arguments: **config**, **image**, or **syslog**. Files reside on the Server Switch in separate file systems. The CLI automatically tracks these file systems, so you do not need to include file-path information to administer these files.

Use the **dir** command with the **image** keyword to see the installed image directories on your Server Switch.

On the Cisco SFS 3012, use the *slot-number* variable to view files on the controller card in slot 1 or slot 14. The **dir** command lists the files of the active controller by default.

Examples The following example displays the configuration files on the Server Switch:

```
SFS-7000P# dir config
=====
Existing Configurations on System
=====
```

dir

```

slot      date-created      size      file-name
-----
1         Thu Oct 24 11:21:06 2002    58        check.cfg
1         Thu Dec  5 14:50:09 2002   39216     check2.cfg
1         Wed Dec 11 09:09:54 2002   1712     config_bc.cfg
1         Thu Dec  5 11:18:21 2002   1712     running_config.cfg
1         Wed Dec  4 07:10:23 2002   4407     running_config.cfg.backup
1         Thu Dec  5 12:04:53 2002   1712     running_config2.cfg
1         Thu Oct 24 11:19:53 2002    58        test.cfg
SFS-7000P#

```

The following example displays installed system images and image files on the Server Switch:

```

SFS-7000P# dir image
=====
Existing Boot-Images on System
=====
slot      date-created      size      file-name
-----
1         Thu Jun  1 11:16:50 2003   23691613  TopspinOS-1.1.3-build548.img
1         Wed Jul 11 00:56:52 2002    1024     TopspinOS-1.1.3/build541
1         Thu Jul  1 00:10:40 2003    1024     TopspinOS-1.1.3/build548
SFS-7000P#

```

The following example displays the log files in the syslog directory on the Server Switch:

```

SFS-7000P# dir syslog
=====
Existing Syslog-files on System
=====
slot      date-created      size      file-name
-----
1         Thu Jun 12 12:13:06 2002   19636     ts_log
1         Wed Jun 11 13:28:54 2002    4978     ts_log.1.gz
1         Tue Jun 10 04:02:02 2002     30        ts_log.2.gz
1         Mon Jun  9 04:02:02 2002     30        ts_log.3.gz
1         Sun Jul  8 04:02:02 2002     30        ts_log.4.gz
1         Sat Jul  7 04:02:02 2002     30        ts_log.5.gz
1         Fri Jul  6 17:20:35 2002   16264     ts_log.6.gz
1         Thu Jul  5 15:14:57 2002     245       ts_log.7.gz
SFS-7000P#

```

The following example displays the files in the image directory on the controller in slot 14 of a Cisco SFS 3012:

```

SFS-7000P# dir 14:image
=====
Existing Boot-Images on System
=====
slot date-created      size      file-name
-----
14   Thu Mar 18 14:59:06 2004  0         TopspinOS-2.0.0/build488

```

Related Commands

[boot-config](#)
[copy](#)
[delete](#)
[install](#)
[more](#)

disable

To exit Privileged Exec mode and return to User Exec mode, enter the **disable** command in Privileged Exec mode.

To disable a trunk group, enter the **disable** command in Trunk Interface Configuration submode.

disable

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Privileged Execute mode, Trunk Interface Configuration (config-if-trunk) submode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Examples

The following example exits Privileged Exec mode and enters User Exec mode:

```
SFS-7000P# disable  
SFS-7000P>
```

The following example deletes a trunk group:

```
SFS-7000P(config-if-trunk)# disable
```

Related Commands

[enable](#)
[show interface ethernet](#)

enable

To enter Privileged Exec mode from User Exec mode, enter the **enable** command in User Exec mode.
 To enable a trunk group, enter the **enable** command in Trunk Interface Configuration submode.

enable

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Trunk Interface Configuration (config-if-trunk) mode.

Usage Guidelines

Platform Availability:
 Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
 General read-only user.

Enter the **enable** command in User Exec mode to make administrative configuration changes to your Server Switch. Enter the **enable** command in Trunk Interface Configuration submode to activate a trunk group.

Examples

The following example enters Privileged Exec mode from User Exec mode:

```
SFS-7000P> enable
SFS-7000P#
```

The following example enables a new trunk group:

```
SFS-7000P(config-if-trunk)# enable
```

Related Commands

- [config TACACS-server host](#)
- [disable](#)
- [exit](#)

exec

To execute a file in the config file system on your Server Switch, enter the **exec** command in Privileged Exec mode.

exec *file-name*

Syntax Description	<i>file-name</i>	Name of the file that you want to execute.
---------------------------	------------------	--

Defaults	This command has no default settings.
-----------------	---------------------------------------

Command Modes	Privileged Execute mode.
----------------------	--------------------------

Usage Guidelines	Platform Availability: Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter
-------------------------	--

Privilege Level:

Unrestricted read-write user.

You can create command files on a management workstation and copy them to config file system on the switch using **copy** command. Then you can execute these files with **exec** command. Use the **save-log** command to save the latest commands that you have executed in the CLI to a file, then copy the file to the management station and use it as an example. See the **save-log** and **copy** commands for further details.



Note

You can run files only from the config directory of your file system.

Examples	The following example executes the test.cfg file in the config file system on the Server Switch:
-----------------	--

```
SFS-7000P# exec test.cfg
```

Related Commands	config TACACS-server host copy
-------------------------	---

exit

To exit your current CLI mode and return to the previous mode, enter the **exit** command in any mode.

exit [**all**]

Syntax Description	all (Optional) Returns you to User Execute mode from any other CLI mode.
--------------------	---

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	All modes.
---------------	------------

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>All users.</p> <p>The exit command performs different functions in different modes.</p>
------------------	--

Table 2-2 Exit Command Modes and Functions

Mode(s)	Function
User Exec	Logs you out of the Server Switch.
Privileged Exec	
Global Configuration	Returns you to Privileged Exec mode.
Configuration submode (any)	Returns you to Global Configuration mode.

Examples	<p>The following example exits Card Configuration submode and enters User Exec mode:</p> <pre>SFS-7000P(config-card-1,2)# exit all SFS-7000P></pre>
----------	---

Related Commands	<p>enable</p> <p>login</p> <p>logout</p>
------------------	--

ftp-server enable

To enable the FTP server on your Server Switch, enter the **ftp-server enable** command in Global Configuration mode. To disable this feature, use the **no** form of this command.

ftp-server enable

no ftp-server enable

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

All users.

The FTP server feature provides read-only access to the file systems on the Server Switch and complements the **copy** command. Use a FTP client on a management workstation to connect to the server using FTP protocol. You can download log files, configuration files or image files.

Examples

The following example disables FTP services on the Server Switch:

```
SFS-7000P(config)# no ftp-server enable
```

Related Commands

[show system-services](#)
[copy](#)
[telnet](#)

gateway

To assign a default IP gateway to

- the Ethernet Management port,
- the virtual in-band InfiniBand port,

enter the **gateway** command in the appropriate Interface Configuration mode. To disassociate a port from a gateway, use the **no** form of this command.

```
gateway gateway
no gateway
```

Syntax Description	<div>gateway</div> <div>IP address of the gateway to assign to the port.</div>
Defaults	<div>The gateway address defaults to 0.0.0.0.</div>
Command Modes	<div>Ethernet Management Interface Configuration (config-if-mgmt-ethernet) submode, InfiniBand Management Interface Configuration (config-if-mgmt-ib) submode.</div>
Usage Guidelines	<div> Platform Availability: Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter </div> <div> Privilege Level: Unrestricted read-write user. </div> <div> The gateway that you assign connects the port to the InfiniBand backplane on your Server Switch. You must configure the gateway through the Serial Console port. Enter the IP address of the gateway when you configure the management interfaces. </div>
Examples	<div>The following example assigns a default IP gateway to the Ethernet Management interface:</div> <div>SFS-7000P(config-if-mgmt-ethernet)# gateway 10.3.0.94</div> <div>The following example assigns a default IP gateway to the InfiniBand Management interface:</div> <div>SFS-7000P(config-if-mgmt-ib)# gateway 10.3.0.2</div>
Related Commands	<div>show interface mgmt-ethernet</div> <div>show interface mgmt-ib</div> <div>snmp-server</div>

help

To view the help options that the CLI provides, enter the **help** command in any mode.

help

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

All modes.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

All users.

This command may be executed in any mode. It provides the methods for you to display the various types of available help. The **help** command provides the same instructions regardless of mode.

Examples

The following example displays help options:

```
SFS-7000P(config-if-ib-16/1-16/12)# help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a
   command argument (e.g. 'show ?') and describes each possible
   argument.
2. Partial help is provided when an abbreviated argument is entered
   and you want to know what arguments match the input
   (e.g. 'show pr?'.)
SFS-7000P360(config-if-ib-16/1-16/12)#
```

history

To display a list of the commands that you executed during your CLI session, enter the **history** command in any mode.

history

Syntax Description

This command has no arguments or keywords.

Defaults

The **history** command stores the last 40 commands that you entered.

Command Modes

All modes.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

All users.

The format of the history output and a configuration file are similar. You can cut and paste the contents of the history output to a text file and, with minor editing, use it as a configuration file.

This global command may be executed in any mode. To display just one screen of history data at a time, configure the terminal display length.

Examples

The following example displays the recent command history:

```
SFS-7000P(config)# history
 1 history
 2 enable
 3 config
 4 arp
 5 boot-conf
 6 boot-config
 7 diagn
 8 interface ib all
 9 exit
10 interface ethernet all
11 ip
12 history
SFS-7000P(config)#
```

Related Commands

[copy](#)
[telnet](#)
[show fan](#)
[show system-services](#)

hostname

To assign a hostname to your Server Switch, enter the **hostname** command in Global Configuration mode.

hostname *name*

Syntax Description

name	Name to assign to the system.
-------------	-------------------------------

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

When you enter the **hostname** command, you apply the new name to the following three areas:

Step 1 Server Switch version information

Step 2 CLI prompt

Step 3 Server Switch network name

After you configure the host name, the name that you assigned appears in the **show version** command output. When you change modes, the new host name will appear in the CLI prompt.

Examples

Note the change in the CLI prompt that occurs in the last line of example output:

```
SFS-7000P(config)# hostname samplename
SFS-7000P(config)# exit
samplename#
```

Related Commands

[ip](#)
[ping](#)
[show version](#)

install

To install an image file on your Server Switch, enter the **install** command in Privileged Exec mode.

```
install [slot-number:]image:file
```

Syntax Description	<i>slot-number</i>	(Optional) Slot of the controller card (1 on the Cisco SFS 3001, Cisco SFS 7000, and Cisco 4x InfiniBand Switch Module for IBM BladeCenter; 1 or 14 on the Cisco SFS 3012; 11 or 12 on the Cisco SFS 7008).
	image	Specifies that the file resides in the image file-system.
	<i>file</i>	The name of the image file to install.

Image files must reside in the image file system and the file name must have the .img extension.

Defaults This command has no default settings.

Command Modes Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.
To run a new system image, you must follow these steps:

- Step 1

Download an image file to your Server Switch. See the **copy** command at the “[copy](#)” section on [page 2-26](#).
- Step 2

Power up all modules in your chassis.
- Step 3

Install the image file with the **install** command.
- Step 4

Configure your Server Switch to run the new system image when it boots. See the **boot** command at the “[boot-config](#)” section on [page 2-10](#).
- Step 5

(Optional) Execute the **action** command with the **delete-inactive-images** keyword for each card in your chassis to remove old images.

The **install** command performs everything necessary to install a new system image to flash memory. The command automatically installs all necessary firmware and component images, and then updates all cards with an administrative status of **up**.

To update additional cards, re-enter the **install** and **boot-config** commands after you add the cards.

**Note**

When you upgrade your Server Switch, your configuration file persists.

Examples

The following example installs a new image on the Server Switch:

```
SFS-7000P# install image:SFS-7000P-sfsOS-2.3.0-build497.img
***** operation completed successfully
SFS-7000P#
```

**Note**

If you try to install an OS image designed for Anafa chips on a system with Anafa 2 chips, you will receive an error message.

```
TS120-1# install image:sfs120-sfsOS-2.2.0-build556.img
Proceed with install? [yes(default) | no]
*****
Error: This image cannot be used with the Anafa2 chip(s) installed.
```

Related Commands

[action](#)
[boot-config](#)
[card](#)
[dir](#)
[reload](#)
[show boot-config](#)
[show card](#)
[shutdown](#)

ip http

To enable or configure HTTP and HTTPS services on your Server Switch, enter the **ip http** command in Global Configuration mode. To disable service or change a port number to the default value, use the **no** form of this command.

```
ip http { polling | port number | secure-cert-common-name { useSysName |
useMgmtEnetIpAddr | useMgmtIbIpAddr } | secure-port | secure-server | server }
```

```
no ip http { polling | port | secure-port | secure-server | server }
```

Syntax Description	polling	Enables polling on the Server Switch.
	port	Specifies the HTTP port that the HTTP server uses. Returns the port configuration to the default value (80) when you use the no form of the command.
	secure-cert-common-name	Specifies where to get the common name used to generate a SSL certificate.
	server	Enables the HTTP server on your Server Switch. Use this keyword with the no form of the command to disable the HTTP server.
	useSysName	Configures your Server Switch to use its system name (that you configure with the hostname command) in SSL certificates.
	useMgmtEnetIpAddr	Configures your Server Switch to use the IP address of its Ethernet Management Port in SSL certificates.
	useMgmtIbIpAddr	Configures your Server Switch to use the IP address of its InfiniBand Management Port in SSL certificates.
	secure-port	Specifies the HTTPS port that the HTTP server uses. Returns the port configuration to the default value (443) when you use the no form of the command.
	secure-server	Enables HTTPS with Secure Sockets Layer (SSL) on your Server Switch. Use this keyword with the no form of the command to disable HTTPS.
	<i>number</i>	HTTP port (integer) that the HTTP server uses.

Defaults

The HTTP port value defaults to 80.
 HTTP services on your Server Switch run by default.
 The HTTPS port value defaults to 443.
 HTTPS services on your Server Switch run by default.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Ethernet read-write user.

Configure the **ip http** command to run Chassis Manager. For more information, refer to the *Chassis Manager User Guide*.

Examples

The following example enables the HTTP server on the Server Switch:

```
SFS-7000P(config)# ip http server
```

Related Commands

[show ip http](#)
[show ip http server secure](#)

link-trap

To configure internal and external ports to generate link-up and link-down SNMP traps when the operating status (oper-status) of the ports changes, enter the **link-trap** command in the appropriate Interface Configuration mode. To disable this function, use the **no** form of this command.

link-trap

no link-trap

Syntax Description

This command has no arguments or keywords.

Defaults

By default, ports do not generate link traps.

Command Modes

All Interface Configuration submodes.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Fibre Channel read-write user, Ethernet read-write user.

Ports generate link-up traps when the oper-status of the port changes to **up** and link-down traps when the oper-status of the port changes to **down**. Trap receivers (that you define with the **snmp-server** command) receive the traps. You can then perform link validation and checking with the receivers, or configure SNMP alerts.

Examples

The following example enables link-trap generation for Fibre Channel interface ports 1 and 2 on card 5:

```
SFS-7000P(config-if-fc-5/1-5/2)# link-trap
```

The following example enables link-trap generation for InfiniBand interface ports 1 through 5 on card 15. The resulting traps are sent to trap receivers, as defined by the **snmp-server** command:

```
SFS-7000P(config-if-ib-15/1-15/5)# link-trap
```

The following example enables link-trap generation for Ethernet interface port 1 on card 4. The resulting traps are sent to trap receivers, as defined by the **snmp-server** command:

```
SFS-7000P(config-if-ether-4/1)# link-trap
```

Related Commands

[auto-negotiate](#)
[shutdown](#)
[show snmp](#)
[snmp-server](#)

location

To assign a text-based location identifier to your Server Switch, enter the **location** command in Global Configuration mode. To reset the location to an empty string, use the **no** form of this command.

location *“string”*

no location

Syntax Description

<i>string</i>	Refers to an ASCII text string. Enclose multi-word strings within double-quotes (“,”).
---------------	--

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Use the **location** command to assign a readable identifier to your Server Switch. Use the location string to identify support providers, the Server Switch owner, the Server Switch itself, or the physical location of the Server Switch. Display the location with the **show location** command.



Note

The **location** command configures the same parameter that the **snmp-server** command configures with the **location** and *location-string* arguments.

Examples

The following example assigns a location to the Server Switch:

```
SFS-7000P(config)# location "515 Ellis Street, Mountain View, CA 94043"
```

Related Commands

[snmp-server](#)
[show location](#)
[show version](#)

logging

To identify a remote server as a server that accepts log messages from your Server Switch, enter the **logging** command in Global Configuration mode. To undo logging settings, use the **no** form of this command.

```
[ No] logging-server one <ip-address>
[ No] logging-server two <ip-address>
```

Syntax Description	<div><div>ip-address</div><div>IP address of the remote syslog server.</div></div>
Defaults	<div>This command has no default settings.</div>
Command Modes	<div>Global Configuration (config) mode.</div>
Usage Guidelines	<div><div>Platform Availability:</div><div>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</div><div>Privilege Level:</div><div>All users.</div><div>Warnings, errors, notifications, and alerts occur once the system boots successfully. The logging command sends these occurrences to the remote server that you specify.</div></div>
Examples	<div><div>The following example configures the Server Switch to send log messages to the host with an IP address of 10.3.0.60:</div><div>SFS-7000P(config)# logging-server one 10.3.0.60</div></div>
Related Commands	<div><div>show logging</div><div>terminal</div><div>snmp-server</div><div>show snmp</div></div>

login

To change user identity during a CLI session, enter the **login** command in User Exec mode or Privileged Exec mode.

login *userid*

Syntax Description

<i>userid</i>	User ID that you want to use to log in.
---------------	---

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

All users.

The **login** command allows you to assume the identity of another user without having to exit the CLI. The CLI prompts you for your password.

**Note**

To change back to a previous login, do not use the **logout** command. Instead, use the **login** command again.

Examples

In the following example, the user moves from the current login to the **super** login:

```
SFS-7000P> login super
Password: xxxxx
SFS-7000P>
```

Related Commands

[exit](#)
[logout](#)
[username](#)
[show user](#)

logout

To log out of the current CLI session, enter the **logout** command in User Exec mode or Privileged Exec mode.

logout

Syntax Description This command has no arguments or keywords.

Defaults This commandhas no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
All users.

The **logout** command ends the current CLI session. If logged in through the Serial Console port, the CLI login prompt appears. If logged in through a Telnet connection, the Telnet session ends and you are returned to your operating system.

Examples

The following example logs the user out of the CLI:

```
SFS-7000P# logout
SFS-7000P#
Connection to host lost.
```

Related Commands

[exit](#)
[login](#)

more

To view the contents of a text file on your terminal screen, enter the **more** command in Privileged Exec mode.

more [*slot-number*:]*file-system*:*file-name*

Syntax Description	<i>slot-number</i>	(Optional) Slot of the controller card (1 on the Cisco SFS 3001 and Cisco SFS 7000, 1 or 14 on the Cisco SFS 3012).
	<i>file-system</i>	File system on your Server Switch in which the text file resides.
		Note For the startup configuration file, you do not need to include the file system in the command syntax.
	<i>file-name</i>	Name of the file to display.

Defaults

This command has no default settings.

Command Modes

Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-write user.

The **more** command displays text data resident on the chassis in increments determined by the **terminal length** command. The specified file-system must be appropriate for the file. See also the **dir** command to list the names of files in the respective file-systems.

Press any key (except the **q** key) to display the next screen of text lines.

The *file-system* variable represents the file system that contains the file. The file system variable may be **config** or **syslog**. You cannot display image file data or compressed system log files. Only the currently active log file, *ts_log*, may be viewed.

Examples

The following example displays the contents of the startup configuration file:

```
SFS-7000P# more config:startup-config
! TopspinOS-2.3.0/build560
! Fri Mar 15 18:06:10 1935
enable
config terminal
!
boot-config primary-image-source TopspinOS-2.3.0/build560
!
interface mgmt-ethernet
ip address 10.3.106.25 255.255.0.0
```

more

```
gateway 10.3.0.1
no shutdown
!
SFS-7000P#
```



Note

The lines beginning with an exclamation point (!) are comments that are ignored when the configuration file executes.

The following example displays the contents of the hwif_log file:

```
SFS-7000P# more 14:syslog:hwif_log
Mon Mar  1 00:32:10 2004: card_startup.x : card is starting up
Mon Mar  1 00:32:26 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 03:58:49 2004: card_startup.x : card is starting up
Mon Mar  1 03:59:05 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 04:01:37 2004: card_startup.x : card is starting up
Mon Mar  1 04:01:53 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 04:04:27 2004: card_startup.x : card is starting up
Mon Mar  1 04:04:43 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 04:07:10 2004: card_startup.x : card is starting up
Mon Mar  1 04:07:26 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 19:27:10 2004: card_startup.x : card is starting up
Mon Mar  1 19:27:26 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 19:30:39 2004: card_startup.x : card is starting up
Mon Mar  1 19:30:55 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
1.200000000.bin: PASSED
Mon Mar  1 19:55:33 2004: card_startup.x : card is starting up
Mon Mar  1 19:55:50 2004: POST: Tavor: Firmware rev 200000000 matches tavor_fw.A
```

Related Commands

[dir](#)
[telnet](#)
[terminal](#)

mtu

To configure the maximum transmission unit on the chassis, enter the **mtu** command in InfiniBand Management Interface Configuration submode.

mtu *integer*

no mtu

Syntax Description

<i>integer</i>	Slot of the controller card (1 on the Cisco SFS 3001 and Cisco SFS 7000, 1 or 14 on the Cisco SFS 3012).
----------------	--

Defaults

The IB MTU value defaults to 1500.

Command Modes

InfiniBand Management Interface Configuration submode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-write user.

The maximum possible MTU for InfiniBand is higher than the MTU for Ethernet. To smoothly transition traffic through Ethernet gateways, the factory setting of IB MTU matches the maximum Ethernet setting. On an IB-only network, you can set the MTU as high as 2044.

Examples

The following example configures the IB MTU:

```
SFS-120(config-if-mgmt-ib)# mtu 1500
```

Related Commands

[show interface mgmt-ib](#)

name

To assign a user-defined name to an interface port, enter the **name** command in the appropriate Interface Configuration submode.

name *string*

Syntax Description	string	Alphanumeric ASCII text string (up to 20 characters, including spaces) to assign to one or more ports.
---------------------------	---------------	--

Defaults	By default, the name of a port appears as a slot#/port# pair.	
-----------------	---	--

Command Modes	Interface Configuration (config-if-fc, config-if-ib, config-if-ether) submodes.	
----------------------	---	--

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Fibre Channel read-write user, InfiniBand read-write user, Ethernet read-write user.</p> <p>The name can be used to simplify port identification and indicate port use. Assign the same name to multiple ports to identify the ports as a group with a uniform function. The name that you assign appears in the name field of the appropriate show interface command.</p>	
-------------------------	--	--

ntp

To synchronize the clock on your Server Switch to primary, secondary, and tertiary NTP servers, enter the **ntp** command in Global Configuration mode. To reset an NTP configuration to the default value, use the **no** form of this command.

ntp {server-one | server-two | server-three} *ip-address*

no ntp {server-one | server-two | server-three}

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Use the **ntp** command to configure your Server Switch to take time information from up to three servers so that your Server Switch can identify a problem when one server sends faulty data packets. We strongly recommend that you configure all three servers for maximum precision.

Examples

The following example assigns primary, secondary, and tertiary NTP servers to the Server Switch:

```
SFS-7000P(config)# ntp server-one 10.0.3.110
SFS-7000P(config)# ntp server-two 10.0.3.111
SFS-7000P(config)# ntp server-three 10.0.3.112
```

Related Commands

[clock set](#)
[show clock](#)
[show ntp](#)
[snmp-server](#)

ping

To verify that your Server Switch can reach a given host, enter the **ping** command from User Exec mode or Privileged Exec mode.

ping *host*

Syntax Description

<i>host</i>	IP address or hostname of the host, port, or expansion module that you want to reach.
-------------	---

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Use the **ping** command to verify connectivity between your Server Switch and a host or port. The reply packet tells you if the host received the ping and the amount of time it took to return the packet.



Note

You must configure a DNS server on your network to use hostnames as an argument in the **ping** command.

Examples

The following example verifies that the Server Switch can contact the device with an IP address of 10.3.102.24:

```
SFS-7000P# ping 10.3.102.24
Sending 5 ICMP Echoes to 10.3.102.24, 56 data bytes
!!!!
Success rate is 100 percent (5/5)
round-trip min/avg/max = 0.000000/0.000000/0.000000 ms
SFS-7000P#
```

Related Commands

[hostname](#)
[ip](#)

power-supply

To enter Power Supply Configuration submode, enter the **power-supply** command from Global Configuration mode.

power-supply [**all** | *selection*]

Syntax Description	all	(Optional) Configures all power supplies.
	<i>selection</i>	(Optional) Selection of power supplies to configure.

Defaults This command has no default settings.

Command Modes Global Configuration mode.

Usage Guidelines

Platform Availability:
Cisco SFS 7000, Cisco SFS 7008

Privilege Level:
General read-write user.

Use the **shutdown** or **no shutdown** commands to bring down and bring up power supplies. The command will only let you bring down one power supply at a time.

Examples The following example enters Power Supply Configuration submode for all power supplies:

```
SFS-120 (config) # power-supply all
```

Related Commands [show power-supply](#)

radius-server

To configure up to three RADIUS servers that your Server Switch uses to authenticate CLI user logins, enter the **radius-server** command in Global Configuration mode. To remove a RADIUS server from the configuration, use the **no** form of this command.

```
radius-server host ip-address [auth-port udp-port] [timeout seconds] [retransmit retries] [key encryption-key]

no radius-server host ip-address
```

Syntax Description	host	Specifies the IP address of the RADIUS server.
	<i>ip-address</i>	IP address of the RADIUS server.
	auth-port	(Optional) Specifies the user datagram protocol (UDP) authentication port of the RADIUS server.
	<i>udp-port</i>	(Optional) UDP authentication port of the RADIUS server.
	timeout	(Optional) Specifies the amount of time that your Server Switch waits for a reply from the server before the login request times out.
	<i>seconds</i>	(Optional) Amount of time, in seconds, that your Server Switch waits for a reply from the server before the login request times out.
	retransmit	(Optional) Specifies the number of times that your Server Switch tries to authenticate after a timeout.
	<i>retries</i>	(Optional) Number of times that your Server Switch tries to authenticate after a timeout.
	key	(Optional) Specifies the authentication key that the client and radius server use.
	<i>encryption-key</i>	(Optional) Encryption key that the client and radius server use.

Defaults

The RADIUS server IP address defaults to 0.0.0.0, which assigns no server, and the Server Switch authenticates locally by default.

The *udp-port* variable defaults to 1812.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write access.

Configure a RADIUS server to authenticate CLI user logins. Enter the **authentication** command to enable authentication and to configure your Server Switch to authenticate with the RADIUS server. Use the **show authentication** command to display the configuration of the radius server, including the priority.

Examples

The following example assigns the RADIUS server that the Server Switch can use to validate logins:

```
SFS-7000P(config)# radius-server host 10.5.0.100
```

Related Commands

[authentication](#)
[boot-config](#)
[clock set](#)
[show authentication](#)
[snmp-server](#)
[config TACACS-server host](#)

reload

To reboot your Server Switch, enter the **reload** command in Privileged Exec mode.

reload [no-failover]

Syntax Description	no-failover (Cisco SFS 3012 only) (Optional) Forces a Cisco SFS 3012 to run from the same controller card when it reboots. By default, Cisco SFS 3012 Server Switches swap active controller cards when they reboot.
--------------------	---

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	Privileged Execute mode.
---------------	--------------------------

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>General read-write user.</p> <p>At stages of chassis and interface setup, you need to reinitialize chassis firmware or restore interface card configurations. Use the reload command because it allows the chassis to close files and prepare for shutdown. The reload command brings down the entire Server Switch and restarts all of the cards in the Server Switch.</p> <p>The Server Switch prompts you to verify the reload. If you have not already saved configuration changes, and the Server Switch detects the changes, it prompts you to save. To store the new configuration as the startup configuration, enter yes at the prompt. To store the configuration elsewhere under a different file name, enter the new file name and press Enter.</p> <p>The system reinitializes itself and then loads the active system image and the startup configuration file. Wait a few minutes and attempt to log onto the chassis.</p>
------------------	---



Note

If your Server Switch includes a second controller card, the CLI will prompt you to save changes to the backup controller as well as to the primary controller.

Examples	<p>The following example reloads the Server Switch:</p> <pre>SFS-7000P# reload System configuration has been modified. Save? [yes(default)/no/*.cfg] yes Proceed with reload? [confirm] SFS-7000P# Connection to host lost. #</pre>
----------	---

Related Commands

[boot-config](#)
[broadcast](#)
[install](#)
[who](#)
[show boot-config](#)

save-log

To save a log file of the last 40 commands that you entered, enter the **save-log** command in Privileged Exec mode.

save-log [*filename*]

Syntax Description	<i>filename</i> (Optional) Name of the file you create to store your command history.
Defaults	<p>If you do not provide a name for the log file, your Server Switch assigns a name with the following format:</p> <p>savelog.mmddhhmmss</p> <p>where <i>mmddhhmmss</i> represents the system UTC time.</p>
Command Modes	Privileged Execute mode.
Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>General read-write user.</p> <p>Your Server Switch stores save-log files to the syslog directory. To execute the commands in the save-log file, copy the file to a host, edit it appropriately, copy it to the config file system on a Server Switch, and run the exec command.</p>
Examples	<p>The following example saves the last 40 commands as a file called mylog.log:</p> <pre>SFS-7000P# save-log mylog.log</pre>
Related Commands	<p>exec</p> <p>history</p>

shutdown

Use the **shutdown** command to disable any of the following:

- A specific interface card or port
- An Ethernet Management port
- An InfiniBand Management port
- A power supply

Enter the **shutdown** command in the appropriate configuration submode. To enable any of these elements, use the **no** form of this command.

shutdown

no shutdown

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Card Configuration (config-card) submode, Ethernet Management Interface Configuration (config-int-mgmt-ethernet) submode, InfiniBand Management Interface Configuration (config-int-mgmt-ib) submode, Ethernet Interface Configuration (config-if-ether) submode, InfiniBand Interface Configuration (config-if-ib) submode, Fibre Channel Interface Configuration (config-if-fc) submode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted or card-specific read-write user.

Enabling/Disabling a card:

Before you use the **action** command on a card, you must enable (bring up) the card. To enable or disable a card, follow these steps:

-
- Step 1** In User Exec mode, enter the **enable** command to enter Privileged Exec mode.
 - Step 2** Enter the **configure terminal** command to enter Global Configuration mode.
 - Step 3** Enter the **card** command and specify the card or cards that you want to enable.
 - Step 4** Enter the **shutdown** command or the **no shutdown** command to disable or enable the cards that you specified in the previous step.
-

When you use the **shutdown** command to disable a card, the card stops processing packets and powers down.

Enabling/Disabling an interface port:

You cannot update or delete the active system image on a card when you disable the card. Before you update the active system image on your Server Switch, enable all cards that you want to update. To enable or disable a port, follow these steps:

-
- Step 1** In User Exec mode, enter the **enable** command to enter Privileged Exec mode.
 - Step 2** Enter the **configure terminal** command to enter Global Configuration mode.
 - Step 3** Enter the **interface** command and appropriate keyword (**ethernet**, **fc**, or **ib**), then specify the port or ports that you want to enable.
 - Step 4** Enter the **shutdown** command or the **no shutdown** command to disable or enable the cards that you specified in [Step 3](#).
-

Enabling/Disabling the Ethernet Management Port:

You cannot update or delete the active system image on a card when you disable the card. Before you update the active system image on your Server Switch, enable all cards that you want to update. To enable or disable the Ethernet Management port, follow these steps:

-
- Step 1** In User Exec mode, enter the **enable** command to enter Privileged Exec mode.
 - Step 2** Enter the **configure terminal** command to enter Global Configuration mode.
 - Step 3** Enter the **interface mgmt-ethernet** command to enter Ethernet Management Interface Configuration submode.
 - Step 4** Enter the **shutdown** command or the **no shutdown** command to disable or enable the port.
-

You must enable the Ethernet Management port before you can configure it. Use the **no shutdown** command to bring up the Ethernet Management port before you assign IP and gateway addresses to the port.

When you disable the Ethernet Management port, the current configuration of the port remains intact. If you experience problems configuring the Ethernet Management port, first check that the admin-status field in the **show interface mgmt-ethernet** command output displays **up**.

Enabling/Disabling the Infiniband Management port:

You cannot update or delete the active system image on a card when you disable the card. Before you update the active system image on your Server Switch, enable all cards that you want to update. To enable or disable the InfiniBand Management port, follow these steps:

-
- Step 1** In User Exec mode, enter the **enable** command to enter Privileged Exec mode.
 - Step 2** Enter the **configure terminal** command to enter Global Configuration mode.
 - Step 3** Enter the **interface mgmt-ib** command to enter InfiniBand Management Interface Configuration submode.

Step 4 Enter the **shutdown** command or the **no shutdown** command to disable or enable the port.

The InfiniBand Management port provides Telnet, SSH, and Element Manager access to InfiniBand hosts that run IPoIB and connect to any of the InfiniBand ports on your Server Switch. With the IB management port, you can run management applications over IPoIB.

**Note**

You must configure the IP address and gateway of the Infiniband Management port through the Serial Console terminal. Use the **ip** and **gateway** commands.

Examples

The following example enables interface card 12:

```
SFS-7000P(config-card-12)# no shutdown
```

The following example enables the interface Management Ethernet port:

```
SFS-7000P(config-if-mgmt-ethernet)# no shutdown
```

The following example enables the interface Management IB port:

```
SFS-7000P360(config-if-mgmt-ib)# no shutdown
```

The following example sets the admin-status field for ports 1 through 6 on InfiniBand card 15 to **up**:

```
SFS-7000P(config-if-ib-15/1-15/6)# no shutdown
```

Related Commands

[action](#)
[auto-negotiate](#)
[card](#)
[gateway](#)
[ip](#)
[link-trap](#)
[show card](#)
[show fc srp initiator](#)
[show interface mgmt-serial](#)
[type](#)

snmp-server

To store contact and location information and to configure the SNMP notification host and SNMPv3 user, enter the **snmp-server** command in Global Configuration mode. To replace these values with empty strings, enter the **no** form of this command.

```
snmp-server { contact "contact-string" | engineID local engine-string | host dest
[community-string] [recv-event-traps] | location "location-string" | enable traps
authentication }
```

```
snmp-server user username { disable | enable | privilege privileges | v3 [encrypted] auth
{md5 | sha} password [priv des56 privacy]}
```

```
no snmp-server { contact | host ip-address [recv-event-traps] | location | user username v3 |
enable traps authentication }
```

Syntax Description

contact	Stores the contact information for your Server Switch. This contact information appears in the show version command output.
host	Configures your Server Switch to communicate with the host that receives SNMP traps from your Server Switch.
engineID	Configures a SNMPv3 engine ID.
local	Configures the engine ID of the local agent.
engine-string	Engine ID, as a 15-octet string.
location	Stores location information about your Server Switch. This contact information appears in the show version command output.
contact-string	ASCII text string of contact information.
dest	IP address or DNS name of an SNMP server.
community-string	(Optional) SNMP community string that authenticates your Server Switch to the SNMP server.
recv-event-traps	(Optional) Configures the Server Switch to send SNMP traps to the receiver. If you configure this keyword, the remote host receives SNMP events as well as traps.
location-string	ASCII text string of location information.
user	Specifies the user ID that you want to configure.
username	User ID that you want to configure.
disable	Disables the SNMP user.
enable	Enables the SNMP user.
privilege	Assigns privileges to the user.
enable traps authentication	Generates a trap each time a user is blocked from accessing the system.

<i>privileges</i>	Privileges to apply to the user. The privileges may be any combination of the following: <ul style="list-style-type: none"> • ib-ro • ib-rw • ip-ethernet-ro • ip-ethernet-rw • fc-ro • fc-rw • unrestricted-rw You must enter whichever privileges you include in the order in which they appear above.
v3	Configures a user with the SNMPv3 security model.
encrypted	(Optional) Specifies passwords as digests
auth	Configures authentication parameters for the user.
md5	Specifies md5 authentication.
sha	Specifies sha authentication.
<i>password</i>	Authentication password to assign to the user.
priv	(Optional) Configures privacy for the user and assigns a privacy password.
des56	(Optional) Configures the privacy type.
<i>privacy</i>	Privacy password.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

The **snmp-server** contact string appears when you view system version or SNMP information.

The **snmp-server** host string appears in the **show snmp** command output.

The **host** keyword configures the IP address of the host that you want to receive traps.

**Note**

SNMPv3 configurations are not portable across Server Switches. You must configure SNMPv3 individually on each chassis. If you migrate a configuration file from one chassis to another, the SNMPv3 section does not appear.

Examples

The following example stores contact information on your Server Switch and assigns a SNMP server to your Server Switch:

```
SFS-7000P(config)# snmp-server contact "support@cisco.com"  
SFS-7000P(config)# snmp-server host 10.3.106.99 secret
```

The following example inputs user “dog” with the SNMPv3 security model, assigns md5 authentication, a password of “cat,” and assigns des56 privacy with a password of “fish” in the configuration:

```
SFS-270(config)# snmp-server user dog v3 auth md5 cat priv des56 fish
```

Related Commands

[gateway](#)
[radius-server](#)
[ntp](#)
[location](#)
[logging](#)

speed

To configure the connection speed between Fibre Channel interface ports on your Server Switch and Fibre Channel devices, enter the **speed** command in Fibre Channel Interface Configuration submode.

To assign an Ethernet connection speed to a port or ports, enter the **speed** command in Ethernet Interface Configuration submode.

speed *speed*

Syntax Description

<i>speed</i>	Integer value that configures the speed (in Mbps) of the connection between your Server Switch and a Fibre Channel device or Ethernet device. For Fibre Channel, enter 1000 for 1 Gbps or 2000 for 2 Gbps.
--------------	--

Defaults

By default, Fibre Channel connections run at 2000 Mbps (2 Gbps).

Command Modes

Fibre Channel Interface Configuration (config-if-fc) mode, Ethernet Interface Configuration (config-if-ether) submode, InfiniBand Interface Configuration (config-if-ib) submode (select Server Switches).

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user, Fibre Channel read-write user, Ethernet read-write user, InfiniBand read-write user.

Fibre Channel:

The speed of a connection does not necessarily match the speed that you configure. If your connection cannot physically connect at the speed that you specify, the connection runs at a slower speed that your Server Switch automatically detects. As soon as a physical change makes your speed setting possible, the connection will run at the speed that you specified.



Note

You cannot manually configure connection speed you enable auto-negotiation. Enter the **no auto-negotiate** command before you manually configure connection speed.

Ethernet:

The **speed** command sets the administrative speed (the speed that you want) only. Self-detection determines the actual speed, which depends on the capabilities of the connection. You must disable the auto-negotiation feature to manually configure speed.

InfiniBand:

The **speed** command sets the administrative speed only. Self-detection determines the actual speed, which depends on the capabilities of the connection. You must disable the auto-negotiation feature to manually configure speed.

Examples

The following example sets the preferred speed to 1,000 Mbps (1 Gbps). The results of this command may be viewed in the admin-speed field for Fibre Channel interfaces using the **show interface fc** command:

```
SFS-7000P(config-if-fc-5/4)# speed 1000
```

The following example sets the ethernet interface (slot 4, port 1) to a speed of 100 Mbps:

```
SFS-7000P(config-if-ether-4/1)# speed 100
```

The following example sets all InfiniBand interfaces on a Cisco SFS 7000 to a speed of 4x:

```
SFS-120(config-if-ib-1/1-1/24)# speed 4x
```

Related Commands

[auto-negotiate](#)
[half-duplex](#)
[show fc srp initiator](#)
[show interface ethernet](#)

system-mode

To configure your Server Switch to deny changes to SRP configuration to preserve VFrame-authorized configurations, enter the system-mode command in Global Configuration mode.

system-mode { normal | vframe-210 }

Syntax Description	normal	Grants all users with appropriate access levels to configure SRP on the Server Switch.
	vframe-210	Prevents changes to the SRP configuration on the Server Switch so as to preserve the VFrame SRP configuration.

Defaults By default, authorized users can manually alter the SRP configuration.

Command Modes Global Configuration mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user, Fibre Channel read-write user

Configure the system-mode of all switches in a VFrame environment to vframe-210 to avoid manual SRP configuration changes that interfere with the VFrame SRP configuration.

Examples The following example locks the SRP configuration for VFrame purposes:

```
SFS-7000P(config)# system-mode normal
```

Related Commands

- [fc srp initiator](#)
- [fc srp initiator-wwpn](#)
- [fc srp it](#)
- [fc srp itl](#)
- [fc srp lu](#)
- [fc srp target](#)
- [fc srp-global gateway-portmask-policy restricted](#)
- [fc srp-global itl](#)
- [fc srp-global lun-policy restricted](#)

system ib-counter-reset

To disable the regular resetting of IB port counters on your server switch, enter the system **ib-counter-reset** command in Global Configuration mode. To reenable the regular resetting of IB port counters on your server switch, use the no form of this command.

```
system ib-counter-reset

no system ib-counter-reset'
```

Syntax Description	This command has no arguments or keywords.
Defaults	Counter resetting is enabled.
Command Modes	Global Configuration mode.
Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted and general read-write user.</p> <p>'Use the system ib-counter-reset command to enable or disable the regular resetting of IB port counters. This is a global, chassis-wide setting that allows you to stop all IB port agents from resetting the IB port counters.</p>
Examples	<p>"The following example disables the regular resetting of IB port counters:</p> <pre>SFS-7000P(config)# no system ib-counter-reset</pre>

telnet

To enable or disable telnet services on your Server Switch, enter the **telnet** command in Privileged Exec mode.

telnet {enable | disable}

Syntax Description

This command has no arguments or keywords.

Defaults

By default, telnet services run on your Server Switch.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write access.

Disable the telnet feature to restrict access to your Server Switch to SSH only. Your Server Switch supports two concurrent telnet log-ins (in addition to the Serial log-in, if applicable).

Examples

The following example enables telnet access to the Server Switch:

```
SFS-7000P(config)# telnet enable
```

Related Commands

[ftp-server enable](#)
[history](#)
[more](#)
[show interface mgmt-ib](#)
[show system-services](#)

terminal

To configure

- the maximum number of lines that appear on the terminal screen when you enter commands that display multiple lines of output,
- the duration of idle time that triggers your Server Switch to automatically log you out and end your CLI session

enter the **terminal length** command in User Exec mode or Privileged Exec mode. To restore these settings to default values, use the **no** form of this command.

terminal {**length** *number-of-lines* | **time-out** *minutes*}

terminal no {**length** | **time-out**}

Syntax Description	length	Specifies the number of lines that appear on the screen when you run commands such as the more command an on-line help (?).
	<i>number-of-lines</i>	Number (integer) of lines that appear on the screen when you run commands such as the more command. Enter 0 to disable paging and display all output at once.
	time-out	Specifies the amount of idle time that your Server Switch allows before it logs a user out of the CLI.
	<i>minutes</i>	Number of minutes (integer ranging from 1 to 100000) of idle time that prompts your Server Switch to end your CLI session and log you out.

Defaults	By default, the CLI displays 24 lines per screen.
	By default, your Server Switch logs you out after 15 minutes of inactivity.

Command Modes	User Execute mode, Privileged Execute mode.
---------------	---

Usage Guidelines	Platform Availability:
	Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter
	Privilege Level:
	General read-only user.

- length

A *number-of-lines* value of 0 turns off paging and displays data on the screen without stopping until completed. We recommend that you set the terminal page length to 0 when you use the **show logging** command with the **end** argument. Otherwise, you will have to keep pressing the space bar to continue each time the maximum display length prints. The **no** form of this command resets the terminal length to the default.

The number of lines specified only applies to the current CLI session. Other users are unaffected by changes to the display length.

NOTE: If you set the page length to 0 to disable paging, do not change the terminal window size. Changing window size restores the terminal length to that of the window and re-enables paging.

- time-out

Changes to this parameter apply immediately to all users and continue to apply to users who log in after you configure the timeout value. Enter **0** to disable timeouts.

NOTE: System timeouts apply if you use Telnet or SSH to connect to your Server Switch.

Examples

The following example configures the CLI to display 66 lines of display output at a time:

```
SFS-7000P# terminal length 66
```

The following example configures the CLI to time out after 60 minutes:

```
SFS-7000P# terminal time-out 60
```

Related Commands

[logging](#)
[more](#)
[show logging](#)
[show system-services](#)

trace

To track internal Server Switch program modules that specific interface cards call, enter the **trace** command in Global Configuration mode.



Note

Use this command only under the direction of support personnel for program debug purposes.

```
trace app app module mod level { no-display | very-terse | terse | verbose | very-verbose |
scream } flowmask val [card slot]
```

Syntax Description

app	Identifies an internal application to trace.
module	Identifies a program module to trace within the specified application.
level	Specifies the verbosity level of the trace command output.
flowmask	Masks modules that you do not want to display.
card	(Optional) Identifies the card to trace.
no-display	Disables tracing when you also set the <i>val</i> variable to 0x00.
very-terse	Contact technical support for details.
terse	Contact technical support for details.
verbose	Contact technical support for details.
very-verbose	Contact technical support for details.
scream	Contact technical support for details.
<i>app</i>	Integer that indicates the internal application to trace.
<i>mod</i>	Program module within the application.
<i>val</i>	Decimal or hexadecimal value of modules to mask. A value of 0xFFFFFFFF masks all modules. A value of 0x00 displays all modules.
<i>slot</i>	(Optional) Slot number of the card to trace.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-write user.

Use this command to debug your system.

The number of applications and modules may change between releases. The numbers assigned to applications and modules may also change. Check application and module number assignments using CLI help (?) before you execute this command, as shown in the example below.

Examples

The following example displays the applications that you can trace (output abridged):

```
SFS-7000P(config)# trace app ?
app <1-25>
app numbers:
APP_ID_CLI          = 1
APP_ID OSPF         = 2
APP_ID RIP          = 3
...
...
APP_ID_IP_AGENT     = 22
APP_ID_FIB_AGENT    = 23
APP_ID_KERNEL       = 24
APP_ID_CARD_AGENT   = 25
APP_ID_SM           = 26
```

The following example enables tracing for application 4, module 36:

```
SFS-7000P(config)# trace app 4 module 36 level very-verbose flowmask 0x12 card 2
```

Related Commands

[help](#)
[show trace](#)

type

To assign an administrative card-type to a slot into which you want to install a card, enter the **type** command in Card Configuration submode.

```
type card-type
```

Syntax Description	card-type	Type of card in the slot. See Table 2-3 for available card types.
--------------------	-----------	---

Defaults	This command has no default settings.	
----------	---------------------------------------	--

Command Modes	Configuration Card (config-card) mode.	
---------------	--	--

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted or card-specific read-write user.</p> <p>Use the type command to reserve slots for particular card types. For instance, if you want a slot to run only Fibre Channel gateway cards, configure the type of the slot to “fc2port2G” so that only that card type will function in the slot. Any other card that you place in the slot will not function. Table 2-3 lists and describes available card types.</p>	
------------------	---	--

Table 2-3 Card Types

Type	Description
controller	Configures the slot for a Cisco SFS 3012 controller card.
controllerIb12port4x	Configures the slot for a Cisco SFS 3001 controller card with 12 4x InfiniBand ports.
controllerIb24port4x	Configures the slot for a Cisco SFS 7000 controller card with 24 4x InfiniBand ports.
en4port1G	Configures the slot for a 4-port, 1Gbps Ethernet gateway.
en6port1G	Configures the slot for a 6-port, 1Gbps Ethernet gateway.
fabric12x	Configures a slot in a Cisco SFS 7008 for a fabric controller module (FCM).
fc2port2G	Configures the slot for a 2-port, 2Gbps Fibre Channel gateway.
fc4port2G	Configures the slot for a 4-port, 2Gbps Fibre Channel gateway.
ib12port4x	Configures the slot for a 12-port, 4X InfiniBand switch card.
ib12port4xTX	Configures a slot in a Cisco SFS 7008 for a line interface module (LIM) with twelve 4x InfiniBand ports.

Table 2-3 **Card Types**

Type	Description
ib14port1x4port4x	Configures a Cisco 4x InfiniBand Switch Module for IBM BladeCenter to run four 4x ports and not one 4x port and one 12x port.
ib24port4x	Configures the slot for a 24-port, 4X InfiniBand switch card.
mgmtIO	Configures the slot for a Cisco SFS 7008 management I/O card.

Examples

The following example assigns a card-type to the expansion module slot on a Cisco SFS 3001:

```
SFS-7000P(config-card-2)# type en4port1G
```

The following example assigns a card-type to expansion modules 2 through 4 on a Cisco SFS 3012:

```
SFS-7000P(config-card-2-4)# type en4port1G
```

Related Commands

[shutdown](#)
[show card](#)

username

To reconfigure or create and configure user accounts, enter the **username** command in Global Configuration mode. To delete a user account, use the **no** form of this command.

username *user* **password** *passwd*

Creates a new user account.

username *user* {[**disable** | **enable**] | [**community-string** *string* / **no-community-string**] | **privilege** *priv*[*priv priv...*]}

Reconfigures an existing user account

no username *user*

Deletes an existing user account.

Syntax Description	password	Configures the password for the user account.
	disable	(Optional) Disables the user account.
	enable	(Optional) Enables the user account.
	community-string	(Optional) Assigns a SNMP community string to the user account.
	no-community-string	(Optional) Clears the SNMP community string of the user.
	privilege	Assigns access privileges to the user.
	Note When you assign privileges, new privileges completely overwrite your previous privilege settings. If you omit an access privilege, the user account will lose this privilege even if you previously assigned it to the account.	
	<i>user</i>	Account login name (up to 20 alphanumeric characters).
	<i>passwd</i>	Account password (5 to 34 alphanumeric characters).
	<i>string</i>	SNMP community string.
	<i>priv</i>	(Optional) Access privilege. The <i>priv</i> variable may be any of the following: <ul style="list-style-type: none"> ib-ro, for InfiniBand read-only access ib-rw, for InfiniBand read-write access ip-ethernet-ro, for Ethernet read-only access ip-ethernet-rw, for Ethernet read-write access fc-ro, for Fibre Channel read-only access fc-rw, for Fibre Channel read-write access unrestricted-rw, for universal read-write access

Defaults Guest user accounts are disabled by default. All other user accounts are enabled.

Command Modes Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user or general read-write user (change own password only).

The **username** command

- Creates and remove user accounts. The default CLI user accounts are guest, admin, and super.
- Changes user password. A user with read-write access may change their own password.
- Assigns access levels based upon functional areas, such as Fibre Channel, Ethernet, and InfiniBand administrative areas. Access levels may be unrestricted or read-only or read-write for the various administrative areas. Unrestricted indicates super user.
- Enables or disables the account.
- Associates user accounts with SNMP community strings. This community string serves as the password for Element Manager access.

You must create the user account with the **password** keyword before you can configure the account. By default, the Server Switch provides the unrestricted user login **super** (that uses a default password of **super**). This login uses **secret** as its default SNMP community string. SNMP community strings provide the user credentials necessary to access Management Information Base (MIB) object.

Each user login uses one unique community string and one password. A login must use a community string to launch an Element Manager session. To restrict a deny a user access to SNMP, do not provide the login with a community string.

**Note**

SNMP community strings are sent across the network in UDP packets with no encryption.

By default, new user accounts have read-only access. You may grant write privileges to a user for functional areas, such as InfiniBand, Ethernet, and Fibre Channel. Privileges are order-dependent. You must enter multiple access privileges in the following order:

1. ib-ro
 2. ib-rw
 3. ip-ethernet-ro
 4. ip-ethernet-rw
 5. fc-ro
 6. fc-rw
 7. unrestricted-rw
-

When changing the privileges of an existing user, specify all the privileges allowed to the user (including re-entering existing privileges) because the privilege argument removes all existing privileges and replaces them with them with the new ones.

For security purposes, since multiple users exist on the system, we recommend that you change the default passwords after initial configuration. The default user accounts are listed in the table below.

Table 2-4 **Default User Accounts**

Username	Password	Privilege
super	By default, the password is super . The default community string is secret .	The super user has unrestricted privileges. Use this account to manage any part of the system. This user may view and modify a configuration, as well as administer user accounts and access privileges. This user configures the console and management ports for initial chassis setup.
admin	By default, the password is admin . The default community string is private .	The admin user has general read-write privileges. This user may view and modify the current configuration. However, the admin user can change only its own user information, such as the admin password.
guest	The default password is guest . The default community string is public .	The guest user has read-only privileges. This user may only view the current configuration. The guest user cannot make any changes during the CLI session.

Examples

The following example creates a user with InfiniBand and Fibre Channel administrative privileges, as well as an SNMP community-string:

```
SFS-7000P(config)# username ib-fc_admin password ibFcAdmin
SFS-7000P(config)# username ib-fc_admin community-string ibFc-commStr
SFS-7000P(config)# username ib-fc_admin privilege ib-rw ip-ethernet-ro fc-rw
SFS-7000P(config)# username ib-fc_admin enable
SFS-7000P(config)# exit
SFS-7000P# show user ib-fc_admin
=====
User Information
=====
      username : ib-fc_admin
      password : $1$JwCI/25k$3aCHn3BAQcTF3V2PGv1m7.
      snmp-community : ibFc-commStr
      permission-level : ib-rw, ip-ethernet-ro, fc-rw
      admin-status : enabled
      num-logins : 0
      num-unsuccessful-logins : 0
      last-login :
      last-unsuccessful-login :
SFS-7000P#
```

The following example disables a user account but does not delete it:

```
SFS-7000P(config)# username ib-fc_admin disable
```

The following example deletes a user account:

```
SFS-7000P(config)# username ib-fc_admin no
```

Related Commands

[show user](#)

who

To display

- the users currently connected to your Server Switch,
- the host system from which each connected user logged in,

enter the **who** command in User Exec mode or Privileged Exec mode.

who

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use this command before you reboot the Server Switch so you can broadcast a message about impending reboots if other users have sessions open to the Server Switch.

Examples

The following example displays the users on the Server Switch:

```
SFS-7000P# who
super          Console
super          10.10.253.47
admin          10.10.196.8
SFS-7000P#
```

Related Commands

[broadcast](#)
[reload](#)
[write](#)

write

To send a text message to another CLI user, enter the **write** command in User Exec mode or Privileged Exec mode.

```
write user "string"
```

Syntax Description

<i>user</i>	User account to which you want to send a message.
<i>string</i>	Text that you want to send to the other user.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Use the **write** command to send messages about administrative functions that impact individual users.

Examples

The following example sends a message to the admin user:

```
SFS-7000P# write admin "Please reconnect ib1 to the switch card."
```

Related Commands

[broadcast](#)
[who](#)



Fibre Channel Commands

This chapter documents the following commands:

- [fc srp initiator, page 3-2](#)
- [fc srp initiator-wwpn, page 3-5](#)
- [fc srp it, page 3-7](#)
- [fc srp itl, page 3-9](#)
- [fc srp lu, page 3-13](#)
- [fc srp target, page 3-17](#)
- [fc srp-global gateway-portmask-policy restricted, page 3-18](#)
- [fc srp-global itl, page 3-19](#)
- [fc srp-global lun-policy restricted, page 3-23](#)



Note

If you enter a Fibre Channel command and receive an error message that reads, “Operation temporarily failed - try again,” give your Fibre Channel gateway time to finish initializing, then retry the command.

fc srp initiator

To configure an initiator—normally a SAN-attached host but in IB terms a SRP host combined with a Server Switch—to communicate with a Fibre Channel SAN across a Fibre Channel gateway on your Server Switch, enter the **fc srp initiator** command in Global Configuration mode. To deny SAN access to the SRP host, to delete an initiator from the running configuration, or to reconfigure the description of the initiator to an empty string, use the **no** form of this command.

```
fc srp initiator guid extension { auto-bind | bootup target target-wwpn lu logical-unit |
description descr | discover-itl | pkey pkey-value | wwnn wwnn-value }
```

```
no fc srp initiator guid extension [description]
```

Syntax Description	
<i>guid</i>	Global unique identifier (GUID) of the SRP host. Note The GUID of your SRP host appears printed on the HCA in your server, and you can use host driver utilities to view the GUID. For more information, refer to the <i>Host Channel Adapter Installation Guide</i> .
<i>extension</i>	GUID extension of the SRP host.
auto-bind	<ol style="list-style-type: none"> 1. Creates the initiator entry in the configuration file and binds the host to a world-wide node name (WWNN) that your Server Switch generates internally to uniquely identify the host. 2. Creates virtual ports for this initiator on every possible physical FC gateway port on your Server Switch. FC devices use these virtual ports to communicate with the initiator.
bootup	Configures the SRP host to boot from a Fibre Channel logical unit (LU).
target	Specifies the world-wide port name (WWPN) of the port of the FC storage device that stores image that you want the initiator to boot.
<i>target-wwpn</i>	WWPN of the port of the FC storage device that stores image that you want the initiator to boot.
lu	Specifies the logical unit (LU) that stores image that you want the initiator to boot.
<i>logical-unit</i>	Logical ID of the LU that stores image that you want the initiator to boot.
description	(Optional) Assigns an alphanumeric ASCII description string to the initiator.
<i>descr</i>	Alphanumeric ASCII description string to assign to the initiator.
discover-itl	Discovers initiator-target-LUN (ITL) combinations and adds them to your configuration file. Targets refer to SAN storage devices, and LUNs refer to the logical units within SAN storage devices.
pkey	Assigns a partition key (P_key) to the initiator. Note Your Server Switch does not currently support partition keys for SRP.
<i>pkey-value</i>	16-bit partition key to assign to the initiator. Assign multiple partition keys by appending a colon, then the next key (aa:aa:bb:bb:cc:cc:dd:dd).

wwnn	Creates the initiator entry in the configuration file and assigns a manually-entered WWNN to the initiator.
<i>wwnn-value</i>	WWNN to assign to the initiator.

Defaults

By default, no P_keys apply to initiators. By default, global policies apply to initiators. Configure global policies with **fc srp-global** commands.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user, Fibre Channel read-write user

Configure initiators so SRP hosts can communicate with SANs.

**Note**

When you configure new initiators, those initiators inherit the global policies that exist at that time. When you change global policies, the new global policies do not apply to existing initiators.

Before you can customize an initiator, you must create an initiator entry with the **auto-bind** keyword or the **wwnn** keyword. Once you identify a host as an initiator, you can customize the initiator with the remaining keywords.

Command Keyword Usage Guidelines:

- auto-bind

You must create initiators and assign, or *bind*, a WWNN (an identifier that FC devices recognize) to each initiator so that FC devices can communicate with initiators. When you use the **auto-bind** keyword to create an initiator and generate a WWNN for an initiator, your Server Switch creates a virtual port (NL_Port) that represents the initiator on every physical port on the FC gateway. Your Server Switch assigns an internally-generated WWPNN to each virtual port. Each physical port on the FC gateway supports 32 virtual ports to form a virtual FC arbitrated loop.

**Note**

We strongly recommend that you use the **auto-bind** keyword to assign WWNNs to initiators as you configure the initiators. If you do manual configuration, you may create duplicate WWNNs that create traffic conflicts.

- description

Enter a description to help identify an initiator without reading its GUID and extension.

- discover-itl

Discover ITLs to add all available initiator-target-LUN (ITL) groups to the running configuration. For detailed information on ITLs, refer to the *Fibre Channel Gateway User Guide*.

- pkey

Refer to the *Element Manager User Guide* to learn more about partitions.

- wwnn

When you enter a question mark (?) after the **wwnn** keyword, the CLI provides a recommended WWNN value.

Examples

The following example adds an initiator to the running configuration and automatically configures the WWNN of the initiator and the WWPNS of the virtual ports that point to the initiator from the physical FC gateway ports:

```
SFS-7000P(config)# fc srp initiator 00:00:2C:90:01:1b:b7:50 00:00:00:00:00:00:00:00
auto-bind
```

The following example assigns the description **InfiniBand Host** to an existing initiator. The name now appears in the **show fc srp initiator** command output:

```
SFS-7000P(config)# fc srp initiator 00:00:2C:90:01:1b:b7:50 00:00:00:00:00:00:00:00
description "InfiniBand Host"
```

The following example discovers all potential initiator-target-LUN (ITL) combinations that your Server Switch can support and adds them to the running configuration. To view the results of this command, enter the **show fc srp itl** command:

```
SFS-7000P(config)# fc srp initiator 00:00:2C:90:01:1b:b7:50 00:00:00:00:00:00:00:00
discover-itl
```

Related Commands

[fc srp-global lun-policy restricted](#)
[show fc srp initiator](#)

fc srp initiator-wwpn

To manually create, on a physical FC gateway port, a virtual port that points to an initiator, enter the **fc srp initiator-wwpn** command in Global Configuration mode.

fc srp initiator-wwpn *guid extension slot#/port# wwpn*

Syntax Description	<i>guid</i>	Global unique identifier (GUID) of the SRP host (initiator) that you want to connect to a Fibre Channel SAN.
	<i>extension</i>	GUID extension of the SRP host that you want to connect to a Fibre Channel SAN.
	<i>slot#</i>	Slot of the FC gateway expansion module that you want to use.
	<i>port#</i>	Fibre Channel gateway port that you want to use to connect your initiator to the SAN.
	<i>wwpn</i>	WWPN to assign to the new virtual port.

Defaults This command has no default settings.

Command Modes Global Configuration (config) mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user or Fibre Channel read-write user.

Configure WWPNs for initiators so that FC devices can recognize them and communicate with them. With virtual ports (NL_ports), physical FC ports can point to multiple initiators, and multiple ports can point to the same initiator. For instance, if you have Initiators X and Y and Physical FC Ports A and B, you can create the following virtual ports:

- virtual port AX on port A that points to initiator X
- virtual port AY on port A that points to initiator Y
- virtual port BX on port B that points to initiator X
- virtual port BY on port B that points to initiator Y

As you can see, in this way, multiple virtual ports can point to one initiator and individual physical ports can support multiple initiators.

When you enter a question mark (?) after the *port#* variable, the CLI provides a suggested WWPN value.



Note

Use the recommended WWPN unless you have a compelling reason to do otherwise. We *strongly* recommend that you use the **fc srp initiator** command with the **auto-bind** keyword to create initiator entries and assign WWPNs to initiators.

Examples

The following example uses the online help (?) to find the recommended WWPn value, then configures a virtual port on port 1 on the FC gateway expansion module in slot 7:

```
SFS-7000P(config)# fc srp initiator-wwpn 00:00:2c:90:01:1b:b7:50 00:00:00:00:00:00:00:00
7/1 ?
<wwpn>                                - wwpn
Suggested wwpn = 20:03:00:05:ad:70:00:02
SFS-7000P(config)# fc srp initiator-wwpn 00:00:2c:90:01:1b:b7:50 00:00:00:00:00:00:00:00
7/1 20:03:00:05:ad:70:00:02
SFS-7000P(config)#
```

Related Commands

[fc srp initiator](#)
[show fc srp initiator](#)

fc srp it

To configure an *initiator-target* (IT) pair—a fully-configured link between an initiator and a target storage device port—with your Server Switch, enter the **fc srp it** command in Global Configuration mode. To delete or reconfigure an IT pair entry from the configuration file, use the **no** form of this command.

```
fc srp it guid extension wwpn { description “descr” | discover-itl | gateway-portmask-policy
{ default | test-mode | restricted port-selection } }
```

```
no fc srp it guid extension wwpn [test-mode | gateway-portmask-policy restricted
port-selection]
```

Syntax Description

<i>guid</i>	Global unique identifier (GUID) of the initiator.
<i>extension</i>	GUID extension of the initiator.
<i>wwpn</i>	World-wide port name (WWPN) of the target port of the FC storage device.
description	Assigns a description to the initiator-target pair.
<i>descr</i>	Alphanumeric description to assign to the initiator target.
discover-itl	Discovers initiator-target-LUN (ITL) groups for the specified target and adds them to the configuration file. For detailed information on ITLs, refer to the <i>Fibre Channel Gateway User Guide</i> .
gateway-portmask-policy	(Optional) Designates the physical FC gateway ports that the initiator can use to access the storage port. When you add FC gateway ports to the policy, the initiator cannot use those ports to access the storage. When you use the no keyword to remove FC gateway ports from the policy, the initiator can access the storage through those ports.
default	Assigns the global gateway portmask policy to the IT. To view your default policy, enter the show fc srp-global command (in User Exec mode or Privileged Exec mode) and view the default-gateway-portmask-policy field.
restricted	(Optional) Denies the initiator access to the ports that you specify with the <i>port-selection</i> variable. Use the no form of the command to add ports to the policy to grant the initiator access.
<i>port-selection</i>	(Optional) Port, list of ports, or range of ports to which you grant or deny the initiator access.
test-mode	(Optional) Sets an inactive initiator-target pairing to test mode, which configures the FC gateway to log in to storage persistently and block log-ins from SRP hosts (initiators). Use test mode as you set up your Fibre Channel connections, then use the no form of the command to return to normal mode. Note You cannot configure an active IT to test mode. Active ITs must remain in normal mode. Note A test-mode configuration does not persist across reboots.

Defaults

By default, this policy denies initiators access to all targets.

Command Modes Global Configuration (config) mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user or Fibre Channel read-write user.

The **fc srp it** command sets policies that control the extent to which the initiator accesses Fibre Channel gateway ports. Use the **no** form of this command with the **gateway-portmask-policy** keyword to grant an initiator access to the ports you specify.



Note

We strongly recommends that you let your Server Switch populate the running configuration with IT pairs; do not manually enter IT pairs.

Examples The following example assigns a description of **entry** to an existing IT:

```
SFS-7000P(config)# fc srp it 00:00:2c:90:01:1b:b7:40 00:00:00:00:00:00:00:00
21:00:00:04:cf:75:6b:3b description "entry"
```

```
Topspin-360(config)# fc srp it 00:02:c9:02:00:40:0e:d4 00:00:00:00:00:00:00:00 2
1:00:00:04:cf:86:a0:1f test-mode
Topspin-360(config)# fc srp it 00:02:c9:02:00:40:0e:d4 00:00:00:00:00:00:00:00 2
1:00:00:04:cf:86:a0:1f normal-mode
Error: Unrecognized command
```

```
Topspin-360(config)# no fc srp it 00:02:c9:02:00:40:0e:d4 00:00:00:00:00:00:00:00
0 21:00:00:04:cf:86:a0:1f test-mode
Topspin-360(config)#
```

Related Commands [fc srp-global gateway-portmask-policy restricted](#)
[show fc srp it](#)
[show interface fc](#)

fc srp itl

To configure an initiator-target-LUN (ITL) group—a fully-configured link between an initiator and Fibre Channel storage—on your Server Switch, enter the **fc srp itl** command in Global Configuration mode. To delete an ITL entry or reset the description of an ITL to an empty string, use the **no** form of this command.



Note

For a breakdown of the different actions that you can perform with the **fc srp itl** command, refer to [Table 3-1](#).

```
fc srp itl guid extension wwpn LUN {description "descr" |
dynamic-gateway-port-failover [default] |
dynamic-gateway-port-loadbalancing [default] | dynamic-path-affinity [default] |
gateway-portmask-policy {default | restricted {port-selection | all}} |
io-hi-mark mark [default] | lun-policy {default | restricted} | max-retry retry [default]
| min-io-timeout timeout [default] | srp-lunid lunid logical-id logical-id}
```

```
no fc srp itl guid extension wwpn LUN {description | dynamic-gateway-port-failover |
dynamic-gateway-port-loadbalancing | dynamic-path-affinity |
gateway-portmask-policy restricted port-selection | io-hi-mark | lun-policy
restricted | max-retry | min-io-timeout}
```

Syntax Description

<i>guid</i>	Global unique identifier (GUID) of the initiator.
<i>extension</i>	GUID extension of the initiator.
<i>wwpn</i>	World-wide port name (WWPN) of the target port of the FC storage device.
<i>LUN</i>	FC LUN ID of the FC storage disk.
description	Assigns a text description to the ITL.
<i>descr</i>	Alphanumeric description (up to 50 characters) to assign to the initiator-target-LUN.
dynamic-gateway-port-failover	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
default	(Optional) Sets an attribute to its global default value.
dynamic-gateway-port-loadbalancing	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
dynamic-path-affinity	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
gateway-portmask-policy	Defines the port restrictions that apply to the initiator for that ITL.
restricted	Denies the initiator access to select ports or LUNs for the ITL. Grants the initiator access to select ports or LUNs when you use the no keyword.
<i>port-selection</i>	Port, list of ports, or range of ports that the initiator can or cannot access for the ITL.

all	Specifies all ports.
lun-policy	Permits the initiator to access the LUN or denies the initiator access to the LUN.
io-hi-mark	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
<i>mark</i>	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
max-retry	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
<i>retry</i>	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
min-io-timeout	The fc srp itl command no longer supports this syntax. Note This syntax appears for legacy purposes. Use the config fc srp lu command to set this feature.
<i>timeout</i>	The fc srp itl command no longer supports this syntax. This syntax appears for legacy purposes.
srp-lunid	Specifies a LUN ID called the SRP LUN ID to which you map an existing FC LUN ID. Essentially, this keyword creates an alias LUN ID.
<i>lunid</i>	SRP LUN ID that maps to an existing FC LUN ID. This value appears in the srp-lunid field of the show fc srp itl command output.
logical-id	Specifies the FC LUN ID to map to the SRP LUN ID.
<i>logical-id</i>	Complete Logical ID (entered without colons, as per the example below) of the LU that maps to the user-created SRP LUN ID. This value appears in the fc-lunid field of the show fc srp itl command output.

Defaults

Default values and behaviors appear in the Syntax Description and [Table 3-1 on page 3-11](#).

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user or Fibre Channel read-write user.

The **fc srp itl** command configures new ITLs and sets policies to control access that the SCSI RDMA Protocol (SRP) initiator has to the Fibre Channel storage devices on a per-lun basis. An “initiator-target-lun” (ITL) identifies a fully-configured link between an initiator and storage.

When an ITL entry is created, the gateway-portmask-policy setting is independent of its IT entry. You may change the setting on a per ITL basis. However, a port is accessible for an ITL only when the port is accessible for both the IT and ITL entries.

The port list specified in this command creates an accumulative effect to the actual gateway-portmask-policy. For example, if your current mask is 2/1 and 2/2, after you enter the **config fc srp itl gateway-portmask-policy restricted 2/1** command, the result of the mask for this ITL would be 2/2. The same effect applies to the no-command for gateway-portmask-policy.

We recommend that you create ITLs with the **discover-itl** keyword in the CLI or the **Discover LUNs** button in Element Manager.

Table 3-1 *fc srp itl Command Usage Examples*

Example	Result
fc srp itl <i>guid extension wwpn LUN srp-lunid lunid logical-id logical-id</i>	Creates an SRP LUN ID alias for an existing FC LUN ID.
no fc srp itl <i>guid extension wwpn LUN</i>	Deletes an ITL entry from the ITL table.
fc srp itl <i>guid extension wwpn LUN description "descr"</i>	Assigns a text description to the ITL.
no fc srp itl <i>guid extension wwpn LUN description</i>	Resets the description of the ITL to an empty string.
fc srp itl <i>guid extension wwpn LUN gateway-portmask-policy restricted port-selection</i>	Denies the ITL access to the ports that you specify with the <i>port-selection</i> variable.
fc srp itl <i>guid extension wwpn LUN gateway-portmask-policy default</i>	Applies the current IT gateway-portmask-policy configuration to the ITL. The whole port list is copied from the IT entry to the ITL entry. You configure the default access with the fc srp-global gateway-portmask-policy restricted command.
no fc srp itl <i>guid extension wwpn LUN gateway-portmask-policy restricted port-selection</i>	Grants the ITL access to the ports that you specify with the <i>port-selection</i> variable. Default: An ITL entry inherits its gateway-portmask-policy configuration from its IT entry at entry creation time.
fc srp itl <i>guid extension wwpn LUN lun-policy restricted</i>	Denies the initiator access to the storage.
no fc srp itl <i>guid extension wwpn LUN lun-policy restricted</i>	Grants the initiator access to the storage.
fc srp itl <i>guid extension wwpn LUN lun-policy default</i>	Resets the LUN-policy to the global default. Set the default with the fc srp-global lun-policy restricted command.

Examples

This example denies the initiator access to port 1 of Fibre Channel interface card 6 for this ITL:

```
SFS-7000P(config)# fc srp itl 00:00:2c:90:01:1b:b7:40 00:00:00:00:00:00:00:00
21:00:00:04:cf:75:6b:3b 00:00:00:00:00:00:00:00 gateway-portmask-policy restricted 6/1
```

The following example creates a SRP LUN and maps a LU to it:

```
SFS-7000P(config)# fc srp itl 00:02:c9:01:07:fc:64:a0 00:00:00:00:00:00:00:00
21:00:00:04:cf:fb:8c:87 00:00:00:00:00:00:00:00 srp-lunid 01:01:01:01:01:01:01
logical-id 0103000820000004cffb8c870000000000000000000000000000000000000000
000000000000000000000000000000000000000000000000000000000000000000000000
```

Related Commands

[fc srp lu](#)
[fc srp target](#)
[show fc srp-global](#)
[show fc srp initiator](#)
[show fc srp it](#)
[show fc srp itl](#)
[show fc srp lu](#)

fc srp lu

To configure a logical unit, enter the **fc srp lu** command in Global Configuration mode. To delete a logical unit or to set a LU attribute to the factory default value, use the **no** form of this command.

```
fc srp lu logical-id {description "descr" | device-category {random target wwpn |  
  sequential target wwpn} | dynamic-gateway-port-failover [default] |  
  dynamic-gateway-port-loadbalancing [default] | dynamic-path-affinity [default] |  
  io-hi-mark mark [default] | max-retry retry [default] | min-io-timeout timeout  
  [default] | target wwpn}
```

```
no fc srp lu logical-id {dynamic-gateway-port-failover |  
  dynamic-gateway-port-loadbalancing | dynamic-path-affinity | target}
```

Syntax Description

<i>logical-id</i>	LU identifier in 64-byte, hexadecimal format <i>without colons</i> (see example).
description	Assigns a textual description to the LU.
<i>descr</i>	Alphanumeric description to assign to the LU.
device-category	Configures the device category of the LU: random (disk) or sequential (tape).
random	Identifies a LU for a random device.
sequential	Identifies a LU for a sequential device
dynamic-gateway-port-failover	Enables dynamic gateway port failover so that if one gateway port fails, the other port on the gateway maintains the traffic to the LU.
default	(Optional) Sets an attribute to its global default value.
dynamic-gateway-port-loadbalancing	Enables gateway port load balancing across multiple ports for this LU to optimize performance and utilize all available bandwidth.
dynamic-path-affinity	Enables dynamic path affinity for this LU, which locks a storage connection to a path for the duration of data transfer to provide faster, more efficient data delivery.
io-hi-mark	Configures the maximum amount of I/O that the LU can send to the initiator.
<i>mark</i>	Maximum amount of I/O (integer value from 1 - 256) that the initiator can send to the storage device (LU). This value defaults to 5.
max-retry	Maximum number of times that the initiator unsuccessfully sends data to a LU before the initiator identifies the LU as inaccessible.
<i>retry</i>	Integer value from 1 - 100. The <i>retry</i> variable defaults to 5.
min-io-timeout	Configures the maximum amount of time during which the storage device can accept I/O.
<i>timeout</i>	Maximum amount of time during which a storage device can accept I/O. Integer value from 1 - 1800. This value defaults to 10.
target	Specifies a target to add to the LU target list.
<i>wwpn</i>	World-wide port name (WWPN) of the target port to add to the LU target list.

Defaults Refer to the Syntax Description for default behavior and values.

Command Modes Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user or Fibre Channel read-write user.

Use the **fc srp lu** command to configure LU attributes.

We recommend that you do not manually create LUs. We recommend that you let your gateway card(s) detect LUs. The gateway card automatically creates LU entries when it discovers LUs.

For the following settings, the LU entry gets the default from srp-global settings at entry creation time depending on the LU category.

Once a LU entry is created, the LU settings are independent of the srp-global. You may change the settings on a per LU basis using this command.

[Table 3-2](#) provides usage guidelines for this command.

Table 3-2 Usage Guidelines for fc srp lu Command Arguments

Argument	Description
dynamic-gateway-port-failover	<p>Default: the configured value of the srp-global itl command for this LU category(random/sequential).</p> <p>Allows the controller to select an alternate gateway interface port if the primary path fails. Enter the fc srp lu command with this keyword to enable this feature. Otherwise, use the no form of the command string to disable this feature. If you enable this policy, you implicitly disable port load balancing and dynamic path affinity.</p>
dynamic-gateway-port-loadbalancing	<p>Default: the configured value of the srp-global itl command for this LU category(random/sequential).</p> <p>Allows data to be sent between the initiator and Fibre Channel target using all available ports on the gateway interface. Port selection relies upon comparative I/O traffic. The controller attempts to distribute traffic equally between the ports. Enter the fc srp lu command with this keyword to enable this feature. Otherwise, user the no form of the command string to disable this feature. If you enable this policy, you implicitly disable port failover and dynamic path affinity.</p>

Table 3-2 *Usage Guidelines for fc srp lu Command Arguments (continued)*

Argument	Description
dynamic-path-affinity	<p>Default: the configured value of srp-global itl for this LU category(random/sequential).</p> <p>Allows the system to maintain a preference for a specific path. If the number of outstanding I/Os becomes excessive, or the path fails, the gateway uses an alternate path. When enabled, the gateway uses the current path until the path condition changes. Note that frequent switching degrades performance. Enter the fc srp lu command with this keyword to enable this feature. Otherwise, use the no form of the command string to disable this feature. If you enable this policy, you implicitly disable port failover and port loadbalancing.</p>
io-hi-mark mark	<p>Default: the configured value of srp-global itl for this LU category(random/sequential).</p> <p>Sets the maximum number of I/O requests that can be sent per logical unit. The value, an integer, must fall between 1 and 256. Enter the fc srp lu command with this keyword and the desired io-hi-mark value to set this feature.</p>
max-retry retry	<p>Default: the configured value of the srp-global itl for this LU category(random/sequential).</p> <p>Number of times the same I/O request may be sent to a logical unit. Increase the value if heavy traffic runs, or increase the min-io-timeout value. The value, an integer, must fall between 1 and 100. Enter the fc srp lu command with this keyword and the desired max-retry value to set this feature. - min-io-timeout timeout Default: the configured value of srp-global itl for this LU category(random/sequential).</p> <p>Maximum amount of time allowed for I/O traffic to be accepted by a logical unit. Increase this value (or increase the max-retry value) if you use a known slow connection. The value, an integer, must fall between 1 and 1800.</p>
target target-wwpn	<p>Specifies a target to add to the LU target list. The LU can be accessed via the target ports configured. You can add at most eight targets to a LU one at a time. Enter the fc srp lu command with this keyword and the desired world-wide port name (WWPN) of the target port value to add the target port to the list. Use the no form of this command to remove a target port from the list.</p>

Examples

The following example assigns a name to more easily identify the logical unit:

[illegible]

Related Commands

[fc srp itl](#)
[show fc srp initiator](#)
[show interface fc](#)
[show fc srp-global](#)
[show fc srp lu](#)

fc srp target

To configure targets, enter the **fc srp target** command in Global Configuration mode. To delete a target from the running configuration, use the **no** form of this command.

fc srp target *wwpn* {**description** *desc* | **ioc-guid** *guid*}

no fc srp target *wwpn* [**description** | **service-name**]

Syntax Description

<i>wwpn</i>	World-wide port name (WWPN) of the target port.
description	(Optional) Applies a text description to the target port.
<i>desc</i>	Description to apply to the target port.
ioc-guid	Manually assigns an I/O Controller (IOC) to the target.
<i>guid</i>	GUID of the IOC to assign to the target.
service-name	(Optional) Configures the service name of the target to an empty string.

Defaults

The service name serves as the default target name.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user or Fibre Channel read-write user.

Use the **fc srp target** command to configure target attributes.

We recommend that you allow your gateway cards to detect targets. We recommend that you let your gateway card(s) detect targets. A gateway card automatically creates FC-SRP target entries when it discovers targets.

Examples

The following example assigns a name to identify the target easily:

```
SFS-7000P(config)# fc srp target 21:00:00:04:cf:75:6b:3b description jumbalya
```

Related Commands

[fc srp itl](#)
[show interface fc](#)
[show fc srp initiator](#)

fc srp-global gateway-portmask-policy restricted

To deny new initiators port access to FC gateway ports, enter the **fc srp-global gateway-portmask-policy restricted** command in Global Configuration mode. To grant port access to new initiators, enter the **no** form of this command.

fc srp-global gateway-portmask-policy restricted

no fc srp-global gateway-portmask-policy restricted

Syntax Description This command has no arguments or keywords.

Defaults Restricted

Command Modes Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user or Fibre Channel read-write user.

Apply the default policy to new ITs and ITLs to restrict access so new SRP initiators do not use the Fibre Channel gateway or see the Fibre Channel fabric. If you do not restrict access, new SRP initiators can communicate through the FC gateway ports. You can modify access policies on an individual basis with the **fc srp itl** command.



Note

Policies only apply to ITs and ITLs that you create after you configure the policies.

Examples The following example denies port access to all new ITLs:

```
SFS-7000P(config)# fc srp-global gateway-portmask-policy restricted
```

Related Commands

[show fc srp initiator](#)
[show interface fc](#)

fc srp-global itl

To configure the default attributes that your Server Switch assigns to all new ITLs, enter the **fc srp-global itl** command in Global Configuration mode. To configure any attribute to an empty string or disable an attribute, use the **no** form of this command.

```
fc srp-global itl [sequential] {dynamic-gateway-port-failover |  
dynamic-gateway-port-loadbalancing | dynamic-path-affinity | io-hi-mark mark |  
max-retry retry | min-io-timeout timeout}
```

```
no fc srp-global itl [sequential] {dynamic-gateway-port-failover |  
dynamic-gateway-port-loadbalancing | dynamic-path-affinity | io-hi-mark |  
max-retry | min-io-timeout}
```

Syntax Description	sequential	(Optional) Configures SRP global defaults for ITLs of sequential access devices.
	dynamic-gateway-port-failover	The fc srp-global itl command no longer supports this syntax. This syntax appears for legacy purposes.
	dynamic-gateway-port-loadbalancing	The fc srp-global itl command no longer supports this syntax. This syntax appears for legacy purposes.
	dynamic-path-affinity	The fc srp-global itl command no longer supports this syntax. This syntax appears for legacy purposes.
	io-hi-mark	Assigns the maximum number of I/O requests that the initiator can send to the storage device.
	<i>mark</i>	Maximum number of requests that the initiator can send to the storage device.
	max-retry	Assigns the maximum number of consecutive, failed attempts to pass traffic to a LUN that the initiator makes before it identifies the LUN as inaccessible.
	<i>retry</i>	Number of retries before an initiator recognizes a LUN as inaccessible.
	min-io-timeout	Configures the maximum amount of time during which the storage device can accept I/O.
	<i>timeout</i>	Maximum amount of time during which a storage device can accept I/O.

Defaults By default, the **fc srp-global itl** command configures ITLs for random (non-sequential) targets. For additional default values, see [Table 3-3 on page 3-20](#).

Command Modes Global Configuration (config) mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user or Fibre Channel read-write user.

Table 3-3 provides usage guidelines for this command.

Table 3-3 Usage Guidelines for `fc srp-global itl` Command Arguments

Policy	Description
sequential	(Optional) Configures SRP global defaults for LUs of sequential access devices. Without this keyword, the configuration will be for the global defaults for LUs of random access devices.
dynamic-gateway-port-failover	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: false Default for sequential devices: true</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Allows the controller to select an alternate gateway interface port if the primary path fails. Enter the fc srp-global itl command with this keyword to enable this feature. Otherwise, include the no keyword at the beginning of the command string to disable this feature. If you enable this policy, you implicitly disable port load balancing and dynamic path affinity.</p>
dynamic-gateway-port-loadbalancing	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: true Default for sequential devices: false</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Allows data to be sent between the initiator and Fibre Channel target using all available ports on the gateway interface. Port selection relies upon comparative I/O traffic. The controller attempts to distribute traffic equally between the ports. Enter the fc srp-global itl command with this keyword to enable this feature. Otherwise, include the no keyword at the beginning of the command string to disable this feature. If you enable this policy, you implicitly disable port failover and dynamic path affinity.</p>

Table 3-3 *Usage Guidelines for fc srp-global itl Command Arguments (continued)*

Policy	Description
dynamic-path-affinity	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: false Default for sequential devices: false</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Allows the system to maintain a preference for a specific path. If the number of outstanding I/Os becomes excessive, or the path fails, the gateway uses an alternate path. When enabled, the gateway uses the current path until the path condition changes.</p> <p>Note Frequent switching degrades performance.</p> <p>Enter the fc srp-global itl command with this keyword to enable this feature. Otherwise, include the no keyword at the beginning of the command string to disable this feature. If you enable this policy, you implicitly disable port failover and port loadbalancing.</p>
io-hi-mark <i>mark</i>	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: 16 Default for sequential devices: 1</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Sets the maximum number of I/O requests that can be sent per logical unit. The value, an integer, must fall between 1 and 256. The hi mark defaults to 16. Enter the fc srp-global itl command with this keyword and the desired io-hi-mark value to set this feature.</p>

Table 3-3 Usage Guidelines for *fc srp-global itl* Command Arguments (continued)

Policy	Description
max-retry <i>retry</i>	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: 5 Default for sequential devices: 1</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Number of times the same I/O request may be sent to a logical unit. Increase the value if heavy traffic runs, or increase the min-io-timeout value. The value, an integer, must fall between 1 and 100. The retry value defaults to 5. Enter the fc srp-global itl command with this keyword and the desired max-retry value to set this feature.</p>
min-io-timeout <i>timeout</i>	<p>SRP global defaults for LUs of random/sequential access devices.</p> <p>Default for random devices: 10 Default for sequential devices: 60</p> <p>This value is applied to LU entries as their default setting at entry creation time. You can overwrite the value on LU basis later.</p> <p>Maximum amount of time allowed for I/O traffic to be accepted by a logical unit. Increase this value (or increase the max-retry value) if you use a known slow connection. The value, an integer, must fall between 1 and 1800. The timeout defaults to 10 seconds.</p>

Examples

The following example sets the I/O high mark of the ITL to 32:

```
SFS-7000P(config)# fc srp itl 00:05:ad:00:00:01:29:c5 00:00:00:00:00:00:00:00
21:00:00:04:cf:f6:c2:ab 00:00:00:00:00:00:00:00 io-hi-mark 32
```

Related Commands

[show interface fc](#)
[show fc srp-global](#)

fc srp-global lun-policy restricted

Enable LUN masking on all new ITs and ITLs, with the **fc srp-global lun-policy restricted** command in Global Configuration mode. Disable default LUN masking with the **no** form of the command.

fc srp-global lun-policy restricted

no fc srp-global lun-policy restricted

Syntax Description This command has no arguments or keywords.

Command Modes Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user or Fibre Channel read-write user.

Enable global LUN masking to deny LUN access to new initiators so that they cannot communicate with SAN nodes until you grant them access on an individual basis. Disable LUN masking to grant new ITLs immediate access to all LUNs.



Note

An initiator requires both port and LUN access before it can successfully access a LUN. To grant port access, use the **fc srp-global gateway-portmask-policy restricted**, **fc srp it** and **fc srp itl** commands.



Note

Policies only apply to ITs and ITLs that you create after you configure the policies.

Examples The following example denies all new initiators access to all LUNs:

```
SFS-7000P(config)# fc srp-global lun-policy restricted
```

Defaults Restricted.

Related Commands

[authentication](#)
[radius-server](#)
[fc srp it](#)
[fc srp itl](#)
[fc srp-global gateway-portmask-policy restricted](#)
[show fc srp-global](#)



InfiniBand Commands

This chapter documents the following commands:

- [ib sm db-sync, page 4-2](#)
- [ib pm, page 4-4](#)
- [ib sm, page 4-8](#)
- [ib sm multicast, page 4-12](#)
- [ib-agent, page 4-14](#)

ib sm db-sync

To configure the database synchronize feature between the master subnet manager and one or more standby (slave) subnet managers, enter the **ib sm db-sync** command in Global Configuration mode. To disable database synchronization features, use the **no** form of this command.



Note

With database sync enabled on all chassis, only the chassis running the master SM will accept partition configuration from the user.

ib sm db-sync subnet-prefix *prefix* { **enable** | **max-backup-sms** *max* | **session-timeout** *timeout* | **poll-interval** *interval* | **cold-sync-timeout** *cs-timeout* | **cold-sync-limit** *cs-limit* | **cold-sync-period** *cs-period* | **new-session-delay** *delay* | **resync-interval** *resync* }

no ib sm db-sync subnet-prefix *prefix* { **enable** | **max-backup-sms** | **session-timeout** | **poll-interval** | **cold-sync-timeout** | **cold-sync-limit** | **cold-sync-period** | **new-session-delay** | **resync-interval** }

Syntax Description

subnet prefix	Specifies the subnet prefix of the IB subnet on which you want to configure performance monitoring.
<i>prefix</i>	Subnet prefix of the IB subnet on which you want to configure performance monitoring.
enable	Enables database synchronization on your IB fabric.
max-backup-sms	Specifies the maximum number of backup subnet managers that will synchronize with the master SM.
	Note Although we offer this configuration option, the master SM currently only supports one standby.
<i>max</i>	Maximum number of backup subnet managers that will synchronize with the master SM. This value defaults to 1.
session-timeout	Specifies the interval, in seconds, during which a synchronization session status MAD packet must arrive at the master SM to maintain synchronization. This value should be greater than the poll-interval value.
<i>timeout</i>	Timeout interval, in seconds. This value defaults to 10 seconds.
poll-interval	Interval at which the master SM polls an active slave SM to verify synchronization.
<i>interval</i>	Poll interval, in seconds. This value defaults to 3 seconds.
cold-sync-timeout	Allots a maximum amount of time in which to perform a cold sync. During the cold sync, the master SM copies all out-of-sync tables to the standby.
<i>cs-timeout</i>	Cold sync interval, in seconds. This value defaults to 10 seconds.
cold-sync-limit	Specifies the maximum number of cold syncs that may take place during the cold sync period. This value defaults to 2.
<i>cs-limit</i>	Maximum number of cold syncs per cold sync period (integer).
cold-sync-period	Specifies the length of the interval during which cold syncs may occur.
<i>cs-period</i>	Duration, in seconds, of the cold sync period. This value defaults to 900 seconds.

new-session-delay	Specifies the amount of time that the master SM waits before it attempts to initiate a synchronization session with a new SM.
<i>delay</i>	Delay length, in seconds. This value defaults to 120 seconds.
resync-interval	Specifies the interval at which the master SM sends a resynchronization request to all active sync sessions.
<i>resync</i>	Resynchronization interval, in seconds. This value defaults to 3600 seconds.

Defaults

Databases synchronize by default. Use the **disable** keyword to prevent synchronizing SM databases. For attribute-specific defaults, refer to the syntax description.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-write access

Synchronize the database of the master subnet manager with one or more standby subnet managers to retain all database information in the event of a failover.



Note

If you make configuration changes to the master SM and then save the configuration, verify that the master and backup have synchronized, then save the configuration on the backup as well.

Examples

The following example enables database synchronization on the IB fabric:

```
SFS-7000P(config)# ib sm db-sync subnet-prefix fe:80:00:00:00:00:00 enable
```

Related Commands

[show ib sm db-sync](#)

ib pm

To configure performance monitoring, enter the **ib pm** command in Global Configuration mode.

```
ib pm subnet-prefix prefix { connection { monitor | reset-counter | test } src-lid source-LID
dst-lid destination-LID | polling-period seconds | port { counter | monitor node-guid
GUID port-num num | reset-counter [node-guid GUID [port-num num]] } | start-delay
delay | state { disable | enable | enable-topspin-switches | enable-all } | threshold
{ excess-buf-overruns | link-downs | link-recovery-errors | local-link-errors |
rcv-constrnt-errors | rcv-errors | rcv-rate | rcv-rem-phy-errors |
rcv-sw-relay-errors | symbol-errors | vl15-droppeds | xmit-constrnt-errors |
xmit-discards | xmit-rate } int }
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of the IB subnet on which you want to configure performance monitoring.
<i>prefix</i>	Subnet prefix of the IB subnet on which you want to configure performance monitoring
connection	Specifies a connection-level action. Designates a connection that you want to monitor, reset, or test. You specify the connection with the src-lid and dst-lid arguments.
monitor	Configures monitoring of the port or connection.
reset-counter	Resets the performance monitoring counter(s).
test	Starts a connection test.
src-lid	Specifies the source Local Identifier (LID) of the connection.
<i>source-LID</i>	Source Local Identifier (LID) of the connection.
dst-lid	Specifies the destination Local Identifier (LID) of the connection.
<i>destination-LID</i>	Destination Local Identifier (LID) of the connection.
polling-period	Interval at which monitoring polls occur.
<i>seconds</i>	Interval at which monitoring polls occur, in seconds.
port	Specifies a port-level action. Designates a port you want to monitor or reset. Specify the port with the node-guid and port-num arguments.
counter	Enables the IB PM port counter feature.
node-guid	Specifies the GUID of the node that contains the port that you want to monitor.
<i>GUID</i>	GUID of the node that contains the port that you want to monitor.
port-num	Specifies the port number to monitor.
<i>num</i>	Port number to monitor.
start-delay	Delay time before performance monitoring starts after being enabled.
<i>delay</i>	Delay time before starting performance monitoring, in seconds.
state	Configures the state of performance monitoring.
disable	Disables monitoring.
enable	Enables monitoring.
enable-topspin-switches	Enables monitoring on all Server Switches in the subnet.
enable-all	Enables monitoring on all ports in the subnet.

threshold	Configures threshold values.
excess-buf-overruns	Configures the threshold for the number of “excess buffer overrun” errors.
link-downs	Configures the threshold for the number of “link down” errors.
link-recovery-errors	Configures the threshold for the number of “link recovery” errors.
local-link-errors	Configures the threshold for the number of “local link integrity” errors.
rcv-constrnt-errors	Configures the threshold for the number of “receive constraint” errors.
rcv-errors	Configures the threshold for the number of “receive” errors.
rcv-rate	Configures receive rate thresholds.
rcv-rem-phy-errors	Configures the threshold for the number of “receive remote physical” errors.
rcv-sw-relay-errors	Configures the threshold for the number of “receive remote relay” errors.
symbol-errors	Configures the threshold for the number of “symbol” errors.
vl15-dropped	Configures the threshold for the number of “vl15 dropped” events.
xmit-constrnt-errors	Configures the threshold for the number of “transmit constraint” errors.
xmit-discards	Configures the threshold for the number of “transmit discard” errors.
xmit-rate	Configures transmit rate thresholds.
<i>int</i>	Threshold value (integer).

Defaults

Performance monitoring is disabled by default.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-write access

Use performance manager to do the following:

- View IB port counters.
- Test connectivity between two IB ports (test a connection).
- Monitor any/all IB ports for errors, generating SNMP traps and log messages when user-defined thresholds are exceeded.

To monitor IB ports for errors, follow these steps:

- Configure error thresholds.
- (Optional) Configure specific ports and/or connections to monitor.
- (Optional) Configure new start-delay and/or polling-period values.
- Start performance monitoring.

* Either use the **show ib pm** commands to check for errors, or wait for SNMP traps or log messages to be generated by your Server Switch.'

Examples

The following example configures a symbol-errors threshold of 3:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 threshold symbol-errors 3
```

The following example configures a link-downs threshold of 1:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 threshold link-downs 1
```

The following example configures a polling period of 5 seconds:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 polling-period 5
```

The following example configures a start delay of 0 seconds:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 start-delay 0
```

The following example starts performance monitoring on all IB ports:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 state enable-all
```

The following example stops performance monitoring:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 state disable
```

The following example starts performance monitoring on only the specific connections and ports configured by the user:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 state enable
```

The following example configures a specific connection from LID 3 to LID 7 to monitor:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 connection monitor src-lid 3 dst-lid 7
```

The following example configures a specific port to monitor:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 port monitor node-guid 00:05:ad:00:00:01:34:e0 port-num 3
```

The following example resets the counters on all ports:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 port reset-counter
```

The following example resets the counters on a specific port:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 port reset-counter node-guid 00:05:ad:00:00:01:34:e0 port-num 3
```

The following example resets the counters on all ports on the connection from LID 3 to LID 7:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 connection reset-counter src-lid 3 dst-lid 7
```

The following example initiates a connection test from LID 3 to LID 7:

```
SFS-7000P(config)# ib pm subnet-prefix fe:80:00:00:00:00:00:00 connection test src-lid 3 dst-lid 7'
```


Related Commands

[show ib pm config](#)
[show ib pm connection counter](#)
[show ib pm connection counter](#)
[show ib pm port counter](#)
[show ib pm port monitor](#)
[show ib pm threshold](#)

ib sm

To administer the subnet manager (SM) on your Server Switch for everything except multicast, and to create and populate partitions, enter the **ib sm** command in Global Configuration mode. To undo configurations and partitions, use the **no** form of this command. Enter this command without arguments to add a subnet manager with default values.

```
ib sm subnet-prefix prefix [p_key pkey [partition-member partition member port full member
/ limited member ] | priority sm-priority [sm-key key | lid-mask-control lmc] |
response-timeout timeout | sm-key key | sweep-interval interval | lid-mask-control
LMC | master-poll-intval mp-interval | master-poll-retries retries | max-active-sms
SMs | ca-link-hoqlife life / sw-link-hoqlife life / / switch-life-time life / max-hops 1-64
/ mad-retries retries / node-timeout seconds / response-timeout milliseconds /
sa-mad-queue-death size]
```

```
no ib sm subnet-prefix prefix [p_key pkey [partition-member partition-member port] |
priority sm-priority / response-timeout timeout | sweep-interval interval |
lid-mask-control LMC | master-poll-intval mp-interval | master-poll-retries retries |
max-active-sms SMs]
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of the subnet manager.
<i>prefix</i>	Subnet prefix of the subnet manager. You may enter any prefix, but we recommend that you enter fe:80:00:00:00:00:00:00 to indicate a locally administered subnet.
p_key	(Optional) Creates a partition and optionally assigns members to the partition, or assigns a partition key to a multicast group. Note With database sync enabled on all chassis, only the chassis running the master SM will accept partition configuration from the user.
<i>pkey</i>	(Optional) Partition identifier, in ###:## format.
partition-member	(Optional) Node guid for the partition member.
<i>port</i>	(Optional) Port number of the partition-member.
<i>full member / limited member</i>	(Optional) Type of partition membership.
priority	(Optional) Assigns a priority level to the subnet manager. Because multiple subnet managers can run on the system and other SMs may run in your IB network, the priority attribute identifies the master SM.
<i>sm-priority</i>	(Optional) Integer value that represents the subnet manager priority level. The higher the integer, the higher the priority.
sm-key	(Optional) Assigns a subnet management key to a new subnet manager. Note We recommend that you do not create additional subnet managers. A subnet manager resides on your Server Switch from the moment you boot.
<i>key</i>	(Optional) 64-bit subnet management key.
<i>timeout</i>	(Optional) Maximum amount of time, in milliseconds, that the SM waits for a response after it sends a packet to a port. The <i>timeout</i> variable defaults to 400 milliseconds.

sweep-interval	(Optional) Specifies how frequently the SM queries the InfiniBand fabric for network changes.
<i>interval</i>	(Optional) Frequency, in seconds, at which the SM queries the InfiniBand fabric for network changes.
lid-mask-control	(Optional) Assigns the number of path bits present in the base LID to each channel adapter port. Increasing the LMC value increases the number of LIDs assigned to each port to increase the number of potential paths to reach each port. This value defaults to 0.
<i>LMC</i>	(Optional) Number of path bits.
master-poll-interval	(Optional) Specifies the interval at which the slave SM polls the master to see if it still runs.
<i>mp-interval</i>	(Optional) Poll interval, in seconds. This value defaults to 3 seconds.
master-poll-retries	(Optional) Specifies the number of unanswered polls that cause the slave to identify the master as dead.
<i>retries</i>	(Optional) Number of unanswered polls (integer). This value defaults to 2.
max-active-sm	(Optional) Specifies the maximum number of standby SMs that the master supports. This value defaults to 0, which indicates unlimited SMs.
<i>SMs</i>	(Optional) Number of standby SMs that the master supports (integer).
switch-life-time	(Optional) Specifies the packet lifetime inside a Server Switch.
sw-link-hoqlife	(Optional) Specifies the packet lifetime at the head-of-queue of a switch port.
ca-link-hoqlife	(Optional) Specifies the lifetime of a packet at the head-of-queue of the host port.
<i>life</i>	(Optional) lifetime interval (0 - 20). The interval is a function of microseconds.
max-hops <i>integer</i>	(Optional) Configure maximum length path for SM to examine for routing.
<i>integer</i>	(Optional) Specifies the number of hops. Range is from 0 to 64. Default is 64.
mad-retries <i>retries</i>	Number of times the SM will retry sending a MAD after not receiving a response. The value range is 0 - 100; the default value is 5.
node-timeout <i>seconds</i>	Minimum amount of time in seconds that a HCA may be unresponsive before the SM will remove it from the IB fabric. The value range is 1 - 2000 seconds; the default value is 10 seconds.
response-timeout <i>milliseconds</i>	(Optional) Maximum amount of time in milliseconds that the SM waits for a response before resending a MAD. The value range is 100-5000 milliseconds; the default value is 200 milliseconds.
wait-report-response <i><true / false></i>	Determines whether SM waits to receive ReportResponse MADs once. If boolean value is false, SM sends Report MADs once. If true, the SM continues to send Report MADs until either the ReportResponse MAD is received or the maximum number of Report MADs are sent. Default is false.
sa-mad-queue-depth <i>size</i>	Size of the SA's internal queue for receiving MADs. The value range is 256 - 1024; the default value is 256.

Defaults

Table 4-1 *ib sm subnet-prefix Command Defaults*

Variable	Default
sm-key	00:00:00:00:00:00:00:00
priority	10
sweep-interval	10 seconds
response-timeout	400 microseconds
max-hops	64
mad-retries	5
node-timeout	10
response-timeout	200
wait-report-response	false
sa-mad-queue-depth	256

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-write user.

The subnet manager:

- Discovers the subnet topology and dynamically updates it at a specified sweep interval that you specify with the *interval* variable.
- Assigns the local identifiers (LIDs), global identifier (GID) subnet prefix, and partition keys for each HCA port.
- Assigns the LIDs, GID subnet prefix, and forwarding databases for each switch on the subnet.
- Maintains the end-node and service databases of the subnet, providing a GUID to LID/GID resolution service as well as a services directory.

One subnet manager administers the InfiniBand fabric. All InfiniBand hosts run on this one subnet. The subnet manager loads upon bootup.

Each node in the fabric has a subnet management agent (SMA) to shuttle communication requests between the node and the subnet manager. Communication between the subnet manager and the subnet management agent uses the common management datagram (MAD) message structure.

Only multicast and p_Key configuration attributes are synchronized between master and standby SMs. If other attributes are changed, they must be manually issued at the standby SMs as well.

If, in the future, there is a change in the location of standby SMs, run the command **show config** to list all of the configuration changes previously made at the master SM. Then replay the configuration changes at the new standby SMs.

Regarding Partitions:

Partitions are created, and then ports are added to those partitions to enforce isolation.

Examples

The following example defines a subnet manager, or redefines the existing subnet manager, with the specified priority, sm-key, response-timeout, and sweep-interval configurations:

```
SFS-7000P(config)# ib sm subnet-prefix fe:80:00:00:00:00:00:00 priority 10 sm-key  
00:00:00:00:00:00:00:00 response-timeout 2000 sweep-interval 10
```

The following example removes a specified subnet manager:

```
SFS-7000P(config)# no ib sm subnet-prefix fe:80:00:00:00:00:00:00
```

The following example resets the response-timeout value for the specified subnet manager back to its default value:

```
SFS-7000P(config)# no ib sm subnet-prefix fe:80:00:00:00:00:00:00 response-timeout
```

The following example creates a partition and adds a member:

```
SFS-7000P(config)# ib sm subnet-prefix fe:80:00:00:00:00:00:00 p_key 00:02  
partition-member 00:00:2c:90:01:1a:c8:00 3 full-member
```

Related Commands

[ib-agent](#)
[ib sm multicast](#)
[ib sm db-sync](#)
[show ib sm configuration](#)

ib sm multicast

To administer the subnet manager (SM) multicast on your Server Switch, and to create and populate partitions, enter the **ib sm multicast** command in Global Configuration mode. To undo configurations and partitions, use the **no** form of this command. Enter this command without arguments to add a subnet manager with default values.

```
ib sm subnet-prefix prefix [multicast {mgid GID-address [mtu MTU-value] [p_key pkey]
[[q_key qkey] [rate GBPS] [sl service-level] | ipoib p_key pkey [mtu MTU-value] [q_key
qkey] [rate GBPS] [scope {link-local | site-local | org-local | global}}]

no ib sm subnet-prefix prefix [multicast {mgid GID-address [mtu MTU-value] [p_key pkey]
[[q_key qkey] [rate GBPS] [sl service-level] | ipoib p_key pkey [mtu MTU-value] [q_key qkey]
[rate GBPS] [scope {link-local | site-local | org-local | global}}]
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of the subnet manager.
<i>prefix</i>	Subnet prefix of the subnet manager. You may enter any prefix, but we recommend that you enter fe:80:00:00:00:00:00 to indicate a locally administered subnet.
multicast	Creates a multicast group.
mgid	Specifies the global ID of the multicast group.
<i>GID-address</i>	Global ID of the multicast group.
mtu	(Optional) Specifies the maximum transmission unit of the multicast group.
<i>MTU-value</i>	(Optional) Maximum transmission unit of the multicast group.
q_key	(Optional) Specifies the queue key of the multicast group.
<i>qkey</i>	(Optional) Queue key of the multicast group.
rate	(Optional) Specifies the data rate of the multicast group, in Gbps.
<i>GBPS</i>	(Optional) Data rate of the multicast group, in Gbps.
sl	(Optional) Specifies the service level of the multicast group.
<i>service-level</i>	(Optional) Service level of the multicast group.
ipoib	(Optional) Creates an IPoIB broadcast multicast group.
scope	(Optional) Specifies the scope of the broadcast multicast group.
link-local	(Optional) Applies a link-local scope to the broadcast multicast group.
site-local	(Optional) Applies a site-local scope to the broadcast multicast group.
org-local	(Optional) Applies an org-local scope to the broadcast multicast group.
global	(Optional) Applies a global scope to the broadcast multicast group.

Defaults

There are no defaults for this command.

Command Modes

Global Configuration (config) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-write user.

The subnet manager

- Discovers the subnet topology and dynamically updates it at a specified sweep interval that you specify with the *interval* variable.
- Assigns the local identifiers (LIDs), global identifier (GID) subnet prefix, and partition keys for each HCA port.
- Assigns the LIDs, GID subnet prefix, and forwarding databases for each switch on the subnet.
- Maintains the end-node and service databases of the subnet, providing a GUID to LID/GID resolution service as well as a services directory.

One subnet manager administers the InfiniBand fabric. All InfiniBand hosts run on this one subnet. The subnet manager loads upon bootup.

Each node in the fabric has a subnet management agent (SMA) to shuttle communication requests between the node and the subnet manager. Communication between the subnet manager and the subnet management agent uses the common management datagram (MAD) message structure.

Only multicast and p_Key configuration attributes are synchronized between master and standby SMs. If other attributes are changed, they must be manually issued at the standby SMs as well.

If, in the future, there is a change in the location of standby SMs, run the command **show config** to list all of the configuration changes previously made at the master SM. Then replay the configuration changes at the new standby SMs.

Regarding Partitions:

Partitions are created, and then ports are added to those partitions to enforce isolation.

Examples

The following example creates a multicast group:

```
SFS-7000P(config)# ib sm subnet-prefix fe:80:00:00:00:00:00:00 multicast mgid  
fe:80:00:00:00:00:00:00:00:00:00:00:00:00:00:00
```

Related Commands

[ib-agent](#)
[ib sm db-sync](#)
[ib sm](#)
[show ib sm configuration](#)

ib-agent

To configure subnet management agent (SMA) node strings, enter the **ib-agent** command in Global Configuration mode.

ib-agent { **channel-adapter** *HCA-port-guid* | **switch** *switch-guid* } **node-string** "string"

Syntax Description

channel-adapter	Specifies that you are changing the node string for an HCA.
<i>HCA-port-guid</i>	GUID of the HCA that you want to identify with a node string.
switch	Specifies that you are changing the node string for a switch.
<i>switch-guid</i>	GUID of the switch that you want to identify with a node string.
node-string	Specifies the node string description.
<i>string</i>	Node string description.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and InfiniBand read-write users.

The **ib-agent** command allows a user to modify the node description string displayed by the **show ib-agent** command. By specifying an IB node (either switch or HCA) inside the switch chassis, and providing a string, the user will override the description string for the given node.



Note

This command does not affect how the node appears on the IB subnet, and the IB "NodeDescription" string is not modified by this command.

Examples

The following example changes the node string of a channel adapter:

```
SFS-7000P(config)# ib-agent channel-adapter 00:05:ad:00:00:00:13:f7 node-string "primary HCA"
```

The following example changes the node string of a switch:

```
SFS-7000P(config)# ib-agent switch 00:05:ad:00:00:00:13:da node-string "Switch 0, LID 2"
```

Related Commands

[ib sm](#)
[show ib sm configuration](#)
[show ib-agent summary](#)



IP Commands

This chapter documents the following commands:

- [arp ethernet, page 5-2](#)
- [bridge-group, page 5-3](#)
- [distribution-type, page 5-5](#)
- [half-duplex, page 5-7](#)
- [ip, page 5-8](#)
- [redundancy-group, page 5-11](#)
- [trunk-group, page 5-12](#)



Note

The 6-port Ethernet gateway does not support half duplex transmission or 10 Mbps speed.

arp ethernet

To statically map an IP address to the physical machine address of an Ethernet host on the local network, enter the **arp ethernet** command in Global Configuration mode. To clear a static IP address, use the **no** form of this command.

arp ethernet *ip-address mac-address slot#/port#*

no arp ethernet *ip-address mac-address*

Syntax Description

<i>ip-address</i>	IP address of the host.
<i>mac-address</i>	MAC address of the host.
<i>slot#</i>	Slot on the Server Switch that holds the Ethernet gateway that connects to the host.
<i>port#</i>	Ethernet gateway port that connects to the host.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-write user.

The Server Switch supports dynamic ARP so that any IP host that connects to an Ethernet gateway port may see or detect all the other connected IP and IPoIB hosts.

An ARP table contains the available ARP records in the gateway. An ARP record may be dynamically learned or statically created. In most cases, you can rely upon dynamic ARP addressing. Dynamic ARP records may be deleted from the table after a period of time, or updated, if a host address-change occurs.

Examples

```
SFS-7000P(config)# arp ethernet 10.2.0.50 00:30:48:23:A9:0A 4/1
```

Related Commands

[show arp ethernet](#)

bridge-group

To create and configure bridge groups, enter the **bridge-group** command in Global Configuration mode or Ethernet Interface Configuration submode. To remove bridge groups or attributes of bridge groups, use the **no** form of this command.

```
bridge-group bridgegroupID { broadcast-forwarding | eth-next-hop ip-address [dest
dest-addr dest-mask] | ib-next-hop ip-address [dest dest-addr dest-mask] | name
“name-string” | subnet-prefix prefix length | loop-protection { one | two } | multicast |
fail-over-priority priority | redundancy-group group}
```

```
bridge-group bridgegroupID [pkey partition-key]
```

```
no bridge-group bridgegroupID [broadcast-forwarding | eth-next-hop | ib-next-hop |
loop-protection { one | two } | multicast | redundancy-group group]
```

```
no bridge-group bridgegroupID [pkey | subnet-prefix prefix length]
```

Syntax Description

<i>bridgegroupID</i>	Bridge group to create or reconfigure.
broadcast-forwarding	(Optional) Enables broadcast forwarding for the bridge group.
eth-next-hop	(Optional) Identifies the next-hop IP address connected to the ethernet gateway.
<i>ip-address</i>	(Optional) Next-hop IP address
ib-next-hop	(Optional) Identifies the next-hop IP address connected to the IB switch.
loop-protection	(Optional) Specifies the type of loop protection for the bridge-group.
one	Specifies type one loop protection (ARP packet painting enabled).
two	Specifies type two loop protection (ARP packet painting disabled).
multicast	(Optional) Enables IP-V4 multicast forwarding for the bridge group.
name	Assigns an ASCII text string identifier to the bridge group.
<i>name-string</i>	ASCII text string identifier for the bridge group.
subnet-prefix	(Optional) Assigns a subnet to the bridge-group.
<i>prefix</i>	(Optional) Subnet to assign to the bridge group.
<i>length</i>	(Optional) Length, in bits, of the subnet mask to assign to the bridge group.
fail-over-priority	Specifies the failover priority of the bridge group.
<i>priority</i>	Integer value (1 - 255), where the lower the integer the higher the priority.
redundancy-group	(Optional) Assigns the bridge group to a redundancy group.
<i>group</i>	(Optional) Redundancy group to which you want the bridge group to belong.
pkey	(Optional) Specifies a partition key to assign to the bridge group.
<i>partition-key</i>	Partition key to assign to the bridge group.
dest	(Optional) Specifies the destination subnet.
<i>dest-addr</i>	(Optional) Address of the destination subnet.
<i>dest-mask</i>	(Optional) Mask of the destination subnet.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode, Ethernet Interface Configuration (config-if-ether) submode, Gateway Interface Configuration (config-if-gw) mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-write user.

Create bridge-groups to associate specific Ethernet gateway ports with Ethernet switch ports. Bridge Groups are used to associate the InfiniBand fabric with an Ethernet subnet.

Examples

The following example creates a bridge group and uses auto-detect to discover all available subnets:

```
SFS-7000P(config)# bridge-group 61
```

The following example assigns a subnet prefix to a bridge group:

```
SFS-7000P(config)# bridge-group 61 subnet-prefix 61.0.0.0 16
```

The following example disables multicast forwarding for a bridge-group:

```
SFS-7000P(config)# no bridge-group 61 multicast
```

The following example assigns bridge group 62 to the Ethernet interface slot 6, port 2:

```
SFS-7000P(config-if-ether-6/2)# bridge-group 62
```

The following example assigns bridge group 62 to the internal gateway interface slot 6, ports 1 and 2:

```
SFS-7000P(config-if-gw-6)# bridge-group 62
```

The following example assigns a bridge group to a redundancy group and configures the failover priority of the bridge group:

```
SFS-7000P(config)# bridge-group 11 redundancy-group 11 fail-over-priority 10
```

Related Commands

[config TACACS-server host](#)
[redundancy-group](#)
[show bridge-group](#)

distribution-type

To configure the type of load distribution that your Ethernet gateway uses to communicate with a Link Aggregation-aware switch, enter the **distribution-type** command in Trunk Interface Configuration submode.

distribution-type { **dist-ip** | **dst-mac** | **src-dst-ip** | **src-dst-mac** | **src-ip** | **src-mac** | **round-robin** }

Syntax Description		
dst-ip		Bases the load distribution on the destination IP address of the incoming packet. Packets to the same destination travel on the same port, but packets to different destinations travel on different ports in the channel.
dst-mac		Bases the load distribution on the destination host MAC address of the incoming packet. Packets to the same destination travel on the same port, but packets to different destinations travel on different ports in the channel.
src-dst-ip		Bases load distribution on the IP address of the source logic gate (XOR) destination.
src-dst-mac		Bases load distribution on the MAC address of the source logic gate (XOR) destination.
src-ip		Bases the load distribution on the source IP address. Packets from the same source travel on the same port, but packets from different sources travel on different ports in the channel.
src-mac		Bases load distribution on the source MAC address of the incoming packet. Packets from different hosts use different ports in the channel, but packets from the same host use the same port in the channel.
round-robin		Bases the load distribution on a circular pattern to create an evenly distributed load.

Defaults The distribution-type defaults to src-mac.

Command Modes Trunk Interface Configuration (config-if-trunk) submode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Ethernet read-write user.

You must configure a distribution type to bridge to a load aggregation-aware Ethernet switch. Contact your administrator to discover if a switch is load aggregation-aware.

Examples

The following example configures src-mac distribution for the trunk interface:

```
SFS-7000P# interface trunk 1
SFS-7000P(config-if-trunk)# distribution-type src-mac
```

Related Commands

[show trunk](#)

half-duplex

To configure an Ethernet connection in half duplex mode, enter the **half-duplex** command in Ethernet Interface Configuration submode. To undo this configuration, use the **no** form of this command.

half-duplex

no half-duplex

Syntax Description

This command has no arguments or keywords.

Defaults

Your Server Switch runs in full duplex mode by default.

Command Modes

Ethernet Interface Configuration (config-if-ether) submode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-write user.

If you disable auto-negotiation, set speed and duplex mode with the **half-duplex** command and **speed** command.

You cannot manually configure half duplex mode while auto-negotiation runs on your Server Switch or while the connection speed exceeds 1000 Mbps.

**Note**

The 6-port Ethernet gateway does not support half duplex transmission or 10 Mbps speed.

Examples

The example below configures half duplex mode for ports 1 - 4 on slot 4:

```
SFS-7000P(config-if-ether-4/1-4/4)# half-duplex
```

Related Commands

[auto-negotiate](#)
[show interface ethernet](#)
[speed](#)

ip

To assign an IP address or backup address and subnet mask to an Ethernet port, enter the **ip** command in Ethernet Interface Configuration submode. To clear this configuration, use the **no** form of this command.

To assign an IP address to the Ethernet Management Interface port, enter the **ip** command in Ethernet Management Interface submode. To clear this configuration, use the **no** form of this command.

To assign an IP address to the InfiniBand Management Interface port, enter the **ip** command in InfiniBand Management Interface submode. To clear this configuration, use the **no** form of this command.

To configure IP networking attributes on your Server Switch, enter the **ip** command in Global Configuration mode. To clear this configuration, use the **no** form of this command.



Note Layer 3 only; available to 4-port Ethernet gateways but not 6-port.

ip {**address** *ip-address subnet-mask* [**priority** *address-priority*]} **no ip** {**address** *ip-address subnet-mask*} //configures Ethernet ports

ip address *ip-address subnet-mask* //configures the Ethernet Management port

no ip

ip address *ip-address subnet-mask* //configures the InfiniBand Management port

no ip

ip {**domain-name** *name-string* | **name-server-one** *server* | **name-server-two** *server* | **route** *dest-address dest-subnet-mask next-hop*} //configures a Server Switch

no ip {**domain-name** | **name-server-one** | **name-server-two** | **route** *dest-address subnet-mask next-hop*}

Syntax Description

address	Assigns a primary IP address to a port.
<i>ip-address</i>	IP address to assign
<i>subnet-mask</i>	Subnet mask to assign.
priority	Assigns a priority to the backup address that determines the order in which the backup address adopts the traffic of the primary address. Your Server Switch does not currently support this feature.
<i>address-priority</i>	Priority to assign. The higher the integer value, the higher the priority.
domain-name	Assigns a DNS name to your Server Switch.
<i>name-string</i>	Domain name to assign.
name-server-one	Specifies a primary domain name server (DNS).
name-server-two	Specifies a secondary DNS.
<i>server</i>	Domain name server for your Server Switch to use.
route	Defines static routes to remote hosts or networks to forward IP packets.
<i>dest-address</i>	IP address of the host or network that you want to reach.

<i>dest-subnet-mask</i>	Netmask used to resolve host and network addressing. The netmask may be an IP network address, a host route (for example, 255.255.255.255), or the default route (0.0.0.0).
<i>next hop</i>	IP address of the next hop (out of your Server Switch) on the way to the destination.

Defaults

This command has no default settings.

Command Modes

Ethernet Interface Configuration (config-if-ether) submode, Ethernet Management Interface Configuration (config-if-mgmt-ethernet) submode, InfiniBand Management Interface (config-if-mgmt-ib) submode, Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-write user.

- You can only assign an IP address to one port at a time.
- Assign a DNS name and servers to support network name resolution.
- The maximum transmission unit dictates payload size. TCP uses the MTU to determine the maximum payload allowed for every transmission. Too great a value can overwhelm routers and result in data retransmission. Too small a value results in degraded performance because there are more headers and acknowledgements required to transmit the same amount of data.
- Configure IP routes to hosts that reside one or more hops away from your Server Switch.

Examples

The following example assigns the IP address 10.3.0.24 and the subnet mask 255.255.255.0 to ethernet card 4 port 1:

```
SFS-7000P(config-if-ether-4/1)# ip address 10.3.0.24 255.255.255.0
```

The following example assigns the domain name **shasta** to the Server Switch:

```
SFS-7000P(config)# ip domain-name "shasta"
```

The following example configures your Server Switch to use a primary DNS:

```
SFS-7000P(config)# ip name-server-one 10.3.103.22
```

The following example configures your Server Switch to use a secondary DNS:

```
SFS-7000P(config)# ip name-server-two 10.3.103.23
```

The following example configures a static route on which to forward IP packets:

```
SFS-7000P(config)# ip route 192.168.3.0 255.255.255.0 10.10.1.0
```

Related Commands

[hostname](#)
[ip](#)
[ping](#)

redundancy-group

To create or configure a redundancy group, enter the **redundancy-group** command in Global Configuration mode. To disable an attribute of a redundancy group or to delete a redundancy group, use the **no** form of this command.

redundancy-group *rg-number* [**broadcast-forwarding** | **load-balancing** | **multicast** | **new-member-force-reelection** | **name** *name*]

no redundancy-group *rg-number* [**broadcast-forwarding** | **load-balancing** | **multicast** | **new-member-force-reelection**]

Syntax Description	<i>rg-number</i>	Number of the redundancy group.
	broadcast-forwarding	(Optional) Enables broadcast forwarding for all members of the redundancy group
	load-balancing	(Optional) Enables load balancing among all members of the group.
	multicast	(Optional) Enables multicast forwarding for all members of the redundancy group
	new-member-force-reelection	(Optional) Configures the redundancy group to force reelection when a new member joins.
	name	(Optional) Configures a name for the redundancy group
	<i>name</i>	Name to assign to the redundancy group.

Defaults By default, load balancing does not run on redundancy groups.

Command Modes Global Configuration (config) mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Ethernet read-write user.

Create and configure redundancy groups with this command.

Examples The following example creates a redundancy group:

```
SFS-7000P(config)# redundancy-group 11
```

Related Commands [show redundancy-group](#)
[bridge-group](#)

trunk-group

To assign a trunk group to one or more Ethernet interfaces, enter the **trunk-group** command in Ethernet Interface Configuration submode. To remove a trunk group from the configuration, enter the **no** form of this command.

```
trunk-group id
no trunk-group id
```

Syntax Description	<i>id</i> Integer that identifies the trunk-group.
--------------------	--

Defaults	By default, trunk groups do not apply to interfaces.
----------	--

Command Modes	Ethernet Interface Configuration (config-if-ether) submode.
---------------	---

Usage Guidelines	<p>Platform Availability: Cisco SFS 3001, Cisco SFS 3012</p> <p>Privilege Level: Ethernet read-write user.</p> <p>The trunk-group command assigns an already-configured trunk group to the Ethernet interface.</p>
------------------	---

Examples	<p>The following example assigns a trunk group to the Ethernet interface (slot 2, ports 1 - 4):</p> <pre>SFS-7000P(config-if-ether-2/1-2/4)# trunk-group 2</pre>
----------	--

Related Commands	<p>config TACACS-server host</p> <p>show trunk</p> <p>show interface ethernet</p>
------------------	---



Show Commands

This chapter documents the following commands:

- [show arp ethernet, page 6-4](#)
- [show authentication, page 6-6](#)
- [show backplane, page 6-8](#)
- [show boot-config, page 6-10](#)
- [show bridge-forwarding, page 6-12](#)
- [show bridge-group, page 6-14](#)
- [show bridge-subnets, page 6-16](#)
- [show card, page 6-17](#)
- [show card-inventory, page 6-22](#)
- [show cdp, page 6-25](#)
- [show cdp entry, page 6-27](#)
- [show cdp neighbors, page 6-28](#)
- [show clock, page 6-29](#)
- [show config, page 6-30](#)
- [show diagnostic, page 6-32](#)
- [show diagnostic card, page 6-33](#)
- [show diagnostic chassis, page 6-35](#)
- [show diagnostic fan, page 6-36](#)
- [show diagnostic fru-error, page 6-38](#)
- [show diagnostic interface ethernet, page 6-40](#)
- [show diagnostic interface fc, page 6-42](#)
- [show diagnostic interface ib, page 6-44](#)
- [show diagnostic post, page 6-46](#)
- [show diagnostic power-supply, page 6-48](#)
- [show diagnostic rack-locator, page 6-50](#)
- [show fan, page 6-52](#)
- [show fc srp initiator, page 6-54](#)

- [show fc srp initiator-wwpn-view](#), page 6-57
- [show fc srp it](#), page 6-59
- [show fc srp itl](#), page 6-61
- [show fc srp itl-statistics](#), page 64
- [show fc srp lu](#), page 6-66
- [show fc srp statistics](#), page 6-69
- [show fc srp target](#), page 6-71
- [show fc srp-global](#), page 6-73
- [show host](#), page 6-74
- [show ib dm ioc](#), page 6-76
- [show ib dm iou](#), page 6-79
- [show ib pm config](#), page 6-81
- [show ib pm connection counter](#), page 6-83
- [show ib pm connection monitor](#), page 6-86
- [show ib pm port counter config](#), page 6-88
- [show ib pm port counter](#), page 6-89
- [show ib pm port monitor](#), page 6-91
- [show ib pm threshold](#), page 6-94
- [show ib sm configuration](#), page 6-96
- [show ib sm db-sync](#), page 6-99
- [show ib sm lft](#), page 6-101
- [show ib sm mft](#), page 6-103
- [show ib sm multicast](#), page 6-106
- [show ib sm neighbor](#), page 6-108
- [show ib sm node](#), page 6-110
- [show ib sm partition](#), page 6-113
- [show ib sm port](#), page 6-115
- [show ib sm service](#), page 6-122
- [show ib sm switch](#), page 6-127
- [show ib sm switch-elem-route](#), page 6-130
- [show ib sm switch-route](#), page 6-132
- [show ib-agent channel-adapter](#), page 6-134
- [show ib-agent summary](#), page 6-136
- [show ib-agent switch](#), page 6-138
- [show interface ethernet](#), page 6-148
- [show interface fc](#), page 6-156
- [show interface gateway](#), page 6-162
- [show interface ib](#), page 6-167

- [show interface mgmt-ethernet](#), page 6-177
- [show interface mgmt-ib](#), page 6-179
- [show interface mgmt-serial](#), page 6-180
- [show inventory](#), page 6-181
- [show ip](#), page 6-183
- [show ip http](#), page 6-185
- [show location](#), page 6-189
- [show logging](#), page 6-190
- [show ntp](#), page 6-192
- [show power-supply](#), page 6-193
- [show redundancy-group](#), page 6-195
- [show running-status](#), page 6-197
- [show sensor](#), page 6-199
- [show snmp](#), page 6-201
- [show system-mode](#), page 6-204
- [show system-services](#), page 6-205
- [show terminal](#), page 6-207
- [show trace](#), page 6-208
- [show trunk](#), page 6-209
- [show user](#), page 6-210
- [show version](#), page 6-212

show arp ethernet

To display entries in the Ethernet ARP routing table, enter the **show arp ethernet** command in User Exec mode or Privileged Exec mode.

show arp ethernet

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Ethernet read-only user.

Your Server Switch dynamically creates ARP connections on an as-needed basis and removes ARP entries from ARP routing tables when connections drop.

Command Output:
[Table 6-1](#) describes the fields in the **show arp ethernet** command output.

Table 6-1 *show arp ethernet Command Field Descriptions*

Field	Description
port	Port (in slot#/port# format) on your Server Switch to which the host connects.
physical-address	MAC address of the host.
net-address	IP address of the host.
type	Type of route between the host and your Server Switch, either static or dynamic .

Examples The following example displays the entries in the Ethernet ARP routing table of the Server Switch:

```
SFS-7000P# show arp ethernet
=====
                        ARP Information
=====
port    physical-address    net-address    type
-----
4/1     00:05:ad:00:10:41        20.45.0.1     static
```

Related Commands [arp ethernet](#)

show authentication

To display how your system authenticates logins, enter the **show authentication** command in Privileged Exec mode.

show authentication

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use this command to determine if your Server Switch uses a RADIUS server or TACACS+ client, along with the local database, to authenticate CLI user logins. If your Server Switch uses multiple resources, the command output displays the order in which your Server Switch authenticates logins.

Command Output:

[Table 6-2](#) describes the fields in the **show authentication** command output.

Table 6-2 *show authentication Command Field Descriptions*

Field	Description
authentication method	Displays whether your Server Switch authenticates logins with the local CLI database, the RADIUS server, a TACACS+ client, or a combination. If dual configuration is used (local and either RADIUS or TACACS+), the output displays the order in which your Server Switch authenticates the login.

Examples

The following example displays the authentication method that the Server Switch uses:

```
SFS-7000P> show authentication
```

```
authentication method: tacacs+ and then local
-----
```

```
tacacs-server : 171.71.27.230
                  priority : 1
                  port : 49
                  key : testing123
```

```
                timeout : 5
            max-retries : 2
    access-request-count : 3
        access-accept-count : 0
        access-reject-count : 1
        server-timeout-count : 4
SFS-7000P>
```

Related Commands

[authentication](#)
[radius-server](#)
[config TACACS-server host](#)

show backplane

To display a breakdown of Serial Electrically Erasable and Programmable Read-Only Memory (SEEPROM) details of your Server Switch, enter the **show backplane** command in User Exec mode or Privileged Exec mode.

show backplane

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012

Privilege Level:

General read-only user.

The output of the **show backplane** command assists product support personnel.

Command Output:

Table 6-3 describes the fields in the **show backplane** command output.

Table 6-3 *show backplane Command Field Descriptions*

Field	Description
base-mac-addr	24-bit base MAC address of this chassis.
chassis-id	Factory-assigned, 64-bit chassis-identification number.
chassis-guid	Factory-assigned GUID of the chassis.
product serial-number	Factory-assigned product serial number.
pca serial-number	Printed circuit assembly (PCA) serial number.
pca number	Printed Circuit Assembly (PCA) assembly number.
fru number	Field replaceable unit (FRU) number for the actual switch (Cisco SFS 3001) or chassis (Cisco SFS 3012).

Examples

The following example displays the SEEPROM details of the Server Switch backplane:

```
SFS-7000P> show backplane
```

```
=====
                        Backplane Seeprom
=====
base-mac-addr      chassis-id      chassis-guid
-----
0:5:ad:1:5f:f2     0x5ad0000015ff2      0x5ad0000015ff2
```

```
=====
                        Backplane Seeprom
=====
product      pca      pca      fru
serial-number serial-number number      number
-----
MX3054100107 C3054100150 95-00078-01 99-00140-01
```

```
SFS-7000P>
```

show boot-config

To display the active system image that runs when your Server Switch boots, enter the **show boot-config** command in User Exec mode or Privileged Exec mode.

show boot-config

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

The **show boot-config** command displays the image that initializes chassis firmware and configures the interfaces.

This command lists the files that were used to bring up the system, the files to use the next time the system reboots, and the backup files to use in the event that the primary boot files are not available.

Command Output:

[Table 6-4](#) describes the fields in the **show boot-config** command output.

Table 6-4 *show boot-config Command Field Descriptions*

Field	Description
slot-id	Slot identifier of the controller card in use.
sw-version	Version of the software image that initialized chassis components.
last-image-source	Directory name of the active system image used to initialize chassis components.
primary-image-source	Name and directory location of the active system image to use to initialize chassis components the next time the system boots.

Examples

The following example displays the image that the Server Switch boots:

```
SFS-7000P# show boot-config
=====
                System Boot Configuration
=====
                slot-id : 1
                sw-version : OS-1.1.3/build255
                last-image-source : OS-1.1.3/build255
                primary-image-source : OS-1.1.3/build255
```

Related Commands

[boot-config](#)
[install](#)
[reload](#)
[show version](#)

show bridge-forwarding

Display subnets to which bridge groups forward traffic with the **show bridge-forwarding** command.

show bridge-forwarding [*integer*] [**subnet** *subnet-prefix prefix-length*]

Syntax Description

<i>integer</i>	(Optional) Bridge group number limits forwarding information to bridge group.
subnet	(Optional) Specifies a particular subnet to display in the command output.
<i>subnet-prefix</i>	(Optional) Particular subnet to display in the command output.
<i>prefix-length</i>	(Optional) Prefix length of the subnet to display in the command output.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user.

Command Output:

[Table 6-7](#) explains the fields that appear in the **show bridge-subnets** command output.

Table 6-5 *show bridge-subnets Command Field Descriptions*

Field	Description
bridge	Number of the bridge group that bridges the subnet.
subnet-prefix	Subnet prefix that the bridge-group bridges.
subnet-prefix-len	Length of the subnet prefix of the subnet.

Examples

The following example provides sample output of the **show bridge-subnets** command:

```
SFS-7000P# show bridge-subnets
```

```
=====
                        Bridge Subnets
=====
bridge subnet-prefix  subnet-prefix-len
-----
1      192.168.0.0    22
2      192.168.13.32  29
```

Related Commands [bridge-group](#)

show bridge-group

To display the attributes of bridge groups, enter the **show bridge-group** command in User Exec mode or Privileged Exec mode.

```
show bridge-group [bridge-groupID#]
```

Syntax Description	bridge-groupID#	(Optional) Integer value that represents a bridge group. Use the bridge-group ID number to view the attributes of one specific bridge group.
--------------------	-----------------	--

Defaults Without an argument, the **show bridge-group** command shows all bridge groups.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines: **Privilege Level:**
General read-only user.

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Command Output:
Table 6-6 describes the fields in the **show bridge-group** command output.

Table 6-6 show bridge-group Command Field Descriptions

Field	Description
bridge-group-id	Displays the integer-value identifier of the bridge group that the administrator assigned with the bridge-group command.
bridge-group-name	Displays the ASCII text string identifier that the administrator assigned with the bridge-group command.
eth-bridge-port	Displays the trunk that the bridge group uses to connect to the Ethernet switch.
ib-bridge-port	Displays the internal gateway slot#/port# of the bridge-group.
broadcast-forwarding	Displays true if you enable broadcast-forwarding. Displays false if you disable broadcast forwarding.
broadcast-forwarding-mode	
loop-protection-method	Displays one if you enable ARP Packet Painting. Displays ? if you disable ARP Packet Painting. See the <i>Ethernet Gateway User Guide</i> for more information.
multicast	Displays true if the bridge group belongs to a multicast group. Displays false if the bridge group does not belong to a multicast group.

Table 6-6 *show bridge-group Command Field Descriptions (continued)*

Field	Description
redundancy-group	Displays the redundancy group to which the bridge group belongs.
status-in-redundancy-group	Displays none (when the bridge group is not in a redundancy group), primary , or secondary .

Examples

The following example (output abridged) shows all bridge groups on the Server Switch:

```
SFS-7000P# show bridge-group
```

```
=====
                        Bridge Groups
=====
      bridge-group-id : 1
      bridge-group-name :
      eth-bridge-port : trunk 1 (not tagged)
      ib-bridge-port : 5/2 (gw) (pkey: ff:ff)
      broadcast-forwarding : false
      broadcast-forwarding-mode : inherit-from-redundancy-group
      loop-protection-method : one
      multicast : false
      multicast-mode : inherit-from-redundancy-group
      redundancy-group : 1
      status-in-redundancy-group : primary
```

Related Commands

[bridge-group](#)

show bridge-subnets

To display the subnets that a particular bridge group bridges, enter the **show bridge-subnets** command in User Exec mode or Privileged Exec mode.

show bridge-subnets [*bridge-group-number*]

Syntax Description

<i>bridge-group-number</i>	(Optional) Limits the command output to the subnets of one particular bridge group.
----------------------------	---

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user.

Command Output:

[Table 6-7](#) explains the fields that appear in the **show bridge-subnets** command output.

Table 6-7 *show bridge-subnets Command Field Descriptions*

Field	Description
bridge	Number of the bridge group that bridges the subnet.
subnet-prefix	Subnet prefix that the bridge-group bridges.
subnet-prefix-len	Length of the subnet prefix of the subnet.

Examples

The following example provides sample output of the **show bridge-subnets** command:

```
SFS-7000P# show bridge-subnets
```

```
=====
                        Bridge Subnets
=====
bridge subnet-prefix  subnet-prefix-len
-----
1      192.168.0.0    22
2      192.168.13.32  29
```

Related Commands

[bridge-group](#)

show card

To display the configuration, status, and Serial Electrically Erasable and Programmable Read Only Memory (EEPROM) details of interface cards, enter the **show card** command in User Exec mode or Privileged Exec mode.

show card {*card-selection* | **all**}

Syntax Description

<i>card-selection</i>	Card, list of cards, or range of cards to view.
all	Displays the details of all interface cards in your Server Switch.

Defaults

The **show card** command displays all cards by default.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

- Use the following syntax format to display the details of one card:
show card 5
- Use the following syntax format to display the details of a list of cards:
show card 5,9,14
- Use the following syntax format to display the details of a range of cards:
show card 5-9
- Use the following syntax format to display the details of a list with ranges of cards:
show card 5, 7-9, 14

Command Output:

Table 6-8 describes the fields in the **show card** command output.

Table 6-8 *show card Command Field Descriptions*

Field	Description
slot	Displays the number of the slot that the card occupies.
admin type	<p>Displays the type of the interface card that the administrator specified with the type command. The first two letters of the entry indicate the general type of the card:</p> <ul style="list-style-type: none"> • en for Ethernet • ib for InfiniBand • fc for Fibre Channel <p>The number of ports on the card follow the two-letter type identifier. The remaining number and letter identify the speed of the ports on the card. The admin type fc2port2G indicates a Fibre Channel card with two ports that run at a maximum speed of 2 Gbps.</p> <p>Note The controller and controllerIb12port4x cards serve as an exception to these rules.</p> <p>The “admin type” identifier “controller” indicates the type of independent controller card found on both sides of the system chassis. The “admin type” identifier “controllerIb12port4x” indicates a controller card that piggy-backs onto a 12-port InfiniBand switch card, where each port connection can support speeds up to 4X.</p>
oper type	Displays the type of the card as detected by the controller. If any conflict occurs between “admin type” and “oper type”, the system assumes that the type specified by oper type is correct and allows you to configure the card based upon this assumption. If a type mismatch occurs, verify that you are selecting the correct type for the card in the chassis.
admin status	Displays the administrative status (that you configure with the shutdown and no shutdown commands) of the port.
oper status	<p>Displays the operational status as detected by the controller. Oper status represents the absolute status of the interface card based upon self-detection. The value of this read-only field appears as one of the following:</p> <ul style="list-style-type: none"> • unknown, which generally indicates that an error occurred when the card booted • up, which indicates that the card is operating normally • down, which indicates that a user disabled the card with the shutdown command • failure, which indicates that the card failed to boot correctly <p>The “up” indicator means that your card is operating normally. You can only configure cards that have an operational status of “up.”</p>

Table 6-8 *show card Command Field Descriptions (continued)*

Field	Description
oper code	<p>Displays the general condition of the interface card. The general condition may appear as any of the following:</p> <ul style="list-style-type: none"> • unknown • normal • wrongBootImage • bootFailed • tooHot • checkingBootImage • rebooting • booting • standby • recoveryImage <p>A condition of “unknown” indicates an unsupported interface card. To address this condition, replace the card with a supported card.</p> <p>The oper code of a card must appear as normal for the oper status of the card to appear as up.</p> <p>A wrong-image condition indicates that the active system image on the interface card does not match the active system image on the controller. All cards must run the same active system image as the controller card to function.</p> <p>A bootFailed condition indicates that the active system image on the card was incompletely or incorrectly loaded. If the other interface cards come up successfully, reset the individual card. Otherwise, reboot your entire Server Switch.</p> <p>When your card overheats, the tooHot condition appears in the show card command output. Enter the show fan command to see if your fans have failed.</p> <p>The booting condition indicates that the card has not finished loading the necessary image data for internal configuration.</p>
boot stage	<p>Boot Stage could be any of the following:</p> <ul style="list-style-type: none"> • recovery • ipl • ppcboot • fpga • pic • ib • rootfs • kernel • exe • done

Table 6-8 *show card Command Field Descriptions (continued)*

Field	Description
boot status	Boot Status may appear as any of the following: <ul style="list-style-type: none"> • upgrading • success • failed • badVersion • badCrc • memoryError • outOfSpace • programmingError • hardwareError • fileNotFound • inProgress
boot image	Displays the active system image that the card runs when it boots.
product serial-number	Displays the factory-assigned product serial number of the card.
pca serial-number	Displays the Printed Circuit-Assembly (PCA) serial number of the card.
pca number	Displays the Printed Circuit-Assembly (PCA) assembly number of the card.
fru number	Displays the field-replaceable unit (FRU) number of the card.

**Note**

When you run the **show card** command on a Cisco SFS 7008, an asterisk (*) next to the slot number identifies the controller card on which you executed this command. The asterisk does not identify the normal or standby controllers. That information appears in the oper code column.

Examples

This example displays the configuration and status information for cards 5, 9, 14, and 16:

```
SFS-7000P# show card 5,9,14,16
=====
Card Information
=====
  admin      oper      admin      oper      oper
slot type          type          status    status    code
-----
 5  en4port1G      en4port1G      up        up        normal
 9  fc2port2G      fc2port2G      up        up        normal
14  controller     controller     up        up        normal
16  ib12port4x     ib12port4x     up        up        normal
=====
Card Boot Information
=====
  boot      boot      boot
slot stage  status    image
-----
 5  done      success    OS-1.1.2/build084
 9  done      success    OS-1.1.2/build084
14  done      success    OS-1.1.2/build084
16  done      success    OS-1.1.2/build084
```

```

=====
                        Card Seeprom
=====
      product      pca      pca      fru
slot serial-number serial-number number number
-----
5      00024      1234      95-00007-01      1234
9      1234      1234      95-00008-01      1234
14     00002      00002      95-00005-01      1234
16     1234      1234      95-00006-01      1234
SFS-7000P#

```

On the Cisco SFS 7008, an asterisk (*) designates the active controller card from which you have initiated your CLI session. See the example below:

SFS-270# **show card**

```

=====
                        Card Information
=====
      admin      oper      admin      oper      oper
slot type      type      status      status      code
-----
11* controllerFabric12x controllerFabric12x up      up      normal
12  controllerFabric12x controllerFabric12x up      up      standby

```

Related Commands

[action](#)
[boot-config](#)
[card](#)
[install](#)
[shutdown](#)
[type](#)

show card-inventory

To display the system resources and image data of interface cards, enter the **show card-inventory** command in User Execute mode or Privileged Execute mode.



Note

The **show card-inventory** command only displays cards with an oper-status of **up**.

show card-inventory [*card-selection* | **all**]

Syntax Description

<i>card-selection</i>	(Optional) Card, list of cards, or range of cards to view.
all	(Optional) Displays resources and data of all cards in the chassis.

Defaults

The **show card-inventory** defaults to **show card-inventory all**.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Each interface card is a system in itself. The following comprise system resources:

- available and used memory
- available and used flash memory
- active system image on the interface card
- CPU name and version

The active system image should match the active image that runs on the controller card. Occasions may occur when you update the system image on the controller but not on an interface card, such as when you swap interface cards between chassis or update the system image on the controller when an interface card goes down. Disk space may be an issue if you try to update the system image on the controller but cannot propagate this data to the interface card because the interface card has no free space.

The CPU description may be requested by support personnel in the event you experience difficulties with a controller or an interface card.

Command Output:

Table 6-9 describes the fields in the **show card-inventory** command output.

Table 6-9 *show card-inventory Command Field Descriptions*

field	description
slot-id	Slot number of the controller card, gateway module, or InfiniBand switch.
up-time	Number of seconds card has been active.
used-memory	Total amount of local RAM being used by the card.
slot-id	Displays the slot ID.
used-memory	Total amount of memory used in local RAM.
free-memory	Total amount of available local RAM.
used-disk-space	Total amount of local flash memory space being used by the card.
free-disk-space	Total amount of available local flash memory space.
last-image-source	Last image that the card booted.
primary-image-source	Active system image to use when the system reboots. This value should be the same for all cards in the system.
image	If only one instance of the image field appears, it indicates the system image used to initialize the card firmware. If there are two instances of the image field, the second instance indicates that a second system image is present on the card.
cpu-descr	CPU type, model, and firmware version. The disk on chip (DOC) versions are appended to the existing CPU descriptions in this release.
fpga-firmware-rev	Current FPGA firmware version that the card runs.
ib-firmware-rev	Version of InfiniBand firmware on the card. Note The CLI displays the device-ID and version number of the InfiniBand chip for each card for Anafa 2 chips. This content appears in parentheses next to the firmware version. For original Anafa chips, no parenthetical text appears. The Cisco SFS 3001 and Cisco SFS 3012 chassis run original Anafa chips. The Cisco SFS 7000 and Cisco SFS 7008 chassis run later models.

Examples

The following example displays the configuration and status information for the cards on the Server Switch:

```
SFS-7000P# show card-inventory
```

```
=====
Card Resource/Inventory Information
=====
slot-id : 1
up-time : 615398 (seconds)
used-memory : 24184 (kbytes)
free-memory : 103652 (kbytes)
used-disk-space : 36123 (kbytes)
free-disk-space : 58702 (kbytes)
```

```
last-image-source : TopspinOS-2.6.0/build141
primary-image-source : TopspinOS-2.6.0/build141
    image : TopspinOS-2.6.0/build141
    cpu-descr : PPC 440GP Rev. C - Rev 4.129 (pvr 4012 0481) (doc G3)
fpga-firmware-rev : ab
ib-firmware-rev : 0008002ace (hw-rev b924 1a1)
```

Related Commands

[boot-config](#)
[card](#)

show cdp

Display the Cisco Discovery Protocol (CDP) advertisement information, with the **show cdp** command.

show cdp

Syntax Description

This command has no arguments or keywords.

Defaults

CDP is running when the chassis boots.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Cisco Discovery Protocol (CDP) obtains protocol addresses of neighboring devices and discovers the platform of those devices. Using it with the MIB database allows applications to learn the device and the SNMP agent address of neighboring devices. CDP uses the CISCO-CDP-MIB.

Each device configured for CDP sends periodic messages, known as advertisements, to a multicast address. Each device advertises at least one address at which it can receive SNMP messages. Advertisements also contain time-to-live, or hold time, information, that indicates the length of time that a receiving device holds CDP information before discarding it. Each device also listens to the CDP messages sent by others to learn when the media interfaces of neighboring devices go up or down.

CDP Version-2 is the latest release of the protocol. With CDP Version-2, detailed information is provided on the VLAN Trunking Protocol (VTP) management domain and duplex modes of neighbor devices, CDP-related counters, and VLAN IDs of connecting ports. This helps Ethernet gateway configuration. CDP is run on server switches over both management-Ethernet and management-IB interfaces.

Examples

The following example displays the CDP advertisement information:

```
SFS-7000P# show cdp
=====
                        CDP Information
=====
                run : false
        message-interval : 60
                hold-time : 180
        device-id : SFS(00:05:ad:01:5f:f2)
```

Related Commands

[show cdp neighbors](#)
[show clock](#)

show cdp entry

To display the Cisco Discovery Protocol (CDP) information for a specific neighbor, enter the **show cdp entry** command in User Exec mode or Privileged Exec mode.

show cdp entry entry-name [*protocol* | *version*]

Syntax Description	entry-name	Specifies the entry name
	<i>protocol</i>	(Optional) Specifies the protocol.
	<i>version</i>	(Optional) Specifies the version

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.

Examples The following example displays the CDP entry information:

SFS-7000P# **show cdp entry**

```
=====
                        CDP entry
=====
      device-id : svbu-h46-c2950.svbu-h46-c2950.cisco.com
      platform  : cisco WS-C2950T-24
capabilities  : switch
      device-port : FastEthernet0/1224
      version    : Cisco Internetwork OS C2950 Software
(C2950-I6Q4L2-M) Version 12.1(22)
      native-vlan : 230
      duplex     : half
```

Related Commands [show cdp](#)
[show cdp neighbors](#)
[show clock](#)

show cdp neighbors

To display the information for neighbors CDP has discovered, enter the **show cdp neighbors** command in User Exec mode or Privileged Exec mode.

show cdp neighbors [**type number**] [**detail**]

Syntax Description	type number	(Optional) Displays the type of device discovered, the device name, the number and type of the local interface (port), the number of seconds the CDP advertisement is valid for the port, the device type, the device product number, and the port ID.
	detail	(Optional) Displays information about the native VLAN ID, the duplex mode, and the VTP domain name associated with the neighbor device.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.

Examples The following example displays the CDP neighbors information:

```
SFS-7000P# show cdp neighbors

=====
                        CDP neighbors
=====
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater, P - Phone

device-id                hold-time capability platform          port-id
-----
svbu-q8-c2950.svbu-q8-c2950.cisco.com2 (- 180          S          cisco WS-C2950T-24
FastEthernet0/4-24
```

Related Commands

- [show cdp](#)
- [show cdp entry](#)
- [show clock](#)

show clock

To display the current system time, enter the **show clock** command in User Exec mode or Privileged Exec mode.

show clock

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.
If you have not set the clock, system time begins at 00:00:00, January 1, 1970.

Examples The following example displays the clock settings of the Server Switch:

```
SFS-7000P# show clock
Mon Mar 17 02:26:32 2003 (UTC)
SFS-7000P#
```

Related Commands [clock set](#)

show config

To display the startup configuration, enter the **show config** command in User Exec mode or Privileged Exec mode.

show config

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

The **show config** command displays the current configuration as a series of commands in the format that you use when you execute commands in a CLI session. This command queries all active service components to collect their current configuration data and translates the data into a CLI command format.

This record of the configuration may be saved, edited, and reused to replicate a configuration.

**Note**

ITLs (see the [“fc srp itl” section on page 3-9](#)) with default attributes (see the [“fc srp-global itl” section on page 3-19](#)) do not appear in the **show config** command output.

Examples

The following example displays the running configuration on the Server Switch:

```
SFS-7000P# show config
enable
config terminal
card 2
type en4port1G
no shutdown
ib sm subnet-prefix fe:80:00:00:00:00:00:00 priority 0
interface gateway 2
authentication login default local tacacs
ip address 192.168.2.1 255.255.255.0
interface ethernet 2/1
ip address 192.168.1.1 255.255.255.0
```

```
interface ethernet 2/2
ip address 192.168.3.1 255.255.255.0
arp ib 192.168.2.2 gid fe:80:00:00:00:00:00:00:02:c9:00:00:13:68:c3 qpn 2 2/0
arp ib 192.168.2.3 gid fe:80:00:00:00:00:00:00:02:c9:00:00:16:af:d3 qpn 2 2/0
SFS-7000P#
```

Related Commands

[copy](#)
[history](#)

show diagnostic

To display diagnostics, enter the **show diagnostic** command in User Exec mode or Privileged Exec mode.

show diagnostic

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Examples

The following example displays the system diagnostics available:

```
SFS-270# diagnostic ?
SFS-7000P# show diag ?
card                - Show card specific diagnostic test
chassis             - Show chassis specific diagnostic test
fan                 - Show fan specific diagnostic test
fru-error           - Show the last hardware error (if any) detected
interface           - Show interface specific diagnostic test
post                - Show POST status of all FRUs in the system
power-supply        - Show power supply specific diagnostic test
rack-locator        - Show rack locator specific diagnostic test
```

Related Commands

[show diagnostic card](#)
[show diagnostic chassis](#)
[show diagnostic fan](#)
[show diagnostic fru-error](#)
[show diagnostic interface ethernet](#)
[show diagnostic interface fc](#)
[show diagnostic interface ib](#)
[show diagnostic post](#)
[show diagnostic power-supply](#)
[show diagnostic rack-locator](#)

show diagnostic card

To display completed or ongoing diagnostic tests for cards, enter the **show diagnostic card** command in User Exec mode or Privileged Exec mode.

show diagnostic card { **all** | *card-selection* }

Syntax Description

all	Specifies all cards on the Server Switch.
<i>card-selection</i>	Card or cards with the tests that you want to view.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Command Output:

[Table 6-10](#) describes the fields in the **show diagnostic card** command.

Table 6-10 *show diagnostic card Command Field Descriptions*

Field	Description
test	Test that ran or runs on the card.
slot-id	Slot of the card.
iterations	Number of iterations that the test completed.
action	Last action that an administrator applied to the test.
result	Result of the last action that an administrator applied to the test.
percentage-completed	Percentage of the test that has executed.
result-string	Diagnostic test results.

Examples

The following example displays the completed and ongoing diagnostic tests on card 3:

```
SFS-7000P# show diag card 3
```

```
=====
                        Diagnostic Tests For Cards
=====
```

```
test : led
slot-id : 3
iterations : 1
action : stop
result : success
percentage-completed : 100
result-string : Card LED Test, Final report : PASSED
```

The following example displays the available test parameters:

```
SFS-7000P(config)# diagnostic card 16
SFS-7000P(config-diag-card-16)# ?
diagnostic Configuration Commands:
exit                - Exit current mode
help                - Show command help
history             - Show command history
start               - Initiate a test
stop                - Stop a test
test                - Configure test type
SFS-7000P(config-diag-card-16)# test ?
> led                - Test type is LED test
> self-test          - Test type is self-test
```

Related Commands [show diagnostic](#)

show diagnostic chassis

To display completed or ongoing diagnostic tests the chassis, enter the **show diagnostic chassis** command in User Exec mode or Privileged Exec mode.

show diagnostic chassis

Syntax Description

This command has no arguments or keywords.

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Privilege Level:

Unrestricted read-write user.

Examples

The following example displays the completed and ongoing diagnostic tests on card 3:

```
SFS-120# show diagnostic chassis
```

```
=====
                        Diagnostic Tests For Chassis
=====
      module-type : chassis
      module-number : 1
          test : self-test
          iterations : 1
              option : stopOnError
              action : start
              result : success
      percentage-completed : 100
      result-string : Self Test, Final report : PASSED; Please reboot syst
em
SFS-120#
```

Related Commands

[show diagnostic](#)

show diagnostic fan

To display completed or ongoing diagnostic tests for fans, enter the **show diagnostic fan** command in User Exec mode or Privileged Exec mode.

```
show diagnostic fan {all | fan-selection}
```

Syntax Description	all	Specifies all fans on the Server Switch.
	fan-selection	Fan or fans with the tests that you want to view.

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	User Execute mode, Privileged Execute mode.
---------------	---

Usage Guidelines	Platform Availability: Cisco SFS 7000, Cisco SFS 7008
	Privilege Level: Unrestricted read-write user.

Command Output:
[Table 6-11](#) describes the fields in the **show diagnostic fan** command.

Table 6-11 show diagnostic card Command Field Descriptions

Field	Description
test	Test that ran or runs on the card.
slot-id	Slot of the card.
iterations	Number of iterations that the test completed.
action	Last action that an administrator applied to the test.
result	Result of the last action that an administrator applied to the test.
percentage-completed	Percentage of the test that has executed.
result-string	Diagnostic test results.

Examples

The following example displays diagnostic test results for a fan:

```
SFS-120# show diag fan
```

```
=====
                                     Diagnostic Tests For Fan
=====

      module-type : fan
      module-number : 3
           test : self-test
      iterations : 1
           action : stop
           result : success
percentage-completed : 100
      result-string : Fan Self Test Completed, Final report : Passed=1, Failed=0, Total=1
```

Related Commands

[show diagnostic](#)

show diagnostic fru-error

To display field-replaceable unit (FRU) run-time errors, enter the **show diagnostic fru-error** command in User Exec mode or Privileged Exec mode.

show diagnostic fru-error

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes: User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 7000, Cisco SFS 7008

Privilege Level:
Unrestricted read-write user.

Command Output:
[Table 6-12](#) describes the fields in the **show diagnostic fru-error** command.

Table 6-12 *show diagnostic card Command Field Descriptions*

Field	Description
fru-slot	FRU type (such as fan or power supply) and slot.
fru-error	FRU error, if any.

Examples

The following example displays FRU errors on a Cisco SFS 7000:

```
SFS-270# show diagnostic fru-error
```

```
=====
                                Fru-Error
=====
```

```
fru-slot      fru-error
-----
```

```
card(1)       none
card(2)       none
card(9)       none
card(11)      _FRU_ETHERNET_ERR
card(12)      _FRU_ETHERNET_ERR
card(15)      none
card(16)      none
fan(1)        none
fan(2)        none
fan(3)        none
fan(4)        none
power-supply(1) none
power-supply(2) none
```

Related Commands

[show diagnostic](#)

show diagnostic interface ethernet

To display completed or ongoing diagnostic tests for Ethernet gateway ports, enter the **show diagnostic interface ethernet** command in User Exec mode or Privileged Exec mode.

show diagnostic interface ethernet {*port* | **all**}

Syntax Description

<i>port</i>	Ethernet port, in slot#/port# notation.
all	Specifies all Ethernet ports on the Server Switch.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-only user.

Command Output:

[Table 6-13](#) describes the fields in the **show diagnostic interface ethernet** command.

Table 6-13 *show diagnostic interface ethernet Command Field Descriptions*

Field	Description
test	Test that ran or runs on the card.
port	Ethernet port number, in slot#/port# notation.
validation	Displays enabled or disabled to indicate validation status.
data-size	Size of the test data.
data-pattern	Pattern of the test data.
iterations	Number of iterations of the test.
action	Last action that an administrator performed on the test.
result	Result of the last action that an administrator performed on the test.
percentage-completed	Percentage of the test that has executed.
result-string	Result of the diagnostic test.

Examples

The following example displays the completed and ongoing diagnostic tests on port 1 of Ethernet gateway 9:

```
SFS-7000P# show diagnostic interface ethernet 9/1

=====
Diagnostic Tests For Ethernet Interfaces
=====
      test : led
      port : 9/1
  validation : enabled
    data-size : 0
 data-pattern : 00:00:00:00
      iterations : 0
        action : stop
        result : none
 percentage-completed : 0
    result-string : Unknown Test Unknown status, Current report : Passed=0,
Failed=0, Total=0
```

The following example displays the diagnostic tests available:

```
SFS-7000P# (config)# diagnostic interface ethernet 2/1
SFS-7000P# (config-diag-if-ether-2/1)# ?
>diagnostic Configuration Commands:
data-pattern      - Configure a data pattern to use in traffic test
cases
  data-size       - Configure size (in octects) of payload data
  exit            - Exit current mode
  help            - Show command help
  history         - Show command history
  iterations      - Configure number of iterations the test case
should be run
  no              - Disable a configuration or set default
  start           - Initiate a test
  stop            - Stop a test
  test            - Configure the test case to run
  validate        - Enable data validation to be performed on
received packets
SFS-7000P# (config-diag-if-ether-2/1)# test ?
ext-loopback      - Configure External-Loopback test
led               - Configure LED test
```

Related Commands [show diagnostic](#)

show diagnostic interface fc

To display completed or ongoing diagnostic tests for Fibre Channel gateway ports, enter the **show diagnostic interface fc** command in User Exec mode or Privileged Exec mode.

show diagnostic interface fc {*port* | **all**}

Syntax Description

<i>port</i>	Ethernet port, in slot#/port# notation.
all	Specifies all Ethernet ports on the Server Switch.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

Command Output:

[Table 6-14](#) describes the fields in the **show diagnostic interface fc** command.

Table 6-14 *show diagnostic card Command Field Descriptions*

Field	Description
test	Test that ran or runs on the card.
port	Fibre Channel port number, in slot#/port# notation.
validation	Displays enabled or disabled to indicate validation status.
data-size	Size of the test data.
data-pattern	Pattern of the test data.
iterations	Number of iterations of the test.
source-id	Source WWPN for the test.
target-id	Target WWPN for the test.
action	Last action that an administrator performed on the test.
result	Result of the last action that an administrator performed on the test.
percentage-completed	Percentage of the test that has executed.
result-string	Result of the diagnostic test.

Examples

The following example displays the completed and ongoing diagnostic tests on all Ethernet ports:

```
SFS-7000P# show diagnostic interface ethernet all

=====
Diagnostic Tests For Ethernet Interfaces
=====
      test : external-loopback
      port : 6/3
      validation : enabled
      data-size : 0
      data-pattern : 00:00:00:00
      iterations : 0
      action : stop
      result : none
      percentage-completed : 0
      result-string : External Loopback Test In-progress, Current report : Passed=0,
Failed=0, Total=0
```

The following example displays the diagnostic tests available:

```
SFS-7000P(config)# diagnostic interface fc 6/1
SFS-7000P(config-diag-if-fc-6/1)# ?
> diagnostic Configuration Commands:
> data-pattern          - Configure a data pattern to use in traffic test
> cases
> data-size             - Configure size (in octects) of payload data
> exit                  - Exit current mode
> help                  - Show command help
> history               - Show command history
> iterations            - Configure number of iterations the test case
> should be run
> no                    - Disable a configuration or set default
> source-id             - Specify source identifier for use with FC Echo test
> start                 - Initiate a test
> stop                  - Stop a test
> target-id             - Specify target identifier for use with FC Echo test
> test                  - Configure the test case to run
> validate              - Enable data validation to be performed on
> received packets
> Topspin-360(config-diag-if-fc-6/1)# test ?
> echo                  - Configure Echo test
> ext-loopback          - Configure External-Loopback test
> int-loopback          - Configure Internal-Loopback test
```

Related Commands [show diagnostic](#)

show diagnostic interface ib

To display completed or ongoing diagnostic tests for InfiniBand switch ports, enter the **show diagnostic interface ib** command in User Exec mode or Privileged Exec mode.

show diagnostic interface ib {*port* | **all**}

Syntax Description

<i>port</i>	Ethernet port, in slot#/port# notation.
all	Specifies all Ethernet ports on the Server Switch.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Command Output:

[Table 6-15](#) describes the fields in the **show diagnostic interface ib** command.

Table 6-15 *show diagnostic card Command Field Descriptions*

Field	Description
test	Test that ran or runs on the card.
port	InfiniBand port number, in slot#/port# notation.
validation	Displays enabled or disabled to indicate validation status.
data-size	Size of the test data.
data-pattern	Pattern of the test data.
iterations	Number of iterations of the test.
source-id	Source LID for the test.
target-id	Target LID for the test.
action	Last action that an administrator performed on the test.
result	Result of the last action that an administrator performed on the test.
percentage-completed	Percentage of the test that has executed.
result-string	Result of the diagnostic test.

Examples

The following example displays the completed and ongoing diagnostic tests on port 1 of InfiniBand switch card 16:

```
SFS-7000P> show diagnostic interface ib 16/1

=====
Diagnostic Tests For IB Interfaces
=====
      test : external-loopback
      port : 16/1
  validation : enabled
    data-size : 0
data-pattern : 00:00:00:00
    iterations : 0
    source-id : 00:00:00
    target-id : 00:00:00
      action : stop
      result : none
percentage-completed : 0
    result-string : External Loopback Test Unknown status, Current report :
Passed=0, Failed=0, Total=0
```

The following example displays the available diagnostics tests:

```
SFS-7000P(config)# diagnostic interface ib 16/1
> SFS-7000P(config-diag-if-ib-16/1)# ?
> diagnostic Configuration Commands:
> data-pattern          - Configure a data pattern to use in traffic test
> cases
> exit                  - Exit current mode
> help                  - Show command help
> history                - Show command history
> iterations             - Configure number of iterations the test case
> should be run
> no                     - Disable a configuration or set default
> start                  - Initiate a test
> stop                  - Stop a test
> test                  - Configure the test case to run
> validate               - Enable data validation to be performed on
> received packets
> SFS-7000P(config-diag-if-ib-16/1)# test ?
> ext-cable              - Configure External-Cable test
> ext-loopback           - Configure External-Loopback test
> int-loopback           - Configure Internal-Loopback test
```

Related Commands [show diagnostic](#)

show diagnostic post

To display POST error messages, enter the **show diagnostic post** command in User Exec mode or Privileged Exec mode.

show diagnostic post

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 7000, Cisco SFS 7008

Privilege Level:
Unrestricted read-write user.

Command Output:
Table 6-16 describes the fields in the **show diagnostic post** command.

Table 6-16 show diagnostic card Command Field Descriptions

Field	Description
fru-slot	FRU type (such as fan or power supply) and slot.
post-status	Status of the POST test.
error-codes	Applicable error codes.

Examples

The following example displays POST error messages on a Cisco SFS 7000:

```
SFS-270# show diagnostic post
```

```
=====
                                Post Status
=====
fru-slot      post-status      post-error
-----
card(1)       passed           none
card(2)       passed           none
card(9)       passed           none
card(11)      failed           _FRU_ETHERNET_ERR
card(12)      failed           _FRU_ETHERNET_ERR
card(15)      passed           none
card(16)      passed           none
fan(1)        passed           none
fan(2)        passed           none
fan(3)        passed           none
fan(4)        passed           none
power-supply(1) passed       none
power-supply(2) passed       none
```

Related Commands

[show diagnostic](#)

show diagnostic power-supply

To display completed or ongoing diagnostic tests for power supplies, enter the **show diagnostic power-supply** command in User Exec mode or Privileged Exec mode.

show diagnostic power-supply { **all** | *power-supply-selection* }

Syntax Description

all	Specifies all fans on the Server Switch.
<i>power-supply-selection</i>	Power supply or supplies with the tests that you want to view.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 7000, Cisco SFS 7008

Privilege Level:

Unrestricted read-write user.

Command Output:

[Table 6-11](#) describes the fields in the **show diagnostic power-supply** command.

Table 6-17 *show diagnostic card Command Field Descriptions*

Field	Description
module-number	Power supply module number.
test	Test that ran or runs on the card.
iterations	Number of iterations that the test completed.
action	Last action that an administrator applied to the test.
result	Result of the last action that an administrator applied to the test.
percentage-completed	Percentage of the test that has executed
result-string	Diagnostic test results.

Examples

The following example displays the completed and ongoing diagnostic tests on all power supplies:

```
SFS-270> show diagnostic power-supply all
```

```
=====
                        Diagnostic Tests For Power Supplies
=====
      module-number : 1
            test    : none
        iterations  : 1
            action   : stop
            result    : none
percentage-completed : 0
      result-string :
```

show diagnostic rack-locator

To display the results of the rack locator test, enter the **show diagnostic rack-locator** command in User Exec mode or Privileged Exec mode.

show diagnostic rack-locator

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 7000, Cisco SFS 7008

Privilege Level:

Unrestricted read-write user.

[Table 6-18](#) describes the fields in the **show diagnostic rack-locator** command.

Command Output:

Table 6-18 *show diagnostic rack-locator Command Field Descriptions*

Field	Description
module-type	Type of test.
module-number	Module tested.
test	Last test executed.
iterations	Number of iterations of last test executed.
action	Last test action taken.
result	Result of test.
percentage-completed	Percentage of test completed.
result-string	Test results.

The following example displays rack locator test results:

```
SFS-7000P# show diagnostic rack-locator
=====
Diagnostic Tests For Rack Locator
=====
      module-type : rack-locator
      module-number : 1
              test : led
            iterations : 1
```



```
        action : stop
        result  : success
percentage-completed : 100
result-string  : LED Test, Final report : PASSED
```

Related Commands [show diagnostic](#)

show fan

To display the status of the fans in your Server Switch, enter the **show fan** command in User Exec mode or Privileged Exec mode.

show fan

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012

Privilege Level:
General read-only user.

For the health of your Server Switch, both fans should be operating while your Server Switch runs. If the operational status of a fan appears as "down," contact customer support for a fan module replacement.

Command Output:
[Table 6-19](#) describes the fields in the **show fan** command output.

Table 6-19 show fan Command Field Descriptions

field	description
fan	Fan number. Fan 1 resides on the left-side as you are facing the front of the chassis. Fan 2 resides on the right-side of the chassis.
oper status	Operational status of the fan. The value appears as unknown, up, down, or failure. An up value indicates the fan functions correctly.
speed (%)	Speed of the fan as a percentage of the maximum speed of the fan.
product serial number	Factory-assigned product serial-number.
pca serial-number	Printed Circuit-Assembly (PCA) serial-number.
pca number	Printed Circuit-Assembly (PCA) assembly-number.
fru number	Field-replaceable unit (FRU) number.

Examples

The following example displays the fan settings on the Server Switch:

```
SFS-7000P# show fan
```

```
=====
                        Fan Information
=====
fan  oper-status  speed(%)
-----
1    up           93
2    up           91
3    up           89
4    up           85

=====
                        Fan Seeprom
=====
                product          pca          pca          fru
fan  serial-number  serial-number  number      number
-----
1    PY-0323-000055  PY-0323-000055  95-00011-01  98-00004-01
2    PY-0323-000055  PY-0323-000055  95-00011-01  98-00004-01
3    PY-0323-000059  PY-0323-000059  95-00011-01  98-00004-01
4    PY-0323-000059  PY-0323-000059  95-00011-01  98-00004-01
```

Related Commands

[show power-supply](#)
[show sensor](#)

show fc srp initiator

To display the attributes of initiators that you have configured on your Server Switch, enter the **show fc srp initiator** command in User Exec mode or Privileged Exec mode.

show fc srp initiator [*guid extension*]

Syntax Description

<i>guid</i> (optional)	GUID of the initiator to view.
<i>extension</i> (optional)	GUID extension of the initiator to view.

Defaults

Enter the **show fc srp initiator** command with no arguments to display all initiators.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

This command displays active and inactive initiators.

Enter this command without any arguments to display the initiator information for all configured SRP initiators. If you specify a GUID, you must also specify the extension.



Note

Initiators do not need to connect to the Server Switch to appear in the show output. As long as you configured them, they appear in the command output.

Command Output:

[Table 6-20](#) describes the fields in the **show fan** command output.

Table 6-20 *show fc srp initiator Command Field Descriptions*

Field	Description
guid	GUID of the initiator.
extension	GUID extension of the initiator.
description	User-assigned ASCII description of the initiator.
wwnn	World-wide node name (WWNN) of the initiator.
credit	Indicates the amount of traffic that the initiator can accept.
active-ports	IB ports on your Server Switch through which the initiator passes traffic.
pkeys	Partition keys of the initiator.

Table 6-20 *show fc srp initiator Command Field Descriptions (continued)*

Field	Description
action	Displays the last action you performed using the fc srp initiator command on this initiator. Displays the last action you have performed using the config fc arp initiator command on this initiator. The action can be <i>discover-ntl</i> or <i>auto-bind</i> . Possible values are none (when no action was taken), success, in-progress, or fail.
result	Displays the result of the action that appears in the “action” field. Possible values are none (when no action was taken), success, in-progress, or fail. Any results other than “Operation completed successfully” occur due to interface errors.
wwpns	World-wide port names (WWPNs) of the virtual ports (NL_ports) that point to the initiator.

Examples

The following example displays the initiators that users have configured on the Server Switch:

```
SFS-7000P# show fc srp initiator
```

```
=====
                        SRP Initiators
=====
      guid: 00:05:ad:00:00:01:29:c5
      extension: 00:00:00:00:00:00:00:00
      description: Bender
      wwnn: 20:01:00:05:ad:00:40:00
      credit: 0
      active-ports: 6/1
      pkeys:
      action: none
      result: none
      wwpns: port      wwpn      fc-addr
                  2/1      20:01:00:05:ad:20:40:00  00:00:00
                  2/2      20:01:00:05:ad:24:40:00  00:00:00
                  3/1      20:01:00:05:ad:30:40:00  00:00:00
                  3/2      20:01:00:05:ad:34:40:00  00:00:00
                  4/1      20:01:00:05:ad:40:40:00  00:00:00
                  4/2      20:01:00:05:ad:44:40:00  00:00:00
                  5/1      20:01:00:05:ad:50:40:00  00:00:00
                  5/2      20:01:00:05:ad:54:40:00  00:00:00
                  6/1      20:01:00:05:ad:60:40:00  00:00:02
                  6/2      20:01:00:05:ad:64:40:00  00:00:00
                  7/1      20:01:00:05:ad:70:40:00  00:00:00
                  7/2      20:01:00:05:ad:74:40:00  00:00:00
                  8/1      20:01:00:05:ad:80:40:00  00:00:00
                  8/2      20:01:00:05:ad:84:40:00  00:00:00
                  9/1      20:01:00:05:ad:90:40:00  00:00:00
                  9/2      20:01:00:05:ad:94:40:00  00:00:00
                  10/1     20:01:00:05:ad:a0:40:00  00:00:00
                  10/2     20:01:00:05:ad:a4:40:00  00:00:00
                  11/1     20:01:00:05:ad:b0:40:00  00:00:00
                  11/2     20:01:00:05:ad:b4:40:00  00:00:00
                  12/1     20:01:00:05:ad:c0:40:00  00:00:00
                  12/2     20:01:00:05:ad:c4:40:00  00:00:00
                  13/1     20:01:00:05:ad:d0:40:00  00:00:00
                  13/2     20:01:00:05:ad:d4:40:00  00:00:00
                  14/1     20:01:00:05:ad:e0:40:00  00:00:00
                  14/2     20:01:00:05:ad:e4:40:00  00:00:00

Total: 1 initiators.
```

Related Commands

[fc srp initiator auto-bind](#)
[fc srp initiator-wwpn](#)
[fc srp it](#)
[fc srp itl](#)
[fc srp lu](#)
[fc srp target](#)
[fc srp-global gateway-portmask-policy restricted](#)
[fc srp-global lun-policy restricted](#)
[speed](#)

show fc srp initiator-wwpn-view

To display SRP targets that an initiator can access through one of its virtual ports, enter the **show fc srp initiator-wwpn-view** command in User Exec mode or Privileged Exec mode.

show fc srp initiator-wwpn-view *wwpn* **target**

Syntax Description

<i>wwpn</i>	World-wide port name (WWPN) of the virtual port of the initiator.
target	Displays the targets that your initiator can access through the virtual port.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

Use this command to verify that your initiator connects to all of the targets that you configured for it.

[Table 6-21](#) describes the fields in the **show fc srp initiator-wwpn-view** command output.

Table 6-21 *show fc srp initiator-wwpn-view* Command Field Descriptions

Field	Description
wwpn	World-wide port name (WWPN) of the target port that the initiator can access through the virtual port.
wwnn	World-wide node name (WWNN) of the target.
description	Description of the target.
ioc-guid	GUID of the I/O controller of the target.
service-name	Service name of the target.
protocol-ids	Protocols that the target supports.
fc-address	Fibre Channel address of the target.
mtu	Maximum transmission unit (MTU), in bytes, of the target.
connection-type	Displays nl-port to indicate a virtual FC port.
physical-access	Physical FC port (in slot#/port# format) of the virtual port.

Examples

The following example displays the targets that the initiator can access through the specified virtual port:

```
SFS-7000P> show fc srp initiator-wwpn-view 20:03:00:05:ad:21:5a:5c target

=====
      SRP Targets Accessible to Initiator Via Port WWN 20:03:00:05:ad:51:5a:5c
=====
      wwpn: 20:01:00:60:45:17:36:1c
      wwnn: 20:09:00:60:45:17:36:1c
      description: SRP.T10:200100604517361C
      ioc-guid: 00:05:ad:00:00:01:38:80
      service-name: SRP.T10:200100604517361C
      protocol-ids: 04:00:00:00:00:00:00:00:00:00
      fc-address: 61:1b:13
      mtu: 0
      connection-type: nl-port
      physical-access: 5/1-5/2,7/1
```

Related Commands

[fc srp initiator](#)
[fc srp-global lun-policy restricted](#)
[show fc srp initiator](#)

show fc srp it

To display initiator-target pairs that you have configured or that your Server Switch has discovered, enter the **show fc srp it** command in User Exec mode or Privileged Exec mode.

show fc srp it [*guid extension target-wwpn*]

Syntax Description

<i>guid</i>	(Optional) GUID of the initiator in the IT pair.
<i>extension</i>	(Optional) GUID extension of the initiator in the IT pair.
<i>target-wwpn</i>	(Optional) World-wide port name (WWPN) of the target FC storage port in the IT pair.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user.

Use this command to verify that you successfully created IT pairs on your Server Switch.

Table 6-22 *show fc srp it Command Output Field Descriptions*

Field	Description
guid	GUID of the initiator in the initiator-target pair.
extension	GUID extension of the initiator in the initiator-target pair.
target-wwpn	WWPN of the target storage.
description	User-assigned description of the initiator-target pair.
non-restricted-ports	Ports on your Server Switch that grant the initiator of the IT pair access to storage.
active-ports	Ports on your Server Switch through which the initiator of the IT pair passes traffic.
physical-access	Physical ports on your Server Switch to which the initiator of the IT pair connects.
mode	Displays “normal-mode” or “test-mode.” Configure the mode to normal-mode to permit initiators to log in to storage. In test-mode, the FC gateway persistently logs in to storage and blocks the initiators.

Table 6-22 *show fc srp it Command Output Field Descriptions*

Field	Description
action	Displays the last action you performed using the config fc srp it command on this initiator target. The action can be <i>discover-itl</i>
result	Displays the result of the action that appears in the “action” field. Possible values are none (when no action was taken), success, in-progress, or fail. Any result other than “Operation completed successfully” occurs due to interface errors.

Examples

The following example displays the details of an IT pair:

```
SFS-7000P# show fc srp it
```

```
=====
                        SRP IT
=====
                        guid: 00:02:c9:02:00:40:0e:d4
                        extension: 00:00:00:00:00:00:00:00
                        target-wwpn: 21:00:00:04:cf:86:a0:1f
                        description: it
non-restricted-ports: 2/1-2/4,3/1-3/4,4/1-4/4,5/1-5/4,
                      : 6/1-6/4,7/1-7/4,8/1-8/4,9/1-9/4,
                      : 10/1-10/4,11/1-11/4,12/1-12/4,13/1-13/4
active-ports: 5/1-5/2
physical-access: 5/1-5/2,7/2
mode: normal-mode
action: none
result: none
```

Related Commands

[fc srp-global gateway-portmask-policy restricted](#)
[fc srp it](#)
[show interface fc](#)

show fc srp itl

To display all ITLs that run through your Server Switch, enter the **show fc srp itl** command in User Exec mode or Privileged Exec mode.

show fc srp itl [*guid extension wwpn LUN*]

Syntax Description	<i>guid</i>	(Optional) Global unique identifier (GUID) of the initiator.
	<i>extension</i>	(Optional) GUID extension of the initiator.
	<i>wwpn</i>	(Optional) World-wide port name (WWPN) of the target port on the FC storage device.
	<i>LUN</i>	(Optional) Logical unit number (LUN) of the FC storage device.

Defaults Enter the **show fc srp itl** command with not arguments to display all ITLs on your Server Switch.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Unrestricted read-write user.

Enter this command without arguments to display the ITL information for all connected Fibre Channel devices. This command displays active and inactive ITLs.

[Table 6-23](#) describes the fields in the **show fc srp itl** command output.

Table 6-23 *show fc srp itl Command Field Descriptions*

Field	Description
guid	GUID of the initiator.
extension	GUID extension of the initiator.
target-wwpn	WWPN of the target port on the FC storage device.
fc-lunid	Fibre Channel LUN ID of the storage disk/tape/stripe.
description	User-configured description.
srp-lunid	Internal SRP LUN ID. This value serves as a SRP-side alias for a FC LUN ID. By default, the srp-lunid value matches the <i>LUN</i> variable.
logical-id (raw 64 bytes)	Numeric disk LU.
logical-id (formatted display)	Alphanumeric disk LU.

Table 6-23 *show fc srp itl Command Field Descriptions (continued)*

Field	Description
gateway-port-mask-policy	Displays a list of unrestricted ports through which the ITL traffic can pass.
lun-policy	Displays restricted when you activate the LUN masking policy and non-restricted when you deactivate the policy.
hi-mark	The maximum number of outstanding requests from the initiator to the storage that the ITL can maintain.
max-retry	Configures the maximum number of retries that the initiator can send to the storage device.
min-io-timeout	Maximum amount of time, in seconds, that elapses before a SRP request times out.
dynamic-path-affinity	Displays true when you enable the feature; otherwise, displays false.
dynamic-gateway-port-loadbalancing	Displays true when you enable the feature; otherwise, displays false.
dynamic-storage-port-loadbalancing	Displays true when you enable the feature; otherwise, displays false. If this feature does not apply to the storage, no output appears.
dynamic-gateway-port-failover	Displays true when you enable the feature; otherwise, displays false.
dynamic-storage-port-failover	Displays true when you enable the feature; otherwise, displays false. If this feature does not apply to the storage, no output appears.
active-slots	Slots on which ITL traffic actively runs.

Examples

The following example displays the ITLs in the configuration file on the Server Switch:

```
SFS-7000P# show fc srp itl
```

```
=====
                        SRP ITL
=====
                        guid: 00:05:ad:00:00:01:29:c5
                        extension: 00:00:00:00:00:00:00:00
                        target-wwpn: 21:00:00:04:cf:f6:c2:ab
                        fc-lunid: 00:00:00:00:00:00:00:00
                        srp-lunid: 00:00:00:00:00:00:00:00
logical-id (raw 64 bytes): 01:03:00:08:20:00:00:04:cf:f6:c2:ab:00:00:00:00
                        : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
                        : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
                        : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
logical-id (formatted display): 2000000000000000
                        description: itl
                        device-category: random
                        lun-policy: non restricted
non-restricted-ports: none
                        active-ports: 6/1
                        physical-access: 6/1
                        hi-mark: 16
                        max-retry: 5
```

```
min-io-timeout: 10
dynamic-path-affinity: false
dynamic-gateway-port-loadbalancing: true
dynamic-storage-port-loadbalancing:
dynamic-gateway-port-failover: false
dynamic-storage-port-failover:
active-slots: 6
```

Total: 1 itls.

Related Commands

[fc srp itl](#)
[fc srp lu](#)
[show fc srp it](#)
[show interface fc](#)

show fc srp itl-statistics

Enter this command without any arguments to display the SRP/Fibre Channel statistics for every ITL. To display ITL I/O statistics, enter the **show fc srp itl-statistics** command in User Exec mode or Privileged Exec mode.

show fc srp itl-statistics [*guid extension wwpn LUN*]

Syntax Description

<i>guid</i>	(Optional) Global unique identifier (GUID) of the initiator.
<i>extension</i>	(Optional) GUID extension of the initiator.
<i>wwpn</i>	(Optional) World-wide port name (WWPN) of the target port on the FC storage device.
<i>LUN</i>	(Optional) Logical unit number (LUN) of the FC storage device.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

Command Output:

[Table 6-24](#) describes the output of the **show fc srp itl-statistics** command.

Table 6-24 *show fc srp itl-statistics Command Field Descriptions*

Field	Description
guid	GUID of the initiator.
extension	GUID extension of the initiator.
target-wwpn	WWPN of the target.
srp-lunid	LUN ID of the LUN in the ITL.
slot-id	Slot on the Server Switch in which the FC gateway resides.
srp-cmds-outstanding	Cumulative number of outstanding SRP commands.
srp-errors	Cumulative number of SRP errors.
srp-initiated-ios	Total number of SRP I/O requests.
srp-bytes-read	Cumulative number of SRP bytes read by one or all FC gateways.
srp-bytes-written	Cumulative number of SRP bytes written by one or all FC gateways.

Table 6-24 *show fc srp itl-statistics Command Field Descriptions (continued)*

Field	Description
fcpcmds-outstanding	Cumulative number of outstanding FC commands.
fcpcmds-completed	Cumulative number of commands that one or all FC gateways executed.
fcpc-errors	Cumulative number of FC errors on one or all gateways.
fcpc-initiated-ios	Total number of FC I/O requests.
fcpc-bytes-read	Cumulative number of FC bytes read by one or all FC gateways.
fcpc-bytes-written	Cumulative number of FC bytes written by one or all FC gateways.

Examples

The following example displays ITL traffic statistics for the ITLs in the configuration file on the Server Switch:

```
SFS-7000P# show fc srp itl-statistics
=====
                        SRP ITL statistics
=====
                        guid: 00:02:c9:00:01:1d:aa:00
                        extension: 00:00:00:00:00:00:00:00
                        target-wwpn: 20:01:00:60:45:17:36:1c
                        srp-lunid: 00:00:00:00:00:00:00:00
                        slot-id: 5
srpcmds-outstanding: 0
srpc-errors: 0
srpc-initiated-ios: 0
srpc-bytes-read: 0
srpc-bytes-written: 0
fcpcmds-outstanding: 0
fcpcmds-completed: 0
fcpc-errors: 0
fcpc-initiated-ios: 0
fcpc-bytes-read: 0
fcpc-bytes-written: 0
```

Related Commands

[fc srp itl](#)
[show fc srp statistics](#)

show fc srp lu

To display attributes of logical units, enter the **show fc srp lu** command in User Exec mode or Privileged Exec mode.

show fc srp lu [*logical-id*]

Syntax Description

<i>logical-id</i>	(Optional) LU identifier, in 64-byte, hexadecimal format. Be sure to omit all colons.
-------------------	---

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

[Table 6-25](#) describes the fields in the **show fc srp lu** command output.

Table 6-25 *show fc srp lu Command Field Descriptions*

Field	Description
logical-id (formatted display)	ID of the LUN.
description	User-defined LU description.
device-category	Displays “random” or “sequential” to identify the type of LUN.
targets	Displays the WWPN of the target in which the LUN resides.
hi-mark	The maximum number of outstanding requests from the initiator to the storage that the ITL can maintain.
max-retry	Displays the number of failed communication attempts that must occur before the LUN identifies the initiator as inaccessible.
min-io-timeout	Maximum amount of time that elapses before a SRP request times out.
dynamic-path-affinity	Displays true if you enable the feature and false if you disable the feature.
dynamic-gateway-port-loadbalancing	Displays true if you enable the feature and false if you disable the feature.

Field	Description
dynamic-storage-port-loadbalancing	Displays true if you enable the feature and false if you disable the feature.
vendor-id	Vendor-assigned ID of the LUN.
product-id	Vendor-assigned product ID of the LUN.
product-revision	Manufacturer-assigned product revision number.
physical-access	FC gateway Ports on your Server Switch that connect to the LU.

The following example displays the LUs (storage disks) that connect to the Server Switch:


```

=====
                        SRP LUs
=====
        logical-id (raw 64 bytes): 01:03:00:08:20:00:00:04:cf:f6:c2:ab:00:00:00:00
                                   : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
                                   : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
                                   : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
        logical-id (formatted display): 20000000000000000
        description: lu-SEAGATE -ST336753FC      -0005
        device-category: random
        targets: 21:00:00:04:cf:f6:c2:ab
        hi-mark: 16
        max-retry: 5
        min-io-timeout: 10
        dynamic-path-affinity: false
        dynamic-gateway-port-loadbalancing: true
        dynamic-gateway-port-failover: false
        vendor-id: SEAGATE
        product-id: ST336753FC
        product-revision: 0005
        physical-access: 6/1

Total: 1 lus.

```

[illegible]

 **show fc srp lu**

```

        hi-mark: 16
        max-retry: 5
        min-io-timeout: 10
        dynamic-path-affinity: false
dynamic-gateway-port-loadbalancing: true
dynamic-gateway-port-failover: false
        vendor-id: SEAGATE
        product-id: ST336753FC
product-revision: 0005
        physical-access: 5/1-5/2,7/2
SFS-7000P#
```

Related Commands

[fc srp lu](#)
[show fc srp initiator](#)
[show fc srp itl](#)
[show interface fc](#)

show fc srp statistics

To display aggregate SRP I/O statistics for all ITLs on your Server Switch, enter the **show fc srp statistics** command in User Exec mode or Privileged Exec mode.

show fc srp statistics

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes: User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

Use the **show fc srp statistics** command to determine load and error count.

The statistical information consists of the following:

- SRP and Fibre Channel commands initiated, outstanding, and completed.
- SRP and Fibre Channel bytes read and written.
- SRP and Fibre Channel errors reported.

[Table 6-26](#) describes the fields in the **show fc srp statistics** command output.

Table 6-26 *show fc srp statistics Command Field Descriptions*

Field	Description
link-events	Total number of link events (link up, link down) processed by the Fibre Channel interface gateways.
srp-cmds-outstanding	Total number of SRP commands outstanding on the Fibre Channel interface gateways.
srp-cmds-completed	Total number of SRP commands completed on the Fibre Channel interface gateways.
srp-errors	Total number of SRP errors encountered on the Fibre Channel interface gateway(s).
srp-initiated-ios	Total number of I/O transactions requested by the SRP initiator.
srp-bytes-read	Total number of I/O bytes read by the SRP initiator that connects to this chassis.
srp-bytes-written	Total number of I/O bytes written by the SRP initiator.

Table 6-26 *show fc srp statistics Command Field Descriptions (continued)*

Field	Description
srp-connections	Total number of connections used by the SRP initiator.
fcp-cmds-outstanding	Total number of FCP commands outstanding on the Fibre Channel interface gateways.
fcp-cmds-completed	Total number of FCP commands completed on the Fibre Channel interface gateways.
fcp-errors	Total number of FCP errors encountered on the Fibre Channel interface gateways.
fcp-initiated-ios	Total number of I/O responses by the Fibre Channel device to SRP initiator requests.
fcp-bytes-read	Total number of I/O bytes read by the target device.
fcp-bytes-written	Total number of I/O bytes written by the target device.

Examples

The following example displays traffic statistics for all of the ITLs on your Server Switch:

```
SFS-7000P# show fc srp statistics
```

```
=====
                        SRP Global Statistics
=====
link-events: 1410805
srp-cmds-outstanding: 0
srp-cmds-completed: 4
srp-errors: 0
srp-initiated-ios: 4
srp-bytes-read: 288
srp-bytes-written: 0
srp-connections: 2
fcp-cmds-outstanding: 0
fcp-cmds-completed: 2
fcp-errors: 0
fcp-initiated-ios: 2
fcp-bytes-read: 0
fcp-bytes-written: 0
```

Related Commands

[show fc srp initiator](#)
[show fc srp itl](#)
[show interface fc](#)

show fc srp target

To display the properties of targets (that you manually configured or that your Server Switch discovered), enter the **show fc srp target** command in User Exec mode or Privileged Exec mode.

show fc srp target [*wwpn*]

Syntax Description

wwpn (Optional) World-wide port name (WWPN) of the target port.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

Enter this command without any arguments to display all target devices known to the Server Switch.

[Table 6-27](#) describes the fields in the **show fc srp target** command output.

Table 6-27 *show fc srp target Command Field Descriptions*

Field	Description
wwpn	Fibre Channel interface port name of the SRP target.
wwnn	World-wide node name of the target.
description	Text label used to identify the service in the Element Manager GUI or CLI output. If you do not apply a description, the system defaults to the service name.
ioc-guid	InfiniBand I/O controller (IOC) through which the initiator accesses the target. On the Cisco SFS 3012 and Cisco SFS 3001 platforms, the IOC identifies a Fibre Channel gateway slot.
service-name	Name of the service to associate with the target.
protocol-ids	Protocols that the target supports.
fc-address	3-byte Fibre Channel Protocol address of the target.
mtu	Maximum transmission unit, in bytes, of the target.
connection-type	Displays “down” if the connection cannot pass traffic. Displays “nl-port” when the target communicates with the virtual port on the Fibre Channel gateway.
physical -access	Fibre Channel port that physically connects to the target.

Examples

The following example displays the targets that connect to the Server Switch:

```
SFS-7000P# show fc srp target
=====
                        SRP Targets
=====
                        wwpn: 20:01:00:60:45:17:36:1c
                        wwnn: 20:09:00:60:45:17:36:1c
                        description: SRP.T10:200100604517361C
                        ioc-guid: 00:05:ad:00:00:01:38:80
                        service-name: SRP.T10:200100604517361C
                        protocol-ids: 04:00:00:00:00:00:00:00:00
                        fc-address: 61:1b:13
                        mtu: 0
                        connection-type: nl-port
                        physical-access: 5/1-5/2
```

Related Commands

[fc srp target](#)
[show fc srp initiator](#)

show fc srp-global

To display the permissions that automatically apply to all new ITs and ITLs, enter the **show fc srp-global** command in User Exec mode or Privileged Exec mode.

show fc srp-global

Syntax Description This command has no arguments or keywords.

Defaults See the [fc srp-global itl](#) command for defaults.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Fibre Channel read-only user.

Examples: The following example displays the default attributes of new ITLs:

```
SFS-7000P# show fc srp-global
```

```
=====
                        SRP Global Information
=====
                        default-gateway-portmask-policy : restricted
                                default-lun-policy : restricted
                                default-itl-hi-mark : 16
                                default-itl-max-retry : 5
                                default-itl-min-io-timeout : 10
                                default-itl-dynamic-path-affinity : false
default-itl-dynamic-gateway-port-load-balancing : true
        default-itl-dynamic-gateway-port-failover : false
                                default-seq-itl-hi-mark : 1
                                default-seq-itl-max-retry : 1
                                default-seq-itl-min-io-timeout : 60
                                default-seq-itl-dynamic-path-affinity : false
default-seq-itl-dynamic-gateway-port-load-balancing : false
        default-seq-itl-dynamic-gateway-port-failover : true
```

Related Commands [fc srp-global gateway-portmask-policy restricted](#)
[fc srp-global itl](#)
[fc srp-global lun-policy restricted](#)

show host

To display the DNS name servers and domain name that your Server Switch uses, enter the **show host** command in User Exec mode or Privileged Exec mode.

show host

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Fibre Channel read-only user.

Use this command to display the network domain of the chassis and the DNS servers that your Server Switch uses to resolve network names to IP addresses.

[Table 6-28](#) describes the fields in the **show host** command output.

Table 6-28 *show host Command Field Descriptions*

Field	Description
name-server-one	IP address of the primary name server.
name-server-two	IP address of the backup name server.
domain-name	Host name of the Server Switch.

Examples The following example displays the IP addresses of the DNS servers that the Server Switch uses to resolve host names:

```
SFS-7000P# show host
=====
                        Host Information
=====
      name-server-one : 10.3.106.20
      name-server-two : 0.0.0.0
      domain-name     : shasta
SFS-7000P#
```

Related Commands

[hostname](#)
[ip](#)

show ib dm ioc

To display the Device Manager input/output controller (IOC) configuration, enter the **show ib dm ioc** command in User Exec mode or Privileged Exec mode.

show ib dm ioc [*ioc-guid* | **all**] [**services**]

Syntax Description

<i>ioc-guid</i>	(Optional) GUID of the controller that you want to view.
all	(Optional) Displays all controllers on the InfiniBand fabric.
services	(Optional) Displays the services that run on the input/output controllers.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

General read-only user.

Command Output:

[Table 6-29](#) describes the fields in the **show ib dm ioc** command output:

Table 6-29 *show ib dm ioc Command Field Descriptions*

Field	Description
guid	GUID of the controller
description	User-assigned description.
vendor-id	Organization Unique Identifier (OUI) of the vendor.
ioc-device-id	Vendor-assigned device identifier.
device-version	Vendor-assigned device version.
subsystem-vendor-id	Vendor-assigned subsystem vendor identifier.
subsystem-id	Vendor-assigned subsystem identifier.
io-class	I/O class that the IOC supports.
io-subclass	Subclass of the I/O class protocol of the IOC.
protocol	Standard protocol definition that the IOC supports.
protocol-version	Protocol version that the IOC supports.
send-msg-q-depth	Maximum number of messages that the send message queue supports.
rdma-read-q-depth	Maximum depth of the per-channel RDMA Read Queue.

Table 6-29 *show ib dm ioc Command Field Descriptions (continued)*

Field	Description
send-msg-size	Maximum size, in bytes, of send messages.
rdma-transfer-size	Maximum size, in bytes, of outbound RDMA transfers that the IOC initiates.
controller-op-cap	Integer value (from 8 cumulative bits) between 1 and 255 that represents the operation types that the IOC supports. <ul style="list-style-type: none"> • bit 0: ST; Send Messages To IOC • bit 1: SF; Send Messages From IOC • bit 2: RT; RDMA Read Requests To IOC • bit 3: RF; RDMA Read Requests From IOC • bit 4: WT; RDMA Write Requests To IOC • bit 5: WF; RDMA Write Requests From IOC • bit 6: AT; Atomic Operations To IOC • bit 7: AF; Atomic Operations From IOC
service-entries	Number of services that the IOC provides.

Table 6-30 describes the fields in the services keyword output.

Table 6-30 *services Keyword Display Output*

Field	Description
ioc-guid	GUID of the node that provides the service.
service-name	ASCII identifier of the service.
service-id	Numeric identifier that nodes use to call the service.

Examples

The following example displays all input/output controller configurations of on the fabric:

```
SFS-7000P> show ib dm ioc
```

```
=====
                        IB Device Manager I/O Controller
=====
                        guid: 00:05:ad:00:00:00:14:fe
                        description:
                        vendor-id: 0x5ad
                        ioc-device-id: 0x5ad
                        device-version: 1
                        subsystem-vendor-id: 0x5ad
                        subsystem-id: 0x5ad
                        io-class: 256
                        io-subclass: 24734
                        protocol: 264
                        protocol-version: 1
                        send-msg-q-depth: 65535
                        rdma-read-q-depth: 65535
```

```

        send-msg-size: -1
rdma-transfer-size: -1
controller-op-cap: 255
service-entries: 14

```

The following example displays all services on all of the input/output controllers in the fabric (output abridged).

```
SFS-7000P> show ib dm ioc services
```

```

=====
IB Device Manager Services
=====
        ioc-guid: 00:05:ad:00:00:00:14:fe
        service-name: SRP.T10:2200000C5002CA21
        service-id: 00:00:00:00:00:00:00:66

        ioc-guid: 00:05:ad:00:00:00:14:fe
        service-name: SRP.T10:2200000C50056281
        service-id: 00:00:00:00:00:00:00:66

```

Related Commands [show ib dm iou](#)

show ib dm iou

To display the Device Manager input/output unit (IOU) configuration, enter the **show ib dm iou** command in User Exec mode or Privileged Exec mode.

show ib dm iou

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012

Privilege Level:
General read-only user.

[Table 6-31](#) describes the fields in the **show ib dm** command output.

Table 6-31 *show ib dm Command Output Fields*

Field	Description
change-id	Cumulative number of changes to the controller list since the device last booted.
max-controllers	Maximum number of controllers that your device can support.
diag-device-id	Displays “1” if diagnostics can provide IOC details; otherwise, displays “0.”
option-rom	Indicates the presence or absence of Option ROM.
controllers	Lists the virtual slots on your Server Switch that run IOC controllers. Note All references to “slot” in this field see virtual slots, not physical slots on the Server Switch.

Examples The following example displays the DM I/O details for the Server Switch:

```
SFS-7000P> show ib dm iou
=====
                        IB Device Manager I/O Unit
=====
                        change-id: 2352
                        max-controllers: 1
                        diag-device-id: 0
                        option-rom: absent
                        controllers: slot-1 IOC present
```

■ show ib dm iou

Related Commands [show ib dm ioc](#)

show ib pm config

To view the performance monitoring configuration on an InfiniBand subnet, enter the **show ib pm config** command in User Execute mode or Privileged Execute mode.

show ib pm config subnet-prefix *prefix*

Syntax Description	subnet-prefix	Specifies the subnet prefix of the InfiniBand subnet for which you want to view performance monitoring.
	<i>prefix</i>	Subnet prefix of the InfiniBand subnet for which you want to view performance monitoring

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

[Table 6-32](#) describes the fields in the show ib pm config command output.

Table 6-32 show ib pm config Command Output Descriptions

Field	Description
subnet-prefix	Subnet prefix of the InfiniBand subnet with the performance monitoring configuration you are viewing.
state	State of performance monitoring (enabled or disabled).
polling period	Interval at which the feature polls ports and connections (in seconds).
start-delay	Time that elapses before performance managing executes (in seconds).

Examples The following example displays the output of the show ib pm config command:

```
SFS-120# show ib pm config subnet-prefix fe:80:00:00:00:00:00:00
=====
                        IB PM Configuration
=====
      subnet-prefix : fe:80:00:00:00:00:00:00
        state      : enable
    polling-period  : 10
      start-delay   : 60
```

■ show ib pm config

Related Commands [ib pm](#)

show ib pm connection counter

To view the performance monitoring counters on all ports on a connection, enter the **show ib pm connection counter** command in User Execute mode or Privileged Execute mode.

show ib pm connection counter subnet-prefix *prefix* **src-lid** *source* **dst-lid** *destination*

Syntax Description		
subnet-prefix		Specifies the subnet prefix of the InfiniBand subnet for which you want to view performance monitoring.
<i>prefix</i>		Subnet prefix of the InfiniBand subnet for which you want to view performance monitoring
src-lid		Specifies the source Local Identifier (LID) of the connection.
<i>source</i>		Source LID of the connection
dst-lid		Specifies the destination LID of the connection.
<i>destination</i>		Destination LID of the connection.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Command Output Description:

subnet-prefix	Subnet to which the connection belongs
node-guid	GUID of the node belonging to the connection
port-num	Port number on the node belonging to the connection.
chassis-guid	GUID of the chassis to which the port belongs (if available)
slot-num	Slot number on the chassis to which the port belongs (if available)
ext-port-num	Port number on the chassis slot to which the port belongs (if available)
data-is-valid	If the value is false, re-run the command to obtain valid data
symbol-errors	Symbol error counter
link-recovery-errors	Link Error Recovery counter
link-downs	Link Downed counter
rcv-errors	Port Receive Error counter

subnet-prefix	Subnet to which the connection belongs
rcv-remote-phy-errors	Port Receive Remote Physical Error counter
rcv-switch-relay-errors	Port Receive Switch Relay Error counter
xmit-discards	Port Transmit Discards counter
xmit-constraint-errors	Port Transmit Constraint Error counter
rcv-constraint-errors	Port Receive Constraint Error counter
local-link-integrity-errors	Local Link Integrity Error counter
excessive-buf-overflow-errors	Excessive Buffer Overflow Error counter.
vl15-dropped	VL15 Dropped counter
xmit-data	Port Transmit Data counter
rcv-data	Port Receive Data counter
xmit-pkts	Port Transmit Packet counter
rcv-pkts	Port Receive Packet counter

See Section 16.1.3.5, PortCounters, InfiniBand Architecture, Vol. 1, Release 1.2, for more information on the port counters.'

Examples

The following example displays performance monitoring counters on all ports on a connection:

```
SFS-120# show ib pm connection counter subnet-prefix fe:80:00:00:00:00:00 src-1
id 2 dst-lid 2
```

```
=====
                        IB PM Port Counter Table
=====
subnet-prefix : fe:80:00:00:00:00:00
node-guid    : 00:05:ad:00:00:01:73:bf
port-num     : 1
chassis-guid : 00:05:ad:00:00:01:73:bf
slot-num     : 1
ext-port-num : 1
data-is-valid : false
symbol-errors : 0
link-recovery-errors : 0
link-downs   : 0
rcv-errors   : 0
rcv-remote-phy-errors : 0
rcv-switch-relay-errors : 0
xmit-discards : 0
xmit-constraint-errors : 0
rcv-constraint-errors : 0
local-link-integrity-errors : 0
excessive-buf-overflow-errors : 0
vl15-dropped : 0
xmit-data    : 0
rcv-data     : 0
xmit-pkts    : 0
rcv-pkts     : 0
```

Related Commands [ib pm](#)

show ib pm connection monitor

To view the state of a performance monitored connection, enter the **show ib pm connection monitor** command in User Execute mode or Privileged Execute mode.

show ib pm connection monitor subnet-prefix *prefix* **src-lid** *source* **dst-lid** *destination*

Syntax Description

subnet-prefix	Specifies the subnet prefix of the InfiniBand subnet for which you want to view performance monitoring.
<i>prefix</i>	Subnet prefix of the InfiniBand subnet for which you want to view performance monitoring
src-lid	Specifies the source Local Identifier (LID) of the connection.
<i>source</i>	Source LID of the connection
dst-lid	Specifies the destination LID of the connection.
<i>destination</i>	Destination LID of the connection.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Command Output Description:

subnet-prefix	Subnet to which the monitored connection belongs
src-lid	16-bit source LID of the connection
dst-lid	16-bit destination LID of the connection
error-status	Error threshold status. If any of the ports in the connection have exceeded a user-defined error threshold, the error-status will be exceeded.
util-status	Utilization threshold status. If any of the ports in the connection have exceeded a user-defined utilization rate threshold, the error-status will be exceeded.

Examples

The following example displays the connection monitor table of a connection:

```
SFS-120# show ib pm connection monitor subnet-prefix fe:80:00:00:00:00:00 src-lid 2 dst-lid 2
```

```
=====
                        IB PM Connection Monitor Table
=====
subnet-prefix : fe:80:00:00:00:00:00
src-lid       : 2
dst-lid       : 2
error-status  : unknown
util-status   : unknown
```

Related Commands [ib pm](#)

show ib pm port counter config

To display the port counter configuration whether access to port counters is either enabled or disabled, enter the **show ib pm port counter config subnet-prefix** command in User Execute mode or Privileged Execute mode. Use the following syntax for this version of the command:

```
show ib pm port counter config subnet-prefix prefix
```

Syntax Description	config	Port counter configuration.
	subnet-prefix	Specifies the subnet prefix of the counters to view.
	<i>prefix</i>	Subnet prefix of the counters to view.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Command Output Description:

subnet-prefix	Subnet to which the port counter configuration applies.
state	State of port counter access. If 'enabled', then access to port counters is enabled.

Examples

The following example shows the configuration of the performance monitoring port counter:

```
SFS-120# show ib pm port counter config subnet-prefix fe:80:00:00:00:00:00:00
=====
IB PM Port Counter Configuration
=====
subnet-prefix : fe:80:00:00:00:00:00:00
state : enabled
```

show ib pm port counter

To display the performance monitoring counters for one or more InfiniBand ports, enter the **show ib pm port counter config subnet-prefix** command in User Execute mode or Privileged Execute mode. Use the following syntax for this version of the command:

show ib pm port counter subnet-prefix *prefix* [**node-guid** *guid* [**port-num** *port*]]

Syntax Descriptionx	subnet-prefix	Subnet prefix to which the port belongs.
	<i>prefix</i>	Prefix number such as fe:80:00:00:00:00:00
	node-guid	GUID of the node to which the port belongs.
	<i>guid</i>	GUID number such as 00:05:ad:00:00:01:0c:19
	port-num	Port number on the node.
	<i>port</i>	Port number such as 1

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Command Output:

Table 6-33 shows the output from this command.

Table 6-33 show ib pm port counter (version 2) Command Output

subnet-prefix	Subnet prefix to which the port belongs.
node-guid	GUID of the node to which the port belongs
port-num	Port number on the node
chassis-guid	GUID of the chassis to which the port belongs (if available)
slot-num	Slot number on the chassis to which the port belongs (if available)
ext-port-num	Port number (if available) on the chassis slot to which the port belongs
data-is-valid	If false, re-run the command to obtain valid data
symbol-errors	Symbol error counter
link-recovery-errors	Link Error Recovery counter
link-downs	Link Downed counter
rcv-errors	Port Receive Error counter
rcv-remote-phy-errors	Port Receive Remote Physical Error counter

rcv-switch-relay-errors	Port Receive Switch Relay Error counter
xmit-discards	Port Transmit Discards counter
xmit-constraint-errors	Port Transmit Constraint Error counter
rcv-constraint-errors	Port Receive Constraint Error counter
local-link-integrity-errors	Local Link Integrity Error counter
excessive-buf-overflow-errors	Excessive Buffer Overflow Error counter
vl15-dropped	VL15 Dropped counter
xmit-data	Port Transmit Data counter
rcv-data	Port Receive Data counter
xmit-pkts	Port Transmit Packet counter
rcv-pkts	Port Receive Packet counter

See Section 16.1.3.5, PortCounters, InfiniBand Architecture, Vol. 1, Release 1.2, for more information on the port counters.

Examples

The following example displays the performance monitoring configuration for an InfiniBand port subnet-prefix:

SFS-7000P# **show ib pm port counter config subnet-prefix fe:80:00:00:00:00:00**

show ib pm port monitor

To show the performance monitoring user-configured monitored ports, or the cumulative port counters, or the cumulative port counters for ports that have exceeded thresholds, enter the **show ib pm port monitor** command in User Execute mode or Privileged Execute mode.

show ib pm port monitor [**counter** | **error-counter**] **subnet-prefix** prefix [**node-guid** guid [**port-num** port]]

Syntax Description	
counter	(Optional) Show the counters accumulated since monitoring was enabled.
error-counter	(Optional) Show the counters accumulated for ports that have exceeded thresholds.
subnet-prefix	Specifies the subnet prefix of the port monitor.
<i>prefix</i>	Subnet prefix of the port monitor.
node-guid	(Optional) Specifies the GUID of the device with the ports that you want to view.
<i>guid</i>	(Optional) GUID of the device with the ports that you want to view.
port-num	(Optional) Specifies the port number of the port that you want to view.
<i>port</i>	(Optional) Port number of the port that you want to view.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Command Output:

subnet-prefix	Subnet to which the connection belongs
node-guid	GUID of the node belonging to the connection
port-num	Port number on the node belonging to the connection.
chassis-guid	GUID of the chassis to which the port belongs (if available)
slot-num	Slot number on the chassis to which the port belongs (if available)
ext-port-num	Port number on the chassis slot to which the port belongs (if available)
data-is-valid	If the value is false, re-run the command to obtain valid data

subnet-prefix	Subnet to which the connection belongs
error-status	Whether or not the error limit has been exceeded.
util status	Whether or not the util limit has been exceeded
symbol-errors	Symbol error counter
link-recovery-errors	Link Error Recovery counter
link-downs	Link Downed counter
rcv-errors	Port Receive Error counter
rcv-remote-phy-errors	Port Receive Remote Physical Error counter
rcv-switch-relay-errors	Port Receive Switch Relay Error counter
xmit-discards	Port Transmit Discards counter
rcv-data	Port Receive Data counter
xmit-pkts	Port Transmit Packet counter
rcv-pkts	Port Receive Packet counter

Examples

The following example displays the user-configured monitored ports for a subnet-prefix:

```
SFS-120# show ib pm port monitor subnet-prefix fe:80:00:00:00:00:00
=====
IB PM Port Monitor Configured Ports Table
=====
subnet-prefix : fe:80:00:00:00:00:00
node-guid : 00:05:ad:00:00:01:73:bf
port-num : 2

subnet-prefix : fe:80:00:00:00:00:00
node-guid : 00:05:ad:00:00:01:73:bf
port-num : 3
```

The following example displays the performance monitoring cumulative counters:

```
SFS-7000P# show ib pm port monitor counter subnet-prefix fe:80:00:00:00:00:00
=====
IB PM Port Monitor Table
=====
subnet-prefix : fe:80:00:00:00:00:00
node-guid : 00:05:ad:00:00:01:3d:90
port-num : 1
chassis-guid : 00:00:00:00:00:00:00
slot-num : 0
ext-port-num : 0
data-is-valid : true
error-status : not-exceeded
util-status : not-exceeded
symbol-errors : 10
link-recovery-errors : 1020
link-downs : 1
rcv-errors : 0
rcv-remote-phy-errors : 0
rcv-switch-relay-errors : 0
xmit-discards : 3
Press any key to continue (Q to quit)
```

The following example displays the performance monitoring cumulative counters for all ports that have exceeded thresholds:

```
show ib pm port monitor error-counter
```

Related Commands

[ib pm](#)

show ib pm threshold

To view performance monitoring thresholds, enter the **show ib pm threshold** command in User Execute mode or Privileged Execute mode.

show ib pm threshold subnet-prefix *prefix*

Syntax Description

subnet-prefix	Specifies the subnet prefix of the thresholds to view.
<i>prefix</i>	Subnet prefix of the thresholds to view.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Command Output:

subnet-prefix	Subnet to which the threshold configuration applies.
symbol-errors	Threshold for Symbol Error counters.
link-recovery-errors	Threshold for Link Recovery Error counters.
link-downs	Threshold for Link Downed counters.
rcv-errors	Threshold for Port Receive Error counters.
rcv-remote-phy-errors	Threshold for Port Receive Remote Physical Error counters.
rcv-switch-relay-errors	Threshold for Port Receive Switch Relay Error counters.
xmit-discards	Threshold for Port Transmit Discard Error counters.
xmit-constraint-errors	Threshold for Port Transmit Constraint Error counters.
rcv-constraint-errors	Threshold for Port Receive Constraint Error counters.
local-link-integrity-errors	Threshold for Local Link Integrity Error counters.
excessive-buf-overflow-errors	Threshold for Excessive Buffer Overflow Error counters
vl15-dropped	Threshold for VL15 Dropped Error counters
xmit-rate	Threshold for transmit rate, as a percentage of total port bandwidth
rcv-rate	Threshold for receive rate, as a percentage of total port bandwidth

Examples

The following example displays performance monitoring thresholds:

```
SFS-120# show ib pm threshold subnet-prefix fe:80:00:00:00:00:00
```

```
=====
                        IB PM Thresholds
=====
      subnet-prefix : fe:80:00:00:00:00:00
      symbol-errors  : none
    link-recovery-errors : none
          link-downs  : 1
          rcv-errors  : none
    rcv-remote-phy-errors : none
    rcv-switch-relay-errors : none
          xmit-discards : none
    xmit-constraint-errors : none
          rcv-constraint-errors : none
    local-link-integrity-errors : none
    excessive-buf-overflow-errors : none
          vl15-dropped : none
          xmit-rate    : 1
          rcv-rate     : 1
```

Related Commands [ib pm](#)

show ib sm configuration

To display information about the subnet managers on your InfiniBand fabric, enter the **show ib sm configuration** command in User Exec mode or Privileged Exec mode.

```
show ib sm configuration { subnet-prefix prefix | all } [summary]
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of subnet manager that you want to view.
prefix	Subnet prefix of the subnet manager that you want to view.
all	The current CLI can only report the local subnet manager configuration data. Therefore, the subnet-prefix value of 'all' is just an alias to the subnet value of the subnet manager local to the CLI.
summary	(Optional) Displays an abridged form of the command output. The abridged information includes the subnet prefix, GUID, priority, and subnet manager key of the subnet managers.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:
[Table 6-34](#) describes the fields in the **show ib sm configuration** command output.

Table 6-34 show ib sm configuration Command Field Descriptions

Field	Description
subnet-prefix	64-bit value used that identifies the InfiniBand subnet. This is a unique subnet identifier joins with the GUID to form the global identifier (GID) of the port. Each GIDs within a subnet has the same subnet prefix.
guid	GUID of this subnet manager.
priority	User-assigned priority for this subnet manager. You must enter an integer between 0 and 15. The value defaults to 10. Note When the chassis boots, the subnet manager priority defaults to 10. When you add the subnet manager manually, the priority defaults to 10.

Table 6-34 *show ib sm configuration Command Field Descriptions (continued)*

Field	Description
sm-key	64-bit subnet management key assigned to the subnet manager. The sm-key defaults to 00:00:00:00:00:00:00:00. The sm-key serves as the prefix of all GIDs and brands nodes as members of this subnet.
oper-status	Operational status of the subnet manager. Self-detection determines this status. The value appears as notActive, discovering, standby, or master. If notActive appears, the subnet manager has not been enabled or has been disabled. The discovering output appears when the subnet manager sweeps the fabric. If standby appears, the subnet manager serves as a slave subnet manager. If only one subnet manager runs on the fabric, it serves as the master.
act-count	Activity counter that increments each time the subnet manager issues a subnet management packet (SMP) or performs other management activities.
status	Status of the subnet manager. It appears as active or inactive . If active , it is actively managing subnets. If inactive , it is not managing subnets.
master-poll-interval	Interval at which the slave subnet manager polls the master to see if the master is still active.
master-poll-retries	Number of unanswered polls that cause the slave to identify the master as inactive.
max-active-sms	Maximum number of standby subnet managers that the master supports.
LID-mask-control	Number of path bits present in the base LID to each channel adapter port. Increasing the LMC value increases the number of LIDs assigned to each port to increase the number of potential paths to reach each port.
switch-life-time	The packet lifetime inside a Server Switch.
switch-hoq-life-time	The packet lifetime at the head-of-queue of a switch port.
host-hoq-life-time	The lifetime of a packet at the head-of-queue of the host port.
max-hops	Maximum number of times the subnet manager can be redirected.
mad-retries	Number of times the subnet manager will retry to send a management diagram after not receiving a response. The value range is 0 - 100; the default value is 5.
node-timeout	Minimum amount of time in seconds that a HCA may be unresponsive before the subnet manager will remove it from the InfiniBand fabric. The value range is 1 - 2000 seconds; the default value is 10 seconds.
wait-report-response <true false>	Determines whether or not the subnet manager waits to receive a ReportResponse MAD in response to the Report MAD that it forwards. This value is Boolean. If false, the subnet manager sends the Report MAD only once; if set to true, the subnet manager continues to send the Report MAD until either the ReportResponse MAD is received or the maximum number of Report MAD have been sent. The default value is false.
sa-mad-queue-deoth	Size of the SA's internal queue for receiving a management diagram. The value range is 256 - 1024; the default value is 256.

Examples

The following example shows the detailed configuration of a subnet manager:

```
SFS-7000P# show ib sm configuration subnet-prefix fe:80:00:00:00:00:00:00

=====
Subnet Manager Information
=====
subnet-prefix : fe:80:00:00:00:00:00:00
  guid       : 00:05:ad:00:00:01:5f:f2
  priority   : 10
  sm-key     : 00:00:00:00:00:00:00:00
  oper-status : master
  act-count  : 43392
  sweep-interval(sec) : 10
  response-timeout(msec) : 200
  master-poll-intval(sec) : 3
  master-poll-retries : 2
  max-active-sms : 0
  LID-mask-control : 0
  switch-life-time : 20
  switch-hoq-life-time : 20
  host-hoq-life-time : 20
  max-hops : 64
  mad-retries : 5
  node-timeout(sec) : 5
  wait-report-response : false
  sa-mad-queue-depth : 256
```

The following example shows the summary configuration of a subnet manager:

```
SFS-7000P> show ib sm configuration subnet-prefix fe:80:00:00:00:00:00:00 summary

=====
Subnet Manager Configuration Summary
=====
subnet-prefix      guid                priority sm-key
-----
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:5f:f2 10      00:00:00:00:00:00:00:00
SFS-7000P>
```

Related Commands

[ib sm](#)
[ib-agent](#)
[show ib-agent switch](#)
[name](#)

show ib sm db-sync

Use this command to determine the following:

- If the database of the master subnet manager synchronizes with one or more standby databases.
- The frequency with which the databases synchronize.

To display subnet manager synchronization information, enter the **show ib sm db-sync** command in User Exec mode or Privileged Exec mode.

show ib sm db-sync subnet-prefix {*prefix* | **all**}

Syntax Description	subnet-prefix	Specifies the subnet prefix of the subnet manager with the synchronization status that you want to view.
	<i>prefix</i>	Prefix of the subnet manager with the synchronization status that you want to view.
	all	Displays synchronization data for all subnet managers on the fabric.

Defaults This command has no default settings.

Command Modes User Exec mode, Privileged Exec mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:

Table 6-35 *show ib sm db-sync Command Field Descriptions*

Field	Description
subnet-prefix	Subnet prefix of the subnet with the synchronization information that you want to view.
enable	Displays true if an administrator has enabled synchronization; otherwise, displays false.
max-backup-sms	The maximum number of backup subnet managers that the master subnet manager supports.
session-timeout	The interval, in seconds, during which a synchronization session status management diagram packet must arrive at the master subnet manager to maintain synchronization.

Table 6-35 *show ib sm db-sync Command Field Descriptions*

Field	Description
poll-interval	Interval at which the master subnet manager polls an active slave subnet manager to verify synchronization.
cold-sync-timeout	Maximum amount of time in which subnet managers can perform a cold synchronization. During the cold-sync, the master subnet manager copies all out-of-sync tables to the standby subnet manager.
cold-sync-limit	Maximum number of cold synchronizations that may take place during the cold-sync period.
cold-sync-period	Length of the interval during which cold-syncs may occur.
new-session-delay	Amount of time that the master subnet manager waits before it attempts to initiate a synchronization session with a new subnet manager.
resync-interval	Specifies the interval at which the master subnet manager sends a re-synchronization request to all active synchronization sessions.
state	Specifies whether or not the subnet manager is synchronized with the backup.

Examples

The following example displays subnet manager synchronization information:

```
show ib sm db-sync subnet-prefix fe:80:00:00:00:00:00
```

```
=====
Subnet Manager Database Synchronization Information
=====

subnet-prefix : fe:80:00:00:00:00:00
enable       : false
max-backup-sms : 1
session-timeout : 10
poll-interval  : 3
cold-sync-timeout : 10
cold-sync-limit : 2
cold-sync-period : 900
new-session-delay : 120
resync-interval : 3600
state        : not in-sync
```

Related Commands [ib sm db-sync](#)

show ib sm lft

Use this command to display the following:

- Linear forwarding information based on the block number.
- Linear entries that are currently in use by subnet manager.

To display linear forwarding information based on the LID block number, enter the **show ib sm lft** command in User Exec mode or Privileged Exec mode. The command reports only entries that are currently in use by the subnet manager.

show ib sm lft subnet-prefix {*prefix* | **all**}[**lid** *lid* | **node-guide** *guid*]

Syntax Description

subnet-prefix	Subnet prefix of the subnet manager with the status that you want to view.
<i>prefix</i>	Displays the linear forwarding table info for a specific subnet or all the subnets in the fabric.
all	Currently, "all" is an alias to the subnet value of the local subnet manager.
lid	Local ID of the subnet.
<i>lid</i>	Local ID number.
node-guide	Guid of the switch node in the subnet with the FDB is to be accessed.
<i>guid</i>	Guid number.

Defaults

This command has no default settings.

Command Modes

User Exec mode, Privileged Exec mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Command Output:

Table 6-36 *show ib sm lft Command Field Descriptions*

Field	Description
NodeGuid	Guid of the switch node in the subnet with the FDB that you want to access.
LID	Local ID of the subnet.
Port	Port number.

Examples

This example displays linear forwarding information for all subnets based on the LID block number:

```
Topspin-120# show ib sm lft subnet-prefix all
```

```
=====
                        Linear Forwarding Table
=====
node-guid                lid port
-----
00:05:ad:00:00:00:14:cd  2    5
00:05:ad:00:00:00:14:cd  5    5
00:05:ad:00:00:00:14:cd  6    0
00:05:ad:00:00:00:14:cd  7    5
00:05:ad:00:00:00:14:cd  8    2
00:05:ad:00:00:00:14:cd  9    5
```

show ib sm mft

Use this command to display the following:

- Multicast forwarding information based on the block number.
- Multicast entries that are currently in use by a subnet manager.

To display multicast forwarding information based on the LID block number, enter the **show ib sm mft** command in User Exec mode or Privileged Exec mode. The command reports only the entries that are currently in use by a subnet manager.

show ib sm mft subnet-prefix {*prefix* | **all**} [**lid** *lid* | **node-guide** *guid*]

Syntax Description		
subnet-prefix		Specifies the subnet prefix of the subnet manager with the status that you want to view.
<i>prefix</i>		Displays the multicast forwarding table info for a specific subnet or all the subnets in the fabric.
all		Currently, “all” is just an alias to the subnet value of the local subnet manager.
lid		Local ID of the subnet.
<i>lid</i>		Local ID number.
node-guide		Guide of the switch node in the subnet with the FDB to be accessed.
<i>guid</i>		Guide number.

Defaults

This command has no default settings.

Command Modes

User Exec mode, Privileged Exec mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Examples

This example displays multicast forwarding information for all subnets, based on the LID block number:

```
Topspin-360> show ib sm mft subnet-prefix all
=====
Multicast Forwarding Table
=====
node-guid                mlid      port-mask(0, 1, 2 ...)
-----
00:05:ad:00:00:00:02:30  49152     0x1a
00:05:ad:00:00:00:02:30  49153     0x11a
00:05:ad:00:00:00:02:30  49154     0x11a
00:05:ad:00:00:00:02:30  49155     0x118
00:05:ad:00:00:00:02:30  49156     0x118
00:05:ad:00:00:00:02:30  49157     0x118
00:05:ad:00:00:00:02:30  49158     0x118
00:05:ad:00:00:00:02:30  49159     0x118
00:05:ad:00:00:00:02:30  49160     0x118
```

show ib sm sm-info

To display subnet manager information maintained by the subnet manager on this device, enter the **show ib sm sm-info** command in User Exec mode or Privileged Exec mode.

show ib sm sm-info subnet-prefix *subnet-prefix* [**port-guid** *port-guid*] [**summary**]

Syntax Description		
subnet-prefix		Displays the information of subnet managers discovered in the subnet specified by subnet-prefix.
<i>subnet-prefix</i>		Prefix of the subnet with the desired Subnet Managers' information, for example, fe:80:00:00:00:00:00:00.
port-guid		(Optional) Displays the information of the Subnet Manager residing at the port specified by port-guid.
<i>port-guid</i>		(Optional) Specifies the port-guid.
summary		(Optional) Displays a summary of the discovered subnet managers in the fabric.

Defaults This command has no default settings.

Command Modes User Exec mode, Privileged Exec mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Examples This example displays subnet manager information:

```
SFS-270# show ib sm sm-info subnet-prefix fe:80:00:00:00:00:00:00 summary
=====
Summary of Discovered Subnet Managers in Fabric
=====
subnet-prefix          port-guid              priority state
-----
fe:80:00:00:00:00:00  00:05:ad:00:00:01:5f:f2  10
```

Related Commands [ib sm db-sync](#)

show ib sm multicast

Troubleshoot with this command when a host does not receive a broadcast packet. Use this command to verify that the multicast group includes the host. The subnet manager dynamically configures all multicast groups. To display attributes of the multicast groups on your Server Switch, enter the **show ib sm multicast summary** command in User Exec or Privileged Exec mode.

```
show ib sm multicast {subnet-prefix {prefix / all} [mgid multicast-group-GID] [summary]}
|| summary}
```

Syntax Description

subnet-prefix	Prefix of the subnet containing multicast groups.
<i>prefix</i>	Prefix address, such as fe:80:00:00:00:00:00.
all	Display multicast groups configured in the entire fabric.
mgid	(Optional) Specifies the global identifier (GID) of the multicast group.
<i>multicast-group-GID</i>	Global identifier, such as ff:12:40:1b:ff:f1:00:00:00:00:00:00:ff:ff:ff:ff.
summary	(Optional) Displays an abridged form of the data. The abridged information includes the subnet prefix, GUID, priority, and subnet manager key of the subnet managers.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Command Output:

[Table 6-37](#) describes the fields in the **show ib sm configuration** command output.

Table 6-37 *show ib sm multicast Command Field Descriptions*

Field	Description
subnet-prefix	Subnet prefix of the subnet manager.
MGID	Multicast group identifier.
port-GID	Global identifier of a port that belongs to the multicast group.

Table 6-37 *show ib sm multicast Command Field Descriptions (continued)*

Field	Description
member-join-state	Type of membership that the member has in the multicast group. Members qualify as full members, non-members, or send-only members.
proxy-join-status	This field displays false except for trusted requests. For details, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .

Examples

The following example displays a summary of the multicast groups on the Server Switch:

```
SFS-7000P# show ib sm multicast summary
=====
Summary of Multicast-Groups on Device
=====
subnet-prefix : fe:80:00:00:00:00:00:00
MGID : ff:12:40:1b:ff:f1:00:00:00:00:00:00:00:ff:ff:ff:ff

multicast-group-members :
port-GID : fe:80:00:00:00:00:00:00:00:05:ad:00:00:00:12:bf
member-join-state : full-member
proxy-join-status : false
```

Related Commands [ib sm](#)

show ib sm neighbor

To display the InfiniBand devices that directly connect to your Server Switch, enter the **show ib sm neighbor** command in User Exec mode or Privileged Exec mode.

show ib sm neighbor

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:
[Table 6-38](#) describes the fields in the **show ib sm neighbor** command output.

Table 6-38 *show ib sm neighbor Command Field Descriptions*

Field	Description
subnet-prefix	64-bit value that identifies the InfiniBand subnet to which this neighbor node belongs.
local-node-guid	64-bit GUID of the InfiniBand node.
local-port-id	Port ID of the InfiniBand node. You must enter an integer between 0 and 255.
local-node-type	Type of the InfiniBand node. The value appears as channel-adapter, switch, or router.
remote-node-guid	64-bit GUID of the neighboring InfiniBand node to which the local node links.
remote-port-id	Port ID of the neighboring InfiniBand node to which the local node links. You must enter an integer between 0 and 255.
remote-node-type	Type of the neighboring InfiniBand node. The value appears as channel-adapter, switch, or router.
link-state	State of the link between the local and neighboring nodes. The value appears as noStateChange, down, initialize, armed, or active.
link-width-active	Active link width. This parameter, with LinkSpeedActive, determines the link rate between the two connected nodes. The value appears as width1x, width4x, or width12x.

Examples

The following example displays the GUIDs that connect to your Server Switch and the GUIDs within your Server Switch:

**Note**

Truncated output appears here.

```
SFS-7000P# show ib sm neighbor
=====
Subnet Management Neighbors
=====
subnet-prefix : fe:80:00:00:00:00:00
local-node-guid : 00:05:ad:00:00:00:11:97
local-port-id : 2
local-node-type : channel-adapter
remote-node-guid : 00:05:ad:00:00:00:13:da
remote-port-id : 1
remote-node-type : switch
link-state : active
link-width-active : width4x
```

Related Commands

[ib sm](#)

show ib sm node

Use this command to display the configuration of all the nodes on a subnet or to display the configuration of an individual node. The output may also be displayed in summary form. The summary comprises the subnet-manager prefix, the node guide and type, and the vendor identification. The node summary includes the node GUID, node type, vendor identification, description, and system-image-guid. To display the configuration and attributes of subnet management nodes in a subnet, enter the **show ib sm node** command in User Exec mode or Privileged Exec mode.

show ib sm node subnet-prefix *prefix* / **all** [**node-guid** *guid*] [**summary**]

Syntax Description

subnet-prefix	Specifies the subnet prefix of the nodes that you want to view.
<i>prefix</i>	Subnet prefix of the nodes that you want to view.
all	Display subnet management nodes configured in the entire fabric.
node-guid	(Optional) Specifies the GUID of an individual node that you want to view.
<i>guid</i>	(Optional) GUID of an individual node that you want to view.
summary	(Optional) Displays abridged command output.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

All nodes that the subnet manager on your Server Switch actively manages qualify as subnet management nodes.

Command Output:

[Table 6-39](#) describes the fields in the **show ib sm node** command output.

Table 6-39 *show ib sm node Command Field Descriptions*

Field	Description
subnet-prefix	64-bit value that identifies the InfiniBand subnet to which this node belongs.
node-guid	Guide of the node.

Table 6-39 *show ib sm node Command Field Descriptions (continued)*

Field	Description
base-version	Supported base management datagram (MAD) version. Indicates that this channel adapter, switch, or router supports versions up to and including this version. See section 13.4.2, Management Datagram Format, in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
class-version	Supported MAD class format version. Indicates that this channel adapter, switch, or router supports versions up to, and including, this version.
type	Type of node being managed. The value appears as channel adapter, switch, router, or error. An error entry indicates an unknown type.
num-ports	Number of physical ports on the node.
port-guid	Guide of the port that connects the node to the Server Switch. A port within a node can return the node GUID as its PortGUID if the port serves as an integral part of the node and you cannot replace the port in the field (not swappable).
partition-cap	Capacity of entries in the partition table for channel adapter, router, and the switch management port. The value appears the same for all ports on the node. This defaults to at least 1 for all nodes including switches. You cannot configure this value.
device-id	Manufacturer-assigned device identification.
revision	Manufacturer-assigned device revision.
local-portnum	The link port number from which this subnet management packet (SMP) arrived. The value appears the same for all ports on the node.
vendor-id	Device vendor ID. The value appears the same for all ports on the node.
system-image-guid	Guide of an associated supervisory node. No supervisory node exists if the command output displays 00:00:00:00:00:00:00:00.

Examples

The following example (output abridged) displays the configuration of all the nodes on all the subnets on the InfiniBand fabric:

```
SFS-7000P# show ib sm node subnet-prefix fe:80:00:00:00:00:00:00
```

```
=====
                        Subnet Management Nodes
=====
subnet-prefix : fe:80:00:00:00:00:00:00
node-guid    : 00:00:2c:90:01:1b:ba:80
description  : swfc5 HCA-1 (Topspin HCA)
base-version : 1
class-version : 1
type         : channel adapter
num-ports    : 2
port-guid    : 00:00:2c:90:01:1b:ba:81
partition-cap : 64
device-id    : 0
revision     : 0
local-portnum : 1
vendor-id    : 00:2c:90
system-image-guid : 00:00:00:00:00:00:00:00
```

```

subnet-prefix : fe:80:00:00:00:00:00:00
node-guid : 00:05:ad:00:00:00:13:da
description : Topspin Switch - U1
base-version : 1
class-version : 1
type : switch
num-ports : 8
port-guid : 00:05:ad:00:00:00:13:da
partition-cap : 32
device-id : 0
revision : 0
local-portnum : 6
vendor-id : 00:05:ad
system-image-guid : 00:00:00:00:00:00:00:00

```

The following example displays a node configuration in summary form:

```

SFS-7000P# show ib sm node subnet-prefix fe:80:00:00:00:00:00:00 node-guid
00:05:ad:00:00:00:13:80 summary
=====
Subnet Manager Node Summary
=====
node-guid           node-type           vendor-id description      System-image-guid
-----
00:05:ad:00:00:00:13:80 channel adapter 00:05:ad              00:00:00:00:00:00:00:00
SFS-7000P#

```

Related Commands

[ib sm](#)

show ib sm partition

To display the partitions that the subnet manager on your Server Switch manages, enter the **show ib sm partition** command in User Exec mode or Privileged Exec mode.

show ib sm partition *[[node-guid guid port-num num]][subnet-prefix val]*

Syntax Description	Field	Description
	node-guid	GUID of the node in the partition.
	<i>guid</i>	GUID value, such as 00:05:ad:00:00:00:02:40.
	port-num	Port on the node that belongs to the partition.
	<i>num</i>	Port number value, such as zero.
	subnet-prefix	Subnet prefix of the subnet with the partitions that you want to view.
	<i>val</i>	Subnet-prefix value such as fe:80:00:00:00:00:00:00.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

A single partition can have members that have full-membership, as well as members that have limited membership.

See the *Cisco SFS 7000 Series Product Family Element Manager User Guide* for detailed information about partitions.

Command Output:

In the output, ff:ff refers to the default partition, which cannot be altered. Members of partitions are identified by their Node GUID and port-number, as displayed below.

[Table 6-40](#) describes the fields in the **show ib sm partition** command output.

Table 6-40 *show ib sm partition Command Field Descriptions*

Field	Description
subnet-prefix	Subnet prefix of the subnet with the partitions that you want to view.
p_key	Partition key of the partition with the members the display prints below.
node-guid	GUID of the node in the partition.

Table 6-40 show ib sm partition Command Field Descriptions (continued)

Field	Description
port-number	Port on the node that belongs to the partition.
member-type	Type of membership that an administrator assigns to the node, either full or limited.

Examples

The following example displays the configuration of all nodes on all subnets on the InfiniBand fabric:

```
SFS-7000P# show ib sm partition
=====
Partitions Managed By The Subnet Managers
=====
subnet-prefix : fe:80:00:00:00:00:00:00
p_key : ff:ff

partition-members :
    node-guid : 00:05:ad:00:00:00:02:40
    port-number : 0
    member-type : full-member

    node-guid : 00:05:ad:00:00:00:02:42
    port-number : 0
    member-type : full-member
```

Related Commands [ib sm](#)

show ib sm port

Use this command to verify that all ports in your fabric came up when the subnet manager initialized them. To display all InfiniBand ports on the fabric, the nodes to which the ports belong, the capabilities of the ports, and the link statistics of the ports, enter the **show ib sm port** command in User Exec mode or Privileged Exec mode.

show ib sm port subnet-prefix *prefix* / **all** [**node-guid** *guid*] [**summary**]

Syntax Description		
subnet-prefix		Specifies the subnet prefix of the subnet manager that manages the ports that you want to view.
<i>prefix</i>		Subnet prefix of the subnet manager that manages the ports that you want to view.
all		Display all subnet management ports in the fabric.
node-guid		(Optional) Specifies the GUID of an individual node with the ports that you want to view.
<i>guid</i>		(Optional) GUID of an individual node with the ports that you want to view.
summary		(Optional) Displays abridged command output.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Port information may be reported for all the ports on a specific subnet or all the ports comprising a specific node. The output may also be displayed in summary form.

Command Output:

Table 6-41 describes the fields in the **show ib sm port** command output.

Table 6-41 show ib sm port Command Field Descriptions

Field	Description
subnet-prefix	64-bit value that identifies the InfiniBand subnet to which this port belongs.
node-guid	64-bit GUID of the node to which this port belongs.
if-index	Port number (integer) on the node (host).

Table 6-41 show ib sm port Command Field Descriptions (continued)

Field	Description
mkey	64-bit management key for this port. See section 14.2.4, Management Key and 3.5.3, Keys, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
gid-prefix	64-bit Global identifier prefix for this port. The subnet manager assigns this prefix based upon the port router and the rules for local identifiers. See section 4.1.3, Local Identifiers, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
lid	16-bit base-LID of this port.
master-sm-lid	16-bit base LID of the master subnet manager managing this port.
cap-mask	The capability mask identifies the functions that the host supports. 32-bit bitmask that specifies the supported capabilities of the port. A bit value of 1 (one) indicates a supported capability. The bits are 0, 11-15, 18, 21-31 (Reserved and always 0.), 1 IsSM, 2 IsNoticeSupported, 3 IsTrapSupported, 4 IsResetSupported, 5 IsAutomaticMigrationSupported, 6 IsSLMappingSupported, 7 IsMKeyNVRAM (supports M_Key in NVRAM), 8 IsPKeyNVRAM (supports P_Key in NVRAM), 9 Is LED Info Supported, 10 IsSMdisabled, 16 IsConnectionManagementSupported, 17 IsSNMPTunnelingSupported, 19 IsDeviceManagementSupported, 20 IsVendorClassSupported. Values are expressed in hexadecimal.
diag-code	16-bit diagnostic code. See section 14.2.5.6.1 Interpretation of Diagcode, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information. This field does not currently apply to your Server Switch.
mkey-lease-period	Initial value of the lease-period timer, in seconds. The lease period is the length of time that the M_Key protection bits are to remain non-zero after a SubnSet (PortInfo) fails an M_Key check. After the lease period expires, clearing the M_Key protection bits allows any subnet manager to read (and then set) the M_Key. Set this field to 0 to indicate that the lease period never expires. See <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 14.2.4, “Management Key.”
link-width-enabled	Enabled link width (bandwidth). The value (an integer) indicates the enabled link-width sets for this port. The value may be <ul style="list-style-type: none"> • 0 (no state change), • 1 (1x), • 2 (4x), • 3 (1x or 4x), • 8 (12x), • 9 (1x or 12x), • 10 (4x or 12x), • 11 (1x, 4x or 12x), • 255 (set this parameter to the link-width-supported value).
link-width-supported	Supported link width. The value appears as 1 (1x), 3 (1x or 4x), or 11 (1x, 4x, or 12x).
link-width-active	Active link width. Used in conjunction with LinkSpeedActive to determine the link rate between two nodes. The value appears as 1 (1x), 2 (4x), or 8 (12x).

Table 6-41 *show ib sm port Command Field Descriptions (continued)*

Field	Description
link-speed-supported	Supported link speed. The value appears as 1 (2.5 Gbps).
state	A higher form of addressing than PhyState, state determines that the nodes can actually communicate and indicates the state transition that has occurred. A transition identifies a port change from down to initialize, initialize to down, armed to down, or active to down as a result of link state machine logic. Changes to the port state resulting from SubnSet have no affect on this parameter value. The value appears as noStateChange, down, initialize, armed, or active.
phy-state	Indicates the physical state of the port, whether or not electricity flows between nodes and that they can perform a handshake. The value appears as noStateChange, sleeping, polling, disabled, portConfigurationTraining, linkup, or linkErrorRecovery. The state, upon power-up, defaults to polling.
link-down-def-state	Default LinkDown state to return to. The value appears as noStateChange, sleeping, or polling. See section 5.5.2, Status Outputs (MAD GET), <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
mkey-prot-bits	Management key protection bits for the port. The bits are 0, 1, 2, and 3. See section 14.2.4.1, Levels of Protection, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
lmc	Local-identifier mask control (LMC) for multi-path support. A LMC resides on each channel adapter and router port on the subnet. It provides multiple virtual ports within a single physical port. The value of the LMC specifies the number of path bits in the LID. A value of 0 (zero) indicates one LID can apply to this port. See sections 3.5.10, Addressing, and 4.1.3, Local Identifiers, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
link-speed-active	Speed of an active link. The value appears as 1 (2.5 Gbps).
link-speed-enabled	Maximum speed that the link can handle. The value appears as 0 (No state change), 1 (2.5 Gbps), or 3 (value derived from link-speed-supported).
neighbor-mtu	Active maximum transmission unit enabled on this port for transmit. Check the mtu-cap value at both ends of every link and use the lesser speed. The value appears as mtu256, mtu512, mtu1024, mtu2048, or mtu4096.
master-sm-SL	Administrative service level required for this port to send a non-SMP message to the subnet manager.
VL-cap	Maximum range of data virtual lanes supported by this port. The value appears as vl0, vl0ToV11, vl0ToV13, vl0ToV17, or vl0ToV114. See also oper-VL. Each port can support up to 15 virtual lanes (VLs 0 - 15). The VL-cap field displays the range of those lanes (for example, lanes 0 - 7) that the port currently supports.
VL-high-limit	Maximum high-priority limit on the number of bytes allowed for transmitting high-priority packets when both ends of a link operate with multiple data virtual-lanes. Used with the virtual-lane arbitration table. The maximum high-limit matches the vl-arb-high-cap on the other side of the link and then negotiating downward.

Table 6-41 show ib sm port Command Field Descriptions (continued)

Field	Description
VL-arb-high-cap	Highest arbitration value allowed by the arbiter in determining the next packet in a set of packets to send across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. See section 14.2.5.9, VL Arbitration Table, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
VL-arb-low-cap	Lowest arbitration value allowed by the arbiter in determining the next packet in a set of packets to send across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. See section 14.2.5.9, VL Arbitration Table, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
mtu-cap	Used in conjunction with neighbor-mtu to determine the maximum transmission size supported on this port. The lesser of mtu-cap and neighbor-mtu determines the actual MTU used. The value appears as 256, 512, 1024, 2048, or 4096.
VL-stall-count	Number of sequentially dropped packets at which the port enters a VLStalled state. The virtual lane exits the VLStalled state (8 * HLL) units after entering it. See section 18.2.5.4, Transmitter Queuing, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for a description of HLL.
HOQ-life	Maximum duration allowed to packets at the head of a virtual-lane queue. Used with VL-stall-count to determine the outgoing packets to discard.
oper-VL	Administrative limit for the number of virtual lanes allowed to the link. Do not set this above the VL-cap value. The value appears as v10, v10-V11, v10-V13, v10-V17, or v10-V114.
in-part-enforce	Boolean value that indicates whether or not to support optional partition enforcement for the packets that were received by this port. No default value applies.
out-part-enforce	Boolean value that indicates whether or not to support optional partition enforcement for the packets transmitted by this port. No default value applies.
in-filter-raw-pkt-enforce	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets that were received by this port. No default value applies.
out-filter-raw-pkt-enforce	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets transmitted by this port. No default value applies.
mkey-violation	Number of subnet management packets (SMPs) that have been received on this port with invalid M_Keys since initial power up or the last reset. See section 14.2.4, Management Key, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
pkey-violation	Number of subnet management packets that have been received on this port with invalid P_Keys since initial power up or the last reset. See section 9.2.7, partition key (P_KEY), <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.

Table 6-41 *show ib sm port Command Field Descriptions (continued)*

Field	Description
qkey-violation	Number of subnet management packets that have been received on this port with invalid Q_Keys since initial power up or the last reset. See section 10.2.4, Q Keys, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
guid-cap	Number of GUID entries allowed for this port in the port table. Any entries that exceed this value are ignored on write and read back as zero. See section 14.2.5.5, GUIDCap, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
subnet-timeout	Maximum propagation delay allowed for this port to reach any other port in the subnet. This value also affects the maximum rate at which traps can be sent from this port. Switch configuration affects delay. Requestors may use this parameter to determine the interval to wait for a response to a request. Duration matches $(4.096 \text{ ms} * 2^{\text{SubnetTimeout}})$.
resp-time	Maximum time allowed between the port reception of a subnet management packet and the transmission of the associated response. See section 13.4.6.2, Timers and Timeouts, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
local-phy-error	Threshold at which ICRC, VCRC, FCCRC, and all physical errors result in an entry into the BAD PACKET or BAD PACKET DISCARD states of the local packet receiver. See section 7.12.2, Error Recovery Procedures, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
local-overflow-error	Threshold at which the count of buffer overruns, across consecutive flow-control update periods, result in an overflow error. A possible cause of such errors is when an earlier packet has physical errors and the buffers are not immediately reclaimed.

Examples

The following example displays the details of the ports that the specified subnet manager manages:

```
SFS-7000P> show ib sm port subnet-prefix fe:80:00:00:00:00:00:00
```

```
=====
                        Subnet Management Ports
=====
subnet-prefix : fe:80:00:00:00:00:00:00
node-guid    : 00:02:c9:01:07:e4:41:d0
if-index     : 1
mkey         : 00:00:00:00:00:00:00:00
gid-prefix   : fe:80:00:00:00:00:00:00
lid          : 2
master-sm-lid : 1
cap-mask     : 00:10:02:48
diag-code    : 10:26
mkey-lease-period : 15
link-width-enabled : 3
link-width-supported : 3
link-width-active : 2
link-speed-supported : 1
```

```

state : active
phy-state : no state change
link-down-def-state : polling
mkey-prot-bits : 0
lmc : 0
link-speed-active : 1
link-speed-enabled : 1
neighbor-mtu : 2048
master-sm-SL : 0
VL-cap : vl0-vl7
VL-high-limit : 0
VL-arb-high-cap : 8
VL-arb-low-cap : 8
mtu-cap : 2048
VL-stall-count : 16
HOQ-life : 7
oper-VL : vl0-vl7
in-part-enforce : false
out-part-enforce : false
in-filter-raw-pkt-enf : false
out-filter-raw-pkt-enf : false
mkey-violation : 0
pkey-violation : 0
qkey-violation : 0
guid-cap : 32
subnet-timeout : 8
resp-time : 8
local-phy-error : 0
local-overflow-error : 0

```

The following example displays a summary of the ports that the specified subnet manager manages:

```
SFS-7000P> show ib sm port subnet-prefix fe:80:00:00:00:00:00:00:00 summary
```

```

=====
Subnet Manager Port Summary
=====
subnet-prefix      node-guid          if-index    lid    state
-----
fe:80:00:00:00:00:00:00 00:02:c9:01:07:e4:41:d0 1          2    active
fe:80:00:00:00:00:00:00 00:02:c9:01:07:e4:41:d0 2          3    active
fe:80:00:00:00:00:00:00 00:02:c9:01:07:e4:57:b0 1          6    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 0          1    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 1          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 2          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 3          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 4          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 5          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 6          0    down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 7          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:60 8          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 0          4    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 1          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 2          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 3          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 4          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 5          0    down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 6          0    down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 7          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:62 8          0    down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 0          5    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 1          0    active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 2          0    active

```

```
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 3      0      active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 4      0      active
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 5      0      down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 6      0      down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 7      0      down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:1c:64 8      0      down
fe:80:00:00:00:00:00:00 00:05:ad:00:00:01:29:8f 1      7      active
SFS-7000P>
```

Related Commands

ib sm
show ib sm configuration
show ib sm multicast
show ib sm neighbor
show ib sm partition
show ib sm port

show ib sm service

To display services available on your subnet, enter the **show ib sm service** command in User Exec mode or Privileged Exec mode.

```
show ib sm service [subnet-prefix prefix [p_key pkey | service-gid GID | service-id ID]]
[summary]
```

Syntax Description	subnet-prefix	(Optional) Specifies the subnet prefix of the subnet that you want to display.
	<i>prefix</i>	Subnet prefix of the subnet that you want to display.
	p_key	(Optional) Specifies a partition with the nodes run services that you want to view.
	<i>pkey</i>	(Optional) Partition that contains nodes that run services that you want to view.
	service-gid	(Optional) Specifies the Global identifier of the service (the GID of the node that provides the service).
	<i>GID</i>	(Optional) Global identifier of the service (node).
	service-id	(Optional) Specifies the ID of the service to display.
	<i>ID</i>	(Optional) ID of the service to display.
	summary	(Optional) Displays a summarized version of the command output.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

User Execute mode, Privileged Execute mode.

Privilege Level:
InfiniBand read-only user.

Services represent actions or functions that a node can perform across the network at the request of another node. Nodes register their services with the subnet manager so other nodes can discover and use these services. The Global identifier of a service matches the Global identifier of the host that provides the service.

Command Output:

Table 6-42 describes the fields in the **show ib sm service** command output.

Table 6-42 *show ib sm service Command Field Descriptions*

Field	Description
subnet-prefix	Subnet prefix of the service.
service-id	Service ID of the service.
GID	Global identifier of the service.
p_key	Partition key of the service.
lease	Specifies the lease service.
service-key	Specifies the service key.
service-name	Name of the service.
service-data	Header of the data types: 8, 16, 32, and 64.
data-8	Specifies data type 8.
data-16	Specifies data type 16.
data-32	Specifies data type 32.
data-64	Specifies data type 64.

Examples

The following example displays the services on the Server Switch:

```
SFS-120# show ib sm service subnet-prefix fe:80:00:00:00:00:00:00
```

```
=====
                        Summary of Services on Device
=====
subnet-prefix : fe:80:00:00:00:00:00:00
  service-id  : 10:00:0c:e1:00:41:54:53
      GID     : fe:80:00:00:00:00:00:00:02:c9:02:00:00:24:41
      p_key   : ff:ff
      lease   : indefinite
  service-key : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
  service-name : DAPL Address Translation Service
  service-data :
    data-8 : 00:00:00:00:00:00:00:00:00:00:00:00:c0:a8:01:02
    data-16 : 0000:0000:0000:0000:0000:0000:0000:0000:0000
    data-32 : 00000000:00000000:00000000:00000000
    data-64 : 0000000000000000:0000000000000000

subnet-prefix : fe:80:00:00:00:00:00:00
  service-id  : 10:00:0c:e1:00:41:54:53
      GID     : fe:80:00:00:00:00:00:00:00:02:c9:02:00:00:24:7d
      p_key   : ff:ff
      lease   : indefinite
  service-key : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
  service-name : DAPL Address Translation Service
  service-data :
    data-8 : 00:00:00:00:00:00:00:00:00:00:00:00:c0:a8:01:01
    data-16 : 0000:0000:0000:0000:0000:0000:0000:0000:0000
    data-32 : 00000000:00000000:00000000:00000000
    data-64 : 0000000000000000:0000000000000000
```

The following example displays a summary of the services on the Server Switch:

```
SFS-120# show ib sm service subnet-prefix fe:80:00:00:00:00:00 summary
```

```
=====
                        Summary of Services on Device
=====
subnet-prefix : fe:80:00:00:00:00:00
service-id    : 10:00:0c:e1:00:41:54:53
               GID : fe:80:00:00:00:00:00:00:00:02:c9:02:00:00:24:41
service-data  :
  data-8      : 00:00:00:00:00:00:00:00:00:00:00:00:c0:a8:01:02
  data-16     : 0000:0000:0000:0000:0000:0000:0000:0000
  data-32     : 00000000:00000000:00000000:00000000
  data-64     : 0000000000000000:0000000000000000

subnet-prefix : fe:80:00:00:00:00:00
service-id    : 10:00:0c:e1:00:41:54:53
               GID : fe:80:00:00:00:00:00:00:00:02:c9:02:00:00:24:7d
service-data  :
  data-8      : 00:00:00:00:00:00:00:00:00:00:00:00:c0:a8:01:01
  data-16     : 0000:0000:0000:0000:0000:0000:0000:0000
  data-32     : 00000000:00000000:00000000:00000000
  data-64     : 0000000000000000:0000000000000000
```

Related Commands

[ib sm](#)
[show ib sm configuration](#)
[show ib sm multicast](#)
[show ib sm neighbor](#)
[show ib sm partition](#)
[show ib sm port](#)

show ib sm subscription

To display event subscriptions or information records managed by your subnet manager on this device, enter the **show ib sm subscription** command in User Exec mode or Privileged Exec mode.

show ib sm subscription [**subnet-prefix** {*subnet-prefix*}] [**lid** *LID*] [**node-guid** *GUID*] [**port-num** *port-num*]] [**summary**]

Syntax Description		
subnet-prefix	(Optional)	Specifies the subnet prefix of the subnet managers that you want to display.
<i>subnet-prefix</i>	(Optional)	Subnet prefix of the subnet managers that you want to display.
lid	(Optional)	Specifies the LID of the service (the LID of the node that provides the service).
<i>LID</i>	(Optional)	LID of the service (node), for example: aa:aa:aa:aa:aa:aa:aa:aa
node-guid	(Optional)	Specifies the global identifier of the node (the GUID of the node that provides the service).
<i>GUID</i>	(Optional)	Global identifier of the service (node).
port-num	(Optional)	Specifies the port number
<i>port-num</i>	(Optional)	Port number.
summary	(Optional)	Displays a summarized version of the command output.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Subscriptions represent the local ID of a node, which matches the local ID of the host that provides the service. The global ID of a service matches the global ID of the host that provides the service.

Command Output:

[Table 6-43](#) describes the fields in the **show ib sm service** command output.

Table 6-43 *show ib sm subscription Command Field Descriptions*

Field	Description
LID	Local ID of the node.
node-guid	Global ID of the host.

Table 6-43 *show ib sm subscription Command Field Descriptions (continued)*

Field	Description
port-num	Port number.
LID range	Specifies the LID range.
is-generic	Specifies the is generic value.
trap-num-device-id	Name of the service.

Examples

The following example displays a summary of the event subscriptions managed on the Server Switch:

```

Topspin-120# show ib sm subscription subnet-prefix fe:80:00:00:00:00:00:00 summary
=====
Summary of Event Subscriptions Managed
=====
LID node-guid port-num LID-range is-generic trap-num-device-id
-----
985 00:05:ad:00:00:01:29:aa 1 65535-0 true 65
993 00:05:ad:00:00:01:29:ad 1 65535-0 true 65
Topspin-120# show ib sm subscription subnet-prefix fe:80:00:00:00:00:00:00 node-guid
00:05:ad:00:00:01:29:aa

=====
Summary of Event Subscriptions Managed
=====
subnet-prefix : fe:80:00:00:00:00:00:00
LID : 985
node-guid : 00:05:ad:00:00:01:29:aa
port-num : 1
source-QPN : 00:00:01
GID : 00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
LID-range-start : 65535
LID-range-end : 0
is-generic : true
trap-num-device-id : 65
producer-type-vendor-id : subnet-management
type : subnet-management
resp-time-value : 0

```

Related Commands

[ib sm](#)
[show ib sm configuration](#)
[show ib sm multicast](#)
[show ib sm neighbor](#)
[show ib sm partition](#)
[show ib sm port](#)

show ib sm switch

To display the attributes of all InfiniBand switches in your fabric (for debug purposes), enter the **show ib sm switch** command in User Exec mode or Privileged Exec mode.

show ib sm switch {**subnet-prefix** *prefix* | **all**} [**node-guid** *guid*][**summary**]

Syntax Description	subnet-prefix	Specifies the subnet prefix of the subnet managers that you want to view.
	<i>prefix</i>	Subnet prefix of the subnet managers that you want to view.
	all	Displays the attributes of all subnet managers that run on your InfiniBand fabric.
	node-guid	(Optional) Specifies the GUID of the switch that you want to view.
	<i>guid</i>	(Optional) GUID of the switch that you want to view.
	summary	(Optional) Displays a summarized version of the command output.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Switch information may be reported for all the switches on a specific subnet or all the switches comprising a specific node. The output may also be displayed in summary form.

Command Output:

[Table 6-44](#) describes the fields in the **show ib sm switch** command output.

Table 6-44 *show ib sm switch Command Field Descriptions*

Field	Description
subnet-prefix	64-bit value that identifies the InfiniBand subnet to which this node belongs.
node-guid	64-bit GUID of the node.
linear-fdb-cap	Maximum number of entries allowed in the linear unicast forwarding table. 0 (zero) indicates the absence of a linear forwarding database.
random-fdb-cap	Maximum number of entries allowed in the random unicast forwarding table. 0 (zero) indicates an absence of a random forwarding database.
mcast-fdb-cap	Maximum number of entries allowed in the multicast forwarding table.

Table 6-44 *show ib sm switch Command Field Descriptions (continued)*

Field	Description
linear-fdb-top	Specifies the top of the linear forwarding table. Packets that were received with unicast LIDs greater than this value are discarded by the switch. This parameter applies only to switches that implement linear forwarding tables. Switches that implement random forwarding tables ignore this parameter.
default-port	Specifies the default port to which to forward all the unicast packets from other ports when the destination location ID (DLID) does not exist in the random forwarding table.
default-pri-mcast-port	Specifies the default port to which to forward all the multicast packets from other ports when the DLID does not exist in the multicast forwarding table.
def-non-pri-mcast-port	Specifies the port to which to forward all the multicast packets from default-pri-mcast-port when the DLID does not exist in the multicast forwarding table.
life-time-value	Specifies the duration a packet can live in the switch. Time units are in milliseconds. See section 18.2.5.4, Transmitter Queueing, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
port-state-change	Indicates a change in port state. The value changes from NotInTransition to PortInTransition anytime the State parameter of a port changes from down to initialize, initialize to down, armed to down, or active to down, as a result of link state machine logic.
lid-per-port	Number of LID/LMC combinations that may be assigned to a given external port for switches that support the random forwarding table. This value is always 0. 0 indicates one LID per port.
partition-enf-cap	Number of entries in this partition enforcement table per physical port. 0 (zero) indicates that the Server Switch does not support partition enforcement.
in-enf-cap	Indicates if the switch can enforce partitions on received packets. The value appears as true or false.
out-enf-cap	Indicates if the Server Switch can enforce partitions on transmitted packets. The value appears as true or false.
in-filter-raw-pkt-cap	Indicates if the Server Switch can enforce raw packets on received packets. The value appears as true or false.
out-filter-raw-pkt-cap	Indicates if the switch enforces raw packets on transmitted packets. The value appears as true or false.

Examples

The following example displays attributes of the InfiniBand switch with a guid of 00:05:ad:00:00:00:13:81:

```
SFS-7000P# show ib sm switch subnet-prefix fe:80:00:00:00:00:00:00 node-guid
00:05:ad:00:00:00:13:81
=====
Subnet Management Switches
=====
subnet-prefix : fe:80:00:00:00:00:00:00
node-guid    : 00:05:ad:00:00:00:13:81
linear-fdb-cap : 49152
random-fdb-cap : 0
```

```

        mcast-fdb-cap : 1024
        linear-fdb-top : 1024
        default-port : 255
    def-pri-mcast-port : 255
    def-non-pri-mcast-port : 255
        life-time-value : 11
    port-state-change : port in transition
        lid-per-port : 0
    partition-enf-cap : 64
        in-enf-cap : false
        out-enf-cap : false
    in-filter-raw-pkt-cap : true
    out-filter-raw-pkt-cap : true
SFS-7000P#

```

The following example displays the switches of a subnet in summary form:

```

SFS-7000P# show ib sm switch subnet-prefix fe:80:00:00:00:00:00:00 summary
=====
                        Subnet Manager Switch Summary
=====
subnet-prefix          node-guid
-----
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:7f
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:81
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:83
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:85
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:87
fe:80:00:00:00:00:00:00 00:05:ad:00:00:00:13:89
SFS-7000P#

```

Related Commands

[ib sm](#)
[show ib sm configuration](#)
[show ib sm multicast](#)
[show ib sm neighbor](#)
[show ib sm partition](#)
[show ib sm port](#)

show ib sm switch-elem-route

This command displays all the external ports of all the server switches through which traffic enters and exits as it travels from the source LID to the destination LID. To display the subnet manager route switch element table, enter the **show ib sm switch-elem-route** command in User Exec mode or Privileged Exec mode.

```
show ib sm switch-elem-route subnet-prefix {prefix [src-lid srclid dst-lid dstlid] | all}
[summary]
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of the route.
<i>prefix</i>	Subnet prefix of the route.
src-lid	(Optional) Specifies the source LID of the route.
<i>srclid</i>	(Optional) Source LID of the route.
dst-lid	(Optional) Specifies the destination LID of the route.
<i>dstlid</i>	(Optional) Destination LID of the route.
all	(Optional) Specifies all routes in the subnet.
summary	(Optional) Displays fewer output fields.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:
[Table 6-45](#) describes the field of this command output.

Table 6-45 show ib sm switch-elem-route Command Output Field Descriptions

Field	Description
subnet-prefix	Subnet prefix of the route.
src-lid	Source LID of the route.
dst-lid	Destination LID of the route.
chassis-GUID	Chassis that runs the route.

Table 6-45 *show ib sm switch-elem-route Command Output Field Descriptions (continued)*

Field	Description
input-port	Input port of the route.
output-port	Output port of the route.

Examples

The following example displays the subnet manager route switch element table for one source and destination:

```
SFS-7000P# show ib sm switch-elem-route subnet-prefix fe:80:00:00:00:00:00:00 src-lid 858
dst-lid 857
```

```
=====
                        SM Switch Route Element
=====
subnet-prefix : fe:80:00:00:00:00:00:00
src-lid       : 858
dst-lid       : 857
chassis-GUID  : 00:05:ad:00:00:00:03:00
input-port    : 0/7
output-port   : 0/8
```

The following example displays a summary of the subnet manager route switch element table for one source and destination:

```
SFS-7000P# show ib sm switch-elem-route subnet-prefix fe:80:00:00:00:00:00:00 src-lid 889
dst-lid 9 summary
```

```
=====
                        SM Switch Route Elements Summary
=====
subnet-prefix : fe:80:00:00:00:00:00:00
src-lid       : 1
dst-lid       : 1
```

Related Commands [ib sm](#)

show ib sm switch-route

This command displays all the ports, both internal and external, of all the Server Switches through which traffic travels from a source LID to a destination LID. The complete path that traffic takes through the InfiniBand fabric from the source LID to the destination LID, enter the **show ib sm switch-route** command in User Exec mode or Privileged Exec mode.

```
show ib sm switch-route subnet-prefix {prefix [src-lid srclid dst-lid dstlid] | all}
[summary]
```

Syntax Description

subnet-prefix	Specifies the subnet prefix of the route.
<i>prefix</i>	Subnet prefix of the route.
src-lid	(Optional) Specifies the source LID of the route.
<i>srclid</i>	(Optional) Source LID of the route.
dst-lid	(Optional) Specifies the destination LID of the route.
<i>dstlid</i>	(Optional) Destination LID of the route.
all	Specifies all routes in the subnet.
summary	(Optional) Displays fewer output fields.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:
[Table 6-46](#) describes the fields in the command output.

Table 6-46 show ib sm switch-route Command Output Field Descriptions

Field	Description
subnet-prefix	Subnet prefix of the route.
src-lid	Source LID of the route.
dst-lid	Destination LID of the route.
node-GUID	Node that runs the route.

Table 6-46 *show ib sm switch-route Command Output Field Descriptions (continued)*

Field	Description
input-port	Input port of the route.
output-port	Output port of the route.

Examples

The following example displays all switch routes:

```
SFS-7000P# show ib sm switch-route subnet-prefix all
```

```
=====
                        SM Switch Route
=====
    subnet-prefix : fe:80:00:00:00:00:00:00
      src-lid : 2
      dst-lid : 2

    subnet-prefix : fe:80:00:00:00:00:00:00
      src-lid : 2
      dst-lid : 889

    subnet-prefix : fe:80:00:00:00:00:00:00
      src-lid : 889
      dst-lid : 2

      node-GUID : 00:05:ad:00:00:02:5a:95
      input-port : 5
      output-port : 0

    subnet-prefix : fe:80:00:00:00:00:00:00
      src-lid : 889
      dst-lid : 889
```

The following example displays the switch route for one source/destination LID pair:

```
SFS-7000P# show ib sm switch-route subnet-prefix fe:80:00:00:00:00:00:00 src-lid 858
dst-lid 857
```

```
=====
                        SM Switch Route
=====
    subnet-prefix : fe:80:00:00:00:00:00:00
      src-lid : 858
      dst-lid : 857
      node-GUID : 00:05:ad:00:00:00:03:00
      input-port : 7
      output-port : 8
```

Related Commands [ib sm](#)

show ib-agent channel-adapter

To view the attributes of InfiniBand agents for channel adapters (gateways and controllers) on your Server Switch, enter the show **ib-agent channel-adapter** command in Privileged Exec mode or User Exec mode.

show ib-agent channel-adapter node-info

Syntax Description

node-info	InfiniBand information for the channel adapter (CA).
------------------	--

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Each system channel adapter runs its own subnet-management agent.

Command Output:

[Table 6-47](#) describes the fields in the **show ib-agent channel-adapter** command output.

Table 6-47 *show ib-agent channel-adapter Command Field Descriptions*

Field	Description
guid	Globally unique identifier of the CA as an 8-byte string.
type	Type of device this SMA supports. The field always displays “adapter.”
lid	LID of the channel-adapter port.
base-version	Supported base management datagram version supported.
class-version	Supported subnet-management class.
port-guid	Globally unique identifier of the node port.
partition-cap	Number of entries in the partition table for channelAdapter, router, and switch management ports. This displays, at a minimum, 1 for all nodes including switches.
device-id	Device ID information, as assigned by the device manufacturer.
revision	Device revision, as assigned by the device manufacturer.
local-port-num	Number of the link port which received this request; otherwise, the field displays 0.
vendor-id	Device vendor, per the IEEE standard.

Table 6-47 *show ib-agent channel-adapter Command Field Descriptions (continued)*

Field	Description
trap-buffer	Special purpose string buffer for InfiniBand trap data.
num-ports	Number of physical ports on this node.
string	Node description string. Unicode characters are 16 bits.

Examples

The following example displays the attributes of the InfiniBand host with a GUID of 00:05:ad:00:00:00:13:17:

```
SFS-3012# show ib-agent channel-adapter 00:05:ad:00:00:00:13:17 node-info
=====
                        SMA Node Information
=====
                        guid : 00:05:ad:00:00:00:13:17
                        type : adapter
                        lid : 14
                        base-version : 1
                        class-version : 1
                        port-guid : 00:05:ad:00:00:00:13:18
                        partition-cap : 64
                        device-id : 5a:44
                        revision : 00:00:00:a0
                        local-port-num : 1
                        vendor-id : 00:05:ad
                        trap-buffer :
                        num-ports : 2
                        string : slot 7: /dev/ts_ua0

                        guid : 00:05:ad:00:00:00:13:17
                        type : adapter
                        lid : 0
                        base-version : 1
                        class-version : 1
                        port-guid : 00:05:ad:00:00:00:13:18
                        partition-cap : 64
                        device-id : 5a:44
                        revision : 00:00:00:a0
                        local-port-num : 1
                        vendor-id : 00:05:ad
                        trap-buffer :
                        num-ports : 2
                        string : slot 7: /dev/ts_ua0
```

Related Commands [ib-agent](#)

show ib-agent summary

To view the attributes of all InfiniBand agents on your Server Switch, enter the **show ib-agent summary** command in Privileged Exec mode or User Exec mode.

show ib-agent summary

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Subnet-management agent information may be displayed in a summary form. This summary helps you assign IP addresses to Ethernet interface gateways because the summary supplies much of the important information you need to configure gateways, such as GUID and LID values.

This command is also useful for gathering information about which GUIDs are present in which switch chassis. Also, use this command when working with output that is presented in terms of GUIDs, for example, output from the **show sm** commands. Having a list of GUIDs for each switch chassis in the network is necessary for locating a GUID.

Command Output:

[Table 6-48](#) describes the fields in the **show ib-agent summary** command output.

Table 6-48 *show ib-agent summary Command Field Descriptions*

Field	Description
slot	Chassis slot to which the HCA or switch connects.
type	Type of node being managed. The value appears as adapter, switch, router, or error. The error value indicates an unknown type.
state	Logical state of the port. The value appears as either “down” or “active.”
port	SMA-node port-number.
guid	Globally unique identifier of the InfiniBand node (switch or channel adapter).

Table 6-48 *show ib-agent summary Command Field Descriptions (continued)*

Field	Description
string	Node description string. Defaults to the chassis slot and internal device name used by the chassis OS to communicate with the device. This default can be overridden with the ib-agent configuration command
lid	LID, in decimal format, of this port.

Examples

The following example displays a summary of all the SMA nodes:

```
SFS-7000P# show ib-agent summary
=====
SMA Node Information Summary
=====
slot  type      state  port  guid                                string                                lid
-----
7      adapter    active 1    00:05:ad:00:00:00:13:17  slot 7: /dev/ts_ua0 14
7      adapter    down  2    00:05:ad:00:00:00:13:17  slot 7: /dev/ts_ua0  0
16     switch     active 0    00:05:ad:00:00:00:13:7f  slot 16: /dev/ts_ua0  2
16     switch     active 0    00:05:ad:00:00:00:13:81  slot 16: /dev/ts_ua1  4
16     switch     active 0    00:05:ad:00:00:00:13:83  slot 16: /dev/ts_ua2  6
16     switch     active 0    00:05:ad:00:00:00:13:85  slot 16: /dev/ts_ua3  8
16     switch     active 0    00:05:ad:00:00:00:13:87  slot 16: /dev/ts_ua4 10
16     switch     active 0    00:05:ad:00:00:00:13:89  slot 16: /dev/ts_ua5 12
1      adapter    down  1    00:05:ad:00:00:00:13:f3  slot 1: /dev/ts_ua0  0
1      adapter    active 2    00:05:ad:00:00:00:13:f3  slot 1: /dev/ts_ua0  1
4      adapter    active 1    00:05:ad:00:00:00:14:14  slot 4: /dev/ts_ua0 15
4      adapter    down  2    00:05:ad:00:00:00:14:14  slot 4: /dev/ts_ua0  0
SFS-7000P#
```

Related Commands

[ib sm](#)
[ib-agent](#)
[show ib sm configuration](#)
[show ib sm multicast](#)
[show ib sm neighbor](#)
[show ib sm partition](#)
[show ib sm port](#)

show ib-agent switch

To view the attributes of InfiniBand agents for switches on your Server Switch, enter the **show ib-agent switch** command in Privileged Exec mode or User Exec mode.

```
show ib-agent switch {guid | all} {linear-frd-info lid {lids | all} | mcast-info lid {lids | all}
| node-info | pkey-info | port-info | sl-vl-map | switch-info}
```

Syntax Description	<div> <div>guid</div> <div>GUID of the switch that you want to view.</div> </div>
all	<div> <ul style="list-style-type: none"> When the all keyword follows the show ib-agent switch command, it displays statistics for all switches in the chassis. When the all keyword follows the lid keyword, it displays the attributes of all applicable ports. </div>
linear-frd-info	Linear forwarding tables of specified switches.
lid	Local IDs of the ports that you want to view.
lids	LID, list of LIDs, or range of LIDs that you want to view.
mcast-info	Multicast forwarding tables of specified switches.
node-info	Attributes of specified switch nodes.
pkey-info	Partition key table of specified switch nodes.
port-info	Port attributes of specified switch nodes.
sl-vl-map	Service level (SL) to virtual lane (VL) mapping table for specified switch nodes.
switch-info	Displays InfiniBand attributes specific to InfiniBand switches.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
InfiniBand read-only user.

Command Output:

Table 6-49 describes the fields in the **linear-frd-info** keyword output.

Table 6-49 *linear-frd-info Keyword Output Field Descriptions*

Field	Description
switch-guid	GUID of the switch.
lid	LID of the port.
0 - 7	Represents ports 0 - 7 on an InfiniBand switch card.

Table 6-50 describes the fields in the **mcast-info** keyword output.

Table 6-50 *mcast-info Keyword Output Field Descriptions*

Field	Description
node-guid	GUID of the switch with the LID immediately following.
block-index	Determines which multicast LIDs and ports on the current switch chip are displayed in the following table. See the Multicast Forwarding Table section of the Subnet Management chapter of the InfiniBand specification for details.
lid	LIDs of the ports on the switch.
port-mask	Shows to which ports a multicast packet for the given LID will be transmitted.

Table 6-51 describes the fields in the **node-info** keyword output.

Table 6-51 *node-info Keyword Output Field Descriptions*

Field	Description
guid	GUID of the node.
type	Type of SMA node. This value always appears as “switch.”
lid	LID of the port that connects to the node.
base-version	Base management datagram version that the switch supports.
class-version	Subnet management class that the switch supports.
port-guid	GUID of the port that connects to the node.
partition-cap	Number of partitions that the node supports.
device-id	Manufacturer-assigned device ID.
revision	Manufacturer-assigned device revision.
local-port-num	Number of the link port that received this show request.
vendor-id	Device vendor ID, as per the IEEE standard.
trap-buffer	Number of traps that the node supports.
num-ports	Number of physical ports on the SMA node.
string	SMA node description string.

Table 6-52 describes the fields in the **port-info** keyword output.

Table 6-52 port-info Keyword Output Field Descriptions

Field	Description
node-guid	64-bit GUID of the SMA node to which this port belongs.
port	Number of the port on the SMA node.
mkey	64-bit management key for the port. For more information, see sections 14.2.4, “Management Key” and 3.5.3, “Keys” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
gid-prefix	64-bit global IDprefix for this port. The subnet manager assigns this prefix. For more information, see section 4.1.3, “Local Identifiers” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
lid	16-bit base LID of the port.
master-SML-id	16-bit base LID of the master subnet manager that manages this port.
capability-mask	<p>32-bit bitmask that specifies the supported capabilities of the port.</p> <p>A bit value of 1 (one) indicates a supported capability. The bits are as follows:</p> <ul style="list-style-type: none"> • 0, 11-15, 18, 21-31 (Reserved and always 0.), • 1 IsSM, • 2 IsNoticeSupported, • 3 IsTrapSupported, • 4 IsResetSupported, • 5 IsAutomaticMigrationSupported, • 6 IsSLMappingSupported, • 7 IsMKeyNVRAM (supports M_Key in NVRAM), • 8 IsPKeyNVRAM (supports P_Key in NVRAM), • 9 IsLEDInfoSupported, • 10 IsSMdisabled, • 16 IsConnectionManagementSupported, • 17 IsSNMPTunnelingSupported, • 19 IsDeviceManagementSupported, • 20 IsVendorClassSupported. <p>Values are expressed in hexadecimal.</p>
diag-code	16-bit diagnostic code. For more information, see section 14.2.5.6.1, “Interpretation of Diagcode” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
mkey-lease-period	Initial value of the lease-period timer, in seconds. The lease period indicates the length of time that the M_Key protection bits remain non-zero after a SubnSet (Portinfo) fails an M_Key check. After the lease period expires, clearing the M_Key protection bits allows any subnet manager to read (and then set) the M_Key. Set this field to 0 to indicate that the lease period never expires. For more information, see section 14.2.4, Management Key in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
local-port-num	Number of the link port that received this SNMP request.

Table 6-52 *port-info Keyword Output Field Descriptions (continued)*

Field	Description
link-width-enabled	Integer value that indicates the enabled link-width sets for this port. The value may be any of the following: <ul style="list-style-type: none"> • 0 (no state change) • 1 (1x) • 2 (4x) • 3 (1x or 4x) • 8 (12x) • 9 (1x or 12x) • 10 (4x or 12x) • 11 (1x, 4x, or 12x) • 255 (sets this parameter to the LinkWidthSupported value).
link-width-supported	Supported link width. Value may be any of the following: <ul style="list-style-type: none"> • 1x • 1x or 4x • 1x, 4x, or 12x
link-width active	Active width of the link. Value may be 1x, 4x, or 12x.
link-speed-supported	Supported link speed. This value always appears as 2.5 Gbps.
state	Displays the logical state of the port. If this parameter is anything other than “down,” it indicates that the port has successfully completed link negotiation and is physically communicating with another port in the subnet. The most common states are down, init, and active. Init means that the port has completed its physical negotiation, but the subnet manager has not yet brought it to the active state, so it cannot yet transmit or receive data traffic. Active means the port is fully operational. See the PortInfo section of the Subnet Management chapter of the InfiniBand specification for more information.
port-phys	Displays the physical state of the port. This parameter indicates the state of the low-level hardware link negotiation. The most common states are polling, disabled, and linkup. Polling means that the port is enabled but is not communicating with another port. Disabled means that the port is shut down and will not communicate with another port, even if connected. Linkup means that the port has complete link negotiations with another port and is physically ready to pass traffic. See the PortInfo section of the Subnet Management chapter of the InfiniBand specification for more information.
link-down-def	LinkDown state to return to. The value appears as noStateChange, sleeping, or polling. For more information, see section 5.5.2, “Status Outputs” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
mkey-protect-bits	Management key protection bits for the port. The bits are 0, 1, 2, and 3. For more information, see section 14.2.4.1, “Levels of Protection” of <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .

Table 6-52 *port-info Keyword Output Field Descriptions (continued)*

Field	Description
lmc	Local-identifier mask control (LMC) for multipath support. A LMC resides on each channel adapter and router port on the subnet. It provides multiple virtual ports within a single physical port. The value of the LMC specifies the number of path bits in the LID. A value of 0 allows one LID on the port. For more information, see sections 3.5.10, “Addressing” and 4.1.3, “Local Identifiers” in <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
ls-active	Speed of an active link. The field displays 2.5 Gbps.
ls-active-enabled	Maximum speed that the link can handle. The value can be 0 (no state change), 1 (2.5 Gbps), or 3 (value derived from LinkSpeedSupported).
neighbor-MTU	Active maximum transmission unit (MTU) enabled on this port for transmission. The subnet manager is responsible for checking the MTUCap on both ends of a link and setting the neighbor-MTU on both sides appropriately. The value appears as 256, 512, 1024, 2048, or 4096.
master-SMSL	Administrative service level required for this port to send a non-SMP message to the subnet manager.
VL-cap	Maximum range of data virtual lanes (VLs) supported by this port.
VL-high-limit	Maximum high-priority limit on the number of bytes allowed for transmitting high-priority packets when both ends of a link operate with multiple data virtual lanes. Used with the virtual-lane arbitration table. The maximum high-limit is determined by checking the v1-arbitration-high-cap on the other side of the link and then negotiating downward.
VL-arbitration-high-cap	Highest arbitration value allowed by the arbiter in determining the next packet in a set of packets to transmit across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. For more information, see section 14.2.5.9, “VL Arbitration Table” of <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
VL-arbitration-low-cap	Lowest arbitration value allowed by the arbiter in determining the next packet in a set of packets to transmit across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. For more information, see section 14.2.5.9, “VL Arbitration Table” of <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
MTU-cap	Determines, with neighbor-mtu, the maximum transmission size supported on this port. The lesser of MTUCap and NeighborMTU determines the actual MTU used. The value appears as 256, 512, 1024, 2048, or 4096.
VL-stall-count	Number of sequentially dropped packets at which the port enters a VLStalled state. For more information, see section 18.2.5.4, “Transmitter Queuing” in <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
HOQ-life	Maximum duration allowed to packets at the head of a virtual-lane queue. Used with VLStallCount to determine the outgoing packets to discard.
op-VLs	Administrative limit for the number of virtual lanes allowed to the link. Do not set this above the VLCap value.
pkey-enf-in	Boolean value that indicated whether or not to support optional partition enforcement for the packets that were received by this port.

Table 6-52 *port-info Keyword Output Field Descriptions (continued)*

Field	Description
pkey-enf-out	Boolean value that indicates whether or not to support optional partition enforcement for the packets transmitted by this port.
filter-raw-pkt-in	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets that were received by this port.
filter-raw-pkt-out	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets transmitted by this port.
mkey-violations	Number of subnet management packets (SMPs) that have been received on this port with invalid M_Keys since initial power-up or last reset. For more information see section 14.2.4, “Management Key” in <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
pkey-violations	Number of subnet management packets that have been received on this port with invalid P_Keys since initial power-up or the last reset. For more information, see section 9.2.7, “Partition Key” in <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1.
qkey-violations	Number of subnet management packets that have been received on this port with invalid Q_Keys since initial power up or the last reset. For more information, see <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, section 10.2.4, “Q Keys.”
guid-cap	Number of GUID entries allowed for this port in the port table. For more information, see <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, section 14.2.5.5, “GUIDCap.”
subnet-timeout	Maximum propagation delay allowed for this port to reach any other port in the subnet. This value also affects the maximum rate at which traps can be sent from this port.
resp-time-value	Maximum time allowed between the port reception of a subnet management packet and the transmission of the associated response. For more information, see <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, section 13.4.6.2, “Timers and Timeouts.”
local-phys-err	Threshold at which ICRC, VCRC, FCCRC, and all physical errors result in an entry into the BAD PACKET or BAD PACKET DISCARD states of the local packet receiver. For more information, see <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, section 7.12.2, “Error Recovery Procedures.”
overrun-err	Threshold at which the count of buffer overruns across consecutive flow-control update periods results in an overrun error.
sl-vl-map	Service lane to virtual lane map. Fields in this mapping as described in Table 6-53 .

Table 6-53 describes the fields in the **sl-vl-map** keyword output.

Table 6-53 *sl-vl-map Keyword Output Field Descriptions*

Field	Description
node-guid	GUID of the SMA node.
in-ib-port	The ingress port of an InfiniBand data packet.
out-ib-port	The egress port of an InfiniBand data packet.
SL to VL mapping	For each service lane, show the underlying virtual lane which will be used for a packet on the given ingress port, which will be routed out the given egress port.

Table 6-54 describes the switch info keyword output fields.

Table 6-54 *switch info Keyword Output Field Descriptions*

Field	Description
guid	GUID of the SMA node.
lft-cap	The current maximum used entry in the Linear Forwarding Table.
rft-cap	The maximum capacity of the switch Random Forwarding Table. (This capacity is generally unmet, since only one LFT or RFT is implemented on any given switch and all Cisco SFS 7000 switches use the LFT.)
mft-cap	The maximum capacity of the Multicast Forwarding Table.
lft-top	The current maximum used entry in the Linear Forwarding Table.
default-port	Port used if the Random Forwarding Table is implemented. This port is the one to which packets are sent when the LID is not specified in the Random Forwarding Table.
def-mcast-pri-port	Default Multicast Primary Port—port to which multicast packets are sent when the LID is not present in the Multicast Forwarding Table.
def-mcast-NP-port	Default Multicast Not Primary Port—Same as above, but for multicast packets arriving on the Default Multicast Primary Port.
life-time-value	Specifies the maximum time a packet can live in the switch. See the InfiniBand specification for the definition of this value.
port-state-change	Indicates that a port on the switch has changed its state. Used by the subnet manager to determine if it needs to look at the port states.
lids-per-port	Specifies the number of LID/LMC combinations that may be used per port if the Random Forwarding Table is implemented.
partition-enf-cap	The number of entries in the Partition Enforcement Table per port.
inbound-enf-cap	Indicates whether or not the switch is capable of partition enforcement on inbound (received) packets.
outbound-enf-cap	Indicates whether or not the switch is capable of partition enforcement on outbound (transmitted) packets.
filter-raw-pkt-in-cap	Indicates whether or not the switch is capable of raw packet enforcement on inbound (received) packets.
filter-raw-pkt-out-cap	Indicates whether or not the switch is capable of raw packet enforcement on outbound (transmitted) packets.

The following example displays the linear forwarding details of the InfiniBand switch:

```
SFS-7000P# show ib-agent switch 00:05:ad:00:00:00:13:7f linear-frd-info lid 2
=====
                        Linear Forwarding Information
=====
switch-guid : 00:05:ad:00:00:00:13:7f
lid         0         1         2         3         4         5         6         7
-----
0                               0
SFS-7000P#
```

The following example displays the multicast information of the InfiniBand switch:

```
SFS-7000P# show ib-agent switch 00:05:ad:00:00:00:13:7f mcast-info lid all
=====
                        Multicast Information
=====
node-guid   : 00:05:ad:00:00:00:13:7f
block-index : 0
lid         port-mask
49152      00:00
49153      00:00
49154      00:00
49155      00:00
49156      00:00
49157      00:00
49158      00:00
49159      00:00
49160      00:00
49161      00:00
49162      00:00
49163      00:00
49164      00:00
...
```

The following example displays attributes of the InfiniBand nodes that connect to the switch:

```
SFS-7000P# show ib-agent switch all node-info
=====
                        SMA Node Information
=====
                        guid : 00:05:ad:00:00:00:13:7f
                        type : switch
                        lid  : 2
                        base-version : 1
                        class-version : 1
                        port-guid : 00:05:ad:00:00:00:13:7f
                        partition-cap : 1
                        device-id  : a8:7c
                        revision   : 00:00:00:a0
                        local-port-num : 255
                        vendor-id  : 00:05:ad
                        trap-buffer :
                        num-ports  : 9
                        string     : slot 16: /dev/ts_ua0
```

The following example displays the port attributes of the switch:

```
SFS-7000P# show ib-agent switch 00:05:ad:00:00:00:13:7f port-info
=====
Port Information
=====
node-guid : 00:05:ad:00:00:00:13:7f
port : 0
mkey : 00:00:00:00:00:00:00:00
gid-prefix : 00:00:00:00:00:00:00:00
lid : 2
master-SML-id : 1
capability-mask : 00:00:02:08
diag-code : 00:00
mkey-lease-period : 00:00
local-port-num : 255
link-width-enabled : 1x, 4x
link-width-supported : 1x, 4x
link-width-active : 1x
link-speed-supported : 2.5 Gbps
state : active
port-phys : nop
link-down-def : polling
mkey-protect-bits : 0
LMC : 0
ls-active : 2.5 Gbps
ls-active-enabled : 2.5 Gbps
neighbor-MTU : 256
master-SMSL : 0
VL-cap : VL0 - VL7
VL-high-limit : 0
VL-arbitration-high-cap : 8
VL-arbitration-low-cap : 8
MTU-cap : 1024
VL-stall-count : 0
HOQ-life : 7
op-VLs : VL0 - VL7
pkey-enf-in : 0
pkey-enf-out : 0
filter-raw-pkt-in : 0
filter-raw-pkt-out : 0
mkey-violations : 0
pkey-violations : 0
qkey-violations : 0
guid-cap : 1
subnet-timeout : 31
resp-time-value : 8
local-phys-err : 4
overrun-err : 0
```


The following example displays the service level to virtual lane mapping table on the switch:

```
SFS-7000P# show ib-agent switch 00:05:ad:00:00:00:13:7f sl-vl-map
=====
                        SLVL-Map Table
=====
      node-guid : 00:05:ad:00:00:00:13:7f
      in-ib-port : 0
      out-ib-port : 0
      sl0toVl : 0
      sl1toVl : 0
      sl2toVl : 0
      sl3toVl : 0
      sl4toVl : 0
      sl5toVl : 0
      sl6toVl : 0
      sl7toVl : 0
      sl8toVl : 0
      sl9toVl : 0
      sl10toVl : 0
      sl11toVl : 0
      sl12toVl : 0
      sl13toVl : 0
      sl14toVl : 0
      sl15toVl : 0
      ...
```

The following example displays SMA switch information:

```
SFS-7000P# show ib-agent switch all switch-info
=====
                        SMA Switch Information
=====
      guid : 00:05:ad:00:00:00:02:40
      lft-cap : 49152
      rft-cap : 0
      mft-cap : 1024
      lft-top : 1024
      default-port : 255
      def-mcast-pri-port : 255
      def-mcast-NP-port : 255
      life-time-value : 11
      port-state-change : 0
      lids-per-port : 0
      partition-enf-cap : 64
      inbound-enf-cap : 1
      outbound-enf-cap : 1
      filter-raw-pkt-in-cap : 1
      filter-raw-pkt-out-cap : 1
```

Related Commands

ib sm
show ib sm configuration
show ib sm neighbor
show ib sm partition
show ib sm port

show interface ethernet

To display the attributes of Ethernet ports, enter the **show interface ethernet** command in User Exec mode or Privileged Exec mode.

```
show interface ethernet {port-selection | all} [ip {ip-address | all} ip-info | ip-backup
                        {backup-address | all} | statistics]
```

Syntax Description	port-selection	Port, list of port, or range of ports that you want to view.
	all	<ul style="list-style-type: none"> Displays the attributes of all the Ethernet ports on your Server Switch when you enter it after the show interface ethernet command. Displays details on all IP addresses when you enter it after the ip keyword. (Optional) Displays details on all backup IP addresses when you enter it after the ip-backup keyword.
	ip	(Optional) Displays IP address table of the ports that you specify.
	ip-address	(Optional) IP address with the details that you want to view.
	ip-info	(Optional) Displays statistical data of the transmissions that occur on IP addresses.
	ip-backup	(Optional) Displays statistical data of the transmissions that occur on the backup IP addresses.
	backup-address	(Optional) Backup IP address with the details that you want to view.
	statistics	(Optional) Displays Ethernet interface statistics for diagnostic purposes.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 3012

Privilege Level:
Ethernet read-only user.

Use this command to help diagnose Ethernet connectivity problems.

Command Output:

Table 6-55 describes the fields in the **show interface ethernet** command output.

Table 6-55 *show interface ethernet Command Field Descriptions*

Field	Description
port	Port number, in slot#/port# format.
name	Administratively-configured port name.
type	Type of port.
desc	Name that you assign with the name command.
last-change	Time of the most recent configuration change that a user made to the port.
mac-address	MAC address of the port.
mtu	Maximum transmission unit (MTU) of the port, in bytes.
auto-negotiate-supported	Displays “yes” if the port supports auto-negotiation.
auto-negotiate	Displays “enabled” if you have configured auto-negotiation to run on the port.
admin-status	Administrative status of the port.
oper-status	Operational status of the port.
admin-speed	Administrative speed that you configured on the port.
oper-speed	Operational (actual) speed at which the port runs. Actual speed differs from admin speed if the port on the other end of the connection cannot support the speed that you configured.
admin-duplex	Administrative duplex type (half or full) that you configured to run on the port.
oper-duplex	Operational (actual) duplex type at which the port runs. Actual duplex type differs from admin duplex type if the port on the other end of the connection cannot support the type that you specified.
link-trap	Displays “enabled” if you configured the port to send link traps with the link-trap command.
action	Action (such as flushing the ARP table) that you had the interface perform.
result	Status of the action that you had the interface perform.

Table 6-56 describes the fields in the **ip** keyword output.

Table 6-56 *ip Keyword Output Field Descriptions*

Field	Description
port	Port number, in card#port# format. A port# of 0 represents the gateway port of the interface card.
address	IP address that you assigned to the port.
mask	Subnet mask that you assigned to the port.
bcast-addr format	IP broadcast address format that the port uses.

Table 6-56 *ip Keyword Output Field Descriptions (continued)*

Field	Description
reasm max-size	Size of the largest IP datagram which this port can receive and reassemble from incoming fragmented IP datagrams.
type	Displays “primary” or “backup” to indicate that the interface card acts as the primary or backup interface for the IP address that appears in the address field.
status	Displays “active” or “inactive” to indicate that the card actively services IP packets addressed to the IP address in the address field or does not service packets to the specified address.

Table 6-57 describes the fields in the **ip-info** keyword output.

Table 6-57 *ip-info Keyword Output Field Descriptions*

Field	Description
port	Port number, in slot#/port# format.
default-ttl	Default time-to-live value, in seconds.
in-receives	Cumulative number of input datagrams (including errors) that interfaces received for the IP address that you specified with the ip keyword.
in-hdr-errors	Cumulative number of datagrams that interfaces discarded. Reasons to discard a datagram include the following: <ul style="list-style-type: none"> • bad checksums • version number mismatches • format errors • exceeded time-to-live values • IP option processing errors
in-addr-errors	Cumulative number of input datagrams that ports discarded because the IP address in the destination field of the header of the datagram was not a valid address to be received by the port.
forw-datagrams	Cumulative number of datagrams that arrived at the port en-route to a final destination. For non-IP-gateway ports, this value includes only packets that the port Source-Routed successfully.
in-unknown-protos	Cumulative number of datagrams that the port successfully received but discarded due to an unknown or unsupported protocol.
in-discards	Cumulative number of datagrams that the port discarded for a reason other than a problem with the datagram (for example, lack of buffer space).
in-delivers	Cumulative number of input datagrams that the port successfully delivered to IP user-protocols, including Internet Control-Message Protocol (ICMP).
out-requests	Cumulative number of IP datagrams that local IP user-protocols (including ICMP) supplied to IP in-requests. This counter does not include any datagrams counted as forw-datagrams.
out-discards	Cumulative number of output IP datagrams that the port discarded for a reason other than a problem with the datagram (for example, lack of buffer space).

Table 6-57 *ip-info Keyword Output Field Descriptions (continued)*

Field	Description
out-no-routes	Cumulative number of IP datagrams that the port discarded because a route could not be found to transmit them to their destination. This counter includes any packets counted in forw-datagrams that still qualify. This counter also includes any datagrams that a Server Switch cannot route because all of the gateways on the Server Switch are down.
frag-OKs	Cumulative number of IP datagrams that the port has successfully fragmented.
frag-fails	Cumulative number of IP datagrams that the port discarded because the port could not fragment them. (For instance, this situation occurs when the Don't Fragment flag of the datagram is set.)
frag-creates	Cumulative number of IP datagram fragments that the port has generated.

Table 6-58 describes the fields in the **ip-backup** keyword output.

Table 6-58 *ip-backup Keyword Output Field Descriptions*

Field	Description
if-index	Port number.
priority	Priority of the backup address that you applied with the ip command.

Table 6-58 describes the fields in the **statistics** keyword output.

Table 6-59 *statistics Keyword Output Field Descriptions*

Field	Description
port	Port identifier, in slot#/port# format.
name	Administrative port name that you configured with the name command. The parenthetical identifier represents the SNMP identifier.
in-octets	Cumulative number of octets that arrived at the port, including framing characters.
in-ucast-pkts	Cumulative number of incoming packets destined for a single port.
in-multicast-pkts	Cumulative number of incoming packets destined for the ports of a multicast group.
in-broadcast-pkts	Cumulative number of incoming packets destined for all ports on the fabric.
in-discards	Cumulative number of inbound packets that the port discarded for a reason other than a packet error (for example, lack of buffer space).
in-errors	Number of inbound packets with errors that the port discarded.

Table 6-59 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
in-unknown-protos	For packet-oriented interfaces, the number of packets that were received through the interface and were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing, the number of transmission units received through the interface that were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter is always 0.
out-octets	Total number of octets transmitted out of the interface, including framing characters.
out-ucast-pkts	Total number of packets that higher-level protocols requested be transmitted and that were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
out-multicast-pkts	Total number of packets that higher-level protocols requested be transmitted and that were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
out-broadcast-pkts	Total number of packets that higher-level protocols requested to be transmitted and that were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.
out-discards	Number of outbound packets that were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free-up buffer space.
our-errors	For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.
alignment-errors	A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are counted exclusively according to the error status presented to the LLC. This counter does not increment for 8-bit wide group encoding schemes.
fcs-errors	<p>A count of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check. This count does not include frames received with frame-too-long or frame-too-short error. The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are counted exclusively according to the error status presented to the LLC.</p> <p>Coding errors detected by the physical layer for speeds above 10 Mbps will cause the frame to fail the FCS check.</p>

Table 6-59 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
single-collision-frames	A count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision. A frame that is counted by an instance of this object is also counted by the corresponding instance of the out-ucast-pkts, out-multicast-pkts, or out-broadcast-pkts, and is not counted by the corresponding instance of the multiple-collision-frames object. This counter does not increment when the interface is operating in full-duplex mode.
multiple-collision-frames	A count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. A frame that is counted by an instance of this object is also counted by the corresponding instance of the out-ucast-pkts, out-multicast-pkts, or out-broadcast-pkts, and is not counted by the corresponding instance of the single-collision-frames object. This counter does not increment when the interface is operating in full-duplex mode.
sqe-test-errors	A count of times that the SQE TEST ERROR message is generated by the PLS sublayer for a particular interface. The SQE TEST ERROR is set in accordance with the rules for verification of the SQE detection mechanism in the PLS Carrier Sense Function, as described in IEEE Std. 802.3, 1998 Edition, section 7.2.4.6. This counter does not increment on interfaces operating at speeds greater than 10 Mbps or on interfaces operating in full-duplex mode.
deferred-transmissions	A count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. The count represented by an instance of this object does not include frames involved in collisions. This counter does not increment when the interface is operating in full-duplex mode.
late-collisions	The number of times that a collision is detected on a particular interface later than one Ethernet slot-time unit into the transmission of a packet. A late collision included in a count represented by an instance of this object is also considered as a generic collision for purposes of other collision-related statistics. This counter does not increment when the interface is operating in full-duplex mode.
excessive-collisions	A count of frames for which transmission on a particular interface fails due to excessive collisions. This counter does not increment when the interface is operating in full-duplex mode.
internal-mac-transmit-errors	A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of the late-collisions object, the excessive-collisions object, or the carrier-sense-errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that is not otherwise counted.

Table 6-59 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
carrier-sense-errors	Number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface. The count represented by an instance of this object is incremented at most once per transmission attempt, even if the carrier sense condition fluctuates during a transmission attempt. This counter does not increment when the interface is operating in full-duplex mode.
frame-too-longs	A count of frames received on a particular interface that exceed the maximum permitted frame size. The count represented by an instance of this object is incremented when the frame-too-longs status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are counted exclusively according to the error status presented to the LLC.
internal-mac-receive-errors	A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of the frame-too-longs, alignment-errors, or fcs-errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of receive errors on a particular interface that is not otherwise counted.

Examples

The following example shows the general information about a specific IP address on an Ethernet interface port:

```
SFS-7000P# show inter ether 4/1 ip 10.3.22.4
=====
                        IP Address Table
=====
port  address          mask                bcast-addr reasm    type    status
                        format      max-size
-----
4/1    10.3.22.4           255.255.255.0      1          0        primary active
SFS-7000P#
```

The following examples displays statistical data regarding the IP transactions of all the IP addresses on an interface port. Statistical data is comprised of transmission errors, requests, discards, packet fragments, and so on.

```
SFS-7000P# show inter ether 4/1 ip all ip-info
=====
                        IP Information
=====
port : 4/1
default-ttl : 0
in-receives : 0
in-hdr-errors : 0
in-addr-errors : 0
forw-datagrams : 0
in-unknown-protos : 0
in-discards : 0
in-delivers : 0
```



```
        out-requests : 0
        out-discards : 0
    out-no-routes : 0
        frag-OKs : 0
        frag-fails : 0
        frag-creates : 0
SFS-7000P#
```

The following example displays traffic statistics for port 4/1:

```
SFS-7000P# show interface ethernet 4/1 statistics
=====
                        Ethernet Interface Statistics
=====
                        port : 4/1
                        name : 4/1 (257)
                        in-octets : 0
                        in-ucast-pkts : 0
                        in-multicast-pkts : 0
                        in-broadcast-pkts : 0
                        in-discards : 0
                        in-errors : 0
                        in-unknown-protos : 0
                        out-octets : 0
                        out-ucast-pkts : 0
                        out-multicast-pkts : 0
                        out-broadcast-pkts : 0
                        out-discards : 0
                        out-errors : 0

                        alignment-errors : 0
                        fcs-errors : 0
                        single-collision-frames : 0
                        multiple-collision-frames : 0
                        sqe-test-errors : 0
                        deferred-transmissions : 0
                        late-collisions : 0
                        excessive-collisions : 0
                        internal-mac-transmit-errors : 0
                        carrier-sense-errors : 0
                        frame-too-longs : 0
                        internal-mac-receive-errors : 0
SFS-7000P#
```

Related Commands

[half-duplex](#)
[ip](#)
[trunk-group](#)

show interface fc

To display the attributes of Fibre Channel ports, enter the **show interface fc** command in User Exec mode or Privileged Exec mode.

show interface fc *{port-selection | all}* [**statistics** | **targets** | **virtual-ports**]

Syntax Description

<i>port-selection</i>	Port, list of ports, or range of ports to display.
all	Displays all Fibre Channel ports on your Server Switch.
statistics	(Optional) Displays traffic statistics for the ports that you specify.
targets	(Optional) Displays the targets that the portss that you specify can access.
virtual-ports	(Optional) Displays the virtual ports that the FC gateway mapped to the ports that you specify.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Fibre Channel read-only user.

The administrative (admin) status, speed, and connection-type reflect the values you had assigned. The operational (oper) status, speed, and connection-type reflect the values derived from the physical hardware and its connections. This situation allows you to verify your configuration settings against the actual hardware. The admin/oper pairs do not have to match for you to use the card. However, if there is a mismatch, the operational value is used.

Command Output:

[Table 6-60](#) describes the fields in the **show interface fc** command output.

Table 6-60 *show interface fc Command Field Descriptions*

Field	Description
port	Fibre Channel gateway port number, in slot#/port# format.
name	Administrative port name that you configure with the name command.
type	Identifies the type of the port. All type identifiers begin with “fc” for Fibre Channel ports.

Table 6-60 *show interface fc Command Field Descriptions (continued)*

Field	Description
desc	Text description of the interface port. The default is the port identifier in the form slot#/port#. The parenthetical number to the right of the description is the SNMP identifier. The SNMP identifier is useful if you are running your own SNMP software.
last-change	Time of the most recent configuration change that a user made to the port.
fc-address	Fibre Channel Protocol address of the port.
wwnn	World-wide node name of the port. The WWNN defaults to 00:00:00:00:00:00:00:00.
wwpn	World-wide port name of the port. The WWPN defaults to 00:00:00:00:00:00:00:00.
mtu	Maximum Transmission Unit (MTU) of the port. The MTU value defaults to 2080 bytes.
auto-negotiate-supported	Displays yes if the port supports auto-negotiation or no if the port does not support auto-negotiation.
auto-negotiate	Indicates if the Fibre Channel port on the interface card is configured to automatically negotiate connection parameters when it connects with a Fibre Channel device. If auto-negotiation is enabled, the connection speed and mode (duplex, half-duplex) are determined at the time of connection. If the device does not support auto-negotiation, this field still displays a value, but the value does not apply. The value is enabled or disabled . The default is disabled. This field is set by the auto-negotiate command.
admin-status	Indicates if you have enabled the port for configuration and use. The value of this field may be up or "down." The default is "down." The field is set by the shutdown command.
oper-status	Indicates if the port is physically ready for configuration and use. The value of this field may be up or "down." If this field is down but the admin-status is up, check that the Fibre Channel interface card is securely seated in the slot and a cable is attached between the port and the target FC device.
admin-speed	Indicates the speed administratively assigned to the Fibre Channel port. The value of this field may be 2 Gbps or 1 Gbps. Speed defaults to 2 Gbps. You can configure this setting with the speed command.
oper-speed	Indicates the maximum speed of the Fibre Channel port, based upon the attached Fibre Channel cable and polling the connected Fibre Channel device.
admin-connection-type	Indicates the type of connection administratively assigned to the interface port. The value may be forceNLPort for the fc2port2G, force-e, force-f, auto-e, or auto-f for the fc4port2G, forceBPort, or none. The default is forceNLPort. This field is set by the type command.

Table 6-60 *show interface fc Command Field Descriptions (continued)*

Field	Description
oper-connection-type	Indicates the type of connection dynamically discovered for the interface port.
link-trap	Indicates if connection link errors are to be captured and sent to trap recipients. The value may be either enabled or disabled. This field is set by the link-trap command.

Table 6-61 describes the fields in the **statistics** keyword output.

Table 6-61 *statistics Keyword Output Field Descriptions*

Field	Description
port	Fibre Channel gateway port number, in slot#/port# format.
name	Administratively assigned or default name of the port. The default name is the port name in the form slot#/port#. Configure this field with the name command. The number in parentheses to the right of the name is the SNMP identifier. The SNMP identifier is useful if you are running your own SNMP software.
in-octets	Cumulative number of octets received on the interface, including framing characters.
in-ucast-pkts	Cumulative number of packets, delivered by this sub-layer to a higher layer, that were not addressed to a multicast or broadcast address at this sub-layer.
in-multicast-pkts	Cumulative number of packets, delivered by this sub-layer to a higher layer, that were addressed to a multicast address at this sub-layer. For a MAC layer protocol, this includes both Group and Functional addresses.
in-broadcast-pkts	Cumulative number of packets, delivered by this sub-layer to a higher layer, that were addressed to a broadcast address at this sub-layer.
in-discards	Cumulative number of inbound packets that were discarded even though no errors had been detected to prevent their being delivered to a higher-layer protocol. One possible reason for discarding such a packet can be to free-up buffer space.
in-errors	For packet-oriented interfaces, the cumulative number of inbound packets that contained errors that prevented them from being delivered to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being delivered to a higher-layer protocol.
in-unknown-protos	For packet-oriented interfaces, the cumulative number of packets that were received through the interface that were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing, the number of transmission units received through the interface that were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter is always 0.

Table 6-61 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
out-octets	Cumulative number of octets transmitted out of the interface, including framing characters.
out-ucast-pkts	Cumulative number of packets that higher-level protocols requested be transmitted and that were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
out-multicast-pkts	Cumulative number of packets that higher-level protocols requested be transmitted and that were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
out-broadcast-pkts	Cumulative number of packets that higher-level protocols requested to be transmitted and that were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.
out-discards	Cumulative number of outbound packets that were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free-up buffer space.
out-errors	For packet-oriented interfaces, the cumulative number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.
link-events	Cumulative number of link events processed by the Fibre Channel interface port.
fcp-cmds-outstanding	Cumulative number of FCP commands outstanding on the Fibre Channel interface port.
fcp-cmds-completed	Cumulative number of FCP commands completed on the Fibre Channel interface port.
fcp-errors	Cumulative number of FCP errors encountered on the Fibre Channel interface port.
fc-initiator-IO	Cumulative number of transactions between the Fibre Channel initiator and this port.

Table 6-62 describes the fields in the **targets** keyword output.

Table 6-62 *targets Keyword Output Field Descriptions*

Field	Description
wwpn	World-wide port name (WWPN) of the target.
wwnn	World-wide node name (WWNN) of the target.
description	Dynamically-assigned or administratively-assigned description of the target. Enter the fc srp target command with the description keyword to configure this field.
ioc-guid	I/O controller (IOC) GUID of the FC gateway that accesses the target.
service-name	Name of the service that the target runs.

Table 6-62 *targets Keyword Output Field Descriptions (continued)*

Field	Description
protocol-ids	Lists the protocols that the target supports.
fc-address	Fibre Channel protocol address of the target.
mtu	Maximum transmission unit (MTU) of the target, in bytes.
connection-type	For this release, all targets connect to NL_Ports.
physical-access	Port, in slot#/port# format, on your Server Switch to which the target connects.

Table 6-63 describes the fields in the **virtual-ports** keyword output.

Table 6-63 *virtual-ports Keyword Output Field Descriptions*

Field	Description
guid	GUID of the physical initiator.
extension	GUID extension of the physical initiator.
initiator-description	Administratively-assigned description of the initiator.
wwnn	World-wide node name (WWNN) of the initiator.
port	Physical port on your Server Switch to which the virtual port maps.
wwpn	World-wide port name (WWPN) of the virtual port.
fc-address	Fibre Channel protocol address of the virtual port.

Examples

The following example shows the output of the **show interface fc** command without the **statistics** keyword:

```
SFS-7000P# show interface fc 5/1
=====
Fibre Channel Interface Info
=====
      port : 5/1
      name : 5/1
      type : fc2GFX
      desc : 5/1 (321)
last-change : none
  fc-address : 00:00:00
      wwnn : 00:00:00:00:00:00:00:00
      wwpn : 00:00:00:00:00:00:00:00
      mtu : 2080
auto-negotiate-supported : yes
  auto-negotiate : enabled
  admin-status : up
  oper-status : down
  admin-speed : 2gbps
  oper-speed : unknown
  oper-duplex : unknown
admin-connection-type : force-NL
  oper-connection-type : down
      link-trap : enabled
```

The following example displays all FC targets that the FC interfaces encounter:

```
SFS-7000P# show interface fc all targets
=====
                        Fc Targets
=====
                        wwpn: 50:06:01:60:10:20:4e:31
                        wwnn: 50:06:01:60:90:20:4e:31
                        description: SRP.T10:5006016010204E31
                        ioc-guid: 00:05:ad:00:00:01:38:80
                        service-name: SRP.T10:5006016010204E31
                        protocol-ids: 04:00:00:00:00:00:00:00:00
                        fc-address: 61:07:13
                        mtu: 0
                        connection-type: nl-port
                        physical-access: 9/2

                        wwpn: 50:06:01:68:10:20:4e:31
                        wwnn: 50:06:01:60:90:20:4e:31
                        description: SRP.T10:5006016810204E31
                        ioc-guid: 00:05:ad:00:00:01:38:80
                        service-name: SRP.T10:5006016810204E31
                        protocol-ids: 04:00:00:00:00:00:00:00:00
<output truncated>
```

The following example displays all virtual ports on the interface:

```
SFS-7000P# show interface fc all virtual-ports
=====
                        Fc Virtual Ports
=====
                        guid: 00:05:ad:00:00:12:34:56
                        extension: 00:00:00:00:00:00:00:00
                        initiator-description: kauai
                        wwnn: 20:01:00:05:ad:01:5a:5c
                        port: 9/1
                        wwpn: 20:01:00:05:ad:91:5a:5c
                        fc-address: 61:0a:02

                        guid: 00:05:ad:00:00:12:34:56
                        extension: 00:00:00:00:00:00:00:00
                        initiator-description: kauai
                        wwnn: 20:01:00:05:ad:01:5a:5c
                        port: 9/2
                        wwpn: 20:01:00:05:ad:95:5a:5c
                        fc-address: 61:05:02
```

Related Commands

[fc srp-global gateway-portmask-policy restricted](#)
[fc srp-global itl](#)
[fc srp it](#)
[fc srp target](#)
[show fc srp initiator](#)
[show interface fc](#)
[type](#)

show interface gateway

To display attributes of the internal InfiniBand gateway ports of Fibre Channel and Ethernet expansion modules, enter the **show interface gateway** command in User Exec mode or Privileged Exec mode.

```
show interface gateway slot-selection [fc srp initiator-target guid extension | {ip |
ip-backup} {ip-address | all} | sma {node-info | port-info [details]}| statistics]
```

Syntax Description

<i>slot-selection</i>	Internal gateway port that you want to view.
fc srp initiator-target	(Optional) Displays FC targets that an initiator can access.
<i>guid</i>	(Optional) GUID of the initiator.
<i>extension</i>	(Optional) GUID extension of the initiator.
ip	(Optional) Displays attributes of IP addresses on the card.
ip-backup	Displays attributes of backup IP addresses on the card.
ip-address	Individual IP address with the attributes that you want to view.
all	Displays attributes of all addresses.
sma	Displays SMA information.
node-info	Displays SMA node information
port-info	Displays SMA port information.
details	(Optional) Displays detailed SMA port information.
statistics	(Optional) Displays gateway statistics of the card.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3012, Cisco SFS 3001

Privilege Level:
Fibre Channel read-only user.

Use this command to troubleshoot connectivity issues. Verify that the show output matches the configuration file.

Command Output:

Table 6-64 describes the fields in the **show interface gateway** command output.

Table 6-64 *show interface gateway Command Field Descriptions*

Field	Description
gateway	Number of the slot in which the gateway resides.
name	Administrative name that you configure with the name command.
type	Type of interface card, either Ethernet or Fibre Channel.
desc	Description of the port, in slot#/port# format. The port identifier appears as zero (0) to indicate an internal port. The number in parentheses serves as the SNMP identifier.
last-change	Time of the most recent configuration change that a user made to the port.
mtu	Maximum transmission unit (MTU) of the internal gateway port.
admin-status	Administrative status of the gateway that you configure with the shutdown command.
oper-status	Actual status of the gateway.

Table 6-65 describes the fields that appear when you use the **fc srp initiator-target** argument with the **show interface gateway** command.

Table 6-65 *fc srp initiator-target Keyword Output Field Descriptions*

Field	Description
wwpn	World-wide port name (WWPN) of the target that the initiator can access.
wwnn	World-wide node name (WWNN) of the target that the initiator can access.
description	Description of the target.
ioc-guid	GUID of the IOC assigned to the target.
service-name	Service that the target runs.
protocol-ids	Lists the protocols that the target supports.
fc-address	Fibre Channel protocol address of the target.
mtu	Maximum transmission unit (MTU) of the target.
connection-type	Type of connection between the storage and the InfiniBand host. The field will always display nl-port , because all storage-to-IB host connections occur over a virtual port, or NL_Port.
physical-access	Port or ports through which the target connects to the initiator.

Table 6-66 describes the fields that appear when you use the **ip** keyword with the **show interface gateway** command.

Table 6-66 *ip Keyword Output Field Descriptions*

Field	Description
port	Port number, in card#port# format. A port# of 0 represents the gateway port of the interface card.
address	IP address that you assigned to the port.
mask	Subnet mask that you assigned to the port.
bcast-addr format	IP broadcast address format that the port uses.
reasm max-size	Size of the largest IP datagram that this port can receive and reassemble from incoming fragmented IP datagrams.
type	Displays “primary” or “backup” to indicate that the interface card acts as the primary or backup interface for the IP address that appears in the “address” field.
status	Displays “active” or “inactive” to indicate that the card actively services IP packets addressed to the IP address in the “address” field or does not service packets to the specified address.

Command Output:

Table 6-67 describes the fields that appear when you use the **ip-backup** keyword with the **show interface gateway** command.

Table 6-67 *ip-backup Keyword Output Field Descriptions*

Field	Description
if-index	Numeric identifier, or “interface index,” of the port, in slot#/port# notation.
priority	Displays the priority of each backup address.



Note

This keyword applies to Fibre Channel cards only.

Table 6-68 *statistics Keyword Output Field Descriptions*

Field	Description
slot-id	Chassis slot that contains the gateway that you want to display.
link-events	Cumulative number of link events that the gateway has processed.
srp-cmds-outstanding	Cumulative number of unresolved SRP commands on the gateway.
srp-cmds-completed	Cumulative number of SRP commands that the gateway executed.
srp-errors	Cumulative number of SRP errors that the gateway encountered.
srp-initiated-ios	Cumulative number of I/O transactions that initiators requested of FC devices through the gateway.
srp-bytes-read	Cumulative number of I/O bytes that the gateway has read.
srp-bytes-written	Cumulative number of I/O bytes that the gateway has written.

Table 6-68 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
srp-connections	Cumulative number of I/O connections that the gateway has used.
fcp-cmds-outstanding	Cumulative number of unresolved FCP commands on the gateway.
fcp-cmds-completed	Cumulative number of FCP commands that the gateway executed.
fcp-errors	Cumulative number of FCP errors that the gateway encountered.
fcp-initiated-ios	Cumulative number of I/O replies that FC devices sent through the gateway in response to SRP requests from initiators.
fcp-bytes-read	Cumulative number of Fibre Channel Protocol bytes that the card has read since it came up.
fcp-bytes-written	Cumulative number of Fibre Channel Protocol bytes that the card has written since it came up.

Examples

The following example displays the attributes of the IP address of the gateway port:

```
SFS-7000P# show interface gateway 5 ip all
=====
                        IP Address Table
=====
port  address          mask          bcast-addr reasm    type    status
      format          max-size
-----
4/0   10.3.22.0         255.255.255.0  1          0        primary active
SFS-7000P#
```

The following example uses the **show interface gateway** command to display general gateway properties. The information fields displayed depend upon the interface type. The example below displays the properties of a Fibre Channel gateway port. To see the properties of an Ethernet port, see the description of [“show interface ethernet”](#) section on page 6-148.

```
SFS-7000P# show interface gateway 4
=====
                        Gateway Information
=====
gateway : 4
name    : 4/0
type    : fc-gateway
desc    : 4/0 (320)
last-change : none
mtu     : 0
admin-status : up
oper-status : up
SFS-7000P#
```

The following example displays traffic statistics for the internal gateway port:

```
SFS-7000P# show inter gateway 2 stat
=====
Gateway Statistics
=====
slot-id: 2
link-events: 0
srp-cmds-outstanding: 0
srp-cmds-completed: 0
srp-errors: 0
srp-initiated-ios: 0
srp-bytes-read: 0
srp-bytes-written: 0
srp-connections: 0
fcp-cmds-outstanding: 0
fcp-cmds-completed: 0
fcp-errors: 0
fcp-initiated-ios: 0
fcp-bytes-read: 0
fcp-bytes-written: 0
SFS-7000P#
```

Related Commands

[fc srp initiator](#)
[fc srp it](#)
[show ip](#)

show interface ib

To display attributes of InfiniBand ports, enter the **show interface ib** command in User Exec mode or Privileged Exec mode.

show interface ib *port-selection* [**sma** {**node-info** | **port-info** [**detail**]} | **statistics**]

Syntax Description

<i>port-selection</i>	Port, list of ports, or range of ports that you want to view.
sma	(Optional) Displays subnet management agent (SMA) information.
node-info	(Optional) Displays node-based SMA information.
port-info	(Optional) Displays port-based SMA information.
detail	(Optional) Displays detailed, port-based SMA information.
statistics	(Optional) Displays InfiniBand interface traffic statistics.

Defaults

See [Table 6-69](#) through [Table 6-73](#).

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

InfiniBand read-only user.

Without the optional **sma** or **statistics** keywords, the **show interface ib** command displays general information about the InfiniBand interface port, such as its administrative status, its operational speed and status, and duplex mode.

Command Output:

[Table 6-69](#) describes the fields in the **show interface ib** command output.

Table 6-69 *show interface ib Command Field Descriptions*

Field	Description
port	Identifies the InfiniBand interface card and port. The format is slot#/port#.
name	User assigned name. If no name is assigned, the port name is displayed instead. This field is set by the name command.

Table 6-69 *show interface ib Command Field Descriptions (continued)*

Field	Description
type	Identifies the type of the InfiniBand card. Supported cards are ib1xTX, ib1xFX, ib4xTX, ib4xFX, and ib4xTXP. This field is set by the type command.
desc	Description of the port, in slot#/port# format. The number in parentheses serves as the SNMP identifier.
last-change	Time at which the InfiniBand port configuration was last changed.
mtu	Maximum Transmission Unit for the InfiniBand port. Used to configure the MTU size of IP network traffic.
auto-negotiate supported (select Server Switches)	Displays "yes" if the port supports auto-negotiation or "no" if the port does not support auto-negotiation.
auto-negotiate (select Server Switches)	Indicates if the InfiniBand port on the interface card is configured to automatically negotiate connection parameters when it connects with an InfiniBand device. If auto-negotiation is enabled, the connection speed is determined at the time of connection. If the device does not support auto-negotiation, this field still displays a value, but the value does not apply. The value is enabled or disabled . The default is disabled. This field is set by the auto-negotiate command.
admin-status	Indicates if you have enabled the port for configuration and use. The value of this field may be up or "down." The default is "down." The field is set by the shutdown command.
oper-status	Indicates if the port is physically ready for configuration and use. The value of this field may be up or "down." If this field is down but the admin-status is up, check that the InfiniBand interface card is securely seated in the slot and a cable is attached between the port and the target InfiniBand host.
admin-speed (select Server Switches)	Indicates the speed administratively assigned to the InfiniBand port. You can configure this setting with the speed command.
oper-speed (select Server Switches)	Indicates the maximum speed of the InfiniBand port, based upon the attached InfiniBand cable and polling the connected InfiniBand device.

Table 6-69 *show interface ib Command Field Descriptions (continued)*

Field	Description
link-trap	Indicates if connection link errors are to be captured and sent to trap recipients. The value may be either enabled or disabled. This field is set by the link-trap command.
dongle-type	Displays the port power connector dongle type variable.

The administrative (admin) status, speed, and connection-type reflect the values you had assigned. The operational (oper) status, speed, and connection-type reflect the values derived from the physical hardware and its connections. This allows you to verify your configuration settings against the actual hardware. The admin/oper pairs do not have to match for you to use the card. However, if there is a mismatch, the oper value is used.

[Table 6-70](#) describes the fields that appear when you use the **sma node-info** argument with the **show interface ib** command.

Table 6-70 *sma node-info Keyword Output Field Descriptions*

Field	Description
guid	GUID of the host.
type	Type of SMA node. This value always appears as switch.
lid	Base Local Identifier (LID) of the port.
base-version	Base management datagram version that the switch supports.
class-version	Subnet management class that the switch supports.
port-guid	GUID of the ports that you specified with the <i>port-selection</i> variable.
partition-cap	Maximum number of partitions that the port supports.
device-id	Manufacturer-assigned device ID.
revision	Manufacturer-assigned device revision.
local-port-num	Number of the link port that received this show request.
vendor-id	Device vendor ID, as per the IEEE standard.
trap-buffer	Special purpose string buffer for InfiniBand Trap Data.
num-ports	Number of physical ports on the SMA node.
string	SMA node description string.

[Table 6-71](#) describes the fields that appear when you use the **sma port-info** argument with the **show interface ib** command.

Table 6-71 *sma port-info Keyword Output Field Descriptions*

Field	Description
node-guid	GUID of the InfiniBand host that connects to the port.
port	Host port that connects to your Server Switch.

Table 6-71 *sma port-info Keyword Output Field Descriptions*

Field	Description
mkey	64-bit management key for this port. See section 14.2.4, Management Key and 3.5.3, Keys, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
gid-prefix	64-bit global ID prefix for this port. This prefix is assigned by the subnet manager, based upon the port router and the rules for local identifiers. See section 4.1.3, Local Identifiers, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
lid	16-bit base-LID of this port.
capability-mask	32-bit bitmask that specifies the supported capabilities of the port. A bit value of 1 (one) indicates a supported capability. The bits are 0, 11-15, 18, 21-31 (Reserved and always 0.), 1 IsSM, 2 IsNoticeSupported, 3 IsTrapSupported, 4 IsResetSupported, 5 IsAutomaticMigrationSupported, 6 IsSLMappingSupported, 7 IsMKeyNVRAM (supports M_Key in NVRAM), 8 IsPKeyNVRAM (supports P_Key in NVRAM), 9 Is LED Info Supported, 10 IsSMdisabled, 16 IsConnectionManagementSupported, 17 IsSNMPTunnelingSupported, 19 IsDeviceManagementSupported, 20 IsVendorClassSupported. Values are expressed in hexadecimal.
state	A higher form of addressing than PhyState, state determines that the nodes can actually communicate and indicates the state transition that has occurred. A transition is a port change from down to "initialize", "initialize" to "down," "armed" to "down," or active to down as a result of link state machine logic. Changes to the port state resulting from SubnSet have no affect on this parameter value. The value is noStateChange, down, initialize, armed, or active.

Table 6-72 describes the fields that appear when you use the **sma port-info details** argument with the **show interface ib** command.

Table 6-72 *sma port-info details Keyword Output Field Descriptions*

Field	Description
node-guid	GUID of the InfiniBand host that connects to the port.
port	Host port that connects to your Server Switch.
mkey	64-bit management key for this port. See section 14.2.4, Management Key and 3.5.3, Keys, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
gid-prefix	64-bit global ID prefix for this port. This prefix is assigned by the subnet manager, based upon the port router and the rules for local identifiers. See section 4.1.3, Local Identifiers, <i>InfiniBand Architecture®</i> , Vol. 1, Release 1.1, for more information.
lid	16-bit base-LID of this port.
master-sm-lid	16-bit base LID of the master subnet manager managing this port.

Table 6-72 *sma port-info details Keyword Output Field Descriptions (continued)*

Field	Description
capability-mask	32-bit bitmask that specifies the supported capabilities of the port. A bit value of 1 (one) indicates a supported capability. The bits are 0, 11-15, 18, 21-31 (Reserved and always 0.), 1 IsSM, 2 IsNoticeSupported, 3 IsTrapSupported, 4 IsResetSupported, 5 IsAutomaticMigrationSupported, 6 IsSLMappingSupported, 7 IsMKeyNVRAM (supports M_Key in NVRAM), 8 IsPKeyNVRAM (supports P_Key in NVRAM), 9 Is LED Info Supported, 10 IsSMdisabled, 16 IsConnectionManagementSupported, 17 IsSNMPTunnelingSupported, 19 IsDeviceManagementSupported, 20 IsVendorClassSupported. Values are expressed in hexadecimal.
diag-code	16-bit diagnostic code. For more information, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 14.2.5.6.1, “Interpretation of Diagcode.”
mkey-lease-period	Initial value of the lease-period timer in seconds. The lease period is the length of time that the M_Key protection bits are to remain non-zero after a SubnSet (PortInfo) fails an M_Key check. After the lease period expires, clearing the M_Key protection bits allows any subnet manager to read (and then set) the M_Key. Set this field to 0 to indicate that the lease period is never to expire. See <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 14.2.4, “Management Key.”
local-port-num	Number of the link port that received this request; otherwise, the value is 0.
link-width-enabled	Enabled link width (speed). The value is an integer that indicates the enabled link-width sets for this port. The value may be <ul style="list-style-type: none"> • 0 (no state change) • 1 (1x) • 2 (4x) • 3 (1x or 4x) • 8 (12x) • 9 (1x or 12x) • 10 (4x or 12x) • 11 (1x, 4x or 12x) • 255 (set this parameter to the link-width-supported value)
link-width-supported	Supported link width. The value is 1 (1x), 3 (1x or 4x), or 11 (1x, 4x, or 12x).
link-width-active	Active link width. This parameter is used with LinkSpeedActive to determine the link rate between the two connected nodes. The value is width1x, width4x, or width12x.
link-speed-supported	Speed that the link between the host and your device supports.

Table 6-72 sma port-info details Keyword Output Field Descriptions (continued)

Field	Description
state	A higher form of addressing than PhyState, state determines that the nodes can actually communicate and indicates the state transition that has occurred. A transition is a port change from down to "initialize", "initialize" to "down," "armed" to "down," or active to down as a result of link state machine logic. Changes to the port state resulting from SubnSet have no affect on this parameter value. The value is noStateChange, down, initialize, armed, or active.
port-phys	Indicates the actual state of the port. Determines that electricity flows between nodes so they can hand-shake. The value is noStateChange, sleeping, polling, disabled, portConfigurationTrainig, linkup, or linkErrorRecovery.
link-down-def	Default LinkDown state to return to. The value is noStateChange, sleeping, or polling. See section 5.5.2, Status Outputs (MAD GET), <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
mkey-protect-bits	Management key protection bits for the port. The bits are 0, 1, 2, and 3. See section 14.2.4.1, Levels of Protection, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
lmc	Local-identifier mask control (LMC) for multipath support. A LMC is assigned to each channel adapter and router port on the subnet. It provides multiple virtual ports within a single physical port. The value of the LMC specifies the number of path bits in the LID. A value of 0 (zero) indicates one LID is allowed on this port. See sections 3.5.10, Addressing, and 4.1.3, Local Identifiers, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
ls-active	Speed of an active link. The value is 1 (2.5 Gbps).
ls-active-enabled	Maximum speed the link is capable of handling. The value is 0 (No state change), 1 (2.5 Gbps), or 3 (value derived from link-speed-supported).
neighbor-mtu	Active maximum transmission unit enabled on this port for transmit. Check the mtu-cap value at both ends of every link and use the lesser speed. The value is mtu256, mtu512, mtu1024, mtu2048, or mtu4096.
master-sm-sl	Administrative service level required for this port to send a non-SMP message to the subnet manager.
vl-cap	Maximum range of data virtual lanes supported by this port. The value is vl0, vl0ToVl1, vl0ToVl3, vl0ToVl7, or vl0ToVl14. See also oper-VL.
vl-high-limit	Maximum high-priority limit on the number of bytes allowed for transmitting high-priority packets when both ends of a link operate with multiple data virtual-lanes. Used with the virtual-lane arbitration table. The maximum high-limit is determined by checking the vl-arb-high-cap on the other side of the link and then negotiating downward.
vl-arbitration-high-cap	Highest arbitration value allowed by the arbiter in determining the next packet in a set of packets to send across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. See section 14.2.5.9, VL Arbitration Table, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.

Table 6-72 sma port-info details Keyword Output Field Descriptions (continued)

Field	Description
vl-arbitration-low-cap	Lowest arbitration value allowed by the arbiter in determining the next packet in a set of packets to send across the link. Used with the virtual-lane arbitration table and specified as a VL/Weight pair. See section 14.2.5.9, VL Arbitration Table, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for more information.
mtu-cap	Used in conjunction with neighbor-mtu to determine the maximum transmission size supported on this port. The lesser of mtu-cap and neighbor-mtu determines the actual MTU used. The value is 256, 512, 1024, 2048, or 4096.
vl-stall-count	Number of sequentially dropped packets at which the port enters a VLStalled state. The virtual lane exits the VLStalled state (8 * HLL) units after entering it. See section 18.2.5.4, Transmitter Queuing, <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , for a description of HLL.
hoq-life	Maximum duration allowed to packets at the head of a virtual-lane queue. Used with VL-stall-count to determine the outgoing packets to discard.
op-vls	Administrative limit for the number of virtual lanes allowed to the link. Do not set this above the VL-cap value. The value is vl0, vl0-V11, vl0-V13, vl0-V17, or vl0-V114.
pkey-enf-in	Boolean value that indicated whether or not to support optional partition enforcement for the packets that were received by this port.
pkey-enf-out	Boolean value that indicates whether or not to support optional partition enforcement for the packets transmitted by this port.
filter-raw-pkt-in	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets that were received by this port.
filter-raw-pkt-out	Boolean value that indicates whether or not to support optional raw packet enforcement for the raw packets transmitted by this port.
mkey-violations	Number of subnet management packets (SMPs) that have been received on this port with invalid M_Keys since initial power-up or last reset. For more information see section 14.2.4, “Management Key” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
pkey-violations	Number of subnet management packets that have been received on this port with invalid P_Keys since initial power-up or the last reset. For more information, see section 9.2.7, “Partition Key” in <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> .
qkey-violations	Number of subnet management packets that have been received on this port with invalid Q_Keys since initial power up or the last reset. For more information, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 10.2.4, “Q Keys.”
guid-cap	Number of GUID entries allowed for this port in the port table. For more information, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 14.2.5.5, “GUIDCap.”
subnet-timeout	Maximum propagation delay allowed for this port to reach any other port in the subnet. This value also affects the maximum rate at which traps can be sent from this port.

Table 6-72 *sma port-info details Keyword Output Field Descriptions (continued)*

Field	Description
resp-timeout	Maximum time allowed between the port reception of a subnet management packet and the transmission of the associated response. For more information, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 13.4.6.2, “Timers and Timeouts.”
local-phys-err	Threshold at which ICRC, VCRC, FCCRC, and all physical errors result in an entry into the BAD PACKET or BAD PACKET DISCARD states of the local packet receiver. For more information, see <i>InfiniBand Architecture®, Vol. 1, Release 1.1</i> , section 7.12.2, “Error Recovery Procedures.”
overrun-err	Threshold at which buffer count overruns across consecutive flow-control update periods and results in an overrun error.

Command Output:

Table 6-73 describes the fields that appear when you use the **statistics** keyword with the **show interface ib** command.

Table 6-73 *statistics Keyword Output Field Descriptions*

Field	Description
port	Port identifier, in slot#/port# format.
name	Administrative port name that you configured with the name command.
in-octets	Cumulative number of octets that arrived at the port, including framing characters.
in-ucast-pkts	Cumulative number of incoming packets destined for a single port.
in-multicast-pkts	Cumulative number of incoming packets destined for the ports of a multicast group.
in-broadcast-pkts	Cumulative number of incoming packets destined for all ports on the fabric.
in-discards	Cumulative number of inbound packets that the port discarded for a reason other than a packet error (for example, lack of buffer space).
in-errors	Number of inbound packets with errors that the port discarded.
in-unknown-protos	For packet-oriented interfaces, the number of packets that were received through the interface that were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing, the number of transmission units received through the interface that were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter is always 0.
out-octets	Total number of octets transmitted out of the interface, including framing characters.
out-ucast-pkts	Total number of packets that higher-level protocols requested be transmitted and that were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

Table 6-73 *statistics Keyword Output Field Descriptions (continued)*

Field	Description
out-multicast-pkts	Total number of packets that higher-level protocols requested be transmitted and that were addressed to a multicast address at this sub-layer, including those that were discarded or not sent.
out-broadcast-pkts	Total number of packets that higher-level protocols requested to be transmitted and that were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.
out-discards	Number of outbound packets that were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free-up buffer space.
out-errors	For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.

Examples

The following example shows the output of the **show interface ib** command without the **sma** or **statistics** keywords:

```
SFS-270# show interface ib 4/7
=====
                        InfiniBand Interface Information
=====
                        port : 1
                        name : 1
                        type : ib4xTXP
                        desc : 1 (65)
        last-change : none
                        mtu : 0
auto-negotiate-supported : yes
        auto-negotiate : disabled
        admin-status : up
        oper-status : down
        admin-speed : 10gbps
        oper-speed : unknown
        link-trap : enabled
        phy-state : polling
        dongle-type : ib4xFX
```

The following example shows the output of the **show interface ib** command with the **statistics** keyword:

```
SFS-270# show interface ib 4/7 statistics
```

```

                        InfiniBand Interface Statistics
=====
                        port : 4/7
                        name : 4/7
                        in-octets : 0
                        in-ucast-pkts : 0
                        in-multicast-pkts : 0
                        in-broadcast-pkts : 0
                        in-discards : 0
                        in-errors : 0
                        in-unknown-protos : 0
                        out-octets : 0
                        out-ucast-pkts : 0
                        out-multicast-pkts : 0
                        out-broadcast-pkts : 0
                        out-discards : 0
                        out-errors : 0
```

Related Commands [ib-agent
name](#)

show interface mgmt-ethernet

To show the configuration of the Ethernet Management port on the controller card of your Server Switch, enter the **show interface mgmt-ethernet** command in User Exec mode or Privileged Exec mode.

show interface mgmt-ethernet

Syntax Description This command has no arguments or keywords.

Defaults The gateway address value defaults to 0.0.0.0.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

The Ethernet Management port is an Out-of-Band Management (OBM) port that provides network access to the system chassis in order to run remote CLI and Element Manager sessions. The port must be configured before it can be used.

This command displays the administrative status of the interface port, its assigned IP address and subnet mask, plus the IP address of the gateway port used to connect to the Ethernet Management port. If the Ethernet host is directly connected to the Ethernet Management port, without having to go through Ethernet switches, the default gateway-addr value is 0.0.0.0.

On the Cisco SFS 3012, you may access the Ethernet Management port on the currently active controller card only. The CLI always defaults to port 2 on the active controller card.

Command Output:

Table 6-74 describes the fields that appear in the **show interface mgmt-ethernet** command output.

Table 6-74 *show interface mgmt-ethernet Command Output Fields*

Field	Description
port	Ethernet management port number, in slot#/port# format.
mac-address	MAC address of the Ethernet management port.
auto-negotiate	Displays enabled if the port automatically negotiates link speed.
admin-status	Displays up if you enabled the port and down if you disabled the port.
ip-addr	IP address of the port.
mask	Subnet mask of the port.

Table 6-74 show interface mgmt-ethernet Command Output Fields (continued)

Field	Description
gateway-addr	Gateway configured for the port.
addr-option	Address option of the port (see the command: addr-option , page 2-5).

Examples

The following example displays the configuration of the Ethernet Management port on the active controller:

```
SFS-270# show interface mgmt-ethernet

=====

                        Mgmt-Ethernet Information
=====

                port : 15/1
                mac-address : 00:05:ad:00:19:16
        auto-negotiate : enabled
                admin-status : up
                ip-addr : 10.3.108.43
                mask : 255.255.0.0
        gateway-addr : 10.3.0.1
                addr-option : static
```

Related Commands

[gateway](#)

show interface mgmt-ib

To display the status and address information for the virtual InfiniBand Management port, enter the **show interface mgmt-ib** command in User Exec mode or Privileged Exec mode.

show interface mgmt-ib

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use this command to verify that you have configured your InfiniBand Management port successfully. Compare this output to the configuration file and check for discrepancies. You must configure the InfiniBand Management port successfully to run telnet, SSH, and Element Manager.

Examples

The following example displays the status and address information of the InfiniBand Management port:

```
SFS-7000P# show interface mgmt-ib
=====
                        Mgmt-InfiniBand Information
=====
      descr : Inband Management Port
      admin-status : up
      ip-addr : 192.168.2.200
      mask : 255.255.255.0
      gateway-addr : 0.0.0.0
SFS-7000P#
```

Related Commands

[gateway](#)
[telnet](#)

show interface mgmt-serial

This command displays the default configuration. This configuration cannot be changed. To display the configuration of the Serial Console port on the controller card of your Server Switch, enter the **show interface mgmt-serial** command in User Exec mode or Privileged Exec mode.

show interface mgmt-serial

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	This command has no default settings.
-----------------	---------------------------------------

Command Modes	User Execute mode, Privileged Execute mode.
----------------------	---

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p>
-------------------------	---

Privilege Level:

General read-only user.

The Serial Console port is the initial connection point with the system chassis and is used to configure the Ethernet Management and Infiniband Management ports. This port must be configured and a management station attached before any interaction with the system chassis is possible.

For the Cisco SFS 3012, you may only access the Serial Console port on the currently active controller card.

Examples	The following example displays the default interface management serial configuration:
-----------------	---

```
SFS-7000P# show interface mgmt-serial
=====
                        Mgmt-Serial Information
=====
                        baud-rate : 9600
                        data-bits  : 8
                        stop-bits  : 1
                        parity     : off
SFS-7000P#
```

Related Commands	show interface mgmt-ethernet show interface mgmt-ib shutdown
-------------------------	--

show inventory

To display the inventory of your Server Switch and to see a description of the chassis and slots, enter the **show inventory** command in User Exec mode or Privileged Exec mode.

show inventory

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012

Privilege Level:

General read-only user.

Command Output:

[Table 6-75](#) describes the fields in the **show inventory** command output.

Table 6-75 Show Inventory Output

Field	Description
Name	Name of the switch.
Description	Description of the chassis or slot.
PID	Password ID.
VID	Volume ID.
SN	Serial number.

Examples

The following example displays the inventory of a Server Switch:

```
SFS-7008P# show inventory
```

```
=====
                        Inventory Information
=====
NAME : "chassis-0x5ad00000019d1" , DESCR : "Cisco Topspin 270 Chassis"
PID : TOPSPIN-270 , VID : B0 , SN : USP041800095

NAME : "slot-1" , DESCR : "Cisco Topspin 270 Powered 4x LIM Card"
PID : TS270LIM4XCP , VID : B0 , SN : PY0410xxxxxx

NAME : "slot-5" , DESCR : "Cisco Topspin 270 12X LIM Card"
```

```
PID : TS270LIM12XCP , VID : B0 , SN : PY0430000002

NAME : "slot-6" , DESCR : "Cisco Topspin 270 12X LIM Card"
PID : TS270LIM12XCP , VID : B0 , SN : PY0430000014

NAME : "slot-7" , DESCR : "Cisco Topspin 270 Powered 4x LIM Card"
PID : TS270LIM4XCP , VID : B0 , SN : PY0410xxxxxx

NAME : "slot-8" , DESCR : "Cisco Topspin 270 Powered 4x LIM Card"
PID : TS270LIM4XCP , VID : B0 , SN : PY0410xxxxxx

NAME : "slot-9" , DESCR : "Cisco Topspin 270 Fabric Card"
PID : TS270FABRIC , VID : B1 , SN : USP041300011

NAME : "slot-11" , DESCR : "Cisco Topspin 270 Fabric Card"
PID : TS270FABRIC , VID : B1 , SN : USP041300010

NAME : "slot-12" , DESCR : "Cisco Topspin 270 Fabric Card"
PID : TS270FABRIC , VID : B1 , SN : USP041200010

NAME : "slot-13" , DESCR : "Cisco Topspin 270 Fabric Card"
PID : TS270FABRIC , VID : A0 , SN : USP034000008

NAME : "slot-16" , DESCR : "Cisco Topspin 270 Management I/O Card"
PID : TS270MGMTIO , VID : A5 , SN : MX3054200258

SFS-7008P#
```

Related Commands [show card](#)

show ip

To display IP configuration data, enter the **show ip** command in User Exec mode or Privileged Exec mode.

show ip [**address-table** | **route** | **http** [**server secure**]]

Syntax Description

address-table	(Optional) This keyword displays the address information of Ethernet interface ports, Ethernet interface cards, and InfiniBand interface cards. It lists the IP addresses, netmasks, broadcast formats, reassembly sizes, and whether or not the IP address is a primary or backup.
route	(Optional) This keyword displays the Classless Inter-Domain Routing (CIDR) forwarding records or routes (both static and dynamic) of all IP routes to system ports. Included in this information are the route destination, route type, route protocol, next hop, and port used.
http	(Optional) Displays current HTTP settings.
server secure	(Optional) Displays current secure HTTP server settings.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Use this command to view the results of the **ip** command.

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-only user.

Examples

The example below shows the output of the **show ip address-table** command. Note that port 0 always indicates the gateway port of the interface card.

```
SFS-7000P# show ip address-table
=====
                        IP Address Table
=====
port  address            mask                bcast-addr reasm    type    status
                        format      max-size
-----
  4/0  192.168.2.1          255.255.255.0       1          0      primary active
  4/1  192.168.1.1          255.255.255.0       1          0      primary active
  4/2  192.168.3.1          255.255.255.0       1          0      primary active
SFS-7000P#
```

The example below shows the local Ethernet routes for the system chassis. Local routes are automatically generated whenever you assign an IP address to a system card or port. The codes shown in the **proto** column are explained in the output header. A next-hop value of 0.0.0.0 always indicates a local route.

```
SFS-7000P# show ip route
=====
                                IP Routes
=====
Protocol Codes: OT - other      L - local      NM - netmgmt    IC - icmp
E - egp      G - ggp      H - hello      R - rip      IS - ISIS      ES - ES_IS,
CI - ciscoIgrp  BS - bbnSpfIgp  O - OSPF      B - BGP      ID - IDPR

dest          mask          next-hop      port   type   proto metric
-----
10.10.0.3     255.255.255.0    192.168.1.0   4/1    remote NM      0
192.168.1.0   255.255.255.0    0.0.0.0       4/1    local  L       0
192.168.2.0   255.255.255.0    0.0.0.0       4/0    local  L       0
192.168.3.0   255.255.255.0    0.0.0.0       4/2    local  L       0
SFS-7000P#
```

Related Commands [ip](#)

show ip http

To view the configuration of the HTTP server on your Server Switch, enter the **show ip http** command in User Exec mode or Privileged Exec mode.

show ip http

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Ethernet read-only user.

Use this command to determine if your HTTP server actively runs on your Server Switch, and to determine the HTTP port number that it uses.

Command Output:

[Table 6-76](#) describes the fields in the command output.


Table 6-76 *show ip http Command Output Field Descriptions*

Field	Description
server	Displays “enabled” if you have activated the server with the ip http server command. Displays “disabled” if you have deactivated the server with the no ip http server command.
port	Displays the HTTP port number that the HTTP server uses.
polling	Displays “enabled” or “disabled” to indicate polling status.

Examples

The following example displays the configuration of the HTTP server on the Server Switch:

```
SFS-270# show ip http
=====
                        IP HTTP Info
=====
      server : enabled
        port : 80
    polling : enabled
```

 show ip http

Related Commands [ip http](#)

show ip http server secure

To view the HTTPS configuration on your Server Switch, enter the **show ip http secure server** command in User Exec mode or Privileged Exec mode.

show ip http secure server

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Ethernet read-only user.

Use this command to determine if HTTPS actively runs on your Server Switch and to determine the HTTPS port number that it uses.

Command Output:

Table 6-77 describes the fields in the command output.

Table 6-77 *show ip http Command Output Field Descriptions*

Field	Description
secure-server	Displays “enabled” if you have activated the server with the ip http server command. Displays “disabled” if you have deactivated the server with the no ip http server command.
secure-port	Displays the HTTP port number that the HTTP server uses.
secure-cert-common-name	Certificate name of the secure server.

Examples

The following example displays the HTTPS configuration on the Server Switch:

```
SFS-270# show ip http server secure
=====
                        IP HTTP Secure Info
=====
      secure-server : enabled
      secure-port   : 443
secure-cert-common-name : useMgmtEnetIpAddr
```

■ show ip http server secure

Related Commands [ip http](#)

show location

To display the location data on your Server Switch, enter the **show location** command in User Exec mode or Privileged Exec mode.

show location

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

The **show location** command displays some contact information to the user; however, it may be configured to display any desired text string.

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Examples

The following example displays the location information that you configured with the **location** command:

```
SFS-7000P# show location
515 Ellis Street, Mountain View, CA 94043
SFS-7000P#
```

Related Commands

[location](#)
[snmp-server](#)
[show version](#)

show logging

To display the active system log file, enter the **show logging** command in User Exec mode or Privileged Exec mode.

show logging [end]

Syntax Description	end	(Optional) Displays approximately the last 10 entries in the system log and then continues to display log entries as they occur.
--------------------	-----	--

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	User Execute mode, Privileged Execute mode.
---------------	---

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>General read-only user.</p> <p>Use this command to view any of the following:</p> <ul style="list-style-type: none">warningserrorsnotificationsalerts <p>You may want to set the number of lines displayed per screen using the terminal length command. You can also use the more command on ts_log instead of the show logging command.</p> <p>The show logging end command is the equivalent of using the UNIX tail -f command. The CLI continues to display log entries as they occur until you enter Ctrl-c. No other CLI commands may be entered until Ctrl-c is used to stop the log display.</p> <p>We recommend that you set the terminal page length to 0 when using the end argument. Otherwise, you need to press the space bar to continue each time the maximum display length is reached. After you set the page length, do not change the terminal window size. Changing window size restores the terminal length to that of the window and restarts paging.</p> <p>The system log file on the chassis controller is /var/log/topspin.</p>
------------------	--

Examples:

The following example displays the last 10 log entries:

```
SFS-7000P# show logging end
Jan  3 11:09:58 igr-cc ib_sm.x[597]: [INFO]: Successfully add pgid
fe800000000000000000000000000005ad00000001199 to mgid ff18a01b000000000000000005ad000000002
Jan  3 17:02:56 igr-cc port_mgr.x[535]: [INFO]: port down - port=16/7, type=ib4xFX
Jan  3 17:02:58 igr-cc port_mgr.x[535]: [INFO]: port up - port=16/7, type=ib4xFX
Jan  3 18:21:46 igr-cc port_mgr.x[535]: [INFO]: port down - port=16/2, type=ib4xFX
Jan  3 18:21:48 igr-cc port_mgr.x[535]: [INFO]: port up - port=16/2, type=ib4xFX
Jan  3 19:35:55 igr-cc chassis_mgr.x[523]: [CONF]: [super]: config snmp trap-receiver
10.10.253.47
Jan  3 19:35:55 igr-cc chassis_mgr.x[523]: [CONF]: [super]: config snmp trap-receiver
10.10.253.47 version v2c
Jan  3 19:35:55 igr-cc chassis_mgr.x[523]: [CONF]: [super]: config snmp trap-receiver
10.10.253.47 community public
Jan  3 19:35:55 igr-cc chassis_mgr.x[523]: [CONF]: [super]: config snmp trap-receiver
10.10.253.47 community public
```

Related Commands

[copy](#)
[logging](#)
[show fan](#)
[telnet](#)
[terminal](#)

show ntp

To display

- the current date and time of your Server Switch,
- the Network Time Protocol (NTP) servers that your Server Switch uses to set the system clock,

enter the **show ntp** command in User Exec mode or Privileged Exec mode.

show ntp

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use the **clock set** command to set the time and date. Use the **ntp** command to set the NTP servers that are to maintain the system clock.

Examples

The following example displays the current date and time, as well as NTP server details:

```
SFS-7000P> show ntp
=====
                        NTP Information
=====
                        Date : 04/16/03
                        Time : 16:02:43
                        Server One : 10.3.120.55
                        Server Two : 10.3.120.56
                        Server Three : 10.3.120.57
SFS-7000P>
```

Related Commands

[ntp](#)
[clock set](#)

show power-supply

To display the status of the power supplies on your Server Switch, enter the **show power-supply** command in User Exec mode or Privileged Exec mode.

show power-supply

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012

Privilege Level:

General read-only user.

Use this command to monitor the power supply. This command primarily serves to help management tools continuously monitor power supply status. Errors in the ts_log file may prompt you to check power supply status. [Table 6-78](#) describes the power-supply fields.

Table 6-78 *show power-supply Command Field Descriptions*

Field	Description
type	Indicates AC power.
oper-status	Displays “up” or “down” to indicate the status of the power supply.
utilization	Displays percentage of power utilization when multiple power supplies provide power. Displays “n/a” when one power supply runs.
voltage	Voltage of the power supply.
product serial-number	Factory-assigned product serial number.
pca serial-number	Printed circuit assembly (PCA) serial number.
pca number	Printed Circuit Assembly (PCA) assembly number.
fru number	Field replaceable unit (FRU) number for the actual switch (select chassis) or chassis (select chassis).

Examples

The following example displays power supply details:

```
SFS-270> show power-supply

=====
Power-supply Information
=====
ps      type      oper-status  utilization  voltage
-----
1       AC         up           n/a          48
2       AC         down         n/a          48

=====
Power-supply Seeprom
=====
ps      product      pca          pca          fru
serial-number serial-number number        number
-----
1       -            -            -            -
2
```

Related Commands

- show backplane
- show fan
- show sensor

show redundancy-group

To display redundancy group information, enter the **show redundancy-group** command in User Exec mode or Privileged Exec mode.

show redundancy-group [*rlb-id*]

Syntax Description

rlb-id (Optional) Number of the redundancy group that you want to view.

Defaults

This command displays all redundancy groups by default.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Ethernet read-only user.

Use this command to view redundancy groups and attributes of redundancy groups.

Command Output:

[Table 6-79](#) describes the fields in the command output.

Table 6-79 *show redundancy-group* Command Field Descriptions

Field	Description
rlb-id	Redundancy group ID.
name	Redundancy group name.
group-p_key	Partition key of the group.
load-balancing	Displays “enabled” if load balancing runs; otherwise, it displays disabled.
broadcast-forwarding	Displays true if broadcast forwarding is enabled; otherwise, it displays false.
multicast	Displays true if multicast forwarding is enabled; otherwise, it displays false.
num-members	Number of members in the redundancy group.
new-member-force-reelection	Displays true if the group is configured to reelect a new primary when a new member joins; otherwise, it displays false.

Examples

The following example displays the redundancy groups on the chassis:

```
SFS-7000P# show redundancy-group
```

```
=====
                        Redundancy Groups
=====
      rlb-id : 1
      name : QA_Test_1
      group-p_key : ff:ff
      load-balancing : enabled
      broadcast-forwarding : false
      multicast : true
      num-members : 2
      new-member-force-reelection : false

=====
                        Redundancy Group Members
=====

bridge-group src-addr      last-receive
-----
1          192.168.3.248   Thu Jan  1 08:41:19 1970
3          192.168.3.248   Thu Jan  1 09:21:47 1970
```

Related Commands [redundancy-group](#)

show running-status

To execute a thorough range of show commands for a particular technology, enter the **show running-status** command in User Exec mode or Privileged Exec mode.

show running-status { **all** | **ethernet** | **fc** | **ib** } [**to-file**]

Syntax Description

all	Runs show commands for Ethernet, Fibre Channel, and InfiniBand technologies.
ethernet	Runs show commands for Ethernet only.
fc	Runs show commands for Fibre Channel only.
ib	Runs show command for InfiniBand only.
to-file	(Optional) Saves the output of the show commands to a file in the syslog directory on your Server Switch and displays the name of the file.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

This command can generate a large amount of data. Data is displayed per **terminal length** command settings. When executed, this command first prompts you to verify your desire to generate the data. Enter **y** to continue or **n** to cancel.

The default output file is **syslog:igr_interface_runningstatus**, where *interface* may be ether, fc, ib, or all. If the file already exists, it will be overwritten. This text file may be uploaded to another system using the **copy** command or viewed using the **more** command.

Examples

The following example runs all Ethernet show commands:

```
SFS-7000P> show running-status ethernet
Are you sure you want to continue? [yes/no] y
Gathering system-wide information, please wait.....
SFS-7000P> show arp ethernet
=====
                        ARP Information
=====
port      physical-address      net-address      type
-----
```

```
SFS-7000P> show arp ib

=====
                        ARP Information
=====
port physical-address                               net-address    type
-----
SFS-7000P> show backplane

=====
                        Backplane Seeprom
=====
base-mac-addr      chassis-id
-----
1a:0:a:3a:0:a      0x600000000
...
...
```

Related Commands See most of the other **show** commands.

[show interface ethernet](#)

[show interface fc](#)

show sensor

To display the temperature at several key locations in your Server Switch, enter the **show sensor** command in User Exec mode or Privileged Exec mode.

show sensor

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

The **show sensor** command identifies the temperature sensors in the system chassis. It also reports their location in the chassis and the current temperature at that location. Chassis temperature should be monitored to verify the cooling efficiency of the blowers and your data center air-conditioning.

Temperatures are in degrees Celsius and vary depending upon their location.

Normal temperature levels for the Cisco SFS 3001 remain 10 to 20 degrees Celsius above the ambient temperature.

75 C would be an alarm temperature and the system will reset itself at 85 C.

Command Output:

[Table 6-60](#) describes the output of the **show sensor** command.

Table 6-80 *show sensor Command Field Descriptions*

Field	Descriptions
sensor	Number of the temperature sensor.
oper-status	Operational status of the sensor (“up” or “down”).
oper-code (select Server Switches)	Operational code of the sensor.
temperature	Temperature that the sensor reads, in degrees Celsius.
alarm-temp (select Server Switches)	Temperature at which the sensor sounds an alarm.
shutdown-temp (select Server Switches)	Temperature at which the sensor shuts down the Server Switch.

Examples

The following example displays the temperature sensor information on the Server Switch:

```
SFS-270# show sensor

=====

                        Sensor Information
=====

sensor oper-status oper-code  temperature(c)  alarm-temp(c)  shutdown-temp(c)
-----
10/1   up           normal         35             75             85
11/1   up           normal         31             75             85
12/1   up           normal         29             75             85
13/1   up           normal         31             75             85
15/1   up           normal         38             70             80
16/1   up           normal         37             70             80
```

Related Commands

- show fan
- show power-supply

show snmp

To display the SNMP receivers for link traps on your Server Switch, enter the **show snmp** command in User Exec mode or Privileged Exec mode.

show snmp [**user** {**all** | *user-name*}]

Syntax Description	user	(Optional) Displays SNMP information for all users or for one particular user if you specify that user with the <i>user-name</i> variable.
	<i>user-name</i>	(Optional) User with the SNMP information that you want to display.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.
Use this command to verify the SNMP servers that you configure with the **snmp-server** command.

Examples The following example displays the SNMP trap receivers configured on the Server Switch:

SFS-270# **show snmp**

```
=====
                        SNMP Information
=====
                contact : support@topspin.com
                location : 515 Ellis Street, Mountain View, CA 94043

=====
                        Trap Receivers
=====
ipaddr          version    community        recv-events
-----
```

The following example displays the SNMP trap receivers for all users:

```
SFS-270# show snmp user
```

```
=====
                        SNMPv3 User Information
=====
engine-id : 80:00:18:3b:05:05:00:30:30:30:30:30:31:39:37:64

      username : admin
      auth-type : sha
auth-password : C568FC22657A9EF602C0B81EEC159554B89DD75A
      priv-type : des56
priv-password : C568FC22657A9EF602C0B81EEC159554
permission-level : ib-rw, ip-ethernet-rw, fc-rw
      enable : disabled

      username : guest
      auth-type : none
      priv-type : none
permission-level : ib-ro, ip-ethernet-ro, fc-ro
      enable : disabled

      username : super
      auth-type : md5
auth-password : C447A2DCD5FE2AD2167DF19401881AE0
      priv-type : des56
priv-password : C447A2DCD5FE2AD2167DF19401881AE0
permission-level : unrestricted-rw
      enable : disabled
```

Related Commands

[link-trap](#)
[location](#)
[logging](#)
[snmp-server](#)

show system

To display the current system global settings, enter the **show system** command in User Execute mode or Privileged Execute mode.

show system

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted read-write user.

Use this command to verify that the SRP configuration is locked or unlocked.

Examples

The following example indicates that the ib counter reset is enabled:

```
SFS-7000P# show system
=====
                        System Global Settings
=====
enable ib counter reset : enabled
```

Related Commands

[system-mode](#)

show system-mode

Use this command to verify that the SRP configuration is locked or unlocked. To display the current system mode (normal or VFrame), enter the show system-mode command in User Execute mode or Privileged Execute mode.

show system-mode

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Unrestricted read-write user.

Examples The following example indicates that the Server Switch is in its default unlocked mode:

```
SFS-7000P# show system-mode

=====
                        System Operation Mode
=====
oper-mode : normal
```

Related Commands [system-mode](#)

show system-services

Use this command to discover which system services (for example, telnet, ftp, and syslog) run on your Server Switch. You can configure any or all of these services to manage your Server Switch. To display system services such as FTP and telnet, enter the **show system-services** command in User Exec mode or Privileged Exec mode.

show system-services

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	This command has no default settings.
-----------------	---------------------------------------

Command Modes	User Execute mode, Privileged Execute mode.
----------------------	---

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012</p> <p>Privilege Level:</p> <p>Unrestricted read-write user.</p>
-------------------------	--

Examples	The following example displays the system services that run on the Server Switch:
-----------------	---

```
SFS-7000P# show system-services
=====
                        System Services
=====
      ftp service : disabled
      telnet service : enabled
      syslog-server-one : 0.0.0.0
      syslog-server-two : 0.0.0.0
=====
                        NTP Information
=====
      date : 03/29/06
      time : 17:01:35
      server-one : 0.0.0.0
      server-two : 0.0.0.0
Press any key to continue (Q to quit)
```

Related Commands	ftp-server enable history radius-server snmp-server ntp hostname
-------------------------	---

ip
telnet
terminal
config TACACS-server host

show terminal

To display terminal parameters, enter the **show terminal** command in User Exec mode or Privileged Exec mode.

show terminal

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only user.

Use this command to view information about your CLI session. The command provides useful information such as timeout parameters, output-screen length, and history-buffer size.

Examples

The following example displays information about this CLI session.

```
SFS-7000P# show terminal
Console is enabled
Connection host address is 10.10.253.128
Length: 25 lines, Width: 80 columns
Timeouts: enabled, Value: 15 minutes
Session limit is set to 3
History is enabled, history size is 30
Maximum command length is 512 characters
Maximum login attempts is 5
```

Related Commands

[telnet](#)
[terminal](#)

show trace

To display the system program modules that your Server Switch calls, enter the **show trace** command in User Exec mode or Privileged Exec mode.

```
show trace app application-number [module module-number] [card card-number]
```

Syntax Description	app	Specifies the application to trace.
	<i>application-number</i>	Number of the application to trace. Use the online help (?) to view a list of applications and application numbers.
	module	(Optional) Specifies the module to trace.
	<i>module-number</i>	Number of the module to trace. Use the online help (?) to view a list of modules and module numbers.
	card	(Optional) Specifies the card to trace.
	<i>card-number</i>	Number of the card to trace. Use the online help (?) to view a list of cards and card numbers.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.
Use this command for program debugging.

Examples The following example traces application 9, module 1, card 2:

```
SFS-7000P> show trace app 9 mod 1 card 2
AMF          1      0x0          0x0
```

Related Commands [show logging](#)
[trace](#)

show trunk

To display the current configuration of trunk groups, enter the **show trunk** command in User Exec mode or Privileged Exec mode.

show trunk [*trunk id*]

Syntax Description

trunk id (Optional) ID of the trunk group.

Defaults

This command has no default settings.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 3012

Privilege Level:

Unrestricted read-write user.

Use this command to view the trunk groups that you have configured on your Server Switch. You can verify trunk-group related changes that you have made to the configuration file with the **show trunk** command.

Examples

The following example displays the trunk groups on the Server Switch:

```
SFS-7000P# show trunk
```

```
=====
                        Trunks Groups
=====

      trunk-group-id : 1
      trunk-group-name :
      distribution-type : src-dst-mac
      port-members :
          enable : false
          mtu : 0
      mac-addr : 00:00:00:00:00:00
      ifindex : 45057
```

Related Commands

[distribution-type](#)
[trunk-group](#)

show user

To display user information for yourself or one or more users on the Server Switch, enter the **show user** command in User Exec mode or Privileged Exec mode. No TACACS+ user information is stored locally, so the command **show user all** shows only local users.

show user [*user* | **all**]

Syntax Description

user	(Optional) User to display.
all	(Optional) Displays all users in the user database.

Defaults

The **show user** command without arguments displays the account information for the user who executes the command.

Command Modes

User Execute mode, Privileged Execute mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-only and unrestricted read-write user.

Enter the **show user** command with no arguments to display your current user information. The command lists username, access level, status, and login statistics. All users may view their own user information, however, only an unrestricted read-write user may view the user information of others. The **show user** command tracks statistics that start from the last time the Server Switch booted.

[Table 6-81](#) describes the fields in the **show user** command output.

Table 6-81 *show user Command Field Descriptions*

Field	Description
username	Login name of the user.
password	Encrypted user password.
snmp-community	The SNMP community string that the user needs to run SNMP commands and the Element Manager GUI.
permission-level	Permission restrictions that define the commands in the CLI that the user can access.
admin-status	Displays enabled if the user account can log in and execute commands. Displays disabled if an unrestricted user has suspended the account so no one can use it. Enable or disable an account with the username command.
num-logins	Number of times the login logged in since the Server Switch booted.

Table 6-81 *show user Command Field Descriptions (continued)*

Field	Description
num-unsuccessful-logins	Number of times the login failed to log in successfully since the Server Switch booted.
last-login	Most recent login with the username.
last-unsuccessful-login	Most recent failed login with the username.

Examples

The following example displays the admin user:

```
SFS-7000P> show user admin
=====
                        User Information
=====
      username : admin
      password : $1$IJ5..U6.$1Sxb8uqVuUG7kOmiRxxHt1
      snmp-community : private
      permission-level : ib-rw, ip-ethernet-rw, fc-rw
      admin-status : enabled
      num-logins : 1
      num-unsuccessful-logins : 0
      last-login : Thu Apr 10 22:06:48 2003
      last-unsuccessful-login :
SFS-7000P>
```

The following example shows the login information of the current user:

```
SFS-7000P> show user
=====
                        User Information
=====
      username : super
      password : $1$IJ5..U6.$ES3pIhx/ccUaCKgM65vp6.
      snmp-community : secret
      permission-level : unrestricted-rw
      admin-status : enabled
      num-logins : 4
      num-unsuccessful-logins : 0
      last-login : Thu Apr 10 22:06:59 2003
      last-unsuccessful-login :
SFS-7000P>
```

Related Commands

[username](#)

show version

This command provides the software version, contact information, system up-time, time of last configuration change, and the last action performed on the Server Switch. To display a general, high-level description of your Server Switch, enter the **show version** command in User Exec mode or Privileged Exec mode.

show version

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes User Execute mode, Privileged Execute mode.

Usage Guidelines **Platform Availability:**
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
General read-only user.

Command Output:
[Table 6-82](#) describes the fields in the command output.

Table 6-82 Show Version Command Field Descriptions

Field	Description
system-version	OS version that the Server Switch runs.
contact	Displays the contact information that you configure with the snmp-server command. See the “snmp-server” section on page 2-66 .
name	Displays the device name that you configure with the hostname command. See the “hostname” section on page 2-41 .
location	Displays the location information that you configure with the snmp-server command. See the “snmp-server” section on page 2-66 .
up-time	Amount of time since last boot.
last-change	Date and time of last configuration change.
last-config-save	Date and time that an administrator last saved the running configuration.
action	Executed action. See the “action” section on page 2-3 .

Table 6-82 Show Version Command Field Descriptions (continued)

Field	Description
result	Result of executed action.
oper-mode	System mode of the Server Switch. See the “system-mode” section on page 2-71 .
sys-sync-state (select chassis only)	Displays the synchronization state between the primary controller card and the hot standby controller card.

Examples

The following example displays the system version:

```
SFS-7000P# show version
```

```
=====
                        System Version Information
=====
      system-version : SFS-7000P TopspinOS 2.4.0 releng #14 05/26/2
005 09:20:57
      contact : support@topspin.com
      name : SFS-7000P
      location : 515 Ellis Street, Mountain View, CA 94043
      up-time : 1 (d) :13 (h) :45 (m) :12 (s)
      last-change : Sat May 28 20:58:21 2005
      last-config-save : Fri May 27 08:12:03 2005
      action : none
      result : none
      oper-mode : normal
```

On the Cisco SFS 7008, the output includes the **sys-sync-state** field to display the synchronization state between the primary controller card and the hot standby controller card.

```
SFS-270# show version
```

```
=====
                        System Version Information
=====
      system-version : TS 96-Port 4x Fabric Copper Switch (3xxxxx-001) Release
2.2.0 releng #9 01/15/2005 10:38:47
      contact : Local TS support representative
      name : SFS-7000P
      location : 515 Ellis St Mountain View CA 94043
      rack-uid : 0x0
      up-time : 0 (d) :0 (h) :4 (m) :12 (s)
      last-change : none
      last-config-save : none
      action : none
      result : none
      sys-sync-state : complete
```

Related Commands

[hostname](#)
[location](#)
[snmp-server](#)
[show boot-config](#)



Diagnostic Commands

This chapter documents the following commands:

- [diagnostic](#), page 7-217
- [data-pattern](#), page 7-219
- [data-size](#), page 7-220
- [iterations](#), page 7-221
- [source-wwpn](#), page 7-222
- [start](#), page 7-223
- [stop](#), page 7-224
- [target-wwpn](#), page 7-225
- [test](#), page 7-226
- [validate](#), page 7-227

Running Diagnostic Tests

To perform a diagnostic test, follow these high-level steps:

-
- | | |
|---------------|---|
| Step 1 | Enter the appropriate configuration submode for the port or card that you want to test. |
| Step 2 | Configure the properties of the test: <ul style="list-style-type: none">• data-pattern• data-size• iterations• source-wwpn (Fibre Channel only)• target-wwpn (Fibre Channel only) |
| Step 3 | Configure the type of test: <ul style="list-style-type: none">• internal-loopback• external-loopback• echo• self-test |

**Note**

Available test types vary by card type and interface type.

Step 4

Start and stop tests as needed. See the [“start” section on page 7-223](#) and the [“stop” section on page 7-224](#).

diagnostic

To enter Diagnostic Configuration submode, enter the **diagnostic** command in Global Configuration mode.

```
diagnostic { card { card-selection | all } | chassis | interface { fc | ib | ethernet } { interface-selection | all } | fan { fan-number | all } | power-supply { supply | all } | rack-locator { locator | all } }
```



Note

Not all syntax applies to all hardware platforms. Enter Diagnostic submode to run test on cards and interfaces.

Syntax Description

card	Enters Card Diagnostic Configuration submode.
<i>card-selection</i>	Card, list of cards, or range of cards to diagnose.
chassis	Configures chassis-specific diagnostic tests.
fan	Configures fan-specific diagnostic tests.
interface	Enters Interface Diagnostic Configuration submode.
fc	Specifies Fibre Channel interfaces.
ib	Specifies InfiniBand interfaces.
ethernet	Specifies Ethernet interfaces.
<i>interface-selection</i>	Interface, list of interfaces, or range of interfaces to diagnose.
all	Specifies all interfaces of the technology type that you specified for all cards.
power-supply	Configures power supply-specific diagnostic tests.
rack-locator	Configures rack locator-specific diagnostic tests.

Defaults

This command has no default settings.

Command Modes

Global Configuration (config) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter



Note

The SFS 3001 and SFS 3012 can run card and interface tests only. For the SFS 7000 and SFS 7008, the **rack-locator** keyword supports only 12x, not 4x.

Privilege Level:

Read-write user for the appropriate technology.

Examples

The following example enters Diagnostic Configuration submode for Ethernet port 2/1:

```
SFS-7000P(config)# diagnostic interface ethernet 2/1  
SFS-7000P(config-diag-if-ether-2/1)#
```

Related Commands

[show diagnostic](#)
[show card](#)
[start](#)
[stop](#)
[test](#)

data-pattern

To specify a data pattern when you run a diagnostic test on an interfaces, enter the data-pattern command in Interface Diagnostic Configuration submode. To clear the data pattern, use the no form of this command.

data-pattern *pattern*

no data-pattern *pattern*

Syntax Description

<i>pattern</i>	Artificial traffic pattern to create for testing purposes.
----------------	--

Defaults

This command has no default settings.

Command Modes

Interface Diagnostic Configuration (config-diag-if) mode.

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

Examples

The following example configures the data pattern that runs during a diagnostic test:

```
SFS-7000P(config-diag-if-fc-4/1)# data pattern 11:22:33:44
```

Related Commands

[test](#)
[diagnostic](#)
[start](#)
[stop](#)
[show interface ethernet](#)
[show interface fc](#)
[show interface ib](#)

data-size

Configure the data size property of your test to customize the size of packets, frames, or IB packets that your Server Switch uses for your test. To configure the payload size of an interface, enter the **data-size** command in Interface Diagnostic Configuration submenu. To clear the data size, use the **no** form of this command.

data-size *size*

no data-size *size*

Syntax Description	Data size defaults to 4 octets.
	<i>size</i> Integer value that represents the payload size, in octets.

Command Modes	Interface Diagnostic Configuration submenu.
---------------	---

Usage Guidelines	Platform Availability: Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter
	Privilege Level: Unrestricted and general read-write user.

Examples	The following example configures the payload size for a diagnostic test:
	<code>SFS-7000P(config-diag-if-fc-4/1)# data size 8</code>

Related Commands	diagnostic
	show interface ethernet
	show interface fc
	show interface gateway
	start
	stop
	test

iterations

To specify the number of times to run a diagnostic test on an interface, enter the **iterations** command in Interface Diagnostic Configuration submode. If you do not specify a specific number of repetitions for a test to run, use the **stop** command.

iterations *repetitions*

Syntax Description	<i>repetitions</i> Integer value for the number of times that you want a test to run.
Defaults	The iterations value defaults to zero, which causes the test to run until you stop it with the stop command.
Command Modes	Interface Diagnostic Configuration submode.
Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted and general read-write user.</p>
Examples	<p>The following example configures diagnostic tests to run four times and then stop:</p> <pre>SFS-7000P(config-diag-if-fc-4/1)# iterations 4</pre>
Related Commands	<p>diagnostic</p> <p>show interface ethernet</p> <p>show interface fc</p> <p>show interface gateway</p> <p>start</p> <p>stop</p> <p>test</p>

source-wwpn

To configure an optional WWPN identifier for a Fibre Channel interface Echo test, enter the source-wwpn command in Fibre Channel Interface Diagnostic Configuration submode.

```
source-wwpn wwpn  
  
no source-wwpn wwpn
```

Syntax Description	<i>wwpn</i>	Optional 24-bit source identifier to use with the Fibre Channel interface Echo test.
--------------------	-------------	--

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	Interface Diagnostic Configuration submode.
---------------	---

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Unrestricted and general read-write user.</p>
------------------	---

Examples	<p>The following example sets the source wwpn:</p> <pre>SFS-7000P(config-diag-if-fc-4/1)# source-wwpn 20:01:00:05:ad:00:40:00</pre>
----------	---

Related Commands	<p>diagnostic</p> <p>show interface ethernet</p> <p>show interface fc</p> <p>show interface gateway</p> <p>start</p> <p>stop</p> <p>test</p>
------------------	--

start

To begin a diagnostic test, enter the **start** command in the appropriate Interface Diagnostic Configuration submode.

start

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Fibre Channel Interface Diagnostic Configuration (config-diag-if-fc) submode, Ethernet Interface Diagnostic Configuration (config-diag-if-en) submode, or Card Interface Diagnostic Configuration (config-diag-if-card) submode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Unrestricted and general read-write user.

Examples

The following example starts a LED diag test on a Fibre Channel interface:

```
SFS-7000P(config-diag-if-fc-4/1)# test led
SFS-7000P(config-diag-if-fc-4/1)# start
```

The following example starts a self-test diagnostic test on a card:

```
FS-7000P (config-diag-card-6)# test self-test
SFS-7000P (config-diag-card-6)# start
```

Related Commands

diagnostic
show interface ethernet
show interface fc
show interface gateway
stop
test

stop

To end a diagnostic test, enter the **stop** command in the appropriate Interface DiagnosticConfiguration submode.

stop

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Fibre Channel Interface Diagnostic Configuration (config-diag-if-fc) submode, Ethernet Interface Diagnostic Configuration (config-diag-if-en) submode, or Card Interface Diagnostic Configuration (config-diag-if-card) submode, Card Diagnostic Configuration submode (config-diag-card), Chassis Diagnostic Configuration submode (config-diag-chassis), Fan Diagnostic Configuration submode (config-diag-fan), Power Supply Diagnostic Configuration submode (config-diag-power-supply), Rack Locator Diagnostic Configuration submode (config-diag-rack-locator), InfiniBand Interface Diagnostic Configuration submode (config-diag-if-ib)

Usage Guidelines

Platform Availability:

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

Fibre Channelread-write user.

Examples

The following example stops the test running on Fibre Channel port 4/1:

```
SFS-7000P(config-diag-if-fc-4/1)# stop
```

The following example stops the test running on card 6:

```
FS-7000P (config-diag-card-6)# stop
```

Related Commands

[diagnostic](#)
[show interface ethernet](#)
[show interface fc](#)
[show interface gateway](#)
[start](#)
[test](#)

target-wwpn

To configure an optional WWPN identifier for a Fibre Channel interface Echo test, enter the **target-wwpn** command in Fibre Channel Interface Diagnostic Configuration submode.

```
source-wwpn wwpn  
  
no source-wwpn wwpn
```

Syntax Descriptionn	<i>wwpn</i>	Optional 24-bit source identifier to use with the Fibre Channel interface Echo test.
---------------------	-------------	--

Defaults	This command has no default settings.
----------	---------------------------------------

Command Modes	Configuration Diag Interface Fibre Channel (config-diag-if-fc) submode.
---------------	---

Usage Guidelines	<p>Platform Availability:</p> <p>Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter</p> <p>Privilege Level:</p> <p>Fibre Channelread-write user.</p>
------------------	---

Examples	<p>The following example enables database synchronization on the IB fabric:</p> <pre>SFS-7000P(config-diag-if-fc-4/1)# ib sm db-sync subnet-prefix fe:80:00:00:00:00:00 enable</pre>
----------	--

Related Commands	<p>diagnostic show interface ethernet show interface fc show interface gateway start stop test</p>
------------------	--

test

Specify a diagnostic test to run with the test command in appropriate Diagnostic Configuration submode.

test {echo | int-loopback | ext-loopback | led | self-test}



Note

The SFS 7000 does not support external loopback tests for InfiniBand interfaces. Table 7-8 describes the different tests that you can run and the interfaces or cards on which you can run them.

Syntax Description

echo	Echo test (Fibre Channel gateway only).
int-loopback	Internal loopback test (unsupported).
ext-loopback	External loopback test (Fibre Channel gateway only).
led	LED test.
self-test	Self test.
ext-cable	External cable test (unsupported).

Defaults

This command has no default settings.

Command Modes

Fibre Channel Interface Diagnostic Configuration (config-diag-if-fc) submode, Ethernet Interface Diagnostic Configuration (config-diag-if-en) submode, InfiniBand Interface Diagnostic Configuration

Usage Guidelines

Platform Availability:
Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:
Read-write user.

Examples

The following example specifies a LED test to run on card 11 when the **start** command executes:

```
SFS-7000P (config-diag-card-11)# test LED
```

Related Commands

diagnostic
show interface ethernet
show interface fc
show interface gateway
start
stop

validate

To validate diagnostic tests, enter the **validate** command in the appropriate Diagnostic Configuration submode.

validate

no validate

Syntax Description

This command has no arguments or keywords.

Defaults

This command has no default settings.

Command Modes

Diagnostic Configuration (config-diag) submode.

Usage Guidelines**Platform Availability:**

Cisco SFS 3001, Cisco SFS 7000, Cisco SFS 7008, Cisco SFS 3012, Cisco 4x InfiniBand Switch Module for IBM BladeCenter

Privilege Level:

General read-write user.

Examples

The following example validates diagnostic tests on port 6/2:

```
SFS-7000P (config-diag-if-en-6/2)# validate
```

Related Commands

[diagnostic](#)
[show interface ethernet](#)
[show interface fc](#)
[show interface gateway](#)
[start](#)
[stop](#)



A

act-count [6-97](#)
action command [2-3](#)
addr-option command [2-5](#)
admin-connection-type [6-157](#)
admin-duplex [6-149](#)
admin-speed [6-157, 6-168](#)
admin-status [6-157, 6-163, 6-168](#)
alarm-temp [6-199](#)
alignment-errors [6-152](#)
arp ethernet command [5-2](#)
authentication command [2-6](#)
auto-negotiate [6-149, 6-157](#)
auto-negotiate command [2-8](#)
auto-negotiate supported [6-168](#)
auto-negotiate-supported [6-157](#)

B

bad checksums [6-150](#)
base-version [6-111, 6-134](#)
bcast-addr format [6-149, 6-164](#)
boot-config command [2-10](#)
bridge-group command [5-3](#)
broadcast command [2-11](#)
broadcast-forwarding [6-195](#)

C

capability mask [6-116](#)
capability-mask [6-140, 6-170, 6-171](#)
cap-mask [6-116](#)

card command [2-12](#)
carrier-sense-errors [6-154](#)
cdp advertise-v2 command [2-13](#)
cdp holdtime command [2-15](#)
cdp run command [2-16](#)
cdp timer command [2-18](#)
certificates [6-187](#)
chassis-GUID [6-130](#)
class-version [6-111, 6-134](#)
clear cdp counters command [2-19](#)
clear cdp table command [2-20](#)
clock set command [2-21, 6-192](#)
cold-sync-limit [6-100](#)
cold-sync-period [6-100](#)
cold-sync-timeout [6-100](#)
command
 show version [6-212](#)
commands
 action [2-3](#)
 addr-option [2-5](#)
 arp ethernet [5-2](#)
 authentication [2-6](#)
 auto-negotiate [2-8](#)
 boot-config [2-10](#)
 bridge-group [5-3](#)
 broadcast [2-11](#)
 card [2-12](#)
 cdp advertise-v2 [2-13](#)
 cdp holdtime [2-15](#)
 cdp run [2-16](#)
 cdp timer [2-18](#)
 clear cdp counters [2-19](#)
 clear cdp table [2-20](#)

- clock set [2-21](#)
- configure system [2-6](#)
- configure terminal [2-24](#)
- copy [2-26](#)
- delete [2-29](#)
- dir [2-31](#)
- disable [2-33](#)
- distribution-type [5-5](#)
- enable [2-34](#)
- exec [2-35](#)
- exit [2-36](#)
- fc srp-global gateway-portmask-policy restricted [3-18](#)
- fc srp-global itl [3-19](#)
- fc srp-global lun-policy restricted [3-23](#)
- fc srp initiator [3-2](#)
- fc srp initiator-wwpn [3-5](#)
- fc srp it [3-7](#)
- fc srp itl [3-9](#)
- fc srp lu [3-13](#)
- fc srp target [3-17](#)
- ftp-server enable [2-37](#)
- gateway [2-38](#)
- half-duplex [5-7](#)
- help [2-39](#)
- history [2-40](#)
- hostname [2-41](#)
- ib-agent [4-14](#)
- ib pm [4-4](#)
- ib sm [4-8, 4-12](#)
- ib sm db-sync [4-2](#)
- install [2-42](#)
- ip (internal gateway ports, ethernet ports) [5-8](#)
- ip http [2-44](#)
- link-trap [2-46](#)
- location [2-47](#)
- logging [2-48](#)
- login [2-49](#)
- logout [2-50](#)
- more [2-51, 2-53](#)
- name [2-54](#)
- ntp [2-55](#)
- ping [2-56, 2-57](#)
- radius-server [2-58](#)
- redundancy-group [5-11](#)
- reload [2-60](#)
- save-log [2-62](#)
- show arp ethernet [6-4](#)
- show authentication [6-6](#)
- show backplane [6-8](#)
- show boot-config [6-10](#)
- show bridge-forwarding [6-12](#)
- show bridge-group [6-14](#)
- show bridge-subnets [6-16](#)
- show card [6-17](#)
- show card-inventory [6-22](#)
- show cdp [6-25, 6-27](#)
- show cdp neighbors [6-28](#)
- show clock [6-29](#)
- show config [6-30](#)
- show diagnostic [6-32](#)
- show diagnostic card [6-33](#)
- show diagnostic chassis [6-35](#)
- show diagnostic fan [6-36](#)
- show diagnostic fru-error [6-38](#)
- show diagnostic interface ethernet [6-40](#)
- show diagnostic interface fc [6-42](#)
- show diagnostic interface ib [6-44](#)
- show diagnostic post [6-46](#)
- show diagnostic power-supply [6-48](#)
- show diagnostic rack-locator [6-50](#)
- show fan [6-52](#)
- show fc srp-global [6-73](#)
- show fc srp initiator [6-54](#)
- show fc srp initiator-wwpn-view [6-57](#)
- show fc srp it [6-59](#)
- show fc srp itl [6-61](#)
- show fc srp itl-statistics [6-64](#)
- show fc srp lu [6-66](#)

- show fc srp statistics [6-69](#)
 - show fc srp target [6-71](#)
 - show host [6-74](#)
 - show ib-agent channel-adapter [6-134](#)
 - show ib-agent summary [6-136](#)
 - show ib-agent switch [6-138](#)
 - show ib dm ioc [6-76](#)
 - show ib dm iou [6-79](#)
 - show ib pm port counter [6-81, 6-83, 6-86, 6-89, 6-91](#)
 - show ib pm port counter config [6-88](#)
 - show ib pm threshold [6-94](#)
 - show ib sm configuration [6-96](#)
 - show ib sm db-sync [6-99](#)
 - show ib sm multicast [6-106](#)
 - show ib sm neighbor [6-108](#)
 - show ib sm node [6-110](#)
 - show ib sm partition [6-113](#)
 - show ib sm port [6-115](#)
 - show ib sm service [6-122, 6-125](#)
 - show ib sm sm-info [6-105](#)
 - show ib sm switch [6-127](#)
 - show ib sm switch-element-route [6-130](#)
 - show ib sm switch-route [6-132](#)
 - show interface ethernet [6-148](#)
 - show interface fc [6-156](#)
 - show interface gateway [6-162](#)
 - show interface ib [6-167](#)
 - show interface mgmt-ethernet [6-177](#)
 - show interface mgmt-ib [6-179](#)
 - show interface mgmt-serial [6-180](#)
 - show inventory [6-181](#)
 - show ip [6-183](#)
 - show ip http [6-185](#)
 - show ip http server secure [6-187](#)
 - show location [6-189](#)
 - show logging [6-190](#)
 - show ntp [6-192](#)
 - show power-supply [6-193](#)
 - show redundancy-group [6-195](#)
 - show running-status [6-197](#)
 - show sensor [6-199](#)
 - show snmp [6-201](#)
 - show system [6-203](#)
 - show system mode [6-204](#)
 - show system-services [6-205](#)
 - show terminal [6-207](#)
 - show trace [6-208](#)
 - show trunk [6-209](#)
 - show user [6-210](#)
 - shutdown [2-63](#)
 - snmp-server [2-66](#)
 - speed (Fibre Channel) [2-69](#)
 - system-mode [2-71](#)
 - telnet [2-73](#)
 - terminal [2-74](#)
 - trace [2-76](#)
 - trunk-group [5-12](#)
 - type [2-78](#)
 - username [2-80](#)
 - who [2-83](#)
 - write [2-84](#)
 - configure system command [2-6](#)
 - configure terminal command [2-24](#)
 - connection-type [6-160, 6-163](#)
 - copy command [2-26, 6-197](#)
-
- ## D
- data-pattern command [219](#)
 - data-size command [220](#)
 - default-port [6-128](#)
 - default-pri-mcast-port [6-128](#)
 - default-ttl [6-150](#)
 - deferred-transmissions [6-153](#)
 - def-mcast-NP-port [6-144](#)
 - def-mcast-pri-port [6-144](#)
 - def-non-pri-mcast-port [6-128](#)
 - delete command [2-29](#)

device vendor ID [6-139](#)
diag-code [6-116, 6-140, 6-171](#)
diagnostic command [217](#)
diagnostic test [215](#)
 ending [224](#)
dir command [2-31](#)
disable command [2-33](#)
distribution-type command [5-5](#)
documentation
 additional publications [xiii](#)
 conventions [xii](#)
 organization [xi](#)
dongle-type [6-169](#)
duplex type [6-149](#)

E

egress [6-144](#)
enable command [2-34](#)
errors [6-150](#)
ethernet [6-197](#)
exceeded time-to-live values [6-150](#)
excessive-collisions [6-153](#)
exec command [2-35](#)
exit command [2-36](#)

F

fc [6-197](#)
fc-initiator-IO [6-159](#)
fc-p-bytes-read [6-165](#)
fc-p-bytes-written [6-165](#)
fc-p-cmds-completed [6-159, 6-165](#)
fc-p-cmds-outstanding [6-159, 6-165](#)
FCP commands [6-159](#)
fc-p-errors [6-159, 6-165](#)
fc-p-initiated-ios [6-165](#)
fcs-errors [6-152](#)

fc srp-global gateway-portmask-policy restricted
 command [3-18](#)
fc srp-global itl command [3-19](#)
fc srp-global lun-policy restricted command [3-23](#)
fc srp initiator command [3-2](#)
fc srp initiator-wwpn command [3-5](#)
fc srp it command [3-7](#)
fc srp itl [3-10](#)
fc srp itl command [3-9](#)
fc srp lu command [3-13](#)
fc srp target command [3-17](#)
filter-raw-pkt-in [6-143, 6-173](#)
filter-raw-pkt-in-cap [6-144](#)
filter-raw-pkt-out [6-143, 6-173](#)
filter-raw-pkt-out-cap [6-144](#)
format errors [6-150](#)
forw-datagrams [6-150](#)
frag-creates [6-151](#)
frag-fails [6-151](#)
frag-OKs [6-151](#)
frame-too-longs [6-154](#)
FRU [6-193](#)
fru number [6-193](#)
ftp-server enable command [2-37](#)

G

gateway [6-163](#)
gateway command [2-38](#)
generic value [6-126](#)
GID [6-122, 6-123](#)
GID prefix [6-170](#)
gid-prefix [6-116, 6-140](#)
Global Configuration mode [1-5](#)
group-p_key [6-195](#)
GUID [6-170](#)
guid-cap [6-119, 6-143, 6-173](#)

H

half-duplex command [5-7](#)
HCA [6-136](#)
help command [2-39](#)
history command [2-40](#)
HOQ-life [6-118, 6-142](#)
hoq-life [6-173](#)
host-hoq-life-time [6-97](#)
hostname command [2-41](#)
HTTP server [6-185, 6-187](#)

I

ib [6-197](#)
ib-agent command [4-14](#)
ib pm command [4-4](#)
ib sm command [4-8, 4-12](#)
ib sm db-sync command [4-2](#)
IEEE standard [6-139](#)
if-index [6-115, 6-151, 6-164](#)
in-addr-errors [6-150](#)
inbound-enf-cap [6-144](#)
in-broadcast-pkts [6-151, 6-158, 6-174](#)
in-delivers [6-150](#)
in-discards [6-150, 6-151, 6-158, 6-174](#)
in-enf-cap [6-128](#)
in-errors [6-151, 6-158, 6-174](#)
in-filter-raw-pkt-cap [6-128](#)
in-filter-raw-pkt-enforce [6-118](#)
ingress [6-144](#)
in-hdr-errors [6-150](#)
in-ib-port [6-144](#)
in-multicast-pkts [6-151, 6-158, 6-174](#)
in-octets [6-151, 6-158, 6-174](#)
in-part-enforce [6-118](#)
input-port [6-131](#)
in-receives [6-150](#)
install command [2-42](#)

internal-mac-receive-errors [6-154](#)
internal-mac-transmit-errors [6-153](#)
in-ucast-pkts [6-151, 6-158, 6-174](#)
in-unknown-protos [6-150, 6-152, 6-158, 6-174](#)
inventory [6-181](#)
ioc-guid [6-159, 6-163](#)
IP broadcast address format [6-149](#)
ip command, internal gateway ports and ethernet ports [5-8](#)
IP datagram [6-150](#)
ip http command [2-44](#)
ip http server command [6-187](#)
IP option processing errors [6-150](#)
iterations command [221](#)

L

late-collisions [6-153](#)
lease [6-123](#)
LED test [226](#)
lft-cap [6-144](#)
lft-top [6-144](#)
LID [6-125, 6-138, 6-170](#)
lid [6-116, 6-134](#)
LID-mask-control [6-97](#)
lid-per-port [6-128](#)
LID range [6-126](#)
lids-per-port [6-144](#)
life-time-value [6-128, 6-144](#)
linear-fdb-cap [6-127](#)
linear-fdb-top [6-128](#)
linear forwarding table [6-144](#)
linear-frd-info [6-138](#)
linear unicast forwarding table [6-127](#)
link-down-def [6-141, 6-172](#)
link-down-def-state [6-117](#)
link-events [6-159, 6-164](#)
link-speed-active [6-117](#)
link-speed-enabled [6-117](#)

link-speed-supported [6-141, 6-171](#)
 link-state [6-108](#)
 link-trap [6-149, 6-158, 6-169](#)
 link-trap command [2-46](#)
 link-width active [6-141](#)
 link-width-active [6-108, 6-116, 6-171](#)
 link-width-enabled [6-116, 6-141, 6-171](#)
 link-width-supported [6-116, 6-141, 6-171](#)
 lmc [6-117, 6-172](#)
 load-balancing [6-195](#)
 local-node-guid [6-108](#)
 local-node-type [6-108](#)
 local-overflow-error [6-119](#)
 local-phy-error [6-119](#)
 local-phys-err [6-143, 6-174](#)
 local-port-id [6-108](#)
 local-port-num [6-134, 6-140](#)
 local-portnum [6-111](#)
 location command [2-47](#)
 logging [6-190](#)
 logging command [2-48](#)
 login command [2-49](#)
 logout command [2-50](#)
 ls-active [6-142, 6-172](#)
 ls-active-enabled [6-142, 6-172](#)

M

MAC address [6-149](#)
 mad-retries [6-97](#)
 MAD version [6-111](#)
 management key [6-116, 6-170](#)
 mask [6-164](#)
 master-poll-interval [6-97](#)
 master-poll-retries [6-97](#)
 master-SML-id [6-140](#)
 master-sm-lid [6-116, 6-170](#)
 master-SMSL [6-142](#)
 master-sm-SL [6-117](#)

master-sm-sl [6-172](#)
 max-active-sms [6-97](#)
 max-backup-sms [6-99](#)
 mcast-fdb-cap [6-127](#)
 mcast-info [6-138](#)
 member-join-state [6-107](#)
 mft-cap [6-144](#)
 MGID [6-106](#)
 mkey [6-116, 6-170](#)
 mkey-lease-period [6-116, 6-140, 6-171](#)
 mkey-prot-bits [6-117](#)
 mkey-protect-bits [6-141, 6-172](#)
 mkey-violations [6-143, 6-173](#)
 more command [2-51, 2-53, 6-197](#)
 mtu [6-149, 6-160, 6-163, 6-168](#)
 MTU-cap [6-142](#)
 mtu-cap [6-118, 6-173](#)
 multicast [6-195](#)
 Multicast Forwarding Table [6-144](#)
 multicast forwarding table [6-127](#)
 multicast group [6-174](#)
 multiple-collision-frames [6-153](#)

N

name [2-54](#)
 name command [2-54](#)
 neighbor-MTU [6-142](#)
 neighbor-mtu [6-117, 6-172](#)
 new-member-force-reelection [6-195](#)
 new-session-delay [6-100](#)
 node-guid [6-110, 6-113, 6-115, 6-125, 6-127, 6-144](#)
 node-info [6-138](#)
 node membership [6-114](#)
 node-timeout [6-97](#)
 no ip http server command [6-185, 6-187](#)
 ntp command [2-55, 6-192](#)
 num-members [6-195](#)
 num-ports [6-111, 6-135](#)

O

octets [6-151, 6-158, 6-174](#)
 oper-code [6-199](#)
 oper-connection-type [6-158](#)
 oper-duplex [6-149](#)
 oper-speed [6-149, 6-157, 6-168](#)
 oper-status [6-97, 6-149, 6-157, 6-163, 6-168, 6-193, 6-199](#)
 oper-VL [6-118](#)
 op-VLs [6-142](#)
 op-vls [6-173](#)
 our-errors [6-152](#)
 outbound-enf-cap [6-144](#)
 out-broadcast-pkts [6-152, 6-159, 6-175](#)
 out-discards [6-150, 6-152, 6-159, 6-175](#)
 out-enf-cap [6-128](#)
 out-errors [6-159, 6-175](#)
 out-filter-raw-pkt-cap [6-128](#)
 out-filter-raw-pkt-enforce [6-118](#)
 out-ib-port [6-144](#)
 out-multicast-pkts [6-152, 6-159, 6-175](#)
 out-no-routes [6-151](#)
 out-octets [6-152, 6-159, 6-174](#)
 out-part-enforce [6-118](#)
 output-port [6-131](#)
 out-requests [6-150](#)
 out-ucast-pkts [6-152, 6-159, 6-174](#)
 overrun-err [6-143, 6-174](#)

P

p_key [6-113, 6-123](#)
 partition
 show sm [6-113](#)
 partition-cap [6-111, 6-134](#)
 partition-enf-cap [6-128, 6-144](#)
 partition key [6-113, 6-123](#)
 partitions, creating and changing [4-8, 4-12](#)
 partitions node supports [6-139](#)

payload size [220](#)
 pca number [6-193](#)
 pca serial-number [6-193](#)
 physical-access [6-160, 6-163](#)
 PhyState [6-170](#)
 phy-state [6-117](#)
 ping command [2-56, 2-57](#)
 pkey-enf-in [6-142, 6-173](#)
 pkey-enf-out [6-143, 6-173](#)
 pkey-info [6-138](#)
 pkey-violations [6-143, 6-173](#)
 polling [6-185](#)
 poll-interval [6-100](#)
 port-GID [6-106](#)
 port-guid [6-111, 6-134](#)
 port-info [6-138](#)
 port-phys [6-141, 6-172](#)
 port-state-change [6-128, 6-144](#)
 power supplies [6-193](#)
 priority [6-151](#)
 product serial-number [6-193](#)
 prompt [1-5](#)
 customizing [1-4](#)
 protocol-ids [6-160, 6-163](#)
 proxy-join-status [6-107](#)

Q

qkey-violation [6-119](#)
 qkey-violations [6-143, 6-173](#)

R

RADIUS server [6-6](#)
 radius-server command [2-58](#)
 random-fdb-cap [6-127](#)
 random forwarding table [6-144](#)
 random unicast forwarding table [6-127](#)

reasm max-size [6-150, 6-164](#)
 redundancy-group command [5-11](#)
 redundancy groups [6-195](#)
 reload command [2-60](#)
 remote-node-guid [6-108](#)
 remote-node-type [6-108](#)
 remote-port-id [6-108](#)
 resp-time [6-119](#)
 resp-timeout [6-174](#)
 resp-time-value [6-143](#)
 resync-interval [6-100](#)
 revision [6-134](#)
 rft-cap [6-144](#)
 rlb-id [6-195](#)

S

sa-mad-queue-death [6-97](#)
 save-log command [2-62](#)
 secure-cert-common-name [6-187](#)
 secure-port [6-187](#)
 secure-server [6-187](#)
 sensor [6-199](#)
 serial-number [6-193](#)
 service-data [6-123](#)
 service-id [6-123](#)
 service-key [6-123](#)
 service-name [6-123, 6-159](#)
 session-timeout [6-99](#)
 show arp ethernet command [6-4](#)
 show authentication command [6-6](#)
 show backplane command [6-8](#)
 show boot-config command [6-10](#)
 show bridge-forwarding command [6-12](#)
 show bridge-group command [6-14](#)
 show bridge-subnets command [6-16](#)
 show card command [6-17](#)
 show card-inventory command [6-22](#)
 show cdp command [6-25](#)
 show cdp entry command [6-27](#)
 show cdp neighbors command [6-28](#)
 show clock command [6-29](#)
 show config [6-30](#)
 show config command [6-30](#)
 show diagnostic card command [6-33](#)
 show diagnostic chassis command [6-35](#)
 show diagnostic command [6-32](#)
 show diagnostic fan command [6-36](#)
 show diagnostic fru-error command [6-38](#)
 show diagnostic interface ethernet command [6-40](#)
 show diagnostic interface fc command [6-42](#)
 show diagnostic interface ib command [6-44](#)
 show diagnostic post command [6-46](#)
 show diagnostic power-supply command [6-48](#)
 show diagnostic rack-locator command [6-50](#)
 show fan command [6-52](#)
 show fc srp-global command [6-73](#)
 show fc srp initiator command [6-54](#)
 show fc srp initiator-wwpn-view command [6-57](#)
 show fc srp it command [6-59](#)
 show fc srp itl command [6-61](#)
 show fc srp itl-statistics command [6-64](#)
 show fc srp lu command [6-66](#)
 show fc srp statistics command [6-69](#)
 show fc srp target command [6-71](#)
 show host command [6-74](#)
 show ib-agent channel-adapter command [6-134](#)
 show ib-agent summary command [6-136](#)
 show ib-agent switch command [6-138](#)
 show ib dm ioc command [6-76](#)
 show ib dm iou command [6-79](#)
 show ib pm port counter command [6-81, 6-83, 6-86, 6-89, 6-91](#)
 show ib pm port counter config command [6-88](#)
 show ib pm threshold command [6-94](#)
 show ib sm configuration command [6-96](#)
 show ib sm db-sync command [6-99](#)
 show ib sm multicast command [6-106](#)
 show ib sm neighbor command [6-108](#)

show ib sm node command [6-110](#)
 show ib sm partition command [6-113](#)
 show ib sm port command [6-115](#)
 show ib sm service command [6-122, 6-125](#)
 show ib sm sm-info command [6-105](#)
 show ib sm switch command [6-127](#)
 show ib sm switch-element-route command [6-130](#)
 show ib sm switch-route command [6-132](#)
 show interface ethernet command [6-148](#)
 show interface fc command [6-156](#)
 show interface gateway command [6-162](#)
 show interface ib command [6-167](#)
 show interface mgmt-ethernet command [6-177](#)
 show interface mgmt-ib command [6-179](#)
 show interface mgmt-serial command [6-180](#)
 show inventory command [6-181](#)
 show ip command [6-183](#)
 show ip http command [6-185](#)
 show ip http server secure command [6-187](#)
 show location command [6-189](#)
 show logging command [6-190](#)
 show ntp command [6-192](#)
 show power-supply command [6-193](#)
 show redundancy-group command [6-195](#)
 show running-status command [6-197](#)
 show sensor command [6-199](#)
 show snmp command [6-201](#)
 show systemcommand [6-203](#)
 show system-mode command [6-204](#)
 show system-services command [6-205](#)
 show terminal command [6-207](#)
 show trace command [6-208](#)
 show trunk command [6-209](#)
 show user command [6-210](#)
 show version command [6-212](#)
 shutdown command [2-63](#)
 shutdown-temp [6-199](#)
 single-collision-frames [6-153](#)
 slot-id [6-164](#)

SL to VL mapping [6-144](#)
 sl-vl-map [6-138, 6-143](#)
 SM GUID, viewing [6-96](#)
 SMPs [6-173](#)
 SNMP receivers for link traps [6-201](#)
 snmp-server command [2-66](#)
 source-wwpn command [222](#)
 speed command, Fibre Channel [2-69](#)
 sqe-test-errors [6-153](#)
 src-lid [6-130](#)
 srp-bytes-read [6-164](#)
 srp-bytes-written [6-164](#)
 srp-cmds-completed [6-164](#)
 srp-cmds-outstanding [6-164](#)
 srp-connections [6-165](#)
 srp-errors [6-164](#)
 srp-initiated-ios [6-164](#)
 start command [223](#)
 state [6-100, 6-117, 6-170, 6-172](#)
 state of port
 logical [6-141](#)
 stop command [224](#)
 subnet manager GUID, viewing [6-96](#)
 subnet mask [6-164](#)
 subnet-prefix [6-130](#)
 subnet-timeout [6-119, 6-143, 6-173](#)
 switch-hoq-life-time [6-97](#)
 switch-info [6-138](#)
 switch-life-time [6-97](#)
 system-image-guid [6-111](#)
 system-mode command [2-71](#)

T

TACACS client [6-6](#)
 target-wwpn command [225](#)
 telnet command [2-73](#)
 temperature [6-199](#)
 terminal [6-207](#)

terminal command [2-74](#)
terminal length command [6-197](#)
test command [226](#)
to-file [6-197](#)
trace [6-208](#)
trace command [2-76](#)
trap-buffer [6-135](#)
trap-num-device-id [6-126](#)
trunk group [6-209](#)
trunk-group command [5-12](#)
type command [2-78](#)

who command [2-83](#)
write command [2-84](#)

U

username command [2-80](#)

V

validate command [227](#)
vendor-id [6-111, 6-134](#)
version number mismatches [6-150](#)
VL-arb-high-cap [6-118](#)
VL-arbitration-high-cap [6-142](#)
vl-arbitration-high-cap [6-172](#)
VL-arbitration-low-cap [6-142](#)
vl-arbitration-low-cap [6-173](#)
VL-arb-low-cap [6-118](#)
VL-cap [6-117, 6-142](#)
vl-cap [6-172](#)
VL-high-limit [6-117, 6-142](#)
vl-high-limit [6-172](#)
VL-stall-count [6-118, 6-142](#)
vl-stall-count [6-173](#)
voltage [6-193](#)

W

wait-report-response [6-97](#)