



CHAPTER 1

About Chassis Manager

Chassis Manager runs directly on Cisco SFS Server Switches to perform administration tasks. These topics introduce the various components of the interface:

- [Introduction, page 1-1](#)
- [Browser Requirements, page 1-7](#)
- [Platform Requirements, page 1-8](#)

Introduction

Chassis Manager runs in a standard web browser and displays information in standard HTML formats. The GUI has three frames:

- [System Frame, page 1-1](#) (See [Figure 1-1](#).)
- [Tree Frame, page 1-2](#) (See [Figure 1-2](#).)
- [View Frame, page 1-6](#) (See [Figure 1-4](#).)

System Frame

The System frame displays and updates the status of the cards, power supplies, and fans in your device. Each number in the Cards, Power Supplies, and Fans fields identifies a field-replaceable unit (FRU) in your device based on the slot number in which it resides. The color of the slot number indicates the status of the FRU. [Figure 1-1](#) shows a system frame for an SFS 7008P Server Switch.

Figure 1-1 **System Frame**




Table 1-1 lists the colors in the display and explains what each color indicates.

Table 1-1 *FRU Color Indicators*

Color	Indication
green	Operational and administrative status of up.
gray	Administrative status of down.
red	Operational status of down.

- Launch a CLI session to the server switch by clicking the IP address in the IP Address field to open a Telnet window.
- Contact Cisco TAC from the Support Contact field by clicking the e-mail address and sending an e-mail message.
- Start the online help by clicking on **Help**.

Tree Frame

The Tree frame appears on the lower left of the Chassis Manager display and provides a navigation tree that groups the functional branches of your device under icons. [Figure 1-2](#) displays the Tree frame on a Cisco SFS 3001 Server Switch.

Figure 1-2 *Tree Frame*



Note

[Figure 1-2](#) displays a tree frame for a user with unrestricted access. Restricted users may see fewer icons. For more information, see the [“Understanding Access Privileges”](#) section on [page 2-9](#).

Table 1-2 describes the icons in the Tree frame.

Table 1-2 *Tree Frame Icons*

Icon	Description
Chassis ()	The Chassis icon lets you view and configure hardware in your server switch. Access this icon to view the status of all field-replaceable units (FRUs) on your device.
Maintenance ()	The Maintenance icon contains branches that let you perform basic administrative tasks on your server switch. Access this icon to configure Network Time Protocol (NTP) servers, assign a boot-config file, view the contents of the file system, and so on.

Table 1-2 Tree Frame Icons (continued)

Icon	Description
InfiniBand ()	The InfiniBand icon provides subnet manager and I/O details. You can click the Subnet Manager branch of this icon to configure basic subnet manager properties.
Ethernet () (select hardware platforms only)	The Ethernet icon lets you view and configure many aspects of IP traffic on your server switch.
Fibre Channel () (select hardware platforms only)	The Fibre Channel icon shows your SRP host and Fibre Channel storage details and lets you configure global policies.
Help ()	The Help icon takes you to online help and support resources.

Click a plus-sign icon () to expand an icon and display the branches that you can configure. After you expand an icon, click a branch icon () to open the configuration options for that branch in the View frame.

Table 1-3 describes the configurable branches under the Chassis icon.

Table 1-3 Chassis Icon Branches

Branch	Description
Cards	Click this branch to display and configure controller, switch, and gateway cards.
Ports	Click this branch to display and configure all external InfiniBand, Ethernet, and Fibre Channel ports on your device.
Power Supplies (select hardware platforms only)	Click this branch to view the status of the power supplies on your device.
Fans (select hardware platforms only)	Click this branch to view the status of the fans on your device.
Sensors	Click this branch to view the status and readings on the temperature sensors on your device.
Backplane (select hardware platforms only)	Click this branch to view backplane details.
Management Ports	Expand the Management Ports icon to display the following branches: - Serial displays the Serial Console port configuration. - Ethernet displays the Ethernet Management port configuration. - InfiniBand displays the InfiniBand Management port configuration.

Table 1-4 describes the configurable branches under the Maintenance icon.

Table 1-4 Maintenance Icon Branches

Branch	Description
System Information	Click this branch to view and configure the information that appears in the System frame.
System Global Settings	Click this branch to view the system global settings.
Time	Click this branch to configure the time and date on your server switch and to assign NTP servers to your device.
File Management	Click this branch to view, import, export, and install files in the file system on your device.
Boot Configuration	Click this branch to select a configuration for your server switch to use when it boots.
Backup Configuration	Click this branch to save your running configuration to a file.
Save Config	Click this branch to save the running configuration as the startup configuration. When your server switch reboots, it runs the updated configuration.
Reboot	Click this branch when you want to reload your server switch.
Services	Expand the Services icon to display the following branches: • General Displays the following system services and lets you configure them: – DNS – FTP – Telnet – Syslog – RADIUS – TACACS+ • HTTP Displays HTTP properties and configuration options. • Radius Servers Displays the RADIUS server(s) that your device can use to authenticate user logins and lets you configure attributes of the server(s). • Tacacs Servers Displays the TACACS+ server(s) that your device can use to authenticate user logins and lets you configure attributes of the server(s). • Authentication Failures Lists CLI, SNMP, and HTTP authentication failures.
Diagnostics	Expand this branch to view server switch diagnostic data in the following branches: • POST • Fru Error

Table 1-5 describes the configurable branches under the InfiniBand icon.

Table 1-5 *InfiniBand Icon Branches*

Branch	Description
Subnet Managers	Click this branch to view and configure the subnet managers in your fabric.
Services	Click this branch to view the IB fabric services that have registered with the subnet manager.
Topology	Expand the Topology icon to display the following branches: - Nodes Click this branch to view the IB nodes in your IB fabric. - Ports Click this branch to view the IB ports in your IB fabric. - Neighbors Click this branch to display the interconnecting IB nodes and relevant ports in your IB fabric.
Device Management (select hardware platforms only)	Expand the Device Management icon to display the following branches: - IOU Click this branch to view the I/O unit on your server switch. - IOCs Click this branch to view the controller(s) on your device. - IOC Services Click this branch to view the IB features on your device.

Table 1-6 describes the configurable branches under the Ethernet icon.

Table 1-6 *Ethernet Icon Branches*

Branch	Description
Bridge Groups	Click this branch to view bridge groups on your server switch.
Bridge Subnet	Click this branch to view the subnets of bridge groups.
Bridge Forwarding	Click this branch to view the forwarding properties of bridge groups.
Redundancy Group	Click this branch to view redundancy groups.
Trunk Groups	Click this branch to view trunk groups on your server switch.

Table 1-7 describes the configurable branches under the Fibre Channel icon.

Table 1-7 Fibre Channel Icon Branches

Branch	Description
Global Policies	Click this branch to view and configure the default attributes of new IB-to-FC connections.
SRP Hosts	Click this branch to view and configure SRP hosts that serve as initiators for SAN fabrics.
Targets	Click this branch to view and configure Fibre Channel targets that connect to your server switch through FC gateways.
Logical Units	Click this branch to view and configure Fibre Channel LUNs that connect to your server switch through FC gateways.
ITs	Click this branch to view and configure attributes of initiator-target connections.
ITLs	Click this branch to view and configure attributes of initiator-target-LUN connections.
Global Statistics	Click this branch to view IB-to-FC traffic statistics.

Table 1-8 describes the configurable branches under the Help icon.

Table 1-8 Help Icon Branches

Branch	Description
Help Index	Click this branch to launch Chassis Manager online help.
Support	Click this branch to open the support website.

View Frame

The View frame appears on the right of the interface. Input fields and device details appear in this frame. The contents of the View frame vary based on the branch that you click in the Tree frame. [Figure 1-3](#) displays the graphic of the cable end, or service end, of the chassis that appears in the View frame when you first log in to the chassis manager.

Figure 1-3 View Frame on Logon



Ports 1 through 24 are InfiniBand ports.

- Ports with an operational status of up show with green pins.
- InfiniBand ports configured with double data rate (DDR) operational speed show with green pins and an orange surround.
- InfiniBand ports configured with single data rate (SDR) operational speed appear with green pins and a grey surround.

Figure 1-4 shows another View Frame example. You get this display when you expand **Chassis** in the tree frame and then click the **Ports** branch.

Figure 1-4 View Frame Example

Ports

10.3.102.66 > Chassis > Ports

Properties Refresh Show Options... ▼

	Port	Name	Type	Admin Status	Oper Status	MTU
☐	5/1	5/1	fc2GFX	up	up	2048
☐	5/2	5/2	fc2GFX	up	up	2048
☐	7/1	7/1	fc2GFX	up	down	2048
☐	7/2	7/2	fc2GFX	up	up	2048
☐	16/1	16/1	ib4xTX	up	down	4096
☐	16/2	16/2	ib4xFX	up	up	2048
☐	16/3	16/3	ib4xTX	up	down	4096
☐	16/4	16/4	ib4xFX	up	up	2048
☐	16/5	16/5	ib4xFX	up	up	2048
☐	16/6	16/6	ib4xTX	up	down	4096
☐	16/7	16/7	ib4xTX	up	down	4096
☐	16/8	16/8	ib4xTX	up	down	4096
☐	16/9	16/9	ib4xFX	up	up	2048
☐	16/10	16/10	ib4xTX	up	down	4096
☐	16/11	16/11	ib4xTX	up	down	4096
☐	16/12	16/12	ib4xTX	up	down	4096

Data Refreshed At - Wednesday, March 17, 2004 8:46:32 AM

154739

Browser Requirements

Chassis Manager supports the following browsers:

- Microsoft Internet Explorer Version 6
- Netscape Navigator Version 6
- Mozilla Version 1.4

Platform Requirements

Chassis Manager runs on the following platforms:

- Windows
- Solaris
- Linux