



Cisco Catalyst Blade Switch 3130 and 3032 for Dell Show Platform Commands

This appendix describes the **show platform** privileged EXEC commands that have been created or changed for use with the switch. These commands display information helpful in diagnosing and resolving internetworking problems and should be used only under the guidance of Cisco technical support staff.

show platform acl

Use the **show platform acl** privileged EXEC command to display platform-dependent access control list (ACL) manager information.

show platform acl {interface interface-id | label label-number [detail] | statistics asic-number |
usage asic-number [summary] | vlan vlan-id} [| {begin | exclude | include} expression]

Syntax Description	interface interface-id	Display per-interface ACL manager information for the specified interface. The interface can be a physical interface or a VLAN.
	label label-number [detail]	Display per-label ACL manager information. The <i>label-number</i> range is 0 to 255. The keyword has this meaning:
		• detail —(Optional) Display detailed ACL manager label information.
	statistics asic-number	Display per-ASIC ACL manager information. The <i>asic-number</i> is the port ASIC number, either 0 or 1.
	usage asic-number	Display per-ASIC ACL usage information. The keyword has this meaning:
	[summary]	• summary—(Optional) Display usage information in a brief format.
	vlan vlan-id	Display per-VLAN ACL manager information. The <i>vlan-id</i> range is from 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform backup interface

Use the **show platform backup interface** privileged EXEC command to display platform-dependent backup information used in a Flex Links configuration.

show platform backup interface [interface-id | dummyQ] [| {begin | exclude | include}
expression]

Syntax Description	interface-id	(Optional) Display backup information for all interfaces or the specified
		interface. The interface can be a physical interface or a port channel.
	dummyQ	(Optional) Display dummy queue information.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command History	Palaaaa	Modification
Command History	Release 12.2(40)EX1	Modification This command was introduced.
Command History Usage Guidelines	You should use this while troubleshooti you to do so.	

Cisco Catalyst Blade Switch 3130 and 3032 for Dell Command Reference

show platform configuration

Use the **show platform configuration** privileged EXEC command to display platform-dependent configuration-manager related information.

show platform configuration {config-output | default | running | startup} [| {begin | exclude | include} expression]

Syntax Description	config-output	Display the output of the last auto-configuration application.
	default	Display whether or not the system is running the default configuration.
	running	Display a snapshot of the backed-up running configuration on the local switch.
	startup	Display a snapshot of the backed-up startup configuration on the local switch.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform dl

Use the **show platform dl** privileged EXEC command to display dynamically loaded module information.

show platform dl [detail] [| {begin | exclude | include} expression]

Syntax Description	detail	(Optional) Display detailed dynamically loaded module information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
Command History	Release 12.2(40)EX1	Modification This command was introduced.
Command History Usage Guidelines	12.2(40)EX1 You should use this	

show platform etherchannel

Use the **show platform etherchannel** privileged EXEC command to display platform-dependent EtherChannel information.

show platform etherchannel {flags | time-stamps} [| {begin | exclude | include} expression]

Suntax Description	flage	Disalar EtherChannel as at flash
Syntax Description	flags	Display EtherChannel port flags.
	time-stamps	Display EtherChannel time stamps.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

do not appear, but the lines that contain Output appear.

Cisco Catalyst Blade Switch 3130 and 3032 for Dell Command Reference

show platform forward

Use the **show platform forward** privileged EXEC command for an interface to specify how the hardware would forward a frame that matches the specified parameters.

show platform forward interface-id [vlan vlan-id] src-mac dst-mac [l3protocol-id] [ipv6 | sap |
snap] [cos cos] [ip src-ip dst-ip [frag field] [dscp dscp] {l4protocol-id | icmp icmp-type
icmp-code | igmp igmp-version igmp-type | sctp src-port dst-port | tcp src-port dst-port flags |
udp src-port dst-port] [| {begin | exclude | include} expression]

Syntax Description	interface-id	The input physical interface, the port on which the packet comes in to the switch (including type, stack member, module, and port number).
	vlan vlan-id	(Optional) Input VLAN ID. The range is 1 to 4094. If not specified, and the input interface is not a routed port, the default is 1.
	src-mac	48-bit source MAC address.
	dst-mac	48-bit destination MAC address.
	l3protocol-id	(Optional) The Layer 3 protocol used in the packet. The number is a value 0 to 65535.
	ipv6	(Optional) IPv6 frame. This keyword is supported only if the switch or switch stack is running the IP services feature set.
	sap	(Optional) Service access point (SAP) encapsulation type.
	snap	(Optional) Subnetwork Access Protocol (SNAP) encapsulation type.
	cos cos	(Optional) Class of service (CoS) value of the frame. The range is 0 to 7.
	ip src-ip dst-ip	(Optional, but required for IP packets) Source and destination IP addresses in dotted decimal notation.
	frag field	(Optional) The IP fragment field for a fragmented IP packet. The range is 0 to 65535.
	dscp dscp	(Optional) Differentiated Services Code Point (DSCP) field in the IP header. The range is 0 to 63.
	l4protocol-id	The numeric value of the Layer 4 protocol field in the IP header. The range is 0 to 255. For example, 47 is generic routing encapsulation (GRE), and 89 is Open Shortest Path First (OSPF). If the protocol is TCP, User Datagram Protocol (UDP), Internet Control Message Protocol (ICMP), or Internet Group Management Protocol (IGMP), you should use the appropriate keyword instead of a numeric value.
	icmp <i>icmp-type</i> <i>icmp-code</i>	ICMP parameters. The <i>icmp-type</i> and <i>icmp-code</i> ranges are 0 to 255.
	igmp igmp-version igmp-type	IGMP parameters. The <i>igmp-version</i> range is 1 to 15; the <i>igmp-type</i> range is 0 to 15.
	sctp src-port dst-port	Stream Control Transmission Protocol (SCTP) parameters. The ranges for the SCTP source and destination ports are 0 to 65535.
	tcp src-port dst-port flags	TCP parameters: TCP source port, destination port, and the numeric value of the TCP flags byte in the header. The <i>src-port</i> and <i>dst-port</i> ranges are 0 to 65535. The flag range is 0 to 1024.
	udp src-port dst-port	UDP parameters. The <i>src-port</i> and <i>dst-port</i> ranges are 0 to 65535.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .

	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines	You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.	
	-	e sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.
Examples	-	show platform forward command output displays and what they mean, see the chapter of the software configuration guide for this release.

show platform frontend-controller

Use the **show platform frontend-controller** privileged EXEC command to display counter and status information for the front-end controller manager and subordinate applications and to display the hardware and software information for the front-end controller.

show platform frontend-controller {buffer | generic | manager number | subordinate number |
version number} [| {begin | exclude | include} expression]

Syntax Description	buffer	Display the last 1024 bytes sent from the manager to the subordinate and the reverse.
	generic	Display the generic counters that do not specifically apply to the manager or subordinate.
	manager number	Display the counters for the manager and the subordinate specified by <i>number</i> . See the "Usage Guidelines" section for the <i>number</i> range.
	subordinate number	Display the subordinate status and the counters for the subordinate specified by <i>number</i> . See the "Usage Guidelines" section for the <i>number</i> range.
	version number	Display the hardware and software version information for the subordinate status specified by <i>number</i> . See the "Usage Guidelines" section for the <i>number</i> range.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines

The subordinate number range is 0 to 2.

You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform ip igmp snooping

Use the **show platform ip igmp snooping** privileged EXEC command to display platform-dependent Internet Group Management Protocol (IGMP) snooping information.

show platform ip igmp snooping {all | control [di] | counters | flood [vlan vlan-id] | group
ip-address | hardware | retry [count | local [count] | remote [count]]} [| {begin | exclude |
include} expression]

Syntax Description	all	Display all IGMP snooping platform IP multicast information.
	control [di]	Display IGMP snooping control entries. The keyword has this meaning:
		• di —(Optional) Display IGMP snooping control destination index entries.
	counters	Display IGMP snooping counters.
	flood [vlan vlan-id]	Display IGMP snooping flood information. The keyword has this meaning:
		• vlan <i>vlan-id</i> —(Optional) Display flood information for the specified VLAN. The range is 1 to 4094.
	group ip-address	Display the IGMP snooping multicast group information, where <i>ip-address</i> is the IP address of the group.
	hardware	Display IGMP snooping information loaded into hardware.
	retry [count local [count]	Display IGMP snooping retry information. The keywords have these meanings:
		• count —(Optional) Display only the retry count.
		• local—(Optional) Display local retry entries.
	remote [count]	Display remote entries. The keyword has this meaning:
		• count —(Optional) Display only the remote count.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks

you to do so.

show platform ip multicast

Use the **show platform ip multicast** privileged EXEC command to display platform-dependent IP multicast tables and other information.

show platform ip multicast {acl-full-info | counters | groups | hardware [detail] | interfaces |
 locks | mdfs-routes | mroute-retry | retry | trace} [| {begin | exclude | include} expression]

SVILAX DESCRIPTION		Diaplay ID multipast neuting assage control list (ACI) information in
Syntax Description	acl-full-info	Display IP multicast routing access-control list (ACL) information, in particular the number of outgoing VLANs for which router ACLs at the
		output cannot be applied in hardware.
	counters	Display IP multicast counters and statistics.
	groups	Display IP multicast routes per group.
	hardware [detail]	Display IP multicast routes loaded into hardware. The optional detail
		keyword is used to show port members in the destination index and route
		index.
	interfaces	Display IP multicast interfaces.
	locks	Display IP multicast destination-index locks.
	mdfs-routes	Display multicast distributed fast switching (MDFS) IP multicast routes.
	mroute-retry	Display the IP multicast route retry queue.
	retry	Display the IP multicast routes in the retry queue.
	trace	Display the IP multicast trace buffer.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
	Privileged EXEC	
Command Modes Command History		Expression in the output to use as a reference point. Modification
Command History	Privileged EXEC Release 12.2(40)EX1 You should use this co while troubleshooting	Modification This command was introduced. mmand only when you are working directly with a technical support representation
	Privileged EXEC Release 12.2(40)EX1 You should use this co while troubleshooting you to do so.	Modification

show platform ip unicast

Use the **show platform ip unicast** privileged EXEC command to display platform-dependent IP unicast routing information.

Syntax Description	adjacency	Display the platform adjacency database.
	cef-idb	Display platform information corresponding to Cisco Express Forwarding (CEF) interface descriptor block.
	counts	Display the current counts for the Layer 3 unicast databases.
	dhcp	Display the DHCP system dynamic addresses.
	failed {adjacency arp [A.B.C.D] route}	Display the hardware resource failures. The keywords have these meanings
		• adjacency —Display the adjacency entries that failed to be programmed in hardware.
		• arp —Display the Address Resolution Protocol (ARP) deletions because of failure and because of retries.
		• <i>A.B.C.D</i> —(Optional) Prefix of the ARP entries to display.
		• route —Display the route entries that failed to be programmed in hardware.
	loadbalance	Display the platform load-balance database.
	mpaths	Display the Layer 3 unicast routing multipath adjacency database.
	proxy	Display the platform proxy ARP database.
	route	Display the platform route database.
	rpf { <i>A.B.C.D</i> { <i>A.B.C.D</i> } stats	Display the unicast reverse path forwarding (unicast RPF) platform information. The keywords have these meanings:
	interface-id}	• A.B.C.D {A.B.C.D}—Prefix and prefix mask of the RPF entries to display.
		stats—Display the unicast RPF statistics for the specified interface.
	standby	Display the platform standby information.
	statistics	Display the Layer 3 unicast routing accumulated statistics.
	table	Display the platform IP version 4 (IPv4) information.
	trace	Display the platform event trace logs.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.



Though visible in the command-line help strings, the **proxy** and **table** keywords are not supported.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform ip unicast vrf compaction

Use the **show platform ip unicast vrf compaction** privileged EXEC command to display the compaction request queues and compaction status.

show platform ip unicast vrf compaction [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	Modification
Command History	12.2(40)EX1	This command was introduced.

you to do so.

show platform ip unicast vrf tcam-label

Use the **show platform ip unicast vrf tcam-label** privileged EXEC command to display PBR and VRF-Lite labels and the number of labels in use by PBR.

show platform ip unicast vrf tcam-label [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines		command only when you are working directly with a technical support representative as a problem. Do not use this command unless a technical support representative asks

you to do so.

show platform ip wccp

Use the **show platform ip wccp** privileged EXEC command to display platform-dependent Web Cache Communication Protocol (WCCP) information.

show platform ip wccp {detail | label} [| {begin | exclude | include} expression]

This command is supported only if your switch is running the IP services feature set.

Syntax Description	detail	Display the platform WCCP details.
	label	Display the platform WCCP labels.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines	while troubleshooti you to do so. Expressions are cas	command only when you are working directly with a technical support representative ng a problem. Do not use this command unless a technical support representative asks se sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.

show platform ipc trace

Use the **show platform ipc trace** privileged EXEC command to display platform-dependent Interprocess Communication (IPC) Protocol trace log information.

show platform ipc trace [| {begin | exclude | include} expression]



This command is supported only on stacking-capable switches.

Syntax Description	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
·	12.2(40)EX1	This command was introduced.
Usage Guidelines	You should use this	This command was introduced. command only when you are working directly with a technical support representative ng a problem. Do not use this command unless a technical support representative asks

do not appear, but the lines that contain Output appear.

show platform ipv6 unicast

Use the **show platform ipv6 unicast** privileged EXEC command to display platform-dependent IPv6 unicast routing information.

show platform ipv6 unicast {adjacency [ipv6-prefix] | backwalk {adjacency | loadbalance} |
 compress ipv6-prefix/prefix length | interface | loadbalance | mpath | retry {adjacency |
 route} | route [ipv6-prefix/prefix length | tcam] [detail] | statistics | table [detail] | trace}
 [I {begin | exclude | include} expression]

This command is supported only if the switch or switch stack is running the IP services feature set.

Syntax Description	adjacency	Display IPv6 adjacency information for the switch or for the specified IPv6 network.
	ipv6-prefix	(Optional) The IPv6 network to be displayed. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
	backwalk {adjacency	Display IPv6 backwalk information.
	loadbalance}	• adjacency —Display adjacency backwalk information.
		• loadbalance—Display backwalk load-balance information.
	compress	Display IPv6 prefix compression information.
	ipv6-prefix/prefix	• <i>ipv6-prefix</i> —The IPv6 network.
	length	• <i>/prefix length</i> —The length of the IPv6 network prefix. A decimal value from 0 to 128 that shows how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.
	interface	Display IPv6 interface information.
	loadbalance	Display IPv6 load-balance information
	mpath	Display IPv6 multipath information
	retry {adjacency route}	Display IPv6 retry information.
		• adjacency —Display IPv6 adjacency retry information.
		• route—Display IPv6 route retry information.
	route	Display IPv6 route information.
	tcam	(Optional) Display the IPv6 hardware route table information.
	detail	(Optional) Display detailed IPv6 route information.
	statistics	Display IPv6 accumulated statistics.
	table	Display IPv6 unicast table information.
	trace	Display IPv6 unicast traces.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform layer4op

Use the **show platform layer4op** privileged EXEC command to display platform-dependent Layer 4 operator information.

show platform layer4op {acl | pacl [port-asic] | qos [port-asic] } {and-or | map | or-and | vcu}
[| {begin | exclude | include} expression]

Syntax Description acl Display access control list (ACL) Layer 4 operators information. pacl [port-asic] Display port ACL Layer 4 operators information. The keyword has this mean • port-asic—(Optional) Port ASIC number. qos [port-asic] Display quality of service (QoS) Layer 4 operators information. The keyword this meaning: • port-asic—(Optional) QoS port ASIC number. and-or Display AND-OR registers information.	
 <i>port-asic</i>—(Optional) Port ASIC number. qos [<i>port-asic</i>] Display quality of service (QoS) Layer 4 operators information. The keyworthis meaning: <i>port-asic</i>—(Optional) QoS port ASIC number. 	
qos [port-asic]Display quality of service (QoS) Layer 4 operators information. The keywor this meaning:• port-asic—(Optional) QoS port ASIC number.	ning:
 this meaning: <i>port-asic</i>—(Optional) QoS port ASIC number. 	
	d has
and-or Display AND-OR registers information.	
mapDisplay select map information.	
or-and Display OR-AND registers information.	
vcuDisplay value compare unit (VCU) register information.	
begin (Optional) Display begins with the line that matches the <i>expression</i> .	
l exclude (Optional) Display excludes lines that match the <i>expression</i> .	
l include (Optional) Display includes lines that match the specified <i>expression</i> .	
<i>expression</i> Expression in the output to use as a reference point.	

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform mac-address-table

Use the **show platform mac-address-table** privileged EXEC command to display platform-dependent MAC address table information.

show platform mac-address-table [aging-array | hash-table | mac-address mac-address] [vlan
vlan-id]] [| {begin | exclude | include} expression]

Syntax Description	aging-array	(Optional) Display the MAC address table aging array.
	hash-table	(Optional) Display the MAC address table hash table.
	mac-address mac-address	(Optional) Display the MAC address table MAC address information, where <i>mac-address</i> is the 48-bit hardware address.
	vlan vlan-id	(Optional) Display information for the specified VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform messaging

Use the **show platform messaging** privileged EXEC command to display platform-dependent application and performance message information.

show platform messaging {application [incoming | outgoing | summary] | hiperf
[class-number]} [| {begin | exclude | include} expression]

Syntax Description	application [incoming outgoing summary]	Display application message information. The keywords have these meanings:	
		• incoming —(Optional) Display only information about incoming application messaging requests.	
		• outgoing —(Optional) Display only information about incoming application messaging requests.	
		• summary —(Optional) Display summary information about all application messaging requests.	
	hiperf [class-number]	Display outgoing high-performance message information. Specify the <i>class-number</i> option to display information about high-performance messages for this class number. The range is 0 to 36.	
	begin	(Optional) Display begins with the line that matches the expression.	
	exclude	(Optional) Display excludes lines that match the expression.	
	include	(Optional) Display includes lines that match the specified expression.	
	expression	Expression in the output to use as a reference point.	

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform monitor

Use the **show platform monitor** privileged EXEC command to display platform-dependent Switched Port Analyzer (SPAN) information.

show platform monitor [session session-number] [| {begin | exclude | include} expression]

Syntax Description	session session-number	(Optional) Display SPAN information for the specified SPAN session. The range is 1 to 66.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines		command only when you are working directly with a technical support representative g a problem. Do not use this command unless a technical support representative asks
	Expressions are case	e sensitive. For example, if you enter exclude output, the lines that contain output

show platform mvr table

Use the **show platform mvr table** privileged EXEC command to display the platform-dependent Multicast VLAN Registration (MVR) multi-expansion descriptor (MED) group mapping table.

show platform mvr table [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines	while troubleshooting you to do so. Expressions are case	ommand only when you are working directly with a technical support representative g a problem. Do not use this command unless a technical support representative asks sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear.

show platform pm

Use the **show platform pm** privileged EXEC command to display platform-dependent port-manager information.

show platform pm {counters | group-masks | idbs {active-idbs | deleted-idbs} | if-numbers |
 link-status | platform-block | port-info interface-id | stack-view | vlan {info | line-state}
 [| {begin | exclude | include} expression]

Syntax Description	counters	Display module counters information.
	group-masks	Display EtherChannel group masks information.
	idbs {active-idbs deleted-idbs}	Display interface data block (IDB) information. The keywords have these meanings:
		• active-idbs—Display active IDB information.
		• deleted-idbs —Display deleted and leaked IDB information.
	if-numbers	Display interface numbers information.
	link-status	Display local port link status information.
	platform-block	Display platform port block information.
	port-info interface-id	Display port administrative and operation fields for the specified interface.
	stack-view	Display status information for the stack.
		This keyword is supported only on stacking-capable switches.
	vlan {info line-state}	Display platform VLAN information. The keywords have these meanings:
		• info —Display information for active VLANs.
		• line-state —Display line-state information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform port-asic

Use the **show platform port-asic** privileged EXEC command to display platform-dependent port ASIC register information.

show platform port-asic {cpu-queue-map-table [asic number | port number [asic number]] | dest-map index number | etherchannel-info [asic number | port number [asic number]] | exception [asic number | port number [asic number]] | global-status [asic number | port number [asic number]] | learning [asic number | port number [asic number]] | mac-info [asic number | port number [asic number]] | mvid [asic number] | packet-info-ram [asic number | index number [asic number]] | port-info [asic number | port number [asic number]] | prog-parser [asic number | port number [asic number]] | receive {buffer-queue | port-fifo | supervisor-sram} [asic number | port number [asic number]]| span [vlan-id [asic number] | [asic number] stack {control | dest-map | learning | messages | mvid | prog-parser | span | stats [asic number | port number [asic number]] stats {drop | enqueue | miscellaneous | supervisor } [asic number | port number [asic number]]| transmit {port-fifo | queue | supervisor-sram } [asic number | port number [asic number]] vct [asic number | port number [asic number]] version} [| { **begin** | **exclude** | **include** } *expression*]

Syntax Description	cpu-queue-map-table [asic number port number [asic number]]	 Display the CPU queue-map table entries. The keywords have these meanings: asic number—(Optional) Display information for the specified ASIC. The range is 0 to 1.
		• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27.
	dest-map index number	Display destination-map information for the specified index. The range is 0 to 65535.
	etherchannel-info [asic number port number [asic number]]	Display the contents of the EtherChannel information register. The keywords have these meanings:
		• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
		• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.

exception [asic number port number [asic number]]	Display the exception-index register information. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
global-status [asic number port number [asic number]]	Display global and interrupt status. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
learning [asic number port number [asic number]]	Display entries in the learning cache. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
mac-info [asic number port number [asic number]]	Display the contents of the MAC information register. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
mvid [asic number]	Display the mapped VLAN ID table. The keyword has this meaning:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
packet-info-ram [asic number index number [asic number]]	Display the packet information RAM. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• index <i>number</i> —(Optional) Display information for the specified packet RAM index number and ASIC number. The range is 0 to 63.

port-info [asic number port number [asic number]]	Display port information register values. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
prog-parser [asic number port number [asic number]]	Display the programmable parser tables. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
receive { buffer-queue port-fifo	Display receive information. The keywords have these meanings:
<pre>supervisor-sram { [asic number port number [asic number]]</pre>	• buffer-queue —Display the buffer queue information.
port number [asic number]]	• port-fifo —Display the port-FIFO information.
	• supervisor-sram —Display the supervisor static RAM (SRAM) information.
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
<pre>span [vlan-id asic number]</pre>	Display the Switched Port Analyzer (SPAN)-related information. The keywords have these meanings:
	• <i>vlan-id</i> —(Optional) Display information for the specified VLAN. The range is 0 to 1023.
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.

<pre>stack {control dest-map learning messages mvid prog-parser span stats [asic number port number [asic number]]</pre>	 Display stack-related information. The keywords have these meanings: control—Display stack control-status register information. dest-map—Display destination-map information. learning—Display entries in the learning-cache. messages—Display the stack-message register information. mvid—Display entries in the mapped VLAN-ID table. prog-parser—Display the programmable parser tables. span—Display SPAN-related information. stats—Display raw statistics for the port ASIC. asic number—(Optional) Display information for the specified ASIC. The range is 0 to 1.
	port <i>number</i> —(Optional) Display information for the specifie port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
stats {drop enqueue miscellaneous supervisor} [asic	This keyword is supported only on stacking-capable switches. Display raw statistics for the port ASIC. The keywords have the meanings:
number port number [asic number]]	 drop—Display drop statistics.
	• enqueue—Display enqueue statistics.
	• miscellaneous—Display miscellaneous statistics.
	 supervisor—Display supervisor statistics. asic <i>number</i>—(Optional) Display information for the
	specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, wh 0 is the supervisor and 1 to 25 are the ports.
transmit {port-fifo queue	Display transmit information. The keywords have these meaning
<pre>supervisor-sram { [asic number port number [asic number]]</pre>	• port-fifo —Display the contents of the port-FIFO informat register.
	• queue —Display the contents of the queue information register.
	• supervisor-sram—Display supervisor SRAM information
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, when is the supervisor and 1 to 25 are the ports.

vct [asic number port number [asic number]]	Display the VLAN compression table entries for the specified ASIC or for the specified port and ASIC. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
version	Display version and device type information for port ASICs.
l begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform port-security

Use the **show platform port-security** privileged EXEC command to display platform-dependent port-security information.

show platform port-security [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines	You should use this	s command only when you are working directly with your technical support
usaye duluennes	representative while representative asks	e troubleshooting a problem. Do not use this command unless your technical support you to do so.

do not appear, but the lines that contain Output appear.

Cisco Catalyst Blade Switch 3130 and 3032 for Dell Command Reference

show platform qos

Use the **show platform qos** privileged EXEC command to display platform-dependent quality of service (QoS) information.

show platform qos {label asic number | policer { parameters asic number |
 port alloc number asic number} } [| {begin | exclude | include} expression]

Syntax Description	label asic number	Display QoS label maps for the specified ASIC.
oyntax booonption	inder usie number	
		(Optional) For asic <i>number</i> , the range is 0 to 1.
	<pre>policer { parameters asic number port alloc number asic number }</pre>	Display policer information. The keywords have these meanings:
		• parameters asic <i>number</i> —Display parameter information for the specified ASIC. The range is 0 to 1.
		• port alloc <i>number</i> asic <i>number</i> —Display port allocation information for the specified port and ASIC. The port allocation range is 0 to 25. The ASIC range is 0 to 1.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(40)EX1	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform resource-manager

Use the **show platform resource-manager** privileged EXEC command to display platform-dependent resource-manager information.

show platform resource-manager {dm [index number] | erd [index number] |
mad [index number] | med [index number] | mod | msm {hash-table [vlan vlan-id] |
mac-address mac-address [vlan vlan-id]} | sd [index number] |
vld [index number]} [| {begin | exclude | include} expression]

Syntax Description	dm [index number]	Display the destination map. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	erd [index number]	Display the equal-cost-route descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	mad [index number]	Display the MAC-address descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	med [index number]	Display the multi-expansion descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	mod	Display the resource-manager module information.
	msm {hash-table [vlan vlan-id]	Display the MAC-address descriptor table and the station descriptor table information. The keywords have these meanings:
	mac-address mac-address [vlan vlan-id]}	• hash-table [vlan <i>vlan-id</i>]—Display the hash table for all VLANs or the specified VLAN. The range is 1 to 4094.
	vian-ia]}	• mac-address <i>mac-address</i> [vlan <i>vlan-id</i>]—Display the MAC-address descriptor table for the specified MAC address represented by the 48-bit hardware address for all VLANs or the specified VLAN. The range is 1 to 4094.
	sd [index number]	Display the station descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	vld [index number]	Display the VLAN-list descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	

	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines		command only when you are working directly with your technical support e troubleshooting a problem. Do not use this command unless your technical support you to do so

show platform snmp counters

Use the **show platform snmp counters** privileged EXEC command to display platform-dependent Simple Network Management Protocol (SNMP) counter information.

show platform snmp counters [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(40)EX1	This command was introduced.
Usage Guidelines		is command only when you are working directly with your technical support ile troubleshooting a problem. Do not use this command unless your technical support is you to do so.
	Expressions are ca	ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i>

do not appear, but the lines that contain Output appear.

Cisco Catalyst Blade Switch 3130 and 3032 for Dell Command Reference

show platform spanning-tree

Use the show platform spanning-tree privileged EXEC command to display platform-dependent spanning-tree information.

show platform spanning-tree synchronization [detail | vlan vlan-id] [| {begin | exclude | include { expression]

	nchronization etail vlan	Display spanning-tree state synchronization information. The keywords have these meanings:
vla	an-id]	• detail —(Optional) Display detailed spanning-tree information.
		• vlan <i>vlan-id</i> —(Optional) Display VLAN switch spanning-tree information for the specified VLAN. The range is 1 to 4094.
b	oegin	(Optional) Display begins with the line that matches the <i>expression</i> .
le	exclude	(Optional) Display excludes lines that match the expression.
iı	nclude	(Optional) Display includes lines that match the specified expression.
ex	pression	Expression in the output to use as a reference point.

ivileged EXEC

Command History	Release	Modification	
12.2(40)EX1		This command was introduced.	

Usage Guidelines

You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

show platform stp-instance

Use the **show platform stp-instance** privileged EXEC command to display platform-dependent spanning-tree instance information.

show platform stp-instance vlan-id [| {begin | exclude | include} expression]

Syntax Description	vlan-id	Display spanning-tree instance information for the specified VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	I include (Optional) Display includes lines that match the specified <i>expression</i> .	
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
Command History		Modification This command was introduced.
Command History Usage Guidelines	Release 12.2(40)EX1 You should use the	This command was introduced. is command only when you are working directly with your technical support ile troubleshooting a problem. Do not use this command unless your technical support

do not appear, but the lines that contain Output appear.

The command syntax changed from show platform stack-manager to show

show platform stack manager

12.2(50)SE

Use the **show platform stack manager** privileged EXEC command to display platform-dependent switch-stack information.

show platform stack manager {all | counters | trace [sdp [reverse] | state [reverse]]}
[| {begin | exclude | include} expression]

```
Note
```

This command is supported only on stacking-capable switches.

Syntax Description	all	Display all information for the entire switch stack.					
	counters	Display the stack manager counters.					
	trace [sdp [reverse]]	Display trace information. The keywords have these meanings:					
		• sdp—(Optional) Display Stack Discovery Protocol (SDP) information.					
		• reverse —(Optional) Display trace information in reverse chronological order (from recent to older chronological sequence).					
	trace [state [reverse]]	Display trace information. The keywords have these meanings:					
		• state —(Optional) Display stack state machine information.					
		• reverse —(Optional) Display trace information in reverse chronological order (from recent to older chronological sequence).					
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .					
	include	(Optional) Display includes lines that match the specified expression.					
	expression	Expression in the output to use as a reference point.					
Command Modes							
Command Modes	Privileged EXEC						
Command History	Release	Modification					
	12.2(40)EX1	This command was introduced.					

platform stack manager.				
Usage Guidelines	Use this command only when you are working directly with your technical support representative while			

troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

The summary information about the switch stack shows these states:

• Waiting—A switch is booting up and waiting for communication from other switches in the stack. The switch has not yet determined whether or not it is a stack master.

Stack members not participating in a stack master election remain in the waiting state until the stack master is elected and ready.

- Initializing—A switch has determined whether its stack master status. If it is not the stack master, it is receiving its system- and interface-level configuration from the stack master and loading it.
- Ready—The member has completed loading the system- and interface-level configurations and can forward traffic.
- Master Re-Init—The state immediately after a master re-election and a different member is elected master. The new master is re-initializing its configuration. This state applies only to the new master.
- Ver Mismatch—A switch in version mismatch mode. Version-mismatch mode is when a switch joining the stack has a different stack protocol minor version number than the master.

A typical state transition for a stack member (including a stack master) booting up is Waiting -> Initializing -> Ready.

A typical state transition for a stack member to a stack master after an master election is Ready -> Master Re-Init -> Ready.

A typical state transition for a stack member in version mismatch (VM) mode is Waiting -> Ver Mismatch.

Use the **show platform stack ports** privileged EXEC command to display platform-dependent stack information.

show platform stack ports {buffer | history}[| {begin | exclude | include} expression]

show platform stack ports

This command is supported only on stacking-capable switches.

Syntax Description	buffer	Display the stack port link and syr	nc state events.				
	history	Display the stack port history.					
	begin	(Optional) Display begins with the	e line that mate	hes the expr	ression.		
	exclude	(Optional) Display excludes lines	that match the	expression.			
	include	(Optional) Display includes lines that match the specified expression.					
	expression	Expression in the output to use as	a reference poi	nt.			
command Modes	Privileged EXEC						
Command History	Release	Modification					
	12.2(50)SE	This command was introduced.					
Jsage Guidelines		aly when you are working directly with yo blem. Do not use this command unless y					
Usage Guidelines	troubleshooting a pro you to do so. Expressions are case		our technical s	support repr	esentative a		
Usage Guidelines Examples	troubleshooting a proyou to do so. Expressions are case do not appear, but the This is an example o Switch# show platf	oblem. Do not use this command unless y sensitive. For example, if you enter exc	rour technical s lude output , th	ne lines that	esentative a		
-	troubleshooting a pro- you to do so. Expressions are case do not appear, but the This is an example of Switch# show platf Stac ====================================	bblem. Do not use this command unless y sensitive. For example, if you enter l exc e lines that contain <i>Output</i> appear. f the show platform stack port buffer c orm stack ports buffer k Debug Event Data Trace	our technical s lude output, th ommand outpu	ne lines that	esentative		
	troubleshooting a pro- you to do so. Expressions are case do not appear, but the This is an example of Switch# show platf Stac Event type LINK: L Event type RAC: RA Event type SYNC: S Event type SYNC: S Event Stack Count Port	oblem. Do not use this command unless y sensitive. For example, if you enter exc e lines that contain <i>Output</i> appear. f the show platform stack port buffer c orm stack ports buffer k Debug Event Data Trace ink status change C changes to Not OK ync changes to Not OK	our technical s lude output, th ommand outpu	tt:	esentative a		

000000012	1	FF08FF00	860302A5	AA55FFFF	FFFFFFFF	1CE61CE6	Yes/Yes	No cable
000000012	2	FF08FF00	86031805	55AAFFFF	FFFFFFFF	1CE61CE6	Yes/Yes	No cable
Event type:	RAC							
000000013	1	FF08FF00	860302A5	AA55FFFF	FFFFFFFF	1CE61CE6	Yes/Yes	No cable
000000013	2	FF08FF00	86031805	55AAFFFF	FFFFFFFF	1CE61CE6	Yes/Yes	No cable

This is an example of show platform stack ports history command output:

Switch# show platform stack ports history

Switch#/ Port#	Lost Sync Events	# times Link Not OK	# Changes To LinkOK
1/1	0	0	0
1/2	3	4	3
2/1	3	4	3
2/2	0	0	0
3/1	0	0	0
3/2	0	0	0

Cisco Catalyst Blade Switch 3130 and 3032 for Dell Command Reference

show platform tb

Use the **show platform tb** privileged EXEC command to display platform-dependent trusted-boundary information during a stack master change to a new stack master.

show platform tb [| {begin | exclude | include} expression]



This command is supported only on stacking-capable switches.

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .					
	include	(Optional) Display includes lines that match the specified <i>expression</i> .					
	expression						
Command Modes	Privileged EXEC						
Command History	Release	Modification					
-	12.2(40)EX1	This command was introduced.					
Usage Guidelines	representative whi representative ask Expressions are ca	is command only when you are working directly with your technical support ile troubleshooting a problem. Do not use this command unless your technical support is you to do so. ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> it the lines that contain <i>Output</i> appear.					
Examples	This is an example	e of output from the show platform tb command:					
·	Switch# show pla Print TB sub-blo (Fa1/0/2) device	atform tb ock information					
	Current master switch:(Yes) /* Is this switch the current master switch? */						
	New elected master $$:(No) /* Is the master switch-over occurred and this is the new master switch? */						
	Master ready /* Is the Master	:(No) r switch in ready state? */					
	HULC TB process /* Is the TB pla	on :(No) atform process currently running? */					
	CDP stable timer	r ON :(No)(360 secs)					

/* Is the CDP stable timer running? After the CDP stable timer expired, CDP neighbors of all the TB enabled interfaces will be verified to make sure the replacement of IP phone and PC did not happen during the master switch-over. */

Print TB residue trust ports information /* The interfaces with TB enabled right before master switch-over. */

Print port CDP neighbor information
/* Is the CDP message still received after switch-over? */

HULC TB is not detecting CDP events /* Currently, this switch is not detecting any CDP event. */

show platform tcam

Use the **show platform tcam** privileged EXEC command to display platform-dependent hardware memory driver information.

- show platform tcam {handle number | log-results | table { acl | all | equal-cost-route | ipv6 { acl | qos | secondary } local | mac-address | multicast-expansion | qos | secondary | station | vlan-list } | usage } [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | [invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include } expression]
- show platform tcam table acl [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table all [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table equal-cost-route [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table ipv6 {acl | qos | secondary} [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table local [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table mac-address [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table multicast-expansion [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table qos [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table secondary [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table station [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table vlan-list [[asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]

Syntax Description	handle number	Display the hardware memory handle. The range is 0 to 4294967295.		
	log-results	Display the hardware memory log results.		
	table {acl all equal-cost-route ipv6 {acl qos secondary}	Display lookup and forwarding table information. The keywords have these meanings:		
	local mac-address	• acl —Display the access-control list (ACL) table.		
	multicast-expansion qos secondary station vlan-list }	• all —Display all the hardware memory tables.		
	. ,	• equal-cost-route—Display the equal-cost-route table.		
		• ipv6 —Display IPv6 information.		
		- acl—Display the IPv6 ACL-table information.		
		- qos—Display the IPv6 QoS-table information.		
		 secondary—Display the IPv6 secondary-table information. 		
		• local—Display the local table.		
		• mac-address—Display the MAC-address table.		
		• multicast-expansion —Display the IPv6 multicast-expansion table.		
		• qos —Display the QoS table.		
		• secondary —Display the secondary table.		
		• station —Display the station table.		
		• vlan-list —Display the VLAN list table.		
	usage	Display the CAM and forwarding table usage.		
	[[asic number [detail [invalid]]	Display information. The keywords have these meanings:		
	[index number [detail [invalid]] invalid num number [detail [invalid]] invalid] [invalid] [num number [detail [invalid]] invalid]]	• asic <i>number</i> —Display information for the specified ASIC device ID. The range is 0 to 15.		
		• detail [invalid]—(Optional) Display valid or invalid details.		
		• index <i>number</i> —(Optional) Display information for the specified hardware memory table index. The range is 0 to 32768.		
		• num <i>number</i> —(Optional) Display information for the specified hardware memory table number. The range is 0 to 32768.		
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
	include	(Optional) Display includes lines that match the specified <i>expression</i> .		
	expression	Expression in the output to use as a reference point.		



Though visible in the command-line help strings, the **usage** keyword is not supported.

Command Modes	Privileged EXEC		
Command History	Release Modification		
	12.2(40)EX1	This command was introduced.	
Usage Guidelines	representative while representative asks		
	-	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear.	

show platform vlan

Use the **show platform vlan** privileged EXEC command to display platform-dependent VLAN information.

Syntax Description	misc	Display miscellaneous VLAN module information.				
Syntax Description						
	mvid	Display the mapped VLAN ID (MVID) allocation information.				
	prune	Display the stack pruning database on stacking-capable switches. Display the				
		platform-maintained pruning database on nonstacking-capable switches.				
	refcount	Display the VLAN lock module-wise reference counts.				
	rpc {receive	Display remote procedure call (RPC) messages. The keywords have these				
	transmit }	meanings:				
		• receive—Display received information.				
		• transmit —Display sent information.				
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .				
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
	include	(Optional) Display includes lines that match the specified <i>expression</i> .				
	expression	Expression in the output to use as a reference point.				
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.2(40)EX1	This command was introduced.				
Usage Guidelines	representative while representative asks					
	-	e sensitive. For example, if you enter l exclude output , the lines that contain <i>outpu</i> he lines that contain <i>Output</i> appear.				