



CHAPTER 11

I Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See [“About the CLI Command Modes”](#) section on page 1-3 to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

Send documentation comments to mdsfeedback-doc@cisco.com

identity

To configure the identity for the IKE protocol, use the **identity** command in IKE configuration submode. To delete the identity, use the **no** form of the command.

identity {address | hostname}

no identity {address | hostname}

Syntax Description	address	Sets the IKE identity to be the IPv4 address of the switch.
	hostname	Sets the IKE identity to be the host name of the switch.

Defaults None.

Command Modes IKE configuration submode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines To use this command, the IKE protocol must be enabled using the **crypto ike enable** command. Before configuring a certificate for the switch, configure the host name and domain name, and set the identity to be the host name. This allows the certificate to be used for authentication.



Note

The host name is the fully qualified domain name (FQDN) of the switch. To use the switch FQDN for the IKE identity, you must first configure both the switch name and the domain name. The FQDN is required for using RSA signatures for authentication. By default "address" is identified.

Examples The following example shows how to set the IKE identity to the IP address of the switch:

```
switch# config terminal
switch(config)# crypto ike domain ipsec
switch(config-ike-ipsec)# identity address
```

The following example shows how to delete the IKE identity:

```
switch(config-ike-ipsec)# no identity address
```

The following example shows how to set the IKE identity to the host name:

```
switch(config-ike-ipsec)# identity hostname
```

The following example shows how to delete the IKE identity:

```
switch(config-ike-ipsec)# no identity hostname
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	crypto ike domain ipsec	Enters IKE configuration mode.
	crypto ike enable	Enables the IKE protocol.
	show crypto ike domain ipsec	Displays IKE information for the IPsec domain.

Send documentation comments to mdsfeedback-doc@cisco.com

in-order-guarantee

To enable in-order delivery, use the **in-order-guarantee** command in configuration mode. To disable in-order delivery, use the **no** form of the command.

in-order-guarantee [**vsan** *vsan-id*]

no in-order-guarantee [**vsan** *vsan-id*]

Syntax Description	vsan <i>vsan-id</i> (Optional) Specifies a VSAN ID. The range is 1 to 4093.	
Defaults	Disabled.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.3(4)	This command was introduced.
Usage Guidelines	In-order delivery of data frames guarantees frame delivery to a destination in the same order that they were sent by the originator.	
Examples	The following example shows how to enable in-order delivery for the entire switch:	
	<pre>switch# config terminal switch(config) # in-order-guarantee</pre>	
	The following example shows how to disable in-order delivery for the entire switch:	
	<pre>switch(config) # no in-order-guarantee</pre>	
	The following example shows how to enable in-order delivery for a specific VSAN:	
	<pre>switch(config) # in-order-guarantee vsan 3452</pre>	
	The following example shows how to disable in-order delivery for a specific VSAN:	
	<pre>switch(config) # no in-order-guarantee vsan 101</pre>	
Related Commands	Command	Description
	show in-order-guarantee	Displays the in-order-guarantee status.

Send documentation comments to mdsfeedback-doc@cisco.com

initiator

To configure the initiator version and address, use the **initiator** command IKE configuration submode. To revert to the default, use the **no** form of the command.

initiator version *version* **address** *ip-address*

no initiator version *version* **address** *ip-address*

Syntax Description	<i>version</i>	Specifies the protocol version number. The only valid value is 1.
	address <i>ip-address</i>	Specifies the IP address for the IKE peer. The format is <i>A.B.C.D</i> .
Defaults	IKE version 2.	
Command Modes	IKE configuration submode.	
Command History	Release	Modification
	2.0(x)	This command was introduced.
Usage Guidelines	To use this command, the IKE protocol must be enabled using the crypto ike enable command.	
Examples	The following example shows how initiator information for the IKE protocol: switch# config terminal switch(config)# crypto ike domain ipsec switch(config-ike-ipsec)# initiator version 1 address 10.1.1.1	
Related Commands	Command	Description
	crypto ike domain ipsec	Enters IKE configuration mode.
	crypto ike enable	Enables the IKE protocol.
	show crypto ike domain ipsec	Displays IKE information for the IPsec domain.

Send documentation comments to mdsfeedback-doc@cisco.com

install all

To upgrade all modules in any Cisco MDS 9000 family switch, use the **install all** command. This upgrade can happen nondisruptively or disruptively depending on the current configuration of your switch.

```
install all [{asm-sfn file name | kickstart | ssi | system} URL]
```

Syntax Description

asm-sfn <i>filename</i>	(Optional) Upgrades the ASM image.
kickstart	(Optional) Upgrades the kickstart image.
ssi	(Optional) Upgrades the SSI image.
system	(Optional) Upgrades the system image.
<i>URL</i>	(Optional) Specifies the location URL of the source file to be installed.

The following table lists the aliases for *URL*.

bootflash:	Source location for internal bootflash memory.
slot0:	Source location for the CompactFlash memory or PCMCIA card.
volatile:	Source location for the volatile file system.
tftp:	Source location for a Trivial File Transfer Protocol (TFTP) network server. The syntax for this URL is tftp:[<i>//location</i>]/<i>directory</i>]/<i>filename</i> .
ftp:	Source location for a File Transfer Protocol (FTP) network server. The syntax for this URL is ftp:[<i>//location</i>]/<i>directory</i>]/<i>filename</i> .
sftp:	Source location for a Secure Trivial File Transfer Protocol (SFTP) network server. The syntax for this URL is sftp:[<i>//<username>location</i>]/<i>directory</i>]/<i>filename</i> .
scp:	Source location for a Secure Copy Protocol (SCP) network server. The syntax for this URL is scp:[<i>//location</i>]/<i>directory</i>]/<i>filename</i> .
<i>image-filename</i>	The name of the source image file.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
1.0(3)	This command was introduced.
1.2(2)	Added the asm-sfn keyword and made all keywords optional.
2.0(1b)	Added the ssi keyword.

Usage Guidelines

The **install all** command upgrades all modules in any Cisco MDS 9000 Family switch.

Send documentation comments to mdsfeedback-doc@cisco.com



Tip

During a software upgrade to Cisco MDS SAN-OS 3.1(3), all modules that are online are tested and the installation stops if any modules are running with a faulty CompactFlash. When this occurs, the switch can not be upgraded until the situation is corrected. A system message displays the module information and indicates that you must issue the **system health cf-crc-check module** CLI command to troubleshoot.



Caution

If a switchover is required when you issue the **install all** command from a Telnet or SSH session, all open sessions are terminated. If no switchover is required, the session remains unaffected. The software issues a self-explanatory warning at this point and provides the option to continue or terminate the installation.

See the *Cisco MDS 9000 Family CLI Configuration Guide* for detailed procedures.

Examples

The following example displays the result of the **install all** command if the system and kickstart files are specified locally:

```
switch# install all sys bootflash:isan-1.3.1 kickstart bootflash:boot-1.3.1
```

```
Verifying image bootflash:/boot-1.3.1
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:/isan-1.3.1
[#####] 100% -- SUCCESS
```

```
Extracting "slc" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "ips" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "system" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "kickstart" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "loader" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS
```

Compatibility check is done:

Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	disruptive	rolling	Hitless upgrade is not supported
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	

Images will be upgraded according to following table:

Send documentation comments to mdsfeedback-doc@cisco.com

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3 (2a)	1.3 (1)	yes
1	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
2	ips	1.3 (2a)	1.3 (1)	yes
2	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
3	ips	1.3 (2a)	1.3 (1)	yes
3	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
4	slc	1.3 (2a)	1.3 (1)	yes
4	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
5	system	1.3 (2a)	1.3 (1)	yes
5	kickstart	1.3 (2a)	1.3 (1)	yes
5	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
5	loader	1.2 (2)	1.2 (2)	no
6	system	1.3 (2a)	1.3 (1)	yes
6	kickstart	1.3 (2a)	1.3 (1)	yes
6	bios	v1.1.0 (10/24/03)	v1.1.0 (10/24/03)	no
6	loader	1.2 (2)	1.2 (2)	no

```
Do you want to continue with the installation (y/n)? [n] y
```

Install is in progress, please wait.

Syncing image bootflash:/boot-1.3.1 to standby.

```
[#####] 100% -- SUCCESS
```

```
Syncing image bootflash:/isan-1.3.1 to standby.
```

```
[#####] 100% -- SUCCESS
```

```
Jan 18 23:40:03 Hacienda %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from
```

Performing configuration copy.

```
[#####] 100% -- SUCCESS
```

Module 6: Waiting for module online.

1

```
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
```

```
Booting kickstart image: bootflash:/boot-1.3.1....
```

.....Image verification OK

Starting kernel...

```
INIT: version 2.78 booting
```

```
Checking all filesystems..r.r.. done.
```

Loading system software

```
Uncompressing system image: bootflash:/isan-1.3.1
```

[illegible]

CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC

```
INIT: Entering runlevel: 3
```

The following example displays the file output continuation of the **install all** command on the console of the standby supervisor module:

Hacienda (standby) #

```
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
```

```
Booting kickstart image: bootflash:/boot-1.3.1....
```

.....Image verification OK

Starting kernel...

```
INIT: version 2.78 booting
```

```
Checking all filesystems..r.r.. done.
```

Loading system software

```
Uncompressing system image: bootflash:/isan-1.3.1
```

OL-18089-01, Cisco MDS NX-OS Release 4.x

Send documentation comments to mdsfeedback-doc@cisco.com

For scp://user@171.69.16.26, please enter password:

```
Copying image from
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sflek9-kickstart-mz.1.3.2a.bin
to bootflash:///m9500-sflek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Copying image from
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sflek9-mz.1.3.2a.bin to
bootflash:///m9500-sflek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:///m9500-sflek9-kickstart-mz.1.3.2a.bin
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:///m9500-sflek9-mz.1.3.2a.bin
[#####] 100% -- SUCCESS
```

```
Extracting "slc" version from image bootflash:///m9500-sflek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Extracting "ips" version from image bootflash:///m9500-sflek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Extracting "system" version from image bootflash:///m9500-sflek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Extracting "kickstart" version from image
bootflash:///m9500-sflek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

```
Extracting "loader" version from image bootflash:///m9500-sflek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS
```

Compatibility check is done:

Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	non-disruptive	rolling	
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	
7	yes	non-disruptive	rolling	
8	yes	non-disruptive	rolling	
9	yes	disruptive	rolling	Hitless upgrade is not supported

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(1)	1.3(2a)	yes
1	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
2	ips	1.3(1)	1.3(2a)	yes
2	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
3	slc	1.3(1)	1.3(2a)	yes
3	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
4	slc	1.3(1)	1.3(2a)	yes
4	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	system	1.3(1)	1.3(2a)	yes
5	kickstart	1.3(1)	1.3(2a)	yes
5	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no

Send documentation comments to mdsfeedback-doc@cisco.com

```

5      loader                1.2(2)                1.2(2)                no
6      system                1.3(1)                1.3(2a)               yes
6      kickstart             1.3(1)                1.3(2a)               yes
6      bios                  v1.1.0(10/24/03)          v1.0.8(08/07/03)      no
6      loader                1.2(2)                1.2(2)                no
7      slc                   1.3(1)                1.3(2a)               yes
7      bios                  v1.1.0(10/24/03)          v1.0.8(08/07/03)      no
8      slc                   1.3(1)                1.3(2a)               yes
8      bios                  v1.1.0(10/24/03)          v1.0.8(08/07/03)      no
9      ips                   1.3(1)                1.3(2a)               yes
9      bios                  v1.1.0(10/24/03)          v1.0.8(08/07/03)      no

```

Do you want to continue with the installation (y/n)? [n]

Related Commands

Command	Description
install module bios	Upgrades the supervisor or switching module BIOS.
install module loader	Upgrades the bootloader on the active or standby supervisor or modules.
show version	Displays software image version information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

install clock-module

To upgrade the EPLD images of the clock module on a Cisco MDS 9513 Switch Director, use the **install clock-module** command.

install clock-module [epld { bootflash: | slot0: | volatile:}]

Syntax Description	epld	(Optional) Installs the clock module EPLD from the EPLD image.
	bootflash:	(Optional) Specifies the local URI containing EPLD image.
	slot0:	(Optional) Specifies the local URI containing EPLD image.
	volatile:	(Optional) Specifies the local URI containing EPLD image.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines Use this command on the active supervisor to install the standby clock module EPLD from the specified EPLD image. After upgrading the clock module, power cycle the entire chassis for the change to take effect. It is not sufficient to reboot the chassis; you must turn the power off and on.



Note

This command is supported only on the Cisco MDS 9513 Multilayer Switch Director.

Examples The following example upgrades the EPLD images for the clock module:

```
switch# install clock-module epld bootflash:m9000-epld-3.0.0.278.img
Len 3031343, CS 0x58, string MDS series EPLD image, built on Fri Nov 11 01:11:09 2005
EPLD Curr Ver New Ver
-----
Clock Controller 0x03 0x04
There are some newer versions of EPLDs in the image!
Do you want to continue (y/n) ? y
Proceeding to program Clock Module B.
Do you want to switchover Clock Modules after programming Clock Module B.
System Will Reset! y/n) ?n
|
Clock Module B EPLD upgrade is successful.
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands

Command	Description
<code>show version clock-module epld</code>	Displays the current EPLD versions on the clock module.

Send documentation comments to mdsfeedback-doc@cisco.com

install license

To program the supervisor or switching module BIOS, use the **install license** command.

install license [**bootflash:** | **slot0:** | **volatile:**] *file-name*

Syntax Description	bootflash:	(Optional) Specifies the source location for the license file.
	slot0:	(Optional) Specifies the source location for the license file.
	volatile:	(Optional) Specifies the source location for the license file.
	<i>file-name</i>	Specifies the name of the license file.

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.2(1)	This command was introduced.

Usage Guidelines	If a target filename is provided after the source URL, the license file is installed with that name. Otherwise, the filename in the source URL is used. This command also verifies the license file before installing it.
-------------------------	---

Examples	The following example installs a file named license-file which resides in the bootflash: directory: <pre>switch# install license bootflash:license-file</pre>
-----------------	---

Related Commands	Command	Description
	show license	Displays license information.

Send documentation comments to mdsfeedback-doc@cisco.com

install module bios

To program the supervisor or switching module BIOS, use the **install module bios** command.

install module *module-number* **bios** [**system** [**bootflash:** | **slot0:** | **volatile:** | *system-image*]]

Syntax Description	<i>module-number</i>	Specifies the module number from slot 1 to 9 in a Cisco MDS 9500 Series switch.
		Specifies the module number from slot 1 to 2 in a Cisco MDS 9200 Series switch.
	system	(Optional) Specifies the system image to use (optional). If system is not specified, the current running image is used.
	bootflash:	(Optional) Specifies the source location for internal bootflash memory
	slot0:	(Optional) Specifies the source location for the CompactFlash memory or PCMCIA card.
	volatile:	(Optional) Specifies the source location for the volatile file system.
	<i>system-image</i>	Specifies the name of the system or kickstart image.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	1.0(3)	This command was introduced.

Usage Guidelines

If the BIOS is upgraded, you need to reboot to make the new BIOS effective. You can schedule the reboot at a convenient time so traffic will not be impacted.

The console baud rate automatically reverts to the default rate (9600) after any BIOS upgrade.

The URL is always the system image URL in the supervisor module, and points to the bootflash: or slot0: directories.

Examples The following example shows how to perform a nondisruptive upgrade for the system:

```
switch# install module 1 bios
Started bios programming .... please wait
###
BIOS upgrade succeeded for module 1
```

In this example, the switching module in slot 1 was updated.

Send documentation comments to mdsfeedback-doc@cisco.com

install module epld

To upgrade the electrically programmable logical devices (EPLDs) module, use the **install module epld** command. This command is only for supervisor modules, not switching modules.

install module *module-number* **epld** [**bootflash:** | **ftp:** | **scp:** | **sftp:** | **tftp:** | **volatile:**]

Syntax Description

<i>module-number</i>	Enters the number for the standby supervisor modules or any other line card.
bootflash:	(Optional) Specifies the source location for internal bootflash memory.
ftp	(Optional) Specifies the local/remote URI containing EPLD image.
scp	(Optional) Specifies the local/remote URI containing EPLD image.
sftp	(Optional) Specifies the local/remote URI containing EPLD image.
tftp	(Optional) Specifies the local/remote URI containing EPLD image.
volatile:	(Optional) Specifies the source location for the volatile file system.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
1.2(1)	This command was introduced.

Usage Guidelines

Issue this command from the active supervisor module to update any other module.

If you forcefully upgrade a module that is not online, all EPLDs are forcefully upgraded. If the module is not present in the switch, an error is returned. If the module is present, the command process continues.

Do not insert or extract any modules while an EPLD upgrade or downgrade is in progress.

Examples

The following example upgrades the EPLDs for the module in slot 2:

```
switch# install module 2 epld scp://user@10.6.16.22/users/dino/epld.img
```

```
The authenticity of host '10.6.16.22' can't be established.
RSA1 key fingerprint is 55:2e:1f:0b:18:76:24:02:c2:3b:62:dc:9b:6b:7f:b7.
Are you sure you want to continue connecting (yes/no)? yes
Warning: Permanently added '10.6.16.22' (RSA1) to the list of known hosts.
user@10.6.16.22's password:
epld.img                               100% |*****| 1269 KB    00:00
```

```
Module Number                2
EPLD                        Curr Ver    New Ver
-----
Power Manager                0x06
XBUS IO                      0x07      0x08
```

Send documentation comments to mdsfeedback-doc@cisco.com

```

UD chip Fix                                0x05
Sahara                                    0x05      0x05

Module 2 will be powered down now!!
Do you want to continue (y/n) ? y
\ <-----progress twirl
Module 2 EPLD upgrade is successful

```

The following example forcefully upgrades the EPLDs for the module in slot 2:

```

switch# install module 2 epld scp://user@10.6.16.22/epld-img-file-path

Module 2 is not online, Do you want to continue (y/n) ? y
cchetty@171.69.16.22's password:
epld.img                                100% |*****| 1269 KB    00:00
\ <-----progress twirl
Module 2 EPLD upgrade is successful

```

Related Commands

Command	Description
show version epld	Displays the available EPLD versions.
show version module <i>number</i> epld	Displays the current EPLD versions.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

install module loader

To upgrade the bootloader on either the active or standby supervisor module, use the **install module loader** command. This command is only for supervisor modules, not switching modules.

install module *module-number* **loader kickstart** [**bootflash:** | **slot0:** | **volatile:** | *kickstart-image*]

Syntax Description	<i>module-number</i>	Enters the module number for the active or standby supervisor modules (only slot 5 or 6).
	kickstart	Specifies the kickstart image to use.
	bootflash:	(Optional) Specifies the source location for internal bootflash memory
	slot0:	(Optional) Specifies the source location for the CompactFlash memory or PCMCIA card.
	volatile:	(Optional) Specifies the source location for the volatile file system.
	<i>kickstart-image</i>	Specifies the name of the kickstart image.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	1.0(3)	This command was introduced.

Usage Guidelines

Before issuing the **install module loader** command, be sure to read the release notes to verify compatibility issues between the boot loader and the kickstart or system images.

If you install a loader version that is the same as the currently installed version, the loader will not be upgraded. When both the current version and the installed version are the same, use the **init system** command to force a loader upgrade.

Examples

The following example shows how to perform a non disruptive upgrade for the system:

```
switch# install module 6 loader bootflash:kickstart_image
```

This example displays the command being issued on the standby supervisor module in slot 6.

Related Commands	Command	Description
	show version	Verify the output before and after the upgrade.

Send documentation comments to mdsfeedback-doc@cisco.com

install ssi

To perform a nondisruptive upgrade of the SSI image on an SSM, use the **install ssi** command.

```
install ssi { bootflash: | slot0: | modflash: } file-name module slot
```

Syntax Description

bootflash:	Specifies the source location for the SSI boot image file.
slot0:	Specifies the source location for the SSI boot image file.
modflash:	Specifies the source location for the SSI boot image file.
<i>file-name</i>	Specifies the SSI boot image filename.
module <i>slot</i>	Specifies the module slot number.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
2.1(2)	This command was introduced.

Usage Guidelines

You can use the **install ssi** command to upgrade or downgrade the SSI boot image if the SSM is only configured for Fibre Channel switching. If your SSM is configured for VSFN or Intelligent Storage Services, you must use the **boot** command to reconfigure the SSI boot variable and reload the module.

The **install ssi** command implicitly sets the SSI boot variable.



Note

The SSM must be running EPLD version 2.1(2) to use the **install ssi** command. You must install the SSM on a Cisco MDS 9500 Series switch to update the EPLD.



Note

The **install ssi** command does not support files located on the SSM modflash.

Examples

The following example installs the SSI boot image on the module in slot 2:

```
switch# install ssi bootflash:lm9000-ek9-ssi-mz.2.1.2.bin module 2
```

Related Commands

Command	Description
boot	Configures the boot variables.
show boot	Displays the current contents of boot variables.
show module	Verifies the status of a module.

Send documentation comments to mdsfeedback-doc@cisco.com

interface

To configure an interface on the Cisco MDS 9000 Family of switches, use the **interface** command in configuration mode.

interface { **cpp** | **fc** | **fc-tunnel** | **fcip** | **gigabitethernet** | **iscsi** | **mgmt** | **port-channel** | **svc** | **vsan** }



Note

On a Cisco Fabric Switch for HP c-Class BladeSystem and on a Cisco Fabric Switch for IBM BladeCenter, the syntax differs as follows:

interface [**bay port** | **ext port**]

Syntax Description

bay port ext port	(Optional) Configures a a Fibre Channel interface on a port on a Cisco Fabric Switch for HP c-Class BladeSystem or on a Cisco Fabric Switch for IBM BladeCenter. The range is 0 to 48.
cpp	Configures a Control Plane Process (CPP) interface.
fc	(Optional) Configures a Fiber Channel interface on an MDS 9000 Family switch (see the interface fc command).
fc-tunnel	Configures a Fiber Channel link interface (see the interface fc-tunnel command).
fcip	Configures a Fibre Channel over IP (FCIP) interface (see the interface fcip command).
gigabitethernet	Configures a Gigabit Ethernet interface (see the interface gigabitethernet command).
iscsi	Configures an iSCSI interface (see the interface iscsi command).
mgmt	Configures a management interface (see the interface mgmt command).
port-channel	Configures a PortChannel interface (see the interface port-channel command).
svc	Configures a SAN Volume Controller (SVC) interface for the Caching Services Module (CSM) (see the interface svc command).
vsan	Configures a VSAN interface (see the interface vsan command).

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
1.0(2)	This command was introduced.
3.1(2)	Added the bay port option.

Send documentation comments to mdsfeedback-doc@cisco.com**Usage Guidelines**

You can specify a range of interfaces by issuing a command with the following example format:

interface fc1/1 - 5 , fc2/5 - 7

The spaces are required before and after the dash (-) and before and after the comma (,).

Examples

The following example selects the mgmt 0 interface and enters interface configuration submode:

```
switch# config terminal  
switch(config)# interface mgmt 0
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface bay | ext

To configure a Fibre Channel interface on a Cisco Fabric Switch for HP c-Class BladeSystem and on a Cisco Fabric Switch for IBM BladeCenter, use the **interface bay** or **interface ext** command in configuration mode.

```
interface {bay port | ext port}
```

Syntax Description	bay port ext port Configures a Fibre Channel interface on a port. The range is 0 to 48.	
Defaults	Disabled.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	3.1(2)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example configures Fibre Channel interface bay2 and enters interface configuration submenu: <pre>switch# config terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)# int bay 2 switch(config-if)#</pre>	
Related Commands	Command	Description
	show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface fc

To configure a Fibre Channel interface on the Cisco MDS 9000 Family of switches, use the **interface fc** command in EXEC mode. To revert to defaults, use the **no** form of the command.

```
interface fc slot/port channel-group {group-id [force] | auto} fcdomain rcf-reject vsan vsan-id
fspf {cost link-cost vsan vsan-id | ficon portnumber portnumber | dead-interval seconds vsan
vsan-id | hello-interval seconds vsan vsan-id | passive vsan vsan-id | retransmit-interval
seconds vsan vsan-id}
```

```
no interface fc slot/port channel-group {group-id [force] | auto} fcdomain rcf-reject vsan
vsan-id fspf {cost link_cost vsan vsan-id | ficon portnumber portnumber | dead-interval
seconds vsan vsan-id | hello-interval seconds vsan vsan-id | passive vsan vsan-id |
retransmit-interval seconds vsan vsan-id}
```

Syntax Description

<i>slot/port</i>	Specifies a slot number and port number.
channel-group	Adds to or removes from a PortChannel.
<i>group-id</i>	Specifies a PortChannel group number from 1 to 128.
force	(Optional) Forcefully adds a port.
auto	Enables autocreation of PortChannels.
fcdomain	Enters the interface submenu.
rcf-reject	Configures the rcf-reject flag.
vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
fspf	Configures FSPF parameters.
cost <i>link-cost</i>	Configures FSPF link cost. The range is 1 to 65535.
portnumber <i>portnumber</i>	Configures the FICON port number for this interface.
dead-interval <i>seconds</i>	Configures FSPF dead interval in seconds. The range is 2 to 65535.
ficon	Configures FICON parameters.
hello-interval <i>seconds</i>	Configures FSPF hello-interval. The range is 1 to 65535.
passive	Enables or disables FSPF on the interface.
retransmit-interval <i>seconds</i>	Configures FSPF retransmit interface in seconds. The range is 1 to 65535.

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
1.0(2)	This command was introduced.
2.0(x)	Added the auto option to the channel-group keyword.

Send documentation comments to mdsfeedback-doc@cisco.com

Usage Guidelines

You can specify a range of interfaces by issuing a command with the following example format.

interface*space***fc1/1***space-space5**space,space***fc2/5***space-space7*

Refer to the *Cisco MDS 9000 Family CLI Configuration Guide* for information on port number allocation.

Use the **no shutdown** command to enable the interface.

The **channel-group auto** command enables autocreation of port channels. If autocreation of port channels is enabled for an interface, you must first disable this configuration before downgrading to earlier software versions or before configuring the interface in a manually configured channel group.

Examples

The following example configures ports 1 to 4 in Fibre Channel interface 9:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# int fc9/1 - 4
```

The following example enables the Fibre Channel interface:

```
switch# config terminal
switch(config)# interface fc1/1
switch(config-if)# no shutdown
```

The following example assigns the FICON port number to the selected Fibre Channel interface:

```
switch# config terminal
switch(config)# interface fc1/1
switch(config-if)# ficon portnumber 15
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.
shutdown	Disables and enables an interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface fc-tunnel

To configure a Fibre Channel tunnel and facilitate RSPAN traffic, use the **interface fc-tunnel** command. To remove a configured tunnel or revert to factory defaults, use the **no** form of the command.

interface fc-tunnel *number* **destination** *ip-address* [**explicit-path** *path-name* **source** *ip-address*]

no interface fc-tunnel *number* **destination** *ip-address* [**explicit-path** *path-name* **source** *ip-address*]

Syntax Description

<i>number</i>	Specifies a tunnel ID range from 1 to 255.
destination <i>ip-address</i>	Maps the IP address of the destination switch.
explicit-path <i>path-name</i>	Specifies a name for the explicit path. Maximum length is 16 alphanumeric characters.
source <i>ip-address</i>	Maps the IP address of the source switch.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
1.2(1)	This command was introduced.

Usage Guidelines

None.

Examples

The following example initiates the FC tunnel (100) in the source switch (switch S):

```
switch(config)# config terminal
switch(config)# interface fc-tunnel 100
switch(config-if)#
```

The following example maps the IP address of the source switch (switch S) to the FC tunnel (100):

```
switchS(config-if)# source 209.165.200.226
```

The following example maps the IP address of the destination switch (switch D) to the FC tunnel (100):

```
switch(config-if)# destination 209.165.200.227
```

The following example enables traffic flow through this interface:

```
switch(config-if)# no shutdown
```

The following example references the configured path in the source switch (switch S):

```
switch# config t
switch(config)# interface fc-tunnel 100
switch(config)# explicit-path Path1
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	fc-tunnel explicit-path	Configures a new or existing next-hop path.
	show interface fc-tunnel	Displays an FC tunnel interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface fcip

To configure a Fibre Channel over IP Protocol (FCIP) interface, use the **interface fcip** command. To disable a FCIP interface, use the **no** form of the command.

interface fcip *interface_number* **bport bport-keepalives channel-group** *number* [**force**] **fcdomain rcf-reject vsan** *vsan-id* **ficon portnumber** *portnumber* **fspf** {**cost** *link-cost* | **dead-interval** *seconds* | **hello-interval** *seconds* | **passive** | **retransmit-interval** *seconds*} **vsan** *vsan-id* **passive-mode peer-info ipaddr** *ip-address* [**port** *number*] **qos control** *control-value* **data** *data-value* **special-frame peer-wwn** *pwwn-id* **tcp-connections** *number* **time-stamp** [**acceptable-diff** *number*] **use-profile** *profile-id*

no interface fcip *interface_number* **bport bport-keepalives channel-group** *number* [**force**] **fcdomain rcf-reject vsan** *vsan-id* **ficon portnumber** *portnumber* **fspf** {**cost** *link-cost* | **dead-interval** *seconds* | **hello-interval** *seconds* | **passive** | **retransmit-interval** *seconds*} **vsan** *vsan-id* **qos control-value** *data* *data-value* **passive-mode peer-info ipaddr** *ip-address* [**port** *number*] **special-frame peer-wwn** *pwwn-id* **tcp-connections** *number* **time-stamp** [**acceptable-diff** *number*] **use-profile** *profile-id*

Syntax Description

<i>interface-number</i>	Configures the specified interface from 1 to 255.
bport	Sets the B port mode.
bport-keepalives	Sets the B port keepalive responses.
channel-group <i>number</i>	Specifies a PortChannel number from 1 to 128.
force	(Optional) Forcefully adds a port.
fcdomain	Enters the fcdomain mode for this FCIP interface
rcf-reject	Configures the rcf-reject flag.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.
ficon	Configures FICON parameters.
portnumber <i>portnumber</i>	Configures the FICON port number for this interface.
fspf	Configures FSPF parameters.
cost <i>link-cost</i>	Enters FSPF link cost. The range is 1 to 65535
dead-interval <i>seconds</i>	Specifies the dead interval in seconds. The range is 1 to 65535.
hello-interval <i>seconds</i>	Specifies FSPF hello-interval in seconds. The range is 1 to 65535.
passive	Enables or disables FSPF on the interface.
retransmit-interval	Specifies FSPF retransmit interface in seconds. The range is 1 to 65535.
passive-mode	Configures a passive connection.
peer-info	Configures the peer information.
ipaddr <i>ip-address</i>	Specifies the peer IP address.
port <i>number</i>	(Optional) Specifies the peer port number. The range is 1 to 65535.
qos	Configures the differentiated services code point (DSCP) value to mark all IP packets.
control <i>control-value</i>	Specifies the control value for DSCP.
data <i>data-value</i>	Specifies the data value for DSCP.
special-frame	Configures special frames.

Send documentation comments to mdsfeedback-doc@cisco.com

peer-wwn <i>pwwn-id</i>	Specifies the peer WWN for special frames.
switchport	Configures switchport parameters.
tcp-connections <i>number</i>	Specifies the number of TCP connection attempts. Valid values are 1 or 2.
time-stamp	Configures the time stamp.
acceptable-diff <i>number</i>	(Optional) Specifies the acceptable time difference for time stamps. The range is 1 to 60000.
use-profile <i>profile-id</i>	Specifies the interface using an existing profile ID. The range is 1 to 255.

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
1.1(1)	This command was introduced.
1.3(1)	Added the ficon portnumber subcommand.
2.0(x)	Added the qos subcommand.

Usage Guidelines

You can specify a range of interfaces by issuing a command with the following example format:

interface fcip*1space-space5space,spacefcip10space-space12space*

Refer to the *Cisco MDS 9000 Family CLI Configuration Guide* for information on port number allocation.

Examples

The following example selects an FCIP interface and enters interface configuration submode:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface fcip 1
switch(config-if)#
```

The following example assigns the FICON port number to the selected FCIP interface:

```
switch# config terminal
switch(config)# interface fcip 51
switch(config-if)# ficon portnumber 234
```

Related Commands

Command	Description
show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface gigabitethernet

To configure an Gigabit Ethernet interface, use the **interface gigabitethernet** command. To revert to the default values, use the **no** form of the command.

interface gigabitethernet *slot/port* **cdp enable** **channel-group** *group-id* [**force**] **isns** *profile-name*

no interface gigabitethernet *slot/port* **cdp enable** **channel-group** **isns** *profile-name*

Syntax Description		
<i>slot/port</i>		Specifies a slot number and port number.
cdp enable		Enables Cisco Discovery Protocol (CDP) configuration parameters.
channel-group <i>group-id</i>		Adds to or removes from a PortChannel. The range is 1 to 128.
force		(Optional) Forcefully adds a port.
isns <i>profile-name</i>		Specifies the profile name to tag the interface. Maximum length is 64 characters.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	1.0(3a)	This command was introduced.
	1.1(1a)	Added the channel-group subcommand.
	1.3(1)	Added the isns subcommand.

Usage Guidelines You can specify a range of interfaces by issuing a command with the following example format:
interface gigabitethernet*1/1space-space2space,spacegigabitethernet3/1space-space2*

Examples The following example configures the Gigabit Ethernet interface at slot 4 port 1:

```
switch# config terminal
switch(config)# interface gigabitethernet 4/1
switch(config-if)#
```

The following example enters a IP address and subnet mask for the selected Gigabit Ethernet interface:

```
switch(config-if)# ip address 209.165.200.226 255.255.255.0
```

The following example changes the IP maximum transmission unit (MTU) value for the selected Gigabit Ethernet interface:

```
switch(config-if)# switchport mtu 3000
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following example creates a VR ID for the selected Gigabit Ethernet interface, configures the virtual IP address for the VR ID (VRRP group), and assigns a priority:

```
switch(config-if)# vrrp 100
switch(config-if-vrrp)# address 209.165.200.226
switch(config-if-vrrp)# priority 10
```

The following example adds the selected Gigabit Ethernet interface to a channel group. If the channel group does not exist, it is created, and the port is shut down:

```
switch(config-if)# channel-group 10
gigabitethernet 4/1 added to port-channel 10 and disabled
please do the same operation on the switch at the other end of the port-channel, then do
"no shutdown" at both ends to bring them up
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface iscsi

To configure an iSCSI interface, use the **interface iscsi** command. To revert to default values, use the **no** form of the command.

interface iscsi *slot/port* **mode** { **pass-thru** | **store-and-forward** } **tcp qos** *value*

no interface iscsi *slot/port* **mode** { **pass-thru** | **store-and-forward** | **cut-thru** } **tcp qos** *value*

<i>slot/port</i>	Specifies a slot number and port number.
mode	Configures a forwarding mode.
pass-thru	Forwards one frame at a time.
store-and-forward	Forwards data in one assembled unit (default).
cut-thru	Forwards one frame at a time without waiting for the exchange to complete.
tcp qos <i>value</i>	Configures the differentiated services code point (DSCP) value to apply to all outgoing IP packets. The range is 0 to 63.

Defaults

Disabled.
The TCP QoS default is 0.
The forwarding mode default is **store-and-forward**.

Command Modes

Configuration mode.

Command History

Release	Modification
1.3(1)	This command was introduced.
2.1(1)	Added the cut-thru option for the mode subcommand.

Usage Guidelines

To configure iSCSI interface, enable iSCSI using the **iscsi enable** command.
You can specify a range of interfaces by issuing a command with the following example format:
interface iscsi *space* *fc1/1space-space5space,spacefc2/5space-space7*

Examples

The following example enables the iSCSI feature:

```
switch# config t
switch(config)# iscsi enable
```

The following example enables the store-and-forward mode for iSCSI interfaces 9/1 to 9/4:

```
switch(config)# interface iscsi 9/1 - 4
switch(config-if)# mode store-and-forward
```

The following example reverts to using the default pass-thru mode for iSCSI interface 9/1:

```
switch(config)# interface iscsi 9/1
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config-if)# mode pass-thru
```

Related Commands

Command	Description
iscsi enable	Enables iSCSI.
show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface mgmt

To configure a management interface, use the **interface mgmt** command in configuration mode.

interface mgmt *number*

Syntax Description	<i>number</i>	Specifies the management interface number which is 0.
--------------------	---------------	---

Defaults	Disabled.
----------	-----------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	When you try to shut down a management interface(mgmt0), a follow-up message confirms your action before performing the operation. Use the force option to bypass this confirmation, if required.
------------------	--

Examples	The following example configures the management interface, displays the options available for the configured interface, and exits to configuration mode:
----------	--

```
switch# config terminal
switch(config)#
switch(config)# interface mgmt 0
switch(config-if)# exit
switch(config)#
```

The following example shuts down the interface without using the **force** option:

```
switch# config terminal
switch(config)# interface mgmt 0
switch(config-if)# shutdown
Shutting down this interface will drop all telnet sessions.
Do you wish to continue (y/n)? y
```

The following example shuts down the interface using the **force** option:

```
switch# config terminal
switch(config)# interface mgmt 0
switch(config-if)# shutdown force
switch(config-if)#
```

Related Commands	Command	Description
	show interface mgmt	Displays interface configuration for specified interface.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

interface port-channel

To configure a PortChannel interface on the Cisco MDS 9000 Family of switches, use the **interface port-channel** command.

```
interface port-channel number channel mode active fcdomain rcf-reject vsan vsan-id fspf [cost
link_cost | dead-interval seconds | ficon portnumber portnumber | hello-interval seconds |
isns profile-name | passive | retransmit-interval seconds]
```

```
no interface port-channel number channel mode active fcdomain rcf-reject vsan vsan-id fspf
[cost link_cost | dead-interval seconds | ficon portnumber portnumber | hello-interval
seconds | isns profile-name | passive | retransmit-interval seconds]
```

```
no interface port-channel number
```

Syntax Description

<i>number</i>	Specifies the PortChannel number. The range is 1 to 128.
channel mode active	Configures the channel mode for the PortChannel interface.
fcdomain	Specifies the interface submenu.
rcf-reject	Configure the rcf-reject flag.
vsan	Specifies the vsan range.
<i>vsan-id</i>	Specifies the ID of the VSAN is from 1 to 4093.
fspf	Configure the FSPF parameters.
cost	(Optional) Configure the FSPF link cost.
<i>link_cost</i>	Specifies the FSPF link cost which is 1-65535.
dead-interval	(Optional) Configure the FSPF dead interval.
<i>seconds</i>	Specifies the dead interval (in seconds) from 2-65535.
ficon	(Optional) Configures the FICON parameters.
portnumber <i>portnumber</i>	(Optional) Configures the FICON port number for this interface.
hello-interval	(Optional) Configure FSPF hello-interval.
<i>seconds</i>	Specifies the hello interval (in seconds) from 1-65535.
isns	Tags this interface to the Internet Storage Name Service (iSNS) profile.
<i>profile-name</i>	Specifies the profile name to tag the interface.
passive	Enable/disable FSPF on the interface.
retransmit-interval	(Optional) Configure FSPF retransmit interface.
<i>seconds</i>	Specifies the retransmit interval (in seconds) from 1-65535.

Defaults

Disabled.

Command Modes

Configuration mode.

Send documentation comments to mdsfeedback-doc@cisco.com

Command History	Release	Modification
	1.0(2)	This command was introduced.
	1.3(1)	Added channel mode active subcommand.

Usage Guidelines Refer to the *Cisco MDS 9000 Family CLI Configuration Guide* for information on port number allocation.

Examples The following example enters configuration mode and configures a PortChannel interface:

```
switch# config terminal
switch(config)# interface port-channel 32
switch(config-if)#
```

The following example assigns the FICON port number to the selected PortChannel port:

```
switch# config terminal
switch(config)# interface Port-channel 1
switch(config-if)# ficon portnumber 234
```

Related Commands	Command	Description
	show interface	Displays interface configuration for specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

interface sme

To configure the Cisco SME interface on a switch, use the **interface sme** command. To remove the interface, use the **no** form of the command,

interface sme *slot /port*

no interface sme *slot /port*

Syntax Description

<i>slot</i>	Identifies the number of the MPS-18/4 module slot.
<i>port</i>	Identifies the number of the Cisco SME port.

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
3.2(2)	This command was introduced.

Usage Guidelines

To use this command, clustering must be enabled using the **cluster enable** command and Cisco SME services must be activated using the **sme enable** command.

Once you have configured the interface, use the **no shutdown** command to enable the interface.

To delete the Cisco SME interface, you must first remove the switch from the cluster. Use the **no sme cluster** command to remove the switch from the cluster and then use the **no interface** command to delete the interface.

The interface commands are available in the (**config-if**) submode.

Examples

The following example configures and enables the Cisco SME interface on the MPS-18/4 module slot and the default Cisco SME port:

```
switch# config terminal
switch(config)# interface sme 3/1
switch(config-if)# no shutdown
```

Related Commands

Command	Description
show interface sme	Displays interface information.
shutdown	Enables or disables an interface.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

interface sme (Cisco SME cluster node configuration submode)

To add Cisco SME interface from a local or a remote switch to a cluster, use the **interface sme** command. To delete the interface, use the **no** form of the command.

interface sme (*slot/port*) [**force**]

no interface sme (*slot/port*) [**force**]

Syntax Description

<i>slot</i>	Identifies the MPS-18/4 module slot.
<i>port</i>	Identifies the Cisco SME port.
force	(Optional) Forcibly clears the previous interface context in the interface.

Defaults

Disabled.

Command Modes

Cisco SME cluster node configuration submode.

Command History

Release	Modification
3.2(2)	This command was introduced.

Usage Guidelines

You have to first configure a node using the **fabric-membership** command before this command can be executed.

To use this command, clustering must be enabled using the **cluster enable** command and Cisco SME services must be activated using the **sme enable** command.

To delete the Cisco SME interface, first remove the switch from the cluster. Use the **no sme cluster** command to remove the switch from the cluster and then use the **no interface** command to delete the interface.

Examples

The following example specifies the fabric to which the node belongs and then adds the Cisco SME interface (4/1) from a local switch using the **force** option:

```
switch# config t
switch(config)# sme cluster clustername1
switch(config-sme-cl)# node local
switch(config-sme-cl-node)# fabric-membership f1
switch(config-sme-cl-node)# interface sme 4/1 fabric sw-xyz
```

The following example specifies the fabric to which the node belongs and then adds the Cisco SME interface (4/1) from a remote switch using the **force** option:

```
switch# config t
switch(config)# sme cluster clustername1
switch(config-sme-cl)# node 171.71.23.33
switch(config-sme-cl-node)# fabric-membership f1
switch(config-sme-cl-node)# interface sme 4/1 fabric sw-xyz
```

 interface sme (Cisco SME cluster node configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands

Command	Description
fabric-membership	Adds the node to a fabric.
show interface	Displays Cisco SME interface details.

Send documentation comments to mdsfeedback-doc@cisco.com

interface vsan

To configure a VSAN interface, use the **interface vsan** command. To remove a VSAN interface, use the **no** form of the command.

interface vsan *vsan-id*

no interface vsan *vsan-id*

Syntax Description	<i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
--------------------	----------------	--

Defaults	Disabled.
----------	-----------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	None.
------------------	-------

Examples	The following example selects a VSAN interface and enters interface configuration submode:
----------	--

```
switch# config terminal
switch(config)# interface vsan 1
switch(config-if)#
```

Related Commands	Command	Description
	show interface	Displays interface configuration for specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com

ip access-group

To apply an access list to an interface, use the **ip access-group** command in interface mode. Use the **no** form of this command to negate a previously issued command or revert to factory defaults.

ip access-group *access-list-name* [**in** | **out**]

Syntax Description	<i>access-list-name</i>	Specifies the IP access list name. The maximum length is 64 alphanumeric characters and the text is case insensitive.
	in	(Optional) Specifies that the group is for ingress traffic.
	out	(Optional) Specifies that the group is for egress traffic.

Defaults The access list is applied to both ingress and egress traffic.

Command Modes Interface mode.

Command History	Release	Modification
	1.2(1)	This command was introduced.

Usage Guidelines

The **ip access-group** command controls access to an interface. Each interface can only be associated with one access list. The access group becomes active immediately.

We recommend creating all rules in an access list, before creating the access group that uses that access list.

If you create an access group before an access list, the access list is created and all packets in that interface are dropped, because the access list is empty.

The access-group configuration for the ingress traffic applies to both local and remote traffic. The access-group configuration for the egress traffic applies only to local traffic. You can apply a different access list for each type of traffic.

Examples The following example creates an access group called aclPermit for both the ingress and egress traffic (default):

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermit permit ip any any
switch(config)# interface GigabitEthernet 3/1
switch(config-if)# ip access-group aclPermit
```

The following example deletes the access group called aclPermit:

```
switch(config-if)# no ip access-group aclPermit
```

The following example creates an access group called aclDenyTcp (if it does not already exist) for ingress traffic:

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# ip access-list aclDenyTcp deny tcp any any  
switch(config)# interface gigabitethernet 3/1  
switch(config-if)# ip access-group aclDenyTcp in
```

The following example deletes the access group called aclDenyTcp for ingress traffic:

```
switch(config-if)# no ip access-group aclDenyTcp in
```

The following example creates an access list called aclPermitUdp (if it does not already exist) for local egress traffic:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# ip access-list aclPermitUdp permit udp 192.168.32.0 0.0.7.255 any  
switch(config)# interface gigabitethernet 3/1  
switch(config-if)# ip access-group aclPermitUdp out
```

The following example removes the access list called aclPermitUdp for local egress traffic:

```
switch(config-if)# no ip access-group aclPermitUdp out
```

Related Commands

Command	Description
ip access-list	Configures IP access control lists.
show ip access-list	Displays the IP-ACL configuration information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ip access-list

To configure IP access control lists (ACLs), use the **ip access-list** command in configuration mode. To negate a previously issued command or revert to factory defaults, use the **no** form of the command.

ip access-list *list-name* {**deny** | **permit**} *ip-protocol* {*src-addr src-wildcard*} {*dest-addr dest-wildcard* | *operator port-value*} [*operator port port-value*] [**established** | **icmp-type** *icmp-value*] [**tos** *tos-value*] [**log-deny**]

no ip access-list *list-name* {**deny** | **permit**} *ip-protocol* {*src-addr src-wildcard*} {*dest-addr dest-wildcard* | *operator port-value*} [*operator port port-value*] [**established** | **icmp-type** *icmp-value*] [**tos** *tos-value*] [**log-deny**]

Syntax Description

<i>list-name</i>	Configures an access list with this name. The maximum length is 64 characters.
deny	Denies access if the conditions match.
permit	Allows access if the conditions match.
<i>ip-protocol</i>	Specifies the name or number (integer range from 0 to 255) of an IP protocol. The IP protocol name can be icmp , ip , tcp , or udp .
<i>src-addr</i>	Specifies the network from which the packet is sent. There are two ways to specify the source: - A 32-bit quantity in four-part, dotted-decimal format - A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>src-wildcard</i>	Applies the wildcard bits to the source. Each wildcard bit set to zero indicates that the corresponding bit position in the packet's IP address must exactly match the bit value in the corresponding position of the packet's ip address or it will not be considered a match to this access list. There are two ways to specify the destination wildcard: - A 32-bit quantity in four-part, dotted-decimal format - A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>dest-addr</i>	Specifies the network from which the packet is sent. There are two ways to specify the destination: - A 32-bit quantity in four-part, dotted-decimal format - A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>dest-wildcard</i>	Applies the wildcard bits to the destination. There are two ways to specify the destination wildcard: - A 32-bit quantity in four-part, dotted-decimal format - A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255

Send documentation comments to mdsfeedback-doc@cisco.com

<i>operator</i>	Compares source or destination ports to the packet and has the following options: any = Any destination IP eq = Equal source port gt = Greater than and including source port lt = Less than and including source port range port = Source port range <i>port-value</i>
port <i>port-value</i>	Specifies the decimal number (ranging from 0 to 65535) or one of the following names to indicate a TCP or UDP port. The TCP port names are dns, ftp, ftp-data, http, ntp, radius, sftp, smtp, snmp, snmp-trap, ssh, syslog, tacacs-ds, telnet, wbem-http, wbem-https, and www. The UDP port names are dns, ftp, ftp-data, http, ntp, radius, sftp, smtp, snmp, snmp-trap, ssh, syslog, tacacs-ds, telnet, tftp, wbem-http, wbem-https, and www.
icmp-type <i>icmp-value</i>	(Optional) Filters ICMP packets by ICMP message type. The range is 0 to 255. The types include echo, echo-reply, redirect, time-exceeded, traceroute, and unreachable.
established	(Optional) Indicates an established connection for the TCP protocol. A match occurs if the TCP datagram has the ACK, FIN, PSH, RST, SYN or URG control bits set. The non matching case is that of the initial TCP datagram to form a connection.
tos <i>tos-value</i>	(Optional) Filters packets by the following type of service level: normal-service (0), monetary-cost (1), reliability (2), throughput (4), and delay (8).
log-deny	(Optional) Sends an information logging message to the console about the packet that is denied entry.

Defaults

Denied.

Command Modes

Configuration mode.

Command History

Release	Modification
4.1(1b)	Added a note information for the usage section.
1.2(1)	This command was introduced.

Usage Guidelines

Using the **log-deny** option at the end of the individual ACL entries shows the ACL number and whether the packet was permitted or denied, in addition to port-specific information. This option causes an information logging message about the packet that matches the dropped entry (or entries).

Examples

The following example configures the an IP-ACL called `aclPermit` and permits IP traffic from any source address to any destination address:

```
switch# config terminal
```

Send documentation comments to mdsfeedback-doc@cisco.com

Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# **ip access-list aclPermit permit ip any any**

The following example removes the IP-ACL called aclPermit:

```
switch(config-if)# no ip access-group aclPermit
```

The following example updates aclPermit to deny TCP traffic from any source address to any destination address:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# ip access-list aclPermit deny tcp any any
```

The following example defines an IP-ACL that permits this network. Subtracting 255.255.248.0 (normal mask) from 255.255.255.255 yields 0.0.7.255:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# ip access-list aclPermitUdp permit udp 192.168.32.0 0.0.7.255 any
```

The following example permits all IP traffic from and to the specified networks:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# ip access-list aclPermitIpToServer permit ip 10.1.1.0 0.0.0.255 172.16.1.0 0.0.0.255
```

The following example denies TCP traffic from 1.2.3.0 through source port 5 to any destination:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/  
switch(config)# ip access-list aclDenyTcpIpPrt5 deny tcp 1.2.3.0 0.0.0.255 eq port 5 any
```

The following example removes this entry from the IP-ACL:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/  
switch(config)# no ip access-list aclDenyTcpIpPrt5 deny tcp 1.2.3.0 0.0.0.255 eq port 5 any
```

Related Commands

Command	Description
show ip access-list	Displays the IP-ACL configuration information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ip address (FCIP profile configuration submode)

To assign the local IP address of a Gigabit Ethernet interface to the FCIP profile, use the **ip address** command. To remove the IP address, use the **no** form of the command.

ip address *address*

no ip address *address*

Syntax Description	<i>address</i>	Specifies the IP address.
--------------------	----------------	---------------------------

Defaults	Disabled.
----------	-----------

Command Modes	FCIP profile configuration submode.
---------------	-------------------------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	To create a FCIP profile, you must assign a local IP address of a Gigabit Ethernet interface to the FCIP profile.
------------------	---

Examples	The following example assigns the local IP address of a Gigabit Ethernet interface to the FCIP profile:
----------	---

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile)# ip address 209.165.200.226
```

Related Commands	Command	Description
	interface fcip interface_number use-profile profile-id	Configures the interface using an existing profile ID from 1 to 255.
	show fcip profile	Displays information about the FCIP profile.
	interface fcip interface_number use-profile profile-id	Configures the interface using an existing profile ID from 1 to 255.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ip address (interface configuration)

To assign an IP address to a Gigabit Ethernet interface, use the **ip address** command in interface configuration submode. To remove the IP address, use the **no** form of the command.

ip address *address netmask*

no ip address *address netmask*

Syntax Description	<i>address</i>	Specifies the IP address.
	<i>netmask</i>	Specifies the network mask.
Defaults	None.	
Command Modes	Interface configuration submode.	
Command History	Release	Modification
	1.1(2)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example assigns an IP address to a Gigabit Ethernet interface:	
	<pre>switch# config terminal switch(config)# interface gigabitethernet 1/2 switch(config-profile)# ip address 10.5.1.1 255.255.0.0</pre>	
Related Commands	Command	Description
	interface fcip interface_number use-profile profile-id	Configures the interface using an existing profile ID from 1 to 255.
	show fcip profile	Displays information about the FCIP profile.
	show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com

ip-compression

To enable compression on the FCIP link, use the **ip-compression** command in interface configuration submode. To disable compression, use the **no** form of the command.

ip-compression [**auto** | **mode1** | **mode2** | **mode3**]

no ip-compression [**auto** | **mode1** | **mode2** | **mode3**]

Syntax Description	
auto	(Optional) Enables the automatic compression setting.
mode1	(Optional) Enables fast compression for the following high bandwidth links: PS-4 and IPS-8, less than 100 Mbps MPS-14/2, up to 1 Gbps
mode2	(Optional) Enables moderate compression for medium bandwidth links less than 25 Mbps.
mode3	(Optional) Enables compression for bandwidth links less than 10 Mbps.

Defaults	Disabled.
----------	-----------

Command Modes	Interface configuration submode.
---------------	----------------------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.
	2.0(x)	Changed the keywords from high-throughput and high-comp-ratio to mode1 , mode2 , and mode3 .

Usage Guidelines	When no compression mode is entered in the command, the default is auto .
------------------	--

The FCIP compression feature introduced in Cisco SAN-OS Release 1.3 allows IP packets to be compressed on the FCIP link if this feature is enabled on that link. By default the FCIP compression is disabled. When enabled, the software defaults to using the auto mode (if a mode is not specified).

With Cisco SAN-OS Release 2.0(1b) and later, you can configure FCIP compression using one of the following modes:

- **mode1** is a fast compression mode for high bandwidth links (> 25 Mbps).
- **mode2** is a moderate compression mode for moderately low bandwidth links (between 10 and 25 Mbps).
- **mode3** is a high compression mode for low bandwidth links (< 10 Mbps).
- **auto** (default) mode determines the appropriate compression scheme based on the bandwidth of the link (the bandwidth of the link configured in the FCIP profile's TCP parameters).

Send documentation comments to mdsfeedback-doc@cisco.com

The IP compression feature behavior differs between the IPS module(s) and the MPS-14/2 module. While **mode2** and **mode3** perform software compression in both modules, **mode1** performs hardware-based compression in MPS-14/2 modules, and software compression in IPS-4 and IPS-8 modules.

In Cisco MDS SAN-OS Release 2.1(1a) and later, the **auto** mode option uses a combination of compression modes to effectively utilize the WAN bandwidth. The compression modes change dynamically to maximize the WAN bandwidth utilization.

Examples

The following example enables faster compression:

```
switch# config terminal
switch(config) interface fcip 1
switch(config-if) # ip-compression mode1
```

The following example enables automatic compression by default:

```
switch(config-if) # ip-compression
```

The following example disables compression:

```
switch(config-if) # no ip-compression
```

Related Commands

Command	Description
show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com

ip default-gateway

To configure the IP address of the default gateway, use the **ip default-gateway** command. To disable the IP address of the default gateway, use the **no** form of the command.

ip default-gateway *destination-ip-address* [**interface** **cpp** *slot_number*/*processor-number*/*vsan-id*]

no ip default-gateway *destination-ip-address* [**interface** **cpp** *slot*/*processor-number*/*vsan-id*]

Syntax Description	
<i>destination-ip-address</i>	Specifies the IP address,
interface	(Optional) Configures an interface.
cpp	(Optional) Specifies a virtualization IPFC interface.
<i>slot</i>	(Optional) Specifies a slot number of the ASM.
<i>processor-number</i>	(Optional) Specifies the processor number for the IPFC interface. The current processor number is always 1.
<i>vsan-id</i>	(Optional) Specifies the ID of the management VSAN. The range 1 to 4093.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines None.

Examples The following example configures the IP default gateway to 1.1.1.4:

```
switch# config terminal
switch(config)# ip default-gateway 1.1.1.4
```

Related Commands	Command	Description
	show ip route	Displays the IP address of the default gateway.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ip default-network

To configure the IP address of the default network, use the **ip default-network** command in configuration mode. To disable the IP address of the default network, use the **no** form of the command.

ip default-network *ip-address*

no ip default-network *ip-address*

Syntax Description	<i>ip-address</i> Specifies the IP address of the default network.	
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.0(2)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example configures the IP address of the default network to 1.1.1.4:	
	<pre>switch# config terminal switch(config)# ip default-network 209.165.200.226 switch(config)# ip default-gateway 209.165.200.227</pre>	
Related Commands	Command	Description
	show ip route	Displays the IP address of the default gateway.

Send documentation comments to mdsfeedback-doc@cisco.com

ip domain-list

To configure the IP domain list, use the **ip domain-list** command in configuration mode. To disable the IP domain list, use the **no** form of the command.

ip domain-list *domain-name*

no ip domain-list *domain-name*

Syntax Description	<i>domain-name</i>	Specifies the domain name for the IP domain list. Maximum length is 80 characters.
--------------------	--------------------	--

Defaults	None.
----------	-------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	None.
------------------	-------

Examples The following example configures the IP domain list:

```
switch# config terminal
switch(config)# ip domain MyList
```

Related Commands	Command	Description
	show ip route	Displays the IP address of the default gateway.

Send documentation comments to mdsfeedback-doc@cisco.com

ip domain-lookup

To enable the DNS server lookup feature, use the **ip domain-lookup** command in configuration mode. Use the **no** form of this command to disable this feature.

ip domain-lookup

no ip domain-lookup

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	Instead of IP addresses, you can configure the switch using meaningful names. The configured name automatically looks up the corresponding IP address.
-------------------------	--

Examples	The following example configures a DNS server lookup feature:
-----------------	---

```
switch# config terminal
switch(config)# ip domain-lookup
```

Related Commands	Command	Description
	show ip route	Displays the IP address of the default gateway.

Send documentation comments to mdsfeedback-doc@cisco.com

ip domain-name

To configure a domain name, use the **ip domain-name** command in configuration mode. To delete a domain name, use the **no** form of the command.

ip domain-name *domain-name*

no ip domain-name *domain-name*

Syntax Description

<i>domain-name</i>	Specifies the domain name.
--------------------	----------------------------

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
1.0(2)	This command was introduced.

Usage Guidelines

None.

Examples

The following example configures a domain name:

```
switch# config terminal
switch(config)# ip domain-name MyDomain
```

Related Commands

Command	Description
show ip route	Displays the IP address of the default gateway.

Send documentation comments to mdsfeedback-doc@cisco.com

ip name-server

To configure a name server, use the **ip name-server** command in configuration mode. To disable this feature, use the **no** form of the command.

ip name-server *ip-address*

no ip name-server *ip-address*

Syntax Description	<i>ip-address</i>	Specifies the IP address for the name server.
---------------------------	-------------------	---

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	You can configure a maximum of six servers. By default, no server is configured.
-------------------------	--

Examples	The following example configure a name server with an IP address of 1.1.1.4:
	<pre>switch# config terminal switch(config)# ip name-server 209.165.200.226</pre>
	The following example specifies the first address (15.1.0.1) as the primary server and the second address (15.2.0.0) as the secondary sever:
	<pre>switch(config)# ip name-server 209.165.200.226 209.165.200.227</pre>
	The following example deletes the configured server(s) and reverts to factory default:
	<pre>switch(config)# no ip name-server</pre>

Related Commands	Command	Description
	show ip route	Displays the IP address of the default gateway.

Send documentation comments to mdsfeedback-doc@cisco.com

ip route

To configure a static route, use the **ip route** command in configuration mode.

ip route *ip-address subnet-mask* [*nexthop_ip-address*] [**interface** {**gigabitethernet** *slot /port* | **mgmt 0** | **port-channel** *channel-id* | **vsan** *vsan-id*} | **distance** *distance-number*]

no ip route *ip-address subnet-mask* [*nexthop_ip-address*] [**interface** {**gigabitethernet** *slot /port* | **mgmt 0** | **port-channel** *channel-id* | **vsan** *vsan-id*} | **distance** *distance-number*]

Syntax Description

<i>ip-address</i>	Specifies the IP address for the route.
<i>subnet-mask</i>	Specifies the subnet mask for the route.
<i>nexthop_ip-address</i>	(Optional) Specifies the IP address of the next hop switch.
interface	(Optional) Configures the interface associated with the route.
gigabitethernet <i>slot /port</i>	Specifies a Gigabit Ethernet interface at a port and slot.
mgmt 0	Specifies the management interface (mgmt 0).
port-channel <i>channel-id</i>	Specifies a PortChannel interface. The range is 1 to 128.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.
distance <i>distance-number</i>	(Optional) Specifies the distance metric for this route. It can be from 0 to 32766.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
1.0(2)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to configure a static route:

```
switch# config terminal
switch(config)# IP route 10.0.0.0 255.0.0.0 20.20.20.10 distance 10 interface vsan 1
```

Related Commands

Command	Description
show ip route	Displays the IP address routes configured in the system.

Send documentation comments to mdsfeedback-doc@cisco.com

ip routing

To enable the IP forwarding feature, use the **ip routing** command in configuration mode. To disable this feature, use the **no** form of the command.

ip routing

no ip routing

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example enables the IP forwarding feature:
-----------------	--

```
switch# config terminal
switch(config)# ip routing
```

Related Commands	Command	Description
	show ip routing	Displays the IP routing state.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim delay-ms

To delay packets that arrive at a specified Gigabit Ethernet interface specifying milliseconds, use the **ips netsim delay** command in SAN extension tuner configuration submode.

ips netsim delay-ms *milliseconds* **ingress** **gigabitethernet** *slot/port*

Syntax Description	<i>milliseconds</i>	Specifies the delay in milliseconds. The range is 0 to 150.
	ingress	Specifies the ingress direction.
	gigabitethernet	Specifies the the slot and port number of the Gigabit Ethernet interface.
	<i>slot/port</i>	

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command. This command introduces a delay for all packets entering the Gigabit Ethernet interface. Delay is unidirectional. To introduce delay in the opposite direction, use the slot and port number of the adjacent interface.

Examples The following example shows how to configure a delay of 50 milliseconds for packets entering Gigabit Ethernet interface 2/3:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim delay-ms 50 ingress gigabitethernet 2/3
```

Related Commands	Command	Description
	ips netsim enable	Enables the IP Network Simulator.
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim delay-us

To delay packets that arrive at a specified Gigabit Ethernet interface specifying microseconds, use the **ips netsim delay** command in SAN extension tuner configuration submode.

ips netsim delay-us *microseconds* **ingress** **gigabitethernet** *slot/port*

Syntax Description	<i>microseconds</i>	Specifies the delay in microseconds. The range is 0 to 150000.
	ingress	Specifies the ingress direction.
	gigabitethernet	Specifies the the slot and port number of the Gigabit Ethernet interface.
	<i>slot/port</i>	

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command. This command introduces a delay for all packets entering the Gigabit Ethernet interface. Delay is unidirectional. To introduce delay in the opposite direction, use the slot and port number of the adjacent interface.

Examples The following example shows how to configure a delay of 50 microseconds for packets entering Gigabit Ethernet interface 2/3:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim delay-us 50 ingress gigabitethernet 2/3
```

Related Commands	Command	Description
	ips netsim enable	Enables the IP Network Simulator.
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim drop nth

To drop packets every nth packet at a specified Gigabit Ethernet interface, use the **ips netsim drop nth** command in SAN extension tuner configuration submode.

ips netsim drop nth *packet* {**burst** *burst-size* **ingress** **gigabitethernet** *slot/port* | **ingress** **gigabitethernet** *slot/port*}

Syntax Description	
<i>packet</i>	Specifies a specific packet to drop. The range is 0 to 10,000.
burst <i>burst-size</i>	Specifies the packet burst size. The range is 1 to 100.
ingress	Specifies the ingress direction.
gigabitethernet <i>slot/ port</i>	Specifies the the slot and port number of the Gigabit Ethernet interface.

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines

To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command. You can configure the IP Network Simulator to simulate packet drops (even when the queue is not full) randomly (specified as a percentage) or every Nth packet. Percentage is represented as the number of packets in 10,000. For example, if you want to drop one percent of packets, then specify it as 100 packets in 10,000. To simulate a realistic scenario for IP networks using random drops, the drop percentage should be between zero and one percent of packet drops in the specified traffic direction.

If you use the optional burst parameter, then a specified number of packets are dropped. If you do not specify the burst parameter, then only one packet is dropped. The burst limit for either random or Nth drops is 1 to 100 packets. Take the burst parameter into account when specifying the percentage of packets dropped. For example, if you select a random drop of 100 packets in 10,000 (or one percent) with a burst of 2, 200 packets (or two percent) in every 10,000 packets are dropped. Specifying 2 for burst doubles the packet drop.

Examples The following example shows how to configure an interface to drop every 100th packet, 2 packets at a time:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim drop nth 100 burst 2 ingress gigabitethernet 2/3
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	ips netsim enable	Enables the IP Network Simulator.
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim drop random

To drop packets randomly at a specified Gigabit Ethernet interface, use the **ips netsim drop random** command in SAN extension tuner configuration submode.

ips netsim drop random *packet-percentage* {**burst** *burst-size* **ingress** **gigabitethernet** *slot/port* | **ingress** **gigabitethernet** *slot/port*}

Syntax Description	
<i>packet-percentage</i>	Specifies the percentage of packets dropped. The range is 0 to 10000.
burst <i>burst-size</i>	Specifies the packet burst size. The range is 1 to 100.
ingress	Specifies the ingress direction.
gigabitethernet <i>slot/ port</i>	Specifies the the slot and port number of the Gigabit Ethernet interface.

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command. You can configure the IP Network Simulator to simulate packet drops (even when the queue is not full) randomly (specified as a percentage) or every Nth packet. Percentage is represented as the number of packets in 10,000. For example, if you want to drop one percent of packets, then specify it as 100 packets in 10,000. To simulate a realistic scenario for IP networks using random drops, the drop percentage should be between zero and one percent of packet drops in the specified traffic direction.

If you use the optional burst parameter, then a specified number of packets are dropped. If you do not specify the burst parameter, then only one packet is dropped. The burst limit for either random or Nth drops is 1 to 100 packets. Take the burst parameter into account when specifying the percentage of packets dropped. For example, if you select a random drop of 100 packets in 10,000 (or one percent) with a burst of 2, 200 packets (or two percent) in every 10,000 packets are dropped. Specifying 2 for burst doubles the packet drop.

Examples The following example shows how to configure an interface to drop one percent of packets:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim drop random 100 burst 1 ingress gigabitethernet 2/3
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.
	ips netsim enable	Enables the IP Network Simulator.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim enable

To enable two Gigabit Ethernet interfaces to operate in the network simulation mode, enter the **ips netsim enable** command in SAN extension tuner configuration submode. To disable this feature, use the **no** form of the command.

ips netsim enable interface gigabitethernet *slot/port* gigabitethernet *slot/port*

no ips netsim enable interface gigabitethernet *slot/port* gigabitethernet *slot/port*

Syntax Description

interface	Specifies that interfaces are enabled.
gigabitethernet <i>slot/port</i>	Specifies the the slot and port number of the Gigabit Ethernet interface.

Defaults

Disabled.

Command Modes

SAN extension tuner configuration submode.

Command History

Release	Modification
3.1(1)	This command was introduced.

Usage Guidelines

This command enables two Gigabit Ethernet interfaces to simulate network characteristics. The first interface specified is the ingress port and the second interface specified is the egress port. Ports must be adjacent and the ingress interface must be an odd-numbered port.

Interfaces configured with this command can no longer be used for FCIP or iSCSI. When the SAN extension tuner configuration submode is turned off, any interface configured for network simulation reverts back to normal operation.

Examples

The following example enables the IP Network Simulator and configures interfaces 2/3 and 2/4 for network simulation:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim enable interface gigabitethernet 2/3 gigabitethernet 2/4
```

Related Commands

Command	Description
show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim max-bandwidth-kbps

To limit the bandwidth in kilobytes per second of a specified Gigabit Ethernet interface, use the **ips netsim max-bandwidth-kbps** command in SAN extension tuner configuration submode.

ips netsim max-bandwidth-kbps *bandwidth* **ingress** **gigabitethernet** *slot/port*

Syntax Description

<i>bandwidth</i>	Specifies the bandwidth in kilobytes per second. The range is 1000 to 1000000.
ingress	Specifies the ingress direction.
gigabitethernet <i>slot/port</i>	Specifies the the slot and port number of the Gigabit Ethernet interface.

Defaults

Disabled.

Command Modes

SAN extension tuner configuration submode.

Command History

Release	Modification
3.1(1)	This command was introduced.

Usage Guidelines

To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command.

Examples

The following example shows how to limit the interface bandwidth to 4500 Kbps:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim max-bandwidth-kbps 4500 ingress gigabitethernet 2/3
```

Related Commands

Command	Description
ips netsim enable	Enables the IP Network Simulator.
show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim max-bandwidth-mbps

To limit the bandwidth in megabytes per second of a specified Gigabit Ethernet interface, use the **ips netsim max-bandwidth-mbps** command in SAN extension tuner configuration submode.

ips netsim max-bandwidth-mbps *bandwidth* **ingress** **gigabitethernet** *slot/port*

Syntax Description	<i>bandwidth</i>	Specifies the bandwidth in megabytes per second. The range is 1 to 1000.
	ingress	Specifies the ingress direction.
	gigabitethernet	Specifies the the slot and port number of the Gigabit Ethernet interface.
	<i>slot/port</i>	

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command.

Examples The following example shows how to limit the interface bandwidth to 45 Mbps:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim max-bandwidth-mbps 45 ingress gigabitethernet 2/3
```

Related Commands	Command	Description
	ips netsim enable	Enables the IP Network Simulator.
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim qsize

To limit the size of the queue on a specified Gigabit Ethernet interface, use the **ips netsim qsize** command in SAN extension tuner configuration submode.

ips netsim qsize *queue-size* **ingress** **gigabitethernet** *slot/port*

Syntax Description	<i>queue-size</i>	Specifies the queue size. The range is 0 to 1000000.
	ingress	Specifies the ingress direction.
	gigabitethernet	Specifies the the slot and port number of the Gigabit Ethernet interface.
	<i>slot/ port</i>	

Defaults Disabled.

Command Modes SAN extension tuner configuration submode.

Command History	Release	Modification
	3.1(1)	This command was introduced.

Usage Guidelines To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command. This command rate limits the size of the queue on a specified Gigabit Ethernet port. The recommended queue size for network simulation is 50000 to 150000. If the queue becomes full, packets are dropped.

Examples The following example shows how to limit the queue size to 75 KB:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim qsize 75 ingress gigabitethernet 2/3
```

Related Commands	Command	Description
	ips netsim enable	Enables the IP Network Simulator.
	show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ips netsim reorder

To reorder packets entering a specified Gigabit Ethernet interface, use the **ips netsim reorder** command in SAN extension tuner configuration submode.

```
ips netsim reorder {nth packet distance dist-packet ingress gigabitethernet slot/port | nth packet
ingress gigabitethernet slot/port} | {random percent distance dist-packet ingress
gigabitethernet slot/port | random percent ingress gigabitethernet slot/port}
```

Syntax Description

nth packet	Specifies a specific packet reordered. The range is 0 to 10,000.
distance <i>dist-packet</i>	Specifies the distance between the packet to be reordered and the packet at the head of the queue. The range is 1 to 10.
ingress	Specifies the ingress direction.
gigabitethernet <i>slot/port</i>	Specifies the the slot and port number of the Gigabit Ethernet interface.
random percent	Specifies the percentage of packets passed before a reorder. The range is 0 to 10,000.

Defaults

Disabled.

Command Modes

SAN extension tuner configuration submode.

Command History

Release	Modification
3.1(1)	This command was introduced.

Usage Guidelines

To use this command, you must enable the IP Network Simulator using the **ips netsim enable** command.

You can configure network simulator to reorder packets (even when the queue is not full) randomly (specified as a percentage) or every Nth packet. Percentage is represented as the number of packets in 10,000. For example, if you want to reorder one percent of packets, then specify it as 100 packets in 10,000. To simulate a realistic scenario for IP networks using random reordering, the percentage should be between zero and one percent of packet reordered in the specified traffic direction.

If you use the optional burst parameter, then the specified number of packets will be reordered. If you do not specify the burst parameter, then only one packet is reordered.

Examples

The following example shows reordering at 50 percent with a distance limit of 5:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim reorder random 50 distance 5 ingress gigabitethernet 2/3
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following example shows reordering of every 50th packet with a distance limit of 5:

```
switch# config terminal
switch(config)#
switch(config)# san-ext-tuner enable
switch(config)# exit
switch#
switch# ips netsim reorder nth 50 distance 5 ingress gigabitethernet 2/3
```

Related Commands

Command	Description
ips netsim enable	Enables the IP Network Simulator.
show ips netsim	Displays a summary of the interfaces that are currently operating in network simulation mode.

Send documentation comments to mdsfeedback-doc@cisco.com

ipv6 access-list

To configure an IPv6 access control list (ACL) and enter IPv6-ACL configuration submode, use the **ipv6 access-list** command in configuration mode. To discard an IPv6 ACL, use the **no** form of the command.

ipv6 access-list *list-name*

no ipv6 access-list *list-name*

Syntax Description	<i>list-name</i>	Specifies an IP access control list name. The maximum size is 64.
--------------------	------------------	---

Defaults	None.
----------	-------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	Before using the ipv6 access-list command to configure an IPv6 ACL on a switch, become familiar with the features of IPv6 and its extended addressing capabilities. In particular, it is important to understand the different types of IPv6 address formats, the IPv6 address prefix format, and the different IPv6 address types. For detailed information about IPv6, refer to the <i>Cisco MDS 9000 Family CLI Configuration Guide</i> .
------------------	---

Examples	The following example configures an IPv6 access list called List1 and enters IPv6-ACL configuration submode:
----------	--

```
switch # config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config) # ipv6 access-list List1
switch(config-ipv6-acl) #
```

The following example removes the IPv6 access list called List1 and all of its entries:

```
switch(config) # no ipv6 access-list List1
switch(config) #
```

Related Commands	ipv6 route	Configures an IPv6 static route.
	ipv6 routing	Enables IPv6 unicast routing.
	show ipv6 access-list	Displays a summary of ACLs.
	show ipv6 route	Displays the IPv6 static routes configured on the switch.
	show ipv6 routing	Displays the IPv6 unicast routing configured on the switch.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ipv6 address

To enable IPv6 processing and configure an IPv6 address on the interface, use the **ipv6 address** command in interface configuration submode. To remove an IPv6 address, use the **no** form of the command.

ipv6 address *ipv6-address-prefix*

no ipv6 address *ipv6-address-prefix*

Syntax Description	<i>ipv6-address-prefix</i> Specifies the IPv6 address prefix. The format is <i>X:X:X::X/n</i> .	
Defaults	None.	
Command Modes	Interface configuration submode.	
Command History	Release	Modification
	3.0(1)	This command was introduced.
Usage Guidelines	You can use the ipv6 address command to enable IPv6 processing and configure the IPv6 address on the interface. An IPv6 address must be configured on an interface for the interface to forward IPv6 traffic. Assigning a unicast address generates a link local address and implicitly enables IPv6.	
 Note	The <i>ipv6-address-prefix</i> argument in the ipv6 address command must be in the form documented in RFC 2373, where the address is specified in hexadecimal using 16-bit values between colons. A slash mark (/) precedes a decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address).	
Examples	The following example assigns a unicast IPv6 address to the interface and enables IPv6 processing on the interface: <pre>switch# config terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)# interface gigabitethernet 2/2 switch(config-if)# ipv6 address 2001:0DB8:800:200C::417A/64</pre>	
Related Commands	ipv6 address autoconfig	Enables automatic configuration of IPv6 addresses using stateless autoconfiguration on an interface and enables IPv6 processing on the interface.
	ipv6 enable	Enables IPv6 processing on the interface.

Send documentation comments to mdsfeedback-doc@cisco.com

ipv6 nd	Configures IPv6 neighbor discovery commands on the interface.
ipv6 traffic-filter	Configures IPv6 ACLs to filter traffic for packets on the interface.
show interface	Displays interface configuration information.

Send documentation comments to mdsfeedback-doc@cisco.com

ipv6 address autoconfig

To enable automatic configuration of IPv6 addresses using stateless autoconfiguration on an interface and enable IPv6 processing on the interface, use the **ipv6 address autoconfig** command in interface configuration submode. To remove the address from the interface, use the **no** form of the command.

ipv6 address autoconfig

no ipv6 address autoconfig

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Interface configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	You can use the ipv6 address autoconfig command to enable IPv6 stateless autoconfiguration on the specified interface. For additional information about autoconfiguration, refer to the <i>Cisco MDS 9000 Family CLI Configuration Guide</i> .
-------------------------	---

Examples	The following example assigns enables IPv6 stateless autoconfiguration on the interface:
-----------------	--

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface gigabitethernet 2/2
switch(config-if)# ipv6 address autoconfig
```

Related Commands	ipv6 address	Enables IPv6 processing and configures an IPv6 address on an interface.
	ipv6 enable	Enables IPv6 processing on the interface.
	ipv6 nd	Configures IPv6 neighbor discovery commands on the interface.
	ipv6 traffic-filter	Configures IPv6 ACLs to filter traffic for packets on the interface.
	show interface	Displays interface configuration information.

Send documentation comments to mdsfeedback-doc@cisco.com

ipv6 enable

To enable IPv6 processing and configure an IPv6 link-local address on the interface, use the **ipv6 enable** command in interface configuration submode. To disable IPv6 processing and remove the link-local address, use the **no** form of the command.

ipv6 enable

no ipv6 enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Interface configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	When you enable IPv6 on an interface, a link local address is automatically assigned. This address is used for communication on the switch:
-------------------------	---

Examples	The following example enables IPv6 processing on the interface.
-----------------	---

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# interface gigabitethernet 2/2  
switch(config-if)# ipv6 enable
```

The following example disables IPv6 processing on the interface.

```
switch(config-if)# no ipv6 enable
```

Related Commands	ipv6 address	Configures the IPv6 address and enables IPv6 processing.
	ipv6 nd	Configures IPv6 neighbor discovery commands on the interface.
	ipv6 traffic-filter	Configures IPv6 ACLs to filter traffic for packets on the interface.
	show interface	Displays interface configuration information.

Send documentation comments to mdsfeedback-doc@cisco.com

ipv6 nd

To configure IPv6 neighbor discovery commands on the interface, use the **ipv6 nd** command in interface configuration submode. To remove IPv6 neighbor discovery configuration commands, use the **no** form of the command.

ipv6 nd {**dad attempts** *number* | **reachable-time** *time* | **retransmission-time** *time*}

no ipv6 nd {**dad attempts** *number* | **reachable-time** *time* | **retransmission-time** *time*}

Syntax Description

dad attempts <i>number</i>	Configures duplicate address detection (DAD) attempts. The range is 0 to 15.
reachable-time <i>time</i>	Configures reachability time. Specifies the reachability time in milliseconds. The range is 1000 to 3600000.
retransmission-time <i>time</i>	Configures the retransmission timer. Specifies the retransmission time in milliseconds. The range is 1000 to 3600000.

Defaults

DAD attempts: 0.

Reachable-time: 30000 milliseconds.

Retransmission-time: 1000 milliseconds.

Command Modes

Interface configuration submode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

A router must be able to determine the link-local address for each of its neighboring routers in order to ensure that the target address (the final destination) in a redirect message identifies the neighbor router by its link-local address. For static routing, the address of the next-hop router should be specified using the link-local address of the router; for dynamic routing, all IPv6 routing protocols must exchange the link-local addresses of neighboring routers.



Note

A high number of DAD attempts (greater than 2) can delay address assignment.

For complete information about IPv6 neighbor discovery, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

Examples

The following example sets the duplicate address detection attempts count to 2:

```
switch# config terminal
switch(config)# interface gigabitethernet 2/2
switch(config-if)# ipv6 nd dad attempts 2
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following example sets the reachability time to 10000 milliseconds:

```
switch(config-if)# ipv6 nd reachability-time 10000
```

The following example sets the retransmission time to 20000 milliseconds:

```
switch(config-if)# ipv6 nd retransmission-time 20000
```

Related Commands

ipv6 address	Configures the IPv6 address and enables IPv6 processing.
ipv6 enable	Enables IPv6 processing on the interface.
ipv6 traffic-filter	Configures IPv6 ACLs to filter traffic for packets on the interface.
show interface	Displays interface configuration information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ipv6 route

To configure an IPv6 static route, use the **ipv6 route** command in configuration mode. To remove or disable an IPv6 static route, use the **no** form of the command.

ipv6 route *destination-address-prefix next-hop-address* [**distance** *distance-metric* | **interface** {**gigabitethernet** *slot/port* | **mgmt** *number* | **port-channel** *number* | **vsan** *vsan-id*}] [**distance** *distance-metric*]

no ipv6 route *destination-address-prefix next-hop-address* [**distance** *distance-metric* | **interface** {**gigabitethernet** *slot/port* | **mgmt** *number* | **port-channel** *number* | **vsan** *vsan-id*}] [**distance** *distance-metric*]

Syntax Description

<i>destination-address-prefix</i>	Specifies the IPv6 destination address prefix. The format is <i>X:X:X:X/n</i> .
<i>next-hop-address</i>	Specifies the next hop IPv6 address. The format is <i>X:X:X::X</i> .
distance	Configures an IPv6 route metric.
<i>distance-metric</i>	Specifies a distance metric for the specified route. The range is 0 to 32766.
interface	Configures a next hop IPv6 address.
gigabitethernet <i>slot/port</i>	Specifies a Gigabit Ethernet slot and port number.
mgmt <i>number</i>	Specifies the management interface.
port-channel <i>number</i>	Specifies a PortChannel number. The range is 1 to 128.
vsan <i>vsan-id</i>	Specifies an IPFC VSAN ID. The range is 1 to 4093.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

Before using the **ipv6 route** command to configure IPv6 features on a switch, become familiar with the features of IPv6 and its extended addressing capabilities. In particular, it is important to understand the different types of IPv6 address formats, the IPv6 address prefix format, and the different IPv6 address types. For detailed information about IPv6, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

Examples

The following example configures a static default IPv6 route on a Gigabit Ethernet interface:

```
switch # config terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config)# ipv6 route ::/0 gigabitethernet 3/1
```

The following example configures a fully specified static route on a Gigabit Ethernet interface:

```
switch(config)# ipv6 route 2001:0DB8::/32 gigabitethernet 3/2
```

The following example configures a recursive static route to a specified next hop address:

```
switch(config)# ipv6 route 2001:0DB8::/32 2001:0DB8:2002::1
```

The following example configures a recursive static route to a specified next hop address, from which the output interface is automatically derived, and to a specified interface:

```
switch(config)# ipv6 route 2001:0DB8::/32 2001:0DB8:2002::1 gigabitethernet 3/2
```

The following example configures a static IPv6 route with an administrative distance of 20.

```
switch(config)# ipv6 route 2001:0DB8::/32 interface gigabitethernet 2/0 distance 20
```

Related Commands

ipv6 access-list	Configures an IPv6 access control list (ACL) and enters IPv6-ACL configuration submode.
ipv6 routing	Enables IPv6 unicast routing.
show ipv6 access-list	Displays a summary of ACLs.
show ipv6 route	Displays the static IPv6 routes configured on the switch.
show ipv6 routing	Displays the IPv6 unicast routing configured on the switch.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ipv6 routing

To enable IPv6 unicast routing, use the **ipv6 routing** command in configuration mode. To disable IPv6 unicast routing, use the **no** form of the command.

ipv6 routing

no ipv6 routing

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines Before using the **ipv6 routing** command to configure IPv6 features on a switch, become familiar with the features of IPv6 and its extended addressing capabilities. In particular, it is important to understand the different types of IPv6 address formats, the IPv6 address prefix format, and the different IPv6 address types. For detailed information about IPv6, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

Examples The following example enables IPv6 routing:

```
switch # config terminal
switch(config)# ipv6 routing
```

The following example disables IPv6 routing:

```
switch(config)# no ipv6 routing
```

Related Commands	ipv6 access-list	Configures an IPv6 access control list (ACL) and enters IPv6-ACL configuration submode.
	ipv6 route	Configures a static IPv6 route.
	show ipv6 access-list	Displays a summary of ACLs.
	show ipv6 route	Displays the static IPv6 routes configured on the switch.
	show ipv6 routing	Displays the IPv6 unicast routing configured on the switch.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ipv6 traffic-filter

To configure IPv6 access control lists (ACLs) to filter traffic for packets on the interface, use the **ipv6 traffic-filter** command in interface configuration submenu. To remove an IPv6-ACL traffic filter on the switch, use the **no** form of the command.

ipv6 traffic-filter *access-list-name* {**in** | **out**}

no ipv6 traffic-filter *access-list-name* {**in** | **out**}

Syntax Description

<i>access-list-name</i>	Specifies the name of an access control list for packets. The maximum size is 64 characters.
in	Configures inbound packets.
out	Configures outbound packets.

Defaults

None.

Command Modes

Interface configuration submenu.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

None.

Examples

The following example configures a traffic filter, called testfilter, for inbound packets:

```
switch# config terminal
switch(config)# interface gigabitethernet 2/2
switch(config-if)# ipv6 traffic-filter testfilter in
```

Related Commands

ipv6 address	Configures the IPv6 address and enables IPv6 processing.
ipv6 enable	Enables IPv6 processing on the interface.
ipv6 nd	Configures IPv6 ACLs to filter traffic for packets on the interface.
show interface	Displays interface configuration information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

iscsi authentication

To configure the default authentication method for iSCSI, use the **iscsi authentication** command. To revert to the default, use the **no** form of the command.

iscsi authentication { **chap** | **chap-none** | **none** | **username** *username* **password** [**0** | **7**] *password* }

no iscsi authentication { **chap** | **chap-none** | **none** | **username** }

Syntax Description

chap-none	Configures either the CHAP or no authentication.
chap	Configures the Challenge Handshake Authentication Protocol (CHAP) authentication method.
none	Specifies that no authentication is required for the selected interface
username <i>username</i>	Assigns CHAP username to be used when switch is authenticated.
password	Configures the password for the username.
0	Specifies that the password is a cleartext CHAP password.
7	Specifies that the password is an encrypted CHAP password.
<i>password</i>	Specifies a password for the username.

Defaults

chap-none.

The default password is a cleartext password.

Command Modes

Configuration mode.

Command History

Release	Modification
1.1(1)	This command was introduced.
2.0(x)	Added the username option.

Usage Guidelines

By default, the Cisco MDS 9000 Family switch accepts an iSCSI initiator with either no authentication or CHAP authentication. If CHAP authentication is always required, use the **iscsi authentication chap** command. If no authentication is always required, use the **iscsi authentication none** command.

Use the **chap-none** option to override the global configuration which might have been configured to allow only one option either CHAP or none but not both.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following example configures CHAP only for iSCSI authentication:

```
switch# config terminal
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config)# iscsi authentication chap
```

Related Commands

Command	Description
show iscsi global	Displays all iSCSI initiators configured by the user.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi duplicate-wwn-check

To check the current running configuration for conflicts between iSCSI initiators' static WWN allocation and what the system thinks is available in its WWN pool, use the **iscsi duplicate-wwn-check** command in configuration mode.

iscsi duplicate-wwn-check

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	2.1(2)	This command was introduced.

Usage Guidelines Prior to Cisco MDS SAN-OS Release 2.1(2), WWNs assigned to static iSCSI initiators by the system can be inadvertently returned to the system when an upgrade fails or the system software is manually downgraded (that is, when you manually boot up an older Cisco MDS SAN-OS release without using the **install all** command). In these instances, the system can later assign those WWNs to other iSCSI initiators (dynamic or static) and cause conflicts.

As of Cisco MDS SAN-OS Release 2.1(2), you can use the **iscsi duplicate-wwn-check** command to check for and remove any configured WWNs that belong to the system.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples The following example shows how to check the current running configuration for conflicts between iSCSI initiators' static WWN allocation and what the system thinks is available in its WWN pool:

```
switch# config terminal
Enter configuration command, one per line. End with CNTL/Z.
switch(config)# iscsi duplicate-wwn-check
```

```
List of Potential WWN Conflicts:
-----
```

```
Node : iqn.test-local-nwnn:1-local-pwwn:1
      nWWN : 22:03:00:0d:ec:02:cb:02
      pWWN : 22:04:00:0d:ec:02:cb:02
```

The following example shows how to remove the conflicting nWWN and pWWN.

```
switch(config)# iscsi initiator name iqn.test-local-nwnn:1-local-pwwn:1
switch(config-iscsi-init)# no static nWWN 22:03:00:0d:ec:02:cb:02
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config-iscsi-init)# no static pWWN 22:04:00:0d:ec:02:cb:02
```

Related Commands	Command	Description
	iscsi initiator name	Assigns an iSCSI name and changes to iSCSI initiator configuration submode.
	static	Assigns persistent WWNs to an iSCSI initiator in iSCSI initiator configuration submode.
	show iscsi initiator	Displays information about configured iSCSI initiators.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

iscsi dynamic initiator

To configure dynamic initiator modes, use the **iscsi dynamic initiator** command in configuration mode. To revert to the default mode, use the **no** form of the command.

iscsi dynamic initiator {deny | islb}

no dynamic initiator {deny | islb}

Syntax Description

deny	Specifies that dynamic initiators are denied from logging on to the MDS switch.
islb	Specifies iSLB dynamic initiator mode.

Defaults

iSCSI.

Command Modes

Configuration mode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

Three dynamic initiator modes are supported:

- iSCSI—Dynamic initiators are treated as iSCSI initiators and can access dynamic virtual targets and configured iSCSI virtual targets.
- iSLB—Dynamic initiators are treated as iSLB initiators and can access dynamic virtual targets.
- Deny—Dynamic initiators are not allowed to log in to the MDS switch.

iSCSI dynamic initiator is the default mode of operation. This configuration is distributed using CFS.



Note

Configuring dynamic initiator modes is supported only through the CLI, not through Device Manager or Fabric Manager.

A dynamic iSCSI initiator can be converted to a static iSCSI initiator and its WWNs can be made persistent.

A dynamic iSLB initiator can be converted to a static iSLB initiator and its WWNs can be made persistent.



Note

You cannot convert a dynamic iSCSI initiator to a static iSLB initiator, or a dynamic iSLB initiator to a static iSCSI initiator.

Send documentation comments to mdsfeedback-doc@cisco.com

**Note**

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following command configures the dynamic initiator mode as iSLB:

```
switch(config)# iscsi dynamic initiator islb
```

The following command configures the dynamic initiator mode as deny:

```
switch(config)# iscsi dynamic initiator deny
```

The following command reverts to the default dynamic initiator mode of iSCSI:

```
switch(config)# no iscsi dynamic initiator deny
```

Related Commands

Command	Description
iscsi save-initiator	Permanently saves the automatically assigned nWWN or pWWN mapping.
show iscsi global	Displays global iSCSI configured information.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi enable

To enable the iSCSI feature in any Cisco MDS switch, use the **iscsi enable** command. To disable this feature, use the **no** form of the command.

iscsi enable

no iscsi enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History

Release	Modification
1.3(1)	This command was introduced.
3.2(2c)	Updated the example command.
NX-OS 4.1(1)	This command was deprecated.

Usage Guidelines

The configuration and verification commands for the iSCSI feature are only available when iSCSI is enabled on a switch. When you disable this feature, all related configurations are automatically discarded.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following command enables the iSCSI feature:

```
switch(config)# iscsi enable
switch(config)# iscsi enable module 8
switch(config)# int iscsi 2/1
switch(config-if)#
switch(config)# no shutdown
```

The following command disables the iSCSI feature (default):

```
switch(config)# no iscsi enable
```

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi enable module

To enable iSCSI features for each IPS linecard to create corresponding iSCSI interfaces, use the **iscsi enable module** command.

iscsi enable module *module-num*

Syntax Description

<i>module-num</i>	Specifies the desired IPS linecard module number on which iSCSI interfaces need to be enabled.
-------------------	--

Defaults

iSCSI interfaces are disabled on IPS linecards by default.

Command Modes

Configuration mode.

Command History

Release	Modification
3.2(1)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to enable the iSCSI interface on a desired module number on the switch:

```
switch# config
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# iscsi enable module 1
```



Note

The iSCSI feature must be enabled before executing this command.

Related Commands

Command	Description
iscsi enable	Enables the iSCSI features but does not create the interfaces.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi import target fc

To allow dynamic mapping of Fibre Channel targets, use the **iscsi import target fc** command. To disable this feature, use the **no** form of the command.

iscsi import target fc

no iscsi import target fc

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Release	Modification
1.1(1)	This command was introduced.

Usage Guidelines This command directs iSCSI to dynamically import all Fibre Channel targets into iSCSI.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples The following example allows dynamic mapping of Fibre Channel targets:

```
switch# config terminal
switch(config)# iscsi import target fc
```

The following example disables dynamic mapping of Fibre Channel targets:

```
switch(config)# no iscsi import target fc
```

Command	Description
show iscsi global	Displays all iSCSI initiators configured by the user.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi initiator idle-timeout

To configure the iSCSI initiator idle timeout, use the **iscsi initiator idle-timeout** command. To revert to the default, use the **no** form of the command.

iscsi initiator idle-timeout *seconds*

no iscsi initiator idle-timeout *seconds*

Syntax Description	<i>seconds</i>	Specifies the timeout in seconds. The range is 0 to 3600.
--------------------	----------------	---

Defaults	300 seconds.
----------	--------------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	1.3	This command was introduced.

Usage Guidelines	When the idle timeout value is set to 0, the initiator information is cleared immediately after the last session from the initiator terminates.
------------------	---



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples	The following example configures the iSCSI initiator idle timeout to 180 seconds:
----------	---

```
switch# config terminal
switch(config)# iscsi initiator idle-timeout 180
```

The following example reverts the default value of 300 seconds:

```
switch# config terminal
switch(config)# no iscsi initiator idle-timeout 240
```

Related Commands	Command	Description
	show iscsi global	Displays global iSCSI configuration information.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi initiator ip-address

To assign persistent WWNs to an iSCSI initiator or assign an iSCSI initiator into VSANs other than the default VSAN, use the **iscsi initiator ip-address** command. To revert to the default, use the **no** form of the command.

iscsi initiator ip-address *ipaddress static* { **nwwn** | **pwwn** } { *wwn-id* | **system-assign number** } **vsan** *vsan-id*

no iscsi initiator ip-address *ipaddress static* { **nwwn** | **pwwn** } { *wwn-id* | **system-assign number** } **vsan** *vsan-id*

Syntax Description

<i>ipaddress</i>	Specifies the initiator IP address.
<i>nwwn</i>	Configures the initiator node WWN hex value.
<i>pwwn</i>	Configures the peer WWN for special frames.
<i>wwn-id</i>	Enters the pWWN or nWWN ID.
system-assign number	Generates the nWWN value automatically. The number ranges from 1 to 64.
<i>vsan vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
1.1(1)	This command was introduced.

Usage Guidelines

Under a circumstance where an iSCSI initiator needs to have a persistent binding to FC WWNs, this command should be used. Also, an iSCSI initiator can be put into multiple VSANs. An iSCSI host can become a member of one or more VSANs.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following command configures an iSCSI initiator. using the IP address of the initiator node.

```
switch(config)# iscsi initiator ip address 209.165.200.226
```

The following command deletes the configured iSCSI initiator.

```
switch(config)# no iscsi initiator ip address 209.165.200.226
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following command uses the switch's WWN pool to allocate the nWWN for this iSCSI initiator and keeps it persistent.

```
switch(config-(iscsi-init))# static nWWN system-assign
```

The following command assigns the user provided WWN as nWWN for the iSCSI initiator. You can only specify one nWWN for each iSCSI node.

```
switch(config-(iscsi-init))# nWWN 20:00:00:05:30:00:59:11
```

The following command uses the switch's WWN pool to allocate two pWWNs for this iSCSI initiator and keeps it persistent.

```
switch(config-(iscsi-init))# static pWWN system-assign 2
```

The following command assigns the user provided WWN as pWWN for the iSCSI initiator.

```
switch(config-(iscsi-init))# pWWN 21:00:00:20:37:73:3b:20
```

Related Commands

Command	Description
show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi initiator name

To configure an iSCSI initiator name and change to iSCSI configuration mode, use the **iscsi initiator name** command. To revert to factory defaults, use the **no** form of the command.

iscsi initiator name *name*

no iscsi initiator name *name*

Syntax Description	<i>name</i>	Enters the initiator name to be used. The minimum length is 16 characters and maximum is 223 characters.
---------------------------	-------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(2)	This command was introduced.

Usage Guidelines	Under a circumstance where an iSCSI initiator needs to have a persistent binding to FC WWNs, this command should be used. Also, an iSCSI initiator can be put into multiple VSANs. An iSCSI host can become a member of one or more VSANs.
-------------------------	--



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples	The following example configures an iSCSI initiator using the iSCSI name of the initiator node:
-----------------	---

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# iscsi initiator name iqn.1987-02.com.cisco.initiator
```

Related Commands	Command	Description
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi interface vsan-membership

To configure VSAN membership for iSCSI interfaces, use the **iscsi interface vsan-membership** command. Use the **no** form of this command to disable this feature or to revert to factory defaults.

iscsi interface vsan-membership

no iscsi interface vsan-membership

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines If the **iscsi interface vsan-membership** command is disabled, you will not be able to configure iSCSI VSAN membership.



Caution

Changing the VSAN membership, the forwarding mode, and the authentication of an iSCSI interface that is part of an iSLB VRRP group impacts load balancing on the interface.

For additional information, refer to the “Configuring iSCSI” chapter of the *Cisco MDS 9000 Family CLI Configuration Guide*.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples The following command enables the iSCSI interface VSAN membership:

```
switch# config terminal
switch(config)# iscsi interface vsan-membership
```

The following command disables the iSCSI interface VSAN membership (default):

```
switch(config)# no iscsi interface vsan-membership
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi save-initiator

To permanently save the automatically-assigned nWWN/pWWN mapping, use the **iscsi save-initiator** command.

iscsi save-initiator [**ip-address** *ip-address* | **name** *name*]

Syntax Description

ip-address <i>ip-address</i>	(Optional) Specifies the initiator IP address.
name <i>name</i>	(Optional) Specifies the initiator name to be used from 1 to 255 characters. The minimum length is 16 characters.

Defaults

If initiator name or IP address is not specified, the nWWN/pWWN mapping for all initiators becomes permanent.

Command Modes

Configuration mode.

Command History

Release	Modification
1.3(1)	This command was introduced.

Usage Guidelines

After executing the **iscsi save-initiator** command, issue the **copy running-config startup-config** to save the nWWN/pWWN mapping across switch reboots.

After a dynamic iSCSI initiator has logged in, you may decide to permanently save the automatically assigned nWWN/pWWN mapping so this initiator uses the same mapping the next time it logs in.

You can convert a dynamic iSCSI initiator to static iSCSI initiator and make its WWNs persistent.



Note

You cannot convert a dynamic iSCSI initiator to a static iSLB initiator or a dynamic iSLB initiator to a static iSCSI initiator.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following example shows how to save the nWWN/pWWN mapping for all the initiators:

```
switch(config)# iscsi save-initiator
```

The following example shows how to save the nWWN/pWWN mapping for an initiator named iqn.1987-02.com.cisco.initiator:

```
switch(config)# iscsi save-initiator name iqn.1987-02.com.cisco.initiator
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	iscsi initiator	Configures an iSCSI initiator.
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com

iscsi virtual-target name

To create a static iSCSI virtual target, use the **iscsi virtual-target** command. To revert to the default values, use the **no** form of the command.

iscsi virtual-target name *name* **advertise interface** {*gigabitethernet slot/port* [*.subinterface*] | *port-channel channel-id* [*.subinterface*]} **all-initiator-permit initiator** {*initiator-name* | **ip-address** *ipaddress* [*netmask*]} **permit pwwn** *pwwn-id* [**fc-lun** *number* **iscsi-lun** *number* [**secondary-pwwn** *pwwn-id* [**sec-lun** *number*]]] | **secondary-pwwn** *pwwn-id*]
revert-primary-port trespass

no iscsi virtual-target name *name* **advertise interface** {*gigabitethernet slot/port* [*.subinterface*] | *port-channel channel-id* [*.subinterface*]} **all-initiator-permit initiator** {*initiator-name* | **ip-address** *ipaddress* [*netmask*]} **permit pwwn** *pwwn-id* [**fc-lun** *number* **iscsi-lun** *number* [**secondary-pwwn** *pwwn-id* [**sec-lun** *number*]]] | **secondary-pwwn** *pwwn-id*]
revert-primary-port trespass

Syntax Description

<i>name</i>	Enters the virtual target name to be used. The minimum length is 16 characters and maximum of 223 bytes.
advertise interface	Advertises the virtual target name on the specified interface.
gigabitethernet <i>slot/port</i> <i>subinterface</i>	Selects the Gigabit Ethernet interface or subinterface to configure.
port-channel <i>channel-id</i> <i>subinterface</i>	Selects the Port Channel interface or subinterface to configure.
all-initiator-permit	Enables all iSCSI initiator access to this target.
initiator	Configures specific iSCSI initiator access to this target.
<i>initiator-name</i>	Specifies the iSCSI initiator name to be used access a specified target. Maximum length is 255 characters.
ip-address <i>ip-address</i>	Specifies the iSCSI initiator IP address.
permit	Permits access to the specified target.
pwwn <i>pwwn-id</i>	Specifies the peer WWN ID for special frames.
secondary-pwwn <i>pwwn-id</i>	Specifies the secondary pWWN ID.
fc-lun <i>number</i>	Specifies the Fibre Channel Logical Unit Number (LUN).
iscsi-lun <i>number</i>	Specifies the iSCSI virtual target number.
sec-lun <i>number</i>	Specifies the secondary Fibre Channel LUN.
revert-primary-port trespass	Moves LUNs forcefully from one port to another.

Defaults

Disabled.

Command Modes

Configuration mode.

Send documentation comments to mdsfeedback-doc@cisco.com

Command History

Release	Modification
1.1(1)	This command was introduced.
1.3(1)	Added revert-to-primary and trespass subcommands.

Usage Guidelines

This command is used to configure a static iSCSI target for access by iSCSI initiators. A virtual target may contain a subset of LUs of an FC target or one whole FC target.

Do not specify the LUN if you want to map the whole Fibre Channel target to an iSCSI target. All Fibre Channel LUN targets are exposed to iSCSI.



Note

The CLI interprets the LUN identifier value as a hexadecimal value whether or not the 0x prefix is included.

One iSCSI target cannot contain more than one Fibre Channel target.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples

The following example creates a static virtual target and enters ISCSI target configuration submode:

```
switch# config terminal
switch(config)# iscsi virtual-target name 0123456789ABDEFGHI
switch(config-iscsi-tgt)#
```

The following command advertises the virtual target only on the specified interface. By default, it is advertised on all interfaces in all IPS modules.

```
switch(config-iscsi-tgt)# advertise interface gigabitethernet 4/1
```

The following command maps a virtual target node to a Fibre Channel target:

```
switch(config-iscsi-tgt)# pwwn 26:00:01:02:03:04:05:06
```

The following command enters the secondary pWWN for the virtual target node:

```
switch(config-iscsi-tgt)# pwwn 26:00:01:02:03:04:05:06 secondary-pwwn
66:00:01:02:03:04:05:02
```

Use the LUN option to map different Fibre Channel LUNs to different iSCSI virtual targets. If you have already mapped the whole Fibre Channel target, you will not be able to use this option.

```
switch(config-iscsi-tgt)# pwwn 26:00:01:02:03:04:05:06 fc-lun 0 iscsi-lun 0
```

The following command allows the specified iSCSI initiator node to access this virtual target. You can issue this command multiple times to allow multiple initiators.

```
switch(config-iscsi-tgt)# initiator ign.1987-02.com.cisco.initiator1 permit
```

The following command prevents the specified initiator node from accessing virtual targets:

```
switch(config-iscsi-tgt)# no initiator ign.1987-02.com.cisco.initiator1 permit
```

The following command allows the specified IP address to access this virtual target:

```
switch(config-iscsi-tgt)# initiator ip-address 209.165.200.226 permit
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following command prevents the specified IP address from accessing virtual targets:

```
switch(config-iscsi-tgt)# no initiator ip-address 209.165.200.226 permit
```

The following command allows all initiators in this subnetwork to access this virtual target:

```
switch(config-iscsi-tgt)# initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following command prevents all initiators in this subnetwork from accessing virtual targets:

```
switch(config-iscsi-tgt)# no initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following command allows all initiator nodes to access this virtual target:

```
switch(config-iscsi-tgt)# all-initiator-permit
```

The following command prevents any initiator node from accessing virtual targets:

```
switch(config-iscsi-tgt)# no all-initiator-permit
```

The following command configures a primary and secondary port and moves the LUNs from one port to the other using the **trespass** command:

```
switch# config terminal
switch(config)#iscsi virtual-target name iqn.1987-02.com.cisco.initiator
switch(config-iscsi-tgt)# pwwn 50:00:00:a1:94:cc secondary-pwwn 50:00:00:a1:97:ac
switch(config-iscsi-tgt)# trespass
```

Related Commands

Command	Description
show iscsi virtual target	Displays information about iSCSI virtual targets.

Send documentation comments to mdsfeedback-doc@cisco.com

islb abort

To discard a pending iSCSI Server Load Balancing (iSLB) configuration, use the **islb abort** command.

islb abort

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	You can use the islb abort command to discard the pending changes to the iSLB configuration and release the fabric lock. This action has no effect on the active configuration on any switch in the fabric. The islb abort command can be issued only by the user who started the Cisco Fabric Services (CFS) session and only on the switch that started the CFS session.
-------------------------	--

Examples	The following example discards the pending iSLB configuration distribution:
-----------------	---

```
switch# config t  
switch(config)# islb abort
```

Related Commands	Command	Description
	clear islb session	Clears a pending iSLB configuration. This command can be issued on any switch by a user with admin privileges.
	islb commit	Commits the iSLB configuration distribution and releases the fabric lock.
	show islb cfs-session status	Displays iSLB information.
	show islb pending	Displays the pending configuration changes.
	show islb pending-diff	Displays the differences between the pending configuration and the current configuration.

Send documentation comments to mdsfeedback-doc@cisco.com

islb commit

To commit a pending iSCSI server load balancing (iSLB) configuration, use the **islb commit** command.

islb commit

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines You can use the **islb commit** command to commit the pending changes to the iSLB configuration and release the fabric lock. This action changes the active configuration on all Cisco MDS switches in the fabric.

The **islb commit** command can be issued only by the user who started the Cisco Fabric Services (CFS) session and only on the switch that started the CFS session.

Examples The following example commits the pending iSLB configuration distribution:

```
switch# config t
switch(config)# islb commit
```

Related Commands	Command	Description
	clear islb session	Clears a pending iSLB configuration. This command can be issued on any switch by a user with admin privileges.
	islb abort	Discards the pending iSLB configuration distribution and releases the fabric lock.
	islb distribute	Enables iSLB configuration distribution.
	show islb cfs-session status	Displays iSLB information.
	show islb pending	Displays the pending configuration changes.
	show islb pending-diff	Displays the differences between the pending configuration and the current configuration.

Send documentation comments to mdsfeedback-doc@cisco.com

islb distribute

To enable Cisco Fabric Services for iSCSI Server Load Balancing (iSLB) configuration, use the **islb distribute** command. To disable the iSLB configuration distribution, use the **no** form of the command

islb distribute

no islb distribute

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	You can use the islb distribute command to enable the distribution of iSLB configuration information to other Cisco MDS switches in the fabric using the Cisco Fabric Services (CFS) infrastructure. You can synchronize the iSLB configuration across the fabric from the console of a single MDS switch.
-------------------------	---



Note

The only initiator configuration that is distributed throughout the fabric using CFS is a statically mapped, iSLB initiator configuration. Dynamically mapped and statically mapped iSCSI initiator configurations are not distributed. iSCSI initiator idle-timeout and global authentication parameters are also distributed.

If you are using both iSLB and inter-VSAN routing (IVR), ensure that the following conditions are satisfied; otherwise, traffic may be disrupted in the fabric.

- You must enable both features on at least one switch in the fabric.
- You must configure and activate zoning from the switch for normal zones, IVR zones, and and iSLB zones.

Examples	The following example enables iSLB configuration distribution:
-----------------	--

```
switch# config t  
switch(config)# islb distribute
```

The following example disables iSLB configuration distribution:

```
switch(config)# no islb distribute
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	clear islb session	Clears a pending iSLB configuration. This command can be issued on any switch by a user with admin privileges.
	islb abort	Discards the pending iSLB configuration distribution and releases the fabric lock.
	islb commit	Commits the iSLB configuration distribution and releases the fabric lock.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

islb initiator

To configure the iSCSI server load balancing (iSLB) initiator and enter iSLB initiator configuration submode, use the **islb initiator** command. To delete the configured iSLB initiator, use the **no** form of the command.

islb initiator {**ip-address** {*ip-address* | *ipv6-address*} | **name** *name*}

no islb initiator name *name*

Syntax Description

ip-address	Specifies the iSLB initiator node IP address.
<i>ip-address</i>	Specifies the initiator IPv4 address.
<i>ipv6-address</i>	Specifies the initiator IPv6 address.
name <i>name</i>	Specifies the iSLB initiator node name. The maximum size is 223.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

You can use the **islb initiator** command to enter iSLB initiator configuration submode to configure static mapping for an iSLB initiator.

Examples

The following example enters iSLB initiator configuration submode to configure static mapping (using the IPv4 ip-address option) for an iSLB initiator:

```
switch# config t
switch(config)# islb initiator ipaddress 10.1.2.3
switch(config-islb-init)#
```

The following example deletes the configured iSLB initiator:

```
switch(config)# no islb initiator ipaddress 10.1.2.3
```

The following example enters iSLB initiator configuration submode to configure static mapping (using the IPv6 option) for an iSLB initiator:

```
switch# config t
switch(config)# islb initiator ipaddress 1111.2222.3333.4::5
switch(config-islb-init)#
```

The following example deletes the configured iSLB initiator:

```
switch(config)# no islb initiator ipaddress 1111.2222.3333.4::5
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following example enters iSLB initiator configuration submode to configure static mapping (using the name option) for an iSLB initiator:

```
switch# config t
switch(config)# isl b initiator name iqn.1987-02.co..cisco.initiator
switch(config-isl b-init)#
```

The following example deletes the configured iSLB initiator:

```
switch(config)# no isl b initiator ipaddress name iqn.1987-02.co..cisco.initiator
```

Related Commands

Command	Description
show isl b initiator configured	Displays iSLB initiator configuration information.
show isl b initiator detail	Displays more detailed information about the iSLB configuration.
show isl b initiator iscsi-session	Displays iSLB session details.
show isl b initiator summary	Displays iSLB initiator summary information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

islb save-initiator

To permanently save the automatically-assigned nWWN/pWWN mapping for the iSLB initiator, use the **islb save-initiator** command.

islb save-initiator [**ip-address** *ip-address* | **name** *name*]

Syntax Description

ip-address <i>ip-address</i>	(Optional) Specifies the initiator IP address. The format is <i>A.B.C.D</i> or <i>X:X:X::X</i> .
name <i>name</i>	(Optional) Specifies the initiator name to be used from 1 to 223 characters.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

Saving the automatically assigned nWWN/pWWN mapping allows the initiator to use the same mapping the next time it logs in.

You can convert a dynamic iSLB initiator to a static iSLB initiator and make its WWNs persistent.



Note

You cannot convert a dynamic iSCSI initiator to a static iSLB initiator or a dynamic iSLB initiator to a static iSCSI initiator.



Note

Making the dynamic mapping for iSLB initiators static is the same as for iSCSI.



Note

Only a statically mapped iSLB initiator configuration is distributed throughout the fabric using CFS. Dynamically and statically configured iSCSI initiator configurations are not distributed.

Examples

The following example saves the nWWNs and pWWNs that have automatically been assigned to the iSLB initiator whose name is specified:

```
switch# config t
switch(config)# islb save-initiator name iqn.1987-02.com.cisco.initiator
```

The following example saves the nWWNs and pWWNs that have automatically been assigned to the iSLB initiator whose IPv4 address is specified:

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config)# islb save-initiator ip-address 10.10.100.11
```

The following example saves the nWWNs and pWWNs that have automatically been assigned to all the iSLB initiators.

```
switch(config)# islb save-initiator
```

Please execute "copy run start" to keep the WWNs persistent across switch reboots

Related Commands

Command	Description
show islb session	Displays detailed iSLB session information.

Send documentation comments to mdsfeedback-doc@cisco.com

islb virtual-target name

To configure an iSLB virtual target and enter iSLB target configuration submode, use the **islb virtual-target name** command. To revert to the default values, use the **no** form of the command.

islb virtual-target name *name* {**all-initiator-permit** | **initiator** {*initiator-name* **permit** | **ip address** {*A.B.C.D* **permit** | *X:X:X::X* **permit**}} | **pWWN** **permit** | **revert-primary-port permit** | **trespass permit**}

no islb virtual-target name *name* {**all-initiator-permit** | **initiator** {*initiator-name* **permit** | **ip address** {*A.B.C.D* **permit** | *X:X:X::X* **permit**}} | **pWWN** **permit** | **revert-primary-port permit** | **trespass permit**}

Syntax Description		
<i>name</i>		Specifies the virtual target name to be used. The minimum length is 16 bytes and the maximum length is 223 bytes.
all-initiator-permit		Configures all iSLB initiators to access the target.
initiator		Configures the iSLB initiator to access the target.
initiator-name		Specifies the initiator name. The minimum length is 16 bytes and the maximum length is 223 bytes.
<i>X:X:X::X</i> permit		Permits access to the specified target.
ip address		Specifies the initiator IP address. The format is <i>A.B.C.D</i> or <i>X:X:X::X</i> .
pWWN <i>pwwn-id</i>		Specifies the pWWN of the Fibre Channel target. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> .
revert-primary-port permit		Reverts to the primary port when it becomes active again.
trespass permit		Enables trespass support.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines This command is used to configure a static target for access by iSLB initiators.

Examples The following example creates a static virtual target and enters iSLB target configuration submode:

```
switch# config terminal
switch(config)# islb virtual-target name ABCDEFGHIJ1234567890
ips-hac1(config-islb-tgt)#
```

Send documentation comments to mdsfeedback-doc@cisco.com

The following example allows all iSLB initiators to access the target:

```
ips-hacl(config-islb-tgt)# all-initiator-permit
```

The following command allows the specified IP address to access this virtual target:

```
switch(config-islb-tgt)# initiator ip-address 209.165.200.226 permit
```

The following example prevents the specified IP address from accessing virtual targets:

```
switch(config-islb-tgt)# no initiator ip-address 209.165.200.226 permit
```

The following example allows all initiators in this subnetwork to access this virtual target:

```
switch(config-islb-tgt)# initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following example prevents all initiators in this subnetwork from accessing virtual targets:

```
switch(config-islb-tgt)# no initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following example maps a pWWN to a Fibre Channel target:

```
ips-hacl(config-islb-tgt)# pwwn 26:00:01:02:03:04:05:06
```

Related Commands

Command	Description
show islb virtual-target	Displays information about iSLB virtual targets.

Send documentation comments to mdsfeedback-doc@cisco.com

islb vrrp

To configure iSCSI server load balancing (iSLB) on a Virtual Router Redundancy Protocol (VRRP) group, use the **islb vrrp** command. To disable the iSLB configuration on the VRRP group, use the **no** form of the command.

islb vrrp {*group-number* **load-balance** | **ipv6** *group-number* **load-balance**}

no islb vrrp {*group-number* **load-balance** | **ipv6** *group-number* **load-balance**}

Syntax Description

<i>group-number</i>	Specifies an IPv4 Virtual Router group number. The range is 1 to 255.
load-balance	Enables load balancing on the VRRP group.
ipv6	Specifies IPv6 on the VRRP group.
<i>group-number</i>	Specifies an IPv6 Virtual Router group number. The range is 1 to 255.
load-balance	Enables load balancing on the VRRP group.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.0(1)	This command was introduced.

Usage Guidelines

The host is configured with a VRRP address as the portal address. When the VRRP master port receives the first iSCSI session from an initiator, it assigns a slave port to serve that particular host. The information is synchronized to all switches via Cisco Fabric Services (CFS) if recovery is needed when a master port fails. The initiator gets a temporary redirect iSCSI login response. The host then logs in to the slave port at its physical IP address. If the slave port goes down, the host will revert to the master port. The master port knows through CFS that the slave port has gone down and redirects the host to another slave port.

There are separate VRRP groups for IPv4 and IPv6. Each address family is allowed 256 virtual routers.



Note

An initiator can also be redirected to the physical IP address of the master interface.



Tip

The load balancing distribution is based on the number of initiators on a port and not on the number of sessions.

Send documentation comments to mdsfeedback-doc@cisco.com

**Caution**

A Gigabit Ethernet interface configured for iSLB can only be in one VRRP group because redirected sessions do not carry information about the VRRP IP address or group. This restriction allows the slave port to uniquely identify the VRRP group to which it belongs.

**Caution**

Changing the VSAN membership, the forwarding mode, and the authentication of an iSCSI interface that is part of an iSLB VRRP group impacts load balancing on the interface.

For additional information, refer to the “Configuring iSCSI” chapter of the *Cisco MDS 9000 Family CLI Configuration Guide*.

Examples

The following example enables VRRP load balancing for IPv4 Virtual Router group 20:

```
switch# config t  
switch(config)# islb vrrp 20 load-balance
```

The following example disables VRRP load balancing for IPv4 Virtual Router group 20:

```
switch(config)# no isl b vrrp 20 load-balance
```

The following example enables VRRP load balancing for IPv6 Virtual Router group 30:

```
switch(config)# islb vrrp ipv6 30 load-balance
```

The following example disables VRRP load balancing for IPv6 Virtual Router group 30:

```
switch(config)# no isl b ipv6 30 load-balance
```

Related Commands

Command	Description
show isl b session	Displays detailed iSLB session information.

Send documentation comments to mdsfeedback-doc@cisco.com

islb zoneset activate

To activate iSCSI server load balancing (iSLB) auto zones, use the **islb zoneset activate** command.

islb zoneset activate

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	Auto-zoning of the initiator with the initiator targets is enabled by default. A zone set must be active for a VSAN for auto-zones to be created in that VSAN. The zoneset activate command creates auto-zones only if at least one other change has been made to the zone set.
-------------------------	--

Examples	The following example activates an iSLB auto zone:
-----------------	--

```
switch# config t
switch(config)# islb zoneset activate
```

Related Commands	Command	Description
	show zoneset active	Displays active zone sets.

Send documentation comments to mdsfeedback-doc@cisco.com

isns

To tag a Gigabit Ethernet or PortChannel interface to an Internet Storage Name Service (iSNS) profile, use the **isns** command in interface configuration submode. To untag the interface, use the **no** form of the command.

isns *profile-name*

no isns *profile-name*

Syntax Description

<i>profile-name</i>	Specifies the iSNS profile name.
---------------------	----------------------------------

Defaults

Disabled.

Command Modes

Interface configuration submode.

Command History

Release	Modification
2.0(x)	This command was introduced.

Usage Guidelines

To use this command, iSNS must be enabled using the **isns-server enable** command.

Use the **isns reregister** command in EXEC mode to reregister associated iSNS objects (tagged to an iSNS profile) with the iSNS server.

Examples

The following example shows how to tag a Gigabit Ethernet interface to an iSNS profile:

```
switch# config terminal
switch(config)# interface gigabitethernet 1/2
switch(config-if)# isns Profile1
```

The following example shows how to tag a PortChannel interface to an iSNS profile:

```
switch# config terminal
switch(config)# interface port-channel 2
switch(config-if)# isns Profile2
```

Related Commands

Command	Description
isns reregister	Reregisters the iSNS object.
isns-server enable	Enables the iSNS server.
show interface gigabitethernet	Displays configuration and status information for a specified Gigabit Ethernet interface.

Send documentation comments to mdsfeedback-doc@cisco.com

Command	Description
show interface port-channel	Displays configuration and status information for a specified PortChannel interface.
show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com

isns distribute

To enable Cisco Fabric Services (CFS) distribution for Internet Storage Name Service (iSNS), use the **isns distribute** command. To disable this feature, use the **no** form of the command.

isns distribute

no isns distribute

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	Enabled.
-----------------	----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	To use this command, iSNS must be enabled using the isns-server enable command. You can configure the pWWN and nWWN of iSCSI initiators and permit a group of iSCSI initiators to share a given nWWN/pWWN pair by using a proxy initiator. The number of iSCSI initiators that register with the iSNS server is more than the number of iSCSI targets that register with the iSNS server. To synchronize the iSCSI initiator entries across switches, you can distribute the iSCSI initiator configuration to iSNS servers across switches.
-------------------------	--

Examples	The following example shows how to initiate iSNS information distribution:
-----------------	--

```
switch# config terminal
switch(config)# isns distribute
```

The following example shows how to cancel iSNS information distribution:

```
switch# config terminal
switch(config)# no isns distribute
```

Related Commands	Command	Description
	isns-server enable	Enables the iSNS server.
	show isns	Displays iSNS information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

isns esi retries

To configure the number of entity status inquiry (ESI) retry attempts, use the **isns esi retries** command in configuration mode. To revert to the default value, use the **no** form of the command.

isns esi retries *number*

no isns esi retries *number*

Syntax Description	<i>number</i>	Specifies the number of retries. The range is 0 to 10.
---------------------------	---------------	--

Defaults	3 retries.
-----------------	------------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	To use this command, Internet Storage Name Service (iSNS) must be enabled using the isns-server enable command.
-------------------------	--

The iSNS client queries the ESI port at user-configured intervals. Receipt of a response indicates that the client is still alive. Based on the configured value, the interval specifies the number of failed tries before which the client is deregistered from the server.

Examples	The following example shows how change the ESI retries limit to eight: switch# config terminal switch(config)# isns esi retries 8
-----------------	---

Related Commands	Command	Description
	isns-server enable	Enables the iSNS server.
	show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com

isns profile name

To create an Internet Storage Name Service (iSNS) profile and enter iSNS profile configuration submode, use the **isns profile name** command in configuration mode. To delete the iSNS profile, use the **no** form of the command.

isns profile name *profile-name*

no isns profile name *profile-name*

Syntax Description	<i>profile-name</i> Specifies the profile name. Maximum length is 64 characters.							
Defaults	None.							
Command Modes	Configuration mode.							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>1.3(1)</td><td>This command was introduced.</td></tr></table>		Release	Modification	1.3(1)	This command was introduced.		
Release	Modification							
1.3(1)	This command was introduced.							
Usage Guidelines	To use this command, iSNS must be enabled using the isns-server enable command.							
Examples	The following example shows how to specify an iSNS profile name and enter iSNS profile configuration submode: <pre>switch# config terminal switch(config)# isns profile name UserProfile switch(config-isns-profile)#</pre>							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>server</td><td>Configures a server IP address in an iSNS profile.</td></tr><tr><td>show isns</td><td>Displays iSNS information.</td></tr></table>		Command	Description	server	Configures a server IP address in an iSNS profile.	show isns	Displays iSNS information.
Command	Description							
server	Configures a server IP address in an iSNS profile.							
show isns	Displays iSNS information.							

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

isns reregister

To register all Internet Storage Name Service (iSNS) objects for an interface that is already tagged to an iSNS profile, use the **isns register** command.

```
isns reregister { gigabitethernet slotnumber | port-channel channel-group }
```

Syntax Description

gigabitethernet <i>slot/port</i>	Specifies tagged Gigabit Ethernet interface slot and port.
port-channel <i>channel-group</i>	Specifies tagged PortChannel group. The range is 1 to 128.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
1.3(1)	This command was introduced.

Usage Guidelines

Use this command to reregister portals and targets with the iSNS server for a tagged interface.

Examples

The following command reregisters portal and targets for a tagged interface:

```
switch# isns reregister gigabitethernet 1/4
```

Related Commands

Command	Description
show isns profile	Displays details for configured iSNS profiles.

Send documentation comments to mdsfeedback-doc@cisco.com

isns-server enable

To enable the Internet Storage Name Service (iSNS) server, use the **isns-server enable** command in configuration mode. To disable iSNS, use the **no** form of the command.

isns-server enable

no isns-server enable

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	Performing the isns-server enable command enables the commands used to configure iSNS.
-------------------------	---

Examples	The following example shows how to enable iSNS:
-----------------	---

```
switch# config terminal
switch(config)# isns-server enable
```

The following example shows how to disable iSNS:

```
switch# config terminal
switch(config)# no isns-server enable
```

Related Commands	Command	Description
	isns distribute	Enables iSNS distributed support.
	isns esi retries	Configures ESI retry attempts.
	isns profile name	Creates and configures iSNS profiles.
	server	Configures iSNS server attributes.
	show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr abort

To discard an Inter-VSAN Routing (IVR) CFS distribution session in progress, use the **ivr abort** command in configuration mode.

ivr abort

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to discard an IVR CFS distribution session in progress:
-----------------	---

```
switch# config terminal
switch(config)# ivr abort
```

Related Commands	Command	Description
	ivr distribute	Enables CFS distribution for IVR.
	show ivr	Displays IVR CFS distribution status and other details.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr commit

To apply the pending configuration pertaining to the Inter-VSAN Routing (IVR) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **ivr commit** command in **configuration mode**.

ivr commit

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to apply an IVR configuration to the switches in the fabric:
-----------------	--

<pre>switch# config terminal switch(config)# ivr commit</pre>

Related Commands	Command	Description
	ivr distribute	Enables CFS distribution for IVR.
	show ivr	Displays IVR CFS distribution status and other details.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr copy active-service-group user-configured-service-group

To copy the active service group to the user configured service group, use the **ivr copy active-service-group user-configured-service-group** command in EXEC mode.

ivr copy active-service-group user-configured-service-group

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines None.

Examples The following example copies the active service group to the user-defined service group:

```
switch# ivr copy active-service-group user-configured-service-group
Successfully copied active service group to user-configured service group database
```

Related Commands	Command	Description
	clear ivr service-group database	Clears the IVR service group database.
	show ivr service-group	Displays IVR service groups.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr copy active-topology user-configured-topology

To copy the active inter-VSAN routing (IVR) VSAN topology to the user configured topology, use the **ivr copy active-topology user-configured-topology** command in EXEC mode.

ivr copy active-topology user-configured-topology

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines The **ivr copy active-topology user-configured-topology** command is useful if you need to edit the active IVR topology, which is not allowed. Instead you copy the active IVR topology to the user configured topology, and then edit the user configured topology.

Examples The following example copies the active IVR topology to the user configured topology:

```
switch# ivr copy active-topology user-configured-topology  
Successfully copied active VSAN-topology to user-configured topology database
```

Related Commands	Command	Description
	ivr copy active-zoneset full-zoneset	Copies the active zone set to the full zone set.
	ivr copy auto-topology user-configured topology	Copies the automatically discovered inter-VSAN routing (IVR) VSAN topology to the user configured topology.
	show ivr vsan topology	Displays the IVR VSAN topology configuration.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr copy active-zoneset full-zoneset

To copy the active zone set to the full zone set, use the **ivr copy active-zoneset full-zoneset** command in EXEC mode.

ivr copy active-zoneset full-zoneset

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines Copying the active zone set to the full zone set may overwrite common zone and zone set configurations in the full zoning database.

Examples The following example copies the active zone set to the full zone set:

```
switch# ivr copy active-zoneset full-zoneset
WARNING: This command may overwrite common zones/zonesets
         in the IVR full zoneset database
Please enter yes to proceed.(y/n) [n]?
```

Related Commands	Command	Description
	ivr copy active-topology user-configured topology	Copies the active inter-VSAN routing (IVR) VSAN topology to the user configured topology.
	ivr copy auto-topology user-configure topology	Copies the automatically discovered inter-VSAN routing (IVR) VSAN topology to the user configured topology.
	show ivr zoneset active	Displays the active IVR zone set.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr copy auto-topology user-configured-topology

To copy the automatically discovered inter-VSAN routing (IVR) VSAN topology to the user configured topology, use the **ivr copy auto-topology user-configured-topology** command in EXEC mode.

ivr copy auto-topology user-configured-topology

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC configuration mode.
----------------------	--------------------------

Command History	Release	Modification
	2.1(1a)	This command was introduced.

Usage Guidelines	After using the ivr copy auto-topology user-configured-topology command to copy the automatically discovered VSAN topology into the user- configured topology you must use the ivr commit command to apply the pending configuration changes to the IVR topology using Cisco Fabric Services (CFS) distribution.
-------------------------	--

Examples	The following example copies the automatically discovered VSAN topology into the user configured topology:
-----------------	--

```
switch# ivr copy auto-topology user-configured-topology
```

Related Commands	Command	Description
	ivr commit	Applies the changes to the IVR topology.
	ivr copy active-topology user-configured topology	Copies the active inter-VSAN routing (IVR) VSAN topology to the user configured topology.
	ivr copy active-zoneset full-zoneset	Copies the active zone set to the full zone set.
	show ivr vsan topology	Displays the IVR VSAN topology configuration .

Send documentation comments to mdsfeedback-doc@cisco.com

ivr distribute

To enable Cisco Fabric Services (CFS) distribution for Inter-VSAN Routing (IVR), use the **ivr distribute** command. To disable this feature, use the **no** form of the command.

ivr distribute

no ivr distribute

Syntax Description	This command has no other arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to enable IVR fabric distribution:
	<pre>switch# config terminal switch(config)# ivr distribute</pre>

Related Commands	Command	Description
	ivr commit	Commits temporary IVR configuration changes to the active configuration.
	show ivr	Displays IVR CFS distribution status and other details.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr enable

To enable the Inter-VSAN Routing (IVR) feature, use the **ivr enable** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr enable

no ivr enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	1.3(1)	This command was introduced.
	NX-OS 4.1(1b)	This command was deprecated.

Usage Guidelines

The IVR feature must be enabled in all edge switches in the fabric that participate in the IVR.

The configuration and display commands for the IVR feature are only available when IVR is enabled on a switch.

When you disable this configuration, all related configurations are automatically discarded.



Note

This command is not supported on the Cisco MDS 9124 switch, the Cisco Fabric Switch for HP c-Class BladeSystem, and the Cisco Fabric Switch for IBM BladeCenter.

Examples The following command enters the configuration mode and enables the IVR feature on this switch:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
```

Related Commands	Command	Description
	show ivr	Displays IVR feature information.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

ivr fcdomain database autonomous-fabric-num

To create IVR persistent FC IDs, use the **ivr fcdomain database autonomous-fabric-num** command. To delete the IVR fcdomain entry for a given AFID and VSAN, use the **no** form of the command.

ivr fcdomain database autonomous-fabric-num *afid-num* **vsan** *vsan-id*

no ivr fcdomain database autonomous-fabric-num *afid-num* **vsan** *vsan-id*

Syntax Description	<i>afid-num</i>	Specifies the current AFID. The range is 1 to 64.
	vsan <i>vsan-id</i>	Specifies the current VSAN. The range is 1 to 4093.

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.1(2)	This command was introduced.

Usage Guidelines	This configuration only takes effect when NAT mode is enabled.
-------------------------	--

Examples	The following example shows how to enter IVR fcdomain database configuration submode for AFID 10 and VSAN 20:
-----------------	---

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config) fcdomain#
```

The following example shows how to delete all persistent FC ID database entries for AFID 10 and VSAN 20:

```
switch# config t
switch(config)# no ivr fcdomain database autonomous-fabric-num 10 vsan 20
```

Related Commands	Command	Description
	show ivr fcdomain database	Displays IVR fcdomain database entry information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr nat

To explicitly enable Network Address Translation (NAT) functionality for Inter-VSAN Routing (IVR), use the **ivr nat** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr nat

no ivr nat

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.1(1a)	This command was introduced.

Usage Guidelines	The ivr nat command allows you to explicitly enable NAT functionality of IVR. Upgrading to SAN-OS Release 2.x from SAN-OS Release 1.3.x does not automatically enable the Fibre Channel NAT functionality. This command also allows you to continue to operate in non-NAT mode even in SAN-OS Release 2.x and later.
-------------------------	---



Note

You might need to operate in non-NAT mode to support proprietary protocols that embed FCIDs in the frame payloads.
--

Examples	The following example shows how to explicitly enable NAT functionality for IVR:
-----------------	---

```
switch# config terminal
Enter configuration commands, one per line.  End with CNTL/Z.
switch(config)# ivr nat
```

Related Commands	Command	Description
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr refresh

To refresh devices being advertised by Inter-VSAN Routing (IVR), use the **ivr refresh** command in EXEC mode.

ivr refresh

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	2.0(2)	This command was introduced.

Usage Guidelines	The ivr refresh command runs internally when ivr zoneset or topology is activated. The limit for the maximum number of IVR zones per VSAN is 250 zones (two members per zone).
-------------------------	---

Examples	The following example shows refresh devices being advertised by IVR: switch# ivr refresh
-----------------	--

Related Commands	Command	Description
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
	ivr withdraw domain	Withdraws an overlapping virtual domain from a specified VSAN.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr service-group activate

To activate an inter-VSAN routing (IVR) service group, use the **ivr service-group activate** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr service-group activate [default-sg-deny]

no ivr service-group activate [default-sg-deny]

Syntax Description	default-sg-deny (Optional) Sets the policy to deny for the default service group.
---------------------------	--

Defaults	Deactivated.
-----------------	--------------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	You must activate a configured IVR service group for the IVR service group to take effect. Once a configured IVR service group is activated, it replaces the currently activated service group, if there is one.
	Activating an IVR service group with the default-sg-deny option sets the default service group policy to deny. To change the default service group policy to allow, issue the ivr service-group activate command again, but without the default-sg-deny option.

Examples	The following example activates the default IVR service group:
-----------------	--

```
switch# config terminal
switch(config)# ivr service-group activate
```

The following example sets the default IVR service group policy to deny:

```
switch# config terminal
switch(config)# ivr service-group activate default-sg-deny
```

The following example disables the default service group:

```
switch# config terminal
switch(config)# no ivr service-group activate
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	ivr enable	Enables inter-VSAN routing (IVR).
	ivr service-group name	Configures an inter-VSAN routing (IVR) service group.
	show ivr service-group database	Displays an inter-VSAN routing service group database.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr service-group name

To configure an Inter-VSAN Routing (IVR) service group, use the **ivr service-group name** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr service-group name *service-group*

no ivr service-group name *service-group*

Syntax Description	<i>service-group</i>	Specifies the service group name.
--------------------	----------------------	-----------------------------------

Defaults	Disabled.
----------	-----------

Command Modes	Configuration mode.
---------------	---------------------

Command History	Release	Modification
	2.1(1a)	This command was introduced.

Usage Guidelines

In a complex network topology, you might only have a few IVR-enabled VSANs. To reduce the amount of traffic to non-IVR-enabled VSANs, you can configure a service group that restricts the traffic to the IVR-enabled VSANs. A service group is a combination of AFIDs and VSANs. Up to 16 service groups can be configured. A VSAN or AFID can belong to just one service group. When a new IVR-enabled switch is added to the network, you must update the service group to include the new VSANs.

There can be a maximum of 128 AFID/VSAN combinations in all service group. However, all 128 combinations can be in one service group.

The default service group ID is 0. The default service group is for all VSANs that are not a part of a user-defined service group.

Before configuring an IVR service group, you must enable the following:

- IVR using the **ivr commit** command
- IVR distribution using the **ivr commit** command
- Automatic IVR topology discovery using the **ivr commit auto command**.

Using the **autonomous-fabric-id (IVR topology database configuration)** command, you can restrict the IVR traffic to the AFIDs and VSANs configured in the service group.

Examples

The following example shows how to configure an IVR service group and change to IVR service group configuration mode:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
switch(config)# ivr vsan-topology auto
switch(config)# ivr service-group name serviceGroup1
```

 `ivr service-group name`

Send documentation comments to mdsfeedback-doc@cisco.com

```
switch(config-ivr-sg)#
```

Related Commands	Command	Description
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature
	ivr vsan-topology auto	Enables automatic discovery of the IVR topology.
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr virtual-fcdomain-add

To add the Inter-VSAN Routing (IVR) virtual domains in a specific VSAN(s) to the assigned domains list in that VSAN, use the **ivr virtual-fcdomain-add** command. To delete the IVR virtual domains, use the **no** form of the command.

ivr virtual-fcdomain-add vsan-ranges *vsan-range*

no ivr virtual-fcdomain-add vsan-ranges *vsan-range*

Syntax Description	vsan-ranges <i>vsan-range</i> Specifies the IVR VSANs or range of VSANs. The range of values for a VSAN ID is 1 to 4093.
---------------------------	---

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(4)	This command was introduced.

Usage Guidelines	Use the no ivr virtual-fcdomain-add command to remove the currently active domains from the fcdomain manager list in a specified VSAN.
-------------------------	---

Examples	The following command adds the IVR virtual domains in VSAN :
-----------------	--

```
switch# config terminal
switch(config)# ivr virtual-fcdomain-add vsan-ranges 1
```

The following command reverts to the factory default of not adding IVR virtual domains:

```
switch# config terminal
switch(config)# ivr virtual-fcdomain-add vsan-ranges 1
```

Related Commands	Command	Description
	ivr withdraw domain	Removes overlapping domains.
	show ivr virtual-fcdomain-add-status	Displays the configured VSAN topology for a fabric.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr virtual-fcdomain-add2

To configure the request domain_ID (RDI) mode in a specific autonomous fabric ID (AFID) and VSAN for all IVR-enabled switches, use the **ivr virtual-fcdomain-add2** command. To delete the RDI mode, use the **no** form of the command.

ivr virtual-fcdomain-add2 autonomous-fabric-id *value* **vsan-ranges** *value*

no ivr virtual-fcdomain-add2 autonomous-fabric-id *value* **vsan-ranges** *value*

Syntax Description	fabric-id <i>value</i>	Specifies the fabric ID on which the RDI mode needs to be configured.
	vsan-ranges <i>value</i>	Specifies the VSAN range value on which the RDI mode needs to be configured.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	3.3(1a)	This command was introduced.

Usage Guidelines This is a CFS distributable command.

Examples The following example configures the RDI mode on a specific AFID and VSAN:

```
switch# config
Enter configuration commands, one per line. End with CNTL/Z.
switch# ivr virtual-fcdomain-add2 autonomous-fabric-id 1 vsan-ranges 2
switch# fabric is now locked for configuration. Please 'commit' configuration when done.
switch(config)# ivr commit
```

Related Commands	Command	Description
	show ivr virtual-fcdomain-add-status2	Displays the RDI mode in a specific AFID and VSAN for all IVR-enabled switches.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr vsan-topology

To configure manual or automatic discovery of the Inter-VSAN Routing (IVR) topology, use the **ivr vsan-topology** command in configuration mode.

ivr vsan-topology {activate | auto}

Syntax Description

activate	Configures manual discovery of the IVR topology and disables automatic discovery mode.
auto	Configures automatic discovery of the IVR topology.

Defaults

Disabled.

Command Modes

Configuration mode.

Command History

Release	Modification
1.3(1)	This command was introduced.
2.1(1a)	Added auto keyword.

Usage Guidelines

To use this command you must first enable IVR using the **ivr enable** command and configure the IVR database using the **ivr vsan-topology database** command.



Caution

Active IVR topologies cannot be deactivated. You can only switch to automatic topology discovery mode.

Examples

The following **ivr vsan-topology activate** command activates the VSAN topology database:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
switch(config)# ivr vsan-topology database
switch(config-ivr-topology-db)# autonomous-fabric-id 1 switch 20:00:00:00:30:00:3c:5e
vsan-ranges 2,2000
switch(config)# ivr vsan-topology activate
```

The following command enables VSAN topology database auto mode, which allows the switch to automatically discover the IVR topology:

```
switch(config)# ivr vsan-topology auto
```

Send documentation comments to mdsfeedback-doc@cisco.com

Related Commands	Command	Description
	autonomous-fabric-id (IVR topology database configuration)	Configure an autonomous phobic ID into the IVR topology database.
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr vsan-topology database

To configure an Inter-VSAN Routing (IVR) topology database, use the **ivr vsan-topology database** command in configuration mode. To delete an IVR topology database, use the **no** form of the command.

ivr vsan-topology database

no ivr vsan-topology database

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines To use this command you must first enable IVR using the **ivr enable** command.

You can have up to 64 VSANs (or 128 VSANs as of Cisco MDS SAN-OS Release 2.1(1a)) in an IVR topology. Specify the IVR topology using the following information:

- The switch WWNs of the IVR-enabled switches.
- A minimum of two VSANs to which the IVR-enabled switch belongs.
- The autonomous fabric ID (AFID), which distinguishes two VSANs that are logically and physically separate, but have the same VSAN number. Cisco MDS SAN-OS Release 1.3(1) and later supports only one default AFID (AFID 1) and thus does not support non-unique VSAN IDs in the network. As of Cisco MDS SAN-OS Release 2.1(1a), you can specify up to 64 AFIDs.



Note

The use of a single AFID does not allow for VSANs that are logically and physically separate but have the same VSAN number in an IVR topology.



Caution

You can only configure a maximum of 128 IVR-enabled switches and 64 distinct VSANs (or 128 distinct VSANs as of Cisco MDS SAN-OS Release 2.1(1a)) in an IVR topology.

The **no ivr vsan-topology database** command only clears the configured database, not the active database. You can only delete the user-defined entries in the configured database. Auto mode entries only exist in the active database.

Send documentation comments to mdsfeedback-doc@cisco.com

Examples

The following command enters configuration mode, enables the IVR feature, enters the VSAN topology database, and configures the pWWN-VSAN association for VSANs 2 and 2000:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
switch(config)# ivr vsan-topology database
switch(config-ivr-topology-db)# autonomous-fabric-id 1 switch 20:00:00:00:30:00:3c:5e
vsan-ranges 2,2000
```

Related Commands

Command	Description
autonomous0fabric-id (IVR topology database configuration)	Configure an autonomous phobic ID into the IVR topology database
ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr withdraw domain

To withdraw overlapping virtual domain from a specified VSAN, use the **ivr withdraw domain** command in EXEC mode.

ivr withdraw domain *domain-id* **vsan** *vsan-id*

Syntax Description	<i>domain-id</i>	Specifies the domain id. The range is 1 to 239.
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.3(4)	This command was introduced.

Usage Guidelines	When you enable the ivr virtual-fcdomain-add command, links may fail to come up due to overlapping virtual domain identifiers. If so, temporarily withdraw the overlapping virtual domain from that VSAN using the ivr withdraw domain command in EXEC mode.
-------------------------	--

Examples	The following command withdraws overlapping domains:
-----------------	--

```
switch# ivr withdraw domain 10 vsan 20
```

Related Commands	Command	Description
	show ivr virtual-fcdomain-add-status	Displays the configured VSAN topology for a fabric.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr zone name

To configure a zone for Inter-VSAN Routing (IVR), use the **ivr zone name** command. To disable a zone for IVR, use the **no** form of the command.

ivr zone name *ivzs-name*

no ivr zone name *ivz-name*

Syntax Description	<i>ivz-name</i> Specifies the IVZ name. Maximum length is 59 characters.	
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.3(1)	This command was introduced.
Usage Guidelines	This command enters IVR zone configuration submode.	
Examples	The following command enters the configuration mode, enables the IVR feature, creates an IVZ, and adds a pWWN-VSAN member:	
	<pre>switch# config terminal switch(config)# ivr enable switch(config)# ivr zone name Ivz_vsan2-3 switch(config-ivr-zone)# member pwn 21:00:00:e0:8b:02:ca:4a vsan 3</pre>	
Related Commands	Command	Description
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr zone rename

To rename an inter-VSAN routing (IVR) zone, use the **ivr zone rename** command.

ivr zone rename *current-name new-name*

Syntax Description	<i>current-name</i>	Specifies the current zone name. The maximum size is 64 characters.
	<i>new-name</i>	Specifies the new zone name. The maximum size is 64 characters.

Defaults	None.
----------	-------

Command Modes	EXEC mode.
---------------	------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	None.
------------------	-------

Examples	The following example renames the IVR zone from <i>east</i> to <i>west</i> : switch# ivr zone rename east west
----------	--

Related Commands	Command	Description
	ivr zone name	Creates and configures an IVR zone.
	show ivr	Displays IVR information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr zoneset

To configure a zoneset for Inter-VSAN Routing (IVR), use the **ivr zoneset** command. To revert to the factory defaults, use the **no** form of the command.

ivr zoneset {activate name *ivzs-name* [force] | name *ivzs-name*}

no ivr zoneset {activate name *ivzs-name* [force] | name *ivzs-name*}

Syntax Description	activate	Activates a previously configured IVZS.
	force	(Optional) Forces a IVZS activation
	name <i>ivzs-name</i>	Specifies the IVZS name. Maximum length is 59 characters.

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	This command enters IVR zoneset configuration submode.
-------------------------	--

Examples The following command enters the configuration mode, enables the IVR feature, creates an IVZS, adds a IVZ member, and activates the IVZS:

```
switch# config terminal
switch(config)# ivr enable
switch(config)# ivr zoneset name Ivr_zoneset1
switch(config-ivr-zoneset)# member Ivz_vsan2-3
switch(config-ivr-zoneset)# exit
switch(config)# ivr zoneset activate name IVR_ZoneSet1
```

Related Commands	Command	Description
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com

ivr zoneset rename

To rename an inter-VSAN routing (IVR) zone set, use the **ivr zoneset rename** command.

ivr zoneset rename *current-name new-name*

Syntax Description	<i>current-name</i>	Specifies the current zone set name. The maximum size is 64 characters.
	<i>new-name</i>	Specifies the new zone set name. The maximum size is 64 characters.

Defaults	None.
----------	-------

Command Modes	EXEC mode.
---------------	------------

Command History	Release	Modification
	3.0(1)	This command was introduced.

Usage Guidelines	None.
------------------	-------

Examples	The following example renames the IVR zone set from <i>north</i> to <i>south</i> : switch# ivr zoneset rename north south
----------	---

Related Commands	Command	Description
	ivr zoneset name	Creates and configures an IVR zone set.
	show ivr	Displays IVR information.

Send documentation comments to mdsfeedback-doc@cisco.com