

CHAPTER 9

Configuring SNMP

The CLI and SNMP use common roles in all switches in the Cisco MDS 9000 Family. You can use SNMP to modify a role that was created using the CLI and vice versa.

Users, passwords, and roles for all CLI and SNMP users are the same. A user configured through the CLI can access the switch using SNMP (for example, the Fabric Manager or the Device Manager) and vice versa.


This chapter includes the following sections:

- [About SNMP Security, page 9-1](#)
- [SNMPv3 CLI User Management and AAA Integration, page 9-2](#)
- [Creating and Modifying Users, page 9-4](#)
- [SNMP Trap and Inform Notifications, page 9-8](#)
- [Default Settings, page 9-15](#)

About SNMP Security

SNMP is an application layer protocol that facilitates the exchange of management information between network devices. In all Cisco MDS 9000 Family switches, three SNMP versions are available: SNMPv1, SNMPv2c, and SNMPv3 (see [Figure 9-1](#)).

Figure 9-1 *SNMP Security*



85473

Send documentation comments to fm-docfeedback@cisco.com

This section includes the following topics:

- [SNMP Version 1 and Version 2c, page 9-2](#)
- [SNMP Version 3, page 9-2](#)
- [Assigning SNMP Switch Contact and Location Information, page 9-2](#)

SNMP Version 1 and Version 2c

SNMP Version 1 (SNMPv1) and SNMP Version 2c (SNMPv2c) use a community string match for user authentication. Community strings provided a weak form of access control in earlier versions of SNMP. SNMPv3 provides much improved access control using strong authentication and should be preferred over SNMPv1 and SNMPv2c wherever it is supported.

SNMP Version 3

SNMP Version 3 (SNMPv3) is an interoperable standards-based protocol for network management. SNMPv3 provides secure access to devices by a combination of authenticating and encrypting frames over the network. The security features provided in SNMPv3 are:

- Message integrity—Ensures that a packet has not been tampered with in-transit.
- Authentication—Determines the message is from a valid source.
- Encryption—Scrambles the packet contents to prevent it from being seen by unauthorized sources.

SNMPv3 provides for both security models and security levels. A security model is an authentication strategy that is set up for a user and the role in which the user resides. A security level is the permitted level of security within a security model. A combination of a security model and a security level determines which security mechanism is employed when handling an SNMP packet.

Assigning SNMP Switch Contact and Location Information

You can assign the switch contact information, which is limited to 32 characters (without spaces) and the switch location.

To configure contact and location information, using Fabric Manager, follow these steps:

-
- | | |
|---------------|--|
| Step 1 | Expand Switches from the Physical Attributes pane. You see the switch settings in the Information pane. |
| Step 2 | Fill in the Location and Contact fields for each switch. |
| Step 3 | Click Apply Changes to save these changes or click Undo Changes to discard any unsaved changes. |
-

SNMPv3 CLI User Management and AAA Integration

The Cisco NX-OS software implements RFC 3414 and RFC 3415, including user-based security model (USM) and role-based access control. While SNMP and the CLI have common role management and share the same credentials and access privileges, the local user database was not synchronized in earlier releases.

Send documentation comments to fm-docfeedback@cisco.com

SNMPv3 user management can be centralized at the AAA server level. This centralized user management allows the SNMP agent running on the Cisco MDS switch to leverage the user authentication service of the AAA server. Once user authentication is verified, the SNMP PDUs are processed further. The AAA server also is used to store user group names. SNMP uses the group names to apply the access/role policy that is locally available in the switch.

This section includes the following topics:

- [CLI and SNMP User Synchronization, page 9-3](#)
- [Restricting Switch Access, page 9-3](#)
- [Group-Based SNMP Access, page 9-3](#)

CLI and SNMP User Synchronization

Any configuration changes made to the user group, role, or password results in database synchronization for both SNMP and AAA.

Users are synchronized as follows:

- Deleting a user using either command results in the user being deleted for both SNMP and the CLI.
- User-role mapping changes are synchronized in SNMP and the CLI.

**Note**

When the passphrase/password is specified in localized key/encrypted format, the password is not synchronized.

**Note**

Starting in 3.0(1), the temporary SNMP login created for Fabric Manager is no longer 24 hours. It is one hour.

- Existing SNMP users continue to retain the auth and priv passphrases without any changes.
- If the management station creates an SNMP user in the `usmUserTable`, the corresponding CLI user is created without any password (login is disabled) and will have the `network-operator` role.

Restricting Switch Access

You can restrict access to a Cisco MDS 9000 Family switch using IP Access Control Lists (IP-ACLs).

Group-Based SNMP Access

**Note**

Because *group* is a standard SNMP term used industry-wide, we refer to role(s) as group(s) in this SNMP section.

SNMP access rights are organized by groups. Each group in SNMP is similar to a role through the CLI. Each group is defined with three accesses: read access, write access, and notification access. Each access can be enabled or disabled within each group.

Send documentation comments to fm-docfeedback@cisco.com

You can begin communicating with the agent once your user name is created, your roles are set up by your administrator, and you are added to the roles.

Creating and Modifying Users

You can create users or modify existing users using SNMP, Fabric Manager, or the CLI.

- **SNMP**—Create a user as a clone of an existing user in the `usmUserTable` on the switch. Once you have created the user, change the cloned secret key before activating the user. Refer to RFC 2574.
- **Fabric Manager**.
- **CLI**—Create a user or modify an existing user using the **`snmp-server user`** command.

A network-operator and network-admin roles are available in a Cisco MDS 9000 Family switch. There is also a default-role if you want to use the GUI (Fabric Manager and Device Manager). You can also use any role that is configured in the Common Roles database.



Tip

All updates to the CLI security database and the SNMP user database are synchronized. You can use the SNMP password to log into either Fabric Manager or Device Manager. However, after you use the CLI password to log into Fabric Manager or Device Manager, you must use the CLI password for all future logins. If a user exists in both the SNMP database and the CLI database before upgrading to Cisco MDS SAN-OS Release 2.0(1b), then the set of roles assigned to the user becomes the union of both sets of roles after the upgrade.

This section includes the following topics:

- [About AES Encryption-Based Privacy, page 9-4](#)
- [Enforcing SNMPv3 Message Encryption, page 9-5](#)
- [Assigning SNMPv3 Users to Multiple Roles, page 9-6](#)
- [Adding Communities, page 9-7](#)
- [Deleting a Community String, page 9-7](#)

About AES Encryption-Based Privacy

The Advanced Encryption Standard (AES) is the symmetric cipher algorithm. The Cisco NX-OS software uses AES as one of the privacy protocols for SNMP message encryption and conforms with RFC 3826.

The **priv** option offers a choice of DES or 128-bit AES encryption for SNMP security encryption. The **priv** option along with the **aes-128** token indicates that this privacy password is for generating a 128-bit AES key. The AES priv password can have a minimum of eight characters. If the passphrases are specified in clear text, you can specify a maximum of 64 characters. If you use the localized key, you can specify a maximum of 130 characters.



Note

For an SNMPv3 operation using the external AAA server, user configurations in the external AAA server require AES to be the privacy protocol to use SNMP PDU encryption.

Send documentation comments to fm-docfeedback@cisco.com

Enforcing SNMPv3 Message Encryption

By default the SNMP agent allows the securityLevel parameters of authNoPriv and authPriv for the SNMPv3 messages that use user-configured SNMPv3 message encryption with auth and priv keys.

To enforce the message encryption for a user using Fabric Manager, follow these steps:

- Step 1** Expand **Switches > Security** and then select **Users and Roles** from the Physical Attributes pane.
- Step 2** Click the **Users** tab in the Information pane to see a list of users (see [Figure 9-2](#)).


Figure 9-2 User Information Under the User Tab



Switch	User	Role	Password (not echoed)	Digest	Encryption	ExpiryDate (eg. yyyy/mm/dd-hh:mm:ss)	SSH Key File Configured	SSH Key File ([bootflash: volatile:]) (not echoed)	Creation Time
sw172-22-46-174	admin	network-admin		MD5	DES		false		localCred
sw172-22-46-174	mdchinn	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-174	md5usr	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-174	shausr	network-admin		NoAuth	NoPriv		false		localCred
sw172-22-46-220	admin	network-admin		MD5	DES		false		localCred
sw172-22-46-220	md5usr	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-220	mdchinn	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-220	mdchinn	network-admin, network-operator		MD5	DES		false		localCred
sw172-22-46-220	md5usr	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-220	newusr	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-220	shausr	network-admin, network-operator		NoAuth	NoPriv		false		localCred
sw172-22-46-220	mdchinn	network-admin, network-operator		NoAuth	NoPriv		false		localCred

- Step 3** Click **Create Row**.
- You see the Create Users dialog box.
- Step 4** Enter the user name in the **New User** field.
- Step 5** Select the role from the Role drop-down menu. You can enter a new role name in the field if you do not want to select one from the drop-down menu. If you do this, you must go back and configure this role appropriately.
- Step 6** Enter a password for the user in Password field.
- Step 7** Click the **Privacy** tab (see [Figure 9-3](#)).

Figure 9-3 Privacy Tab



Switch	Enforce SNMP Privacy Encryption
sw172-22-46-233	☒
sw172-22-46-220	☒
sw172-22-46-223	☒
sw172-22-46-221	☒
sw172-22-46-225	☒
sw172-22-46-222	☒
sw172-22-46-174	☒

- Step 8** Check the **Enforce SNMP Privacy Encryption** check box to encrypt management traffic.
- Step 9** Click **Create** to create the new entry.

To enforce the SNMPv3 message encryption globally on all the users using Fabric Manager, follow these steps:

Send documentation comments to fm-docfeedback@cisco.com

-
- Step 1** Select a VSAN in the Logical Domains pane. This will not work if you select All VSANS.
- Step 2** Expand **Switches > Security** and then select **Users and Roles** in the Physical Attributes pane. Click the **Global** tab in the Information pane.
- Step 3** Check the **GlobalEnforcePriv** check box.
- Step 4** Click the **Apply Changes** icon to save these changes.
-

Assigning SNMPv3 Users to Multiple Roles

The SNMP server user configuration is enhanced to accommodate multiple roles (groups) for SNMPv3 users. After the initial SNMPv3 user creation, you can map additional roles for the user.



Note


Only users belonging to a network-admin role can assign roles to other users.

To add multiple roles to a new user using Fabric Manager, follow these steps:

-
- Step 1** Expand **Switches > Security** and then select **Users and Roles** from the Physical Attributes pane.
- Step 2** Click the **Users** tab in the Information pane to see a list of users (see [Figure 9-2](#)).
- Step 3** Click **Create Row**.

You see the Create Users dialog box (see [Figure 9-4](#)).

Figure 9-4 Create Users Dialog Box



- Step 4** Choose roles using the check boxes.
- Step 5** Choose an option for Digest and one for Encryption.

Send documentation comments to fm-docfeedback@cisco.com


- Step 6** (Optional) Provide an expiration date for the user and the file name of an SSH key.
- Step 7** Click **Create** to create the new roles.

Adding Communities

You can configure read-only or read-write access for SNMPv1 and SNMPv2 users. Refer to RFC 2576. To create an SNMPv1 or SNMPv2c community string using Fabric Manager, follow these steps:

- Step 1** Expand **Switches > Security** and then select **Users and Roles** from the Physical Attributes pane.
- Step 2** Click the **Communities** tab in the Information pane.
- You see the existing communities (see [Figure 9-5](#)).

Figure 9-5 *Communities Tab Under Users and Roles*



Switch	Community	Role
sw172-22-46-225	newpublic	network-operator
sw172-22-46-220	newprivate	network-admin
sw172-22-46-224	newpublic	network-operator
sw172-22-46-221	newprivate	network-admin
sw172-22-46-223	newprivate	network-admin
sw172-22-46-225	newprivate	network-admin
sw172-22-46-174	newprivate	network-admin
sw172-22-46-222	newpublic	network-operator
sw172-22-46-220	public	network-admin
sw172-22-46-224	newprivate	network-admin

- Step 3** Click **Create Row**.
- You see the Create Community String dialog box.
- Step 4** Check the **Switch** check boxes to specify one or more switches.
- Step 5** Enter the community name in the Community field.
- Step 6** Select the role from Role drop-down list.



Note You can enter a new role name in the field if you do not want to select one from the drop-down list. If you do this, you must go back and configure this role appropriately.

- Step 7** Click **Create** to create the new entry.

Deleting a Community String

To delete a community string using Fabric Manager, follow these steps:

- Step 1** Expand **Switches > Security** and then select **Users and Roles** from the Physical Attributes pane.
- Step 2** Click the **Communities** tab in the Information pane.
- Step 3** Click the name of the community you want to delete.

Send documentation comments to fm-docfeedback@cisco.com

Step 4 Click **Delete Row** to delete this community.

SNMP Trap and Inform Notifications

You can configure the Cisco MDS switch to send notifications to SNMP managers when particular events occur.



Note

Use the SNMP-TARGET-MIB to obtain more information on the destinations to which notifications are to be sent either as traps or as informs. Refer to the *Cisco MDS 9000 Family MIB Quick Reference*.

This section includes the following topics:

- [Configuring SNMPv2c Notifications, page 9-8](#)
- [Configuring SNMPv3 Notifications, page 9-9](#)
- [Enabling SNMP Notifications, page 9-9](#)
- [Configuring the Notification Target User, page 9-12](#)
- [Configuring Event Security, page 9-14](#)
- [Viewing the SNMP Events Log, page 9-14](#)

Configuring SNMPv2c Notifications

To configure SNMPv2c notifications using Fabric Manager, follow these steps:

Step 1 Expand **Switches > Events** and then select **SNMP Traps** in the Physical Attributes pane. You see the SNMP notification configuration in the Information pane (see [Figure 9-6](#)).

Figure 9-6 *SNMP Notifications*

Switch	Domain Mgr RCF	Zone Rejects	Zone Merge Failures	Zone Merge Successes	Zone Default Policy Change	Zone Unsuppd Mode	RSCN ILS	RSCN ILS Rx	RSCN ILS	FSPF Neighbor Changes	Name Server
sw172-22-46-224	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-220	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-225	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-223	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-221	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-222	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
sw172-22-46-174	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒


Step 2 Click the **Destinations** tab to add or modify a receiver for SNMP notifications.

Step 3 Click **Create Row** to create a new notification destination.

You see the Create Destinations dialog box (see [Figure 9-7](#)).

Send documentation comments to fm-docfeedback@cisco.com

Figure 9-7 Create Destinations Dialog Box



- Step 4** Check the switches for which you want to configure a new destination.
- Step 5** Set the destination IP address and UDP port.
- Step 6** Choose either the **trap** or **inform** radio button.
- Step 7** (Optional) Set the timeout or retry count values.
- Step 8** Click **Create** to add this destination to the selected switches.
- Step 9** (Optional) Click the **Other** tab to enable specific notification types per switch.
- Step 10** Click the **Apply changes** icon to create the entry.



Note

Switches can forward events (SNMP traps and informs) up to 10 destinations.

Configuring SNMPv3 Notifications



Note

To configure SNMPv3 notifications using IPv4 using Fabric Manager, select **v3** from the Security drop-down list in the Create Destinations dialog box (see [Figure 9-7](#)). Optionally, set the inform time out and retry values. Click **Create** to add this destination to the selected switches.



Note

In the case of SNMPv3 notifications, the SNMP manager is expected to know the user credentials (authKey/PrivKey) based on the switch's engineID to authenticate and decrypt the SNMP messages.

Enabling SNMP Notifications

Notifications (traps and informs) are system alerts that the switch generates when certain events occur. You can enable or disable notifications. By default, no notification is defined or issued. If a notification name is not specified, all notifications are disabled or enabled.

Send documentation comments to fm-docfeedback@cisco.com

Table 9-1 lists the Fabric Manager procedures that enable the notifications for Cisco NX-OS MIBs. Choose **Switches > Events > SNMP Traps** to see the check boxes listed in this table.



Note

Choosing **Switches > Events > SNMP Traps** enables both traps and informs, depending on how you configured SNMP notifications. See the notifications displayed with the “[Configuring SNMPv3 Notifications](#)” section on page 9-9.

Table 9-1 Enabling SNMP Notifications

MIB	Fabric Manager Check boxes
CISCO-ENTITY-FRU-CONTROL-MIB	Select the Other tab and check FRU Changes .
CISCO-FCC-MIB	Select the Other tab and check FCC .
CISCO-DM-MIB	Select the FC tab and check Domain Mgr RCF .
CISCO-NS-MIB	Select the FC tab and check Name Server .
CISCO-FCS-MIB	Select the Other tab and check FCS Rejects .
CISCO-FDMI-MIB	Select the Other tab and check FDMI .
CISCO-FSPF-MIB	Select the FC tab and check FSPF Neighbor Change .
CISCO-LICENSE-MGR-MIB	Select the Other tab and check License Manager .
CISCO-IPSEC-SIGNALING-MIB	Select the Other tab and check IPSEC .
CISCO-PSM-MIB	Select the Other tab and check Port Security .
CISCO-RSCN-MIB	Select the FC tab and check RSCN ILS , and RCSN ELS .
SNMPv2-MIB	Select the Other tab and check SNMP AuthFailure .
VRRP-MIB, CISCO-IETF-VRRP-MIB	Select the Other tab and check VRRP .
CISCO-ZS-MIB	Select the FC tab and check Zone Rejects , Zone Merge Failures , Zone Merge Successes , Zone Default Policy Change , and Zone Unsuppd Mode .

The following notifications are enabled by default:

- entity fru
- license
- link ietf-extended

All other notifications are disabled by default.

To enable individual notifications using Fabric Manager, follow these steps:

- Step 1** Expand **Switches > Events** and then select **SNMP Traps** in the Physical Attributes pane.
You see the SNMP notification configuration in the Information pane.
- Step 2** Click the **FC** tab to enable Fibre Channel related notifications.
- Step 3** Check each notification check box that you want to enable.
- Step 4** Click the **Other** tab to enable other notifications.


Send documentation comments to fm-docfeedback@cisco.com

Step 5 Check each notification check box that you want to enable.

Step 6 Click the **Control** tab to enable notification applicable variables.

From NX-OS Release 4.2(1), the **Control** tab is available for the notification control feature. This feature allows you to enable or disable all the notification applicable variables via SNMP (see [Figure 9-8](#)).

Figure 9-8 *SNMP Traps Window*



Note

The **Control** tab is available for NX-OS Release 4.2(1) and later only.

Step 7 Check each notification check box that you want to enable.

Step 8 Click the **Apply changes** icon to create the entry.



Note

In Device Manager, the command **no snmp-server enable traps link** disables generation of link traps in the switch, however the individual interfaces may have the link trap enabled.


To enable individual notifications using Device Manager, follow these steps:

Step 1 Expand **Admin > Events** and then select **Filters**.

You see the event filters window showing a table populated by the switch (see [Figure 9-9](#)).

Send documentation comments to fm-docfeedback@cisco.com

Figure 9-9 Event Filters Window



Step 2 Click the **Control** tab to enable notification applicable variables.

From NX-OS Release 4.2(1), the **Control** tab is available for the notification control feature. This feature allows you to enable or disable all the notification applicable variables via SNMP.



Note

The **Control** tab is available for NX-OS Release 4.2(1) and later only.

Step 3 Check each notification check box that you want to enable.

Step 4 Click the **Apply changes** icon to create the entry.

Configuring the Notification Target User

You must configure a notification target user on the switch for sending SNMPv3 inform notifications to the SNMP manager.

To configure the notification target user, refer to the *Cisco MDS 9000 Family NX-OS System Management Configuration Guide*.

The credentials of the notification target user are used for encrypting the SNMPv3 inform notification messages to the configured SNMP.

Send documentation comments to fm-docfeedback@cisco.com

**Note**

For authenticating and decrypting the received INFORM PDU, the SNMP manager should have the same user credentials in its local configuration data store of users.

Configuring LinkUp/LinkDown Notifications for Switches

You can configure which linkUp/linkDown notifications to enable on switches. You can enable the following types of linkUp/linkDown notifications:

- Cisco—Only notifications (cieLinkUp, cieLinkDown) defined in CISCO-IF-EXTENSION-MIB.my are sent for an interface, if ifLinkUpDownTrapEnable (defined in IF-MIB) is enabled for that interface.
- IETF—Only notifications (linkUp, linkDown) defined in IF-MIB are sent for an interface, if ifLinkUpDownTrapEnable (defined in IF-MIB) is enabled for that interface. Only the varbinds defined in the notification definition are sent with the notifications.
- IETF extended—Only notifications (linkUp, linkDown) defined in IF-MIB are sent for an interface, if ifLinkUpDownTrapEnable (defined in IF-MIB) is enabled for that interface. In addition to the varbinds defined in the notification definition, varbinds defined in the IF-MIB specific to the Cisco Systems implementation are sent. This is the default setting.
- IETF Cisco—Only notifications (linkUp, linkDown) defined in IF-MIB and notifications (cieLinkUp, cieLinkDown) defined in CISCO-IF-EXTENSION-MIB.my are sent for an interface, if ifLinkUpDownTrapEnable (defined in IF-MIB) is enabled for that interface. Only the varbinds defined in the notification definition are sent with the linkUp and linkDown notifications.
- IETF extended Cisco—Only notifications (linkUp, linkDown) defined in IF-MIB and notifications (cieLinkUp, cieLinkDown) defined in CISCO-IF-EXTENSION-MIB.my are sent for an interface, if ifLinkUpDownTrapEnable (defined in IF-MIB) is enabled for that interface. In addition to the varbinds defined in linkUp and linkDown notification definition, varbinds defined in the IF-MIB specific to the Cisco Systems implementation are sent with the linkUp and linkDown notifications.

**Note**

For more information on the varbinds defined in the IF-MIB specific to the Cisco Systems implementation, refer to the *Cisco MDS 9000 Family MIB Quick Reference*.

Configuring Up/Down SNMP Link-State Traps for Interfaces

By default, SNMP link-state traps are enabled for all interfaces. Whenever a link toggles its state from Up to Down or vice versa, an SNMP trap is generated.

In some instances, you may find that you have numerous switches with hundreds of interfaces, many of which do not require monitoring of the link state. In such cases, you may elect to disable link-state traps.

Scope of Link Up/Down Trap Settings

The link Up/Down trap settings for the interfaces generate traps based on the following scope:

Send documentation comments to fm-docfeedback@cisco.com

Switch-level Trap Setting	Interface-level Trap Setting	Trap Generated for Interface Links?
Enabled (default)	Enabled (default)	Yes
Enabled	Disabled	No
Disabled	Enabled	No
Disabled	Disabled	No

Configuring Event Security



Caution

This is an advanced function that should only be used by administrators having experience with SNMPv3.

SNMP events can be secured against interception or eavesdropping in the same way that SNMP messages are secured. Fabric Manager or Device Manager allow you to configure the message processing model, the security model, and the security level for the SNMP events that the switch generates.

To configure SNMP event security using Fabric Manager, follow these steps:

- Step 1** Expand **Switches > Events** and then select **SNMP Traps**.
- Step 2** Click the **Security** tab in the Information pane.
You see the security information for SNMP notifications.
- Step 3** Set the message protocol model (MPModel), security model, security name, and security level.
- Step 4** Click the **Apply Changes** icon to save and apply your changes.

Viewing the SNMP Events Log

To view the SNMP events log from Fabric Manager, click the **Events** tab (see [Figure 9-10](#)). You see the Events listed with a log of events for a single switch.

Figure 9-10 Events Information

Type	Time	Severity	Source	Description
Fabric Purged	2007/04/26-08:22:50	Warning	Fabric v-185	Down elements in fabric Fabric v-185 are purged by 171.70.223.82
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN4010
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN10
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN2
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN4010
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN1
N_Port Unreac...	2007/04/26-08:22:45	Warning	Fabric v-185	10:00:00:00:77:99:34:8c <-> c-186,fc1/12, Last seen 2007/04/09-16:00:53
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN2
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN1
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN10
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN2000
YSAN Segmented	2007/04/26-08:22:45	Info	Fabric v-185	Fabric v-185/YSAN2000

Send documentation comments to fm-docfeedback@cisco.com

**Note**

The MDS syslog manager must be set up before you can view the event logs.

**Caution**

Changing these values from different Fabric Manager workstations at the same time may cause unpredictable results.

Default Settings

Table 9-2 lists the default settings for all SNMP features in any switch.

Table 9-2 **Default SNMP Settings**

Parameters	Default
User account	No expiry (unless configured)
Password	None

Send documentation comments to fm-docfeedback@cisco.com