

Send comments to nexus5k-docfeedback@cisco.com



I Commands

This chapter describes the Cisco NX-OS Ethernet and virtual Ethernet commands that begin with I.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

install certificate

To install a certificate that is used to connect to a vCenter Server, use the **install certificate** command. To remove a certificate, use the **no** form of this command.

install certificate { **bootflash:**[//server/] | **default** }

no install certificate

Syntax Description	bootflash: [//server/]	Specifies the source or destination URL for boot flash memory to install the certificate. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local .
	default	Specifies the default path.

Command Default	None
-----------------	------

Command Modes	SVS connection configuration mode
---------------	-----------------------------------

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to install a certificate to the boot flash memory:
----------	---

```
switch# configure terminal
switch(config)# svcs connection SVSConn
switch(config-svs-conn)# install certificate bootflash:///
switch(config-svs-conn)#
```

This example shows how to remove a certificate:

```
switch# configure terminal
switch(config)# svcs connection SVSConn
switch(config-svs-conn)# no install certificate
switch(config-svs-conn)#
```

Related Commands	Command	Description
	show svcs connections	Displays SVS connection information.
	svcs connection	Enables an SVS connection.

Send comments to nexus5k-docfeedback@cisco.com

install feature-set virtualization

To install the Cisco virtual machine feature set on the switch, use the **install feature-set virtualization** command. To remove the Cisco virtual machine feature set, use the **no** form of this command.

install feature-set virtualization

no install feature-set virtualization

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

Usage Guidelines



Note

The Cisco virtual machine feature is supported only on the Cisco Nexus 5500 Series switches.

This command requires an Enhanced Layer 2 license.

Examples This example shows how to install the Cisco virtual machine feature set on the switch:

```
switch# configure terminal
switch(config)# install feature-set virtualization
switch(config)#
```

Related Commands	Command	Description
	feature vmfex	Enables or disables Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch.
	feature-set virtualization	Enables the Cisco virtual machine feature set on the switch.
	show feature-set	Displays the status of the virtualization feature set.
	show running-config	Displays the running system configuration information.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

instance vlan

To map a VLAN or a set of VLANs to a Multiple Spanning Tree instance (MSTI), use the **instance vlan** command. To delete the instance and return the VLANs to the default instance (Common and Internal Spanning Tree [CIST]), use the **no** form of this command.

instance *instance-id* **vlan** *vlan-id*

no instance *instance-id* [**vlan** *vlan-id*]

Syntax Description

<i>instance-id</i>	Instances to which the specified VLANs are mapped. The range is from 0 to 4094.
vlan <i>vlan-id</i>	Specifies the number of the VLANs that you are mapping to the specified MSTI. The VLAN ID range is from 1 to 4094.

Command Default

No VLANs are mapped to any MST instance (all VLANs are mapped to the CIST instance).

Command Modes

MST configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

The VLAN identifier is entered as a single value or a range.

The mapping is incremental, not absolute. When you enter a range of VLANs, this range is added to or removed from the existing instances.

Any unmapped VLAN is mapped to the CIST instance.



Caution

When you change the VLAN-to-MSTI mapping, the system restarts MST.

Examples

This example shows how to map a range of VLANs to MSTI 4:

```
switch(config)# spanning-tree mst configuration
switch(config-mst)# instance 4 vlan 100-200
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	show spanning-tree mst configuration	Displays information about the MST protocol.
	spanning-tree mst configuration	Enters MST configuration mode.

Send comments to nexus5k-docfeedback@cisco.com

interface ethernet

To enter interface configuration mode for an Ethernet IEEE 802.3 interface, use the **interface ethernet** command.

interface ethernet [*chassis_ID*] *slot/port*

Syntax Description

<i>chassis_ID</i>	(Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. Note This argument is not optional when addressing the host interfaces of a Cisco Nexus 2000 Series Fabric Extender.
<i>slot</i>	Slot from 1 to 3. The following list defines the slots available: - Slot 1 includes all the fixed ports. A Fabric Extender only has one slot. - Slot 2 includes the ports on the upper expansion module (if populated). - Slot 3 includes the ports on the lower expansion module (if populated).
<i>port</i>	Port number within a particular slot. The port number is from 1 to 128.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
4.0(1a)N2(1)	This command was modified to provide the chassis ID argument.
5.0(3)N1(1)	Support for Layer 3 interfaces was added.

Examples

This example shows how to enter configuration mode for Ethernet interface 1/4:

```
switch(config)# interface ethernet 1/4
switch(config-if)#
```

This example shows how to enter configuration mode for a host interface on a Fabric Extender:

```
switch(config)# interface ethernet 101/1/1
switch(config-if)#
```

Related Commands

Command	Description
interface vethernet	Configures a virtual Ethernet interface.
show fex	Displays all configured Fabric Extender chassis connected to the switch.

Send comments to nexus5k-docfeedback@cisco.com

Command	Description
show interface ethernet	Displays various parameters of an Ethernet IEEE 802.3 interface.
speed	Sets the speed on the interface.
vtp (interface)	Enables VLAN Trunking Protocol (VTP) on an interface.

Send comments to nexus5k-docfeedback@cisco.com

interface ethernet (Layer 3)

To configure a Layer 3 Ethernet IEEE 802.3 routed interface, use the **interface ethernet** command.

interface ethernet [*chassis_ID*] *slot*/*port*[*.subintf-port-no*]

Syntax Description

<i>chassis_ID</i>	(Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. Note This argument is not optional when addressing the host interfaces of a Cisco Nexus 2000 Series Fabric Extender.
<i>slot</i>	Slot from 1 to 3. The following list defines the slots available: - Slot 1 includes all the fixed ports. A Fabric Extender only has one slot. - Slot 2 includes the ports on the upper expansion module (if populated). - Slot 3 includes the ports on the lower expansion module (if populated).
<i>port</i>	Port number within a particular slot. The port number is from 1 to 128.
.	(Optional) Specifies the subinterface separator.
<i>subintf-port-no</i>	(Optional) Port number for the subinterface. The range is from 1 to 48.

Command Default

None

Command Modes

Global configuration mode
Interface configuration mode

Command History

Release	Modification
5.0(3)N1(1)	This command was introduced.

Usage Guidelines

You must use the **no switchport** command in the interface configuration mode to configure the interface as a Layer 3 routed interface. When you configure the interface as a Layer 3 interface, all Layer 2 specific configurations on this interface are deleted.

Use the **switchport** command to convert a Layer 3 interface into a Layer 2 interface. When you configure the interface as a Layer 2 interface, all Layer 3 specific configurations on this interface are deleted.

Examples

This example shows how to enter configuration mode for a Layer 3 Ethernet interface 1/5:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)# ip address 10.1.1.1/24
switch(config-if)#
```

Send comments to nexus5k-docfeedback@cisco.com

This example shows how to configure a Layer 3 subinterface for Ethernet interface 1/5 in the global configuration mode:

```
switch(config)# interface ethernet 1/5.2
switch(config-if)# no switchport
switch(config-subif)# ip address 10.1.1.1/24
switch(config-subif)#
```

This example shows how to configure a Layer 3 subinterface in interface configuration mode:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)# interface ethernet 1/5.1
switch(config-subif)# ip address 10.1.1.1/24
switch(config-subif)#
```

This example shows how to convert a Layer 3 interface to a Layer 2 interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)# ip address 10.1.1.1/24
switch(config-if)# switchport
switch(config-if)#
```

Related Commands

Command	Description
bandwidth	Sets the bandwidth parameters for an interface.
delay	Configures the interface throughput delay value.
encapsulation	Sets the encapsulation type for an interface.
ip address	Sets a primary or secondary IP address for an interface.
inherit	Assigns a port profile to an interface.
interface vethernet	Configures a virtual Ethernet interface.
no switchport	Configures an interface as a Layer 3 interface.
service-policy	Configures a service policy for an interface.
show fex	Displays all configured Fabric Extender chassis connected to the switch.
show interface ethernet	Displays various parameters of an Ethernet IEEE 802.3 interface.

Send comments to nexus5k-docfeedback@cisco.com

interface loopback

To create a loopback interface and enter interface configuration mode, use the **interface loopback** command. To remove a loopback interface, use the **no** form of this command.

interface loopback *number*

no interface loopback *number*

Syntax Description	<i>number</i>	Interface number; valid values are from 0 to 1023.
---------------------------	---------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.0(3)N1(1)	This command was introduced.

Usage Guidelines	Use the interface loopback command to create or modify loopback interfaces.
	From the loopback interface configuration mode, the following parameters are available: • description—Provides a description of the purpose of the interface. • ip—Configures IP features, such as the IP address for the interface, Address Resolution Protocol (ARP) attributes, load balancing, Unicast Reverse Path Forwarding (RPF) or IP Source Guard. • logging—Configure logging of events. • shutdown—Shut down traffic on the interface.
	This command does not require a license.

Examples	This example shows how to create a loopback interface: <pre>switch(config)# interface loopback 50 switch(config-if)# ip address 10.1.1.1/24 switch(config-if)#</pre>
-----------------	---

Related Commands	Command	Description
	show interface loopback	Displays information about the traffic on the specified loopback interface.

Send comments to nexus5k-docfeedback@cisco.com

interface mgmt

To enter the management interface configuration mode, use the **interface mgmt** command.

interface mgmt *mgmt-intf-num*

Syntax Description	<i>mgmt-intf-num</i>	Management interface number. The interface number is 0.
--------------------	----------------------	---

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to enter the management interface configuration mode:
----------	--

```
switch# configure terminal
switch(config)# interface mgmt 0
switch(config-if)#
```

Related Commands	Command	Description
	show interface mgmt	Displays information about the management interface.
	cdp enable	Enables the Cisco Discovery Protocol (CDP) on an interface.
	description (interface)	Adds a description to an interface configuration.
	duplex	Configures the duplex mode for an interface.
	lldp (interface)	Enables the reception or transmission of Link Layer Discovery Protocol (LLDP) packets on an interface.
	rate-limit cpu direction	Configures the packet per second (PPS) rate limit for an interface.
	snmp trap link-status	Enables Simple Network Management Protocol (SNMP) link trap generation on an interface.
	speed	Configures the transmit and receive speed for an interface.
	vrf member	Adds an interface to a virtual routing and forwarding (VRF) instance.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

interface port-channel

To create an EtherChannel interface and enter interface configuration mode, use the **interface port-channel** command. To remove an EtherChannel interface, use the **no** form of this command.

interface port-channel *channel-number* [*.subintf-channel-no*]

no interface port-channel *channel-number* [*.subintf-channel-no*]

Syntax Description

<i>channel-number</i>	Channel number that is assigned to this EtherChannel logical interface. The range is from 1 to 4096.
.	(Optional) Specifies the subinterface separator.
	Note Applies to Layer 3 interfaces.
<i>subintf-channel-no</i>	(Optional) Port number of the EtherChannel subinterface. The range is from 1 to 4093.
	Note Applies to Layer 3 interfaces.

Command Default

None

Command Modes

Global configuration mode
Interface configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
5.0(3)N1(1)	Support for Layer 3 interfaces and subinterfaces was added.

Usage Guidelines

A port can belong to only one channel group.

When you use the **interface port-channel** command for Layer 2 interfaces, follow these guidelines:

- If you are using CDP, you must configure it only on the physical interface and not on the EtherChannel interface.
- If you do not assign a static MAC address on the EtherChannel interface, a MAC address is automatically assigned. If you assign a static MAC address and then later remove it, the MAC address is automatically assigned.
- The MAC address of the EtherChannel is the address of the first operational port added to the channel group. If this first-added port is removed from the channel, the MAC address comes from the next operational port added, if there is one.

You must use the **no switchport** command in the interface configuration mode to configure the EtherChannel interface as a Layer 3 interface. When you configure the interface as a Layer 3 interface, all Layer 2 specific configurations on this interface are deleted.

Send comments to nexus5k-docfeedback@cisco.com

Use the **switchport** command to convert a Layer 3 EtherChannel interface into a Layer 2 interface. When you configure the interface as a Layer 2 interface, all Layer 3 specific configurations on this interface are deleted.

You can configure one or more subinterfaces on a port channel made from routed interfaces.

Examples

This example shows how to create an EtherChannel group interface with channel-group number 50:

```
switch(config)# interface port-channel 50
switch(config-if)#
```

This example shows how to create a Layer 3 EtherChannel group interface with channel-group number 10:

```
switch(config)# interface port-channel 10
switch(config-if)# no switchport
switch(config-if)# ip address 192.0.2.1/24
switch(config-if)#
```

This example shows how to configure a Layer 3 EtherChannel subinterface with channel-group number 1 in interface configuration mode:

```
switch(config)# interface port-channel 10
switch(config-if)# no switchport
switch(config-if)# interface port-channel 10.1
switch(config-subif)# ip address 192.0.2.2/24
switch(config-subif)#
```

This example shows how to configure a Layer 3 EtherChannel subinterface with channel-group number 20.1 in global configuration mode:

```
switch(config)# interface port-channel 20.1
switch(config-subif)# ip address 192.0.2.3/24
switch(config-subif)#
```

Related Commands

Command	Description
encapsulation	(Layer 3 interfaces) Sets the encapsulation type for an interface.
ip address	(Layer 3 interfaces) Sets a primary or secondary IP address for an interface.
no switchport	(Layer 3 interfaces) Configures an interface as a Layer 3 interface.
show interface	Displays configuration information about interfaces.
show lacp	Displays LACP information.
show port-channel summary	Displays information on the EtherChannels.
vtp (interface)	Enables VLAN Trunking Protocol (VTP) on an interface.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

interface vethernet

To enter interface configuration mode for a virtual Ethernet (vEth) interface, use the **interface vethernet** command. To remove a virtual Ethernet interface, use the **no** form of this command.

interface vethernet *veth-id*[, **vethernet** *veth-id*, ...]

no interface vethernet *veth-id*[, **vethernet** *veth-id*, ...]

Syntax Description

<i>veth-id</i>	Virtual Ethernet interface number. The range is from 1 to 1,048,575. You can specify more than one virtual Ethernet interface. Make sure you use the comma (,) separator.
----------------	--

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.

Usage Guidelines

Before you use a virtual Ethernet interface, you must enable the Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch by using the **feature vmfex** command.

You must configure a virtual Ethernet interface on each switch. The configuration in the secondary switch must be identical to that of the primary switch.

You can create a maximum of 1000 virtual Ethernet interfaces on a Cisco Nexus 5548 switch. Before you disable Adapter-FEX on the switch, make sure that you delete these interfaces. After you delete a virtual Ethernet interface, make sure that you save the running configuration of the switch to the startup configuration file.

Examples

This example shows how to enter configuration mode for virtual Ethernet interface 10:

```
switch# configure terminal
switch(config)# interface vethernet 10
switch(config-if)#
```

This example shows how to enter configuration mode for multiple virtual Ethernet interfaces:

```
switch# configure terminal
switch(config)# interface vethernet 10, vethernet 2
switch(config-if-range)#
```

This example shows how to bind an interface, configure a vEthernet access interface, assign the access VLAN for that interface, and then assign a port profile named ppVEth, and a class of service (CoS) value 3 to a virtual Ethernet interface:

Send comments to nexus5k-docfeedback@cisco.com

```
switch# configure terminal
switch(config)# port-profile type vethernet ppVEth
switch(config-port-prof)# switchport mode access
switch(config-port-prof)# service-policy type qos input my_policy1
switch(config-port-prof)# exit
switch(config)# interface vethernet 10
switch(config-if)# bind interface ethernet 1/5 channel 10
switch(config-if)# inherit port-profile ppVEth
switch(config-if)# untagged cos 3
switch(config-if)#
```

This example shows how to remove a virtual Ethernet interface:

```
switch# configure terminal
switch(config)# no interface vethernet 2
switch(config)#
```

Related Commands

Command	Description
bind	Binds an interface to a virtual Ethernet interface.
feature vmfex	enables VM-FEX on the switch.
port-profile	Configures a port profile.
show interface ethernet	Displays information about Ethernet interfaces.
show interface vethernet	Displays various parameters of a virtual Ethernet interface.
show running-config interface	Displays the running configuration of an interface.
vethernet auto-create	Sets the default policy to enable auto creation of virtual Ethernet interfaces.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

interface vlan

To create a VLAN interface and enter interface configuration mode, use the **interface vlan** command. To remove a VLAN interface, use the **no** form of this command.

interface vlan *vlan-id*

no interface vlan *vlan-id*

Syntax Description

<i>vlan-id</i>	VLAN to set when the interface is in access mode; valid values are from 1 to 4094, except for the VLANs reserved for the internal switch use.
----------------	---

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.

Usage Guidelines

Before you use this command, enable the interface-vlan feature by using the **feature interface-vlan** command.

Use the **interface vlan** command to create or modify VLAN interfaces.

The VLAN interface is created the first time that you enter the **interface vlan** command for a particular VLAN. The *vlan-id* argument corresponds to the VLAN tag that is associated with the data frames on an IEEE 802.1Q-encapsulated trunk, or the VLAN ID that is configured for an access port.

This command does not require a license.

Examples

This example shows how to create a VLAN interface for VLAN 50:

```
switch(config)# interface vlan 50
switch(config-if)#
```

Related Commands

Command	Description
feature interface-vlan	Enables the ability to create VLAN interfaces.
show interface vlan	Displays information about the traffic on the specified VLAN interface.

Send comments to nexus5k-docfeedback@cisco.com

ip igmp snooping (EXEC)

To enable Internet Group Management Protocol (IGMP), use the **ip igmp snooping** command. To disable IGMP snooping, use the **no** form of this command.

ip igmp snooping

no ip igmp snooping

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	IGMP snooping is enabled.
------------------------	---------------------------



Note

If the global setting is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Examples	This example shows how to enable IGMP snooping: <pre>switch# ip igmp snooping</pre>
-----------------	--

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information and configuration.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

ip igmp snooping (VLAN)

To configure Internet Group Management Protocol (IGMP) on a VLAN, use the **ip igmp snooping** command. To negate the command or return to the default settings, use the **no** form of this command

ip igmp snooping *parameter*

no ip igmp snooping *parameter*

Syntax Description

<i>parameter</i>	Parameter to configure. See the “Usage Guidelines” section for additional information.
------------------	--

Command Default

The default settings are as follows:

- **explicit-tracking**—enabled
- **fast-leave**—disabled for all VLANs
- **last-member-query-interval** *seconds*—1
- **querier** *IP-address*—disabled
- **report-suppression**—enabled

Command Modes

VLAN configuration mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
5.1(3)N1(1)	Support for this command was introduced for the Cisco Adapter Fabric Extender (Adapter-FEX).

Usage Guidelines

[Table 1](#) lists the valid values for *parameter*.

Table 1 IGMP Snooping Parameters

Keyword and Argument	Description
explicit-tracking	Enables tracking IGMPv3 membership reports for each port on a per-VLAN basis. The default is enabled on all VLANs.
fast-leave	Enables IGMPv3 snooping fast-leave processing. The default is disabled for all VLANs.
last-member-query-interval <i>seconds</i>	Removes the group if no hosts respond to an IGMP query message. Valid value is from 1 to 25 seconds. The default is 1 second.
mrouter interface <i>interface</i>	Configures a static connection to a multicast router. The specified interface is Ethernet or EtherChannel.

Send comments to nexus5k-docfeedback@cisco.com

Table 1 *IGMP Snooping Parameters (continued)*

Keyword and Argument	Description
querier <i>IP-address</i>	Configures a snooping querier. The IP address is used as the source in messages. The default is disabled.
report-suppression	Limits the membership report traffic sent to multicast-capable routers. When you disable report suppression, all IGMP reports are sent as is to multicast-capable routers. The default is enabled.
static-group <i>group-ip-addr</i> [source <i>source-ip-addr</i>] interface <i>interface</i>	Configures an interface belonging to a VLAN as a static member of a multicast group. The specified interface is Ethernet or EtherChannel, or virtual Ethernet.

Examples

This example shows how to configure IGMP snooping parameters for VLAN 5:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# ip igmp snooping last-member-query-interval 3
switch(config-vlan)# ip igmp snooping querier 192.168.2.106
switch(config-vlan)# ip igmp snooping explicit-tracking
switch(config-vlan)# ip igmp snooping fast-leave
switch(config-vlan)# ip igmp snooping report-suppression
switch(config-vlan)# ip igmp snooping mrouter interface ethernet 1/10
switch(config-vlan)# ip igmp snooping static-group 192.0.2.1 interface ethernet 1/10
switch(config-vlan)# ip igmp snooping static-group 192.0.2.12 interface vethernet 4/1
switch(config-vlan)#
```

Related Commands

Command	Description
show ip igmp snooping	Displays the IGMP snooping information and configuration.

Send comments to nexus5k-docfeedback@cisco.com