



Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5000 Series NX-OS Unicast Routing Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page xxiii](#)
- [Supported Switches, page xxiii](#)
- [Organization, page xxiv](#)
- [Document Conventions, page xxv](#)
- [Related Documentation, page xxvi](#)
- [Obtaining Documentation and Submitting a Service Request, page xxviii](#)

Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

Supported Switches

This section includes the following topics:

- [Cisco Nexus 5000 Platform Switches, page xxiii](#)
- [Cisco Nexus 5500 Platform Switches, page xxiv](#)

Cisco Nexus 5000 Platform Switches

[Table 1](#) lists the Cisco switches supported in the Cisco Nexus 5000 Platform.



Note

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

Send comments to nexus5k-docfeedback@cisco.com

Table 1 Supported Cisco Nexus 5000 Platform Switches

Switch	Description
Cisco Nexus 5010 Switch	The Cisco Nexus 5010 is a 1 rack unit (RU) switch. It delivers 500 Gbps of wire-speed switching capacity designed for traditional, virtualized, unified, and high-performance computing (HPC) environments.
Cisco Nexus 5020 Switch	The Cisco Nexus 5020 is a 2 rack unit (RU) switch. It delivers 1+ Tbps of wire-speed switching capacity designed for traditional, virtualized, unified, and HPC environments.



Note

The Cisco Nexus 5000 Platform switches only supports Internet Group Management Protocol (IGMP) snooping. IGMP, Protocol Independent Multicast (PIM), and Multicast Source Discovery Protocol (MSDP) are not supported on the Cisco Nexus 5000 Platform switches.

Cisco Nexus 5500 Platform Switches

Table 2 lists the Cisco switches supported in the Cisco Nexus 5500 Platform.



Note

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:
http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

Table 2 Supported Cisco Nexus 5500 Platform Switches

Switch	Description
Cisco Nexus 5548P Switch	The Cisco Nexus 5548P switch is the first switch in the Cisco Nexus 5500 Platform. It is a one-rack-unit (1 RU), 10-Gigabit Ethernet and Fibre Channel over Ethernet (FCoE) switch that offers up to 960-Gbps throughput and up to 48 ports.
Cisco Nexus 5596P Switch	The Cisco Nexus 5596P switch is a top-of-rack, 10-Gigabit Ethernet and FCoE switch offering up to 1920-Gigabit throughput and up to 96 ports.

Organization

This document is organized as follows:

Send comments to nexus5k-docfeedback@cisco.com

Chapter Title	Description
New and Changed Information	Describes the new and changed information for the new Cisco NX-OS software releases.
BGP Commands	Describes the Cisco NX-OS Border Gateway Protocol (BGP) commands.
EIGRP Commands	Describes the Cisco NX-OS Enhanced Interior Gateway Routing Protocol (EIGRP) commands.
HSRP Commands	Describes the Cisco NX-OS Hot Standby Router Protocol (HSRP) commands.
Layer 3 Interfaces Commands	Describes the Cisco NX-OS Layer 3 interfaces commands.
Object Tracking Commands	Describes the Cisco NX-OS object tracking commands.
OSPF Commands	Describes the Cisco NX-OS Open Shortest Path First (OSPF) commands.
RIP Commands	Describes the Cisco NX-OS Routing Information Protocol (RIP) commands.
Unicast RIB and FIB Commands	Describes the Cisco NX-OS unicast Routing Information Base (RIB) and the Forwarding Information Base (FIB) commands.
VRRP Commands	Describes the Cisco NX-OS Virtual Router Redundancy Protocol (VRRP) commands.

Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
{x y z}	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

screen font	Terminal sessions and information that the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Send comments to nexus5k-docfeedback@cisco.com

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means reader *be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extender is available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

The following are related Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender documents:

Release Notes

Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Release Notes

Cisco Nexus 5000 Series Switch Release Notes

Configuration Guides

Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 5.0(2)N1(1)

Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 4.2(1)N1(1) and Release 4.2(1)N2(1)

Cisco Nexus 5000 Series NX-OS Fibre Channel over Ethernet Configuration Guide

Cisco Nexus 5000 Series NX-OS Layer 2 Switching Configuration Guide

Cisco Nexus 5000 Series NX-OS Multicast Routing Configuration Guide

Cisco Nexus 5000 Series NX-OS Quality of Service Configuration Guide

Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide

Cisco Nexus 5000 Series NX-OS Security Configuration Guide

Cisco Nexus 5000 Series NX-OS System Management Configuration Guide

Cisco Nexus 5000 Series NX-OS Unicast Routing Configuration Guide

Cisco Nexus 5000 Series Switch NX-OS Software Configuration Guide

Cisco Nexus 5000 Series Fabric Manager Configuration Guide, Release 3.4(1a)

Cisco Nexus 7000 Series NX-OS Fundamentals Configuration Guide, Release 6.x

Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide

Send comments to nexus5k-docfeedback@cisco.com

Maintain and Operate Guides

Cisco Nexus 5000 Series NX-OS Operations Guide

Installation and Upgrade Guides

Cisco Nexus 5000 Series and Cisco Nexus 5500 Platform Hardware Installation Guide

Cisco Nexus 2000 Series Hardware Installation Guide

Cisco Nexus 5000 Series NX-OS Software Upgrade and Downgrade Guide, Release 4.2(1)N1(1)

Regulatory Compliance and Safety Information for the Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders

Licensing Guide

Cisco NX-OS Licensing Guide

Command References

Cisco Nexus 5000 Series NX-OS FabricPath Command Reference

Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference

Cisco Nexus 5000 Series NX-OS Fibre Channel Command Reference

Cisco Nexus 5000 Series NX-OS Fundamentals Command Reference

Cisco Nexus 5000 Series NX-OS Layer 2 Interfaces Command Reference

Cisco Nexus 5000 Series NX-OS Multicast Routing Command Reference

Cisco Nexus 5000 Series NX-OS QoS Command Reference

Cisco Nexus 5000 Series NX-OS Security Command Reference

Cisco Nexus 5000 Series NX-OS System Management Command Reference

Cisco Nexus 5000 Series NX-OS TrustSec Command Reference

Cisco Nexus 5000 Series NX-OS Unicast Routing Command Reference

Cisco Nexus 5000 Series NX-OS vPC Command Reference

Technical References

Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender MIBs Reference

Error and System Messages

Cisco NX-OS System Messages Reference

Send comments to nexus5k-docfeedback@cisco.com

Troubleshooting Guide

Cisco Nexus 5000 Troubleshooting Guide

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.