



V Commands

This chapter describes the Cisco NX-OS object tracking commands that begin with V.

vrf member

To add an interface to a virtual routing and forwarding (VRF) instance or to configure object tracking on a VRF instance, use the **vrf member** command. To remove the object tracking for this route, use the **no** form of this command.

vrf member *vrf-name*

no vrf member *vrf-name*

Syntax Description	<i>vrf-name</i>	VRF name. The name can be any case-sensitive, alphanumeric string up to 32 characters.
---------------------------	-----------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode Object tracking configuration mode
----------------------	--

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines	Use the vrf member command in object tracking configuration mode to track objects in a nondefault VRF.
-------------------------	---

Examples This example shows how to track an IP route in VRF Red:

```
switch(config)# track 1 ip route 10.10.10.0/8 reachability
switch(config-track)# vrf member Red
switch(config-track)#
```

This example shows how to add the Ethernet interface 1/5 to VRF RemoteOfficeVRF:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)# vrf member RemoteOfficeVRF
switch(config-if)#
```

Related Commands	Command	Description
	show ip eigrp	Displays Enhanced Interior Gateway Routing Protocol (EIGRP) information.
	show ip ospf interface	Displays Open Shortest Path First (OSPF) interface-related information.
	show ip rip	Displays a summary of RIP information for all RIP instances.

Command	Description
show track	Displays information about object tracking.
track ip route	Tracks an interface.

