

T Commands

This chapter describes the Cisco NX-OS Virtual Router Redundancy Protocol (VRRP) commands that begin with T.

track (VRRP)

To modify the priority for a virtual router based on a tracked object, use the **track** command. To disable priority tracking for a virtual router, use the **no** form of this command.

track object-number [decrement value]

no track object-number [decrement value]

Syntax Description

object-number	Number for a configured tracked object. The range is from 1 to 500.
decrement value	(Optional) Decrements the VRRP priority if the tracked object is down. The range is from 1 to 254.

Command Default

None

Command Modes

VRRP configuration mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

Use the **track** (**VRRP**) command to change the priority of the virtual router based on the state of a configured tracked object. Use the track command to configure the tracked object. When the tracked object is down, the priority reverts to the priority value for the virtual router. When the tracked object is up, the priority of the virtual router is restored to the original value.

This command does not require a license.

Examples

This example shows how to enable object tracking for a virtual router:

switch# configure terminal
switch(config)# track 33 ip route 192.0.2.0/24 reachability
switch(config)# interface ethernet 2/1
switch(config-if)# no switchport
switch(config-if)# vrrp 250
switch(config-if-vrrp)# track 33 priority 2
switch(config-if-vrrp)#

Related Commands

Command	Description
feature vrrp	Enables VRRP.
show vrrp	Displays VRRP configuration information.

Command	Description
track interfave (VRRP)	Tracks the state of an interface and modifies the VRRP priority if that interface state goes down.
vrrp	Configures a VRRP group.

track interface (VRRP)

To track the priority for a virtual router based on an interface, use the **track interface** command. To disable priority tracking for a virtual router, use the **no** form of this command.

track interface {ethernet slot/port | port-channel number[.sub_if_number]} priority value

no track interface {ethernet slot/port | **port-channel** number[.sub_if_number]} **priority** value

Syntax Description

ethernet slot/port	Specifies the virtual router interface for which to track the priority. The slot number is from 1 to 255, and the port number is from 1 to 128.
port-channel number	Specifies the port-channel group for which to track priority. The range is from 1 to 4096
sub_if-number	(Optional) Subinterface number. The range is from 1 to 4093.
priority value	Specifies the interface priority for a virtual router. The range of values is from 1 to 254. If this router is the owner of the IP addresses, the value is automatically set to 254.

Command Default

Disabled

Command Modes

VRRP configuration mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

Use the **track** command to change the priority of the virtual router based on the state of another interface in the switch. When the tracked interface is down, the priority reverts to the priority value for the virtual router. When the tracked interface is up, the priority of the virtual router is restored to the interface state tracking value.



Interface state tracking will not be operational unless you enable preemption on the interface.

This command does not require a license.

Examples

This example shows how to enable interface state tracking for a virtual router:

```
switch# configure terminal
switch(config)# interface ethernet 2/1
switch(config-if)# no switchport
switch(config-if)# vrrp 250
switch(config-if-vrrp)# track interface ethernet 2/2 priority 2
switch(config-if-vrrp)#
```

Related Commands

Command	Description
feature vrrp	Enables VRRP.
show vrrp	Displays VRRP configuration information.
track (VRRP)	Tracks an object to modify the VRRP priority.
vrrp	Configures a VRRP group.

track interface (VRRP)