



Cisco ME 3400E Ethernet Access Switch Show Platform Commands

This appendix describes the **show platform** privileged EXEC commands that have been created or changed for use with the Cisco ME 3400E Ethernet Access switch. These commands display information helpful in diagnosing and resolving internetworking problems and should be used only under the guidance of Cisco technical support staff.

show platform acl

Use the **show platform acl** privileged EXEC command to display platform-dependent access control list (ACL) manager information.

show platform acl {interface interface-id | label label-number [detail] | statistics asic-number |
usage asic-number [summary] | vlan vlan-id} [| {begin | exclude | include} expression]

Syntax Description	interface interface-id	Display per-interface ACL manager information for the specified interface. The interface can be a physical interface or a VLAN.
	label label-number [detail]	Display per-label ACL manager information. The <i>label-number</i> range is 0 to 255. The keyword has this meaning:
		• detail —(Optional) Display detailed ACL manager label information.
	statistics asic-number	Display per-ASIC ACL statistics. The <i>asic-number</i> is the port ASIC number, always 0.
	usage asic-number [summary]	Display per-ASIC ACL usage. The <i>asic-number</i> is the port ASIC number, always 0. The keyword has this meaning:
		• summary —(Optional) Display brief usage information.
	vlan vlan-id	Display per-VLAN ACL manager information. The <i>vlan-id</i> range is from 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform backup interface

Use the **show platform backup interface** privileged EXEC command to display platform-dependent backup information used in a Flex Links configuration.

show platform backup interface [interface-id | dummyQ] [| {begin | exclude | include}
expression]

Syntax Description	interface-id	(Optional) Display backup information for all interfaces or the specified interface. The interface can be a physical interface or a port channel.
	dummyQ	(Optional) Display dummy queue information.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command Modes	Release	Modification
		Modification This command was introduced.
	Release 12.2(44)EY You should use this while troubleshooti you to do so.	

show platform cfm

Use the **show platform cfm** privileged EXEC command to display platform-dependent Ethernet Connectivity Fault Management (CFM) information. CFM is an end-to-end per-service-instance Ethernet layer operation, administration, and management (OAM) protocol that provides proactive connectivity monitoring, fault verification, and fault isolation for large Ethernet networks.

show platform cfm [| {begin | exclude | include} expression]

	·	
Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines	while troubleshooting you to do so.	ommand only when you are working directly with a technical support representative g a problem. Do not use this command unless a technical support representative asks sensitive. For example, if you enter exclude output , the lines that contain <i>output</i>
	are not displayed bu	t the lines that contain <i>Output</i> are displayed.

show platform configuration

show platform configuration

Use the **show platform configuration** privileged EXEC command to display platform-dependent configuration-manager related information.

show platform configuration {config-output | default | running | startup} [| {begin | exclude |
include} expression]

Syntax Description	config-output	Display the output of the last auto-configuration application.
	default	Display whether or not the system is running the default configuration.
	running	Display a snapshot of the backed-up running configuration on the local switch.
	startup	Display a snapshot of the backed-up startup configuration on the local switch.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform dl

Use the **show platform dl** privileged EXEC command to display dynamically loaded module information.

show platform dl [detail] [| {begin | exclude | include} expression]

Syntax Description	detail	(Optional) Display detailed dynamically loaded module information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
Command History	Release 12.2(44)EY	Modification This command was introduced.
Command History Usage Guidelines	12.2(44)EY You should use this co	

show platform etherchannel

Use the **show platform etherchannel** privileged EXEC command to display platform-dependent EtherChannel information.

show platform etherchannel {flags | time-stamps} [| {begin | exclude | include} expression]

Syntax Description	flags	Display EtherChannel port flags.
	time-stamps	Display EtherChannel time stamps.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		command only when you are working directly with a technical support representative and a problem. Do not use this command unless a technical support representative asks

show platform forward

Use the **show platform forward** privileged EXEC command for an interface to specify how the hardware would forward a frame that matches the specified parameters.

show platform forward interface-id [vlan vlan-id] src-mac dst-mac [l3protocol-id] [sap | snap]
[cos cos] [ip src-ip dst-ip [frag field] [dscp dscp] {l4protocol-id | icmp icmp-type icmp-code |
igmp igmp-version igmp-type | tcp src-port dst-port flags | udp src-port dst-port} [| {begin |
exclude | include} expression]

Syntax Description	interface-id	The input physical interface, the port on which the packet comes in to the switch (including type and port number).
	vlan vlan-id	(Optional) Input VLAN ID. The range is 1 to 4094. If not specified, and the input interface is not a routed port, the default is 1.
	src-mac	48-bit source MAC address.
	dst-mac	48-bit destination MAC address.
	l3protocol-id	(Optional) The Layer 3 protocol used in the packet. The number is a value 0 to 65535.
	sap	(Optional) Service access point (SAP) encapsulation type.
	snap	(Optional) Subnetwork Access Protocol (SNAP) encapsulation type.
	cos cos	(Optional) Class of service (CoS) value of the frame. The range is 0 to 7
	ip src-ip dst-ip	(Optional, but required for IP packets) Source and destination IP addresses in dotted decimal notation.
	frag field	(Optional) The IP fragment field for a fragmented IP packet. The range is 0 to 65535.
	dscp dscp	(Optional) Differentiated Services Code Point (DSCP) field in the IP header. The range is 0 to 63.
	l4protocol-id	The numeric value of the Layer 4 protocol field in the IP header. The range is 0 to 255. For example, 47 is generic routing encapsulation (GRE), and 89 is Open Shortest Path First (OSPF). If the protocol is TCP, UDP, ICMP, or IGMP, you should use the appropriate keyword instead of a numeric value.
	icmp <i>icmp-type</i> <i>icmp-code</i>	Internet Control Message Protocol (ICMP) parameters. The <i>icmp-type</i> and <i>icmp-code</i> ranges are 0 to 255.
	igmp igmp-version igmp-type	Internet Group Management Protocol (IGMP) parameters. The <i>igmp-version</i> range is 1 to 15; the <i>igmp-type</i> range is 0 to 15.
	tcp src-port dst-port flags	TCP parameters: TCP source port, destination port, and the numeric value of the TCP flags byte in the header. The <i>src-port</i> and <i>dst-port</i> ranges are 0 to 65535. The flag range is from 0 to 1024.
	udp src-port dst-port	User Datagram Protocol (UDP) parameters. The <i>src-port</i> and <i>dst-port</i> ranges are 0 to 65535.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

<u>)</u> Note

Though visible in the command-line help strings, the **ipv6** keyword is not supported.

Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		command only when you are working directly with a technical support representative ng a problem. Do not use this command unless a technical support representative asks
	-	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear.
Examples		ooting" chapter of the software configuration guide for this release for examples of forward command output displays and what they mean.

show platform frontend-controller

Use the **show platform frontend-controller** privileged EXEC command to display counter and status information for the front-end controller manager and subordinate applications and to display the hardware and software information for the front-end controller.

show platform frontend-controller {buffer | generic | manager number | subordinate number |
version number} [| {begin | exclude | include} expression]

Syntax Description	buffer	Display the last 1024 bytes sent from the manager to the subordinate and the reverse.
	generic	Display the generic counters that do not specifically apply to the manager or subordinate.
	manager number	Display the counters for the manager and the subordinate specified by <i>number</i> . See the "Usage Guidelines" section for the <i>number</i> range.
	subordinate number	Display the subordinate status and the counters for the subordinate specified by <i>number</i> . See the "Usage Guidelines" section for the <i>number</i> range.
	version number	Display the hardware and software version information for the subordinate status specified by <i>number</i> . The range is from 0 to 1.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		nmand only when you are working directly with a technical support representative problem. Do not use this command unless a technical support representative asks
	-	nsitive. For example, if you enter exclude output , the lines that contain <i>output</i> ines that contain <i>Output</i> appear.

show platform ip igmp snooping

Use the **show platform ip igmp snooping** privileged EXEC command to display platform-dependent Internet Group Management Protocol (IGMP) snooping information.

show platform ip igmp snooping {all | control [di] | counters | flood [vlan vlan-id] | group
ip-address | hardware | retry [count | local [count] | remote [count]]} [| {begin | exclude |
include} expression]

Syntax Description	all	Display all IGMP snooping platform IP multicast information.
	control [di]	Display IGMP snooping control entries. The keyword has this meaning:
		• di —(Optional) Display IGMP snooping control destination index entries.
	counters	Display IGMP snooping counters.
	flood [vlan vlan-id]	Display IGMP snooping flood information. The keyword has this meaning:
		• vlan <i>vlan-id</i> —(Optional) Display flood information for the specified VLAN. The range is 1 to 4094.
	group ip-address	Display the IGMP snooping multicast group information, where <i>ip-address</i> is the IP address of the group.
	hardware	Display IGMP snooping information loaded into hardware.
	retry [count local [count]	Display IGMP snooping retry information. The keywords have these meanings:
		• count —(Optional) Display only the retry count.
		• local—(Optional) Display local retry entries.
	remote [count]	Display remote entries. The keyword has this meaning:
		• count —(Optional) Display only the remote count.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes Privile

Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform ip multicast

Use the **show platform ip multicast** privileged EXEC command to display platform-dependent IP multicast tables and other information.

show platform ip multicast {acl-full-info | counters | groups | hardware [detail] | interfaces |
 locks | mdfs-routes | retry | trace} [| {begin | exclude | include} expression]

Syntax Description	acl-full-info	Display IP multicast routing access-control list (ACL) information, in particular the number of outgoing VLANs for which router ACLs at the
		output cannot be applied in hardware.
	counters	Display IP multicast counters and statistics.
	groups	Display IP multicast routes per group.
	hardware [detail]	Display IP multicast routes loaded into hardware. The optional detail keyword is used to show port members in the destination index and route index.
	interfaces	Display IP multicast interfaces.
	locks	Display IP multicast destination-index locks.
	mdfs-routes	Display multicast distributed fast switching (MDFS) IP multicast routes.
	retry	Display the IP multicast routes in the retry queue.
	trace	Display the IP multicast trace buffer.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		mmand only when you are working directly with a technical support representative a problem. Do not use this command unless a technical support representative asks
	-	ensitive. For example, if you enter exclude output , the lines that contain <i>output</i> lines that contain <i>Output</i> appear.

show platform ip unicast

Use the **show platform ip unicast** privileged EXEC command to display platform-dependent IP unicast routing information.

Syntax Description	adjacency	Display the platform adjacency database.
	cef-idb	Display platform information corresponding to Cisco Express Forwarding (CEF) interface descriptor block.
	counts	Display the current counts for the Layer 3 unicast databases.
	dhcp	Display the DHCP system dynamic addresses.
	failed {adjacency	Display the hardware resource failures. The keywords have these meanings
	arp [A.B.C.D] route}	• adjacency —Display the adjacency entries that failed to be programmed in hardware.
		• arp —Display the Address Resolution Protocol (ARP) deletions because of failure and because of retries.
		• <i>A.B.C.D</i> —(Optional) Prefix of the ARP entries to display.
		• route —Display the route entries that failed to be programmed in hardware.
	loadbalance	Display the platform load balancing database.
	mpaths	Display the Layer 3 unicast routing multipath adjacency database.
	route	Display the platform route database.
	standby	Display the platform standby information.
	statistics	Display the Layer 3 unicast routing accumulated statistics.
	trace	Display the platform event trace logs.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.



Though visible in the command-line help strings, the proxy and table keywords are not supported.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative

while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform ipc trace

Use the **show platform ipc trace** privileged EXEC command to display platform-dependent Interprocess Communication (IPC) Protocol trace log information.

show platform ipc trace [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		ommand only when you are working directly with a technical support representative g a problem. Do not use this command unless a technical support representative asks
	Expressions are case	sensitive. For example, if you enter exclude output, the lines that contain <i>output</i>

do not appear, but the lines that contain Output appear.

Cisco ME 3400E Ethernet Access Switch Command Reference

show platform ipv6 unicast

Use the **show platform ipv6 unicast** privileged EXEC command to display platform-dependent IPv6 unicast routing information.

show platform ipv6 unicast {adjacency [ipv6-prefix] | backwalk {adjacency | loadbalance} |
compress ipv6-prefix/prefix length | interface | loadbalance | mpath | retry {adjacency |
route} | route [ipv6-prefix/prefix length | tcam] [detail] | statistics | table [detail] | trace}
[I {begin | exclude | include} expression]

Note

This command is available only if the switch is running the metro IP access image and you have configured a dual IPv4 and IPv6 Switch Database Management (SDM) template on the switch.

Syntax Description	adjacency	Display IPv6 adjacency information for the switch or for the specified IPv6 network.
	ipv6-prefix	(Optional) The IPv6 network to be displayed. The address must be specified in hexadecimal using 16-bit values between colons.
	backwalk {adjacency	Display IPv6 backwalk information.
	loadbalance}	• adjacency —Display adjacency backwalk information.
		• loadbalance—Display backwalk load-balance information.
	compress	Display IPv6 prefix compression information.
	ipv6-prefix/prefix	• <i>ipv6-prefix</i> —The IPv6 network.
	length	• <i>/prefix length</i> —The length of the IPv6 network prefix. A decimal value from 0 to 128 that shows how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.
	interface	Display IPv6 interface information.
	loadbalance	Display IPv6 load-balance information
	mpath	Display IPv6 multipath information
	retry {adjacency	Display IPv6 retry information.
	route}	• adjacency —Display IPv6 adjacency retry information.
		• route—Display IPv6 route retry information.
	route	Display IPv6 route information.
	tcam	(Optional) Display the IPv6 hardware route table information.
	detail	(Optional) Display detailed IPv6 route information.
	statistics	Display IPv6 accumulated statistics.
	table	Display IPv6 unicast table information.
	trace	Display IPv6 unicast traces.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(50)SE	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform l2pt dm

Use the **show platform l2pt dm** privileged EXEC command to display Layer 2 protocol tunneling destination maps and associated ports.

show platform l2pt dm [| {begin | exclude | include} expression]

		
Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXE	C
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines	while troublesho you to do so.	his command only when you are working directly with a technical support representative boting a problem. Do not use this command unless a technical support representative asks
	-	case sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> ut the lines that contain <i>Output</i> appear.

show platform layer4op

Use the **show platform layer4op** privileged EXEC command to display platform-dependent Layer 4 operator information.

show platform layer4op {acl | qos [port-asic]} {and-or | map | or-and | vcu} [| {begin | exclude | include} expression]

Syntax Description	acl	Display access control list (ACL) Layer 4 operators information.
-,	qos [port-asic]	Display quality of service (QoS) Layer 4 operators information. The keyword has this meaning:
		• <i>port-asic</i> —(Optional) QoS port ASIC number. The value can be 0 or 1.
	and-or	Display AND-OR registers information.
	map	Display select map information.
	or-and	Display OR-AND registers information.
	vcu	Display value compare unit (VCU) register information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines	while troubleshoo you to do so. Expressions are c	is command only when you are working directly with a technical support representative oting a problem. Do not use this command unless a technical support representative asks ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i>
	do not appear, but	t the lines that contain Output appear.

show platform mac-address-table

Use the **show platform mac-address-table** privileged EXEC command to display platform-dependent MAC address table information.

show platform mac-address-table [aging-array | hash-table | mac-address mac-address] [vlan vlan-id]] [| {begin | exclude | include} expression]

Syntax Description	aging-array	(Optional) Display the MAC address table aging array.
oyntax bescription		
	hash-table	(Optional) Display the MAC address table hash table.
	mac-address mac-address	(Optional) Display the MAC address table MAC address information, where <i>mac-address</i> is the 48-bit hardware address.
	vlan vlan-id	(Optional) Display information for the specified VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

show platform messaging

Use the **show platform messaging** privileged EXEC command to display platform-dependent application and performance message information.

show platform messaging {application [incoming | outgoing | summary] | hiperf
[class-number]} [| {begin | exclude | include} expression]

Syntax Description	application [incoming outgoing summary]	Display application message information. The keywords have these meanings:
		• incoming —(Optional) Display only information about incoming application messaging requests.
		• outgoing —(Optional) Display only information about incoming application messaging requests.
		• summary —(Optional) Display summary information about all application messaging requests.
	hiperf [class-number]	Display outgoing high-performance message information. Specify the <i>class-number</i> option to display information about high-performance messages for this class number. The range is 0 to 36.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

show platform monitor

Use the **show platform monitor** privileged EXEC command to display platform-dependent Switched Port Analyzer (SPAN) information.

show platform monitor [session session-number] [| {begin | exclude | include} expression]

Syntax Description	session session-number	(Optional) Display SPAN information for the specified SPAN session. The range is 1 to 66.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Commond History	Polooso	Medification
Command History	Release 12.2(44)EY	Modification This command was introduced.

show platform mvr table

Use the **show platform mvr table** privileged EXEC command to display the platform-dependent Multicast VLAN Registration (MVR) multi-expansion descriptor (MED) group mapping table.

show platform mvr table [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
	exclude	exclude (Optional) Display excludes lines that match the <i>expression</i> .		
	include	(Optional) Display includes lines that match the specified <i>expression</i> .		
	expression	Expression in the output to use as a reference point.		
Command Modes	Privileged EXEC			
Command History	Release	Modification		
	12.2(44)EY	This command was introduced.		
Usage Guidelines		command only when you are working directly with a technical support representative g a problem. Do not use this command unless a technical support representative asks		
	Expressions are case	e sensitive. For example, if you enter exclude output, the lines that contain output		

do not appear, but the lines that contain Output appear.

Cisco ME 3400E Ethernet Access Switch Command Reference

show platform pm

Use the **show platform pm** privileged EXEC command to display platform-dependent port-manager information.

show platform pm {counters | group-masks | idbs {active-idbs | deleted-idbs} | if-numbers |
 link-status | platform-block | port-info interface-id | vlan {info | line-state}
 [| {begin | exclude | include} expression]

Syntax Description	counters	Display module counters information.			
	group-masks	Display EtherChannel group masks information.			
	idbs {active-idbs deleted-idbs}	Display interface data block (IDB) information. The keywords have thes meanings:			
		• active-idbs—Display active IDB information.			
		• deleted-idbs —Display deleted and leaked IDB information.			
	if-numbers	Display interface numbers information.			
	link-status	Display local port link status information.			
	platform-block	Display platform port block information.			
	port-info interface-id	Display port administrative and operation fields for the specified interface.			
	vlan {info line-state}	Display platform VLAN information. The keywords have these meanings:			
		• info —Display information for active VLANs.			
		• line-state —Display line-state information.			
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .			
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .			
	include	(Optional) Display includes lines that match the specified expression.			
	expression	Expression in the output to use as a reference point.			
Note	Though visible in the cor	nmand-line help strings, the stack-view keyword is not supported.			
Command Modes	Privileged EXEC				
Command History	Release	Modification			
	12.2(44)EY	This command was introduced.			

Usage Guidelines

You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform policer cpu

Use the **show platform policer cpu** privileged EXEC command to display CPU control-plane policer statistics per feature or the indexes and the corresponding feature for the specified port.

show platform policer cpu {classification | interface interface-id} [| {begin | exclude | include}
expression]

Syntax Description	classification	Displays policer statistics per feature.	
	interface	Display the policer indexes for a specific interface.	
	interface-id		
	begin	(Optional) Display begins with the line that matches the expression.	
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
	include	(Optional) Display includes lines that match the specified <i>expression</i> .	
	expression	Expression in the output to use as a reference point.	
Command Modes	Privileged EXE	С	
Command History	Release	Modification	
	12.2(44)EY	This command was introduced.	
Usage Guidelines	switch pre-alloc a policer of 26 r value of 0 to 25 policer value of	tion of user network interfaces (UNIs) and enhanced network interfaces (ENIs), the ates the 27 CPU protection policers, numbered 0 to 26. On the ME 3400E-24TS switch, neans a drop policer; any traffic type shown as 26 on any port is dropped. A policer of a means that a rate-limiting policer is assigned to the port for the control protocol. A 255 means that no policer is assigned to a control protocol. Network node interfaces policers assigned.	
	For the ME 3400EG-12CS and ME 34000EG-2CS switches, a policer of 4 means a drop policer. A traffic type shown as 4 on a port is dropped. A policer value of 0 to 3 means that a rate-limiting policer is assigned to the port for the protocol.		
	-	case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> d, but the lines that contain <i>Output</i> are displayed.	

Examples

Note

This is an example of output from the **show platform policer cpu classification** command:

Unless otherwise indicated, the examples are for an ME 3400E-24TS switch.

Switch# show platform p	-	fication
SWITCH 1		
Feature	Bytes	Frames
STP LACP	3912792 0	 61278 0
8021X RSVD_STP	0	0
_ PVST_PLUS CDP	0 1012542	0 2552
DTP UDLD	131264 0	2051 0
PAGP VTP	0 0	0 0
CISCO_L2 KEEPALIVE	0 0	0 0
CFM SWITCH_MAC	0 0	0 0
SWITCH_ROUTER_MAC SWITCH_IGMP	896 289408	14 4522
SWITCH_L2PT	0	0

This example of the output from the **show platform policer cpu interface** command shows the default policer configuration for a UNI. Because the port is Fast Ethernet 1, the identifier for rate-limited protocols is 0; a display for Fast Ethernet port 5 would display an identifier of 4. The *Policer Index* refers to the specific protocol. The ASIC number indicates when the policer is on a different ASIC.

Because UNIs do not support STP, CDP, LLDP, LACP, and PAgP, these packets are dropped (physical policer of 26). These protocols are disabled by default on ENIs as well, but you can enable them. When enabled on ENIs, the control packets are rate-limited and a rate-limiting policers is assigned to the port for these protocols (physical policer of 22).

 ${\tt Switch}\#$ show platform policer cpu interface fastethernet 0/3

Policers assigned for CPU protection

			======
Feature	Policer Index	Physical Policer	Asic Num
			=======
Fa0/1			
STP	1	26	0
LACP	2	26	0
8021X	3	26	0
RSVD_STP	4	26	0
PVST_PLUS	5	26	0
CDP	6	26	0
LLDP	7	26	0
DTP	8	26	0
UDLD	9	26	0
PAGP	10	26	0
VTP	11	26	0
CISCO_L2	12	26	0
KEEPALIVE	13	0	0
CFM	14	255	0
SWITCH_MAC	15	26	0
SWITCH_ROUTER_MAC	16	26	0

SWITCH_IGMP	17	0	0
SWITCH_L2PT	18	26	0

This example shows the policers assigned to a ENI when control protocols are enabled on the interface. A value of 22 indicates that protocol packets are rate-limited for that protocol. When the protocol is not enabled, the defaults are the same as for a UNI.

Switch# show platform policer cpu interface fastethernet0/23

Policers assigned for CPU protection

rorroorb abbrghoa ror oro	processi		
		=======================================	:=======
Feature	Policer	Physical	Asic
	Index	Policer	Num
		=======================================	=======
Fa0/23			
STP	1	26	0
LACP	2	22	0
8021X	3	26	0
RSVD_STP	4	26	0
PVST_PLUS	5	26	0
CDP	6	22	0
LLDP	7	26	0
DTP	8	26	0
UDLD	9	26	0
PAGP	10	26	0
VTP	11	26	0
CISCO_L2	12	22	0
KEEPALIVE	13	22	0
CFM	14	255	0
SWITCH_MAC	15	26	0
SWITCH_ROUTER_MAC	16	26	0
SWITCH_IGMP	17	22	0
SWITCH_L2PT	18	22	0

This example shows rate limiting on a ME 3400EG-12CS or ME 34000EG-2CS switch. A value of 1 shows that protocol packets are rate limited for that protocol.

Policers assigned for CPU pro	otection		
Feature	Policer Index	Physical Policer	===== Asic Num
=======================================		================================	======
Gi0/2			
STP	1	4	0
LACP	2	4	0
8021X	3	4	0
RSVD_STP	4	1	0
PVST_PLUS	5	4	0
CDP	6	4	0
LLDP	7	4	0
DTP	8	4	0
UDLD	9	4	0
PAGP	10	4	0
VTP	11	4	0
CISCO_L2	12	4	0
KEEPALIVE	13	1	0
CFM	14	255	0
SWITCH_MAC	15	4	0
SWITCH_ROUTER_MAC	16	4	0
SWITCH_IGMP	17	1	0
SWITCH_L2PT	18	4	0

Switch **#show platform policer cpu interface gigabitethernet 0/2**

This example shows the default policers assigned to NNIs. Most protocols have no policers assigned to NNIs. A value of 255 means that no policer is assigned to the port for the protocol.

Switch **#show platform policer cpu interface gigabitethernet 0/1** Policers assigned for CPU protection

	=======================================	=======================================	
Feature	Policer	Physical	Asic
	Index	Policer	Num
			======
Gi0/1			
STP	1	255	0
LACP	2	255	0
8021X	3	255	0
RSVD_STP	4	255	0
PVST_PLUS	5	255	0
CDP	6	255	0
LLDP	7	255	0
DTP	8	255	0
UDLD	9	255	0
PAGP	10	255	0
VTP	11	255	0
CISCO_L2	12	255	0
KEEPALIVE	13	255	0
CFM	14	255	0
SWITCH_MAC	15	255	0
SWITCH_ROUTER_MAC	16	255	0
SWITCH_IGMP	17	255	0
SWITCH_L2PT	18	255	0

 S
 Command
 Description

 show policer cpu uni-eni
 Displays control-plane policer information for the switch.

show platform port-asic

Use the show platform port-asic privileged EXEC command to display platform-dependent port
application-specific integrated circuit (ASIC) register information.

show platform port-asic {cpu-queue-map-table [asic number | port number [asic number]] |
 dest-map index number | etherchannel-info [asic number | port number [asic number]] |
 exception [asic number | port number [asic number]] | global-status [asic number |
 port number [asic number]] | learning [asic number | port number [asic number]] |
 mac-info [asic number | port number [asic number]] | mvid [asic number] |
 packet-info-ram [asic number | index number [asic number]] |
 port-info [asic number | port number [asic number]] |
 port-info [asic number | port number [asic number]] |
 prog-parser [asic number | port number [asic number]] |
 receive {buffer-queue | port-fifo | supervisor-sram } [asic number | port number [asic number]] |
 stats {drop | enqueue | miscellaneous | supervisor } [asic number | port number [asic number]] |
 transmit {port-fifo | queue | supervisor-sram } [asic number | port number [asic number]] |
 vct [asic number | port number [asic number]] {
 [t [begin | exclude | include } expression]
 }
}

Syntax Description	cpu-queue-map-table [asic number port number [asic number]]	Display the CPU queue-map table entries. The keywords have these meanings:
		• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.
		• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27.
	dest-map index number	Display destination-map information for the specified index. The range is 0 to 65535.
	etherchannel-info [asic number port number [asic number]]	Display the contents of the EtherChannel information register. The keywords have these meanings:
		• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
		• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
	exception [asic number port number [asic number]]	Display the exception-index register information. The keywords have these meanings:
		• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
		• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.

global-status [asic number port number [asic number]]	Display global and interrupt status. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
learning [asic number port number [asic number]]	Display entries in the learning cache. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
mac-info [asic number port number [asic number]]	Display the contents of the MAC information register. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
mvid [asic number]	Display the mapped VLAN ID table. The keyword has this meaning:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
packet-info-ram [asic number index number [asic number]]	Display the packet information RAM. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• index <i>number</i> —(Optional) Display information for the specified packet RAM index number and ASIC number. The range is 0 to 63.
port-info [asic number port number [asic number]]	Display port information register values. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.

prog-parser [asic number port number [asic number]]	Display the programmable parser tables. The keywords have these meanings:
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
receive { buffer-queue port-fifo	Display receive information. The keywords have these meanings:
<pre>supervisor-sram { [asic number port number [asic number]]</pre>	• buffer-queue —Display the buffer queue information.
port number [asic number]]	• port-fifo —Display the port-FIFO information.
	• supervisor-sram —Display the supervisor static RAM (SRAM) information.
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.
span [vlan-id asic number]	Display the Switched Port Analyzer (SPAN)-related information. The keywords have these meanings:
	• <i>vlan-id</i> —(Optional) Display information for the specified VLAN. The range is 0 to 1023.
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
stats {drop enqueue miscellaneous supervisor } [asic	Display raw statistics for the port ASIC. The keywords have these meanings:
number port number [asic	• drop —Display drop statistics.
number]]	• enqueue—Display enqueue statistics.
	• miscellaneous —Display miscellaneous statistics.
	• supervisor —Display supervisor statistics.
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The number is always 0.
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.

transmit {port-fifo queue	 Display transmit information. The keywords have these meanings: port-fifo—Display the contents of the port-FIFO information register. 	
<pre>supervisor-sram } [asic number port number [asic number]]</pre>		
	• queue —Display the contents of the queue information register.	
	• supervisor-sram —Display supervisor SRAM information.	
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.	
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.	
vct [asic number port number [asic number]]	Display the VLAN compression table entries for the specified ASIC or for the specified port and ASIC. The keywords have these meanings:	
	• asic <i>number</i> —(Optional) Display information for the specified ASIC. The range is 0 to 1.	
	• port <i>number</i> —(Optional) Display information for the specified port and ASIC number. The range is 0 to 27, where 0 is the supervisor and 1 to 25 are the ports.	
l begin	(Optional) Display begins with the line that matches the <i>expression</i> .	
exclude	(Optional) Display excludes lines that match the expression.	
l include	(Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Note

Though visible in the command-line help strings, the **stack** {**control** | **dest-map** | **learning** | **messages** | **mvid** | **prog-parser** | **span** | **stats** [**asic** *number* | **port** *number* [**asic** *number*]] keywords are not supported.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform port-security

Use the **show platform port-security** privileged EXEC command to display platform-dependent port-security information.

show platform port-security [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines	You should use th	is command only when you are working directly with your technical support
Usaye duluennes	representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.	
	Expressions are c	ase sensitive. For example, if you enter exclude output, the lines that contain output

do not appear, but the lines that contain Output appear.

Cisco ME 3400E Ethernet Access Switch Command Reference

show platform qos

Use the **show platform qos** privileged EXEC command to display platform-dependent quality of service (QoS) information.

show platform qos debug [aggregate-policer aggregate-policer.name | global-config |
input-queue | [interface [interface-id] [buffers | policers | queuing]] | label-table
[dynamic-label {dscp value cos value | label-number value | policy-map policy-map-name
class-map class-map-name } [asic number] | policer {parameter-table | qos-table|
selection-table} [asic number] | policy-map policy-map-name [asic number] | port-class [asic
number] | port-config port-number [asic number] | port-info port-number [asic number] |
table-map | vlan vlan-id] [| {begin | exclude | include} expression]

show platform qos statistics [interface [interface-id]] [| {**begin** | **exclude** | **include**} expression]

Syntax Description	debug	Display QoS debug messages for the switch or for the specified keyword.
	aggregate-policer aggregate-policer-name	(Optional) Display QoS aggregate policer information for the specified aggregate policer.
	global-config	(Optional) Display QoS global configuration information.
	input-queue	(Optional) Display QoS input queue information.
	interface [interface-id] [buffers policers queuing]	(Optional) Display QoS information for all interfaces or the specified interface. The keywords have these meanings:
		• buffers —(Optional) Display information about QoS buffers.
		• policers —(Optional) Display information about QoS policers.
		• queuing —(Optional) Display information about QoS output queues.
	label-table [dynamic-label { dscp <i>value</i> cos <i>value</i> label-number <i>value</i> policy-map <i>policy-map-name</i> class-map <i>class-map-name</i> } [asic <i>number</i>]	(Optional) Display Qos label table information. The keywords have these meanings:
		• dynamic-label —(Optional) Display dynamic label information.
		• dscp <i>value</i> cos <i>value</i> —Display information based on Differentiated Services Code Point (DSCP) value (0 to 63) and class of service (CoS) value (0 to 7).
		• label-number <i>value</i> —Display information based on the dynamic label number. The range is from 158 to 255.
		• policy-map <i>policy-map-name</i> class-map <i>class-map-name</i> —Display information for the specified policy map and class map.
		• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.

<pre>policer {parameter-table qos-table selection-table } [asic number]</pre>		
	• parameter-table —Display the policer parameter table.	
	• qos-table —Display the policer QoS table.	
	• selection-table —Display the port allocation table.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
policy-map <i>policy-map-name</i> [asic <i>number</i>]	(Optional) Display QoS information for the specified policy map.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
port-class [asic number]	(Optional) Display QoS port class tables.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
port-config port-number [asic number]	(Optional) Display QoS port configuration information. The keywords have these meanings:	
	• <i>port-number</i> —Display QoS configuration for the specified port number. The range is 0 to 25.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
port-info port-number [asic number]	(Optional) Display QoS port information. The keywords have these meanings:	
	• <i>port-number</i> —Display QoS configuration for the specified port number. The range is 0 to 25.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
table-map <i>table-map-name</i> [asic <i>number</i>]	(Optional) Display QoS information for the specified table map.	
	• asic <i>number</i> —(Optional) Display information based on the port ASIC number. The number is always 0.	
vlan vlan-id	(Optional) Display QoS information for the specified VLAN. The range is 1 to 4094.	
statistics	Display QoS interface statistics.	
begin	(Optional) Display begins with the line that matches the <i>expression</i> .	
exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
include	(Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes Privil

Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show platform resource-manager

Use the **show platform resource-manager** privileged EXEC command to display platform-dependent resource-manager information.

show platform resource-manager {dm [index number] | erd [index number] |
mad [index number] | med [index number] | mod | msm {hash-table [vlan vlan-id] |
mac-address mac-address [vlan vlan-id]} | sd [index number] | vld [index number]} [| {begin
| exclude | include} expression]

Syntax Description	dm [index number]	Display the destination map. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	erd [index number]	Display the equal-cost-route descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	mad [index number]	Display the MAC-address descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	med [index number]	Display the multi-expansion descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	mod	Display the resource-manager module information.
	msm {hash-table [vlan vlan-id] mac-address mac-address [vlan vlan-id]}	Display the MAC-address station descriptor table. The keywords have these meanings:
		• hash-table—Display the msm hash table.
		• mac-address <i>mac-address</i> —Display the table for the specified MAC address.
		• vlan <i>vlan-id</i> —(Optional) Display the table for the specified VLAN. The range is 1 to 4094.
	sd [index number]	Display the station descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	vld [index number]	Display the VLAN-list descriptor table for the specified index. The keyword has this meaning:
		• index <i>number</i> —(Optional) Display the specified index. The range is 0 to 65535.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .

	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
Command History	Release 12.2(44)EY	Modification This command was introduced.

show platform snmp counters

Use the **show platform snmp counters** privileged EXEC command to display platform-dependent Simple Network Management Protocol (SNMP) counter information.

show platform snmp counters [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		is command only when you are working directly with your technical support ile troubleshooting a problem. Do not use this command unless your technical support is you to do so.
	Expressions are ca	ase sensitive. For example, if you enter exclude output, the lines that contain output

do not appear, but the lines that contain Output appear.

Cisco ME 3400E Ethernet Access Switch Command Reference

OL-16486-02

show platform spanning-tree synchronization

Use the **show platform spanning-tree synchronization** privileged EXEC command to display platform-dependent spanning-tree state synchronization information.

show platform spanning-tree synchronization [detail | vlan vlan-id] [| {begin | exclude |
 include} expression]

Syntax Description	detail	(Optional) Display detailed spanning-tree synchronization information.
	vlan vlan-id	(Optional) Display spanning-tree synchronization information for the specified VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command History	Release	Modification
Command History	Release 12.2(44)EY	Modification This command was introduced.

Cisco ME 3400E Ethernet Access Switch Command Reference

show platform status

Use the **show platform status** privileged EXEC command to display platform-dependent status information.

show platform status [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines		s command only when you are working directly with a technical support representative ting a problem. Do not use this command unless a technical support representative asks

do not appear, but the lines that contain Output appear.

Cisco ME 3400E Ethernet Access Switch Command Reference

show platform stp-instance

Use the **show platform stp-instance** privileged EXEC command to display platform-dependent spanning-tree instance information.

show platform stp-instance vlan-id [| {begin | exclude | include} expression]

Syntax Description	vlan-id	Display spanning-tree instance information for the specified VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
	Dalaasa	
Command History	Release	Modification
Command History	12.2(44)EY	This command was introduced.

show platform tcam

Use the **show platform tcam** privileged EXEC command to display platform-dependent ternary content addressable memory (TCAM) driver information.

- show platform tcam {handle number | log-results | table {acl | all | equal-cost-route | local |
 mac-address | multicast-expansion | qos | secondary | station | vlan-list } | usage } [asic
 number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail
 [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude
 | include } expression]
- show platform tcam table acl [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table all [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table equal-cost-route [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table local [asic number [detail [invalid]] | [index number [detail [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table mac-address [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table qos [asic number [detail [invalid]] | [index number [detail [invalid]] |
 invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail [invalid]]
 | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table secondary [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table station [asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]
- show platform tcam table vlan-list [[asic number [detail [invalid]] | [index number [detail
 [invalid]] | invalid | num number [detail [invalid]] | invalid] | [invalid] | [num number [detail
 [invalid]] | invalid]] [| {begin | exclude | include} expression]

Syntax Description	handle number	Display the TCAM handle. The range is 0 to 4294967295.
	log-results	Display the TCAM log results.

table {acl all equal-cost-route ipv6 {acl qos secondary}	Display lookup and forwarding table information. The keywords have these meanings:
local mac-address qos secondary station vlan-list }	• acl —Display the access-control list (ACL) table.
secondary + station + vian-list}	• all—Display all the TCAM tables.
	• equal-cost-route—Display the equal-cost-route table.
	• local—Display the local table.
	• mac-address—Display the MAC-address table.
	• qos —Display the QoS table.
	• secondary —Display the secondary table.
	• station —Display the station table.
	• vlan-list—Display the VLAN list table.
usage	Display the CAM and forwarding table usage.
[[asic number [detail [invalid]]	Display information. The keywords have these meanings:
[index number [detail [invalid]] invalid num number [detail [invalid]] invalid] [invalid]	• asic <i>number</i> —Display information for the specified ASIC device ID. The range is 0 to 15.
[num number [detail [invalid]]	• detail [invalid]—(Optional) Display valid or invalid details.
invalid]]	• index <i>number</i> —(Optional) Display information for the specified TCAM table index. The range is 0 to 32768.
	• num <i>number</i> —(Optional) Display information for the specified TCAM table number. The range is 0 to 32768.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Note

Though visible in the command-line help strings, the **ipv6**, **multicast-expansion** and **usage** keywords are not supported.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

OL-16486-02

show platform vlan

Use the **show platform vlan** privileged EXEC command to display platform-dependent VLAN information.

show platform vlan {mapping | misc | mvid | refcount | rpc {receive | transmit}} [| {begin | exclude | include} expression]

Syntax Description	mapping	See the show platform vlan mapping command.
	misc	Display miscellaneous VLAN module information.
	mvid	Display the mapped VLAN ID (MVID) allocation information.
	refcount	Display the VLAN lock module-wise reference counts.
	rpc {receive transmit}	Display remote procedure call (RPC) messages. The keywords have these meanings:
		• receive —Display received information.
		• transmit —Display sent information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Note

Though visible in the command-line help strings, the prune keyword is not supported.

Command Modes

Privileged EXEC

Command History	Release	Modification
	12.2(44)EY	This command was introduced.

Usage Guidelines

You should use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

show platform vlan mapping

Use the **show platform vlan mapping** privileged EXEC command to display platform-dependent VLAN mapping information.

Syntax Description	interface-id	(Optional) Enter the physical interface ID or port channel number. Port channel range is form 1 to 48.
	vlan-id	(Optional) Display information for the original VLAN on the wire, the customer VLAN ID (C-VLAN). VLAN ID range is from 1 to 4094.
	handle handle-id	(Optional) Display the VLAN mapping handle details. The handle-ID range is from 0 to 65535.
	usage	(Optional) Display the VLAN mapping hardware resource usage.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(44)EY	This command was introduced.
Usage Guidelines	Use this command when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.	
	Expressions are case sensitive. For example, if you enter exclude output, the lines that contain <i>output</i> do not appear, but the lines that contain <i>Output</i> appear.	
Examples	These are examples of output from the show platform vlan mapping command:	
	Switch# show platform vlan mapping fastethernet 0/1 Platform Vlan Mapping Information	
	Interface Fa0/1: 1-to-1 option: 0 cvlan: 10 cvlanlist: 10 cinnervlan: spvlan: 100 spinnervlan: ingress block:	0 (0) 0

egress block: 10 hw state: on-hold ingress handle: 0, egress handle: 1 ingress block handle: 2, egress block handle: 3 Switch# show platform vlan mapping handle 1 Platform Vlan Mapping Information _____ Handle number: 1 Type: 1-to-1 Asic: 0 Region: Match 1 vlan First entry: 977 Number of entries: 1 Index TCAM ENTRY TCAM MASK DESCRIPTOR 977 7C006400 00000000 FE0FFF00 00004000 8010100A 0000000 Stat handle: 1 Packets: 0, Bytes: 0 Switch# show platform vlan mapping usage Platform Vlan Mapping Information _____ Port ASIC 0 Region Name | Min | Start | End | Used | Avail | Total | Percentage _____

 Loopback
 *
 0
 0
 6
 0
 6
 0%

 Drop
 0
 6
 492
 0
 486
 486
 0%

 Match 2 vlans
 0
 492
 976
 0
 484
 484
 0%

 Match 1 vlan
 0
 976
 1460
 2
 482
 484
 0%

 Default operations 104 1460 1564 0 104 Vlan blocking 0 1564 2048 2 482 104 0% Vlan blocking 0 1564 2048 2 482 484 08 _____ _____ _____ * = region needs compacting Section Total Start | End | Used | Avail | Total | Percentage 0 2048 4 2044 2048 0%

show platform vlan mapping