



CHAPTER 1

Using Cisco TelePresence Recording Server CLI Commands

September 2010

Contents

- [Introduction, page 1-1](#)
- [Starting a CLI Session, page 1-1](#)
- [CLI Command Basics, page 1-2](#)
- [Ending a CLI Session, page 1-2](#)

Introduction

This chapter explains how to use the Cisco TelePresence Recording Server (CTRS) command line interface (CLI).

Starting a CLI Session

You can access the CTRS CLI through the physical console or remotely. If you want to access the CTRS CLI remotely, use Secure Shell (SSH) from a personal computer or workstation to connect securely to CTRS.

You will need the following to log in to CTRS:

- CTRS IP address
- Admin ID and password



Note

The admin ID and password can be changed from the default in the Cisco Unified Communications Manager (Unified CM) for CTRS device page.

To start a CLI session:

Step 1 From a remote system, use SSH to connect securely to CTRS. In the SSH client, enter the following information: `ssh adminname@IP Address`

- `adminname` is the Admin ID
- `IP Address` is the IP address of CTRS

Step 2 When the system prompts you, enter the password.

Step 3 The CLI prompt displays. You can now enter any command.



Note The prompt will always be “admin.”

CLI Command Basics

- Enter the beginning of a command and press **Tab** to have the system complete the command for you.
- Enter a full command and press **Tab** to display all commands or subcommands that are available. If you press **Tab** and the current command line repeats, no additional syntax is available.
- To get detailed help, enter **help** *command name* at the prompt.
- To get command syntax for a particular command, enter *command name?* at the prompt.

Ending a CLI Session

To end a CLI session:

Step 1 At the prompt, enter **quit**.
