



CHAPTER 3

Maintaining the Server

This chapter describes how to diagnose server system problems using LEDs. It also provides information about how to install or replace hardware components, and it includes the following sections:

- [Server Monitoring and Management Tools, page 3-1](#)
- [Status LEDs and Buttons, page 3-2](#)
- [Preparing for Server Component Installation, page 3-6](#)
- [Installing or Replacing Server Components, page 3-11](#)

Server Monitoring and Management Tools

Cisco Integrated Management Interface (CIMC)

You can monitor the server inventory, health, and system event logs by using the built-in Cisco Integrated Management Controller (CIMC) GUI or CLI interfaces. See the user documentation for your firmware release at the following URL:

http://www.cisco.com/en/US/products/ps10739/products_installation_and_configuration_guides_list.html

Server Configuration Utility

Cisco has also developed the Cisco Server Configuration Utility for C-Series servers, which can aid and simplify the following tasks:

- Monitoring server inventory and health
- Diagnosing common server problems with diagnostic tools and logs
- Setting the BIOS booting order
- Configuring some RAID configurations
- Installing operating systems

This utility is available to order on an optional 16-GB USB thumb drive (see [Overview of the Pre-Loaded 16-GB Cisco USB Flash Drive, page 3-44](#)). You can also download the ISO from Cisco.com. See the user documentation for your version of the utility at the following URL:

http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html

Status LEDs and Buttons


This section describes the location and meaning of LEDs and buttons and includes the following topics

- [Front Panel LEDs, page 3-2](#)
- [Rear Panel LEDs and Buttons, page 3-4](#)

Front Panel LEDs

Figure 3-1 shows the front panel LEDs. Table 3-1 defines the front panel LED states.

Figure 3-1 Front Panel LEDs



1	Hard drive fault LED	6	Fan status LED
2	Hard drive activity LED	7	System status LED
3	Network link activity LED	8	Identification button/LED
4	Power supply status LED	9	Power button/power status LED
5	Temperature status LED		—

Table 3-1 Front Panel LEDs, Definitions of States

LED Name	State
Hard drive fault	<ul style="list-style-type: none"> • Off—The hard drive is operating properly. • Amber—This hard drive has failed. • Amber, blinking—The device is rebuilding.
Hard drive activity	<ul style="list-style-type: none"> • Off—There is no hard drive in the hard drive sled (no access, no fault). • Green—The hard drive is ready. • Green, blinking—The hard drive is reading or writing data.
Network link activity	<ul style="list-style-type: none"> • Off—The Ethernet link is idle. • Green—One or more Ethernet LOM ports are link-active, but there is no activity. • Green, blinking—One or more Ethernet LOM ports are link-active, with activity.


Table 3-1 *Front Panel LEDs, Definitions of States (continued)*

LED Name	State
Power supply status	<ul style="list-style-type: none"> Green—All power supplies are operating normally. Amber, steady—One or more power supplies are in a degraded operational state. Amber, blinking—One or more power supplies are in a critical fault state.
Temperature status	<ul style="list-style-type: none"> Green—The server is operating at normal temperature. Amber, steady—One or more temperature sensors have exceeded a warning threshold. Amber, blinking—One or more temperature sensors have exceeded a critical threshold.
Fan status	<ul style="list-style-type: none"> Green—All fan modules are operating properly. Amber, steady—One fan module has failed. Amber, blinking—Critical fault, two or more fan modules have failed.
System status	<ul style="list-style-type: none"> Green—The server is running in normal operating condition. Green, blinking—The server is performing system initialization and memory check. Amber, steady—The server is in a degraded operational state. For example: <ul style="list-style-type: none"> Power supply redundancy is lost. CPUs are mismatched. At least one CPU is faulty. At least one DIMM is faulty. At least one drive in a RAID configuration failed. Amber, blinking—The server is in a critical fault state. For example: <ul style="list-style-type: none"> Boot failed. Fatal CPU and/or bus error is detected. Server is in over-temperature condition.
Identification	<ul style="list-style-type: none"> Off—The Identification LED is not in use. Blue—The Identification LED is activated.
Power button/Power status LED	<ul style="list-style-type: none"> Off—There is no AC power to the server. Amber—The server is in standby power mode. Power is supplied only to the CIMC and some motherboard functions. Green—The server is in main power mode. Power is supplied to all server components.

Rear Panel LEDs and Buttons

Figure 3-2 shows the rear panel LEDs and buttons. Table 3-2 defines the LED states.

Figure 3-2 Rear Panel LEDs and Buttons



1	Power supply fault LED	5	10/100/1000 Ethernet dedicated management link status LED
2	Power supply AC OK LED	6	10/100/1000 Ethernet dedicated management link speed LED
3	1-Gb Ethernet link speed LED	7	Identification button/LED
4	1-Gb Ethernet link status LED		—

Table 3-2 Rear Panel LEDs, Definitions of States

LED Name	State
Power supply fault	<ul style="list-style-type: none"> Off—The power supply is operating normally. Amber, blinking—An event warning threshold has been reached, but the power supply continues to operate. Amber, solid—A critical fault threshold has been reached, causing the power supply to shut down (for example, a fan failure or an over-temperature condition).
Power supply AC OK	<ul style="list-style-type: none"> Off—There is no AC power to the power supply. Green, blinking—AC power OK, DC output not enabled. Green, solid—AC power OK, DC outputs OK.
1-Gb Ethernet link speed	<ul style="list-style-type: none"> Off—link speed is 10 Mbps. Amber—link speed is 100 Mbps. Green—link speed is 1 Gbps.
1-Gb Ethernet link status	<ul style="list-style-type: none"> Off—No link is present. Green—Link is active. Green, blinking—Traffic is present on the active link.
10/100/1000 Ethernet dedicated management link speed	<ul style="list-style-type: none"> Off—link speed is 10 Mbps. Amber—link speed is 100 Mbps. Green—link speed is 1 Gbps.

Table 3-2 *Rear Panel LEDs, Definitions of States (continued)*

LED Name	State
10/100/1000 Ethernet dedicated management link status	<ul style="list-style-type: none">• Off—No link is present.• Green—Link is active.• Green, blinking—Traffic is present on the active link.
Identification	<ul style="list-style-type: none">• Off—The Identification LED is not in use.• Blue—The Identification LED is activated.

Preparing for Server Component Installation

This section describes how to prepare for component installation, and it includes the following topics:

- [Required Equipment, page 3-6](#)
- [Shutting Down and Powering Off the Server, page 3-6](#)
- [Removing and Replacing the Server Top Cover, page 3-7](#)
- [Removing and Replacing the Front Chassis Panel, page 3-8](#)
- [Replaceable Component Locations, page 3-9](#)
- [Serial Number Location, page 3-9](#)

Required Equipment

The following equipment is used to perform the procedures in this chapter:

- Number 2 Phillips-head screwdriver
- Electrostatic discharge (ESD) strap or other grounding equipment such as a grounded mat

Shutting Down and Powering Off the Server

The server can run in two power modes:

- Main power mode—Power is supplied to all server components and any operating system on your drives can run.
- Standby power mode—Power is supplied only to the service processor and the cooling fans and it is safe to power off the server from this mode.

You can invoke a graceful shutdown or an hard shutdown by using either of the following methods:

- Use the CIMC management interface.
- Use the **Power** button on the server front panel. To use the **Power** button, follow these steps:

-
- Step 1** Check the color of the Power Status LED (see the [“Front Panel LEDs” section on page 3-2](#)).
- Green—the server is in main power mode and must be shut down before it can be safely powered off. Go to [Step 2](#).
 - Amber—the server is already in standby mode and can be safely powered off. Go to [Step 3](#).

- Step 2** Invoke either a graceful shutdown or a hard shutdown:



Caution

To avoid data loss or damage to your operating system, you should always invoke a graceful shutdown of the operating system.

- Graceful shutdown—Press and release the **Power** button. The operating system performs a graceful shutdown and the server goes to standby mode, which is indicated by an amber Power Status LED.
- Emergency shutdown—Press and hold the **Power** button for 4 seconds to force the main power off and immediately enter standby mode.

- Step 3** Disconnect the power cords from the power supplies in your server to completely power off the server.
-

Removing and Replacing the Server Top Cover

To remove or replace the top cover of the server, follow these steps:



Tip

You do not have to remove the cover to replace hard drives or power supplies.

Step 1 Remove the top cover (see [Figure 3-3](#)).

- a. Loosen the two captive thumbscrews that secure the rear edge of the top cover to the chassis.
- b. Push the top cover toward the server rear about one-half inch (1.27 cm), until it stops.
- c. Lift the top cover straight up from the server and set it aside.

Step 2 Replace the top cover:

- a. Place the cover on top of the server about one-half inch (1.27 cm) behind the lip of the front chassis panel. The cover should sit flat.




Note

The rear of the cover has a wrap-around flanged edge that must be correctly aligned with the chassis rear edge when sliding the cover forward.

- b. Slide the top cover toward the front chassis panel until it stops.
- c. Tighten the two captive thumbscrews that secure the rear edge of the cover to the chassis.

Figure 3-3 Removing the Top Cover or Front Chassis Panel



1	Front chassis panel	3	Top cover
2	Front chassis panel securing screws (three)	4	Top cover thumbscrews (two)

Removing and Replacing the Front Chassis Panel

To remove or replace the front chassis panel of the server, follow these steps:

**Tip**

Remove this panel only if you are instructed to do so in a procedure in this book.

Step 1 Remove the front chassis panel (see [Figure 3-3](#)):

- a. Remove the top cover from the server as described in [Removing and Replacing the Server Top Cover, page 3-7](#).
- b. Use a #2 Phillips-head screwdriver to remove the three screws that secure the front chassis panel to the chassis (see [Figure 3-3](#)).
- c. Push the panel forward about 1/4-inch, until it stops. The wrap-around front edge of the panel must become free from the front edge of the chassis.
- d. Lift the panel straight up from the server and set it aside.


Step 2 Replace the front chassis panel:

- a. Set the front chassis panel back in place, with its wrap-around front edge about 1/4 inch (1.27 cm) forward of the chassis front edge.
 - b. Slide the front chassis panel toward the server rear to lock it in place. The wrap-around front edge of the panel must wrap around the chassis front edge.
 - c. Replace the three screws that secure the panel to the chassis (see [Figure 3-3](#)).
 - d. Replace the top cover to the server as described in [Removing and Replacing the Server Top Cover, page 3-7](#).
-

Replaceable Component Locations

This section shows the locations of the components that are discussed in this chapter. The view in [Figure 3-4](#) is from the top down with the top cover, front chassis panel, and air baffle removed.

Figure 3-4 Replaceable Component Locations



1	Drives (hot-swappable, accessed through front panel)	8	Internal USB 2.0 port on motherboard
2	Drive backplane (optionally either 24-drive or 16-drive)	9	RTC battery on motherboard
3	SAS expander (with 24-drive backplane only)	10	PCIe riser 2 (three half-height slots)
4	Fan modules (four)	11	Trusted platform module socket on motherboard
5	DIMM slots on motherboard (twelve)	12	Power supplies (two, hot-swappable access through rear panel)
6	CPUs and heatsinks (up to two)	13	RAID backup unit mounting cage (holds up to two units)
7	PCIe riser 1 (two full-height slots)		

Serial Number Location

The serial number for the server is printed on a label on the top of the server, near the front.

Color-Coded Touch Points

This server has color-coded touch points that indicate thumbscrews and latches on replaceable and hot-swappable components.

- Hot-swappable components have green plastic touch points. This includes the internal cooling fans and the power supplies. (An exception is the drive trays on the front panel, which are hot-swappable but not green).
- Some replaceable but non-hot-swappable components have light-blue plastic touch-points.

Installing or Replacing Server Components

**Warning**

Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place.

Statement 1029

**Warning**

Class 1 laser product.

Statement 1008

**Caution**

When handling server components, wear an ESD strap to avoid damage.

**Tip**

You can press the Identification button on the front panel or rear panel to turn on a flashing Identification LED on the front and rear panels of the server. This allows you to locate the specific server that you are servicing when you go to the opposite side of the rack. You can also activate these LEDs remotely by using the CIMC interface. See the [“Status LEDs and Buttons” section on page 3-2](#) for locations of these LEDs.

This section describes how to install and replace server components, and it includes the following topics:

- [Replacing Hard Drives or Solid State Drives, page 3-12](#)
- [Replacing a Drive Backplane, page 3-14](#)
- [Replacing Fan Modules, page 3-18](#)
- [Replacing DIMMs, page 3-20](#)
- [Replacing CPUs and Heatsinks, page 3-25](#)
- [Replacing the Motherboard RTC Battery, page 3-32](#)
- [Replacing a PCIe Riser, page 3-34](#)
- [Replacing a PCIe Card, page 3-36](#)
- [Replacing a SuperCap Power Module \(RAID Backup Unit\), page 3-42](#)
- [Replacing a Cisco USB Flash Drive, page 3-44](#)
- [Installing a Trusted Platform Module, page 3-48](#)
- [Replacing a SCU Upgrade ROM Module, page 3-51](#)
- [Replacing a Software RAID Key Module, page 3-52](#)
- [Replacing Power Supplies, page 3-53](#)

Replacing Hard Drives or Solid State Drives

This section includes the following information:

- [Drive Population Guidelines](#), page 3-12
- [Drive Replacement Procedure](#), page 3-13

Drive Population Guidelines

The server is orderable in two different versions, each with one of two different front panel/backplane configurations:

- Cisco UCS C24 (small form-factor (SFF) drives, with 24-drive backplane and expander). Holds up to twenty-four 2.5-inch hard drives or solid state drives.
- Cisco UCS C24 (small form-factor (SFF) drives, with 16-drive backplane, no expander). Holds up to sixteen 2.5-inch hard drives or solid state drives.



Note When the server has the 16-drive backplane, only the first 16 drive bays are used.

- Cisco UCS C24 (large form-factor (LFF) drives, with 12-drive backplane and expander). Holds up to twelve 3.5-inch hard drives.

The drive-bay numbering is shown in [Figure 3-5](#) and [Figure 3-6](#).

Figure 3-5 Drive Numbering, Small Form Factor





Figure 3-6 Drive Numbering, Large Form Factor



Observe these drive population guidelines for optimal performance:

- When populating drives, add drives in the lowest numbered bays first (populate HDD01 first).



Note **Sixteen-drive backplane option:** If your SFF-drives server has the 16-drive backplane installed, only the first 16 drive bays are used, with population order HDD1 to HDD16. Keep blanking trays in all empty bays to ensure optimal air flow and cooling.

- Keep an empty drive blanking tray in any unused bays to ensure optimal air flow and cooling.

- You can mix hard drives and solid state drives in the same server. However, You cannot configure a logical volume (virtual drive) that contains a mix of hard drives and SSDs. That is, when you create a logical volume, it must contain all hard drives or all SSDs.



Note The LFF-drives version of the server does not support 3.5-inch solid state drives.

Drive Replacement Procedure

To replace or install a hot-pluggable drive, follow these steps:




Tip

You do not have to shut down or power off the server to replace hard drives or solid state drives (SSDs) because they are hot-pluggable.

- Step 1** Remove the drive that you are replacing or remove a blank drive tray from an empty bay:
- Press the release button on the face of the drive tray. See [Figure 3-7](#).
 - Grasp and open the ejector lever and then pull the drive tray out of the slot.
 - If you are replacing an existing drive, remove the four drive-tray screws that secure the drive to the tray and then lift the drive out of the tray.
- Step 2** Install a new drive:
- Place a new drive in the empty drive tray and replace the four drive-tray screws.
 - With the ejector lever on the drive tray open, insert the drive tray into the empty drive bay.
 - Push the tray into the slot until it touches the backplane, then close the ejector lever to lock the drive in place.

Figure 3-7 Replacing Hard Drives



1	Release button	3	Drive tray securing screws (4)
2	Ejector lever		—

Replacing a Drive Backplane

**Note**

The Small Form-Factor (24-drive or 16-drive) and Large Form-Factor (12-drive) backplanes are factory-configurable options. When replacing a backplane, you must replace it with the same version of the backplane.

To install or replace a drive backplane, follow these steps:

Step 1

Prepare the server for component replacement:

- a. Power off the server as described in the [“Shutting Down and Powering Off the Server”](#) section on [page 3-6](#).
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in [“Removing and Replacing the Server Top Cover”](#) section on [page 3-7](#).
- d. Remove the front chassis panel as described in [Removing and Replacing the Front Chassis Panel](#), [page 3-8](#).

Step 2

Remove all drives and any empty drive trays from the server.

Step 3

Disconnect all cables from the backplane.

**Tip**

Label the cables as you remove them to aid replacement.

Step 4

Disconnect all cables from the SAS expander card.

Step 5

Remove the two screws that secure the backplane assembly to the chassis floor (see [Figure 3-8](#)).

Step 6

Lift the backplane assembly, including steel tray and expander card straight up from the chassis.

Step 7

Remove the SAS expander card from the backplane assembly:

- a. Remove the three screws that secure the SAS expander to the backplane assembly steel tray (see [Figure 3-9](#)).
- b. Pull the SAS expander from the sockets on the drive backplane and then set the SAS expander aside on an antistatic surface.

Step 8

Install the SAS expander card to the new backplane assembly:

- a. Push the two connectors on the SAS expander into the two sockets on the backplane assembly.
- b. Install the three screws that secure the SAS expander to the backplane assembly steel tray (see [Figure 3-9](#)).

Step 9

Align the new backplane assembly within the chassis walls, and then lower it evenly to the chassis floor until the screw-holes in the assembly align with the corresponding screw-holes in the chassis floor.

Step 10

Install the two screws that secure the backplane assembly to the chassis floor.

Step 11


Reconnect all cables to the SAS expander.

Step 12

Reconnect all cables to the backplane.

- Step 13** Replace all drives and drives trays to the drive bays.
- Step 14** Replace the front chassis panel.
- Step 15** Replace the top cover.
- Step 16** Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Figure 3-8 Replacing the Drive Backplane



- | | |
|---------------------------------------------------|-----------------------------------------------|
| 1 Backplane assembly securing screws (two) | 2 SAS expander securing screws (three) |
|---------------------------------------------------|-----------------------------------------------|

Replacing a SAS Expander

The SAS expander is a card that plugs directly into the drive backplane. The SAS expander allows control of up to 24 drives with one RAID controller card. See [Appendix C, “RAID Controller Considerations”](#) for more information about supported RAID controllers.

**Note**

The SAS expander is required for the SFF 24-drive option and the LFF 12-drive option. The SFF 16-drive option does not use the SAS expander.

To install or replace a SAS expander, follow these steps:

Step 1

Prepare the server for component replacement:

- a. Power off the server as described in the [“Shutting Down and Powering Off the Server”](#) section on page 3-6.
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in [“Removing and Replacing the Server Top Cover”](#) section on page 3-7.
- d. Remove the front chassis panel as described in [Removing and Replacing the Front Chassis Panel](#), page 3-8.

Step 2

Disconnect all cables from the SAS expander.

**Tip**

Label the cables as you remove them to aid replacement.

Step 3

Remove the SAS expander:

- a. Remove the three screws that secure the SAS expander to the backplane assembly steel tray (see [Figure 3-9](#)).
- b. Grasp both ends of the SAS expander and pull evenly to disengage it from the sockets on the drive backplane. Do not tilt the SAS expander until it is free from the sockets on the backplane.

Step 4

Install the new SAS expander:

- a. Lower the SAS expander to its position on the backplane assembly. Return the SAS expander to a horizontal position before you begin pushing it into the backplane sockets.
- a. Evenly push the two connectors on the edge of the new SAS expander into the two sockets on the backplane. Stop when the screw-holes in the SAS expander align with the screw-holes in the backplane assembly steel tray.
- b. Install the three screws that secure the SAS expander to the backplane assembly steel tray (see [Figure 3-9](#)).

Step 5

Reconnect SAS cables to the new SAS expander.

Step 6


Replace the front chassis panel.

Step 7

Replace the top cover.

- Step 8** Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Figure 3-9 Replacing the SAS Expander



1	SAS expander securing screws (three)	—
---	--------------------------------------	---

Replacing Fan Modules

The four hot-pluggable fan modules in the server are numbered as follows when you are facing the front of the server.

Figure 3-10 Fan Module Numbering

FAN1	FAN2	FAN3	FAN4
------	------	------	------

To replace or install a hot-pluggable fan module, follow these steps:



Caution

You do not have to shut down or power off the server to replace fan modules because they are hot-pluggable. However, to maintain proper cooling, do not operate the server for more than one minute with any fan module removed.

Step 1

Remove a fan module that you are replacing (see [Figure 3-11](#)):

- a. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- b. Remove the top cover as described in “[Removing and Replacing the Server Top Cover](#)” section on [page 3-7](#).
- c. Grasp and squeeze together the two green plastic finger-latches on the top of the fan module and then lift straight up to disengage the fan from the fan tray connector.

Step 2

Install a new fan module:


- a. Set the new fan module in place, aligning the connector on the fan module with the connector on the fan tray (see [Figure 3-11](#)).



Note

The arrow on the top of the fan module should point toward the rear of server.

- b. Press down gently on the fan module until the finger-latches click and lock in place.
- c. Replace the top cover.
- d. Replace the server in the rack.

Figure 3-11 Replacing Fan Modules

1	Fan tray connector (one on each fan module)	3	Connector on underside of fan module
2	Finger latches (two on each fan module)		

Replacing DIMMs

This section includes the following topics:

- [Memory Performance Guidelines and Population Rules, page 3-20](#)
- [DIMM Replacement Procedure, page 3-23](#)

**Caution**

DIMMs and their sockets are fragile and must be handled with care to avoid damage during installation.

**Caution**

Cisco does not support 3rd-party DIMMs. Using non-Cisco DIMMs in the server might result in system problems or damage to the motherboard.

**Note**

To ensure the best server performance, it is important that you are familiar with memory performance guidelines and population rules before you install or replace memory.


Memory Performance Guidelines and Population Rules

This section describes the type of memory that the server requires and its effect on performance. The section includes the following topics:

- [DIMM Slot Numbering, page 3-20](#)
- [DIMM Population Rules, page 3-21](#)
- [Memory Mirroring, page 3-23](#)

DIMM Slot Numbering

[Figure 3-12](#) shows the numbering of the DIMM slots.

Figure 3-12 *DIMM Slots and CPUs*

DIMM Population Rules

Observe the following guidelines when installing or replacing DIMMs:

- Each CPU supports three memory channels.
 - CPU1 supports channels A, B, and C.
 - CPU2 supports channels D, E, and F



Note In a single-CPU system, the maximum number of DIMMs is six (only the six slots supported by CPU1).

- Each channel has two DIMM slots (for example, channel A = slots A1 and A2).
 - A channel can operate with one or two DIMMs installed.
 - If a channel has only one DIMM, populate slot 0 first (the blue slot).
- When both CPUs are installed, populate the DIMM slots of each CPU identically.
 - Fill blue slots in the channels first: A1, D1, B1, E1, C1, F1
 - Fill black slots in the channels second: A2, D2, B2, E2, C2, F2
- Any DIMM installed in a DIMM socket for which the CPU is absent is not recognized. In a single-CPU configuration, populate the channels for CPU1 only.

- Although 1600 MHz DIMMs can be run in Power Savings Mode (1.35 V operation), 1600 MHz operation is supported only when the DDR mode is set to Performance Mode (see “[Enabling Low-Voltage DIMM Operation](#).”) A 1600 MHz DIMM set to Power Savings Mode operates at 1066 MHz.
- Observe the DIMM mixing rules shown in [Table 3-3](#).

Table 3-3 *DIMM Mixing Rules*

DIMM Parameter Mixed	Mix Within Single Channel?	Mix Across Multiple Channels?
DIMM size (4, 8, 16 GB)	Yes—Can be different sizes in the channel.	Yes—Can be different sizes in server.
DIMM speed (1333 or 1600 MHz)	No—Must be same speed in channel.	No—Must be the same speed in server.
DIMM type (RDIMM or UDIMM)	No—Must be same type in channel.	No—Must be the same type in server.

- Memory mirroring reduces the amount of memory available by 50% because only one of the two populated channels provides data. When memory mirroring is enabled, DIMMs must be installed in sets of four as described in [Memory Mirroring, page 3-23](#).
- Note the following restrictions when using UDIMMs. Even though a UDIMM might be rated at 1600 MHz, actual operational speeds are slower because of the Intel implementation.
 - In Performance Mode (1.5 V operation), UDIMMs run at 1333 MHz in 1 DPC configurations or at 1066 MHz in 2 DPC configurations.
 - In Power Saving Mode (1.35 V operation), UDIMMs run at 1333 MHz in 1 DPC configurations or at 1066 MHz in 2 DPC configurations.

Enabling Low-Voltage DIMM Operation

You can enable low voltage (1.35 V) DIMM operation for all DIMMs in the server. There is a setting in the BIOS Setup utility that you can use to change the DDR memory mode to Power Saving mode, as described in the following procedure:

-
- Step 1** Enter the BIOS setup utility by pressing the **F2** key when prompted during bootup.
 - Step 2** Select the **Advanced** tab.
 - Step 3** Select **Low Voltage DDR Mode**.
 - Step 4** In the pop-up window, select either **Power Saving** or **Performance Mode**:
 - Power Saving Mode—Prioritizes low-voltage memory operation.
 - Performance Mode—Prioritizes performance memory operation. If you mix low-voltage DIMMs with standard DIMMs, the system defaults to this setting.
 - Step 5** Press **F10** to save your changes and exit the setup utility.
-

Memory Mirroring

When memory mirroring is enabled, the memory subsystem simultaneously writes identical data to two channels. If a memory read from one of the channels returns incorrect data due to an uncorrectable memory error, the system automatically retrieves the data from the other channel. A transient or soft error in one channel does not affect the mirrored data, and operation continues unless there is a simultaneous error in exactly the same location on a DIMM and its mirrored DIMM. Memory mirroring reduces the amount of memory available to the operating system by 50% because only one of the two populated channels provides data.

If you choose to enable memory mirroring, populate the DIMM slots in the order shown in [Table 3-4](#) or [Table 3-5](#).

Table 3-4 Two-CPU Memory Mirroring DIMM Population

Number of DIMMs per CPU	CPU 1 Population	CPU2 Population
2	A1; B1	D1; E1
4	A1, B1; A2, B2	D1, E1; D2, E2

Table 3-5 One-CPU Memory Mirroring DIMM Population

Number of DIMMs per CPU	CPU 1 Population	CPU2 Population
2	A1; B1	CPU2 slots not available
4	A1, B1; A2, B2	CPU2 slots not available

DIMM Replacement Procedure

To install a DIMM assembly, follow these steps:

- Step 1** Remove the DIMMs that you are replacing:
- Power off the server as described in [Shutting Down and Powering Off the Server](#), page 3-6.
 - Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- Remove the top cover as described in [Removing and Replacing the Server Top Cover](#), page 3-7.
- Remove PCIe riser 1 to provide clearance and set it aside on an antistatic surface (see [Replacing a PCIe Riser](#), page 3-34).
- Remove the plastic air baffle that covers the DIMM slots and CPUs.
- Open the ejector levers at both ends of the DIMM slot, then lift the DIMM out of the slot.

- Step 2** Install a new DIMM:

**Note**

Before installing DIMMs, refer to the population guidelines. See [Memory Performance Guidelines and Population Rules, page 3-20](#).

- a. Align the new DIMM with the empty slot on the motherboard. Use the alignment key in the DIMM slot to correctly orient the notch on the bottom edge of the DIMM.
- b. Push down evenly on the top corners of the DIMM until it is fully seated and the ejector levers on both ends lock into place.
- c. Replace the plastic air baffle over the DIMM slots.
- d. Replace PCIe riser 1 to its slot. See [Replacing a PCIe Riser, page 3-34](#).
- e. Replace the top cover.
- f. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Replacing CPUs and Heatsinks

This server can have up to two CPUs. Each CPU supports three DIMM channels (six DIMM slots). See [Figure 3-12](#). This section includes the following topics:

- [Special Information For Upgrades to Intel E5-2400 v2 Series CPUs](#), page 3-25
- [Single-CPU Restrictions](#), page 3-26
- [CPU Replacement Procedure](#), page 3-26
- [Additional CPU-Related Parts To Order With RMA Replacement Motherboards](#), page 3-30

Special Information For *Upgrades* to Intel E5-2400 v2 Series CPUs

**Note**

Do not upgrade your Cisco UCS C24 server to Intel E5-2400 v2 Series CPUs if you use the server integrated under Cisco UCS Manager control. Cisco UCS C24 servers that have Intel E5-2400 v2 Series CPUs are not supported with Cisco UCS Manager integration at this time.

**Caution**

You must upgrade your server firmware to the required minimum level *before* you upgrade to Intel E5-2400 v2 Series CPUs. Older firmware versions cannot recognize the new CPUs and this results in a non-bootable server.

The minimum software and firmware versions required for the server to support Intel E5-2400 v2 Series CPUs are as follows:

Table 3-6 Minimum Requirements For Intel E5-2400 v2 Series CPUs

Software or Firmware	Minimum Version
Server CIMC	1.5(5)
Server BIOS	1.5(5)
Cisco UCS Manager (UCSM-managed system only)	Not supported at this time.

Do one of the following actions:

- If your server's firmware and/or Cisco UCS Manager software are already at the required levels shown in [Table 3-6](#), you can replace the CPU hardware by using the procedure in this section.
- If your server's firmware and/or Cisco UCS Manager software is earlier than the required levels, use the instructions in the [Cisco UCS C-Series Servers Upgrade Guide for Intel E5-2600 v2 Series CPUs](#) to upgrade your firmware. After you upgrade the software, return to the procedure in this section to replace the CPU and heatsink hardware.

Single-CPU Restrictions

The minimum configuration is that the server must have at least CPU1 installed. Install CPU1 first, then CPU2.

The following restrictions apply when using a single-CPU configuration:

- The maximum number of DIMMs is six (only the six slots controlled by CPU1 are active).
- PCIe riser 2 is unavailable (PCIe slots 3, 4, and 5).

CPU Replacement Procedure

**Caution**

CPUs and their motherboard sockets are fragile and must be handled with care to avoid damaging pins during installation. The CPUs must be installed with heatsinks and their thermal pads to ensure proper cooling. Failure to install a CPU correctly might result in damage to the server.

**Caution**

The Pick-and-Place tools used in this procedure are required to prevent damage to the contact pins between the motherboard and the CPU. Do not attempt this procedure without the required tools, which are included with each CPU option kit. If you do not have the tool, you can order a spare (Cisco PID UCS-CPU-EN-PNP).

To install or replace a CPU heatsink and CPU, follow these steps:

Step 1

Remove the CPU and heatsink that you are replacing:

- a. Power off the server as described in the [“Shutting Down and Powering Off the Server”](#) section on page 3-6.
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**


If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in [“Removing and Replacing the Server Top Cover”](#) section on page 3-7.
- d. Remove the internal air baffle from the server to provide access to the CPUs.
- e. Use a #2 Phillips-head screwdriver to loosen the four captive screws that secure the heatsink and then lift it off of the CPU.

**Note**

Alternate loosening each screw evenly to avoid damaging the heatsink or CPU.


- f. Unclip the CPU retaining latch, then open the hinged CPU cover plate. See [Figure 3-13](#).

Figure 3-13 CPU Socket Latches

1	Heatsink screws (four)	4	Hinged CPU cover plate
2	Heatsink	5	CPU
3	CPU retaining latch		


Step 2 Remove a protective cap or an old CPU from the socket (if present):

- If you are removing an old CPU, skip to [Step 3](#).
- If you are installing a new CPU to a socket that was shipped empty, the socket has a protective cap that is intended to prevent bent contact pins. Use the tool as shown in [Figure 3-14](#) to grasp the protective cap and then pivot to remove the cap.

Figure 3-14 Protective Cap Removal Tool

Step 3 Remove an old CPU:


- a. Set the Pick-and-Place tool on the CPU in the socket, aligning the arrow on the tool with the registration mark on the socket (the small triangular mark). See [Figure 3-15](#).
- b. Press the top button on the tool to grasp the installed CPU.
- c. Lift the tool and CPU straight up.
- d. Press the top button on the tool to release the old CPU on an anti-static surface.

Figure 3-15 Removing or Inserting a CPU

1	Arrow on tool	2	Registration mark on CPU socket
----------	---------------	----------	---------------------------------

Step 4 Insert the new CPU into the Pick-and-Place tool:

- a. Remove the new CPU from the packaging and place it on the pedestal that is included in the kit. Align the registration mark on the corner of the CPU with the arrow on the corner of the pedestal (see [Figure 3-16](#)).
- b. Set the Pick-and-Place tool on the CPU pedestal, aligning the arrow on the tool with the arrow on the corner of the pedestal. Make sure that the tabs on the tool are fully seated in the slots on the pedestal.
- c. Press the top button on the tool to grasp and lock in the CPU.
- d. Lift the tool and CPU straight up off the pedestal.

Figure 3-16 CPU and Pick-and-Place Tool on Pedestal

1	Arrow marks for alignment
----------	---------------------------

Step 5 Install a new CPU:

- a. Set the Pick-and-Place tool with CPU over the empty CPU socket on the motherboard.

**Note**

Align the arrow on the top of the tool with the registration mark (small triangle) that is stamped on the metal of the CPU socket, as shown in [Figure 3-15](#).

- b. Press the top button on the tool to set the CPU into the socket. Remove the empty tool.
- c. Close the hinged CPU cover plate.
- d. Clip down the CPU retaining latch. See [Figure 3-13](#).

Step 6 Install a heatsink:**Caution**

The heatsink must have a new, undamaged thermal pad on the heatsink-to-CPU surface to ensure proper cooling. If you are replacing a heatsink that was previously used, you must remove the old thermal pad. If you are installing a new heatsink, skip to step [d.](#) below.

- a. Apply an alcohol-based cleaning solution to the old thermal pad and let it soak for a least 15 seconds.
- b. Wipe all of the old thermal pad off the old heatsink using a soft cloth that will not scratch the heatsink surface.


- c. Apply thermal grease from an included syringe to the top of the CPU.

Apply about 2 cubic centimeters of grease (about half the syringe contents) to the top of the CPU in the pattern that is shown in [Figure 3-17](#).



Note If you do not have a syringe of thermal grease, you can order a spare (Cisco PID UCS-CPU-GREASE).

Figure 3-17 Thermal Grease Application Pattern



- d. For a new heatsink, peel the protective film from the thermal pad that is on the bottom of the new heatsink.



Note Do not apply a syringe of thermal grease if you are installing a new heatsink that already has a pre-applied thermal pad.

- e. Align the heatsink captive screws with the motherboard standoffs, then use a Number 2 Phillips-head screwdriver to tighten the captive screws evenly.



Note Alternate tightening each screw evenly to avoid damaging the heatsink or CPU.

- f. Replace the top cover.
- g. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Additional CPU-Related Parts To Order With RMA Replacement Motherboards

When a return material authorization (RMA) of the motherboard or CPU is done on a Cisco UCS C-series server, there are additional parts that might not be included with the CPU or motherboard spare bill of materials (BOM). The TAC engineer might need to add the additional parts to the RMA to help ensure a successful replacement.

- Scenario 1—You are re-using the existing heatsinks:

- Heat sink cleaning kit (UCSX-HSCK=)
 - Thermal grease kit for C24 (UCS-CPU-GREASE=)
 - Intel CPU Pick-n-Place tool for EP CPUs (UCS-CPU-EN-PNP=)
- Scenario 2—You are replacing the existing heatsinks:
 - Heat sink (UCSC-HS-EN-M3=)
 - Heat sink cleaning kit (UCSX-HSCK=)
 - Intel CPU Pick-n-Place tool for EP CPUs (UCS-CPU-EN-PNP=)

A CPU heatsink cleaning kit is good for up to four CPU and heatsink cleanings. The cleaning kit contains two bottles of solution, one to clean the CPU and heatsink of old thermal interface material and the other to prepare the surface of the heatsink.

New heatsink spares have preinstalled thermal interface material covered by a small sheet of plastic. It is important to clean the old thermal interface material off of the CPU prior to installing the heatsinks. Therefore, when ordering new heatsinks it is still necessary to order the heatsink cleaning kit at a minimum.

Replacing the Motherboard RTC Battery

**Warning**

There is danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. [Statement 1015]

The real-time clock (RTC) battery retains system settings when the server is disconnected from power. The RTC battery is on the motherboard under the fan tray.

The battery type is Panasonic CR2032 or equivalent.

To replace or install the motherboard CMOS battery, follow these steps:

Step 1 Remove the RTC battery (see [Figure 3-18](#)):

- a. Power off the server as described in the “[Shutting Down and Powering Off the Server](#)” section on [page 3-6](#).
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in “[Removing and Replacing the Server Top Cover](#)” section on [page 3-7](#).
- d. Locate the RTC battery on the motherboard between the PCIe risers (see [Figure 3-18](#)).
- e. Use a small screwdriver or pointed object to push aside the metal clip that holds the battery in the holder.

**Note**

If you have difficulty reaching the battery because of cards in the PCIe risers, remove PCIe riser 1 to provide access. See [Replacing a PCIe Riser, page 3-34](#).

- f. Lift the battery from the holder.


Step 2 Install an RTC battery:

- a. Insert the battery into its holder positive-side-up and press down until it clicks in place.

**Note**

The positive side of the battery marked “3V+” should face upward.

- b. If you removed PCIe riser 1, replace it to its slot. See [Replacing a PCIe Riser, page 3-34](#).
- c. Replace the top cover.
- d. Replace the server in the rack, replace cables, and power on the server by pressing the **Power** button.

Figure 3-18 Replacing the Motherboard RTC Battery

1	RTC battery holder on motherboard	—
---	-----------------------------------	---

Replacing a PCIe Riser


The server contains two toolless PCIe risers for horizontal installation of PCIe cards.

See [PCIe Slots, page 3-36](#) for specifications of the PCIe slots on the risers.


Note

PCIe riser 2 (slots 3, 4, and 5) is not available in single-CPU configurations.

Figure 3-19 Rear Panel, Showing PCIe Slots



1	PCIe riser 2 slots (three half-height slots)	2	PCIe riser 1 slots (two full-height slots)
----------	----------------------------------------------	----------	--------------------------------------------

To install or replace a PCIe riser, follow these steps:

Step 1 Remove the PCIe riser that you are replacing:

- Power off the server as described in the [“Shutting Down and Powering Off the Server”](#) section on [page 3-6](#).
- Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.


Caution

If you cannot safely view and access the component, remove the server from the rack.

- Remove the top cover as described in [“Removing and Replacing the Server Top Cover”](#) section on [page 3-7](#).
- Disconnect all cables from any PCIe cards that are installed in the PCIe riser.
- Grasp both ends of the riser and evenly pull straight up to disengage its circuit board from the socket on the motherboard. Set the riser on an antistatic surface.
- If the riser has a card installed, remove the card from the riser (see [Replacing a PCIe Card, page 3-36](#)).

Step 2 Install a new PCIe riser:


- If you removed a card from the old PCIe riser, install the card to the new riser (see [Replacing a PCIe Card, page 3-36](#)).
- Position the PCIe riser over its socket on the motherboard and over its alignment points in the chassis (see [Figure 3-20](#)).


Caution

Make sure that the circuit board connector of the riser is aligned correctly with the motherboard socket before you push down to seat the riser in the next step.

- c. Carefully push down on both ends of the PCIe riser to fully engage its circuit board connector with the socket on the motherboard.
- d. Reconnect cables to any PCIe cards installed in the riser.
- e. Replace the top cover.
- f. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Figure 3-20 Replacing the PCIe Riser



1 PCIe riser 1 alignment point locations (three)	2 PCIe riser 2 alignment point locations (two)
--------------------------------------------------	------------------------------------------------

Replacing a PCIe Card


Caution

Cisco supports all PCIe cards qualified and sold by Cisco. PCIe cards not qualified or sold by Cisco are the responsibility of the customer. Although Cisco will always stand behind and support the C-Series rack-mount servers, customers using standard, off-the-shelf, third-party cards must go to the third-party card vendor for support if any issue with that particular third-party card occurs.

This section includes the following topics:

- [PCIe Slots, page 3-36](#)
- [Replacing a PCIe Card, page 3-37](#)
- [Special Considerations for Cisco UCS Virtual Interface Cards, page 3-39](#)
- [RAID Controller Card Cable Routing, page 3-39](#)
- [Installing Multiple PCIe Cards and Resolving Limited Resources, page 3-39](#)

PCIe Slots

The server contains two PCIe risers for horizontal installation of PCIe cards. See [Figure 3-21](#) and [Table 3-7](#).


Note

In a single-CPU system, PCIe riser 2 (slots 3, 4, 5) is not available.

Figure 3-21 *Rear Panel, Showing PCIe Slots*




Table 3-7 *PCIe Expansion Slots*

Slot Number	Electrical Lane Width	Connector Length	Card Length ¹	Card Height ²	NCSI ³ Support
1	Gen-3 x16	x16 extended	Full length	Full-height	Yes ⁴
2	Gen-3 x4	x8 connector	1/2 length	Full-height	No
3	Gen-3 x8	x16 connector	1/2 length	Half-height	No
4	Gen-3 x8	x8 connector	1/2 length	Half-height	No
5	Gen-3 x4	x8 connector	1/2 length	Half-height	No

1. This is the supported length because of internal clearance.
2. This is the size of the rear panel opening.
3. Network Communications Services Interface protocol.
4. Slot 1 can operate when the server is in standby power mode.

Replacing a PCIe Card



Note

If you are installing a Cisco UCS Virtual Interface Card, there are prerequisite considerations. See [Special Considerations for Cisco UCS Virtual Interface Cards, page 3-39](#).



Note

If you are installing a RAID controller card, see [RAID Controller Considerations, page C-1](#) for more information about supported cards and cabling.

To install or replace a PCIe card, follow these steps:

Step 1

Remove a PCIe card (or a blank filler panel) from the PCIe riser assembly:

- a. Shut down and power off the server as described in the [“Shutting Down and Powering Off the Server” section on page 3-6](#).
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in the [“Removing and Replacing the Server Top Cover” section on page 3-7](#).
- d. Disconnect cables from the PCIe cards that you are replacing.



Tip

Label the cables when you disconnect them to aid correct connection to the new card.

- e. Grasp both ends of the riser and evenly pull straight up to disengage its circuit board from the socket on the motherboard. Set the riser on an antistatic surface.
- f. Remove the single screw that secures the tab of the card to the riser.
- g. Pull evenly on both ends of the card to disengage it from the socket on the riser (or remove a blanking panel) and then set the card aside.

Step 2 Install a PCIe card:

- a. Align the new card with the empty socket on the riser.
- b. Push down evenly on both ends of the card until it is fully seated in the socket.
Ensure that the card rear panel tab sits flat against the riser rear panel opening.
- c. Replace the screw that secures the tab of the card to the riser.
- d. Position the riser over its socket on the motherboard and over its alignment features in the chassis (see [Figure 3-20](#)).

**Caution**

Make sure that the circuit board connector of the riser is aligned correctly with the motherboard socket before you push down to seat the riser in the next step.

- e. Carefully push down on both ends of the PCIe riser to fully engage its circuit board connector with the socket on the motherboard.
- f. Connect cables to the PCIe card. See [RAID Controller Considerations, page C-1](#) for more information about supported cards and cabling.
- g. Replace the top cover.
- h. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.
- i. If you replaced a RAID controller card, continue with [Restoring RAID Configuration After Replacing a RAID Controller, page C-21](#).

Special Considerations for Cisco UCS Virtual Interface Cards

Table 3-8 describes the requirements for the supported Cisco UCS virtual interface cards (VICs).

Table 3-8 Cisco UCS C24 Requirements for Virtual Interface Cards

Virtual Interface Card (VIC)	Number of VICs Supported in Server	Slots That Support VICs ¹	Primary Slot For UCS Integration or Cisco Card NIC Mode	Minimum CIMC Firmware	Minimum VIC Firmware For Use With UCS Integration	Minimum Nexus OS on an Upstream Nexus Fabric Interconnect
Cisco UCS VIC P81E ² N2XX-ACPCI01	2	PCIE 1 PCIE 2	PCIE 1	1.4(5)	2.0(2)	5.0
Cisco UCS VIC 1225 UCSC-PCIE-CSC-02	2	PCIE 1 PCIE 2	PCIE 1	1.4(6)	2.1(0)	5.0
Cisco UCS VIC1225T UCSC-PCIE-C10T-02	2	PCIE 1 PCIE 2	PCIE 1 ³	1.5(1)	2.1(1)	5.0

1. See [PCIe Slots](#), page 3-36.

2. See note below.

3. The Cisco UCS VIC1225T is not supported for UCS integration at this time.



Note

Cisco UCS VIC P81E is not supported in the following server versions: C24 LFF (12-drive) or C24 16HDD (16-drive direct-connect backplane).

RAID Controller Card Cable Routing

If the PCIe card that you are installing or replacing is a RAID controller card, see [RAID Controller Considerations](#), page C-1 for cable routing and other guidelines.

See also [Replacing a SuperCap Power Module \(RAID Backup Unit\)](#), page 3-42 for instructions on installing a RAID backup unit for a RAID controller card.

Installing Multiple PCIe Cards and Resolving Limited Resources

When a large number of PCIe add-on cards are installed in the server, the system may run out of the following resources required for PCIe devices:

- Option ROM memory space
- 16-bit I/O space

The topics in this section provide guidelines for resolving the issues related to these limited resources.

- [Resolving Insufficient Memory Space to Execute Option ROMs](#), page 3-40
- [Resolving Insufficient 16-Bit I/O Space](#), page 3-41

Resolving Insufficient Memory Space to Execute Option ROMs

The system has very limited memory to execute PCIe legacy option ROMs, so when a large number of PCIe add-on cards are installed in the server, the system BIOS might not be able to execute all of the option ROMs. The system BIOS loads and executes the option ROMs in the order that the PCIe cards are enumerated (Slot 1, Slot 2, Slot 3, etc.).

If the system BIOS does not have sufficient memory space to load any PCIe option ROM, it skips loading that option ROM, reports a system event log (SEL) event to the CIMC controller and reports the following error in the Error Manager page of the BIOS Setup utility:

ERROR CODE	SEVERITY	INSTANCE	DESCRIPTION
146	Major	N/A	PCI out of resources error. Major severity requires user intervention but does not prevent system boot.

To resolve this issue, disable the Option ROMs that are not needed for system booting. The BIOS Setup Utility provides the setup options to enable or disable the Option ROMs at the PCIe slot level for the PCIe expansion slots and at the port level for the onboard NICs. These options can be found in the BIOS Setup Utility **Advanced** → **PCI Configuration** page.

- **Guidelines for RAID controller booting:**

If the server is configured to boot primarily from RAID storage, make sure that the option ROMs for the slots where your RAID controllers are installed are enabled in the BIOS, depending on your RAID controller configuration.

If the RAID controller does not appear in the system boot order even with the option ROMs for those slots enabled, the RAID controller option ROM might not have sufficient memory space to execute. In that case, disable other option ROMs that are not needed for the system configuration to free up some memory space for the RAID controller option ROM.

- **Guidelines for onboard NIC PXE booting:**

If the system is configured to primarily perform PXE boot from onboard NICs, make sure that the option ROMs for the onboard NICs to be booted from are enabled in the BIOS Setup Utility. Disable other option ROMs that are not needed to create sufficient memory space for the onboard NICs.

Resolving Insufficient 16-Bit I/O Space

The system has only 64 KB of legacy 16-bit I/O resources available. This 64 KB of I/O space is divided between the CPUs in the system because the PCIe controller is integrated into the CPUs. This server BIOS has the capability to dynamically detect the 16-bit I/O resource requirement for each CPU and then balance the 16-bit I/O resource allocation between the CPUs accordingly during the PCI bus enumeration phase of the BIOS POST.

When a large number of PCIe cards are installed in the system, the system BIOS might not have sufficient I/O space for some PCIe devices. If the system BIOS is not able to allocate the required I/O resources for any PCIe devices, the following symptoms have been observed:

- The system might get stuck in an infinite reset loop.
- The BIOS might appear to hang while initializing PCIe devices.
- The PCIe option ROMs might take excessive time to complete, which appears to lock up the system.
- PCIe boot devices might not be accessible from the BIOS.
- PCIe option ROMs might report initialization errors. These errors are seen before the BIOS passes control to the operating system.
- The keyboard might not work.

To work around this problem, rebalance the 16-bit I/O load using the following methods:

1. Physically remove any unused PCIe cards.
2. If the system has one or more Cisco virtual interface cards (VICs) installed, disable the PXE boot on the VICs that are not required for the system boot configuration by using the Network Adapters page in the CIMC WebUI to free up some 16-bit I/O resources. Each VIC uses a minimum 16 KB of 16-bit I/O resource, so disabling PXE boot on Cisco VICs would free up some 16-bit I/O resources that can be used for other PCIe cards that are installed in the system.

Replacing a SuperCap Power Module (RAID Backup Unit)

This server supports installation of up to two SuperCap power modules (SCPMs). The SCPMs mount inside a cage that is next to the cooling fans (see [Figure 3-22](#)).

The SCPM is supported only when using the LSI MegaRAID-CV controller card. This supercap module provides approximately 3 years of backup for the disk write-back cache DRAM in the case of sudden power loss by offloading the cache to the NAND flash.

To replace the RAID backup unit, follow these steps:

- Step 1** Remove an SCPM (see [Figure 3-22](#)).
- Power off the server as described in the “[Shutting Down and Powering Off the Server](#)” section on [page 3-6](#).
 - Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**

If you cannot safely view and access the component, remove the server from the rack.

- Remove the top cover as described in the “[Removing and Replacing the Server Top Cover](#)” section on [page 3-7](#).
- Disconnect the RAID controller cable that is attached to the existing SCPM.
- Remove the cage that holds the SCPMs (see [Figure 3-22](#)).
 - Use a screwdriver to loosen the captive thumbscrew that secures the cage to the chassis floor.

**Note**

If you cannot access the thumbscrew, you can remove the front chassis panel to provide clearance. See [Removing and Replacing the Front Chassis Panel](#), [page 3-8](#).

- Push the cage toward the server front about 1/4 inch to free the pegs on the sides of the cage from the keyed slots on the chassis bracket.


- Remove the SCPM holder, with backup unit, from the cage (see [Figure 3-22](#)).
- Remove the SCPM from the holder.

Step 2 Install a new SCPM:

- Insert the new SCPM into the empty holder that you removed in the previous step (see [Figure 3-22](#)).
- Insert the holder, with new SCPM, into the cage.
- Replace the cage to the chassis.
 - Set the cage in place in the chassis bracket, aligning the pegs on the sides of the cage with the keyed slots in the chassis bracket.
 - Push the cage toward the server rear about 1/4 inch to lock it into the keyed slots on the chassis bracket.
 - Use a screwdriver to tighten the captive thumbscrew that secures the cage to the chassis floor.
- Reconnect the cable from the RAID controller to the new SCPM.
- Replace the top cover.

- f. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Figure 3-22 Replacing an SCPM



1	Captive thumbscrew on SCPM cage	4	SCPM holders with SCPMs installed (up to two)
2	SuperCap power module (SCPM)	5	SCPM cage removed from server
3	SCPM holder	6	SCPM cage with holders and SCPMs installed (up to two)

Replacing a Cisco USB Flash Drive

This server can be ordered with an optional 16-GB Cisco USB flash drive that is pre-loaded with Cisco UCS C-Series Utilities.

This section includes the following topics:

- [Overview of the Pre-Loaded 16-GB Cisco USB Flash Drive, page 3-44](#)
- [Enabling a Pre-Loaded Cisco USB Flash Drive Virtual Drive, page 3-44](#)
- [Booting a Pre-Loaded Cisco USB Flash Drive Virtual Drive, page 3-45](#)
- [Monitoring and Managing a Cisco USB Flash Drive, page 3-46](#)
- [Internal Cisco USB Flash Drive Replacement Procedure, page 3-46](#)
- [Enabling or Disabling the Internal USB Port, page 3-47](#)

Overview of the Pre-Loaded 16-GB Cisco USB Flash Drive

This Cisco USB flash drive is pre-loaded with three software bundles, each on one of four preconfigured virtual drives (VDs). The fourth VD allows you to install an OS or embedded hypervisor.

The VD's are configured as follows:

1. Cisco UCS Server Configuration Utility (SCU).
2. Hypervisor (HV). This is a VD that you can use for your own purposes.
3. Cisco Drivers (Drivers).
4. Cisco Host Upgrade Utility (HUU).

Enabling a Pre-Loaded Cisco USB Flash Drive Virtual Drive

Each of the VD's on the pre-loaded Cisco USB flash drive can be separately enabled or hidden from the host. The default as shipped from the factory is for all VD's to be hidden.

To enable VD's and expose them to the host, follow these steps:

-
- | | |
|---------------|-------------------------------------------------------------------------------------------------------------|
| Step 1 | Log in to CIMC interface for the server, using the IP address of the server. |
| Step 2 | Navigate through GUI tabs to Server > Inventory > Storage . |
| Step 3 | Click UNIGEN USB in the Storage Adapters list. |
| Step 4 | Click on Configure Operational Profile in the Actions area.
The Operational Profile dialog opens. |
| Step 5 | Check the box for each VD that you want to enable and expose to the host, then click Save Changes . |
-

Booting a Pre-Loaded Cisco USB Flash Drive Virtual Drive

When you want to access the Cisco SCU or Cisco HUU software, you boot its VD with a one-time boot option. When you want to boot the hypervisor (HV) VD, you boot it with a permanent boot order selection. See the following topics in this section:

- [Booting the Cisco SCU and Cisco HUU Software VDs, page 3-45](#)
- [Booting the Hypervisor VD, page 3-45](#)

Booting the Cisco SCU and Cisco HUU Software VDs

You can access the preinstalled Cisco SCU and Cisco HUU software bundles by booting their respective VDs with a one-time boot option:

-
- Step 1** Enable the SCU or HUU VD.
See [Enabling a Pre-Loaded Cisco USB Flash Drive Virtual Drive, page 3-44](#).
- Step 2** In the CIMC GUI interface, navigate through the tabs to **Server > BIOS**.
- Step 3** Click **Configure Boot Override Priority**.
The Boot Override Priority dialog opens.
- Step 4** Pull down the menu and select **SCU** or **HUU**, then click **OK**.
- Step 5** Reboot the server.
The server boots the selected VD.



Note This is a one-time boot option. After running Cisco SCU or Cisco HUU, the server returns to its previously configured boot path.

Booting the Hypervisor VD

You can boot the hypervisor (HV) VD with a more permanent boot selection. (To change the boot order one time, use the procedure in [Booting the Cisco SCU and Cisco HUU Software VDs, page 3-45](#).)

To permanently set the boot order for an HV VD, use the following steps:

-
- Step 1** Boot the server and watch for the prompt to press F2 to open the BIOS Setup utility.
- Step 2** When prompted, press **F2** to open the BIOS Setup utility.
- Step 3** Navigate to the **Boot Options** tab.
- Step 4** Use the Boot Options screen to set the HV VD to your desired boot order for the server.
-

Monitoring and Managing a Cisco USB Flash Drive

You can monitor and manage your installed Cisco USB Flash Drive by using the CIMC GUI interface or the CLI interface. See the *Cisco UCS C-Series Rack-Mount Server Configuration Guide* or the *Cisco UCS C-Series Rack-Mount Server CLI Configuration Guide* in the documentation roadmap linked below. The links to these documents are in the C-Series documentation roadmap:

<http://www.cisco.com/go/unifiedcomputing/c-series-doc>

Internal Cisco USB Flash Drive Replacement Procedure

To install or replace an internal Cisco USB Flash Drive, follow these steps:


-
- Step 1** Remove the USB flash drive that you are replacing. See [Figure 3-23](#):
- Power off the server as described in the “[Shutting Down and Powering Off the Server](#)” section on [page 3-6](#).
 - Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- Remove the top cover as described in “[Removing and Replacing the Server Top Cover](#)” section on [page 3-7](#).
 - Remove PCIe riser 1 to provide access to the USB flash drive socket that is on the motherboard (see [Figure 3-23](#)). See [Replacing a PCIe Riser, page 3-34](#) for more information.
 - Pull the USB flash drive from the socket.
- Step 2** Install a USB flash drive:
- Insert the USB flash drive into the socket.
 - Replace PCIe riser 1 to the server. See [Replacing a PCIe Riser, page 3-34](#) for more information.
 - Replace the top cover.
 - Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Figure 3-23 Cisco USB Flash Drive Socket

1	Cisco USB flash drive socket on motherboard
----------	---------------------------------------------

Enabling or Disabling the Internal USB Port

The factory default is for all USB ports on the server to be enabled. However, the internal USB port can be enabled or disabled in the server BIOS. To enable or disable the internal USB port, follow these steps:

- Step 1** Enter the BIOS Setup utility by pressing the **F2** key when prompted during bootup.
- Step 2** Navigate to the **Advanced** tab.
- Step 3** On the Advanced tab, select **USB Configuration**.
- Step 4** On the USB Configuration page, select **USB Ports Configuration**.
- Step 5** Scroll to **USB Port: Internal**, press **Enter**, and then select either Enabled or Disabled from the pop-up menu.
- Step 6** Press **F10** to save and exit the utility.

Installing a Trusted Platform Module

The trusted platform module (TPM) is a small circuit board that attaches to a motherboard socket. The socket location is on the motherboard, underneath PCIe riser 1 (see [Figure 3-24](#)).

**Note**

For security purposes, the TPM is installed with a one-way screw. It cannot be removed with a standard screwdriver.

To install a trusted platform module (TPM), follow these steps:

Step 1 Prepare the server for component installation.

- a. Power off the server as described in the “[Shutting Down and Powering Off the Server](#)” section on [page 3-6](#).
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.

**Caution**

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in the “[Removing and Replacing the Server Top Cover](#)” section on [page 3-7](#).
- d. Remove PCIe riser 2 to provide access (see [Figure 3-24](#)). See [Replacing a PCIe Riser, page 3-34](#).

Step 2 Install a TPM (see [Figure 3-24](#)):

- a. Locate the TPM socket on the motherboard, as shown in [Figure 3-24](#).
- b. Align the connector that is on the bottom of the TPM circuit board with the motherboard TPM socket. Align the screw hole and standoff on the TPM board with the screw hole adjacent to the TPM socket.
- c. Push down evenly on the TPM to seat it in the motherboard socket.
- d. Install the single one-way screw that secures the TPM to the motherboard.
- e. Replace PCIe riser 2 to its motherboard socket. See [Replacing a PCIe Riser, page 3-34](#).
- f. Replace the top cover.
- g. Replace the server in the rack, replace cables, and then power on the server by pressing the **Power** button.

Step 3 Enable the TPM:


- a. Watch during bootup for the F2 prompt, and then press **F2** to enter BIOS setup.
- b. Log into the BIOS Setup utility with your BIOS Administrator password.
- c. On the BIOS Setup utility screen, select the **Advanced** tab.
- d. Select **Trusted Computing** to open the TPM Security Device Configuration screen.
- e. Change TPM SUPPORT to **Enabled**.
- f. Press **F10** to save your settings and reboot the server.

- Step 4** Verify that the TPM is now enabled.
- Watch during bootup for the F2 prompt, and then press **F2** to enter BIOS setup.
 - Log into the BIOS Setup utility with your BIOS Administrator password.
 - Select the **Advanced** tab.
 - Select **Trusted Computing** to open the TPM Security Device Configuration screen.
 - Verify that TPM SUPPORT is Enabled.

**Note**

If you want to use the Intel Trusted Execution Technology (TXT) feature, it must be enabled in the server BIOS as described in [Enabling the Intel Trusted Execution Technology \(TXT\) Feature For the TPM](#), page 3-49.

Figure 3-24 TPM Socket Location on Motherboard



Enabling the Intel Trusted Execution Technology (TXT) Feature For the TPM

Intel TXT provides greater protection for information that is used and stored on the business server. A key aspect of that protection is the provision of an isolated execution environment and associated sections of memory where operations can be conducted on sensitive data, invisibly to the rest of the system. Likewise, Intel TXT provides for a sealed portion of storage where sensitive data such as encryption keys can be kept, helping to shield them from being compromised during an attack by malicious code.

To enable the TXT feature, follow these steps:

Step 1 Verify that a TPM is now installed and enabled in the server:

- a. Either attach a VGA monitor and USB keyboard to the server, or log in remotely to the CIMC interface of the server and open a virtual KVM console window.
- b. Reboot the server.
- c. Watch during bootup for the F2 prompt, and then press **F2** to enter BIOS setup.
- d. Log in to the BIOS Setup utility with your BIOS Administrator password.



Note You must be logged in as the BIOS administrator to perform this procedure. If you have not done so already, set a BIOS administrator password on the Security tab of the BIOS Setup utility.

- e. Select the **Advanced** tab.
- f. On the Advanced tab, select **Trusted Computing** to open the TPM Security Device Configuration screen.
- g. Verify that **TPM SUPPORT** is **Enabled**. If it is not, set TPM SUPPORT to Enabled.
- h. Press **Escape** to return to the BIOS Setup utility **Advanced** tab.

Step 2 Enable the Intel Trusted Execution Technology (TXT) feature:

- a. On the Advanced tab, select **Intel TXT(LT-SX) Configuration** to open the Intel TXT(LT-SX) Hardware Support screen.



Note The Intel Trusted Execution Technology feature can be enabled only when the server has a TPM installed on the TPM header.

- b. Set **TXT Support** to **Enabled**.

Step 3 On the same screen, verify that the Intel Virtualization Technology (VT) and the Intel VT for Directed I/O (VT-d) features are enabled (the factory default).

- a. On the Intel TXT(LT-SX) Hardware Support screen, verify that **VT-d Support** and **VT Support** are both listed as **Enabled**.
 - If they are already enabled, skip to [Step 4](#).
 - If VT-d Support and VT Support are not enabled, continue with the next steps to enable them.
- b. Press **Escape** to return to the BIOS Setup utility **Advanced** tab.
- c. On the Advanced tab, select **Processor Configuration** to open the Processor Configuration screen.
- d. Set **Intel (R) VT** and **Intel (R) VT-d** to Enabled.

Step 4 Press **F10** to save your changes and exit the BIOS Setup utility.

Step 5 Verify that the Intel TXT, VT, and VT-d features are enabled:

- a. Reboot the server.
 - b. Watch during bootup for the F2 prompt, and then press **F2** to enter BIOS setup.
 - c. Select the **Advanced** tab.
 - d. Select **Intel TXT(LT-SX) Configuration** and verify that TXT Support, VT-d Support, and VT Support are Enabled.
-

Replacing a SCU Upgrade ROM Module

To remove and replace a module, use the following procedure.

Step 1 Prepare the server for component installation:

- a. Power off the server as described in [Shutting Down and Powering Off the Server](#), page 3-6.
- b. Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- c. Remove the top cover as described in [Removing and Replacing the Server Top Cover](#), page 3-7.

Step 2 Remove the SCU upgrade ROM module:

- a. Locate the module on the motherboard (see [Figure C-1](#)).
- b. Grasp the printed circuit board of the module and lift it from the header.




Note

The module has a small retention feature that must have clearance from the header before the module can be pulled up. Tilt the module back, then pull up as shown in [Figure 3-25](#).

Step 3 Install a new SCU upgrade ROM module:

- a. Align the module with the pins in the motherboard header.
- b. Gently press down on the module until it is seated and the retention feature locks into the header.

Figure 3-25 SCU Upgrade ROM Module Retention Feature



1	Printed circuit board on module	3	Motherboard header
2	Retention feature on module	4	Retention feature in installed position

For more information about using the module and embedded RAID, see [Embedded MegaRAID Controller](#), page C-5.

Replacing a Software RAID Key Module

To remove and replace a software RAID key module, use the following procedure.

- Step 1** Prepare the server for component installation:
- Power off the server as described in [Shutting Down and Powering Off the Server](#), page 3-6.
 - Slide the server out the front of the rack far enough so that you can remove the top cover. You might have to detach cables from the rear panel to provide clearance.



Caution

If you cannot safely view and access the component, remove the server from the rack.

- Remove the top cover as described in [Removing and Replacing the Server Top Cover](#), page 3-7.

- Step 2** Remove the software RAID key module:

- Locate the module on the motherboard (see [Figure C-1](#)).
- Grasp the printed circuit board of the module and lift it from the header.




Note

The module must have clearance from the retention clip on the header before the module can be pulled up. Open the retention clip, then pull up as shown in [Figure 3-26](#).

- Step 3** Install a new software RAID key module:
- Align the module with the pins in the motherboard header.
 - Gently press down on the module until it is seated and the retention clip locks over the module.

Figure 3-26 Software RAID Key Module Retention Feature



1	Printed circuit board on module	3	Motherboard header
2	Retention feature on motherboard header	4	Retention feature in installed position

For more information about using the module and embedded RAID, see [Embedded MegaRAID Controller](#), page C-5.

Replacing Power Supplies

The server can have one or two power supplies. When two power supplies are installed they are redundant as 1+1.


Note

The power supplies must both be either 450W or 650W; do not mix power supply types.

See [Power Specifications, page A-2](#) for more information about the power supplies. See [Rear Panel LEDs and Buttons, page 3-4](#) for information about the power supply LEDs.


To replace or install a power supply, follow these steps:


Note

If you have ordered a server with power supply redundancy (two power supplies), you do not have to power off the server to replace power supplies because they are redundant as 1+1.

- Step 1** Remove the power supply that you are replacing or a blank panel from an empty bay (see [Figure 3-27](#)):
- Perform one of the following actions:
 - If your server has only one power supply, shut down and power off the server as described in the [“Shutting Down and Powering Off the Server”](#) section on page 3-6.
 - If your server has two power supplies, you do not have to shut down the server.
 - Remove the power cord from the power supply that you are replacing.
 - Grasp the power supply handle while pinching the release lever towards the handle.
 - Pull the power supply out of the bay.
- Step 2** Install a new power supply:
- Grasp the power supply handle and insert the new power supply into the empty bay.
 - Push the power supply into the bay until the release lever locks.
 - Connect the power cord to the new power supply.
 - If you shut down the server, press the **Power** button to return the server to main power mode.

Figure 3-27 Removing and Replacing Power Supplies



1	Power supply handle	2	Power supply release lever
---	---------------------	---	----------------------------

