

Quick Reference



Cisco Host Upgrade Utility Release 1.3(x) Quick Start Guide

[Cisco Host Upgrade Utility](#) 2

[Overview](#) 2

[Requirements and Support](#) 2

[Using the Utility](#) 3

[Troubleshooting](#) 6

[Additional Information](#) 6

Revised: October 10, 2011,

Cisco Host Upgrade Utility

Overview

The Cisco Host Upgrade Utility is a tool that upgrades the following firmware:

- Cisco Integrated Management Controller (CIMC)
- System BIOS
- LAN on motherboard (LOM)
- LSI (for any third-party LSI storage controllers that are installed)
- Cisco UCS P81E Virtual Interface Card (VIC)

The image file for the firmware is embedded in the ISO. The utility displays a menu that allows you to choose which firmware components to upgrade. After the upgrade, you can also choose whether to reboot with existing CIMC settings or with the factory default CIMC settings.



Important

If you are using UCSM Mode to integrate this server with Cisco UCS Manager, you must use Release 1.2(x) CIMC and BIOS firmware. To upgrade the 1.2(x) firmware, you need to use the Cisco Host Upgrade Utility for 1.2(x). For details, see the following URL: http://www.cisco.com/en/US/docs/unified_computing/ucs/c/sw/lomug/install/LOMUG.html

Requirements and Support

Requirements

This utility supports firmware upgrades for C-Series servers. When launched, this utility determines the server model, then checks for the minimum required firmware level as listed in the table below.

Server	Minimum CIMC and BIOS Version Required to Use This Utility
C200	1.2(1a)
C210	1.2(1a)
C250	1.2(1a)
C260	1.3(3a)
C460 (M1)	1.2(1a)

Support

This utility checks for and then updates firmware for the following LOM and LSI controller devices in each server:

Server	LOM Device	LSI Controller
C200	Intel 82576	1064E 1068E 8708EM2 9260-4i 9260-8i 9280-4i4e
C210	Intel 82576	1064E 9261-8i
C250	Broadcom BCM5709	3081E-R 9261-8i
C260	Broadcom BCM5709 Broadcom BCM57712	9261-8i
C460 (M1)	Broadcom BCM5709 Broadcom BCM57711	9260-8i 9240-8i

Using the Utility

You can use the utility ISO to upgrade components of the server from the host locally with a writable disk (DVD or CD) or remotely by mounting the utility ISO as a virtual device.

Procedure

-
- Step 1** Find the ISO file download for your server online and download it to a temporary location on your workstation:
- Navigate to the following URL: <http://www.cisco.com/cisco/software/navigator.html>.
 - Click **Unified Computing and Servers** in the middle column.
 - Click **Cisco UCS C-Series Rack-Mount Standalone Server Software** in the right-hand column.
 - Click the name of your model of server in the right-hand column.
 - Click **Unified Computing System (UCS) Server Firmware**.
 - Click the **1.3** release number.
 - Click **Download Now** to download the `hostUpgrade_<version>.iso` file.
 - Verify the information on the next page, then click **Proceed With Download**.

- i) Continue through the subsequent screens to accept the license agreement and browse to a location where you want to save the `hostUpgrade_<version>.iso` file.

Step 2 If you want to prepare the ISO for a local upgrade, complete this step. Otherwise go to [Step 3, on page 4](#).

- a) Burn the ISO image onto a writable disk (DVD or CD).
- b) Connect a VGA monitor and USB keyboard to the Cisco C-Series server.
- c) Insert the disk into the DVD drive of the Cisco C-Series server.
- d) Go to [Step 4, on page 4](#).

Step 3 Prepare the ISO for a remote upgrade using KVM.

- a) Use a browser to connect to the CIMC Manager software on the server that you are upgrading.
- b) Enter the CIMC IP address for that server in the address field of the browser, then enter your user name and password.
- c) Click the **Launch KVM Console** button in the toolbar to launch the KVM console.
- d) The way you access virtual media depends on the version of the KVM Console that you are using. If the **KVM Console** dialog box has a **VM** tab, click on that tab. Otherwise, select **Tools > Launch Virtual Media**.
- e) Click **Add Image** and use the dialog to select the `hostUpgrade_<version>.iso` file.
- f) In the **Client View** section, check the check box in the **Mapped** column for the ISO file that you added and then wait for mapping to complete.
The KVM displays the progress in the **Details** section.
- g) After the ISO file appears as a mapped remote device, go to [Step 4, on page 4](#).

Step 4 Boot the server and press F6 when prompted to open the **Boot Menu** screen.

Step 5 On the **Boot Menu** screen, select the prepared ISO:

- For a local upgrade, select the physical CD/DVD device and then press Enter. For example, SATA5:TSSTcorp CDDVDW TS-L633C.
- For a remote upgrade, select **Cisco Virtual CD/DVD** and press Enter.

The server reboots from the selected device.

Step 6 The server displays a screen with the server BIOS and CIMC firmware versions. At the “**Have you read the Cisco EULA**” (end user license agreement)? prompt:

- Press y to accept the EULA and continue the update.
- Press n to read the EULA. The EULA is displayed and you are prompted to press y to continue the update, or n to cancel. If you press n, the server will reboot without updating.
- Press q to exit without updating. This selection reboots the server.

After you accept the EULA, the server displays the **Host Upgrade Menu**.

Step 7 On the **Host Upgrade Menu**, enter one of the following numbers at the `Enter Choice` prompt:

Option	Description
1. Update CIMC Firmware - <version>	The utility selects the correct CIMC firmware for your server and then performs the upgrade. Wait until you see confirmation that the upgrade was successful, then either select another option from this menu or go to Step 8, on page 5. Note We recommend you always upgrade the BIOS when you upgrade the CIMC firmware.

Option	Description
2. Update BIOS	The utility selects the correct BIOS firmware for your server and then performs the upgrade. Wait until you see confirmation that the upgrade was successful, then either select another option from this menu or go to Step 8, on page 5. Note We recommend you always upgrade the CIMC firmware when you upgrade the BIOS.
3. Update LOM Firmware	The utility selects the correct LOM firmware for your server and then performs the upgrade. The updated image reverts LOM firmware settings back to factory defaults. Wait until you see confirmation that the upgrade was successful, then either select another option from this menu or go to Step 8, on page 5. Note It is possible that some older systems might fail the PHY link upgrade. If this happens, power cycle the server and try the LOM update again.
4. Update LSI Firmware	The utility checks for any installed and supported LSI storage controller cards, selects the correct LSI firmware and NVdata, and then performs the upgrade. Wait until you see confirmation that the upgrade was successful, then either select another option from this menu or go to Step 8, on page 5. Note These upgrades take place after the server reboots.
5. Update UCS P81E VIC	The utility checks for any installed Cisco UCS P81E Virtual Interface Cards (VICs), selects the correct firmware, and then performs the upgrade. Wait until you see confirmation that the upgrade was successful, then either select another option from this menu or go to Step 8, on page 5.
6. All of the above	The utility selects the correct firmware components for your server and then upgrades the CIMC, BIOS, LOM, LSI, P81E VIC firmware, and in that order. Wait until you see confirmation that the upgrade was successful, then go to Step 8, on page 5.

Step 8 After all upgrades are successful, select the appropriate CIMC settings to use during the reboot from the **Host Upgrade Menu**.

Option	Description
7. Reboot (Retains current settings of CIMC)	The utility reboots the server with your existing CIMC settings. Use this selection if you are upgrading a standalone server that you want to continue using in standalone mode with your current settings. Note This reboot will end connection with the CIMC and you must log in again to re-establish connection to the CIMC and reopen any KVM session that you had open.
8. Reboot (Restore factory default settings)	The utility reboots the server with factory default settings. This option is not available on C260 and C460 servers.

Note Option **8** enables DHCP, Active-Active NIC redundancy, and Shared LOM NIC mode, which enables CIMC control through the 1Gb LOM ports rather than the management port. Any static IP addresses and the management port are disabled, so you lose connection with the CIMC and you must log in again to re-establish connection to the CIMC and then reopen any KVM session that you had open.

After you select option **7** or **8**, the server reboots. If you upgraded the CIMC firmware, the new firmware version is activated during this reboot.

Step 9 (Optional) If you updated the LOM firmware, you must fully power cycle the server. You can do this by:

- Unplugging the power cords from all power supplies for a few moments and then reattaching them.
- Using your APC device to shut off power to the server and then restore it.

Troubleshooting

The following table describes troubleshooting suggestions for issues that you might encounter.

Issue	Suggested Solution
Connection to CIMC is lost after an update and reboot and the KVM session ends.	This is expected behavior after a firmware update. Log back in to the CIMC and reestablish your KVM session.
KVM console screen goes blank when it is idle during an upgrade.	Select View > Refresh from the menu in the KVM tab to return the display to the screen.

Additional Information

Related Cisco UCS Documentation

Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/c-series-doc>.

Other Documentation Resources

An ISO file containing all B and C-Series documents is available at the following URL: <http://www.cisco.com/cisco/software/type.html?mdfid=283853163&flowid=25821>. From this page, click **Unified Computing System (UCS) Documentation Roadmap Bundle**.

The ISO file is updated after every major documentation release.

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly [What's New in Cisco Product Documentation](#), which also lists all new and revised Cisco technical documentation.

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@external.cisco.com. We appreciate your feedback.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at <http://cisco.com/go/trademarks>. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1101R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.

**Americas Headquarters**

Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters

Cisco Systems (USA) Pte. Ltd.
Singapore

Europe Headquarters

Cisco Systems International BV
Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.