Troubleshooting SSC Set-Tops with Single- and Triple-LEDs

_	If you see this	Try this first	Try this second	Mark Repair Tag
Power LED Blink Pattern	POWER LED blinks twice quickly, pauses, repeats continuously [cA.rd/dn.Ld – CableCARD [®] module download error]	Check RF levels at download frequency. If needed, adjust levels	Verify image is on BFS. If not, contact DNCS operator to troubleshoot.	D11. CableCARD Download Incomplete
	POWER LED on or off, POWER button unresponsive to power [No display]	Switch AC input and power cycle the set-top	RETURN TO CISCO REPAIR	F1. No Power / Dead
	POWER LED on or off, POWER button responsive to power [No display]	Connect to known good RF cable, power cycle the set-top, and wait 5 minutes	RETURN TO CISCO REPAIR	D2. Unable to Connect to Network
	POWER LED on for two seconds, off for two seconds, repeats continuously [Br.xx – OS trap]	Reboot set-top (Power off, unplug power cord, plug power cord back in, then power the set- top back on)	Force a download by following these steps: Disconnect the AC power cord from the back of the set-top. Simultaneously reconnect the AC power cord while pressing and holding the POWER button until either the POWER LED (single LED set-tops) or the REMOTE LED (three LED set-tops) begins blinking. Press the POWER button again so the LED blinks faster. In a few seconds, the set-top will start downloading code.	D7. Error Code (BRXX, ERXX, or XXXX)
	POWER LED blinks 8 times quickly, pauses, repeats continuously [Stuck in Brick Mode]	Confirm set-top MAC address matches billing MAC address and that set-top is authorized for service. Have DNCS operator correct any existing mismatch and send 'Hit' to set-top.	SEE POWERKEY [®] TROUBLESHOOTING SECTION IN 4019359 Troubleshooting Cisco's Separable Security Set-Tops	S2. Stays in Brick Mode () S3. Invalid Sub Expire Date S1. No EMMs / ISE / EA
	POWER LED blinks twice, pauses for one second, repeatsTHREE-LED SET-TOPS - LEDs blink in a rotating pattern to the left, continuously	Connect to known good RF cable, power cycle, then force download by turning the set-top off. Press and hold the POWER button until the POWER LED begins blinking. Press POWER again so the LED blinks faster. After a few seconds, the set-top will start downloading code.	Confirm hardware type on set-top label is associated with ROM version file on DNCS, then compare with known good set-top of same type.	D6. DHCT in Hunt Mode (hXXX)
	[h.xxx – Hunt mode, will not download]			
	POWER LED blinks three times, pauses, repeats continuously	Perform force download to known good set-top by following these steps: Disconnect the AC power cord from the back of the set-top.	If known good set-top of same type and revision does not download, contact DNCS operator to resolve network issue.	D2. Unable to Connect to Network
	THREE-LED SET-TOPS - LEDs rotate left, rotate right, repeat continuously	Simultaneously reconnect the AC power cord while pressing and holding the POWER button until either the POWER LED (single LED set- tops) or the REMOTE LED (three LED set-		
	[r.xxx – Will not download]	tops) begins blinking. Press the POWER button again so the LED blinks faster. In a few seconds, the set-top will start downloading code.		
	Set-top continually reboots	Power cycle the set-top	RETURN TO CISCO REPAIR	D5. Constantly Resets / Reboots

Cisco Systems, Inc. All rights reserved. Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks².

CableCARD is a trademark of Cable Television Laboratories, Inc.

Other third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R) Product and service availability are subject to change without notice.

© 2009, 2012 Cisco and/or its affiliates. All rights reserved.

October 2012

Printed in USA

Part Number 78-4021198-01 Rev B