



A

AAR

- MLPP interaction [13-26](#)

access

- restricting with partitions [10-3](#)

access control

- MLPP numbering plan

 - example (figure) [13-20](#)

 - explained [13-19](#)

- precedence patterns

 - example (figure) [13-20](#)

 - explained [13-19](#)

ac user

- associating with devices and pilot points [16-27](#)

- configuring [16-20](#)

alternate party diversion (APD)

- example (figure) [13-10](#)

- explained [13-9](#)

announcements

- blocked precedence [13-18](#)

- blocked precedence (figure) [13-18](#)

- busy station [13-18](#)

- MLPP [13-16](#)

- unauthorized precedence [13-17](#)

- unauthorized precedence (figure) [13-17](#)

application dial rules

- configuring for WebDialer [15-10](#)

Attendant Console

- See Cisco Unified CallManager Attendant Console*

audio sources

- configuring [6-16](#)

- creating for MOH [6-9](#)

- default MOH sample [6-9](#)

- for MOH [6-8](#)

- managing for MOH [6-10](#)

- multicast [6-10](#)

- storing for MOH [6-9](#)

- unicast [6-10](#)

- auto call pickup [10-2](#)

- automated alternate routing (AAR)

 - MLPP interaction [13-26](#)

B

bandwidth

- insufficient with AAR for MLPP [13-26](#)

barge

- activating with built-in conference bridge [8-8](#)

- configuration checklist (table) [8-9](#)

- installing and activating [8-8](#)

- interactions and restrictions [8-6](#)

- overview [8-1](#)

- service parameters [8-10](#)

- softkey [8-3](#)

- system requirements [8-5](#)

BLF/SpeedDial

- buttons [20-19](#)

- configuration settings (table) [20-20](#)

- configuring [20-18](#)

built-in conference bridge

- barge [8-8](#)

C

call display restrictions

- configuration checklist (table) [17-5](#)
- configuring [17-5](#)
- configuring in user device profile [1-18](#)
- enabling [17-2](#)
- interactions [17-3](#)
- introduction [17-1](#)
- overview [17-1](#)
- sample configurations [17-8](#)
- scenarios [17-3](#)
- system requirements [17-3](#)

call forward

- MLPP interaction [13-24](#)

calling search spaces

- Cisco Unified CallManager Assistant
 - configuration tips [2-17](#)
- SUBSCRIBE (for Presence) [20-8, 20-13](#)

call park

- configuration checklist (table) [9-6](#)
- configuration settings (table) [9-10](#)
- configuring [9-6](#)
- configuring a number [9-9](#)
- deleting a number [9-11](#)
- example with MOH [6-5](#)
- finding a number [9-7](#)
- installing and activating [9-6](#)
- interactions [9-4](#)
- introduction [9-1](#)
- overview [9-1](#)
- restrictions [9-6](#)
- setting service parameters [9-7](#)
- system requirements [9-4](#)
- troubleshooting [9-11](#)
- usage example [9-2](#)

call pickup group

- assigning call pickup group to a directory number [10-14](#)
- auto call pickup [10-2](#)

configuration checklist (table) [10-6](#)

configuration settings (table) [10-12](#)

configuring [10-1, 10-11](#)

defining a pickup group for other group call
pickup [10-13](#)

deleting [10-13](#)

finding [10-10](#)

installing and activating [10-1](#)

interactions and restrictions [10-4](#)

introducing [10-1](#)

restricting access [10-3](#)

setting the service parameters [10-9](#)

system requirements [10-1, 10-3](#)

using with partitions [10-3](#)

call preservation

- with MLPP [13-26](#)

call queuing [16-9](#)

call transfer

- MLPP interaction [13-25](#)

call waiting

- MLPP interaction [13-25](#)

cBarge

- activating with shared conference bridge [8-8](#)
- softkey [8-4](#)

CDR

- recording for precedence calls [13-24](#)

channel nonpreemptable [13-12](#)

Cisco Call Back

- additional information for Cisco Call Back notification
with SIP phones [4-5](#)
- configuration checklist [4-7](#)
- description [4-1](#)
- interactions and restrictions [4-5](#)
- interactions with Call Forward, iDivert, and Voice-Mail
System features [4-6](#)
- overview [4-1](#)
- setting service parameters [4-9](#)
- softkey template [4-8](#)
- suspend/resume functionality [4-4](#)
- system requirements [4-4](#)

- understanding [4-2](#)
- Cisco CallManager Attendant Console Server service
 - service parameters [16-31](#)
 - understanding [16-10](#)
- Cisco CallManager Unified AutoAttendant
 - configuration checklist (table) [7-5](#)
- Cisco CRS engine [7-9](#)
 - adding Cisco Unified CallManager AutoAttendant [7-16](#)
 - configuring for Cisco Unified CallManager AutoAttendant [7-9](#)
- Cisco Customer Response Platform
 - components [7-3](#)
- Cisco Extension Mobility
 - adding [1-14](#)
 - bulk administration tool [1-8](#)
 - configuration checklist [1-12](#)
 - configuration example [1-11, 1-12](#)
 - configuring [1-10](#)
 - description [1-3](#)
 - device profiles [1-2](#)
 - illustrated (figure) [1-3](#)
 - information for users [1-25](#)
 - installing [1-10](#)
 - interaction with Presence [20-9](#)
 - login call flow [1-6](#)
 - logout call flow [1-6](#)
 - overview [1-1](#)
 - subscribing [1-22](#)
 - system requirements [1-7](#)
 - user device profile, associating [1-22](#)
- Cisco IPMA
 - See* Cisco Unified CallManager Assistant
- Cisco Unified CallManager
 - configuring for Cisco Unified CallManager AutoAttendant [7-5](#)
 - creating user [7-5](#)
 - MOH servers [6-7](#)
- Cisco Unified CallManager Assistant
 - architecture overview [2-2, 3-2](#)
 - assistant console dialog options [2-34, 3-23](#)
 - assistant console interface [2-4, 3-3](#)
 - assistant interfaces [2-5, 3-4](#)
 - bulk administration tool [2-7, 3-6](#)
 - calling search space and partitions
 - configuration tips [2-17](#)
 - Cisco Unified IP Phone interface [2-5, 3-4](#)
 - Cisco Unified IP Phone Services, configuration tips [2-22](#)
 - configuration checklist for proxy line support (table) [2-11](#)
 - configuration wizard for proxy line [2-14](#)
 - configuring assistant phones
 - tips [2-24](#)
 - configuring assistant proxy and incoming intercom lines [2-29](#)
 - configuring manager and assigning assistant for proxy line [2-26](#)
 - configuring manager and assigning assistant for shared line [3-16](#)
 - configuring manager phones
 - tips [2-23](#)
 - configuring manager primary and incoming intercom lines [2-26, 3-16](#)
 - configuring shared and incoming intercom lines for assistant [3-19](#)
 - database and directory access architecture
 - understanding [2-5, 3-4](#)
 - deleting assistant information [2-31, 3-21](#)
 - deleting manager information [2-28, 3-18](#)
 - dial rules configuration [2-33, 3-22](#)
 - extension mobility [2-8, 3-7](#)
 - installing and activating [2-10](#)
 - installing the assistant console application [2-33, 3-23](#)
 - IPMASecureSysUser [2-21, 3-13](#)
 - manager and assistant phone configuration [2-22, 3-14](#)
 - manager assistant administration interface [2-6, 3-5](#)
 - manager configuration [2-34, 3-24](#)
 - manager interfaces [2-5, 3-4](#)
 - multilevel precedence and preemption [2-9](#)
 - Multilevel Precedence and Preemption (MLPP) [3-8](#)

- phones
 - configuration tips [2-25, 3-16](#)
- providing information to managers and assistants [2-33, 3-23](#)
- reporting tools [2-8, 3-7](#)
- restrictions [2-10](#)
- route point
 - configuration tips [2-19](#)
- security [2-21, 3-13](#)
- setting service parameters [2-19, 3-12](#)
- softkeys [2-6, 3-5](#)
- starting the Cisco IPMA service [2-22, 3-14](#)
- system configuration with proxy line [2-14](#)
- system requirements [2-6, 3-5](#)
- time-of-day routing [2-9](#)
- understanding [2-2, 3-2](#)
- updating assistant information [2-32, 3-21](#)
- updating manager information [2-28, 3-18](#)
- with proxy line support
 - overview [2-1](#)
- with shared line support
 - overview [3-1](#)
- Cisco Unified CallManager Attendant Console
 - associating devices and pilot points with ac user [16-27](#)
 - client configuration settings (table) [16-36](#)
 - configuration checklist [16-16](#)
 - configuring [16-15](#)
 - configuring attendant settings [16-35](#)
 - configuring held icon timers [16-37](#)
 - CorporateDirectory.txt file
 - creating and uploading [16-31](#)
 - deleting [16-33](#)
 - dependency records [16-38](#)
 - directory [16-9](#)
 - hunt groups
 - configuration settings (table) [16-29](#)
 - deleting members [16-30](#)
 - understanding [16-2](#)
 - viewing members [16-30](#)
 - installation and activation [16-15](#)
 - installing [16-33](#)
 - interactions [16-13](#)
 - overview [16-1](#)
 - performance monitors [16-38](#)
 - pilot points
 - configuration settings [16-24](#)
 - configuring [16-23](#)
 - deleting [16-26](#)
 - finding [16-22](#)
 - resetting [16-26](#)
 - understanding [16-2](#)
 - redundancy [16-11](#)
 - restrictions [16-14](#)
 - starting after installing Windows XP SP2 [16-35](#)
 - system requirements [16-12](#)
 - users
 - configuration settings [16-19](#)
 - configuring [16-17](#)
 - configuring the ac user [16-20](#)
 - deleting [16-20](#)
 - finding [16-18](#)
 - understanding [16-2](#)
- Cisco Unified CallManager AutoAttendant [7-5](#)
 - adding a JTAPI call control group [7-11](#)
 - adding to Cisco CRS [7-16](#)
 - choose media types [7-15](#)
 - Cisco Unified CallManager and the CRS engine [7-4](#)
 - cluster setup [7-10](#)
 - components [7-3](#)
 - configuration (table) [7-5](#)
 - configuring welcome prompt [7-22](#)
 - creating user [7-5](#)
 - customizing [7-20](#)
 - description [7-1](#)
 - installation requirements [7-3](#)
 - installing [7-4](#)
 - installing or upgrading [7-4](#)
 - installing the CRS engine [7-3](#)

- JTAPI trigger [7-17](#)
- managing [7-24](#)
- modifying instance [7-20](#)
- modifying prompts [7-21](#)
- overview [7-2](#)
- provisioning Cisco media termination subsystem [7-15](#)
- recording welcome prompt [7-21](#)
- script [7-2](#)
- server setup [7-11](#)
- understanding [7-1](#)
- uploading spoken name [7-23](#)
- Cisco Unified IP Phone Services
 - Cisco Unified CallManager Assistant
 - configuration tips [2-22](#)
- Cisco WebDialer [15-1](#)
- Client Matter Codes
 - configuration checklist (table) [5-5](#)
 - configuration settings (table) [5-8](#)
 - configuring [5-7](#)
 - CTI, JTAPI, and TAPI usage [5-4](#)
 - deleting [5-8](#)
 - described [5-2](#)
 - enabling for route patterns [5-8](#)
 - finding [5-6](#)
 - installation [5-5](#)
 - interactions [5-3](#)
 - requirements [5-5](#)
 - restrictions [5-3](#)
 - system requirements [5-5](#)
 - user information [5-13](#)
- common network facility preemption
 - example (figure) [13-13](#)
 - example with retry timer Trr (figure) [13-14](#)
 - explained [13-13](#)
- CorporateDirectory.txt file
 - creating and uploading [16-31](#)
 - deleting [16-33](#)
- creating
 - Cisco Unified CallManager user [7-5](#)

- CRS
 - server setup [7-11](#)
- CRS engine
 - hardware and software requirements [7-3](#)
- CTI route points
 - Cisco Unified CallManager Assistant configuration tips [2-19](#)
- Customer Response Solutions
 - server [7-11](#)
- Customer Response Solutions engine
 - installing and upgrading [7-3](#)
- custom phone rings
 - creating [14-3](#)
 - customizing files [14-2](#)
 - introduction [14-1](#)
 - overview [14-1](#)
 - PCM file requirements [14-3](#)

D

- database
 - scalability [6-7](#)
- dependency records
 - Cisco Unified CallManager Attendant Console [16-38](#)
- device profiles
 - and Cisco Extension Mobility [1-2](#)
- directory
 - Cisco Unified CallManager Attendant Console, understanding [16-9](#)
- directory number
 - assigning a call pickup group [10-14](#)
- directory server settings, Cisco Unified CallManager AutoAttendant [7-10](#)
- domain
 - identifier for MLPP [13-6](#)

E

enterprise parameters

MLPP [13-30](#)

Presence [20-12](#)

external call transfer restrictions

block offnet to offnet transfer service parameter [19-7](#)

call classification service parameter [19-7](#)

configuration checklist (table) [19-6](#)

gateway configuration [19-7](#)

installing and activating [19-5](#)

interactions [19-5](#)

overview [19-1](#)

restrictions [19-5](#)

route pattern configuration [19-8](#)

service parameters [19-7](#)

system requirements [19-4](#)

trunk configuration [19-8](#)

multilevel precedence and preemption [2-9](#)

Multilevel Precedence and Preemption (MLLP) [3-8](#)

phones [2-25, 3-16](#)

reporting tools [2-8, 3-7](#)

route point [2-19](#)

softkeys [2-6, 3-5](#)

time-of-day routing [2-9](#)

understanding [2-2, 3-2](#)

understanding architecture [2-2, 3-2](#)

understanding database and directory access
architecture [2-5, 3-4](#)

external call transfer restrictions [19-1](#)

immediate divert [11-1](#)

Malicious Call ID (MCID) [12-1](#)

Multilevel Precedence and Preemption (MLPP)

using with Cisco Unified CallManager Assistant [3-8](#)

Presence [20-1, 20-2](#)

privacy [8-1](#)

QRT [18-1](#)

WebDialer [15-1](#)

file format

Ringlist.xml [14-2](#)

fixed audio source

configuration settings (table) [6-23](#)

configuring [6-21, 6-22](#)

deleting [6-22](#)

Forced Authorization Codes

configuration checklist (table) [5-5](#)

configuration settings (table) [5-11](#)

configuring [5-10](#)

CTI, JTAPI, and TAPI usage [5-4](#)

deleting [5-11](#)

described [5-2](#)

enabling for route patterns [5-12](#)

finding [5-9](#)

installation [5-5](#)

interactions [5-3](#)

requirements [5-5](#)

restrictions [5-3](#)

F

features

barge [8-1](#)

call display restrictions [17-1](#)

call park [9-1](#)

Cisco Extension Mobility

bulk administration tool [1-8](#)

Cisco Unified CallManager Assistant

assistant console interface [2-4, 3-3](#)

assistant interfaces [2-5, 3-4](#)

bulk administration tool [2-7, 3-6](#)

calling search space and partitions [2-17](#)

Cisco Unified IP Phone interface [2-5, 3-4](#)

Cisco Unified IP Phone Services [2-22](#)

configuration checklist for proxy line support
(table) [2-11](#)

extension mobility [2-8, 3-7](#)

manager assistant administration interface [2-6, 3-5](#)

manager interfaces [2-5, 3-4](#)

system requirements [5-5](#)
 user information [5-13](#)

G

group call pickup
 configuration settings (table) [10-12](#)

H

held icon timers, configuring [16-37](#)
 hunt groups
 broadcast, understanding [16-8](#)
 circular, understanding [16-6](#)
 configuration settings (table) [16-29](#)
 configuring [16-28](#)
 deleting members [16-30](#)
 linked, understanding [16-4](#)
 understanding [16-2](#)
 viewing members [16-30](#)

I

immediate divert
 configuration checklist (table) [11-7](#)
 installing and activating [11-7](#)
 interactions [11-5](#)
 more information [11-8](#)
 overview [11-1](#)
 restrictions [11-6](#)
 setting service parameters [11-8](#)
 system requirements [11-2](#)
 using [11-4](#)
 indication enabled [13-8](#)
 insufficient bandwidth
 AAR for MLPP [13-26](#)

L

lines
 interaction with MLPP [13-24](#)
 login call flow
 Cisco Extension Mobility [1-6](#)
 logout call flow
 Cisco Extension Mobility [1-6](#)

M

malicious call ID
 adding a softkey template [12-6](#)
 configuration checklist (table) [12-5](#)
 configuring alarms [12-6](#)
 explained
 giving MCID to users [12-7](#)
 installing [12-4](#)
 interactions [12-3](#)
 overview [12-1](#)
 removing MCID feature [12-7](#)
 restrictions [12-4](#)
 services [12-1](#)
 setting service parameters [12-5](#)
 system requirements [12-2](#)
 troubleshooting [12-8](#)
 using feature with Cisco Unified CallManager [12-2](#)
 feature code [12-2](#)
 Malicious Call Identification (MCID), see malicious call ID
 MCGP
 and MLPP [13-26](#)
 MLPP
 activating [13-28](#)
 announcements
 blocked precedence [13-18](#)
 blocked precedence (figure) [13-18](#)
 busy station [13-18](#)
 explained [13-16](#)

- unauthorized precedence [13-17](#)
- unauthorized precedence (figure) [13-17](#)
- automated alternate routing (AAR) [13-26](#)
- call forward [13-24](#)
- call preservation [13-26](#)
- call transfer [13-25](#)
- call waiting [13-25](#)
- CDR recording [13-24](#)
- configuration checklist (table) [13-29](#)
- described [13-1](#)
- domain [13-6](#)
- enterprise parameters [13-30](#)
- hierarchical configuration [13-23](#)
- indication [13-8](#)
- installing [13-28](#)
- interactions [13-26, 13-27](#)
- introducing [13-1](#)
- line feature interaction [13-24](#)
- MGCP [13-26](#)
- numbering plan
 - example (figure) [13-20](#)
 - explained [13-19](#)
- precedence
 - alternate party diversion (APD) [13-9](#)
 - alternate party diversion example (figure) [13-10](#)
 - call setup [13-8](#)
 - explained [13-3](#)
 - patterns [13-7](#)
- precedence patterns
 - example (figure) [13-20](#)
 - explained [13-19](#)
- preemption
 - common network facility [13-13](#)
 - common network facility example (figure) [13-13](#)
 - common network facility example with retry timer Trr (figure) [13-14](#)
 - details [13-11](#)
 - enabled [13-10, 13-11](#)
 - explained [13-6](#)
 - receiving [13-10](#)
 - user access [13-11](#)
 - user access channel nonpreemptable [13-12](#)
 - user access example (figure) [13-12](#)
- PRI [13-26](#)
- restrictions [13-26, 13-27](#)
- service parameter [13-23](#)
- shared lines [13-25](#)
- terminology [13-2](#)
- trunk selection
 - example (figure) [13-22](#)
 - explained [13-21](#)
- modifying files [14-2](#)
- MOH
 - audio files
 - deleting [6-29](#)
 - displaying [6-28](#)
 - managing [6-28](#)
 - uploading [6-29](#)
 - audio sources [6-16](#)
 - configuration settings (table) [6-19](#)
 - configuring [6-18](#)
 - deleting [6-19](#)
 - explained [6-8](#)
 - finding [6-17](#)
 - call park example [6-5](#)
 - characteristics [6-3](#)
 - configuration checklist (table) [6-14](#)
 - configuring [6-23](#)
 - creating audio sources [6-9](#)
 - database scalability [6-7](#)
 - default MOH sample [6-9](#)
 - definitions [6-2](#)
 - described [6-1](#)
 - failover and fallback [6-13](#)
 - features
 - database requirements [6-7](#)
 - database scalability [6-7](#)
 - manageability [6-7](#)

- MOH servers [6-5](#)
 - server manageability [6-6](#)
 - server redundancy [6-6](#)
 - server scalability [6-6](#)
- fixed audio source [6-21](#)
 - configuration settings (table) [6-23](#)
 - configuring [6-22](#)
 - deleting [6-22](#)
- functionality [6-4](#)
- list of topics [6-1](#)
- managing audio sources [6-10](#)
- monitoring performance
 - overview (table) [6-15](#)
 - service states [6-16](#)
- requirements and limits [6-12](#)
- server configuration settings (table) [6-26](#)
- servers
 - characteristics [6-5](#)
 - configuring [6-24](#)
 - database requirements [6-7](#)
 - explained [6-8](#)
 - finding [6-23](#)
 - manageability [6-6](#)
 - perfmon counters [6-15](#)
 - redundancy [6-6](#)
 - resetting [6-25](#)
 - scalability [6-6](#)
- storing audio sources [6-9](#)
- supported features [6-5](#)
- transfer hold example [6-5](#)
- understanding [6-1](#)
- user hold example [6-5](#)
- multicast
 - audio sources for MOH [6-10](#)
 - configuration checklist (table) [6-12](#)
 - explained [6-10](#)
- multilevel precedence and preemption
 - activating [13-28](#)
- announcements
 - blocked precedence [13-18](#)
 - blocked precedence (figure) [13-18](#)
 - busy station [13-18](#)
 - explained [13-16](#)
 - unauthorized precedence [13-17](#)
 - unauthorized precedence (figure) [13-17](#)
- automated alternate routing (AAR) [13-26](#)
- call forward [13-24](#)
- call preservation [13-26](#)
- call transfer [13-25](#)
- call waiting [13-25](#)
- CDR recording [13-24](#)
- configuration checklist (table) [13-29](#)
- described [13-1](#)
- domain [13-6](#)
- enterprise parameters [13-30](#)
- hierarchical configuration [13-23](#)
- indication [13-8](#)
- installing [13-28](#)
- interactions [13-26, 13-27](#)
- introducing [13-1](#)
- line feature interaction [13-24](#)
- MGCP [13-26](#)
- numbering plan
 - example (figure) [13-20](#)
 - explained [13-19](#)
- precedence
 - alternate party diversion (APD) [13-9](#)
 - alternate party diversion example (figure) [13-10](#)
 - call setup [13-8](#)
 - explained [13-3](#)
 - patterns [13-7](#)
- precedence patterns
 - example (figure) [13-20](#)
 - explained [13-19](#)
- preemption
 - common network facility [13-13](#)
 - common network facility example (figure) [13-13](#)

- common network facility example with retry timer Trr (figure) [13-14](#)
- details [13-11](#)
- enabled [13-10](#), [13-11](#)
- explained [13-6](#)
- receiving [13-10](#)
- user access [13-11](#)
- user access channel nonpreemptable [13-12](#)
- user access example (figure) [13-12](#)
- restrictions [13-26](#), [13-27](#)
- service parameter [13-23](#)
- shared lines [13-25](#)
- terminology [13-2](#)
- trunk selection
 - example (figure) [13-22](#)
 - explained [13-21](#)
- Multilevel Precedence and Preemption (MLPP)
 - using with Cisco Unified CallManager Assistant
 - configuration checklist with shared line support (table) [3-10](#)
 - installing and activating [3-9](#)
 - restrictions [3-8](#)
- music on hold (MOH)
 - audio sources [6-8](#)
 - call park example [6-5](#)
 - characteristics [6-3](#)
 - configuration checklist (table) [6-14](#)
 - creating audio sources [6-9](#)
 - default MOH sample [6-9](#)
 - definitions [6-2](#)
 - described [6-1](#)
 - failover and fallback [6-13](#)
 - functionality [6-4](#)
 - list of topics [6-1](#)
 - managing audio sources [6-10](#)
 - monitoring performance
 - overview (table) [6-15](#)
 - service states [6-16](#)
 - requirements and limits [6-12](#)

- servers
 - characteristics [6-5](#)
 - database requirements [6-7](#)
 - explained [6-8](#)
 - manageability [6-6](#)
 - perfmon counters [6-15](#)
 - redundancy [6-6](#)
 - scalability [6-6](#)
- storing audio sources [6-9](#)
- supported features [6-5](#)
- transfer hold example [6-5](#)
- understanding [6-1](#)
- user hold example [6-5](#)

N

- nonpreemptable user access channel [13-12](#)
- numbering plan
 - MLPP (figure) [13-20](#)
 - MLPP access control [13-19](#)

O

- other call pickup
 - configuration checklist (table) [10-8](#)

P

- parameters, service
 - CDR [12-5](#)
- partitions
 - restricting access [10-3](#)
 - using call pickup [10-3](#)
- partition support
 - overview [15-10](#)
- PCM file requirements
 - for custom ring types [14-3](#)

- perfmon counters
 - counter descriptions (table) [6-16](#)
 - using to view MOH servers [6-15](#)
- phones
 - custom rings
 - creating [14-1, 14-3](#)
 - overview [14-1](#)
 - PCM file requirements [14-3](#)
 - interaction with Presence [20-2](#)
- pilot points
 - associating with the ac user [16-27](#)
 - configuration settings [16-24](#)
 - configuring [16-23](#)
 - deleting [16-26](#)
 - finding [16-22](#)
 - resetting [16-26](#)
 - understanding [16-2](#)
- precedence
 - alternate party diversion (APD)
 - example (figure) [13-10](#)
 - explained [13-9](#)
 - blocked [13-18](#)
 - blocked (figure) [13-18](#)
 - busy station [13-18](#)
 - call setup [13-8](#)
 - CDR recording [13-24](#)
 - explained [13-3](#)
 - patterns
 - access control [13-19](#)
 - MLPP (figure) [13-20](#)
 - setup [13-7](#)
 - unauthorized [13-17](#)
 - unauthorized (figure) [13-17](#)
- preemption
 - common network facility [13-13](#)
 - common network facility example (figure) [13-13](#)
 - common network facility example with retry timer Trr (figure) [13-14](#)
 - details [13-11](#)
 - enabled [13-10, 13-11](#)
 - explained [13-6](#)
 - receiving [13-10](#)
 - user access [13-11](#)
 - user access channel nonpreemptable [13-12](#)
 - user access example (figure) [13-12](#)
- Presence
 - authorization [20-7](#)
 - BLF/SpeedDial
 - configuration settings (table) [20-20](#)
 - configuring [20-18](#)
 - BLF/SpeedDial buttons
 - configuring [20-19](#)
 - configuration checklist (table) [20-10](#)
 - feature interactions and restrictions [20-9](#)
 - groups [20-4](#)
 - applying [20-17](#)
 - configuration example [20-5](#)
 - configuration settings (table) [20-15](#)
 - interaction examples [20-6, 20-7](#)
 - interaction with Cisco Extension Mobility [20-9](#)
 - interaction with phones and trunks [20-2](#)
 - interaction with route lists [20-4](#)
 - more information [20-21](#)
 - overview [20-1, 20-2](#)
 - request
 - examples [20-3](#)
 - SUBSCRIBE calling search space [20-8, 20-13](#)
 - tips for presence group and presence
 - authorization [20-18](#)
- PRI
 - and MLPP [13-26](#)
- privacy
 - activating [8-8](#)
 - configuration checklist (table) [8-10](#)
 - installing and activating [8-8](#)
 - interactions and restrictions [8-6](#)
 - overview [8-1](#)
 - service parameters [8-10](#)

system requirements [8-5](#)
 prompts, Cisco Unified CallManager AutoAttendant [7-21](#)
 proxy user
 creating for WebDialer [15-11](#)

Q

QRT

adding softkey template to phones [18-20](#)
 Cisco Extended Functions service [18-5](#)
 configuration checklist [18-16](#)
 configuring [18-15](#)
 creating softkey template [18-16](#)
 description [18-2](#)
 extended menu choices [18-9](#)
 installing [18-14](#)
 interactions and restrictions [18-14](#)
 IP phone support [18-5](#)
 overview [18-1](#)
 problem categories and reason codes [18-10](#)
 QRT reports [18-26](#)
 securing signaling connections [18-7](#)
 serviceability features [18-21](#)
 setting service parameters [18-24](#)
 system requirements [18-5](#)
 user interface [18-8](#)
 using [18-8](#)
 using the QRT Viewer [18-26](#)
 Quality Report Tool (QRT) [18-1](#)

R

redirector servlet
 configuring [15-10](#)
 redundancy
 Cisco Unified CallManager Attendant Console [16-11](#)
 MOH servers [6-6](#)
 WebDialer [15-2](#)

requirements
 Cisco Call Back [4-4](#)
 Cisco Extension Mobility [1-7](#)
 retry timer Trr example (figure) [13-14](#)
 Ringlist.xml file format [14-2](#)
 route list
 interaction with Presence [20-4](#)

S

security
 Cisco Unified CallManager Assistant [2-21, 3-13](#)
 IPMASecureSysUser [2-21, 3-13](#)
 Presence authorization [20-7](#)
 service parameters
 barge [8-10](#)
 CDR [12-5](#)
 external call transfer restrictions [19-7](#)
 MLPP [13-23](#)
 Presence [20-12](#)
 privacy [8-10](#)
 WebDialer [15-6](#)
 services
 Cisco Extension Mobility, adding [1-14](#)
 shared conference bridge
 cBarge [8-8](#)
 shared lines
 MLPP interaction [13-25](#)
 softkey
 barge [8-3](#)
 cBarge [8-4](#)
 templates for MCID [12-6](#)
 spoken name, uploading [7-23](#)
 standard Cisco Unified CallManager end users group
 adding users for WebDialer [15-11](#)

T

templates, softkey

MCID [12-6](#)

trace settings

WebDialer [15-13](#)

transfer

external call transfer restrictions [19-1](#)

transfer hold, example with MOH [6-5](#)

Trr retry timer preemption example (figure) [13-14](#)

trunks

interaction with Presence [20-2](#)

selection for MLPP

example (figure) [13-22](#)

explained [13-21](#)

U

unicast

audio sources for MOH [6-10](#)

explained [6-10](#)

user

creating Cisco Unified CallManager [7-5](#)

user hold, example with MOH [6-5](#)

users

Cisco Unified CallManager Attendant Console

configuring [16-17](#)

understanding [16-2](#)

W

WebDialer

adding users to standard Cisco Unified CallManager end
users group [15-11](#)

configuration checklist (table) [15-5](#)

configuring application dial rules [15-10](#)

configuring Webdialer servlet [15-6](#)

creating a proxy user [15-11](#)

installing and activating [15-4](#)

interactions and restrictions [15-3](#)

overview [15-1](#)

redirector servlet [15-2](#)

redundancy [15-2](#)

service parameters [15-6](#)

servlet

configuring [15-6](#)

described [15-1](#)

system requirements [15-3](#)

trace settings [15-13](#)

