



## INDEX

---

### A

- About box [2-6](#)
- active version [32-1](#)
- adding a phone for a user [8-3](#)
- adding user to the system [8-2](#)
- ad hoc conference
  - configuration [8-6](#)
  - described [5-2](#)
  - interactions and restrictions [5-2](#)
- administrative interface, described [1-3](#)
- administrator
  - permissions [10-1](#)
  - settings [10-1](#)
  - username and password [10-1](#)
- administrator username and password
  - defaults [2-8](#)
  - described [2-8](#)
  - strong passwords [2-9](#)
- auto attendant
  - configuration [8-13](#)
  - described [1-9](#)
  - interactions and restrictions [1-9](#)
  - settings in GUI [12-1](#)
  - setting up system so that calls go to auto attendant if operator is not available [8-15](#)
  - setting up system so that calls go to auto attendant instead of operator [8-14](#)
  - using auto attendant without voicemail [2-19](#)

---

### B

- backup
  - described [2-15](#)

- settings in GUI [13-1](#)
- barge
  - configuration [8-6](#)
  - described [5-2](#)
  - interactions and restrictions [5-2](#)
- before deployment
  - questions to ask your customer [6-7](#)
  - working in the Cisco-provided data configuration file [3-1](#)
- benefits of deploying [1-2](#)
- browser support [2-5](#)
- busy lamp feature
  - described [5-14](#)

---

### C

- call back
  - described [5-3](#)
  - interactions and restrictions [5-3](#)
- call barge
  - configuration [8-6](#)
  - described [5-2](#)
  - interactions and restrictions [5-2](#)
- call detail records
  - described [2-15](#)
  - exporting, described [2-15](#)
  - settings [14-1](#)
- call detail reports [14-1](#)
  - settings [14-1](#)
- call divert
  - configuration [8-6](#)
  - described [5-4](#)
  - interactions and restrictions [5-4](#)

- caller ID
  - configuration [5-8](#)
  - described [5-8](#)
- call forward all
  - configuration [8-7](#)
  - described [5-5](#)
- call forward busy
  - configuration [8-7](#)
  - described [5-6](#)
- call forward no answer
  - configuration [8-7](#)
- call forward no busy
  - described [5-6](#)
- call history
  - configuration [5-6](#)
  - described [5-6](#)
- call park
  - configuration [8-8](#)
  - described [5-7](#)
  - interactions and restrictions [5-7](#)
- call pickup
  - configuration [8-8](#)
  - described [5-7](#)
  - interactions and restrictions [5-7](#)
- call waiting
  - configuration [8-11](#)
  - described [5-8](#)
- CCO cases, opening a case [50-93](#)
- CDR [14-1](#)
- Cisco Extension Mobility
  - configuration [8-8](#)
  - described [5-8](#)
  - interactions and restrictions [5-8](#)
  - reports [16-1](#)
- Cisco-provided data configuration file
  - considerations
    - for bulk insertion after initial deployment [3-2](#)
    - for initial deployment and after initial deployment [3-2](#)
    - for initial deployment only [3-2](#)
  - introduction [1-5](#)
  - settings
    - date and time tab [3-6](#)
    - dial plan tab [3-7](#)
    - gateway tab [3-6](#)
    - network tab [3-4](#)
    - phone tab [3-13](#)
    - sites tab [3-9](#)
    - usage profile tab [3-10](#)
    - user tab [3-15](#)
  - when to use [3-1](#)
- Cisco Unified Business Appliance Administration Guide
  - organization [xviii](#)
- Cisco Unified Communications Manager Business Edition
  - 3000 Administrative Interface, described [1-3](#)
  - 3000 First Time Setup Wizard, described [1-3](#)
  - 3000 User Preferences Interface, described [1-4](#)
- Cisco Web Dialer [2-19](#)
  - described [5-9](#)
- Click to Call
  - described [5-9](#)
- components of system
  - auto attendant [1-2](#)
  - Cisco-provided data configuration file [1-2](#)
  - DHCP [1-2](#)
  - DNS [1-2](#)
  - gateway [1-2](#)
  - phones [1-2](#)
  - server [1-2](#)
  - SFTP server [1-2](#)
  - USB support [1-2](#)
  - voicemail [1-2](#)
- configuration export
  - described [2-16](#)
  - importing to another system [2-16](#)
  - settings in GUI [17-1](#)
- configuring

- adding [2-9](#)
- copying [2-9](#)
- deleting [2-9](#)
- finding [2-9](#)
  - search settings [34-1](#)
- Post-Setup Wizard [2-14](#)
- when configuration is not allowed [2-13](#)
- conventions [xviii](#)
- country pack
  - described [2-7](#)
  - installing [2-7](#)
  - obtaining [2-7](#)

---

## D

- date and time
  - settings
    - from Cisco-provided data configuration file [3-6](#)
    - in GUI [18-1](#)
- departments
  - adding a department and public-space phone [8-5](#)
  - described [1-42](#)
  - settings
    - in GUI [19-3](#)
- deployment model, example [1-47](#)
- devices
  - settings
    - from GUI [20-1](#)
- DHCP
  - described [1-31](#)
- diagnostics
  - settings [21-1](#)
- dial plan
  - described [1-35](#)
  - settings
    - for translation rules [22-3](#)
    - from Cisco-provided data configuration file [3-7](#)
    - from GUI [22-1](#)
- distinctive ringing

- described [5-10](#)
- divert
  - configuration [8-6](#)
  - described [5-4](#)
  - interactions and restrictions [5-4](#)
- DNS [1-32](#)
- document
  - conventions [xviii](#)
  - organization [xviii](#)
  - product security overview [xix](#)
- do not disturb
  - configuration [8-9](#)
  - described [5-10](#)
  - interactions and restrictions [5-10](#)
  - settings
    - in Phone page [28-1](#)
    - in voice features settings page [43-29](#)

---

## E

- Extension Mobility
  - configuration [8-8](#)
  - described [5-8](#)
  - interactions and restrictions [5-8](#)
  - reports [16-1](#)

---

## F

- fax
  - setting up fax [8-5](#)
- finding
  - settings [34-1](#)
- first time setup wizard, described [1-3](#)

---

## G

- gateway
  - configuring

- adding [7-1](#)
- deleting [7-1](#)
- updating (editing) [7-1](#)
- described [1-10](#)
- settings
  - from Cisco-provided data configuration file [3-6](#)
- gathering customer data before deployment [6-1](#)

## GUIs

- administrative interface
  - described [1-3](#)
- browser support [2-5](#)
- first time setup wizard
  - described [1-3](#)
- logging into and out of [2-2](#)
- user preferences interface
  - described [1-4](#)
  - making user updates [2-19](#)

## H

- health summary [24-1](#)
- troubleshooting issues [47-51](#)
  - additional system resources exceeded threshold [47-62](#)
  - conference bridge issue [47-53](#)
  - conference bridge resources insufficient [47-53](#)
  - CPU usage high [47-61](#)
  - external call resources low [47-62](#)
  - gateway issue [47-54](#)
  - gateway out of service [47-55](#)
  - hardware failure occurred [47-58](#)
  - internal call resources low [47-63](#)
  - internal synchronization issue occurred [47-63](#)
  - phone failed to register [47-64](#)
  - required service failed [47-58](#)
  - unregistered devices large [47-54](#)
- hold and resume
  - configuration [5-6](#)
  - described [5-6](#)

- hostname resolution [1-32](#)
- hunt lists
  - described [1-46](#)
  - settings from GUI [23-5](#)

- inactive version [32-1](#)

- introduction [1-1](#)

## L

- licensing
  - backing up licenses [4-10](#)
  - deleting licenses [4-10](#)
  - how borrowing and loaning works [4-5](#)
  - how it works [4-2](#)
  - installing a license file [4-8](#)
  - interactions and restrictions [4-6](#)
  - license types [4-4](#)
  - more information [4-11](#)
  - obtaining licenses [4-7](#)
  - overview [4-1](#)
  - restoring licenses [4-10](#)
  - settings in GUI [25-1](#)
  - viewing contents of license file [4-8](#)
  - viewing number of licenses that are used, borrowed, and so on [4-9](#)
  - viewing status [4-9](#)
- lines
  - how lines relate to users and phones [1-42](#)
  - rollover
    - configuration [8-11](#)
    - described [5-13](#)
  - shared
    - described [5-13](#)
- locale
  - described [2-7](#)
  - settings in GUI [15-1](#)

logging into and out of GUIs [2-2](#)  
 logical partitioning [36-18](#)

## M

meet-me conference  
     configuration [8-9](#)  
 meet me conferences  
     described [5-11](#)  
 monitoring [2-20](#)  
 music on hold  
     audio source file requirements [26-1](#)  
     configuration [8-9](#)  
     described [5-11](#)  
     interactions and restrictions [5-11](#)  
     settings in GUI [26-1](#)  
     uploading audio source files [26-1](#)  
 mute and volume control  
     described [5-11](#)

## N

network  
     settings  
         from Cisco-provided data configuration file [3-4](#)  
         from GUI [27-1](#)  
 network layout [50-92](#)

## O

online help [2-7](#)  
 open a TAC case, required information [50-92](#)  
 opening a CCO case, url location [50-93](#)  
 operator  
     setting up system so that calls go to auto attendant if  
     operator is not available [8-15](#)  
     setting up system so that calls go to auto attendant  
     instead of operator [8-14](#)  
     setting up system so that calls go to operator [8-14](#)

organization [xviii](#)  
 overview [1-1](#)

## P

passwords  
     creating strong passwords [2-9](#)  
     default [2-8](#)  
 phone application  
     configuration [8-10](#)  
 phone applications  
     described [5-12](#)  
     settings in GUI [29-1](#)  
 phone button template [1-42](#)  
     configuration [40-14](#)  
     described [1-42](#)  
 phone registration [2-18](#)  
 phones  
     adding a department and public-space phone [8-5](#)  
     adding a phone for a user [8-3](#)  
     described [1-6](#)  
     determining if the phone is registered [2-18](#)  
     how ownership works [1-42](#)  
     logging out users from Cisco Extension  
     Mobility-enabled phones [2-18](#)  
     restarting [2-18](#)  
     settings  
         from Cisco-provided data configuration file [3-13](#)  
         from GUI [28-1](#)  
 post-setup wizard  
     described [2-14](#)  
 problem solving guidelines [45-36](#)  
 product security overview [xix](#)  
 pstn connections  
     settings  
         from GUI [31-1](#)

---

**Q**

questions to ask your customer [6-7](#)

---

**R**

Reach Me Anywhere

configuration [8-11](#)

described [5-12](#)

interactions and restrictions [5-12](#)

reports

Extension Mobility [16-1](#)

restart [32-1](#)

automatic restarts [2-17](#)

described [2-17](#)

manual restarts [2-17](#)

phones [2-18](#)

settings [32-1](#)

restore

settings in GUI [33-1](#)

when to restore data [2-15](#)

rollover lines

configuration [8-11](#)

described [5-13](#)

---

**S**

search

settings in GUI [34-1](#)

security [2-6](#)

server, described [1-3](#)

setting up fax [8-5](#)

setting up system so that calls go to auto attendant if operator is not available [8-15](#)

setting up system so that calls to operator [8-14](#)

setting up system so that incoming calls reach the auto attendant [8-14](#)

setting up the customer network and sites [6-2](#)

setup mode page

settings in GUI [35-1](#)

SFTP server

described [1-33](#)

shared lines

configuration [8-11](#)

described [5-13](#)

shutdown [32-1](#)

sites

configuration considerations [1-36](#)

described [1-36](#)

settings

from Cisco-provided data configuration file [3-9](#)

from GUI [36-1](#)

speed dials

configuration [8-12](#)

described [5-14](#)

summary

settings in GUI [37-1](#)

switch version [32-1](#)

---

**T**

TAC

required information [50-92](#)

TCP Port Usage [49-87](#)

transfer

configuration [5-7](#)

described [5-7](#)

translation rules

described [1-35](#)

settings in GUI [22-3](#)

troubleshooting [2-20](#)

caller experience an error when using voicemail [47-68](#)

CPU is high for voicemail or auto attendant [47-68](#)

diagnostics page [21-1](#)

disk space full for voicemail [47-68](#)

from Diagnostics page [46-41](#)

from Health Summary page [46-39](#)

- gateway not listed in site's gateway usage list [47-71](#)
- gateways from a deleted site are no longer used [47-72](#)
- health summary page [24-1](#)
- issued occurred with voicemail database [47-66](#)
- licensing out of compliance [47-65](#)
- local gateway not listed in site's gateway list [47-71](#)
- opening a case [50-93](#)
- operator assisted dialing does not work always [47-70](#)
- order of the PSTN gateways used to route calls changes [47-73](#)
- phone call cannot be established [47-70](#)
- phone has one-way audio [47-70](#)
- phone is registered but automatically resets [47-69](#)
- problem solving guidelines [45-36](#)
- remote gateway not listed in site's gateway list [47-71](#)
- required preliminary information [50-92](#)
- restore of data failed [47-74](#)
- text in English, not my chosen locale [47-74](#)
- tips [45-36](#)
- transit network dialing does not work always [47-70](#)
- upgrade of Unified CMBE 3000 software failed [47-73](#)
- voicemail or auto attendant service not running [47-66](#)
- voicemail port failed to register to telephony system [47-67](#)
- voicemail port locked [47-67](#)
- voicemail ports busy [47-67](#)
- when you cannot access the graphical user interfaces [46-44](#)
- with Network USB key [46-47](#)
- with the diagnostic USB key [46-44](#)
- typical deployment model [1-47](#)

---

## U

- UDP Port Usage [49-87](#)
- upgrade
  - described [2-14](#)
  - settings in GUI [38-1](#)
- upgrade settings [39-5](#)

- usage profiles
  - described [1-39](#)
  - settings
    - from Cisco-provided data configuration file [3-10](#)
    - in GUI [40-7](#)
- USB
  - support described [1-4](#)
- user
  - adding user to the system [8-2](#)
  - described [1-42](#)
  - settings
    - from Cisco-provided data configuration file [3-15](#)
    - in GUI [41-17](#)
- user preferences
  - changing user password [42-23](#)
  - changing user PIN [42-23](#)
  - interface, described [1-4](#)
  - settings [42-23](#)
  - using the web page [42-23](#)

---

## V

- viewing version of software [2-6](#)
- voice feature
  - settings
    - in GUI [43-29](#)
- voicemail
  - configuration [8-12](#)
  - described [1-8, 5-15](#)

---

## W

- Web Dialer [2-19](#)
  - described [5-9](#)

