



Viewing and Updating a Central Voicemail Server

Last updated: August 5, 2011

Procedure

Step 1 Select **Configure > Central Voicemail Servers**.

The system displays the Central Voicemail Servers page, containing a list of the [central voicemail servers](#) that you have configured.

Step 2 To view the details of a central voicemail server, click the underlined name of a server.

The system displays the CUC Profile page with the Profile tab highlighted. The system displays the cluster profile information.

Parameter	Description
Cluster Name	Name of this cluster .
Primary Node	The primary node for this cluster.
Secondary Node	The secondary node for this cluster.
REST Username	The user name for the REST user.
REST Password	The password for the REST user.
REST Pacing Interval	The delay (measured in milliseconds) that the Cisco UMG device inserts between accesses of the Cisco Unity Connection REST interface. We recommend that you leave this value at 0, unless you notice a significant performance impact on the Cisco Unity Connection system during Cisco UMG device provisioning.
E.164 Phone Number	The E.164 phone number that can be dialed from the Cisco Unified SRST site to reach the central Cisco Unity Connection via the PSTN. If configured, this phone number is provisioned on the SRSV-CUE device and allow users to speed dial the central Cisco Unity Connection by pressing 1-1.

Parameter	Description
Enable Provisioning	Whether provisioning is enabled for this cluster.
Auto Attendant Default Root Call Handler	The call handler , or greeting, that is configured on SRSV-CUE devices that have this Cisco Unity Connection as their central voicemail system.

Step 3 To update the profile information, enter the new information and click **Update**.

Related Topics

- [Viewing and Removing Central Voicemail Servers](#)
- [Viewing the Cluster Nodes Associated With a Central Voicemail Server](#)
- [Viewing the Call Handlers Associated With a Central Voicemail Server](#)