



Cisco Wireless LAN Controller Command Reference, Release 7.4

First Published: December 17, 2013

Last Modified: January 28, 2013

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-28745-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2012 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface xlvii

Audience xlvii

Document Organization xlvii

Document Conventions xlvii

Related Documentation I

Obtaining Documentation and Submitting a Service Request I

CHAPTER 1

Using the Command-Line Interface 1

CLI Command Keyboard Shortcuts 1

Using the Interactive Help Feature 2

Using the Help Command 3

Using the ? command 3

Using the partial? command 4

Using the partial command<tab> 4

Using the command ? 5

command keyword ? 6

PART I

System Management Commands 7

CHAPTER 2

CLI Commands 9

show Commands 9

show 802.11 cu-metrics 10

show advanced 802.11 l2roam 11

show advanced send-disassoc-on-handoff 12

show advanced sip-preferred-call-no 13

show advanced sip-snooping-ports 14

show arp kernel 15

show arp switch	16
show avc applications	17
show avc profile	19
show avc statistics application	21
show avc statistics client	23
show avc statistics guest-lan	25
show avc statistics remote-lan	27
show avc statistics top-apps	29
show avc statistics wlan	31
show boot	33
show band-select	34
show buffers	35
show cac voice stats	36
show cac voice summary	38
show cac video stats	39
show cac video summary	40
show cdp	41
show certificate lsc	42
show certificate ssc	43
show certificate summary	44
show client calls	45
show client roam-history	46
show client summary	47
show client summary guest-lan	48
show client tsm	49
show client username	50
show client voice-diag	51
show coredump summary	52
show cpu	53
show custom-web	54
show database summary	55
show dhcp	56
show dtls connections	58
show dhcp proxy	59
show dhcp timeout	60

show flow exporter	61
show flow monitor summary	62
show guest-lan	63
show invalid-config	64
show inventory	65
show license all	66
show license capacity	68
show license detail	69
show license expiring	70
show license evaluation	71
show license feature	72
show license file	73
show license handle	74
show license image-level	75
show license in-use	76
show license permanent	77
show license status	78
show license statistics	79
show license summary	80
show license udi	81
show load-balancing	82
show logging	83
show loginsession	85
show mgmtuser	86
show mdns profile	87
show mdns service	89
show netuser	91
show netuser guest-roles	92
show network	93
show network summary	94
show network multicast mgid detail	96
show network multicast mgid summary	97
show nmsp notify-interval summary	98
show nmsp statistics	99
show nmsp status	101

show nmsp subscription	102
show ntp-keys	103
show qos	104
show reset	105
show route kernel	106
show route summary	107
show sessions	108
show snmpcommunity	109
show snmpengineID	110
show snmptrap	111
show snmpv3user	112
show snmpversion	113
show switchconfig	114
show sysinfo	115
show tech-support	116
show time	117
show trapflags	119
show traplog	121
show rfid client	122
show rfid config	123
show rfid detail	124
show rfid summary	125
config Commands	125
config 802.11h channelswitch	126
config 802.11h powerconstraint	127
config 802.11h setchannel	128
config 802.11 11n support	129
config 802.11 11n support a-mpdu tx priority	130
config 802.11 11n support a-mpdu tx scheduler	132
config 802.11 11n support antenna	133
config 802.11 11n support guard-interval	134
config 802.11 11n support mcs tx	135
config 802.11 11n support rifs	137
config 802.11 beacon period	138
config 802.11 cac defaults	139

config 802.11 cac video acm **141**
config 802.11 cac video cac-method **142**
config 802.11 cac video load-based **144**
config 802.11 cac video max-bandwidth **146**
config 802.11 cac media-stream **148**
config 802.11 cac multimedia **150**
config 802.11 cac video roam-bandwidth **152**
config 802.11 cac video sip **154**
config 802.11 cac video tspec-inactivity-timeout **156**
config 802.11 cac voice acm **158**
config 802.11 cac voice max-bandwidth **159**
config 802.11 cac voice roam-bandwidth **161**
config 802.11 cac voice tspec-inactivity-timeout **163**
config 802.11 cac voice load-based **165**
config 802.11 cac voice max-calls **167**
config 802.11 cac voice sip bandwidth **169**
config 802.11 cac voice sip codec **171**
config 802.11 cac voice stream-size **173**
config 802.11 disable **175**
config 802.11 dtpc **176**
config 802.11 enable **177**
config 802.11 exp-bwreq **178**
config 802.11 fragmentation **179**
config 802.11 l2roam rf-params **180**
config 802.11 max-clients **182**
config 802.11 multicast data-rate **183**
config 802.11 rate **184**
config 802.11 tsm **185**
config advanced 802.11 7920VSIEConfig **186**
config advanced 802.11 edca-parameters **187**
config advanced fastpath fastcache **188**
config advanced fastpath pkt-capture **189**
config advanced sip-preferred-call-no **190**
config advanced sip-snooping-ports **191**
config avc profile create **192**

[config avc profile delete](#) 193

[config avc profile rule](#) 194

[config band-select cycle-count](#) 196

[config band-select cycle-threshold](#) 197

[config band-select expire](#) 198

[config band-select client-rssi](#) 199

[config boot](#) 200

[config cdp](#) 201

[config certificate](#) 202

[config certificate lsc](#) 203

[config certificate ssc](#) 205

[config certificate use-device-certificate webadmin](#) 206

[config coredump](#) 207

[config coredump ftp](#) 208

[config coredump username](#) 209

[config custom-web ext-webauth-mode](#) 210

[config custom-web ext-webauth-url](#) 211

[config custom-web ext-webserver](#) 212

[config custom-web logout-popup](#) 213

[config custom-web redirectUrl](#) 214

[config custom-web webauth-type](#) 215

[config custom-web weblogo](#) 216

[config custom-web webmessage](#) 217

[config custom-web webtitle](#) 218

[config dhcp](#) 219

[config dhcp proxy](#) 222

[config dhcp timeout](#) 223

[config flow](#) 224

[config guest-lan](#) 225

[config guest-lan custom-web ext-webauth-url](#) 226

[config guest-lan custom-web global disable](#) 227

[config guest-lan custom-web login_page](#) 228

[config guest-lan custom-web webauth-type](#) 229

[config guest-lan ingress-interface](#) 230

[config guest-lan interface](#) 231

config guest-lan mobility anchor	232
config guest-lan nac	233
config guest-lan security	234
config license boot	235
config load-balancing	236
config location	238
config logging buffered	240
config logging console	241
config logging debug	242
config logging fileinfo	243
config logging procinfo	244
config logging traceinfo	245
config logging syslog host	246
config logging syslog facility	247
config logging syslog level	249
config login session close	250
config mdns profile	251
config mdns query interval	253
config mdns service	255
config mdns snooping	257
config mgmtuser add	258
config mgmtuser delete	259
config mgmtuser description	260
config mgmtuser password	261
config netuser add	262
config netuser delete	264
config netuser description	265
config netuser guest-lan-id	266
config netuser guest-role apply	267
config netuser guest-role create	268
config netuser guest-role delete	269
config netuser guest-role qos data-rate average-data-rate	270
config netuser guest-role qos data-rate average-realtime-rate	271
config netuser guest-role qos data-rate burst-data-rate	272
config netuser guest-role qos data-rate burst-realtime-rate	273

config netuser lifetime	274
config netuser maxUserLogin	275
config netuser password	276
config netuser wlan-id	277
config network 802.3-bridging	278
config network allow-old-bridge-aps	279
config network ap-discovery	280
config network ap-fallback	281
config network ap-priority	282
config network apple-talk	283
config network arptimeout	284
config network bridging-shared-secret	285
config network broadcast	286
config network fast-ssid-change	287
config network ip-mac-binding	288
config network master-base	289
config network mgmt-via-wireless	290
config network multicast global	291
config network multicast igmp query interval	292
config network multicast igmp snooping	293
config network multicast igmp timeout	294
config network multicast l2mcast	295
config network multicast mld	296
config network multicast mode multicast	297
config network multicast mode unicast	298
config network oeap-600 dual-rlan-ports	299
config network oeap-600 local-network	300
config network otap-mode	301
config network rf-network-name	302
config network secureweb	303
config network secureweb cipher-option	304
config network ssh	305
config network telnet	306
config network usertimeout	307
config network web-auth captive-bypass	308

[config network web-auth cmcc-support 309](#)
[config network web-auth port 310](#)
[config network web-auth proxy-redirect 311](#)
[config network web-auth secureweb 312](#)
[config network webmode 313](#)
[config network web-auth 314](#)
[config network zero-config 315](#)
[config nmsp notify-interval measurement 316](#)
[config paging 317](#)
[config passwd-cleartext 318](#)
[config prompt 319](#)
[config qos average-data-rate 320](#)
[config qos average-realtime-rate 321](#)
[config qos burst-data-rate 322](#)
[config qos burst-realtime-rate 323](#)
[config qos description 324](#)
[config qos max-rf-usage 325](#)
[config qos dot1p-tag 326](#)
[config qos priority 327](#)
[config qos protocol-type 329](#)
[config qos queue_length 330](#)
[config rfid auto-timeout 331](#)
[config rfid status 332](#)
[config rfid timeout 333](#)
[config service timestamps 334](#)
[config sessions maxsessions 335](#)
[config sessions timeout 336](#)
[config switchconfig boot-break 337](#)
[config switchconfig fips-prerequisite 338](#)
[config switchconfig strong-pwd 339](#)
[config switchconfig flowcontrol 340](#)
[config switchconfig mode 341](#)
[config switchconfig secret-obfuscation 342](#)
[config sysname 343](#)
[config snmp community accessmode 344](#)

config snmp community create	345
config snmp community delete	346
config snmp community ipaddr	347
config snmp community mode	348
config snmp engineID	349
config snmp syscontact	350
config snmp syslocation	351
config snmp trapreceiver create	352
config snmp trapreceiver delete	353
config snmp trapreceiver mode	354
config snmp v3user create	355
config snmp v3user delete	357
config snmp version	358
config time manual	359
config time ntp	360
config time timezone	362
config time timezone location	363
config trapflags 802.11-Security	366
config trapflags aaa	367
config trapflags adjchannel-rogueap	368
config trapflags ap	369
config trapflags authentication	370
config trapflags client	371
config trapflags client max-warning-threshold	372
config trapflags configsave	373
config trapflags IPsec	374
config trapflags linkmode	375
config trapflags mesh	376
config trapflags multiusers	377
config trapflags rfid	378
config trapflags rogueap	380
config trapflags rrm-params	381
config trapflags rrm-profile	382
config trapflags stpmode	383
config trapflags strong-pwdcheck	384

config trapflags wps	385
save config	386
Timeout Commands	386
config 802.11 cac video tspec-inactivity-timeout	387
config 802.11 cac voice tspec-inactivity-timeout	389
config advanced timers	391
config dhcp timeout	394
config ldap	395
config remote-lan session-timeout	396
config network usertimeout	397
config radius acct retransmit-timeout	398
config radius auth mgmt-retransmit-timeout	399
config radius auth retransmit-timeout	400
config radius auth server-timeout	401
config rogue ap timeout	402
config tacacs athr mgmt-server-timeout	403
config tacacs auth mgmt-server-timeout	404
config rfid auto-timeout	405
config rfid timeout	406
config wlan session-timeout	407
config wlan usertimeout	408
config wlan security wpa akm ft	409
config wlan security ft	410
Clearing Configurations, Log files, and Other Actions	410
clear acl counters	411
clear ap-config	412
clear ap-eventlog	413
clear ap join stats	414
clear arp	415
clear avc statistics	416
clear client tsm	418
clear config	419
clear ext-webauth-url	420
clear location rfid	421
clear location statistics rfid	422

clear loop statistics	423
clear login-banner	424
clear lwapp private-config	425
clear mdns service-database	426
clear nmsp statistics	427
clear radius acct statistics	428
clear tacacs auth statistics	429
clear redirect-url	430
clear stats ap wlan	431
clear stats local-auth	432
clear stats mobility	433
clear stats port	434
clear stats radius	435
clear stats switch	436
clear stats tacacs	437
clear transfer	438
clear traplog	439
clear webimage	440
clear webmessage	441
clear webtitle	442
Resetting the System Reboot Time	442
reset system at	443
reset system in	444
reset system cancel	445
reset system notify-time	446
reset peer-system	447
Uploading and Downloading Files and Configurations	447
transfer download certpasswor	448
transfer download datatype	449
transfer download filename	451
transfer download mode	452
transfer download password	453
transfer download path	454
transfer download port	455
transfer download serverip	456

transfer download start	458
transfer download tftpPktTimeout	459
transfer download tftpMaxRetries	460
transfer download username	461
transfer encrypt	462
transfer upload datatype	463
transfer upload filename	465
transfer upload mode	466
transfer upload pac	467
transfer upload password	468
transfer upload path	469
transfer upload peer-start	470
transfer upload port	471
transfer upload serverip	472
transfer upload start	473
transfer upload username	474
Installing and Modifying Licenses on Cisco 5500 Series Controllers	474
license clear	476
license comment	477
license install	478
license modify priority	479
license revoke	481
license save	482
Right to Use Licensing Commands	482
license activate ap-count eval	483
license activate feature	484
license add ap-count	485
license add feature	486
license deactivate ap-count eval	487
license deactivate feature	488
license delete ap-count	489
license delete feature	490
Troubleshooting the Controller Settings	490
debug arp	491
debug avc	492

- debug cac 493
- debug cdp 494
- debug crypto 495
- debug dhcp 496
- debug dhcp service-port 497
- debug disable-all 498
- debug l2age 499
- debug mac 500
- debug mdns all 501
- debug mdns detail 502
- debug mdns error 503
- debug mdns message 504
- debug memory 505
- debug nmsp 506
- debug ntp 507
- debug packet error 508
- debug packet logging 509
- debug poe 512
- debug rbc 513
- debug rfid 514
- debug snmp 515
- debug transfer 516
- debug voice-diag 517
- show debug 518
- show eventlog 520
- show memory monitor 521
- show run-config 522
- show process 523
- show tech-support 524
- config memory monitor errors 525
- config memory monitor leaks 526
- config msglog level critical 528
- config msglog level error 529
- config msglog level security 530
- config msglog level verbose 531

config msglog level warning 532

PART II

Ports and Interfaces Commands 533

CHAPTER 3

CLI Commands 535

show Commands 535

show advanced sip-snooping-ports 536

show advanced statistics 537

show interface 538

show interface group 540

show lag eth-port-hash 541

show lag ip-port-hash 542

show lag summary 543

show port 544

show serial 546

show spanningtree port 547

show spanningtree switch 548

show stats port 549

show stats switch 551

config Commands 552

config advanced statistics 553

config interface acl 554

config interface address 555

config interface address peer-redundancy-management 557

config interface address redundancy-management 558

config interface ap-manager 559

config interface create 560

config interface delete 561

config interface dhcp 562

config interface address 564

config interface guest-lan 566

config interface hostname 567

config interface nasid 568

config interface nat-address 569

config interface port 570

config interface quarantine vlan	571
config interface vlan	572
config interface group mdns-profile	573
config interface mdns-profile	574
config lag	576
config macfilter	577
config macfilter description	578
config macfilter interface	579
config macfilter ip-address	580
config macfilter mac-delimiter	581
config macfilter radius-compat	582
config macfilter wlan-id	583
config macfilter wlan-id	584
config port adminmode	585
config port autoneg	586
config port linktrap	587
config port multicast appliance	588
config port power	589
config route add	590
config route delete	591
config serial baudrate	592
config serial timeout	593
config spanningtree port mode	594
config spanningtree port pathcost	595
config spanningtree port priority	596
config spanningtree switch bridgepriority	597
config spanningtree switch forwarddelay	598
config spanningtree switch hellotime	599
config spanningtree switch maxage	600
config spanningtree switch mode	601
clear Commands	601
clear stats port	602

PART III**VideoStream Commands 603**

CHAPTER 4**CLI Commands 605****show Commands 605**

show 802.11 606

show 802.11 media-stream 608

show media-stream client 609

show media-stream group detail 610

show media-stream group summary 611

config Commands 611

config 802.11 cac video acm 612

config 802.11 cac video cac-method 613

config 802.11 cac video load-based 615

config 802.11 cac video max-bandwidth 617

config 802.11 cac media-stream 619

config 802.11 cac multimedia 621

config 802.11 cac video roam-bandwidth 623

config 802.11 cac video sip 625

config 802.11 cac video tspec-inactivity-timeout 627

config 802.11 cac voice acm 629

config 802.11 cac voice max-bandwidth 630

config 802.11 cac voice roam-bandwidth 632

config 802.11 cac voice tspec-inactivity-timeout 634

config 802.11 cac voice load-based 636

config 802.11 cac voice max-calls 638

config 802.11 cac voice sip bandwidth 640

config 802.11 cac voice sip codec 642

config 802.11 cac voice stream-size 644

config advanced 802.11 edca-parameters 646

config 802.11 media-stream multicast-direct 647

config 802.11 media-stream video-redirect 649

config media-stream multicast-direct 650

config media-stream message 651

config media-stream add 653

config media-stream admit 655

config media-stream deny 656

[config media-stream delete](#) 657

[config wlan media-stream](#) 658

PART IV

[Security Commands](#) 659

CHAPTER 5

[CLI Commands](#) 661

[show Commands](#) 662

[show 802.11](#) 663

[show aaa auth](#) 665

[show acl](#) 666

[show advanced eap](#) 668

[show database summary](#) 669

[show exclusionlist](#) 670

[show ike](#) 671

[show IPsec](#) 672

[show ipv6 acl](#) 674

[show ipv6 summary](#) 675

[show l2tp](#) 676

[show ldap](#) 677

[show ldap statistics](#) 678

[show ldap summary](#) 679

[show local-auth certificates](#) 680

[show local-auth config](#) 682

[show local-auth statistics](#) 684

[show nac statistics](#) 685

[show nac summary](#) 686

[show netuser](#) 687

[show netuser guest-roles](#) 688

[show network](#) 689

[show network summary](#) 690

[show ntp-keys](#) 692

[show rules](#) 693

[show switchconfig](#) 694

[show rogue adhoc custom summary](#) 695

[show rogue adhoc detailed](#) 696

show rogue adhoc friendly summary	697
show rogue adhoc malicious summary	698
show rogue adhoc unclassified summary	699
show rogue adhoc summary	700
show rogue ap custom summary	701
show rogue ap clients	702
show rogue ap detailed	703
show rogue ap summary	705
show rogue ap friendly summary	707
show rogue ap malicious summary	708
show rogue ap unclassified summary	709
show rogue auto-contain	710
show rogue client detailed	711
show rogue client summary	712
show rogue ignore-list	713
show rogue rule detailed	715
show rogue rule summary	716
show tacacs acct statistics	717
show tacacs athr statistics	718
show tacacs auth statistics	719
show tacacs summary	720
show wps ap-authentication summary	721
show wps cids-sensor	722
show wps mfp	723
show wps shun-list	724
show wps signature detail	725
show wps signature events	726
show wps signature summary	728
show wps summary	729
show wps wips statistics	731
show wps wips summary	732
config Commands	733
config 802.11b preamble	734
config aaa auth	735
config aaa auth mgmt	736

config acl apply	737
config acl counter	738
config acl create	739
config acl cpu	740
config acl delete	741
config acl rule	742
config auth-list add	744
config auth-list ap-policy	745
config auth-list delete	746
config advanced eap	747
config advanced timers auth-timeout	749
config advanced timers eap-timeout	750
config advanced timers eap-identity-request-delay	751
config cts sxp	752
config database size	753
config exclusionlist	754
config ldap	755
config ldap add	756
config ldap simple-bind	757
config local-auth active-timeout	758
config local-auth eap-profile	759
config local-auth method fast	761
config local-auth user-credentials	763
config ipv6 acl	764
config netuser add	766
config netuser delete	768
config netuser description	769
config network bridging-shared-secret	770
config network web-auth captive-bypass	771
config network web-auth port	772
config network web-auth proxy-redirect	773
config network web-auth secureweb	774
config network webmode	775
config network web-auth	776
config radius acct	777

[config radius acct ipsec authentication](#) 778

[config radius acct ipsec disable](#) 779

[config radius acct ipsec enable](#) 780

[config radius acct ipsec encryption](#) 781

[config radius acct ipsec ike](#) 782

[config radius acct mac-delimiter](#) 783

[config radius acct network](#) 784

[config radius acct retransmit-timeout](#) 785

[config radius auth](#) 786

[config radius auth IPsec authentication](#) 787

[config radius auth IPsec disable](#) 788

[config radius auth IPsec encryption](#) 789

[config radius auth IPsec ike](#) 790

[config radius auth keywrap](#) 791

[config radius auth mac-delimiter](#) 792

[config radius auth management](#) 793

[config radius auth mgmt-retransmit-timeout](#) 794

[config radius auth network](#) 795

[config radius auth retransmit-timeout](#) 796

[config radius auth rfc3576](#) 797

[config radius auth server-timeout](#) 798

[config radius aggressive-failover disabled](#) 799

[config radius backward compatibility](#) 800

[config radius callStationIdCase](#) 801

[config radius callStationIdType](#) 802

[config radius fallback-test](#) 804

[config rogue adhoc](#) 806

[config rogue ap classify](#) 809

[config rogue ap friendly](#) 811

[config rogue ap rldp](#) 813

[config rogue ap ssid](#) 815

[config rogue ap timeout](#) 817

[config rogue auto-contain level](#) 818

[config rogue ap valid-client](#) 819

[config rogue client](#) 821

config rogue detection	823
config rogue detection min-rssi	824
config rogue detection monitor-ap	825
config rogue rule	827
config tacacs acct	831
config tacacs athr	832
config tacacs athr mgmt-server-timeout	833
config tacacs auth	834
config tacacs auth mgmt-server-timeout	835
config wps ap-authentication	836
config wps auto-immune	837
config wps cids-sensor	838
config wps client-exclusion	840
config wps mfp	841
config wps shun-list re-sync	842
config wps signature	843
config wps signature frequency	844
config wps signature interval	845
config wps signature mac-frequency	846
config wps signature quiet-time	847
config wps signature reset	848
clear Commands	849
clear acl counters	850
clear radius acct statistics	851
clear tacacs auth statistics	852
clear stats local-auth	853
clear stats radius	854
clear stats tacacs	855
debug Commands	856
debug llw-pmf	857
debug aaa	858
debug aaa local-auth	859
debug bcast	861
debug cckm	862
debug cts sxp	863

[debug dot1x](#) 864
[debug dtls](#) 865
[debug cckm](#) 866
[debug nac](#) 867
[debug pm](#) 868
[debug web-auth](#) 870
[debug wips](#) 871
[debug wps sig](#) 872
[debug wps mfp](#) 873

PART V

WLAN Commands 875

CHAPTER 6

CLI Commands 877

[show Commands](#) 877
[show advanced hotspot](#) 878
[show avc statistics wlan](#) 879
[show call-control ap](#) 881
[show call-control client](#) 885
[show client ccx client-capability](#) 886
[show client ccx frame-data](#) 887
[show client ccx last-response-status](#) 888
[show client ccx last-test-status](#) 889
[show client ccx log-response](#) 890
[show client ccx manufacturer-info](#) 891
[show client ccx operating-parameters](#) 892
[show client ccx profiles](#) 893
[show client ccx results](#) 895
[show client ccx rm](#) 896
[show client ccx stats-report](#) 898
[show client detail](#) 899
[show client location-calibration summary](#) 901
[show client probing](#) 902
[show client roam-history](#) 903
[show client summary](#) 904
[show client wlan](#) 905

show dhcp	906
show dhcp proxy	908
show dhcp timeout	909
show guest-lan	910
show ipv6 acl	911
show ipv6 neighbor-binding	912
show ipv6 ra-guard	914
show ipv6 summary	915
show macfilter	916
show pmk-cache	917
show remote-lan	918
show rf-profile summary	920
show rf-profile details	921
show wlan	923
config Commands	927
config 802.11 dtpe	928
config auto-configure voice	929
config client ccx clear-reports	932
config client ccx clear-results	933
config client ccx default-gw-ping	934
config client ccx dhcp-test	935
config client ccx dns-ping	936
config client ccx dns-resolve	937
config client ccx get-client-capability	938
config client ccx get-manufacturer-info	939
config client ccx get-operating-parameters	940
config client ccx get-profiles	941
config client ccx log-request	942
config client ccx send-message	944
config client ccx stats-request	947
config client ccx test-abort	948
config client ccx test-association	949
config client ccx test-dot1x	950
config client ccx test-profile	951
config client deauthenticate	952

config client location-calibration	953
config ipv6 disable	954
config ipv6 enable	955
config ipv6 acl	956
config ipv6 neighbor-binding	958
config ipv6 ns-mcast-fwd	960
config ipv6 ra-guard	961
config remote-lan	962
config remote-lan aaa-override	963
config remote-lan acl	964
config remote-lan create	965
config remote-lan custom-web	966
config remote-lan delete	968
config remote-lan dhcp_server	969
config remote-lan exclusionlist	970
config remote-lan interface	971
config remote-lan ldap	972
config remote-lan mac-filtering	973
config remote-lan max-associated-clients	974
config remote-lan radius_server	975
config remote-lan security	977
config remote-lan session-timeout	978
config remote-lan webauth-exclude	979
config rf-profile band-select	980
config rf-profile client-trap-threshold	982
config rf-profile create	983
config rf-profile coverage	984
config rf-profile data-rates	986
config rf-profile delete	988
config rf-profile description	989
config rf-profile load-balancing	990
config rf-profile max-clients	992
config rf-profile multicast data-rate	993
config rf-profile out-of-box	994
config rf-profile tx-power-control-thresh-v1	996

config rf-profile tx-power-control-thresh-v2	997
config rf-profile tx-power-max	998
config rf-profile tx-power-min	999
config watchlist add	1000
config watchlist delete	1001
config watchlist disable	1002
config watchlist enable	1003
config wlan	1004
config wlan 7920-support	1005
config wlan 802.11e	1006
config wlan aaa-override	1007
config wlan acl	1008
config wlan assisted-roaming	1009
config wlan avc	1010
config wlan apgroup	1012
config wlan band-select allow	1020
config wlan broadcast-ssid	1021
config wlan call-snoop	1022
config wlan chd	1023
config wlan ccx aironet-ie	1024
config wlan channel-scan defer-priority	1025
config wlan channel-scan defer-time	1026
config wlan custom-web	1027
config wlan dhcp_server	1029
config wlan diag-channel	1030
config wlan dtim	1031
config wlan exclusionlist	1032
config wlan flow	1033
config wlan flexconnect ap-auth	1034
config wlan flexconnect learn-ipaddr	1035
config wlan flexconnect local-switching	1036
config wlan flexconnect vlan-central-switching	1038
config wlan hotspot	1039
config wlan hotspot dot11u	1040
config wlan hotspot dot11u 3gpp-info	1042

config wlan hotspot dot11u auth-type	1044
config wlan hotspot dot11u disable	1046
config wlan hotspot dot11u domain	1047
config wlan hotspot dot11u enable	1049
config wlan hotspot dot11u hessid	1050
config wlan hotspot dot11u ipaddr-type	1051
config wlan hotspot dot11u nai-realm	1053
config wlan hotspot dot11u network-type	1056
config wlan hotspot dot11u roam-oi	1058
config wlan hotspot hs2	1060
config wlan hotspot msap	1063
config wlan interface	1064
config wlan ipv6 acl	1065
config wlan kts-cac	1066
config wlan learn-ipaddr-cswlan	1067
config wlan ldap	1068
config wlan load-balance	1069
config wlan mac-filtering	1070
config wlan max-associated-clients	1071
config wlan max-radio-clients	1072
config wlan mdns	1073
config wlan media-stream	1075
config wlan mfp	1076
config wlan mobility anchor	1077
config wlan mobility foreign-map	1078
config wlan multicast buffer	1079
config wlan multicast interface	1080
config wlan nac	1081
config wlan override-rate-limit	1082
config wlan passive-client	1084
config wlan peer-blocking	1085
config wlan pmipv6 default-realm	1086
config wlan pmipv6 mobility-type	1087
config wlan pmipv6 profile_name	1088
config wlan profiling	1089

config wlan qos	1091
config wlan radio	1092
config wlan radius_server acct	1093
config wlan radius_server acct interim-update	1094
config wlan radius_server auth	1095
config wlan radius_server acct interim-update	1096
config wlan radius_server overwrite-interface	1097
config wlan roamed-voice-client re-anchor	1098
config wlan security 802.1X	1099
config wlan security ckip	1101
config wlan security cond-web-redir	1102
config wlan security eap-passthru	1103
config wlan security ft	1104
config wlan security ft over-the-ds	1105
config wlan security IPsec disable	1106
config wlan security IPsec enable	1107
config wlan security IPsec authentication	1108
config wlan security IPsec encryption	1109
config wlan security IPsec config	1110
config wlan security IPsec ike authentication	1111
config wlan security IPsec ike dh-group	1112
config wlan security IPsec ike lifetime	1113
config wlan security IPsec ike phase1	1114
config wlan security IPsec ike contivity	1115
config wlan security passthru	1116
config wlan security pmf	1117
config wlan security splash-page-web-redir	1119
config wlan security static-wep-key authentication	1120
config wlan security static-wep-key disable	1121
config wlan security static-wep-key enable	1122
config wlan security static-wep-key encryption	1123
config wlan security tkip	1124
config wlan security web-auth	1125
config wlan security web-passthrough acl	1127
config wlan security web-passthrough disable	1128

config wlan security web-passthrough email-input	1129
config wlan security web-passthrough enable	1130
config wlan security wpa akm 802.1x	1131
config wlan security wpa akm cckm	1132
config wlan security wpa akm ft	1133
config wlan security wpa akm pmf	1134
config wlan security wpa akm psk	1135
config wlan security wpa disable	1136
config wlan security wpa enable	1137
config wlan security wpa ciphers	1138
config wlan security wpa gtk-random	1139
config wlan security wpa wpa1 disable	1140
config wlan security wpa wpa1 enable	1141
config wlan security wpa wpa2 disable	1142
config wlan security wpa wpa2 enable	1143
config wlan security wpa wpa2 cache	1144
config wlan security wpa wpa2 cache sticky	1145
config wlan security wpa wpa2 ciphers	1146
config wlan sip-cac disassoc-client	1147
config wlan sip-cac send-486busy	1148
config wlan static-ip tunneling	1149
config wlan session-timeout	1150
config wlan user-idle-threshold	1151
config wlan usertimeout	1152
config wlan webauth-exclude	1153
config wlan wmm	1154
clear Commands	1154
clear ipv6 neighbor-binding	1155
debug Commands	1155
debug llw-pmf	1157
debug call-control	1158
debug client	1159
debug dhcp	1160
debug dhcp service-port	1161
debug hotspot events	1162

- debug hotspot packets 1163
- debug ipv6 1164
- debug profiling 1166
- debug wcp 1167
- test Commands 1167
 - test pmk-cache delete 1168

PART VI

Lightweight Access Point Commands 1169

CHAPTER 7

CLI Commands 1171

- show Commands 1171
 - show advanced backup-controller 1172
 - show advanced max-lx-sessions 1173
 - show advanced probe 1174
 - show advanced rate 1175
 - show advanced timers 1176
 - show ap auto-rf 1177
 - show ap ccx rm 1179
 - show ap cdp 1180
 - show ap channel 1182
 - show ap config 1183
 - show ap config global 1189
 - show ap core-dump 1190
 - show ap crash-file 1191
 - show ap data-plane 1192
 - show ap ethernet tag 1193
 - show ap eventlog 1194
 - show ap image 1195
 - show ap inventory 1196
 - show ap join stats detailed 1197
 - show ap join stats summary 1198
 - show ap join stats summary all 1199
 - show ap led-state 1200
 - show ap led-flash 1201
 - show ap link-encryption 1202

show ap monitor-mode summary	1203
show ap packet-dump status	1204
show ap retransmit	1205
show ap stats	1206
show ap summary	1209
show ap tcp-mss-adjust	1210
show ap wlan	1211
show auth-list	1212
show client ap	1213
show boot	1214
show call-control ap	1215
show country	1219
show country channels	1220
show country supported	1221
show dtls connections	1223
show known ap	1224
show ipv6 ra-guard	1225
show msglog	1226
show network summary	1227
show redundancy summary	1229
show redundancy latency	1230
show redundancy interfaces	1231
show redundancy mobilitymac	1232
show redundancy peer-route summary	1233
show redundancy statistics	1234
show redundancy timers	1236
show watchlist	1237
capwap ap Commands	1238
capwap ap controller ip address	1239
capwap ap dot1x	1240
capwap ap hostname	1241
capwap ap ip address	1242
capwap ap ip default-gateway	1243
capwap ap log-server	1244
capwap ap primary-base	1245

capwap ap primed-timer	1246
capwap ap secondary-base	1247
capwap ap tertiary-base	1248
lwapp ap controller ip address	1249
config Commands	1249
config 802.11-a antenna extAntGain	1250
config 802.11-a channel ap	1251
config 802.11-a txpower ap	1252
config 802.11 antenna diversity	1253
config 802.11 antenna extAntGain	1254
config 802.11 antenna mode	1255
config 802.11 antenna selection	1256
config 802.11 beamforming	1257
config 802.11 disable	1259
config advanced 802.11 profile clients	1260
config advanced 802.11 profile customize	1261
config advanced 802.11 profile foreign	1262
config advanced 802.11 profile noise	1263
config advanced 802.11 profile throughput	1264
config advanced 802.11 profile utilization	1265
config advanced backup-controller primary	1266
config advanced backup-controller secondary	1267
config advanced client-handoff	1268
config advanced dot11-padding	1269
config advanced assoc-limit	1270
config advanced max-lx-sessions	1271
config advanced rate	1272
config advanced probe filter	1273
config advanced probe limit	1274
config advanced timers	1275
config ap	1278
config ap autoconvert	1279
config ap bhrate	1280
config ap bridgegroupname	1281
config ap bridging	1282

[config ap cdp 1283](#)
[config ap core-dump 1285](#)
[config ap crash-file clear-all 1286](#)
[config ap crash-file delete 1287](#)
[config ap crash-file get-crash-file 1288](#)
[config ap crash-file get-radio-core-dump 1289](#)
[config ap dot1xuser 1290](#)
[config ap dot1xuser delete 1291](#)
[config ap dot1xuser disable 1292](#)
[config ap ethernet duplex 1293](#)
[config ap ethernet duplex 1294](#)
[config ap ethernet tag 1295](#)
[config ap group-name 1296](#)
[config ap hotspot 1297](#)
[config ap image predownload 1304](#)
[config ap image swap 1305](#)
[config ap led-state 1306](#)
[config ap link-encryption 1307](#)
[config ap link-latency 1308](#)
[config ap location 1309](#)
[config ap logging syslog level 1310](#)
[config ap mgmtuser add 1312](#)
[config ap mgmtuser delete 1314](#)
[config ap mode 1315](#)
[config ap monitor-mode 1317](#)
[config ap name 1318](#)
[config ap packet-dump 1319](#)
[config ap port 1321](#)
[config ap power injector 1322](#)
[config ap power pre-standard 1323](#)
[config ap primary-base 1324](#)
[config ap priority 1325](#)
[config ap reporting-period 1326](#)
[config ap reset 1327](#)
[config ap retransmit interval 1328](#)

config ap retransmit count	1329
config ap role	1330
config ap rst-button	1331
config ap secondary-base	1332
config ap sniff	1333
config ap ssh	1334
config ap static-ip	1335
config ap stats-timer	1337
config ap syslog host global	1338
config ap syslog host specific	1339
config ap tcp-adjust-mss	1340
config ap telnet	1341
config ap tertiary-base	1342
config ap tftp-downgrade	1343
config ap username	1344
config ap venue	1345
config ap wlan	1349
config country	1350
config ipv6 ra-guard	1351
config known ap	1352
config network allow-old-bridge-aps	1353
config network ap-discovery	1354
config network ap-fallback	1355
config network ap-priority	1356
config network apple-talk	1357
config network bridging-shared-secret	1358
config network master-base	1359
config network oeap-600 dual-rlan-ports	1360
config network oeap-600 local-network	1361
config network otap-mode	1362
config network zero-config	1363
config redundancy interface address peer-service-port	1364
config redundancy mobilitymac	1365
config redundancy mode	1366
config redundancy peer-route	1367

config redundancy timer keep-alive-timer	1368
config redundancy timer peer-search-timer	1369
config redundancy unit	1370
redundancy force-switchover	1371
config redundancy management-gateway-failover	1372
config redundancy link-encryption	1373
config slot	1374
config wgb vlan	1375
clear Commands	1375
clear ap-config	1376
clear ap-eventlog	1377
clear ap join stats	1378
clear ap tsm	1379
clear lwapp private-config	1380
debug Commands	1380
debug ap	1381
debug ap enable	1382
debug ap packet-dump	1383
debug ap show stats	1384
debug ap show stats video	1386
debug capwap	1387
debug group	1388
debug lwapp console cli	1389
debug redundancy-link-encryption	1390
debug rfac	1391
debug rmgr	1392
debug rsyncmgr	1393
debug service ap-monitor	1394
transfer download peer-start	1395
transfer upload peer-start	1396
Resetting the System Reboot Time	1396
reset system at	1397
reset system in	1398
reset system cancel	1399
reset system notify-time	1400

reset peer-system 1401

test Commands 1401

test ap pmtu 1402

test capwap 1403

PART VII

Mesh Access Point Commands 1405

CHAPTER 8

CLI Commands 1407

show mesh Commands 1408

show mesh ap 1409

show mesh astools stats 1410

show mesh backhaul 1411

show mesh cac 1412

show mesh client-access 1414

show mesh config 1415

show mesh env 1416

show mesh neigh 1417

show mesh path 1420

show mesh per-stats 1421

show mesh public-safety 1422

show mesh queue-stats 1423

show mesh security-stats 1424

show mesh stats 1426

config mesh Commands 1427

config mesh alarm 1428

config mesh astools 1430

config mesh backhaul rate-adapt 1431

config mesh backhaul slot 1432

config mesh battery-state 1433

config mesh client-access 1434

config mesh ethernet-bridging vlan-transparent 1436

config mesh full-sector-dfs 1437

config mesh linkdata 1438

config mesh linktest 1441

config mesh lsc 1444

- config mesh multicast 1445
- config mesh parent preferred 1447
- config mesh public-safety 1449
- config mesh radius-server 1450
- config mesh range 1451
- config mesh secondary-backhaul 1452
- config mesh security 1453
- config mesh slot-bias 1454
- config lsc mesh 1455
- debug Commands 1455
 - debug mesh security 1456

PART VIII

Radio Resource Management Commands 1457

CHAPTER 9

CLI Commands 1459

- show Commands 1459
 - show 802.11 extended 1460
 - show advanced 802.11 channel 1461
 - show advanced 802.11 coverage 1462
 - show advanced 802.11 group 1463
 - show advanced 802.11 l2roam 1464
 - show advanced 802.11 logging 1465
 - show advanced 802.11 monitor 1466
 - show advanced 802.11 profile 1467
 - show advanced 802.11 receiver 1468
 - show advanced 802.11 summary 1469
 - show advanced 802.11 txpower 1470
 - show advanced dot11-padding 1471
 - show client ccx rm 1472
 - show client location-calibration summary 1474
 - show wps ap-authentication summary 1475
- config Commands 1475
 - config 802.11-a 1476
 - config 802.11-a antenna extAntGain 1477
 - config 802.11-a channel ap 1478

[config 802.11-a txpower ap 1479](#)

[config 802.11-abgn 1480](#)

[config 802.11b 11gSupport 1481](#)

[config 802.11b preamble 1482](#)

[config 802.11h channelswitch 1483](#)

[config 802.11h powerconstraint 1484](#)

[config 802.11h setchannel 1485](#)

[config 802.11 11n support 1486](#)

[config 802.11 11n support a-mpdu tx priority 1487](#)

[config 802.11 11n support a-mpdu tx scheduler 1489](#)

[config 802.11 11n support antenna 1490](#)

[config 802.11 11n support guard-interval 1491](#)

[config 802.11 11n support mcs tx 1492](#)

[config 802.11 11n support rifs 1494](#)

[config 802.11 antenna diversity 1495](#)

[config 802.11 antenna extAntGain 1496](#)

[config 802.11 antenna mode 1497](#)

[config 802.11 antenna selection 1498](#)

[config 802.11 channel 1499](#)

[config 802.11 channel ap 1501](#)

[config 802.11 chan_width 1502](#)

[config 802.11 txPower 1504](#)

[config advanced 802.11 7920VSIEConfig 1506](#)

[config advanced 802.11 channel add 1507](#)

[config advanced 802.11 channel cleanair-event 1508](#)

[config advanced 802.11 channel dca anchor-time 1509](#)

[config advanced 802.11 channel dca chan-width-11n 1510](#)

[config advanced 802.11 channel dca interval 1511](#)

[config advanced 802.11 channel dca min-metric 1512](#)

[config advanced 802.11 channel dca sensitivity 1513](#)

[config advanced 802.11 channel foreign 1515](#)

[config advanced 802.11 channel load 1516](#)

[config advanced 802.11 channel noise 1517](#)

[config advanced 802.11 channel outdoor-ap-dca 1518](#)

[config advanced 802.11 channel pda-prop 1519](#)

config advanced 802.11 channel update	1520
config advanced 802.11 coverage	1521
config advanced 802.11 coverage exception global	1522
config advanced 802.11 coverage fail-rate	1523
config advanced 802.11 coverage level global	1524
config advanced 802.11 coverage packet-count	1525
config advanced 802.11 coverage rssi-threshold	1526
config advanced 802.11 edca-parameters	1528
config advanced 802.11 factory	1529
config advanced 802.11 group-member	1530
config advanced 802.11 group-mode	1531
config advanced 802.11 logging channel	1532
config advanced 802.11 logging coverage	1533
config advanced 802.11 logging foreign	1534
config advanced 802.11 logging load	1535
config advanced 802.11 logging noise	1536
config advanced 802.11 logging performance	1537
config advanced 802.11 logging txpower	1538
config advanced 802.11 monitor channel-list	1539
config advanced 802.11 monitor coverage	1540
config advanced 802.11 monitor load	1541
config advanced 802.11 monitor mode	1542
config advanced 802.11 monitor ndp-type	1543
config advanced 802.11 monitor noise	1544
config advanced 802.11 monitor signal	1545
config advanced 802.11 profile foreign	1546
config advanced 802.11 profile noise	1547
config advanced 802.11 profile throughput	1548
config advanced 802.11 profile utilization	1549
config advanced 802.11 receiver	1550
config advanced 802.11 tpc-version	1551
config advanced 802.11 tpcv1-thresh	1552
config advanced 802.11 tpcv2-intense	1553
config advanced 802.11 tpcv2-per-chan	1554
config advanced 802.11 tpcv2-thresh	1555

- config advanced 802.11 txpower-update 1556
- config advanced dot11-padding 1557
- config client location-calibration 1558
- config network rf-network-name 1559
- Configuring 802.11k and Assisted Roaming 1559
 - config assisted-roaming 1560
 - config wlan assisted-roaming 1561
 - show assisted-roaming 1562
 - debug 11k 1563
- debug Commands 1563
 - debug airewave-director 1565
 - debug dot11 1567

PART IX

CleanAir Commands 1569

CHAPTER 10

CLI Commands 1571

- show Commands 1571
 - show 802.11 cleanair 1572
 - show 802.11 cleanair air-quality summary 1574
 - show 802.11 cleanair air-quality worst 1575
 - show 802.11 cleanair device ap 1576
 - show 802.11 cleanair device type 1577
 - show advanced 802.11 channel 1578
 - show ap auto-rf 1579
- config Commands 1580
 - config 802.11 cleanair 1581
 - config 802.11 cleanair device 1583
 - config 802.11 cleanair alarm 1585
 - config advanced 802.11 channel cleanair-event 1587
 - config advanced 802.11 channel pda-prop 1588
 - config advanced 802.11 channel update 1589
- test Commands 1589
 - test cleanair show 1590

PART X

FlexConnect Commands 1591

CHAPTER 11**CLI Commands 1593****show Commands 1593**[show capwap reap association 1594](#)[show capwap reap status 1595](#)[show flexconnect acl detailed 1596](#)[show flexconnect acl summary 1597](#)[show flexconnect group detail 1598](#)[show flexconnect group summary 1599](#)[show flexconnect office-extend 1600](#)**config Commands 1600**[config ap autoconvert 1601](#)[config ap flexconnect central-dhcp 1602](#)[config ap flexconnect local-split 1604](#)[config ap flexconnect radius auth set 1605](#)[config ap flexconnect vlan 1606](#)[config ap flexconnect vlan add 1607](#)[config ap flexconnect vlan native 1608](#)[config ap flexconnect vlan wlan 1609](#)[config ap flexconnect web-auth 1610](#)[config ap flexconnect web-policy acl 1611](#)[config flexconnect acl 1612](#)[config flexconnect acl rule 1613](#)[config flexconnect group 1615](#)[config flexconnect group vlan 1620](#)[config flexconnect group web-auth 1621](#)[config flexconnect group web-policy 1622](#)[config flexconnect join min-latency 1623](#)[config flexconnect office-extend 1624](#)[config wlan flexconnect ap-auth 1625](#)[config wlan flexconnect learn-ipaddr 1626](#)[config wlan flexconnect local-switching 1627](#)[config wlan flexconnect vlan-central-switching 1629](#)**Integrated Management Module Commands in Cisco Flex 7500 Series Controllers 1629**[imm address 1630](#)

imm dhcp	1631
imm mode	1632
imm restart	1633
imm summary	1634
imm username	1635
debug Commands	1635
debug capwap reap	1636
debug dot11 mgmt interface	1637
debug dot11 mgmt msg	1638
debug dot11 mgmt ssid	1639
debug dot11 mgmt state-machine	1640
debug dot11 mgmt station	1641
debug flexconnect aaa	1642
debug flexconnect acl	1643
debug flexconnect cckm	1644
debug flexconnect group	1645
debug pem	1646

PART XI
Mobility Commands 1647

CHAPTER 12
CLI Commands 1649

show Commands	1649
show advanced client-handoff	1650
show l2tp	1651
show logging	1652
show mobility anchor	1654
show mobility ap-list	1656
show mobility foreign-map	1657
show mobility group member	1658
show mobility statistics	1659
show mobility summary	1661
show pmipv6 domain	1663
show pmipv6 mag bindings	1664
show pmipv6 mag globals	1666
show pmipv6 mag stats	1667

show pmipv6 profile summary	1669
config Commands	1669
config mobility dscp	1670
config mobility group anchor	1671
config mobility group domain	1673
config mobility group keepalive count	1674
config mobility group keepalive interval	1675
config mobility group member	1676
config mobility group multicast-address	1678
config mobility multicast-mode	1679
config mobility secure-mode	1680
config mobility statistics reset	1681
config pmipv6 domain	1682
config pmipv6 add profile	1683
config pmipv6 delete	1685
config pmipv6 mag binding init-retx-time	1686
config pmipv6 mag binding lifetime	1687
config pmipv6 mag binding max-retx-time	1688
config pmipv6 mag binding maximum	1689
config pmipv6 mag binding refresh-time	1690
config pmipv6 mag bri delay	1691
config pmipv6 mag bri retries	1692
config pmipv6 mag lma	1693
config pmipv6 mag replay-protection	1694
config wlan mobility anchor	1696
config wlan mobility foreign-map	1697
config wlan pmipv6 default-realm	1698
config wlan pmipv6 mobility-type	1699
config wlan pmipv6 profile_name	1700
clear, debug and ping Commands	1700
clear stats mobility	1701
debug dot11	1702
debug client	1703
debug mobility	1704
eping	1706

[mping](#) 1707



Preface

This preface describes the audience, organization, and conventions of the *Cisco Wireless LAN Controller Command Reference Guide*. It also provides information on how to obtain other documentation. This chapter includes the following sections:

- [Audience, page xlvii](#)
- [Document Organization, page xlvii](#)
- [Document Conventions, page xlvii](#)
- [Related Documentation, page 1](#)
- [Obtaining Documentation and Submitting a Service Request, page 1](#)

Audience

This publication is for experienced network administrators who configure and maintain Cisco wireless LAN controllers and Cisco lightweight access points.

Document Organization

This document is organized into the following chapters:

Chapter	Description
Overview	Describes how to use the command-line interface (CLI) on the controller.
CLI Commands	Provides detailed information about the CLI commands for the controller.

Document Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font.
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic</i> font.
[]	Elements in square brackets are optional.
{ x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier</code> font.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means reader take note. Notes contain helpful suggestions or references to material not covered in the manual.

**Tip**

Means the following information will help you solve a problem.

**Caution**

Means reader be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Warning**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. (To see translations of the warnings that appear in this publication, refer to the appendix "Translated Safety Warnings.")

Warning Title	Description
Waarschuwing	Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van standaard maatregelen om ongelukken te voorkomen. (Voor vertalingen van de waarschuwingen die in deze publicatie verschijnen, kunt u het aanhangsel "Translated Safety Warnings" (Vertalingen van veiligheidsvoorschriften) raadplegen.)
Varoitus	Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä vaaroista ja tavanomaisista onnettomuuksien ehkäisykeinoista. (Tässä julkaisussa esiintyvien varoitusten käännökset löydät liitteestä "Translated Safety Warnings" (käännetyt turvallisuutta koskevat varoitukset).)
Attention	Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures. Avant d'accéder à cet équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures courantes de prévention des accidents. Pour obtenir les traductions des mises en garde figurant dans cette publication, veuillez consulter l'annexe intitulée « Translated Safety Warnings » (Traduction des avis de sécurité).
Warnung	Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewusst. (Übersetzungen der in dieser Veröffentlichung enthaltenen Warnhinweise finden Sie im Anhang mit dem Titel "Translated Safety Warnings" (Übersetzung der Warnhinweise).)
Avvertenza	Questo simbolo di avvertenza indica un pericolo. Si è in una situazione che può causare infortuni. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti. La traduzione delle avvertenze riportate in questa pubblicazione si trova nell'appendice, "Translated Safety Warnings" (Traduzione delle avvertenze di sicurezza).
Advarsel	Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskade. Før du utfører arbeid på utstyr, må du være oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker. (Hvis du vil se oversettelser av de advarslene som finnes i denne publikasjonen, kan du se i vedlegget "Translated Safety Warnings" [Oversatte sikkerhetsadvarsler].)
Aviso	Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes. (Para ver as traduções dos avisos que constam desta publicação, consulte o apêndice "Translated Safety Warnings" - "Traduções dos Avisos de Segurança").

Warning Title	Description
¡Advertencia!	Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes. (Para ver traducciones de las advertencias que aparecen en esta publicación, consultar el apéndice titulado "Translated Safety Warnings.")
Varning	Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador. (Se förklaringar av de varningar som förekommer i denna publikation i appendix "Translated Safety Warnings" [Översatta säkerhetsvarningar].)

Related Documentation

These documents provide complete information about the Cisco Unified Wireless Network solution:

- *Cisco Wireless LAN Controller Configuration Guide*
- *Cisco Wireless LAN Controller System Message Guide*
- *Release Notes for Cisco Wireless LAN Controllers and Lightweight Access Points*

Obtaining Documentation and Submitting a Service Request

For information about obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.



Using the Command-Line Interface

This chapter contains the following topics:

- [CLI Command Keyboard Shortcuts, page 1](#)
- [Using the Interactive Help Feature, page 2](#)

CLI Command Keyboard Shortcuts

The table below lists the CLI keyboard shortcuts to help you enter and edit command lines on the controller.

Table 1: CLI Command Keyboard Shortcuts

Action	Description	Keyboard Shortcut
Change	The word at the cursor to lowercase.	Esc l
	The word at the cursor to uppercase.	Esc u
Delete	A character to the left of the cursor.	Ctrl-h, Delete, or Backspace
	All characters from the cursor to the beginning of the line.	Ctrl-u
	All characters from the cursor to the end of the line.	Ctrl-k
	All characters from the cursor to the end of the word.	Esc d
	The word to the left of the cursor.	Ctrl-w or Esc Backspace
Display MORE output	Exit from MORE output.	q, Q, or Ctrl-C
	Next additional screen. The default is one screen. To display more than one screen, enter a number before pressing the Spacebar key.	Spacebar

Action	Description	Keyboard Shortcut
	Next line. The default is one line. To display more than one line, enter the number before pressing the Enter key.	Enter
	Enter an Enter or Return key character.	Ctrl-m
	Expand the command or abbreviation.	Ctrl-t or Tab
Move the cursor	One character to the left (back).	Ctrl-b or Left Arrow
	One character to the right (forward).	Ctrl-f or Right Arrow
	One word to the left (back), to the beginning of the current or previous word.	Esc b
	One word to the right (forward), to the end of the current or next word.	Esc f
	To the beginning of the line.	Ctrl-a
	To the end of the line.	Ctrl-e
	Redraw the screen at the prompt.	Ctrl-l or Ctrl-r
	Return to the EXEC mode from any configuration mode	Ctrl-z
	Return to the previous mode or exit from the CLI from Exec mode.	exit command
	Transpose a character at the cursor with a character to the left of the cursor.	Ctrl-t

Using the Interactive Help Feature

The question mark (?) character allows you to get the following type of help about the command at the command line. The table below lists the interactive help feature list.

Table 2: Interactive Help Feature List

Command	
help	Provides a brief description of the Help feature in any command mode.
? at the command prompt	Lists all commands available for a particular command mode.
partial command?	Provides a list of commands that begin with the character string.

Command	
partial command<Tab>	Completes a partial command name.
command ?	Lists the keywords, arguments, or both associated with a command.
command keyword ?	Lists the arguments that are associated with the keyword.

Using the Help Command

Before You Begin

To look up keyboard commands, use the help command at the root level.

help

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must back up until entering a '?' shows the available options. Two types of help are available

1. Full help is available when you are ready to enter a command argument (for example show ?) and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (for example show pr?).

Examples

```
> help
HELP:
Special keys:
  DEL, BS... delete previous character
  Ctrl-A .... go to beginning of line
  Ctrl-E .... go to end of line
  Ctrl-F .... go forward one character
  Ctrl-B .... go backward one character
  Ctrl-D .... delete current character
  Ctrl-U, X. delete to beginning of line
  Ctrl-K .... delete to end of line
  Ctrl-W .... delete previous word
  Ctrl-T .... transpose previous character
  Ctrl-P .... go to previous line in history buffer
  Ctrl-N .... go to next line in history buffer
  Ctrl-Z .... return to root command prompt
  Tab, <SPACE> command-line completion
  Exit .... go to next lower command prompt
  ? .... list choices
```

Using the ? command

Before You Begin

To display all of the commands in your current level of the command tree, or to display more information about a particular command, use the ? command.

command name ?

When you enter a command information request, put a space between the **command name** and **?**.

Examples

This command shows you all the commands and levels available from the root level.

```
> ?
clear          Clear selected configuration elements.
config         Configure switch options and settings.
debug          Manages system debug options.
help           Help
linktest       Perform a link test to a specified MAC address.
logout         Exit this session. Any unsaved changes are lost.
ping           Send ICMP echo packets to a specified IP address.
reset          Reset options.
save           Save switch configurations.
show           Display switch options and settings.
transfer       Transfer a file to or from the switch.
```

Using the partial? command

Before You Begin

To provide a list of commands that begin with the character string, use the partial command **?**.

partial command?

There should be no space between the command and the question mark.

Examples

This example shows how to provide a command that begin with the character string "ad":

```
> controller> config>ad?
The command that matches with the string "ad" is as follows:

advanced
```

Using the partial command<tab>

Before You Begin

To complete a partial command name, use the partial command<tab> command.

partial command<tab>

There should be no space between the command and <tab>.

Examples

This example shows how to complete a partial command name that begin with the character string "ad":

```
> Controller>config>cert<tab> certificate
```

Using the command ?

Examples

To list the keywords, arguments, or both associated with the command, use the command ?.

command ?

There should be space between the command and the question mark.

This example shows how to list the arguments and keyword for the command acl:

```
> Controller >config acl ?
```

Information similar to the following appears:

apply	Applies the ACL to the data path.
counter	Start/Stop the ACL Counters.
create	Create a new ACL.
delete	Delete an ACL.
rule	Configure rules in the ACL.
cpu	Configure the CPU Acl Information

command keyword ?

To list the arguments that are associated with the keyword, use the command keyword ?
command keyword ?

Usage Guidelines

There should be space between the keyword and the question mark.

Examples

This example shows how to display the arguments associated with the keyword cpu:

```
> controller>config acl cpu ?
```

Information similar to the following appears:

none	None - Disable the CPU ACL
<name>	<name> - Name of the CPU ACL



PART **I**

System Management Commands

- [CLI Commands, page 9](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco wireless LAN controller and configure the controller and its associated access points.

- [show Commands, page 9](#)
- [config Commands, page 125](#)
- [Timeout Commands, page 386](#)
- [Clearing Configurations, Log files, and Other Actions, page 410](#)
- [Resetting the System Reboot Time, page 442](#)
- [Uploading and Downloading Files and Configurations, page 447](#)
- [Installing and Modifying Licenses on Cisco 5500 Series Controllers, page 474](#)
- [Right to Use Licensing Commands, page 482](#)
- [Troubleshooting the Controller Settings, page 490](#)

show Commands

This section lists the **show** commands that you can use to display information about the controller settings and user accounts.

show 802.11 cu-metrics

To display access point channel utilization metrics, use the **show 802.11 cu-metrics** command.

show 802.11 {a | b} **cu-metrics** *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Access point name.

Command Default

None.

Examples

This example shows how to display AP channel utilization metrics of the AP myAP1:

```
> show 802.11a cu-metrics AP1
AP Interface Mac:          30:37:a6:c8:8a:50
Measurement Duration:      90sec
Timestamp                  Thu Jan 27 09:08:48 2011
Channel Utilization stats
=====
Picc (50th Percentile)..... 0
Pib (50th Percentile)..... 76
Picc (90th Percentile)..... 0
Pib (90th Percentile)..... 77
Timestamp                  Thu Jan 27 09:34:34 2011
```


show advanced 802.11 l2roam

To display 802.11a or 802.11b/g Layer 2 client roaming information, use the **show advanced 802.11 l2roam** command.

show advanced 802.11 {a | b} l2roam {rf-param | statistics} mac_address

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
rf-param	Specifies the Layer 2 frequency parameters.
statistics	Specifies the Layer 2 client roaming statistics.
<i>mac_address</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to display 802.11b Layer 2 client roaming information:

```
> show advanced 802.11b l2roam rf-param

L2Roam 802.11bg RF Parameters.....
  Config Mode..... Default
  Minimum RSSI..... -85
  Roam Hysteresis..... 2
  Scan Threshold..... -72
  Transition time..... 5
```

Related Commands

config 802.11 l2roam rf-params

show advanced send-disassoc-on-handoff

To display whether the WLAN controller disassociates clients after a handoff, use the **show advanced send-disassoc-on-handoff** command.

show advanced send-disassoc-on-handoff

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the disassociated clients after a handoff:

```
> show advanced send-disassoc-on-handoff
Send Disassociate on Handoff..... Disabled
```

show advanced sip-preferred-call-no

To display the list of preferred call numbers, use the **show advanced sip-preferred-call-no** command.

show advanced sip-preferred-call-no

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the list of preferred call numbers:

```
> show advanced sip-preferred-call-no
Preferred Call Numbers List
Call Index          Preferred Call No
-----
1                   911
2                   100
3                   101
4                   102
5                   103
6                   104
```

show advanced sip-snooping-ports

To display the port range for call snooping, use the **show advanced sip-snooping-ports** command.

show advanced sip-snooping-ports

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the call snooping port range:

```
> show advanced sip-snooping-ports
SIP Call Snoop Ports: 1000 - 2000
```

Related Commands

- show cac voice stats**
- show cac voice summary**
- show cac video stats**
- show cac video summary**
- config 802.11 cac video sip**
- config 802.11 cac voice sip**
- show advanced sip-preferred-call-no**
- config advanced sip-snooping-ports**
- debug cac**

show arp kernel

To display the kernel Address Resolution Protocol (ARP) cache information, use the **show arp kernel** command.

show arp kernel

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display kernel ARP cache information:

```
> show arp kernel
IP address      HW type      Flags      HW address      Mask      Device
192.0.2.1       0x1          0x2        00:1A:6C:2A:09:C2  *         dt10
192.0.2.8       0x1          0x6        00:1E:E5:E6:DB:56  *         dt10
```

Related Commands

- clear arp**
- debug arp**
- show route kernel**

show arp switch

To display the Cisco wireless LAN controller MAC addresses, IP addresses, and port types, use the **show arp switch** command.

show arp switch

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display Address Resolution Protocol (ARP) cache information for the switch:

```
> show arp switch
MAC Address      IP Address      Port      VLAN      Type
-----
xx:xx:xx:xx:xx:xx  xxx.xxx.xxx.xxx  service port  1
xx:xx:xx:xx:xx:xx  xxx.xxx.xxx.xxx  service port
xx:xx:xx:xx:xx:xx  xxx.xxx.xxx.xxx  service port
```

Related Commands

clear arp

debug arp

show arp kernel

show avc applications

To display all the supported Application Visibility and Control (AVC) applications, use the **show avc applications** command.

show avc applications

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release	Modification
	7.4	This command was introduced.

Usage Guidelines AVC uses the Network-Based Application Recognition (NBAR) deep packet inspection technology to classify applications based on the protocol they use. Using AVC, the controller can detect more than 1500 Layer 4 to Layer 7 protocols.

Examples The following is a sample output of the **show avc applications** command.

Device > **show avc applications**

Application-Name	App-ID	Engine-ID	Selector-ID	Application-Group-Name
=====	=====	=====	=====	=====
3com-amp3	538	3	629	other
3com-tsmux	977	3	106	obsolete
3pc	788	1	34	layer3-over-ip
914c/g	1109	3	211	net-admin
9pfs	479	3	564	net-admin
acap	582	3	674	net-admin
acas	939	3	62	other
accessbuilder	662	3	888	other
accessnetwork	607	3	699	other
acp	513	3	599	other
acr-nema	975	3	104	industrial-protocols
active-directory	1194	13	473	other
activesync	1419	13	490	business-and-productivity-tools
adobe-connect	1441	13	505	other
aed-512	963	3	149	obsolete
afpovertcp	1327	3	548	business-and-productivity-tools
agentx	609	3	705	net-admin
alpes	377	3	463	net-admin
aminet	558	3	2639	file-sharing
an	861	1	107	layer3-over-ip
----	----	---	-----	-----

Related Commands

- config avc profile delete
- config avc profile create

config avc profile rule

config wlan avc

show avc profile

show avc applications

show avc statistics

debug avc error

debug avc events

show avc profile

To display Application Visibility and Control (AVC) profiles, use the **show avc profile** command.

show avc profile {**summary** | **detailed** *profile_name* }

Syntax Description

summary	Displays a summary of AVC profiles.
detailed	Displays the details of an AVC profile.
<i>profile_name</i>	Name of the AVC profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc profile summary** command.

Device > **show avc profile summary**

```

Profile-Name                Number of Rules
=====
profile 1                   3
avc_profile2                1

```

The following is a sample output of the **show avc profile detailed** command.

Device > **show avc profile detailed**

```

Application-Name            Application-Group-Name      Action  DSCP
=====
ftp                         file-sharing              Drop    -
flash-video                 browsing                  Mark    10
facebook                    browsing                  Mark    10

Associated WLAN IDs         :
Associated Remote LAN IDs  :
Associated Guest LAN IDs   :

```

Related Commands

config avc profile delete
config avc profile create
config avc profile rule
config wlan avc

show avc profile
show avc applications
show avc statistics
debug avc error
debug avc events

show avc statistics application

To display the statistics of an application, use the **show avc statistics application** command.

show avc statistics application *application_name* **top-users** [**downstream wlan** | **upstream wlan** | **wlan**] [*wlan_id*]}

Syntax Description

<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-users	Displays AVC statistics for top application users.
downstream	(Optional) Displays statistics of top downstream applications.
wlan	(Optional) Displays AVC statistics of a WLAN.
<i>wlan_id</i>	WLAN identifier from 1 to 512.
upstream	(Optional) Displays statistics of top upstream applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics application** command.

Device > **show avc statistics application ftp top-users downstream wlan 1**

Client MAC Bytes (Up/Down) (Total)	DSCP In Out	Client IP	WLAN ID	Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)
00:0a:ab:15:00:9c (U)	338 0 0	172.16.31.156	1	16	91	5	43
6409 0 0	(D)	172.16.31.156	1	22	5911	268	48
00:0a:ab:15:00:5a (U)	84 0 0	172.16.31.90	1	7	39	5	13
5869 0 0	(D)	172.16.31.90	1	12	5723	476	18
00:0a:ab:15:00:60 (U)	8666 0 0	172.16.31.96	1	19	117	6	75
9595 0 0	(D)	172.16.31.96	1	19	4433	233	83
00:0a:ab:15:00:a4 (U)	161 0 0	172.16.31.164	1	18	139	7	21
	(D)	172.16.31.164	1	23	4409	191	24

4439	0	0						
00:0a:ab:15:00:48 (U)	172.16.31.72	1	21	2738	130	21		
2738	0	0						
(D)	172.16.31.72	1	22	4367	198	22		
4367	0	0						
00:0a:ab:15:00:87 (U)	172.16.31.135	1	11	47	4	49		
301	0	0						
(D)	172.16.31.135	1	12	4208	350	48		
7755	0	0						
00:0a:ab:15:00:92 (U)	172.16.31.146	1	10	73	7	11		
84	0	0						
(D)	172.16.31.146	1	9	4168	463	11		
4201	0	0						
00:0a:ab:15:00:31 (U)	172.16.31.49	1	11	95	8	34		
250	0	0						
(D)	172.16.31.49	1	18	3201	177	43		
3755	0	0						
00:0a:ab:15:00:46 (U)	172.16.31.70	1	7	47	6	20		
175	0	0						
(D)	172.16.31.70	1	10	3162	316	23		
3448	0	0						
00:0a:ab:15:00:b3 (U)	172.16.31.179	1	10	85	8	34		
241	0	0						

Related Commands**config avc profile delete****config avc profile create****config avc profile rule****config wlan avc****show avc profile****show avc applications****show avc statistics client****show avc statistics wlan****show avc statistics top-apps****show avc statistics guest-lan****show avc statistics remote-lan****debug avc error****debug avc events**

show avc statistics client

To display the client Application Visibility and Control (AVC) statistics, use the **show avc statistics client** command.

show avc statistics client *client_MAC* {**application** *application_name* | **top-apps** [**upstream** | **downstream**]}

Syntax Description

<i>client_MAC</i>	MAC address of the client.
application	Displays AVC statistics for an application.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-apps	Displays AVC statistics for top applications.
upstream	(Optional) Displays statistics of top upstream applications.
downstream	(Optional) Displays statistics of top downstream applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics client** command.

Device > **show avc statistics client 00:0a:ab:15:00:01 application http**

Description	Upstream	Downstream
=====	=====	=====
Number of Packtes(n secs)	5059	6369
Number of Bytes(n secs)	170144	8655115
Average Packet size(n secs)	33	1358
Total Number of Packtes	131878	150169
Total Number of Bytes	6054464	205239972
DSCP Incoming packet	16	0
DSCP Outgoing Packet	16	0

The following is a sample output of the **show avc statistics client** command.

Device > **show avc statistics client 00:0a:ab:15:00:01 top-apps**

Application-Name (Up/Down)	Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)	DSCP In	DSCP Out
=====	=====	=====	=====	=====	=====	=====	=====
http	(U) 6035	637728	105	6035	637728	16	16
	(D) 5420	7218796	1331	5420	7218796	0	0
ggp	(U) 1331	1362944	1024	1331	1362944	0	0
	(D) 0	0	0	0	0	0	0

smp	(U)	1046	1071104	1024	1046	1071104	0	0
	(D)	0	0	0	0	0	0	0
vrrp	(U)	205	209920	1024	205	209920	0	0
	(D)	0	0	0	0	0	0	0
bittorrent	(U)	117	1604	13	117	1604	0	0
	(D)	121	70469	582	121	70469	0	0
icmp	(U)	0	0	0	0	0	0	0
	(D)	72	40032	556	72	40032	48	48
edonkey	(U)	112	4620	41	112	4620	0	0
	(D)	105	33076	315	105	33076	0	0
dns	(U)	10	380	38	10	380	0	0
	(D)	7	1743	249	7	1743	0	0
realmedia	(U)	2	158	79	2	158	24	24
	(D)	2	65	32	2	65	0	0

Related Commands

config avc profile delete
config avc profile create
config avc profile rule
config wlan avc
show avc profile
show avc applications
show avc statistics applications
show avc statistics wlan
show avc statistics top-apps
show avc statistics guest-lan
show avc statistics remote-lan
debug avc error
debug avc events

show avc statistics guest-lan

To display the Application Visibility and Control (AVC) statistics of a guest LAN, use the **show avc statistics guest-lan** command.

show avc statistics guest-lan *guest-lan_id* {**application** *application_name* | **top-app-groups** [**upstream** | **downstream**] | **top-apps** [**upstream** | **downstream**]}

Syntax Description

<i>guest-lan_id</i>	Guest LAN identifier from 1 to 5.
application	Displays AVC statistics for an application.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-app-groups	Displays AVC statistics for top application groups.
upstream	(Optional) Displays statistics of top upstream applications.
downstream	(Optional) Displays statistics of top downstream applications.
top-apps	Displays AVC statistics for top applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics** command.

Device > **show avc statistics guest-lan 1**

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
=====		=====	=====	=====	=====	=====
unclassified	(U)	191464	208627	1	92208613	11138796586
	(D)	63427	53440610	842	16295621	9657054635
ftp	(U)	805	72880	90	172939	11206202
	(D)	911	58143	63	190900	17418653
http	(U)	264904	12508288	47	27493945	2837672192
	(D)	319894	436915253	1365	29850934	36817587924
gre	(U)	0	0	0	10158872	10402684928
	(D)	0	0	0	0	0
icmp	(U)	1	40	40	323	98476
	(D)	7262	4034576	555	2888266	1605133372
ipinip	(U)	62565	64066560	1024	11992305	12280120320
	(D)	0	0	0	0	0
imap	(U)	1430	16798	11	305161	3795766

	(D)	1555	576371	370	332290	125799465
irc	(U)	9	74	8	1736	9133
	(D)	11	371	33	1972	173381
nntp	(U)	22	158	7	1705	9612
	(D)	22	372	16	2047	214391

Related Commands

config avc profile delete
config avc profile create
config avc profile rule
config wlan avc
show avc profile
show avc applications
show avc statistics client
show avc statistics wlan
show avc statistics top-apps
show avc statistics applications
show avc statistics remote-lan
debug avc error
debug avc events

show avc statistics remote-lan

To display the Application Visibility and Control (AVC) statistics of a remote LAN, use the **show avc statistics remote-lan** command.

show avc statistics remote-lan *remote-lan_id* {**application** *application_name* | **top-app-groups** [**upstream** | **downstream**] | **top-apps** [**upstream** | **downstream**]}

Syntax Description

<i>remote-lan_id</i>	Remote LAN identifier from 1 to 512.
application	Displays AVC statistics for an application.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-app-groups	Displays AVC statistics for top application groups.
upstream	(Optional) Displays statistics of top upstream applications.
downstream	(Optional) Displays statistics of top downstream applications.
top-apps	Displays AVC statistics for top applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics remote-lan** command.

Device > **show avc statistics remote-lan 1**

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
=====		=====	=====	=====	=====	=====
unclassified	(U)	191464	208627	1	92208613	11138796586
	(D)	63427	53440610	842	16295621	9657054635
ftp	(U)	805	72880	90	172939	11206202
	(D)	911	58143	63	190900	17418653
http	(U)	264904	12508288	47	27493945	2837672192
	(D)	319894	436915253	1365	29850934	36817587924
gre	(U)	0	0	0	10158872	10402684928
	(D)	0	0	0	0	0
icmp	(U)	1	40	40	323	98476
	(D)	7262	4034576	555	2888266	1605133372
ipinip	(U)	62565	64066560	1024	11992305	12280120320
	(D)	0	0	0	0	0
imap	(U)	1430	16798	11	305161	3795766

	(D)	1555	576371	370	332290	125799465
irc	(U)	9	74	8	1736	9133
	(D)	11	371	33	1972	173381
nntp	(U)	22	158	7	1705	9612
	(D)	22	372	16	2047	214391

Related Commands

config avc profile delete
config avc profile create
config avc profile rule
config wlan avc
show avc profile
show avc applications
show avc statistics client
show avc statistics wlan
show avc statistics top-apps
show avc statistics guest-lan
show avc statistics applications
debug avc error
debug avc events

show avc statistics top-apps

To display the Application Visibility and Control (AVC) statistics for the top applications, use the **show avc statistics top-apps** command.

show avc statistics top-apps [upstream | downstream]

Syntax Description	upstream	(Optional) Displays statistics of top upstream applications.
	downstream	(Optional) Displays statistics of top downstream applications.
Command Default	None	
Command History	Release	Modification
	7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics top-apps** command.

Device > **show avc statistics top-apps**

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
=====		=====	=====	=====	=====	=====
http	(U)	204570	10610912	51	28272539	2882294016
	(D)	240936	327624221	1359	30750570	38026889010
realmedia	(U)	908	62154	68	400698	26470359
	(D)	166694	220522943	1322	35802836	47131836785
mpls-in-ip	(U)	77448	79306752	1024	10292787	10539813888
	(D)	0	0	0	0	0
fire	(U)	70890	72591360	1024	10242484	10488303616
	(D)	0	0	0	0	0
pipe	(U)	68296	69935104	1024	10224255	10469637120
	(D)	0	0	0	0	0
gre	(U)	60982	62445568	1024	10340221	10588386304
	(D)	0	0	0	0	0
crudp	(U)	26430	27064320	1024	10109812	10352447488
	(D)	0	0	0	0	0
rtp	(U)	0	0	0	0	0
	(D)	7482	9936096	1328	2603923	3458009744
icmp	(U)	0	0	0	323	98476
	(D)	10155	5640504	555	2924693	1625363564

Related Commands	config avc profile delete
	config avc profile create
	config avc profile rule
	config wlan avc
	show avc profile

show avc applications
show avc statistics client
show avc statistics wlan
show avc statistics applications
show avc statistics guest-lan
show avc statistics remote-lan
debug avc error
debug avc events

show avc statistics wlan

To display the Application Visibility and Control (AVC) statistics of a WLAN, use the **show avc statistics wlan** command.

show avc statistics wlan *wlan_id* {**application** *application_name* | **top-app-groups** [**upstream** | **downstream**] | **top-apps** [**upstream** | **downstream**]}

Syntax Description

<i>wlan_id</i>	WLAN identifier from 1 to 512.
application	Displays AVC statistics for an application.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-app-groups	Displays AVC statistics for top application groups.
upstream	(Optional) Displays statistics of top upstream applications.
downstream	(Optional) Displays statistics of top downstream applications.
top-apps	Displays AVC statistics for top applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics** command.

Device > **show avc statistics wlan 1**

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
=====		=====	=====	=====	=====	=====
unclassified	(U)	191464	208627	1	92208613	11138796586
	(D)	63427	53440610	842	16295621	9657054635
ftp	(U)	805	72880	90	172939	11206202
	(D)	911	58143	63	190900	17418653
http	(U)	264904	12508288	47	27493945	2837672192
	(D)	319894	436915253	1365	29850934	36817587924
gre	(U)	0	0	0	10158872	10402684928
	(D)	0	0	0	0	0
icmp	(U)	1	40	40	323	98476
	(D)	7262	4034576	555	2888266	1605133372
ipinip	(U)	62565	64066560	1024	11992305	12280120320
	(D)	0	0	0	0	0
imap	(U)	1430	16798	11	305161	3795766

	(D)	1555	576371	370	332290	125799465
irc	(U)	9	74	8	1736	9133
	(D)	11	371	33	1972	173381
nntp	(U)	22	158	7	1705	9612
	(D)	22	372	16	2047	214391

The following is a sample output of the **show avc statistics wlan** command.

Device > **show avc statistics wlan 1 application ftp**

Description	Upstream	Downstream
=====	=====	=====
Number of Packtes(n secs)	0	0
Number of Bytes(n secs)	0	0
Average Packet size(n secs)	0	0
Total Number of Packtes	32459	64888
Total Number of Bytes	274	94673983

Related Commands

- config avc profile delete**
- config avc profile create**
- config avc profile rule**
- config wlan avc**
- show avc profile**
- show avc applications**
- show avc statistics client**
- show avc statistics applications**
- show avc statistics top-apps**
- show avc statistics guest-lan**
- show avc statistics remote-lan**
- debug avc error**
- debug avc events**

show boot

To display the primary and backup software build numbers with an indication of which is active, use the **show boot** command.

show boot

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Usage Guidelines

Each Cisco wireless LAN controller retains one primary and one backup operating system software load in nonvolatile RAM to allow controllers to boot off the primary load (default) or revert to the backup load when desired.

Examples

This example shows how to display the default boot image information:

```
> show boot
Primary Boot Image..... 3.2.13.0 (active)
Backup Boot Image..... 3.2.15.0
```

Related Commands

config boot

show band-select

To display band selection information, use the **show band-select** command.

show band-select

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display band selection information:

```
> show band-select
Band Select Probe Response..... per WLAN enabling
  Cycle Count..... 3 cycles
  Cycle Threshold..... 200 milliseconds
  Age Out Suppression..... 20 seconds
  Age Out Dual Band..... 60 seconds
  Client RSSI..... -80 dBm
```

Related Commands

- config band-select**
- config wlan band-select**

show buffers

To display buffer information of the controller, use the **show buffers** command.

show buffers

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display buffer information of the controller:

```
> show buffers
Pool[00]: 16 byte chunks
  chunks in pool: 50000
  chunks in use: 9196
  bytes in use: 147136
  bytes requested: 73218 (73918 overhead bytes)
Pool[01]: 64 byte chunks
  chunks in pool: 50100
  chunks in use: 19222
  bytes in use: 1230208
  bytes requested: 729199 (501009 overhead bytes)
Pool[02]: 128 byte chunks
  chunks in pool: 26200
  chunks in use: 9861
  bytes in use: 1262208
  bytes requested: 848732 (413476 overhead bytes)
Pool[03]: 256 byte chunks
  chunks in pool: 3000
  chunks in use: 596
  bytes in use: 152576
  bytes requested: 93145 (59431 overhead bytes)
Pool[04]: 384 byte chunks
  chunks in pool: 6000
  chunks in use: 258
  bytes in use: 99072
  bytes requested: 68235 (30837 overhead bytes)
Pool[05]: 512 byte chunks
  chunks in pool: 18700
  chunks in use: 18667
  bytes in use: 9557504
  bytes requested: 7933814 (1623690 overhead bytes)
Pool[06]: 1024 byte chunks
  chunks in pool: 3500
  chunks in use: 94
  bytes in use: 96256
  bytes requested: 75598 (20658 overhead bytes)
Pool[07]: 2048 byte chunks
  chunks in pool: 1000
  chunks in use: 54
  bytes in use: 110592
  bytes requested: 76153 (34439 overhead bytes)
Pool[08]: 4096 byte chunks
  chunks in pool: 1000
  chunks in use: 47
  bytes in use: 192512
  bytes requested: 128258 (64254 overhead bytes)
Raw Pool:
  chunks in use: 256
  bytes requested: 289575125
```

show cac voice stats

To view the detailed voice CAC statistics of the 802.11a or 802.11b radio, use the **show cac voice stats** command.

show cac voice stats {802.11a | 802.11b}

Syntax Description

802.11a	Displays detailed voice CAC statistics for 802.11a.
802.11b	Displays detailed voice CAC statistics for 802.11b/g.

Examples

This example shows how to view the detailed voice CAC statistics for the 802.11b radio:

```
> show cac voice stats 802.11b
```

```
WLC Voice Call Statistics for 802.11b Radio
```

```
WMM TSPEC CAC Call Stats
  Total num of Calls in progress..... 0
  Num of Roam Calls in progress..... 0
  Total Num of Calls Admitted..... 0
  Total Num of Roam Calls Admitted..... 0
  Total Num of exp bw requests received..... 0
  Total Num of exp bw requests Admitted..... 0
  Total Num of Calls Rejected..... 0
  Total Num of Roam Calls Rejected..... 0
  Num of Calls Rejected due to insufficient bw.... 0
  Num of Calls Rejected due to invalid params.... 0
  Num of Calls Rejected due to PHY rate..... 0
  Num of Calls Rejected due to QoS policy..... 0
SIP CAC Call Stats
  Total Num of Calls in progress..... 0
  Num of Roam Calls in progress..... 0
  Total Num of Calls Admitted..... 0
  Total Num of Roam Calls Admitted..... 0
  Total Num of Preferred Calls Received..... 0
  Total Num of Preferred Calls Admitted..... 0
  Total Num of Ongoing Preferred Calls..... 0
  Total Num of Calls Rejected(Insuff BW)..... 0
  Total Num of Roam Calls Rejected(Insuff BW).... 0
KTS based CAC Call Stats
  Total Num of Calls in progress..... 0
  Num of Roam Calls in progress..... 0
  Total Num of Calls Admitted..... 0
  Total Num of Roam Calls Admitted..... 0
  Total Num of Calls Rejected(Insuff BW)..... 0
  Total Num of Roam Calls Rejected(Insuff BW).... 0
```

Related Commands

config 802.11 cac voice
config 802.11 cac defaults
config 802.11 cac defaults
config 802.11 cac video
config 802.11 cac multimedia

show cac voice summary

show cac video stats

show cac video summary

show cac voice summary

To view the list of all APs with brief voice statistics (includes bandwidth used, maximum bandwidth available, and the number of calls information), use the **show cac voice summary** command.

show cac voice summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the list of all APs with brief voice statistics:

```
> show cac voice summary
  AP Name          Slot#   Radio   BW Used/Max   Calls
-----
APc47d.4f3a.3547   0       11b/g    0/23437      0
  1       11a    1072/23437    1
```

Related Commands **show mesh cac**

show cac video stats

To view the detailed video CAC statistics of the 802.11a or 802.11b radio, use the **show cac video stats** command.

show cac video stats {802.11a | 802.11b}

Syntax	Description
802.11a	Displays detailed video CAC statistics for 802.11a.
802.11b	Displays detailed video CAC statistics for 802.11b/g.

Examples

This example shows how to view the detailed video CAC statistics for the 802.11b radio:

```
> show cac video stats 802.11b

WLC Video Call Statistics for 802.11b Radio

WMM TSPEC CAC Call Stats
  Total num of Calls in progress..... 0
  Num of Roam Calls in progress..... 0
  Total Num of Calls Admitted..... 0
  Total Num of Roam Calls Admitted..... 0
  Total Num of Calls Rejected..... 0
  Total Num of Roam Calls Rejected..... 0
  Num of Calls Rejected due to insufficient bw.... 0
  Num of Calls Rejected due to invalid params.... 0
  Num of Calls Rejected due to PHY rate..... 0
  Num of Calls Rejected due to QoS policy..... 0
SIP CAC Call Stats
  Total Num of Calls in progress..... 0
  Num of Roam Calls in progress..... 0
  Total Num of Calls Admitted..... 0
  Total Num of Roam Calls Admitted..... 0
  Total Num of Calls Rejected(Insuff BW)..... 0
  Total Num of Roam Calls Rejected(Insuff BW).... 0
```

Related Commands

config 802.11 cac voice
config 802.11 cac defaults
config 802.11 cac video
config 802.11 cac multimedia
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video load-based
config 802.11 cac video cac-method
config 802.11 cac video sip

show cac video summary

To view the list of all access points with brief video statistics (includes bandwidth used, maximum bandwidth available, and the number of calls information), use the **show cac video summary** command.

show cac video summary

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the list of all access points with brief video statistics:

```
> show cac video summary
```

AP Name	Slot#	Radio	BW Used/Max	Calls
AP001b.d571.88e0	0	11b/g	0/10937	0
	1	11a	0/18750	0
AP5_1250	0	11b/g	0/10937	0
	1	11a	0/18750	0

Related Commands

config 802.11 cac voice
config 802.11 cac defaults
config 802.11 cac video
config 802.11 cac multimedia
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video load-based
config 802.11 cac video cac-method
config 802.11 cac video sip

show cdp

To display the status and details of the Cisco Discovery Protocol (CDP), use the **show cdp** command.

show cdp {**neighbors** [**detail**] | **entry all** | **traffic**}

Syntax Description		
neighbors		Displays a list of all CDP neighbors on all interfaces.
detail		(Optional) Displays detailed information of the controller's CDP neighbors. This command shows only the CDP neighbors of the controller; it does not show the CDP neighbors of the controller's associated access points.
entry all		Displays all CDP entries in the database.
traffic		Displays CDP traffic information.

Command Default None.

Examples This example shows how to display the CDP traffic information:

```
> show cdp
CDP counters :
Total packets output: 0, Input: 0
Chksum error: 0
No memory: 0, Invalid packet: 0,
```

Related Commands

- config cdp**
- config ap cdp**
- show ap cdp**

show certificate lsc

To verify that the controller has generated a Locally Significant Certificate (LSC), use the **show certificate lsc summary** command.

show certificate lsc {summary | ap-provision}

Syntax Description

summary	Displays a summary of LSC certificate settings and certificates.
ap-provision	Displays details about the access points that are provisioned using the LSC.

Command Default

None.

Examples

This example shows how to display a summary of the LSC:

```
> show certificate lsc summary
LSC Enabled..... Yes
LSC CA-Server..... http://10.0.0.1:8080/caserver
LSC AP-Provisioning..... Yes
Provision-List..... Not Configured
LSC Revert Count in AP reboots..... 3
LSC Params:
Country..... 4
State..... ca
City..... ss
Orgn..... org
Dept..... dep
Email..... dep@co.com
KeySize..... 390
LSC Certs:
CA Cert..... Not Configured
RA Cert..... Not Configured
```

This example shows how to display the details about the access points that are provisioned using the LSC:

```
> show certificate lsc ap-provision
LSC AP-Provisioning..... Yes
Provision-List..... Present
Idx Mac Address
---
1 00:18:74:c7:c0:90
```

Related Commands

config certificate lsc
show certificate compatibility
config certificate
show certificate summary
show local-auth certificates

show certificate ssc

To view the Self Signed Device Certificate (SSC) and hash key of the virtual controller, use the **show certificate ssc** command.

show certificate ssc

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the SSC:

```
> show certificate ssc
SSC Hash validation..... Enabled.

SSC Device Certificate details:

    Subject Name :
      C=US, ST=California, L=San Jose, O=Cisco Virtual Wireless LAN Controller,
      CN=DEVICE-vWLC-AIR-CTVM-K9-000C297F2CF7, MAILTO=support@vwlc.com

    Validity :
      Start : 2012 Jul 23rd, 15:47:53 GMT
      End   : 2022 Jun 1st, 15:47:53 GMT

    Hash key : 5870ffabb15de2a617132bafcd73
```

Related Commands

show certificate ssc
show mobility group member
config certificate ssc
config mobility group member hash

show certificate summary

To verify that the controller has generated a certificate, use the **show certificate summary** command.

show certificate summary

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display a summary of the certificate:

```
> show certificate summary
Web Administration Certificate..... Locally Generated
Web Authentication Certificate..... Locally Generated
Certificate compatibility mode:..... off
```

Related Commands

config certificate

config certificate lsc

show certificate lsc

show certificate compatibility

show local-auth certificate

show client calls

To display the total number of active or rejected calls on the controller, use the **show client calls** command.

show client calls {**active** | **rejected**} {**802.11a** | **802.11b/g** | **all**}

Syntax Description

active	Specifies active calls.
rejected	Specifies rejected calls.
802.11a	Specifies the 802.11a network.
802.11b/g	Specifies the 802.11b/g network.
all	Specifies both the 802.11a and 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the active client calls on an 802.11a network:

```
> show client calls active 802.11a
Client MAC      Username      Total Call      AP Name      Radio Type
Duration (sec)
-----
00:09: ef: 02:65:70      abc          45      VJ-1240C-ed45cc      802.11a
00:13: ce: cc: 51:39      xyz          45      AP1130-a416          802.11a
00:40:96: af: 15:15      def          45      AP1130-a416          802.11a
00:40:96:b2:69: df       def          45      AP1130-a416          802.11a
Number of Active Calls ----- 4
```

Related Commands

debug voice-diag

show client roam-history

To display the roaming history of a specified client, use the **show client roam-history** command.

show client roam-history *mac_address*

Syntax Description
<i>mac_address</i>

Client MAC address.

Command Default
None.

Examples
This example shows how to display the roaming history of a specified client: <pre>> show client roam-history 00:14:6c:0a:57:77</pre>

show client summary

To display a summary of clients associated with a Cisco lightweight access point, use the **show client summary** command.

show client summary

Syntax Description

This command has no arguments or keywords up to Release 7.4.

Command Default

None.

Usage Guidelines

Use **show client ap** command to list the status of automatically disabled clients. Use the **show exclusionlist** command to display clients on the exclusion list (blacklisted).

Examples

This example shows how to display a summary of the active clients:

```
> show client summary
Number of Clients..... 24
Number of PMIPv6 Clients..... 200
MAC Address      AP Name      Status      WLAN/GLAN/RLAN Auth Protocol      Port
Wired  PMIPv6
-----
00:00:15:01:00:01 NMSP-TalwarSIM1-2 Associated      1              Yes  802.11a      13
No      Yes
00:00:15:01:00:02 NMSP-TalwarSIM1-2 Associated      1              Yes  802.11a      13
No      No
00:00:15:01:00:03 NMSP-TalwarSIM1-2 Associated      1              Yes  802.11a      13
No      Yes
00:00:15:01:00:04 NMSP-TalwarSIM1-2 Associated      1              Yes  802.11a      13
No      No
```

Related Commands

show client summary guest-lan

show client summary guest-lan

To display the active wired guest LAN clients, use the **show client summary guest-lan** command.

show client summary guest-lan

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of the active wired guest LAN clients:

```
> show client summary guest-lan
Number of Clients..... 1
MAC Address      AP Name      Status      WLAN  Auth  Protocol  Port  Wired
-----
00:16:36:40:ac:58  N/A         Associated   1     No    802.3     1     Yes
```

Related Commands **show client summary**

show client tsm

To display the client traffic stream metrics (TSM) statistics, use the **show client tsm** command.

show client tsm 802.11 {a | b} client_mac {ap_mac | all}

Syntax	Description
802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11 b/g network.
<i>client_mac</i>	MAC address of the client.
<i>ap_mac</i>	MAC address of the tsm access point.
all	Specifies the list of all access points to which the client has associations.

Command Default None.

Examples This example shows how to display the client's TSM for the 802.11a network:

```
> show client tsm 802.11a xx:xx:xx:xx:xx:xx all
AP Interface MAC: 00:0b:85:01:02:03
Client Interface Mac: 00:01:02:03:04:05
Measurement Duration: 90 seconds
Timestamp 1st Jan 2006, 06:35:80
  UpLink Stats
  =====
    Average Delay (5sec intervals).....35
    Delay less than 10 ms.....20
    Delay bet 10 - 20 ms.....20
    Delay bet 20 - 40 ms.....20
    Delay greater than 40 ms.....20
    Total packet Count.....80
    Total packet lost count (5sec).....10
    Maximum Lost Packet count(5sec).....5
    Average Lost Packet count(5secs).....2
  DownLink Stats
  =====
    Average Delay (5sec intervals).....35
    Delay less than 10 ms.....20
    Delay bet 10 - 20 ms.....20
    Delay bet 20 - 40 ms.....20
    Delay greater than 40 ms.....20
    Total packet Count.....80
    Total packet lost count (5sec).....10
    Maximum Lost Packet count(5sec).....5
    Average Lost Packet count(5secs).....2
```

Related Commands

- show client ap**
- show client detail**
- show client summary**

show client username

To display the client data by the username, use the **show client username** command.

show client username *username*

Syntax Description

<i>username</i>	Client's username.

Command Default

None.

Examples

This example shows how to display the detailed information for a client by name:

```
> show client username IT_007
MAC Address      AP ID   Status      WLAN Id   Authenticated
-----
xx:xx:xx:xx:xx:xx  1      Associated   1         No
```

Related Commands

show client ap

show client detail

show client summary

show client voice-diag

To display voice diagnostics statistics, use the **show client voice-diag** command.

show client voice-diag {quos-map | roam-history | rssi | status | tspec}

Syntax Description

quos-map	Displays information about the QoS/DSCP mapping and packet statistics in each of the four queues: VO, VI, BE, BK. The different DSCP values are also displayed.
roam-history	Displays information about history of the last three roamings. The output contains the timestamp, access point associated with the roaming, the roaming reason, and if there is a roaming failure, the reason for the roaming failure.
rssi	Displays the client's RSSI values in the last 5 seconds when voice diagnostics are enabled.
status	Displays the status of voice diagnostics for clients.
tspec	Displays TSPEC for the voice diagnostic for clients.

Command Default

None.

Examples

This example shows how to display the status of the voice diagnostics for clients:

```
> show client voice-diag status
Voice Diagnostics Status: FALSE
```

Related Commands

show client ap
show client detail
show client summary
debug voice-diag

show coredump summary

To display a summary of the controller's core dump file, use the **show coredump summary** command.

show coredump summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the core dump summary:

```
> show coredump summary
Core Dump is enabled
FTP Server IP..... 10.10.10.17
FTP Filename..... file1
FTP Username..... ftpuser
FTP Password..... *****
```

Related Commands

- config coredump**
- config coredump ftp**
- config coredump username**

show cpu

To display current WLAN controller CPU usage information, use the **show cpu** command.

show cpu

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the current CPU usage information:

```
> show cpu  
Current CPU load: 2.50%
```

show custom-web

To display web authentication customization information, use the **show custom-web** command.

show custom-web

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the web authentication customization information:

```
> show custom-web
Radius Authentication Method..... PAP
Cisco Logo..... Enabled
CustomLogo..... None
Custom Title..... None
Custom Message..... None
Custom Redirect URL..... None
External web authentication Mode..... Disabled
External web authentication URL..... None
```

Related Commands

- config custom-web weblogo**
- config custom-web webmessage**
- config custom-web webtitle**
- config custom-web weblogo**
- config custom-web ext-webauth-mode**
- config custom-web redirectUrl**
- config custom-web ext-webauth-type**
- config custom-web ext-webauth-url**
- show custom-web**

show database summary

To display the maximum number of entries in the database, use the **show database summary** command.

show database summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of the local database configuration:

```
> show database summary
Maximum Database Entries..... 2048
Maximum Database Entries On Next Reboot..... 2048
Database Contents
  MAC Filter Entries..... 2
  Exclusion List Entries..... 0
  AP Authorization List Entries..... 1
  Management Users..... 1
  Local Network Users..... 1
    Local Users..... 1
    Guest Users..... 0
  Total..... 5
```

Related Commands **config database size**

show dhcp

To display the internal Dynamic Host Configuration Protocol (DHCP) server configuration, use the **show dhcp** command.

show dhcp {leases | summary | scope}

Syntax Description

leases	Displays allocated DHCP leases.
summary	Displays DHCP summary information.
<i>scope</i>	Name of a scope to display the DHCP information for that scope.

Command Default

None.

Examples

This example shows how to display the allocated DHCP leases:

```
> show dhcp leases
No leases allocated.
```

This example shows how to display the DHCP summary information:

```
> show dhcp summary
Scope Name          Enabled      Address Range
003                  No          0.0.0.0 -> 0.0.0.0
```

This example shows how to display the DHCP information for the scope 003:

```
> show dhcp 003
Enabled..... No
Lease Time..... 0
Pool Start..... 0.0.0.0
Pool End..... 0.0.0.0
Network..... 0.0.0.0
Netmask..... 0.0.0.0
Default Routers..... 0.0.0.0 0.0.0.0 0.0.0.0
DNS Domain.....
DNS..... 0.0.0.0 0.0.0.0 0.0.0.0
Netbios Name Servers..... 0.0.0.0 0.0.0.0 0.0.0.0
```

Related Commands

config dhcp proxy
config dhcp timeout
config interface dhcp
config wlan dhcp server
debug dhcp
debug dhcp service-port
debug disable-all

config dhcp
show dhcp proxy

show dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show dtls connections** command.

show dtls connections

Syntax Description This command has no arguments or keywords.

Command Default None

Examples The following is a sample output of the **show dtls connections** command.

Device > **show dtls connections**

AP Name	Local Port	Peer IP	Peer Port	Ciphersuite
1130	Capwap_Ctrl	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1130	Capwap_Data	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1240	Capwap_Ctrl	1.100.163.209	59674	TLS_RSA_WITH_AES_128_CBC_SHA

Related Commands **debug dtls**

show dhcp proxy

To display the status of DHCP proxy handling, use the **show dhcp proxy** command.

show dhcp proxy

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the status of DHCP proxy information:

```
> show dhcp proxy  
DHCP Proxy Behavior: enabled
```

Related Commands

- config dhcp proxy**
- config dhcp timeout**
- config interface dhcp**
- config wlan dhcp_server**
- debug dhcp**
- debug dhcp service-port**
- debug disable-all**
- show dhcp**
- config dhcp**

show dhcp timeout

To display the DHCP timeout value, use the **show dhcp timeout** command.

show dhcp timeout

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the DHCP timeout value:

```
> show dhcp timeout  
DHCP Timeout (seconds)..... 10
```

Related Commands

- config dhcp proxy
- config dhcp
- config interface dhcp
- config wlan dhcp_server
- debug dhcp
- debug dhcp service-port
- debug disable-all
- show dhcp
- show dhcp proxy

show flow exporter

To display the details or the statistics of the flow exporter, use the **show flow exporter** command.

show flow exporter {summary | statistics}

Syntax Description

summary	Displays a summary of the flow exporter.
statistics	Displays the statistics of flow exporters such as the number of records sent, or the time when the last record was sent.

Command Default

None.

Examples

This example shows how to display the flow exporter details:

```
> show flow exporter summary
Exporter-Name      Exporter-IP      Port
=====
expol              9.9.120.115     800
```

Related Commands

show flow monitor
config flow
config wlan flow

show flow monitor summary

To display the details of the NetFlow monitor, use the **show flow monitor summary** command.

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines Netflow record monitoring and export are used for integration with an NMS or any Netflow analysis tool.

Examples This example shows how to display the details of the NetFlow monitor:

```
> show flow monitor summary
Monitor-Name      Exporter-Name      Exporter-IP      Port  Record Name
=====
mon1              expol              9.9.120.115      800
ipv4_client_app_flow_record
```

Related Commands

- show flow exporter**
- config flow**
- config wlan flow**

show guest-lan

To display the configuration of a specific wired guest LAN, use the **show guest-lan** command.

show guest-lan *guest_lan_id*

Syntax Description	
<i>guest_lan_id</i>	ID of the selected wired guest LAN.

Command Default None.

Usage Guidelines To display all wired guest LANs configured on the controller, use the **show guest-lan summary** command.

Examples This example shows how to display the guest LAN configuration:

```
> show guest-lan 2
Guest LAN Identifier..... 1
Profile Name..... guestlan
Network Name (SSID)..... guestlan
Status..... Enabled
AAA Policy Override..... Disabled
Number of Active Clients..... 1
Exclusionlist Timeout..... 60 seconds
Session Timeout..... Infinity
Interface..... wired
Ingress Interface..... wired-guest
WLAN ACL..... unconfigured
DHCP Server..... 10.20.236.90
DHCP Address Assignment Required..... Disabled
Quality of Service..... Silver (best effort)
Security
  Web Based Authentication..... Enabled
  ACL..... Unconfigured
  Web-Passthrough..... Disabled
  Conditional Web Redirect..... Disabled
  Auto Anchor..... Disabled
Mobility Anchor List
GLAN ID IP Address Status
```

Related Commands

- config guest-lan**
- config guest-lan custom-web ext-webauth-url**
- config guest-lan custom-web global disable**
- config guest-lan custom-web login_page**
- config guest-lan nac**
- config guest-lan security**

show invalid-config

To see any ignored commands or invalid configuration values in an edited configuration file, use the **show invalid-config** command.

show invalid-config

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines You can enter this command only before the **clear config** or **save config** command.

Examples This example shows how to display a list of any ignored commands or invalid configuration values in a configuration file:

```
> show invalid-config
config wlan peer-blocking drop 3
config wlan dhcp_server 3 192.168.0.44 required
```

show inventory

To display a physical inventory of the Cisco wireless LAN controller, use the **show inventory** command.

show inventory

Syntax Description	This command has no arguments or keywords.
Command Default	None.
Usage Guidelines	Some wireless LAN controllers may have no crypto accelerator (VPN termination module) or power supplies listed because they have no provisions for VPN termination modules or power supplies.
Examples	This example shows how to display a physical inventory of the controller: <pre>> show inventory Switch Description..... Cisco Controller Machine Model..... WLC4404-100 Serial Number..... FLS0923003B Burned-in MAC Address..... 00:0B:85:32:AB:60 Crypto Accelerator 1..... Absent Crypto Accelerator 2..... Absent Power Supply 1..... Absent Power Supply 2..... Present, OK</pre>
Related Commands	show ap inventory

show license all

To display information for all licenses on the Cisco 5500 Series Controller, use the **show license all** command.

show license all

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display all the licenses:

```
> show license all
License Store: Primary License Storage
StoreIndex: 0 Feature: wplus-ap-count Version: 1.0
    License Type: Permanent
    License State: Inactive
    License Count: 12/0/0
    License Priority: Medium
StoreIndex: 1 Feature: base Version: 1.0
    License Type: Permanent
    License State: Active, Not in Use
    License Count: Non-Counted
    License Priority: Medium
StoreIndex: 2 Feature: wplus Version: 1.0
    License Type: Permanent
    License State: Active, In Use
    License Count: Non-Counted
    License Priority: Medium
License Store: Evaluation License Storage
StoreIndex: 0 Feature: wplus Version: 1.0
    License Type: Evaluation
    License State: Inactive
        Evaluation total period: 8 weeks 4 days
        Evaluation period left: 6 weeks 6 days
    License Count: Non-Counted
    License Priority: Low
StoreIndex: 1 Feature: wplus-ap-count Version: 1.0
    License Type: Evaluation
    License State: Active, In Use
        Evaluation total period: 8 weeks 4 days
        Evaluation period left: 2 weeks 3 days
        Expiry date: Thu Jun 25 18:09:43 2009
    License Count: 250/250/0
    License Priority: High
StoreIndex: 2 Feature: base Version: 1.0
    License Type: Evaluation
    License State: Inactive
        Evaluation total period: 8 weeks 4 days
        Evaluation period left: 8 weeks 4 days
    License Count: Non-Counted
    License Priority: Low
StoreIndex: 3 Feature: base-ap-count Version: 1.0
    License Type: Evaluation
    License State: Active, Not in Use, EULA accepted
        Evaluation total period: 8 weeks 4 days
        Evaluation period left: 8 weeks 3 days
    License Count: 250/0/0
    License Priority: Low
```


Related Commands

license install
show license agent
show license detail
show license feature
show license image-level
show license summary
license modify priority

show license capacity

To display the maximum number of access points allowed for this license on the Cisco 5500 Series Controller, the number of access points currently joined to the controller, and the number of access points that can still join the controller, use the **show license capacity** command.

show license capacity

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the license capacity:

```
> show license capacity
Licensed Feature    Max Count    Current Count    Remaining Count
-----
AP Count            250          47              203
```

Related Commands

- license install
- show license all
- show license detail
- show license feature
- show license image-level
- show license summary
- license modify priority
- show license evaluation

show license detail

To display details of a specific license on the Cisco 5500 Series Controller, use the **show license detail** command.

show license detail *license-name*

Syntax Description

<i>license-name</i>	Name of a specific license.

Command Default

None.

Examples

This example shows how to display the license details:

```
> show license detail wplus
Feature: wplus          Period left: Life time
Index: 1      Feature: wplus  Version: 1.0
      License Type: Permanent
      License State: Active, In Use
      License Count: Non-Counted
      License Priority: Medium
      Store Index: 2
      Store Name: Primary License Storage
Index: 2      Feature: wplus  Version: 1.0
      License Type: Evaluation
      License State: Inactive
      Evaluation total period:  8 weeks  4 days
      Evaluation period left:  6 weeks  6 days
      License Count: Non-Counted
      License Priority: Low
      Store Index: 0
```

Related Commands

license install
show license agent
show license all
show license feature
show license image-level
show license summary
license modify priority

show license expiring

To display details of expiring licenses on the Cisco 5500 Series Controller, use the **show license expiring** command.

show license expiring

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the details of the expiring licenses:

```
> show license expiring
StoreIndex: 0 Feature: wplus Version: 1.0
  License Type: Evaluation
  License State: Inactive
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 6 weeks 6 days
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 1 Feature: wplus-ap-count Version: 1.0
  License Type: Evaluation
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 2 weeks 3 days
    Expiry date: Thu Jun 25 18:09:43 2009
  License Count: 250/250/0
  License Priority: High
StoreIndex: 2 Feature: base Version: 1.0
  License Type: Evaluation
  License State: Inactive
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 3 Feature: base-ap-count Version: 1.0
  License Type: Evaluation
  License State: Active, Not in Use, EULA accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 3 days
  License Count: 250/0/0
  License Priority: Low
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license in-use**
- show license summary**
- license modify priority**
- show license evaluation**

show license evaluation

To display details of evaluation licenses on the Cisco 5500 Series Controller, use the **show license evaluation** command.

show license evaluation

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the details of the evaluation licenses:

```
> show license evaluation
StoreIndex: 0 Feature: wplus Version: 1.0
  License Type: Evaluation
  License State: Inactive
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 6 weeks 6 days
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 1 Feature: wplus-ap-count Version: 1.0
  License Type: Evaluation
  License State: Active, In Use
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 2 weeks 3 days
    Expiry date: Thu Jun 25 18:09:43 2009
  License Count: 250/250/0
  License Priority: High
StoreIndex: 2 Feature: base Version: 1.0
  License Type: Evaluation
  License State: Inactive
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 4 days
  License Count: Non-Counted
  License Priority: Low
StoreIndex: 3 Feature: base-ap-count Version: 1.0
  License Type: Evaluation
  License State: Active, Not in Use, EULA accepted
    Evaluation total period: 8 weeks 4 days
    Evaluation period left: 8 weeks 3 days
  License Count: 250/0/0
  License Priority: Low
```

Related Commands

- license install
- show license all
- show license detail
- show license expiring
- show license in-use
- show license summary
- license modify priority

show license feature

To display a summary of license-enabled features on the Cisco 5500 Series Controller, use the **show license feature** command.

show license feature

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the license-enabled features:

```
> show license feature
      Feature name Enforcement Evaluation Clear Allowed Enabled
      wplus          yes          yes      yes      yes      yes
wplus-ap-count      yes          yes      yes      yes      yes
      base           no          yes      yes      yes      no
base-ap-count       yes          yes      yes      yes      no
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license expiring**
- show license image-level**
- show license in-use**
- show license summary**
- show license modify priority**
- show license evaluation**

show license file

To display a summary of license-enabled features on the Cisco 5500 Series Controller, use the **show license file** command.

show license file

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the license files:

```
> show license file
License Store: Primary License Storage
Store Index: 0
License: 11 wplus-ap-count 1.0 LONG NORMAL STANDALONE EXCL 12 KEYS INFINIT
E KEYS NEVER NEVER NiL SLM_CODE CL_ND_LCK NiL *1AR5NS7M5AD8PPU400
NiL NiL NiL 5_MINS <UDI><PID>AIR-CT5508-K9</PID><SN>RFD000P2D27<
/SN></UDI> Pe0L7tv8KDUqo:z1Pe423S5wasgM8G,tTs0i,7zLyA3VfxhnIe5aJa
m631r518JM3DPkr4O2DI43iLlKn7jomo3RF11LjMRqLkKhlJ2tOyuftQSq2bCAO6
nR3wIb38xKi3t$<WLC>AQEBIQAB//++mCzRUbOhw28vz0czAY0iAm7ocDLUMb9ER0
+BD3w2PhNEYwsBN/T3xXBqJqfC+oKRqwinXo3s+nsLU7rOtdOxoIXYZAo3LYmUJ+M
FzsqlhKoJVlPyEvQ8H21MNUjVbhoN0gyIWsyiJaM8AQIkVBQFzhr10GYolVzdzfJf
EPQIx6tZ++/Vtc/q3SF/5Ko8XCY=</WLC>
Comment:
Hash: iOGjuLlXgLhcTB113ohIzxVioHA=
. . .
```

Related Commands

license install
show license all
show license detail
show license expiring
show license feature
show license image-level
show license in-use
show license summary
show license evaluation

show license handle

To display the license handles on the Cisco 5500 Series Controller, use the **show license handle** command.

show license handle

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the license handles:

```
> show license handle
Feature: wplus                               , Handle Count: 1
  Units: 01( 0), ID: 0x5e000001, NotifyPC: 0x1001e8f4 LS-Handle (0x00000001),
Units: ( 1)
  Registered clients: 1
    Context 0x1051b610, epID 0x10029378
Feature: base                               , Handle Count: 0
  Registered clients: 1
    Context 0x1053ace0, epID 0x10029378
Feature: wplus-ap-count                     , Handle Count: 1
  Units: 250( 0), ID: 0xd4000002, NotifyPC: 0x1001e8f4      LS-Handle (0x000
00002), Units: (250)
  Registered clients: None
Feature: base-ap-count                     , Handle Count: 0
  Registered clients: None
Global Registered clients: 2
    Context 0x10546270, epID 0x100294cc
    Context 0x1053bae8, epID 0x100294cc
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license expiring**
- show license feature**
- show license image-level**
- show license in-use**
- show license summary**

show license image-level

To display the license image level that is in use on the Cisco 5500 Series Controller, use the **show license image-level** command.

show license image-level

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the image level license settings:

```
> show license image-level
Module name  Image level  Priority  Configured  Valid license
wnbu         wplus        1        YES         wplus
             base        2        NO
NOTE: wplus includes two additional features: Office Extend AP, Mesh AP.
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license expiring**
- show license feature**
- license modify priority**
- show license in-use**
- show license summary**

show license in-use

To display the licenses that are in use on the Cisco 5500 Series Controller, use the **show license in-use** command.

show license in-use

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the licenses that are in use:

```
> show license in-use
StoreIndex:  2  Feature: wplus  Version: 1.0
    License Type: Permanent
    License State: Active, In Use
    License Count: Non-Counted
    License Priority: Medium
StoreIndex:  1  Feature: wplus-ap-count  Version: 1.0
    License Type: Evaluation
    License State: Active, In Use
        Evaluation total period:  8 weeks  4 days
        Evaluation period left:  2 weeks  3 days
        Expiry date: Thu Jun 25 18:09:43 2009
    License Count: 250/250/0
    License Priority: High
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license expiring**
- show license feature**
- show license image-level**
- show license modify priority**
- show license summary**
- show license permanent**
- show license evaluation**

show license permanent

To display the permanent licenses on the Cisco 5500 Series Controller, use the **show license permanent** command.

show license permanent

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the permanent license's information:

```
> show license permanent
StoreIndex: 0 Feature: wplus-ap-count Version: 1.0
    License Type: Permanent
    License State: Inactive
    License Count: 12/0/0
    License Priority: Medium
StoreIndex: 1 Feature: base Version: 1.0
    License Type: Permanent
    License State: Active, Not in Use
    License Count: Non-Counted
    License Priority: Medium
StoreIndex: 2 Feature: wplus Version: 1.0
    License Type: Permanent
    License State: Active, In Use
    License Count: Non-Counted
    License Priority: Medium
```

Related Commands

- license install
- show license all
- show license detail
- show license expiring
- show license feature
- show license image-level
- show license in-use
- show license summary
- license modify priority
- show license evaluation

show license status

To display the license status on the Cisco 5500 Series Controller, use the **show license status** command.

show license status

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the license status:

```
> show license status
      License Type Supported
permanent Non-expiring node locked license
extension Expiring node locked license
evaluation Expiring non node locked license
      License Operation Supported
install    Install license
clear      Clear license
annotate   Comment license
save       Save license
revoke     Revoke license
      Device status
Device Credential type: DEVICE
Device Credential Verification: PASS
Rehost Type: DC_OR_IC
```

Related Commands

- license install
- show license all
- show license detail
- show license expiring
- show license feature
- show license image-level
- show license in-use
- show license summary
- license modify priority
- show license evaluation

show license statistics

To display license statistics on the Cisco 5500 Series Controller, use the **show license statistics** command.

show license statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the license statistics:

```
> show license statistics
      Administrative statistics
      Install success count:      0
      Install failure count:     0
      Install duplicate count:   0
      Comment add count:         0
      Comment delete count:      0
      Clear count:               0
c    Save count:                 0
      Save cred count:           0
      Client status
      Request success count      2
      Request failure count      0
      Release count              0
      Global Notify count        0
```

Related Commands

- license install
- show license all
- show license detail
- show license expiring
- show license feature
- show license image-level
- show license in-use
- show license summary
- license modify priority
- show license evaluation

show license summary

To display a brief summary of all licenses on the Cisco 5500 Series Controller, use the **show license summary** command.

show license summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a brief summary of all licenses:

```
> show license summary
Index 1 Feature: wplus
      Period left: Life time
      License Type: Permanent
      License State: Active, In Use
      License Count: Non-Counted
      License Priority: Medium
Index 2 Feature: wplus-ap-count
      Period left:  2 weeks  3 days
      License Type: Evaluation
      License State: Active, In Use
      License Count: 250/250/0
      License Priority: High
Index 3 Feature: base
      Period left: Life time
      License Type: Permanent
      License State: Active, Not in Use
      License Count: Non-Counted
      License Priority: Medium
Index 4 Feature: base-ap-count
      Period left:  8 weeks  3 days
      License Type: Evaluation
      License State: Active, Not in Use, EULA accepted
      License Count: 250/0/0
      License Priority: Low
```

Related Commands

- license install
- show license all
- show license detail
- show license expiring
- show license feature
- show license image-level
- show license in-use
- show license permanent
- license modify priority
- show license evaluation

show license udi

To display unique device identifier (UDI) values for licenses on the Cisco 5500 Series Controller, use the **show license udi** command.

show license udi

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the UDI values for licenses:

```
> show license udi
Device# PID                               SN                               UDI
-----
*0      AIR-CT5508-K9                      RFD000P2D27                     AIR-CT5508-K9:RFD000P2D27
```

Related Commands

- license install**
- show license all**
- show license detail**
- show license expiring**
- show license feature**
- show license image-level**
- show license in-use**
- show license summary**
- license modify priority**
- show license evaluation**

show load-balancing

To display the status of the load-balancing feature, use the **show load-balancing** command.

show load-balancing

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the load-balancing status:

```
> show load-balancing
Aggressive Load Balancing..... Enabled
Aggressive Load Balancing Window..... 0 clients
Aggressive Load Balancing Denial Count..... 3
Statistics
Total Denied Count..... 10 clients
Total Denial Sent..... 20 messages
Exceeded Denial Max Limit Count..... 0 times
None 5G Candidate Count..... 0 times
None 2.4G Candidate Count..... 0 times
```

Related Commands	config load-balancing

show logging

To display the syslog facility logging parameters and buffer contents, use the **show logging** command.

show logging

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the current settings and buffer content details:

```
> show logging
Logging to buffer :
- Logging of system messages to buffer :
  - Logging filter level..... errors
  - Number of system messages logged..... 67227
  - Number of system messages dropped..... 21136
- Logging of debug messages to buffer ..... Disabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
Logging to console :
- Logging of system messages to console :
  - Logging filter level..... errors
  - Number of system messages logged..... 0
  - Number of system messages dropped..... 88363
- Logging of debug messages to console ..... Enabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
Logging to syslog :
- Syslog facility..... local0
- Logging of system messages to syslog :
  - Logging filter level..... errors
  - Number of system messages logged..... 67227
  - Number of system messages dropped..... 21136
- Logging of debug messages to syslog ..... Disabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
- Number of remote syslog hosts..... 0
  - Host 0..... Not Configured
  - Host 1..... Not Configured
  - Host 2..... Not Configured
Logging of traceback..... Disabled
Logging of process information..... Disabled
Logging of source file informational..... Enabled
Timestamping of messages.....
- Timestamping of system messages..... Enabled
  - Timestamp format..... Date and Time
- Timestamping of debug messages..... Enabled
  - Timestamp format..... Date and Time
Logging buffer (67227 logged, 21136 dropped)
*Apr 03 09:48:01.728: %MM-3-INVALID_PKT_RECVD: mm_listen.c:5508 Received an invalid
packet from 1.100.163.51. Source member:0.0.0.0. source member unknown.
*Apr 03 09:47:34.194: %LWAPP-3-DECODE_ERR: spam_lrad.c:1271 Error decoding discovery
request from AP 00:13:5f:0e:d4:20
*Apr 03 09:47:34.194: %LWAPP-3-DISC_OTAP_ERR: spam_lrad.c:5554 Ignoring OTAP discovery
request from AP 00:13:5f:0e:d4:20, OTAP is disabled
Previous message occurred 2 times.
```

Related Commands **config logging syslog host**

config logging syslog facility

config logging syslog level

show loginsession

To display the existing sessions, use the **show loginsession** command.

show loginsession

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the current session details:

```
> show loginsession
ID      username      Connection From  Idle Time  Session Time
-----
00 admin          EIA-232         00:00:00     00:19:04
```

Related Commands **config loginsession close**

show mgmtuser

To display the local management user accounts on the Cisco wireless LAN controller, use the **show mgmtuser** command.

show mgmtuser

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a list of management users:

```
> show mgmtuser
User Name          Permissions      Description      Password Strength
-----
admin              read-write      -----
Weak
```

Related Commands

- config mgmtuser add**
- config mgmtuser delete**
- config mgmtuser description**
- config mgmtuser password**

show mdns profile

To display mDNS profile information, use the **show mdns profile** command.

show mdns profile {**summary** | **detailed** *profile-name*}

Syntax Description

summary	Displays the summary of the mDNS profiles.
detailed	Displays details of an mDNS profile.
<i>profile-name</i>	Name of the mDNS profile.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

This example shows how to display a summary of all the mDNS profiles:

```
> show mdns profile summary
Number of Profiles..... 2

ProfileName                No. Of Services
-----
default-mdns-profile      5
profile1                  2
```

This example shows how to display the detailed information of an mDNS profile:

```
> show mdns profile detailed default-mdns-profile

Profile Name..... default-mdns-profile
Profile Id..... 1
No of Services..... 5
Services..... AirPrint
               AppleTV
               HP_Photosmart_Printer_1
               HP_Photosmart_Printer_2
               Printer

No. Interfaces Attached..... 0
No. Interface Groups Attached..... 0
No. Wlans Attached..... 1
Wlan Ids..... 1
```

Related Commands

config mdns query interval
config mdns service

config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
config mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail
debug mdns message

show mdns service

To display multicast DNS (mDNS) service information, use the **show mnds service** command.

show mdns service {**summary** | **detailed** *service-name* }

Syntax Description

summary	Displays a summary of all mDNS services.
detailed	Displays details of an mDNS service.
<i>service-name</i>	Name of the mDNS service.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following are sample outputs of the **show mnds service** command.

```
Device > show mdns service summary
```

```
Number of Services..... 5
```

```
Service-Name          Service-string
-----
AirPrint              _ipp._tcp.local.
AppleTV               _airplay._tcp.local.
HP_Photosmart_Printer_1 _universal._sub._ipp._tcp.local.
HP_Photosmart_Printer_2 _cups._sub._ipp._tcp.local.
Printer              _printer._tcp.local.
```

```
Device > show mdns service detailed AirPrint
```

```
Service Name..... AirPrint
Service Id..... 1
Service query status..... Enabled

Number of Profiles..... 2
Profile..... student-profile
               guest-profile

Number of Service Providers ..... 2
Service Provider  MAC-Address          VLAN ID  Type
-----
user1             60:33:4b:2b:a6:9a          104      Wired
laptopa          00:21:1b:ea:36:60    105      Wireless
```

Related Commands

Command	Description
config wlan mdns	Configures an mDNS profile for a WLAN.
config mdns profile	Configures an mDNS profile.
config mdns query interval	Configures the query interval for mDNS services.
config mdns service	Configures mDNS services in the master services database.
config mdns snooping	Enables or disables global mDNS snooping on the Cisco WLC.
clear mdns service-database	Clears the mDNS service database.
debug mdns all	Debugs all mDNS messages, details, and errors.
debug mdns detail	Debugs all mDNS details.
debug mdns error	Debugs all mDNS errors.
debug mdns message	Debugs all mDNS messages.
show mdns profile	Displays mDNS profile information.

show netuser

To display the configuration of a particular user in the local user database, use the **show netuser** command.

show netuser {**detail** *user_name* | **guest-roles** | **summary**}

Syntax Description

detail	Displays detailed information about the specified network user.
<i>user_name</i>	Network user.
guest_roles	Displays configured roles for guest users.
summary	Displays a summary of all users in the local user database.

Command Default

None.

Examples

This example shows how to display a summary of all users in the local user database:

```
> show netuser summary
Maximum logins allowed for a given username .....Unlimited
```

This example shows how to display detailed information on the specified network user:

```
> show netuser detail john10
username..... abc
WLAN Id..... Any
Lifetime..... Permanent
Description..... test user
```

Related Commands

config netuser add
config netuser delete
config netuser description
config netuser guest-role apply
config netuser wlan-id
config netuser guest-roles

show netuser guest-roles

To display a list of the current quality of service (QoS) roles and their bandwidth parameters, use the **show netuser guest-roles** command.

show netuser guest-roles

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a QoS role for the guest network user:

```
> show netuser guest-roles
Role Name..... Contractor
  Average Data Rate..... 10
  Burst Data Rate..... 10
  Average Realtime Rate..... 100
  Burst Realtime Rate..... 100
Role Name..... Vendor
  Average Data Rate..... unconfigured
  Burst Data Rate..... unconfigured
  Average Realtime Rate..... unconfigured
  Burst Realtime Rate..... unconfigured
```

Related Commands

- config netuser add**
- config netuser delete**
- config netuser description**
- config netuser guest-role apply**
- config netuser wlan-id**
- show netuser guest-roles**
- show netuser**

show network

To display the current status of 802.3 bridging for all WLANs, use the **show network** command.

show network

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the network details:

```
> show network
```

Related Commands

- config network**
- show network summary**
- show network multicast mgid detail**
- show network multicast mgid summary**

show network summary

To display the network configuration of the Cisco wireless LAN controller, use the **show network summary** command.

show network summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary configuration:

```
> show network summary
RF-Network Name..... RF
Web Mode..... Disable
Secure Web Mode..... Enable
Secure Web Mode Cipher-Option High..... Disable
Secure Web Mode Cipher-Option SSLv2..... Disable
Secure Web Mode RC4 Cipher Preference..... Disable
OCSP..... Disabled
OCSP responder URL.....
Secure Shell (ssh)..... Enable
Telnet..... Enable
Ethernet Multicast Mode..... Disable   Mode: Ucast
Ethernet Broadcast Mode..... Disable
Ethernet Multicast Forwarding..... Disable
Ethernet Broadcast Forwarding..... Disable
AP Multicast/Broadcast Mode..... Unicast
IGMP snooping..... Disabled
IGMP timeout..... 60 seconds
IGMP Query Interval..... 20 seconds
MLD snooping..... Disabled
MLD timeout..... 60 seconds
MLD query interval..... 20 seconds
User Idle Timeout..... 300 seconds
AP Join Priority..... Disable
ARP Idle Timeout..... 300 seconds
ARP Unicast Mode..... Disabled
Cisco AP Default Master..... Disable
Mgmt Via Wireless Interface..... Disable
Mgmt Via Dynamic Interface..... Disable
Bridge MAC filter Config..... Enable
Bridge Security Mode..... EAP
Over The Air Provisioning of AP's..... Enable
Apple Talk ..... Disable
Mesh Full Sector DFS..... Enable
AP Fallback ..... Disable
Web Auth CMCC Support ..... Disabled
Web Auth Redirect Ports ..... 80
Web Auth Proxy Redirect ..... Disable
Web Auth Captive-Bypass ..... Disable
Web Auth Secure Web ..... Enable
Fast SSID Change ..... Disabled
AP Discovery - NAT IP Only ..... Enabled
IP/MAC Addr Binding Check ..... Enabled
CCX-lite status ..... Disable
oeap-600 dual-rlan-ports ..... Disable
oeap-600 local-network ..... Enable
mDNS snooping..... Disabled
mDNS Query Interval..... 15 minutes
```

Related Commands

config network
show network multicast mgid summary
show network multicast mgid detail
show network

show network multicast mgid detail

To display all the clients joined to the multicast group in a specific multicast group identification (MGID), use the **show network multicast mgid detail** command.

show network multicast mgid detail *mgid_value*

Syntax Description

<i>mgid_value</i>	Number between 550 and 4095.

Command Default

None.

Examples

This example shows how to display details of the multicast database:

```
> show network multicast mgid detail
Mgid ..... 550
Multicast Group Address ..... 239.255.255.250
Vlan ..... 0
Rx Packet Count ..... 807399588
No of clients ..... 1
Client List .....
  Client MAC      Expire TIme (mm:ss)
  00:13:02:23:82:ad  0:20
```

Related Commands

show network summary
show network multicast mgid detail
show network

show network multicast mgid summary

To display all the multicast groups and their corresponding multicast group identifications (MGIDs), use the **show network multicast mgid summary** command.

show network multicast mgid summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of multicast groups and their MGIDs:

```
> show network multicast mgid summary
Layer2 MGID Mapping:
-----
InterfaceName          vlanId      MGID
-----
management              0           0
test                    0           9
wired                   20          8
Layer3 MGID Mapping:
-----
Number of Layer3 MGIDs ..... 1
Group address          Vlan      MGID
-----
239.255.255.250        0         550
```

Related Commands

- show network summary**
- show network multicast mgid detail**
- show network**

show nmsp notify-interval summary

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmsp notify-interval summary** command.

show nmsp notify-interval summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display NMSP configuration settings:

```
> show nmsp notify-interval summary
NMSP Notification Interval Summary
Client
    Measurement interval:    2 sec
RFID
    Measurement interval:    8 sec
Rogue AP
    Measurement interval:    2 sec
Rogue Client
    Measurement interval:    2 sec
```

Related Commands

- clear locp statistics**
- clear nmsp statistics**
- config nmsp notify-interval measurement**
- show nmsp statistics**
- show nmsp status**

show nmsp statistics

To display Network Mobility Services Protocol (NMSP) counters, use the **show nmsp statistics** command.

show nmsp statistics {summary | connection all}

Syntax Description

summary	Displays common NMSP counters.
connection all	Displays all connection-specific counters.

Command Default

None.

Examples

This example shows how to display a summary of common NMSP counters:

```
> show nmsp statistics summary
Send RSSI with no entry:      0
Send too big msg:            0
Failed SSL write:            0
Partial SSL write:           0
SSL write attempts to want write:
Transmit Q full:0
Max Measure Notify Msg:      0
Max Info Notify Msg:         0
Max Tx Q Size:               2
Max Rx Size:                 1
Max Info Notify Q Size:      0
Max Client Info Notify Delay: 0
Max Rogue AP Info Notify Delay: 0
Max Rogue Client Info Notify Delay: 0
Max Client Measure Notify Delay: 0
Max Tag Measure Notify Delay: 0
Max Rogue AP Measure Notify Delay: 0
Max Rogue Client Measure Notify Delay: 0
Max Client Stats Notify Delay: 0
Max Tag Stats Notify Delay:  0
RFID Measurement Periodic :  0
RFID Measurement Immediate :  0
Reconnect Before Conn Timeout: 0
```

This example shows how to display all the connection-specific NMSP counters:

```
> show nmsp statistics connection all
NMSP Connection Counters
Connection 1 :
Connection status:  UP
Freed Connection:   0
Nmosp Subscr Req:   0      NMSP Subscr Resp:  0
Info Req:           1      Info Resp:         1
Measure Req:        2      Measure Resp:      2
Stats Req:          2      Stats Resp:        2
Info Notify:        0      Measure Notify:    0
Loc Capability:     2
Location Req:       0      Location Resp:     0
Loc Subscr Req:     0      Loc Subscr Resp:   0
Loc Notif:          0
Loc Unsubscr Req:   0      Loc Unsubscr Resp: 0
IDS Get Req:        0      IDS Get Resp:      0
```

```
IDS Notif:          0
IDS Set Req:        0      IDS Set Resp:      0
```

Related Commands**show nmsp notify-interval summary****clear nmsp statistics****config nmsp notify-interval measurement****show nmsp status**

show nmsp status

To display the status of active Network Mobility Services Protocol (NMSP) connections, use the **show nmsp status** command.

show nmsp status

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the status of the active NMSP connections:

```
> show nmsp status
LocServer IP    TxEchoResp  RxEchoReq TxData  RxData
-----
171.71.132.158 21642       21642      51278   21253
```

Related Commands

- show nmsp notify-interval summary**
- clear nmsp statistics**
- config nmsp notify-interval measurement**
- show nmsp status**
- clear locp statistics**
- show nmsp statistics**

show nmosp subscription

To display the Network Mobility Services Protocol (NMSP) services that are active on the controller, use the **show nmosp subscription** command.

show nmosp subscription {**summary** | **detail** *ip_addr*}

Syntax Description

summary	Displays all of the NMSP services to which the controller is subscribed.
detail	Displays details for all of the NMSP services to which the controller is subscribed.
<i>ip_addr</i>	Details only for the NMSP services subscribed to by a specific IP address.

Command Default

None.

Examples

This example shows how to display a summary of all the NMSP services to which the controller is subscribed:

```
> show nmosp subscription summary
Mobility Services Subscribed:
Server IP      Services
-----
10.10.10.31    RSSI, Info, Statistics
```

This example shows how to display details of all the NMSP services:

```
> show nmosp subscription detail 10.10.10.31
Mobility Services Subscribed by 10.10.10.31
Services      Sub-services
-----
RSSI          Mobile Station, Tags,
Info          Mobile Station,
Statistics    Mobile Station, Tags,
```

Related Commands

show nmosp notify-interval summary
show nmosp statistics
config nmosp notify-interval measurement
clear nmosp statistics
clear loop statistics

show ntp-keys

To display network time protocol authentication key details, use the **show ntp-keys** command.

show ntp-keys

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display NTP authentication key details:

```
> show ntp-keys
Ntp Authentication Key Details.....
   Key Index
   -----
       1
       3
```

Related Commands **config time ntp**

show qos

To display quality of service (QoS) information, use the **show qos** command.

show qos {bronze | gold | platinum | silver}

Syntax Description

bronze	Displays QoS information for the bronze profile of the WLAN.
gold	Displays QoS information for the gold profile of the WLAN.
platinum	Displays QoS information for the platinum profile of the WLAN.
silver	Displays QoS information for the silver profile of the WLAN.

Command Default

None.

Examples

This example shows how to display QoS information for the silver profile:

```
> show qos
```

```
Description..... For Best Effort
Maximum Priority..... besteffort
Unicast Default Priority..... besteffort
Multicast Default Priority..... besteffort
Per-SSID Rate Limits..... Upstream      Downstream
Average Data Rate.....      0            0
Average Realtime Data Rate.....      0            0
Burst Data Rate.....      0            0
Burst Realtime Data Rate.....      0            0
Per-Client Rate Limits..... Upstream      Downstream
Average Data Rate.....      0            0
Average Realtime Data Rate.....      0            0
Burst Data Rate.....      0            0
Burst Realtime Data Rate.....      0            0
protocol..... none
```

Related Commands

config qos protocol-type

show reset

To display the scheduled system reset parameters, use the **show reset** command.

show reset

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the scheduled system reset parameters:

```
> show reset
System reset is scheduled for Mar 27 01 :01 :01 2010
Current local time and date is Mar 24 02:57:44 2010
A trap will be generated 10 minutes before each scheduled system reset.
Use 'reset system cancel' to cancel the reset.
Configuration will be saved before the system reset.
```

Related Commands

- reset system at**
- reset system in**
- reset system cancel**
- reset system notify-time**

show route kernel

To display the kernel route cache information, use the **show route kernel** command.

show route kernel

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the kernel route cache information:

```
> show route kernel
Iface Destination Gateway Flags RefCnt Use Metric Mask MTU Window IRTT
dt10 14010100 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 28282800 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 34010100 00000000 0001 0 0 0 FFFFFFF0 0 0 0
eth0 02020200 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 33010100 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 0A010100 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 32010100 00000000 0001 0 0 0 FFFFFFF0 0 0 0
dt10 0A000000 0202020A 0003 0 0 0 FF000000 0 0 0
lo 7F000000 00000000 0001 0 0 0 FF000000 0 0 0
dt10 00000000 0A010109 0003 0 0 0 00000000 0 0 0
```

Related Commands

- clear ap
- debug arp
- show arp kernel
- config route add
- config route delete

show route summary

To display the routes assigned to the Cisco wireless LAN controller service port, use the **show route summary** command.

show route summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display all the configured routes:

```
> show route summary
Number of Routes..... 1
Destination Network      Genmask      Gateway
-----
xxx.xxx.xxx.xxx         255.255.255.0   xxx.xxx.xxx.xxx
```

Related Commands **config route**

show sessions

To display the console port login timeout and maximum number of simultaneous command-line interface (CLI) sessions, use the **show sessions** command.

show sessions

Syntax Description	This command has no arguments or keywords.

Command Default	5 minutes, 5 sessions.

Examples	This example shows how to display the CLI session configuration setting:

```
> show sessions
CLI Login Timeout (minutes)..... 0
Maximum Number of CLI Sessions..... 5
```

The response indicates that the CLI sessions never time out and that the Cisco wireless LAN controller can host up to five simultaneous CLI sessions.

Related Commands	config sessions maxsessions config sessions timeout

show snmpcommunity

To display Simple Network Management Protocol (SNMP) community entries, use the **show snmpcommunity** command.

show snmpcommunity

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display SNMP community entries:

```
> show snmpcommunity
SNMP Community Name Client IP Address Client IP Mask Access Mode Status
-----
public              0.0.0.0          0.0.0.0          Read Only    Enable
*****             0.0.0.0          0.0.0.0          Read/Write   Enable
```

Related Commands

- config snmp community accessmode
- config snmp community create
- config snmp community delete
- config snmp community ipaddr
- config snmp community mode
- config snmp syscontact

show snmpengineID

To display the SNMP engine ID, use the **show snmpengineID** command.

show snmpengineID

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the SNMP engine ID:

```
> show snmpengineID
SNMP EngineId... ffffffff
```

Related Commands **config snmp engineID**

show snmptrap

To display Cisco wireless LAN controller Simple Network Management Protocol (SNMP) trap receivers and their status, use the **show snmptrap** command.

show snmptrap

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display SNMP trap receivers and their status:

```
> show snmptrap
SNMP Trap Receiver Name      IP Address      Status
-----
xxx.xxx.xxx.xxx             xxx.xxx.xxx.xxx  Enable
```

Related Commands

- config snmp trapreceiver create**
- config snmp trapreceiver delete**

show snmpv3user

To display Simple Network Management Protocol (SNMP) version 3 configuration, use the **show snmpv3user** command.

show snmpv3user

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Examples

This example shows how to display SNMP version 3 configuration information:

```
> show snmpv3user
SNMP v3 username      AccessMode  Authentication  Encryption
-----
default                Read/Write  HMAC-SHA       CFB-AES
```

Related Commands

config snmp v3user create

config snmp v3user delete

show snmpversion

To display which versions of Simple Network Management Protocol (SNMP) are enabled or disabled on your controller, use the **show snmpversion** command.

show snmpversion

Syntax Description This command has no arguments or keywords.

Command Default Enable.

Examples This example shows how to display the SNMP v1/v2/v3 status:

```
> show snmpversion
SNMP v1 Mode..... Disable
SNMP v2c Mode..... Enable
SNMP v3 Mode..... Enable
```

Related Commands **config snmp version**

show switchconfig

To display parameters that apply to the Cisco wireless LAN controller, use the **show switchconfig** command.

show switchconfig

Syntax Description This command has no arguments or keywords.

Command Default Enabled.

Examples This example shows how to display parameters that apply to the Cisco wireless LAN controller:

```
> show switchconfig
802.3x Flow Control Mode..... Disabled
FIPS prerequisite features..... Enabled
Boot Break..... Enabled
secret obfuscation..... Enabled
Strong Password Check Features:
    case-check .....Disabled
    consecutive-check ....Disabled
    default-check .....Disabled
    username-check .....Disabled
```

Related Commands

- config switchconfig mode
- config switchconfig secret-obfuscation
- config switchconfig strong-pwd
- config switchconfig flowcontrol
- config switchconfig fips-prerequisite
- show stats switch

show sysinfo

To display high-level Cisco wireless LAN controller information, use the **show sysinfo** command.

show sysinfo

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display wireless LAN controller information:

```
> show sysinfo
Manufacturer's Name..... Cisco Systems Inc.
Product Name..... Cisco Controller
Product Version..... 6.0.133.0
Build Information..... Tue Mar 31 11:44:12 PDT 2009
Bootloader Version..... 0.14.0
Field Recovery Image Version..... 5.3.38.0-BL-9-16
Firmware Version..... FPGA 1.0, Env 0.8, USB console 1.27
Build Type..... DATA + WPS
System Name..... 5500
System Location.....
System Contact.....
System ObjectID..... 1.3.6.1.4.1.9.1.1
IP Address..... 10.10.10.7
Last Reset..... Software reset
System Up Time..... 1 days 15 hrs 17 mins 48 secs
System Timezone Location.....
Current Boot License Level..... wplus
Current Boot License Type..... Permanent
Next Boot License Level..... wplus
Next Boot License Type..... Permanent
Configured Country..... US - United States
Operating Environment..... Commercial (0 to 40 C)
Internal Temp Alarm Limits..... 0 to 65 C
Internal Temperature..... +45 C
External Temperature..... +29 C
Fan Status..... OK
State of 802.11b Network..... Enabled
State of 802.11a Network..... Disabled
Number of WLANs..... 18
3rd Party Access Point Support..... Disabled
Number of Active Clients..... 1
Burned-in MAC Address..... 00:00:1B:EE:12:E0
Power Supply 1..... Not Available
Power Supply 2..... Not Available
Maximum number of APs supported..... 250
```

Related Commands **config sysname**

show tech-support

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support** command.

show tech-support

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display system resource information:

```
> show tech-support
Current CPU Load..... 0%
System Buffers
  Max Free Buffers..... 4608
  Free Buffers..... 4604
  Buffers In Use..... 4
Web Server Resources
  Descriptors Allocated..... 152
  Descriptors Used..... 3
  Segments Allocated..... 152
  Segments Used..... 3
System Resources
  Uptime..... 747040 Secs
  Total Ram..... 127552 Kbytes
  Free Ram..... 19540 Kbytes
  Shared Ram..... 0 Kbytes
  Buffer Ram..... 460 Kbytes
```

show time

To display the Cisco wireless LAN controller time and date, use the **show time** command.

show time

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the controller time and date when authentication is not enabled:

```
> show time
Time..... Wed Apr 13 09:29:15 2011
Timezone delta..... 0:0
Timezone location..... (GMT +5:30) Colombo, New Delhi, Chennai, Kolkata
NTP Servers
  NTP Polling Interval..... 3600
  Index      NTP Key Index      NTP Server      NTP Msg Auth Status
  -----
    1          0          9.2.60.60      AUTH DISABLED
```

This example shows successful authentication of NTP Message results in the AUTH Success:

```
> show time
Time..... Thu Apr 7 13:56:37 2011
Timezone delta..... 0:0
Timezone location..... (GMT +5:30) Colombo, New Delhi, Chennai, Kolkata
NTP Servers
  NTP Polling Interval..... 3600
  Index      NTP Key Index      NTP Server      NTP Msg Auth Status
  -----
    1          1          9.2.60.60      AUTH SUCCESS
```

This example shows that if the packet received has errors, then the NTP Msg Auth status will show AUTH Failure:

```
> show time
Time..... Thu Apr 7 13:56:37 2011
Timezone delta..... 0:0
Timezone location..... (GMT +5:30) Colombo, New Delhi, Chennai, Kolkata
NTP Servers
  NTP Polling Interval..... 3600
  Index      NTP Key Index      NTP Server      NTP Msg Auth Status
  -----
    1         10          9.2.60.60      AUTH FAILURE
```

This example shows that if there is no response from NTP server for the packets, the NTP Msg Auth status will be blank:

```
> show time
Time..... Thu Apr 7 13:56:37 2011
Timezone delta..... 0:0
Timezone location..... (GMT +5:30) Colombo, New Delhi, Chennai, Kolkata
NTP Servers
  NTP Polling Interval..... 3600
  Index      NTP Key Index      NTP Server      NTP Msg Auth Status
```

1

11

9.2.60.60

Related Commands

config time manual

config time ntp

config time timezone

config time timezone location

show trapflags

To display the Cisco wireless LAN controller Simple Network Management Protocol (SNMP) trap flags, use the **show trapflags** command.

show trapflags

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display controller SNMP trap flags:

```
> show trapflags
Authentication Flag..... Enable
Link Up/Down Flag..... Enable
Multiple Users Flag..... Enable
Spanning Tree Flag..... Enable
Client Related Traps
  802.11 Disassociation..... Disable
  802.11 Association..... Disabled
  802.11 Deauthenticate..... Disable
  802.11 Authenticate Failure..... Disable
  802.11 Association Failure..... Disable
  Authentication..... Disabled
  Excluded..... Disable
  Max Client Warning Threshold..... 90%
Nac-Alert Traps..... Disabled
RFID Related Traps
  Max RFIDs Warning Threshold..... 90%

802.11 Security related traps
  WEP Decrypt Error..... Enable
  IDS Signature Attack..... Disable

Cisco AP
  Register..... Enable
  InterfaceUp..... Enable
Auto-RF Profiles
  Load..... Enable
  Noise..... Enable
  Interference..... Enable
  Coverage..... Enable
Auto-RF Thresholds
  tx-power..... Enable
  channel..... Enable
  antenna..... Enable

AAA
  auth..... Enable
  servers..... Enable
rogueap..... Enable
adjchannel-rogueap..... Disabled
wps..... Enable
configsave..... Enable
IP Security
  esp-auth..... Enable
  esp-replay..... Enable
  invalidSPI..... Enable
  ike-neg..... Enable
  suite-neg..... Enable
  invalid-cookie..... Enable

Mesh
```

```

auth failure..... Enabled
child excluded parent..... Enabled
parent change..... Enabled
child moved..... Enabled
excessive parent change..... Enabled
onset SNR..... Enabled
abate SNR..... Enabled
console login..... Enabled
excessive association..... Enabled
default bridge group name..... Enabled
excessive hop count..... Disabled
excessive children..... Enabled
sec backhaul change..... Disabled

```

Related Commands**config trapflags 802.11-Security****config trapflags aaa****config trapflags ap****config trapflags authentication****config trapflags client****config trapflags configsave****config trapflags IPsec****config trapflags linkmode**

show traplog

To display the Cisco wireless LAN controller Simple Network Management Protocol (SNMP) trap log, use the **show traplog** command.

show traplog

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display controller SNMP trap log settings:

```
> show traplog
Number of Traps Since Last Reset..... 2447
Number of Traps Since Log Last Displayed... 2447
Log System Time          Trap
-----
 0 Thu Aug  4 19:54:14 2005 Rogue AP : 00:0b:85:52:62:fe detected on Base Rad
io MAC : 00:0b:85:18:b6:50 Interface no:1(802.11
b/g) with RSSI: -78 and SNR: 10
 1 Thu Aug  4 19:54:14 2005 Rogue AP : 00:0b:85:52:19:d8 detected on Base Rad
io MAC : 00:0b:85:18:b6:50 Interface no:1(802.11
b/g) with RSSI: -72 and SNR: 16
 2 Thu Aug  4 19:54:14 2005 Rogue AP : 00:0b:85:26:a1:8d detected on Base Rad
io MAC : 00:0b:85:18:b6:50 Interface no:1(802.11
b/g) with RSSI: -82 and SNR: 6
 3 Thu Aug  4 19:54:14 2005 Rogue AP : 00:0b:85:14:b3:4f detected on Base Rad
io MAC : 00:0b:85:18:b6:50 Interface no:1(802.11
b/g) with RSSI: -56 and SNR: 30
Would you like to display more entries? (y/n)
```

Related Commands **show trapflags**

show rfid client

To display the radio frequency identification (RFID) tags that are associated to the controller as clients, use the **show rfid client** command.

show rfid client

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines When the RFID tag is not in client mode, the above fields are blank.

Examples This example shows how to display the RFID tag that is associated to the controller as clients:

```
> show rfid client
-----
RFID Mac          VENDOR      Heard      Associated AP      Chnl      Client State
-----
00:14:7e:00:0b:b1 Pango        35         AP0019.e75c.fef4   1         Probing
```

Related Commands

- config rfid status**
- config rfid timeout**
- show rfid config**
- show rfid detail**
- show rfid summary**

show rfid config

To display the current radio frequency identification (RFID) configuration settings, use the **show rfid config** command.

show rfid config

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the current RFID configuration settings:

```
> show rfid config
RFID Tag Data Collection ..... Enabled
RFID Tag Auto-Timeout ..... Enabled
RFID Client Data Collection ..... Disabled
RFID Data Timeout ..... 200 seconds
```

Related Commands

- config rfid status**
- config rfid timeout**
- show rfid client**
- show rfid detail**
- show rfid summary**

show rfid detail

To display detailed radio frequency identification (RFID) information for a specified tag, use the **show rfid detail** command.

show rfid detail *mac_address*

Syntax Description

<i>mac_address</i>	MAC address of an RFID tag.

Command Default

None.

Examples

This example shows how to display detailed RFID information:

```
> show rfid detail 00:12:b8:00:20:52
RFID address..... 00:12:b8:00:20:52
Vendor..... G2
Last Heard..... 51 seconds ago
Packets Received..... 2
Bytes Received..... 324
Cisco Type.....
Content Header
=====
Version..... 0
Tx Power..... 12 dBm
Channel..... 1
Reg Class..... 12
Burst Length..... 1
CCX Payload
=====
Last Sequence Control..... 0
Payload length..... 127
Last Sequence Control..... 0
Payload length..... 127
Payload Data Hex Dump
01 09 00 00 00 00 0b 85 52 52 52 02 07 4b ff ff
7f ff ff ff 03 14 00 12 7b 10 48 53 c1 f7 51 4b
50 ba 5b 97 27 80 00 67 00 01 03 05 01 42 34 00
00 03 05 02 42 5c 00 00 03 05 03 42 82 00 00 03
05 04 42 96 00 00 03 05 05 00 00 00 55 03 05 06
42 be 00 00 03 02 07 05 03 12 08 10 00 01 02 03
04 05 06 07 08 09 0a 0b 0c 0d 0e 0f 03 0d 09 03
08 05 07 a8 02 00 10 00 23 b2 4e 03 02 0a 03
Nearby AP Statistics:
lap1242-2(slot 0, chan 1) 50 seconds ag.... -76 dBm
lap1242(slot 0, chan 1) 50 seconds ago..... -65 dBm
```

Related Commands

- config rfid status**
- config rfid timeout**
- show rfid config**
- show rfid client**
- show rfid summary**

show rfid summary

To display a summary of the radio frequency identification (RFID) information for a specified tag, use the **show rfid summary** command.

show rfid summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of RFID information:

```
> show rfid summary
Total Number of RFID : 5
```

RFID ID	VENDOR	Closest AP	RSSI	Time Since Last Heard
00:04:f1:00:00:04	Wherenet	ap:1120	-51	858 seconds ago
00:0c:cc:5c:06:d3	Aerosct	ap:1120	-51	68 seconds ago
00:0c:cc:5c:08:45	Aerosct	AP_1130	-54	477 seconds ago
00:0c:cc:5c:08:4b	Aerosct	wolverine	-54	332 seconds ago
00:0c:cc:5c:08:52	Aerosct	ap:1120	-51	699 seconds ago

Related Commands

- config rfid status**
- config rfid timeout**
- show rfid client**
- show rfid detail**
- show rfid config**

config Commands

This section lists the **config** commands that you can use to configure the controller settings, and manage user accounts.

config 802.11h channelswitch

To configure a 802.11h channel switch announcement, use the **config 802.11h channelswitch** command.

config 802.11h channelswitch {**enable** *mode value* | **disable**}

Syntax Description

enable	Enables the 802.11h channel switch announcement.
<i>mode</i>	802.11h channel switch announcement mode.
<i>value</i>	802.11h channel announcement value.
disable	Disables the 802.11h channel switch announcement.

Command Default

None.

Examples

This example shows how to disable the 802.11h switch announcement:

```
> config 802.11h channelswitch disable
```

Related Commands

show 802.11h

config 802.11h powerconstraint

To configure the 802.11h power constraint value, use the **config 802.11h powerconstraint** command.

config 802.11h powerconstraint *value*

Syntax Description

<i>value</i>	802.11h power constraint value.

Command Default

None.

Examples

This example shows how to configure the 802.11h power constraint to 5:

```
> config 802.11h powerconstraint 5
```

Related Commands

show 802.11h

config 802.11h setchannel

To configure a new channel using 802.11h channel announcement, use the **config 802.11h setchannel** command.

config 802.11h setchannel *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure a new channel using the 802.11h channel:

```
> config 802.11h setchannel ap02
```

Related Commands

show 802.11h

config 802.11 11nsupport

To enable 802.11n support on the network, use the **config 802.11 11nsupport** command.

config 802.11 {a | b} 11nsupport {enable | disable}

Syntax Description

a	Specifies the 802.11a network settings.
b	Specifies the 802.11b/g network settings.
enable	Enables the 802.11n support.
disable	Disables the 802.11n support.

Command Default

None.

Examples

This example shows how to enable the 802.11n support on an 802.11a network:

```
> config 802.11a 11nsupport enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11 11nsupport a-mpdu tx priority
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport a-mpdu tx priority

To specify the aggregation method used for 802.11n packets, use the **config 802.11 11nsupport a-mpdu tx priority** command.

config 802.11 {a | b} 11nsupport a-mpdu tx priority {0-7 | all} {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
0-7	Specifies the aggregated MAC protocol data unit priority level between 0 through 7.
all	Configures all of the priority levels at once.
enable	Specifies the traffic associated with the priority level uses A-MPDU transmission.
disable	Specifies the traffic associated with the priority level uses A-MSDU transmission.

Command Default

By default, Priority 0 is enabled.

Usage Guidelines

Aggregation is the process of grouping packet data frames together rather than transmitting them separately. Two aggregation methods are available: Aggregated MAC Protocol Data Unit (A-MPDU) and Aggregated MAC Service Data Unit (A-MSDU). A-MPDU is performed in the software whereas A-MSDU is performed in the hardware.

Aggregated MAC Protocol Data Unit priority levels assigned per traffic type are as follows:

- 1—Background
- 2—Spare
- 0—Best effort
- 3—Excellent effort
- 4—Controlled load
- 5—Video, less than 100-ms latency and jitter
- 6—Voice, less than 10-ms latency and jitter
- 7—Network control
- all—Configure all of the priority levels at once.



Note

Configure the priority levels to match the aggregation method used by the clients.

Examples

This example shows how to configure all the priority levels at once so that the traffic associated with the priority level uses A-MSDU transmission:

```
> config 802.11a 11nsupport a-mpdu tx priority all enable
```

Related Commands

config 802.11 11nsupport mcs tx

config 802.11a disable network

config 802.11a disable

config 802.11a channel ap

config 802.11a txpower ap

config 802.11 11nsupport a-mpdu tx scheduler

To configure the 802.11n-5 GHz A-MPDU transmit aggregation scheduler, use the **config 802.11 11nsupport a-mpdu tx scheduler** command.

config 802.11 {a | b} 11nsupport a-mpdu tx scheduler {enable | disable | timeout rt *timeout-value*}

Syntax Description

enable	Enables the 802.11n-5 GHz A-MPDU transmit aggregation scheduler.
disable	Disables the 802.11n-5 GHz A-MPDU transmit aggregation scheduler.
timeout rt	Configures the A-MPDU transmit aggregation scheduler realtime traffic timeout.
<i>timeout-value</i>	Timeout value in milliseconds. The valid range is between 1 millisecond to 1000 milliseconds.

Command Default

None.

Usage Guidelines

Ensure that the 802.11 network is disabled before you enter this command.

Examples

This example shows how to configure the A-MPDU transmit aggregation scheduler realtime traffic timeout of 100 milliseconds:

```
> config 802.11 11nsupport a-mpdu tx scheduler timeout rt 100
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport antenna

To configure an access point to use a specific antenna, use the **config 802.11 11nsupport antenna** command.

config 802.11 {a | b} 11nsupport antenna *cisco_ap* {A | B | C | D} {enable | disable}

Syntax Description

a	Specifies the 802.11a/n network.
b	Specifies the 802.11b/g/n network.
<i>cisco_ap</i>	Access point.
A/B/C/D	Specifies an antenna port.
enable	Enables the configuration.
disable	Disables the configuration.

Command Default

None.

Examples

This example shows how to configure transmission to a single antenna for legacy orthogonal frequency-division multiplexing:

```
> config 802.11 11nsupport antenna AP1 C enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport guard-interval

To configure the guard interval, use the **config 802.11 11nsupport guard-interval** command.

config 802.11 {a | b} 11nsupport guard-interval {any | long}

Syntax Description

any	Enables either a short or a long guard interval.
long	Enables only a long guard interval.

Command Default

None.

Examples

This example shows how to configure a long guard interval:

```
> config 802.11 11nsupport guard-interval long
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport mcs tx

To specify the modulation and coding scheme (MCS) rates at which data can be transmitted between the access point and the client, use the **config 802.11 11nsupport mcs tx** command.

config 802.11 {a | b} 11nsupport mcs tx {0-15} {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
11nsupport	Specifies support for 802.11n devices.
mcs tx	Specifies the modulation and coding scheme data rates as follows: • 0 (7 Mbps) • 1 (14 Mbps) • 2 (21 Mbps) • 3 (29 Mbps) • 4 (43 Mbps) • 5 (58 Mbps) • 6 (65 Mbps) • 7 (72 Mbps) • 8 (14 Mbps) • 9 (29 Mbps) • 10 (43 Mbps) • 11 (58 Mbps) • 12 (87 Mbps) • 13 (116 Mbps) • 14 (130 Mbps) • 15 (144 Mbps)
enable	Enables this configuration.
disable	Disables this configuration.

Command Default

None.

Examples

This example shows how to specify MCS rates:

```
> config 802.11a 11nsupport mcs tx 5 enable
```

Related Commands

config 802.11 11nsupport
config wlan wmm required
config 802.11 11nsupport a-mpdu tx priority
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport rifs

To configure the Reduced Interframe Space (RIFS) between data frames and its acknowledgment, use the **config 802.11 11nsupport rifs** command.

config 802.11 {a | b} 11nsupport rifs {enable | disable}

Syntax Description

enable	Enables RIFS for the 802.11 network.
disable	Disables RIFS for the 802.11 network.

Command Default

None.

Examples

This example shows how to enable RIFS:

```
> config 802.11a 11nsupport rifs enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 beacon period

To change the beacon period globally for an 802.11a, 802.11b, or other supported 802.11 network, use the **config 802.11 beacon period** command.

config 802.11 {a | b} beacon period *time_units*



Note

Disable the 802.11 network before using this command. See the “Usage Guidelines” section.

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>time_units</i>	Beacon interval in time units (TU). One TU is 1024 microseconds.

Command Default

None.

Usage Guidelines

In Cisco wireless LAN solution 802.11 networks, all Cisco lightweight access point wireless LANs broadcast a beacon at regular intervals. This beacon notifies clients that the 802.11a service is available and allows the clients to synchronize with the lightweight access point.

Before you change the beacon period, make sure that you have disabled the 802.11 network by using the **config 802.11 disable** command. After changing the beacon period, enable the 802.11 network by using the **config 802.11 enable** command.

Examples

This example shows how to configure an 802.11a network for a beacon period of 120 time units:

```
> config 802.11 beacon period 120
```

Related Commands

show 802.11a
config 802.11b beaconperiod
config 802.11a disable
config 802.11a enable

config 802.11 cac defaults

To configure the default Call Admission Control (CAC) parameters for the 802.11a and 802.11b/g network, use the **config 802.11 cac defaults** command.

config 802.11 {a | b} cac defaults

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config command**.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the default CAC parameters for the 802.11a network:

```
> config 802.11 cac defaults
```

Related Commands

```
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
```

```
config 802.11 cac media-stream  
config 802.11 cac multimedia  
config 802.11 cac video cac-method  
debug cac
```

config 802.11 cac video acm

To enable or disable video Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac video acm** command.

config 802.11 {a | b} cac video acm {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables video CAC settings.
disable	Disables video CAC settings.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable**, or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the video CAC for the 802.11a network:

```
> config 802.11 cac video acm enable
```

This example shows how to disable the video CAC for the 802.11b network:

```
> config 802.11 cac video acm disable
```

Related Commands

config 802.11 cac video max-bandwidth
config 802.11 cac video roam-bandwidth
config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video cac-method

To configure the Call Admission Control (CAC) method for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video cac-method** command.

config 802.11 {a | b} cac video cac-method {static | load-based}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
static	Enables the static CAC method for video applications on the 802.11a or 802.11b/g network. Static or bandwidth-based CAC enables the client to specify how much bandwidth or shared medium time is required to accept a new video request and in turn enables the access point to determine whether it is capable of accommodating the request.
load-based	Enables the load-based CAC method for video applications on the 802.11a or 802.11b/g network. Load-based or dynamic CAC incorporates a measurement scheme that takes into account the bandwidth consumed by all traffic types from itself, from co-channel access points, and by colocated channel interference. Load-based CAC also covers the additional bandwidth consumption results from PHY and channel impairment. The access point admits a new call only if the channel has enough unused bandwidth to support that call. Load-based CAC is not supported if SIP-CAC is enabled.

Command Default

Static.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Video CAC consists of two parts: Unicast Video-CAC and MC2UC CAC. If you need only Unicast Video-CAC, you must configure only static mode. If you need only MC2UC CAC, you must configure Static or Load-based CAC. Load-based CAC is not supported if SIP-CAC is enabled.

Examples

This example shows how to enable the static CAC method for video applications on the 802.11a network:

```
> config 802.11 cac video cac-method static
```

Related Commands

```
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac media-stream
config 802.11 cac multimedia
debug cac
```

config 802.11 cac video load-based

To enable or disable load-based Call Admission Control (CAC) for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video load-based** command.

config 802.11 {a | b} cac video load-based {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables load-based CAC for video applications on the 802.11a or 802.11b/g network. Load-based or dynamic CAC incorporates a measurement scheme that takes into account the bandwidth consumed by all traffic types from itself, from co-channel access points, and by collocated channel interference. Load-based CAC also covers the additional bandwidth consumption results from PHY and channel impairment. The access point admits a new call only if the channel has enough unused bandwidth to support that call.
disable	Disables load-based CAC method for video applications on the 802.11a or 802.11b/g network.

Command Default

Disabled.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Video CAC consists of two parts: Unicast Video-CAC and MC2UC CAC. If you need only Unicast Video-CAC, you must configure only static mode. If you need only MC2UC CAC, you must configure Static or Load-based CAC. Load-based CAC is not supported if SIP-CAC is enabled.

**Note**

Load-based CAC is not supported if SIP-CAC is enabled.

Examples

This example shows how to enable load-based CAC method for video applications on the 802.11a network:

```
> config 802.11 cac video load-based enable
```

Related Commands

show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac media-stream
config 802.11 cac multimedia
config 802.11 cac video cac-method
debug cac

config 802.11 cac video max-bandwidth

To set the percentage of the maximum bandwidth allocated to clients for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video max-bandwidth** command.

config 802.11 {a | b} cac video max-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. Once the client reaches the value specified, the access point rejects new calls on this network.



Note

If this parameter is set to zero (0), the controller assumes that you do not want to allocate any bandwidth and allows all bandwidth requests.

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable**, or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth for video applications on the selected radio band:

```
> config 802.11 cac video max-bandwidth 50
```

Related Commands

config 802.11 cac video acm

config 802.11 cac video roam-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice roam-bandwidth

config 802.11 cac media-stream

To configure media stream Call Admission Control (CAC) voice and video quality parameters for 802.11a and 802.11b networks, use the **config 802.11 cac media-stream** command.

config 802.11 {a | b} cac media-stream multicast-direct {max-retry-percent *retry-percentage* | min-client-rate *dot11-rate*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
multicast-direct	Configures CAC parameters for multicast-direct media streams.
max-retry-percent	Configures the percentage of maximum retries that are allowed for multicast-direct media streams.
<i>retry-percentage</i>	Percentage of maximum retries that are allowed for multicast-direct media streams.
min-client-rate	Configures the minimum transmission data rate to the client for multicast-direct media streams.
<i>dot11-rate</i>	Minimum transmission data rate to the client for multicast-direct media streams. Rate in kbps at which the client can operate. If the transmission data rate is below this rate, either the video will not start or the client may be classified as a bad client. The bad client video can be demoted for better effort QoS or subject to denial. The available data rates are 6000, 9000, 12000, 18000, 24000, 36000, 48000, 54000, and 11n rates.

Command Default

The default value for the maximum retry percent is 80. If it exceeds 80, either the video will not start or the client might be classified as a bad client. The bad client video will be demoted for better effort QoS or is subject to denial.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.

- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the maximum retry percent for multicast-direct media streams as 90 on a 802.11a network:

```
> config 802.11 cac media-stream multicast-direct max-retry-percent 90
```

Related Commands

```
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac multimedia
debug cac
```

config 802.11 cac multimedia

To configure the CAC media voice and video quality parameters for 802.11a and 802.11b networks, use the **config 802.11 cac multimedia** command.

config 802.11 {a | b} cac multimedia max-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
max-bandwidth	Configures the percentage of maximum bandwidth allocated to Wi-Fi Multimedia (WMM) clients for voice and video applications on the 802.11a or 802.11b/g network.
<i>bandwidth</i>	Percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a or 802.11b/g network. Once the client reaches the specified value, the access point rejects new calls on this radio band. The range is from 5 to 85%.

Command Default

The default value is 85%.

Usage Guidelines

Call Admission Control (CAC) commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a network:

```
> config 802.11 cac multimedia max-bandwidth 80
```

Related Commands

show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
debug cac

config 802.11 cac video roam-bandwidth

To configure the percentage of the maximum allocated bandwidth reserved for roaming video clients on the 802.11a or 802.11b/g network, use the **config 802.11 cac video roam-bandwidth** command.

config 802.11 {a | b} cac video roam-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The controller reserves the specified bandwidth from the maximum allocated bandwidth for roaming video clients.



Note

If this parameter is set to zero (0), the controller assumes that you do not want to do any bandwidth allocation and, therefore, allows all bandwidth requests.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth reserved for roaming video clients on the selected radio band:

```
> config 802.11 cac video roam-bandwidth 10
```

Related Commands

config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video max-bandwidth

config 802.11 cac video acm

config 802.11 cac video cac-method

config 802.11 cac video sip

config 802.11 cac video load-based

config 802.11 cac video sip

To enable or disable video Call Admission Control (CAC) for nontraffic specifications (TSPEC) SIP clients using video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video sip** command.

config 802.11 {a | b} cac video sip {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables video CAC for non-TSPEC SIP clients using video applications on the 802.11a or 802.11b/g network. When you enable video CAC for non-TSPEC SIP clients, you can use applications like Facetime and CIUS video calls.
disable	Disables video CAC for non-TSPEC SIP clients using video applications on the 802.11a or 802.11b/g network.

Command Default

None.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.
- Enable call snooping on the WLAN on which the SIP client is present by entering the **config wlan call-snoop enable wlan_id** command.

Examples

This example shows how to enable video CAC for non-TSPEC SIP clients using video applications on the 802.11a network:

```
> config 802.11 cac video sip enable
```


Related Commands

config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video max-bandwidth

config 802.11 cac video acm

config 802.11 cac video cac-method

config 802.11 cac video load-based

config 802.11 cac video roam-bandwidth

config 802.11 cac video tspec-inactivity-timeout

To process or ignore the Call Admission Control (CAC) Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac video tspec-inactivity-timeout** command.

config 802.11 {a | b} cac video tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
ab	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to process the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout enable
```

This example shows how to ignore the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout ignore
```

Related Commands

config 802.11 cac video acm

config 802.11 cac video max-bandwidth

config 802.11 cac video roam-bandwidth

config 802.11 cac voice acm

To enable or disable bandwidth-based voice Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice acm** command.

config 802.11 {a | b} cac voice acm {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the bandwidth-based CAC.
disable	Disables the bandwidth-based CAC.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the bandwidth-based CAC:

```
> config 802.11c cac voice acm enable
```

This example shows how to disable the bandwidth-based CAC:

```
> config 802.11b cac voice acm disable
```

Related Commands

config 802.11 cac video acm

config 802.11 cac voice max-bandwidth

To set the percentage of the maximum bandwidth allocated to clients for voice applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac voice max-bandwidth** command.

config 802.11 {a | b} cac voice max-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. Once the client reaches the value specified, the access point rejects new calls on this network.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth for voice applications on the selected radio band:

```
> config 802.11a cac voice max-bandwidth 50
```

Related Commands

config 802.11 cac voice roam-bandwidth
config 802.11 cac voice stream-size
config 802.11 exp-bwreq
config 802.11 tsm

config wlan save
show wlan
show wlan summary
config 802.11 cac voice tspec-inactivity-timeout
config 802.11 cac voice load-based
config 802.11 cac video acm

config 802.11 cac voice roam-bandwidth

To configure the percentage of the Call Admission Control (CAC) maximum allocated bandwidth reserved for roaming voice clients on the 802.11a or 802.11b/g network, use the **config 802.11 cac voice roam-bandwidth** command.

config 802.11 {a | b} cac voice roam-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 0 to 85%.

Command Default

85%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. The controller reserves the specified bandwidth from the maximum allocated bandwidth for roaming voice clients.



Note

If this parameter is set to zero (0), the controller assumes you do not want to allocate any bandwidth and therefore allows all bandwidth requests.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming voice clients on the selected radio band:

```
> config 802.11 cac voice roam-bandwidth 10
```

Related Commands

config 802.11 cac voice acm

config 802.11cac voice max-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice tspec-inactivity-timeout

To process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac voice tspec-inactivity-timeout** command.

config 802.11 {a | b} cac voice tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
> config 802.11 cac voice tspec-inactivity-timeout enable
```

Related Commands

config 802.11 cac voice load-based
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice acm

config 802.11cac voice max-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice load-based

To enable or disable load-based Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice load-based** command.

config 802.11 {a | b} cac voice load-based {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables load-based CAC.
disable	Disables load-based CAC.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id command**.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config command**.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the voice load-based CAC parameters:

```
> config 802.11a cac voice load-based enable
```

This example shows how to disable the voice load-based CAC parameters:

```
> config 802.11a cac voice load-based disable
```

Related Commands

config 802.11 cac voice tspec-inactivity-timeout

config 802.11 cac video max-bandwidth

config 802.11 cac video acm

config 802.11 cac voice stream-size

config 802.11 cac voice max-calls



Note

Do not use the **config 802.11 cac voice max-calls** command if the SIP call snooping feature is disabled and if the SIP based Call Admission Control (CAC) requirements are not met.

To configure the maximum number of voice call supported by the radio, use the **config 802.11 cac voice max-calls** command.

config 802.11 {a | b} cac voice max-calls *number*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>number</i>	Number of calls to be allowed per radio.

Command Default

0, which means that there is no maximum limit check for the number of calls.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the maximum number of voice calls supported by radio:

```
> config 802.11 cac voice max-calls 10
```

Related Commands

config 802.11 cac voice roam-bandwidth
config 802.11 cac voice stream-size
config 802.11 exp-bwreq

config 802.11 cac voice tspec-inactivity-timeout

config 802.11 cac voice load-based

config 802.11 cac video acm

config 802.11 cac voice sip bandwidth



Note

SIP bandwidth and sample intervals are used to compute per call bandwidth for the SIP-based Call Admission Control (CAC).

To configure the bandwidth that is required per call for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice sip bandwidth** command.

config 802.11 {a | b} cac voice sip bandwidth *bw_kbps* sample-interval *number_msecs*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bw_kbps</i>	Bandwidth in kbps.
sample-interval	Specifies the packetization interval for SIP codec.
<i>number_msecs</i>	Packetization sample interval in msecs. The sample interval for SIP codec is 20 seconds.

Command Default

None.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the bandwidth and voice packetization interval for a SIP codec:

```
> config 802.11 cac voice sip bandwidth 10 sample-interval 40
```

Related Commands

config 802.11 cac voice acm
config 802.11 cac voice load-based
config 802.11 cac voice max-bandwidth
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice tspec-inactivity-timeout
config 802.11 exp-bwreq

config 802.11 cac voice sip codec

To configure the Call Admission Control (CAC) codec name and sample interval as parameters and to calculate the required bandwidth per call for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice sip codec** command.

config 802.11 {a | b} cac voice sip codec {g711 | g729} sample-interval *number_msecs*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
g711	Specifies CAC parameters for the SIP G711 codec.
g729	Specifies CAC parameters for the SIP G729 codec.
sample-interval	Specifies the packetization interval for SIP codec.
<i>number_msecs</i>	Packetization interval in msecs. The sample interval for SIP codec value is 20 seconds.

Command Default

g711.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the codec name and sample interval as parameters for SIP G711 codec:

```
> config 802.11a cac voice sip codec g711 sample-interval 40
```

This example shows how to configure the codec name and sample interval as parameters for SIP G729 codec:

```
> config 802.11a cac voice sip codec g729 sample-interval 40
```

Related Commands

config 802.11 cac voice acm
config 802.11 cac voice load-based
config 802.11 cac voice max-bandwidth
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice tspec-inactivity-timeout
config 802.11 exp-bwreq

config 802.11 cac voice stream-size

To configure the number of aggregated voice Wi-Fi Multimedia (WMM) traffic specification (TSPEC) streams at a specified data rate for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice stream-size** command.

config 802.11 {a | b} cac voice stream-size *stream_size number mean_datarate max-streams mean_datarate*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
stream-size	Configures the maximum data rate for the stream.
<i>stream_size</i>	Range of stream size is between 84000 and 92100.
<i>number</i>	Number (1 to 5) of voice streams.
mean_datarate	Configures the mean data rate.
max-streams	Configures the mean data rate of a voice stream.
<i>mean_datarate</i>	Mean data rate (84 to 91.2 kbps) of a voice stream.

Command Default

The default number of streams is 2 and the mean data rate of a stream is 84 kbps.

Usage Guidelines

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the number of aggregated voice traffic specifications stream with the stream size 5 and the mean data rate of 85000 kbps:

```
> config 802.11 cac voice stream-size 5 max-streams size 85
```

Related Commands

```
config 802.11 cac voice acm  
config 802.11 cac voice load-based  
config 802.11 cac voice max-bandwidth  
config 802.11 cac voice roam-bandwidth  
config 802.11 cac voice tspec-inactivity-timeout  
config 802.11 exp-bwreq
```

config 802.11 disable

To disable radio transmission for an entire 802.11 network or for an individual Cisco radio, use the **config 802.11 disable** command.

config 802.11 {a | b} disable {network | cisco_ap}

Syntax Description

a	Configures the 802.11a radio.
b	Specifies the 802.11b/g network.
network	Disables transmission for the entire 802.11a network.
<i>cisco_ap</i>	Individual Cisco lightweight access point radio.

Command Default

The transmission is enabled for the entire network by default.

Usage Guidelines

Note

You must use this command to disable the network before using many config 802.11 commands.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to disable the entire 802.11a network:

```
> config 802.11a disable network
```

This example shows how to disable access point AP01 802.11b transmissions:

```
> config 802.11b disable AP01
```

Related Commands

show sysinfo
show 802.11a
config 802.11a enable
config 802.11b disable
config 802.11b enable
config 802.11a beaconperiod

config 802.11 dtpc

To enable or disable the Dynamic Transmit Power Control (DTPC) setting for an 802.11 network, use the **config 802.11 dtpc** command.

config 802.11 {a | b} dtpc {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the support for this command.
disable	Disables the support for this command.

Command Default

Enabled.

Examples

This example shows how to disable DTPC for an 802.11a network:

```
> config 802.11a dtpc disable
```

Related Commands

show 802.11a
config 802.11a beaconperiod
config 802.11a disable
config 802.11a enable

config 802.11 enable

To enable radio transmission for an entire 802.11 network or for an individual Cisco radio, use the **config 802.11 enable** command.

config 802.11 {a | b} enable {network | cisco_ap}

Syntax Description

a	Configures the 802.11a radio
b	Specifies the 802.11b/g network.
network	Disables transmission for the entire 802.11a network.
<i>cisco_ap</i>	Individual Cisco lightweight access point radio.

Command Default

The transmission is enabled for the entire network by default.

Usage Guidelines

Note

Use this command with the **config 802.11 disable** command when configuring 802.11 settings.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to enable radio transmission for the entire 802.11a network:

```
> config 802.11a enable network
```

This example shows how to enable radio transmission for AP1 on an 802.11b network:

```
> config 802.11b enable AP1
```

Related Commands

```
show sysinfo show 802.11a
config wlan radio
config 802.11a disable
config 802.11b disable
config 802.11b enable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
```

config 802.11 exp-bwreq

To enable or disable the Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature for an 802.11 radio, use the **config 802.11 exp-bwreq** command.

config 802.11 {a | b} exp-bwreq {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the expedited bandwidth request feature.
disable	Disables the expedited bandwidth request feature.

Command Default

The expedited bandwidth request feature is disabled by default.

Usage Guidelines

When this command is enabled, the controller configures all joining access points for this feature.

Examples

This example shows how to enable the CCX expedited bandwidth settings:

```
> config 802.11a exp-bwreq enable
Cannot change Exp Bw Req mode while 802.11a network is operational.
```

This example shows how to disable the CCX expedited bandwidth settings:

```
> config 802.11a exp-bwreq disable
```

Related Commands

show 802.11a
show ap stats 802.11a

config 802.11 fragmentation

To configure the fragmentation threshold on an 802.11 network, use the **config 802.11 fragmentation** command.

config 802.11 {a | b} fragmentation *threshold*



Note

This command can only be used when the network is disabled using the **config 802.11 disable** command.

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>threshold</i>	Number between 256 and 2346 bytes (inclusive).

Command Default

None.

Examples

This example shows how to configure the fragmentation threshold on an 802.11a network with the threshold number of 6500 bytes:

```
> config 802.11a fragmentation 6500
```

Related Commands

config 802.11b fragmentation
show 802.11b
show ap auto-rtf

config 802.11 l2roam rf-params

To configure 802.11a or 802.11b/g Layer 2 client roaming parameters, use the **config 802.11 l2roam rf-params** command.

config 802.11 {a | b} l2roam rf-params {default | custom min_rssi roam_hyst scan_thresh trans_time}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
default	Restores Layer 2 client roaming RF parameters to default values.
custom	Configures custom Layer 2 client roaming RF parameters.
<i>min_rssi</i>	Minimum received signal strength indicator (RSSI) that is required for the client to associate to the access point. If the client's average received signal power dips below this threshold, reliable communication is usually impossible. Clients must already have found and roamed to another access point with a stronger signal before the minimum RSSI value is reached. The valid range is –80 to –90 dBm, and the default value is –85 dBm.
<i>roam_hyst</i>	How much greater the signal strength of a neighboring access point must be in order for the client to roam to it. This parameter is intended to reduce the amount of roaming between access points if the client is physically located on or near the border between the two access points. The valid range is 2 to 4 dB, and the default value is 2 dB.
<i>scan_thresh</i>	Minimum RSSI that is allowed before the client should roam to a better access point. When the RSSI drops below the specified value, the client must be able to roam to a better access point within the specified transition time. This parameter also provides a power-save method to minimize the time that the client spends in active or passive scanning. For example, the client can scan slowly when the RSSI is above the threshold and scan more rapidly when the RSSI is below the threshold. The valid range is –70 to –77 dBm, and the default value is –72 dBm.
<i>trans_time</i>	Maximum time allowed for the client to detect a suitable neighboring access point to roam to and to complete the roam, whenever the RSSI from the client's associated access point is below the scan threshold. The valid range is 1 to 10 seconds, and the default value is 5 seconds.
Note For high-speed client roaming applications in outdoor mesh environments, we recommend that you set the transition time to 1 second.	

Command Default

<i>min_rssi</i>	-85
<i>roam_hyst</i>	2
<i>scan_thresh</i>	-72
<i>trans_time</i>	5

Usage Guidelines

For high-speed client roaming applications in outdoor mesh environments, we recommend that you set the *trans_time* to 1 second.

Examples

This example shows how to configure custom Layer 2 client roaming parameters on an 802.11a network:

```
> config 802.11 l2roam rf-params custom -80 2 -70 7
```

Related Commands

show advanced 802.11 l2roam

show l2tp

config 802.11 max-clients

To configure the maximum number of clients per access point, use the **config 802.11 max-clients** command.

config 802.11 {a | b} max-clients *max-clients*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
max-clients	Configures the maximum number of client connections per access point.
<i>max-clients</i>	Maximum number of client connections per access point. The range is from 1 to 200.

Command Default

None.

Examples

This example shows how to set the maximum number of clients at 22:

```
> config 802.11 max-clients 22
```

Related Commands

show ap config 802.11a
config 802.11b rate

config 802.11 multicast data-rate

To configure the minimum multicast data rate, use the **config 802.11 multicast data-rate** command.

config 802.11 {a | b} multicast data-rate *data_rate* [**ap** *ap_name* | **default**]

Syntax Description

<i>data_rate</i>	Minimum multicast data rates. The options are 6, 9, 12, 18, 24, 36, 48, 54. Enter 0 to specify that APs will dynamically adjust the number of the buffer allocated for multicast.
<i>ap_name</i>	Specific AP radio in this data rate.
default	Configures all APs radio in this data rate.

Command Default

The default is 0 where the configuration is disabled and the multicast rate is the lowest mandatory data rate and unicast client data rate.

Usage Guidelines

When you configure the data rate without the AP name or **default** keyword, you globally reset all the APs to the new value and update the controller global default with this new data rate value. If you configure the data rate with **default** keyword, you only update the controller global default value and do not reset the value of the APs that are already joined to the controller. The APs that join the controller after the new data rate value is set receives the new data rate value.

Examples

This example shows how to configure minimum multicast data rate settings:

```
> config 802.11 multicast data-rate 12
```

config 802.11 rate

To set mandatory and supported operational data rates for an 802.11 network, use the **config 802.11 rate** command.

config 802.11 {a | b} rate {disabled | mandatory | supported} rate

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
disabled	Disables a specific data rate.
mandatory	Specifies that a client supports the data rate in order to use the network.
supported	Specifies to allow any associated client that supports the data rate to use the network.
<i>rate</i>	Rate value of 6, 9, 12, 18, 24, 36, 48, or 54 Mbps.

Command Default

None.

Usage Guidelines

The data rates set with this command are negotiated between the client and the Cisco wireless LAN controller. If the data rate is set to **mandatory**, the client must support it in order to use the network. If a data rate is set as **supported** by the Cisco wireless LAN controller, any associated client that also supports that rate may communicate with the Cisco lightweight access point using that rate. It is not required that a client is able to use all the rates marked **supported** in order to associate.

Examples

This example shows how to set the 802.11b transmission at a mandatory rate at 12 Mbps:

```
> config 802.11b rate mandatory 12
```

Related Commands

show ap config 802.11a

config 802.11b rate

config 802.11 tsm

To enable or disable the video Traffic Stream Metric (TSM) option for the 802.11a or 802.11b/g network, use the **config 802.11 tsm** command.

config 802.11 {a | b} tsm {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the video TSM settings.
disable	Disables the video TSM settings.

Command Default

Disabled.

Examples

This example shows how to enable the video TSM option for the 802.11b/g network:

```
> config 802.11b tsm enable
```

This example shows how to disable the video TSM option for the 802.11b/g network:

```
> config 802.11b tsm disable
```

Related Commands

show ap stats
show client tsm

config advanced 802.11 7920VSIEConfig

To configure the Cisco unified wireless IP phone 7920 VISE parameters, use the **config advanced 802.11 7920VSIEConfig** command.

config advanced 802.11 {a | b} 7920VSIEConfig {call-admission-limit *limit* | G711-CU-Quantum *quantum*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
call-admission-limit	Configures the call admission limit for the 7920s.
G711-CU-Quantum	Configures the value supplied by the infrastructure indicating the current number of channel utilization units that would be used by a single G.711-20ms call.
<i>limit</i>	Call admission limit (from 0 to 255). The default value is 105.
<i>quantum</i>	G711 quantum value. The default value is 15.

Command Default

None.

Examples

This example shows how to configure the call admission limit for 7920 VISE parameters:

```
> config advanced 802.11 7920VSIEConfig call-admission-limit 4
```


config advanced 802.11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 802.11a network, use the **config advanced 802.11 edca-parameters** command.

config advanced 802.11 {a | b} edca-parameters {wmm-default | svp-voice | optimized-voice | optimized-video-voice | custom-voice}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.
svp-voice	Enables Spectralink voice priority parameters. Choose this option if Spectralink phones are deployed on your network to improve the quality of calls.
optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than Spectralink are deployed on your network.
optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network. Note If you deploy video services, admission control (ACM) must be disabled.
custom-voice	Enables custom voice EDCA parameters for 802.11a. The EDCA parameters under this option also match the 6.0 WMM EDCA parameters when this profile is applied.

Command Default

wmm-default

Examples

This example shows how to enable Spectralink voice priority parameters:

```
> config advanced 802.11 edca-parameters svp-voice
```

Related Commands

show 802.11a
config advanced 802.11b edca-parameters

config advanced fastpath fastcache

To configure the fastpath fast cache control, use the **config advanced fastpath fastcache** command.

config advanced fastpath fastcache {enable | disable}

Syntax Description

enable	Enables the fastpath fast cache control.
disable	Disables the fastpath fast cache control.

Command Default

None.

Examples

This example shows how to enable the fastpath fast cache control:

```
> config advanced fastpath fastcache enable
```

Related Commands

config advanced fastpath pkt-capture

config advanced fastpath pkt-capture

To configure the fastpath packet capture, use the **config advanced fastpath pkt-capture** command.

config advanced fastpath pkt-capture {enable | disable}

Syntax Description

enable	Enables the fastpath packet capture.
disable	Disables the fastpath packet capture.

Command Default

None.

Examples

This example shows how to enable the fastpath packet capture:

```
> config advanced fastpath pkt-capture enable
```

Related Commands

config advanced fastpath fastcache

config advanced sip-preferred-call-no

To configure voice prioritization, use the **config advanced sip-preferred-call-no** command.

config advanced sip-preferred-call-no *call_index* {*call_number* | **none**}

Syntax Description

<i>call_index</i>	Call index with valid values between 1 and 6.
<i>call_number</i>	Preferred call number that can contain up to 27 characters.
none	Deletes the preferred call set for the specified index.

Command Default

None.

Usage Guidelines

Before you configure voice prioritization, you must complete the following prerequisites:

- Set the voice to the platinum QoS level by entering the **config wlan qos wlan-id platinum** command.
- Enable the admission control (ACM) to this radio by entering the **config 802.11 {a | b} cac {voice | video} acm enable** command.
- Enable the call-snooping feature for a particular WLAN by entering the **config wlan call-snoop enable wlan-id** command.

To view statistics about preferred calls, enter the **show ap stats {802.11 {a | b} | wlan} cisco_ap** command.

Examples

This example shows how to add a new preferred call for index 2:

```
> config advanced sip-preferred-call-no 2 0123456789
```

Related Commands

config wlan qos
config 802.11 cac video acm
config 802.11 cac voice acm
config wlan call-snoop
show ap stats

config advanced sip-snooping-ports

To configure call snooping ports, use the **config advanced sip-snooping-ports** command.

config advanced sip-snooping-ports *start_port end_port*

Syntax Description

<i>start_port</i>	Starting port for call snooping. The range is from 0 to 65535.
<i>end_port</i>	Ending port for call snooping. The range is from 0 to 65535.

Usage Guidelines

If you need only a single port for call snooping, configure the start and end port with the same number. The port used by the CIUS tablet is 5060 and the port range used by Facetime is from 16384 to 16402.

Examples

This example shows how to configure the call snooping ports:

```
> config advanced sip-snooping-ports 4000 4500
```

Related Commands

show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video sip
config 802.11 cac voice sip
show advanced sip-preferred-call-no
show advanced sip-snooping-ports
debug cac

config avc profile create

To create a new Application Visibility and Control (AVC) profile, use the **config avc profile create** command.

config avc profile *profile_name* **create**

Syntax Description

<i>profile_name</i>	Name of the AVC profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
create	Creates a new AVC profile.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

You can configure up to 16 AVC profiles on a controller and associate an AVC profile with multiple WLANs. You can configure only one AVC profile per WLAN and each AVC profile can have up to 32 rules. Each rule states a Mark or Drop action for an application, which allows you to configure up to 32 application actions per WLAN.

Examples

The following example shows how to create a new AVC profile:

```
Device > config avc profile avcprofile1 create
```

Related Commands

config avc profile delete
config avc profile rule
config wlan avc
show avc profile
show avc applications
show avc statistics
debug avc error
debug avc events

config avc profile delete

To delete an Application Visibility and Control (AVC) profile, use the **config avc profile delete** command.

config avc profile *profile_name* **delete**

Syntax Description

<i>profile_name</i>	Name of the AVC profile.
delete	Deletes an AVC profile.

Command Default

The AVC profile is not deleted.

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following example shows how to delete an AVC profile.

```
Device > config avc profile avcprofile1 delete
```

Related Commands

config avc profile create
config avc profile rule
config wlan avc
show avc profile summary
show avc profile detailed
debug avc error
debug avc events

config avc profile rule

To configure a rule for an Application Visibility and Control (AVC) profile, use the **config avc profile rule** command.

config avc profile *profile_name* **rule** {**add** | **remove**} **application** *application_name* {**drop** | **mark** *dscp*}

Syntax Description

<i>profile_name</i>	Name of the AVC profile.
rule	Configures a rule for the AVC profile.
add	Creates a rule for the AVC profile.
remove	Deletes a rule for the AVC profile.
application	Specifies the application that has to be dropped or marked.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
drop	Drops the upstream and downstream packets that correspond to the chosen application.
mark	Marks the upstream and downstream packets that correspond to the chosen application with the Differentiated Services Code Point (DSCP) value that you specify in the drop-down list. The DSCP value helps you provide differentiated services based on the QoS levels.
<i>dscp</i>	Packet header code that is used to define the QoS across the Internet. The range is from 0 to 63.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following example shows how to configure a rule for an AVC profile.

```
Device > config avc profile avcprofile1 rule add application gmail mark 10
```

Related Commands

config avc profile delete
config avc profile create

config wlan avc
show avc profile
show avc applications
show avc statistics
debug avc error
debug avc events

config band-select cycle-count

To set the band select probe cycle count, use the **config band-select cycle-count** command.

config band-select cycle-count *count*

Syntax Description

count

Value for the cycle count between 1 to 10.

Command Default

None.

Examples

This example shows how to set the probe cycle count for band select to 8:

```
> config band-select cycle-count 8
```

Related Commands

config band-select cycle-threshold

config band-select expire

config band-select client-rssi

config band-select cycle-threshold

To set the time threshold for a new scanning cycle, use the **config band-select cycle-threshold** command.

config band-select cycle-threshold *threshold*

Syntax Description	
<i>threshold</i>	Value for the cycle threshold between 1 and 1000 milliseconds.

Command Default None.

Examples This example shows how to set the time threshold for a new scanning cycle with threshold value of 700 milliseconds:

```
> config band-select cycle-threshold 700
```

Related Commands

- config band-select cycle-count
- config band-select expire
- config band-select client-rssi

config band-select expire

To set the entry expire for band select, use the **config band-select expire** command.

config band-select expire {**suppression** | **dual-band**} *seconds*

Syntax Description

suppression	Sets the suppression expire to the band select.
dual-band	Sets the dual band expire to the band select.
<i>seconds</i>	• Value for suppression between 10 to 200 seconds. • Value for a dual-band between 10 to 300 seconds.

Command Default

None.

Examples

This example shows how to set the suppression expire to 70 seconds:

```
> config band-select expire suppression 70
```

Related Commands

config band-select cycle-threshold
config band-select client-rssi
config band-select cycle-count

config band-select client-rssi

To set the client received signal strength indicator (RSSI) threshold for band select, use the **config band-select client-rssi** command.

config band-select client-rssi *rssi*

Syntax Description

rssi

Minimum dBm of a client RSSI to respond to probe between 20 and 90.

Command Default

None.

Examples

This example shows how to set the RSSI threshold for band select to 70:

```
> config band-select client-rssi 70
```

Related Commands

config band-select cycle-threshold

config band-select expire

config band-select cycle-count

config boot

To change a Cisco wireless LAN controller boot option, use the **config boot** command.

config boot {primary | backup}

Syntax Description

primary	Sets the primary image as active.
backup	Sets the backup image as active.

Command Default

Primary.

Usage Guidelines

Each Cisco wireless LAN controller can boot off the primary, last-loaded operating system image (OS) or boot off the backup, earlier-loaded OS image.

Examples

This example shows how to set the primary image as active so that the LAN controller can boot off the primary, last loaded image:

```
> config boot primary
```

This example shows how to set the backup image as active so that the LAN controller can boot off the backup, earlier loaded OS image:

```
> config boot backup
```

Related Commands

show boot

config cdp

To configure the Cisco Discovery Protocol (CDP) on the controller, use the **config cdp** command.

config cdp {**enable** | **disable** | **advertise-v2** {**enable** | **disable**} | **timer***seconds* | **holdtime** *holdtime_interval*}

Syntax Description

enable	Enables CDP on the controller.
disable	Disables CDP on the controller.
advertise-v2	Configures CDP version 2 advertisements.
timer	Configures the interval at which CDP messages are to be generated.
<i>seconds</i>	Time interval at which CDP messages are to be generated. The range is from 5 to 254 seconds.
holdtime	Configures the amount of time to be advertised as the time-to-live value in generated CDP packets.
<i>holdtime_interval</i>	Maximum hold timer value. The range is from 10 to 255 seconds.

Command Default

The default value for CDP timer is 60 seconds.

The default value for CDP holdtime is 180 seconds.

Examples

This example shows how to configure the CDP maximum hold timer to 150 seconds:

```
> config cdp timer 150
```

Related Commands

config ap cdp
show cdp
show ap cdp

config certificate

To configure Secure Sockets Layer (SSL) certificates, use the **config certificate** command.

config certificate {generate {webadmin | webauth} | compatibility {on | off}}

Syntax Description

generate	Specifies authentication certificate generation settings.
webadmin	Generates a new web administration certificate.
webauth	Generates a new web authentication certificate.
compatibility	Specifies the compatibility mode for inter-Cisco wireless LAN controller IPsec settings.
on	Enables the compatibility mode.
off	Disables the compatibility mode.

Command Default

None.

Examples

This example shows how to generate a new web administration SSL certificate:

```
> config certificate generate webadmin
Creating a certificate may take some time. Do you wish to continue? (y/n)
```

This example shows how to configure the compatibility mode for inter-Cisco wireless LAN controller IPsec settings:

```
> config certificate compatibility
```

Related Commands

config certificate lsc
show certificate compatibility
show certificate lsc
show certificate summary
show local-auth certificates

config certificate lsc

To configure Locally Significant Certificate (LSC) certificates, use the **config certificate lsc** command.

```
config certificate lsc {enable | disable | ca-server http://url:port/path | ca-cert {add | delete} |
subject-params country state city orgn dept email | other-params keysize} | ap-provision {auth-list {add
| delete} ap_mac | revert-cert retries}
```

Syntax Description

enable	Enables LSC certificates on the controller.
disable	Disables LSC certificates on the controller.
ca-server	Specifies the Certificate Authority (CA) server settings.
<i>http://url:port/path</i>	Domain name or IP address of the CA server.
ca-cert	Specifies CA certificate database settings.
add	Obtains a CA certificate from the CA server and adds it to the controller's certificate database.
delete	Deletes a CA certificate from the controller's certificate database.
subject-params	Specifies the device certificate settings.
<i>country state city orgn dept email</i>	Country, state, city, organization, department, and email of the certificate authority. Note The common name (CN) is generated automatically on the access point using the current MIC/SSC format <i>Cxxxx-MacAddr</i> , where <i>xxxx</i> is the product number.
other-params	Specifies the device certificate key size settings.
<i>keysize</i>	Value from 384 to 2048 (in bits); the default value is 2048.
ap-provision	Specifies the access point provision list settings.
auth-list	Specifies the provision list authorization settings.
<i>ap_mac</i>	MAC address of access point to be added or deleted from the provision list.
revert-cert	Specifies the number of times the access point attempts to join the controller using an LSC before reverting to the default certificate.
<i>retries</i>	Value from 0 to 255; the default value is 3. Note If you set the number of retries to 0 and the access point fails to join the controller using an LSC, the access point does not attempt to join the controller using the default certificate. If you are configuring LSC for the first time, we recommend that you configure a nonzero value.

Command Default

The default value of *keysize* is 2048 bits. The default value of *retries* is 3.

Usage Guidelines

You can configure only one CA server. To configure a different CA server, delete the configured CA server by using the **config certificate lsc ca-server delete** command, and then configure a different CA server.

If you configure an access point provision list, only the access points in the provision list are provisioned when you enable AP provisioning (in Step 8). If you do not configure an access point provision list, all access points with an MIC or SSC certificate that join the controller are LSC provisioned.

Examples

This example shows how to enable the LSC settings:

```
> config certificate lsc enable
```

This example shows how to enable the LSC settings for Certificate Authority (CA) server settings:

```
> config certificate lsc ca-server http://10.0.0.1:8080/caserver
```

This example shows how to add a CA certificate from the CA server and add it to the controller's certificate database:

```
> config certificate lsc ca-cert add
```

This example shows how to configure an LSC certificate with the keysize of 2048 bits:

```
> config certificate lsc keysize 2048
```

Related Commands

config certificate
show certificate compatibility
show certificate lsc
show certificate summary
show local-auth certificates

config certificate ssc

To configure Self Signed Certificates (SSC) certificates, use the **config certificate ssc** command.

config certificate ssc hash validation {enable | disable}

Syntax Description

hash	Configures the SSC hash key.
validation	Configures hash validation of the SSC certificate.
enable	Enables hash validation of the SSC certificate.
disable	Disables hash validation of the SSC certificate.

Command Default

Enabled.

Usage Guidelines

When you enable the SSC hash validation, an AP validates the SSC certificate of the virtual controller. When an AP validates the SSC certificate, it checks if the hash key of the virtual controller matches the hash key stored in its flash. If a match is found, the validation passes and the AP moves to the Run state. If a match is not found, the validation fails and the AP disconnects from the controller and restarts the discovery process. By default, hash validation is enabled. Hence, an AP must have the virtual controller hash key in its flash before associating with the virtual controller. If you disable hash validation of the SSC certificate, the AP bypasses the hash validation and directly moves to the Run state.

APs can associate with a physical controller, download the hash keys and then associate with a virtual controller. If the AP is associated to a physical controller and if hash validation is disabled, it joins any virtual controller without hash validation.

Examples

This example shows how to enable hash validation of the SSC certificate:

```
> config certificate ssc hash validation enable
```

Related Commands

show certificate ssc
show mobility group member
config mobility group member hash
config certificate
show certificate compatibility
show certificate lsc
show certificate summary
show local-auth certificates

config certificate use-device-certificate webadmin

To use a device certificate for web administration, use the **config certificate use-device-certificate webadmin** command.

config certificate use-device-certificate webadmin

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to use a device certificate for web administration:

```
> config certificate use-device-certificate webadmin
Use device certificate for web administration. Do you wish to continue? (y/n) y
Using device certificate for web administration.
Save configuration and restart controller to use new certificate.
```

Related Commands

- config certificate**
- show certificate compatibility**
- show certificate lsc**
- show certificate ssc**
- show certificate summary**
- show local-auth certificates**

config coredump

To enable or disable the controller to generate a core dump file following a crash, use the **config coredump** command.

config coredump {enable | disable}

Syntax Description

enable	Enables the controller to generate a core dump file.
disable	Disables the controller to generate a core dump file.

Command Default

None.

Examples

This example shows how to enable the controller to generate a core dump file following a crash:

```
> config coredump enable
```

Related Commands

config coredump ftp
config coredump username
show coredump summary

config coredump ftp

To automatically upload a controller core dump file to an FTP server after experiencing a crash, use the **config coredump ftp** command.

config coredump ftp *server_ip_address filename*

Syntax Description

<i>server_ip_address</i>	IP address of the FTP server to which the controller sends its core dump file.
<i>filename</i>	Name given to the controller core dump file.

Command Default

None.

Usage Guidelines

The controller must be able to reach the FTP server to use this command.

Examples

This example shows how to configure the controller to upload a core dump file named *core_dump_controller* to an FTP server at network address *192.168.0.13*:

```
> config coredump ftp 192.168.0.13 core_dump_controller
```

Related Commands

config coredump
config coredump username
show coredump summary

config coredump username

To specify the FTP server username and password when uploading a controller core dump file after experiencing a crash, use the **config coredump username** command.

config coredump username *ftp_username* **password** *ftp_password*

Syntax Description

<i>ftp_username</i>	FTP server login username.

<i>ftp_password</i>	FTP server login password.

Command Default

None.

Usage Guidelines

The controller must be able to reach the FTP server to use this command.

Examples

This example shows how to specify a FTP server username of *admin* and password *adminpassword* for the core dump file upload:

```
> config coredump username admin password adminpassword
```

Related Commands

config coredump ftp

config coredump

show coredump summary

config custom-web ext-webauth-mode

To configure external URL web-based client authorization for the custom-web authentication page, use the **config custom-web ext-webauth-mode** command.

config custom-web ext-webauth-mode {enable | disable}

Syntax Description

enable	Enables the external URL web-based client authorization.
disable	Disables the external URL we-based client authentication.

Command Default

None.

Examples

This example shows how to enable the external URL web-based client authorization:

```
> config custom-web ext-webauth-mode enable
```

Related Commands

config custom-web redirectUrl
config custom-web weblogo
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-url show custom-web

config custom-web ext-webauth-url

To configure the complete external web authentication URL for the custom-web authentication page, use the **config custom-web ext-webauth-url** command.

config custom-web ext-webauth-url *URL*

Syntax Description

<i>URL</i>	URL used for web-based client authorization.

Command Default

None.

Examples

This example shows how to configure the complete external web authentication URL `http://www.AuthorizationURL.com/` for the web-based client authorization:

```
> config custom-web ext-webauth-url http://www.AuthorizationURL.com/
```

Related Commands

config custom-web redirectUrl
config custom-web weblogo
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-mode show custom-web

config custom-web ext-webserver

To configure an external web server, use the **config custom-web ext-webserver** command.

config custom-web ext-webserver {**add** *index* *IP_address* | **delete** *index*}

Syntax Description

add	Adds an external web server.
<i>index</i>	Index of the external web server in the list of external web server. The index must be a number between 1 and 20.
<i>IP_address</i>	IP address of the external web server.
delete	Deletes an external web server.

Command Default

None.

Examples

This example shows how to add the index of the external web server 2 to the IP address of the external web server 192.23.32.19:

```
> config custom-web ext-webserver add 2 192.23.32.19
```

Related Commands

config custom-web redirectUrl
config custom-web weblogo
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-mode
config custom-web ext-webauth-url
show custom-web

config custom-web logout-popup

To enable or disable the custom web authentication logout popup, use the **config custom-web logout-popup** command.

config custom-web logout-popup {enable| disable}

Syntax Description

enable	Enables the custom web authentication logout popup. This page appears after a successful login or a redirect of the custom web authentication page.
disable	Disables the custom web authentication logout popup.

Command Default

None.

Examples

This example shows how to disable the custom web authentication logout popup:

```
> config custom-web logout-popup disable
```

Related Commands

config custom-web redirectUrl
config custom-web weblogo
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-url show custom-web

config custom-web redirectUrl

To configure the redirect URL for the custom-web authentication page, use the **config custom-web redirectUrl** command.

config custom-web redirectUrl *URL*

Syntax Description

<i>URL</i>	URL that is redirected to the specified address.

Command Default

None.

Examples

This example shows how to configure the URL that is redirected to abc.com:

```
> config custom-web redirectUrl abc.com
```

Related Commands

- config custom-web weblogo**
- config custom-web webmessage**
- config custom-web webtitle**
- config custom-web ext-webauth-mode**
- config custom-web ext-webauth-url**
- show custom-web**

config custom-web webauth-type

To configure the type of web authentication, use the **config custom-web webauth-type** command.

config custom-web webauth-type {**internal** | **customized** | **external**}

Syntax Description

internal	Configures the web authentication type to internal.
customized	Configures the web authentication type to customized.
external	Configures the web authentication type to external.

Command Default

The default web authentication type is **internal**.

Examples

This example shows how to configure the type of the web authentication type to internal:

```
> config custom-web webauth-type internal
```

Related Commands

config custom-web redirectUrl
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-mode
config custom-web ext-webauth-url
show custom-web

config custom-web weblogo

To configure the web authentication logo for the custom-web authentication page, use the **config custom-web weblogo** command.

config custom-web weblogo {enable | disable}

Syntax Description

enable	Enables the web authentication logo settings.
disable	Enable or disable the web authentication logo settings.

Command Default

None.

Examples

This example shows how to enable the web authentication logo:

```
> config custom-web weblogo enable
```

Related Commands

config custom-web redirectUrl
config custom-web webmessage
config custom-web webtitle
config custom-web ext-webauth-mode
config custom-web ext-webauth-url
show custom-web

config custom-web webmessage

To configure the custom web authentication message text for the custom-web authentication page, use the **config custom-web webmessage** command.

config custom-web webmessage *message*

Syntax Description

<i>message</i>	Message text for web authentication.

Command Default

None.

Examples

This example shows how to configure the message text Thisistheplace for webauthentication:

```
> config custom-web webmessage Thisistheplace
```

Related Commands

- config custom-web redirectUrl**
- config custom-web weblogo**
- config custom-web webtitle**
- config custom-web ext-webauth-mode**
- config custom-web ext-webauth-url**
- show custom-web**

config custom-web webtitle

To configure the web authentication title text for the custom-web authentication page, use the **config custom-web webtitle** command.

config custom-web webtitle *title*

Syntax Description

<i>title</i>	Custom title text for web authentication.

Command Default

None.

Examples

This example shows how to set the custom title text Helpdesk for web authentication:

```
> config custom-web webtitle Helpdesk
```

Related Commands

- config custom-web redirectUrl**
- config custom-web weblogo**
- config custom-web webmessage**
- config custom-web ext-webauth-mode**
- config custom-web ext-webauth-url**
- show custom-web**

config dhcp

To configure the internal DHCP, use the **config dhcp** command.

```
config dhcp {address-pool scope start end | create-scope scope | default-router scope router_1 [router_2] [router_3] | delete-scope scope | disable scope | dns-servers scope dns1 [dns2] [dns3] | domain scope domain | enable scope | lease scope lease_duration | nethbios-name-server scope wins1 [wins2] [wins3] | networkscope network netmask}
```

```
config dhcpopt-82 remote-id {ap_mac | ap_mac:ssid | ap-ethmac | apname:ssid | ap-group-name | flex-group-name | ap-location | apmac-vlan_id | apname-vlan_id | ap-ethmac-ssid}
```

Syntax Description

address-pool <i>scope start end</i>	Configures an address range to allocate. You must specify the scope name and the first and last addresses of the address range.
create-scope <i>name</i>	Creates a new DHCP scope. You must specify the scope name.
default-router <i>scope router_1</i> [<i>router_2</i>] [<i>router_3</i>]	Configures the default routers for the specified scope and specify the IP address of a router. Optionally, you can specify the IP addresses of secondary and tertiary routers.
delete-scope <i>scope</i>	Deletes the specified DHCP scope.
disable <i>scope</i>	Disables the specified DHCP scope.
dns-servers <i>scope dns1</i> [<i>dns2</i>] [<i>dns3</i>]	Configures the name servers for the given scope. You must also specify at least one name server. Optionally, you can specify secondary and tertiary name servers.
domain <i>scope domain</i>	Configures the DNS domain name. You must specify the scope and domain names.
enable <i>scope</i>	Enables the specified dhcp scope.
lease <i>scope lease_duration</i>	Configures the lease duration (in seconds) for the specified scope.

netbios-name-server <i>scope wins1 [wins2] [wins3]</i>	Configures the netbios name servers. You must specify the scope name and the IP address of a name server. Optionally, you can specify the IP addresses of secondary and tertiary name servers.
network <i>scope network netmask</i>	Configures the network and netmask. You must specify the scope name, the network address, and the network mask.
opt-82 remote-id	Configures the DHCP option 82 remote ID field format. DHCP option 82 provides additional security when DHCP is used to allocate network addresses. The controller acts as a DHCP relay agent to prevent DHCP client requests from untrusted sources. The controller adds option 82 information to DHCP requests from clients before forwarding the requests to the DHCP server.
<i>ap_mac</i>	MAC address of the access point to the DHCP option 82 payload.
<i>ap_mac:ssid</i>	MAC address and SSID of the access point to the DHCP option 82 payload.
<i>ap-ethmac</i>	Remote ID format as AP Ethernet MAC address.
<i>apname:ssid</i>	Remote ID format as AP name:SSID.
<i>ap-group-name</i>	Remote ID format as AP group name.
<i>flex-group-name</i>	Remote ID format as FlexConnect group name .
<i>ap-location</i>	Remote ID format as AP location.
<i>apmac-vlan_id</i>	Remote ID format as AP radio MAC address:VLAN_ID.
<i>apname-vlan_id</i>	Remote ID format as AP Name:VLAN_ID.
<i>ap-ethmac-ssid</i>	Remote ID format as AP Ethernet MAC:SSID address.

Command Default

The default value for ap-group-name is default-group, and for ap-location, the default value is default location. If ap-group-name and flex-group-name are null, the system MAC is sent as the remote ID field.

Usage Guidelines

Use the **show dhcp** command to display the internal DHCP configuration.

Examples

This example shows how to configure the DHCP lease for the scope 003:

```
> config dhcp lease 003
```

Related Commands

- config dhcp proxy
- config dhcp timeout
- config interface dhcp
- config wlan dhcp_server
- debug dhcp
- debug dhcp service-port
- debug disable-all
- show dhcp
- show dhcp proxy

config dhcp proxy

To specify the level at which DHCP packets are modified, use the **config dhcp proxy** command.

config dhcp proxy {enable | disable {bootp-broadcast [enable | disable]}}

Syntax Description

enable	Allows the controller to modify the DHCP packets without a limit.
disable	Reduces the DHCP packet modification to the level of a relay.
bootp-broadcast	Configures DHCP BootP broadcast option.

Command Default

Enabled.

Usage Guidelines

Use the **show dhcp proxy** command to display the status of DHCP proxy handling.

To enable third-party WGB support, you must enable the passive-client feature on the wireless LAN by entering the **config wlan passive-client enable** command.

Examples

This example shows how to disable the DHCP packet modification:

```
> config dhcp proxy disable
```

This example shows how to enable the DHCP BootP broadcast option:

```
> config dhcp proxy disable bootp-broadcast enable
```

Related Commands

config dhcp
config dhcp timeout
config interface dhcp
config wlan dhcp_server
debug dhcp
debug dhcp service-port
debug disable-all
show dhcp
show dhcp proxy

config dhcp timeout

To configure a DHCP timeout, use the **config dhcp timeout** command.

config dhcp timeout *timeout-value*

Syntax Description

<i>timeout-value</i>	Timeout value in the range of 5 to 120 seconds.

Command Default

None.

Examples

This example shows how to set the DHCP timeout to 10 seconds:

```
> config dhcp timeout 10
```

Related Commands

- config dhcp proxy
- config dhcp timeout
- config interface dhcp
- config wlan dhcp_server
- debug dhcp
- debug dhcp service-port
- debug disable-all
- show dhcp
- show dhcp proxy

config flow

To configure the NetFlow monitor and exporter, use the **config flow** command.

config flow {add | delete} **monitor** *monitor_name* {**exporter** *exporter_name* | **record** *record_name*}

Syntax Description

add	Associates a NetFlow monitor with an exporter, or a NetFlow record with a NetFlow monitor.
delete	Dissociates a NetFlow monitor from an exporter, or a NetFlow record from a NetFlow monitor.
monitor	Configures a NetFlow monitor.
<i>monitor_name</i>	Name of the NetFlow monitor. The monitor name can be up to 32 case-sensitive, alphanumeric characters. You cannot include spaces for a monitor name.
exporter	Configures a NetFlow exporter.
<i>exporter_name</i>	Name of the NetFlow exporter. The exporter name can be up to 32 case-sensitive, alphanumeric characters. You cannot include spaces for an exporter name.
record	Associates a NetFlow record to the NetFlow monitor.
<i>record_name</i>	Name of the IPv4 NetFlow record of the client application.

Command Default

None.

Usage Guidelines

An exporter is a network entity that exports the template with the IP traffic information. The controller acts as an exporter. A NetFlow record in the controller contains the information about the traffic in a given flow such as client MAC address, client source IP address, WLAN ID, incoming and outgoing bytes of data, incoming and outgoing packets, incoming and outgoing DSCP.

Examples

This example shows how to configure the flow monitor and exporter:

```
> config flow add monitor monitor1 exporter exporter1
```

Related Commands

show flow exporter
show flow monitor
config wlan flow

config guest-lan

To create, delete, enable or disable a wireless LAN, use the **config guest-lan** command.

config guest-lan {create | delete} *guest_lan_id* *interface_name* | {enable | disable} *guest_lan_id*

Syntax Description

create	Creates a wired LAN settings.
delete	Deletes a wired LAN settings:
<i>guest_lan_id</i>	LAN identifier between 1 and 5 (inclusive).
<i>interface_name</i>	Interface name up to 32 alphanumeric characters.
enable	Enables a wireless LAN.
disable	Disables a wireless LAN.

Command Default

None.

Examples

This example shows how to enable a wireless LAN with the LAN ID 16:

```
> config guest-lan enable 16
```

Related Commands

show wlan

config guest-lan custom-web ext-webauth-url

To redirect guest users to an external server before accessing the web login page, use the **config guest-lan custom-web ext-webauth-url** command.

config guest-lan custom-web ext-webauth-url *ext_web_url* *guest_lan_id*

Syntax Description

<i>ext_web_url</i>	URL for the external server.
<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).

Command Default

None.

Examples

This example shows how to enable a wireless LAN with the LAN ID 16:

```
> config guest-lan custom-web ext-webauth-url http://www.AuthorizationURL.com/ 1
```

Related Commands

config guest-lan
config guest-lan create
config guest-lan custom-web login_page

config guest-lan custom-web global disable

To use a guest-LAN specific custom web configuration rather than a global custom web configuration, use the **config guest-lan custom-web global disable** command.

config guest-lan custom-web global disable *guest_lan_id*

Syntax Description

guest_lan_id	Guest LAN identifier between 1 and 5 (inclusive).

Command Default

None.

Usage Guidelines

If you enter the **config guest-lan custom-web global enable** *guest_lan_id* command, the custom web authentication configuration at the global level is used.

Examples

This example shows how to disable the global web configuration for guest LAN ID 1:

```
> config guest-lan custom-web global disable 1
```

Related Commands

config guest-lan
config guest-lan create
config guest-lan custom-web ext-webauth-url
config guest-lan custom-web login_page
config guest-lan custom-web webauth-type

config guest-lan custom-web login_page

To enable wired guest users to log into a customized web login page, use the **config guest-lan custom-web login_page** command.

config guest-lan custom-web login_page *page_name* *guest_lan_id*

Syntax Description

<i>page_name</i>	Name of the customized web login page.
<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).

Command Default

None.

Examples

This example shows how to customize a web login page custompage1 for guest LAN ID 1:

```
> config guest-lan custom-web login_page custompage1 1
```

Related Commands

config guest-lan
config guest-lan create
config guest-lan custom-web ext-webauth-url

config guest-lan custom-web webauth-type

To define the web login page for wired guest users, use the **config guest-lan custom-web webauth-type** command.

config guest-lan custom-web webauth-type {**internal** | **customized** | **external**} *guest_lan_id*

Syntax Description

internal	Displays the default web login page for the controller. This is the default value.
customized	Displays the custom web login page that was previously configured.
external	Redirects users to the URL that was previously configured.
<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).

Command Default

Internal.

Examples

This example shows how to configure the guest LAN with the webauth-type as internal for guest LAN ID 1:

```
> config guest-lan custom-web webauth-type internal 1
```

Related Commands

config guest-lan
config guest-lan create
config guest-lan custom-web ext-webauth-url

config guest-lan ingress-interface

To configure the wired guest VLAN's ingress interface that provides a path between the wired guest client and the controller through the Layer 2 access switch, use the **config guest-lan ingress-interface** command.

config guest-lan ingress-interface *guest_lan_id interface_name*

Syntax Description

<i>guest_lan_id</i>	Guest LAN identifier from 1 to 5 (inclusive).
<i>interface_name</i>	Interface name.

Command Default

None.

Examples

This example shows how to provide a path between the wired guest client and the controller with guest LAN ID 1 and the interface name guest01:

```
> config guest-lan ingress-interface 1 guest01
```

Related Commands

config interface guest-lan
config guest-lan create

config guest-lan interface

To configure an egress interface to transmit wired guest traffic out of the controller, use the **config guest-lan interface** command.

config guest-lan interface *guest_lan_id* *interface_name*

Syntax Description

<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).
<i>interface_name</i>	Interface name.

Command Default

None.

Examples

This example shows how to configure an egress interface to transmit guest traffic out of the controller for guest LAN ID 1 and interface name guest01:

```
> config guest-lan interface 1 guest01
```

Related Commands

config ingress-interface guest-lan
config guest-lan create

config guest-lan mobility anchor

To add or delete mobility anchor, use the **config guest-lan mobility anchor** command.

config guest-lan mobility anchor {add | delete} *wlan_id* *anchor_ip*

Syntax Description

add	Adds a mobility anchor.
delete	Deletes a mobility anchor.
<i>wlan_id</i>	WLAN identifier.
<i>anchor_ip</i>	IP address of the mobility anchor.

Command Default

None.

Examples

This example shows how to delete a mobility anchor for WAN ID 4 and the anchor IP *192.168.0.14*:

```
> config guest-lan mobility anchor delete 4 192.168.0.14
```

Related Commands

config mobility group anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config guest-lan nac

To enable or disable Network Admission Control (NAC) out-of-band support for a guest LAN, use the **config guest-lan nac** command:

```
config guest-lan nac {enable | disable} guest_lan_id
```

Syntax Description

enable	Enables the NAC out-of-band support.
disable	Disables the NAC out-of-band support.
<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).

Command Default

None.

Examples

This example shows how to enable the NAC out-of-band support for guest LAN ID 3:

```
> config guest-lan nac enable 3
```

Related Commands

```
show nac statistics  
show nac summary  
config wlan nac  
debug nac
```

config guest-lan security

To configure the security policy for the wired guest LAN, use the **config guest-lan security** command.

config guest-lan security {web-auth {enable | disable | acl | server-precedence} *guest_lan_id* | web-passthrough {acl | email-input | disable | enable} *guest_lan_id*}

Syntax Description

web-auth	Specifies web authentication.
enable	Enables the web authentication settings.
disable	Disables the web authentication settings.
acl	Configures an access control list.
server-precedence	Configures the authentication server precedence order for web authentication users.
<i>guest_lan_id</i>	LAN identifier between 1 and 5 (inclusive).
web-passthrough	Specifies the web captive portal with no authentication required.
email-input	Configures the web captive portal using an e-mail address.

Command Default

Web authentication.

Examples

This example shows how to configure the security web authentication policy for guest LAN ID 1:

```
> config guest-lan security web-auth enable 1
```

Related Commands

config ingress-interface guest-lan
config guest-lan create
config interface guest-lan

config license boot

To specify the license level to be used on the next reboot of the Cisco 5500 Series Controller, use the **config license boot** command.

config license boot {base | wplus | auto}

Syntax Description

base	Specifies the base boot level.
wplus	Specifies the wplus boot level.
auto	Specifies the auto boot level.

Command Default

None.

Usage Guidelines

If you enter **auto**, the licensing software automatically chooses the license level to use on the next reboot. It generally chooses permanent licenses over evaluation licenses and wplus licenses over base licenses.



Note

If you are considering upgrading from a base license to a wplus license, you can try an evaluation wplus license before upgrading to a permanent wplus license. To activate the evaluation license, you need to set the image level to wplus in order for the controller to use the wplus evaluation license instead of the base permanent license.



Note

To prevent disruptions in operation, the controller does not switch licenses when an evaluation license expires. You must reboot the controller in order to return to a permanent license. Following a reboot, the controller defaults to the same feature set level as the expired evaluation license. If no permanent license at the same feature set level is installed, the controller uses a permanent license at another level or an unexpired evaluation license.

Examples

This example shows how to set the license boot settings to wplus:

```
> config license boot wplus
```

Related Commands

license install
show license in-use
license modify priority

config load-balancing

To globally configure aggressive load balancing on the controller, use the **config load-balancing** command.

config load-balancing {**window** *client_count* | **status** {**enable** | **disable**} | **denial** *denial_count*}

config load-balancing uplink-threshold *traffic_threshold*

Syntax Description

window	Specifies the aggressive load balancing client window.
<i>client_count</i>	Aggressive load balancing client window with the number of clients from 1 to 20.
status	Sets the load balancing status.
enable	Enables load balancing feature.
disable	Disables load balancing feature.
denial	Specifies the number of association denials during load balancing.
<i>denial_count</i>	Maximum number of association denials during load balancing. from 0 to 10.
uplink-threshold	Specifies the threshold traffic for an access point to deny new associations.
<i>traffic_threshold</i>	Threshold traffic for an access point to deny new associations. This value is a percentage of the WAN utilization measured over a 90 second interval. For example, the default threshold value of 50 triggers the load balancing upon detecting an utilization of 50% or more on an access point WAN interface.

Command Default

Disabled.

Usage Guidelines

Load-balancing-enabled WLANs do not support time-sensitive applications like voice and video because of roaming delays.

When you use Cisco 7921 and 7920 Wireless IP Phones with controllers, make sure that aggressive load balancing is disabled on the voice WLANs for each controller. Otherwise, the initial roam attempt by the phone might fail, causing a disruption in the audio path.

Clients can only be load balanced across access points joined to the same controller. The WAN utilization is calculated as a percentage using the following formula: (Transmitted Data Rate (per second) + Received Data Rate (per second))/(1000Mbps TX + 1000Mbps RX) * 100

Examples

This example shows how to enable the aggressive load-balancing settings:

```
> config load-balancing aggressive enable
```

Related Commands

show load-balancing

config wlan load-balance

config location

To configure a location-based system, use the **config location** command.

config location {**add** *location* [*description*] | **delete** *location* | **enable** | **disable** | **description** *location* *description* | **algorithm** {**simple** | **rss****i-average**} | {**rss****i-half-life** | **expiry**} [**client** | **calibrating-client** | **tags** | **rogue-aps**] *seconds* | **notify-threshold** [**client** | **tags** | **rogue-aps**] *threshold* | **interface-mapping** {**add** | **delete**} *location wlan_id interface_name* | **plm** {**client** {**enable** | **disable**} *burst_interval* | **calibrating** {**enable** | **disable**} {**uniband** | **multiband**}}}

Syntax Description

add	Adds a location element.
<i>location</i>	Location element name.
<i>description</i>	Element description. Optional with the add command, and required with the description command.
delete	Deletes a location element.
enable	Enables the access point location-based overrides.
disable	Disables the access point location-based overrides.
algorithm	Note We recommend that you do not use or modify the config location algorithm command. It is set to optimal default values. Configures the algorithm used to average RSSI and SNR values.
simple	Specifies a faster algorithm that requires low CPU overhead but provides less accuracy.
rss i-average	Specifies a more accurate algorithm but requires more CPU overhead.
rss i-half-life	Note We recommend that you do not use or modify the config location rss i-half-life command. It is set to optimal default values. Configures the half-life when averaging two RSSI readings.
expiry	Note We recommend that you do not use or modify the config location expiry command. It is set to optimal default values. Configures the timeout for RSSI values.
client	(Optional) Specifies the parameter applies to client devices.
calibrating-client	(Optional) Specifies the parameter is used for calibrating client devices.
tags	(Optional) Specifies the parameter applies to radio frequency identification (RFID) tags.
rogue-aps	(Optional) Specifies the parameter applies to rogue access points.

<i>seconds</i>	Time value (0, 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, 300 seconds).
notify-threshold	Note We recommend that you do not use or modify the config location notify-threshold command. It is set to optimal default values. Specifies the NMSP notification threshold for RSSI measurements.
<i>threshold</i>	Threshold parameter. The range is 0 to 10 dB, and the default value is 0 dB.
interface-mapping	Adds or deletes a new location, wireless LAN, or interface mapping element.
<i>wlan_id</i>	WLAN identification name.
<i>interface_name</i>	Name of interface to which mapping element applies.
plm	Specifies the path loss measurement (S60) request for normal clients or calibrating clients.
client	Specifies normal, noncalibrating clients.
<i>burst_interval</i>	Burst interval. The range is from 1 to 3600 seconds, and the default value is 60 seconds.
calibrating	Specifies calibrating clients.
uniband	Specifies the associated 802.11a or 802.11b/g radio (uniband).
multiband	Specifies the associated 802.11a/b/g radio (multiband).

Command Default

See the “Syntax Description” section for default values of individual arguments and keywords.

Examples

This example shows how to specify the simple algorithm for averaging RSSI and SNR values on a location-based controller:

```
> config location algorithm simple
```

Related Commands

clear location rfid
clear location statistics rfid
show location
show location statistics rfid

config logging buffered

To set the severity level for logging messages to the controller buffer, use the **config logging buffered** command.

config logging buffered security_level

Syntax Description

security_level

Security level. Choose one of the following:

- emergencies—Severity level 0
- alerts—Severity level 1
- critical—Severity level 2
- errors—Severity level 3
- warnings—Severity level 4
- notifications—Severity level 5
- informational—Severity level 6
- debugging—Severity level 7

Command Default

None.

Examples

This example shows how to set the controller buffer severity level for logging messages to 4:

```
> config logging buffered 4
```

Related Commands

config logging syslog facility
config logging syslog level
show logging

config logging console

To set the severity level for logging messages to the controller console, use the **config logging console** command.

config logging console *security_level*

Syntax Description	<i>security_level</i> Severity level. Choose one of the following: • emergencies—Severity level 0 • alerts—Severity level 1 • critical—Severity level 2 • errors—Severity level 3 • warnings—Severity level 4 • notifications—Severity level 5 • informational—Severity level 6 • debugging—Severity level 7
Command Default	None.
Examples	This example shows how to set the controller console severity level for logging messages to 3: <pre>> config logging console 3</pre>
Related Commands	config logging syslog facility config logging syslog level show logging

config logging debug

To save debug messages to the controller buffer, the controller console, or a syslog server, use the **config logging debug** command.

config logging debug {**buffered** | **console** | **syslog**} {**enable** | **disable**}

Syntax Description

buffered	Saves debug messages to the controller buffer.
console	Saves debug messages to the controller console.
syslog	Saves debug messages to the syslog server.
enable	Enables logging of debug messages.
disable	Disables logging of debug messages.

Command Default

The **console** command is enabled,
The **buffered** and **syslog** commands are disabled.

Examples

This example shows how to save the debug messages to the controller console:

```
> config logging debug console enable
```

Related Commands

show logging

config logging fileinfo

To cause the controller to include information about the source file in the message logs or to prevent the controller from displaying this information, use the **config logging fileinfo** command.

config logging fileinfo {enable | disable}

Syntax Description

enable	Includes information about the source file in the message logs.
disable	Prevents the controller from displaying information about the source file in the message logs.

Command Default

None.

Examples

This example shows how to enable the controller to include information about the source file in the message logs:

```
> config logging fileinfo enable
```

Related Commands

show logging

config logging procinfo

To cause the controller to include process information in the message logs or to prevent the controller from displaying this information, use the **config logging procinfo** command.

config logging procinfo {enable | disable}

Syntax Description

enable	Includes process information in the message logs.
disable	Prevents the controller from displaying process information in the message logs.

Command Default

None.

Examples

This example shows how to enable the controller to include the process information in the message logs:

```
> config logging procinfo enable
```

Related Commands

show logging

config logging traceinfo

To cause the controller to include traceback information in the message logs or to prevent the controller from displaying this information, use the **config logging traceinfo** command.

config logging traceinfo {enable | disable}

Syntax Description	enable	Includes traceback information in the message logs.
	disable	Prevents the controller from displaying traceback information in the message logs.

Command Default None.

Examples This example shows how to disable the controller to include the traceback information in the message logs:

```
> config logging traceinfo disable
```

Related Commands **show logging**

config logging syslog host

To configure a remote host for sending syslog messages, use the **config logging syslog host** command.

config logging syslog host *host_IP_address*

Syntax Description

<i>host_IP_address</i>	IP address for the remote host.

Command Default

None.

Usage Guidelines

To remove a remote host that was configured for sending syslog messages, enter the **config logging syslog host** *host_IP_address* **delete** command.

Examples

This example shows how to configure a remote host 10.92.125.52 for sending the syslog messages:

```
> config logging syslog host 10.92.125.52
```

Related Commands

config logging syslog facility
config logging syslog level
show logging

config logging syslog facility

To set the facility for outgoing syslog messages to the remote host, use the **config logging syslog facility** command.

config logging syslog facility *facility_code*

Syntax Description

facility_code

Facility code. Choose one of the following:

- authorization—Authorization system. Facility level—4.
- auth-private—Authorization system (private). Facility level—10.
- cron—Cron/at facility. Facility level—9.
- daemon—System daemons. Facility level—3.
- ftp—FTP daemon. Facility level—11.
- kern—Kernel. Facility level—0.
- local0—Local use. Facility level—16.
- local1—Local use. Facility level—17.
- local2—Local use. Facility level—18.
- local3—Local use. Facility level—19.
- local4—Local use. Facility level—20.
- local5—Local use. Facility level—21.
- local6—Local use. Facility level—22.
- local7—Local use. Facility level—23.
- lpr—Line printer system. Facility level—6.
- mail—Mail system. Facility level—2.
- news—USENET news. Facility level—7.
- sys12—System use. Facility level—12.
- sys13—System use. Facility level—13.
- sys14—System use. Facility level—14.
- sys15—System use. Facility level—15.
- syslog—The syslog itself. Facility level—5.
- user—User process. Facility level—1.
- uucp—UNIX-to-UNIX copy system. Facility level—8.

Command Default

None.

Examples

This example shows how to set the facility for outgoing syslog messages to authorization:

```
> config logging syslog facility authorization
```

Related Commands

config logging syslog host

config logging syslog level

show logging

config logging syslog level

To set the severity level for filtering syslog messages to the remote host, use the **config logging syslog level** command.

config logging syslog level *severity_level*

Syntax Description

severity_level

Severity level. Choose one of the following:

- emergencies—Severity level 0
- alerts—Severity level 1
- critical—Severity level 2
- errors—Severity level 3
- warnings—Severity level 4
- notifications—Severity level 5
- informational—Severity level 6
- debugging—Severity level 7

Command Default

None.

Examples

This example shows how to set the severity level for syslog messages to 3:

```
> config logging syslog level 3
```

Related Commands

config logging syslog host
config logging syslog facility
show logging

config login session close

To close all active Telnet sessions, use the **config login session close** command.

config login session close {*session_id* | **all**}

Syntax Description

<i>session_id</i>	ID of the session to close.
all	Closes all Telnet sessions.

Command Default

None.

Examples

This example shows how to close all active Telnet sessions:

```
> config login session close all
```

Related Commands

show login session

config mdns profile

To configure a multicast DNS (mDNS) profile and associate a service with the profile, use the **config mdns profile** command.

config mdns profile {create | delete | service {add | delete} *service_name* *profile_name*

Syntax Description

create	Creates an mDNS profile.
delete	Deletes an mDNS profile. If the profile is associated to an interface group, an interface, or a WLAN, an error appears.
service	Configures an mDNS service.
add	Adds an mDNS service to an mDNS profile.
delete	Deletes an mDNS service from an mDNS profile.
<i>service_name</i>	Name of the mDNS service.
<i>profile_name</i>	Name of the mDNS profile. You can create a maximum of 16 profiles.

Command Default

By default, the controller has an mDNS profile, default-mdns-profile. You cannot delete this default profile.

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

After creating a new profile, you must map the profile to an interface group, an interface, or a WLAN. Clients receive service advertisements only for the services associated with the profile. The controller gives the highest priority to the profiles associated to interface groups, followed by the interface profiles, and then the WLAN profiles. Each client is mapped to a profile based on the order of priority.

By default, the controller has an mDNS profile, default-mdns-profile. You cannot delete this default profile.

Examples

The following example shows how to add the Apple TV mDNS service to the mDNS profile1.

```
Device > config mdns profile create profile1 Apple TV
```

Related Commands

config mdns query interval
config mdns service
config mdns snooping

config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail
debug mdns message

config mdns query interval

To configure the query interval for multicast DNS (mDNS) services, use the **config mdns query interval** command.

config mdns query interval *interval_value*

Syntax Description

<i>interval_value</i>	mDNS query interval, in minutes, that you can set. The query interval is the frequency at which the controller sends periodic queries to all the services defined in the Master Services database. The range is from 10 to 120.

Command Default

The default query interval for an mDNS service is 15 minutes.

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

The controller snoops and learns about the mDNS service advertisements only if the service is available in the Master Services database. mDNS uses the multicast IP address 224.0.0.251 as the destination address and 5353 as UDP destination port.

Examples

The following example shows how to configure the query interval for mDNS services as 20 minutes.

```
Device > config mdns query interval 20
```

Related Commands

- config mdns profile**
- config mdns service**
- config mdns snooping**
- config interface mdns-profile**
- config interface group mdns-profile**
- config wlan mdns**
- show mdns profile**
- show mnds service**
- clear mdns service-database**
- debug mdns all**
- debug mdns error**
- debug mdns detail**

debug mdns message

config mdns service

To configure multicast DNS (mDNS) services in the master services database, use the **config mdns service** command.

config mdns service {**create** *service_name service_string* **query** {**enable** | **disable**} | **delete** *service_name* | **query** {**enable** | **disable**}}

Syntax Description

create	Adds a new mDNS service to the Master Services database.
<i>service_name</i>	Name of the mDNS service. For example, Air Tunes, iTunes Music Sharing, FTP, Apple File Sharing Protocol (AFP).
<i>service_string</i>	Unique string associated to an mDNS service. For example, “_airplay._tcp.local.” is the service string associated with Apple TV.
delete	Deletes an mDNS service from the Master Services database. Before deleting the service, the controller checks if any profile uses the service. You must delete the service from all profiles before deleting the service.
query	Configures the query status for the mDNS service.
enable	Enables periodic query for an mDNS service by the controller.
disable	Disables periodic query for an mDNS service by the controller.

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

The controller snoops and learns about the mDNS service advertisements only if the service is available in the Master Services database. The controller can snoop and learn a maximum of 64 services in Release 7.4.

Related Commands

Command	Description
config wlan mdns	Configures an mDNS profile for a WLAN.
config mdns profile	Configures an mDNS profile.
config mdns query interval	Configures the query interval for mDNS services.
config mdns snooping	Enables or disables global mDNS snooping on the Cisco WLC.

Command	Description
clear mdns service-database	Clears the mDNS service database.
debug mdns all	Debugs all mDNS messages, details, and errors.
debug mdns detail	Debugs all mDNS details.
debug mdns error	Debugs all mDNS errors.
debug mdns message	Debugs all mDNS messages.
show mdns profile	Displays mDNS profile information.
show mdns service	Displays mDNS service information.

config mdns snooping

To enable or disable global multicast DNS (mDNS) snooping on the Cisco WLC, use the **config mdns snooping** command.

config mdns snooping {enable | disable}

Syntax Description

enable	Enables mDNS snooping on the Cisco WLC.
disable	Disables mDNS snooping on the Cisco WLC.

Command Default

By default, mDNS snooping is enabled on the Cisco WLC.

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

mDNS service discovery provides a way to announce and discover services on the local network. mDNS perform DNS queries over IP multicast. mDNS supports zero configuration IP networking.

Examples

The following example shows how to enable mDNS snooping.

```
Device > config mdns snooping enable
```

Related Commands

config mdns query interval
config mdns service
config mdns profile
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail
debug mdns message

config mgmtuser add

To add a local management user to the controller, use the **config mgmtuser add** command.

config mgmtuser add *username password* {**read-write** | **read-only**} [*description*]

Syntax Description

<i>username</i>	Account username. The username can be up to 24 alphanumeric characters.
<i>password</i>	Account password. The password can be up to 24 alphanumeric characters.
read-write	Creates a management user with read-write access.
read-only	Creates a management user with read-only access.
<i>description</i>	(Optional) Description of the account. The description can be up to 32 alphanumeric characters within double quotes.

Command Default

None

Examples

The following example shows how to create a management user account with read-write access.

```
Device > config mgmtuser add admin admin read-write "Main account"
```

Related Commands

show mgmtuser

config mgmtuser delete

To delete a management user from the controller, use the **config mgmtuser delete** command.

config mgmtuser delete *username*

Syntax Description

<i>username</i>	Account username. The username can be up to 24 alphanumeric characters.

Command Default

The management user is not deleted.

Examples

The following example shows how to delete a management user account admin from the controller.

```
Device > config mgmtuser delete admin
Deleted user admin
```

Related Commands

show mgmtuser

config mgmtuser description

To add a description to an existing management user login to the controller, use the **config mgmtuser description** command.

config mgmtuser description *username description*

Syntax Description

<i>username</i>	Account username. The username can be up to 24 alphanumeric characters.
<i>description</i>	Description of the account. The description can be up to 32 alphanumeric characters within double quotes.

Command Default

No description is added to the management user.

Examples

The following example shows how to add a description "master-user" to the management user "admin".

```
Device > config mgmtuser description admin "master user"
```

Related Commands

config mgmtuser add
config mgmtuser delete
config mgmtuser password
show mgmtuser

config mgmtuser password

To configure a management user password, use the **config mgmtuser password** command.

config mgmtuser password *username password*

Syntax Description

<i>username</i>	Account username. The username can be up to 24 alphanumeric characters.
<i>password</i>	Account password. The password can be up to 24 alphanumeric characters.

Command Default

None

Examples

This example shows how to change the password of the management user “admin” with the new password 5rTfm:

```
> config mgmtuser password admin 5rTfm
```

Related Commands

show mgmtuser

config netuser add

To add a guest user on a WLAN or wired guest LAN to the local user database on the controller, use the **config netuser add** command.

config netuser add *username password {wlan wlan_id | guestlan guestlan_id} userType guest lifetime lifetime description description*

Syntax Description

<i>username</i>	Guest username. The username can be up to 50 alphanumeric characters.
<i>password</i>	User password. The password can be up to 24 alphanumeric characters.
wlan	Specifies the wireless LAN identifier to associate with or zero for any wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier assigned to the user. A zero value associates the user with any wireless LAN.
guestlan	Specifies the guest LAN identifier to associate with or zero for any wireless LAN.
<i>guestlan_id</i>	Guest LAN ID.
userType	Specifies the user type.
guest	Specifies the guest for the guest user.
lifetime	Specifies the lifetime.
<i>lifetime</i>	Lifetime value (60 to 259200 or 0) in seconds for the guest user. Note A value of 0 indicates an unlimited lifetime.
<i>description</i>	Short description of user. The description can be up to 32 characters enclosed in double-quotes.

Command Default

None.

Usage Guidelines

Local network usernames must be unique because they are stored in the same database.

Examples

This example shows how to add a permanent username Jane to the wireless network for 1 hour:

```
> config netuser add jane able2 1 wlan_id 1 userType permanent
```

This example shows how to add a guest username George to the wireless network for 1 hour:

```
> config netuser add george able1 guestlan 1 3600
```

Related Commands

show netuser
config netuser delete

config netuser delete

To delete an existing user from the local network, use the **config netuser delete** command.

config netuser delete *username*

Syntax Description

<i>username</i>	Network username. The username can be up to 24 alphanumeric characters.

Command Default

None.

Usage Guidelines

Local network usernames must be unique because they are stored in the same database.

Examples

This example shows how to delete an existing username named able1 from the network:

```
> config netuser delete able1
Deleted user able1
```

Related Commands

show netuser

config netuser description

To add a description to an existing net user, use the **config netuser description** command.

config netuser description *username description*

Syntax Description

<i>username</i>	Network username. The username can contain up to 24 alphanumeric characters.
<i>description</i>	(Optional) User description. The description can be up to 32 alphanumeric characters enclosed in double quotes.

Command Default

None.

Examples

This example shows how to add a user description "HQ1 Contact" to an existing network user named able 1:

```
> config netuser description able1 "HQ1 Contact"
```

Related Commands

show netuser

config netuser guest-lan-id

To configure a wired guest LAN ID for a network user, use the **config netuser guest-lan-id** command.

config netuser guest-lan-id *username lan_id*

Syntax Description

<i>username</i>	Network username. The username can be 24 alphanumeric characters.
<i>lan_id</i>	Wired guest LAN identifier to associate with the user. A zero value associates the user with any wired LAN.

Command Default

None.

Examples

This example shows how to configure a wired LAN ID 2 to associate with the user named aire1:

```
> config netuser guest- lan-id aire1 2
```

Related Commands

show netuser

show wlan summary

config netuser guest-role apply

To apply a quality of service (QoS) role to a guest user, use the **config netuser guest-role apply** command.

config netuser guest-role apply *username role_name*

Syntax Description

<i>username</i>	Name of the user.
<i>role_name</i>	QoS guest role name.

Command Default

None.

Usage Guidelines

If you do not assign a QoS role to a guest user, the Role field in the User Details shows the role as default. The bandwidth contracts for this user are defined in the QoS profile for the WLAN.

If you want to unassign a QoS role from a guest user, use the **config netuser guest-role apply username default**. This user now uses the bandwidth contracts defined in the QoS profile for the WLAN.

Examples

This example shows how to apply a QoS role to a guest user jsmith with the QoS guest role named Contractor:

```
> config netuser guest-role apply jsmith Contractor
```

Related Commands

config netuser guest-role create
config netuser guest-role delete

config netuser guest-role create

To create a quality of service (QoS) role for a guest user, use the **config netuser guest-role create** command.

config netuser guest-role create *role_name*

Syntax Description

<i>role name</i>	QoS guest role name.

Command Default

None.

Usage Guidelines

To delete a QoS role, use the **config netuser guest-role delete** role-name.

Examples

This example shows how to create a QoS role for the guest user named guestuser1:

```
> config netuser guest-role create guestuser1
```

Related Commands

config netuser guest-role delete

config netuser guest-role delete

To delete a quality of service (QoS) role for a guest user, use the **config netuser guest-role delete** command.

config netuser guest-role delete *role_name*

Syntax Description

<i>role name</i>	Quality of service (QoS) guest role name.

Command Default

None.

Examples

This example shows how to delete a quality of service (QoS) role for guestuser1:

```
> config netuser guest-role delete guestuser1
```

Related Commands

config netuser guest-role create

config netuser guest-role qos data-rate average-data-rate

To configure the average data rate for TCP traffic on a per user basis, use the **config netuser guest-role qos data-rate average-data-rate** command.

config netuser guest-role qos data-rate average-data-rate *role_name* *rate*

Syntax Description

<i>role_name</i>	Quality of service (QoS) guest role name.
<i>rate</i>	Rate for TCP traffic on a per user basis.

Command Default

None.

Usage Guidelines

For the *role_name* parameter in each of these commands, enter a name for the new QoS role. The name uniquely identifies the role of the QoS user (such as contractor, vendor, and so on.). For the *rate* parameter, you can enter a value between 0 and 60,000 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS role.

Examples

This example shows how to configure an average rate for the QoS guest named guestuser1:

```
> config netuser guest-role qos data-rate average-data-rate guestuser1 0
```

Related Commands

config netuser guest-role create
config netuser guest-role delete
config netuser guest-role qos data-rate burst-data-rate

config netuser guest-role qos data-rate average-realtime-rate

To configure the average data rate for TCP traffic on a per user basis, use the **config netuser guest-role qos data-rate average-realtime-rate** command.

config netuser guest-role qos data-rate average-realtime-rate *role_name* *rate*

Syntax Description

<i>role_name</i>	Quality of service (QoS) guest role name.
<i>rate</i>	Rate for TCP traffic on a per user basis.

Command Default

None.

Usage Guidelines

For the *role_name* parameter in each of these commands, enter a name for the new QoS role. The name uniquely identifies the role of the QoS user (such as contractor, vendor, and so on.). For the *rate* parameter, you can enter a value between 0 and 60,000 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS role.

Examples

This example shows how to configure an average data rate for the QoS guest user named guestuser1 with the rate for TCP traffic of 0 Kbps:

```
> config netuser guest-role qos data-rate average-realtime-rate guestuser1 0
```

Related Commands

config netuser guest-role

config netuser guest-role qos data-rate average-data-rate

config netuser guest-role qos data-rate burst-data-rate

To configure the peak data rate for TCP traffic on a per user basis, use the **config netuser guest-role qos data-rate burst-data-rate** command.

config netuser guest-role qos data-rate burst-data-rate *role_name* *rate*

Syntax Description

<i>role_name</i>	Quality of service (QoS) guest role name.
<i>rate</i>	Rate for TCP traffic on a per user basis.

Command Default

None.

Usage Guidelines

The burst data rate should be greater than or equal to the average data rate. Otherwise, the QoS policy may block traffic to and from the wireless client.

For the *role_name* parameter in each of these commands, enter a name for the new QoS role. The name uniquely identifies the role of the QoS user (such as contractor, vendor, and so on.). For the *rate* parameter, you can enter a value between 0 and 60,000 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS role.

Examples

This example shows how to configure the peak data rate for the QoS guest named guestuser1 with the rate for TCP traffic of 0 Kbps:

```
> config netuser guest-role qos data-rate burst-data-rate guestuser1 0
```

Related Commands

config netuser guest-role create
config netuser guest-role delete
config netuser guest-role qos data-rate average-data-rate

config netuser guest-role qos data-rate burst-realtime-rate

To configure the burst real-time data rate for UDP traffic on a per user basis, use the **config netuser guest-role qos data-rate burst-realtime-rate** command.

config netuser guest-role qos data-rate burst-realtime-rate *role_name* *rate*

Syntax Description

<i>role_name</i>	Quality of service (QoS) guest role name.
<i>rate</i>	Rate for TCP traffic on a per user basis.

Command Default

None.

Usage Guidelines

The burst real-time rate should be greater than or equal to the average real-time rate. Otherwise, the quality of service (QoS) policy may block traffic to and from the wireless client.

For the *role_name* parameter in each of these commands, enter a name for the new QoS role. The name uniquely identifies the role of the QoS user (such as contractor, vendor, and so on.). For the *rate* parameter, you can enter a value between 0 and 60,000 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS role.

Examples

This example shows how to configure a burst real-time rate for the QoS guest user named guestuser1 with the rate for TCP traffic of 0 Kbps:

```
> config netuser guest-role qos data-rate burst-realtime-rate guestuser1 0
```

Related Commands

config netuser guest-role
config netuser guest-role qos data-rate average-data-rate
config netuser guest-role qos data-rate burst-data-rate

config netuser lifetime

To configure the lifetime for a guest network user, use the **config netuser lifetime** command.

config netuser lifetime *username time*

Syntax Description

<i>username</i>	Network username. The username can be up to 50 alphanumeric characters.
<i>time</i>	Lifetime between 60 to 2592000 seconds or 0 for no limit.

Command Default

None.

Examples

This example shows how to configure a the lifetime for a guest network user:

```
> config netuser lifetime guestuser1 22450
```

Related Commands

show netuser

show wlan summary

config netuser maxUserLogin

To configure the maximum number of login sessions allowed for a network user, use the **config netuser maxUserLogin** command.

config netuser maxUserLogin *count*

Syntax Description	<i>count</i>	Maximum number of login sessions for a single user. The allowed values are from 0 (unlimited) to 8.
Command Default	0 (unlimited)	
Examples	This example shows how to configure the maximum number of login sessions for a single user to 8: > config netuser maxUserLogin 8	
Related Commands	show netuser	

config netuser password

To change a local network user password, use the **config netuser password** command.

config netuser password *username password*

Syntax Description

<i>username</i>	Network username. The username can be up to 24 alphanumeric characters.
<i>password</i>	Network user password. The password can contain up to 24 alphanumeric characters.

Command Default

None.

Examples

This example shows how to change the network user password from aire1 to aire2:

```
> config netuser password aire1 aire2
```

Related Commands

show netuser

config netuser wlan-id

To configure a wireless LAN ID for a network user, use the **config netuser wlan-id** command.

config netuser wlan-id *username wlan_id*

Syntax Description

<i>username</i>	Network username. The username can be 24 alphanumeric characters.
<i>wlan_id</i>	Wireless LAN identifier to associate with the user. A zero value associates the user with any wireless LAN.

Command Default

None.

Examples

This example shows how to configure a wireless LAN ID 2 to associate with the user named aire1:

```
> config netuser wlan-id aire1 2
```

Related Commands

show netuser
show wlan summary

config network 802.3-bridging

To enable or disable 802.3 bridging on a controller, use the **config network 802.3-bridging** command.

config network 802.3-bridging {enable | disable}

Syntax Description

enable	Enables the 802.3 bridging.
disable	Disables the 802.3 bridging.

Command Default

Disabled.

Usage Guidelines

In controller software release 5.2, the software-based forwarding architecture for Cisco 2100 Series Controllers is being replaced with a new forwarding plane architecture. As a result, Cisco 2100 Series Controllers and the Cisco wireless LAN controller Network Module for Cisco Integrated Services Routers bridge 802.3 packets by default. Therefore, 802.3 bridging can now be disabled only on Cisco 4400 Series Controllers, the Cisco WiSM, and the Catalyst 3750G Wireless LAN Controller Switch.

To determine the status of 802.3 bridging, enter the **show netuser guest-roles** command.

Examples

This example shows how to enable the 802.3 bridging:

```
> config network 802.3-bridging enable
```

Related Commands

show netuser guest-roles
show network

config network allow-old-bridge-aps

To configure an old bridge access point's ability to associate with a switch, use the **config network allow-old-bridge-aps** command.

config network allow-old-bridge-aps {enable | disable}

Syntax Description

enable	Enables the switch association.
disable	Disables the switch association.

Command Default

Enabled.

Examples

This example shows how to configure an old bridge access point to associate with the switch:

```
> config network allow-old-bridge-aps enable
```

Related Commands

show network summary

config network ap-discovery

To enable or disable NAT IP in an AP discovery response, use the **config network ap-discovery** command.

config network ap-discovery nat-ip-only {enable | disable}

Syntax Description

enable	Enables use of NAT IP only in discovery response. This is the default.
disable	Enables use of both NAT IP and non NAT IP in discovery response.

Command Default

Enabled.

Usage Guidelines

If the **config interface nat-address management** command is set, this command controls which address(es) are sent in the CAPWAP discovery responses.

If all APs are on the outside of the NAT gateway of the controller, enter the **config network ap-discovery nat-ip-only enable** command, and only the management NAT address is sent.

If the controller has both APs on the outside and the inside of its NAT gateway, enter the **config network ap-discovery nat-ip-only disable** command, and both the management NAT address and the management inside address are sent. Ensure that you have entered the **config ap link-latency disable all** command to avoid stranding APs.

Examples

This example shows how to enable NAT IP in an AP discovery response:

```
> config network ap-discovery nat-ip-only enable
```

config network ap-fallback

To configure Cisco lightweight access point fallback, use the **config network ap-fallback** command.

config network ap-fallback {enable | disable}

Syntax Description

enable	Enables the Cisco lightweight access point fallback.
disable	Disables the Cisco lightweight access point fallback.

Command Default

Enabled.

Examples

This example shows how to enable the Cisco lightweight access point fallback:

```
> config network ap-fallback enable
```

Related Commands

show network summary

config network ap-priority

To enable or disable the option to prioritize lightweight access points so that after a controller failure they reauthenticate by priority rather than on a first-come-until-full basis, use the **config network ap-priority** command.

config network ap-priority {enable | disable}

Syntax Description

enable	Enables the lightweight access point priority reauthentication.
disable	Disables the lightweight access point priority reauthentication.

Command Default

Disabled.

Examples

This example shows how to enable the lightweight access point priority reauthorization:

```
> config network ap-priority enable
```

Related Commands

config ap priority
show ap summary
show network summary

config network apple-talk

To configure AppleTalk bridging, use the **config network apple-talk** command.

config network apple-talk {enable | disable}

Syntax Description

enable	Enables the AppleTalk bridging.
disable	Disables the AppleTalk bridging.

Command Default

None.

Examples

This example shows how to configure AppleTalk bridging:

```
> config network apple-talk enable
```

Related Commands

show network summary

config network arptimeout

To set the Address Resolution Protocol (ARP) entry timeout value, use the **config network arptimeout** command.

config network arptimeout *seconds*

Syntax Description

<i>seconds</i>	Timeout in seconds. The minimum value is 10. The default value is 300.

Command Default

300.

Examples

This example shows how to set the ARP entry timeout value to 240 seconds:

```
> config network arptimeout 240
```

Related Commands

show network summary

config network bridging-shared-secret

To configure the bridging shared secret, use the **config network bridging-shared-secret** command.

config network bridging-shared-secret *shared_secret*

Syntax Description	<i>shared_secret</i> Bridging shared secret string. The string can contain up to 10 bytes.
Command Default	Enabled.
Usage Guidelines	This command creates a secret that encrypts backhaul user data for the mesh access points that connect to the switch. The zero-touch configuration must be enabled for this command to work.
Examples	This example shows how to configure the bridging shared secret string “shhh1”: <pre>> config network bridging-shared-secret shhh1</pre>
Related Commands	show network summary

config network broadcast

To enable or disable broadcast packet forwarding, use the **config network broadcast** command.

config network broadcast {enable | disable}

Syntax Description

enable	Enables the broadcast packet forwarding.
disable	Disables the broadcast packet forwarding.

Command Default

Disabled.

Usage Guidelines

This command allows you to enable or disable broadcasting. You must enable multicast mode before enabling broadcast forwarding. Use the **config network multicast mode command** to configure multicast mode on the controller.



Note

The default multicast mode is unicast in case of all controllers except for Cisco 2106 Controllers. The broadcast packets and multicast packets can be independently controlled. If multicast is off and broadcast is on, broadcast packets still reach the access points, based on the configured multicast mode.

Examples

This example shows how to enable broadcast packet forwarding:

```
> config network broadcast enable
```

Related Commands

show network summary
config network multicast global
config network multicast mode

config network fast-ssid-change

To enable or disable fast Service Set Identifier (SSID) changing for mobile stations, use the **config network fast-ssid-change** command.

config network fast-ssid-change {enable | disable}

Syntax Description

enable	Enables the fast SSID changing for mobile stations
disable	Disables the fast SSID changing for mobile stations.

Command Default

None.

Usage Guidelines

When you enable the Fast SSID Change feature, the controller allows clients to move between SSIDs. When the client sends a new association for a different SSID, the client entry in the controller connection table is cleared before the client is added to the new SSID.

When you disable the FastSSID Change feature, the controller enforces a delay before clients are allowed to move to a new SSID.

Examples

This example shows how to enable the fast SSID changing for mobile stations:

```
> config network fast-ssid-change enable
```

Related Commands

show network summary

config network ip-mac-binding

To validate the source IP address and MAC address binding within client packets, use the **config network ip-mac-binding** command.

config network ip-network-binding {enable | disable}

Syntax Description

enable	Enables the validation of the source IP address to MAC address binding in clients packets.
disable	Disables the validation of the source IP address to MAC address binding in clients packets.

Command Default

Enabled.

Usage Guidelines

In controller software release 5.2, the controller enforces strict IP address-to-MAC address binding in client packets. The controller checks the IP address and MAC address in a packet, compares them to the addresses that are registered with the controller, and forwards the packet only if they both match. In previous releases, the controller checks only the MAC address of the client and ignores the IP address.



Note

You might want to disable this binding check if you have a routed network behind a workgroup bridge (WGB).

Examples

This example shows how to validate the source IP and MAC address within client packets:

```
> config network ip-mac-binding enable
```

config network master-base

To enable or disable the Cisco wireless LAN controller as an access point default master, use the **config network master-base** command.

config network master-base {enable | disable}

Syntax Description

enable	Enables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.
disable	Disables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.

Command Default

None.

Usage Guidelines

This setting is only used upon network installation and should be disabled after the initial network configuration. Because the Master Cisco wireless LAN controller is normally not used in a deployed network, the Master Cisco wireless LAN controller setting can be saved from 6.0.199.0 or later releases.

Examples

This example shows how to enable the Cisco wireless LAN controller as a default master:

```
> config network master-base enable
```

config network mgmt-via-wireless

To enable Cisco wireless LAN controller management from an associated wireless client, use the **config network mgmt-via-wireless** command.

config network mgmt-via-wireless {enable | disable}

Syntax Description

enable	Enables the switch management from a wireless interface.
disable	Disables the switch management from a wireless interface.

Command Default

Disabled.

Usage Guidelines

This feature allows wireless clients to manage only the Cisco wireless LAN controller associated with the client and the associated Cisco lightweight access point. That is, clients cannot manage another Cisco wireless LAN controller with which they are not associated.

Examples

This example shows how to configure switch management from a wireless interface:

```
> config network mgmt-via-wireless enable
```

Related Commands

show network summary

config network multicast global

To enable or disable multicasting on the controller, use the **config network multicast global** command.

config network multicast global {enable | disable}

Syntax Description

enable	Enables the multicast global support.
disable	Disables the multicast global support.

Command Default

Disabled.

Usage Guidelines

The **config network broadcast {enable | disable}** command allows you to enable or disable broadcasting without enabling or disabling multicasting as well. This command uses the multicast mode configured on the controller (by using the **config network multicast mode command**) to operate.

Examples

This example shows how to enable the global multicast support:

```
> config network multicast global enable
```

Related Commands

show network summary
config network broadcast
config network multicast mode

config network multicast igmp query interval

To configure the IGMP query interval, use the **config network multicast igmp query interval** command.

config network multicast igmp query interval *value*

Syntax Description

<i>value</i>	Frequency at which controller sends IGMP query messages. The range is from 15 to 2400 seconds.

Command Default

20 seconds.

Usage Guidelines

To configure IGMP query interval, ensure that you do the following:

- Enable the global multicast by entering the **config network multicast global enable** command.
- Enable IGMP snooping by entering the **config network multicast igmp snooping enable** command.

Examples

This example shows how to configure the IGMP query interval at 20 seconds:

```
> config network multicast igmp query interval 20
```

Related Commands

config network multicast global
config network multicast igmp snooping
config network multicast igmp timeout

config network multicast igmp snooping

To enable or disable IGMP snooping, use the **config network multicast igmp snooping** command.

config network multicast igmp snooping {enable | disable}

Syntax Description

enable	Enables IGMP snooping.
disable	Disables IGMP snooping.

Command Default

None.

Examples

This example shows how to enable internet IGMP snooping settings:

```
> config network multicast igmp snooping enable
```

Related Commands

config network multicast global
config network multicast igmp query interval
config network multicast igmp timeout

config network multicast igmp timeout

To set the IGMP timeout value, use the **config network multicast igmp timeout** command.

config network multicast igmp timeout *value*

Syntax Description

<i>value</i>	Timeout range from 30 to 7200 seconds.

Command Default

None.

Usage Guidelines

You can enter a timeout value between 30 and 7200 seconds. The controller sends three queries in one timeout value at an interval of timeout/3 to see if any clients exist for a particular multicast group. If the controller does not receive a response through an IGMP report from the client, the controller times out the client entry from the MGID table. When no clients are left for a particular multicast group, the controller waits for the IGMP timeout value to expire and then deletes the MGID entry from the controller. The controller always generates a general IGMP query (to destination address 224.0.0.1) and sends it on all WLANs with an MGID value of 1.

Examples

This example shows how to configure the timeout value 50 for IGMP network settings:

```
> config network multicast igmp timeout 50
```

Related Commands

config network multicast global
config network igmp snooping
config network multicast igmp query interval

config network multicast l2mcast

To configure the Layer 2 multicast on an interface or all interfaces, use the **config network multicast l2mcast** command.

config network multicast l2mcast {enable| disable} {all | *interface-name*}

Syntax Description

enable	Enables Layer 2 multicast.
disable	Disables Layer 2 multicast.
all	Applies to all interfaces.
<i>interface-name</i>	Interface name for which the Layer 2 multicast is to enabled or disabled.

Command Default

None.

Examples

This example shows how to enable Layer 2 multicast for all interfaces:

```
> config network multicast l2mcast enable all
```

Related Commands

config network multicast global
config network multicast igmp snooping
config network multicast igmp query interval
config network multicast mld

config network multicast mld

To configure the Multicast Listener Discovery (MLD) parameters, use the **config network multicast mld** command.

config network multicast mld {**query interval** *interval-value* | **snooping** {**enable** | **disable**} | **timeout** *timeout-value*}

Syntax Description

query interval	Configures query interval to send MLD query messages.
<i>interval-value</i>	Query interval in seconds. The range is from 15 to 2400 seconds.
snooping	Configures MLD snooping.
enable	Enables MLD snooping.
disable	Disables MLD snooping.
timeout	Configures MLD timeout.
<i>timeout-value</i>	Timeout value in seconds. The range is from 30 seconds to 7200 seconds.

Command Default

None.

Examples

This example shows how to set a query interval of 20 seconds for MLD query messages:

```
> config network multicast mld query interval 20
```

Related Commands

config network multicast global
config network multicast igmp snooping
config network multicast igmp query interval
config network multicast l2mcast

config network multicast mode multicast

To configure the controller to use the multicast method to send broadcast or multicast packets to an access point, use the **config network multicast mode multicast** command.

config network multicast mode multicast

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to configure the multicast mode to send a single copy of data to multiple receivers:

```
> config network multicast mode multicast
```

Related Commands	config network multicast global config network broadcast config network multicast mode unicast

config network multicast mode unicast

To configure the controller to use the unicast method to send broadcast or multicast packets to an access point, use the **config network multicast mode unicast** command.

config network multicast mode unicast

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to configure the controller to use the unicast mode:

```
> config network multicast mode unicast
```

Related Commands

- config network multicast global**
- config network broadcast**
- config network multicast mode multicast**

config network oeap-600 dual-rlan-ports

To configure the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4, use the **config network oeap-600 dual-rlan-ports** command.

config network oeap-600 dual-rlan-ports {enable | disable}

Syntax Description

enable	Enables Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4.
disable	Resets the Ethernet port 3 Cisco OfficeExtend 600 Series access points to function as a local LAN port.

Command Default

Disabled.

Examples

This example shows how to enable the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port:

```
> config network oeap-600 dual-rlan-ports enable
```

Related Commands

show network summary

config network oeap-600 local-network

To configure access to the local network for the Cisco 600 Series OfficeExtend access points, use the **config network oeap-600 local-network** command.

config network oeap-600 local-network {enable | disable}

Syntax Description

enable	Enables access to the local network for the Cisco 600 Series OfficeExtend access points.
disable	Disables access to the local network for the Cisco 600 Series OfficeExtend access points.

Command Default

Disabled.

Examples

This example shows how to enable access to the local network for the Cisco 600 Series OfficeExtend access points:

```
> config network oeap-600 local-network enable
```

Related Commands

show network summary

config network otap-mode

To enable or disable over-the-air provisioning (OTAP) of Cisco lightweight access points, use the **config network otap-mode** command.

config network otap-mode {enable | disable}

Syntax Description

enable	Enables the OTAP provisioning.
disable	Disables the OTAP provisioning.

Command Default

Enabled.

Examples

This example shows how to disable the OTAP provisioning:

```
> config network otap-mode disable
```

Related Commands

show network summary

config network rf-network-name

To set the RF-Network name, use the **config network rf-network-name** command.

config network rf-network-name *name*

Syntax Description

<i>name</i>	RF-Network name. The name can contain up to 19 characters.

Command Default

None.

Examples

This example shows how to set the RF-network name to travelers:

```
> config network rf-network-name travelers
```

Related Commands

show network summary

config network secureweb

To change the state of the secure web (https is http and SSL) interface for management users, use the **config network secureweb** command.

config network secureweb {enable | disable}

Syntax Description

enable	Enables the secure web interface for management users.
disable	Disables the secure web interface for management users.

Command Default

Enabled.

Usage Guidelines

This command allows management users to access the controller GUI using an http://ip-address. Web mode is not a secure connection.

Examples

This example shows how to enable the secure web interface settings for management users:

```
> config network secureweb enable
You must reboot for the change to take effect.
```

Related Commands

config network secureweb cipher-option
show network summary

config network secureweb cipher-option

To enable or disable secure web mode with increased security, or to enable or disable Secure Sockets Layer (SSL v2) for web administration and web authentication, use the **config network secureweb cipher-option** command.

config network secureweb cipher-option {**high** | **ssl2** | **rc4-preference**} {**enable** | **disable**}

Syntax Description

high	Configures whether or not 128-bit ciphers are required for web administration and web authentication.
ssl2	Configures SSLv2 for both web administration and web authentication.
rc4-preference	Configures preference for RC4-SHA (Rivest Cipher 4-Secure Hash Algorithm) cipher suites (over CBC cipher suites) for web authentication and web administration.
enable	Enables the secure web interface.
disable	Disables the secure web interface.

Command Default

The default is disabled for secure web mode with increased security and **enabled** for SSL v2.

Usage Guidelines

Note

The **config network secureweb cipher-option** command allows users to access the controller GUI using an http://ip-address but only from browsers that support 128-bit (or larger) ciphers.

When cipher-option ssl2 is disabled, users cannot connect using a browser configured with SSLv2 only. They must use a browser that is configured to use a more secure protocol such as SSLv3 or later.

In RC4-SHA based cipher suites, RC4 is used for encryption and SHA is used for message authentication.

Examples

This example shows how to enable secure web mode with increased security:

```
> config network secureweb cipher-option
```

This example shows how to disable SSL v2:

```
> config network secureweb cipher-option ssl2 disable
```

Related Commands

config network secureweb
show network summary

config network ssh

To allow or disallow new Secure Shell (SSH) sessions, use the **config network ssh** command.

config network ssh {enable | disable}

Syntax Description

enable	Allows the new SSH sessions.
disable	Disallows the new SSH sessions.

Command Default

Disabled.

Examples

This example shows how to enable the new SSH session:

```
> config network ssh enable
```

Related Commands

show network summary

config network telnet

To allow or disallow new Telnet sessions, use the **config network telnet** command.

config network telnet {enable | disable}

Syntax Description

enable	Allows new Telnet sessions.
disable	Disallows new Telnet sessions.

Command Default

Disabled.

Examples

This example shows how to configure the new Telnet sessions:

```
> config network telnet enable
```

Related Commands

config ap telnet
show network summary

config network usertimeout

To change the timeout for idle client sessions, use the **config network usertimeout** command.

config network usertimeout *seconds*

Syntax Description	<i>seconds</i>	Timeout duration in seconds. The minimum value is 90. The default value is 300.
Command Default	300.	
Usage Guidelines	Use this command to set the idle client session duration on the Cisco wireless LAN controller. The minimum duration is 90 seconds.	
Examples	This example shows how to configure the idle session timeout to 1200 seconds: > config network usertimeout 1200	
Related Commands	show network summary	

config network web-auth captive-bypass

To configure the controller to support bypass of captive portals at the network level, use the **config network web-auth captive-bypass** command.

config network web-auth captive-bypass {enable | disable}

Syntax Description

enable	Allows the controller to support bypass of captive portals.
disable	Disallows the controller to support bypass of captive portals.

Command Default

None.

Examples

This example shows how to configure the controller to support bypass of captive portals:

```
> config network web-auth captive-bypass enable
```

Related Commands

show network summary
config network web-auth cmcc-support

config network web-auth cmcc-support

To configure eWalk on the controller, use the **config network web-auth cmcc-support** command.

config network web-auth cmcc-support {enable | disable}

Syntax Description

enable	Enables eWalk on the controller.
disable	Disables eWalk on the controller.

Command Default

None.

Examples

This example shows how to enable eWalk on the controller:

```
> config network web-auth cmcc-support enable
```

Related Commands

show network summary
config network web-auth captive-bypass

config network web-auth port

To configure an additional port to be redirected for web authentication at the network level, use the **config network web-auth port** command.

config network web-auth port *port*

Syntax Description

<i>port</i>	Port number. The valid range is from 0 to 65535.

Command Default

None.

Examples

This example shows how to configure an additional port number 1200 to be redirected for web authentication:

```
> config network web-auth port 1200
```

Related Commands

show network summary

config network web-auth proxy-redirect

To configure proxy redirect support for web authentication clients, use the **config network web-auth proxy-redirect** command.

config network web-auth proxy-redirect {enable | disable}

Syntax Description	enable	Allows proxy redirect support for web authentication clients.
	disable	Disallows proxy redirect support for web authentication clients.

Command Default None.

Examples This example shows how to enable proxy redirect support for web authentication clients:

```
> config network web-auth proxy-redirect enable
```

Related Commands **show network summary**

config network web-auth secureweb

To configure the secure web (https) authentication for clients, use the **config network web-auth secureweb** command.

config network web-auth secureweb {enable | disable}

Syntax Description

enable	Allows secure web (https) authentication for clients.
disable	Disallows secure web (https) authentication for clients. Enables http web authentication for clients.

Command Default

Enabled.

Examples

This example shows how to enable the secure web (https) authentication for clients:

```
> config network web-auth secureweb enable
```

Related Commands

show network summary

config network webmode

To enable or disable the web mode, use the **config network webmode** command.

config network webmode {enable | disable}

Syntax Description

enable	Enables the web interface.
disable	Disables the web interface.

Command Default

Enabled.

Examples

This example shows how to disable the web interface mode:

```
> config network webmode disable
```

Related Commands

show network summary

config network web-auth

To configure the network-level web authentication options, use the **config network web-auth** command.

config network web-auth {**port** *port-number*} | {**proxy-redirect** {**enable** | **disable**}}

Syntax Description

port	Configures additional ports for web authentication redirection.
<i>port-number</i>	Port number (between 0 and 65535).
proxy-redirect	Configures proxy redirect support for web authentication clients.
enable	Enables proxy redirect support for web authentication clients. Note Web-auth proxy redirection will be enabled for ports 80, 8080, and 3128, along with user defined port 345.
disable	Disables proxy redirect support for web authentication clients.

Command Default

Disabled.

Usage Guidelines

You must reset the system for the configuration to take effect.

Examples

This example shows how to enable proxy redirect support for web authentication clients:

```
> config network web-auth proxy-redirect enable
```

Related Commands

show network summary
show run-config
config qos protocol-type

config network zero-config

To configure bridge access point ZeroConfig support, use the **config network zero-config** command.

config network zero-config {enable | disable}

Syntax Description

enable	Enables the bridge access point ZeroConfig support.
disable	Disables the bridge access point ZeroConfig support.

Command Default

Enabled.

Examples

This example shows how to enable the bridge access point ZeroConfig support:

```
> config network zero-config enable
```

Related Commands

show network summary

config nmosp notify-interval measurement

To modify the Network Mobility Services Protocol (NMSP) notification interval value on the controller to address latency in the network, use the **config nmosp notify-interval measurement** command.

config nmosp notify-interval measurement {client | rfid | rogue} *interval*

Syntax Description

client	Modifies the interval for clients.
rfid	Modifies the interval for active radio frequency identification (RFID) tags.
rogue	Modifies the interval for rogue access points and rogue clients.
<i>interval</i>	Time interval. The range is from 1 to 30 seconds.

Command Default

None.

Usage Guidelines

The TCP port (16113) that the controller and location appliance communicate over must be open (not blocked) on any firewall that exists between the controller and the location appliance for NMSP to function.

Examples

This example shows how to modify the NMSP notification interval for the active RFID tags to 25 seconds:

```
> config nmosp notify-interval measurement rfid 25
```

Related Commands

clear locp statistics
clear nmosp statistics
show nmosp notify-interval summary
show nmosp statistics
show nmosp status

config paging

To enable or disable scrolling of the page, use the **config paging** command.

config paging {enable | disable}

Syntax Description

enable	Enables the scrolling of the page.
disable	Disables the scrolling of the page.

Command Default

Enabled.

Examples

This example shows how to enable scrolling of the page

```
> config paging enable
```

Related Commands

show run-config

config passwd-cleartext

To enable or disable temporary display of passwords in plain text, use the **config passwd-cleartext** command.

config passwd-cleartext {enable | disable}

Syntax Description

enable	Enables the display of passwords in plain text.
disable	Disables the display of passwords in plain text.

Command Default

Disabled.

Usage Guidelines

This command must be enabled if you want to see user-assigned passwords displayed in clear text when using the **show run-config** command.

To execute this command, you must enter an admin password. This command is valid only for this particular session. It is not saved following a reboot.

Examples

This example shows how to enable display of passwords in plain text:

```
> config passwd-cleartext enable
The way you see your passwds will be changed
You are being warned.
Enter admin password:
```

Related Commands

show run-config

config prompt

To change the CLI system prompt, use the **config prompt** command.

config prompt *prompt*

Syntax Description

<i>prompt</i>	New CLI system prompt enclosed in double quotes. The prompt can be up to 31 alphanumeric characters and is case sensitive.

Command Default

The system prompt is configured using the startup wizard.

Usage Guidelines

Because the system prompt is a user-defined variable, it is omitted from the rest of this documentation.

Examples

This example shows how to change the CLI system prompt to Cisco 4400:

```
> config prompt "Cisco 4400"
```

config qos average-data-rate

To define the average data rate in Kbps for TCP traffic per user or per service set identifier (SSID), use the **config qos average-data-rate** command.

config qos average-data-rate {**bronze** | **silver** | **gold** | **platinum**} {**per-ssid** | **per-client**} {**downstream** | **upstream**} *rate*

Syntax Description

bronze	Specifies the average data rate for the queue bronze.
silver	Specifies the average data rate for the queue silver.
gold	Specifies the average data rate for the queue gold.
platinum	Specifies the average data rate for the queue platinum.
per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
per-client	Configures the rate limit for each client associated with the SSID.
downstream	Configures the rate limit for downstream traffic.
upstream	Configures the rate limit for upstream traffic.
<i>rate</i>	Average data rate for TCP traffic per user. A value between 0 and 51,200 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS profile.

Command Default

None.

Examples

This example shows how to configure the average data rate 0 Kbps for the queue gold per SSID:

```
> config qos average-data-rate gold per ssid downstream 0
```

Related Commands

config qos burst-data-rate
config qos average-realtime-rate
config qos burst-realtime-rate
config wlan override-rate-limit

config qos average-realtime-rate

To define the average real-time data rate in Kbps for UDP traffic per user or per service set identifier (SSID), use the **config qos average-realtime-rate** command.

config qos average-realtime-rate {**bronze** | **silver** | **gold** | **platinum**} {**per-ssid** | **per-client**} {**downstream** | **upstream**} *rate*

Syntax Description

bronze	Specifies the average real-time data rate for the queue bronze.
silver	Specifies the average real-time data rate for the queue silver.
gold	Specifies the average real-time data rate for the queue gold.
platinum	Specifies the average real-time data rate for the queue platinum.
per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
per-client	Configures the rate limit for each client associated with the SSID.
downstream	Configures the rate limit for downstream traffic.
upstream	Configures the rate limit for upstream traffic.
<i>rate</i>	Average real-time data rate for UDP traffic per user. A value between 0 and 51,200 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS profile.

Command Default

None.

Examples

This example shows how to configure the average real-time actual rate for queue gold:

```
> config qos average-realtime-rate gold per ssid downstream 10
```

Related Commands

config qos average-data-rate
config qos burst-data-rate
config qos burst-realtime-rate
config wlan override-rate-limit

config qos burst-data-rate

To define the peak data rate in Kbps for TCP traffic per user or per service set identifier (SSID), use the **config qos burst-data-rate** command.

config qos burst-data-rate {bronze | silver | gold | platinum} {per-ssid | per-client} {downstream | upstream} *rate*

Syntax Description

bronze	Specifies the peak data rate for the queue bronze.
silver	Specifies the peak data rate for the queue silver.
gold	Specifies the peak data rate for the queue gold.
platinum	Specifies the peak data rate for the queue platinum.
per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
per-client	Configures the rate limit for each client associated with the SSID.
downstream	Configures the rate limit for downstream traffic.
upstream	Configures the rate limit for upstream traffic.
<i>rate</i>	Peak data rate for TCP traffic per user. A value between 0 and 51,200 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS profile.

Command Default

None.

Examples

This example shows how to configure the peak rate 30000 Kbps for the queue gold:

```
> config qos burst-data-rate gold per ssid downstream 30000
```

Related Commands

config qos average-data-rate
config qos average-realtime-rate
config qos burst-realtime-rate
config wlan override-rate-limit

config qos burst-realtime-rate

To define the burst real-time data rate in Kbps for UDP traffic per user or per service set identifier (SSID), use the **config qos burst-realtime-rate** command.

config qos burst-realtime-rate {bronze | silver | gold | platinum} { per-ssid | per-client } { downstream | upstream } *rate*

Syntax Description

bronze	Specifies the burst real-time data rate for the queue bronze.
silver	Specifies the burst real-time data rate for the queue silver.
gold	Specifies the burst real-time data rate for the queue gold.
platinum	Specifies the burst real-time data rate for the queue platinum.
per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
per-client	Configures the rate limit for each client associated with the SSID.
downstream	Configures the rate limit for downstream traffic.
upstream	Configures the rate limit for upstream traffic.
<i>rate</i>	Burst real-time data rate for UDP traffic per user. A value between 0 and 51,200 Kbps (inclusive). A value of 0 imposes no bandwidth restriction on the QoS profile.

Command Default

None.

Examples

This example shows how to configure the burst real-time actual rate 2000 Kbps for the queue gold:

```
> config qos burst-realtime-rate gold per ssid downstream 2000
```

Related Commands

config qos average-data-rate
config qos burst-data-rate
config qos average-realtime-rate
config wlan override-rate-limit

config qos description

To change the profile description, use the **config qos description** command.

config qos description {**bronze** | **silver** | **gold** | **platinum**} *description*

Syntax Description

bronze	Specifies the QoS profile description for the queue bronze.
silver	Specifies the QoS profile description for the queue silver.
gold	Specifies the QoS profile description for the queue gold.
platinum	Specifies the QoS profile description for the queue platinum.
<i>description</i>	QoS profile description.

Command Default

None.

Examples

This example shows how to configure the QoS profile description “description” for the queue gold:

```
> config qos description gold abc
```

Related Commands

show qos average-data-rate
config qos burst-data-rate
config qos average-realtime-rate
config qos burst-realtime-rate
config qos max-rf-usage

config qos max-rf-usage

To specify the maximum percentage of RF usage per access point, use the **config qos max-rf-usage** command.

config qos max-rf-usage {**bronze** | **silver** | **gold** | **platinum**} *usage_percentage*

Syntax Description

bronze	Specifies the maximum percentage of RF usage for the queue bronze.
silver	Specifies the maximum percentage of RF usage for the queue silver.
gold	Specifies the maximum percentage of RF usage for the queue gold.
platinum	Specifies the maximum percentage of RF usage for the queue platinum.
<i>usage-percentage</i>	Maximum percentage of RF usage.

Command Default

None.

Examples

This example shows how to specify the maximum percentage of RF usage for the queue gold:

```
> config qos max-rf-usage gold 20
```

Related Commands

show qos description
config qos average-data-rate
config qos burst-data-rate
config qos average-realtime-rate
config qos burst-realtime-rate

config qos dot1p-tag

To define the maximum value (0 to 7) for the priority tag associated with packets that fall within the profile, use the **config qos dot1p-tag** command.

config qos dot1p-tag {bronze | silver | gold | platinum} dot1p_tag

Syntax Description

bronze	Specifies the QoS 802.1p tag for the queue bronze.
silver	Specifies the QoS 802.1p tag for the queue silver.
gold	Specifies the QoS 802.1p tag for the queue gold.
platinum	Specifies the QoS 802.1p tag for the queue platinum.
<i>dot1p_tag</i>	Dot1p tag value between 1 and 7.

Command Default

None.

Examples

This example shows how to configure the a QoS 802.1p tag for the queue gold with the dot1p tag value of 5:

```
> config qos dot1p-tag gold 5
```

Related Commands

show qos queue_length all

config qos protocol-type

config qos priority

To define the maximum and default QoS levels for unicast and multicast traffic when you assign a QoS profile to a WLAN, use the **config qos priority** command.

config qos priority {**bronze** | **silver** | **gold** | **platinum**} {*maximum-priority* | *default-unicast-priority* | *default-multicast-priority*}

Syntax Description

bronze	Specifies a Bronze profile of the WLAN.
silver	Specifies a Silver profile of the WLAN.
gold	Specifies a Gold profile of the WLAN.
platinum	Specifies a Platinum profile of the WLAN.
<i>maximum-priority</i>	Maximum QoS priority as one of the following: • besteffort • background • video • voice
<i>default-unicast-priority</i>	Default unicast priority as one of the following: • besteffort • background • video • voice
<i>default-multicast-priority</i>	Default multicast priority as one of the following: • besteffort • background • video • voice

Usage Guidelines

The maximum priority level should not be lower than the default unicast and multicast priority levels.

Examples

This example shows how to configure the QoS priority for a gold profile of the WLAN with voice as the maximum priority, video as the default unicast priority, and besteffort as the default multicast priority.

```
> config qos priority gold voice video besteffort
```

Related Commands

`config qos protocol-type`

config qos protocol-type

To define the maximum value (0 to 7) for the priority tag associated with packets that fall within the profile, use the **config qos protocol-type** command.

config qos protocol-type {**bronze** | **silver** | **gold** | **platinum**} {**none** | *dot1p*}

Syntax Description

bronze	Specifies the QoS 802.1p tag for the queue bronze.
silver	Specifies the QoS 802.1p tag for the queue silver.
gold	Specifies the QoS 802.1p tag for the queue gold.
platinum	Specifies the QoS 802.1p tag for the queue platinum.
none	Specifies when no specific protocol is assigned.
<i>dot1p</i>	Specifies when dot1p type protocol is assigned.

Command Default

None.

Examples

This example shows how to configure the QoS protocol type silver:

```
> config qos protocol-type silver dot1p
```

Related Commands

show qos queue_length all
config qos dot1p-tag

config qos queue_length

To specify the maximum number of packets that access points keep in their queues, use the **config qos queue_length** command.

```
config qos queue_length {bronze | silver | gold | platinum} queue_length
```

Syntax Description

bronze	Specifies the QoS length for the queue bronze.
silver	Specifies the QoS length for the queue silver.
gold	Specifies the QoS length for the queue gold.
platinum	Specifies the QoS length for the queue platinum.
<i>queue_length</i>	Maximum queue length values (10 to 255).

Command Default

None.

Examples

This example shows how to configure the QoS length for the queue “gold” with the maximum queue length value as 12:

```
> config qos queue_length gold 12
```

Related Commands

show qos

config rfid auto-timeout

To configure an automatic timeout of radio frequency identification (RFID) tags, use the **config rfid auto-timeout** command.

config rfid auto-timeout {enable | disable}

Syntax Description	enable	Enables an automatic timeout.
	disable	Disables an automatic timeout.

Command Default None.

Examples This example shows how to enable an automatic timeout of RFID tags:

```
> config rfid auto-timeout enable
```

Related Commands

- show rfid summary
- config rfid status
- config rfid timeout

config rfid status

To configure radio frequency identification (RFID) tag data tracking, use the **config rfid status** command.

config rfid status {enable | disable}

Syntax Description

enable	Enables RFID tag tracking.
disable	Enables RFID tag tracking.

Command Default

None.

Examples

This example shows how to configure RFID tag tracking settings:

```
> config rfid status enable
```

Related Commands

show rfid summary
config rfid auto-timeout
config rfid timeout

config rfid timeout

To configure a static radio frequency identification (RFID) tag data timeout, use the **config rfid timeout** command.

config rfid timeout *seconds*

Syntax Description	
	<i>seconds</i> Timeout in seconds (from 60 to 7200).

Command Default	
	None.

Examples	
	This example shows how to configure a static RFID tag data timeout of 60 seconds:
	> config rfid timeout 60

Related Commands	
	show rfid summary
	config rfid statistics

config service timestamps

To enable or disable time stamps in message logs, use the **config service timestamps** command.

config service timestamps {**debug** | **log**} {**datetime** | **disable**}

Syntax Description

debug	Configures time stamps in debug messages.
log	Configures time stamps in log messages.
datetime	Specifies to time-stamp message logs with the standard date and time.
disable	Specifies to prevent message logs being time-stamped.

Command Default

Disabled.

Examples

This example shows how to configure time-stamp message logs with the standard date and time:

```
> config service timestamps log datetime
```

This example shows how to prevent message logs being time-stamped:

```
> config service timestamps debug disable
```

Related Commands

show logging

config sessions maxsessions

To configure the number of Telnet CLI sessions allowed by the Cisco wireless LAN controller, use the **config sessions maxsessions** command.

config sessions maxsessions *session_num*

Syntax Description

<i>session_num</i>	Number of sessions from 0 to 5.

Command Default

5.

Usage Guidelines

Up to five sessions are possible while a setting of zero prohibits any Telnet CLI sessions.

Examples

This example shows how to configure the number of allowed CLI sessions to 2:

```
> config sessions maxsessions 2
```

Related Commands

show sessions

config sessions timeout

To configure the inactivity timeout for Telnet CLI sessions, use the **config sessions timeout** command.

config sessions timeout *timeout*

Syntax Description

<i>timeout</i>	Timeout of Telnet session in minutes (from 0 to 160). A value of 0 indicates no timeout.

Command Default

5.

Examples

This example shows how to configure the inactivity timeout for Telnet sessions to 20 minutes:

```
> config sessions timeout 20
```

Related Commands

show sessions

config switchconfig boot-break

To enable or disable the breaking into boot prompt by pressing the Esc key at system startup, use the **config switchconfig boot-break** command.

config switchconfig boot-break {enable | disable}

Syntax Description	<table> <tr> <td>enable</td><td>Enables the breaking into boot prompt by pressing the Esc key at system startup.</td></tr> <tr> <td>disable</td><td>Disables the breaking into boot prompt by pressing the Esc key at system startup.</td></tr> </table>	enable	Enables the breaking into boot prompt by pressing the Esc key at system startup.	disable	Disables the breaking into boot prompt by pressing the Esc key at system startup.
enable	Enables the breaking into boot prompt by pressing the Esc key at system startup.				
disable	Disables the breaking into boot prompt by pressing the Esc key at system startup.				
Command Default	Disabled.				
Usage Guidelines	You must enable the features that are prerequisites for the Federal Information Processing Standard (FIPS) mode before enabling or disabling the breaking into boot prompt.				
Examples	This example shows how to enable the breaking into boot prompt by pressing the Esc key at system startup: <pre>> config switchconfig boot-break enable</pre>				
Related Commands	show switchconfig config switchconfig flowcontrol config switchconfig mode config switchconfig secret-obfuscation config switchconfig fips-prerequisite config switchconfig strong-pwd				

config switchconfig fips-prerequisite

To enable or disable the features that are prerequisites for the Federal Information Processing Standard (FIPS) mode, use the **config switchconfig fips-prerequisite** command.

config switchconfig fips-prerequisite {enable | disable}

Syntax Description

enable	Enables the features that are prerequisites for the FIPS mode.
disable	Disables the features that are prerequisites for the FIPS mode.

Command Default

Disabled.

Usage Guidelines

You must configure the FIPS authorization secret before you can enable or disable the FIPS prerequisite features.

Examples

This example shows how to enable the features that are prerequisites for the FIPS mode:

```
> config switchconfig fips-prerequisite enable
```

Related Commands

show switchconfig
config switchconfig flowcontrol
config switchconfig mode
config switchconfig secret-obfuscation
config switchconfig boot-break
config switchconfig strong-pwd

config switchconfig strong-pwd

To enable or disable your controller to check the strength of newly created passwords, use the **config switchconfig strong-pwd** command.

config switchconfig strong-pwd {**case-check** | **consecutive-check** | **default-check** | **username-check** | **all-checks**} {**enable** | **disable**}

Syntax Description

case-check	Checks at least three combinations: lowercase characters, uppercase characters, digits, or special characters.
consecutive-check	Checks the occurrence of the same character three times.
default-check	Checks for default values or use of their variants.
username-check	Checks whether the username is specified or not.
all-checks	Checks all the cases.
enable	Enables a strong password check for the access point and Cisco WLC.
disable	Disables a strong password check for the access point and Cisco WLC.

Command Default

None

Examples

The following example shows how to enable the Strong Password Check feature:

```
Device > config switchconfig strong-pwd case-check enable
```

Related Commands

show switchconfig
config switchconfig flowcontrol
config switchconfig mode
config switchconfig secret-obfuscation
config switchconfig fips-prerequisite
config switchconfig boot-break

config switchconfig flowcontrol

To enable or disable 802.3x flow control, use the **config switchconfig flowcontrol** command.

config switchconfig flowcontrol {enable | disable}

Syntax Description

enable	Enables 802.3x flow control.
disable	Disables 802.3x flow control.

Command Default

Disabled.

Examples

This example shows how to enable 802.3x flow control on Cisco wireless LAN controller parameters:

```
> config switchconfig flowcontrol enable
```

Related Commands

show switchconfig

config switchconfig mode

To configure Lightweight Access Port Protocol (LWAPP) transport mode for Layer 2 or Layer 3, use the **config switchconfig mode** command.

config switchconfig mode {L2 | L3}

Syntax Description

L2	Specifies Layer 2 as the transport mode.
L3	Specifies Layer 3 as the transport mode.

Command Default

L3

Examples

This example shows how to configure LWAPP transport mode to Layer 3:

```
> config switchconfig mode L3
```

Related Commands

show switchconfig

config switchconfig secret-obfuscation

To enable or disable secret obfuscation, use the **config switchconfig secret-obfuscation** command.

config switchconfig secret-obfuscation {enable | disable}

Syntax Description

enable	Enables secret obfuscation.
disable	Disables secret obfuscation.

Command Default

Secrets and user passwords are obfuscated in the exported XML configuration file.

Usage Guidelines

To keep the secret contents of your configuration file secure, do not disable secret obfuscation. To further enhance the security of the configuration file, enable configuration file encryption.

Examples

This example shows how to enable secret obfuscation:

```
> config switchconfig secret-obfuscation enable
```

Related Commands

show switchconfig

config sysname

To set the Cisco wireless LAN controller system name, use the **config sysname** command.

config sysname *name*

Syntax Description	
	<i>name</i> System name. The name can contain up to 31 alphanumeric characters.

Command Default	
	None.

Examples	
	This example shows how to configure the system named Ent_01: > config sysname Ent_01

Related Commands	
	show sysinfo

config snmp community accessmode

To modify the access mode (read only or read/write) of an SNMP community, use the **config snmp community accessmode** command.

config snmp community accessmode {ro | rw} name

Syntax Description

ro	Specifies a read-only mode.
rw	Specifies a read/write mode.
<i>name</i>	SNMP community name.

Command Default

Two communities are provided by default with the following settings:

SNMP Community Name	Client IP Address	Client IP Mask	Access Mode	Status
public	0.0.0.0	0.0.0.0	Read Only	Enable
private	0.0.0.0	0.0.0.0	Read/Write	Enable

Examples

This example shows how to configure read/write access mode for SNMP community:

```
> config snmp community accessmode rw private
```

Related Commands

show snmp community
config snmp community mode
config snmp community create
config snmp community delete
config snmp community ipaddr

config snmp community create

To create a new SNMP community, use the **config snmp community create** command.

config snmp community create *name*

Syntax Description

<i>name</i>	SNMP community name of up to 16 characters.

Command Default

None.

Usage Guidelines

Use this command to create a new community with the default configuration.

Examples

This example shows how to create a new SNMP community named test:

```
> config snmp community create test
```

Related Commands

show snmp community
config snmp community mode
config snmp community accessmode
config snmp community delete
config snmp community ipaddr

config snmp community delete

To delete an SNMP community, use the **config snmp community delete** command.

config snmp community delete *name*

Syntax Description

<i>name</i>	SNMP community name.

Command Default

None.

Examples

This example shows how to delete an SNMP community named test:

```
> config snmp community delete test
```

Related Commands

show snmp community
config snmp community mode
config snmp community accessmode
config snmp community create
config snmp community ipaddr

config snmp community ipaddr

To configure the IP address of an SNMP community, use the **config snmp community ipaddr** command.

config snmp community ipaddr *ip_address ip_mask name*

Syntax Description

<i>ip_address</i>	SNMP community IP address.
<i>ip_mask</i>	SNMP community subnet mask.
<i>name</i>	SNMP community name.

Command Default

None.

Examples

This example shows how to configure an SNMP community with the IP address 10.10.10.10, IP mask 255.255.255.0, and SNMP community named public:

```
> config snmp community ipaddr 10.10.10.10 255.255.255.0 public
```

Related Commands

show snmp community
config snmp community mode
config snmp community accessmode
config snmp community create
config snmp community delete

config snmp community mode

To enable or disable an SNMP community, use the **config snmp community mode** command.

config snmp community mode {enable | disable} *name*

Syntax Description

enable	Enables the community.
disable	Disables the community.
<i>name</i>	SNMP community name.

Command Default

None.

Examples

This example shows how to enable the SNMP community named public:

```
> config snmp community mode enable public
```

Related Commands

show snmp community
config snmp community delete
config snmp community accessmode
config snmp community create
config snmp community ipaddr

config snmp engineID

To configure the SNMP engine ID, use the **config snmp engineID** command.

config snmp engineID {*engine_id* | **default**}

Syntax Description

<i>engine_id</i>	Engine ID in hexadecimal characters (a minimum of 10 and a maximum of 24 characters are allowed).
default	Restores the default engine ID.

Command Default

None.

Usage Guidelines

The SNMP engine ID is a unique string used to identify the device for administration purposes. You do need to specify an engine ID for the device because a default string is automatically generated using Cisco's enterprise number and the MAC address of the first interface on the device.

If you change the engine ID, then a reboot is required for the change to take effect.

Caution If you change the value of the SNMP engine ID, then the password of the user entered on the command line is converted to an MD5 (Message-Digest algorithm 5) or SHA (Secure Hash Algorithm) security digest. This digest is based on both the password and the local engine ID. The command line password is then deleted. Because of this deletion, if the local value of the engine ID changes, the security digests of the SNMP users will become invalid, and the users will have to be reconfigured.

Examples

This example shows how to configure the SNMP engine ID with the value ffffffff:

```
> config snmp engineID ffffffff
```

Related Commands

show snmpengineID

config snmp syscontact

To set the SNMP system contact name, use the **config snmp syscontact** command.

config snmp syscontact *contact*

Syntax Description

<i>contact</i>	SNMP system contact name. The contact can be up to 31 alphanumeric characters.

Command Default

None.

Examples

This example shows how to set the SMNP system contact named Cisco WLAN Solution_administrator:

```
> config snmp syscontact Cisco WLAN Solution_administrator
```

Related Commands

show snmpcommunity

config snmp syslocation

To configure the SNMP system location name, use the **config snmp syslocation** command.

config snmp syslocation *location*

Syntax Description

<i>location</i>	SNMP system location name. The location can be up to 31 alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure the SNMP system location name to Building_2a:

```
> config snmp syslocation Building_2a
```

Related Commands

show snmpcommunity

config snmp trapreceiver create

To configure a server to receive SNMP traps, use the **config snmp trapreceiver create** command.

config snmp trapreceiver create *name ip_address*

Syntax Description

<i>name</i>	SNMP community name. The name contain up to 16 characters.
<i>ip_address</i>	SNMP community IP address.

Command Default

None.

Usage Guidelines

The IP address must be valid for the command to add the new server.

Examples

This example shows how to add a new SNMP trap receiver with the SNMP community named test and IP address 10.1.1.1:

```
> config snmp trapreceiver create test 10.1.1.1
```

Related Commands

show snmp trap

config snmp trapreceiver delete

To delete a server from the trap receiver list, use the **config snmp trapreceiver delete** command.

config snmp trapreceiver delete *name*

Syntax Description

<i>name</i>	SNMP community name. The name can contain up to 16 characters.

Command Default

None.

Examples

This example shows how to delete a server named test from the SNMP trap receiver list:

```
> config snmp trapreceiver delete test
```

Related Commands

show snmp trap

config snmp trapreceiver mode

To send or disable sending traps to a selected server, use the **config snmp trapreceiver mode** command.

config snmp trapreceiver mode {enable | disable} *name*

Syntax Description

enable	Enables an SNMP trap receiver.
disable	Disables an SNMP trap receiver.
<i>name</i>	SNMP community name.

Command Default

None.

Usage Guidelines

This command enables or disables the Cisco wireless LAN controller from sending the traps to the selected server.

Examples

This example shows how to disable an SNMP trap receiver from sending traps to a server named server1:

```
> config snmp trapreceiver mode disable server1
```

Related Commands

show snmp trap

config snmp v3user create

To create a version 3 SNMP user, use the **config snmp v3user create** command.

config snmp v3user create *username* {**ro** | **rw**} {**none** | **hmacmd5** | **hmacsha**} {**none** | **des** | **aescfb128**} [*auth_key*] [*encrypt_key*]

Syntax Description

<i>username</i>	Version 3 SNMP username.
ro	Specifies a read-only user privilege.
rw	Specifies a read-write user privilege.
none	Specifies if no authentication is required.
hmacmd5	Specifies Hashed Message Authentication Coding Message Digest 5 (HMAC-MD5) for authentication.
hmacsha	Specifies Hashed Message Authentication Coding-Secure Hashing Algorithm (HMAC-SHA) for authentication.
none	Specifies if no encryption is required.
des	Specifies to use Cipher Block Chaining-Digital Encryption Standard (CBC-DES) encryption.
aescfb128	Specifies to use Cipher Feedback Mode-Advanced Encryption Standard-128 (CFB-AES-128) encryption.
<i>auth_key</i>	(Optional) Authentication key for the HMAC-MD5 or HMAC-SHA authentication protocol.
<i>encrypt_key</i>	(Optional) Encryption key for the CBC-DES or CFB-AES-128 encryption protocol.

Command Default

SNMP v3 username AccessMode Authentication Encryption

----- Read/Write ----- HMAC-SHA ----- CFB-AES

Examples

This example shows how to add an SNMP username named test with read-only privileges and no encryption or authentication:

```
> config snmp v3user create test ro none none
```

Related Commands

`show snmpv3user`

config snmp v3user delete

To delete a version 3 SNMP user, use the **config snmp v3user delete** command.

config snmp v3user delete *username*

Syntax Description

<i>username</i>	Username to delete.

Command Default

None.

Examples

This example shows how to remove an SNMP user named test:

```
> config snmp v3user delete test
```

Related Commands

show snmp v3user

config snmp version

To enable or disable selected SNMP versions, use the **config snmp version** command.

config snmp version {v1 | v2 | v3} {enable | disable}

Syntax Description

v1	Specifies an SNMP version to enable or disable.
v2	Specifies an SNMP version to enable or disable.
v3	Specifies an SNMP version to enable or disable.
enable	Enables a specified version.
disable	Disables a specified version.

Command Default

All versions enabled.

Examples

This example shows how to enable SNMP version v1:

```
> config snmp version v1 enable
```

Related Commands

show snmpversion

config time manual

To set the system time, use the **config time manual** command.

config time manual *MM | DD | YY HH:MM:SS*

Syntax Description

<i>MM/DD/YY</i>	Date.
<i>HH:MM:SS</i>	Time.

Command Default

None.

Examples

This example shows how to configure the system date to 04/04/2010 and time to 15:29:00:

```
> config time manual 04/04/2010 15:29:00
```

Related Commands

show time

config time ntp

To set the Network Time Protocol (NTP), use the **config time ntp** command.

config time ntp {**auth** {**enable** *server_index* *key_index* | **disable** *server_index*} } | {**interval** *seconds*} | {**key-auth** {**add** *key_index* **md5** {**ascii** | **hex**} *key_value* | **delete** *key_index*} } | {**server** *server_index* *ip-address*}

Syntax Description

auth	Configures the NTP authentication.
enable	Enables the NTP authentication.
<i>server_index</i>	NTP server index.
<i>key_index</i>	Key index between 1 and 4294967295.
disable	Disables the NTP authentication.
interval	Configures the NTP polling interval.
<i>seconds</i>	NTP polling interval in seconds (between 3600 and 604800).
key-auth	Configures the NTP authentication key.
add	Adds an NTP authentication key.
md5	Specifies the authentication protocol.
ascii	Specifies the ASCII key format (a maximum of 16 characters).
hex	Specifies the hexadecimal key format (a maximum of 32 digits).
delete	Deletes an authentication key.
server	Configures the NTP servers.
<i>ip_address</i>	NTP server's IP address. Use 0.0.0.0 to delete the entry.

Command Default

None.

Examples

This example shows how to configure the NTP polling interval to 7000 seconds:

```
> config time ntp interval 7000
```

This example shows how to enable NTP authentication where the server index is 4 and the key index is 1:

```
> config time ntp auth enable 4 1
```

This example shows how to add an NTP authentication key of value ff where the key format is in hexadecimal characters and the key index is 1:

```
> config time ntp key-auth add 1 md5 hex ff
```

This example shows how to add an NTP authentication key of value ff where the key format is in ASCII characters and the key index is 1:

```
> config time ntp key-auth add 1 md5 ascii ciscokey
```

Related Commands

show ntp-keys

config time timezone

To configure the system time zone, use the **config time timezone** command.

config time timezone {**enable** | **disable**} *delta_hours delta_mins*

Syntax Description

enable	Enables daylight saving time.
disable	Disables daylight saving time.
<i>delta_hours</i>	Local hour difference from the Universal Coordinated Time (UCT).
<i>delta_mins</i>	Local minute difference from UCT.

Command Default

None.

Examples

This example shows how to enable the daylight saving time:

```
> config time timezone enable 2 0
```

Related Commands

show time

config time timezone location

To set the location of the time zone in order to have daylight saving time set automatically when it occurs, use the **config time timezone location** command.

config time timezone location *location_index*

Syntax Description*location_index*

Number representing the time zone required. The time zones are as follows:

- (GMT-12:00) International Date Line West
- (GMT-11:00) Samoa
- (GMT-10:00) Hawaii
- (GMT-9:00) Alaska
- (GMT-8:00) Pacific Time (US and Canada)
- (GMT-7:00) Mountain Time (US and Canada)
- (GMT-6:00) Central Time (US and Canada)
- (GMT-5:00) Eastern Time (US and Canada)
- (GMT-4:00) Atlantic Time (Canada)
- (GMT-3:00) Buenos Aires (Argentina)
- (GMT-2:00) Mid-Atlantic
- (GMT-1:00) Azores
- (GMT) London, Lisbon, Dublin, Edinburgh (default value)
- (GMT +1:00) Amsterdam, Berlin, Rome, Vienna
- (GMT +2:00) Jerusalem
- (GMT +3:00) Baghdad
- (GMT +4:00) Muscat, Abu Dhabi
- (GMT +4:30) Kabul
- (GMT +5:00) Karachi, Islamabad, Tashkent
- (GMT +5:30) Colombo, Kolkata, Mumbai, New Delhi
- (GMT +5:45) Katmandu
- (GMT +6:00) Almaty, Novosibirsk
- (GMT +6:30) Rangoon
- (GMT +7:00) Saigon, Hanoi, Bangkok, Jakarta
- (GMT +8:00) Hong Kong, Beijing, Chongqing
- (GMT +9:00) Tokyo, Osaka, Sapporo
- (GMT +9:30) Darwin
- (GMT+10:00) Sydney, Melbourne, Canberra
- (GMT+11:00) Magadan, Solomon Is., New Caledonia
- (GMT+12:00) Kamchatka, Marshall Is., Fiji
- (GMT+12:00) Auckland (New Zealand)

Command Default

None.

Examples

This example shows how to set the location of the time zone in order to set the daylight saving time to location index 10 automatically:

```
> config time timezone location 10
```

Related Commands

show time

config trapflags 802.11-Security

To enable or disable sending 802.11 security-related traps, use the **config trapflags 802.11-Security** command.

config trapflags 802.11-Security wepDecryptError {enable | disable}

Syntax Description

enable	Enables sending 802.11 security-related traps.
disable	Disables sending 802.11 security-related traps.

Command Default

Enabled.

Examples

This example shows how to disable the 802.11 security related traps:

```
> config trapflags 802.11-Security wepDecryptError disable
```

Related Commands

show trapflags

config trapflags aaa

To enable or disable the sending of AAA server-related traps, use the **config trapflags aaa** command.

config trapflags aaa {auth | servers} {enable | disable}

Syntax Description

auth	Enables trap sending when an AAA authentication failure occurs for management user, net user, or MAC filter.
servers	Enables trap sending when no RADIUS servers are responding.
enable	Enables the sending of AAA server-related traps.
disable	Disables the sending of AAA server-related traps.

Command Default

Enabled.

Examples

This example shows how to enable the sending of AAA server-related traps:

```
> config trapflags aaa auth enable
```

Related Commands

show watchlist

config trapflags adjchannel-rogueap

To configure trap notifications when a rogue access point is detected at the adjacent channel, use the **config trapflags adjchannel-rogueap** command.

config trapflags adjchannel-rogueap {enable | disable}

Syntax Description

enable	Enables trap notifications when a rogue access point is detected at the adjacent channel.
disable	Disables trap notifications when a rogue access point is detected at the adjacent channel.

Command Default

None.

Examples

This example shows how to enable trap notifications when a rogue access point is detected at the adjacent channel:

```
> config trapflags adjchannel-rogueap enable
```

Related Commands

config trapflags 802.11-Security
config trapflags aaa
config trapflags ap
config trapflags authentication
config trapflags client
config trapflags configsave
config trapflags IPsec
config trapflags linkmode
config trapflags multiusers
config trapflags mesh
config trapflags strong-pwdcheck
config trapflags rfid
config trapflags rogueap
show trapflags

config trapflags ap

To enable or disable the sending of Cisco lightweight access point traps, use the **config trapflags ap** command.

config trapflags ap {register | interfaceUp} {enable | disable}

Syntax Description

register	Enables sending a trap when a Cisco lightweight access point registers with Cisco switch.
interfaceUp	Enables sending a trap when a Cisco lightweight access point interface (A or B) comes up.
enable	Enables sending access point-related traps.
disable	Disables sending access point-related traps.

Command Default

Enabled.

Examples

This example shows how to prevent traps from sending access point-related traps:

```
> config trapflags ap register disable
```

Related Commands

show trapflags

config trapflags authentication

To enable or disable sending traps with invalid SNMP access, use the **config trapflags authentication** command.

config trapflags authentication {enable | disable}

Syntax Description

enable	Enables sending traps with invalid SNMP access.
disable	Disables sending traps with invalid SNMP access.

Command Default

Enabled.

Examples

This example shows how to prevent sending traps on invalid SNMP access:

```
> config trapflags authentication disable
```

Related Commands

show trapflags

config trapflags client

To enable or disable the sending of client-related DOT11 traps, use the **config trapflags client** command.

config trapflags client {802.11-associate 802.11-disassociate | 802.11-deauthenticate | 802.11-authfail | 802.11-assocfail | authentication | excluded} {enable | disable}

Syntax Description		
	802.11-associate	Enables the sending of Dot11 association traps to clients.
	802.11-disassociate	Enables the sending of Dot11 disassociation traps to clients.
	802.11-deauthenticate	Enables the sending of Dot11 deauthentication traps to clients.
	802.11-authfail	Enables the sending of Dot11 authentication fail traps to clients.
	802.11-assocfail	Enables the sending of Dot11 association fail traps to clients.
	authentication	Enables the sending of authentication success traps to clients.
	excluded	Enables the sending of excluded trap to clients.
	enable	Enables sending of client-related DOT11 traps.
	disable	Disables sending of client-related DOT11 traps.

Command Default Disabled.

Examples This example shows how to enable the sending of Dot11 disassociation trap to clients:

```
> config trapflags client 802.11-disassociate enable
```

Related Commands show trapflags

config trapflags client max-warning-threshold

To configure the threshold value of the number of clients that associate with the controller, after which an SNMP trap and a syslog message is sent to the controller, use the **config trapflags client max-warning-threshold** command.

config trapflags client max-warning-threshold {threshold | enable | disable}

Syntax Description

threshold	Configures the threshold percentage value of the number of clients that associate with the controller, after which an SNMP trap and a syslog message is sent to the controller. The range is from 80 to 100. The minimum interval between two warnings is 10 mins You cannot configure this interval.
enable	Enables the generation of the traps and syslog messages.
disable	Disables the generation of the traps and syslog messages.

Command Default

90.

Usage Guidelines

This table lists the maximum number of clients for different controllers.

Table 3: Maximum Number of Clients Supported on Different Controllers

Controller	Maximum Number of Supported Clients
Cisco 5500 Series Controllers	7000
Cisco 2500 Series Controllers	500
Cisco Wireless Services Module 2	15000
Cisco Flex 7500 Series Controllers	64000
Cisco 8500 Series Controllers	64000
Cisco Virtual Wireless LAN Controllers	30000

Examples

This example shows how to configure the threshold value of the number of clients that associate with the controller:

```
> config trapflags client max-warning-threshold 80
```

Related Commands

show trapflags
config trapflags client

config trapflags configsave

To enable or disable the sending of configuration-saved traps, use the **config trapflags configsave** command.

config trapflags configsave {enable | disable}

Syntax Description

enable	Enables sending of configuration-saved traps.
disable	Disables the sending of configuration-saved traps.

Command Default

Enabled.

Examples

This example shows how to enable the sending of configuration-saved traps:

```
> config trapflags configsave enable
```

Related Commands

show trapflags

config trapflags IPsec

To enable or disable the sending of IPsec traps, use the **config trapflags IPsec** command.

config trapflags IPsec {esp-auth | esp-reply | invalidSPI | ike-neg | suite-neg | invalid-cookie} {enable | disable}

Syntax Description

esp-auth	Enables the sending of IPsec traps when an ESP authentication failure occurs.
esp-reply	Enables the sending of IPsec traps when an ESP replay failure occurs.
invalidSPI	Enables the sending of IPsec traps when an ESP invalid SPI is detected.
ike-neg	Enables the sending of IPsec traps when an IKE negotiation failure occurs.
suite-neg	Enables the sending of IPsec traps when a suite negotiation failure occurs.
invalid-cookie	Enables the sending of IPsec traps when a Isakamp invalid cookie is detected.
enable	Enables sending of IPsec traps.
disable	Disables sending of IPsec traps.

Command Default

Enabled.

Examples

This example shows how to enable the sending of IPsec traps when ESP authentication failure occurs:

```
> config trapflags IPsec esp-auth enable
```

Related Commands

show trapflags

config trapflags linkmode

To enable or disable Cisco wireless LAN controller level link up/down trap flags, use the **config trapflags linkmode** command.

config trapflags linkmode {enable | disable}

Syntax Description	enable	Enables Cisco wireless LAN controller level link up/down trap flags.
	disable	Disables Cisco wireless LAN controller level link up/down trap flags.

Command Default Enabled.

Examples This example shows how to enable the Cisco wireless LAN controller level link up/down trap:

```
> config trapflags linkmode disable
```

Related Commands **show trapflags**

config trapflags mesh

To configure trap notifications when a mesh access point is detected, use the **config trapflags mesh** command.

config trapflags mesh {enable | disable}

Syntax Description

enable	Enables trap notifications when a mesh access point is detected.
disable	Disables trap notifications when a mesh access point is detected.

Command Default

None.

Examples

This example shows how to enable trap notifications when a mesh access point is detected:

```
> config trapflags mesh enable
```

Related Commands

config trapflags 802.11-Security
config trapflags aaa
config trapflags ap
config trapflags adjchannel-rogueap
config trapflags authentication
config trapflags client
config trapflags configsave
config trapflags IPsec
config trapflags linkmode
config trapflags multiusers
config trapflags strong-pwdcheck
config trapflags rfid
config trapflags rogueap
show trapflags

config trapflags multiusers

To enable or disable the sending of traps when multiple logins are active, use the **config trapflags multiusers** command.

config trapflags multiusers {enable | disable}

Syntax Description	enable	Enables the sending of traps when multiple logins are active.
	disable	Disables the sending of traps when multiple logins are active.

Command Default Enabled.

Examples This example shows how to disable the sending of traps when multiple logins are active:

```
> config trapflags multiusers disable
```

Related Commands **show trapflags**

config trapflags rfid

To configure the threshold value of the maximum number of radio frequency identification (RFID) tags, after which an SNMP trap and a syslog message is sent to the controller, use the **config trapflags rfid** command.

config trapflags rfid {threshold | enable | disable}

Syntax Description

threshold	Configures the threshold percentage value of the maximum number of RFID tags, after which an SNMP trap and a syslog message is sent to the controller. The range is from 80 to 100. The traps and syslog messages are generated every 10 minutes. You cannot configure this interval.
enable	Enables the generation of the traps and syslog messages.
disable	Disables the generation of the traps and syslog messages.

Command Default

90.

Usage Guidelines

This table shows the maximum number of RFID tags supported on different controllers:

Table 4: Maximum Number of RFID Tags Supported on Different Controllers

Controller	Maximum Number of Supported Clients
Cisco 5500 Series Controllers	5000
Cisco 2500 Series Controllers	500
Cisco Wireless Services Module 2	10000
Cisco Flex 7500 Series Controllers	50000
Cisco 8500 Series Controllers	50000
Cisco Virtual Wireless LAN Controllers	3000

Examples

This example shows how to configure the threshold value of the maximum number of RFID tags:

```
> config trapflags rfid 80
```

Related Commands

config trapflags 802.11-Security
config trapflags aaa
config trapflags ap

config trapflags adjchannel-rogueap
config trapflags authentication
config trapflags client
config trapflags configsave
config trapflags IPsec
config trapflags linkmode
config trapflags multiusers
config trapflags mesh
config trapflags strong-pwdcheck
config trapflags rogueap
config trapflags mesh
show trapflags

config trapflags rogueap

To enable or disable sending rogue access point detection traps, use the **config trapflags rogueap** command.

config trapflags rogueap {enable | disable}

Syntax Description

enable	Enables the sending of rogue access point detection traps.
disable	Disables the sending of rogue access point detection traps.

Command Default

Enabled

Examples

This example shows how to disable the sending of rogue access point detection traps:

```
> config trapflags rogueap disable
```

Related Commands

config rogue ap classify
config rogue ap friendly
config rogue ap rldp
config rogue ap ssid
config rogue ap timeout
config rogue ap valid-client
show rogue ap clients
show rogue ap detailed
show rogue ap summary
show rogue ap friendly summary
show rogue ap malicious summary
show rogue ap unclassified summary
show trapflags

config trapflags rrm-params

To enable or disable the sending of Radio Resource Management (RRM) parameters traps, use the **config trapflags rrm-params** command.

config trapflags rrm-params {**tx-power** | **channel** | **antenna**} {**enable** | **disable**}

Syntax Description

tx-power	Enables trap sending when the RF manager automatically changes the tx-power level for the Cisco lightweight access point interface.
channel	Enables trap sending when the RF manager automatically changes the channel for the Cisco lightweight access point interface.
antenna	Enables trap sending when the RF manager automatically changes the antenna for the Cisco lightweight access point interface.
enable	Enables the sending of RRM parameter-related traps.
disable	Disables the sending of RRM parameter-related traps.

Command Default

Enabled.

Examples

This example shows how to enable the sending of RRM parameter-related traps:

```
> config trapflags rrm-params tx-power enable
```

Related Commands

show trapflags

config trapflags rrm-profile

To enable or disable the sending of Radio Resource Management (RRM) profile-related traps, use the **config trapflags rrm-profile** command.

config trapflags rrm-profile {load | noise | interference | coverage} {enable | disable}

Syntax Description

load	Enables trap sending when the load profile maintained by the RF manager fails.
noise	Enables trap sending when the noise profile maintained by the RF manager fails.
interference	Enables trap sending when the interference profile maintained by the RF manager fails.
coverage	Enables trap sending when the coverage profile maintained by the RF manager fails.
enable	Enables the sending of RRM profile-related traps.
disable	Disables the sending of RRM profile-related traps.

Command Default

Enabled.

Examples

This example shows how to disable the sending of RRM profile-related traps:

```
> config trapflags rrm-profile load disable
```

Related Commands

show trapflags

config trapflags stpmode

To enable or disable the sending of spanning tree traps, use the **config trapflags stpmode** command.

config trapflags stpmode {enable | disable}

Syntax Description

enable	Enables the sending of spanning tree traps.
disable	Disables the sending of spanning tree traps.

Command Default

Enabled.

Examples

This example shows how to disable the sending of spanning tree traps:

```
> config trapflags stpmode disable
```

Related Commands

show trapflags

config trapflags strong-pwdcheck

To configure trap notifications for strong password checks, use the **config trapflags strong-pwdcheck** command.

config trapflags strong-pwdcheck {enable | disable}

Syntax Description

enable	Enables trap notifications for strong password checks.
disable	Disables trap notifications for strong password checks.

Command Default

None.

Examples

This example shows how to enable trap notifications for strong password checks:

```
> config trapflags strong-pwdcheck enable
```

Related Commands

config trapflags 802.11-Security
config trapflags aaa
config trapflags ap
config trapflags adjchannel-rogueap
config trapflags authentication
config trapflags client
config trapflags configsave
config trapflags IPsec
config trapflags linkmode
config trapflags multiusers
config trapflags mesh
config trapflags rfid
config trapflags rogueap
show trapflags

config trapflags wps

To enable or disable Wireless Protection System (WPS) trap sending, use the **config trapflags wps** command.

config trapflags wps {enable | disable}

Syntax Description

enable	Enables WPS trap sending.

disable	Disables WPS trap sending.

Command Default

Enabled.

Examples

This example shows how to disable the WPS traps sending:

```
> config trapflags wps disable
```

Related Commands

show trapflags

save config

To save the controller configurations, use the **save config** command.

save config

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to save the controller settings:

```
> save config
Are you sure you want to save? (y/n) y
Configuration Saved!
```

Related Commands	show sysinfo

Timeout Commands

This section lists the timeout commands of the controller:

config 802.11 cac video tspec-inactivity-timeout

To process or ignore the Call Admission Control (CAC) Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac video tspec-inactivity-timeout** command.

config 802.11 {a | b} cac video tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
ab	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config command**.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to process the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout enable
```

This example shows how to ignore the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout ignore
```

Related Commands

config 802.11 cac video acm

```
config 802.11 cac video max-bandwidth  
config 802.11 cac video roam-bandwidth
```

config 802.11 cac voice tspec-inactivity-timeout

To process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac voice tspec-inactivity-timeout** command.

config 802.11 {a | b} cac voice tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
> config 802.11 cac voice tspec-inactivity-timeout enable
```

Related Commands

config 802.11 cac voice load-based
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice acm

config 802.11cac voice max-bandwidth

config 802.11 cac voice stream-size

config advanced timers

To configure a system timer, use the **config advanced timers** command.

```
config advanced timers {ap-discovery-timeout discovery-timeout | ap-fast-heartbeat {local | flexconnect
| all} {enable | disable} fast_heartbeat_seconds | ap-heartbeat-timeout heartbeat_seconds |
ap-primary-discovery-timeout primary_discovery_timeout | ap-primed-join-timeout primed_join_timeout
| auth-timeout auth_timeout | pkt-fwd-watchdog {enable | disable} {watchdog_timer | default} |
eap-identity-request-delay eap_identity_request_delay | eap-timeout eap_timeout}
```

Syntax Description

ap-discovery-timeout	Configures Cisco lightweight access point discovery timeout value.
<i>discovery-timeout</i>	Cisco lightweight access point discovery timeout value. The range is from 1 to 10 seconds.
ap-fast-heartbeat	Configures the fast heartbeat timer, which reduces the amount of time it takes to detect a controller failure in access points.
local	Configures the fast heartbeat interval for access points in local mode only.
flexconnect	Configures the fast heartbeat interval for access points in FlexConnect mode only.
all	Configures the fast heartbeat interval for all the access points.
enable	Enables the fast heartbeat interval.
disable	Disables the fast heartbeat interval.
<i>fast_heartbeat_seconds</i>	Small heartbeat interval, which reduces the amount of time it takes to detect a controller failure. The range is from 1 to 10 seconds.
ap-heartbeat-timeout	Configures Cisco lightweight access point heartbeat timeout value.
<i>heartbeat_seconds</i>	Cisco lightweight access point heartbeat timeout value. The range is from 1 to 30 seconds. This value should be at least three times larger than the fast heartbeat timer.
ap-primary-discovery-timeout	Configures the access point primary discovery request timer.
<i>primary_discovery_timeout</i>	Access point primary discovery request timer. The range is from 30 to 3600 seconds.
ap-primed-join-timeout	Configures AP primed discovery timeout value.
<i>primed_join_timeout</i>	Access point primed discovery timeout value. The range is from 120 to 43200 seconds.
auth-timeout	Configures the authentication timeout.

<i>auth_timeout</i>	Authentication response timeout value, in seconds, from 10 to 600.
pkt-fwd-watchdog	Configures the packet forwarding watchdog timer to protect from fastpath deadlock.
<i>watchdog_timer</i>	Packet forwarding watchdog timer, in seconds. The range is from 60 to 300.
default	Configures the watchdog timer to the default value of 240 seconds.
eap-identity-request-delay	Configures the advanced Extensible Authentication Protocol (EAP) identity request delay, in seconds.
<i>eap_identity_request_delay</i>	Advanced EAP identity request delay, in seconds. The range is from 0 to 10.
eap-timeout	Configures the EAP expiration timeout.
<i>eap_timeout</i>	EAP timeout value, in seconds. The range is from 8 to 120.

Command Default

The default access point discovery timeout is 10 seconds.

The default access point heartbeat timeout is 30 seconds.

The default access point primary discovery request timer is 120 seconds.

The default authentication timeout is 10 seconds.

The default packet forwarding watchdog timer is 240 seconds.

Usage Guidelines

The Cisco lightweight access point discovery timeout indicates how often a Cisco WLC attempts to discover unconnected Cisco lightweight access points.

The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keepalive signal to the Cisco WLC.

Examples

The following example shows how to configure an access point discovery timeout with a timeout value of 20:

```
Device > config advanced timers ap-discovery-timeout 20
```

The following example shows how to enable the fast heartbeat interval for an access point in FlexConnect mode:

```
Device > config advanced timers ap-fast-heartbeat flexconnect enable 8
```

The following example shows how to configure the authentication timeout to 20 seconds:

```
Device > config advanced timers auth-timeout 20
```

Related Commands show advanced timers

config dhcp timeout

To configure a DHCP timeout, use the **config dhcp timeout** command.

config dhcp timeout *timeout-value*

Syntax Description

<i>timeout-value</i>	Timeout value in the range of 5 to 120 seconds.

Command Default

None.

Examples

This example shows how to set the DHCP timeout to 10 seconds:

```
> config dhcp timeout 10
```

Related Commands

- config dhcp proxy
- config dhcp timeout
- config interface dhcp
- config wlan dhcp_server
- debug dhcp
- debug dhcp service-port
- debug disable-all
- show dhcp
- show dhcp proxy

config ldap

To configure the Lightweight Directory Access Protocol (LDAP) server settings, use the **config ldap** command.

config ldap {**add** | **delete** | **enable** | **disable** | **retransmit-timeout**} *index*

Syntax Description

add	Specifies that an LDAP server is being added.
delete	Specifies that an LDAP server is being deleted.
enable	Specifies that an LDAP serve is enabled.
disable	Specifies that an LDAP server is disabled.
retransmit-timeout	Changes the default retransmit timeout for an LDAP server.
<i>index</i>	LDAP server index. The range is from 1 to 17.

Command Default

None.

Examples

This example shows how to enable LDAP server index 10:

```
> config ldap enable 10
```

Related Commands

config ldap add
config ldap simple-bind
show ldap summary

config remote-lan session-timeout

To configure client session timeout, use the **config remote-lan session-timeout** command.

config remote-lan session-timeout *remote-lan-id seconds*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>seconds</i>	Timeout or session duration in seconds. A value of zero is equivalent to no timeout.

Command Default

None.

Examples

This example shows how to configure the client session timeout to 6000 seconds for a remote LAN with ID 1:

```
> config remote-lan session-timeout 1 6000
```

Related Commands

show remote-lan

config network usertimeout

To change the timeout for idle client sessions, use the **config network usertimeout** command.

config network usertimeout *seconds*

Syntax Description	<i>seconds</i>	Timeout duration in seconds. The minimum value is 90. The default value is 300.
Command Default	300.	
Usage Guidelines	Use this command to set the idle client session duration on the Cisco wireless LAN controller. The minimum duration is 90 seconds.	
Examples	This example shows how to configure the idle session timeout to 1200 seconds: > config network usertimeout 1200	
Related Commands	show network summary	

config radius acct retransmit-timeout

To change the default transmission timeout for a RADIUS accounting server for the Cisco wireless LAN controller, use the **config radius acct retransmit-timeout** command.

config radius acct retransmit-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Number of seconds (from 2 to 30) between retransmissions.

Command Default

None.

Examples

This example shows how to configure retransmission timeout value 5 seconds between the retransmission:

```
> config radius acct retransmit-timeout 5
```

Related Commands

show radius acct statistics

config radius auth mgmt-retransmit-timeout

To configure a default RADIUS server retransmission timeout for management users, use the **config radius auth mgmt-retransmit-timeout** command.

config radius auth mgmt-retransmit-timeout *index retransmit-timeout*

Syntax Description	<i>index</i>	RADIUS server index.
	<i>retransmit-timeout</i>	Timeout value. The range is from 1 to 30 seconds.

Command Default None.

Examples This example shows how to configure a default RADIUS server retransmission timeout for management users:

```
> config radius auth mgmt-retransmit-timeout 1 10
```

Related Commands **config radius auth management**

config radius auth retransmit-timeout

To change a default transmission timeout for a RADIUS authentication server for the Cisco wireless LAN controller, use the **config radius auth retransmit-timeout** command.

config radius auth retransmit-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Number of seconds (from 2 to 30) between retransmissions.

Command Default

None.

Examples

This example shows how to configure a retransmission timeout of 5 seconds for a RADIUS authentication server:

```
> config radius auth retransmit-timeout 5
```

Related Commands

show radius auth statistics

config radius auth server-timeout

To configure a retransmission timeout value for a RADIUS accounting server, use the **config radius auth server-timeout** command.

config radius auth server-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Timeout value. The range is from 2 to 30 seconds.

Command Default

The default timeout is 2 seconds.

Examples

This example shows how to configure a server timeout value of 2 seconds for RADIUS authentication server index 10:

```
> config radius auth server-timeout 2 10
```

Related Commands

show radius auth statistics
show radius summary

config rogue ap timeout

To specify the number of seconds after which the rogue access point and client entries expire and are removed from the list, use the **config rogue ap timeout** command.

config rogue ap timeout *seconds*

Syntax Description

<i>seconds</i>	Value of 240 to 3600 seconds (inclusive), with a default value of 1200 seconds.

Command Default

1200 seconds.

Examples

This example shows how to set an expiration time for entries in the rogue access point and client list to 2400 seconds:

```
> config rogue ap timeout 2400
```

Related Commands

- config rogue ap classify**
- config rogue ap friendly**
- config rogue ap rldp**
- config rogue ap ssid**
- config rogue rule**
- config trapflags rogueap**
- show rogue ap clients**
- show rogue ap detailed**
- show rogue ap summary**
- show rogue ap friendly summary**
- show rogue ap malicious summary**
- show rogue ap unclassified summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

config tacacs athr mgmt-server-timeout

To configure a default TACACS+ authorization server timeout for management users, use the **config tacacs athr mgmt-server-timeout** command.

config tacacs athr mgmt-server-timeout *index timeout*

Syntax Description

<i>index</i>	TACACS+ authorization server index.
<i>timeout</i>	Timeout value. The range is 1 to 30 seconds.

Command Default

None.

Examples

This example shows how to configure a default TACACS+ authorization server timeout for management users:

```
> config tacacs athr mgmt-server-timeout 1 10
```

Related Commands

config tacacs athr

config tacacs auth mgmt-server-timeout

To configure a default TACACS+ authentication server timeout for management users, use the **config tacacs auth mgmt-server-timeout** command.

config tacacs auth mgmt-server-timeout *index timeout*

Syntax Description

<i>index</i>	TACACS+ authentication server index.
<i>timeout</i>	Timeout value. The range is 1 to 30 seconds.

Command Default

None.

Examples

This example shows how to configure a default TACACS+ authentication server timeout for management users:

```
> config tacacs auth mgmt-server-timeout 1 10
```

Related Commands

config tacacs auth

config rfid auto-timeout

To configure an automatic timeout of radio frequency identification (RFID) tags, use the **config rfid auto-timeout** command.

config rfid auto-timeout {enable | disable}

Syntax Description	enable	Enables an automatic timeout.
	disable	Disables an automatic timeout.

Command Default None.

Examples This example shows how to enable an automatic timeout of RFID tags:

```
> config rfid auto-timeout enable
```

Related Commands

- show rfid summary
- config rfid status
- config rfid timeout

config rfid timeout

To configure a static radio frequency identification (RFID) tag data timeout, use the **config rfid timeout** command.

config rfid timeout *seconds*

Syntax Description

<i>seconds</i>	Timeout in seconds (from 60 to 7200).

Command Default

None.

Examples

This example shows how to configure a static RFID tag data timeout of 60 seconds:

```
> config rfid timeout 60
```

Related Commands

show rfid summary
config rfid statistics

config wlan session-timeout

To change the timeout of wireless LAN clients, use the **config wlan session-timeout** command.

config wlan timeout {*wlan_id* | **foreignAp**} *seconds*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>seconds</i>	Timeout or session duration in seconds. A value of zero is equivalent to no timeout.

Command Default

None.

Examples

This example shows how to configure the client timeout to 6000 seconds for WLAN ID 1:

```
> config wlan session-timeout 1 6000
```

Related Commands

show wlan

config wlan usertimeout

To configure the timeout for idle client sessions for a WLAN, use the **config wlan usertimeout** command.

config wlan usertimeout *timeout wlan_id*

Syntax Description

<i>timeout</i>	Timeout for idle client sessions for a WLAN. If the client sends traffic less than the threshold, the client is removed on timeout. The range is from 15 to 100000 seconds.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

300 seconds.

Usage Guidelines

The timeout value that you configure here overrides the global timeout that you define using the command **config network usertimeout**.

Examples

This example shows how to configure the idle client sessions for a WLAN:

```
> config wlan usertimeout 100 1
```

Related Commands

config network usertimeout
config wlan user-idle-threshold

config wlan security wpa akm ft

To configure authentication key-management using 802.11r fast transition 802.1X, use the **config wlan security wpa akm ft** command.

config wlan security wpa akm ft [**over-the-air** | **over-the-ds** | **psk** | [**reassociation-timeout** *seconds*]] {**enable** | **disable**} *wlan_id*

Syntax Description

over-the-air	(Optional) Configures 802.11r fast transition roaming over-the-air support.
over-the-ds	(Optional) Configures 802.11r fast transition roaming DS support.
psk	(Optional) Configures 802.11r fast transition PSK support.
reassociation-timeout	(Optional) Configures the reassociation deadline interval. The valid range is between 1 to 100 seconds. The default value is 20 seconds.
<i>seconds</i>	Reassociation deadline interval in seconds.
enable	Enables 802.11r fast transition 802.1X support.
disable	Disables 802.11r fast transition 802.1X support.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure authentication key-management using 802.11r fast transition:

```
> config wlan security wpa akm ft reassociation-timeout 25 1
```

Related Commands

show wlan

config wlan security ft

To configure 802.11r fast transition parameters, use the **config wlan security ft** command.

config wlan security ft {enable | disable | reassociation-timeout *timeout-in-seconds*} *wlan_id*

Syntax Description

enable	Enables 802.11r fast transition roaming support.
disable	Disables 802.11r fast transition roaming support.
reassociation-timeout	Configures reassociation deadline interval.
<i>timeout-in-seconds</i>	Reassociation timeout value in seconds. The valid range is 1 to 100 seconds.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

Ensure that you have disabled the WLAN before you proceed.

Examples

This example shows how to enable 802.11r fast transition roaming support on WLAN 2:

```
> config wlan security ft enable 2
```

This example shows how to set the reassociation timeout value of 20 seconds for 802.11r fast transition roaming support on WLAN 2:

```
> config wlan security ft reassociation-timeout 20 2
```

Related Commands

show wlan

Clearing Configurations, Log files, and Other Actions

Use the **clear** command to clear existing configurations, log files, and other functions.

clear acl counters

To clear the current counters for an access control list (ACL), use the **clear acl counters** command.

clear acl counters *acl_name*

Syntax Description

<i>acl_name</i>	ACL name.

Command Default

None.

Usage Guidelines

Note

ACL counters are available only on the following controllers: Cisco 4400 Series Controller, Cisco WiSM, and Catalyst 3750G Integrated Wireless LAN Controller Switch.

Examples

This example shows how to clear the current counters for acl1:

```
> clear acl counters acl1
```

Related Commands

config acl counter
show acl

clear ap-config

To clear (reset to the default values) a lightweight access point's configuration settings, use the **clear ap-config** command.

clear ap-config *ap_name*

Syntax Description

<i>ap_name</i>	Access point name.

Command Default

None.

Usage Guidelines

Entering this command does not clear the static IP address of the access point.

Examples

This example shows how to clear the access point's configuration settings for the access point named ap1240_322115:

```
> clear ap-config ap1240_322115
Clear ap-config will clear ap config and reboot the AP. Are you sure you want continue?
(y/n)
```

Related Commands

show ap config

clear ap-eventlog

To delete the existing event log and create an empty event log file for a specific access point or for all access points joined to the controller, use the **clear ap-eventlog** command.

clear ap-eventlog {*specific ap_name* | **all**}

Syntax Description

specific	Specifies a specific access point log file.
<i>ap_name</i>	Name of the access point for which the event log file will be emptied.
all	Deletes the event log for all access points joined to the controller.

Command Default

None.

Examples

This example shows how to delete the event log for all access points:

```
> clear ap-eventlog all
This will clear event log contents for all APs. Do you want continue? (y/n) :y
Any AP event log contents have been successfully cleared.
```

Related Commands

show ap eventlog

clear ap join stats

To clear the join statistics for all access points or for a specific access point, use the **clear ap join stats** command.

clear ap join stats {all | *ap_mac*}

Syntax Description

all	Specifies all access points.
<i>ap_mac</i>	Access point MAC address.

Command Default

None.

Examples

This example shows how to clear the join statistics of all the access points:

```
> clear ap join stats all
```

Related Commands

show ap config

clear arp

To clear the Address Resolution Protocol (ARP) table, use the **clear arp** command.

clear arp

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Examples

This example shows how to clear the ARP table:

```
> clear arp
Are you sure you want to clear the ARP cache? (y/n)
```

Related Commands

clear transfer
clear download datatype
clear download filename
clear download mode
clear download serverip
clear download start
clear upload datatype
clear upload filename
clear upload mode
clear upload path
clear upload serverip
clear upload start
clear stats port

clear avc statistics

To clear Application Visibility and Control (AVC) statistics of a client, guest LAN, remote LAN, or a WLAN use the **clear avc statistics** command.

clear avc statistics {**client** {**all** | *client-mac*} | **guest-lan** {**all** | *guest-lan-id*} | **remote-lan** {**all** | *remote-lan-id*} | **wlan** {**all** | *wlan-id*}}

Syntax Description

client	Clears AVC statistics of a client.
all	Clears AVC statistics of all clients.
<i>client-mac</i>	MAC address of a client.
guest-lan	Clears AVC statistics of a guest LAN.
all	Clears AVC statistics of all guest LANs.
<i>guest-lan-id</i>	Guest LAN Identifier between 1 and 5.
remote-lan	Clears AVC statistics of a remote LAN.
all	Clears AVC statistics of all remote LANs.
<i>remote-lan-id</i>	Remote LAN Identifier between 1 and 512.
wlan	Clears AVC statistics of a WLAN.
all	Clears AVC statistics of all WLANs.
<i>wlan-id</i>	WLAN Identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to clear the AVC statistics of a client:

```
> clear avc statistics client 00:21:1b:ea:36:60
```

Related Commands

config avc profile create
config avc profile delete
config avc profile rule
config wlan avc
show avc profile
show avc applications

show avc statistics

debug avc error

debug avc events

clear client tsm

To clear the traffic stream metrics (TSM) statistics for a particular access point or all the access points to which this client is associated, use the **clear client tsm** command.

clear client tsm {**802.11a** | **802.11b**} *client_mac* {*ap_mac* | **all**}

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b network.
<i>client_mac</i>	MAC address of the client.
<i>ap_mac</i>	MAC address of a Cisco lightweight access point.
all	Specifies all access points.

Command Default

None.

Examples

This example shows how to clear the TSM for the MAC address 00:40:96:a8:f7:98:

```
> clear client tsm 802.11a 00:40:96:a8:f7:98 all
```

Related Commands

clear upload start

clear config

To reset configuration data to factory defaults, use the **clear config** command.

clear config

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to reset the configuration data to factory defaults:

```
> clear config
Are you sure you want to clear the configuration? (y/n)
n
Configuration not cleared!
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download serverip**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**
- clear stats port**

clear ext-webauth-url

To clear the external web authentication URL, use the **clear ext-webauth-url** command.

clear ext-webauth-url

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the external web authentication URL:

```
> clear ext-webauth-url
URL cleared.
```

Related Commands

- clear transfer
- clear download datatype
- clear download filename
- clear download mode
- clear download serverip
- clear download start
- clear upload datatype
- clear upload filename
- clear upload mode
- clear upload path
- clear upload serverip
- clear upload start
- clear stats port

clear location rfid

To clear a specific radio frequency identification (RFID) tag or all of the RFID tags in the entire database, use the **clear location rfid** command.

clear location rfid {*mac_address* | **all**}

Syntax Description

<i>mac_address</i>	MAC address of a specific RFID tag.
all	Specifies all of the RFID tags in the database.

Command Default

None.

Examples

This example shows how to clear all of the RFID tags in the database:

```
> clear location rfid all
```

Related Commands

clear location statistics rfid
config location
show location
show location statistics rfid

clear location statistics rfid

To clear radio frequency identification (RFID) statistics, use the **clear location statistics rfid** command.

clear location statistics rfid

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to clear RFID statistics:

```
> clear location statistics rfid
```

Related Commands	config location show location show location statistics rfid

clear locp statistics

To clear the Location Protocol (LOCP) statistics, use the **clear locp statistics** command.

clear locp statistics

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to clear the statistics related to LOCP:

```
> clear locp statistics
```

Related Commands	clear nmsp statistics config nmsp notify-interval measurement show nmsp notify-interval summary show nmsp statistics show nmsp status

clear login-banner

To remove the login banner file from the controller, use the **clear login-banner** command.

clear login-banner

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to clear the login banner file:

```
> clear login-banner
```

Related Commands	transfer download datatype

clear lwapp private-config

To clear (reset to default values) an access point's current Lightweight Access Point Protocol (LWAPP) private configuration, which contains static IP addressing and controller IP address configurations, use the **clear lwapp private-config** command.

clear lwapp private-config

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines Enter the command on the access point console port.

Prior to changing the FlexConnect configuration on an access point using the access point's console port, the access point must be in standalone mode (not connected to a Cisco WLC) and you must remove the current LWAPP private configuration by using the **clear lwapp private-config** command.



Note The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

Examples This example shows how to clear an access point's current LWAPP private configuration:

```
AP# clear lwapp private-config
removing the reap config file flash:/lwapp_reap.cfg
```

Related Commands

- debug capwap
- debug capwap reap
- debug lwapp console cli
- show capwap reap association
- show capwap reap status

clear mdns service-database

To clear the multicast DNS service database, use the **clear mdns service-database** command.

clear mdns service-database {**all** | *service-name*

Syntax Description

all	Clears the mDNS service database.
<i>service-name</i>	Name of the mDNS service. The Cisco WLC clears the details of the mDNS service.

Command Default

None.

Usage Guidelines

The Cisco WLC snoops and learns about the mDNS service advertisements only if the service is available in the Master Services database.

Examples

This example shows how to clear the mDNS service database:

```
> clear mdns service-database all
```

Related Commands

config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
config mdns profile
debug mdns all
debug mdns error
debug mdns detail
debug mdns message

clear nmsp statistics

To clear the Network Mobility Services Protocol (NMSP) statistics, use the **clear nmsp statistics** command.

clear nmsp statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to delete the NMSP statistics log file:

```
> clear nmsp statistics
```

Related Commands

- clear locp statistics**
- config nmsp notify-interval measurement**
- show nmsp notify-interval summary**
- show nmsp status**

clear radius acct statistics

To clear the RADIUS accounting statistics on the controller, use the **clear radius acc statistics** command.

clear radius acct statistics [**index** | **all**]

Syntax Description

index	(Optional) Specifies the index of the RADIUS accounting server.
all	(Optional) Specifies all RADIUS accounting servers.

Command Default

None.

Examples

This example shows how to clear the RADIUS accounting statistics:

```
> clear radius acc statistics
```

Related Commands

show radius acct statistics

clear tacacs auth statistics

To clear the RADIUS authentication server statistics in the controller, use the **clear tacacs auth statistics** command.

clear tacacs auth statistics [**index** | **all**]

Syntax Description

index	(Optional) Specifies the index of the RADIUS authentication server.
all	(Optional) Specifies all RADIUS authentication servers.

Command Default

None.

Examples

This example shows how to clear the RADIUS authentication server statistics:

```
> clear tacacs auth statistics
```

Related Commands

show tacacs auth statistics
show tacacs summary
config tacacs auth

clear redirect-url

To clear the custom web authentication redirect URL on the Cisco Wireless LAN Controller, use the **clear redirect-url** command.

clear redirect-url

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the custom web authentication redirect URL:

```
> clear redirect-url
URL cleared.
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download path**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**

clear stats ap wlan

To clear the WLAN statistics, use the **clear stats ap wlan** command.

clear stats ap wlan *cisco_ap*

Syntax Description	
	<i>cisco_ap</i>
	Selected configuration elements.

Command Default	
	None.

Examples	
	This example shows how to clear the WLAN configuration elements of the access point <i>cisco_ap</i> :
	<pre>> clear stats ap wlan cisco_ap</pre>
	WLAN statistics cleared.

Related Commands	
	show ap stats
	show ap wlan

clear stats local-auth

To clear the local Extensible Authentication Protocol (EAP) statistics, use the **clear stats local-auth** command.

clear stats local-auth

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the local EAP statistics:

```
> clear stats local-auth
Local EAP Authentication Stats Cleared.
```

Related Commands

- config local-auth active-timeout**
- config local-auth eap-profile**
- config local-auth method fast**
- config local-auth user-credentials**
- debug aaa local-auth**
- show local-auth certificates**
- show local-auth config**
- show local-auth statistics**

clear stats mobility

To clear mobility manager statistics, use the **clear stats mobility** command.

clear stats mobility

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear mobility manager statistics:

```
> clear stats mobility
Mobility stats cleared.
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download serverip**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**
- clear stats port**

clear stats port

To clear statistics counters for a specific port, use the **clear stats port** command.

clear stats port *port*

Syntax Description

<i>port</i>	Physical interface port number.

Command Default

None.

Examples

This example shows how to clear the statistics counters for port 9:

```
> clear stats port 9
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download serverip**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**
- clear stats port**

clear stats radius

To clear the statistics for one or more RADIUS servers, use the **clear stats radius** command.

clear stats radius {auth | acct} {index | all}

Syntax Description

auth	Clears statistics regarding authentication.
acct	Clears statistics regarding accounting.
index	Specifies the index number of the RADIUS server to be cleared.
all	Clears statistics for all RADIUS servers.

Command Default

None.

Examples

This example shows how to clear the statistics for all RADIUS authentication servers:

```
> clear stats radius auth all
```

Related Commands

clear transfer
 clear download datatype
 clear download filename
 clear download mode
 clear download serverip
 clear download start
 clear upload datatype
 clear upload filename
 clear upload mode
 clear upload path
 clear upload serverip
 clear upload start
 clear stats port

clear stats switch

To clear all switch statistics counters on a Cisco wireless LAN controller, use the **clear stats switch** command.

clear stats switch

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear all switch statistics counters:

```
> clear stats switch
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download path**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**

clear stats tacacs

To clear the TACACS+ server statistics on the controller, use the **clear stats tacacs** command.

clear stats tacacs [**auth** | **athr** | **acct**] [**index** | **all**]

Syntax Description

auth	(Optional) Clears the TACACS+ authentication server statistics.
athr	(Optional) Clears the TACACS+ authorization server statistics.
acct	(Optional) Clears the TACACS+ accounting server statistics.
index	(Optional) Specifies index of the TACACS+ server.
all	(Optional) Specifies all TACACS+ servers.

Command Default

None.

Examples

This example shows how to clear the TACACS+ accounting server statistics for index 1:

```
> clear stats tacacs acct 1
```

Related Commands

show tacacs summary

clear transfer

To clear the transfer information, use the **clear transfer** command.

clear transfer

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the transfer information:

```
> clear transfer
Are you sure you want to clear the transfer information? (y/n) y
Transfer Information Cleared.
```

Related Commands

- transfer upload datatype
- transfer upload pac
- transfer upload password
- transfer upload port
- transfer upload path
- transfer upload username
- transfer upload datatype
- transfer upload serverip
- transfer upload start

clear traplog

To clear the trap log, use the **clear traplog** command.

clear traplog

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the trap log:

```
> clear traplog
Are you sure you want to clear the trap log? (y/n) y
Trap Log Cleared.
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download path**
- clear download serverip**
- clear download start**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**

clear webimage

To clear the custom web authentication image, use the **clear webimage** command.

clear webimage

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the custom web authentication image:

```
> clear webimage
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download path**
- clear download serverip**
- clear download start**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**

clear webmessage

To clear the custom web authentication message, use the **clear webmessage** command.

clear webmessage

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the custom web authentication message:

```
> clear webmessage  
Message cleared.
```

Related Commands

- clear transfer
- clear download datatype
- clear download filename
- clear download mode
- clear download path
- clear download serverip
- clear download start
- clear upload filename
- clear upload mode
- clear upload path
- clear upload serverip
- clear upload start

clear webtitle

To clear the custom web authentication title, use the **clear webtitle** command.

clear webtitle

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to clear the custom web authentication title:

```
> clear webtitle  
Title cleared.
```

Related Commands	clear transfer clear download datatype clear download filename clear download mode clear download path clear download serverip clear download start clear upload filename clear upload mode clear upload path clear upload serverip clear upload start

Resetting the System Reboot Time

Use the **reset** command to schedule a reboot of the controller and access points.

reset system at

To reset the system at a specified time, use the **reset system at** command.

reset system at YYYY-MM-DD HH:MM:SS image {no-swap|swap} reset-aps [save-config]

Syntax Description		
YYYY-MM-DD		Specifies the date.
HH: MM: SS		Specifies the time in a 24-hour format.
image		Configures the image to be rebooted.
swap		Changes the active boot image.
no-swap		Boots from the active image.
reset-aps		Resets all access points during the system reset.
save-config		(Optional) Saves the configuration before the system reset.

Command Default None.

Examples This example shows how to reset the system at 2010-03-29 and 12:01:01 time:

```
> reset system at 2010-03-29 12:01:01 image swap reset-aps save-config
```

Related Commands

- reset system notify-time
- reset system in

reset system in

To specify the amount of time delay before the devices reboot, use the **reset system in** command.

reset system in HH:MM:SS image {swap | no-swap} reset-aps save-config

Syntax Description

HH :MM :SS	Specifies a delay in duration.
image	Configures the image to be rebooted.
swap	Changes the active boot image.
no-swap	Boots from the active image.
reset-aps	Resets all access points during the system reset.
save-config	Saves the configuration before the system reset.

Command Default

None.

Examples

This example shows how to reset the system after a delay of 00:01:01:

```
> reset system in 00:01:01 image swap reset-aps save-config
```

Related Commands

reset system notify-time
reset system at

reset system cancel

To cancel a scheduled reset, use the **reset system cancel** command.

reset system cancel

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to cancel a scheduled reset:

```
> reset system cancel
```

Related Commands	reset system at reset system in reset system notify-time

reset system notify-time

To configure the trap generation prior to scheduled resets, use the **reset system notify-time** command.

reset system notify-time *minutes*

Syntax Description

minutes

Number of minutes before each scheduled reset at which to generate a trap.

Command Default

The default is 10 minutes.

Examples

This example shows how to configure the trap generation to 10 minutes before the scheduled resets:

```
> reset system notify-time 55
```

Related Commands

reset system in

reset system at

reset peer-system

To reset the peer controller, use the **reset peer-system** command.

reset peer-system

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to reset the peer controller: > reset peer-system

Related Commands	reset system notify-time reset system in

Uploading and Downloading Files and Configurations

Use the **transfer** command to transfer files to or from the Cisco Wireless LAN controller.

transfer download certpassword

To set the password for the .PEM file so that the operating system can decrypt the web administration SSL key and certificate, use the **transfer download certpassword** command.

transfer download certpassword *private_key_password*

Syntax Description

private_key_password Certificate's private key password.

Command Default

None.

Examples

This example shows how to transfer a file to the switch with the certificate's private key password certpassword:

```
> transfer download certpassword
Clearing password
```

Related Commands

clear transfer
 transfer download filename
 transfer download mode
 transfer download path
 transfer download serverip
 transfer download start
 transfer upload datatype
 transfer upload filename
 transfer upload mode
 transfer upload path
 transfer upload serverip
 transfer upload start

transfer download datatype

To set the download file type, use the **transfer download datatype** command.

transfer download datatype {code | config | eapdevcert | eapcert | icon | image | ipseccacert | ipsecdevcert | login-banner | signature | webadmincert | webauthbundle | webauthcert}

Syntax Description

code	Downloads an executable image to the system.
config	Downloads the configuration file.
eapcert	Downloads an EAP ca certificate to the system.
eapdevcert	Downloads an EAP dev certificate to the system.
icon	Downloads an executable image to the system.
image	Downloads a web page login to the system.
ipseccacert	Downloads an IPSec Certificate Authority (CA) certificate to the system.
ipsecdevcert	Downloads an IPSec dev certificate to the system.
login-banner	Downloads the controller login banner. Only text file is supported with a maximum of 1500 bytes.
signature	Downloads a signature file to the system.
webadmincert	Downloads a certificate for web administration to the system.
webauthbundle	Downloads a custom webauth bundle to the system.
webauthcert	Downloads a web certificate for the web portal to the system.

Command Default

None.

Examples

This example shows how to download an executable image to the system:

```
> transfer download datatype code
```

Related Commands

clear transfer
transfer download filename
transfer download mode

transfer download path
transfer download serverip
transfer download start
transfer upload filename
transfer upload mode
transfer upload path
transfer upload serverip
transfer upload start

transfer download filename

To download a specific file, use the **transfer download filename** command.

transfer download filename *filename*

Syntax Description

<i>filename</i>	Filename that contains up to 512 alphanumeric characters.

Command Default

None.

Usage Guidelines

You cannot use special characters such as \ : * ? " < > | for the filename.

Examples

This example shows how to transfer a file named build603:

```
> transfer download filename build603
```

Related Commands

- clear transfer
- transfer download certpassword
- transfer download mode
- transfer download path
- transfer download serverip
- transfer download start
- transfer upload datatype
- transfer upload certpassword
- transfer upload mode
- transfer upload path
- transfer upload serverip
- transfer upload start

transfer download mode

To set the transfer mode, use the **transfer download mode** command.

transfer upload mode {ftp | tftp | sftp}

Syntax Description

ftp	Sets the transfer mode to FTP.
tftp	Sets the transfer mode to TFTP.
sftp	Sets the transfer mode to SFTP.

Command Default

None.

Examples

This example shows how to transfer a file using the TFTP mode:

```
> transfer download mode tftp
```

Related Commands

clear transfer
transfer download filename
transfer download certpassword
transfer download path
transfer download serverip
transfer download start
transfer upload datatype
transfer upload filename
transfer upload path
transfer upload serverip
transfer upload start

transfer download password

To set the password for an FTP transfer, use the **transfer download password** command.

transfer download password *password*

Syntax Description

<i>password</i>	Password.

Command Default

None.

Examples

This example shows how to set the password for FTP transfer to pass01:

```
> transfer download password pass01
```

Related Commands

transfer download mode

transfer download port

transfer download username

transfer download path

To set a specific FTP or TFTP path, use the **transfer download path** command.

transfer download path *path*

Syntax Description

path

Directory path.

Note

Path names on a TFTP or FTP server are relative to the server's default or root directory. For example, in the case of the Solarwinds TFTP server, the path is "/".

Command Default

None.

Usage Guidelines

You cannot use special characters such as \ : * ? " < > | for the file path.

Examples

This example shows how to transfer a file to the path c:\install\version2:

```
> transfer download path c:\install\version2
```

Related Commands

clear transfer
transfer download filename
transfer download mode
transfer download certpassword
transfer download serverip
transfer download start
transfer upload datatype
transfer upload filename
transfer upload mode
transfer upload path
transfer upload serverip
transfer upload start

transfer download port

To specify the FTP port, use the **transfer download port** command.

transfer download port *port*

Syntax Description

<i>port</i>	FTP port.

Command Default

The default FTP *port* is 21.

Examples

This example shows how to specify FTP port number 23:

```
> transfer download port 23
```

Related Commands

transfer download mode

transfer download path

transfer download username

transfer download serverip

To configure the IP address of the TFTP server from which to download information, use the **transfer download serverip** command.

transfer download serverip *TFTP_server ip_address*

Syntax Description

<i>TFTP_server</i>	TFTP IP address.
<i>ip_address</i>	Server IP address.

Command Default

None.

Examples

This example shows how to configure the IP address of the TFTP server with the IP address 175.34.56.78:

```
> transfer download serverip 175.34.56.78
```

Related Commands

clear transfer
transfer download filename
transfer download mode
transfer download path
transfer download serverip
transfer download start
transfer upload datatype
transfer upload filename
transfer upload mode
transfer upload path
transfer upload serverip
transfer upload start
clear transfer
transfer download filename
transfer download mode
transfer download path
transfer download certpassword
transfer download start
transfer upload datatype

transfer upload filename

transfer upload mode

transfer upload path

transfer upload serverip

transfer upload start

transfer download start

To initiate a download, use the **transfer download start** command.

transfer download start

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to initiate a download:

```
> transfer download start
Mode..... TFTP
Data Type..... Site Cert
TFTP Server IP..... 172.16.16.78
TFTP Path..... directory path
TFTP Filename..... webadmincert_name
This may take some time.
Are you sure you want to start? (y/n) Y
TFTP Webadmin cert transfer starting.
Certificate installed.
Please restart the switch (reset system) to use the new certificate.
```

Related Commands

- clear transfer**
- transfer download filename**
- transfer download mode**
- transfer download path**
- transfer download serverip**
- transfer download certpassword**
- transfer upload datatype**
- transfer upload filename**
- transfer upload mode**
- transfer upload path**
- transfer upload serverip**
- transfer upload start**

transfer download tftpPktTimeout

To specify the TFTP packet timeout, use the **transfer download tftpPktTimeout** command.

transfer download tftpPktTimeout *timeout*

Syntax Description

<i>timeout</i>	Timeout in seconds between 1 and 254.

Command Default

None.

Examples

This example shows how to transfer a file with the TFTP packet timeout of 55 seconds:

```
> transfer download tftpPktTimeout 55
```

Related Commands

- clear transfer
- transfer download filename
- transfer download mode
- transfer download path
- transfer download serverip
- transfer download start
- transfer upload datatype
- transfer upload filename
- transfer upload mode
- transfer upload path
- transfer upload serverip
- transfer upload start

transfer download tftpMaxRetries

To specify the number of allowed TFTP packet retries, use the **transfer download tftpMaxRetries** command.

transfer download tftpMaxRetries *retries*

Syntax Description

<i>retries</i>	Number of allowed TFTP packet retries between 1 and 254 seconds.

Command Default

None.

Examples

This example shows how to set the number of allowed TFTP packet retries to 55:

```
> transfer download tftpMaxRetries 55
```

Related Commands

- clear transfer
- transfer download filename
- transfer download mode
- transfer download path
- transfer download serverip
- transfer download start
- transfer upload datatype
- transfer upload filename
- transfer upload mode
- transfer upload path
- transfer upload serverip
- transfer upload start

transfer download username

To specify the FTP username, use the **transfer download username** command.

transfer download username *username*

Syntax Description

<i>username</i>	Username.

Command Default

None.

Examples

This example shows how to set the FTP username to ftp_username:

```
> transfer download username ftp_username
```

Related Commands

transfer download mode

transfer download path

transfer download password

transfer encrypt

To configure encryption for configuration file transfers, use the **transfer encrypt** command.

transfer encrypt {**enable** | **disable** | **set-key** *key*}

Syntax Description

enable	Enables the encryption settings.
disable	Disables the encryption settings.
set-key	Specifies the encryption key for configuration file transfers.
<i>key</i>	Encryption key for config file transfers.

Command Default

None.

Examples

This example shows how to enable the encryption settings:

```
> transfer encrypt enable
```

Related Commands

clear transfer
transfer download filename
transfer download mode
transfer download path
transfer download serverip
transfer download start
transfer upload datatype
transfer upload filename
transfer upload mode
transfer upload path
transfer upload serverip
transfer upload start

transfer upload datatype

To set the controller to upload specified log and crash files, use the **transfer upload datatype** command.

transfer upload datatype {**config** | **coredump** | **crashfile** | **errorlog** | **invalid-config** | **pac** | **packet-capture** | **panic-crash-file** | **radio-core-dump** | **signature** | **systemtrace** | **traplog** | **watchdog-crash-file**}

Syntax Description

config	Uploads the system configuration file.
coredump	Uploads the core-dump file.
crashfile	Uploads the system crash file.
errorlog	Uploads the system error log file.
invalid-config	Uploads the system invalid-config file.
pac	Uploads a Protected Access Credential (PAC).
packet-capture	Uploads a packet capture file.
panic-crash-file	Uploads the kernel panic information file.
radio-core-dump	Uploads the system error log.
signature	Uploads the system signature file.
systemtrace	Uploads the system trace file.
traplog	Uploads the system trap log.
watchdog-crash-file	Uploads a console dump file resulting from a software-watchdog-initiated controller reboot following a crash.

Command Default

None.

Examples

This example shows how to upload the system error log file:

```
> transfer upload datatype errorlog
```

Related Commands

clear transfer
transfer upload filename
transfer upload mode
transfer upload pac

transfer upload password

transfer upload path

transfer upload port

transfer upload serverip

transfer upload start

transfer upload username

transfer upload filename

To upload a specific file, use the **transfer upload filename** command.

transfer upload filename *filename*

Syntax Description

<i>filename</i>	Filename that contains up to 16 alphanumeric characters.

Command Default

None.

Usage Guidelines

You cannot use special characters such as \ : * ? " < > | for the filename.

Examples

This example shows how to upload a file build603:

```
> transfer upload filename build603
```

Related Commands

- clear transfer
- transfer upload datatype
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload path
- transfer upload port
- transfer upload serverip
- transfer upload start
- transfer upload username

transfer upload mode

To configure the transfer mode, use the **transfer upload mode** command.

transfer upload mode {ftp | tftp | sftp}

Syntax Description

ftp	Sets the transfer mode to FTP.
tftp	Sets the transfer mode to TFTP.
sftp	Sets the transfer mode to SFTP.

Command Default

None.

Examples

This example shows how to set the transfer mode to TFTP:

```
> transfer upload mode tftp
```

Related Commands

clear transfer
transfer upload filename
transfer upload datatype
transfer upload pac
transfer upload password
transfer upload path
transfer upload port
transfer upload serverip
transfer upload start
transfer upload username

transfer upload pac

To load a Protected Access Credential (PAC) to support the local authentication feature and allow a client to import the PAC, use the **transfer upload pac** command.

transfer upload pac *username validity password*

Syntax Description

<i>username</i>	User identity of the PAC.
<i>validity</i>	Validity period (days) of the PAC.
<i>password</i>	Password to protect the PAC.

Command Default

None.

Usage Guidelines

The client upload process uses a TFTP or FTP server.

Examples

This example shows how to upload a PAC with the username user1, validity period 53, and password pass01:

```
> transfer upload pac user1 53 pass01
```

Related Commands

clear transfer
transfer upload filename
transfer upload mode
transfer upload datatype
transfer upload password
transfer upload path
transfer upload port
transfer upload serverip
transfer upload start
transfer upload username

transfer upload password

To configure the password for FTP transfer, use the **transfer upload password** command.

Syntax Description

<i>password</i>	Password needed to access the FTP server.

transfer upload password *password*

Command Default

None.

Examples

This example shows how to configure the password for the FTP transfer to pass01:

```
> transfer upload password pass01
```

Related Commands

- clear transfer**
- transfer upload filename**
- transfer upload mode**
- transfer upload pac**
- transfer upload datatype**
- transfer upload path**
- transfer upload port**
- transfer upload serverip**
- transfer upload start**
- transfer upload username**

transfer upload path

To set a specific upload path, use the **transfer upload path** command.

transfer upload path *path*

Syntax Description

<i>path</i>	Server path to file.

Command Default

None.

Usage Guidelines

You cannot use special characters such as \ : * ? " < > | for the file path.

Examples

This example shows how to set the upload path to c:\install\version2:

```
> transfer upload path c:\install\version2
```

Related Commands

- clear transfer
- transfer upload filename
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload datatype
- transfer upload port
- transfer upload serverip
- transfer upload start
- transfer upload username

transfer upload peer-start

To upload a file to the peer controller, use the **transfer upload peer-start** command.

transfer upload peer-start

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to start uploading a file to the peer controller:

```
> transfer upload peer-start
Mode..... FTP
FTP Server IP..... 209.165.201.1
FTP Server Port..... 21
FTP Path..... /builds/nimm/
FTP Filename..... AS_5500_7_4_1_20.aes
FTP Username..... wnbu
FTP Password..... *****
Data Type..... Error Log

Are you sure you want to start upload from standby? (y/N) n

Transfer Canceled
```

Related Commands

- clear transfer
- transfer upload filename
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload path
- transfer upload port
- transfer upload serverip
- transfer upload datatype
- transfer upload username
- transfer download peer-start

transfer upload port

To specify the FTP port, use the **transfer upload port** command.

transfer upload port *port*

Syntax Description

<i>port</i>	Port number.

Command Default

The default FTP port is 21.

Examples

This example shows how to specify FTP port 23:

```
> transfer upload port 23
```

Related Commands

- clear transfer
- transfer upload filename
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload path
- transfer upload datatype
- transfer upload serverip
- transfer upload start
- transfer upload username

transfer upload serverip

To configure the IP address of the TFTP server to upload files to, use the **transfer upload serverip** command.

transfer upload serverip *ip_address*

Syntax Description

<i>ip_address</i>	Server IP address.

Command Default

None.

Examples

This example shows how to set the IP address of the TFTP server to 175.31.56.78:

```
> transfer upload serverip 175.31.56.78
```

Related Commands

- clear transfer**
- transfer upload filename**
- transfer upload mode**
- transfer upload pac**
- transfer upload password**
- transfer upload path**
- transfer upload port**
- transfer upload datatype**
- transfer upload start**
- transfer upload username**

transfer upload start

To initiate an upload, use the **transfer upload start** command.

transfer upload start

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to initiate an upload of a file:

```
> transfer upload start
Mode..... TFTP
TFTP Server IP..... 172.16.16.78
TFTP Path..... c:\find\off/
TFTP Filename..... wps_2_0_75_0.aes
Data Type..... Code
Are you sure you want to start? (y/n) n
Transfer Cancelled
```

Related Commands

- clear transfer**
- transfer upload filename**
- transfer upload mode**
- transfer upload pac**
- transfer upload password**
- transfer upload path**
- transfer upload port**
- transfer upload serverip**
- transfer upload datatype**
- transfer upload username**

transfer upload username

To specify the FTP username, use the **transfer upload username** command.

transfer upload username

Syntax Description

<i>username</i>	Username required to access the FTP server. The username can contain up to 31 characters.

Command Default

None.

Examples

This example shows how to set the FTP username to ftp_username:

```
> transfer upload username ftp_username
```

Related Commands

- clear transfer
- transfer upload filename
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload path
- transfer upload port
- transfer upload serverip
- transfer upload start
- transfer upload datatype

Installing and Modifying Licenses on Cisco 5500 Series Controllers

Use the **license** commands to install, remove, modify, or rehost licenses.



Note

Some license commands are available only on the Cisco 5500 Series Controller. Right to Use (RTU) licensing is not supported on Cisco 5500 Series Controllers.

**Note**

For detailed information on installing and rehosting licenses on the Cisco 5500 Series Controller, see the “Installing and Configuring Licenses” section in Chapter 4 of the *Cisco Wireless LAN Controller Configuration Guide*.

license clear

To remove a license from the Cisco 5500 Series Controller, use the **license clear** command.

license clear *license_name*

Syntax Description

<i>license_name</i>	Name of the license.

Command Default

None.

Usage Guidelines

You can delete an expired evaluation license or any unused license. You cannot delete unexpired evaluation licenses, the permanent base image license, or licenses that are in use by the controller.

Examples

This example shows how to remove the license settings of the license named wplus-ap-count:

```
> license clear wplus-ap-count
```

Related Commands

- license comment**
- license install**
- license revoke**
- license save**
- show license all**

license comment

To add comments to a license or delete comments from a license on the Cisco 5500 Series Controller, use the **license comment** command.

license comment {**add** | **delete**} *license_name comment_string*

Syntax Description

add	Adds a comment.
delete	Deletes a comment.
<i>license_name</i>	Name of the license.
<i>comment_string</i>	License comment.

Command Default

None.

Examples

This example shows how to add a comment “wplus ap count license” to the license name wplus-ap-count:

```
> license comment add wplus-ap-count Comment for wplus ap count license
```

Related Commands

license clear
license install
license revoke
license save
show license all

license install

To install a license on the Cisco 5500 Series Controller, use the **license install** command.

license install *url*

Syntax Description

<i>url</i>	URL of the TFTP server (tftp://server_ip/path/filename).

Command Default

None.

Usage Guidelines

We recommend that the access point count be the same for the base-ap-count and wplus-ap-count licenses installed on your controller. If your controller has a base-ap-count license of 100 and you install a wplus-ap-count license of 12, the controller supports up to 100 access points when the base license is in use but only a maximum of 12 access points when the wplus license is in use.

You cannot install a wplus license that has an access point count greater than the controller's base license. For example, you cannot apply a wplus-ap-count 100 license to a controller with an existing base-ap-count 12 license. If you attempt to register for such a license, an error message appears indicating that the license registration has failed. Before upgrading to a wplus-ap-count 100 license, you would first have to upgrade the controller to a base-ap-count 100 or 250 license.

Examples

This example shows how to install a license on the controller from the URL tftp://10.10.10.10/path/license.lic:

```
> license install tftp://10.10.10.10/path/license.lic
```

Related Commands

license clear
license install
license revoke
license save
show license all

license modify priority

To raise or lower the priority of the base-ap-count or wplus-ap-count evaluation license on a Cisco 5500 Series Controller, use the **license modify priority** command.

license modify priority *license_name* {**high** | **low**}

Syntax Description

<i>license_name</i>	Ap-count evaluation license.
high	Modifies the priority of an ap-count evaluation license.
low	Modifies the priority of an ap-count evaluation license.

Command Default

None.

Usage Guidelines

If you are considering upgrading to a license with a higher access point count, you can try an evaluation license before upgrading to a permanent version of the license. For example, if you are using a permanent license with a 50 access point count and want to try an evaluation license with a 100 access point count, you can try out the evaluation license for 60 days.

AP-count evaluation licenses are set to low priority by default so that the controller uses the ap-count permanent license. If you want to try an evaluation license with an increased access point count, you must change its priority to high. If you no longer want to have this higher capacity, you can lower the priority of the ap-count evaluation license, which forces the controller to use the permanent license.



Note

You can set the priority only for ap-count evaluation licenses. AP-count permanent licenses always have a medium priority, which cannot be configured.



Note

If the ap-count evaluation license is a wplus license and the ap-count permanent license is a base license, you must also change the feature set to wplus.



Note

To prevent disruptions in operation, the controller does not switch licenses when an evaluation license expires. You must reboot the controller in order to return to a permanent license. Following a reboot, the controller defaults to the same feature set level as the expired evaluation license. If no permanent license at the same feature set level is installed, the controller uses a permanent license at another level or an unexpired evaluation license.

Examples

This example shows how to set the priority of the wplus-ap-count to high:

```
> license modify priority wplus-ap-count high
```

Related Commands

- license clear
- license install
- license revoke
- license save
- show license all

license revoke

To rehost a license on a Cisco 5500 Series Controller, use the **license revoke** command.

license revoke *{permission_ticket_url | rehost rehost_ticket_url}*

Syntax Description

<i>permission_ticket_url</i>	URL of the TFTP server (tftp://server_ip/path/filename) where you saved the permission ticket.
rehost	Specifies the rehost license settings.
<i>rehost_ticket_url</i>	URL of the TFTP server (tftp://server_ip/path/filename) where you saved the rehost ticket.

Command Default

None.

Usage Guidelines

Before you revoke a license, save the device credentials by using the **license save credential url** command. You can rehost all permanent licenses except the permanent base image license. Evaluation licenses and the permanent base image license cannot be rehosted.

In order to rehost a license, you must generate credential information from the controller and use it to obtain a permission ticket to revoke the license from the Cisco licensing site (www.cisco.com/go/license). Next, you must obtain a rehost ticket and use it to obtain a license installation file for the controller on which you want to install the license.

For detailed information on rehosting licenses, see the “Installing and Configuring Licenses” section in Chapter 4 of the Cisco Wireless LAN Controller Configuration Guide.

Examples

This example shows how to revoke the license settings from the saved permission ticket URL tftp://10.10.10.10/path/permit_ticket.lic:

```
> license revoke tftp://10.10.10.10/path/permit_ticket.lic
```

This example shows how to revoke the license settings from the saved rehost ticket URL tftp://10.10.10.10/path/rehost_ticket.lic:

```
> license revoke rehost tftp://10.10.10.10/path/rehost_ticket.lic
```

Related Commands

license clear
license install
license modify priority
license save
show license all

license save

To save a backup copy of all installed licenses or license credentials on the Cisco 5500 Series Controller, use the **license save** command.

license save *credential url*

Syntax Description

<i>credential</i>	Device credential information.
<i>url</i>	URL of the TFTP server (tftp://server_ip/path/filename).

Command Default

None.

Usage Guidelines

Save the device credentials before you revoke the license by using the **license revoke** command.

Examples

This example shows how to save a backup copy of all installed licenses or license credentials on tftp://10.10.10.10/path/cred.lic:

```
> license save credential tftp://10.10.10.10/path/cred.lic
```

Related Commands

license clear
license install
license revoke
license modify priority
show license all

Right to Use Licensing Commands

Use the **license** commands to configure Right to Use (RTU) licensing on Cisco Flex 7500 Series and 8500 Series controllers. This feature allows you to enable an AP license count on the controller without using any external tools after accepting an End User License Agreement (EULA).

license activate ap-count eval

To activate an evaluation access point license on the Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN Controllers, use the **license activate ap-count eval** command.

license activate ap-count eval

Syntax Description	This command has no arguments or keywords.
Command Default	By default, in release 7.3 Cisco Flex 7500 Series Controllers and Cisco 8500 Series Wireless LAN Controllers support 6000 APs.
Usage Guidelines	When you activate this license, the controller prompts you to accept or reject the End User License Agreement (EULA) for the given license. If you activate a license that supports a smaller number of APs than the current number of APs connected to the controller, the activation command fails.
Examples	This example shows how to activate an evaluation AP-count license on a Cisco Flex 7500 Series controller: <pre>> license activate ap-count eval</pre>
Related Commands	license activate feature license add ap-count license add feature license deactivate feature license deactivate ap-count license delete ap-count license delete feature show license all show license evaluation show license feature show license summary show license detail show license statistics

license activate feature

To activate a feature license on Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN Controllers, use the **license activate feature** command.

license activate feature *license_name*

Syntax Description

<i>license_name</i>	Name of the feature license. The license name can be up to 50 case-sensitive characters.

Command Default

None.

Examples

This example shows how to activate a data DTLS feature license on a Cisco Flex 7500 Series controller:

```
> license activate feature data-DTLS
```

Related Commands

- license activate ap-count eval**
- license add ap-count**
- license add feature**
- license deactivate feature**
- license deactivate ap-count**
- license delete ap-count**
- license delete feature**
- show license all**
- show license evaluation**
- show license feature**
- show license summary**
- show license detail**
- show license statistics**

license add ap-count

To configure the number of access points (APs) that an AP license can support on Cisco Flex 7500 and 8500 Series Wireless LAN controllers, use the **license add ap-count** command.

license add ap-count *count*

Syntax Description

<i>count</i>	Number of APs that the AP license supports. The range is from 1 to the maximum number of APs that the controller can support. The count must be a multiple of 5.

Command Default

None.

Usage Guidelines

Right to Use (RTU) licensing allows you to enable a desired AP license count on the controller after accepting the End User License Agreement (EULA). You can now easily add AP counts on a controller without using external tools. RTU licensing is available only on Cisco Flex 7500 and 8500 series Wireless LAN controllers.

You can use this command to increase the count of an existing AP license. When you activate a license that supports a smaller number of APs than the current number of APs connected to the controller, the activation command fails.

Examples

This example shows how to configure the count of an AP license on a Cisco Flex 7500 Series controller:

```
> license add ap-count 5000
```

Related Commands

- license activate feature**
- license activate ap-count eval**
- license add feature**
- license deactivate feature**
- license deactivate ap-count**
- license delete ap-count**
- license delete feature**
- show license all**
- show license evaluation**
- show license feature**
- show license summary**
- show license detail**
- show license statistics**

license add feature

To add a license for a feature on the Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN controllers, use the **license add feature** command.

license add feature *license_name*

Syntax Description

<i>license_name</i>	Name of the feature license. The license name can be up to 50 case-sensitive characters. For example, data_DTLS.

Command Default

None.

Examples

This example shows how to add a DTLS feature license on a Cisco Flex 7500 Series controller:

```
> license add feature data_DTLS
```

Related Commands

- license add ap-count**
- license activate feature**
- license activate ap-count eval**
- license deactivate feature**
- license deactivate ap-count**
- license delete ap-count**
- license delete feature**
- show license all**
- show license evaluation**
- show license feature**
- show license summary**
- show license detail**
- show license statistics**

license deactivate ap-count eval

To deactivate an evaluation access point license on the Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN Controllers, use the **license deactivate ap-count eval** command.

license deactivate ap-count eval

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to deactivate an evaluation AP license on a Cisco Flex 7500 Series controller:

```
> license deactivate ap-count eval
```

Related Commands

- license activate ap-count
- license activate feature
- license add ap-count
- license add feature
- license deactivate feature
- license delete ap-count
- license delete feature
- show license all
- show license evaluation
- show license feature
- show license summary
- show license detail
- show license statistics

license deactivate feature

To deactivate a feature license on Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN controllers, use the **license deactivate feature** command.

license deactivate feature *license_name*

Syntax Description

<i>license_name</i>	Name of the feature license. The license name can be up to 50 case-sensitive characters.

Command Default

None.

Examples

This example shows how to deactivate a data DTLS feature license on a Cisco Flex 7500 Series controller:

```
> license deactivate feature data_DTLS
```

Related Commands

- license activate ap-count eval**
- license activate feature**
- license add ap-count**
- license add feature**
- license deactivate ap-count**
- license delete ap-count**
- license delete feature**
- show license all**
- show license evaluation**
- show license feature**
- show license summary**
- show license detail**
- show license statistics**

license delete ap-count

To delete an access point (AP) count license on the Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN Controllers, use the **license delete ap-count** command.

license delete ap-count *count*

Syntax Description

<i>count</i>	Number of APs that the AP license supports. The range is from 1 to the maximum number of APs that the controller can support. The count must be a multiple of 5.

Command Default

None.

Examples

This example shows how to delete an AP count license on a Cisco Flex 7500 Series controller:

```
> license delete ap-count 5000
```

Related Commands

- license activate feature**
- license activate ap-count eval**
- license add ap-count**
- license add feature**
- license deactivate feature**
- license deactivate ap-count**
- license delete feature**
- show license all**
- show license evaluation**
- show license feature**
- show license summary**
- show license detail**
- show license statistics**

license delete feature

To delete a license for a feature on Cisco Flex 7500 Series and Cisco 8500 Series Wireless LAN controllers, use the **license delete feature** command.

license delete feature *license_name*

Syntax Description

license_name

Name of the feature license.

Command Default

None.

Examples

This example shows how to delete the High Availability feature license on a Cisco Flex 7500 Series controller:

```
> license delete feature high_availability
```

Related Commands

license activate feature
license activate ap-count eval
license add feature
license add ap-count eval
license deactivate feature
license deactivate ap-count
license delete ap-count
show license all
show license evaluation
show license feature
show license summary
show license detail
show license statistics

Troubleshooting the Controller Settings

This section describes the **debug** and **config** commands that you can use to troubleshoot the controller.

debug arp

To configure the debugging of Address Resolution Protocol (ARP) options, use the **debug arp** command.

debug arp {all | detail | events | message} {enable | disable}

Syntax Description

all	Configures the debugging of all ARP logs.
detail	Configures the debugging of ARP detail messages.
error	Configures the debugging of ARP errors.
message	Configures the debugging of ARP messages.
enable	Enables the ARP debugging.
disable	Disables the ARP debugging.

Command Default

None.

Examples

This example shows how to enable ARP debug settings:

```
> debug arp error enable
```

This example shows how to disable ARP debug settings:

```
> debug arp error disable
```

Related Commands

debug disable-all
show sysinfo

debug avc

To configure the debugging of Application Visibility and Control (AVC) options, use the **debug avc error** command.

debug avc {events | error} {enable | disable}

Syntax Description

events	Configures the debugging of AVC events.
error	Configures the debugging of AVC errors.
enable	Enables the debugging of AVC events or errors.
disable	Disables the debugging of AVC events or errors.

Command Default

Disabled.

Examples

This example shows how to enable the debugging of AVC errors:

```
> debug avc error enable
```

Related Commands

config avc profile delete
config avc profile rule
config wlan avc
show avc profile
show avc applications
show avc statistics

debug cac

To configure the debugging of Call Admission Control (CAC) options, use the **debug cac** command.

debug cac {all | event | packet} {enable | disable}

Syntax Description

all	Configures the debugging options for all CAC messages.
event	Configures the debugging options for CAC events.
packet	Configures the debugging options for selected CAC packets.
kts	Configures the debugging options for KTS-based CAC messages.
enable	Enables the debugging of CAC settings.
disable	Disables the debugging of CAC settings.

Command Default

Disabled.

Examples

This example shows how to enable debugging of CAC settings:

```
> debug cac event enable
> debug cac packet enable
```

Related Commands

```
config 802.11 cac video acm
config 802.11 cac video max-bandwidth
config 802.11 video roam-bandwidth
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac voice load-based
config 802.11 cac voice roam-bandwidth
config 802.11cac voice stream-size
config 802.11cac voice tspec-inactivity-timeout
```

debug cdp

To configure the debugging of Cisco Discovery Protocol (CDP), use the **debug cdp** command.

debug cdp {events | packets} {enable | disable}

Syntax Description

events	Configures the debugging of the CDP events.
packets	Configures the debugging of the CDP packets.
enable	Enables the debugging of the CDP options.
disable	Disables the debugging of the CDP options.

Command Default

None

Examples

The following example shows how to enable CDP event debugging in a Cisco controller.

```
Device > debug cdp
```

Related Commands

Command	Description
config cdp	Configures CDP.
show cdp	Displays the CDP details.

debug crypto

To configure the debugging of the hardware cryptographic options, use the **debug crypto** command.

debug crypto {all | sessions | trace | warning} {enable | disable}

Syntax Description

all	Configures the debugging of all hardware crypto messages.
sessions	Configures the debugging of hardware crypto sessions.
trace	Configures the debugging of hardware crypto sessions.
warning	Configures the debugging of hardware crypto sessions.
enable	Enables the debugging of hardware cryptographic sessions.
disable	Disables the debugging of hardware cryptographic sessions.

Command Default

None.

Examples

This example shows how to enable the debugging of hardware crypto sessions:

```
> debug crypto sessions enable
```

Related Commands

debug disable-all
show sysinfo

debug dhcp

To configure the debugging of DHCP, use the **debug dhcp** command.

debug dhcp {message | packet} {enable | disable}

Syntax Description

message	Configures the debugging of DHCP error messages.
packet	Configures the debugging of DHCP packets.
enable	Enables the debugging DHCP messages or packets.
disable	Disables the debugging of DHCP messages or packets.

Command Default

None.

Examples

This example shows how to enable the debugging of DHCP messages:

```
> debug dhcp message enable
```

Related Commands

debug disable-all
config dhcp
config dhcp proxy
config interface dhcp
config wlan dhcp_server
debug dhcp service-port
show dhcp
show dhcp proxy

debug dhcp service-port

To enable or disable debugging of the Dynamic Host Configuration Protocol (DHCP) packets on the service port, use the **debug dhcp service-port** command.

debug dhcp service-port {enable | disable}

Syntax Description

enable	Enables the debugging of DHCP packets on the service port.
disable	Disables the debugging of DHCP packets on the service port.

Command Default

None.

Examples

This example shows how to enable the debugging of DHCP packets on a service port:

```
> debug dhcp service-port enable
```

Related Commands

debug disable-all
config dhcp
config dhcp proxy
config interface dhcp
config wlan dhcp_server
debug dhcp service-port
show dhcp
show dhcp proxy

debug disable-all

To disable all debug messages, use the **debug disable-all** command.

debug disable-all

Syntax Description This command has no arguments or keywords.

Command Default Disabled.

Examples This example shows how to disable all debug messages:

```
> debug disable-all
```


debug l2age

To configure the debugging of Layer 2 age timeout messages, use the **debug l2age** command.

debug l2age {enable | disable}

Syntax	Description
enable	Enables the debugging of Layer2 age settings.
disable	Disables the debugging Layer2 age settings.

Command Default

None.

Examples

This example shows how to enable the debugging of Layer2 age settings:

```
> debug l2age enable
```

Related Commands

debug disable-all

debug mac

To configure the debugging of the client MAC address, use the **debug mac** command.

debug mac {**disable** | **addr** *MAC*}

Syntax Description

disable	Disables the debugging of the client using the MAC address.
addr	Configures the debugging of the client using the MAC address.
<i>MAC</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to configure the debugging of the client using the MAC address:

```
> debug mac addr 00.0c.41.07.33.a6
```

Related Commands

debug disable-all

debug mdns all

To debug all multicast DNS (mDNS) messages, details, and errors, use the **debug mdns all** command.

debug mdns all {enable | disable}

Syntax Description

enable	Enables the debugging of all mDNS messages, details, and errors.
disable	Disables the debugging of all mDNS messages, details, and errors.

Command Default

Disabled.

Command History

Release	Modification
7.4	This command was introduced.

Examples

This example shows how to enable debugging of all mDNS messages, details, and errors:

```
Device > debug mdns all enable
```

Related Commands

config mdns profile
config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns error
debug mdns detail

debug mdns detail

To debug multicast DNS (mDNS) details, use the **debug mdns detail** command.

debug mdns detail {enable | disable}

Syntax Description

enable	Enables the debugging of mDNS details.
disable	Disables the debugging of mDNS details.

Command Default

This command is disabled by default.

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following example shows how to enable the debugging of mDNS details:

```
Device > debug mdns detail enable
```

Related Commands

config mdns profile
config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error

debug mdns error

To debug multicast DNS (mDNS) errors, use the **debug mdns error** command.

debug mdns error {enable | disable}

Syntax Description

enable	Enables the debugging of mDNS errors.
disable	Disables the debugging of mDNS errors.

Command Default

This command is disabled by default.

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following example shows how to enable the debugging of mDNS errors.

```
Device > debug mdns error enable
```

Related Commands

config mdns profile
config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns detail
debug mdns message

debug mdns message

To debug multicast DNS (mDNS) messages, use the **debug mdns message** command.

debug mdns message {enable | disable}

Syntax Description

enable	Enables the debugging of mDNS messages.
disable	Disables the debugging of mDNS messages.

Command Default

Disabled.

Command History

Release	Modification
7.4	This command was introduced.

Examples

This example shows how to enable the debugging of mDNS messages:

```
Device > debug mdns message enable
```

Related Commands

config mdns profile
config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail

debug memory

To enable or disable the debugging of errors or events during the memory allocation of the Cisco WLC, use the **debug memory** command.

debug memory {errors | events} {enable | disable}

Syntax Description	errors	Configures the debugging of memory leak errors.
	events	Configures debugging of memory leak events.
	enable	Enables the debugging of memory leak events.
	disable	Disables the debugging of memory leak events.

Command Default Disabled.

Examples This example shows how to enable the debugging of memory leak events:

```
> debug memory events enable
```

Related Commands

- config memory monitor errors
- show memory monitor
- config memory monitor leaks

debug nmosp

To configure the debugging of the Network Mobility Services Protocol (NMSP), use the **debug nmosp** command.

debug nmosp {all | connection | detail | error | event | message | packet}

Syntax Description

all	Configures the debugging for all NMSP messages.
connection	Configures the debugging for NMSP connection events.
detail	Configures the debugging for NMSP events in detail.
error	Configures the debugging for NMSP error messages.
event	Configures the debugging for NMSP events.
message	Configures the debugging for NMSP transmit and receive messages.
packet	Configures the debugging for NMSP packet events.

Command Default

None.

Examples

This example shows how to configure the debugging of NMSP connection events:

```
> debug nmosp connection
```

Related Commands

clear nmosp statistics
debug disable-all
config nmosp notify-interval measurement

debug ntp

To configure the debugging of the Network Time Protocol (NTP), use the **debug ntp** command.

debug ntp {**detail** | **low** | **packet**} {**enable** | **disable**}

Syntax Description

detail	Configures the debugging of detailed NTP messages.
low	Configures the debugging of NTP messages.
packet	Configures the debugging of NTP packets.
enable	Enables the NTP debugging.
disable	Disables the NTP debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of NTP settings:

```
> debug ntp packet enable
```

Related Commands

debug disable-all

debug packet error

To configure the debugging of packets sent to the Cisco WLC Central Processing Unit (CPU), use the **debug packet error** command.

debug packet error {enable | disable}

Syntax Description

enable	Enables the debugging of packets sent to the Cisco WLC CPU.
disable	Disables the debugging of packets sent to the Cisco WLC CPU.

Command Default

None

Examples

The following example shows how to enable the debugging of packets sent to the Cisco WLC CPU:

```
Device > debug packet error enable
```

Related Commands

Command	Description
debug packet logging	Configures the logging of packets sent to the Cisco WLC CPU.

debug packet logging

To configure the logging of packets sent to the Cisco WLC Central Processing Unit (CPU), use the **debug packet logging** command.

debug packet logging {**acl** | **disable** | **enable** {**rx** | **tx** | **all**} *packet_count display_size* | **format** {**hex2pcap** | **text2pcap**}}

debug packet acl {**clear-all** | **driver** *rule_index action npu_encap port* | **eoip-eth** *rule_index action dst src type vlan* | **eoip-ip** *rule_index action src dst proto src_port dst_port* | **eth** *rule_index action dst src type vlan* | **ip** *rule_index action src dst proto src_port dst_port* | **lwapp-dot11** *rule_index action dst src bssid type* | **lwapp-ip** *rule_index action src dst proto src_port dst_port*}

Syntax Description

acl	Filters the displayed packets according to a rule.
disable	Disables logging of the packets.
enable	Enables logging of the packets.
rx	Displays all the received packets.
tx	Displays all the transmitted packets.
all	Displays both the transmitted and the received packets.
<i>packet_count</i>	Maximum number of packets to log. The range is from 1 to 65535. The default value is 25.
<i>display_size</i>	Number of bytes to display when printing a packet. By default, the entire packet is displayed.
format	Configures the format of the debug output.
hex2pcap	Configures the output format to be compatible with the hex2pcap format. The standard format used by Cisco IOS supports the use of hex2pcap and can be decoded using an HTML front end.
text2pcap	Configures the output format to be compatible with the text2pcap format. In this format, the sequence of packets can be decoded from the same console log file. .
clear-all	Clears all the existing rules pertaining to the packets.
driver	Filters the packets based on an incoming port or a Network Processing Unit (NPU) encapsulation type.
<i>rule_index</i>	Index of the rule that is a value between 1 and 6 (inclusive).
<i>action</i>	Action for the rule, which can be permit, deny, or disable.

<i>npu_encap</i>	NPU encapsulation type that determines how the packets are filtered. The possible values are <i>dhcp</i> , <i>dot11-mgmt</i> , <i>dot11-probe</i> , <i>dot1x</i> , <i>eoip-ping</i> , <i>iapp</i> , <i>ip</i> , <i>lwapp</i> , <i>multicast</i> , <i>orphan-from-sta</i> , <i>orphan-to-sta</i> , <i>rbcg</i> , <i>wired-guest</i> , or <i>any</i> .
<i>port</i>	Physical port for packet transmission or reception.
eoip-eth	Filters packets based on the Ethernet II header in the EoIP payload.
<i>dst</i>	Destination MAC address.
<i>src</i>	Source MAC address.
<i>type</i>	Two-byte type code, such as 0x800 for IP, 0x806 for ARP. You can also enter a few common string values such as <i>ip</i> (for 0x800) or <i>arp</i> (for 0x806).
<i>vlan</i>	Two-byte VLAN identifier.
eoip-ip	Filters packets based on the IP header in the Ethernet over IP (EoIP) payload.
<i>proto</i>	Protocol. Valid values are: <i>ip</i> , <i>icmp</i> , <i>igmp</i> , <i>ggp</i> , <i>ipencap</i> , <i>st</i> , <i>tcp</i> , <i>egp</i> , <i>pup</i> , <i>udp</i> , <i>hmp</i> , <i>xns-idp</i> , <i>rdp</i> , <i>iso-tp4</i> , <i>xtp</i> , <i>ddp</i> , <i>idpr-cmtg</i> , <i>rsdp</i> , <i>vmtp</i> , <i>ospf</i> , <i>ipip</i> , and <i>encap</i> .
<i>src_port</i>	User Datagram Protocol or Transmission Control Protocol (UDP or TCP) two-byte source port, such as <i>telnet</i> , <i>23</i> , or <i>any</i> . The Cisco WLC supports the following strings: <i>tcpmux</i> , <i>echo</i> , <i>discard</i> , <i>systat</i> , <i>daytime</i> , <i>netstat</i> , <i>qotd</i> , <i>msh</i> , <i>chargen</i> , <i>ftp-data</i> , <i>ftp</i> , <i>fsp</i> , <i>ssh</i> , <i>telnet</i> , <i>smtp</i> , <i>time</i> , <i>rlp</i> , <i>nameserver</i> , <i>whois</i> , <i>re-mail-ck</i> , <i>domain</i> , <i>mtp</i> , <i>bootps</i> , <i>bootpc</i> , <i>tftp</i> , <i>gopher</i> , <i>rje</i> , <i>finger</i> , <i>www</i> , <i>link</i> , <i>kerberos</i> , <i>supdup</i> , <i>hostnames</i> , <i>iso-tsap</i> , <i>csnet-ns</i> , <i>3com-tsmux</i> , <i>rtelnet</i> , <i>pop-2</i> , <i>pop-3</i> , <i>sunrpc</i> , <i>auth</i> , <i>sftp</i> , <i>uucp-path</i> , <i>nntp</i> , <i>ntp</i> , <i>netbios-ns</i> , <i>netbios-dgm</i> , <i>netbios-ssn</i> , <i>imap2</i> , <i>snmp</i> , <i>snmp-trap</i> , <i>cmip-man</i> , <i>cmip-agent</i> , <i>xmcp</i> , <i>nextstep</i> , <i>bgp</i> , <i>prospero</i> , <i>irc</i> , <i>smux</i> , <i>at-rtmp</i> , <i>at-nbp</i> , <i>at-echo</i> , <i>at-zis</i> , <i>qmtg</i> , <i>z3950</i> , <i>ipx</i> , <i>imap3</i> , <i>ulistserv</i> , <i>https</i> , <i>snpp</i> , <i>saft</i> , <i>npmp-local</i> , <i>npmp-gui</i> , and <i>hmp-ind</i> .
<i>dst_port</i>	UDP or TCP two-byte destination port, such as <i>telnet</i> , <i>23</i> , or <i>any</i> . The Cisco WLC supports the same strings as those for the <i>src_port</i> .
eth	Filters packets based on the values in the Ethernet II header.
ip	Filters packets based on the values in the IP header.
lwapp-dot11	Filters packets based on the 802.11 header in the Lightweight Access Point Protocol (LWAPP) payload.
<i>bssid</i>	Basic Service Set Identifier of the VLAN.
lwapp-ip	Filters packets based on the IP header in the LWAPP payload.

Command Default

None

Examples

The following example shows how to enable logging of a packet:

```
Device > debug packet logging enable
```

Related Commands

Command	Description
debug packet error	Configures the debugging of packets sent to the Cisco WLC CPU.

debug poe

To configure the debugging of Power over Ethernet (PoE), use the **debug poe** command.

debug poe {**detail** | **message** | **error**} {**enable** | **disable**}

Syntax Description

detail	Configures the debugging of PoE detail logs.
error	Configures the debugging of PoE error logs.
message	Configures the debugging of PoE messages.
enable	Enables the debugging of PoE logs.
disable	Disables the debugging of PoE logs.

Command Default

None.

Examples

This example shows how to enable the PoE debugging:

```
> debug poe message enable
```

Related Commands

debug disable-all

debug rbc

To configure Router Blade Control (RBCP) debug options, use the **debug rbc** command.

debug rbc {all | detail | errors | packet} {enable | disable}

Syntax Description

all	Configures the debugging of RBCP.
detail	Configures the debugging of RBCP detail.
errors	Configures the debugging of RBCP errors.
packet	Configures the debugging of RBCP packet trace.
enable	Enables the RBCP debugging.
disable	Disables the RBCP debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of RBCP settings:

```
> debug rbc packet enable
```

Related Commands

debug disable-all

debug rfid

To configure radio frequency identification (RFID) debug options, use the **debug rfid** command.

debug rfid {all | detail | errors | nmsp | receive} {enable | disable}

Syntax Description

all	Configures the debugging of all RFID.
detail	Configures the debugging of RFID detail.
errors	Configures the debugging of RFID error messages.
nmsp	Configures the debugging of RFID Network Mobility Services Protocol (NMSP) messages.
receive	Configures the debugging of incoming RFID tag messages.
enable	Enables the RFID debugging.
disable	Disables the RFID debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of RFID error messages:

```
> debug rfid errors enable
```

Related Commands

debug disable-all

debug snmp

To configure SNMP debug options, use the **debug snmp** command.

debug snmp {agent | all | mib | trap} {enable | disable}

Syntax Description

agent	Configures the debugging of the SNMP agent.
all	Configures the debugging of all SNMP messages.
mib	Configures the debugging of the SNMP MIB.
trap	Configures the debugging of SNMP traps.
enable	Enables the SNMP debugging.
disable	Disables the SNMP debugging.

Command Default

None.

Examples

This example shows how to enable the SNMP debugging:

```
> debug snmp trap enable
```

Related Commands

debug disable-all

debug transfer

To configure transfer debug options, use the **debug transfer** command.

debug transfer {all | tftp | trace} {enable | disable}

Syntax Description

all	Configures the debugging of all transfer messages.
tftp	Configures the debugging of TFTP transfers.
trace	Configures the debugging of transfer messages.
enable	Enables the debugging of transfer messages.
disable	Disables the debugging of transfer messages.

Command Default

None.

Examples

This example shows how to enable the debugging of transfer messages:

```
> debug transfer trace enable
```

Related Commands

debug disable-all

debug voice-diag

To trace call or packet flow, use the **debug voice-diag** command.

debug voice-diag {**enable** *client_mac1* [*client_mac2*] [**verbose**] | **disable**}

Syntax Description

enable	Enables the debugging of voice diagnostics for voice clients involved in a call.
<i>client_mac1</i>	MAC address of a voice client.
<i>client_mac2</i>	(Optional) MAC address of an additional voice client.
verbose	(Optional) Enables debug information to be displayed on the console.
	Note When voice diagnostics is enabled from the NCS or Prime Infrastructure, the verbose option is not available.
disable	Disables the debugging of voice diagnostics for voice clients involved in a call.

Command Default

None.

Usage Guidelines

Follow these guidelines when you use the **debug voice-diag** command:

- When the command is entered, the validity of the clients is not checked.
- A few output messages of the command are sent to the NCS or Prime Infrastructure.
- The command expires automatically after 60 minutes.
- The command provides the details of the call flow between a pair of client MACs involved in an active call.



Note Voice diagnostics can be enabled for a maximum of two voice clients at a time.

Examples

This example shows how to enable transfer/upgrade settings:

```
> debug voice-diag enable 00:1a:a1:92:b9:5c 00:1a:a1:92:b5:9c verbose
```

Related Commands

show client voice-diag
show client calls

show debug

To determine if the MAC address and other flag debugging is enabled or disabled, use the **show debug** command.

show debug [packet]

Syntax Description

packet	Displays information about packet debugs.

Command Default

None.

Examples

This example shows how to display if debugging is enabled:

```
> show debug
MAC debugging..... disabled
Debug Flags Enabled:
  arp error enabled.
  bcast error enabled.
```

This example shows how to display if debugging is enabled:

```
> show debug packet
Status..... disabled
Number of packets to display..... 0
Bytes/packet to display..... 0
Packet display format..... text2pcap
  Driver ACL:
    [1]: disabled
    [2]: disabled
    [3]: disabled
    [4]: disabled
    [5]: disabled
    [6]: disabled
  Ethernet ACL:
    [1]: disabled
    [2]: disabled
    [3]: disabled
    [4]: disabled
    [5]: disabled
    [6]: disabled
  IP ACL:
    [1]: disabled
    [2]: disabled
    [3]: disabled
    [4]: disabled
    [5]: disabled
    [6]: disabled
  EoIP-Ethernet ACL:
    [1]: disabled
    [2]: disabled
    [3]: disabled
    [4]: disabled
    [5]: disabled
    [6]: disabled
  EoIP-IP ACL:
    [1]: disabled
    [2]: disabled
    [3]: disabled
    [4]: disabled
```

```
[5]: disabled
[6]: disabled
LWAPP-Dot11 ACL:
[1]: disabled
[2]: disabled
[3]: disabled
[4]: disabled
[5]: disabled
[6]: disabled
LWAPP-IP ACL:
[1]: disabled
[2]: disabled
[3]: disabled
[4]: disabled
[5]: disabled
[6]: disabled
```

Related Commands

debug mac

show eventlog

To display the event log, use the **show eventlog** command.

show eventlog

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the event log entries:

```
> show eventlog
```

	File	Line	TaskID	Code	Time			
					d	h	m	s
EVENT>	bootos.c	788	125CEBCC	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125CEBCC	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	125C597C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	1216C36C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	1216C36C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	1216C36C	AAAAAAAA	0	0	0	6
EVENT>	bootos.c	788	1216C36C	AAAAAAAA	0	0	0	11

show memory monitor

To display a summary of memory analysis settings and any discovered memory issues, use the **show memory monitor** command.

show memory monitor [detail]

Syntax Description	detail	(Optional) Displays details of any memory leaks or corruption.

Command Default None.

Usage Guidelines Be careful when changing the defaults for the **config memory monitor** command unless you know what you are doing, you have detected a problem, or you are collecting troubleshooting information.

Examples This example shows how to display a summary of memory monitoring settings and a summary of test results:

```
> show memory monitor
Memory Leak Monitor Status:
low_threshold(10000), high_threshold(30000), current status(disabled)
-----
Memory Error Monitor Status:
Crash-on-error flag currently set to (disabled)
No memory error detected.
```

This example shows how to display the monitor test results:

```
> show memory monitor detail
Memory error detected. Details:
-----
- Corruption detected at pmalloc entry address:          (0x179a7ec0)
- Corrupt entry:headerMagic(0xdeadf00d),trailer(0xabcd),poison(0xreadceef),
entrysize(128),bytes(100),thread(Unknown task name,task id = (332096592)),
file(pmalloc.c),line(1736),time(1027)
Previous 1K memory dump from error location.
-----
(179a7ac0): 00000000 00000000 00000000 ceeff00d readf00d 00000080 00000000 00000000
(179a7ae0): 17958b20 00000000 1175608c 00000078 00000000 readceef 179a7afc 00000001
(179a7b00): 00000003 00000006 00000001 00000004 00000001 00000009 00000009 0000020d
(179a7b20): 00000001 00000002 00000002 00000001 00000004 00000000 00000000 5d7b9aba
(179a7b40): cbddf004 192f465e 7791acc8 e5032242 5365788c alb7cee6 00000000 00000000
(179a7b60): 00000000 00000000 00000000 00000000 00000000 ceeff00d readf00d 00000080
(179a7b80): 00000000 00000000 17958dc0 00000000 1175608c 00000078 00000000 readceef
(179a7ba0): 179a7ba4 00000001 00000003 00000006 00000001 00000004 00000001 00003763
(179a7c00): 1722246c 1722246c 00000000 00000000 00000000 00000000 00000000 ceeff00d
(179a7c20): readf00d 00000080 00000000 00000000 179a7b78 00000000 1175608c 00000078
...
```

Related Commands

- config memory monitor errors
- config memory monitor leaks
- debug memory

show run-config

To display a comprehensive view of the current Cisco wireless LAN controller configuration, use the **show run-config** command.

show run-config [**no-ap** | **commands**]

Syntax Description

no-ap	(Optional) Excludes access point configuration settings.
commands	(Optional) Displays a list of user-configured commands on the controller.

Command Default

None.

Usage Guidelines

These commands have replaced the **show running-config** command.

Some WLAN controllers may have no Crypto Accelerator (VPN termination module) or power supplies listed because they have no provisions for VPN termination modules or power supplies.

The **show run-config** command shows only values configured by the user. It does not show system-configured default values.

Examples

This example shows how to display the current controller running configuration:

```
> show run-config
Press Enter to continue...
System Inventory
Switch Description..... Cisco Controller
Machine Model.....
Serial Number..... FLS0923003B
Burned-in MAC Address..... xx:xx:xx:xx:xx:xx
Crypto Accelerator 1..... Absent
Crypto Accelerator 2..... Absent
Power Supply 1..... Absent
Power Supply 2..... Present, OK
Press Enter to continue Or <Ctl Z> to abort...
```

Related Commands

config passwd-cleartext

show process

To display how various processes in the system are using the CPU at that instant in time, use the **show process** command.

show process {cpu | memory}

Syntax Description

cpu	Displays how various system tasks are using the CPU at that moment.
memory	Displays the allocation and deallocation of memory from various processes in the system at that moment.

Command Default

None.

Usage Guidelines

This command is helpful in understanding if any single task is monopolizing the CPU and preventing other tasks from being performed.

Examples

This example shows how to display various tasks in the system that are using the CPU at a given moment:

```
> show process cpu
Name      Priority    CPU Use    Reaper
reaperWatcher ( 3/124)    0 %      ( 0/ 0)%    I
osapiReaper  (10/121)    0 %      ( 0/ 0)%    I
TempStatus   (255/ 1)    0 %      ( 0/ 0)%    I
emWeb        (255/ 1)    0 %      ( 0/ 0)%    T 300
cliWebTask   (255/ 1)    0 %      ( 0/ 0)%    I
UtilTask     (255/ 1)    0 %      ( 0/ 0)%    T 300
```

This example shows how to display the allocation and deallocation of memory from various processes at a given moment:

```
> show process memory
Name      Priority    BytesinUse    Reaper
reaperWatcher ( 3/124)    0      ( 0/ 0)%    I
osapiReaper  (10/121)    0      ( 0/ 0)%    I
TempStatus   (255/ 1)    308      ( 0/ 0)%    I
emWeb        (255/ 1)    294440     ( 0/ 0)%    T 300
cliWebTask   (255/ 1)    738      ( 0/ 0)%    I
UtilTask     (255/ 1)    308      ( 0/ 0)%    T 300
```

Related Commands

debug memory
transfer upload datatype

show tech-support

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support** command.

show tech-support

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display system resource information:

```
> show tech-support
Current CPU Load..... 0%
System Buffers
  Max Free Buffers..... 4608
  Free Buffers..... 4604
  Buffers In Use..... 4
Web Server Resources
  Descriptors Allocated..... 152
  Descriptors Used..... 3
  Segments Allocated..... 152
  Segments Used..... 3
System Resources
  Uptime..... 747040 Secs
  Total Ram..... 127552 Kbytes
  Free Ram..... 19540 Kbytes
  Shared Ram..... 0 Kbytes
  Buffer Ram..... 460 Kbytes
```

config memory monitor errors

To enable or disable monitoring for memory errors and leaks, use the **config memory monitor errors** command.

config memory monitor errors {enable | disable}



Caution

The **config memory monitor** commands can be disruptive to your system and should be run only when you are advised to do so by the Cisco TAC.

Syntax Description

enable	Enables the monitoring for memory settings.
disable	Disables the monitoring for memory settings.

Command Default

Disabled by default.

Usage Guidelines



Note

Be cautious about changing the defaults for the **config memory monitor** command unless you know what you are doing, you have detected a problem, or you are collecting troubleshooting information.

Examples

This example shows how to enable monitoring for memory errors and leaks for a controller:

```
> config memory monitor errors enable
```

Related Commands

config memory monitor leaks
debug memory
show memory monitor

config memory monitor leaks

To configure the controller to perform an auto-leak analysis between two memory thresholds, use the **config memory monitor leaks** command.

config memory monitor leaks *low_thresh high_thresh*



Caution

The **config memory monitor** commands can be disruptive to your system and should be run only when you are advised to do so by the Cisco TAC.

Syntax Description

<i>low_thresh</i>	Value below which free memory cannot fall without crashing. This value cannot be set lower than 10000 KB.
<i>high_thresh</i>	Value below which the controller enters auto-leak-analysis mode. See the “Usage Guidelines” section.

Command Default

The default value for *low_thresh* is 10000 KB; the default value for *high_thresh* is 30000 KB.

Usage Guidelines

Note

Be cautious about changing the defaults for the **config memory monitor** command unless you know what you are doing, you have detected a problem, or you are collecting troubleshooting information.

Use this command if you suspect that a memory leak has occurred.

If the free memory is lower than the *low_thresh* threshold, the system crashes, generating a crash file. The default value for this parameter is 10000 KB, and you cannot set it below this value.

Set the *high_thresh* threshold to the current free memory level or higher so that the system enters auto-leak-analysis mode. After the free memory reaches a level lower than the specified *high_thresh* threshold, the process of tracking and freeing memory allocation begins. As a result, the **debug memory events enable** command shows all allocations and frees, and the **show memory monitor detail** command starts to detect any suspected memory leaks.

Examples

This example shows how to set the threshold values for auto-leak-analysis mode to 12000 KB for the low threshold and 35000 KB for the high threshold:

```
> config memory monitor leaks 12000 35000
```

Related Commands

config memory monitor leaks
debug memory

show memory monitor

config msglog level critical

To reset the message log so that it collects and displays only critical (highest-level) messages, use the **config msglog level critical** command.

config msglog level critical

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines The message log always collects and displays critical messages, regardless of the message log level setting.

Examples This example shows how to configure the message log severity level and display critical messages:

```
> config msglog level critical
```

Related Commands **show msglog**

config msglog level error

To reset the message log so that it collects and displays both critical (highest-level) and error (second-highest) messages, use the **config msglog level error** command.

config msglog level error

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Examples

This example shows how to reset the message log to collect and display critical and noncritical error messages:

```
> config msglog level error
```

Related Commands

show msglog

config msglog level security

To reset the message log so that it collects and displays critical (highest-level), error (second-highest), and security (third-highest) messages, use the **config msglog level security** command.

config msglog level security

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to reset the message log so that it collects and display critical, noncritical, and authentication or security-related errors:

```
> config msglog level security
```

Related Commands	show msglog

config msglog level verbose

To reset the message log so that it collects and displays all messages, use the **config msglog level verbose** command.

config msglog level verbose

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to reset the message logs so that it collects and display all messages:

```
> config msglog level verbose
```

Related Commands	show msglog

config msglog level warning

To reset the message log so that it collects and displays critical (highest-level), error (second-highest), security (third-highest), and warning (fourth-highest) messages, use the **config msglog level warning** command.

config msglog level warning

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to reset the message log so that it collects and displays warning messages in addition to critical, noncritical, and authentication or security-related errors:

```
> config msglog level warning
```

Related Commands	show msglog



PART II

Ports and Interfaces Commands

- [CLI Commands, page 535](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 535](#)
- [config Commands, page 552](#)

show Commands

This section lists the **show** commands that you can use to display information about the controller ports and interfaces.

show advanced sip-snooping-ports

To display the port range for call snooping, use the **show advanced sip-snooping-ports** command.

show advanced sip-snooping-ports

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the call snooping port range:

```
> show advanced sip-snooping-ports
SIP Call Snoop Ports: 1000 - 2000
```

Related Commands

- show cac voice stats**
- show cac voice summary**
- show cac video stats**
- show cac video summary**
- config 802.11 cac video sip**
- config 802.11 cac voice sip**
- show advanced sip-preferred-call-no**
- config advanced sip-snooping-ports**
- debug cac**

show advanced statistics

To display whether or not the Cisco wireless LAN controller port statistics are enabled or disabled, use the **show advanced statistics** command.

show advanced statistics

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display switch port statistics mode:

```
> show advanced statistics
Switch port statistics..... Enabled
```

Related Commands	config advanced statistics

show interface

To display details of the system interfaces, use the **show interface** command.

show interface {**summary** | **detailed** {*interface_name* | **management** | **redundancy-management** | **redundancy-port** | **service-port** | **virtual**}

Syntax Description

summary	Displays a summary of the local interfaces.
detailed	Displays detailed interface information.
<i>interface_name</i>	Interface name for detailed display.
management	Displays detailed management interface information.
redundancy-management	Displays detailed redundancy management interface information.
redundancy-port	Displays detailed redundancy port information.
service-port	Displays detailed service port information.
virtual	Displays detailed virtual gateway interface information.

Command Default

None.

Examples

This example shows how to display a summary of the local interfaces:

```
> show interface summary
Interface Name      Port  Vlan Id  IP Address      Type  Ap Mgr Guest
-----
ap-manager          1      untagged  xxx.xxx.xxx.xxx Static   Yes   No
management          1      untagged  xxx.xxx.xxx.xxx Static   No    No
service-port        N/A     N/A      xxx.xxx.xxx.xxx Static   No    No
virtual             N/A     N/A      xxx.xxx.xxx.xxx Static   No    No
```

This example shows how to display the detailed interface information:

```
> show interface detailed management
Interface Name..... management
MAC Address..... 88:43:e1:7e:0b:20
IP Address..... 9.4.120.99
IP Netmask..... 255.255.255.0
IP Gateway..... 9.4.120.1
External NAT IP State..... Disabled
External NAT IP Address..... 0.0.0.0
VLAN..... 120
Quarantine-vlan..... 0
NAS-Identifier..... Building1
Active Physical Port..... 1
Primary Physical Port..... 1
```



```

Backup Physical Port..... Unconfigured
DHCP Proxy Mode..... Global
Primary DHCP Server..... 9.1.0.100
Secondary DHCP Server..... Unconfigured
DHCP Option 82..... Disabled
ACL..... Unconfigured
mDNS Profile Name..... Unconfigured
AP Manager..... Yes
Guest Interface..... No
L2 Multicast..... Enabled

```

**Note**

Some WLAN controllers may have only one physical port listed because they have only one physical port.

This example shows how to display the detailed redundancy management interface information:

```

> show interface detailed redundancy-management
Interface Name..... redundancy-management
MAC Address..... 88:43:e1:7e:0b:20
IP Address..... 209.165.201.2

```

This example shows how to display the detailed redundancy port information:

```

> show interface detailed redundancy-port
Interface Name..... redundancy-port
MAC Address..... 88:43:e1:7e:0b:22
IP Address..... 169.254.120.5

```

This example shows how to display the detailed service port information:

```

> show interface detailed service-port
Interface Name..... redundancy-port
MAC Address..... 88:43:e1:7e:0b:22
IP Address..... 169.254.120.5

```

This example shows how to display the detailed virtual gateway interface information:

```

> show interface detailed virtual
Interface Name..... virtual
MAC Address..... 88:43:e1:7e:0b:20
IP Address..... 1.1.1.1
Virtual DNS Host Name..... Disabled
AP Manager..... No
Guest Interface..... No

```

Related Commands

config interface

config interface group

show interface group

show interface group

To display details of system interface groups, use the **show interface group** command.

show interface group {**summary** | **detailed** *interface_group_name*}

Syntax Description

summary	Displays a summary of the local interface groups.
detailed	Displays detailed interface group information.
<i>interface_group_name</i>	Interface group name for a detailed display.

Command Default

None.

Examples

This example shows how to display a summary of local interface groups:

```
> show interface group summary
Interface Group Name      Total Interfaces      Total WLANs      Total AP Groups      Quarantine
-----
mygroup1                  1                     0                 0                     No
mygroup2                  1                     0                 0                     No
mygroup3                  5                     1                 0                     No
```

This example shows how to display the detailed interface group information:

```
> show interface group detailed mygroup1
Interface Group Name..... mygroup1
Quarantine ..... No
Number of Wlans using the Interface Group..... 0
Number of AP Groups using the Interface Group.... 0
Number of Interfaces Contained..... 1
mDNS Profile Name..... NCS12Prof
Interface Group Description..... My Interface Group
Next interface for allocation to client..... testabc
Interfaces Contained in this group ..... testabc
Interface marked with * indicates DHCP dirty interface
Interface list sorted based on vlan:

Index  Vlan      Interface Name
-----
0      42        testabc
```

Related Commands

show interface
config interface group

show lag eth-port-hash

To display the physical port used for specific MAC addresses, use the **show lag eth-port-hash** command.

show lag eth-port-hash *dest_MAC* [*source_MAC*]

Syntax Description

<i>dest_MAC</i>	MAC address to determine output port for non-IP packets.
<i>source_MAC</i>	(Optional) MAC address to determine output port for non-IP packets.

Command Default

None.

Examples

This example shows how to display the physical port used for a specific MAC address:

```
> show lag eth-port-hash 11:11:11:11:11:11
Destination MAC 11:11:11:11:11:11 currently maps to port 1
```

Related Commands

config lag

show lag ip-port-hash

To display the physical port used for specific IP addresses, use the **show lag ip-port-hash** command.

show lag ip-port-hash *dest_IP* [*source_IP*]

Syntax Description

<i>dest_IP</i>	IP address to determine the output port for IP packets.
<i>source_IP</i>	(Optional) IP address to determine the output port for IP packets.

Command Default

None.

Usage Guidelines

For CAPWAP packets, enter the AP's IP address. For EOIP packets, enter the WLC's IP address. For WIRED_GUEST packets, enter its IP address. For nontunneled IP packets from WLC, enter the destination IP address. For other nontunneled IP packets, enter both destination and source IP addresses.

Examples

This example shows how to display the physical port used for a specific IP address:

```
> show lag ip-port-hash 192.168.102.138
Destination IP 192.168.102.138 currently maps to port 1
```

Related Commands

config lag

show lag summary

To display the current link aggregation (LAG) status, use the **show lag summary** command.

show lag summary

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the current status of the LAG configuration:

```
> show lag summary  
LAG Enabled
```

Related Commands	config lag

show port

To display the Cisco wireless LAN controller port settings on an individual or global basis, use the **show port** command.

show port {*port* | **summary**}

Syntax Description

<i>port</i>	Information on the individual ports.
summary	Displays all ports.

Command Default

None.

Examples

This example shows how to display information about an individual wireless LAN controller port:

```
> show port 1
```

Pr	Type	STP Stat	Admin Mode	Physical Mode	Physical Status	Link Status	Link Trap	Mcast Appliance	POE
1	Normal	Disa	Enable	Auto	1000 Full	Down	Enable	Enable	N/A



Note

Some WLAN controllers may not have multicast or Power over Ethernet (PoE) listed because they do not support those features.

This example shows how to display a summary of all ports:

```
> show port summary
```

Pr	Type	STP Stat	Admin Mode	Physical Mode	Physical Status	Link Status	Link Trap	Mcast Appliance	POE	SFPTtype
1	Normal	Forw	Enable	Auto	1000 Full	Up	Enable	Enable	N/A	NotPresent
2	Normal	Disa	Enable	Auto	1000 Full	Down	Enable	Enable	N/A	NotPresent
3	Normal	Disa	Enable	Auto	1000 Full	Down	Enable	Enable	N/A	NotPresent
4	Normal	Disa	Enable	Auto	1000 Full	Down	Enable	Enable	N/A	NotPresent



Note

Some WLAN controllers may have only one port listed because they have only one physical port.

Related Commands

config stats port
config ap port
config interface port
config network web-auth port
config port

config spanningtree port mode
config spanningtree port pathcost
config spanningtree port priority
show stats port

show serial

To display the serial (console) port configuration, use the **show serial** command.

show serial

Syntax Description This command has no arguments or keywords.

Command Default 9600, 8, off, 1, none.

Examples This example shows how to display EIA-232 parameters and the serial port inactivity timeout:

```
> show serial
Serial Port Login Timeout (minutes)..... 45
Baud Rate..... 9600
Character Size..... 8
Flow Control:..... Disable
Stop Bits..... 1
Parity Type:..... none
```

Related Commands

- config serial baudrate**
- config serial timeout**

show spanningtree port

To display the Cisco wireless LAN controller spanning tree port configuration, use the **show spanningtree port** command.

show spanningtree port *port*

Syntax Description

port

Physical port number:

- 1 through 4 on Cisco 2100 Series Wireless LAN Controller.
- 1 or 2 on Cisco 4402 Series Wireless LAN Controller.
- 1 through 4 on Cisco 4404 Series Wireless LAN Controller.

Command Default

800C, Disabled, 802.1D, 128, 100, Auto.

Usage Guidelines

When the a Cisco 4400 Series wireless LAN controller is configured for port redundancy, the Spanning Tree Protocol (STP) must be disabled for all ports on the Cisco 4400 Series Wireless LAN Controller. STP can remain enabled on the switch connected to the Cisco 4400 Series Wireless LAN Controller.



Note

Some WLAN controllers do not support the spanning tree function.

Examples

This example shows how to display spanning tree values on a per port basis:

```
> show spanningtree port 3
STP Port ID..... 800C
STP Port State..... Disabled
STP Port Administrative Mode..... 802.1D
STP Port Priority..... 128
STP Port Path Cost..... 100
STP Port Path Cost Mode..... Auto
```

Related Commands

config spanningtree port mode
config spanningtree port pathcost
config spanningtree port priority
show spanningtree switch

show spanningtree switch

To display the Cisco wireless LAN controller network (DS port) spanning tree configuration, use the **show spanningtree switch** command.

show spanningtree switch

Syntax Description	This command has no arguments or keywords.
Command Default	None.
Usage Guidelines	Some WLAN controllers do not support the spanning tree function.
Examples	This example shows how to display spanning tree values on a per switch basis:

```
> show spanningtree switch
STP Specification..... IEEE 802.1D
STP Base MAC Address..... 00:0B:85:02:0D:20
Spanning Tree Algorithm..... Disable
STP Bridge Priority..... 32768
STP Bridge Max. Age (seconds)..... 20
STP Bridge Hello Time (seconds)..... 2
STP Bridge Forward Delay (seconds)..... 15
```

Related Commands	config spanningtree switch bridgepriority
	config spanningtree switch forwarddelay
	config spanningtree switch hellotime
	config spanningtree switch maxage
	config spanningtree switch mode

show stats port

To display physical port receive and transmit statistics, use the **show stats port** command.

show stats port {**detailed** *port* | **summary** *port*}

Syntax Description

detailed	Displays detailed port statistics.
summary	Displays port summary statistics.
<i>port</i>	Physical port number: • 1 through 4 on Cisco 2100 Series Wireless LAN Controllers. • 1 or 2 on Cisco 4402 Series Wireless LAN Controllers. • 1 through 4 on Cisco 4404 Series Wireless LAN Controllers. • 1 on Cisco WLCM Series Wireless LAN Controllers.

Command Default

None.

Examples

This example shows how to display the port summary information:

```
> show stats port summary
Packets Received Without Error..... 399958
Packets Received With Error..... 0
Broadcast Packets Received..... 8350
Packets Transmitted Without Error..... 106060
Transmit Packets Errors..... 0
Collisions Frames..... 0
Time Since Counters Last Cleared..... 2 day 11 hr 16 min 23 sec
```

This example shows how to display the detailed port information:

```
> show stats port detailed 1
PACKETS RECEIVED (OCTETS)
Total Bytes..... 267799881
64 byte pkts :918281
65-127 byte pkts :354016      128-255 byte pkts :1283092
256-511 byte pkts :8406      512-1023 byte pkts :3006
1024-1518 byte pkts :1184      1519-1530 byte pkts :0
> 1530 byte pkts :2
PACKETS RECEIVED SUCCESSFULLY
Total..... 2567987
Unicast Pkts :2547844      Multicast Pkts:0      Broadcast Pkts:20143
PACKETS RECEIVED WITH MAC ERRORS
Total..... 0
Jabbers :0      Undersize :0      Alignment :0
FCS Errors:0      Overruns :0
RECEIVED PACKETS NOT FORWARDED
Total..... 0
Local Traffic Frames:0      RX Pause Frames :0
Unacceptable Frames :0      VLAN Membership :0
VLAN Viable Discards:0      MulticastTree Viable:0
```

```

ReserveAddr Discards:0
CFI Discards :0 Upstream Threshold :0
PACKETS TRANSMITTED (OCTETS)
Total Bytes..... 353831
64 byte pkts :0 65-127 byte pkts :0
128-255 byte pkts :0 256-511 byte pkts :0
512-1023 byte pkts :0 1024-1518 byte pkts :2
1519-1530 byte pkts :0 Max Info :1522
PACKETS TRANSMITTED SUCCESSFULLY
Total..... 5875
Unicast Pkts :5868 Multicast Pkts:0 Broadcast Pkts:7
TRANSMIT ERRORS
Total Errors..... 0
FCS Error :0 TX Oversized :0 Underrun Error:0
TRANSMIT DISCARDS
Total Discards..... 0
Single Coll Frames :0 Multiple Coll Frames:0
Excessive Coll Frame:0 Port Membership :0
VLAN Viable Discards:0
PROTOCOL STATISTICS
BPDUs Received :6 BPDUs Transmitted :0
802.3x RX PauseFrame:0
Time Since Counters Last Cleared..... 2 day 0 hr 39 min 59 sec

```

Related Commands

config port adminmode
config port autoneg
config port linktrap
config port power
config port linktrap

show stats switch

To display the network (DS port) receive and transmit statistics, use the **show stats switch** command.

show stats switch {detailed | summary}

Syntax Description

detailed	Displays detailed switch statistics.
summary	Displays switch summary statistics.

Command Default

None.

Examples

This example shows how to display switch summary statistics:

```
> show stats switch summary
Packets Received Without Error..... 136410
Broadcast Packets Received..... 18805
Packets Received With Error..... 0
Packets Transmitted Without Error..... 78002
Broadcast Packets Transmitted..... 3340
Transmit Packet Errors..... 2
Address Entries Currently In Use..... 26
VLAN Entries Currently In Use..... 1
Time Since Counters Last Cleared..... 2 day 11 hr 22 min 17 sec
```

This example shows how to display detailed switch statistics:

```
> show stats switch detailed
RECEIVE
Octets..... 19351718
Total Pkts..... 183468
Unicast Pkts..... 180230
Multicast Pkts..... 3219
Broadcast Pkts..... 19
Pkts Discarded..... 0
TRANSMIT
Octets..... 354251
Total Pkts..... 5882
Unicast Pkts..... 5875
Multicast Pkts..... 0
Broadcast Pkts..... 7
Pkts Discarded..... 0
ADDRESS ENTRIES
Most Ever Used..... 1
Currently In Use..... 1
VLAN ENTRIES
Maximum..... 128
Most Ever Used..... 1
Static In Use..... 1
Dynamic In Use..... 0
VLANs Deleted..... 0
Time Since Ctrs Last Cleared..... 2 day 0 hr 43 min 22 sec
```

Related Commands

config switch
config mode

config switchconfig secret-obfuscation
show switchconfig

config Commands

This section lists the **config** commands to configure controller ports and interfaces.

config advanced statistics

To enable or disable the Cisco wireless LAN controller port statistics collection, use the **config advanced statistics** command.

config advanced statistics {enable | disable}

Syntax Description	enable	Enables the switch port statistics collection.
	disable	Disables the switch port statistics collection.

Command Default Enabled.

Examples This example shows how to disable the switch port statistics collection settings:

```
> config advanced statistics disable
```

Related Commands

- show advanced statistics
- show stats port
- show stats switch

config interface acl

To configure an interface's access control list, use the **config interface acl** command.

config interface acl {**ap-manager** | **management** | *interface_name*} {*ACL* | **none**}

Syntax Description

ap-manager	Configures the access point manager interface.
management	Configures the management interface.
<i>interface_name</i>	Interface name.
<i>ACL</i>	ACL name up to 32 alphanumeric characters.
none	Specifies none.

Command Default

None.

Usage Guidelines

For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.

Examples

This example shows how to configure an access control list with a value None:

```
> config interface acl management none
```

Related Commands

show interface

config interface address

To configure address information for an interface, use the **config interface address** command.

config interface address {**ap-manager** *IP_address netmask gateway* | **management** *IP_address netmask gateway* | **service-port** *IP_address netmask* | **virtual** *IP_address* | **dynamic-interface** *IP_address dynamic_interface netmask gateway* | **redundancy-management** *IP_address* **peer-redundancy-management** *IP_address* }

Syntax Description

ap-manager	Specifies the access point manager interface.
<i>IP_address</i>	IP address.
<i>netmask</i>	Network mask.
<i>gateway</i>	IP address of the gateway.
management	Specifies the management interface.
service-port	Specifies the out-of-band service port interface.
virtual	Specifies the virtual gateway interface.
interface-name	Specifies the interface identified by the <i>interface-name</i> parameter.
<i>interface-name</i>	Interface name.
redundancy-management	Configures redundancy management interface IP address.
peer-redundancy-management	Configures the peer redundancy management interface IP address.

Command Default

None.

Usage Guidelines

For Cisco 5500 Series Controllers, you are not required to configure an AP-manager interface. The management interface acts like an AP-manager interface by default.

Usage Guidelines

Ensure that the management interfaces of both controllers are in the same subnet. Ensure that the Redundant Management IP address for both controllers is the same. Likewise, ensure that the Peer Redundant Management IP address for both the controllers is the same.

Examples

This example shows how to configure an access point manager interface with IP address 209.165.201.31, network mask 255.255.0.0, and gateway address 209.165.201.30:

```
> config interface address ap-manager 209.165.201.31 255.255.0.0 209.165.201.30
```

This example shows how to configure a redundancy management interface on the controller:

```
> config interface address redundancy-management 209.4.120.5 peer-redundancy-management 209.4.120.6
```

This example shows how to configure a virtual interface:

```
> config interface address virtual 1.1.1.1
```

Related Commands **show interface**

config interface address peer-redundancy-management

To configure the management interface IP address of the peer controller, use the **config interface address peer-redundancy-management** command.

config interface address peer-redundancy-management *IP_address*

Syntax Description	<i>IP_address</i>	Management interface IP address of the peer controller.

Command Default None.

Usage Guidelines You can use this command to check the Active-Standby reachability when the keep-alive fails.

Examples This example shows how to configure the management IP addresses of the peer controller:

```
> config interface address peer-redundancy-management 209.165.201.30
```

Related Commands

- config redundancy mobilitymac
- config redundancy interface address peer-service-port
- config redundancy peer-route
- config redundancy unit
- config redundancy timer
- show redundancy timers
- show redundancy summary
- debug rmgr
- debug rsyncmgr

config interface address redundancy-management

To configure the management interface IP address of active and standby controllers, use the **config interface address redundancy-management** command.

config interface address redundancy-management *IP_address1* **peer-redundancy-management** *IP_address2*

Syntax Description

<i>IP_address</i>	Management interface IP address of the active controller.
peer-redundancy-management	Specifies the management interface IP address of the peer controller.
<i>IP_address2</i>	Management interface IP address of the peer controller.

Command Default

None.

Usage Guidelines

You can use this command to check the Active-Standby reachability when the keep-alive fails and to configure an alias IP for the management port of the controller. Both the IP addresses must be in the same subnet.

Examples

This example shows how to configure the management IP addresses of the active and standby controllers:

```
> config interface address redundancy-management 209.165.201.30 peer-redundancy-management 209.165.201.31
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy timers
show redundancy summary
debug rmgr
debug rsyncmgr

config interface ap-manager

To enable or disable access point manager features on the management or dynamic interface, use the **config interface ap-manager** command.

config interface ap-manager {**management** | *interface_name*} {**enable** | **disable**}

Syntax Description

management	Specifies the management interface.
<i>interface_name</i>	Dynamic interface name.
enable	Enables access point manager features on a dynamic interface.
disable	Disables access point manager features on a dynamic interface.

Command Default

None.

Usage Guidelines

Use the **management** option to enable or disable dynamic AP management for the management interface. For Cisco 5500 Series Controllers, the management interface acts like an AP-manager interface by default. If desired, you can disable the management interface as an AP-manager interface and create another dynamic interface as an AP manager.

When you enable this feature for a dynamic interface, the dynamic interface is configured as an AP-manager interface (only one AP-manager interface is allowed per physical port). A dynamic interface that is marked as an AP-manager interface cannot be used as a WLAN interface.

Examples

This example shows how to disable an access point manager myinterface:

```
> config interface ap-manager myinterface disable
```

Related Commands

show interface

config interface create

To create a dynamic interface (VLAN) for wired guest user access, use the **config interface create** command.

config interface create *interface_name* *vlan-id*

Syntax Description

<i>interface_name</i>	Interface name.
<i>vlan-id</i>	VLAN identifier.

Command Default

None.

Examples

This example shows how to create a dynamic interface with the interface named lab2 and VLAN ID 6:

```
> config interface create lab2 6
```

Related Commands

show interface

config interface delete

To delete a dynamic interface, use the **config interface delete** command.

config interface delete *interface-name*

Syntax Description

<i>interface-name</i>	Interface name.

Command Default

None.

Examples

This example shows how to delete a dynamic interface named VLAN501:

```
> config interface delete VLAN501
```

Related Commands

show interface

config interface dhcp

To configure DHCP options on an interface, use the **config interface dhcp** command.

config interface dhcp {**ap-manager** [**primary** *dhcp_server* **secondary** *dhcp_server* | **option-82** [**enable** | **disable**]] | **management** [**primary** *dhcp_server* **secondary** *dhcp_server* | **option-82** [**enable** | **disable**]] | **service-port** {**enable** | **disable**} | **dynamic-interface***interface_name* [**primary** *dhcp_server* **secondary** *dhcp_server* | **option-82** [**enable** | **disable**] | **proxy-mode** {**enable** | **disable** | **global**}]}

Syntax Description

ap-manager	Configures the access point manager interface.
primary	(Optional) Specifies the primary DHCP server.
<i>dhcp_server</i>	IP address of the server.
secondary	(Optional) Specifies the secondary DHCP server.
option-82	(Optional) Configures DHCP Option 82 on the interface.
enable	(Optional) Enables the feature.
disable	(Optional) Disables the feature.
management	Configures the management interface.
service-port	Specifies the DHCP for the out-of-band service port.
dynamic-interface	Specifies the interface and the primary DHCP server. Optionally, you can also enter the address of the alternate DHCP server.
<i>name</i>	Specifies the interface name
proxy-mode	(Optional) Configures the DHCP proxy mode on the interface.
enable	(Optional) Enables the DHCP proxy mode on the interface.
disable	(Optional) Disables the DHCP proxy mode on the interface.
global	(Optional) Uses the global DHCP proxy mode on the interface.

Command Default

None.

Examples

This example shows how to configure ap-manager server with the primary DHCP server 10.21.15.01 and secondary DHCP server 10.21.15.25:

```
> config interface dhcp ap-manager server-1 10.21.15.01 server-2 10.21.15.25
```

This example shows how to configure DHCP option 82 on the ap-manager:

```
> config interface dhcp ap-manager option-82 enable
```

This example shows how to enable the DHCP for the out-of-band service port:

```
> config interface dhcp service-port enable
```

Related Commands

config dhcp

config dhcp proxy

config interface dhcp

config wlan dhcp_server

debug dhcp

debug dhcp service-port

debug disable-all

show dhcp

show dhcp proxy

show interface

config interface address

To configure interface addresses, use the **config interface address** command.

config interface address {**dynamic-interface** *dynamic_interface* *netmask* *gateway* | **management** | **redundancy-management** *IP_address* **peer-redundancy-management** | **service-port** *netmask* | **virtual**} *IP_address*

Syntax Description

dynamic-interface	Configures the dynamic interface of the controller.
<i>dynamic_interface</i>	Dynamic interface of the controller.
<i>IP_address</i>	IP address of the interface.
<i>netmask</i>	Netmask of the interface.
<i>gateway</i>	Gateway of the interface.
management	Configures the management interface IP address.
redundancy-management	Configures redundancy management interface IP address.
peer-redundancy-management	Configures the peer redundancy management interface IP address.
service-port	Configures the out-of-band service port.
virtual	Configures the virtual gateway interface.

Command Default

None.

Usage Guidelines

Ensure that the management interfaces of both controllers are in the same subnet. Ensure that the redundant management IP address for both controllers is the same and that the peer redundant management IP address for both the controllers is the same.

Examples

This example shows how to configure a redundancy management interface on the controller:

```
> config interface address redundancy-management 209.4.120.5 peer-redundancy-management 209.4.120.6
```

This example shows how to configure a virtual interface:

```
> config interface address virtual 1.1.1.1
```

Related Commands

show interface group summary

show interface summary

config interface guest-lan

To enable or disable the guest LAN VLAN, use the **config interface guest-lan** command.

config interface guest-lan *interface_name* {*enable* | *disable*}

Syntax Description

<i>interface_name</i>	Interface name.
enable	Enables the guest LAN.
disable	Disables the guest LAN.

Command Default

None.

Examples

This example shows how to enable the guest LAN feature on the interface named myinterface:

```
> config interface guest-lan myinterface enable
```

Related Commands

config guest-lan create

config interface hostname

To configure the Domain Name System (DNS) hostname of the virtual gateway interface, use the **config interface hostname** command.

config interface hostname virtual *DNS_host*

Syntax Description	<table> <tr> <td data-bbox="386 510 646 537">virtual</td><td data-bbox="678 510 1528 659"> Specifies the virtual gateway interface to use the specified virtual address of the fully qualified DNS name. The virtual gateway IP address is any fictitious, unassigned IP address, such as 1.1.1.1, to be used by Layer 3 security and mobility managers. </td></tr> <tr> <td data-bbox="386 680 646 707"><i>DNS_host</i></td><td data-bbox="678 680 1528 707">DNS hostname.</td></tr> </table>	virtual	Specifies the virtual gateway interface to use the specified virtual address of the fully qualified DNS name. The virtual gateway IP address is any fictitious, unassigned IP address, such as 1.1.1.1, to be used by Layer 3 security and mobility managers.	<i>DNS_host</i>	DNS hostname.
virtual	Specifies the virtual gateway interface to use the specified virtual address of the fully qualified DNS name. The virtual gateway IP address is any fictitious, unassigned IP address, such as 1.1.1.1, to be used by Layer 3 security and mobility managers.				
<i>DNS_host</i>	DNS hostname.				
Command Default	None.				
Examples	This example shows how to configure virtual gateway interface to use the specified virtual address of the fully qualified DNS hostname DNS_Host: <pre>> config interface hostname virtual DNS_Host</pre>				
Related Commands	show interface				

config interface nasid

To configure the Network Access Server identifier (NAS-ID) for the interface, use the **config interface nasid** command.

config interface nasid {*NAS-ID* | **none**} *interface_name*

Syntax Description

<i>NAS-ID</i>	Network Access Server identifier (NAS-ID) for the interface. The NAS-ID is sent to the RADIUS server by the controller (as a RADIUS client) using the authentication request, which is used to classify users to different groups. You can enter up to 32 alphanumeric characters. Beginning in Release 7.4 and later releases, you can configure the NAS-ID on the interface, WLAN, or an access point group. The order of priority is AP group NAS-ID > WLAN NAS-ID > Interface NAS-ID.
none	Configures the controller system name as the NAS-ID.
<i>interface_name</i>	Interface name up to 32 alphanumeric characters.

Command Default

None.

Usage Guidelines

The NAS-ID configured on the controller for AP group or WLAN or interface is used for authentication. The NAS-ID is not propagated across controllers.

Examples

This example shows how to configure the NAS-ID for the interface:

```
> config interface nasid
```

Related Commands

config wlan nasid
config wlan apgroup

config interface nat-address

To deploy your Cisco 5500 Series Controller behind a router or other gateway device that is using one-to-one mapping network address translation (NAT), use the **config interface nat-address** command.

config interface nat-address {**management** | **dynamic-interface** *interface_name*} [{**enable** | **disable**} | {**set** *public_IP_address*}]

Syntax Description

management	Specifies the management interface.
dynamic-interface <i>interface_name</i>	Specifies the dynamic interface name.
enable	Enables one-to-one mapping NAT on the interface.
disable	Disables one-to-one mapping NAT on the interface.
<i>public_IP_address</i>	External NAT IP address.

Command Default

None.

Usage Guidelines

These NAT commands can be used only on Cisco 5500 Series Controllers and only if the management interface is configured for dynamic AP management.

These commands are supported for use only with one-to-one-mapping NAT, where each private client has a direct and fixed mapping to a global address. They do not support one-to-many NAT, which uses source port mapping to enable a group of clients to be represented by a single IP address.

Examples

This example shows how to enable one-to-one mapping NAT on the management interface:

```
> config interface nat-address management enable
```

This example shows how to set the external NAT IP address 10.10.10.10 on the management interface:

```
> config interface nat-address management set 10.10.10.10
```

Related Commands

show interface

config interface port

To map a physical port to the interface (if a link aggregation trunk is not configured), use the **config interface port** command.

config interface port {**management** | *interface_name* | **redundancy-management**} *primary_port* [*secondary_port*]

Syntax Description

management	Specifies the management interface.
<i>interface_name</i>	Interface name.
redundancy-management	Specifies the redundancy management interface.
<i>primary_port</i>	Primary physical port number.
<i>secondary_port</i>	(Optional) Secondary physical port number.

Command Default

None.

Usage Guidelines

You can use the **management** option for all controllers except the Cisco 5500 Series Controllers.

Examples

This example shows how to configure the LAb02 interface's primary port number to 3:

```
> config interface port lab02 3
```

Related Commands

show interface
config interface create

config interface quarantine vlan

To configure a quarantine VLAN on any dynamic interface, use the **config interface quarantine vlan** command.

config interface quarantine vlan *interface-name* *vlan_id*

Syntax Description

<i>interface-name</i>	Interface's name.
<i>vlan_id</i>	VLAN identifier. Note Enter 0 to disable quarantine processing.

Command Default

None.

Examples

This example shows how to configure a quarantine VLAN on the quarantine interface with the VLAN ID 10:

```
> config interface quarantine vlan quarantine 10
```

Related Commands

show interface

config interface vlan

To configure an interface VLAN identifier, use the **config interface vlan** command.

config interface vlan {**ap-manager** | **management** | *interface-name*} *vlan*

Syntax Description

ap-manager	Configures the access point manager interface.
management	Configures the management interface.
<i>interface_name</i>	Interface name.
<i>vlan</i>	VLAN identifier.

Command Default

None.

Examples

This example shows how to configure VLAN ID 10 on the management interface:

```
> config interface vlan management 10
```

Related Commands

show interface

config interface group mdns-profile

To configure an mDNS (multicast DNS) profile for an interface group, use the **config interface group mdns-profile** command.

config interface group mdns-profile {**all** | *interface-group-name*} {*profile-name* | **none**}

Syntax Description		
	all	Configures an mDNS profile for all interface groups.
	<i>interface-group-name</i>	Name of the interface group to which the mDNS profile has to be associated. The interface group name can be up to 32 case-sensitive, alphanumeric characters.
	<i>profile-name</i>	Name of the mDNS profile.
	none	Removes all existing mDNS profiles from the interface group. You cannot configure mDNS profiles on the interface group.

Command Default None.

Usage Guidelines If the mDNS profile is associated to a WLAN, an error appears.

Examples This example shows how to configure an mDNS profile for an interface group floor1:

```
> config interface group mdns-profile floor1 profile1
```

Related Commands

- config mdns query interval
- config mdns service
- config mdns snooping
- config interface mdns-profile
- config mdns profile
- config wlan mdns
- show mdns profile
- show mnds service
- clear mdns service-database
- debug mdns all
- debug mdns error
- debug mdns detail
- debug mdns message

config interface mdns-profile

To configure an mDNS (multicast DNS) profile for an interface, use the **config interface mdns-profile** command.

config interface mdns-profile {**management** | **all** *interface-name*} {*profile-name* | **none**}

Syntax Description

management	Configures an mDNS profile for the management interface.
all	Configures an mDNS profile for all interfaces.
<i>interface-name</i>	Name of the interface on which the mDNS profile has to be configured. The interface name can be up to 32 case-sensitive, alphanumeric characters.
<i>profile-name</i>	Name of the mDNS profile.
none	Removes all existing mDNS profiles from the interface. You cannot configure mDNS profiles on the interface.

Command Default

None.

Usage Guidelines

If the mDNS profile is associated to a WLAN, an error appears.

Examples

This example shows how to configure an mDNS profile for an interface lab1:

```
> config interface mdns-profile lab1 profile1
```

Related Commands

config mdns query interval
config mdns service
config mdns snooping
config mdns profile
config interface group mdns-profile
config wlan mdns
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail

debug mdns message

config lag

To enable or disable link aggregation (LAG), use the **config lag** command.

config lag {enable | disable}

Syntax Description

enable	Enables the link aggregation (LAG) settings.
disable	Disables the link aggregation (LAG) settings.

Command Default

None.

Examples

This example shows how to enable LAG settings:

```
> config lag enable
Enabling LAG will map your current interfaces setting to LAG interface,
All dynamic AP Manager interfaces and Untagged interfaces will be deleted
All WLANs will be disabled and mapped to Mgmt interface
Are you sure you want to continue? (y/n)
You must now reboot for the settings to take effect.
```

This example shows how to disable LAG settings:

```
> config lag disable
Disabling LAG will map all existing interfaces to port 1.
Are you sure you want to continue? (y/n)
You must now reboot for the settings to take effect.
```

Related Commands

show lag summary

config macfilter

To create or delete a MAC filter entry on the Cisco wireless LAN controller, use the **config macfilter** command.

config macfilter {**add** *client_MAC* *wlan_id* [*interface_name*] [*description*] [*macfilter_IP*] | **delete** *client_MAC*}

Syntax Description

add	Adds a MAC filter entry on the controller.
<i>client_MAC</i>	Client MAC address.
<i>wlan_id</i>	Wireless LAN identifier with which the MAC filter entry should associate. A zero value associates the entry with any wireless LAN.
<i>interface_name</i>	(Optional) Name of the interface. Enter 0 to specify no interface.
<i>description</i>	(Optional) Short description of the interface (up to 32 characters) in double quotes. Note A description is mandatory if <i>macfilter_IP</i> is specified.
<i>macfilter_IP</i>	(Optional) IP address of the local MAC filter database.
delete	Deletes a MAC filter entry on the controller.

Command Default

None.

Usage Guidelines

Use the **config macfilter add** command to add a client locally to a wireless LAN on the Cisco wireless LAN controller. This filter bypasses the RADIUS authentication process.

Examples

This example shows how to add a MAC filter entry 00:E0:77:31:A3:55 with the wireless LAN ID 1, interface name labconnect, and MAC filter IP 10.92.125.51 on the controller:

```
> config macfilter add 00:E0:77:31:A3:55 1 lab02 "labconnect" 10.92.125.51
```

Related Commands

show macfilter
config macfilter ip-address

config macfilter description

To add a description to a MAC filter, use the **config macfilter description** command.

config macfilter description *MAC description*

Syntax Description

<i>MAC</i>	Client MAC address.
<i>description</i>	(Optional) Description within double quotes (up to 32 characters).

Command Default

None.

Examples

This example shows how to set the description MAC filter 01 to MAC address 11:11:11:11:11:11:

```
> config macfilter description 11:11:11:11:11:11 "MAC Filter 01"
```

Related Commands

show macfilter

config macfilter interface

To create a MAC filter client interface, use the **config macfilter interface** command.

config macfilter interface *MAC interface*

Syntax Description

<i>MAC</i>	Client MAC address.
<i>interface</i>	Interface name. A value of zero is equivalent to no name.

Command Default

None.

Examples

This example shows how to create a MAC filter interface Lab01 on client 11:11:11:11:11:11:

```
> config macfilter interface 11:11:11:11:11:11 Lab01
```

Related Commands

show macfilter

config macfilter ip-address

To assign an IP address to an existing MAC filter entry if one was not assigned using the **config macfilter add** command, use the **config macfilter ip-address** command.

config macfilter ip-address *MAC_address IP_address*

Syntax Description

<i>MAC_address</i>	Client MAC address.
<i>IP_address</i>	IP address for a specific MAC address in the local MAC filter database.

Command Default

None.

Examples

This example shows how to specify IP address 10.92.125.51 for a MAC 00:E0:77:31:A3:55 in the local MAC filter database:

```
> config macfilter ip-address 00:E0:77:31:A3:55 10.92.125.51
```

Related Commands

show macfilter
config macfilter

config macfilter mac-delimiter

To set the MAC delimiter (colon, hyphen, none, and single-hyphen) for MAC addresses sent to RADIUS servers, use the **config macfilter mac-delimiter** command.

config macfilter mac-delimiter {none | colon | hyphen | single-hyphen}

Syntax Description

none	Disables the delimiters (for example, xxxxxxxxxx).
colon	Sets the delimiter to a colon (for example, xx:xx:xx:xx:xx:xx).
hyphen	Sets the delimiter to a hyphen (for example, xx-xx-xx-xx-xx-xx).
single-hyphen	Sets the delimiter to a single hyphen (for example, xxxxxx-xxxxxx).

Command Default

The default delimiter is hyphen.

Examples

This example shows how to have the operating system send MAC addresses to the RADIUS server in the form aa:bb:cc:dd:ee:ff:

```
> config macfilter mac-delimiter colon
```

This example shows how to have the operating system send MAC addresses to the RADIUS server in the form aa-bb-cc-dd-ee-ff:

```
> config macfilter mac-delimiter hyphen
```

This example shows how to have the operating system send MAC addresses to the RADIUS server in the form aabbccddeeff:

```
> config macfilter mac-delimiter none
```

Related Commands

show macfilter

config macfilter radius-compat

To configure the Cisco wireless LAN controller for compatibility with selected RADIUS servers, use the **config macfilter radius-compat** command.

config macfilter radius-compat {Cisco | free | other}

Syntax Description

Cisco	Configures the Cisco ACS compatibility mode (password is the MAC address of the server).
free	Configures the Free RADIUS server compatibility mode (password is secret).
other	Configures for other server behaviors (no password is necessary).

Command Default

Other.

Examples

This example shows how to configure the Cisco ACS compatibility mode to "other":

```
> config macfilter radius-compat other
```

Related Commands

show macfilter

config macfilter wlan-id

To modify a wireless LAN ID for a MAC filter, use the **config macfilter wlan-id** command.

config macfilter wlan-id *MAC wlan_id*

Syntax Description

<i>MAC</i>	Client MAC address.
<i>wlan_id</i>	Wireless LAN identifier to associate with. A value of zero is not allowed.

Command Default

None.

Examples

This example shows how to modify client wireless LAN ID 2 for a MAC filter 11:11:11:11:11:11:

```
> config macfilter wlan-id 11:11:11:11:11:11 2
```

Related Commands

show macfilter
show wlan

config macfilter wlan-id

To modify a wireless LAN ID for a MAC filter, use the **config macfilter wlan-id** command.

config macfilter wlan-id *MAC wlan_id*

Syntax Description

<i>MAC</i>	Client MAC address.
<i>wlan_id</i>	Wireless LAN identifier to associate with. A value of zero is not allowed.

Command Default

None.

Examples

This example shows how to modify client wireless LAN ID 2 for a MAC filter 11:11:11:11:11:11:

```
> config macfilter wlan-id 11:11:11:11:11:11 2
```

Related Commands

show macfilter
show wlan

config port adminmode

To enable or disable the administrative mode for a specific controller port or for all ports, use the **config port adminmode** command.

config port adminmode {all | *port*} {enable | disable}

Syntax Description

all	Configures all ports.
<i>port</i>	Number of the port.
enable	Enables the specified ports.
disable	Disables the specified ports.

Command Default

Enabled.

Examples

This example shows how to disable port 8:

```
> config port adminmode 8 disable
```

This example shows how to enable all ports:

```
> config port adminmode all enable
```

Related Commands

config port autoneg
config port linktrap
config port multicast appliance
config port physicalmode
config port power
show port
transfer download port

config port autoneg

To configure 10/100BASE-T Ethernet ports for physical port autonegotiation, use the **config port autoneg** command.

config port autoneg {all | *port*} {enable | disable}

Syntax Description

all	Configures all ports.
<i>port</i>	Number of the port.
enable	Enables the specified ports.
disable	Disables the specified ports.

Command Default

The default for all ports is that autonegotiation is enabled.

Usage Guidelines

You must disable port autoconfiguration before you make physical mode manual settings by using the **config port physicalmode** command. The **config port autoneg** command overrides settings that you made using the **config port physicalmode** command.

Examples

This example shows how to turn on physical port autonegotiation for all front-panel Ethernet ports:

```
> config port autoneg all enable
```

This example shows how to disable physical port autonegotiation for front-panel Ethernet port 19:

```
> config port autoneg 19 disable
```

Related Commands

config port adminmode
config port linktrap
config port multicast appliance
config port physicalmode
config port power
show port
transfer download port

config port linktrap

To enable or disable the up and down link traps for a specific controller port or for all ports, use the **config port linktrap** command.

config port linktrap {all | *port*} {enable | disable}

Syntax Description

all	Configures all ports.
<i>port</i>	Number of the port.
enable	Enables the specified ports.
disable	Disables the specified ports.

Command Default

Enabled.

Examples

This example shows how to disable port 8 traps:

```
> config port linktrap 8 disable
```

This example shows how to enable all port traps:

```
> config port linktrap all enable
```

Related Commands

config port adminmode
config port linktrap
config port multicast appliance
config port physicalmode
config port power
show port
transfer download port

config port multicast appliance

To enable or disable the multicast appliance service for a specific controller port or for all ports, use the **config port multicast appliance** commands.

config port multicast appliance {all | *port*} {enable | disable}

Syntax Description

all	Configures all ports.
<i>port</i>	Number of the port.
enable	Enables the specified ports.
disable	Disables the specified ports.

Command Default

Enabled.

Examples

This example shows how to enable multicast appliance service on all ports:

```
> config port multicast appliance all enable
```

This example shows how to disable multicast appliance service on port 8:

```
> config port multicast appliance 8 disable
```

Related Commands

config port adminmode
config port autoneg
config port linktrap
config port physicalmode
config port power
show port
transfer download port

config port power

To enable or disable Power over Ethernet (PoE) for a specific controller port or for all ports, use the **config port power** command.

config port power {all | *port*} {enable | disable}

Syntax Description

all	Configures all ports.
<i>port</i>	Port number.
enable	Enables the specified ports.
disable	Disables the specified ports.

Command Default

Enabled.

Examples

This example shows how to enable PoE on all ports:

```
> config port power all enable
```

This example shows how to disable PoE on port 8:

```
> config port power 8 disable
```

Related Commands

config port adminmode
config port autoneg
config port linktrap
config port physicalmode
config port power
show port
transfer download port

config route add

To configure a network route from the service port to a dedicated workstation IP address range, use the **config route add** command.

config route add *ip_address netmask gateway*

Syntax Description

<i>ip_address</i>	Network IP address.
<i>netmask</i>	Subnet mask for the network.
<i>gateway</i>	IP address of the gateway for the route network.

Command Default

None.

Examples

This example shows how to configure a network route to a dedicated workstation IP address 10.1.1.0, subnet mask 255.255.255.0, and gateway 10.1.1.1:

```
> config route add 10.1.1.0 255.255.255.0 10.1.1.1
```

Related Commands

show route summary
config route delete

config route delete

To remove a network route from the service port, use the **config route delete** command.

config route delete *ip_address*

Syntax Description	
	<i>ip_address</i> Network IP address.

Command Default	
	None.

Examples	
	This example shows how to delete a route from the network IP address 10.1.1.0: > config route delete 10.1.1.0

Related Commands	
	show route all config route add

config serial baudrate

To set the serial port baud rate, use the **config serial baudrate** command.

config serial baudrate {1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600}

Syntax Description

1200	Specifies the supported connection speeds to 1200.
2400	Specifies the supported connection speeds to 2400.
4800	Specifies the supported connection speeds to 4800.
9600	Specifies the supported connection speeds to 9600.
19200	Specifies the supported connection speeds to 19200.
38400	Specifies the supported connection speeds to 38400.
57600	Specifies the supported connection speeds to 57600.

Command Default

9600.

Examples

This example shows how to configure a serial baud rate with the default connection speed of 9600:

```
> config serial baudrate 9600
```

Related Commands

config serial timeout

config serial timeout

To set the timeout of a serial port session, use the **config serial timeout** command.

config serial timeout *minutes*

Syntax Description	<i>minutes</i>	Timeout in minutes from 0 to 160. A value of 0 indicates no timeout.
Command Default	0 (no timeout).	
Usage Guidelines	Use this command to set the timeout for a serial connection to the front of the Cisco wireless LAN controller from 0 to 160 minutes where 0 is no timeout.	
Examples	This example shows how to configure the timeout of a serial port session to 10 minutes: > config serial timeout 10	
Related Commands	config serial timeout	

config spanningtree port mode

To turn fast or 802.1D Spanning Tree Protocol (STP) on or off for one or all Cisco wireless LAN controller ports, use the **config spanningtree port mode** command.

config spanningtree port mode {**off** | **802.1d** | **fast**} {*port* | **all**}

Syntax Description

off	Disables STP for the specified ports.
802.1d	Specifies a supported port mode as 802.1D.
fast	Specifies a supported port mode as fast.
<i>port</i>	Port number (1 through 12 or 1 through 24).
all	Configures all ports.

Command Default

The default is that port STP is off.

Usage Guidelines

When the Cisco 4400 Series Wireless LAN Controller is configured for port redundancy, STP must be disabled for all ports on the controller. STP can remain enabled on the switch connected to the controller.

Entering this command allows the controller to set up STP, detect logical network loops, place redundant ports on standby, and build a network with the most efficient pathways.

Examples

This example shows how to disable STP for all Ethernet ports:

```
> config spanningtree port mode off all
```

This example shows how to turn on STP 802.1D mode for Ethernet port 24:

```
> config spanningtree port mode 802.1d 24
```

This example shows how to turn on fast STP mode for Ethernet port 2:

```
> config spanningtree port mode fast 2
```

Related Commands

show spanningtree port
config spanningtree switch mode
config spanningtree port pathcost
config spanningtree port priority

config spanningtree port pathcost

To set the Spanning Tree Protocol (STP) path cost for an Ethernet port, use the **config spanningtree port pathcost** command.

config spanningtree port pathcost {*cost* | **auto**} {*port* | **all**}

Syntax Description

<i>cost</i>	Cost in decimal as determined by the network planner.
auto	Specifies the default cost.
<i>port</i>	Port number (1 through 12 or 1 through 24), or all to configure all ports.
all	Specifies to configure all ports.

Command Default

Auto.

Usage Guidelines

When the Cisco 4400 Series Wireless LAN Controller is configured for port redundancy, STP must be disabled for all ports on the controller. STP can remain enabled on the switch that is connected to the controller.

Examples

This example shows how to have the STP algorithm automatically assign a path cost for all ports:

```
> config spanningtree port pathcost auto all
```

This example shows how to have the STP algorithm use a port cost of 200 for port 22:

```
> config spanningtree port pathcost 200 22
```

Related Commands

show spanningtree port
config spanningtree port mode
config spanningtree port priority

config spanningtree port priority

To configure the Spanning Tree Protocol (STP) port priority, use the **config spanningtree port priority** command.

config spanningtree port priority *priority_num* *port*

Syntax Description

<i>priority_num</i>	Priority number from 0 to 255.
<i>port</i>	Port number (1 through 12 or 1 through 24).

Command Default

The default STP priority is 128.

Usage Guidelines

When the Cisco 4400 Series Wireless LAN Controller is configured for port redundancy, STP must be disabled for all ports on the controller. STP can remain enabled on the switch connected to the controller.

Examples

This example shows how to set Ethernet port 2 to STP priority 100:

```
> config spanningtree port priority 100 2
```

Related Commands

show spanningtree port
config spanningtree switch mode
config spanningtree port mode
config spanningtree port pathcost

config spanningtree switch bridgepriority

To set the bridge ID, use the **config spanningtree switch bridgepriority** command.

config spanningtree switch bridgepriority *priority_num*

Syntax Description

<i>priority_num</i>	Priority number between 0 and 65535.

Command Default

The default is 32768.

Usage Guidelines

Note

When the Cisco 4400 Series Wireless LAN Controller is configured for port redundancy, STP must be disabled for all ports on the controller. STP can remain enabled on the switch connected to the controller.

The value of the writable portion of the Bridge ID, that is, the first two octets of the (8 octet long) Bridge ID. The other (last) 6 octets of the Bridge ID are given by the value of Bridge MAC address. The value may be specified as a number between 0 and 65535.

Examples

This example shows how to configure spanning tree values on a per switch basis with the bridge priority 40230:

```
> config spanningtree switch bridgepriority 40230
```

Related Commands

show spanningtree switch
config spanningtree switch forwarddelay
config spanningtree switch hellotime
config spanningtree switch maxage
config spanningtree switch mode

config spanningtree switch forwarddelay

To set the bridge timeout, use the **config spanningtree switch forwarddelay** command.

config spanningtree switch forwarddelay *seconds*

Syntax Description

<i>seconds</i>	Timeout in seconds (between 4 and 30).

Command Default

The default is 15.

Usage Guidelines

The value that all bridges use for forward delay when this bridge is acting as the root. 802.1D-1990 specifies that the range for this setting is related to the value of the STP bridge maximum age. The granularity of this timer is specified by 802.1D-1990 to be 1 second. An agent may return a badValue error if a set is attempted to a value that is not a whole number of seconds. The default is 15. Valid values are 4 through 30 seconds.

Examples

This example shows how to configure spanning tree values on a per switch basis with the bridge timeout as 20 seconds:

```
> config spanningtree switch forwarddelay 20
```

Related Commands

- show spanningtree switch bridgepriority**
- config spanningtree switch flowcontrol**
- config spanningtree switch hellotime**
- config spanningtree switch maxage**
- config spanningtree switch mode**

config spanningtree switch hellotime

To set the hello time, use the **config spanningtree switch hellotime** command.

config spanningtree switch hellotime *seconds*

Syntax Description

<i>seconds</i>	STP hello time in seconds.

Command Default

The default is 15.

Usage Guidelines

All bridges use this value for HelloTime when this bridge is acting as the root. The granularity of this timer is specified by 802.1D- 1990 to be 1 second. Valid values are 1 through 10 seconds.

Examples

This example shows how to configure the STP hello time to 4 seconds:

```
> config spanningtree switch hellotime 4
```

Related Commands

show spanningtree switch
show spanningtree switch bridgepriority
config spanningtree switch forwarddelay
config spanningtree switch maxage
config spanningtree switch mode

config spanningtree switch maxage

To set the maximum age, use the **config spanningtree switch maxage** command.

config spanningtree switch maxage *seconds*

Syntax Description

<i>seconds</i>	STP bridge maximum age in seconds.

Command Default

The default is 20.

Usage Guidelines

All bridges use this value for MaxAge when this bridge is acting as the root. 802.1D-1990 specifies that the range for this parameter is related to the value of Stp Bridge Hello Time. The granularity of this timer is specified by 802.1D-1990 to be 1 second. Valid values are 6 through 40 seconds.

Examples

This example shows how to configure the STP bridge maximum age to 30 seconds:

```
> config spanningtree switch maxage 30
```

Related Commands

- show spanningtree switch
- config spanningtree switch bridgepriority
- config spanningtree switch forwarddelay
- config spanningtree switch hellotime
- config spanningtree switch mode

config spanningtree switch mode

To turn the Cisco wireless LAN controller Spanning Tree Protocol (STP) on or off, use the **config spanningtree switch mode** command.

config spanningtree switch mode {enable | disable}

Syntax Description

enable	Enables STP on the switch.
disable	Disables STP on the switch.

Command Default

The default is that STP is disabled.

Usage Guidelines

Using this command allows the controller to set up STP, detect logical network loops, place redundant ports on standby, and build a network with the most efficient pathways.

Examples

This example shows how to support STP on all Cisco wireless LAN controller ports:

```
> config spanningtree switch mode enable
```

Related Commands

show spanningtree switch
config spanningtree switch bridgepriority
config spanningtree switch forwarddelay
config spanningtree switch hellotime
config spanningtree switch maxage

clear Commands

This section lists the **clear** commands to clear the configurations on the controller ports and interfaces.

clear stats port

To clear statistics counters for a specific port, use the **clear stats port** command.

clear stats port *port*

Syntax Description

<i>port</i>	Physical interface port number.

Command Default

None.

Examples

This example shows how to clear the statistics counters for port 9:

```
> clear stats port 9
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download serverip**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**
- clear stats port**



PART

VideoStream Commands

- [CLI Commands, page 605](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 605](#)
- [config Commands, page 611](#)

show Commands

This section lists the **show** commands to display information about your VideoStream configuration settings.

show 802.11

To display basic 802.11a, 802.11b/g, or 802.11h network settings, use the **show 802.11** command.

show 802.11 {a | b | h}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.

Command Default

None.

Examples

This example shows to display basic 802.11a network settings:

```
> show 802.11a
802.11a Network..... Enabled
11nSupport..... Enabled
    802.11a Low Band..... Enabled
    802.11a Mid Band..... Enabled
    802.11a High Band..... Enabled
802.11a Operational Rates
    802.11a 6M Rate..... Mandatory
    802.11a 9M Rate..... Supported
    802.11a 12M Rate..... Mandatory
    802.11a 18M Rate..... Supported
    802.11a 24M Rate..... Mandatory
    802.11a 36M Rate..... Supported
    802.11a 48M Rate..... Supported
    802.11a 54M Rate..... Supported
802.11n MCS Settings:
    MCS 0..... Supported
    MCS 1..... Supported
    MCS 2..... Supported
    MCS 3..... Supported
    MCS 4..... Supported
    MCS 5..... Supported
    MCS 6..... Supported
    MCS 7..... Supported
    MCS 8..... Supported
    MCS 9..... Supported
    MCS 10..... Supported
    MCS 11..... Supported
    MCS 12..... Supported
    MCS 13..... Supported
    MCS 14..... Supported
    MCS 15..... Supported
802.11n Status:
    A-MPDU Tx:
        Priority 0..... Enabled
        Priority 1..... Disabled
        Priority 2..... Disabled
        Priority 3..... Disabled
        Priority 4..... Disabled
        Priority 5..... Disabled
        Priority 6..... Disabled
        Priority 7..... Disabled
```

```

Beacon Interval..... 100
CF Pollable mandatory..... Disabled
CF Poll Request mandatory..... Disabled
--More-- or (q)uit
CFP Period..... 4
CFP Maximum Duration..... 60
Default Channel..... 36
Default Tx Power Level..... 0
DTPC Status..... Enabled
Fragmentation Threshold..... 2346
TI Threshold..... -50
Legacy Tx Beamforming setting..... Disabled
Traffic Stream Metrics Status..... Enabled
Expedited BW Request Status..... Disabled
World Mode..... Enabled
EDCA profile type..... default-wmm
Voice MAC optimization status..... Disabled
Call Admission Control (CAC) configuration
Voice AC:
  Voice AC - Admission control (ACM)..... Disabled
  Voice max RF bandwidth..... 75
  Voice reserved roaming bandwidth..... 6
  Voice load-based CAC mode..... Disabled
  Voice tspec inactivity timeout..... Disabled
  Voice Stream-Size..... 84000
  Voice Max-Streams..... 2
Video AC:
  Video AC - Admission control (ACM)..... Disabled
  Video max RF bandwidth..... Infinite
  Video reserved roaming bandwidth..... 0

```

This example shows how to display basic 802.11h network settings:

```

> show 802.11h
802.11h ..... powerconstraint : 0
802.11h ..... channelswitch : Disable
802.11h ..... channelswitch mode : 0

```

Related Commands

```

show ap stats
show ap summary
show client summary
show network
show network summary
show port
show wlan

```

show 802.11 media-stream

To display the multicast-direct configuration state, use the **show 802.11 media-stream** command.

show 802.11 {a | b | h} media-stream *media_stream_name*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
<i>media_stream_name</i>	Specified media stream name.

Command Default

None.

Examples

This example shows how to display the media-stream configuration:

```
> show 802.11a media-stream rrc
Multicast-direct..... Enabled
Best Effort..... Disabled
Video Re-Direct..... Enabled
Max Allowed Streams Per Radio..... Auto
Max Allowed Streams Per Client..... Auto
Max Video Bandwidth..... 0
Max Voice Bandwidth..... 75
Max Media Bandwidth..... 85
Min PHY Rate..... 6000
Max Retry Percentage..... 80
```

Related Commands

show media-stream group summary

show media-stream client

To display the details for a specific media-stream client or a set of clients, use the **show media-stream client** command.

show media-stream client {*media-stream_name* | **summary**}

Syntax Description

<i>media-stream_name</i>	Name of the media-stream client of which the details is to be displayed.
summary	Displays the details for a set of media-stream clients.

Command Default

None.

Examples

This example shows how to display a summary media-stream clients:

```
> show media-stream client summary
Number of Clients..... 1
Client Mac      Stream Name  Stream Type  Radio  WLAN  QoS   Status
-----
00:1a:73:dd:b1:12  mountainview  MC-direct   2.4    2      Video  Admitted
```

Related Commands

show media-stream group summary

show media-stream group detail

To display the details for a specific media-stream group, use the **show media-stream group detail** command.

show media-stream group detail *media-stream_name*

Syntax Description

<i>media-stream_name</i>	Name of the media-stream group.

Command Default

None.

Examples

This example shows how to display media-stream group configuration details:

```
> show media-stream group detail abc
Media Stream Name..... abc
Start IP Address..... 227.8.8.8
End IP Address..... 227.9.9.9
RRC Parameters
Avg Packet Size(Bytes)..... 1200
Expected Bandwidth(Kbps)..... 300
Policy..... Admit
RRC re-evaluation..... periodic
QoS..... Video
Status..... Multicast-direct
Usage Priority..... 5
Violation..... drop
```

Related Commands

show media-stream group summary

show media-stream group summary

To display the summary of the media stream and client information, use the **show media-stream group summary** command.

show media-stream group summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of the media-stream group:

```
> show media-stream group summary
Stream Name   Start IP      End IP        Operation Status
-----
abc           227.8.8.8     227.9.9.9     Multicast-direct
```

Related Commands

- show 802.11 media-stream client**
- show media-stream client**
- show media-stream group detail**

config Commands

This section lists the **config** commands to configure VideoStream settings on the controller.

config 802.11 cac video acm

To enable or disable video Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac video acm** command.

config 802.11 {a | b} cac video acm {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables video CAC settings.
disable	Disables video CAC settings.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable**, or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the video CAC for the 802.11a network:

```
> config 802.11 cac video acm enable
```

This example shows how to disable the video CAC for the 802.11b network:

```
> config 802.11 cac video acm disable
```

Related Commands

config 802.11 cac video max-bandwidth
config 802.11 cac video roam-bandwidth
config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video cac-method

To configure the Call Admission Control (CAC) method for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video cac-method** command.

config 802.11 {a | b} cac video cac-method {static | load-based}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
static	Enables the static CAC method for video applications on the 802.11a or 802.11b/g network. Static or bandwidth-based CAC enables the client to specify how much bandwidth or shared medium time is required to accept a new video request and in turn enables the access point to determine whether it is capable of accommodating the request.
load-based	Enables the load-based CAC method for video applications on the 802.11a or 802.11b/g network. Load-based or dynamic CAC incorporates a measurement scheme that takes into account the bandwidth consumed by all traffic types from itself, from co-channel access points, and by collocated channel interference. Load-based CAC also covers the additional bandwidth consumption results from PHY and channel impairment. The access point admits a new call only if the channel has enough unused bandwidth to support that call. Load-based CAC is not supported if SIP-CAC is enabled.

Command Default

Static.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Video CAC consists of two parts: Unicast Video-CAC and MC2UC CAC. If you need only Unicast Video-CAC, you must configure only static mode. If you need only MC2UC CAC, you must configure Static or Load-based CAC. Load-based CAC is not supported if SIP-CAC is enabled.

Examples

This example shows how to enable the static CAC method for video applications on the 802.11a network:

```
> config 802.11 cac video cac-method static
```

Related Commands

```
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac media-stream
config 802.11 cac multimedia
debug cac
```

config 802.11 cac video load-based

To enable or disable load-based Call Admission Control (CAC) for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video load-based** command.

config 802.11 {a | b} cac video load-based {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables load-based CAC for video applications on the 802.11a or 802.11b/g network. Load-based or dynamic CAC incorporates a measurement scheme that takes into account the bandwidth consumed by all traffic types from itself, from co-channel access points, and by collocated channel interference. Load-based CAC also covers the additional bandwidth consumption results from PHY and channel impairment. The access point admits a new call only if the channel has enough unused bandwidth to support that call.
disable	Disables load-based CAC method for video applications on the 802.11a or 802.11b/g network.

Command Default

Disabled.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Video CAC consists of two parts: Unicast Video-CAC and MC2UC CAC. If you need only Unicast Video-CAC, you must configure only static mode. If you need only MC2UC CAC, you must configure Static or Load-based CAC. Load-based CAC is not supported if SIP-CAC is enabled.

**Note**

Load-based CAC is not supported if SIP-CAC is enabled.

Examples

This example shows how to enable load-based CAC method for video applications on the 802.11a network:

```
> config 802.11 cac video load-based enable
```

Related Commands

show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac media-stream
config 802.11 cac multimedia
config 802.11 cac video cac-method
debug cac

config 802.11 cac video max-bandwidth

To set the percentage of the maximum bandwidth allocated to clients for video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video max-bandwidth** command.

config 802.11 {a | b} cac video max-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. Once the client reaches the value specified, the access point rejects new calls on this network.



Note

If this parameter is set to zero (0), the controller assumes that you do not want to allocate any bandwidth and allows all bandwidth requests.

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable**, or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth for video applications on the selected radio band:

```
> config 802.11 cac video max-bandwidth 50
```

Related Commands

config 802.11 cac video acm

config 802.11 cac video roam-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice roam-bandwidth

config 802.11 cac media-stream

To configure media stream Call Admission Control (CAC) voice and video quality parameters for 802.11a and 802.11b networks, use the **config 802.11 cac media-stream** command.

config 802.11 {a | b} cac media-stream multicast-direct {max-retry-percent *retry-percentage* | min-client-rate *dot11-rate*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
multicast-direct	Configures CAC parameters for multicast-direct media streams.
max-retry-percent	Configures the percentage of maximum retries that are allowed for multicast-direct media streams.
<i>retry-percentage</i>	Percentage of maximum retries that are allowed for multicast-direct media streams.
min-client-rate	Configures the minimum transmission data rate to the client for multicast-direct media streams.
<i>dot11-rate</i>	Minimum transmission data rate to the client for multicast-direct media streams. Rate in kbps at which the client can operate. If the transmission data rate is below this rate, either the video will not start or the client may be classified as a bad client. The bad client video can be demoted for better effort QoS or subject to denial. The available data rates are 6000, 9000, 12000, 18000, 24000, 36000, 48000, 54000, and 11n rates.

Command Default

The default value for the maximum retry percent is 80. If it exceeds 80, either the video will not start or the client might be classified as a bad client. The bad client video will be demoted for better effort QoS or is subject to denial.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.

- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the maximum retry percent for multicast-direct media streams as 90 on a 802.11a network:

```
> config 802.11 cac media-stream multicast-direct max-retry-percent 90
```

Related Commands

```
show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
config 802.11 cac multimedia
debug cac
```

config 802.11 cac multimedia

To configure the CAC media voice and video quality parameters for 802.11a and 802.11b networks, use the **config 802.11 cac multimedia** command.

config 802.11 {a | b} cac multimedia max-bandwidth *bandwidth*

Syntax Description		
	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	max-bandwidth	Configures the percentage of maximum bandwidth allocated to Wi-Fi Multimedia (WMM) clients for voice and video applications on the 802.11a or 802.11b/g network.
	<i>bandwidth</i>	Percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a or 802.11b/g network. Once the client reaches the specified value, the access point rejects new calls on this radio band. The range is from 5 to 85%.

Command Default The default value is 85%.

Usage Guidelines Call Admission Control (CAC) commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a network:

```
> config 802.11 cac multimedia max-bandwidth 80
```

Related Commands

show cac voice stats
show cac voice summary
show cac video stats
show cac video summary
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm
config 802.11 cac video sip
config 802.11 cac video roam-bandwidth
config 802.11 cac load-based
config 802.11 cac defaults
debug cac

config 802.11 cac video roam-bandwidth

To configure the percentage of the maximum allocated bandwidth reserved for roaming video clients on the 802.11a or 802.11b/g network, use the **config 802.11 cac video roam-bandwidth** command.

config 802.11 {a | b} cac video roam-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The controller reserves the specified bandwidth from the maximum allocated bandwidth for roaming video clients.



Note

If this parameter is set to zero (0), the controller assumes that you do not want to do any bandwidth allocation and, therefore, allows all bandwidth requests.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth reserved for roaming video clients on the selected radio band:

```
> config 802.11 cac video roam-bandwidth 10
```

Related Commands

config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video max-bandwidth

config 802.11 cac video acm

config 802.11 cac video cac-method

config 802.11 cac video sip

config 802.11 cac video load-based

config 802.11 cac video sip

To enable or disable video Call Admission Control (CAC) for nontraffic specifications (TSPEC) SIP clients using video applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac video sip** command.

config 802.11 {a | b} cac video sip {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables video CAC for non-TSPEC SIP clients using video applications on the 802.11a or 802.11b/g network. When you enable video CAC for non-TSPEC SIP clients, you can use applications like Facetime and CIUS video calls.
disable	Disables video CAC for non-TSPEC SIP clients using video applications on the 802.11a or 802.11b/g network.

Command Default

None.

Usage Guidelines

CAC commands for video applications on the 802.11a or 802.11b/g network require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Gold.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
 - Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
 - Save the new configuration by entering the **save config** command.
 - Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** command.
- For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.
- Enable call snooping on the WLAN on which the SIP client is present by entering the **config wlan call-snoop enable wlan_id** command.

Examples

This example shows how to enable video CAC for non-TSPEC SIP clients using video applications on the 802.11a network:

```
> config 802.11 cac video sip enable
```

Related Commands

config 802.11 cac video tspec-inactivity-timeout

config 802.11 cac video max-bandwidth

config 802.11 cac video acm

config 802.11 cac video cac-method

config 802.11 cac video load-based

config 802.11 cac video roam-bandwidth

config 802.11 cac video tspec-inactivity-timeout

To process or ignore the Call Admission Control (CAC) Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac video tspec-inactivity-timeout** command.

config 802.11 {a | b} cac video tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
ab	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to process the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout enable
```

This example shows how to ignore the response to TSPEC inactivity timeout messages received from an access point:

```
> config 802.11a cac video tspec-inactivity-timeout ignore
```

Related Commands

config 802.11 cac video acm

config 802.11 cac video max-bandwidth
config 802.11 cac video roam-bandwidth

config 802.11 cac voice acm

To enable or disable bandwidth-based voice Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice acm** command.

config 802.11 {a | b} cac voice acm {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the bandwidth-based CAC.
disable	Disables the bandwidth-based CAC.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config command**.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the bandwidth-based CAC:

```
> config 802.11c cac voice acm enable
```

This example shows how to disable the bandwidth-based CAC:

```
> config 802.11b cac voice acm disable
```

Related Commands

config 802.11 cac video acm

config 802.11 cac voice max-bandwidth

To set the percentage of the maximum bandwidth allocated to clients for voice applications on the 802.11a or 802.11b/g network, use the **config 802.11 cac voice max-bandwidth** command.

config 802.11 {a | b} cac voice max-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 5 to 85%.

Command Default

0%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. Once the client reaches the value specified, the access point rejects new calls on this network.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to specify the percentage of the maximum allocated bandwidth for voice applications on the selected radio band:

```
> config 802.11a cac voice max-bandwidth 50
```

Related Commands

config 802.11 cac voice roam-bandwidth
config 802.11 cac voice stream-size
config 802.11 exp-bwreq
config 802.11 tsm

config wlan save

show wlan

show wlan summary

config 802.11 cac voice tspec-inactivity-timeout

config 802.11 cac voice load-based

config 802.11 cac video acm

config 802.11 cac voice roam-bandwidth

To configure the percentage of the Call Admission Control (CAC) maximum allocated bandwidth reserved for roaming voice clients on the 802.11a or 802.11b/g network, use the **config 802.11 cac voice roam-bandwidth** command.

config 802.11 {a | b} cac voice roam-bandwidth *bandwidth*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bandwidth</i>	Bandwidth percentage value from 0 to 85%.

Command Default

85%.

Usage Guidelines

The maximum radio frequency (RF) bandwidth cannot exceed 85% for voice and video. The controller reserves the specified bandwidth from the maximum allocated bandwidth for roaming voice clients.



Note

If this parameter is set to zero (0), the controller assumes you do not want to allocate any bandwidth and therefore allows all bandwidth requests.

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming voice clients on the selected radio band:

```
> config 802.11 cac voice roam-bandwidth 10
```

Related Commands

config 802.11 cac voice acm

config 802.11 cac voice max-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice tspec-inactivity-timeout

To process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point, use the **config 802.11 cac voice tspec-inactivity-timeout** command.

config 802.11 {a | b} cac voice tspec-inactivity-timeout {enable | ignore}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages.

Command Default

Disabled (ignore).

Usage Guidelines

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
> config 802.11 cac voice tspec-inactivity-timeout enable
```

Related Commands

config 802.11 cac voice load-based
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice acm

config 802.11cac voice max-bandwidth

config 802.11 cac voice stream-size

config 802.11 cac voice load-based

To enable or disable load-based Call Admission Control (CAC) for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice load-based** command.

config 802.11 {a | b} cac voice load-based {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables load-based CAC.
disable	Disables load-based CAC.

Command Default

Disabled.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable wlan_id command**.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config command**.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to enable the voice load-based CAC parameters:

```
> config 802.11a cac voice load-based enable
```

This example shows how to disable the voice load-based CAC parameters:

```
> config 802.11a cac voice load-based disable
```

Related Commands

config 802.11 cac voice tspec-inactivity-timeout
config 802.11 cac video max-bandwidth
config 802.11 cac video acm

config 802.11 cac voice stream-size

config 802.11 cac voice max-calls



Note

Do not use the **config 802.11 cac voice max-calls** command if the SIP call snooping feature is disabled and if the SIP based Call Admission Control (CAC) requirements are not met.

To configure the maximum number of voice call supported by the radio, use the **config 802.11 cac voice max-calls** command.

config 802.11 {a | b} cac voice max-calls *number*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>number</i>	Number of calls to be allowed per radio.

Command Default

0, which means that there is no maximum limit check for the number of calls.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable network** command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the maximum number of voice calls supported by radio:

```
> config 802.11 cac voice max-calls 10
```

Related Commands

config 802.11 cac voice roam-bandwidth

config 802.11 cac voice stream-size

config 802.11 exp-bwreq

config 802.11 cac voice tspec-inactivity-timeout

config 802.11 cac voice load-based

config 802.11 cac video acm

config 802.11 cac voice sip bandwidth



Note

SIP bandwidth and sample intervals are used to compute per call bandwidth for the SIP-based Call Admission Control (CAC).

To configure the bandwidth that is required per call for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice sip bandwidth** command.

config 802.11 {a | b} cac voice sip bandwidth *bw_kbps* sample-interval *number_msecs*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>bw_kbps</i>	Bandwidth in kbps.
sample-interval	Specifies the packetization interval for SIP codec.
<i>number_msecs</i>	Packetization sample interval in msecs. The sample interval for SIP codec is 20 seconds.

Command Default

None.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the bandwidth and voice packetization interval for a SIP codec:

```
> config 802.11 cac voice sip bandwidth 10 sample-interval 40
```

Related Commands

`config 802.11 cac voice acm`
`config 802.11 cac voice load-based`
`config 802.11 cac voice max-bandwidth`
`config 802.11 cac voice roam-bandwidth`
`config 802.11 cac voice tspec-inactivity-timeout`
`config 802.11 exp-bwreq`

config 802.11 cac voice sip codec

To configure the Call Admission Control (CAC) codec name and sample interval as parameters and to calculate the required bandwidth per call for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice sip codec** command.

config 802.11 {a | b} cac voice sip codec {g711 | g729} sample-interval *number_msecs*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
g711	Specifies CAC parameters for the SIP G711 codec.
g729	Specifies CAC parameters for the SIP G729 codec.
sample-interval	Specifies the packetization interval for SIP codec.
<i>number_msecs</i>	Packetization interval in msecs. The sample interval for SIP codec value is 20 seconds.

Command Default

g711.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable *wlan_id*** command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the codec name and sample interval as parameters for SIP G711 codec:

```
> config 802.11a cac voice sip codec g711 sample-interval 40
```

This example shows how to configure the codec name and sample interval as parameters for SIP G729 codec:

```
> config 802.11a cac voice sip codec g729 sample-interval 40
```


Related Commands

`config 802.11 cac voice acm`
`config 802.11 cac voice load-based`
`config 802.11 cac voice max-bandwidth`
`config 802.11 cac voice roam-bandwidth`
`config 802.11 cac voice tspec-inactivity-timeout`
`config 802.11 exp-bwreq`

config 802.11 cac voice stream-size

To configure the number of aggregated voice Wi-Fi Multimedia (WMM) traffic specification (TSPEC) streams at a specified data rate for the 802.11a or 802.11b/g network, use the **config 802.11 cac voice stream-size** command.

config 802.11 {a | b} cac voice stream-size *stream_size number mean_datarate max-streams mean_datarate*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
stream-size	Configures the maximum data rate for the stream.
<i>stream_size</i>	Range of stream size is between 84000 and 92100.
<i>number</i>	Number (1 to 5) of voice streams.
mean_datarate	Configures the mean data rate.
max-streams	Configures the mean data rate of a voice stream.
<i>mean_datarate</i>	Mean data rate (84 to 91.2 kbps) of a voice stream.

Command Default

The default number of streams is 2 and the mean data rate of a stream is 84 kbps.

Usage Guidelines

Call Admission Control (CAC) commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **config wlan disable** *wlan_id* command.
- Disable the radio network you want to configure by entering the **config 802.11 {a | b} disable** network command.
- Save the new configuration by entering the **save config** command.
- Enable voice or video CAC for the network you want to configure by entering the **config 802.11 {a | b} cac voice acm enable** or **config 802.11 {a | b} cac video acm enable** commands.

For complete instructions, see the “Configuring Voice and Video Parameters” section in the “Configuring Controller Settings” chapter of the *Cisco Wireless LAN Controller Configuration Guide* for your release.

Examples

This example shows how to configure the number of aggregated voice traffic specifications stream with the stream size 5 and the mean data rate of 85000 kbps:

```
> config 802.11 cac voice stream-size 5 max-streams size 85
```

Related Commands

`config 802.11 cac voice acm`
`config 802.11 cac voice load-based`
`config 802.11 cac voice max-bandwidth`
`config 802.11 cac voice roam-bandwidth`
`config 802.11 cac voice tspec-inactivity-timeout`
`config 802.11 exp-bwreq`

config advanced 802.11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 802.11a network, use the **config advanced 802.11 edca-parameters** command.

config advanced 802.11 {a | b} edca-parameters {wmm-default | svp-voice | optimized-voice | optimized-video-voice | custom-voice}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.
svp-voice	Enables Spectralink voice priority parameters. Choose this option if Spectralink phones are deployed on your network to improve the quality of calls.
optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than Spectralink are deployed on your network.
optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network. Note If you deploy video services, admission control (ACM) must be disabled.
custom-voice	Enables custom voice EDCA parameters for 802.11a. The EDCA parameters under this option also match the 6.0 WMM EDCA parameters when this profile is applied.

Command Default

wmm-default

Examples

This example shows how to enable Spectralink voice priority parameters:

```
> config advanced 802.11 edca-parameters svp-voice
```

Related Commands

show 802.11a
config advanced 802.11b edca-parameters

config 802.11 media-stream multicast-direct

To configure the media stream multicast-direct parameters for the 802.11 networks, use the **config 802.11 media-stream multicast-direct** command.

config 802.11 {a | b} media-stream multicast-direct {admission-besteffect {enable | disable} | {client-maximum | radio-maximum} {value | no-limit} | enable | disable}

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b/g network.
admission-besteffect	Admits media stream to best-effort queue.
enable	Enables multicast-direct on a 2.4-GHz or a 5-GHz band.
disable	Disables multicast-direct on a 2.4-GHz or a 5-GHz band.
client-maximum	Specifies the maximum number of streams allowed on a client.
radio-maximum	Specifies the maximum number of streams allowed on a 2.4-GHz or a 5-GHz band.
<i>value</i>	Number of streams allowed on a client or on a 2.4-GHz or a 5-GHz band, between 1 to 20.
no-limit	Specifies the unlimited number of streams allowed on a client or on a 2.4-GHz or a 5-GHz band.

Command Default

None.

Usage Guidelines

Before you configure the media stream multicast-direct parameters on a 802.11 network, ensure that the network is nonoperational.

Examples

This example shows how to enable a media stream multicast-direct settings on an 802.11a network:

```
> config 802.11a media-stream multicast-direct enable
```

This example shows how to admit the media stream to the best-effort queue:

```
> config 802.11a media-stream multicast-direct admission-besteffect enable
```

This example shows how to set the maximum number of streams allowed on a client:

```
> config 802.11a media-stream multicast-direct client-maximum 10
```

Related Commands

config 802.11 media-stream video-redirect
show 802.11a media-stream name
show media-stream group summary
show media-stream group detail

config 802.11 media-stream video-redirect

To configure the media stream video-redirect for the 802.11 networks, use the **config 802.11 media-stream video-redirect** command.

config 802.11 {a | b} media-stream video-redirect {enable | disable}

Syntax Description	802.11a	Specifies the 802.11a network.
	802.11b	Specifies the 802.11b/g network.
	enable	Enables traffic redirection.
	disable	Disables traffic redirection.

Command Default None.

Usage Guidelines Before you configure the media stream video-redirect on a 802.11 network, ensure that the network is nonoperational.

Examples This example shows how to enable media stream traffic redirection on an 802.11a network:

```
> config 802.11a media-stream video-redirect enable
```

Related Commands

- config 802.11 media-stream multicast-redirect
- show 802.11a media-stream name
- show media-stream group summary
- show media-stream group detail

config media-stream multicast-direct

To configure the media-stream multicast direct, use the **config media-stream multicast direct** command.

config media-stream multicast-direct {enable | disable}

Syntax Description

enable	Enables a media stream.
disable	Disables a media stream.

Command Default

None.

Usage Guidelines

Media-stream multicast-direct requires load based Call Admission Control (CAC) to run.

Examples

This example shows how to enable media-stream multicast-direct settings:

```
> config media-stream multicast-direct enable
```

This example shows how to disable media-stream multicast-direct settings:

```
> config media-stream multicast-direct disable
```

Related Commands

config 802.11 media-stream video-redirect
show 802.11a media-stream name
show media-stream group summary
show media-stream group detail

config media-stream message

To configure various parameters of message configuration, use the **config media-stream message** command.

config media-stream message {**state** [**enable** | **disable**] | **url** *url* | **email** *email* | **phone** *phone_number* | **note** *note*}

Syntax Description

state	Specifies the media stream message state.
enable	(Optional) Enables the session announcement message state.
disable	(Optional) Disables the session announcement message state.
url	Configures the URL.
<i>url</i>	Session announcement URL.
email	Configures the email ID.
<i>email</i>	Specifies the session announcement e-mail.
phone	Configures the phone number.
<i>phone_number</i>	Session announcement phone number.
note	Configures the notes.
<i>note</i>	Session announcement notes.

Command Default

Disabled.

Usage Guidelines

Media-stream multicast-direct requires load-based Call Admission Control (CAC) to run.

Examples

This example shows how to enable the session announcement message state:

```
> config media-stream message state enable
```

This example shows how to configure the session announcement e-mail address:

```
> config media-stream message mail abc@co.com
```

Related Commands

```
config media-stream
show 802.11a media-stream name
show media-stream group summary
```

show media-stream group detail

config media-stream add

To configure the various global media-stream configurations, use the **config media-stream add** command.

config media-stream add multicast-direct *media_stream_name* *start-IP end-IP* [**template** {**very coarse** | **coarse** | **ordinary** | **low-resolution** | **med-resolution** | **high-resolution**} | **detail** {*bandwidth* *packet-size* {**periodic** | **initial**} } *qos* *priority* {**drop** | **fallback**}

Syntax Description

multicast-direct	Specifies the media stream for the multicast-direct setting.
<i>media_stream_name</i>	Media-stream name.
<i>start-IP</i>	IP multicast destination start address.
<i>end-IP</i>	IP multicast destination end address.
template	(Optional) Configures the media stream from templates.
very coarse	Applies a very-coarse template.
coarse	Applies a coarse template.
ordinary	Applies an ordinary template.
low-resolution	Applies a low-resolution template.
med-resolution	Applies a medium-resolution template.
high-resolution	Applies a high-resolution template.
detail	Configures the media stream with specific parameters.
<i>bandwidth</i>	Maximum expected stream bandwidth.
<i>packet-size</i>	Average packet size.
periodic	Specifies the periodic admission evaluation.
initial	Specifies the Initial admission evaluation.
<i>qos</i>	AIR QoS class (video only).
<i>priority</i>	Media-stream priority.
drop	Specifies that the stream is dropped on a periodic reevaluation.
fallback	Specifies if the stream is demoted to the best-effort class on a periodic reevaluation.

Command Default

None.

Usage Guidelines

Media-stream multicast-direct requires load-based Call Admission Control (CAC) to run.

Examples

This example shows how to configure a new media stream:

```
> config media-stream add multicast-direct abc 227.8.8.8 227.9.9.9 detail 2 150 periodic  
video 1 drop
```

Related Commands

show 802.11a media-stream name

show media-stream group summary

show media-stream group detail

config media-stream admit

To allow traffic for a media stream group, use the **config media-stream admit** command.

config media-stream admit *media_stream_name*

Syntax Description

<i>media_stream_name</i>	Media-stream group name.

Command Default

None.

Usage Guidelines

When you try to allow traffic for the media stream group, you will be prompted that IGMP snooping will be disabled and enabled again, and all clients might observe a glitch on the multicast traffic.

Examples

This example shows how to allow traffic for a media stream group:

```
> config media-stream admit MymediaStream
```

Related Commands

show 802.11a media-stream name
show media-stream group summary
show media-stream group detail

config media-stream deny

To block traffic for a media stream group, use the **config media-stream deny** command.

Syntax Description

<i>media_stream_name</i>	Media-stream group name.

config media-stream deny *media_stream_name*

Command Default

None.

Usage Guidelines

When you try to block traffic for the media stream group, you will be prompted that IGMP snooping will be disabled and enabled again, and all clients might observe a glitch on the multicast traffic.

Examples

This example shows how to block traffic for a media stream group:

```
> config media-stream deny MymediaStream
```

Related Commands

show 802.11a media-stream name
show media-stream group summary
show media-stream group detail

config media-stream delete

To configure the various global media-stream configurations, use the **config media-stream delete** command.

config media-stream delete *media_stream_name*

Syntax Description

<i>media_stream_name</i>	Media-stream name.

Command Default

None.

Usage Guidelines

Media-stream multicast-direct requires load-based Call Admission Control (CAC) to run.

Examples

This example shows how to configure the media stream named abc:

```
> config media-stream delete abc
```

Related Commands

show 802.11a media-stream name
show media-stream group summary
show media-stream group detail

config wlan media-stream

To configure multicast-direct for a wireless LAN media stream, use the **config wlan media-stream** command.

config wlan media-stream multicast-direct {*wlan_id* | **all**} {**enable** | **disable**}

Syntax Description

multicast-direct	Configures multicast-direct for a wireless LAN media stream.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
all	Configures the wireless LAN on all media streams.
enable	Enables global multicast to unicast conversion.
disable	Disables global multicast to unicast conversion.

Command Default

None.

Usage Guidelines

Media stream multicast-direct requires load based Call Admission Control (CAC) to run. WLAN quality of service (QoS) needs to be set to either gold or platinum.

Examples

This example shows how to enable the global multicast-direct media stream with WLAN ID 2:

```
> config wlan media-stream multicast-direct 2 enable
```

Related Commands

config wlan
config wlan qos
show wlan



PART IV

Security Commands

- [CLI Commands, page 661](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands](#) , page 662
- [config Commands](#), page 733
- [clear Commands](#), page 849
- [debug Commands](#), page 856

show Commands

This section lists the **show** commands to display information about your security configuration settings for the controller.

show 802.11

To display basic 802.11a, 802.11b/g, or 802.11h network settings, use the **show 802.11** command.

show 802.11 {a | b | h}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.

Command Default

None.

Examples

This example shows to display basic 802.11a network settings:

```
> show 802.11a
802.11a Network..... Enabled
11nSupport..... Enabled
    802.11a Low Band..... Enabled
    802.11a Mid Band..... Enabled
    802.11a High Band..... Enabled
802.11a Operational Rates
    802.11a 6M Rate..... Mandatory
    802.11a 9M Rate..... Supported
    802.11a 12M Rate..... Mandatory
    802.11a 18M Rate..... Supported
    802.11a 24M Rate..... Mandatory
    802.11a 36M Rate..... Supported
    802.11a 48M Rate..... Supported
    802.11a 54M Rate..... Supported
802.11n MCS Settings:
    MCS 0..... Supported
    MCS 1..... Supported
    MCS 2..... Supported
    MCS 3..... Supported
    MCS 4..... Supported
    MCS 5..... Supported
    MCS 6..... Supported
    MCS 7..... Supported
    MCS 8..... Supported
    MCS 9..... Supported
    MCS 10..... Supported
    MCS 11..... Supported
    MCS 12..... Supported
    MCS 13..... Supported
    MCS 14..... Supported
    MCS 15..... Supported
802.11n Status:
    A-MPDU Tx:
        Priority 0..... Enabled
        Priority 1..... Disabled
        Priority 2..... Disabled
        Priority 3..... Disabled
        Priority 4..... Disabled
        Priority 5..... Disabled
        Priority 6..... Disabled
        Priority 7..... Disabled
```

```

Beacon Interval..... 100
CF Pollable mandatory..... Disabled
CF Poll Request mandatory..... Disabled
--More-- or (q)uit
CFP Period..... 4
CFP Maximum Duration..... 60
Default Channel..... 36
Default Tx Power Level..... 0
DTPC Status..... Enabled
Fragmentation Threshold..... 2346
TI Threshold..... -50
Legacy Tx Beamforming setting..... Disabled
Traffic Stream Metrics Status..... Enabled
Expedited BW Request Status..... Disabled
World Mode..... Enabled
EDCA profile type..... default-wmm
Voice MAC optimization status..... Disabled
Call Admission Control (CAC) configuration
Voice AC:
  Voice AC - Admission control (ACM)..... Disabled
  Voice max RF bandwidth..... 75
  Voice reserved roaming bandwidth..... 6
  Voice load-based CAC mode..... Disabled
  Voice tspec inactivity timeout..... Disabled
  Voice Stream-Size..... 84000
  Voice Max-Streams..... 2
Video AC:
  Video AC - Admission control (ACM)..... Disabled
  Video max RF bandwidth..... Infinite
  Video reserved roaming bandwidth..... 0

```

This example shows how to display basic 802.11h network settings:

```

> show 802.11h
802.11h ..... powerconstraint : 0
802.11h ..... channelswitch : Disable
802.11h ..... channelswitch mode : 0

```

Related Commands

```

show ap stats
show ap summary
show client summary
show network
show network summary
show port
show wlan

```

show aaa auth

To display the configuration settings for the AAA authentication server database, use the **show aaa auth** command.

show aaa auth

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the configuration settings for the AAA authentication server database:

```
> show aaa auth
Management authentication server order:
 1..... local
 2..... tacacs
```

Related Commands

- config aaa auth**
- config aaa auth mgmt**

show acl

To display the access control lists (ACLs) that are configured on the controller, use the **show acl** command.

show acl {**cpu** | **detailed** *acl_name* | **summary**}

Syntax Description

cpu	Displays the ACLs configured on the Cisco WLC's central processing unit (CPU).
detailed	Displays detailed information about a specific ACL.
<i>acl_name</i>	ACL name. The name can be up to 32 alphanumeric characters.
summary	Displays a summary of all ACLs configured on the controller.

Command Default

None

Examples

The following example shows how to display the access control lists on the CPU.

```
Device > show acl cpu
```

```
CPU Acl Name.....
Wireless Traffic..... Disabled
Wired Traffic..... Disabled
Applied to NPU..... No
```

The following example shows how to display a summary of the access control lists.

```
Device > show acl summary
```

```
ACL Counter Status          Disabled
-----
IPv4 ACL Name               Applied
-----
acl1                        Yes
acl2                        Yes
acl3                        Yes
-----
IPv6 ACL Name               Applied
-----
acl6                        No
```

The following example shows how to display the detailed information of the access control lists.

```
Device > show acl detailed acl_name
```

		Source	Destination	Source Port	Dest Port					
I	Dir	IP Address/Netmask	IP Address/Netmask	Prot	Range	Range	DSCP	Action	Counter	
1	Any	0.0.0.0/0.0.0.0	0.0.0.0/0.0.0.0	Any	0-65535	0-65535	0	Deny	0	
2	In	0.0.0.0/0.0.0.0	200.200.200.0/	6	80-80	0-65535	Any	Permit	0	
			255.255.255.0							
DenyCounter :		0								

**Note**

The Counter field increments each time a packet matches an ACL rule, and the DenyCounter field increments each time a packet does not match any of the rules.

Related Commands

clear acl counters

config acl apply

config acl counter

config acl cpu

config acl create

config acl delete

config interface acl

config acl rule

show advanced eap

To display Extensible Authentication Protocol (EAP) settings, use the **show advanced eap** command.

show advanced eap

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the EAP settings:

```
> show advanced eap
EAP-Identity-Request Timeout (seconds)..... 1
EAP-Identity-Request Max Retries..... 20
EAP Key-Index for Dynamic WEP..... 0
EAP Max-Login Ignore Identity Response..... enable
EAP-Request Timeout (seconds)..... 1
EAP-Request Max Retries..... 20
EAPOL-Key Timeout (milliseconds)..... 1000
EAPOL-Key Max Retries..... 2
```

Related Commands

- config advanced eap**
- config advanced timers eap-identity-request-delay**
- config advanced timers eap-timeout**

show database summary

To display the maximum number of entries in the database, use the **show database summary** command.

show database summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of the local database configuration:

```
> show database summary
Maximum Database Entries..... 2048
Maximum Database Entries On Next Reboot..... 2048
Database Contents
  MAC Filter Entries..... 2
  Exclusion List Entries..... 0
  AP Authorization List Entries..... 1
  Management Users..... 1
  Local Network Users..... 1
    Local Users..... 1
    Guest Users..... 0
  Total..... 5
```

Related Commands **config database size**

show exclusionlist

To display a summary of all clients on the manual exclusion list (blacklisted) from associating with this Cisco wireless LAN controller, use the **show exclusionlist** command.

show exclusionlist

Syntax Description	This command has no arguments or keywords.
Command Default	None.
Usage Guidelines	This command displays all manually excluded MAC addresses.
Examples	This example shows how to display the exclusion list:

```
> show exclusionlist
No manually disabled clients.
Dynamically Disabled Clients
-----
MAC Address           Exclusion Reason           Time Remaining (in secs)
-----
00:40:96:b4:82:55     802.1X Failure            51
```

Related Commands	config exclusionlist

show ike

To display active Internet Key Exchange (IKE) security associations (SAs), use the **show ike** command.

show ike {**brief** | **detailed**} *IP_or_MAC_address*

Syntax Description

brief	Displays a brief summary of all active IKE SAs.
detailed	Displays a detailed summary of all active IKE SAs.
<i>IP_or_MAC_address</i>	IP or MAC address of active IKE SA.

Command Default

None.

Examples

This example shows how to display the active Internet Key Exchange security associations:

```
> show ike brief 209.165.200.254
```

show IPsec

To display active Internet Protocol Security (IPsec) security associations (SAs), use the **show IPsec** command.

show IPsec {**brief** | **detailed**} *IP_or_MAC_address*

Syntax Description

brief	Displays a brief summary of active IPsec SAs.
detailed	Displays a detailed summary of active IPsec SAs.
<i>IP_or_MAC_address</i>	IP address or MAC address of a device.

Command Default

None.

Examples

This example shows how to display brief information about the active Internet Protocol Security (IPsec) security associations (SAs):

```
> show IPsec brief 209.165.200.254
```

Related Commands

config radius acct ipsec authentication
config radius acct ipsec disable
config radius acct ipsec enable
config radius acct ipsec encryption
config radius auth IPsec encryption
config radius auth IPsec authentication
config radius auth IPsec disable
config radius auth IPsec encryption
config radius auth IPsec ike
config trapflags IPsec
config wlan security IPsec disable
config wlan security IPsec enable
config wlan security IPsec authentication
config wlan security IPsec encryption
config wlan security IPsec config
config wlan security IPsec ike authentication
config wlan security IPsec ike dh-group
config wlan security IPsec ike lifetime

config wlan security IPsec ike phase1
config wlan security IPsec ike contivity

show ipv6 acl

To display the IPv6 access control lists (ACLs) that are configured on the controller, use the **show ipv6 acl** command.

show ipv6 acl detailed {*acl_name* | **summary**}

Syntax Description

<i>acl_name</i>	IPv6 ACL name. The name can be up to 32 alphanumeric characters.
detailed	Displays detailed information about a specific ACL.

Command Default

None.

Examples

This example shows how to display the detailed information of the access control lists:

```
> show ipv6 acl detailed acl6
Rule Index..... 1
Direction..... Any
IPv6 source prefix..... ::/0
IPv6 destination prefix..... ::/0
Protocol..... Any
Source Port Range..... 0-65535
Destination Port Range..... 0-65535
DSCP..... Any
Flow label..... 0
Action..... Permit
Counter..... 0
Deny Counter..... 0
```

Related Commands

config ipv6 acl

show ipv6 summary

To display the IPv6 configuration settings, use the **show ipv6 summary** command.

show ipv6 summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the IPv6 configuration settings:

```
> show ipv6 summary
Global Config..... Enabled
Reachable-lifetime value..... 300
Stale-lifetime value..... 86400
Down-lifetime value..... 86400
RA Throttling..... Enabled
RA Throttling allow at-least..... 1
RA Throttling allow at-most..... no-limit
RA Throttling max-through..... no-limit
RA Throttling throttle-period..... 60
RA Throttling interval-option..... throttle
NS Multicast CacheMiss Forwarding..... Disabled
```

Related Commands **show ipv6 acl**

show l2tp

To display Layer 2 Tunneling Protocol (L2TP) sessions, use the **show l2tp** command.

show l2tp {**summary** | *ip_address*}

Syntax Description

summary	Displays all L2TP sessions.
<i>ip_address</i>	IP address.

Command Default

None.

Examples

This example shows how to display a summary of all L2TP sessions:

```
> show l2tp summary
LAC_IPaddr  LTid  LSid  RTid  RSid  ATid  ASid  State
-----
```

show ldap

To display the Lightweight Directory Access Protocol (LDAP) server information for a particular LDAP server, use the **show ldap** command.

show ldap *index*

Syntax Description

<i>index</i>	LDAP server index. Valid values are from 1 to 17.

Command Default

None.

Examples

This example shows how to display the detailed LDAP server information:

```
> show ldap 1
Server Index..... 1
Address..... 2.3.1.4
Port..... 389
Enabled..... Yes
User DN..... name1
User Attribute..... attr1
User Type..... username1
Retransmit Timeout..... 3 seconds
Bind Method ..... Anonymous
```

Related Commands

config ldap
config ldap add
config ldap simple-bind
show ldap statistics
show ldap summary

show ldap statistics

To display all Lightweight Directory Access Protocol (LDAP) server information, use the **show ldap statistics** command.

show ldap statistics

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the LDAP server statistics:

```
> show ldap statistics
Server Index..... 1
Server statistics:
  Initialized OK..... 0
  Initialization failed..... 0
  Initialization retries..... 0
  Closed OK..... 0
Request statistics:
  Received..... 0
  Sent..... 0
  OK..... 0
  Success..... 0
  Authentication failed..... 0
  Server not found..... 0
  No received attributes..... 0
  No passed username..... 0
  Not connected to server..... 0
  Internal error..... 0
  Retries..... 0
Server Index..... 2
...
```

Related Commands

config ldap
config ldap add
config ldap simple-bind
show ldap
show ldap summary

show ldap summary

To display the current Lightweight Directory Access Protocol (LDAP) server status, use the **show ldap summary** command.

show ldap summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of configured LDAP servers:

```
> show ldap summary
Idx  Server Address  Port  Enabled
---  -
1    2.3.1.4         389   Yes
2    10.10.20.22     389   Yes
```

Related Commands

- config ldap**
- config ldap add**
- config ldap simple-bind**
- show ldap statistics**
- show ldap**

show local-auth certificates

To display local authentication certificate information, use the **show local-auth certificates** command:

show local-auth certificates

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the authentication certificate information stored locally:

```
> show local-auth certificates
```

```
Certificates available for Local EAP authentication:
Certificate issuer ..... vendor
CA certificate:
Subject: C=AU, ST=NSW, L=Sydney, O=Cisco Systems
OU=WNBUSydney, CN=wnbu-syd-ac-s-a.cisco.com
Issuer: C=AU, ST=NSW, L=Sydney, O=Cisco Systems
OU=WNBUSydney, CN=wnbu-syd-ac-s-a.cisco.com
Valid: 2005 Jun 15th, 04:53:49 GMT to 2008 Jun 15th, 05:03:34 GMT
Device certificate:
Subject: MAILTO=test@test.net, C=AU, ST=NSW, L=Sydney
O=Cisco Systems, OU=WNBUSydney, CN=concanon
Issuer: C=AU, ST=NSW, L=Sydney, O=Cisco Systems
OU=WNBUSydney, CN=wnbu-syd-ac-s-a.cisco.com
Valid: 2006 Aug 9th, 05:14:16 GMT to 2007 Aug 9th, 05:24:16 GMT

Certificate issuer ..... cisco
CA certificate:
Subject: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Issuer: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Valid: 2003 Feb 12th, 23:38:55 GMT to 2012 Nov 11th, 23:38:55 GMT
Device certificate:
Subject: C=US, ST=California, L=San Jose, O=airespace Inc
CN=000b85335340, MAILTO=support@airespace.com
Issuer: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Valid: 2005 Feb 22nd, 10:52:58 GMT to 2014 Nov 22nd, 10:52:58 GMT

Certificate issuer ..... legacy
CA certificate:
Subject: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Issuer: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Valid: 2003 Feb 12th, 23:38:55 GMT to 2012 Nov 11th, 23:38:55 GMT
Device certificate:
Subject: C=US, ST=California, L=San Jose, O=airespace Inc
CN=000b85335340, MAILTO=support@airespace.com
Issuer: C=US, ST=California, L=San Jose, O=airespace Inc
OU=none, CN=ca, MAILTO=support@airespace.com
Valid: 2005 Feb 22nd, 10:52:58 GMT to 2014 Nov 22nd, 10:52:58 GMT
```

Related Commands

`clear stats local-auth`
`config local-auth active-timeout`
`config local-auth eap-profile`
`config local-auth method fast`
`config local-auth user-credentials`
`debug aaa local-auth`
`show local-auth config`
`show local-auth statistics`

show local-auth config

To display local authentication configuration information, use the **show local-auth config** command.

show local-auth config

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the local authentication configuration information:

```
> show local-auth config
User credentials database search order:
Primary ..... Local DB
Configured EAP profiles:
Name ..... fast-test
Certificate issuer ..... default
Enabled methods ..... fast
Configured on WLANs ..... 2
EAP Method configuration:
EAP-TLS:
Certificate issuer ..... default
Peer verification options:
  Check against CA certificates ..... Enabled
  Verify certificate CN identity .... Disabled
  Check certificate date validity ... Enabled
EAP-FAST:
TTL for the PAC ..... 3 600
Initial client message ..... <none>
Local certificate required ..... No
Client certificate required ..... No
Vendor certificate required ..... No
Anonymous provision allowed ..... Yes
Authenticator ID ..... 7b7fffff000000000000000000000000
Authority Information ..... Test
EAP Profile..... tls-prof
Enabled methods for this profile ..... tls
Active on WLANs ..... 1 3EAP Method configuration:
EAP-TLS:
Certificate issuer used ..... cisco
Peer verification options:
  Check against CA certificates ..... disabled
  Verify certificate CN identity .... disabled
  Check certificate date validity ... disabled
```

Related Commands

- clear stats local-auth**
- config local-auth active-timeout**
- config local-auth eap-profile**
- config local-auth method fast**
- config local-auth user-credentials**
- debug aaa local-auth**
- show local-auth certificates**

show local-auth statistics

show local-auth statistics

To display local Extensible Authentication Protocol (EAP) authentication statistics, use the **show local-auth statistics** command:

show local-auth statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the local authentication certificate statistics:

```
> show local-auth statistics
Local EAP authentication DB statistics:
Requests received ..... 14
Responses returned ..... 14
Requests dropped (no EAP AVP) ..... 0
Requests dropped (other reasons) ..... 0
Authentication timeouts ..... 0
Authentication statistics:
  Method          Success          Fail
  -----
  Unknown          0              0
  LEAP              0              0
  EAP-FAST          2              0
  EAP-TLS           0              0
  PEAP              0              0
Local EAP credential request statistics:
Requests sent to LDAP DB ..... 0
Requests sent to File DB ..... 2
Requests failed (unable to send) ..... 0
Authentication results received:
  Success ..... 2
  Fail ..... 0
Certificate operations:
Local device certificate load failures ..... 0
Total peer certificates checked ..... 0
Failures:
  CA issuer check ..... 0
  CN name not equal to identity ..... 0
  Dates not valid or expired ..... 0
```

Related Commands

- clear stats local-auth**
- config local-auth active-timeout**
- config local-auth eap-profile**
- config local-auth method fast**
- config local-auth user-credentials**
- debug aaa local-auth**
- show local-auth config**
- show local-auth certificates**

show nac statistics

To display detailed Network Access Control (NAC) information about a Cisco wireless LAN controller, use the **show nac statistics** command.

show nac statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display detailed statistics of network access control settings:

```
> show nac statistics
Server Index..... 1
Server Address..... xxx.xxx.xxx.xxx
Number of requests sent..... 0
Number of retransmissions..... 0
Number of requests received..... 0
Number of malformed requests received..... 0
Number of bad auth requests received..... 0
Number of pending requests..... 0
Number of timed out requests..... 0
Number of misc dropped request received..... 0
Number of requests sent..... 0
```

Related Commands

- show nac summary**
- config guest-lan nac**
- config wlan nac**
- debug nac**

show nac summary

To display NAC summary information for a Cisco wireless LAN controller, use the **show nac summary** command.

show nac summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary information of network access control settings:

```
> show nac summary
NAC ACL Name .....
Index  Server Address          Port      State
-----
1      xxx.xxx.xxx.xxx          13336     Enabled
```

Related Commands

- show nac statistics**
- config guest-lan nac**
- config wlan nac**
- debug nac**

show netuser

To display the configuration of a particular user in the local user database, use the **show netuser** command.

show netuser {**detail** *user_name* | **guest-roles** | **summary**}

Syntax Description

detail	Displays detailed information about the specified network user.
<i>user_name</i>	Network user.
guest_roles	Displays configured roles for guest users.
summary	Displays a summary of all users in the local user database.

Command Default

None.

Examples

This example shows how to display a summary of all users in the local user database:

```
> show netuser summary
Maximum logins allowed for a given username .....Unlimited
```

This example shows how to display detailed information on the specified network user:

```
> show netuser detail john10
username..... abc
WLAN Id..... Any
Lifetime..... Permanent
Description..... test user
```

Related Commands

config netuser add
config netuser delete
config netuser description
config netuser guest-role apply
config netuser wlan-id
config netuser guest-roles

show netuser guest-roles

To display a list of the current quality of service (QoS) roles and their bandwidth parameters, use the **show netuser guest-roles** command.

show netuser guest-roles

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a QoS role for the guest network user:

```
> show netuser guest-roles
Role Name..... Contractor
  Average Data Rate..... 10
  Burst Data Rate..... 10
  Average Realtime Rate..... 100
  Burst Realtime Rate..... 100
Role Name..... Vendor
  Average Data Rate..... unconfigured
  Burst Data Rate..... unconfigured
  Average Realtime Rate..... unconfigured
  Burst Realtime Rate..... unconfigured
```

Related Commands

- config netuser add**
- config netuser delete**
- config netuser description**
- config netuser guest-role apply**
- config netuser wlan-id**
- show netuser guest-roles**
- show netuser**

show network

To display the current status of 802.3 bridging for all WLANs, use the **show network** command.

show network

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the network details:

```
> show network
```

Related Commands	config network show network summary show network multicast mgid detail show network multicast mgid summary

show network summary

To display the network configuration of the Cisco wireless LAN controller, use the **show network summary** command.

show network summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary configuration:

```
> show network summary
RF-Network Name..... RF
Web Mode..... Disable
Secure Web Mode..... Enable
Secure Web Mode Cipher-Option High..... Disable
Secure Web Mode Cipher-Option SSLv2..... Disable
Secure Web Mode RC4 Cipher Preference..... Disable
OCSP..... Disabled
OCSP responder URL.....
Secure Shell (ssh)..... Enable
Telnet..... Enable
Ethernet Multicast Mode..... Disable   Mode: Ucast
Ethernet Broadcast Mode..... Disable
Ethernet Multicast Forwarding..... Disable
Ethernet Broadcast Forwarding..... Disable
AP Multicast/Broadcast Mode..... Unicast
IGMP snooping..... Disabled
IGMP timeout..... 60 seconds
IGMP Query Interval..... 20 seconds
MLD snooping..... Disabled
MLD timeout..... 60 seconds
MLD query interval..... 20 seconds
User Idle Timeout..... 300 seconds
AP Join Priority..... Disable
ARP Idle Timeout..... 300 seconds
ARP Unicast Mode..... Disabled
Cisco AP Default Master..... Disable
Mgmt Via Wireless Interface..... Disable
Mgmt Via Dynamic Interface..... Disable
Bridge MAC filter Config..... Enable
Bridge Security Mode..... EAP
Over The Air Provisioning of AP's..... Enable
Apple Talk ..... Disable
Mesh Full Sector DFS..... Enable
AP Fallback ..... Disable
Web Auth CMCC Support ..... Disabled
Web Auth Redirect Ports ..... 80
Web Auth Proxy Redirect ..... Disable
Web Auth Captive-Bypass ..... Disable
Web Auth Secure Web ..... Enable
Fast SSID Change ..... Disabled
AP Discovery - NAT IP Only ..... Enabled
IP/MAC Addr Binding Check ..... Enabled
CCX-lite status ..... Disable
oeap-600 dual-rlan-ports ..... Disable
oeap-600 local-network ..... Enable
mDNS snooping..... Disabled
mDNS Query Interval..... 15 minutes
```


Related Commands

config network
show network multicast mgid summary
show network multicast mgid detail
show network

show ntp-keys

To display network time protocol authentication key details, use the **show ntp-keys** command.

show ntp-keys

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display NTP authentication key details:

```
> show ntp-keys
Ntp Authentication Key Details.....
  Key Index
  -----
      1
      3
```

Related Commands **config time ntp**

show rules

To display the active internal firewall rules, use the **show rules** command.

show rules

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display active internal firewall rules:

```
> show rules
-----
Rule ID.....: 3
Ref count.....: 0
Precedence.....: 99999999
Flags.....: 00000001 ( PASS )
Source IP range:
    (Local stack)
Destination IP range:
    (Local stack)
-----
Rule ID.....: 25
Ref count.....: 0
Precedence.....: 99999999
Flags.....: 00000001 ( PASS )
Service Info
    Service name.....: GDB
    Protocol.....: 6
    Source port low.....: 0
    Source port high.....: 0
    Dest port low.....: 1000
    Dest port high.....: 1000
Source IP range:
IP High.....: 0.0.0.0
    Interface.....: ANY
Destination IP range:
    (Local stack)
-----
```

show switchconfig

To display parameters that apply to the Cisco wireless LAN controller, use the **show switchconfig** command.

show switchconfig

Syntax Description This command has no arguments or keywords.

Command Default Enabled.

Examples This example shows how to display parameters that apply to the Cisco wireless LAN controller:

```
> show switchconfig
802.3x Flow Control Mode..... Disabled
FIPS prerequisite features..... Enabled
Boot Break..... Enabled
secret obfuscation..... Enabled
Strong Password Check Features:
    case-check .....Disabled
    consecutive-check ....Disabled
    default-check .....Disabled
    username-check .....Disabled
```

Related Commands

- config switchconfig mode
- config switchconfig secret-obfuscation
- config switchconfig strong-pwd
- config switchconfig flowcontrol
- config switchconfig fips-prerequisite
- show stats switch

show rogue adhoc custom summary

To display information about custom rogue ad-hoc rogue access points, use the **show rogue adhoc custom summary** command.

show rogue adhoc custom summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display details of custom rogue ad-hoc rogue access points:

```
> show rogue adhoc custom summary
Number of Adhocs.....0

MAC Address           State           # APs # Clients Last Heard
-----
```

Related Commands

- show rogue adhoc detailed**
- show rogue adhoc summary**
- show rogue adhoc friendly summary**
- show rogue adhoc malicious summary**
- show rogue adhoc unclassified summary**
- config rogue adhoc**

show rogue adhoc detailed

To display details of an ad-hoc rogue access point detected by the Cisco wireless LAN controller, use the **show rogue adhoc client detailed** command.

show rogue adhoc detailed *MAC_address*

Syntax Description	<i>MAC_address</i>	Ad-hoc rogue MAC address.

Command Default None.

Examples This example shows how to display detailed ad-hoc rogue MAC address information:

```
> show rogue adhoc client detailed 02:61:ce:8e:a8:8c
Adhoc Rogue MAC address..... 02:61:ce:8e:a8:8c
Adhoc Rogue BSSID..... 02:61:ce:8e:a8:8c
State..... Alert
First Time Adhoc Rogue was Reported..... Tue Dec 11 20:45:45 2007
Last Time Adhoc Rogue was Reported..... Tue Dec 11 20:45:45 2007
Reported By
AP 1
MAC Address..... 00:14:1b:58:4a:e0
Name..... AP0014.1ced.2a60
Radio Type..... 802.11b
SSID..... rf4k3ap
Channel..... 3
RSSI..... -56 dBm
SNR..... 15 dB
Encryption..... Disabled
ShortPreamble..... Disabled
WPA Support..... Disabled
Last reported by this AP..... Tue Dec 11 20:45:45 2007
```

Related Commands

- config rogue adhoc**
- show rogue ignore-list**
- show rogue rule summary**
- show rogue rule detailed**
- config rogue rule**
- show rogue adhoc summary**

show rogue adhoc friendly summary

To display information about friendly rogue ad-hoc rogue access points, use the **show rogue adhoc friendly summary** command.

show rogue adhoc friendly summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display information about friendly rogue ad-hoc rogue access points:

```
> show rogue adhoc friendly summary
```

```
Number of Adhocs.....0
```

```
MAC Address          State          # APs # Clients Last Heard
```

```
-----
```

Related Commands

- show rogue adhoc custom summary**
- show rogue adhoc detailed**
- show rogue adhoc summary**
- show rogue adhoc malicious summary**
- show rogue adhoc unclassified summary**
- config rogue adhoc**

show rogue adhoc malicious summary

To display information about malicious rogue ad-hoc rogue access points, use the **show rogue adhoc malicious summary** command.

show rogue adhoc malicious summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display details of malicious rogue ad-hoc rogue access points:

```
> show rogue adhoc malicious summary
Number of Adhocs.....0

MAC Address           State           # Aps # Clients Last Heard
-----
```

Related Commands

- show rogue adhoc custom summary
- show rogue adhoc detailed
- show rogue adhoc summary
- show rogue adhoc friendly summary
- show rogue adhoc unclassified summary
- config rogue adhoc

show rogue adhoc unclassified summary

To display information about unclassified rogue ad-hoc rogue access points, use the **show rogue adhoc unclassified summary** command.

show rogue adhoc unclassified summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display information about unclassified rogue ad-hoc rogue access points:

```
> show rogue adhoc unclassified summary
```

```
Number of Adhocs.....0
```

```
MAC Address          State          # APs # Clients Last Heard
```

```
-----
```

Related Commands

- show rogue adhoc custom summary**
- show rogue adhoc detailed**
- show rogue adhoc summary**
- show rogue adhoc friendly summary**
- show rogue adhoc malicious summary**
- config rogue adhoc**

show rogue adhoc summary

To display a summary of the ad-hoc rogue access points detected by the Cisco wireless LAN controller, use the **show rogue adhoc summary** command.

show rogue adhoc summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of all ad-hoc rogues:

```
> show rogue adhoc summary
Detect and report Ad-Hoc Networks..... Enabled
Client MAC Address   Adhoc BSSID      State  # APs      Last Heard
-----
xx:xx:xx:xx:xx:xx    super           Alert   1          Sat Aug  9 21:12:50 2004
xx:xx:xx:xx:xx:xx    Alert          1          Aug  9 21:12:50 2003
xx:xx:xx:xx:xx:xx    Alert          1          Sat Aug  9 21:10:50 2003
```

Related Commands

- config rogue adhoc**
- show rogue ignore-list**
- show rogue rule summary**
- show rogue rule detailed**
- config rogue rule**
- show rogue adhoc detailed**

show rogue ap custom summary

To display information about custom rogue ad-hoc rogue access points, use the **show rogue ap custom summary** command.

show rogue ap custom summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display details of custom rogue ad-hoc rogue access points:

```
> show rogue ap custom summary
```

```
Number of APs.....0
```

```
MAC Address          State          # APs # Clients Last Heard
-----
```

Related Commands

config rogue adhoc
config rogue ap classify
config rogue ap friendly
config rogue ap rldp
config rogue ap timeout
config rogue ap valid-client
config rogue client
config trapflags rogueap
show rogue ap clients
show rogue ap detailed
show rogue ap summary
show rogue ap malicious summary
show rogue ap unclassified summary
show rogue client detailed
show rogue client summary
show rogue ignore-list
show rogue rule detailed
show rogue rule summary

show rogue ap clients

To display details of rogue access point clients detected by the Cisco wireless LAN controller, use the **show rogue ap clients** command.

show rogue ap clients *ap_mac_address*

Syntax Description

<i>ap_mac_address</i>	Rogue access point MAC address.

Command Default

None.

Examples

This example shows how to display details of rogue access point clients:

```
> show rogue ap clients xx:xx:xx:xx:xx:xx
MAC Address State # APs Last Heard
-----
00:bb:cd:12:ab:ff Alert 1 Fri Nov 30 11:26:23 2007
```

Related Commands

- config rogue adhoc**
- config rogue ap classify**
- config rogue ap friendly**
- config rogue ap rldp**
- config rogue ap timeout**
- config rogue ap valid-client**
- config rogue client**
- config trapflags rogueap**
- show rogue ap detailed**
- show rogue ap summary**
- show rogue ap friendly summary**
- show rogue ap malicious summary**
- show rogue ap unclassified summary**
- show rogue client detailed**
- show rogue client summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

show rogue ap detailed

To display details of a rogue access point detected by the Cisco wireless LAN controller, use the **show rogue-ap detailed** command.

show rogue ap detailed *ap_mac_address*

Syntax Description

<i>ap_mac_address</i>	Rogue access point MAC address.

Command Default

None.

Examples

This example shows how to display detailed information of a rogue access point:

```
> show rogue ap detailed xx:xx:xx:xx:xx:xx
Rogue BSSID..... 00:0b:85:63:d1:94
Is Rogue on Wired Network..... No
Classification..... Unclassified
State..... Alert
First Time Rogue was Reported..... Fri Nov 30 11:24:56 2007
Last Time Rogue was Reported..... Fri Nov 30 11:24:56 2007
Reported By
AP 1
MAC Address..... 00:12:44:bb:25:d0
Name..... flexconnect
Radio Type..... 802.11g
SSID..... edu-eap
Channel..... 6
RSSI..... -61 dBm
SNR..... -1 dB
Encryption..... Enabled
ShortPreamble..... Enabled
WPA Support..... Disabled
Last reported by this AP..... Fri Nov 30 11:24:56 2007
```

This example shows how to display detailed information of a rogue access point with a customized classification:

```
> show rogue ap detailed xx:xx:xx:xx:xx:xx
Rogue BSSID..... 00:17:0f:34:48:a0
Is Rogue on Wired Network..... No
Classification..... custom
Severity Score ..... 1
Class Name..... VeryMalicious
Class Change by..... Rogue Rule
Classified at ..... -60 dBm
Classified by..... c4:0a:cb:a1:18:80
State..... Contained
State change by..... Rogue Rule
First Time Rogue was Reported..... Mon Jun 4 10:31:18 2012
Last Time Rogue was Reported..... Mon Jun 4 10:31:18 2012
Reported By
AP 1
MAC Address..... c4:0a:cb:a1:18:80
Name..... SHIELD-3600-2027
Radio Type..... 802.11g
SSID..... sri
Channel..... 11
```

```
RSSI..... -87 dBm
SNR..... 4 dB
Encryption..... Enabled
ShortPreamble..... Enabled
WPA Support..... Enabled
Last reported by this AP..... Mon Jun 4 10:31:18 2012
```

Related Commands

- config rogue adhoc**
- config rogue ap classify**
- config rogue ap friendly**
- config rogue ap rldp**
- config rogue ap timeout**
- config rogue ap valid-client**
- config rogue client**
- config trapflags rogueap**
- show rogue ap clients**
- show rogue ap summary**
- show rogue ap friendly summary**
- show rogue ap malicious summary**
- show rogue ap unclassified summary**
- show rogue client detailed**
- show rogue client summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

show rogue ap summary

To display a summary of the rogue access points detected by the Cisco wireless LAN controller, use the **show rogue-ap summary** command.

show rogue ap summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of all rogue access points:

```
> show rogue ap summary
Rogue Location Discovery Protocol..... Disabled
Rogue ap timeout..... 1200
Rogue on wire Auto-Contain..... Disabled
Rogue using our SSID Auto-Contain..... Disabled
Valid client on rogue AP Auto-Contain..... Disabled
Rogue AP timeout..... 1200
Rogue Detection Report Interval..... 10
Rogue Detection Min Rssi..... -128
Rogue Detection Transient Interval..... 0
Rogue Detection Client Num Thershold..... 0
Total Rogues (AP+Ad-hoc) supported..... 2000
Total Rogues classified..... 729
```

MAC Address	Classification	# APs	# Clients	Last Heard
xx:xx:xx:xx:xx:xx	friendly	1	0	Thu Aug 4 18:57:11 2005
xx:xx:xx:xx:xx:xx	malicious	1	0	Thu Aug 4 19:00:11 2005
xx:xx:xx:xx:xx:xx	malicious	1	0	Thu Aug 4 18:57:11 2005
xx:xx:xx:xx:xx:xx	malicious	1	0	Thu Aug 4 18:57:11 2005

Related Commands

- config rogue adhoc
- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap timeout
- config rogue ap valid-client
- config rogue client
- config trapflags rogueap
- show rogue ap clients
- show rogue ap detailed
- show rogue ap friendly summary
- show rogue ap malicious summary
- show rogue ap unclassified summary

show rogue client detailed
show rogue client summary
show rogue ignore-list
show rogue rule detailed
show rogue rule summary

show rogue ap friendly summary

To display a list of the friendly rogue access points detected by the controller, use the **show rogue ap friendly summary** command.

show rogue ap friendly summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of all friendly rogue access points:

```
> show rogue ap friendly summary
Number of APs..... 1
MAC Address      State      # APs  # Clients Last Heard
-----
XX:XX:XX:XX:XX:XX Internal    1     0 Tue Nov 27 13:52:04 2007
```

Related Commands

- config rogue adhoc
- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap timeout
- config rogue ap valid-client
- config rogue client
- config trapflags rogueap
- show rogue ap clients
- show rogue ap detailed
- show rogue ap summary
- show rogue ap malicious summary
- show rogue ap unclassified summary
- show rogue client detailed
- show rogue client summary
- show rogue ignore-list
- show rogue rule detailed
- show rogue rule summary

show rogue ap malicious summary

To display a list of the malicious rogue access points detected by the controller, use the **show rogue ap malicious summary** command.

show rogue ap malicious summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of all malicious rogue access points:

```
> show rogue ap malicious summary
Number of APs..... 2
MAC Address      State      # APs  # Clients Last Heard
-----
XX:XX:XX:XX:XX:XX Alert          1    0  Tue Nov 27 13:52:04 2007
XX:XX:XX:XX:XX:XX Alert          1    0  Tue Nov 27 13:52:04 2007
```

Related Commands

- config rogue adhoc
- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap timeout
- config rogue ap valid-client
- config rogue client
- config trapflags rogueap
- show rogue ap clients
- show rogue ap detailed
- show rogue ap summary
- show rogue ap friendly summary
- show rogue ap unclassified summary
- show rogue client detailed
- show rogue client summary
- show rogue ignore-list
- show rogue rule detailed
- show rogue rule summary

show rogue ap unclassified summary

To display a list of the unclassified rogue access points detected by the controller, use the **show rogue ap unclassified summary** command.

show rogue ap unclassified summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a list of all unclassified rogue access points:

```
> show rogue ap unclassified summary
Number of APs..... 164
MAC Address      State      # APs # Clients Last Heard
-----
XX:XX:XX:XX:XX:XX Alert          1    0  Fri Nov 30 11:12:52 2007
XX:XX:XX:XX:XX:XX Alert          1    0  Fri Nov 30 11:29:01 2007
XX:XX:XX:XX:XX:XX Alert          1    0  Fri Nov 30 11:26:23 2007
XX:XX:XX:XX:XX:XX Alert          1    0  Fri Nov 30 11:26:23 2007
```

Related Commands

- config rogue adhoc
- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap timeout
- config rogue ap valid-client
- config rogue client
- config trapflags rogueap
- show rogue ap clients
- show rogue ap detailed
- show rogue ap summary
- show rogue ap friendly summary
- show rogue ap malicious summary
- show rogue client detailed
- show rogue client summary
- show rogue ignore-list
- show rogue rule detailed
- show rogue rule summary

show rogue auto-contain

To display information about rogue auto-containment, use the **show rogue auto-contain** command.

show rogue auto-contain

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Examples

This example shows how to display information about rogue auto-containment:

```
> show rogue auto-contain
Containment Level..... 3
monitor_ap_only..... false
```

Related Commands

config rogue adhoc

config rogue auto-contain level

show rogue client detailed

To display details of a rogue client detected by a Cisco wireless LAN controller, use the **show rogue client detailed** command.

show rogue client detailed *MAC_address*

Syntax Description	
	<i>MAC_address</i> Rogue client MAC address.

Command Default None.

Examples This example shows how to display detailed information for a rogue client:

```
> show rogue client detailed xx:xx:xx:xx:xx:xx
Rogue BSSID..... 00:0b:85:23:ea:d1
State..... Alert
First Time Rogue was Reported..... Mon Dec 3 21:50:36 2007
Last Time Rogue was Reported..... Mon Dec 3 21:50:36 2007
Rogue Client IP address..... Not known
Reported By
AP 1
MAC Address..... 00:15:c7:82:b6:b0
Name..... AP0016.47b2.31ea
Radio Type..... 802.11a
RSSI..... -71 dBm
SNR..... 23 dB
Channel..... 149
Last reported by this AP..... Mon Dec 3 21:50:36 2007
```

Related Commands

- show rogue client summary**
- show rogue ignore-list**
- config rogue rule client**
- config rogue rule**

show rogue client summary

To display a summary of the rogue clients detected by the Cisco wireless LAN controller, use the **show rogue client summary** command.

show rogue client summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a list of all rogue clients:

```
> show rogue client summary
Validate rogue clients against AAA..... Disabled
Total Rogue Clients supported..... 2500
Total Rogue Clients present..... 3
MAC Address          State          #   APs   Last Heard
-----
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:00:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:09:11 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:03:11 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:03:11 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:09:11 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 18:57:08 2005
xx:xx:xx:xx:xx:xx    Alert          1     Thu Aug 4 19:12:08 2005
```

Related Commands **show rogue client detailed**

show rogue ignore-list

config rogue client

config rogue rule

show rogue ignore-list

To display a list of rogue access points that are configured to be ignored, use the **show rogue ignore-list** command.

show rogue ignore-list

Syntax Description This command has no arguments or keywords.

Command Default None

Examples The following example shows how to display a list of all rogue access points that are configured to be ignored.

```
Device > show rogue ignore-list

MAC Address
-----
xx:xx:xx:xx:xx:xx
```

Related Commands

- config rogue adhoc
- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap ssid
- config rogue ap timeout
- config rogue ap valid-client
- config rogue rule
- config trapflags rogueap
- show rogue client detailed
- show rogue ignore-list
- show rogue rule summary
- show rogue client summary
- show rogue ap unclassified summary
- show rogue ap malicious summary
- show rogue ap friendly summary
- config rogue client
- show rogue ap summary
- show rogue ap clients
- show rogue ap detailed

config rogue rule

show rogue rule detailed

To display detailed information for a specific rogue classification rule, use the **show rogue rule detailed** command.

show rogue rule detailed *rule_name*

Syntax Description	<i>rule_name</i>	Rogue rule name.

Command Default	None

Examples This example shows how to display detailed information on a specific rogue classification rule:

```
> show rogue rule detailed Rule2
Priority..... 2
Rule Name..... Rule2
State..... Enabled
Type..... Malicious
Severity Score..... 1
Class Name..... Very_Malicious
Notify..... All
State ..... Contain
Match Operation..... Any
Hit Count..... 352
Total Conditions..... 2
Condition 1
  type..... Client-count
  value..... 10
Condition 2
  type..... Duration
  value (seconds)..... 2000
Condition 3
  type..... Managed-ssid
  value..... Enabled
Condition 4
  type..... No-encryption
  value..... Enabled
Condition 5
  type..... Rssi
  value (dBm)..... -50
Condition 6
  type..... Ssid
  SSID Count..... 1
  SSID 1..... test
```

Related Commands	config rogue rule show rogue ignore-list show rogue rule summary

show rogue rule summary

To display the rogue classification rules that are configured on the controller, use the **show rogue rule summary** command.

show rogue rule summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a list of all rogue rules that are configured on the controller:

```
> show rogue rule summary
Priority Rule Name      State   Type      Match Hit Count
-----
1       mtest          Enabled Malicious All    0
2       asdfasdf       Enabled Malicious All    0
```

This example shows how to display a list of all rogue rules that are configured on the controller:

```
> show rogue rule summary
Priority Rule Name      Rule state Class Type   Notify   State   Match
Hit Count
-----
1       rule2          Enabled  Friendly Global  Alert   All
234
2       rule1          Enabled  Custom  Global  Alert   All
0
```

Related Commands

- config rogue rule
- show rogue ignore-list
- show rogue rule detailed

show tacacs acct statistics

To display detailed radio frequency identification (RFID) information for a specified tag, use the **show tacacs acct statistics** command.

show tacacs acct statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display detailed RFID information:

```
> show tacacs acct statistics
Accounting Servers:
Server Index..... 1
Server Address..... 10.0.0.0
Msg Round Trip Time..... 0 (1/100 second)
First Requests..... 1
Retry Requests..... 0
Accounting Response..... 0
Accounting Request Success..... 0
Accounting Request Failure..... 0
Malformed Msgs..... 0
Bad Authenticator Msgs..... 0
Pending Requests..... -1
Timeout Requests..... 1
Unknowntype Msgs..... 0
Other Drops..... 0
```

Related Commands

- config tacacs acct**
- config tacacs athr**
- config tacacs auth**
- show tacacs summary**

show tacacs athr statistics

To display TACACS+ server authorization statistics, use the **show tacacs athr statistics** command.

show tacacs athr statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display TACACS server authorization statistics:

```
> show tacacs athr statistics
Authorization Servers:
Server Index..... 3
Server Address..... 10.0.0.3
Msg Round Trip Time..... 0 (1/100 second)
First Requests..... 0
Retry Requests..... 0
Received Responses..... 0
Authorization Success..... 0
Authorization Failure..... 0
Challenge Responses..... 0
Malformed Msgs..... 0
Bad Authenticator Msgs..... 0
Pending Requests..... 0
Timeout Requests..... 0
Unknowntype Msgs..... 0
Other Drops..... 0
```

Related Commands

- config tacacs acct**
- config tacacs athr**
- config tacacs auth**
- show tacacs auth statistics**
- show tacacs summary**

show tacacs auth statistics

To display TACACS+ server authentication statistics, use the **show tacacs auth statistics** command.

show tacacs auth statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display TACACS server authentication statistics:

```
> show tacacs auth statistics
Authentication Servers:
Server Index..... 2
Server Address..... 10.0.0.2
Msg Round Trip Time..... 0 (msec)
First Requests..... 0
Retry Requests..... 0
Accept Responses..... 0
Reject Responses..... 0
Error Responses..... 0
Restart Responses..... 0
Follow Responses..... 0
GetData Responses..... 0
Encrypt no secret Responses..... 0
Challenge Responses..... 0
Malformed Msgs..... 0
Bad Authenticator Msgs..... 0
Pending Requests..... 0
Timeout Requests..... 0
Unknown type Msgs..... 0
Other Drops..... 0
```

Related Commands

- config tacacs acct**
- config tacacs athr**
- config tacacs auth**
- show tacacs summary**

show tacacs summary

To display TACACS+ server summary information, use the **show tacacs summary** command.

show tacacs summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display TACACS server summary information:

```
> show tacacs summary
Authentication Servers
Idx  Server Address  Port    State    Tout
---  -
2    10.0.0.2         6       Enabled  30
Accounting Servers
Idx  Server Address  Port    State    Tout
---  -
1    10.0.0.0         10      Enabled  2
Authorization Servers
Idx  Server Address  Port    State    Tout
---  -
3    10.0.0.3         4       Enabled  2
...
```

Related Commands

- config tacacs acct**
- config tacacs athr**
- config tacacs auth**
- show tacacs summary**
- show tacacs athr statistics**
- show tacacs auth statistics**

show wps ap-authentication summary

To display the access point neighbor authentication configuration on the controller, use the **show wps ap-authentication summary** command.

show wps ap-authentication summary

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display a summary of the Wireless Protection System (WPS) access point neighbor authentication:

```
> show wps ap-authentication summary
AP neighbor authentication is <disabled>.
Authentication alarm threshold is 1.
RF-Network Name: <B1>
```

Related Commands	config wps ap-authentication

show wps cids-sensor

To display Intrusion Detection System (IDS) sensor summary information or detailed information on a specified Wireless Protection System (WPS) IDS sensor, use the **show wps cids-sensor** command.

```
show wps cids-sensor {summary | detail index}
```

Syntax	Description
summary	Displays a summary of sensor settings.
detail	Displays all settings for the selected sensor.
<i>index</i>	IDS sensor identifier.

Command Default	None.

Examples

This example shows how to display all settings for the selected sensor:

[illegible]

Related Commands `config wps ap-authentication`

show wps mfp

To display Management Frame Protection (MFP) information, use the **show wps mfp** command.

show wps mfp {summary | statistics}

Syntax Description

summary	Displays the MFP configuration and status.
statistics	Displays MFP statistics.

Command Default

None.

Examples

This example shows how to display a summary of the MFP configuration and status:

```
> show wps mfp summary
Global Infrastructure MFP state..... DISABLED (*all infrastructure
settings are overridden)
Controller Time Source Valid..... False

WLAN ID  WLAN Name                WLAN      Infra.    Client
-----  -
1         homeap                    Disabled  *Enabled  Optional but inactive
(WPA2 not configured)
2         7921                      Enabled   *Enabled  Optional but inactive
(WPA2 not configured)
3         open1                    Enabled   *Enabled  Optional but inactive
(WPA2 not configured)
4         7920                      Enabled   *Enabled  Optional but inactive
(WPA2 not configured)

AP Name      Infra.    Operational  --Infra. Capability--
-----      Validation Radio    State          Protection Validation
AP1252AG-EW  *Enabled  b/g          Down           Full           Full
              a          Down           Full           Full
```

This example shows how to display the MFP statistics:

```
> show wps mfp statistics
BSSID      Radio Validator AP      Last Source Addr  Found  Error Type
Count      Frame Types
-----
no errors
```

Related Commands

config wps mfp

show wps shun-list

To display the Intrusion Detection System (IDS) sensor shun list, use the **show wps shun-list** command.

show wps shun-list

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the IDS system sensor shun list:

```
> show wps shun-list
```

Related Commands **config wps shun-list re-sync**

show wps signature detail

To display installed signatures, use the **show wps signature detail** command.

show wps signature detail *sig-id*

Syntax Description

<i>sig-id</i>	Signature ID of an installed signature.

Command Default

None.

Examples

This example shows how to display information on the attacks detected by standard signature 1:

```
> show wps signature detail 1
Signature-ID..... 1
Precedence..... 1
Signature Name..... Bcast deauth
Type..... standard
FrameType..... management
State..... enabled
Action..... report
Tracking..... per Signature and Mac
Signature Frequency..... 500 pkts/interval
Signature Mac Frequency..... 300 pkts/interval
Interval..... 10 sec
Quiet Time..... 300 sec
Description..... Broadcast Deauthentication Frame
Patterns:
    0 (Header) : 0x0:0x0
    4 (Header) : 0x0:0x0
```

Related Commands

config wps signature
config wps signature frequency
config wps signature mac-frequency
config wps signature interval
config wps signature quiet-time
config wps signature reset
show wps signature events
show wps signature summary
show wps summary

show wps signature events

To display more information about the attacks detected by a particular standard or custom signature, use the **show wps signature events** command.

show wps signature events {**summary** | {**standard** | **custom**} *precedenceID* {**summary** | **detailed**}

Syntax Description

summary	Displays all tracking signature summary information.
standard	Displays Standard Intrusion Detection System (IDS) signature settings.
custom	Displays custom IDS signature settings.
<i>precedenceID</i>	Signature precedence identification value.
detailed	Displays tracking source MAC address details.

Command Default

None.

Examples

This example shows how to display the number of attacks detected by all enabled signatures:

```
> show wps signature events summary
Precedence  Signature Name      Type      # Events
-----
1           Bcast deauth                Standard    2
2           NULL probe resp 1           Standard    1
```

This example shows how to display a summary of information on the attacks detected by standard signature 1:

```
> show wps signature events standard 1 summary
Precedence..... 1
Signature Name..... Bcast deauth
Type..... Standard
Number of active events..... 2
Source MAC Addr    Track Method  Frequency # APs Last Heard
-----
00:a0:f8:58:60:dd  Per Signature  50          1    Wed Oct 25 15:03:05 2006
00:a0:f8:58:60:dd  Per Mac       30          1    Wed Oct 25 15:02:53 2006
```

Related Commands

config wps signature frequency
config wps signature mac-frequency
config wps signature interval
config wps signature quiet-time
config wps signature reset
config wps signature

show wps signature summary

show wps summary

show wps signature summary

To see individual summaries of all of the standard and custom signatures installed on the controller, use the **show wps signature summary** command.

show wps signature summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of all of the standard and custom signatures:

```
> show wps signature summary
Signature-ID..... 1
Precedence..... 1
Signature Name..... Bcast deauth
Type..... standard
FrameType..... management
State..... enabled
Action..... report
Tracking..... per Signature and Mac
Signature Frequency..... 50 pkts/interval
Signature Mac Frequency..... 30 pkts/interval
Interval..... 1 sec
Quiet Time..... 300 sec
Description..... Broadcast Deauthentication Frame
Patterns:
                0 (Header):0x00c0:0x00ff
                4 (Header):0x01:0x01
...
```

Related Commands

- config wps signature frequency**
- config wps signature interval**
- config wps signature quiet-time**
- config wps signature reset**
- show wps signature events**
- show wps summary**
- config wps signature mac-frequency**
- config wps signature**

show wps summary

To display Wireless Protection System (WPS) summary information, use the **show wps summary** command.

show wps summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display WPS summary information:

```
> show wps summary
Auto-Immune
  Auto-Immune..... Disabled
Client Exclusion Policy
  Excessive 802.11-association failures..... Enabled
  Excessive 802.11-authentication failures..... Enabled
  Excessive 802.1x-authentication..... Enabled
  IP-theft..... Enabled
  Excessive Web authentication failure..... Enabled
Trusted AP Policy
  Management Frame Protection..... Disabled
  Mis-configured AP Action..... Alarm Only
    Enforced encryption policy..... none
    Enforced preamble policy..... none
    Enforced radio type policy..... none
  Validate SSID..... Disabled
  Alert if Trusted AP is missing..... Disabled
  Trusted AP timeout..... 120
Untrusted AP Policy
  Rogue Location Discovery Protocol..... Disabled
  RLDP Action..... Alarm Only
Rogue APs
  Rogues AP advertising my SSID..... Alarm Only
  Detect and report Ad-Hoc Networks..... Enabled
Rogue Clients
  Validate rogue clients against AAA..... Enabled
  Detect trusted clients on rogue APs..... Alarm Only
  Rogue AP timeout..... 1300
Signature Policy
  Signature Processing..... Enabled
...
```

Related Commands

- config wps signature frequency**
- config wps signature interval**
- config wps signature quiet-time**
- config wps signature reset**
- show wps signature events**
- show wps signature mac-frequency**
- show wps summary**
- config wps signature**

config wps signature interval

show wps wips statistics

To display the current state of the Cisco Wireless Intrusion Prevention System (wIPS) operation on the controller, use the **show wps wips statistics** command.

show wps wips statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the statistics of the wIPS operation:

```
> show wps wips statistics
Policy Assignment Requests..... 1
Policy Assignment Responses..... 1
Policy Update Requests..... 0
Policy Update Responses..... 0
Policy Delete Requests..... 0
Policy Delete Responses..... 0
Alarm Updates..... 13572
Device Updates..... 8376
Device Update Requests..... 0
Device Update Responses..... 0
Forensic Updates..... 1001
Invalid WIPS Payloads..... 0
Invalid Messages Received..... 0
NMSP Transmitted Packets..... 22950
NMSP Transmit Packets Dropped..... 0
NMSP Largest Packet..... 1377
```

Related Commands

- config 802.11 enable**
- config ap mode**
- config ap monitor-mode**
- show ap config**
- show ap monitor-mode summary**
- show wps wips summary**

show wps wips summary

To display the adaptive Cisco Wireless Intrusion Prevention System (wIPS) configuration that the Wireless Control System (WCS) forwards to the controller, use the **show wps wips summary** command.

show wps wips summary

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display a summary of the wIPS configuration:

```
> show wps wips summary
Policy Name..... Default
Policy Version..... 3
```

Related Commands	config 802.11 enable config ap mode config ap monitor-mode show ap config show ap monitor-mode summary show wps wips statistics

config Commands

This section lists the **config** commands to configure security settings for the controller.

config 802.11b preamble

To change the 802.11b preamble as defined in subclause 18.2.2.2 to **long** (slower, but more reliable) or **short** (faster, but less reliable), use the **config 802.11b preamble** command.

config 802.11b preamble {long | short}

Syntax Description

long	Specifies the long 802.11b preamble.
short	Specifies the short 802.11b preamble.

Command Default

Short.

Usage Guidelines

Note

You must reboot the Cisco Wireless LAN Controller (reset system) with save to implement this command.

This parameter must be set to **long** to optimize this Cisco wireless LAN controller for some clients, including SpectraLink NetLink telephones.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to change the 802.11b preamble to short:

```
> config 802.11b preamble short
> (reset system with save)
```

Related Commands

show 802.11b

config aaa auth

To configure the AAA authentication search order for management users, use the **config aaa auth** command.

config aaa auth mgmt [*aaa_server_type1* | *aaa_server_type2*]

Syntax Description

mgmt	Configures the AAA authentication search order for controller management users by specifying up to three AAA authentication server types. The order that the server types are entered specifies the AAA authentication search order.
<i>aaa_server_type</i>	(Optional) AAA authentication server type (local , radius , or tacacs). The local setting specifies the local database, the radius setting specifies the RADIUS server, and the tacacs setting specifies the TACACS+ server.

Command Default

None.

Usage Guidelines

You can enter two AAA server types as long as one of the server types is **local**. You cannot enter **radius** and **tacacs** together.

Examples

This example shows how to configure the AAA authentication search order for controller management users by the authentication server type local:

```
> config aaa auth radius local
```

Related Commands

show aaa auth

config aaa auth mgmt

To configure the order of authentication when multiple databases are configured, use the **config aaa auth mgmt** command.

config aaa auth mgmt [**radius** | **tacacs**]

Syntax Description

radius	(Optional) Configures the order of authentication for RADIUS servers.
tacacs	(Optional) Configures the order of authentication for TACACS servers.

Command Default

None.

Examples

This example shows how to configure the order of authentication for the RADIUS server:

```
> config aaa auth mgmt radius
```

This example shows how to configure the order of authentication for the TACACS server:

```
> config aaa auth mgmt tacacs
```

Related Commands

show aaa auth order

config acl apply

To apply an access control list (ACL) to the data path, use the **config acl apply** command.

config acl apply *rule_name*

Syntax Description	<table><tr><td><i>rule_name</i></td><td>ACL name that contains up to 32 alphanumeric characters.</td></tr></table>	<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.		
Command Default	None.		
Usage Guidelines	For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.		
Examples	This example shows how to apply an ACL to the data path: <pre>> config acl apply acl01</pre>		
Related Commands	show acl		

config acl counter

To see if packets are hitting any of the access control lists (ACLs) configured on your controller, use the **config acl counter** command.

config acl counter {start | stop}

Syntax Description

start	Enables ACL counters on your controller.
stop	Disables ACL counters on your controller.

Command Default

None

Usage Guidelines

ACL counters are available only on the following controllers: 4400 series, Cisco WiSM, and Catalyst 3750G Integrated Wireless LAN Controller Switch.

Examples

This example shows how to enable ACL counters on your controller:

```
> config acl counter start
```

Related Commands

clear acl counters
show acl detailed

config acl create

To create a new access control list (ACL), use the **config acl create** command.

config acl create *rule_name*

Syntax Description	<table><tr><td><i>rule_name</i></td><td>ACL name that contains up to 32 alphanumeric characters.</td></tr></table>	<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.		
Command Default	None.		
Usage Guidelines	For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.		
Examples	This example shows how to create a new ACL: <pre>> config acl create acl01</pre>		
Related Commands	show acl		

config acl cpu

To create a new access control list (ACL) rule that restricts the traffic reaching the CPU, use the **config acl cpu** command.

config acl cpu *rule_name* {**wired** | **wireless** | **both**}

Syntax Description

<i>rule_name</i>	Specifies the ACL name.
wired	Specifies an ACL on wired traffic.
wireless	Specifies an ACL on wireless traffic.
both	Specifies an ACL on both wired and wireless traffic.

Command Default

None.

Usage Guidelines

This command allows you to control the type of packets reaching the CPU.

Examples

This example shows how to create an ACL named `acl101` on the CPU and apply it to wired traffic:

```
> config acl cpu acl101 wired
```

Related Commands

show acl cpu

config acl delete

To delete an access control list (ACL), use the **config acl delete** command.

config acl delete *rule_name*

Syntax Description	<table><tr><td><i>rule_name</i></td><td>ACL name that contains up to 32 alphanumeric characters.</td></tr></table>	<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.		
Command Default	None.		
Usage Guidelines	For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.		
Examples	This example shows how to delete an ACL named acl101 on the CPU: <pre>> config acl delete acl101</pre>		
Related Commands	show acl		

config acl rule

To configure ACL rules, use the **config acl rule** command.

config acl rule {**action** *rule_name rule_index* {**permit** | **deny**} | **add** *rule_name rule_index* | **change index** *rule_name old_index new_index* | **delete** *rule_name rule_index* | **destination address** *rule_name rule_index ip_address netmask* | **destination port range** *rule_name rule_index start_port end_port* | **direction** *rule_name rule_index* {**in** | **out** | **any**} | **dscp** *rule_name rule_index dscp* | **protocol** *rule_name rule_index protocol* | **source address** *rule_name rule_index ip_address netmask* | **source port range** *rule_name rule_index start_port end_port* | **swap index** *rule_name index_1 index_2*}

Syntax Description

action	Configures whether to permit or deny access.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_index</i>	Rule index between 1 and 32.
permit	Permits the rule action.
deny	Denies the rule action.
add	Adds a new rule.
change	Changes a rule's index.
index	Specifies a rule index.
delete	Deletes a rule.
destination address	Configures a rule's destination IP address and netmask.
destination port range	Configure a rule's destination port range.
<i>ip_address</i>	IP address of the rule.
<i>netmask</i>	Netmask of the rule.
<i>start_port</i>	Start port number (between 0 and 65535).
<i>end_port</i>	End port number (between 0 and 65535).
direction	Configures a rule's direction to in, out, or any.
in	Configures a rule's direction to in.
out	Configures a rule's direction to out.
any	Configures a rule's direction to any.

dscp	Configures a rule's DSCP.
<i>dscp</i>	Number between 0 and 63, or any .
protocol	Configures a rule's DSCP.
<i>protocol</i>	Number between 0 and 255, or any .
source address	Configures a rule's source IP address and netmask.
source port range	Configures a rule's source port range.
swap	Swaps two rules' indices.

Command Default

None.

Usage Guidelines

For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.

Examples

This example shows how to configure an ACL to permit access:

```
> config acl rule action lab1 4 permit
```

Related Commands

show acl

config auth-list add

To create an authorized access point entry, use the **config auth-list add** command.

config auth-list add {**mic** | **ssc**} *AP_MAC* [*AP_key*]

Syntax Description

mic	Specifies that the access point has a manufacture-installed certificate.
ssc	Specifies that the access point has a self-signed certificate.
<i>AP_MAC</i>	MAC address of a Cisco lightweight access point.
<i>AP_key</i>	(Optional) Key hash value that is equal to 20 bytes or 40 digits.

Command Default

None.

Examples

This example shows how to create an authorized access point entry with a manufacturer-installed certificate on MAC address 00:0b:85:02:0d:20:

```
> config auth-list add 00:0b:85:02:0d:20
```

Related Commands

config auth-list delete
config auth-list ap-policy

config auth-list ap-policy

To configure an access point authorization policy, use the **config auth-list ap-policy** command.

config auth-list ap-policy {authorize-ap {enable | disable} | ssc {enable | disable}}

Syntax Description

authorize-ap enable	Enables the authorization policy.
authorize-ap disable	Disables the AP authorization policy.
ssc enable	Allows the APs with self-signed certificates to connect.
ssc disable	Disallows the APs with self-signed certificates to connect.

Command Default

None.

Examples

This example shows how to enable an access point authorization policy:

```
> config auth-list ap-policy authorize-ap enable
```

This example shows how to enable an access point with a self-signed certificate to connect:

```
> config auth-list ap-policy ssc disable
```

Related Commands

config auth-list delete

config auth-list add

config auth-list delete

To delete an access point entry, use the **config auth-list delete** command.

config auth-list delete *AP_MAC*

Syntax Description

<i>AP_MAC</i>	MAC address of a Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to delete an access point entry for MAC address 00:1f:ca:cf:b6:60:

```
> config auth-list delete 00:1f:ca:cf:b6:60
```

Related Commands

config auth-list delete
config auth-list add
config auth-list ap-policy

config advanced eap

To configure advanced extensible authentication protocol (EAP) settings, use the **config advanced eap** command.

config advanced eap {**bcast-key-interval** *seconds* | **eapol-key-timeout** *timeout* | **eapol-key-retries** *retries* | **identity-request-timeout** *timeout* | **identity-request-retries** *retries* | **key-index** *index* | **max-login-ignore-identity-response** {**enable** | **disable**} **request-timeout** *timeout* | **request-retries** *retries*}

Syntax Description

bcast-key-interval <i>seconds</i>	Specifies the EAP-broadcast key renew interval time in seconds. The range is from 120 to 86400 seconds.
eapol-key-timeout <i>timeout</i>	Specifies the amount of time (200 to 5000 milliseconds) that the controller waits before retransmitting an EAPOL (WPA) key message to a wireless client using EAP or WPA/WPA-2 PSK. The default value is 1000 milliseconds.
eapol-key-retries <i>retries</i>	Specifies the maximum number of times (0 to 4 retries) that the controller retransmits an EAPOL (WPA) key message to a wireless client. The default value is 2.
identity-request- timeout <i>timeout</i>	Specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting an EAP Identity Request message to a wireless client. The default value is 30 seconds.
identity-request- retries	Specifies the maximum number of times (0 to 4 retries) that the controller retransmits an EAPOL (WPA) key message to a wireless client. The default value is 2.
key-index <i>index</i>	Specifies the key index (0 or 3) used for dynamic wired equivalent privacy (WEP).
max-login-ignore- identity-response	Specifies that the maximum EAP identity response login count for a user is ignored. When enabled, this command limits the number of devices that can be connected to the controller with the same username.
enable	Ignores the same username reaching the maximum EAP identity response.
disable	Checks the same username reaching the maximum EAP identity response.

request-timeout	For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting the message to a wireless client. The default value is 30 seconds.
request-retries	(Optional) For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the maximum number of times (0 to 20 retries) that the controller retransmits the message to a wireless client. The default value is 2.

Command Default

Default for **eapol-key-timeout**: 1 second.
Default for **eapol-key-retries**: 2 retries.

Examples

This example shows how to configure the key index used for dynamic wired equivalent privacy (WEP):

```
> config advanced eap key-index 0
```

Related Commands

show advanced eap

config advanced timers auth-timeout

To configure the authentication timeout, use the **config advanced timers auth-timeout** command.

config advanced timers auth-timeout *seconds*

Syntax Description

<i>seconds</i>	Authentication response timeout value in seconds between 10 and 600.

Command Default

10 seconds.

Examples

This example shows how to configure the authentication timeout to 20 seconds:

```
> config advanced timers auth-timeout 20
```

Related Commands

show advanced timers

config advanced timers ap-discovery-timeout

config advanced timers ap-heartbeat-timeout

config advanced timers ap-primary-discovery-timeout

config advanced timers ap-fast-heartbeat

config advanced timers eap-timeout

To configure the Extensible Authentication Protocol (EAP) expiration timeout, use the **config advanced timers eap-timeout** command.

config advanced timers eap-timeout *seconds*

Syntax Description

<i>seconds</i>	EAP timeout value in seconds between 8 and 120.

Command Default

None.

Examples

This example shows how to configure the EAP expiration timeout to 10 seconds:

```
> config advanced timers eap-timeout 10
```

Related Commands

show advanced timers

config advanced timers eap-identity-request-delay

To configure the advanced Extensible Authentication Protocol (EAP) identity request delay in seconds, use the **config advanced timers eap-identity-request-delay** command.

config advanced timers eap-identity-request-delay *seconds*

Syntax Description	<i>seconds</i>	Advanced EAP identity request delay in number of seconds between 0 and 10.

Command Default None.

Examples This example shows how to configure the advanced EAP identity request delay to 8 seconds:

```
> config advanced timers eap-identity-request-delay 8
```

Related Commands

- config advanced timers auth-timeout**
- config advanced timers rogue-ap**
- show advanced timers**

config cts sxp

To configure Cisco TrustSec SXP (CTS) connections on the controller, use the **config cts sxp** command.

config cts sxp {**enable** | **disable** | **connection** {**delete** | **peer**} | **default password** *password* | **retry period** *time-in-seconds*}

Syntax Description

enable	Enables CTS connections on the controller.
disable	Disables CTS connections on the controller.
connection	Configures CTS connection on the controller.
delete	Deletes the CTS connection on the controller.
peer	Configures the next hop switch with which the controller is connected.
<i>ip-address</i>	IPv4 address of the peer.
default password	Configures the default password for MD5 authentication of SXP messages.
<i>password</i>	Default password for MD5 Authentication of SXP messages. The password should contain a minimum of six characters.
retry period	Configures the SXP retry period.
<i>time-in-seconds</i>	Time after which a CTS connection should be again tried for after a failure to connect.

Command Default

None

Examples

This example shows how to enable CTS on the controller:

```
> config cts sxp enable
```

This example shows how to configure a peer for a CTS connection:

```
> config cts sxp connection peer 209.165.200.224
```

Related Commands

debug cts sxp

config database size

To configure the local database, use the **config database size** command.

config database size *count*

Syntax Description	

<i>count</i>	Database size value between 512 and 2040

Command Default	

None.

Usage Guidelines	

Use the show database command to display local database configuration.

Examples	

This example shows how to configure the size of the local database:

```
> config database size 1024
```

Related Commands	

show database

config exclusionlist

To create or delete an exclusion list entry, use the **config exclusionlist** command.

config exclusionlist {**add** *MAC* [*description*] | **delete** *MAC* | **description** *MAC* [*description*]}

Syntax Description

config exclusionlist	Configures the exclusion list.
add	Creates a local exclusion-list entry.
delete	Deletes a local exclusion-list entry
description	Specifies the description for an exclusion-list entry.
<i>MAC</i>	MAC address of the local Excluded entry.
<i>description</i>	(Optional) Description, up to 32 characters, for an excluded entry.

Command Default

None.

Examples

This example shows how to create a local exclusion list entry for the MAC address *xx:xx:xx:xx:xx:xx*:

```
> config exclusionlist add xx:xx:xx:xx:xx:xx lab
```

This example shows how to delete a local exclusion list entry for the MAC address *xx:xx:xx:xx:xx:xx*:

```
> config exclusionlist delete xx:xx:xx:xx:xx:xx lab
```

Related Commands

show exclusionlist

config ldap

To configure the Lightweight Directory Access Protocol (LDAP) server settings, use the **config ldap** command.

config ldap {**add** | **delete** | **enable** | **disable** | **retransmit-timeout**} *index*

Syntax Description

add	Specifies that an LDAP server is being added.
delete	Specifies that an LDAP server is being deleted.
enable	Specifies that an LDAP serve is enabled.
disable	Specifies that an LDAP server is disabled.
retransmit-timeout	Changes the default retransmit timeout for an LDAP server.
<i>index</i>	LDAP server index. The range is from 1 to 17.

Command Default

None.

Examples

This example shows how to enable LDAP server index 10:

```
> config ldap enable 10
```

Related Commands

config ldap add
config ldap simple-bind
show ldap summary

config ldap add

To configure a Lightweight Directory Access Protocol (LDAP) server, use the **config ldap add** command.

config ldap add *index server_ip_address port user_base user_attr user_type*

Syntax Description

<i>index</i>	LDAP server index.
<i>server_ip_address</i>	IP address of the LDAP server.
<i>port</i>	Port number.
<i>user_base</i>	Distinguished name for the subtree that contains all of the users.
<i>user_attr</i>	Attribute that contains the username.
<i>user_type</i>	ObjectType that identifies the user.

Command Default

None.

Examples

This example shows how to configure a LDAP server with the index10, server IP address 209.165.201.30, port number 2:

```
> config ldap add 10 209.165.201.30 2 base_name attr_name type_name
```

Related Commands

config ldap
config ldap simple-bind
show ldap summary

config ldap simple-bind

To configure the local authentication bind method for the Lightweight Directory Access Protocol (LDAP) server, use the **config ldap simple-bind** command.

config ldap simple-bind {**anonymous** *index* | **authenticated** *index username password*}

Syntax Description

anonymous	Allows anonymous access to the LDAP server.
<i>index</i>	LDAP server index.
authenticated	Specifies that a username and password be entered to secure access to the LDAP server.
<i>username</i>	Username for the authenticated bind method.
<i>password</i>	Password for the authenticated bind method.

Command Default

The default bind method is **anonymous**.

Examples

This example shows how to configure the local authentication bind method that allows anonymous access to the LDAP server:

```
> config ldap simple-bind anonymous
```

Related Commands

config ldap add
config ldap
show ldap summary

config local-auth active-timeout

To specify the amount of time in which the controller attempts to authenticate wireless clients using local Extensible Authentication Protocol (EAP) after any pair of configured RADIUS servers fails, use the **config local-auth active-timeout** command.

config local-auth active-timeout *timeout*

Syntax Description

<i>timeout</i>	Timeout measured in seconds. The range is from 1 to 3600.

Command Default

100 seconds.

Examples

This example shows how to specify the active timeout to authenticate wireless clients using EAP to 500 seconds:

```
> config local-auth active-timeout 500
```

Related Commands

- clear stats local-auth**
- config local-auth eap-profile**
- config local-auth method fast**
- config local-auth user-credentials**
- debug aaa local-auth**
- show local-auth certificates**
- show local-auth config**
- show local-auth statistics**

config local-auth eap-profile

To configure local Extensible Authentication Protocol (EAP) authentication profiles, use the **config local-auth eap-profile** command.

```
config local-auth eap-profile {[add | delete] profile_name | cert-issuer {cisco | vendor} | method method
local-cert {enable | disable} profile_name | method method client-cert {enable | disable} profile_name |
method method peer-verify ca-issuer {enable | disable} | method method peer-verify cn-verify {enable |
disable} | method method peer-verify date-valid {enable | disable}
```

Syntax Description

add	(Optional) Specifies that an EAP profile or method is being added.
delete	(Optional) Specifies that an EAP profile or method is being deleted.
<i>profile_name</i>	EAP profile name (up to 63 alphanumeric characters). Do not include spaces within a profile name.
cert-issuer	(For use with EAP-TLS, PEAP, or EAP-FAST with certificates) Specifies the issuer of the certificates that will be sent to the client. The supported certificate issuers are Cisco or a third-party vendor.
cisco	Specifies the Cisco certificate issuer.
vendor	Specifies the third-party vendor.
method	Configures an EAP profile method.
<i>method</i>	EAP profile method name. The supported methods are leap, fast, tls, and peap.
local-cert	(For use with EAP-FAST) Specifies whether the device certificate on the controller is required for authentication.
enable	Specifies that the parameter is enabled.
disable	Specifies that the parameter is disabled.
client-cert	(For use with EAP-FAST) Specifies whether wireless clients are required to send their device certificates to the controller in order to authenticate.
peer-verify	Configures the peer certificate verification options.
ca-issuer	(For use with EAP-TLS or EAP-FAST with certificates) Specifies whether the incoming certificate from the client is to be validated against the Certificate Authority (CA) certificates on the controller.

cn-verify	(For use with EAP-TLS or EAP-FAST with certificates) Specifies whether the common name (CN) in the incoming certificate is to be validated against the CA certificates' CN on the controller.
date-valid	(For use with EAP-TLS or EAP-FAST with certificates) Specifies whether the controller is to verify that the incoming device certificate is still valid and has not expired.

Command Default

None.

Examples

This example shows how to create a local EAP profile named FAST01:

```
> config local-auth eap-profile add FAST01
```

This example shows how to add the EAP-FAST method to a local EAP profile:

```
> config local-auth eap-profile method add fast FAST01
```

This example shows how to specify Cisco as the issuer of the certificates that will be sent to the client for an EAP-FAST profile:

```
> config local-auth eap-profile method fast cert-issuer cisco
```

This example shows how to specify that the incoming certificate from the client be validated against the CA certificates on the controller:

```
> config local-auth eap-profile method fast peer-verify ca-issuer enable
```

Related Commands

config local-auth active-timeout
config local-auth method fast
config local-auth user-credentials
debug aaa local-auth
show local-auth certificates
show local-auth config
show local-auth statistics

config local-auth method fast

To configure an EAP-FAST profile, use the **config local-auth method fast** command.

config local-auth method fast {anon-prov [enable | disable] | authority-id *auth_id* pac-ttl *days* | server-key *key_value*}

Syntax Description

anon-prov	Configures the controller to allow anonymous provisioning, which allows PACs to be sent automatically to clients that do not have one during Protected Access Credentials (PAC) provisioning.
enable	(Optional) Specifies that the parameter is enabled.
disable	(Optional) Specifies that the parameter is disabled.
authority-id	Configures the authority identifier of the local EAP-FAST server.
<i>auth_id</i>	Authority identifier of the local EAP-FAST server (2 to 32 hexadecimal digits).
pac-ttl	Configures the number of days for the Protected Access Credentials (PAC) to remain viable (also known as the time-to-live [TTL] value).
<i>days</i>	Time-to-live value (TTL) value (1 to 1000 days).
server-key	Configures the server key to encrypt or decrypt PACs.
<i>key_value</i>	Encryption key value (2 to 32 hexadecimal digits).

Command Default

None.

Examples

This example shows how to disable the controller to allow anonymous provisioning:

```
> config local-auth method fast anon-prov disable
```

This example shows how to configure the authority identifier 0125631177 of the local EAP-FAST server:

```
> config local-auth method fast authority-id 0125631177
```

This example shows how to configure the number of days to 10 for the PAC to remain viable:

```
> config local-auth method fast pac-ttl 10
```

Related Commands

clear stats local-auth
config local-auth eap-profile
config local-auth active-timeout

config local-auth user-credentials

debug aaa local-auth

show local-auth certificates

show local-auth config

show local-auth statistics

config local-auth user-credentials

To configure the local Extensible Authentication Protocol (EAP) authentication database search order for user credentials, use the **config local-auth user-credentials** command.

config local-auth user-credentials {local [ldap] | ldap [local] }

Syntax Description	local	Specifies that the local database is searched for the user credentials.
	ldap	(Optional) Specifies that the Lightweight Directory Access Protocol (LDAP) database is searched for the user credentials.

Command Default None.

Usage Guidelines The order of the specified database parameters indicate the database search order.

Examples This example shows how to specify the order in which the local EAP authentication database is searched:

```
> config local-auth user-credentials local lda
```

In the above example, the local database is searched first and then the LDAP database.

Related Commands

- clear stats local-auth
- config local-auth eap-profile
- config local-auth method fast
- config local-auth active-timeout
- debug aaa local-auth
- show local-auth certificates
- show local-auth config
- show local-auth statistics

config ipv6 acl

To create or delete an IPv6 acl on the Cisco wireless LAN controller, use the **config ipv6 acl** command.

```
config ipv6 acl {apply ipv6_acl_name | create ipv6_acl_name | delete ipv6_acl_name | rule {action rule_name
rule_index {permit | deny} | add rule_name rule_index | change index rule_name old_index new_index |
delete rule_name rule_index | destination address rule_name rule_index ip_address netmask | destination
port range rule_name rule_index start_port end_port | direction rule_name rule_index {in | out | any} |
dscp rule_name rule_index dscp | protocol rule_name rule_index protocol | source address rule_name
rule_index ip_address netmask | source port range rule_name rule_index start_port end_port | swap index
rule_name index_1 index_2}}
```

Syntax Description

apply	Applies an IPv6 ACL.
<i>ipv6_acl_name</i>	IPv6 ACL name that contains up to 32 alphanumeric characters.
create	Creates an IPv6 ACL.
delete	Deletes an IPv6 ACL.
rule	Configures the IPv6 ACL.
action	Configures whether to permit or deny access.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_index</i>	Rule index between 1 and 32.
permit	Permits the rule action.
deny	Denies the rule action.
add	Adds a new rule.
change	Changes a rule's index.
index	Specifies a rule index.
delete	Deletes a rule.
destination address	Configures a rule's destination IP address and netmask.
<i>ip_address</i>	IP address of the rule.
<i>netmask</i>	Netmask of the rule.
<i>start_port</i>	Start port number (between 0 and 65535).
<i>end_port</i>	End port number (between 0 and 65535).

direction	Configures a rule's direction to in, out, or any.
in	Configures a rule's direction to in.
out	Configures a rule's direction to out.
any	Configures a rule's direction to any.
dscp	Configures a rule's DSCP.
<i>dscp</i>	Number between 0 and 63, or any .
protocol	Configures a rule's DSCP.
<i>protocol</i>	Number between 0 and 255, or any .
source address	Configures a rule's source IP address and netmask.
source port range	Configures a rule's source port range.
swap	Swap's two rules' indices.
destination port range	Configure a rule's destination port range.

Command Default None.

Usage Guidelines For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.

Examples This example shows how to configure an IPv6 ACL to permit access:

```
> config ipv6 acl rule action lab1 4 permit
```

Related Commands `show ipv6 acl`

config netuser add

To add a guest user on a WLAN or wired guest LAN to the local user database on the controller, use the **config netuser add** command.

config netuser add *username password {wlan wlan_id | guestlan guestlan_id} userType guest lifetime lifetime description description*

Syntax Description

<i>username</i>	Guest username. The username can be up to 50 alphanumeric characters.
<i>password</i>	User password. The password can be up to 24 alphanumeric characters.
wlan	Specifies the wireless LAN identifier to associate with or zero for any wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier assigned to the user. A zero value associates the user with any wireless LAN.
guestlan	Specifies the guest LAN identifier to associate with or zero for any wireless LAN.
<i>guestlan_id</i>	Guest LAN ID.
userType	Specifies the user type.
guest	Specifies the guest for the guest user.
lifetime	Specifies the lifetime.
<i>lifetime</i>	Lifetime value (60 to 259200 or 0) in seconds for the guest user. Note A value of 0 indicates an unlimited lifetime.
<i>description</i>	Short description of user. The description can be up to 32 characters enclosed in double-quotes.

Command Default

None.

Usage Guidelines

Local network usernames must be unique because they are stored in the same database.

Examples

This example shows how to add a permanent username Jane to the wireless network for 1 hour:

```
> config netuser add jane able2 1 wlan_id 1 userType permanent
```

This example shows how to add a guest username George to the wireless network for 1 hour:

```
> config netuser add george able1 guestlan 1 3600
```

Related Commands`show netuser``config netuser delete`

config netuser delete

To delete an existing user from the local network, use the **config netuser delete** command.

config netuser delete *username*

Syntax Description

<i>username</i>	Network username. The username can be up to 24 alphanumeric characters.

Command Default

None.

Usage Guidelines

Local network usernames must be unique because they are stored in the same database.

Examples

This example shows how to delete an existing username named able1 from the network:

```
> config netuser delete able1
Deleted user able1
```

Related Commands

show netuser

config netuser description

To add a description to an existing net user, use the **config netuser description** command.

config netuser description *username description*

Syntax Description

<i>username</i>	Network username. The username can contain up to 24 alphanumeric characters.
<i>description</i>	(Optional) User description. The description can be up to 32 alphanumeric characters enclosed in double quotes.

Command Default

None.

Examples

This example shows how to add a user description "HQ1 Contact" to an existing network user named able 1:

```
> config netuser description able1 "HQ1 Contact"
```

Related Commands

show netuser

config network bridging-shared-secret

To configure the bridging shared secret, use the **config network bridging-shared-secret** command.

config network bridging-shared-secret *shared_secret*

Syntax Description

<i>shared_secret</i>	Bridging shared secret string. The string can contain up to 10 bytes.

Command Default

Enabled.

Usage Guidelines

This command creates a secret that encrypts backhaul user data for the mesh access points that connect to the switch.

The zero-touch configuration must be enabled for this command to work.

Examples

This example shows how to configure the bridging shared secret string “shhh1”:

```
> config network bridging-shared-secret shhh1
```

Related Commands

show network summary

config network web-auth captive-bypass

To configure the controller to support bypass of captive portals at the network level, use the **config network web-auth captive-bypass** command.

config network web-auth captive-bypass {enable | disable}

Syntax Description	enable	Allows the controller to support bypass of captive portals.
	disable	Disallows the controller to support bypass of captive portals.

Command Default None.

Examples This example shows how to configure the controller to support bypass of captive portals:

```
> config network web-auth captive-bypass enable
```

Related Commands **show network summary**
 config network web-auth cmcc-support

config network web-auth port

To configure an additional port to be redirected for web authentication at the network level, use the **config network web-auth port** command.

config network web-auth port *port*

Syntax Description

<i>port</i>	Port number. The valid range is from 0 to 65535.

Command Default

None.

Examples

This example shows how to configure an additional port number 1200 to be redirected for web authentication:

```
> config network web-auth port 1200
```

Related Commands

show network summary

config network web-auth proxy-redirect

To configure proxy redirect support for web authentication clients, use the **config network web-auth proxy-redirect** command.

config network web-auth proxy-redirect {enable | disable}

Syntax Description	enable	Allows proxy redirect support for web authentication clients.
	disable	Disallows proxy redirect support for web authentication clients.

Command Default None.

Examples This example shows how to enable proxy redirect support for web authentication clients:

```
> config network web-auth proxy-redirect enable
```

Related Commands **show network summary**

config network web-auth secureweb

To configure the secure web (https) authentication for clients, use the **config network web-auth secureweb** command.

config network web-auth secureweb {enable | disable}

Syntax Description

enable	Allows secure web (https) authentication for clients.
disable	Disallows secure web (https) authentication for clients. Enables http web authentication for clients.

Command Default

Enabled.

Examples

This example shows how to enable the secure web (https) authentication for clients:

```
> config network web-auth secureweb enable
```

Related Commands

show network summary

config network webmode

To enable or disable the web mode, use the **config network webmode** command.

config network webmode {enable | disable}

Syntax Description

enable	Enables the web interface.
disable	Disables the web interface.

Command Default

Enabled.

Examples

This example shows how to disable the web interface mode:

```
> config network webmode disable
```

Related Commands

show network summary

config network web-auth

To configure the network-level web authentication options, use the **config network web-auth** command.

config network web-auth {**port** *port-number*} | {**proxy-redirect** {**enable** | **disable**}}

Syntax Description

port	Configures additional ports for web authentication redirection.
<i>port-number</i>	Port number (between 0 and 65535).
proxy-redirect	Configures proxy redirect support for web authentication clients.
enable	Enables proxy redirect support for web authentication clients. Note Web-auth proxy redirection will be enabled for ports 80, 8080, and 3128, along with user defined port 345.
disable	Disables proxy redirect support for web authentication clients.

Command Default

Disabled.

Usage Guidelines

You must reset the system for the configuration to take effect.

Examples

This example shows how to enable proxy redirect support for web authentication clients:

```
> config network web-auth proxy-redirect enable
```

Related Commands

show network summary
show run-config
config qos protocol-type

config radius acct

To add, delete, or configure settings for a RADIUS accounting server for the Cisco wireless LAN controller, use the **config radius acct** command.

config radius acct [{enable | disable | delete} *index*] | **add** *index server_ip port* {ascii | hex} *secret*

Syntax Description

enable	Enables a RADIUS accounting server.
disable	Disables a RADIUS accounting server.
delete	Deletes a RADIUS accounting server.
<i>index</i>	RADIUS server index. The controller begins the search with 1.
add	Adds a RADIUS accounting server.
<i>server_ip</i>	IP address of RADIUS server.
<i>port</i>	RADIUS server's UDP port number for the interface protocols.
ascii	Specifies the RADIUS server's secret type: ascii .
hex	Specifies the RADIUS server's secret type: hex .
<i>secret</i>	RADIUS server's secret.

Command Default

When adding a RADIUS server, the port number defaults to 1813 and the state is **enabled**.

Examples

This example shows how to configure a priority 1 RADIUS accounting server at *10.10.10.10* using port *1813* with a login password of *admin*:

```
> config radius acct add 1 10.10.10.10 1813 ascii admin
```

Related Commands

show radius acct statistics

config radius acct ipsec authentication

To configure IPsec authentication for the Cisco wireless LAN controller, use the **config radius acct ipsec authentication** command.

config radius acct ipsec authentication {**hmac-md5** | **hmac-sha1**} *index*

Syntax Description

hmac-md5	Enables IPsec HMAC-MD5 authentication.
hmac-sha1	Enables IPsec HMAC-SHA1 authentication.
<i>index</i>	RADIUS server index.

Command Default

None.

Examples

This example shows how to configure the IPsec hmac-md5 authentication service on the RADIUS accounting server index 1:

```
> config radius acct ipsec authentication hmac-md5 1
```

Related Commands

show radius acct statistics

config radius acct ipsec disable

To disable IPsec support for an accounting server for the Cisco wireless LAN controller, use the **config radius acct ipsec disable** command.

config radius acct ipsec disable *index*

Syntax Description	
	<i>index</i> RADIUS server index.

Command Default	None.

Examples	This example shows how to disable the IPsec support for RADIUS accounting server index 1:

```
> config radius acct ipsec disable 1
```

Related Commands	show radius acct statistics

config radius acct ipsec enable

To enable IPsec support for an accounting server for the Cisco wireless LAN controller, use the **config radius acct ipsec enable** command.

config radius acct ipsec enable *index*

Syntax Description

<i>index</i>	RADIUS server index.

Command Default

None.

Examples

This example shows how to enable the IPsec support for RADIUS accounting server index 1:

```
> config radius acct ipsec enable 1
```

Related Commands

show radius acct statistics

config radius acct ipsec encryption

To configure IPsec encryption for an accounting server for the Cisco wireless LAN controller, use the **config radius acct ipsec encryption** command.

config radius acct ipsec encryption {3des | aes | des} *index*

Syntax Description

3des	Enables IPsec 3DES encryption.
aes	Enables IPsec AES encryption.
des	Enables IPsec DES encryption.
<i>index</i>	RADIUS server index value of between 1 and 17.

Command Default

None.

Examples

This example shows how to configure the IPsec 3DES encryption for RADIUS server index value 3:

```
> config radius acct ipsec encryption 3des 3
```

Related Commands

show radius acct statistics
show radius summary

config radius acct ipsec ike

To configure Internet Key Exchange (IKE) for the Cisco WLC, use the **config radius acct ipsec ike** command.

config radius acct ipsec ike **dh-group** {group-1 | group-2 | group-5} | **lifetime** *seconds* | **phase1** {aggressive | main} } *index*

Syntax Description

dh-group	Specifies the Dixie-Hellman (DH) group.
group-1	Configures the DH Group 1 (768 bits).
group-2	Configures the DH Group 2 (1024 bits).
group-5	Configures the DH Group 5 (1024 bits).
lifetime	Configures the IKE lifetime.
<i>seconds</i>	IKE lifetime in seconds.
phase1	Configures the IKE phase1 node.
aggressive	Enables the aggressive mode.
main	Enables the main mode.
<i>index</i>	RADIUS server index.

Command Default

None.

Examples

This example shows how to configure an IKE lifetime of 23 seconds for RADIUS server index 1:

```
> config radius acct ipsec ike lifetime 23 1
```

Related Commands

show radius acct statistics

config radius acct mac-delimiter

To specify the delimiter to be used in the MAC addresses that are sent to the RADIUS accounting server, use the **config radius acct mac-delimiter** command.

config radius acct mac-delimiter {colon | hyphen | single-hyphen | none}

Syntax Description		
colon		Sets the delimiter to a colon (for example, xx:xx:xx:xx:xx:xx).
hyphen		Sets the delimiter to a hyphen (for example, xx-xx-xx-xx-xx-xx).
single-hyphen		Sets the delimiter to a single hyphen (for example, xxxxxx-xxxxxx).
none		Disables the delimiter (for example, xxxxxxxxxxxx).

Command Default The default delimiter is a hyphen.

Examples This example shows how to set the delimiter hyphen to be used in the MAC addresses that are sent to the RADIUS accounting server for the network users:

```
> config radius acct mac-delimiter hyphen
```

Related Commands **show radius acct statistics**

config radius acct network

To configure a default RADIUS server for network users, use the **config radius acct network** command.

config radius acct network *index* {**enable** | **disable**}

Syntax Description

<i>index</i>	RADIUS server index.
enable	Enables the server as a network user's default RADIUS server.
disable	Disables the server as a network user's default RADIUS server.

Command Default

None.

Examples

This example shows how to configure a default RADIUS accounting server for the network users with RADIUS server index 1:

```
> config radius acct network 1 enable
```

Related Commands

show radius acct statistics

config radius acct retransmit-timeout

To change the default transmission timeout for a RADIUS accounting server for the Cisco wireless LAN controller, use the **config radius acct retransmit-timeout** command.

config radius acct retransmit-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Number of seconds (from 2 to 30) between retransmissions.

Command Default

None.

Examples

This example shows how to configure retransmission timeout value 5 seconds between the retransmission:

```
> config radius acct retransmit-timeout 5
```

Related Commands

show radius acct statistics

config radius auth

To add, delete, or configure settings for a RADIUS authentication server for the Cisco wireless LAN controller, use the **config radius auth** command.

config radius auth [{enable | disable | delete} *index* | add *index server_ip port* {ascii | hex} *secret*]

Syntax Description

enable	Enables a RADIUS authentication server.
disable	Disables a RADIUS authentication server.
delete	Deletes a RADIUS authentication server.
<i>index</i>	RADIUS server index. The controller begins the search with 1.
add	Adds a RADIUS authentication server. See the “Defaults” section.
<i>server_ip</i>	IP address of the RADIUS server.
<i>port</i>	RADIUS server’s UDP port number for the interface protocols.
ascii	Specifies RADIUS server’s secret type: ascii .
hex	Specifies RADIUS server’s secret type: hex .
<i>secret</i>	RADIUS server’s secret.

Command Default

When adding a RADIUS server, the port number defaults to 1813 and the state is **enabled**.

Examples

This example shows how to configure a priority 1 RADIUS authentication server at 10.10.10.10 using port 1812 with a login password of *admin*:

```
> config radius auth add 1 10.10.10.10 1812 ascii admin
```

Related Commands

show radius auth statistics

config radius auth IPsec authentication

To configure IPsec support for an authentication server for the Cisco wireless LAN controller, use the **config radius auth IPsec authentication** command.

config radius auth IPsec authentication {hmac-md5 | hmac-sha1} index

Syntax Description	hmac-md5	Enables IPsec HMAC-MD5 authentication.
	hmac-sha1	Enables IPsec HMAC-SHA1 authentication.
	index	RADIUS server index.

Command Default None.

Examples This example shows how to configure the IPsec hmac-md5 support for RADIUS authentication server index 1:

```
> config radius auth IPsec authentication hmac-md5 1
```

Related Commands show radius acct statistics

config radius auth IPsec disable

To disable IPsec support for an authentication server for the Cisco wireless LAN controller, use the **config radius auth IPsec disable** command.

config radius auth IPsec {enable | disable} index

Syntax Description

enable	Enables the IPsec support for an authentication server.
disable	Disables the IPsec support for an authentication server.
<i>index</i>	RADIUS server index.

Command Default

None.

Examples

This example shows how to enable the IPsec support for RADIUS authentication server index 1:

```
> config radius auth IPsec enable 1
```

This example shows how to disable the IPsec support for RADIUS authentication server index 1:

```
> config radius auth IPsec disable 1
```

Related Commands

show radius acct statistics

config radius auth IPsec encryption

To configure IPsec encryption support for an authentication server for the Cisco wireless LAN controller, use the **config radius auth IPsec encryption** command.

config radius auth IPsec encryption {3des | aes | des} *index*

Syntax Description

3des	Enables the IPsec 3DES encryption.
aes	Enables the IPsec AES encryption.
des	Enables the IPsec DES encryption.
index	RADIUS server index.

Command Default

None.

Examples

This example shows how to configure IPsec 3des encryption RADIUS authentication server index 3:

```
> config radius auth IPsec encryption 3des 3
```

Related Commands

show radius acct statistics

config radius auth IPsec ike

To configure Internet Key Exchange (IKE) for the Cisco wireless LAN controller, use the **config radius auth IPsec ike** command.

config radius auth IPsec ike {dh-group {group-1 | group-2 | group-5} | lifetime *seconds* | phase1 {aggressive | main}} *index*

Syntax Description

dh-group	Configures the IKE Diffie-Hellman group.
group-1	Configures the DH Group 1 (768 bits).
group-2	Configures the DH Group 2 (1024 bits).
group-5	Configures the DH Group 2 (1024 bits).
lifetime	Configures the IKE lifetime.
<i>seconds</i>	Lifetime in seconds.
phase1	Configures the IKE phase1 mode.
aggressive	Enables the aggressive mode.
main	Enables the main mode.
<i>index</i>	RADIUS server index.

Command Default

None.

Examples

This example shows how to configure IKE lifetime of 23 seconds for RADIUS authentication server index 1:

```
> config radius auth IPsec ike lifetime 23 1
```

Related Commands

show radius acct statistics

config radius auth keywrap

To enable and configure Advanced Encryption Standard (AES) key wrap, which makes the shared secret between the controller and the RADIUS server more secure, use the **config radius auth keywrap** command.

config radius auth keywrap {enable | disable | add {ascii | hex} *kek mack index*}

Syntax Description		
enable		Enables AES key wrap.
disable		Disables AES key wrap.
add		Configures AES key wrap attributes.
ascii		Configures key wrap in an ASCII format.
hex		Configures key wrap in a hexadecimal format.
<i>kek</i>		16-byte Key Encryption Key (KEK).
<i>mack</i>		20-byte Message Authentication Code Key (MACK).
<i>index</i>		Index of the RADIUS authentication server on which to configure the AES key wrap.

Command Default None.

Examples This example shows how to enable the AES key wrap for a RADIUS authentication server:

```
> config radius auth keywrap enable
```

Related Commands **show radius auth statistics**

config radius auth mac-delimiter

To specify a delimiter to be used in the MAC addresses that are sent to the RADIUS authentication server, use the **config radius auth mac-delimiter** command.

config radius auth mac-delimiter {colon | hyphen | single-hyphen | none}

Syntax Description

colon	Sets a delimiter to a colon (for example, xx:xx:xx:xx:xx:xx).
hyphen	Sets a delimiter to a hyphen (for example, xx-xx-xx-xx-xx-xx).
single-hyphen	Sets a delimiter to a single hyphen (for example, xxxxxx-xxxxxx).
none	Disables the delimiter (for example, xxxxxxxxxxxx).

Command Default

The default delimiter is a hyphen.

Examples

This example shows how to specify a delimiter hyphen to be used for a RADIUS authentication server:

```
> config radius auth mac-delimiter hyphen
```

Related Commands

show radius auth statistics

config radius auth management

To configure a default RADIUS server for management users, use the **config radius auth management** command.

config radius auth management *index* {**enable** | **disable**}

Syntax Description

<i>index</i>	RADIUS server index.
enable	Enables the server as a management user's default RADIUS server.
disable	Disables the server as a management user's default RADIUS server.

Command Default

None.

Examples

This example shows how to configure a RADIUS server for management users:

```
> config radius auth management 1 enable
```

Related Commands

show radius acct statistics
config radius acct network
config radius auth mgmt-retransmit-timeout

config radius auth mgmt-retransmit-timeout

To configure a default RADIUS server retransmission timeout for management users, use the **config radius auth mgmt-retransmit-timeout** command.

config radius auth mgmt-retransmit-timeout *index retransmit-timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>retransmit-timeout</i>	Timeout value. The range is from 1 to 30 seconds.

Command Default

None.

Examples

This example shows how to configure a default RADIUS server retransmission timeout for management users:

```
> config radius auth mgmt-retransmit-timeout 1 10
```

Related Commands

config radius auth management

config radius auth network

To configure a default RADIUS server for network users, use the **config radius auth network** command.

config radius auth network *index* {**enable** | **disable**}

Syntax Description

<i>index</i>	RADIUS server index.
enable	Enables the server as a network user default RADIUS server.
disable	Disables the server as a network user default RADIUS server.

Command Default

None.

Examples

This example shows how to configure a default RADIUS server for network users:

```
> config radius auth network 1 enable
```

Related Commands

show radius acct statistics
config radius acct network

config radius auth retransmit-timeout

To change a default transmission timeout for a RADIUS authentication server for the Cisco wireless LAN controller, use the **config radius auth retransmit-timeout** command.

config radius auth retransmit-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Number of seconds (from 2 to 30) between retransmissions.

Command Default

None.

Examples

This example shows how to configure a retransmission timeout of 5 seconds for a RADIUS authentication server:

```
> config radius auth retransmit-timeout 5
```

Related Commands

show radius auth statistics

config radius auth rfc3576

To configure RADIUS RFC-3576 support for the authentication server for the Cisco wireless LAN controller, use the **config radius auth rfc3576** command.

config radius auth rfc3576 {enable | disable} *index*

Syntax Description	enable	Enables RFC-3576 support for an authentication server.
	disable	Disables RFC-3576 support for an authentication server.
	<i>index</i>	RADIUS server index.

Command Default None.

Usage Guidelines RFC 3576, which is an extension to the RADIUS protocol, allows dynamic changes to a user session. RFC 3576 includes support for disconnecting users and changing authorizations applicable to a user session. Disconnect messages cause a user session to be terminated immediately; CoA messages modify session authorization attributes such as data filters.

Examples This example shows how to enable the RADIUS RFC-3576 support for a RADIUS authentication server:

```
> config radius auth rfc3576 enable 2
```

Related Commands

- show radius auth statistics
- show radius summary
- show radius rfc3576

config radius auth server-timeout

To configure a retransmission timeout value for a RADIUS accounting server, use the **config radius auth server-timeout** command.

config radius auth server-timeout *index timeout*

Syntax Description

<i>index</i>	RADIUS server index.
<i>timeout</i>	Timeout value. The range is from 2 to 30 seconds.

Command Default

The default timeout is 2 seconds.

Examples

This example shows how to configure a server timeout value of 2 seconds for RADIUS authentication server index 10:

```
> config radius auth server-timeout 2 10
```

Related Commands

show radius auth statistics
show radius summary

config radius aggressive-failover disabled

To configure the controller to mark a RADIUS server as down (not responding) after the server does not reply to three consecutive clients, use the **config radius aggressive-failover disabled** command.

config radius aggressive-failover disabled

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to configure the controller to mark a RADIUS server as down:

```
> config radius aggressive-failover disabled
```

Related Commands	show radius summary

config radius backward compatibility

To configure RADIUS backward compatibility for the Cisco wireless LAN controller, use the **config radius backward compatibility** command.

config radius backward compatibility {enable | disable}

Syntax Description

enable	Enables RADIUS vendor ID backward compatibility.
disable	Disables RADIUS vendor ID backward compatibility.

Command Default

Enabled.

Examples

This example shows how to enable the RADIUS backward compatibility settings:

```
> config radius backward compatibility disable
```

Related Commands

show radius summary

config radius callStationIdCase

To configure callStationIdCase information sent in RADIUS messages for the Cisco WLC, use the **config radius callStationIdCase** command.

```
config radius callStationIdCase {legacy | lower | upper}
```

Syntax Description	legacy	Configures Call Station IDs for Layer 2 authentication to RADIUS in uppercase.
	lower	Configures all Call Station IDs to RADIUS in lowercase.
	upper	Configures all Call Station IDs to RADIUS in uppercase.

Command Default	Enabled.

Examples	This example shows how to send the call station ID in lowercase:

```
> config radius callStationIdCase lower
```

Related Commands	show radius summary

config radius callStationIdType

To configure the callStationIdType information sent in RADIUS messages for the Cisco wireless LAN controller, use the **config radius callStationIdType** command.

config radius callStationIdType {ipaddr | macaddr | ap-macaddr | ap-macaddr-ssid | ap-group-name | flex-group-name | ap-name | ap-name-ssid | ap-location| vlan-id}

Syntax Description

ipaddr	Configures the Call Station ID type to use the IP address (only Layer 3).
macaddr	Configures the Call Station ID type to use the system's MAC address (Layers 2 and 3).
ap-macaddr-only	Configures the Call Station ID type to use the access point's MAC address (Layers 2 and 3).
ap-macaddr-ssid	Configures the Call Station ID type to use the access point's MAC address (Layers 2 and 3) in the format <i>AP MAC address:SSID</i> .
ap-group-name	Configures the Call Station ID type to use the AP group name. If the AP is not part of any AP group, default-group is taken as the AP group name.
flex-group-name	Configures the Call Station ID type to use the FlexConnect group name. If the FlexConnect AP is not part of any FlexConnect group, the system MAC address is taken as the Call Station ID.
ap-name	Configures the Call Station ID type to use the access point's name.
ap-name-ssid	Configures the Call Station ID type to use the access point's name in the format <i>AP name:SSID</i>
ap-location	Configures the Call Station ID type to use the access point's location.
vlan-id	Configures the Call Station ID type to use the system's VLAN-ID.

Command Default

The MAC address of the system.

Usage Guidelines

The controller sends the Called Station ID attribute to the RADIUS server in all authentication and accounting packets. The Called Station ID attribute can be used to classify users to different groups based on the attribute value. The command is applicable only for the Called Station and not for the Calling Station.

You cannot send only the SSID as the Called-Station-ID, you can only combine the SSID with either the access point MAC address or the access point name.

Examples

This example shows how to configure the call station ID type to use the IP address:

```
> config radius callStationIdType ipAddr
```

This example shows how to configure the call station ID type to use the system's MAC address:

```
> config radius callStationIdType macAddr
```

This example shows how to configure the call station ID type to use the access point's MAC address:

```
> config radius callStationIdType ap-macAddr
```

Related Commands

show radius summary

config radius fallback-test

To configure the RADIUS server fallback behavior, use the **config radius fallback-test** command.

config radius fallback-test mode {**off** | **passive** | **active**} [**username** *username*] [**interval** *interval*]

Syntax Description

mode	Specifies the mode.
off	Disables RADIUS server fallback.
passive	Causes the controller to revert to a preferable server (with a lower server index) from the available backup servers without using extraneous probe messages. The controller ignores all inactive servers for a time period and retries later when a RADIUS message needs to be sent.
active	Causes the controller to revert to a preferable server (with a lower server index) from the available backup servers by using RADIUS probe messages to proactively determine whether a server that has been marked inactive is back online. The controller ignores all inactive servers for all active RADIUS requests.
username	Specifies the username.
<i>username</i>	Username. The username can be up to 16 alphanumeric characters.
interval	Specifies the probe interval value.
<i>interval</i>	Probe interval. The range is 180 to 3600.

Command Default

The default probe interval is 300.

Examples

This example shows how to disable the RADIUS accounting server fallback behavior:

```
> config radius fallback-test mode off
```

This example shows how to configure the controller to revert to a preferable server from the available backup servers without using the extraneous probe messages:

```
> config radius fallback-test mode passive
```

This example shows how to configure the controller to revert to a preferable server from the available backup servers by using RADIUS probe messages:

```
> config radius fallback-test mode active
```

Related Commands

config advanced probe filter

config advanced probe limit

show advanced probe

show radius acct statistics

config rogue adhoc

To globally or individually configure the status of an Independent Basic Service Set (IBSS or *ad-hoc*) rogue access point, use the **config rogue adhoc** command.

config rogue adhoc {**enable** | **disable** | **external** *rogue_MAC* | **alert** {*rogue_MAC* | **all**} | **auto-contain** [*monitor_ap*] | **contain** *rogue_MAC* *1234_aps*} }

config rogue adhoc {**delete** {**all** | **mac-address** *mac-address*} | **classify** {**friendly state** {**external** | **internal**} *mac-address* | **malicious state** {**alert** | **contain**} *mac-address* | **unclassified state** {**alert** | **contain**} *mac-address*}

Syntax Description

enable	Globally enables detection and reporting of ad-hoc rogues.
disable	Globally disables detection and reporting of ad-hoc rogues.
external	Configure external state on the rogue access point that is outside the network and poses no threat to WLAN security. The controller acknowledges the presence of this rogue access point.
<i>rogue_MAC</i>	MAC address of the ad-hoc rogue access point.
alert	Generates an SMNP trap upon detection of the ad-hoc rogue, and generates an immediate alert to the system administrator for further action.
all	Enables alerts for all ad-hoc rogue access points.
auto-contain	Contains all wired ad-hoc rogues detected by the controller.
<i>monitor_ap</i>	(Optional) IP address of the ad-hoc rogue access point.
contain	Contains the offending device so that its signals no longer interfere with authorized clients.
<i>1234_aps</i>	Maximum number of Cisco access points assigned to actively contain the ad-hoc rogue access point (1 through 4, inclusive).
delete	Deletes ad-hoc rogue access points.
all	Deletes all ad-hoc rogue access points.
mac-address	Deletes ad-hoc rogue access point with the specified MAC address.
<i>mac-address</i>	MAC address of the ad-hoc rogue access point.
classify	Configures ad-hoc rogue access point classification.
friendly state	Classifies ad-hoc rogue access points as friendly.

internal	Configures alert state on rogue access point that is inside the network and poses no threat to WLAN security. The controller trusts this rogue access point.
malicious state	Classifies ad-hoc rogue access points as malicious.
alert	Configures alert state on the rogue access point that is not in the neighbor list or in the user configured friendly MAC list. The controller forwards an immediate alert to the system administrator for further action.
contain	Configures contain state on the rogue access point. Controller contains the offending device so that its signals no longer interfere with authorized clients.
unclassified state	Classifies ad-hoc rogue access points as unclassified.

Command Default

The default for this command is **enabled** and is set to **alert**. The default for auto-containment is **disabled**.

Usage Guidelines

The controller continuously monitors all nearby access points and automatically discovers and collects information on rogue access points and clients. When the controller discovers a rogue access point, it uses RLDP to determine if the rogue is attached to your wired network.



Note

RLDP is not supported for use with Cisco autonomous rogue access points. These access points drop the DHCP Discover request sent by the RLDP client. Also, RLDP is not supported if the rogue access point channel requires dynamic frequency selection (DFS).

When you enter any of the containment commands, the following warning appears:

```
Using this feature may have legal consequences. Do you want to continue? (y/n) :
```

The 2.4- and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party's network could have legal consequences.

Enter the **auto-contain** command with the *monitor_ap* argument to monitor the rogue access point without containing it. Enter the **auto-contain** command without the optional *monitor_ap* to automatically contain all wired ad-hoc rogues detected by the controller.

Examples

This example shows how to enable the detection and reporting of ad-hoc rogues:

```
> config rogue adhoc enable
```

This example shows how to enable alerts for all ad-hoc rogue access points:

```
> config rogue adhoc alert all
```

This example shows how to classify an ad-hoc rogue access point as friendly and configure external state on it:

```
> config rogue adhoc classify friendly state internal 11:11:11:11:11:11
```

Related Commands

config rogue auto-contain level

show rogue ignore-list

show rogue rule detailed

show rogue rule summary

config rogue ap classify

To classify the status of a rogue access point, use the **config rogue ap classify** command.

```
config rogue ap classify {friendly state {internal | external} ap_mac }
```

```
config rogue ap classify {malicious | unclassified} state {alert | contain} ap_mac
```

Syntax Description

friendly	Classifies a rogue access point as friendly.
state	Specifies a response to classification.
internal	Configures the controller to trust this rogue access point.
external	Configures the controller to acknowledge the presence of this access point.
<i>ap_mac</i>	MAC address of the rogue access point.
malicious	Classifies a rogue access point as potentially malicious.
unclassified	Classifies a rogue access point as unknown.
alert	Configures the controller to forward an immediate alert to the system administrator for further action.
contain	Configures the controller to contain the offending device so that its signals no longer interfere with authorized clients.

Command Default

These commands are disabled by default. Therefore, all unknown access points are categorized as **unclassified** by default.

Usage Guidelines

A rogue access point cannot be moved to the unclassified class if its current state is contain.

When you enter any of the containment commands, the following warning appears: "Using this feature may have legal consequences. Do you want to continue?" The 2.4- and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party's network could have legal consequences.

Examples

This example shows how to classify a rogue access point as friendly and can be trusted:

```
> config rogue ap classify friendly state internal 11:11:11:11:11:11
```

This example shows how to classify a rogue access point as malicious and to send an alert:

```
> config rogue ap classify malicious state alert 11:11:11:11:11:11
```

This example shows how to classify a rogue access point as unclassified and to contain it:

```
> config rogue ap classify unclassified state contain 11:11:11:11:11:11
```

Related Commands

- config rogue adhoc**
- config rogue ap friendly**
- config rogue ap rldp**
- config rogue ap ssid**
- config rogue ap timeout**
- config rogue ap valid-client**
- config rogue client**
- config trapflags rogueap**
- show rogue ap clients**
- show rogue ap detailed**
- show rogue ap summary**
- show rogue ap friendly summary**
- show rogue ap malicious summary**
- show rogue ap unclassified summary**
- show rogue client detailed**
- show rogue client summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

config rogue ap friendly

To add a new friendly access point entry to the friendly MAC address list, or delete an existing friendly access point entry from the list, use the **config rogue ap friendly** command.

config rogue ap friendly {add | delete} *ap_mac*

Syntax Description

add	Adds this rogue access point from the friendly MAC address list.
delete	Deletes this rogue access point from the friendly MAC address list.
<i>ap_mac</i>	MAC address of the rogue access point that you want to add or delete.

Command Default

None

Examples

The following example shows how to add a new friendly access point with MAC address 11:11:11:11:11:11 to the friendly MAC address list.

```
Device > config rogue ap friendly add 11:11:11:11:11:11
```

Related Commands

config rogue adhoc
config rogue ap classify
config rogue ap rldp
config rogue ap ssid
config rogue ap timeout
config rogue ap valid-client
config rogue client
config trapflags rogueap
show rogue ap clients
show rogue ap detailed
show rogue ap summary
show rogue ap friendly summary
show rogue ap malicious summary
show rogue ap unclassified summary
show rogue client detailed
show rogue client summary
show rogue ignore-list

show rogue rule detailed

show rogue rule summary

config rogue ap rldp

To enable, disable, or initiate the Rogue Location Discovery Protocol (RLDP), use the **config rogue ap rldp** command.

config rogue ap rldp enable {**alarm-only** | **auto-contain**} [*monitor_ap_only*]

config rogue ap rldp initiate *rogue_mac_address*

config rogue ap rldp disable

Syntax Description

alarm-only	When entered without the optional argument <i>monitor_ap_only</i> , enables RLDP on all access points.
auto-contain	When entered without the optional argument <i>monitor_ap_only</i> , automatically contains all rogue access points.
<i>monitor_ap_only</i>	(Optional) RLDP is enabled (when used with alarm-only keyword), or automatically contained (when used with auto-contain keyword) is enabled only on the designated monitor access point.
initiate	Initiates RLDP on a specific rogue access point.
<i>rogue_mac_address</i>	MAC address of specific rogue access point.
disable	Disables RLDP on all access points.

Command Default

None.

Usage Guidelines

When you enter any of the containment commands, the following warning appears: "Using this feature may have legal consequences. Do you want to continue?" The 2.4- and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party's network could have legal consequences.

Examples

This example shows how to enable RLDP on all access points:

```
> config rogue ap rldp enable alarm-only
```

This example shows how to enable RLDP on monitor-mode access point ap_1:

```
> config rogue ap rldp enable alarm-only ap_1
```

This example shows how to start RLDP on the rogue access point with MAC address 123.456.789.000:

```
> config rogue ap rldp initiate 123.456.789.000
```

This example shows how to disable RLDP on all access points:

```
> config rogue ap rldp disable
```

Related Commands

- config rogue adhoc**
- config rogue ap classify**
- config rogue ap friendly**
- config rogue ap ssid**
- config rogue ap timeout**
- config rogue ap valid-client**
- config rogue client**
- config trapflags rogueap**
- show rogue ap clients**
- show rogue ap detailed**
- show rogue ap summary**
- show rogue ap friendly summary**
- show rogue ap malicious summary**
- show rogue ap unclassified summary**
- show rogue client detailed**
- show rogue client summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

config rogue ap ssid

To generate an alarm only, or to automatically contain a rogue access point that is advertising your network's service set identifier (SSID), use the **config rogue ap ssid** command.

config rogue ap ssid {alarm | auto-contain}

Syntax Description

alarm	Generates only an alarm when a rogue access point is discovered to be advertising your network's SSID.
auto-contain	Automatically contains the rogue access point that is advertising your network's SSID.

Command Default

None.

Usage Guidelines

When you enter any of the containment commands, the following warning appears: "Using this feature may have legal consequences. Do you want to continue?" The 2.4- and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party's network could have legal consequences.

Examples

This example shows how to automatically contain a rogue access point that is advertising your network's SSID:

```
> config rogue ap ssid auto-contain
```

Related Commands

config rogue adhoc
config rogue ap classify
config rogue ap friendly
config rogue ap rldp
config rogue ap timeout
config rogue ap valid-client
config rogue client
config trapflags rogueap
show rogue ap clients
show rogue ap detailed
show rogue ap summary
show rogue ap friendly summary
show rogue ap malicious summary

show rogue ap unclassified summary

show rogue client detailed

show rogue client summary

show rogue ignore-list

show rogue rule detailed

show rogue rule summary

config rogue ap timeout

To specify the number of seconds after which the rogue access point and client entries expire and are removed from the list, use the **config rogue ap timeout** command.

config rogue ap timeout *seconds*

Syntax Description	<i>seconds</i>	Value of 240 to 3600 seconds (inclusive), with a default value of 1200 seconds.

Command Default	1200 seconds.

Examples	This example shows how to set an expiration time for entries in the rogue access point and client list to 2400 seconds:

```
> config rogue ap timeout 2400
```

Related Commands	config rogue ap classify config rogue ap friendly config rogue ap rldp config rogue ap ssid config rogue rule config trapflags rogueap show rogue ap clients show rogue ap detailed show rogue ap summary show rogue ap friendly summary show rogue ap malicious summary show rogue ap unclassified summary show rogue ignore-list show rogue rule detailed show rogue rule summary

config rogue auto-contain level

To configure rogue the auto-containment level, use the **config rogue auto-contain level** command.

config rogue auto-contain level *level* [**monitor_ap_only**]

Syntax Description

<i>level</i>	Rogue auto-containment level in the range of 1 to 4.
Note	Up to four APs can be used to auto-contain when a rogue AP is moved to contained state through any of the auto-containment policies.
monitor_ap_only	(Optional) Configures auto-containment using only monitor AP mode.

Command Default

The default auto-containment level is 1.

Usage Guidelines

The controller continuously monitors all nearby access points and automatically discovers and collects information on rogue access points and clients. When the controller discovers a rogue access point, it uses any of the configured auto-containment policies to start autocontainment. The policies for initiating autocontainment are rogue on wire (detected through RLDP or rogue detector AP), rogue using managed SSID, Valid client on Rogue AP, and AdHoc Rogue.



Note

RLDP is not supported for use with Cisco autonomous rogue access points. These access points drop the DHCP Discover request sent by the RLDP client. Also, RLDP is not supported if the rogue access point channel requires dynamic frequency selection (DFS).

When you enter any of the containment commands, the following warning appears:

```
Using this feature may have legal consequences. Do you want to continue? (y/n) :
```

The 2.4-GHz and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party's network could have legal consequences.

Examples

The following example shows how to configure the auto-contain level to 3:

```
Device > config rogue auto-contain level 3
```

Related Commands

config rogue adhoc
show rogue adhoc summary
show rogue client summary
show rogue ignore-list
show rogue rule summary

config rogue ap valid-client

To generate an alarm only, or to automatically contain a rogue access point to which a trusted client is associated, use the **config rogue ap valid-client** command.

config rogue ap valid-client {alarm | auto-contain}

Syntax Description		
alarm		Generates only an alarm when a rogue access point is discovered to be associated with a valid client.
auto-contain		Automatically contains a rogue access point to which a trusted client is associated.

Command Default None.

Usage Guidelines When you enter any of the containment commands, the following warning appears: “Using this feature may have legal consequences. Do you want to continue?” The 2.4- and 5-GHz frequencies in the Industrial, Scientific, and Medical (ISM) band are open to the public and can be used without a license. As such, containing devices on another party’s network could have legal consequences.

Examples This example shows how to automatically contain a rogue access point that is associated with a valid client:

```
> config rogue ap valid-client auto-contain
```

Related Commands

- config rogue ap classify
- config rogue ap friendly
- config rogue ap rldp
- config rogue ap timeout
- config rogue ap ssid
- config rogue rule
- config trapflags rogueap
- show rogue ap clients
- show rogue ap detailed
- show rogue ap summary
- show rogue ap friendly summary
- show rogue ap malicious summary
- show rogue ap unclassified summary
- show rogue ignore-list

show rogue rule detailed

show rogue rule summary

config rogue client

To configure rogue clients, use the **config rogue client** command.

config rogue client {aaa {enable | disable} | alert *ap_mac* | contain *client_mac*}

Syntax Description

aaa	Configures AAA server or local database to validate whether rogue clients are valid clients. The default is disabled.
enable	Enables the AAA server or local database to check rogue client MAC addresses for validity.
disable	Disables the AAA server or local database to check rogue client MAC addresses for validity.
alert	Configures the controller to forward an immediate alert to the system administrator for further action.
<i>ap_mac</i>	Access point MAC address.
contain	Configures the controller to contain the offending device so that its signals no longer interfere with authorized clients.
<i>client_mac</i>	MAC address of the rogue client.

Command Default

None.

Usage Guidelines

Examples

This example shows how to enable the AAA server or local database to check MAC addresses:

```
> config rogue client aaa enable
```

This example shows how to disable the AAA server or local database from checking MAC addresses:

```
> config rogue client aaa disable
```

Related Commands

config rogue rule
config trapflags rogueap
show rogue ap clients

show rogue ap detailed
show rogue client summary
show rogue ignore-list
show rogue rule detailed
show rogue rule summary

config rogue detection

To enable or disable rogue detection, use the **config rogue detection** command.



Note

If an AP itself is configured with the keyword **all**, the **all access points** case takes precedence over the AP that is with the keyword **all**.

config rogue detection {**enable** | **disable**} {*cisco_ap* | **all**}

Syntax Description

enable	Enables rogue detection on this access point.
disable	Disables rogue detection on this access point.
<i>cisco_ap</i>	Cisco access point.
all	Specifies all access points.

Command Default

Enabled.

Usage Guidelines

Rogue detection is enabled by default for all access points joined to the controller except for OfficeExtend access points. OfficeExtend access points are deployed in a home environment and are likely to detect a large number of rogue devices.

Examples

This example shows how to enable rogue detection on the access point Cisco_AP:

```
> config rogue detection enable Cisco_AP
```

Related Commands

config rogue rule
config trapflags rogueap
show rogue client detailed
show rogue client summary
show rogue ignore-list
show rogue rule detailed
show rogue rule summary

config rogue detection min-rssi

To configure the minimum Received Signal Strength Indicator (RSSI) value at which APs can detect rogues and create a rogue entry in the controller, use the **config rogue detection min-rssi** command.

config rogue detection min-rssi *rssi-in-dBm*

Syntax Description

<i>rssi-in-dBm</i>	Minimum RSSI value. The valid range is from –70 dBm to –128 dBm, and the default value is –128 dBm.

Usage Guidelines

This feature is applicable to all the AP modes.

There can be many rogues with very weak RSSI values that do not provide any valuable information in rogue analysis. Therefore, you can use this option to filter rogues by specifying the minimum RSSI value at which APs should detect rogues.

Examples

This example shows how to configure the minimum RSSI value:

```
> config rogue detection min-rssi -80
```

Related Commands

- config rogue detection**
- show rogue ap clients**
- config rogue rule**
- config trapflags rogueap**
- show rogue client detailed**
- show rogue client summary**
- show rogue ignore-list**
- show rogue rule detailed**
- show rogue rule summary**

config rogue detection monitor-ap

To configure the rogue report interval for all monitor mode Cisco APs, use the **config rogue detection monitor-ap** command.

config rogue detection monitor-ap {**report-interval** | **transient-rogue-interval**} *time-in-seconds*

Syntax Description

report-interval	Specifies the interval at which rogue reports are sent.
transient-rogue-interval	Specifies the interval at which rogues are consistently scanned for by APs after the first time the rogues are scanned.
<i>time-in-seconds</i>	Time in seconds. The valid range is as follows: • 10 to 300 for report-interval • 120 to 1800 for transient-rogue-interval

Usage Guidelines

This feature is applicable to APs that are in monitor mode only.

Using the transient interval values, you can control the time interval at which APs should scan for rogues. APs can also filter the rogues based on their transient interval values.

This feature has the following advantages:

- Rogue reports from APs to the controller are shorter.
- Transient rogue entries are avoided in the controller.
- Unnecessary memory allocation for transient rogues are avoided.

Examples

This example shows how to configure the rogue report interval to 60 seconds:

```
> config rogue detection monitor-ap report-interval 60
```

This example shows how to configure the transient rogue interval to 300 seconds:

```
> config rogue detection monitor-ap transient-rogue-interval 300
```

Related Commands

config rogue detection
config rogue detection min-rssi
config rogue rule
config trapflags rogueap
show rogue ap clients
show rogue client detailed

show rogue client summary

show rogue ignore-list

show rogue rule detailed

show rogue rule summary

config rogue rule

To add and configure rogue classification rules, use the **config rogue rule** command.

```
config rogue rule {add ap priority classify {custom severity-score classification-name | friendly | malicious} notify {all | global | none | local} state {alert | contain | internal | external} rule_name | classify {custom severity-score classification-name | friendly | malicious} rule_name | condition ap {set | delete} condition_type condition_value rule_name | {enable | delete | disable} {all | rule_name} | match {all | any} | priority priority | notify {all | global | none | local} rule_name | state {alert | contain | internal | external} rule_name}
```

Syntax Description

add ap priority	Adds a rule with match any criteria and the priority that you specify.
<i>priority</i>	Priority of this rule within the list of rules.
classify	Specifies the classification of a rule.
custom	Classifies devices matching the rule as custom.
<i>severity-score</i>	Custom classification severity score of the rule. The range is from 1 to 100.
<i>classification-name</i>	Custom classification name. The name can be up to 32 case-sensitive, alphanumeric characters.
friendly	Classifies a rule as friendly.
malicious	Classifies a rule as malicious.
notify	Configures type of notification upon rule match.
all	Notifies the controller and a trap receiver such as Cisco Prime Infrastructure.
global	Notifies only a trap receiver such as Cisco Prime Infrastructure.
local	Notifies only the controller.
none	Notifies neither the controller nor a trap receiver such as Cisco Prime Infrastructure.
state	Configures state of the rogue access point after a rule match.
alert	Configures alert state on the rogue access point that is not in the neighbor list or in the user configured friendly MAC list. The controller forwards an immediate alert to the system administrator for further action.

contain	Configures contain state on the rogue access point. Controller contains the offending device so that its signals no longer interfere with authorized clients.
external	Configures external state on the rogue access point that is outside the network and poses no threat to WLAN security. The controller acknowledges the presence of this rogue access point.
internal	Configures alert state on rogue access point that is inside the network and poses no threat to WLAN security. The controller trusts this rogue access point.
<i>rule_name</i>	Rule to which the command applies, or the name of a new rule.
condition ap	Specifies the conditions for a rule that the rogue access point must meet.
set	Adds conditions to a rule that the rogue access point must meet.
delete	Removes conditions to a rule that the rogue access point must meet.
<i>condition_type</i>	Type of the condition to be configured. The condition types are listed below: • client-count—Requires that a minimum number of clients be associated to a rogue access point. The valid range is 1 to 10 (inclusive). • duration—Requires that a rogue access point be detected for a minimum period of time. The valid range is 0 to 3600 seconds (inclusive). • managed-ssid—Requires that a rogue access point's SSID be known to the controller. • no-encryption—Requires that a rogue access point's advertised WLAN does not have encryption enabled. • rssi—Requires that a rogue access point have a minimum RSSI value. The range is from -95 to -50 dBm (inclusive). • ssid—Requires that a rogue access point have a specific SSID.
<i>condition_value</i>	Value of the condition. This value is dependent upon the condition_type. For instance, if the condition type is ssid, then the condition value is either the SSID name or all.
enable	Enables all rules or a single specific rule.
delete	Deletes all rules or a single specific rule.

disable	Deletes all rules or a single specific rule.
match	Specifies whether a detected rogue access point must meet all or any of the conditions specified by the rule in order for the rule to be matched and the rogue access point to adopt the classification type of the rule.
all	Specifies all rules defined.
any	Specifies any rule meeting certain criteria.
priority	Changes the priority of a specific rule and shifts others in the list accordingly.

Command Default

No rogue rules are configured.

Usage Guidelines

For your changes to be effective, you must enable the rule. You can configure up to 64 rules.

Reclassification of rogue APs according to the RSSI condition of the rogue rule occurs only when the RSSI changes more than +/- 2 dBm of the configured RSSI value. Manual and automatic classification override custom rogue rules. Rules are applied to manually changed rogues if their class type changes to unclassified and state changes to alert. Adhoc rogues are classified and do not go to the pending state. You can have up to 50 classification types.

Examples

The following example shows how to create a rule called rule_1 with a priority of 1 and a classification as friendly.

```
Device > config rogue rule add ap priority 1 classify friendly rule_1
```

The following example shows how to enable rule_1.

```
Device > config rogue rule enable rule_1
```

The following example shows how to change the priority of the last command.

```
Device > config rogue rule priority 2 rule_1
```

The following example shows how to change the classification of the last command.

```
Device > config rogue rule classify malicious rule_1
```

The following example shows how to disable the last command.

```
Device > config rogue rule disable rule_1
```

The following example shows how to delete SSID_2 from the user-configured SSID list in rule-5.

```
Device > config rogue rule condition ap delete ssid ssid_2 rule-5
```

The following example shows how to create a custom rogue rule.

```
Device > config rogue rule classify custom 1 VeryMalicious rule6
```

Related Commands

Command	Description
config rogue adhoc	Configures an ad-hoc rogue access point.
config rogue auto-contain level	Configures the rogue auto-containment level.
config rogue client	Configures rogue client.
config rogue detection	Enables or disables rogue detection.
show rogue ignore-list	Displays the list of rogue access points that are configured to be ignored
show rogue rule detailed	Displays detailed information for a rogue rule.
show rogue rule summary	Displays the rogue classification rules.

config tacacs acct

To configure TACACS+ accounting server settings, use the **config tacacs acct** command.

config tacacs acct add {*server_index* *ip_address* *port* *type* *secret_key*} | **delete** *server_index* | **disable** *server_index* | **enable** *server_index* | **retransmit-timeout** {*server_index* *seconds*}

Syntax Description

add	Adds a new TACACS+ accounting server.
<i>server_index</i>	TACACS+ accounting server index from 1 to 3.
<i>ip_address</i>	IP address for the TACACS+ accounting server.
<i>port</i>	Controller port used for the TACACS+ accounting server.
<i>type</i>	Type of secret key being used (ASCII or HEX).
<i>secret_key</i>	Secret key in ASCII or hexadecimal characters.
delete	Deletes a TACACS+ server.
disable	Disables a TACACS+ server.
enable	Enables a TACACS+ server.
retransmit-timeout	Changes the default retransmit timeout for the TACACS+ server.
<i>seconds</i>	Retransmit timeout (2 to 30 seconds).

Command Default

None.

Examples

This example shows how to add a new TACACS+ accounting server index 3 with the IP address 10.0.0.0, port number 10, and secret key 12345678 in ASCII:

```
> config tacacs acct add 1 10.0.0.0 10 ascii 12345678
```

This example shows how to change the default retransmit timeout of 30 seconds for the TACACS+ accounting server:

```
> config tacacs acct retransmit-timeout 30
```

Related Commands

show run-config
show tacacs acct statistics
show tacacs summary

config tacacs athr

To configure TACACS+ authorization server settings, use the **config tacacs athr** command.

config tacacs athr add {*server_index ip_address port type secret_key*} | **delete** *server_index* | **disable** *server_index* | **enable** *server_index* | **retransmit-timeout** {*server_index seconds*}

Syntax Description

add	Adds a new TACACS+ accounting server.
<i>server_index</i>	TACACS+ accounting server index from 1 to 3.
<i>ip_address</i>	IP address for the TACACS+ accounting server.
<i>port</i>	Controller port used for the TACACS+ accounting server.
<i>type</i>	Type of secret key being used (ASCII or HEX).
<i>secret_key</i>	Secret key in ASCII or hexadecimal characters.
delete	Deletes a TACACS+ server.
disable	Disables a TACACS+ server.
enable	Enables a TACACS+ server.
retransmit-timeout	Changes the default retransmit timeout for the TACACS+ server.
<i>seconds</i>	Retransmit timeout (2 to 30 seconds).

Command Default

None.

Examples

This example shows how to add a new TACACS+ authorization server index 3 with the IP address 10.0.0.0, port number 4, and secret key 12345678 in ASCII:

```
> config tacacs athr add 3 10.0.0.0 4 ascii 12345678
```

This example shows how to change the default retransmit timeout of 30 seconds for the TACACS+ authorization server:

```
> config tacacs athr retransmit-timeout 30
```

Related Commands

show run-config
show tacacs summary
show tacacs athr statistics

config tacacs athr mgmt-server-timeout

To configure a default TACACS+ authorization server timeout for management users, use the **config tacacs athr mgmt-server-timeout** command.

config tacacs athr mgmt-server-timeout *index timeout*

Syntax Description

<i>index</i>	TACACS+ authorization server index.
<i>timeout</i>	Timeout value. The range is 1 to 30 seconds.

Command Default

None.

Examples

This example shows how to configure a default TACACS+ authorization server timeout for management users:

```
> config tacacs athr mgmt-server-timeout 1 10
```

Related Commands

config tacacs athr

config tacacs auth

To configure TACACS+ authentication server settings, use the **config tacacs auth** command.

config tacacs auth add {*server_index* *ip_address* *port* *type* *secret_key*} | **delete** *server_index* | **disable** *server_index* | **enable** *server_index* | **retransmit-timeout** {*server_index* *seconds*}

Syntax Description

add	Adds a new TACACS+ accounting server.
<i>server_index</i>	TACACS+ accounting server index from 1 to 3.
<i>ip_address</i>	IP address for the TACACS+ accounting server.
<i>port</i>	Controller port used for the TACACS+ accounting server.
<i>type</i>	Type of secret key being used (ASCII or HEX).
<i>secret_key</i>	Secret key in ASCII or hexadecimal characters.
delete	Deletes a TACACS+ server.
disable	Disables a TACACS+ server.
enable	Enables a TACACS+ server.
retransmit-timeout	Changes the default retransmit timeout for the TACACS+ server.
<i>seconds</i>	Retransmit timeout (2 to 30 seconds).

Command Default

None.

Examples

This example shows how to add a new TACACS+ authentication server index 2 with the IP address 10.0.0.3, port number 6, and secret key 12345678 in ASCII:

```
> config tacacs auth add 2 10.0.0.3 6 ascii 12345678
```

This example shows how to change the default retransmit timeout of 30 seconds for TACACS+ authentication server:

```
> config tacacs auth retransmit-timeout 30
```

Related Commands

show run-config
show tacacs auth statistics
show tacacs summary

config tacacs auth mgmt-server-timeout

To configure a default TACACS+ authentication server timeout for management users, use the **config tacacs auth mgmt-server-timeout** command.

config tacacs auth mgmt-server-timeout *index timeout*

Syntax Description

<i>index</i>	TACACS+ authentication server index.
<i>timeout</i>	Timeout value. The range is 1 to 30 seconds.

Command Default

None.

Examples

This example shows how to configure a default TACACS+ authentication server timeout for management users:

```
> config tacacs auth mgmt-server-timeout 1 10
```

Related Commands

config tacacs auth

config wps ap-authentication

To configure access point neighbor authentication, use the **config wps ap-authentication** command.

config wps ap-authentication [**enable** | **disable threshold** *threshold_value*]

Syntax Description

enable	(Optional) Enables WMM on the wireless LAN.
disable	(Optional) Disables WMM on the wireless LAN.
threshold	(Optional) Specifies that WMM-enabled clients are on the wireless LAN.
<i>threshold_value</i>	Threshold value (1 to 255).

Command Default

None.

Examples

```
> config wps ap-authentication threshold 25
```

Related Commands

show wps ap-authentication summary

config wps auto-immune

To enable or disable protection from Denial of Service (DoS) attacks, use the **config wps auto-immune** command.

config wps auto-immune {enable | disable}

Syntax Description

enable	Enables the auto-immune feature.
disable	Disables the auto-immune feature.

Command Default

Disabled.

Usage Guidelines

A potential attacker can use specially crafted packets to mislead the Intrusion Detection System (IDS) into treating a legitimate client as an attacker. It causes the controller to disconnect this legitimate client and launch a DoS attack. The auto-immune feature, when enabled, is designed to protect against such attacks. However, conversations using Cisco 792x phones might be interrupted intermittently when the auto-immune feature is enabled. If you experience frequent disruptions when using 792x phones, you might want to disable this feature.

Examples

This example shows how to configure the auto-immune mode:

```
> config wps auto-immune enable
```

Related Commands

show wps summary

config wps cids-sensor

To configure Intrusion Detection System (IDS) sensors for the Wireless Protection System (WPS), use the **config wps cids-sensor** command.

```
config wps cids-sensor { [add index ip_address username password] | [delete index] | [enable index] | [disable index] | [port index port] | [interval index query_interval] | [fingerprint sha1 fingerprint] }
```

Syntax Description

add	(Optional) Configures a new IDS sensor.
<i>index</i>	IDS sensor internal index.
<i>ip_address</i>	IDS sensor IP address.
<i>username</i>	IDS sensor username.
<i>password</i>	IDS sensor password.
delete	(Optional) Deletes an IDS sensor.
enable	(Optional) Enables an IDS sensor.
disable	(Optional) Disables an IDS sensor.
port	(Optional) Configures the IDS sensor's port number.
<i>port</i>	Port number.
interval	(Optional) Specifies the IDS sensor's query interval.
<i>query_interval</i>	Query interval setting.
fingerprint	(Optional) Specifies the IDS sensor's TLS fingerprint.
sha1	(Optional) Specifies the TLS fingerprint.
<i>fingerprint</i>	TLS fingerprint.

Command Default

Command defaults are listed below as follows:

Port	443
Query interval	60
Certification fingerprint	00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00:00
Query state	Disabled

Examples

This example shows how to configure the intrusion detection system with the IDS index 1, IDS sensor IP address 10.0.0.51, IDS username Sensor_user0doc1, and IDS password passowrd01:

```
> config wps cids-sensor add 1 10.0.0.51 Sensor_user0doc1 password01
```

Related Commands

show wps cids-sensor detail

config wps client-exclusion

To configure client exclusion policies, use the **config wps client-exclusion** command.

config wps client-exclusion {802.11-assoc | 802.11-auth | 802.11x-auth | ip-theft | web-auth | all} {enable | disable}

Syntax Description

802.11-assoc	Specifies that the controller excludes clients on the sixth 802.11 association attempt, after five consecutive failures.
802.11-auth	Specifies that the controller excludes clients on the sixth 802.11 authentication attempt, after five consecutive failures.
802.1x-auth	Specifies that the controller excludes clients on the sixth 802.11X authentication attempt, after five consecutive failures.
ip-theft	Specifies that the control excludes clients if the IP address is already assigned to another device.
web-auth	Specifies that the controller excludes clients on the fourth web authentication attempt, after three consecutive failures.
all	Specifies that the controller excludes clients for all of the above reasons.
enable	Enables client exclusion policies.
disable	Disables client exclusion policies.

Command Default

All policies are enabled.

Examples

This example shows how to disable clients on the 802.11 association attempt after five consecutive failures:

```
> config wps client-exclusion 802.11-assoc disable
```

Related Commands

show wps summary

config wps mfp

To configure Management Frame Protection (MFP), use the **config wps mfp** command.

config wps mfp infrastructure {enable | disable}

Syntax Description

infrastructure	Configures the MFP infrastructure.
enable	Enables the MFP feature.
disable	Disables the MFP feature.

Command Default

None.

Examples

This example shows how to enable the infrastructure MFP:

```
> config wps mfp infrastructure enable
```

Related Commands

show wps mfp

config wps shun-list re-sync

To force the controller to synchronization with other controllers in the mobility group for the shun list, use the **config wps shun-list re-sync** command.

config wps shun-list re-sync

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to configure the controller to synchronize with other controllers for the shun list:

```
> config wps shun-list re-sync
```

Related Commands	show wps shun-list

config wps signature

To enable or disable Intrusion Detection System (IDS) signature processing, or to enable or disable a specific IDS signature, use the **config wps signature** command.

config wps signature {**standard** | **custom**} **state** *signature_id* {**enable** | **disable**}

Syntax Description

standard	Configures a standard IDS signature.
custom	Configures a standard IDS signature.
state	Specifies the state of the IDS signature.
<i>signature_id</i>	Identifier for the signature to be enabled or disabled.
enable	Enables the IDS signature processing or a specific IDS signature.
disable	Disables IDS signature processing or a specific IDS signature.

Command Default

IDS signature processing is enabled by default.

Usage Guidelines

If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples

This example shows how to enable IDS signature processing, which enables the processing of all IDS signatures:

```
> config wps signature enable
```

This example shows how to disable a standard individual IDS signature:

```
> config wps signature standard state 15 disable
```

Related Commands

config wps signature frequency
config wps signature interval
config wps signature mac-frequency
config wps signature quiet-time
config wps signature reset
show wps signature events
show wps signature summary
show wps summary

config wps signature frequency

To specify the number of matching packets per interval that must be identified at the individual access point level before an attack is detected, use the **config wps signature frequency** command.

config wps signature frequency *signature_id* *frequency*

Syntax Description

<i>signature_id</i>	Identifier for the signature to be configured.
<i>frequency</i>	Number of matching packets per interval that must be at the individual access point level before an attack is detected. The range is 1 to 32,000 packets per interval.

Command Default

The *frequency* default value varies per signature.

Usage Guidelines

If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples

This example shows how to set the number of matching packets per interval per access point before an attack is detected to 1800 for signature ID 4:

```
> config wps signature frequency 4 1800
```

Related Commands

config wps signature frequency
config wps signature interval
config wps signature quiet-time
config wps signature reset
show wps signature events
show wps signature summary
show wps summary

config wps signature interval

To specify the number of seconds that must elapse before the signature frequency threshold is reached within the configured interval, use the **config wps signature interval** command.

config wps signature interval *signature_id* *interval*

Syntax Description	<i>signature_id</i>	Identifier for the signature to be configured.
	<i>interval</i>	Number of seconds that must elapse before the signature frequency threshold is reached. The range is 1 to 3,600 seconds.

Command Default The default value of *interval* varies per signature.

Usage Guidelines If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples This example shows how to set the number of seconds to elapse before reaching the signature frequency threshold to 200 for signature ID 1:

```
> config wps signature interval 1 200
```

Related Commands

- config wps signature frequency
- config wps signature
- config wps signature mac-frequency
- config wps signature quiet-time
- config wps signature reset
- show wps signature events
- show wps signature summary
- show wps summary

config wps signature mac-frequency

To specify the number of matching packets per interval that must be identified per client per access point before an attack is detected, use the **config wps signature mac-frequency** command.

config wps signature mac-frequency *signature_id mac_frequency*

Syntax Description

<i>signature_id</i>	Identifier for the signature to be configured.
<i>mac_frequency</i>	Number of matching packets per interval that must be identified per client per access point before an attack is detected. The range is 1 to 32,000 packets per interval.

Command Default

The *mac_frequency* default value varies per signature.

Usage Guidelines

If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples

This example shows how to set the number of matching packets per interval per client before an attack is detected to 50 for signature ID 3:

```
> config wps signature mac-frequency 3 50
```

Related Commands

config wps signature frequency
config wps signature interval
config wps signature
config wps signature quiet-time
config wps signature reset
show wps signature events
show wps signature summary
show wps summary

config wps signature quiet-time

To specify the length of time after which no attacks have been detected at the individual access point level and the alarm can stop, use the **config wps signature quiet-time** command.

config wps signature quiet-time *signature_id* *quiet_time*

Syntax Description

<i>signature_id</i>	Identifier for the signature to be configured.
<i>quiet_time</i>	Length of time after which no attacks have been detected at the individual access point level and the alarm can stop. The range is 60 to 32,000 seconds.

Command Default

The default value of *quiet_time* varies per signature.

Usage Guidelines

If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples

This example shows how to set the number of seconds after which no attacks have been detected per access point to 60 for signature ID 1:

```
> config wps signature quiet-time 1 60
```

Related Commands

config wps signature
config wps signature frequency
config wps signature interval
config wps signature mac-frequency
config wps signature reset
show wps signature events
show wps signature summary
show wps summary

config wps signature reset

To reset a specific Intrusion Detection System (IDS) signature or all IDS signatures to default values, use the **config wps signature reset** command.

config wps signature reset {*signature_id* | **all**}

Syntax Description

<i>signature_id</i>	Identifier for the specific IDS signature to be reset.
all	Resets all IDS signatures.

Command Default

None.

Usage Guidelines

If IDS signature processing is disabled, all signatures are disabled, regardless of the state configured for individual signatures.

Examples

This example shows how to reset the IDS signature 1 to default values:

```
> config wps signature reset 1
```

Related Commands

config wps signature
config wps signature frequency
config wps signature interval
config wps signature mac-frequency
config wps signature quiet-time
show wps signature events
show wps signature summary
show wps summary

clear Commands

This section lists the **clear** commands to clear existing security configurations of the controller.

clear acl counters

To clear the current counters for an access control list (ACL), use the **clear acl counters** command.

clear acl counters *acl_name*

Syntax Description

acl_name ACL name.

Command Default

None.

Usage Guidelines



Note

ACL counters are available only on the following controllers: Cisco 4400 Series Controller, Cisco WiSM, and Catalyst 3750G Integrated Wireless LAN Controller Switch.

Examples

This example shows how to clear the current counters for acl1:

```
> clear acl counters acl1
```

Related Commands

config acl counter
show acl

clear radius acct statistics

To clear the RADIUS accounting statistics on the controller, use the **clear radius acc statistics** command.

clear radius acct statistics [**index** | **all**]

Syntax Description	index	(Optional) Specifies the index of the RADIUS accounting server.
	all	(Optional) Specifies all RADIUS accounting servers.

Command Default None.

Examples This example shows how to clear the RADIUS accounting statistics:

> **clear radius acc statistics**

Related Commands **show radius acct statistics**

clear tacacs auth statistics

To clear the RADIUS authentication server statistics in the controller, use the **clear tacacs auth statistics** command.

clear tacacs auth statistics [**index** | **all**]

Syntax Description

index	(Optional) Specifies the index of the RADIUS authentication server.
all	(Optional) Specifies all RADIUS authentication servers.

Command Default

None.

Examples

This example shows how to clear the RADIUS authentication server statistics:

```
> clear tacacs auth statistics
```

Related Commands

show tacacs auth statistics
show tacacs summary
config tacacs auth

clear stats local-auth

To clear the local Extensible Authentication Protocol (EAP) statistics, use the **clear stats local-auth** command.

clear stats local-auth

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear the local EAP statistics:

```
> clear stats local-auth
Local EAP Authentication Stats Cleared.
```

Related Commands

- config local-auth active-timeout**
- config local-auth eap-profile**
- config local-auth method fast**
- config local-auth user-credentials**
- debug aaa local-auth**
- show local-auth certificates**
- show local-auth config**
- show local-auth statistics**

clear stats radius

To clear the statistics for one or more RADIUS servers, use the **clear stats radius** command.

clear stats radius {auth | acct} {index | all}

Syntax Description

auth	Clears statistics regarding authentication.
acct	Clears statistics regarding accounting.
index	Specifies the index number of the RADIUS server to be cleared.
all	Clears statistics for all RADIUS servers.

Command Default

None.

Examples

This example shows how to clear the statistics for all RADIUS authentication servers:

```
> clear stats radius auth all
```

Related Commands

clear transfer
clear download datatype
clear download filename
clear download mode
clear download serverip
clear download start
clear upload datatype
clear upload filename
clear upload mode
clear upload path
clear upload serverip
clear upload start
clear stats port

clear stats tacacs

To clear the TACACS+ server statistics on the controller, use the **clear stats tacacs** command.

clear stats tacacs [**auth** | **athr** | **acct**] [**index** | **all**]

Syntax Description

auth	(Optional) Clears the TACACS+ authentication server statistics.
athr	(Optional) Clears the TACACS+ authorization server statistics.
acct	(Optional) Clears the TACACS+ accounting server statistics.
index	(Optional) Specifies index of the TACACS+ server.
all	(Optional) Specifies all TACACS+ servers.

Command Default

None.

Examples

This example shows how to clear the TACACS+ accounting server statistics for index 1:

```
> clear stats tacacs acct 1
```

Related Commands

show tacacs summary

debug Commands

This section lists the **debug** commands to manage debugging of security settings of the controller.



Caution

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug 11w-pmf

To configure the debugging of 802.11w, use the **debug 11w-pmf** command.

debug 11w-pmf {all | events| keys} {enable | disable}

Syntax Description

all	Configures the debugging of all 802.11w messages.
keys	Configures the debugging of 802.11w keys.
events	Configures the debugging of 802.11w events.
enable	Enables the debugging of 802.1w options.
disable	Disables the debugging of 802.1w options.

Command Default

None.

Examples

This example shows how to enable the debugging of 802.11w keys:

```
> debug 11w-pmf keys enable
```

Related Commands

show wlan
show client detail
config wlan security pmf

debug aaa

To configure the debugging of AAA settings, use the **debug aaa** command.

debug aaa {[all | detail | events | packet | ldap | local-auth | tacacs] [enable | disable]}

Syntax Description

all	(Optional) Configures the debugging of all AAA messages.
detail	(Optional) Configures the debugging of AAA errors.
events	(Optional) Configures the debugging of AAA events.
packet	(Optional) Configures the debugging of AAA packets.
ldap	(Optional) Configures the debugging of the AAA Lightweight Directory Access Protocol (LDAP) events.
local-auth	(Optional) Configures the debugging of the AAA local Extensible Authentication Protocol (EAP) events.
tacacs	(Optional) Configures the debugging of the AAA TACACS+ events.
enable	(Optional) Enables the debugging.
disable	(Optional) Disables the debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of AAA LDAP events:

```
> debug aaa ldap enable
```

Related Commands

debug aaa local-auth cap
show running-config

debug aaa local-auth

To configure the debugging of AAA local authentication on the Cisco WLC, use the **debug aaa local-auth** command.

debug aaa local-auth {db | shim | eap {framework | method} {all | errors | events | packets | sm}} {enable | disable}

Syntax Description

db	Configures the debugging of the AAA local authentication back-end messages and events.
shim	Configures the debugging of the AAA local authentication shim layer events.
eap	Configures the debugging of the AAA local Extensible Authentication Protocol (EAP) authentication.
framework	Configures the debugging of the local EAP framework.
method	Configures the debugging of local EAP methods.
all	Configures the debugging of local EAP messages.
errors	Configures the debugging of local EAP errors.
events	Configures the debugging of local EAP events.
packets	Configures the debugging of local EAP packets.
sm	Configures the debugging of the local EAP state machine.
enable	Starts the debugging.
disable	Stops the debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of the AAA local EAP authentication:

```
> debug aaa local-auth eap method all enable
```

Related Commands

clear stats local-auth
 config local-auth active-timeout
 config local-auth eap-profile
 config local-auth method fast

config local-auth user-credentials

show local-auth certificates

show local-auth config

show local-auth statistics

debug bcast

To configure the debugging of broadcast options, use the **debug bcast** command.

debug bcast {all | error | message | igmp | detail} {enable | disable}

Syntax Description

all	Configures the debugging of all broadcast logs.
error	Configures the debugging of broadcast errors.
message	Configures the debugging of broadcast messages.
igmp	Configures the debugging of broadcast IGMP messages.
detail	Configures the debugging of broadcast detailed messages.
enable	Enables the broadcast debugging.
disable	Disables the broadcast debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of broadcast messages:

```
> debug bcast message enable
```

This example shows how to disable the debugging of broadcast messages:

```
> debug bcast message disable
```

Related Commands

debug disable-all
show sysinfo

debug cckm

To configure the debugging of the Cisco Centralized Key Management (CCKM) options, use the **debug cckm**

debug cckm {client | detailed} {enable| disable}

Syntax Description

client	Configures the debugging of the CCKM of clients.
detailed	Configures the detailed debugging of CCKM.
enable	Enables the debugging of CCKM.
disable	Disables the debugging of CCKM.

Command Default

None

Examples

The following example shows how to enable CCKM detailed debugging in a Cisco controller.

```
Device > debug cckm detailed enable
```

debug cts sxp

To configure the debugging of Cisco TrustSec (CTS) Security Group Tag (SGT) Exchange Protocol (SXP) options, use the **debug cts sxp** command.

debug cts sxp {all | errors | events | framework | message} {enable | disable}

Syntax Description

all	Configures the debugging of all the CTS SXP options.
errors	Configures the debugging of the CTS SXP errors.
events	Configures the debugging of the CTS SXP events.
framework	Configures the debugging of the CTS SXP framework.
message	Configures the debugging of the CTS SXP messages.
enable	Enables the debugging of the CTS SXP options.
disable	Disables the debugging of the CTS SXP options.

Command Default

None

Examples

The following example shows how to enable CTS SXP event debugging in a Cisco WLC

Device > **debug cts sxp**

Related Commands

Command	Description
config cts sxp	Configures CTS connections.

debug dot1x

To configure the debugging of 802.1X options, use the **debug dot1x** command.

debug dot1x {aaa | all | events | packets | states} {enable | disable}

Syntax Description

aaa	Configures the debugging of the 802.1X AAA interactions.
all	Configures the debugging of all the 802.1X messages.
events	Configures the debugging of the 802.1X events.
packets	Configures the debugging of the 802.1X packets.
states	Configures the debugging of the 802.1X state transitions.
enable	Enables the debugging of the 802.1X options.
disable	Disables the debugging of the 802.1X options.

Command Default

None

Examples

The following example shows how to enable 802.1X state transitions debugging in a Cisco controller.

```
Device > debug dot1x states enable
```

Related Commands

Command	Description
config wlan security 802.1X	Configures 802.1X settings on the radio.
config wlan security wpa akm 802.1x	Configures AKM using 802.1X.

debug dtls

To configure the debugging of Datagram Transport Layer Security (DTLS) options, use the **debug dtls** command.

debug dtls {all | event | packet | trace} {enable | disable}

Syntax Description

all	Configures the debugging of all the DTLS messages.
event	Configures the debugging of the DTLS events.
packet	Configures the debugging of the DTLS packets.
trace	Configures the debugging of the DTLS trace messages.
enable	Enables the debugging of the DTLS options.
disable	Disables the debugging of the DTLS options.

Command Default

None

Usage Guidelines

These debugs are used in conjunction with CAPWAP troubleshooting.

Examples

The following example shows how to enable DTLS packet debugging in a Cisco controller.

```
Device > debug dtls packet enable
```

Related Commands

Command	Description
show dtls connections	Displays the DTLS server status.

debug cckm

To configure the debugging of the Cisco Centralized Key Management (CCKM) options, use the **debug cckm**

debug cckm {client | detailed} {enable| disable}

Syntax Description

client	Configures the debugging of the CCKM of clients.
detailed	Configures the detailed debugging of CCKM.
enable	Enables the debugging of CCKM.
disable	Disables the debugging of CCKM.

Command Default

None

Examples

The following example shows how to enable CCKM detailed debugging in a Cisco controller.

```
Device > debug cckm detailed enable
```


debug nac

To configure the debugging of Network Access Control (NAC), use the **debug nac** command.

debug nac {events | packet} {enable | disable}

Syntax Description

events	Configures the debugging of NAC events.
packet	Configures the debugging of NAC packets.
enable	Enables the NAC debugging.
disable	Disables the NAC debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of NAC settings:

```
> debug nac events enable
```

Related Commands

show nac statistics
show nac summary
config guest-lan nac
config wlan nac

debug pm

To configure the debugging of the security policy manager module, use the **debug pm** command.

debug pm {all disable | {config | hwcrypto | ikemsg | init | list | message | pki | rng | rules | sa-export | sa-import | ssh-l2tp | ssh-appgw | ssh-engine | ssh-int | ssh-pmgr | ssh-ppp | ssh-tcp} {enable | disable}}

Syntax Description

all disable	Disables all debugging in the policy manager module.
config	Configures the debugging of the policy manager configuration.
hwcrypto	Configures the debugging of hardware offload events.
ikemsg	Configures the debugging of Internet Key Exchange (IKE) messages.
init	Configures the debugging of policy manager initialization events.
list	Configures the debugging of policy manager list mgmt.
message	Configures the debugging of policy manager message queue events.
pki	Configures the debugging of Public Key Infrastructure (PKI) related events.
rng	Configures the debugging of random number generation.
rules	Configures the debugging of Layer 3 policy events.
sa-export	Configures the debugging of SA export (mobility).
sa-import	Configures the debugging of SA import (mobility).
ssh-l2tp	Configures the debugging of policy manager Layer 2 Tunneling Protocol (L2TP) handling.
ssh-appgw	Configures the debugging of application gateways.
ssh-engine	Configures the debugging of the policy manager engine.
ssh-int	Configures the debugging of the policy manager interceptor.
ssh-pmgr	Configures the debugging of the policy manager.
ssh-ppp	Configures the debugging of policy manager Point To Point Protocol (PPP) handling.
ssh-tcp	Configures the debugging of policy manager TCP handling.
enable	Enables the debugging.
disable	Disables the debugging.

Command Default

None.

Examples

This example shows how to configure the debugging of PKI-related events:

```
> debug pm pki enable
```

Related Commands

debug disable-all

debug web-auth

To configure the debugging of web authenticated clients, use the **debug web-auth** command.

debug web-auth {**redirect** { **enable** **mac** *mac_address* | **disable** } | **webportal-server** {**enable** | **disable**}}

Syntax Description

redirect	Configures the debugging of web authenticated and redirected clients.
enable	Enables the debugging of web authenticated clients.
mac	Configures the MAC address of the web authenticated client.
<i>mac_address</i>	MAC address of the web authenticated client.
disable	Disables the debugging of web authenticated clients.
webportal-server	Configures the debugging of portal authentication of clients.

Command Default

None.

Examples

This example shows how to enable the debugging of a web authenticated and redirected client:

```
> debug web-auth redirect enable mac xx:xx:xx:xx:xx:xx
```

debug wips

To configure the debugging of wireless intrusion prevention system (WIPS), use the **debug wips** command.

debug wips {all | error | event | nmsp | packet} {enable | disable}

Syntax Description

all	Configures the debugging of all WIPS messages.
error	Configures the debugging of WIPS errors.
event	Configures the debugging of WIPS events.
nmsp	Configures the debugging of WIPS Network Mobility Services Protocol (NMSP) events.
packet	Configures the debugging of WIPS packets.
enable	Enables the debugging of WIPS.
disable	Disables the debugging of WIPS.

Command Default

None.

Examples

This example shows how to enable the debugging of all WIPS messages:

```
> debug wips all enable
```

Related Commands

debug client
debug dot11 rogue
show wps summary
show wps wips

debug wps sig

To configure the debugging of Wireless Provisioning Service (WPS) signature settings, use the **debug wps sig** command.

debug wps sig {enable | disable}

Syntax Description

enable	Enables the debugging for WPS settings.
disable	Disables the debugging for WPS settings.

Command Default

None.

Examples

This example shows how to enable the debugging of WPS signature settings:

```
> debug wps sig enable
```

Related Commands

debug wps mfp
debug disable-all

debug wps mfp

To configure the debugging of WPS Management Frame Protection (MFP) settings, use the **debug wps mfp** command.

debug wps mfp {client | capwap | detail | report | mm} {enable | disable}

Syntax Description

client	Configures the debugging for client MFP messages.
capwap	Configures the debugging for MFP messages between the controller and access points.
detail	Configures the detailed debugging for MFP messages.
report	Configures the debugging for MFP reporting.
mm	Configures the debugging for MFP mobility (inter-Cisco WLC) messages.
enable	Enables the debugging for WPS MFP settings.
disable	Disables the debugging for WPS MFP settings.

Command Default

None.

Examples

This example shows how to enable the debugging of WPS MFP settings:

```
> debug wps mfp detail enable
```

Related Commands

debug disable-all
debug wps sig



PART **V**

WLAN Commands

- [CLI Commands, page 877](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 877](#)
- [config Commands, page 927](#)
- [clear Commands, page 1154](#)
- [debug Commands, page 1155](#)
- [test Commands, page 1167](#)

show Commands

This section lists the **show** commands to display information about your WLAN configuration settings.

show advanced hotspot

To display the advanced HotSpot parameters, use the **show advanced hotspot** command.

show advanced hotspot

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the advanced HotSpot parameters:

```
> show advanced hotspot
ANQP 4-way state..... Disabled
GARP Broadcast state: ..... Enabled
GAS request rate limit ..... Disabled
ANQP comeback delay in TUs (TU=1024usec) ..... 50
```

Related Commands

- show wlan**
- debug hotspot events**
- debug hotspot packets**
- config wlan apgroup hotspot**
- config wlan hotspot**
- config ap hotspot venue**
- config advanced hotspot**
- config wlan security wpa gtk-random**

show avc statistics wlan

To display the Application Visibility and Control (AVC) statistics of a WLAN, use the **show avc statistics wlan** command.

show avc statistics wlan *wlan_id* {**application** *application_name* | **top-app-groups** [**upstream** | **downstream**] | **top-apps** [**upstream** | **downstream**]}

Syntax Description

<i>wlan_id</i>	WLAN identifier from 1 to 512.
application	Displays AVC statistics for an application.
<i>application_name</i>	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
top-app-groups	Displays AVC statistics for top application groups.
upstream	(Optional) Displays statistics of top upstream applications.
downstream	(Optional) Displays statistics of top downstream applications.
top-apps	Displays AVC statistics for top applications.

Command Default

None

Command History

Release	Modification
7.4	This command was introduced.

Examples

The following is a sample output of the **show avc statistics** command.

Device > **show avc statistics wlan 1**

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
=====		=====	=====	=====	=====	=====
unclassified	(U)	191464	208627	1	92208613	11138796586
	(D)	63427	53440610	842	16295621	9657054635
ftp	(U)	805	72880	90	172939	11206202
	(D)	911	58143	63	190900	17418653
http	(U)	264904	12508288	47	27493945	2837672192
	(D)	319894	436915253	1365	29850934	36817587924
gre	(U)	0	0	0	10158872	10402684928
	(D)	0	0	0	0	0
icmp	(U)	1	40	40	323	98476
	(D)	7262	4034576	555	2888266	1605133372
ipinip	(U)	62565	64066560	1024	11992305	12280120320
	(D)	0	0	0	0	0
imap	(U)	1430	16798	11	305161	3795766

	(D)	1555	576371	370	332290	125799465
irc	(U)	9	74	8	1736	9133
	(D)	11	371	33	1972	173381
nntp	(U)	22	158	7	1705	9612
	(D)	22	372	16	2047	214391

The following is a sample output of the **show avc statistics wlan** command.

Device > **show avc statistics wlan 1 application ftp**

Description	Upstream	Downstream
=====	=====	=====
Number of Packtes(n secs)	0	0
Number of Bytes(n secs)	0	0
Average Packet size(n secs)	0	0
Total Number of Packtes	32459	64888
Total Number of Bytes	274	94673983

Related Commands

- config avc profile delete**
- config avc profile create**
- config avc profile rule**
- config wlan avc**
- show avc profile**
- show avc applications**
- show avc statistics client**
- show avc statistics applications**
- show avc statistics top-apps**
- show avc statistics guest-lan**
- show avc statistics remote-lan**
- debug avc error**
- debug avc events**

show call-control ap



Note

The **show call-control ap** command is applicable only for SIP based calls.

To see the metrics for successful calls or the traps generated for failed calls, use the **show call-control ap** command.

show call-control ap {802.11a | 802.11b} cisco_ap {metrics | traps}

Syntax Description

802.11a	Specifies the 802.11a network
802.11b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco access point name.
metrics	Specifies the call metrics information.
traps	Specifies the trap information for call control.

Command Default

None.

Examples

This example shows how to display the metrics for successful calls generated for an access point:

```
> show call-control ap 802.11a Cisco_AP metrics
Total Call Duration in Seconds..... 120
Number of Calls..... 10
Number of calls for given client is..... 1
```

This example shows how to display the metrics for the traps generated for an access point:

```
> show call-control ap 802.11a Cisco_AP traps
Number of traps sent in one min..... 2
Last SIP error code..... 404
Last sent trap timestamp..... Jun 20 10:05:06
```

Usage Guidelines

To aid in troubleshooting, the output of this command shows an error code for any failed calls. This table explains the possible error codes for failed calls.

Table 5: Error Codes for Failed VoIP Calls

Error Code	Integer	Description
1	unknown	Unknown error.
400	badRequest	The request could not be understood because of malformed syntax.

Error Code	Integer	Description
401	unauthorized	The request requires user authentication.
402	paymentRequired	Reserved for future use.
403	forbidden	The server understood the request but refuses to fulfill it.
404	notFound	The server has information that the user does not exist at the domain specified in the Request-URI.
405	methodNotAllowed	The method specified in the Request-Line is understood but not allowed for the address identified by the Request-URI.
406	notAcceptable	The resource identified by the request is only capable of generating response entities with content characteristics that are not acceptable according to the Accept header field sent in the request.
407	proxyAuthenticationRequired	The client must first authenticate with the proxy.
408	requestTimeout	The server could not produce a response within a suitable amount of time.
409	conflict	The request could not be completed due to a conflict with the current state of the resource.
410	gone	The requested resource is no longer available at the server, and no forwarding address is known.
411	lengthRequired	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
413	requestEntityTooLarge	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
414	requestURITooLarge	The server is refusing to service the request because the Request-URI is longer than the server is willing to interpret.
415	unsupportedMediaType	The server is refusing to service the request because the message body of the request is in a format not supported by the server for the requested method.
420	badExtension	The server did not understand the protocol extension specified in a Proxy-Require or Require header field.
480	temporarilyNotAvailable	The callee's end system was contacted successfully, but the callee is currently unavailable.

Error Code	Integer	Description
481	callLegDoesNotExist	The UAS received a request that does not match any existing dialog or transaction.
482	loopDetected	The server has detected a loop.
483	tooManyHops	The server received a request that contains a Max-Forwards header field with the value zero.
484	addressIncomplete	The server received a request with a Request-URI that was incomplete.
485	ambiguous	The Request-URI was ambiguous.
486	busy	The callee's end system was contacted successfully, but the callee is currently not willing or able to take additional calls at this end system.
500	internalServerError	The server encountered an unexpected condition that prevented it from fulfilling the request.
501	notImplemented	The server does not support the functionality required to fulfill the request.
502	badGateway	The server, while acting as a gateway or proxy, received an invalid response from the downstream server it accessed in attempting to fulfill the request.
503	serviceUnavailable	The server is temporarily unable to process the request because of a temporary overloading or maintenance of the server.
504	serverTimeout	The server did not receive a timely response from an external server it accessed in attempting to process the request.
505	versionNotSupported	The server does not support or refuses to support the SIP protocol version that was used in the request.
600	busyEverywhere	The callee's end system was contacted successfully, but the callee is busy or does not want to take the call at this time.
603	decline	The callee's machine was contacted successfully, but the user does not want to or cannot participate.
604	doesNotExistAnywhere	The server has information that the user indicated in the Request-URI does not exist anywhere.
606	notAcceptable	The user's agent was contacted successfully, but some aspects of the session description (such as the requested media, bandwidth, or addressing style) were not acceptable.

show call-control client

To see call information for a call-aware client when Voice-over-IP (VoIP) snooping is enabled and the call is active, use the **show call-control client** command

show call-control client callInfo *client_MAC_address*

Syntax Description

callInfo	Specifies the call-control information.
<i>client_MAC_address</i>	Client MAC address.

Command Default

None.

Examples

This example shows how to display the call information such as the IP port for calls related to the client:

```
> show call-control client callInfo 10.10.10.10.10.10
Uplink IP/port..... 0.0.0.0 / 0
Downlink IP/port..... 9.47.96.107 / 5006
UP..... 6
Calling Party..... sip:1021
Called Party..... sip:1000
Call ID..... 38423970c3fca477
Call on hold: ..... FALSE
Number of calls for given client is..... 1
```

Related Commands

show call-control ap

show client ccx client-capability

To display the client's capability information, use the **show client ccx client-capability** command.

show client ccx client-capability *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Usage Guidelines

This command displays the client's available capabilities, not the current settings for the capabilities.

Examples

This example shows how to display the client's capability:

```
> show client ccx client-capability 00:40:96:a8:f7:98
Service Capability..... Voice, Streaming(uni-directional)
Video, Interactive(bi-directional) Video
Radio Type..... DSSS OFDM(802.11a) HRDSSS(802.11b)
ERP(802.11g)
Radio Type..... DSSS
Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
Tx Power Mode..... Automatic
Rate List(MB)..... 1.0 2.0
Radio Type..... HRDSSS(802.11b)
Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
Tx Power Mode..... Automatic
Rate List(MB)..... 5.5 11.0
Radio Type..... ERP(802.11g)
Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
Tx Power Mode..... Automatic
Rate List(MB)..... 6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0
Are you sure you want to start? (y/N)y Are you sure you want to start? (y/N)
```

Related Commands

config client ccx get-client-capability
config client ccx get-operating-parameters
config client ccx get-profiles
config client ccx stats-request
config client ccx operating-parameters
config client ccx profiles
config client ccx stats-report

show client ccx frame-data

To display the data frames sent from the client for the last test, use the **show client ccx frame-data** command.

show client ccx frame-data *client_mac_address*

Syntax Description

<i>client_mac_address</i>	MAC address of the client.

Examples

This example shows how to display the data frame sent from the client for the last test:

```
> show client ccx frame-data
xx:xx:xx:xx:xx:xx
```

show client ccx last-response-status

To display the status of the last test response, use the **show client ccx last-response-status** command.

show client ccx last-response-status *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to display the status of the last test response:

```
> show client ccx last-response-status
Test Status ..... Success
Response Dialog Token..... 87
Response Status..... Successful
Response Test Type..... 802.1x Authentication Test
Response Time..... 3476 seconds since system boot
```

Related Commands

config client ccx clear-reports
config client ccx clear-results
config client ccx default-gw-ping
config client ccx dhcp-test
config client ccx log-request
config client ccx last-response-status
config client ccx last-test-status

show client ccx last-test-status

To display the status of the last test, use the **show client ccx last-test-status** command.

show client ccx last-test-status *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Examples

This example shows how to display the status of the last test of the client:

```
> show client ccx last-test-status

Test Type ..... Gateway Ping Test
Test Status ..... Pending/Success/Timeout
Dialog Token ..... 15
Timeout ..... 15000 ms
Request Time ..... 1329 seconds since system boot
```

Related Commands

config client ccx clear-reports

config client ccx clear-results

config client ccx default-gw-ping

config client ccx dhcp-test

config client ccx log-request

config client ccx last-response-status

show client ccx log-response

To display a log response, use the **show client ccx log-response** command.

show client ccx log-response {roam | rsna | syslog} *client_mac_address*

Syntax Description

roam	(Optional) Displays the CCX client roaming log response.
rsna	(Optional) Displays the CCX client RSNA log response.
syslog	(Optional) Displays the CCX client system log response.
<i>client_mac_address</i>	Inventory for the specified access point.

Command Default

None.

Examples

This example shows how to display the system log response:

```
> show client ccx log-response syslog 00:40:96:a8:f7:98
Tue Jun 26 18:07:48 2007      Syslog Response LogID=131: Status=Successful
      Event Timestamp=0d 00h 19m 42s 278987us
      Client SysLog = '<11> Jun 19 11:49:47 unravall3777 Mandatory elements missing in the
OID response'
      Event Timestamp=0d 00h 19m 42s 278990us
      Client SysLog = '<11> Jun 19 11:49:47 unravall3777 Mandatory elements missing in the
OID response'
Tue Jun 26 18:07:48 2007      Syslog Response LogID=131: Status=Successful
      Event Timestamp=0d 00h 19m 42s 278987us
      Client SysLog = '<11> Jun 19 11:49:47 unravall3777 Mandatory elements missing in the
OID response'
      Event Timestamp=0d 00h 19m 42s 278990us
      Client SysLog = '<11> Jun 19 11:49:47 unravall3777 Mandatory elements missing in the
OID response'
```

This example shows how to display the client roaming log response:

```
> show client ccx log-response roam 00:40:96:a8:f7:98
Thu Jun 22 11:55:14 2007      Roaming Response LogID=20: Status=Successful
      Event Timestamp=0d 00h 00m 13s 322396us      Source BSSID=00:40:96:a8:f7:98
      Target BSSID=00:0b:85:23:26:70,      Transition Time=100(ms)
      Transition Reason: Normal roam, poor link      Transition Result: Success
Thu Jun 22 11:55:14 2007      Roaming Response LogID=133: Status=Successful
      Event Timestamp=0d 00h 00m 16s 599006us      Source BSSID=00:0b:85:81:06:c2
      Target BSSID=00:0b:85:81:06:c2,      Transition Time=3235(ms)
      Transition Reason: Normal roam, poor link      Transition Result: Success
Thu Jun 22 18:28:48 2007      Roaming Response LogID=133: Status=Successful
      Event Timestamp=0d 00h 00m 08s 815477us      Source BSSID=00:0b:85:81:06:c2
      Target BSSID=00:0b:85:81:06:d2,      Transition Time=3281(ms)
      Transition Reason: First association to WLAN      Transition Result: Success
```

Related Commands

config client ccx log-request

show client ccx manufacturer-info

To display the client manufacturing information, use the **show client ccx manufacturer-info** command.

show client ccx manufacturer-info *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Examples

This example shows how to display the client manufacturing information:

```
> show client ccx manufacturer-info 00:40:96:a8:f7:98
Manufacturer OUI ..... 00:40:96
Manufacturer ID ..... Cisco
Manufacturer Model ..... Cisco Aironet 802.11a/b/g Wireless Adapter
Manufacturer Serial ..... FOC1046N3SX
Mac Address ..... 00:40:96:b2:8d:5e
Radio Type ..... DSSS OFDM(802.11a) HRDSSS(802.11b)
    ERP(802.11g)
Antenna Type ..... Omni-directional diversity
Antenna Gain ..... 2 dBi
Rx Sensitivity:
Radio Type ..... DSSS
Rx Sensitivity ..... Rate:1.0 Mbps, MinRssi:-95, MaxRssi:-30
Rx Sensitivity ..... Rate:2.0 Mbps, MinRssi:-95, MaxRssi:-30
Radio Type ..... HRDSSS(802.11b)
Rx Sensitivity ..... Rate:5.5 Mbps, MinRssi:-95, MaxRssi:-30
Rx Sensitivity ..... Rate:11.0 Mbps, MinRssi:-95, MaxRssi:-30
Radio Type ..... ERP(802.11g)
Rx Sensitivity ..... Rate:6.0 Mbps, MinRssi:-95, MaxRssi:-30
Rx Sensitivity ..... Rate:9.0 Mbps, MinRssi:-95, MaxRssi:-30
Rx Sensitivity ..... Rate:12.0 Mbps, MinRssi:-95, MaxRssi:-30
Rx Sensitivity ..... Rate:18.0 Mbps, MinRssi:-95, MaxRssi:-30
```

Related Commands

config client ccx get-client-capability
config client ccx get-operating-parameters
config client ccx get-profiles
config client ccx get-manufacturer-info

show client ccx operating-parameters

To display the client operating-parameters, use the **show client ccx operating-parameters** command.

show client ccx operating-parameters *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to display the client operating parameters:

```
> show client ccx operating-parameters 00:40:96:b2:8d:5e
Client Mac ..... 00:40:96:b2:8d:5e
Radio Type ..... OFDM(802.11a)
Radio Type ..... OFDM(802.11a)
Radio Channels ..... 36 40 44 48 52 56 60 64 100 104 108 112
116 120 124 128 132 136 140 149 153 157 161 165
Tx Power Mode ..... Automatic
Rate List(MB)..... 6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0
Power Save Mode ..... Normal Power Save
SSID ..... wifi
Security Parameters[EAP Method, Credential]..... None
Auth Method ..... None
Key Management..... None
Encryption ..... None
Device Name ..... Wireless Network Connection 15
Device Type ..... 0
OS Id ..... Windows XP
OS Version ..... 5.1.6.2600 Service Pack 2
IP Type ..... DHCP address
IPv4 Address ..... Available
IP Address ..... 70.0.4.66
Subnet Mask ..... 255.0.0.0
Default Gateway ..... 70.1.0.1
IPv6 Address ..... Not Available
IPv6 Address ..... 0:0:0:0:0:0:0:0:0:0:0:0:0:0:0:0:
IPv6 Subnet Mask ..... 0:0:0:0:0:0:0:0:0:0:0:0:0:0:0:0:
DNS Servers ..... 103.0.48.0
WINS Servers .....
System Name ..... URAVAL3777
Firmware Version ..... 4.0.0.187
Driver Version ..... 4.0.0.187
```

Related Commands

config client ccx get-client-capability
config client ccx get-operating-parameters
config client ccx get-profiles
config client ccx get-manufacturer-info

show client ccx profiles

To display the client profiles, use the **show client ccx profiles** command.

show client ccx profiles *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to display the client profiles:

```
> show client ccx profiles 00:40:96:15:21:ac
Number of Profiles ..... 1
Current Profile ..... 1
Profile ID ..... 1
Profile Name ..... wifiEAP
SSID ..... wifiEAP
Security Parameters [EAP Method, Credential]..... EAP-TLS, Host OS Login Credentials
Auth Method ..... EAP
Key Management ..... WPA2+CCKM
Encryption ..... AES-CCMP
Power Save Mode ..... Constantly Awake
Radio Configuration:
Radio Type..... DSSS
  Preamble Type..... Long preamble
  CCA Method..... Energy Detect + Carrier
Detect/Correlation
  Data Retries..... 6
  Fragment Threshold..... 2342
  Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
  Tx Power Mode..... Automatic
  Rate List (MB)..... 1.0 2.0
Radio Type..... HRDSSS(802.11b)
  Preamble Type..... Long preamble
  CCA Method..... Energy Detect + Carrier
Detect/Correlation
  Data Retries..... 6
  Fragment Threshold..... 2342
  Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
  Tx Power Mode..... Automatic
  Rate List (MB)..... 5.5 11.0
Radio Type..... ERP(802.11g)
  Preamble Type..... Long preamble
  CCA Method..... Energy Detect + Carrier
Detect/Correlation
  Data Retries..... 6
  Fragment Threshold..... 2342
  Radio Channels..... 1 2 3 4 5 6 7 8 9 10 11
  Tx Power Mode..... Automatic
  Rate List (MB)..... 6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0
Radio Type..... OFDM(802.11a)
  Preamble Type..... Long preamble
  CCA Method..... Energy Detect + Carrier
Detect/Correlation
  Data Retries..... 6
  Fragment Threshold..... 2342
  Radio Channels..... 36 40 44 48 52 56 60 64 149 153 157 161
  165
```

```
Tx Power Mode..... Automatic
Rate List (MB)..... 6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0
```

Related Commands

config client ccx get-client-capability
config client ccx get-operating-parameters
config client ccx get-profiles
config client ccx get-manufacturer-info

show client ccx results

To display the results from the last successful diagnostic test, use the **show client ccx results** command.

show client ccx results *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to display the results from the last successful diagnostic test:

```
> show client ccx results xx.xx.xx.xx
dot1x Complete..... Success
EAP Method..... *1,Host OS Login Credentials
dot1x Status..... 255
```

Related Commands

config client ccx test-abort
config client ccx test-association
config client ccx test-dot1x
config client ccx clear-reports
config client ccx clear-results
config client ccx test-profile

show client ccx rm

To display Cisco Client eXtension (CCX) client radio management report information, use the **show client ccx rm** command.

show client ccx rm *client_MAC* {**status** | {**report** {**chan-load** | **noise-hist** | **frame** | **beacon** | **pathloss**}}}

Syntax Description

<i>client_MAC</i>	Client MAC address.
status	Displays the client CCX radio management status information.
report	Displays the client CCX radio management report.
chan-load	Displays radio management channel load reports.
noise-hist	Displays radio management noise histogram reports.
beacon	Displays radio management beacon load reports.
frame	Displays radio management frame reports.
pathloss	Displays radio management path loss reports.

Command Default

None.

Examples

This example shows how to display the client radio management status information:

```
> show client ccx rm 00:40:96:15:21:ac status
Client Mac Address..... 00:40:96:15:21:ac
Channel Load Request..... Enabled
Noise Histogram Request..... Enabled
Beacon Request..... Enabled
Frame Request..... Enabled
Interval..... 30
Iteration..... 10
```

This example shows how to display the client radio management load reports:

```
> show client ccx rm 00:40:96:15:21:ac report chan-load
Channel Load Report
Client Mac Address..... 00:40:96:ae:53:bc
Timestamp..... 788751121
Incapable Flag..... On
Refused Flag..... On
Chan CCA Busy Fraction
-----
1 194
2 86
3 103
```

```

4  0
5  178
6  82
7  103
8  95
9  13
10 222
11 75

```

This example shows how to display the client radio management noise histogram reports:

```

> show client ccx rm 00:40:96:15:21:ac report noise-hist
Noise Histogram Report
Client Mac Address..... 00:40:96:15:21:ac
Timestamp..... 4294967295
Incapable Flag..... Off
Refused Flag..... Off
Chan RPI0 RPI1 RPI2 RPI3 RPI4 RPI5 RPI6 RPI7

```

Related Commands

```

config client ccx default-gw-ping
config client ccx dhcp-test

```

show client ccx stats-report

To display the Cisco Client eXtensions (CCX) statistics report from a specified client device, use the **show client ccx stats-report** command.

show client ccx stats-report *client_mac_address*

Syntax Description

<i>client_mac_address</i>	Client MAC address.

Command Default

None.

Examples

This example shows how to displays the statistics report:

```
> show client ccx stats-report 00:0c:41:07:33:a6
Measurement duration = 1
dot11TransmittedFragmentCount          = 1
dot11MulticastTransmittedFrameCount    = 2
dot11FailedCount                        = 3
dot11RetryCount                        = 4
dot11MultipleRetryCount                 = 5
dot11FrameDuplicateCount                = 6
dot11RTSSuccessCount                   = 7
dot11RTSFailureCount                   = 8
dot11ACKFailureCount                   = 9
dot11ReceivedFragmentCount              = 10
dot11MulticastReceivedFrameCount       = 11
dot11FCSErrorCount                     = 12
dot11TransmittedFrameCount              = 13
```

Related Commands

config client ccx default-gw-ping
config client ccx dhcp-test
config client ccx dns-ping

show client detail

To display detailed information for a client on a Cisco lightweight access point, use the **show client detail** command.

show client detail *mac_address*

Syntax Description	
<i>mac_address</i>	Client MAC address.

Command Default None.

Usage Guidelines The **show client ap** command may list the status of automatically disabled clients. Use the **show exclusionlist** command to display clients on the exclusion list (blacklisted).

Examples This example shows how to display the client detailed information:

```
> show client detail 00:0c:41:07:33:a6
Policy Manager State.....POSTURE_REQD
Policy Manager Rule Created.....Yes
Client MAC Address..... 00:16:36:40:ac:58
Client Username..... N/A
Client State..... Associated
Client NAC OOB State..... QUARANTINE
Guest LAN Id..... 1
IP Address..... Unknown
Session Timeout..... 0
QoS Level..... Platinum
802.1P Priority Tag..... disabled
KTS CAC Capability..... Yes
WMM Support..... Enabled
Power Save..... ON
Diff Serv Code Point (DSCP)..... disabled
Mobility State..... Local
Internal Mobility State..... apfMsMmInitial
Security Policy Completed..... No
Policy Manager State..... WEBAUTH_REQD
Policy Manager Rule Created..... Yes
NPU Fast Fast Notified..... Yes
Last Policy Manager State..... WEBAUTH_REQD
Client Entry Create Time..... 460 seconds
Interface..... wired-guest
FlexConnect Authentication..... Local
FlexConnect Data Switching..... Local
VLAN..... 236
Quarantine VLAN..... 0
Client Statistics:
  Number of Bytes Received..... 66806
    Number of Data Bytes Received..... 160783
    Number of Realtime Bytes Received..... 160783
    Number of Data Bytes Sent..... 23436
    Number of Realtime Bytes Sent..... 23436
    Number of Data Packets Received..... 592
    Number of Realtime Packets Received..... 592
    Number of Data Packets Sent..... 131
    Number of Realtime Packets Sent..... 131
    Number of Interim-Update Sent..... 0
    Number of EAP Id Request Msg Timeouts..... 0
```

```
Number of EAP Request Msg Timeouts..... 0
Number of EAP Key Msg Timeouts..... 0
Number of Data Retries..... 0
Number of RTS Retries..... 0
Number of Duplicate Received Packets..... 3
Number of Decrypt Failed Packets..... 0
Number of Mic Failed Packets..... 0
Number of Mic Missing Packets..... 0
Number of RA Packets Dropped..... 6
Number of Policy Errors..... 0
Radio Signal Strength Indicator..... -50 dBm
Signal to Noise Ratio..... 43 dB
...
```

Related Commands **show client summary**

show client location-calibration summary

To display client location calibration summary information, use the **show client location-calibration summary** command.

show client location-calibration summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the location calibration summary information:

```
> show client location-calibration summary
MAC Address Interval
-----
10:10:10:10:10:10 60
21:21:21:21:21:21 45
```

Related Commands

- show client summary**
- show client summary guest-lan**

show client probing

To display the number of probing clients, use the **show client probing** command.

show client probing

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the number of probing clients:

```
> show client probing
Number of Probing Clients..... 0
```

Related Commands

- show client summary**
- show client summary guest-lan**

show client roam-history

To display the roaming history of a specified client, use the **show client roam-history** command.

show client roam-history *mac_address*

Syntax	Description
<i>mac_address</i>	Client MAC address.

Command Default
None.

Examples
This example shows how to display the roaming history of a specified client: <pre>> show client roam-history 00:14:6c:0a:57:77</pre>

show client summary

To display a summary of clients associated with a Cisco lightweight access point, use the **show client summary** command.

show client summary

Syntax Description This command has no arguments or keywords up to Release 7.4.

Command Default None.

Usage Guidelines Use **show client ap** command to list the status of automatically disabled clients. Use the **show exclusionlist** command to display clients on the exclusion list (blacklisted).

Examples This example shows how to display a summary of the active clients:

```
> show client summary
Number of Clients..... 24
Number of PMIPv6 Clients..... 200
MAC Address      AP Name      Status      WLAN/GLAN/RLAN  Auth  Protocol      Port
Wired  PMIPv6
-----
-----
00:00:15:01:00:01 NMSP-TalwarSIM1-2 Associated    1          Yes  802.11a      13
No      Yes
00:00:15:01:00:02 NMSP-TalwarSIM1-2 Associated    1          Yes  802.11a      13
No      No
00:00:15:01:00:03 NMSP-TalwarSIM1-2 Associated    1          Yes  802.11a      13
No      Yes
00:00:15:01:00:04 NMSP-TalwarSIM1-2 Associated    1          Yes  802.11a      13
No      No
```

Related Commands **show client summary guest-lan**

show client wlan

To display the summary of clients associated with a WLAN, use the **show client wlan** command.

show client wlan *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None

Examples

The following are sample outputs of the **show client wlan** command:

```
Device > show client wlan 1
```

```
Number of Clients in WLAN..... 0
```

Related Commands

config client
show wlan

show dhcp

To display the internal Dynamic Host Configuration Protocol (DHCP) server configuration, use the **show dhcp** command.

show dhcp {leases | summary | scope}

Syntax Description

leases	Displays allocated DHCP leases.
summary	Displays DHCP summary information.
<i>scope</i>	Name of a scope to display the DHCP information for that scope.

Command Default

None.

Examples

This example shows how to display the allocated DHCP leases:

```
> show dhcp leases
No leases allocated.
```

This example shows how to display the DHCP summary information:

```
> show dhcp summary
Scope Name          Enabled          Address Range
003                  No              0.0.0.0 -> 0.0.0.0
```

This example shows how to display the DHCP information for the scope 003:

```
> show dhcp 003
Enabled..... No
Lease Time..... 0
Pool Start..... 0.0.0.0
Pool End..... 0.0.0.0
Network..... 0.0.0.0
Netmask..... 0.0.0.0
Default Routers..... 0.0.0.0 0.0.0.0 0.0.0.0
DNS Domain.....
DNS..... 0.0.0.0 0.0.0.0 0.0.0.0
Netbios Name Servers..... 0.0.0.0 0.0.0.0 0.0.0.0
```

Related Commands

config dhcp proxy
config dhcp timeout
config interface dhcp
config wlan dhcp server
debug dhcp
debug dhcp service-port
debug disable-all

config dhcp
show dhcp proxy

show dhcp proxy

To display the status of DHCP proxy handling, use the **show dhcp proxy** command.

show dhcp proxy

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the status of DHCP proxy information:

```
> show dhcp proxy  
DHCP Proxy Behavior: enabled
```

Related Commands

- config dhcp proxy**
- config dhcp timeout**
- config interface dhcp**
- config wlan dhcp_server**
- debug dhcp**
- debug dhcp service-port**
- debug disable-all**
- show dhcp**
- config dhcp**

show dhcp timeout

To display the DHCP timeout value, use the **show dhcp timeout** command.

show dhcp timeout

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the DHCP timeout value:

```
> show dhcp timeout
DHCP Timeout (seconds)..... 10
```

Related Commands	config dhcp proxy config dhcp config interface dhcp config wlan dhcp_server debug dhcp debug dhcp service-port debug disable-all show dhcp show dhcp proxy

show guest-lan

To display the configuration of a specific wired guest LAN, use the **show guest-lan** command.

show guest-lan *guest_lan_id*

Syntax Description

<i>guest_lan_id</i>	ID of the selected wired guest LAN.

Command Default

None.

Usage Guidelines

To display all wired guest LANs configured on the controller, use the **show guest-lan summary** command.

Examples

This example shows how to display the guest LAN configuration:

```
> show guest-lan 2
Guest LAN Identifier..... 1
Profile Name..... guestlan
Network Name (SSID)..... guestlan
Status..... Enabled
AAA Policy Override..... Disabled
Number of Active Clients..... 1
Exclusionlist Timeout..... 60 seconds
Session Timeout..... Infinity
Interface..... wired
Ingress Interface..... wired-guest
WLAN ACL..... unconfigured
DHCP Server..... 10.20.236.90
DHCP Address Assignment Required..... Disabled
Quality of Service..... Silver (best effort)
Security
  Web Based Authentication..... Enabled
  ACL..... Unconfigured
  Web-Passthrough..... Disabled
  Conditional Web Redirect..... Disabled
  Auto Anchor..... Disabled
Mobility Anchor List
GLAN ID IP Address Status
```

Related Commands

- config guest-lan**
- config guest-lan custom-web ext-webauth-url**
- config guest-lan custom-web global disable**
- config guest-lan custom-web login_page**
- config guest-lan nac**
- config guest-lan security**

show ipv6 acl

To display the IPv6 access control lists (ACLs) that are configured on the controller, use the **show ipv6 acl** command.

show ipv6 acl detailed {*acl_name* | **summary**}

Syntax Description	<i>acl_name</i>	IPv6 ACL name. The name can be up to 32 alphanumeric characters.
	detailed	Displays detailed information about a specific ACL.

Command Default None.

Examples This example shows how to display the detailed information of the access control lists:

```
> show ipv6 acl detailed acl6
Rule Index..... 1
Direction..... Any
IPv6 source prefix..... ::/0
IPv6 destination prefix..... ::/0
Protocol..... Any
Source Port Range..... 0-65535
Destination Port Range..... 0-65535
DSCP..... Any
Flow label..... 0
Action..... Permit
Counter..... 0
Deny Counter..... 0
```

Related Commands **config ipv6 acl**

show ipv6 neighbor-binding

To display the IPv6 neighbor binding data that are configured on the controller, use the **show ipv6 neighbor-binding** command.

show ipv6 neighbor-binding {**capture-policy** | **counters** | **detailed** {**mac** *mac_address* | **port** *port_number* | **vlan** *vlan_id*} | **features** | **policies** | **ra-throttle** {**statistics** *vlan_id* | **routers** *vlan_id*} | **summary**}

Syntax Description

capture-policy	Displays IPv6 next-hop message capture policies.
counters	Displays IPv6 next-hop counters.
detailed	Displays the IPv6 neighbor binding table.
mac	Displays the IPv6 binding table entries for a specific MAC address.
<i>mac_address</i>	Displays the IPv6 binding table entries for a specific MAC address.
port	Displays the IPv6 binding table entries for a specific port.
<i>port_number</i>	Port Number. You can enter ap for an access point or LAG for a LAG port.
vlan	Displays the IPv6 neighbor binding table entries for a specific VLAN.
<i>vlan_id</i>	VLAN identifier.
features	Displays IPv6 next-hop registered features.
policies	Displays IPv6 next-hop policies.
ra-throttle	Displays RA throttle information.
statistics	Displays RA throttle statistics.
routers	Displays RA throttle routers.
summary	Displays the IPv6 neighbor binding table.

Command Default

None.

Examples

This example shows how to display the IPv6 neighbor binding data summary:

```
> show ipv6 neighbor-binding summary
Binding Table has 6 entries, 5 dynamic
Codes: L - Local, S - Static, ND - Neighbor Discovery, DH - DDCP
Preflevel flags (prlvl):
0001:MAC and LLA match      0002:Orig trunk          0004:Orig access
0008:Orig trusted access    0010:Orig trusted trunk   0020:DHCP assigned
```

```

0040:Cga authenticated      0080:Cert authenticated    0100:Statically assigned
   IPv6 address                MAC Address          Port VLAN Type      prlvl age
   state      Time left
-----
ND  fe80::216:46ff:fe43:eb01      00:16:46:43:eb:01      1   980 wired      0005
   2 REACHABLE 157
ND  fe80::9cf9:b009:b1b4:1ed9      70:f1:a1:dd:cb:d4      AP   980 wireless  0005
   2 REACHABLE 157
ND  fe80::6233:4bff:fe05:25ef      60:33:4b:05:25:ef      AP   980 wireless  0005
   2 REACHABLE 203
ND  fe80::250:56ff:fe8b:4a8f      00:50:56:8b:4a:8f      AP   980 wireless  0005
   2 REACHABLE 157
ND  2001:410:0:1:51be:2219:56c6:a8ad 70:f1:a1:dd:cb:d4      AP   980 wireless  0005
   5 REACHABLE 157
S   2001:410:0:1::9              00:00:00:00:00:08      AP   980 wireless  0100
   1 REACHABLE 205

```

This example shows how to display the detailed IPv6 neighbor binding data:

```

> show ipv6 neighbor-binding detailed mac 60:33:4b:05:25:ef
macDB has 3 entries for mac 60:33:4b:05:25:ef, 3 dynamic
Codes: L - Local, S - Static, ND - Neighbor Discovery, DH - DDCP
Preflevel flags (prlvl):
0001:MAC and LLA match      0002:Orig trunk          0004:Orig access
0008:Orig trusted access    0010:Orig trusted trunk  0020:DHCP assigned
0040:Cga authenticated      0080:Cert authenticated  0100:Statically assigned
   IPv6 address                MAC Address          Port VLAN Type      prlvl age
   state      Time left
-----
ND  fe80::6233:4bff:fe05:25ef      60:33:4b:05:25:ef      AP   980 wireless  0009
   0 REACHABLE 303
ND  2001:420:0:1:6233:4bff:fe05:25ef 60:33:4b:05:25:ef      AP   980 wireless  0009
   0 REACHABLE 300
ND  2001:410:0:1:6233:4bff:fe05:25ef 60:33:4b:05:25:ef      AP   980 wireless  0009
   0 REACHABLE 301

```

Related Commands

config ipv6 neighbor-binding

show ipv6 ra-guard

To display the RA guard statistics, use the **show ipv6 ra-guard** command.

show ipv6 ra-guard {ap | wlc} summary

Syntax Description

ap	Displays Cisco access point details.
wlc	Displays Cisco controller details.
summary	Displays RA guard statistics.

Command Default

None.

Examples

This example shows how to display the RA guard statistics for an access point:

```
> show ipv6 ra-guard ap summary
IPv6 RA Guard on AP..... Enabled
RA Dropped per client:
MAC Address      AP Name          WLAN/GLAN      Number of RA Dropped
-----
00:40:96:b9:4b:89 Bhavik_1130_1_p13 2              19
-----
Total RA Dropped on AP..... 19
```

This example shows how to display the RA guard statistics for a controller:

```
> show ipv6 ra-guard wlc summary
IPv6 RA Guard on WLC..... Enabled
```

Related Commands

config ipv6 ra-guard

show ipv6 summary

To display the IPv6 configuration settings, use the **show ipv6 summary** command.

show ipv6 summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the IPv6 configuration settings:

```
> show ipv6 summary
Global Config..... Enabled
Reachable-lifetime value..... 300
Stale-lifetime value..... 86400
Down-lifetime value..... 86400
RA Throttling..... Enabled
RA Throttling allow at-least..... 1
RA Throttling allow at-most..... no-limit
RA Throttling max-through..... no-limit
RA Throttling throttle-period..... 60
RA Throttling interval-option..... throttle
NS Multicast CacheMiss Forwarding..... Disabled
```

Related Commands **show ipv6 acl**

show macfilter

To display the MAC filter parameters, use the **show macfilter** command.

show macfilter {**summary** | **detail** *MAC*}

Syntax Description

summary	Displays a summary of all MAC filter entries.
detail <i>MAC</i>	Displays details of a MAC filter entry.

Command Default

None.

Usage Guidelines

The MAC delimiter (none, colon, or hyphen) for MAC addresses sent to RADIUS servers is displayed. The MAC filter table lists the clients that are always allowed to associate with a wireless LAN.

Examples

This example shows how to display the detailed display of a MAC filter entry:

```
> show macfilter detail xx:xx:xx:xx:xx:xx
MAC Address..... xx:xx:xx:xx:xx:xx
WLAN Identifier..... Any
Interface Name..... management
Description..... RAP
```

This example shows how to display a summary of the MAC filter parameters:

```
> show macfilter summary
MAC Filter RADIUS Compatibility mode..... Cisco ACS
MAC Filter Delimiter..... None
Local Mac Filter Table
MAC Address      WLAN Id      Description
-----
xx:xx:xx:xx:xx:xx Any          RAP
xx:xx:xx:xx:xx:xx Any          PAP2 (2nd hop)
xx:xx:xx:xx:xx:xx Any          PAP1 (1st hop)
```

Related Commands

config macfilter
config macfilter ip-address
config macfilter interface
config macfilter description
config macfilter mac-delimiter
config macfilter radius-compat
config macfilter wlan-id

show pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show pmk-cache** command.

show pmk-cache {all | *MAC*}

Syntax Description

all	Displays information about all entries in the PMK cache.
<i>MAC</i>	Information about a single entry in the PMK cache.

Command Default

None.

Examples

This example shows how to display information about a single entry in the PMK cache:

```
> show pmk-cache xx:xx:xx:xx:xx:xx
```

This example shows how to display information about all entries in the PMK cache:

```
> show pmk-cache all
PMK Cache
```

Station	Entry Lifetime	VLAN Override	IP Override
-----	-----	-----	-----

Related Commands

config pmk-cache delete

show remote-lan

To display information about remote LAN configuration, use the **show remote-lan** command.

show remote-lan { **summary** | *remote-lan-id* }

Syntax Description

summary	Displays a summary of all remote LANs.
<i>remote-lan-id</i>	Remote LAN identifier.

Command Default

None.

Examples

This example shows how to display a summary of all remote LANs:

```
> show remote-lan summary
Number of Remote LANS..... 2
RLAN ID  RLAN Profile Name           Status      Interface Name
-----  -
2         remote                     Disabled    management
8         test                       Disabled    management
```

This example shows configuration information about the remote LAN with the *remote-lan-id* 2:

```
> show remote-lan 2
Remote LAN Identifier..... 2
Profile Name..... remote
Status..... Disabled
MAC Filtering..... Disabled
AAA Policy Override..... Disabled
Network Admission Control
  Radius-NAC State..... Disabled
  SNMP-NAC State..... Disabled
  Quarantine VLAN..... 0
Maximum number of Associated Clients..... 0
Number of Active Clients..... 0
Exclusionlist..... Disabled
Session Timeout..... Infinity
CHD per Remote LAN..... Enabled
Webauth DHCP exclusion..... Disabled
Interface..... management
Remote LAN ACL..... unconfigured
DHCP Server..... Default
DHCP Address Assignment Required..... Disabled
Static IP client tunneling..... Disabled
Radius Servers
  Authentication..... Global Servers
  Accounting..... Global Servers
  Dynamic Interface..... Disabled
Security
  Web Based Authentication..... Enabled
  ACL..... Unconfigured
  Web Authentication server precedence:
    1..... local
    2..... radius
    3..... ldap
  Web-Passthrough..... Disabled
  Conditional Web Redirect..... Disabled
  Splash-Page Web Redirect..... Disabled
```

Related Commands

config memory monitor errors
config memory monitor leaks
debug memory

show rf-profile summary

To display a summary of RF profiles in the controller, use the **show rf-profile summary** command.

show rf-profile summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the summary of RF profile:

```
> show rf-profile summary
Number of RF Profiles..... 2
Out Of Box State..... Disabled
RF Profile Name           Band      Description           Applied
-----
T1a                       5 GHz    <none>                No
T1b                       2.4 GHz  <none>                No
```

Related Commands **show rf-profile details**

config wlan band-select allow

config rf-profile client-trap-threshold

config rf-profile coverage

config rf-profile create

config rf-profile data-rates

config rf-profile delete

config rf-profile description

config rf-profile load-balancing

config rf-profile max-clients

config rf-profile multicast

config rf-profile out-of-box

config rf-profile tx-power-control-thresh-v1

config rf-profile tx-power-control-thresh-v2

config rf-profile tx-power-max

config rf-profile tx-power-min

show rf-profile details

To display the RF profile details in the Cisco wireless LAN controller, use the **show rf-profile details** command.

show rf-profile details *rf-profile-name*

Syntax Description

<i>rf-profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to display the details of an RF profile:

```
> show rf-profile details T1a
Description..... <none>
Radio policy..... 5 GHz
Transmit Power Threshold v1..... -70 dBm
Transmit Power Threshold v2..... -67 dBm
Min Transmit Power..... -10 dBm
Max Transmit Power..... 30 dBm
802.11a Operational Rates
  802.11a 6M Rate..... Mandatory
  802.11a 9M Rate..... Supported
  802.11a 12M Rate..... Mandatory
  802.11a 18M Rate..... Supported
  802.11a 24M Rate..... Mandatory
  802.11a 36M Rate..... Supported
  802.11a 48M Rate..... Supported
  802.11a 54M Rate..... Supported
Max Clients..... 200
Client Trap Threshold..... 50
Multicast Data Rate..... 0
Rx Sop Threshold..... 0 dBm
Cca Threshold..... 0 dBm
Slot Admin State:..... Enabled
Band Select Probe Response..... Disabled
Band Select Cycle Count..... 2 cycles
Band Select Cycle Threshold..... 200 milliseconds
Band Select Expire Suppression..... 20 seconds
Band Select Expire Dual Band..... 60 seconds
Band Select Client Rssi..... -80 dBm
Load Balancing Denial..... 3 count
Load Balancing Window..... 5 clients
Coverage Data..... -80 dBm
Coverage Voice..... -80 dBm
Coverage Exception..... 3 clients
Coverage Level..... 25 %
```

Related Commands

show rf-profile summary
config wlan band-select allow
config rf-profile client-trap-threshold
config rf-profile coverage
config rf-profile create

config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min

show wlan

To display configuration information for a specified wireless LAN or a foreign access point, or to display wireless LAN summary information, use the **show wlan** command.

show wlan { **apgroups** | **summary** | *wlan_id* | **foreignAp** }

Syntax Description	
apgroups	Displays access point group information.
summary	Displays a summary of all wireless LANs.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
foreignAp	Displays the configuration for support of foreign access points.

Command Default None.

Examples This example shows how to display a summary of wireless LANs for wlan_id 1:

```
> show wlan 1
WLAN Identifier..... 1
Profile Name..... aicha
Network Name (SSID)..... aicha
Status..... Enabled
MAC Filtering..... Disabled
Broadcast SSID..... Enabled
AAA Policy Override..... Disabled
Network Admission Control
  RADIUS Profiling Status ..... Disabled
  DHCP ..... Disabled
  HTTP ..... Disabled
Client Profiling Status ..... Disabled
  DHCP ..... Disabled
  HTTP ..... Disabled
  Radius-NAC State..... Enabled
  SNMP-NAC State..... Enabled
Quarantine VLAN..... 0
Maximum number of Associated Clients..... 0
Maximum number of Clients per AP Radio..... 200
Number of Active Clients..... 0
Exclusionlist Timeout..... 60 seconds
Session Timeout..... 1800 seconds
User Idle Timeout..... 300 seconds
User Idle Threshold..... 0 Bytes
NAS-identifier..... Talwar1
CHD per WLAN..... Enabled
Webauth DHCP exclusion..... Disabled
Interface..... management
Multicast Interface..... Not Configured
WLAN IPv4 ACL..... unconfigured
WLAN IPv6 ACL..... unconfigured
mDNS Status..... Disabled
mDNS Profile Name..... unconfigured
DHCP Server..... Default
DHCP Address Assignment Required..... Disabled
Static IP client tunneling..... Enabled
PMIPv6 Mobility Type..... none
```

```

Quality of Service..... Silver (best effort)
Per-SSID Rate Limits..... Upstream      Downstream
Average Data Rate..... 0                0
Average Realtime Data Rate..... 0          0
Burst Data Rate..... 0                0
Burst Realtime Data Rate..... 0          0
Per-Client Rate Limits..... Upstream      Downstream
Average Data Rate..... 0                0
Average Realtime Data Rate..... 0          0
Burst Data Rate..... 0                0
Burst Realtime Data Rate..... 0          0
Scan Defer Priority..... 4,5,6
Scan Defer Time..... 100 milliseconds
WMM..... Allowed
WMM UAPSD Compliant Client Support..... Disabled
Media Stream Multicast-direct..... Disabled
CCX - AironetIe Support..... Enabled
CCX - Gratuitous ProbeResponse (GPR)..... Disabled
CCX - Diagnostics Channel Capability..... Disabled
Dot11-Phone Mode (7920)..... Disabled
Wired Protocol..... None
Passive Client Feature..... Disabled
IPv6 Support..... Disabled
Peer-to-Peer Blocking Action..... Disabled
Radio Policy..... All
DTIM period for 802.11a radio..... 1
DTIM period for 802.11b radio..... 1
Radius Servers
  Authentication..... Global Servers
  Accounting..... Global Servers
  Interim Update..... Disabled
  Dynamic Interface..... Disabled
Local EAP Authentication..... Enabled (Profile 'Controller_Local_EAP')
Security
  802.11 Authentication:..... Open System
  FT Support..... Disabled
  Static WEP Keys..... Disabled
  802.1X..... Disabled
  Wi-Fi Protected Access (WPA/WPA2)..... Enabled
    WPA (SSN IE)..... Enabled
      TKIP Cipher..... Disabled
      AES Cipher..... Enabled
    WPA2 (RSN IE)..... Enabled
      TKIP Cipher..... Disabled
      AES Cipher..... Enabled
Auth Key Management
  802.1x..... Enabled
  PSK..... Disabled
  CCKM..... Enabled
  FT(802.11r)..... Disabled
  FT-PSK(802.11r)..... Disabled
  PMF-1X(802.11w)..... Enabled
  PMF-PSK(802.11w)..... Disabled
FT Reassociation Timeout..... 20
FT Over-The-Air mode..... Enabled
FT Over-The-Ds mode..... Enabled
  GTK Randomization..... Disabled
  SKC Cache Support..... Disabled
  CCKM TSF Tolerance..... 1000
  Wi-Fi Direct policy configured..... Disabled
  EAP-Passthrough..... Disabled
CKIP ..... Disabled
  IP Security..... Disabled
  IP Security Passthru..... Disabled
  Web Based Authentication..... Disabled
  Web-Passthrough..... Disabled
  Conditional Web Redirect..... Disabled
  Splash-Page Web Redirect..... Disabled
  Auto Anchor..... Disabled
  FlexConnect Local Switching..... Enabled
  flexconnect Central Dhcp Flag..... Disabled
  flexconnect nat-pat Flag..... Disabled
  flexconnect Dns Override Flag..... Disabled

```

```

FlexConnect Vlan based Central Switching ..... Disabled
FlexConnect Local Authentication..... Disabled
FlexConnect Learn IP Address..... Enabled
Client MFP..... Optional
PMF..... Disabled
PMF Association Comeback Time..... 1
PMF SA Query RetryTimeout..... 200
Tkip MIC Countermeasure Hold-down Timer..... 60
Call Snooping..... Disabled
Roamed Call Re-Anchor Policy..... Disabled
SIP CAC Fail Send-486-Busy Policy..... Enabled
SIP CAC Fail Send Dis-Association Policy..... Disabled
KTS based CAC Policy..... Disabled
Band Select..... Disabled
Load Balancing..... Disabled

Mobility Anchor List
WLAN ID      IP Address      Status
-----
802.11u..... Enabled
Network Access type..... Chargeable Public Network
Internet service..... Enabled
Network Authentication type..... Not Applicable
HESSID..... 00:00:00:00:00:00
IP Address Type Configuration
IPv4 Address type..... Available
IPv6 Address type..... Not Known

Roaming Consortium List
Index      OUI List      In Beacon
-----
1          313131      Yes
2          DDBBCC      No
3          DDDDDD      Yes

Realm configuration summary
Realm index..... 1
Realm name..... jobin
EAP index..... 1
EAP method..... Unsupported

Index      Inner Authentication      Authentication Method
-----
1          Credential Type      SIM
2          Tunneled Eap Credential Type      SIM
3          Credential Type      SIM
4          Credential Type      USIM
5          Credential Type      Hardware Token
6          Credential Type      SoftToken

Domain name configuration summary
Index      Domain name
-----
1          rom3
2          ram
3          rom1

Hotspot 2.0..... Enabled

Operator name configuration summary
Index      Language      Operator name
-----
1          ros      Robin

Port config summary
Index      IP protocol      Port number      Status
-----
1          1          0          Closed
2          1          0          Closed
3          1          0          Closed
4          1          0          Closed
5          1          0          Closed
6          1          0          Closed
7          1          0          Closed

WAN Metrics Info
Link status..... Up
Symmetric Link..... No

```

```

Downlink speed..... 4 kbps
Uplink speed..... 4 kbps

MSAP Services..... Disabled

```

This example shows how to display a summary of all WLANs:

```

> show wlan summary
Number of WLANs..... 1

WLAN ID  WLAN Profile Name / SSID          Status   Interface Name      PMIPv6
Mobility
-----  -
1         apssso / apssso                        Disabled  management          none

```

This example shows how to display the configuration for support of foreign access points:

```

> show wlan foreignap
Foreign AP support is not enabled.

```

This example shows how to display the AP groups:

```

> show wlan apgroups
Total Number of AP Groups..... 1
Site Name..... APuser
Site Description..... <none>
Venue Name..... Not configured
Venue Group Code.....Unspecified
Venue Type Code.....Unspecified
Language Code..... Not configured
AP Operating Class..... 83,84,112,113,115,116,117,118,123
RF Profile
-----
2.4 GHz band..... <none>
5 GHz band..... <none>
WLAN ID      Interface      Network Admission Control      Radio Policy
-----
14           int 4          Disabled                        All
AP Name      Country  Priority  Slots  AP Model      Ethernet MAC      Location      Port
-----
Ibiza        US       1         2      AIR-CAP2602I-A-K9  44:2b:03:9a:8a:73  default location  1
Larch        US       1         2      AIR-CAP3502E-A-K9  f8:66:f2:ab:23:95  default location  1
Zest         US       1         2      AIR-CAP3502I-A-K9  00:22:90:91:6d:b6  ren           1

Number of Clients..... 1

```

Related Commands

```

config wlan
config wlan 7920-support
config wlan acl
config wlan interface
config wlan roamed-voice-client re-anchor

```

config Commands

This section lists the **config** commands to configure WLANs.

config 802.11 dtpc

To enable or disable the Dynamic Transmit Power Control (DTPC) setting for an 802.11 network, use the **config 802.11 dtpc** command.

config 802.11 {a | b} dtpc {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the support for this command.
disable	Disables the support for this command.

Command Default

Enabled.

Examples

This example shows how to disable DTPC for an 802.11a network:

```
> config 802.11a dtpc disable
```

Related Commands

show 802.11a
config 802.11a beaconperiod
config 802.11a disable
config 802.11a enable

config auto-configure voice

To auto-configure voice deployment in WLANs, use the **config auto-configure voice** command.

config auto-configure voice cisco *wlan_id* **radio** {**802.11a** | **802.11b** | **all**}

Syntax Description		
cisco		Auto-configure WLAN for voice deployment of Cisco end points.
<i>wlan_id</i>		Wireless LAN identifier from 1 to 512 (inclusive).
radio		Auto-configures voice deployment for a radio in a WLAN.
802.11a		Auto-configures voice deployment for 802.11a in a WLAN.
802.11b		Auto-configures voice deployment for 802.11b in a WLAN.
all		Auto-configures voice deployment for all radios in a WLAN.

Command Default None.

Usage Guidelines When you configure this command, all WLANs and radios are automatically disabled. After the completion of the configuration, the previous state of the WLANs and radios is restored.

Examples This example shows how to auto-configure voice deployment for all radios in a WLAN:

```
> config auto-configure voice cisco 2 radio all
Warning! This command will automatically disable all WLAN's and Radio's.
It will be reverted to the previous state once configuration is complete.
Are you sure you want to continue? (y/N)y
```

```
Auto-Configuring these commands in WLAN for Voice..
```

```
wlan qos 2 platinum
- Success
wlan call-snoop enable 2
- Success
wlan wmm allow 2
- Success
wlan session-timeout 2 86400
- Success
wlan peer-blocking disable 2
- Success
wlan security tkip hold-down 0 2
- Success
wlan exclusionlist 2 disable
- Success
wlan mac-filtering disable 2
- Success
wlan dtim 802.11a 2 2
- Success
wlan dtim 802.11b 2 2
- Success
wlan ccx aironetIeSupport enabled 2
- Success
```

```

wlan channel-scan defer-priority 4 enable 2
- Success
wlan channel-scan defer-priority 5 enable 2
- Success
wlan channel-scan defer-priority 6 enable 2
- Success
wlan channel-scan defer-time 100 2
- Success
wlan load-balance allow disable 2
- Success
wlan mfp client enable 2
- Success
wlan security wpa akm cckm enable 2
- Success
wlan security wpa akm cckm timestamp-tolerance 5000 2
- Success
wlan band-select allow disable 2
- Success
*****

```

Auto-Configuring these commands for Voice - Radio 802.11a.

```

advanced 802.11a edca-parameter optimized-voice
- Success
802.11a cac voice acm enable
- Success
802.11a cac voice max-bandwidth 75
- Success
802.11a cac voice roam-bandwidth 6
- Success
802.11a cac voice cac-method load-based
- Success
802.11a cac voice sip disable
- Success
802.11a tsm enable
- Success
802.11a exp-bwreq enable
- Success
802.11a txPower global auto
- Success
802.11a channel global auto
- Success
advanced 802.11a channel dca interval 24
- Success
advanced 802.11a channel dca anchor-time 0
- Success
qos protocol-type platinum dot1p
- Success
qos dot1p-tag platinum 6
- Success
qos priority platinum voice voice besteffort
- Success
802.11a beacon period 100
- Success
802.11a dtpc enable
- Success
802.11a Coverage Voice RSSI Threshold -70
- Success
802.11a txPower global min 11
- Success
advanced eap eapol-key-timeout 250
- Success
advanced 802.11a voice-mac-optimization disable
- Success
802.11h channelswitch enable 1
- Success
Note: Data rate configurations are not changed.
It should be changed based on the recommended values after analysis.
*****

```

Auto-Configuring these commands for Voice - Radio 802.11b.

```

advanced 802.11b edca-parameter optimized-voice
- Success

```



```
802.11b cac voice acm enable
- Success
802.11b cac voice max-bandwidth 75
- Success
802.11b cac voice roam-bandwidth 6
- Success
802.11b cac voice cac-method load-based
- Success
802.11b cac voice sip disable
- Success
802.11b tsm enable
- Success
802.11b exp-bwreq enable
- Success
802.11b txPower global auto
- Success
802.11b channel global auto - Success
advanced 802.11b channel dca interval 24
- Success
advanced 802.11b channel dca anchor-time 0
- Success
802.11b beacon period 100
- Success
802.11b dtpc enable
- Success
802.11b Coverage Voice RSSI Threshold -70
- Success
802.11b preamble short
- Success
advanced 802.11a voice-mac-optimization disable
- Success
Note: Data rate configurations are not changed.
It should be changed based on the recommended values after analysis.
```

config client ccx clear-reports

To clear the client reporting information, use the **config client ccx clear-reports** command.

config client ccx clear-reports *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to clear the reporting information of the client MAC address 00:1f:ca:cf:b6:60:

```
> config client ccx clear-reports 00:1f:ca:cf:b6:60
```

Related Commands

config client ccx get-profiles
config client ccx get-operating-parameters
config client ccx get-client-capability
config client ccx get-manufacturer-info
config client ccx profiles
show client ccx operating-parameters
show client ccx manufacturer-info
show client ccx client-capability
config client ccx stats-request
show client ccx stats-report

config client ccx clear-results

To clear the test results on the controller, use the **config client ccx clear-results** command.

config client ccx clear-results *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to clear the test results of the client MAC address 00:1f:ca:cf:b6:60:

```
> config client ccx clear-results 00:1f:ca:cf:b6:60
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-resolve
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx dns-ping
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx default-gw-ping

To send a request to the client to perform the default gateway ping test, use the **config client ccx default-gw-ping** command.

config client ccx default-gw-ping *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Usage Guidelines

This test does not require the client to use the diagnostic channel.

Examples

This example shows how to send a request to the client 00:0b:85:02:0d:20 to perform the default gateway ping test:

```
> config client ccx default-gw-ping 00:0b:85:02:0d:20
```

Related Commands

config client ccx dns-resolve
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx dhcp-test

To send a request to the client to perform the DHCP test, use the **config client ccx dhcp-test** command.

config client ccx dhcp-test *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Usage Guidelines

This test does not require the client to use the diagnostic channel.

Examples

This example shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DHCP test:

```
> config client ccx dhcp-test 00:E0:77:31:A3:55
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-ping
config client ccx dns-resolve
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx dns-ping

To send a request to the client to perform the Domain Name System (DNS) server IP address ping test, use the **config client ccx dns-ping** command.

config client ccx dns-ping *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Usage Guidelines

This test does not require the client to use the diagnostic channel.

Examples

This example shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DNS server IP address ping test:

```
> config client ccx dns-ping 00:E0:77:31:A3:55
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-resolve
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx dns-resolve

To send a request to the client to perform the Domain Name System (DNS) resolution test to the specified hostname, use the **config client ccx dns-resolve** command.

config client ccx dns-resolve *client_mac_address* *host_name*

Syntax Description

client_mac_address MAC address of the client.

host_name Hostname of the client.

Command Default

None.

Usage Guidelines

This test does not require the client to use the diagnostic channel.

Examples

This example shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DNS name resolution test to the specified hostname:

```
> config client ccx dns-resolve 00:E0:77:31:A3:55 host_name
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-ping
config client ccx dhcp-test
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx get-client-capability

To send a request to the client to send its capability information, use the **config client ccx get-client-capability** command.

config client ccx get-client-capability *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to send a request to the client 172.19.28.40 to send its capability information:

```
> config client ccx get-client-capability 172.19.28.40
```

Related Commands

config client ccx get-profiles
config client ccx get-operating-parameters
config client ccx get-manufacturer-info
config client ccx clear-reports
show client ccx profiles
show client ccx operating-parameters
show client ccx manufacturer-info
show client ccx client-capability
config client ccx stats-request
show client ccx stats-report

config client ccx get-manufacturer-info

To send a request to the client to send the manufacturer's information, use the **config client ccx get-manufacturer-info** command.

config client ccx get-manufacturer-info *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to send a request to the client 172.19.28.40 to send the manufacturer's information:

```
> config client ccx get-manufacturer-info 172.19.28.40
```

Related Commands

config client ccx get-profiles
config client ccx get-operating-parameters
config client ccx get-client-capability
config client ccx clear-reports
config client ccx profiles
show client ccx operating-parameters
show client ccx manufacturer-info
show client ccx client-capability
config client ccx stats-request

config client ccx get-operating-parameters

To send a request to the client to send its current operating parameters, use the **config client ccx get-operating-parameters** command.

config client ccx get-operating-parameters *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to send a request to the client 172.19.28.40 to send its current operating parameters:

```
> config client ccx get-operating-parameters 172.19.28.40
```

Related Commands

config client ccx get-profiles
config client ccx get-manufacturer-info
config client ccx get-client-capability
config client ccx clear-reports
config client ccx profiles
show client ccx stats-request
show client ccx manufacturer-info
show client ccx client-capability
config client ccx stats-report

config client ccx get-profiles

To send a request to the client to send its profiles, use the **config client ccx get-profiles** command.

config client ccx get-profiles *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Examples

This example shows how to send a request to the client 172.19.28.40 to send its profile details:

```
> config client ccx get-profiles 172.19.28.40
```

Related Commands

config client ccx get-manufacturer-info
config client ccx get-operating-parameters
config client ccx get-client-capability
config client ccx clear-reports
config client ccx profiles
show client ccx operating-parameters
show client ccx manufacturer-info
show client ccx client-capability
config client ccx stats-request

config client ccx log-request

To configure a Cisco client eXtension (CCX) log request for a specified client device, use the **config client ccx log-request** command.

config client ccx log-request {roam | rsna | syslog} *client_mac_address*

Syntax Description	roam	(Optional) Specifies the request to specify the client CCX roaming log.
	rsna	(Optional) Specifies the request to specify the client CCX RSNA log.
	syslog	(Optional) Specifies the request to specify the client CCX system log.
	<i>client_mac_address</i>	MAC address of the client.

Command Default None.

Examples This example shows how to specify the request to specify the client CCS system log:

```
> config client ccx log-request syslog 00:40:96:a8:f7:98
Tue Oct 05 13:05:21 2006
SysLog Response LogID=1: Status=Successful
Event Timestamp=121212121212
Client SysLog = 'This is a test syslog 2'
Event Timestamp=121212121212
Client SysLog = 'This is a test syslog 1'
Tue Oct 05 13:04:04 2006
SysLog Request LogID=1
```

This example shows how to specify the client CCX roaming log:

```
> config client ccx log-request roam 00:40:96:a8:f7:98
Thu Jun 22 11:55:14 2006
Roaming Response LogID=20: Status=Successful
Event Timestamp=121212121212
Source BSSID=00:40:96:a8:f7:98, Target BSSID=00:0b:85:23:26:70,
Transition Time=100(ms)
Transition Reason: Unspecified Transition Result: Success
Thu Jun 22 11:55:04 2006
Roaming Request LogID=20
Thu Jun 22 11:54:54 2006
Roaming Response LogID=19: Status=Successful
Event Timestamp=121212121212
Source BSSID=00:40:96:a8:f7:98, Target BSSID=00:0b:85:23:26:70,
Transition Time=100(ms)
Transition Reason: Unspecified Transition Result: Success
Thu Jun 22 11:54:33 2006 Roaming Request LogID=19
```

This example shows how to specify the client CCX RSNA log:

```
> config client ccx log-request rsna 00:40:96:a8:f7:98
Tue Oct 05 11:06:48 2006
RSNA Response LogID=2: Status=Successful
Event Timestamp=242424242424
Target BSSID=00:0b:85:23:26:70
RSNA Version=1
Group Cipher Suite=00-0f-ac-01
Pairwise Cipher Suite Count = 2
Pairwise Cipher Suite 0 = 00-0f-ac-02
Pairwise Cipher Suite 1 = 00-0f-ac-04
AKM Suite Count = 2
KM Suite 0 = 00-0f-ac-01
KM Suite 1 = 00-0f-ac-02
SN Capability = 0x1
PMKID Count = 2
PMKID 0 = 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16
PMKID 1 = 0a 0b 0c 0d 0e 0f 17 18 19 20 1a 1b 1c 1d 1e 1f
802.11i Auth Type: EAP_FAST
RSNA Result: Success
```

Related Commands

show client ccx log-response

config client ccx send-message

To send a message to the client, use the **config client ccx send-message** command.

config client ccx send-message *client_mac_address message_id*

Syntax Description

<i>client_mac_address</i>	MAC address of the client.

<i>message_id</i>	Message type that involves one of the following: • 1—The SSID is invalid. • 2—The network settings are invalid. • 3—There is a WLAN credibility mismatch. • 4—The user credentials are incorrect. • 5—Please call support. • 6—The problem is resolved. • 7—The problem has not been resolved. • 8—Please try again later. • 9—Please correct the indicated problem. • 10—Troubleshooting is refused by the network. • 11—Retrieving client reports. • 12—Retrieving client logs. • 13—Retrieval complete. • 14—Beginning association test. • 15—Beginning DHCP test. • 16—Beginning network connectivity test. • 17—Beginning DNS ping test. • 18—Beginning name resolution test. • 19—Beginning 802.1X authentication test. • 20—Redirecting client to a specific profile. • 21—Test complete. • 22—Test passed. • 23—Test failed. • 24—Cancel diagnostic channel operation or select a WLAN profile to resume normal operation. • 25—Log retrieval refused by the client. • 26—Client report retrieval refused by the client. • 27—Test request refused by the client. • 28—Invalid network (IP) setting. • 29—There is a known outage or problem with the network. • 30—Scheduled maintenance period. (continued on next page)

message_type (cont.)

- 31—The WLAN security method is not correct.
 - 32—The WLAN encryption method is not correct.
 - 33—The WLAN authentication method is not correct.
-

Examples

This example shows how to send a message to the client MAC address 172.19.28.40 with the message user-action-required:

```
> config client ccx send-message 172.19.28.40 user-action-required
```

Related Commands

config client ccx default-gw-ping
config client ccx dhcp
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx dns-ping
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx stats-request

To send a request for statistics, use the **config client ccx stats-request** command.

config client ccx stats-request *measurement_duration* [**dot11** | **security**] *client_mac_address*

Syntax Description

<i>measurement_duration</i>	Measurement duration in seconds.
dot11	(Optional) Specifies dot11 counters.
security	(Optional) Specifies security counters.
<i>client_mac_address</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to specify dot11 counter settings:

```
> config client ccx stats-request 1 dot11 00:40:96:a8:f7:98
Measurement duration = 1
dot11TransmittedFragmentCount      = 1
dot11MulticastTransmittedFrameCount = 2
dot11FailedCount                    = 3
dot11RetryCount                     = 4
dot11MultipleRetryCount              = 5
dot11FrameDuplicateCount             = 6
dot11RTSSuccessCount                 = 7
dot11RTSFailureCount                 = 8
dot11ACKFailureCount                 = 9
dot11ReceivedFragmentCount           = 10
dot11MulticastReceivedFrameCount     = 11
dot11FCSErrorCount                   = 12
dot11TransmittedFrameCount           = 13
```

Related Commands

show client ccx stats-report

config client ccx test-abort

To send a request to the client to abort the current test, use the **config client ccx test-abort** command.

config client ccx test-abort *client_mac_address*

Syntax Description

client_mac_address MAC address of the client.

Command Default

None.

Usage Guidelines

Only one test can be pending at a time.

Examples

This example shows how to send a request to the client 11:11:11:11:11:11 to abort the correct test settings:

```
> config client ccx test-abort 11:11:11:11:11:11
```

Related Commands

config client ccx default-gw-ping
config client ccx dhcp
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx dns-ping
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx test-association

To send a request to the client to perform the association test, use the **config client ccx test-association** command.

config client ccx test-association *client_mac_address* *ssid* *bssid* **802.11** {**a** | **b** | **g**} *channel*

Syntax Description

<i>client_mac_address</i>	MAC address of the client.
<i>ssid</i>	Network name.
<i>bssid</i>	Basic SSID.
802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b network.
802.11g	Specifies the 802.11g network.
<i>channel</i>	Channel number.

Command Default

None.

Examples

This example shows how to send a request to the client MAC address 00:0E:77:31:A3:55 to perform the basic SSID association test:

```
> config client ccx test-association 00:E0:77:31:A3:55 ssid bssid 802.11a
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-resolve
config client ccx dhcp
config client ccx test-dot1x
config client ccx test-profile
config client ccx test-abort
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx test-dot1x

To send a request to the client to perform the 802.1x test, use the **config client ccx test-dot1x** command.

config client ccx test-dot1x *client_mac_address* *profile_id* *bssid* **802.11** {**a** | **b** | **g**} *channel*

Syntax Description

<i>client_mac_address</i>	MAC address of the client.
<i>profile_id</i>	Test profile name.
<i>bssid</i>	Basic SSID.
802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b network.
802.11g	Specifies the 802.11g network.
<i>channel</i>	Channel number.

Command Default

None.

Examples

This example shows how to send a request to the client to perform the 802.11b test with the profile name *profile_01*:

```
> config client ccx test-dot1x 172.19.28.40 profile_01 bssid 802.11b
```

Related Commands

config client ccx default-gw-ping
config client ccx dns-resolve
config client ccx test-association
config client ccx test-dot1x
config client ccx test-profile
config client ccx dhcp
config client ccx clear-results
config client ccx send-message
show client ccx last-test-status
show client ccx last-response-status
show client ccx results
show client ccx frame-data

config client ccx test-profile

To send a request to the client to perform the profile redirect test, use the **config client ccx test-profile** command.

config client ccx test-profile *client_mac_address* *profile_id*

Syntax Description

client_mac_address MAC address of the client.

profile_id Test profile name.

Note The *profile_id* should be from one of the client profiles for which client reporting is enabled.

Command Default

None.

Examples

This example shows how to send a request to the client to perform the profile redirect test with the profile name `profile_01`:

```
> config client ccx test-profile 11:11:11:11:11:11 profile_01
```

Related Commands

config client ccx default-gw-ping

config client ccx dhcp

config client ccx dns-ping

config client ccx dns-resolve

config client ccx test-association

config client ccx test-dot1x

config client ccx test-abort

config client ccx clear-results

config client deauthenticate

To disconnect a client, use the **config client deauthenticate** command.

config client deauthenticate *MAC*

Syntax Description

<i>MAC</i>	Client MAC address.

Command Default

None.

Examples

This example shows how to deauthenticate a client using its MAC address:

```
> config client deauthenticate 11:11:11:11:11
```

Related Commands

show client summary

show client detail

config client location-calibration

To configure link aggregation, use the **config client location-calibration** command.

config client location-calibration {*enable mac_address interval* | *disable mac_address*}

Syntax Description

enable	(Optional) Specifies that client location calibration is enabled.
<i>mac_address</i>	MAC address of the client.
<i>interval</i>	Measurement interval in seconds.
disable	(Optional) Specifies that client location calibration is disabled.

Command Default

None.

Examples

This example shows how to enable the client location calibration for the client 37:15:85:2a with a measurement interval of 45 seconds:

```
> config client location-calibration enable 37:15:86:2a:Bc:cf 45
```

Related Commands

show client location-calibration summary

config ipv6 disable

To disable IPv6 globally on the Cisco WLC, use the **config ipv6 disable** command .

config ipv6 disable

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines When you use this command, the controller drops all IPv6 packets and the clients will not receive any IPv6 address.

Examples This example shows how to disable IPv6 on the controller:

```
> config ipv6 disable
```

Related Commands

- show ipv6 summary**
- config ipv6 acl**
- config ipv6 neighbor-binding**
- config ipv6 ns-mcast-fwd**
- config ipv6 ra-guard**
- config ipv6 enable**

config ipv6 enable

To enable IPv6 globally on the Cisco WLC, use the **config ipv6 enable** command.

config ipv6 enable

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to enable IPv6 on the Cisco WLC: <pre>> config ipv6 enable</pre>

Related Commands	show ipv6 summary config ipv6 acl config ipv6 neighbor-binding config ipv6 ns-mcast-fwd config ipv6 ra-guard config ipv6 disable

config ipv6 acl

To create or delete an IPv6 acl on the Cisco wireless LAN controller, use the **config ipv6 acl** command.

```
config ipv6 acl {apply ipv6_acl_name | create ipv6_acl_name | delete ipv6_acl_name | rule {action rule_name
rule_index {permit | deny} | add rule_name rule_index | change index rule_name old_index new_index |
delete rule_name rule_index | destination address rule_name rule_index ip_address netmask | destination
port range rule_name rule_index start_port end_port | direction rule_name rule_index {in | out | any} |
dscp rule_name rule_index dscp | protocol rule_name rule_index protocol | source address rule_name
rule_index ip_address netmask | source port range rule_name rule_index start_port end_port | swap index
rule_name index_1 index_2}}
```

Syntax Description

apply	Applies an IPv6 ACL.
<i>ipv6_acl_name</i>	IPv6 ACL name that contains up to 32 alphanumeric characters.
create	Creates an IPv6 ACL.
delete	Deletes an IPv6 ACL.
rule	Configures the IPv6 ACL.
action	Configures whether to permit or deny access.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_index</i>	Rule index between 1 and 32.
permit	Permits the rule action.
deny	Denies the rule action.
add	Adds a new rule.
change	Changes a rule's index.
index	Specifies a rule index.
delete	Deletes a rule.
destination address	Configures a rule's destination IP address and netmask.
<i>ip_address</i>	IP address of the rule.
<i>netmask</i>	Netmask of the rule.
<i>start_port</i>	Start port number (between 0 and 65535).
<i>end_port</i>	End port number (between 0 and 65535).

direction	Configures a rule's direction to in, out, or any.
in	Configures a rule's direction to in.
out	Configures a rule's direction to out.
any	Configures a rule's direction to any.
dscp	Configures a rule's DSCP.
<i>dscp</i>	Number between 0 and 63, or any .
protocol	Configures a rule's DSCP.
<i>protocol</i>	Number between 0 and 255, or any .
source address	Configures a rule's source IP address and netmask.
source port range	Configures a rule's source port range.
swap	Swap's two rules' indices.
destination port range	Configure a rule's destination port range.

Command Default None.

Usage Guidelines For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.

Examples This example shows how to configure an IPv6 ACL to permit access:

```
> config ipv6 acl rule action lab1 4 permit
```

Related Commands `show ipv6 acl`

config ipv6 neighbor-binding

To configure the Neighbor Binding table on the Cisco wireless LAN controller, use the **config ipv6 neighbor-binding** command.

```
config ipv6 neighbor-binding {timers {down-lifetime down_time | reachable-lifetime reachable_time |
stale-lifetime stale_time } | { ra-throttle {allow at-least at_least_value} | enable | disable | interval-option
{ ignore | passthrough | throttle } | max-through {no_mcast_RA | no-limit} | throttle-period
throttle_period}}
```

Syntax Description

timers	Configures the neighbor binding table timeout timers.
down-lifetime	Configures the down lifetime.
<i>down_time</i>	Down lifetime in seconds. The range is from 0 to 86400. The default is 30 seconds.
reachable-lifetime	Configures the reachable lifetime.
<i>reachable_time</i>	Reachable lifetime in seconds. The range is from 0 to 86400. The default is 300 seconds.
stale-lifetime	Configures the stale lifetime.
<i>stale_time</i>	Stale lifetime in seconds. The range is from 0 to 86400. The default is 86400 seconds.
ra-throttle	Configures IPv6 RA throttling options.
allow	Specifies the number of multicast RAs per router per throttle period.
<i>at_least_value</i>	Number of multicast RAs from router before throttling. The range is from 0 to 32. The default is 1.
enable	Enables IPv6 RA throttling.
disable	Disables IPv6 RA throttling.
interval-option	Adjusts the behavior on RA with RFC3775 interval option.
ignore	Indicates interval option has no influence on throttling.
passthrough	Indicates all RAs with RFC3775 interval option will be forwarded (default).

throttle	Indicates all RAs with RFC3775 interval option will be throttled.
max-through	Specifies unthrottled multicast RAs per VLAN per throttle period.
<i>no_mcast_RA</i>	Number of multicast RAs on VLAN by which throttling is enforced. The default multicast RAs on vlan is 10.
no-limit	Configures no upper bound at the VLAN level.
throttle-period	Configures the throttle period.
<i>throttle_period</i>	Duration of the throttle period in seconds. The range is from 10 to 86400 seconds. The default is 600 seconds.

Command Default

None.

Examples

This example shows how to configure the Neighbor Binding table:

```
> config ipv6 neighbor-binding ra-throttle
```

Related Commands

```
show ipv6 neighbor-binding
```

config ipv6 ns-mcast-fwd

To configure the nonstop multicast cache miss forwarding, use the **config ipv6 ns-mcast-fwd** command.

config ipv6 ns-mcast-fwd {enable | disable}

Syntax Description

enable	Enables nonstop multicast forwarding on a cache miss.
disable	Disables nonstop multicast forwarding on a cache miss.

Command Default

None.

Examples

This example shows how to configure an nonstop multicast forwarding:

```
> config ipv6 ns-mcast-fwd enable
```

Related Commands

show ipv6 summary

config ipv6 ra-guard

To configure the filter for Router Advertisement (RA) packets that originate from a client on an AP, use the **config ipv6 ra-guard** command.

config ipv6 ra-guard ap {enable | disable}

Syntax Description

enable	Enables RA guard on an AP.
disable	Disables RA guard on an AP.

Command Default

None.

Examples

This example shows how to enable IPv6 RA guard:

```
> config ipv6 ra-guard
```

Related Commands

show ipv6 ra-guard

config remote-lan

To configure a remote LAN, use the **config remote-lan** command.

config remote-lan {**enable** | **disable**} {*remote-lan-id* | **all**}

Syntax Description

enable	Enables a remote LAN.
disable	Disables a remote LAN.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
all	Configures all wireless LANs.

Command Default

None.

Examples

This example shows how to enable a remote LAN with ID 2:

```
> config remote-lan enable 2
```

Related Commands

show remote-lan

config remote-lan aaa-override

To configure user policy override through AAA on a remote LAN, use the **config remote-lan aaa-override** command.

config remote-lan aaa-override {enable | disable} *remote-lan-id*

Syntax Description	enable	Enables user policy override through AAA on a remote LAN.
	disable	Disables user policy override through AAA on a remote LAN.
	<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.

Command Default None.

Examples This example shows how to enable user policy override through AAA on a remote LAN where the remote LAN ID is 2:

```
> config remote-lan aaa-override enable 2
```

Related Commands **show remote-lan**

config remote-lan acl

To specify an access control list (ACL) for a remote LAN, use the **config remote-lan acl** command.

config remote-lan acl *remote-lan-id* *acl_name*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>acl_name</i>	ACL name.
Note	Use the show acl summary command to know the ACLs available.

Command Default

None.

Examples

This example shows how to specify ACL1 for a remote LAN whose ID is 2:

```
> config remote-lan acl 2 ACL1
```

Related Commands

show remote-lan

config remote-lan create

To configure a new remote LAN connection, use the **config remote-lan create** command.

config remote-lan create *remote-lan-id* *name*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>name</i>	Remote LAN name. Valid values are up to 32 alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure a new remote LAN, MyRemoteLAN, with the LAN ID as 3:

```
> config remote-lan create 3 MyRemoteLAN
```

Related Commands

show remote-lan

config remote-lan custom-web

To configure web authentication for a remote LAN, use the **config remote-lan custom-web** command.

config remote-lan custom-web {**ext-webauth-url** *URL* } | **global** {**enable** | **disable**} | **login-page** *page-name* | **loginfailure-page** {*page-name* | **none**} | **logout-page** {*page-name* | **none**} | **webauth-type** {**internal** | **customized** | **external**} } *remote-lan-id*

Syntax Description

ext-webauth-url	Configures an external web authentication URL.
<i>URL</i>	Web authentication URL for the Login page.
global	Configures the global status for the remote LAN.
enable	Enables the global status for the remote LAN.
disable	Disables the global status for the remote LAN.
login-page	Configures a login page.
<i>page-name</i>	Login page name.
none	Configures no login page.
logout-page	Configures a logout page.
none	Configures no logout page.
webauth-type	Configures the web authentication type for the remote LAN.
internal	Displays the default login page.
customized	Displays a downloaded login page.
external	Displays a login page that is on an external server.
<i>name</i>	Remote LAN name. Valid values are up to 32 alphanumeric characters.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are from 1 to 512.

Command Default

None.

Usage Guidelines

Follow these guidelines when you use the **config remote-lan custom-web** command:

- When you configure the external Web-Auth URL, do the following:

- Ensure that Web-Auth or Web-Passthrough Security is in enabled state. To enable Web-Auth, use the **config remote-lan security web-auth enable** command. To enable Web-Passthrough, use the **config remote-lan security web-passthrough enable** command.
 - Ensure that the global status of the remote LAN is in disabled state. To enable the global status of the remote LAN, use the **config remote-lan custom-web global disable** command.
 - Ensure that the remote LAN is in disabled state. To disable a remote LAN, use the **config remote-lan disable** command.
- When you configure the Web-Auth type for the remote LAN, do the following:
 - When you configure a customized login page, ensure that you have a login page configured. To configure a login page, use the **config remote-lan custom-web login-page** command.
 - When you configure an external login page, ensure that you have configured preauthentication ACL for external web authentication to function.

Examples

This example shows how to configure an external web authentication URL for a remote LAN with ID 3:

```
> config remote-lan custom-web ext-webauth-url http://www.AuthorizationURL.com/ 3
```

This example shows how to enable the global status of a remote LAN with ID 3:

```
> config remote-lan custom-web global enable 3
```

This example shows how to configure the login page for a remote LAN with ID 3:

```
> config remote-lan custom-web login-page custompage1 3
```

This example shows how to configure a web authentication type with the default login page for a remote LAN with ID 3:

```
> config remote-lan custom-web webauth-type internal 3
```

Related Commands

show remote-lan

config remote-lan delete

To delete a remote LAN connection, use the **config remote-lan delete** command.

config remote-lan delete *remote-lan-id*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.

Command Default

None.

Examples

This example shows how to delete a remote LAN with ID 3:

```
> config remote-lan delete 3
```

Related Commands

show remote-lan

config remote-lan dhcp_server

To configure a dynamic host configuration protocol (DHCP) server for a remote LAN, use the **config remote-lan dhcp_server** command.

config remote-lan dhcp_server *remote-lan-id* *ip_address*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>ip_address</i>	IP address of the DHCP server.

Command Default

None.

Examples

This example shows how to configure a DHCP server for a remote LAN with ID 3:

```
> config remote-lan dhcp_server 3 209.165.200.225
```

Related Commands

show remote-lan

config remote-lan exclusionlist

To configure the exclusion list timeout on a remote LAN, use the **config remote-lan exclusionlist** command.

config remote-lan exclusionlist *remote-lan-id* {*seconds* | **disabled** | **enabled**}

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>seconds</i>	Exclusion list timeout in seconds. A value of 0 requires an administrator override.
disabled	Disables exclusion listing.
enabled	Enables exclusion listing.

Command Default

None.

Examples

This example shows how to configure the exclusion list timeout to 20 seconds on a remote LAN with ID 3:

```
> config remote-lan exclusionlist 3 20
```

Related Commands

show remote-lan

config remote-lan interface

To configure an interface for a remote LAN, use the **config remote-lan interface** command.

config remote-lan interface *remote-lan-id* *interface_name*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>interface_name</i>	Interface name.
Note	Interface name should not be in upper case characters.

Command Default

None.

Examples

This example shows how to configure an interface myinterface for a remote LAN with ID 3:

```
> config remote-lan interface 3 myinterface
```

Related Commands

show remote-lan

config remote-lan ldap

To configure a remote LAN's LDAP servers, use the **config remote-lan ldap** command.

config remote-lan ldap {**add** | **delete**} *remote-lan-id* *index*

Syntax Description

add	Adds a link to a configured LDAP server (maximum of three).
delete	Deletes a link to a configured LDAP server.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>index</i>	LDAP server index.

Command Default

None.

Examples

This example shows how to add an LDAP server with the index number 10 for a remote LAN with ID 3:

```
> config remote-lan ldap add 3 10
```

Related Commands

show remote-lan

config remote-lan mac-filtering

To configure MAC filtering on a remote LAN, use the **config remote-lan mac-filtering** command.

config remote-lan mac-filtering {enable | disable} *remote-lan-id*

Syntax Description

enable	Enables MAC filtering on a remote LAN.
disable	Disables MAC filtering on a remote LAN.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.

Command Default

Enabled.

Examples

This example shows how to disable MAC filtering on a remote LAN with ID 3:

```
> config remote-lan mac-filtering disable 3
```

Related Commands

show remote-lan

config remote-lan max-associated-clients

To configure the maximum number of client connections on a remote LAN, use the **config remote-lan max-associated-clients** command.

config remote-lan max-associated-clients *remote-lan-id max-clients*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>max-clients</i>	Configures the maximum number of client connections on a remote LAN.

Command Default

None.

Examples

This example shows how to configure 10 client connections on a remote LAN with ID 3:

```
> config remote-lan max-associated-clients 3 10
```

Related Commands

show remote-lan

config remote-lan radius_server

To configure the RADIUS servers on a remote LAN, use the **config remote-lan radius_server** command.

```
config remote-lan radius_server {acct {{add | delete} server-index | {enable | disable} | interim-update {interval | enable | disable}} | auth {{add | delete} server-index | {enable | disable}} | overwrite-interface {enable | disable}} remote-lan-id
```

Syntax Description

acct	Configures a RADIUS accounting server.
add	Adds a link to a configured RADIUS server.
delete	Deletes a link to a configured RADIUS server.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>server-index</i>	RADIUS server index.
enable	Enables RADIUS accounting for this remote LAN.
disable	Disables RADIUS accounting for this remote LAN.
interim-update	Enables RADIUS accounting for this remote LAN.
<i>interval</i>	Accounting interim interval. The range is from 180 to 3600 seconds.
enable	Enables accounting interim update.
disable	Disables accounting interim update.
auth	Configures a RADIUS authentication server.
enable	Enables RADIUS authentication for this remote LAN.
disable	Disables RADIUS authentication for this remote LAN.
overwrite-interface	Configures a RADIUS dynamic interface for the remote LAN.
enable	Enables a RADIUS dynamic interface for the remote LAN.
disable	Disables a RADIUS dynamic interface for the remote LAN.

Command Default

The default interim update interval is 600 seconds.

Examples

This example shows how to enable RADIUS accounting for a remote LAN with ID 3:

```
> config remote-lan radius_server acct enable 3
```

Related Commands

show remote-lan

config remote-lan security

To configure security policy for a remote LAN, use the **config remote-lan security** command.

```
config remote-lan security {{web-auth {enable | disable | acl | server-precedence} remote-lan-id |
{web-passthrough {enable | disable | acl | email-input} remote-lan-id}}
```

Syntax Description

web-auth	Specifies web authentication.
enable	Enables the web authentication settings.
disable	Disables the web authentication settings.
acl	Configures an access control list.
server-precedence	Configures the authentication server precedence order for web authentication users.
<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
email-input	Configures the web captive portal using an e-mail address.
web-passthrough	Specifies the web captive portal with no authentication required.

Command Default

None.

Examples

This example shows how to configure the security web authentication policy for remote LAN ID 1:

```
> config remote-lan security web-auth enable 1
```

Related Commands

show remote-lan

config remote-lan session-timeout

To configure client session timeout, use the **config remote-lan session-timeout** command.

config remote-lan session-timeout *remote-lan-id seconds*

Syntax Description

<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
<i>seconds</i>	Timeout or session duration in seconds. A value of zero is equivalent to no timeout.

Command Default

None.

Examples

This example shows how to configure the client session timeout to 6000 seconds for a remote LAN with ID 1:

```
> config remote-lan session-timeout 1 6000
```

Related Commands

show remote-lan

config remote-lan webauth-exclude

To configure web authentication exclusion on a remote LAN, use the **config remote-lan webauth-exclude** command.

config remote-lan webauth-exclude *remote-lan-id* {**enable** | **disable**}

Syntax Description		
	<i>remote-lan-id</i>	Remote LAN identifier. Valid values are between 1 and 512.
	enable	Enables web authentication exclusion on the remote LAN.
	disable	Disables web authentication exclusion on the remote LAN.

Command Default None.

Examples This example shows how to enable web authentication exclusion on a remote LAN with ID 1:

```
> config remote-lan webauth-exclude 1 enable
```

Related Commands **show remote-lan**

config rf-profile band-select

To configure the RF profile band selection parameters, use the **config rf-profile band-select** command.

config rf-profile band-select {**client-rssi** *rssi* | **cycle-count** *cycles* | **cycle-threshold** *value* | **expire** {**dual-band** *value* | **suppression** *value*} | **probe-response** {**enable** | **disable**}} *profile_name*

Syntax Description

client-rssi	Configures the client Received Signal Strength Indicator (RSSI) threshold for the RF profile.
<i>rssi</i>	Minimum RSSI for a client to respond to a probe. The range is from -20 to -90 dBm.
cycle-count	Configures the probe cycle count for the RF profile. The cycle count sets the number of suppression cycles for a new client.
<i>cycles</i>	Value of the cycle count. The range is from 1 to 10.
cycle-threshold	Configures the time threshold for a new scanning RF Profile band select cycle period. This setting determines the time threshold during which new probe requests from a client come in a new scanning cycle.
<i>value</i>	Value of the cycle threshold for the RF profile. The range is from 1 to 1000 milliseconds.
expire	Configures the expiration time of clients for band select.
dual-band	Configures the expiration time for pruning previously known dual-band clients. After this time elapses, clients become new and are subject to probe response suppression.
<i>value</i>	Value for a dual band. The range is from 10 to 300 seconds.
suppression	Configures the expiration time for pruning previously known 802.11b/g clients. After this time elapses, clients become new and are subject to probe response suppression.
<i>value</i>	Value for suppression. The range is from 10 to 200 seconds.
probe-response	Configures the probe response for a RF profile.
enable	Enables probe response suppression on clients operating in the 2.4-GHz band for a RF profile.
disable	Disables probe response suppression on clients operating in the 2.4-GHz band for a RF profile.
<i>profile name</i>	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

The default value for client RSSI is –80 dBm.

The default cycle count is 2.

The default cycle threshold is 200 milliseconds.

The default value for dual-band expiration is 60 seconds.

The default value for suppression expiration is 20 seconds.

Usage Guidelines

When you enable band select on a WLAN, the access point suppresses client probes on 2.4-GHz and moves the dual band clients to the 5-GHz spectrum. The band-selection algorithm directs dual-band clients only from the 2.4-GHz radio to the 5-GHz radio of the same access point, and it only runs on an access point when both the 2.4-GHz and 5-GHz radios are up and running. Band selection can be used only with Cisco Aironet 1040, 1140, and 1250 Series and the 3500 series access points.

Examples

This example shows how to configure the client RSSI:

```
> config rf-profile band-select client-rssi -70
```

Related Commands

show rf-profile details

config wlan band-select allow

config rf-profile client-trap-threshold

config rf-profile coverage

config rf-profile create

config rf-profile data-rates

config rf-profile delete

config rf-profile description

config rf-profile load-balancing

config rf-profile max-clients

config rf-profile multicast

config rf-profile out-of-box

config rf-profile tx-power-control-thresh-v1

config rf-profile tx-power-control-thresh-v2

config rf-profile tx-power-max

config rf-profile tx-power-min

config rf-profile client-trap-threshold

To configure the threshold value of the number of clients that associate with an access point, after which an SNMP trap is sent to the controller, use the **config rf-profile client-trap-threshold** command.

config rf-profile client-trap-threshold *threshold profile_name*

Syntax Description

<i>threshold</i>	Threshold value of the number of clients that associate with an access point, after which an SNMP trap is sent to the controller. The range is from 0 to 200. Traps are disabled if the threshold value is configured as zero.
<i>profile_name</i>	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure the threshold value of the number of clients that associate with an access point:

```
> config rf-profile client-trap-threshold 150
```

Related Commands

- show rf-profile details
- show rf-profile summary
- config rf-profile coverage
- config rf-profile create
- config rf-profile data-rates
- config rf-profile delete
- config rf-profile description
- config rf-profile load-balancing
- config rf-profile max-clients
- config rf-profile multicast data-rate
- config rf-profile out-of-box
- config rf-profile tx-power-control-thresh-v1
- config rf-profile tx-power-control-thresh-v2
- config rf-profile tx-power-max
- config rf-profile tx-power-min
- config rf-profile band-select

config rf-profile create

To create a RF profile, use the **config rf-profile create** command.

config rf-profile create {802.11a | 802.11b/g} *profile-name*

Syntax Description

802.11a	Configures the RF profile for the 2.4GHz band.
802.11b/g	Configures the RF profile for the 5GHz band.
<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to create a new RF profile:

```
> config rf-profile create 802.11a RFtestgroup1
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile coverage

To configure the RF profile coverage hole detection parameters, use the **config rf-profile coverage** command.

config rf-profile coverage { **data** *coverage_level* | **exception** *clients* | **level** *value* | **voice** *coverage_level* } *profile_name*

Syntax Description

data	Configures the threshold value of the data RSSI.
<i>coverage_level</i>	Minimum receive signal strength indication (RSSI) value of data packets received by the access point. The value that you configure is used to identify coverage holes within the network. If the access point receives a packet in the data queue with an RSSI value below the value that you enter here, a potential coverage hole is detected. The range is from –90 to –60 dBm. The access point takes voice RSSI measurements every 5 seconds and reports them to the controller in 90-second intervals.
exception	Configures the coverage exception per access point.
<i>clients</i>	Minimum number of clients on an access point with an RSSI value at or below the data or voice RSSI threshold. The range is from 1 to 75. The default value is 3.
voice	Configures the threshold value of the voice RSSI.
<i>coverage_level</i>	Minimum receive signal strength indication (RSSI) value of voice packets received by the access point. The value that you configure is used to identify coverage holes within the network. If the access point receives a packet in the data queue with an RSSI value below the value that you enter here, a potential coverage hole is detected. The range is from –90 to –60 dBm. The access point takes voice RSSI measurements every 5 seconds and reports them to the controller in 90-second intervals.
level	Configures the coverage exception level per AP.
<i>value</i>	Coverage exception level per AP. Percentage of clients on an access point that are experiencing a low signal level but cannot roam to another access point. The controller determines if the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.
<i>profile_name</i>	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

The default value of the data coverage level is –80 dBm.

The default value of the minimum number of clients on an access point with an RSSI value at or below the data or voice RSSI threshold is 3.

The default value of the percentage of clients on an access point that are experiencing a low signal level is 25%.

The default value of the voice coverage level is –80 dBm.

Examples

This example shows how to configure the threshold value of the data RSSI:

```
> config rf-profile coverage data -80
```

This example shows how to configure the minimum client coverage exception level:

```
> config rf-profile coverage exception 10
```

This example shows how to configure the coverage exception level per AP:

```
> config rf-profile coverage level 30
```

Related Commands

- show rf-profile details
- config rf-profile client-trap-threshold
- config rf-profile create
- config rf-profile data-rates
- config rf-profile delete
- config rf-profile description
- config rf-profile load-balancing
- config rf-profile max-clients
- config rf-profile multicast
- config rf-profile out-of-box
- config rf-profile tx-power-control-thresh-v1
- config rf-profile tx-power-control-thresh-v2
- config rf-profile tx-power-max
- config rf-profile tx-power-min
- config rf-profile band-select

config rf-profile data-rates

To configure the data rate on a RF profile, use the **config rf-profile data-rates** command.

config rf-profile data-rates {802.11a | 802.11b} {disabled | mandatory | supported} *data-rate profile-name*

Syntax Description

802.11a	Specifies 802.11a as the radio policy of the RF profile.
802.11b	Specifies 802.11b as the radio policy of the RF profile.
disabled	Disables a rate.
mandatory	Sets a rate to mandatory.
supported	Sets a rate to supported.
<i>data-rate</i>	802.11 operational rates, which are 1*, 2*, 5.5*, 6, 9, 11*, 12, 18, 24, 36, 48 and 54, where * denotes 802.11b only rates.
<i>profile-name</i>	Name of the RF profile.

Command Default

Default data rates for RF profiles are derived from the controller system defaults, the global data rate configurations. For example, if the RF profile's radio policy is mapped to 802.11a then the global 802.11a data rates are copied into the RF profiles at the time of creation.

The data rates set with this command are negotiated between the client and the Cisco wireless LAN controller. If the data rate is set to mandatory, the client must support it in order to use the network. If a data rate is set as supported by the Cisco wireless LAN controller, any associated client that also supports that rate may communicate with the Cisco lightweight access point using that rate. It is not required that a client is able to use all the rates marked supported in order to associate.

Examples

This example shows how to set the 802.11b transmission of an RF profile at a mandatory rate at 12 Mbps:

```
> config rf-profile 802.11b data-rates mandatory 12 RFGroup1
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing

config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile delete

To delete a RF profile, use the **config rf-profile delete** command.

config rf-profile delete *profile-name*

Syntax Description

<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to delete a RF profile:

```
> config rf-profile delete RFGroup1
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile description

To provide a description to a RF profile, use the **config rf-profile description** command.

config rf-profile description *description profile-name*

Syntax Description

<i>description</i>	Description of the RF profile.
<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to add a description to a RF profile:

```
> config rf-profile description This is a demo description RFGGroup1
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile load-balancing

To configure load balancing on an RF profile, use the **config rf-profile load-balancing** command.

config rf-profile load-balancing {**window** *clients* | **denial** *value*} *profile_name*

Syntax Description

window	Configures the client window for load balancing of an RF profile.
<i>clients</i>	Client window size that limits the number of client associations with an access point. The range is from 0 to 20. The default value is 5. The window size is part of the algorithm that determines whether an access point is too heavily loaded to accept more client associations: $\text{load-balancing window} + \text{client associations on AP with lightest load} = \text{load-balancing threshold}$ Access points with more client associations than this threshold are considered busy, and clients can associate only to access points with client counts lower than the threshold. This window also helps to disassociate sticky clients.
denial	Configures the client denial count for load balancing of an RF profile.
<i>value</i>	Maximum number of association denials during load balancing. The range is from 1 to 10. The default value is 3. When a client tries to associate on a wireless network, it sends an association request to the access point. If the access point is overloaded and load balancing is enabled on the controller, the access point sends a denial to the association request. If there are no other access points in the range of the client, the client tries to associate the same access point again. After the maximum denial count is reached, the client is able to associate. Association attempts on an access point from any client before associating any AP is called a sequence of association. The default is 3.
<i>profile_name</i>	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure the client window size for an RF profile:

```
> config rf-profile load-balancing window 15
```

Related Commands

show rf-profile details
show load-balancing
config wlan load-balance allow
config rf-profile client-trap-threshold

config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile max-clients

To configure the maximum number of client connections per access point of an RF profile, use the **config rf-profile max-clients** commands.

config rf-profile max-clients *clients*

Syntax Description

clients

Maximum number of client connections per access point of an RF profile. The range is from 1 to 200.

Command Default

None.

Usage Guidelines

You can use this command to configure the maximum number of clients on access points that are in client dense areas, or serving high bandwidth video or mission critical voice applications.

Examples

This example shows how to set the maximum number of clients at 50:

```
> config rf-profile max-clients 50
```

Related Commands

show rf-profile details
config wlan max-radio-clients
config wlan max-associated-clients
config rf-profile client-trap-threshold
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile multicast
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile multicast data-rate

To configure the minimum RF profile multicast data rate, use the **config rf-profile multicast data-rate** command.

config rf-profile multicast data-rate *value profile_name*

Syntax Description	
<i>value</i>	Minimum RF profile multicast data rate. The options are 6, 9, 12, 18, 24, 36, 48, 54. Enter 0 to specify that access points will dynamically adjust the data rate.
<i>profile_name</i>	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default The default is 0.

Examples This example shows how to set the multicast data rate for an RF profile:

```
> config rf-profile multicast data-rate 24
```

Related Commands

- show rf-profile details
- config 802.11 multicast data-rate
- config rf-profile client-trap-threshold
- config rf-profile coverage
- config rf-profile create
- config rf-profile data-rates
- config rf-profile delete
- config rf-profile description
- config rf-profile load-balancing
- config rf-profile max-clients
- config rf-profile out-of-box
- config rf-profile tx-power-control-thresh-v1
- config rf-profile tx-power-control-thresh-v2
- config rf-profile tx-power-max
- config rf-profile tx-power-min
- config rf-profile band-select

config rf-profile out-of-box

To create an out-of-box AP group consisting of newly installed access points, use the **config rf-profile out-of-box** command.

config rf-profile out-of-box {enable | disable}

Syntax Description

enable	Enables the creation of an out-of-box AP group. When you enable this command, the following occurs: • Newly installed access points that are part of the default AP group will be part of the out-of-box AP group and their radios will be switched off, which eliminates any RF instability caused by the new access points. • All access points that do not have a group name become part of the out-of-box AP group. • Special RF profiles are created per 802.11 band. These RF profiles have default-settings for all the existing RF parameters and additional new configurations.
disable	Disables the out-of-box AP group. When you disable this feature, only the subscription of new APs to the out-of-box AP group stops. All APs that are subscribed to the out-of-box AP group remain in this AP group. You can move APs to the default group or a custom AP group upon network convergence.

Command Default

None.

Usage Guidelines

When an out-of-box AP associates with the controller for the first time, it will be redirected to a special AP group and the RF profiles applicable to this AP Group will control the radio admin state configuration of the AP. You can move APs to the default group or a custom group upon network convergence.

Examples

This example shows how to enable the creation of an out-of-box AP group:

```
> config rf-profile out-of-box enable
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile client-trap-threshold
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description

config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile tx-power-control-thresh-v1

To configure Transmit Power Control version1 (TPCv1) to an RF profile, use the **config rf-profile tx-power-control-thresh-v1** command.

config rf-profile tx-power-control-thresh-v1 *tpc-threshold profile_name*

Syntax Description

<i>tpc-threshold</i>	TPC threshold.
<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to configure TPCv1 on an RF profile:

```
> config rf-profile tx-power-control-thresh-v1 RFGroup1
```

Related Commands

- show rf-profile details
- show rf-profile summary
- config rf-profile coverage
- config rf-profile create
- config rf-profile data-rates
- config rf-profile delete
- config rf-profile description
- config rf-profile load-balancing
- config rf-profile max-clients
- config rf-profile multicast data-rate
- config rf-profile out-of-box
- config rf-profile tx-power-control-thresh-v2
- config rf-profile tx-power-max
- config rf-profile tx-power-min
- config rf-profile band-select

config rf-profile tx-power-control-thresh-v2

To configure Transmit Power Control version 2 (TPCv2) to an RF profile, use the **config rf-profile tx-power-control-thresh-v2** command.

config rf-profile tx-power-control-thresh-v2 *tpc-threshold profile-name*

Syntax Description		
	<i>tpc-threshold</i>	TPC threshold.
	<i>profile-name</i>	Name of the RF profile.

Command Default None.

Examples This example shows how to configure TPCv2 on an RF profile:

```
> config rf-profile tx-power-control-thresh-v2 RFGroup1
```

Related Commands

- show rf-profile details
- show rf-profile summary
- config rf-profile coverage
- config rf-profile create
- config rf-profile data-rates
- config rf-profile delete
- config rf-profile description
- config rf-profile load-balancing
- config rf-profile max-clients
- config rf-profile multicast data-rate
- config rf-profile out-of-box
- config rf-profile tx-power-control-thresh-v1
- config rf-profile tx-power-max
- config rf-profile tx-power-min
- config rf-profile band-select

config rf-profile tx-power-max

To configure maximum auto-rf to an RF profile, use the **config rf-profile tx-power-max** command.

config rf-profile *tx-power-max profile-name*

Syntax Description

<i>tx-power-max</i>	Maximum auto-rf tx power.
<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to configure tx-power-max on an RF profile:

```
> config rf-profile tx-power-max RFGroup1
```

Related Commands

show rf-profile details
show rf-profile summary
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile client-trap-threshold
config rf-profile tx-power-min
config rf-profile band-select

config rf-profile tx-power-min

To configure minimum auto-rf to an RF profile, use the **config rf-profile tx-power-min** command.

config rf-profile tx-power-min *tx-power-min profile-name*

Syntax Description

<i>tx-power-min</i>	Minimum auto-rf tx power.
<i>profile-name</i>	Name of the RF profile.

Command Default

None.

Examples

This example shows how to configure tx-power-min on an RF profile:

```
> config rf-profile tx-power-min RFGroup1
```

Related Commands

show rf-profile details
config rf-profile coverage
config rf-profile create
config rf-profile data-rates
config rf-profile delete
config rf-profile description
config rf-profile load-balancing
config rf-profile max-clients
config rf-profile multicast data-rate
config rf-profile out-of-box
config rf-profile tx-power-control-thresh-v1
config rf-profile tx-power-control-thresh-v2
config rf-profile tx-power-max
config rf-profile client-trap-threshold
config rf-profile band-select

config watchlist add

To add a watchlist entry for a wireless LAN, use the **config watchlist add** command.

config watchlist add {**mac** *MAC* | **username** *username*}

Syntax Description

mac <i>MAC</i>	Specifies the MAC address of the wireless LAN.
username <i>username</i>	Specifies the name of the user to watch.

Command Default

None.

Examples

This example shows how to add a watchlist entry for the MAC address a5:6b:ac:10:01:6b:

```
> config watchlist add mac a5:6b:ac:10:01:6b
```

Related Commands

config watchlist delete
config watchlist enable
config watchlist disable
show watchlist

config watchlist delete

To delete a watchlist entry for a wireless LAN, use the **config watchlist delete** command.

config watchlist delete {**mac** *MAC* | **username** *username*}

Syntax Description

mac <i>MAC</i>	Specifies the MAC address of the wireless LAN to delete from the list.
username <i>username</i>	Specifies the name of the user to delete from the list.

Command Default

None.

Examples

This example shows how to delete a watchlist entry for the MAC address a5:6b:ac:10:01:6b:

```
> config watchlist delete mac a5:6b:ac:10:01:6b
```

Related Commands

config watchlist add
config watchlist enable
config watchlist disable
show watchlist

config watchlist disable

To disable the client watchlist, use the **config watchlist disable** command.

config watchlist disable

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to disable the client watchlist:

```
> config watchlist disable
```

Related Commands

- config watchlist delete**
- config watchlist enable**
- config watchlist add**
- show watchlist**

config watchlist enable

To enable a watchlist entry for a wireless LAN, use the **config watchlist enable** command.

config watchlist enable

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to enable a watchlist entry:

```
> config watchlist enable
```

Related Commands	config watchlist add config watchlist delete show watchlist

config wlan

To create, delete, enable, or disable a wireless LAN, use the **config wlan** command.

config wlan {**enable** | **disable** | **create** | **delete**} *wlan_id* [*name* | **foreignAp** *name ssid* | **all**]

Syntax Description

enable	Enables a wireless LAN.
disable	Disables a wireless LAN.
create	Creates a wireless LAN.
delete	Deletes a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>name</i>	(Optional) WLAN profile name up to 32 alphanumeric characters.
foreignAp	(Optional) Specifies the third-party access point settings.
<i>ssid</i>	SSID (network name) up to 32 alphanumeric characters.
all	(Optional) Specifies all wireless LANs.

Command Default

None.

Usage Guidelines

When you create a new WLAN using the **config wlan create** command, it is created in disabled mode. Leave it disabled until you have finished configuring it.

If you do not specify an SSID, the profile *name* parameter is used for both the profile name and the SSID.

If the management and AP-manager interfaces are mapped to the same port and are members of the same VLAN, you must disable the WLAN before making a port-mapping change to either interface. If the management and AP-manager interfaces are assigned to different VLANs, you do not need to disable the WLAN.

An error message appears if you try to delete a WLAN that is assigned to an access point group. If you proceed, the WLAN is removed from the access point group and from the access point's radio.

Examples

This example shows how to enable wireless LAN identifier 16:

```
> config wlan enable 16
```

Related Commands

show ap wlan
show wlan

config wlan 7920-support

To configure support for phones, use the **config wlan 7920-support** command.

config wlan 7920-support {**client-cac-limit** | **ap-cac-limit**} {**enable** | **disable**} *wlan_id*

Syntax Description

ap-cac-limit	Supports phones that require client-controlled Call Admission Control (CAC) that expect the Cisco vendor-specific information element (IE).
client-cac-limit	Supports phones that require access point-controlled CAC that expect the IEEE 802.11e Draft 6 QBSS-load.
enable	Enables phone support.
disable	Disables phone support.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

You cannot enable both WMM mode and client-controlled CAC mode on the same WLAN.

Examples

This example shows how to enable the phone support that requires client-controlled CAC with wireless LAN ID 8:

```
> config wlan 7920-support ap-cac-limit enable 8
```

Related Commands

show wlan

config wlan 802.11e

To configure 802.11e support on a wireless LAN, use the **config wlan 802.11e** command.

config wlan 802.11e {**allow** | **disable** | **require**} *wlan_id*

Syntax Description

allow	Allows 802.11e-enabled clients on the wireless LAN.
disable	Disables 802.11e on the wireless LAN.
require	Requires 802.11e-enabled clients on the wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

802.11e provides quality of service (QoS) support for LAN applications, which are critical for delay sensitive applications such as Voice over Wireless IP (VoWIP).

802.11e enhances the 802.11 Media Access Control layer (MAC layer) with a coordinated time division multiple access (TDMA) construct, and adds error-correcting mechanisms for delay sensitive applications such as voice and video. The 802.11e specification provides seamless interoperability and is especially well suited for use in networks that include a multimedia capability.

Examples

This example shows how to allow 802.11e on the wireless LAN with LAN ID 1:

```
> config wlan 802.11e allow 1
```

Related Commands

show trapflags

config wlan aaa-override

To configure a user policy override via AAA on a wireless LAN, use the **config wlan aaa-override** command.

config wlan aaa-override {enable | disable} {wlan_id | foreignAp}

Syntax Description

enable	Enables a policy override.
disable	Disables a policy override.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

Disabled.

Usage Guidelines

When AAA override is enabled and a client has conflicting AAA and Cisco wireless LAN controller wireless LAN authentication parameters, client authentication is performed by the AAA server. As part of this authentication, the operating system will move clients from the default Cisco wireless LAN VLAN to a VLAN returned by the AAA server and predefined in the controller interface configuration (only when configured for MAC filtering, 802.1X, and/or WPA operation). In all cases, the operating system will also use QoS, DSCP, 802.1p priority tag values, and ACLs provided by the AAA server, as long as they are predefined in the controller interface configuration. (This VLAN switching by AAA override is also referred to as Identity Networking.)

If the corporate wireless LAN uses a management interface assigned to VLAN 2, and if AAA override returns a redirect to VLAN 100, the operating system redirects all client transmissions to VLAN 100, regardless of the physical port to which VLAN 100 is assigned.

When AAA override is disabled, all client authentication defaults to the controller authentication parameter settings, and authentication is performed by the AAA server if the controller wireless LAN does not contain any client-specific authentication parameters.

The AAA override values might come from a RADIUS server.

Examples

This example shows how to configure user policy override via AAA on WLAN ID 1:

```
> config wlan aaa-override enable 1
```

Related Commands

show wlan

config wlan acl

To configure a wireless LAN access control list (ACL), use the **config wlan acl** command.

config wlan acl [*acl_name* | **none**]

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier (1 to 512).
<i>acl_name</i>	(Optional) ACL name.
none	(Optional) Clears the ACL settings for the specified wireless LAN.

Command Default

None.

Examples

This example shows how to configure a WLAN access control list with WLAN ID 1 and ACL named office_1:

```
> config wlan acl 1 office_1
```

Related Commands

show wlan

config wlan assisted-roaming

To configure assisted roaming on a WLAN, use the **config wlan assisted-roaming** command.

config wlan assisted-roaming {**neighbor-list** | **dual-list** | **prediction**} {**enable** | **disable**} *wlan_id*

Syntax Description	neighbor-list	Configures an 802.11k neighbor list for a WLAN.
	dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
	prediction	Configures an assisted roaming optimization prediction for a WLAN.
	enable	Enables the configuration on the WLAN.
	disable	Disables the configuration on the WLAN.
	<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).

Command Default

The 802.11k neighbor list is enabled for all WLANs.
By default, dual band list is enabled if the neighbor list feature is enabled for the WLAN.

Usage Guidelines

When you enable the assisted roaming prediction list, a warning appears and load balancing is disabled for the WLAN, if load balancing is already enabled on the WLAN.

Examples

This example shows how to enable an 802.11k neighbor list for a WLAN:

```
> config wlan assisted-roaming neighbor-list enable 1
```

Related Commands

config assisted-roaming
show assisted-roaming
debug 11k

config wlan avc

To configure Application Visibility and Control (AVC) on a WLAN, use the **config wlan avc** command.

config wlan avc *wlan_id* {**profile** *profile_name* | **visibility**} {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
profile	Associates or removes an AVC profile from a WLAN.
<i>profile_name</i>	Name of the AVC profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
visibility	Configures application visibility on a WLAN.
enable	Enables application visibility on a WLAN. You can view the classification of applications based on the Network Based Application Recognition (NBAR) deep packet inspection technology. Use the show avc statistics client command to view the client AVC statistics.
disable	Disables application visibility on a WLAN.

Command Default

None.

Usage Guidelines

You can configure only one AVC profile per WLAN and each AVC profile can have up to 32 rules. Each rule states a Mark or Drop action for an application, which allows you to configure up to 32 application actions per WLAN. You can configure up to 16 AVC profiles on a controller and associate an AVC profile with multiple WLANs.

Examples

This example shows how to associate an AVC profile with a WLAN:

```
> config wlan avc 5 profile profile1 enable
```

Related Commands

config avc profile delete
config avc profile create
config avc profile rule
show avc statistics
show avc profile applications
show avc applications
show avc statistics client

show avc statistics wlan
show avc statistics top-apps
show avc statistics guest-lan
show avc statistics remote-lan
debug avc error
debug avc events

config wlan apgroup

To manage access point group VLAN features, use the **config wlan apgroup** command.

config wlan apgroup {**add** *apgroup_name* [*description*] | **delete** *apgroup_name* | **description** *apgroup_name* *description* | **interface-mapping** {**add** | **delete**} *apgroup_name* *wlan_id* *interface_name* | **nac-snmp** {**enable** | **disable**} *apgroup_name* *wlan_id* | **nasid** *NAS-ID* *apgroup_name* | **profile-mapping** {**add** | **delete**} *apgroup_name* *profile_name* | **wlan-radio-policy** *apgroup_name* *wlan-id* {**802.11a-only** | **802.11bg** | **802.11g-only** | **all**} | **hotspot** {**venue** {**type** *apgroup_name* *group_codetype_code* | **name** *apgroup_name* *language_codevenue_name* } | **operating-class** {**add** | **delete**} *apgroup_name* *operating_class_value*}}

Syntax Description

add	Creates a new access point group (AP group).
<i>apgroup_name</i>	Access point group name.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
delete	Removes a wireless LAN from an AP group.
description	Describes an AP group.
<i>description</i>	Description of the AP group.
interface-mapping	(Optional) Assigns or removes a Wireless LAN from an AP group.
<i>interface_name</i>	(Optional) Interface to which you want to map an AP group.
nac-snmp	Configures NAC SNMP functionality on given AP group. Enables or disables Network Admission Control (NAC) out-of-band support on an access point group.
enable	Enables NAC out-of-band support on an AP group.
disable	Disables NAC out-of-band support on an AP group.
<i>NAS-ID</i>	Network Access Server identifier (NAS-ID) for the AP group. The NAS-ID is sent to the RADIUS server by the controller (as a RADIUS client) using the authentication request, which is used to classify users to different groups. You can enter up to 32 alphanumeric characters. Beginning in Release 7.4 and later releases, you can configure the NAS-ID on the interface, WLAN, or an access point group. The order of priority is AP group NAS-ID > WLAN NAS-ID > Interface NAS-ID.
none	Configures the controller system name as the NAS-ID.

profile-mapping	Configures RF profile mapping on an AP group.
<i>profile_name</i>	RF profile name for a specified AP group.
wlan-radio-policy	Configures WLAN radio policy on an AP group.
802.11a-only	Configures WLAN radio policy on an AP group.
802.11bg	Configures WLAN radio policy on an AP group.
802.11g-only	Configures WLAN radio policy on an AP group.
all	Configures WLAN radio policy on an AP group.
hotspot	Configures a HotSpot on an AP group.
venue	Configures venue information for an AP group.
type	Configures the type of venue for an AP group.
<i>group_code</i>	Venue group information for an AP group. The following options are available: • 0 : UNSPECIFIED • 1 : ASSEMBLY • 2 : BUSINESS • 3 : EDUCATIONAL • 4 : FACTORY-INDUSTRIAL • 5 : INSTITUTIONAL • 6 : MERCANTILE • 7 : RESIDENTIAL • 8 : STORAGE • 9 : UTILITY-MISC • 10 : VEHICULAR • 11 : OUTDOOR

type_code

Venue type information for an AP group.

For venue group 1 (ASSEMBLY), the following options are available:

- 0 : UNSPECIFIED ASSEMBLY
- 1 : ARENA
- 2 : STADIUM
- 3 : PASSENGER TERMINAL
- 4 : AMPHITHEATER
- 5 : AMUSEMENT PARK
- 6 : PLACE OF WORSHIP
- 7 : CONVENTION CENTER
- 8 : LIBRARY
- 9 : MUSEUM
- 10 : RESTAURANT
- 11 : THEATER
- 12 : BAR
- 13 : COFFEE SHOP
- 14 : ZOO OR AQUARIUM
- 15 : EMERGENCY COORDINATION CENTER

For venue group 2 (BUSINESS), the following options are available:

- 0 : UNSPECIFIED BUSINESS
- 1 : DOCTOR OR DENTIST OFFICE
- 2 : BANK
- 3 : FIRE STATION
- 4 : POLICE STATION
- 6 : POST OFFICE
- 7 : PROFESSIONAL OFFICE
- 8 : RESEARCH AND DEVELOPMENT FACILITY
- 9 : ATTORNEY OFFICE

For venue group 3 (EDUCATIONAL), the following options are available:

- 0 : UNSPECIFIED EDUCATIONAL

- 1 : PRIMARY SCHOOL
- 2 : SECONDARY SCHOOL
- 3 : UNIVERSITY OR COLLEGE

For venue group 4 (FACTORY-INDUSTRIAL), the following options are available:

- 0 : UNSPECIFIED FACTORY AND INDUSTRIAL
- 1 : FACTORY

For venue group 5 (INSTITUTIONAL), the following options are available:

- 0 : UNSPECIFIED INSTITUTIONAL
- 1 : HOSPITAL
- 2 : LONG-TERM CARE FACILITY
- 3 : ALCOHOL AND DRUG RE-HABILITATION CENTER
- 4 : GROUP HOME
- 5 : PRISON OR JAIL

For venue group 6 (MERCANTILE), the following options are available:

- 0 : UNSPECIFIED MERCANTILE
- 1 : RETAIL STORE
- 2 : GROCERY MARKET
- 3 : AUTOMOTIVE SERVICE STATION
- 4 : SHOPPING MALL
- 5 : GAS STATION

For venue group 7 (RESIDENTIAL), the following options are available:

- 0 : UNSPECIFIED RESIDENTIAL
- 1 : PRIVATE RESIDENCE
- 2 : HOTEL OR MOTEL
- 3 : DORMITORY
- 4 : BOARDING HOUSE

For venue group 8 (STORAGE), the following options are available:

- 0 : UNSPECIFIED STORAGE

For venue group 9 (UTILITY-MISC), the following options are available:

- 0 : UNSPECIFIED UTILITY AND MISCELLANEOUS

For venue group 10 (VEHICULAR), the following options are available:

- 0 : UNSPECIFIED VEHICULAR
- 1 : AUTOMOBILE OR TRUCK
- 2 : AIRPLANE
- 3 : BUS
- 4 : FERRY
- 5 : SHIP OR BOAT
- 6 : TRAIN
- 7 : MOTOR BIKE

For venue group 11 (OUTDOOR), the following options are available:

- 0 : UNSPECIFIED OUTDOOR
- 1 : MINI-MESH NETWORK
- 2 : CITY PARK
- 3 : REST AREA
- 4 : TRAFFIC CONTROL
- 5 : BUS STOP
- 6 : KIOSK

name	Configures the name of venue for an AP group.
<i>language_code</i>	An ISO-639 encoded string defining the language used at the venue. This string is a three character language code. For example, you can enter ENG for English.
<i>venue_name</i>	Venue name for this AP group. This name is associated with the basic service set (BSS) and is used in cases where the SSID does not provide enough information about the venue. The venue name is case-sensitive and can be up to 252 alphanumeric characters.

add	Adds an operating class for an AP group.
delete	Deletes an operating class for an AP group.
<i>operating_class_value</i>	Operating class for an AP group. The available operating classes are 81, 83, 84, 112, 113, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127.

Command Default

Disabled.

Usage Guidelines

An error message appears if you try to delete an access point group that is used by at least one access point. Before you can delete an AP group in controller software release 6.0, move all APs in this group to another group. The access points are not moved to the default-group access point group as in previous releases. To see the APs, enter the **show wlan apgroups** command. To move APs, enter the **config ap group-name groupname cisco_ap** command.

The NAS-ID configured on the controller for AP group or WLAN or interface is used for authentication. The NAS-ID is not propagated across controllers.

Examples

This example shows how to enable the NAC out-of band support on access point group 4:

```
> config wlan apgroup nac enable apgroup 4
```

Related Commands

config guest-lan nac
config wlan nac
debug group
show ap stats
show ap summary
show ap wlan
show nac statistics
show nac summary
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advance hotspot gas-limit
config wlan security wpa gtk-random

config wlan hotspot dot11u
config wlan hotspot clear-all
config wlan hotspot msap
config wlan nasid
config interface nasid

config wlan band-select allow

To configure band selection on a WLAN, use the **config wlan band-select allow** command.

config wlan band-select allow {enable | disable} *wlan_id*

Syntax Description

enable	Enables band selection on a WLAN.
disable	Disables band selection on a WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

When you enable band select on a WLAN, the access point suppresses client probes on 2.4-GHz and moves the dual band clients to the 5-GHz spectrum. The band-selection algorithm directs dual-band clients only from the 2.4-GHz radio to the 5-GHz radio of the same access point, and it only runs on an access point when both the 2.4-GHz and 5-GHz radios are up and running. Band selection can be used only with Cisco Aironet 1040, 1140, and 1250 Series and the 3500 series access points.

Examples

This example shows how to enable band selection on a WLAN:

```
> config wlan band-select allow enable 6
```

Related Commands

show band-select
show load-balancing
config band-select cycle-threshold
config band-select expire
config band-select cycle-count
config band-select client-rssi

config wlan broadcast-ssid

To configure an Service Set Identifier (SSID) broadcast on a wireless LAN, use the **config wlan broadcast-ssid** command.

config wlan broadcast-ssid {**enable** | **disable**} *wlan_id*

Syntax Description

enable	Enables SSID broadcasts on a wireless LAN.
disable	Disables SSID broadcasts on a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

Disabled.

Examples

This example shows how to configure an SSID broadcast on wireless LAN ID 1:

```
> config wlan broadcast-ssid enable 1
```

Related Commands

show wlan

config wlan call-snoop

To enable or disable Voice-over-IP (VoIP) snooping for a particular WLAN, use the **config wlan call-snoop** command.

config wlan call-snoop {**enable** | **disable**} *wlan_id*

Syntax Description

enable	Enables VoIP snooping on a wireless LAN.
disable	Disables VoIP snooping on a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

WLAN should be with Platinum QoS and it needs to be disabled while invoking this CLI

Examples

This example shows how to enable VoIP snooping for WLAN 3:

```
> config wlan call-snoop 3 enable
```

Related Commands

show wlan
config wlan
show call-control ap
show call-control client

config wlan chd

To enable or disable Coverage Hole Detection (CHD) for a wireless LAN, use the **config wlan chd** command.

config wlan chd *wlan_id* {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables SSID broadcasts on a wireless LAN.
disable	Disables SSID broadcasts on a wireless LAN.

Command Default

None.

Examples

This example shows how to enable CHD for WLAN 3:

```
> config wlan chd 3 enable
```

Related Commands

show wlan
config wlan
config ap wlan

config wlan ccx aironet-ie

To enable or disable Aironet information elements (IEs) for a WLAN, use the **config wlan ccx aironet-ie** command.

config wlan ccx aironet-ie {enable | disable}

Syntax Description

enable	Enables the Aironet information elements.
disable	Disables the Aironet information elements.

Command Default

None.

Examples

This example shows how to enable Aironet information elements for a WLAN:

```
> config wlan ccx aironet-ie enable
```

Related Commands

config wlan
config wlan security ckip
show client detail

config wlan channel-scan defer-priority

To configure the controller to defer priority markings for packets that can defer off channel scanning, use the **config wlan channel-scan defer-priority** command.

config wlan channel-scan defer-priority *priority* [**enable** | **disable**] *wlan_id*

Syntax Description

<i>priority</i>	User priority value (0 to 7).
enable	(Optional) Enables packet at given priority to defer off channel scanning.
disable	(Optional) Disables packet at given priority to defer off channel scanning.
<i>wlan_id</i>	Wireless LAN identifier (1 to 512).

Command Default

None.

Usage Guidelines

The priority value should be set to 6 on the client and on the WLAN.

Examples

This example shows how to enable the controller to defer priority markings that can defer off channel scanning with user priority value 6 and WLAN id 30:

```
> config wlan channel-scan defer-priority 6 enable 30
```

Related Commands

config wlan
show client detail
config wlan channel-scan defer-time

config wlan channel-scan defer-time

To assign the channel scan defer time in milliseconds, use the **config wlan channel-scan defer-time** command.

config wlan channel-scan defer-time *msecs wlan_id*

Syntax Description

<i>msecs</i>	Deferral time in milliseconds (0 to 60000 milliseconds).
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None.

Usage Guidelines

The time value in milliseconds should match the requirements of the equipment on your WLAN.

Examples

This example shows how to assign the scan defer time to 40 milliseconds for WLAN with ID 50:

```
> config wlan channel-scan defer-time 40 50
```

Related Commands

config wlan
show client detail
config wlan channel-scan defer-time

config wlan custom-web

To configure the web authentication page for a WLAN, use the **config wlan custom-web** command.

config wlan custom-web {**ext-webauth-url** *ext-webauth-url* *wlan_id* | **global** {**enable** | **disable**} **login-page** *page-name* | **loginfailure-page** {*page-name* | **none**} | **logout-page** {*page-name* | **none**} | **webauth-type** {**internal** | **customized** | **external**} *wlan_id*}

Syntax Description

ext-webauth-url	Configures an external web authentication URL.
<i>ext-webauth-url</i>	External web authentication URL.
<i>wlan_id</i>	WLAN identifier from 1 to 512.
global	Configures the global status for a WLAN.
enable	Enables the global status for a WLAN.
disable	Disables the global status for a WLAN.
login-page	Configures the name of the login page for an external web authentication URL.
<i>page-name</i>	Login page name for an external web authentication URL.
loginfailure-page	Configures the name of the login failure page for an external web authentication URL.
none	Does not configure a login failure page for an external web authentication URL.
logout-page	Configures the name of the logout page for an external web authentication URL.
webauth-type	Configures the type of web authentication for the WLAN.
internal	Displays the default login page.
customized	Displays a customized login page.
external	Displays a login page on an external web server.

Command Default

None

Examples

The following example shows how to configure the web authentication type as an external.

```
Device > config wlan custom-web webauth-type external
```

config wlan dhcp_server

To configure the internal DHCP server for a wireless LAN, use the **config wlan dhcp_server** command.

config wlan dhcp_server {*wlan_id* | **foreignAp**} *ip_address* [**required**]

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>ip_address</i>	IP address of the internal DHCP server (this parameter is required).
required	(Optional) Specifies whether DHCP address assignment is required.

Command Default

None.

Usage Guidelines

The preferred method for configuring DHCP is to use the primary DHCP address assigned to a particular interface instead of the DHCP server override. If you enable the override, you can use the **show wlan** command to verify that the DHCP server has been assigned to the WLAN.

Examples

This example shows how to configure an IP address 10.10.2.1 of the internal DHCP server for wireless LAN ID 16:

```
> config wlan dhcp_server 16 10.10.2.1
```

Related Commands

show dhcp
show dhcp proxy
config dhcp
config interface dhcp
debug dhcp
debug dhcp service-port
debug disable-all
show dhcp proxy

config wlan diag-channel

To enable the diagnostic channel troubleshooting on a particular WLAN, use the **config wlan diag-channel** command.

config wlan diag-channel [**enable** | **disable**] *wlan_id*

Syntax Description

enable	(Optional) Enables the wireless LAN diagnostic channel.
disable	(Optional) Disables the wireless LAN diagnostic channel.
<i>wlan_id</i>	Wireless LAN identifier (1 to 512).

Command Default

None.

Examples

This example shows how to enable the wireless LAN diagnostic channel for WLAN ID 1:

```
> config wlan diag-channel enable 1
```

Related Commands

show wlan
show run-config

config wlan dtim

To configure a Delivery Traffic Indicator Message (DTIM) for 802.11 radio network **config wlan dtim** command.

config wlan dtim {802.11a | 802.11b} *dtim wlan_id*

Syntax Description

802.11a	Configures DTIM for the 802.11a radio network.
802.11b	Configures DTIM for the 802.11b radio network.
<i>dtim</i>	Value for DTIM (between 1 to 255 inclusive).
<i>wlan_id</i>	Number of the WLAN to be configured.

Command Default

The default is DTIM 1.

Examples

This example shows how to configure DTIM for 802.11a radio network with DTIM value 128 and WLAN ID 1:

```
> config wlan dtim 802.11a 128 1
```

Related Commands

show wlan

config wlan exclusionlist

To configure the wireless LAN exclusion list, use the **config wlan exclusionlist** command.

config wlan exclusionlist {*wlan_id* [**enabled** | **disabled** | *time*] | **foreignAp** [**enabled** | **disabled** | *time*]}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier (1 to 512).
enabled	(Optional) Enables the exclusion list for the specified wireless LAN or foreign access point.
disabled	(Optional) Disables the exclusion list for the specified wireless LAN or a foreign access point.
<i>time</i>	(Optional) Exclusion list timeout in seconds. A value of zero (0) specifies infinite time.
foreignAp	Specifies a third-party access point.

Command Default

None.

Usage Guidelines

This command replaces the **config wlan blacklist** command.

Examples

This example shows how to enable the exclusion list for WLAN ID 1:

```
> config wlan exclusionlist 1 enabled
```

Related Commands

show wlan
show wlan summary

config wlan flow

To associate a NetFlow monitor with a WLAN, use the **config wlan flow** command.

config wlan flow *wlan_id* **monitor** *monitor_name* {**enable** | **disable**}

Syntax Description		
<i>wlan_id</i>		Wireless LAN identifier from 1 to 512 (inclusive).
monitor		Configures a NetFlow monitor.
<i>monitor_name</i>		Name of the NetFlow monitor. The monitor name can be up to 32 case-sensitive, alphanumeric characters. You cannot include spaces for a monitor name.
enable		Associates a NetFlow monitor with a WLAN.
disable		Dissociates a NetFlow monitor from a WLAN.

Command Default None.

Usage Guidelines You can use the **config flow** command to create a new NetFlow monitor.

Examples This example shows how to associate a NetFlow monitor with a WLAN:

```
> config wlan flow 5 monitor monitor1 enable
```

Related Commands

- show flow exporter
- show flow monitor
- config flow

config wlan flexconnect ap-auth

To configure local authentication of clients associated with FlexConnect on a locally switched WLAN, use the **config wlan flexconnect ap-auth** command.

config wlan flexconnect ap-auth *wlan_id* {**enable** | **disable**}

Syntax Description

ap-auth	Configures local authentication of clients associated with an FlexConnect on a locally switched WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables AP authentication on a WLAN.
disable	Disables AP authentication on a WLAN.

Command Default

None.

Usage Guidelines

Local switching must be enabled on the WLAN where you want to configure local authentication of clients associated with FlexConnect.

Examples

This example shows how to enable authentication of clients associated with FlexConnect on a specified WLAN:

```
> config wlan flexconnect ap-auth 6 enable
```

Related Commands

config wlan flexconnect local-switching
show wlan

config wlan flexconnect learn-ipaddr

To enable or disable client IP address learning for the Cisco WLAN controller, use the **config wlan flexconnect learn-ipaddr** command.

config wlan flexconnect learn-ipaddr *wlan_id* {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables client IP address learning on a wireless LAN.
disable	Disables client IP address learning on a wireless LAN.

Command Default

Disabled when the **config wlan flexconnect local-switching** command is disabled. Enabled when the **config wlan flexconnect local-switching** command is enabled.

Usage Guidelines

If the client is configured with Layer 2 encryption, the controller cannot learn the client IP address, and the controller will periodically drop the client. Disable this option to keep the client connection without waiting to learn the client IP address.



Note

The ability to disable IP address learning is not supported with FlexConnect central switching.

Examples

This example shows how to disable client IP address learning for WLAN 6:

```
> config wlan flexconnect learn-ipaddr disable 6
```

Related Commands

config wlan flexconnect local-switching
show wlan

config wlan flexconnect local-switching

To configure local switching, central DHCP, NAT-PAT, or the override DNS option on a FlexConnect WLAN, use the **config wlan flexconnect local switching** command.

```
config wlan flexconnect local-switching wlan_id {enable | disable} { {central-dhcp {enable | disable}
nat-pat {enable | disable} } | {override option dns { enable | disable} } }
```

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
enable	Enables local switching on a FlexConnect WLAN.
disable	Disables local switching on a FlexConnect WLAN.
central-dhcp	Configures central switching of DHCP packets on the local switching FlexConnect WLAN. When you enable this feature, the DHCP packets received from the AP are centrally switched to the controller and forwarded to the corresponding VLAN based on the AP and the SSID.
enable	Enables central DHCP on a FlexConnect WLAN.
disable	Disables central DHCP on a FlexConnect WLAN.
nat-pat	Configures Network Address Translation (NAT) and Port Address Translation (PAT) on the local switching FlexConnect WLAN.
enable	Enables NAT-PAT on the FlexConnect WLAN.
disable	Disables NAT-PAT on the FlexConnect WLAN.
override	Specifies the DHCP override options on the FlexConnect WLAN.
option dns	Specifies the override DNS option on the FlexConnect WLAN. When you override this option, the clients get their DNS server IP address from the AP, not from the controller.
enable	Enables the override DNS option on the FlexConnect WLAN.
disable	Disables the override DNS option on the FlexConnect WLAN.

Command Default

Disabled.

Usage Guidelines

When you enable the **config wlan flexconnect local-switching** command, the **config wlan flexconnect learn-ipaddr** command is enabled by default.

**Note**

The ability to disable IP address learning is not supported with FlexConnect central switching.

Examples

This example shows how to enable WLAN 6 for local switching and enable central DHCP and NAT-PAT:

```
> config wlan flexconnect local-switching 6 enable central-dhcp enable nat-pat enable
```

This example shows how to enable the override DNS option on WLAN 6:

```
> config wlan flexconnect local-switching 6 override option dns enable
```

Related Commands

config wlan flexconnect learn-ipaddr

config wlan flexconnect vlan-central-switching

config wlan flexconnect ap-auth

show wlan

config wlan flexconnect vlan-central-switching

To configure central switching on a locally switched WLAN, use the **config wlan flexconnect vlan-central-switching** command.

config wlan flexconnect vlan-central-switching *wlan_id* { **enable** | **disable** }

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables central switching on a locally switched wireless LAN.
disable	Disables central switching on a locally switched wireless LAN.

Command Default

Disabled.

Usage Guidelines

You must enable Flexconnect local switching to enable VLAN central switching. When you enable WLAN central switching, the access point bridges the traffic locally if the WLAN is configured on the local IEEE 802.1Q link. If the VLAN is not configured on the access point, the AP tunnels the traffic back to the controller and the controller bridges the traffic to the corresponding VLAN.

WLAN central switching does not support:

- FlexConnect local authentication.
- Layer 3 roaming of local switching client.

Examples

This example shows how to enable WLAN 6 for central switching:

```
> config wlan flexconnect vlan-central-switching 6 enable
```

Related Commands

config wlan flexconnect local-switching
show wlan

config wlan hotspot

To configure a HotSpot on a WLAN, use the **config wlan hotspot** command.

config wlan hotspot {**clear-all** *wlan_id* | **dot11u** | **hs2** | **msap**}

Syntax Description

clear-all	Clears the HotSpot configurations on a WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
dot11u	Configures an 802.11u HotSpot on a WLAN.
hs2	Configures HotSpot2 on a WLAN.
msap	Configures the Mobility Services Advertisement Protocol (MSAP) on a WLAN.

Command Default

None.

Usage Guidelines

You can configure up to 32 HotSpot WLANs.

Examples

This example shows how to configure HotSpot2 for a WLAN:

```
> config wlan hotspot hs2 enable 2
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
show advanced hotspot
config wlan security wpa gtk-random

config wlan hotspot dot11u

To configure an 802.11u HotSpot on a WLAN, use the **config wlan hotspot dot11u** command.

config wlan hotspot dot11u {3gpp-info | auth-type | enable | disable | domain | hessid | ipaddr-type | nai-realm | network-type | roam-oi}

Syntax Description

3gpp-info	Configures 3GPP cellular network information.
auth-type	Configures the network authentication type.
enable	Enables 802.11u on the HotSpot profile. IEEE 802.11u enables automatic WLAN offload for 802.1X devices at the HotSpot of mobile or roaming partners.
disable	Disables 802.11u on the HotSpot profile.
domain	Configures a domain.
hessid	Configures the Homogenous Extended Service Set Identifier (HSSID). The HSSID is a 6-octet MAC address that uniquely identifies the network.
ipaddr-type	Configures the IP address availability type.
nai-realm	Configures a realm for 802.11u enabled WLANs.
network-type	Configures the 802.11u network type and Internet access.
roam-oi	Configures the roaming consortium Organizational Identifier (OI) list.

Command Default

None.

Examples

This example shows how to enable 802.11u on a HotSpot profile:

```
> config wlan hotspot dot11u enable 6
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot

show advanced hotspot

config wlan security wpa gtk-random

config wlan hotspot dot11u 3gpp-info

To configure 3GPP cellular network information on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u 3gpp-info** command.

config wlan hotspot dot11u 3gpp-info {**add** | **delete**} *index country_code network_code wlan_id*

Syntax Description

add	Adds mobile cellular network information.
delete	Deletes mobile cellular network information.
<i>index</i>	Cellular index. The range is from 1 to 32.
<i>country_code</i>	Mobile Country Code (MCC) in Binary Coded Decimal (BCD) format. The country code can be up to 3 characters. For example, the MCC for USA is 310.
<i>network_code</i>	Mobile Network Code (MNC) in BCD format. An MNC is used in combination with a Mobile Country Code (MCC) to uniquely identify a mobile phone operator or carrier. The network code can be up to 3 characters. For example, the MNC for T-Mobile is 026.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Usage Guidelines

Number of mobile network codes supported is 32 per WLAN.

Examples

This example shows how to configure 3GPP cellular network information on a WLAN:

```
> config wlan hotspot dot11u 3gpp-info add
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets


```
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random
```

config wlan hotspot dot11u auth-type

To configure the network authentication type on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u auth-type** command.

config wlan hotspot dot11u auth-type *network-auth wlan_id*

Syntax Description

<i>network-auth</i>	Network authentication that you would like to configure on the WLAN. The available values are as follows: • 0—Acceptance of terms and conditions • 1—On-line enrollment • 2—HTTP/HTTPS redirection • 3—DNS Redirection • 4—Not Applicable
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Usage Guidelines

The DNS redirection option is not supported in Release 7.3.

Examples

This example shows how to configure HTTP/HTTPS redirection as the network authentication type on an 802.11u HotSpot WLAN:

```
> config wlan hotspot dot11u auth-type 2 1
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue

config wlan apgroup hotspot operating-class

config ap hotspot venue

config advanced hotspot

config wlan security wpa gtk-random

config wlan hotspot dot11u disable

To disable an 802.11u HotSpot on a WLAN, use the **config wlan hotspot dot11u disable** command.

config wlan hotspot dot11u disable *wlan_id*

Syntax Description

wlan_id

Wireless LAN identifier between 1 and 512.

Examples

This example shows how to disable an 802.11u HotSpot on a WLAN:

```
> config wlan hotspot dot11u disable 6
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advance hotspot gas-limit
config wlan security wpa gtk-random

config wlan hotspot dot11u domain

To configure a domain operating in the 802.11 access network, use the **config wlan hotspot dot11u domain** command.

config wlan hotspot dot11u domain {**add** *wlan_id domain-index domain_name* | **delete** *wlan_id domain-index* | **modify** *wlan_id domain-index domain_name*}

Syntax Description

add	Adds a domain.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>domain-index</i>	Domain index in the range 1 to 32.
<i>domain_name</i>	Domain name. The domain name is case sensitive and can be up to 255 alphanumeric characters.
delete	Deletes a domain.
modify	Modifies a domain.

Examples

This example shows how to add a domain in the 802.11 access network:

```
> config wlan hotspot dot11u domain add 6 30 domain1
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue

config advanced hotspot
config wlan security wpa gtk-random

config wlan hotspot dot11u enable

To enable an 802.11u HotSpot on a WLAN, use the **config wlan hotspot dot11u enable** command.

config wlan hotspot dot11u enable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Examples

This example shows how to enable an 802.11u HotSpot on a WLAN:

```
> config wlan hotspot dot11u enable 6
```

Related Commands

config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advance hotspot gas-limit
config wlan security wpa gtk-random

config wlan hotspot dot11u hessid

To configure a Homogenous Extended Service Set Identifier (HESSID) on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u hessid** command.

config wlan hotspot dot11u hessid *hessid wlan_id*

Syntax Description

<i>hessid</i>	MAC address that can be configured as an HESSID. The HESSID is a 6-octet MAC address that uniquely identifies the network. For example, Basic Service Set Identification (BSSID) of the WLAN can be used as the HESSID.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Examples

This example shows how to configure an HESSID on an 802.11u HotSpot WLAN:

```
> config wlan hotspot dot11u hessid 00:21:1b:ea:36:60 6
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random

config wlan hotspot dot11u ipaddr-type

To configure the type of IP address available on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u ipaddr-type** command.

config wlan hotspot dot11u ipaddr-type *IPv4Type IPv6Type wlan_id*

Syntax Description

<i>IPv4Type</i>	IPv4 type address. Enter one of the following values: 0—IPv4 address not available. 1—Public IPv4 address available. 2—Port restricted IPv4 address available. 3—Single NAT enabled private IPv4 address available. 4—Double NAT enabled private IPv4 address available. 5—Port restricted IPv4 address and single NAT enabled IPv4 address available. 6—Port restricted IPv4 address and double NAT enabled IPv4 address available. 7— Availability of the IPv4 address is not known.
<i>IPv6Type</i>	IPv6 type address. Enter one of the following values: 0—IPv6 address not available. 1—IPv6 address available. 2—Availability of the IPv6 address is not known.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

The default values for IPv4 type address is 1 and for IPv6 type address is 2.

Examples

This example shows how to configure the IP address availability type on an 802.11u HotSpot WLAN:

```
> config wlan hotspot dot11u ipaddr-type 6 2 6
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type

config wlan hotspot dot11u roam-oi
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random

config wlan hotspot dot11u nai-realm

To configure realms for an 802.11u HotSpot WLANs, use the **config wlan hotspot dot11u nai-realm** command.

config wlan hotspot dot11u nai-realm {**add** | **delete** | **modify**} {**auth-method** *wlan_id realm-index eap-index auth-index auth-method auth-parameter* | **eap-method** *wlan_id realm-index eap-index eap-method* | **realm-name** *wlan_id realm-index realm*}

Syntax Description

add	Adds a realm.
delete	Deletes a realm.
modify	Modifies a realm.
auth-method	Specifies the authentication method used.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
<i>realm-index</i>	Realm index. The range is from 1 to 32.
<i>eap-index</i>	EAP index. The range is from 1 to 4.
<i>auth-index</i>	Authentication index value. The range is from 1 to 10.
<i>auth-method</i>	Authentication method to be used. The range is from 1 to 4. The following options are available: • 1—Non-EAP Inner Auth Method • 2—Inner Auth Type • 3—Credential Type • 4—Tunneled EAP Method Credential Type
<i>auth-parameter</i>	Authentication parameter to use. This value depends on the authentication method used. See the following table for more details.
eap-method	Specifies the Extensible Authentication Protocol (EAP) method used.

<i>eap-method</i>	EAP Method. The range is from 0 to 7. The following options are available: • 0—Not Applicable • 1—Lightweight Extensible Authentication Protocol (LEAP) • 2—Protected EAP (PEAP) • 3—EAP-Transport Layer Security (EAP-TLS) • 4—EAP-FAST (Flexible Authentication via Secure Tunneling) • 5—EAP for GSM Subscriber Identity Module (EAP-SIM) • 6—EAP-Tunneled Transport Layer Security (EAP-TTLS) • 7—EAP for UMTS Authentication and Key Agreement (EAP-AKA)
realm-name	Specifies the name of the realm.
<i>realm</i>	Name of the realm. The realm name should be RFC 4282 compliant. For example, Cisco. The realm name is case-sensitive and can be up to 255 alphanumeric characters.

Usage Guidelines

This table lists the authentication parameters.

Table 6: Authentication Parameters

Non-EAP Inner Method(1)	Inner Authentication EAP Method Type(2)	Credential Type(3)/Tunneled EAP Credential Type(4)
0—Reserved	1—LEAP	1—SIM
1—Password authentication protocol (PAP)	2—PEAP	2—USIM
2—Challenge-Handshake Authentication Protocol (CHAP)	3—EAP-TLS	3—NFC Secure Element
3—Microsoft Challenge Handshake Authentication Protocol (MS-CHAP)	4—EAP-FAST	4—Hardware Token
4—MSCHAPV2	5—EAP-SIM	5—Soft Token
	6—EAP-TTLS	6—Certificate
	7—EAP-AKA	7—Username/Password
		8—Reserver
		9—Anonymous
		10—Vendor Specific

Examples

This example shows how to add the Tunneled EAP Method Credential authentication method on WLAN 4:

```
> config wlan hotspot dot11u nai-realm add auth-method 4 10 3 5 4 6
```

Related Commands

`config wlan hotspot dot11u enable`
`config wlan hotspot dot11u disable`
`config wlan hotspot dot11u 3gpp-info`
`config wlan hotspot dot11u domain`
`config wlan hotspot dot11u hessid`
`config wlan hotspot dot11u auth-type`
`config wlan hotspot dot11u ipaddr-type`
`config wlan hotspot dot11u network-type`
`config wlan hotspot dot11u roam-oi`
`show wlan`
`debug hotspot events`
`debug hotspot packets`
`config wlan apgroup hotspot venue`
`config wlan apgroup hotspot operating-class`
`config ap hotspot venue`
`config advanced hotspot`
`config wlan security wpa gtk-random`

config wlan hotspot dot11u network-type

To configure the network type and internet availability on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u network-type** command.

config wlan hotspot dot11u network-type *wlan_id network-type internet-access*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
<i>network-type</i>	Network type. The available options are as follows: • 0—Private Network • 1—Private Network with Guest Access • 2—Chargeable Public Network • 3—Free Public Network • 4—Personal Device Network • 5—Emergency Services Only Network • 14—Test or Experimental • 15—Wildcard
<i>internet-access</i>	Internet availability status. A value of zero indicates no Internet availability and 1 indicates Internet availability.

Examples

This example shows how to configure the network type and Internet availability on an 802.11u HotSpot WLAN:

```
> config wlan hotspot dot11u network-type 2 1
```

Related Commands

```
config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u roam-oi
show wlan
```

debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random

config wlan hotspot dot11u roam-oi

To configure a roaming consortium Organizational Identifier (OI) list on a 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u roam-oi** command.

config wlan hotspot dot11u roam-oi {**add** *wlan_id oi-index oi is-beacon* | **modify** *wlan_id oi-index oi is-beacon* | **delete** *wlan_id oi-index*}

Syntax Description

add	Adds an OI.
<i>wlan-id</i>	Wireless LAN identifier from 1 to 512.
<i>oi-index</i>	Index in the range 1 to 32.
<i>oi</i>	Number that must be a valid 6 digit hexadecimal number and 6 bytes in length. For example, 004096 or AABBDf.
<i>is-beacon</i>	Beacon flag used to add an OI to the beacon. 0 indicates disable and 1 indicates enable. You can add a maximum of 3 OIs for a WLAN with this flag set.
modify	Modifies an OI.
delete	Deletes an OI.

Examples

This example shows how to configure the roaming consortium OI list:

```
> config wlan hotspot dot11u roam-oi add 4 10 004096 1
```

Related Commands

config wlan hotspot dot11u enable
config wlan hotspot dot11u disable
config wlan hotspot dot11u 3gpp-info
config wlan hotspot dot11u domain
config wlan hotspot dot11u hessid
config wlan hotspot dot11u auth-type
config wlan hotspot dot11u ipaddr-type
config wlan hotspot dot11u nai-realm
config wlan hotspot dot11u network-type
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue

config wlan apgroup hotspot operating-class

config ap hotspot venue

config advanced hotspot

config wlan security wpa gtk-random

config wlan hotspot hs2

To configure the HotSpot2 parameters, use the **config wlan hotspot hs2** command.

```
config wlan hotspot hs2 {disable wlan_id | enable wlan_id | operator-name {add wlan_id index
operator_name language-code | delete wlan_id index | modify wlan_id index operator_name language-code}
| port-config {add wlan_id port_config_index ip-protocol port-number status | delete wlan_id
port-config-index | modify wlan_id port-config-index ip-protocol port-number status} | wan-metrics wlan_id
link-status symet-link downlink-speed uplink-speed }
```

Syntax Description

disable	Disables HotSpot2.
<i>wlan-id</i>	Wireless LAN identifier from 1 to 512.
enable	Enables HotSpot2.
operator-name	Specifies the name of the 802.11 operator.
add	Adds the operator name, port configuration, or WAN metrics parameters to the WLAN configuration.
<i>index</i>	Index of the operator. The range is from 1 to 32.
<i>operator-name</i>	Name of the operator.
<i>language-code</i>	Language used. An ISO-14962-1997 encoded string that defines the language. This string is a three character language code. Enter the first three letters of the language in English. For example, eng for English.
delete	Deletes the operator name, port configuration, or WAN metrics parameters from the WLAN.
modify	Modifies the operator name, port configuration, or WAN metrics parameters of the WLAN.
port-config	Configures the port configuration values.
<i>port_config_index</i>	Port configuration index. The range is from 1 to 32. The default value is 1.

<i>ip-protocol</i>	Protocol to use. This parameter provides information on the connection status of the most commonly used communication protocols and ports. The following options are available: 1—ICMP 6—FTP/SSH/TLS/PPTP-VPN/VoIP 17—IKEv2 (IPSec-VPN/VoIP/ESP) 50—ESP (IPSec-VPN)
<i>port-number</i>	Port number. The following options are available: 0—ICMP/ESP (IPSec-VPN) 20—FTP 22—SSH 443—TLS-VPN 500—IKEv2 1723—PPTP-VPN 4500—IKEv2 5060—VoIP
<i>status</i>	Status of the IP port. The following options are available: 0—Closed 1—Open 2—Unknown
wan-metrics	Configures the WAN metrics.
<i>link-status</i>	Link status. The following options are available: • 0—Unknown • 1—Link up • 2—Link down • 3—Link in test state
<i>symet-link</i>	Symmetric link status. The following options are available: • 0—Link speed is different for uplink and downlink. For example: ADSL • 1—Link speed is the same for uplink and downlink. For example: DSL
<i>downlink-speed</i>	Downlink speed of the WAN backhaul link in kbps. Maximum value is 4,194,304 kbps.

uplink-speed

Uplink speed of the WAN backhaul link in kbps. The maximum value is 4,194,304 kbps.

Examples

This example shows how to configure the WAN metrics parameters:

```
> config wlan hotspot hs2 wan-metrics add 345 1 0 3333
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot gas-limit
config wlan security wpa gtk-random
config wlan hotspot dot11u
config wlan hotspot clear-all
config wlan hotspot msap

config wlan hotspot msap

To configure the Mobility Service Advertisement Protocol (MSAP) parameters on a WLAN, use the **config wlan hotspot msap** command.

config wlan hotspot msap {**enable** | **disable** | **server-id** *server_id*} *wlan_id*

Syntax Description

enable	Enables MSAP on the WLAN.
disable	Disables MSAP on the WLAN.
server-id	Specifies the MSAP server id.
<i>server_id</i>	MSAP server ID. The range is from 1 to 10.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Examples

This example shows how to enable MSAP on a WLAN:

```
> config wlan hotspot msap enable 4
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random
config wlan hotspot hs2
config wlan hotspot clear-all
config wlan hotspot msap

config wlan interface

To configure a wireless LAN interface or an interface group, use the **config wlan interface** command.

config wlan interface {*wlan_id* | **foreignAp**} {*interface-name* | *interface-group-name*}

Syntax Description

<i>wlan_id</i>	(Optional) Wireless LAN identifier (1 to 512).
foreignAp	Specifies third-party access points.
<i>interface-name</i>	Interface name.
<i>interface-group-name</i>	Interface group name.

Command Default

None.

Examples

This example shows how to configure an interface named VLAN901:

```
> config wlan interface 16 VLAN901
```

Related Commands

show wlan

config wlan ipv6 acl

To configure IPv6 access control list (ACL) on a wireless LAN, use the **config wlan ipv6 acl** command.

config wlan ipv6 acl *wlan_id* *acl_name*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>acl_name</i>	IPv6 ACL name.

Command Default

None.

Examples

This example shows how to configure an IPv6 ACL for local switching:

```
> config wlan ipv6 acl 22 acl_sample
```

Related Commands

show wlan

config wlan kts-cac

To configure the Key Telephone System-based CAC policy for a WLAN, use the **config wlan kts-cac** command.

config wlan kts-cac {enable | disable} *wlan_id*

Syntax Description

enable	Enables the KTS-based CAC policy.
disable	Disables the KTS-based CAC policy.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

To enable the KTS-based CAC policy for a WLAN, ensure that you do the following:

- Configure the QoS profile for the WLAN to Platinum by entering the following command:
config wlan qos *wlan-id* platinum
- Disable the WLAN by entering the following command:
config wlan disable *wlan-id*
- Disable FlexConnect local switching for the WLAN by entering the following command:
config wlan flexconnect local-switching *wlan-id* disable

Examples

This example shows how to enable the KTS-based CAC policy for a WLAN with the ID 4:

```
> config wlan kts-cac enable 4
```

Related Commands

config wlan
config wlan qos
config wlan flexconnect local-switching
config wlan wmm
config 802.11a cac voice

config wlan learn-ipaddr-cswlan

To configure client IP address learning on a centrally switched WLAN, use the **config wlan learn-ipaddr-cswlan** command.

config wlan learn-ipaddr-cswlan *wlan_id* {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
enable	Enables client IP address learning on the centrally switched WLAN
disable	Disables client IP address learning on the centrally switched WLAN

Command Default

None.

Usage Guidelines

If the client is configured with Layer 2 encryption, the Cisco WLC cannot learn the client IP address and will periodically drop the client. Disable this option so that the Cisco WLC maintains the client connection without waiting to learn the client IP address.

Examples

This example shows how to enable client IP address learning on a centrally switched WLAN:

```
> config wlan learn-ipaddr-cswlan 2 enable
```

Related Commands

config wlan flexconnect learn-ipaddr
show wlan

config wlan ldap

To add or delete a link to a configured Lightweight Directory Access Protocol (LDAP) server, use the **config wlan ldap** command.

config wlan ldap {**add** *wlan_id* *server_id* | **delete** *wlan_id* {**all** | *server_id*}}

Syntax Description

add	Adds a link to a configured LDAP server.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>server_id</i>	LDAP server index.
delete	Removes the link to a configured LDAP server.
all	Specifies all LDAP servers.

Command Default

None.

Usage Guidelines

Use this command to specify the LDAP server priority for the WLAN.

To specify the LDAP server priority, one of the following must be configured and enabled:

- 802.1X authentication and Local EAP
- Web authentication and LDAP



Note

Local EAP was introduced in controller software release 4.1; LDAP support on Web authentication was introduced in controller software release 4.2.

Examples

This example shows how to add a link to a configured LDAP server with the WLAN ID 100 and server ID 4:

```
> config wlan ldap add 100 4
```

Related Commands

config ldap

config wlan load-balance

To override the global load balance configuration and enable or disable load balancing on a particular WLAN, use the **config wlan load-balance** command.

config wlan load-balance allow {**enable** | **disable**} *wlan_id*

Syntax Description	enable	Enables band selection on a wireless LAN.
	disable	Disables band selection on a wireless LAN.
	<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default Enabled.

Examples This example shows how to enable band selection on a wireless LAN with WLAN ID 3:

```
> config wlan load-balance allow enable 3
```

Related Commands **config load-balancing**

config wlan mac-filtering

To change the state of MAC filtering on a wireless LAN, use the **config wlan mac-filtering** command.

config wlan mac-filtering {enable | disable} {*wlan_id* | foreignAp}

Syntax Description

enable	Enables MAC filtering on a wireless LAN.
disable	Disables MAC filtering on a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to enable the MAC filtering on WLAN ID 1:

```
> config wlan mac-filtering enable 1
```

Related Commands

show wlan

config wlan max-associated-clients

To configure the maximum number of client connections on a wireless LAN, guest LAN, or remote LAN, use the **config wlan max-associated-clients** command.

config wlan max-associated-clients *max_clients* *wlan_id*

Syntax Description

<i>max_clients</i>	Maximum number of client connections to be accepted.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to specify the maximum number of client connections on WLAN ID 2:

```
> config wlan max-associated-clients 25 2
```

Related Commands

show wlan

config wlan max-radio-clients

To configure the maximum number of WLAN client per access point, use the **config wlan max-radio-clients** command.

config wlan max-radio-clients *max_radio_clients* *wlan_id*

Syntax Description

<i>max_radio_clients</i>	Maximum number of client connections to be accepted per access point radio. The valid range is from 1 to 200.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to specify the maximum number of client connections per access point radio on WLAN ID 2:

```
> config wlan max-radio-clients 25 2
```

Related Commands

show wlan

config wlan mdns

To configure an multicast DNS (mDNS) profile for a WLAN, use the **config wlan mdns** command.

config wlan mdns {enable | disable | profile {*profile-name* | none}} {*wlan_id* | all}

Syntax Description

enable	Enables mDNS snooping on a WLAN.
disable	Disables mDNS snooping on a WLAN.
profile	Configures an mDNS profile for a WLAN.
<i>profile-name</i>	Name of the mDNS profile to be associated with a WLAN.
none	Removes all existing mDNS profiles from the WLAN. You cannot configure mDNS profiles on the WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
all	Configures the mDNS profile for all WLANs.

Command Default

By default, mDNS snooping is enabled on WLANs.

Command History

Release	Modification
7.4	This command was introduced.

Usage Guidelines

You must disable the WLAN before you use this command. Clients receive service advertisements only for the services associated with the profile. The controller gives the highest priority to the profiles associated to interface groups, followed by the interface profiles, and then the WLAN profiles. Each client is mapped to a profile based on the order of priority.

Examples

The following example shows how to configure an mDNS profile for a WLAN.

```
Device > config wlan mdns profile profile1 1
```

Related Commands

config mdns query interval
config mdns service
config mdns snooping
config interface mdns-profile
config interface group mdns-profile

config mdns profile
show mdns profile
show mnds service
clear mdns service-database
debug mdns all
debug mdns error
debug mdns detail
debug mdns message

config wlan media-stream

To configure multicast-direct for a wireless LAN media stream, use the **config wlan media-stream** command.

config wlan media-stream multicast-direct {*wlan_id* | **all**} {**enable** | **disable**}

Syntax Description

multicast-direct	Configures multicast-direct for a wireless LAN media stream.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
all	Configures the wireless LAN on all media streams.
enable	Enables global multicast to unicast conversion.
disable	Disables global multicast to unicast conversion.

Command Default

None.

Usage Guidelines

Media stream multicast-direct requires load based Call Admission Control (CAC) to run. WLAN quality of service (QoS) needs to be set to either gold or platinum.

Examples

This example shows how to enable the global multicast-direct media stream with WLAN ID 2:

```
> config wlan media-stream multicast-direct 2 enable
```

Related Commands

config wlan
config wlan qos
show wlan

config wlan mfp

To configure management frame protection (MFP) options for the wireless LAN, use the **config wlan mfp** command.

config wlan mfp {client [enable | disable] *wlan_id* | infrastructure protection [enable | disable] *wlan_id*}

Syntax Description

client	Configures client MFP for the wireless LAN.
enable	(Optional) Enables the feature.
disable	(Optional) Disables the feature.
<i>wlan_id</i>	Wireless LAN identifier (1 to 512).
infrastructure protection	(Optional) Configures the infrastructure MFP for the wireless LAN.

Command Default

None.

Examples

This example shows how to configure client management frame protection for WLAN ID 1:

```
> config wlan mfp client enable 1
```

Related Commands

show wlan

show run-config

config wlan mobility anchor

To change the state of MAC filtering on a wireless LAN, use the **config wlan mobility anchor** command.

config wlan mobility anchor {**add** | **delete**} *wlan_id ip_address*

Syntax Description

add	Enables MAC filtering on a wireless LAN.
delete	Disables MAC filtering on a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>ip_address</i>	Member switch IP address for anchoring the wireless LAN.

Command Default

None.

Examples

This example shows how to configure the mobility wireless LAN anchor list with WLAN ID 4 and IP address 192.168.0.14:6:

```
> config wlan mobility anchor add 4 192.168.0.14
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
debug mobility
show mobility anchor
show mobility statistics
show mobility summary
config wlan mobility foreign-map

config wlan mobility foreign-map

To configure interfaces or interface groups for foreign Cisco WLCs, use the **config wlan mobility foreign-map** command.

config wlan mobility foreign-map {add | delete} *wlan_id* *foreign_mac_address* {*interface_name* | *interface_group_name*}

Syntax Description

add	Adds an interface or interface group to the map of foreign controllers.
delete	Deletes an interface or interface group from the map of foreign controllers.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
<i>foreign_mac_address</i>	Foreign switch MAC address on a WLAN.
<i>interface_name</i>	Interface name up to 32 alphanumeric characters.
<i>interface_group_name</i>	Interface group name up to 32 alphanumeric characters.

Command Default

None.

Examples

This example shows how to add an interface group for foreign Cisco WLCs with WLAN ID 4 and a foreign switch MAC address on WLAN 00:21:1b:ea:36:60:

```
> config wlan mobility foreign-map add 4 00:21:1b:ea:36:60 mygroup1
```

Related Commands

config wlan mobility anchor
config mobility group member
debug mobility
show mobility anchor
show mobility summary

config wlan multicast buffer

To configure the radio multicast packet buffer size, use the **config wlan multicast buffer** command.

config wlan multicast buffer {**enable** | **disable**} *buffer-size*

Syntax Description

enable	Enables the multicast interface feature for a wireless LAN.
disable	Disables the multicast interface feature on a wireless LAN.
<i>buffer-size</i>	Radio multicast packet buffer size. The range is from 30 to 60. Enter 0 to indicate APs will dynamically adjust the number of buffers allocated for multicast.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

30.

Examples

This example shows how to configure radio multicast buffer settings:

```
> config wlan multicast buffer enable 45 222
```

Related Commands

config 802.11a multicast data-rate

config wlan multicast interface

To configure a multicast interface for a wireless LAN, use the **config wlan multicast interface** command.

config wlan multicast interface *wlan_id* {**enable** | **disable**} *interface_name*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables multicast interface feature for a wireless LAN.
delete	Disables multicast interface feature on a wireless LAN.
<i>interface_name</i>	Interface name.
Note The interface name can only be specified in lower case characters.	

Command Default

Multicast is disabled.

Examples

This example shows how to enable the multicast interface feature for a wireless LAN with WLAN ID 4 and interface name myinterface1:

```
> config wlan multicast interface 4 enable myinterface1
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
debug mobility
show mobility anchor
show mobility statistics
show mobility summary
config wlan mobility foreign-map

config wlan nac

To enable or disable Network Admission Control (NAC) out-of-band support for a WLAN, use the **config wlan nac** command.

config wlan nac {snmp | radius} {enable | disable} *wlan_id*

Syntax Description

snmp	Configures SNMP NAC support.
radius	Configures RADIUS NAC support.
enable	Enables NAC for the WLAN.
disable	Disables NAC for the WLAN.
<i>wlan_id</i>	WLAN identifier from 1 to 512.

Command Default

None.

Usage Guidelines

You should enable AAA override before you enable the RADIUS NAC state. You also should disable FlexConnect local switching before you enable the RADIUS NAC state.

Examples

This example shows how to configure SNMP NAC support for WLAN 13:

```
> config wlan nac snmp enable 13
```

This example shows how to configure RADIUS NAC support for WLAN 34:

```
> config wlan nac radius enable 20
```

Related Commands

show nac statistics
show nac summary
config guest-lan nac
debug nac

config wlan override-rate-limit

To override the bandwidth limits for upstream and downstream traffic per user and per service set identifier (SSID) defined in the QoS profile, use the **config wlan override-rate-limit** command.

config wlan override-rate-limit *wlan_id* { **average-data-rate** | **average-realtime-rate** | **burst-data-rate** | **burst-realtime-rate** } { **per-ssid** | **per-client** } { **downstream** | **upstream** } *rate*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
average-data-rate	Specifies the average data rate for TCP traffic per user or per SSID. The range is from 0 to 51,200 Kbps.
average-realtime-rate	Specifies the average real-time data rate for UDP traffic per user or per SSID. The range is from 0 to 51,200 Kbps.
burst-data-rate	Specifies the peak data rate for TCP traffic per user or per SSID. The range is from 0 to 51,200 Kbps.
burst-realtime-rate	Specifies the peak real-time data rate for UDP traffic per user or per SSID. The range is from 0 to 51,200 Kbps.
per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
per-client	Configures the rate limit for each client associated with the SSID.
downstream	Configures the rate limit for downstream traffic.
upstream	Configures the rate limit for upstream traffic.
<i>rate</i>	Data rate for TCP or UDP traffic per user or per SSID. The range is from 0 to 51,200 Kbps. A value of 0 imposes no bandwidth restriction on the QoS profile.

Command Default

None.

Usage Guidelines

The rate limits are enforced by the controller and the AP. For central switching, the controller handles the downstream enforcement of per-client rate limit and the AP handles the enforcement of the upstream traffic and per-SSID rate limit for downstream traffic. When the AP enters standalone mode it handles the downstream enforcement of per-client rate limits too.

In FlexConnect local switching and standalone modes, per-client and per-SSID rate limiting is done by the AP for downstream and upstream traffic. However, in FlexConnect standalone mode, the configuration is not

saved on the AP, so when the AP reloads, the configuration is lost and rate limiting does not happen after reboot.

For roaming clients, if the client roams between the APs on the same controller, same rate limit parameters are applied on the client. However, if the client roams from an anchor to a foreign controller, the per-client downstream rate limiting uses the parameters configured on the anchor controller while upstream rate limiting uses the parameters of the foreign controller.

Examples

This example shows how to configure the burst real-time actual rate 2000 Kbps for the upstream traffic per SSID:

```
> config wlan override-rate-limit 2 burst-realtime-rate per-ssid upstream 2000
```

Related Commands

config qos average-realtime-rate

config qos average-data-rate

config qos burst-data-rate

config qos burst-realtime-rate

show qos

show wlan

show client details

show ap stats

config wlan passive-client

To configure passive-client feature on a wireless LAN, use the **config wlan passive-client** command.

config wlan passive-client {enable | disable} *wlan_id*

Syntax Description

enable	Enables the passive-client feature on a WLAN.
disable	Disables the passive-client feature on a WLAN.
<i>wlan_id</i>	WLAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

You need to enable the global multicast mode and multicast-multicast mode by using the **config network multicast global** and **config network multicast mode multicast** commands before entering this command.



Note

You should configure the multicast in multicast-multicast mode only not in unicast mode. The passive client feature does not work with multicast-unicast mode in this release.

Examples

This example shows how to configure the passive client on wireless LAN ID 2:

```
> config wlan passive-client enable 2
```

Related Commands

config wlan
config network multicast global
config network multicast mode multicast
show wlan

config wlan peer-blocking

To configure peer-to-peer blocking on a WLAN, use the **config wlan peer-blocking** command.

config wlan peer-blocking {**disable** | **drop** | **forward-upstream**} *wlan_id*

Syntax Description

disable	Disables peer-to-peer blocking and bridge traffic locally within the controller whenever possible.
drop	Causes the controller to discard the packets.
forward-upstream	Causes the packets to be forwarded on the upstream VLAN. The device above the controller decides what action to take regarding the packets.
<i>wlan_id</i>	WLAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to disable the peer-to-peer blocking for WLAN ID 1:

```
> config wlan peer-blocking disable 1
```

Related Commands

show wlan

config wlan pmipv6 default-realm

To configure a default realm for a PMIPv6 WLAN, use the **config wlan pmipv6 default-realm** command.

config wlan pmipv6 default-realm { *default-realm-name* | **none** } *wlan_id*

Syntax Description

<i>default-realm-name</i>	Default realm name for the WLAN.
none	Clears the realm name for the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure a default realm name on a PMIPv6 WLAN:

```
> config wlan pmipv6 default-realm XYZ 6
```

Related Commands

config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config pmipv6 domain
show wlan summary
show client summary

config wlan pmipv6 mobility-type

To configure the mobility type on a WLAN, use the **config wlan pmipv6 mobility-type** command.

config wlan pmipv6 mobility-type {none | pmipv6 } { *wlan_id* | all }

Syntax Description

none	Configures a WLAN with Simple IP mobility.
pmipv6	Configures a WLAN with PMIPv6 mobility.
all	Enables the specified type of mobility for all WLANs.
<i>wlan_id</i>	WLAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

You must disable the WLAN when you configure the mobility type.

Examples

This example shows how to configure the mobility type as PMIPv6 on a WLAN:

```
> config wlan pmipv6 mobility-type pmipv6 16
```

Related Commands

config wlan pmipv6 profile-name
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary
show client summary

config wlan pmipv6 profile_name

To configure a profile name for the PMIPv6 WLAN, use the **config wlan pmipv6 profile_name** command.

config wlan pmipv6 profile_name *profile_name* *wlan_id*

Syntax Description

<i>profile_name</i>	Profile name for the PMIPv6 WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None.

Usage Guidelines

This command binds a profile name to the PMIPv6 WLAN or SSID. Each time that a mobile node associates with the controller, it uses the profile name and NAI in the trigger to the PMIPv6 module. The PMIPv6 module extracts all the profile specific parameters such as LMA IP, APN, and NAI and sends the PBU to the ASR5K.

Examples

This example shows how to create a profile named ABC01 on a PMIPv6 WLAN:

```
> config wlan pmipv6 profile_name ABC01 16
```

Related Commands

config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary

config wlan profiling

To configure client profiling on a WLAN, use the **config wlan profiling** command.

config wlan profiling {local | radius} {all | dhcp | http} {enable | disable} *wlan_id*

Syntax Description

local	Configures client profiling in Local mode for a WLAN.
radius	Configures client profiling in RADIUS mode on a WLAN.
all	Configures DHCP and HTTP client profiling in a WLAN.
dhcp	Configures DHCP client profiling alone in a WLAN.
http	Configures HTTP client profiling in a WLAN.
enable	Enables the specific type of client profiling in a WLAN. When you enable HTTP profiling, the Cisco WLC collects the HTTP attributes of clients for profiling. When you enable DHCP profiling, the Cisco WLC collects the DHCP attributes of clients for profiling.
disable	Disables the specific type of client profiling in a WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Usage Guidelines

Ensure that you have disabled the WLAN before configuring client profiling on the WLAN.

Command Default

Disabled.

Usage Guidelines

Only clients connected to port 80 for HTTP can be profiled. IPv6 only clients are not profiled.

If a session timeout is configured for a WLAN, clients must send the HTTP traffic before the configured timeout to get profiled.

This feature is not supported on the following:

- FlexConnect Standalone mode
- FlexConnect Local Authentication

Examples

This example shows how to enable both DHCP and HTTP profiling on a WLAN:

```
> config wlan profiling radius all enable 6
    HTTP Profiling successfully enabled.
    DHCP Profiling successfully enabled.
```

Related Commands

show wlan

config wlan qos

To change the quality of service (QoS) for a wireless LAN, use the **config wlan qos** command.

config wlan qos *wlan_id* {**bronze** | **silver** | **gold** | **platinum**}

config wlan qos foreignAp {**bronze** | **silver** | **gold** | **platinum**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
bronze	Specifies the bronze QoS policy.
silver	Specifies the silver QoS policy.
gold	Specifies the gold QoS policy.
platinum	Specifies the platinum QoS policy.
foreignAp	Specifies third-party access points.

Command Default

Silver.

Examples

This example shows how to set the highest level of service on wireless LAN 1:

```
> config wlan qos 1 gold
```

Related Commands

show wlan

config wlan radio

To set the Cisco radio policy on a wireless LAN, use the **config wlan radio** command.

config wlan radio *wlan_id* {all | 802.11a | 802.11bg | 802.11g | 802.11ag}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
all	Configures the wireless LAN on all radio bands.
802.11a	Configures the wireless LAN on only 802.11a.
802.11bg	Configures the wireless LAN on only 802.11b/g (only 802.11b if 802.11g is disabled).
802.11g	Configures the wireless LAN on 802.11g only.

Command Default

None.

Examples

This example shows how to configure the wireless LAN on all radio bands:

```
> config wlan radio 1 all
```

Related Commands

config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan

config wlan radius_server acct

To configure RADIUS accounting servers of a WLAN, use the **config wlan radius_server acct** command.

config wlan radius_server acct {enable | disable} *wlan_id* | {add *wlan_id* *server_id* | delete *wlan_id* {all | *server_id*}}

Syntax Description

enable	Enables RADIUS accounting for the WLAN.
disable	Disables RADIUS accounting for the WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
add	Adds a link to a configured RADIUS accounting server.
<i>server_id</i>	RADIUS server index.
delete	Deletes a link to a configured RADIUS accounting server.

Command Default

None.

Examples

This example shows how to enable RADIUS accounting for the WLAN 2:

```
> config wlan radius_server acct enable 2
```

This example shows how to add a link to a configured RADIUS accounting server:

```
> config wlan radius_server acct add 2 5
```

Related Commands

```
config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan
```

config wlan radius_server acct interim-update

To configure the interim update of a RADIUS accounting server of a WLAN, use the **config wlan radius_server acct interim-update** command.

config wlan radius_server acct interim-update {*interval* | **enable** | **disable**} *wlan_id*

Syntax Description

interim-update	Configures the interim update of the RADIUS accounting server.
<i>interval</i>	Interim update interval that you specify. The valid range is 180 seconds to 3600 seconds.
enable	Enables interim update of the RADIUS accounting server for the WLAN.
disable	Disables interim update of the RADIUS accounting server for the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

Enabled at 600 seconds.

Examples

This example shows how to specify an interim update of 200 seconds to a RADIUS accounting server of WLAN 2:

```
> config wlan radius_server acct interim-update 200 2
```

Related Commands

```
config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan
```

config wlan radius_server auth

To configure RADIUS authentication servers of a WLAN, use the **config wlan radius_server auth** command.

config wlan radius_server auth {enable *wlan_id* | disable *wlan_id*} {add *wlan_id* *server_id* | delete *wlan_id* {all | *server_id*}}

Syntax Description

auth	Configures a RADIUS authentication
enable	Enables RADIUS authentication for this WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
disable	Disables RADIUS authentication for this WLAN.
add	Adds a link to a configured RADIUS server.
<i>server_id</i>	RADIUS server index.
delete	Deletes a link to a configured RADIUS server.
all	Deletes all links to configured RADIUS servers.

Command Default

None.

Examples

This example shows how to add a link to a configured RADIUS authentication server with WLAN ID 1 and Server ID 1:

```
> config wlan radius_server auth add 1 1
```

Related Commands

config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan

config wlan radius_server acct interim-update

To configure a wireless LAN's RADIUS servers, use the **config wlan radius_server acct interim-update** command.

config wlan radius_server*acct interim-update* {**enable** *wlan_id* | **disable** *wlan_id*} {*interval wlan_id*}

Syntax Description

enable	Enables RADIUS authentication or accounting for this WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
disable	Disables RADIUS authentication or accounting for this WLAN.
<i>interval</i>	Accounting interim interval between 180 to 3600 seconds.

Command Default

None.

Usage Guidelines

This command helps to set some time as a default if the timeout interval is not specified.

Examples

This example shows how to force the 10 minutes as the default, if timeout interval is not specified:

```
> config wlan radius_server acct interim-update 600 1
```

Related Commands

```
config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan
```

config wlan radius_server overwrite-interface

To configure a wireless LAN's RADIUS dynamic interface, use the **config wlan radius_server overwrite-interface** command.

config wlan radius_server overwrite-interface {apgroup | enable | disable | wlan} *wlan_id*

Syntax Description

apgroup	Enables AP group's interface for all RADIUS traffic on the WLAN.
enable	Enables RADIUS dynamic interface for this WLAN.
disable	Disables RADIUS dynamic interface for this WLAN.
wlan	Enables WLAN's interface for all RADIUS traffic on the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

The controller uses the management interface as identity. If the RADIUS server is on a directly connected dynamic interface, the traffic is sourced from the dynamic interface. Otherwise, the management IP address is used.

If the feature is enabled, controller uses the interface specified on the WLAN configuration as identity and source for all RADIUS related traffic on the WLAN.

Examples

This example shows how to enable RADIUS dynamic interface for a WLAN with an ID 1:

```
> config wlan radius_server overwrite-interface enable 1
```

Related Commands

```
config 802.11a enable
config 802.11a disable
config 802.11b enable
config 802.11b disable
config 802.11b 11gSupport enable
config 802.11b 11gSupport disable
show wlan
```

config wlan roamed-voice-client re-anchor

To configure a roamed voice client's reanchor policy, use the **config wlan roamed-voice-client re-anchor** command.

config wlan roamed-voice-client re-anchor {enable | disable} *wlan_id*

Syntax Description

enable	Enables the roamed client's reanchor policy.
disable	Disables the roamed client's reanchor policy.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

Disabled.

Examples

This example shows how to enable a roamed voice client's reanchor policy where WLAN ID is 1:

```
> config wlan roamed-voice-client re-anchor enable 1
```

Related Commands

show wlan

config wlan security 802.1X

To change the state of 802.1X security on the wireless LAN Cisco radios, use the **config wlan security 802.1X** command.

config wlan security 802.1X {**enable** {*wlan_id* | **foreignAp**} | **disable** {*wlan_id* | **foreignAp**} | **encryption** {*wlan_id* | **foreignAp**} {**0** | **40** | **104**} | **on-macfilter-failure** {**enable** | **disable**}}

Syntax Description

enable	Enables the 802.1X settings.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
disable	Disables the 802.1X settings.
encryption	Specifies the static WEP keys and indexes.
0	Specifies a WEP key size of 0 (no encryption) bits. The default value is 104. Note All keys within a wireless LAN must be the same size.
40	Specifies a WEP key size of 40 bits. The default value is 104. Note All keys within a wireless LAN must be the same size.
104	Specifies a WEP key size of 104 bits. The default value is 104. Note All keys within a wireless LAN must be the same size.
on-macfilter-failure	Configures 802.1X on MAC filter failure.
enable	Enables 802.1X authentication on MAC filter failure.
disable	Disables 802.1X authentication on MAC filter failure.

Command Default

None

Usage Guidelines

To change the encryption level of 802.1X security on the wireless LAN Cisco radios, use the following key sizes:

- 0—no 802.1X encryption.
- 40—40/64-bit encryption.
- 104—104/128-bit encryption. (This is the default encryption setting.)

Examples

The following example shows how to configure 802.1X security on WLAN ID 16.

```
Device > config wlan security 802.1X enable 16
```

Related Commands

show wlan

config wlan security ckip

To configure Cisco Key Integrity Protocol (CKIP) security options for the wireless LAN, use the **config wlan security ckip** command.

config wlan security ckip {enable | disable} *wlan_id* [**akm psk set-key** {hex | ascii} {40 | 104} **key** *key_index* *wlan_id* | **mmh-mic** {enable | disable} *wlan_id* | **kp** {enable | disable} *wlan_id*]

Syntax Description

enable	Enables CKIP security.
disable	Disables CKIP security.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
akm psk set-key	(Optional) Configures encryption key management for the CKIP wireless LAN.
hex	Specifies a hexadecimal encryption key.
ascii	Specifies an ASCII encryption key.
40	Sets the static encryption key length to 40 bits for the CKIP WLAN. 40-bit keys must contain 5 ASCII text characters or 10 hexadecimal characters.
104	Sets the static encryption key length to 104 bits for the CKIP WLAN. 104-bit keys must contain 13 ASCII text characters or 26 hexadecimal characters.
key	Specifies the CKIP WLAN key settings.
<i>key_index</i>	Configured PSK key index.
mmh-mic	(Optional) Configures multi-modular hash message integrity check (MMH MIC) validation for the CKIP wireless LAN.
kp	(Optional) Configures key-permutation for the CKIP wireless LAN.

Command Default

None.

Examples

This example shows how to configure a CKIP WLAN encryption key of 104 bits (26 hexadecimal characters) for PSK key index 2 on WLAN 03:

```
> config wlan security ckip akm psk set-key hex 104 key 2 03
```

Related Commands

config wlan ccx aironet-ie
show wlan

config wlan security cond-web-redir

To enable or disable conditional web redirect, use the **config wlan security cond-web-redir** command.

config wlan security cond-web-redir {enable | disable} *wlan_id*

Syntax Description

enable	Enables conditional web redirect.
disable	Disables conditional web redirect.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to enable the conditional web direct on WLAN ID 2:

```
> config wlan security cond-web-redir enable 2
```

Related Commands

show wlan

config wlan security eap-passthru

To configure the 802.1X frames pass through on to the external authenticator, use the **config wlan security eap-passthru** command.

config wlan security eap-passthru {enable | disable} *wlan_id*

Syntax Description

enable	Enables 802.1X frames pass through to external authenticator.
disable	Disables 802.1X frames pass through to external authenticator.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to enable the 802.1X frames pass through to external authenticator on WLAN ID 2:

```
> config wlan security eap-passthru enable 2
```

Related Commands

show wlan

config wlan security ft

To configure 802.11r fast transition parameters, use the **config wlan security ft** command.

config wlan security ft {**enable** | **disable** | **reassociation-timeout** *timeout-in-seconds*} *wlan_id*

Syntax Description

enable	Enables 802.11r fast transition roaming support.
disable	Disables 802.11r fast transition roaming support.
reassociation-timeout	Configures reassociation deadline interval.
<i>timeout-in-seconds</i>	Reassociation timeout value in seconds. The valid range is 1 to 100 seconds.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

Ensure that you have disabled the WLAN before you proceed.

Examples

This example shows how to enable 802.11r fast transition roaming support on WLAN 2:

```
> config wlan security ft enable 2
```

This example shows how to set the reassociation timeout value of 20 seconds for 802.11r fast transition roaming support on WLAN 2:

```
> config wlan security ft reassociation-timeout 20 2
```

Related Commands

show wlan

config wlan security ft over-the-ds

To configure 802.11r fast transition parameters over a distributed system, use the **config wlan security ft over-the-ds** command.

config wlan security ft over-the-ds {enable | disable} *wlan_id*

Syntax Description	enable	Enables 802.11r fast transition roaming support over a distributed system.
	disable	Disables 802.11r fast transition roaming support over a distributed system.
	<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default Enabled.

Usage Guidelines Ensure that you have disabled the WLAN before you proceed.
Ensure that 802.11r fast transition is enabled on the WLAN.

Examples This example shows how to enable 802.11r fast transition roaming support over a distributed system on WLAN ID 2:

```
> config wlan security ft over-the-ds enable 2
```

Related Commands **show wlan**

config wlan security IPsec disable

To disable IPsec security, use the **config wlan security IPsec disable** command.

config wlan security IPsec disable {*wlan_id* | **foreignAp**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to disable the IPsec for WLAN ID 16:

```
> config wlan security IPsec disable 16
```

Related Commands

show wlan

config wlan security IPsec enable

To enable IPsec security, use the **config wlan security IPsec enable** command.

config wlan security IPsec enable {*wlan_id* | **foreignAp**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to enable the IPsec for WLAN ID 16:

```
> config wlan security IPsec enable 16
```

Related Commands

show wlan

config wlan security IPsec authentication

To modify the IPsec security authentication protocol used on the wireless LAN, use the **config wlan security IPsec authentication** command.

config wlan security IPsec authentication {**hmac-md5** | **hmac-sha-1**} {*wlan_id* | **foreignAp**}

Syntax Description

hmac-md5	Specifies the IPsec HMAC-MD5 authentication protocol.
hmac-sha-1	Specifies the IPsec HMAC-SHA-1 authentication protocol.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to configure the IPsec HMAC-SHA-1 security authentication parameter for WLAN ID 1:

```
> config wlan security IPsec authentication hmac-sha-1 1
```

Related Commands

show wlan

config wlan security IPsec encryption

To modify the IPsec security encryption protocol used on the wireless LAN, use the **config wlan security IPsec encryption** command.

config wlan security IPsec encryption {3des | aes | des} {*wlan_id* | foreignAp}

Syntax Description

3des	Enables IPsec 3DES encryption.
aes	Enables IPsec AES 128-bit encryption.
des	Enables IPsec DES encryption.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to configure the IPsec AES encryption:

```
> config wlan security IPsec encryption aes 1
```

Related Commands

show wlan

config wlan security IPsec config

To configure the proprietary Internet Key Exchange (IKE) CFG-Mode parameters used on the wireless LAN, use the **config wlan security IPsec config** command.

config wlan security IPsec config qotd *ip_address* [*wlan_id* | **foreignAp**]

Syntax Description

qotd	Configures the quote-of-the-day server IP for cfg-mode.
<i>ip_address</i>	Quote-of-the-day server IP for cfg-mode.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Usage Guidelines

IKE is used as a method of distributing the session keys (encryption and authentication), as well as providing a way for the VPN endpoints to agree on how the data should be protected. IKE keeps track of connections by assigning a bundle of Security Associations (SAs), to each connection.

Examples

This example shows how to configure the quote-of-the-day server IP 44.55.66.77 for cfg-mode for WLAN 1:

```
> config wlan security IPsec config qotd 44.55.66.77 1
```

Related Commands

show wlan

config wlan security IPsec ike authentication

To modify the IPsec Internet Key Exchange (IKE) authentication protocol used on the wireless LAN, use the **config wlan security IPsec ike authentication** command.

config wlan security IPsec ike authentication {**certificates** {*wlan_id* | **foreignAp**} | **pre-share-key** {*wlan_id* | **foreignAp**} *key* | **xauth-psk** {*wlan_id* | **foreignAp**} *key*}

Syntax Description

certificates	Enables the IKE certificate mode.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
pre-share-key	Enables the IKE Xauth with preshared keys.
xauth-psk	Enables the IKE preshared key.
<i>key</i>	Key required for preshare and xauth-psk.

Command Default

None.

Examples

This example shows how to configure the IKE certification mode:

```
> config wlan security IPsec ike authentication certificates 16
```

Related Commands

show wlan

config wlan security IPsec ike dh-group

To modify the IPsec Internet Key Exchange (IKE) Diffie Hellman group used on the wireless LAN, use the **config wlan security IPsec ike dh-group** command.

config wlan security IPsec ike dh-group {*wlan_id* | **foreignAp**} {**group-1** | **group-2** | **group-5**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
group-1	Specifies DH group 1 (768 bits).
group-2	Specifies DH group 2 (1024 bits).
group-5	Specifies DH group 5 (1536 bits).

Command Default

None.

Examples

This example shows how to configure the Diffie Hellman group parameter for group-1:

```
> config wlan security IPsec ike dh-group 1 group-1
```

Related Commands

show wlan

config wlan security IPsec ike lifetime

To modify the IPsec Internet Key Exchange (IKE) lifetime used on the wireless LAN, use the **config wlan security IPsec ike lifetime** command.

config wlan security IPsec ike lifetime {*wlan_id* | **foreignAp**} *seconds*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>seconds</i>	IKE lifetime in seconds, between 1800 and 345600.

Command Default

None.

Examples

This example shows how to configure the IPsec IKE lifetime use on the wireless LAN:

```
> config wlan security IPsec ike lifetime 1 1900
```

Related Commands

show wlan

config wlan security IPsec ike phase1

To modify IPsec Internet Key Exchange (IKE) Phase 1 used on the wireless LAN, use the **config wlan security IPsec ike phase1** command.

config wlan security IPsec ike phase1 {**aggressive** | **main**} {*wlan_id* | **foreignAp**}

Syntax Description

aggressive	Enables the IKE aggressive mode.
main	Enables the IKE main mode.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to modify IPsec IKE Phase 1:

```
> config wlan security IPsec ike phase1 aggressive 16
```

Related Commands

show wlan

config wlan security IPsec ike contivity

To modify Nortel's Contivity VPN client support on the wireless LAN, use the **config wlan security IPsec ike contivity** command.

config wlan security IPsec ike contivity {enable | disable} {*wlan_id* | foreignAp}

Syntax Description

enable	Enables contivity support for this WLAN.
disable	Disables contivity support for this WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to modify Contivity VPN client support:

```
> config wlan security IPsec ike contivity enable 14
```

Related Commands

show wlan

config wlan security passthru

To modify the IPsec pass-through used on the wireless LAN, use the **config wlan security passthru** command.

config wlan security passthru {enable | disable} {wlan_id | foreignAp} [ip_address]

Syntax Description

enable	Enables IPsec pass-through.
disable	Disables IPsec pass-through.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>ip_address</i>	(Optional) IP address of the IPsec gateway (router) that is terminating the VPN tunnel.

Command Default

None.

Examples

This example shows how to modify IPsec pass-through used on the wireless LAN:

```
> config wlan security passthru enable 3 192.12.1.1
```

Related Commands

show wlan

config wlan security pmf

To configure 802.11w Management Frame Protection (MFP) on a WLAN, use the **config wlan security pmf** command.

config wlan security pmf {**disable** | **optional** | **required** | **association-comeback** *association-comeback_timeout* | **saquery-retrytimeout** *saquery-retry_timeout*} *wlan_id*

Syntax Description

disable	Disables 802.11w MFP protection on a WLAN.
optional	Enables 802.11w MFP protection on a WLAN.
required	Requires clients to negotiate 802.11w MFP protection on a WLAN.
association-comeback	Configures the 802.11w association comeback time.
<i>association-comeback_timeout</i>	Association comeback interval in seconds. Time interval that an associated client must wait before the association is tried again after it is denied with a status code 30. The status code 30 message is "Association request rejected temporarily; Try again later". The range is from 1 to 20 seconds.
saquery-retrytimeout	Configures the 802.11w Security Association (SA) query retry timeout.
<i>saquery-retry_timeout</i>	Time interval identified in the association response to an already associated client before the association can be tried again. This time interval checks if the client is a real client and not a rogue client during the association comeback time. If the client does not respond within this time, the client association is deleted from the controller. The range is from 100 to 500 ms.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

Default SA query retry timeout is 200 milliseconds.

Default association comeback timeout is 1 second.

Usage Guidelines

802.11w introduces an Integrity Group Temporal Key (IGTK) that is used to protect broadcast or multicast robust management frames. IGTK is a random value, assigned by the authenticator station (controller) used to protect MAC management protocol data units (MMPDUs) from the source STA. The 802.11w IGTK key is derived using the four way handshake and is used only on WLANs that are configured with WPA or WPA2 security at Layer 2.

Examples

This example shows how to enable 802.11w MFP protection on a WLAN:

```
> config wlan security pmf optional 1
```

Examples

This example shows how to configure the SA query retry timeout on a WLAN:

```
> config wlan security pmf saquery-retrytimeout 300 1
```

Related Commands

show wlan

show client detail

config wlan security wpa akm pmf

debug 11w-pmf

config wlan security splash-page-web-redir

To enable or disable splash page web redirect, use the **config wlan security splash-page-web-redir** command.

config wlan security splash-page-web-redir {enable | disable} *wlan_id*

Syntax Description

enable	Enables splash page web redirect.
disable	Disables splash page web redirect.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

Disabled.

Examples

This example shows how to enable splash page web redirect:

```
> config wlan security splash-page-web-redir enable 2
```

Related Commands

show wlan

config wlan security static-wep-key authentication

To configure static Wired Equivalent Privacy (WEP) key 802.11 authentication on a wireless LAN, use the **config wlan security static-wep-key authentication** command.

config wlan security static-wep-key authentication {**shared-key** | **open**} *wlan_id*

Syntax Description

shared-key	Enables shared key authentication.
open	Enables open system authentication.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to enable the static WEP shared key authentication for WLAN ID 1:

```
> config wlan security static-wep-key authentication shared-key 1
```

Related Commands

show wlan

config wlan security static-wep-key disable

To disable the use of static Wired Equivalent Privacy (WEP) keys, use the **config wlan security static-wep-key disable** command.

config wlan security static-wep-key disable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to disable the static WEP keys for WLAN ID 1:

```
> config wlan security static-wep-key disable 1
```

Related Commands

config wlan security wpa encryption

config wlan security static-wep-key enable

To enable the use of static Wired Equivalent Privacy (WEP) keys, use the **config wlan security static-wep-key enable** command.

config wlan security static-wep-key enable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to enable the use of static WEK keys for WLAN ID 1:

```
> config wlan security static-wep-key enable 1
```

Related Commands

config wlan security wpa encryption

config wlan security static-wep-key encryption

To configure the static Wired Equivalent Privacy (WEP) keys and indexes, use the **config wlan security static-wep-key encryption** command.

config wlan security static-wep-key encryption *wlan_id* {**40** | **104**} {**hex** | **ascii**} *key* *key-index*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
40	Specifies the encryption level of 40.
104	Specifies the encryption level of 104.
hex	Specifies to use hexadecimal characters to enter key.
ascii	Specifies whether to use ASCII characters to enter key.
<i>key</i>	WEP key in ASCII.
<i>key-index</i>	Key index (1 to 4).

Command Default

None.

Usage Guidelines

One unique WEP key index can be applied to each wireless LAN. Because there are only four WEP key indexes, only four wireless LANs can be configured for static WEP Layer 2 encryption.

Make sure to disable 802.1X before using this command.

Examples

This example shows how to configure the static WEP keys for WLAN ID 1 that uses hexadecimal character 0201702001 and key index 2:

```
> config wlan security static-wep-key encryption 1 40 hex 0201702001 2
```

Related Commands

show wlan

config wlan security tkip

To configure the Temporal Key Integrity Protocol (TKIP) Message Integrity Check (MIC) countermeasure hold-down timer, use the **config wlan security tkip** command.

config wlan security tkip hold-down *time wlan_id*

Syntax Description

hold-down	Configures the TKIP MIC countermeasure hold-down timer.
<i>time</i>	TKIP MIC countermeasure hold-down time in seconds. The range is from 0 to 60 seconds.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

60 seconds.

Usage Guidelines

TKIP countermeasure mode can occur if the access point receives 2 MIC errors within a 60 second period. When this situation occurs, the access point deauthenticates all TKIP clients that are associated to that 802.11 radio and holds off any clients for the countermeasure holdoff time.

Examples

This example shows how to configure the TKIP MIC countermeasure hold-down timer:

```
> config wlan security tkip
```

Related Commands

show wlan

config wlan security web-auth

To change the status of web authentication used on a wireless LAN, use the **config wlan security web-auth** command.

```
config wlan security web-auth {{acl | enable | disable} {wlan_id | foreignAp} [acl_name | none]} |
{on-macfilter-failure wlan_id} | {server-precedence wlan_id | local | ldap | radius} | {flexacl wlan_id
[ipv4_acl_name | none]} | {ipv6 acl wlan_id [ipv6_acl_name | none]}
```

Syntax Description

acl	Configures the access control list.
enable	Enables web authentication.
disable	Disables web authentication.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
foreignAp	Specifies third-party access points.
<i>acl_name</i>	(Optional) ACL name (up to 32 alphanumeric characters).
none	(Optional) Specifies no ACL name.
on-macfilter-failure	Enables web authentication on MAC filter failure.
server-precedence	Configures the authentication server precedence order for Web-Auth users.
local	Specifies the server type.
ldap	Specifies the server type.
radius	Specifies the server type.
flexacl	Specifies the IPv4 ACL name. You can enter up to 32 alphanumeric characters.
<i>ipv4_acl_name</i>	(Optional) IPv4 ACL name. You can enter up to 32 alphanumeric characters.
<i>ipv6_acl_name</i>	(Optional) IPv6 ACL name. You can enter up to 32 alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure the security policy for WLAN ID 1 and an ACL named ACL03:

```
> config wlan security web-auth acl 1 ACL03
```

Related Commands

show wlan

config wlan security web-passthrough acl

To add an access control list (ACL) to the wireless LAN definition, use the **config wlan security web-passthrough acl** command.

config wlan security web-passthrough acl {*wlan_id* | **foreignAp**} {*acl_name* | **none**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>acl_name</i>	ACL name (up to 32 alphanumeric characters).
none	Specifies that there is no ACL.

Command Default

None.

Examples

This example shows how to add an ACL to the wireless LAN definition:

```
> config wlan security web-passthrough acl 1 ACL03
```

Related Commands

show wlan

config wlan security web-passthrough disable

To disable a web captive portal with no authentication required on a wireless LAN, use the **config wlan security web-passthrough disable** command.

config wlan security web-passthrough disable {*wlan_id* | **foreignAp**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to disable a web captive portal with no authentication required on wireless LAN ID 1:

```
> config wlan security web-passthrough disable 1
```

Related Commands

show wlan

config wlan security web-passthrough email-input

To configure a web captive portal using an e-mail address, use the **config wlan security web-passthrough email-input** command.

config wlan security web-passthrough email-input {enable | disable} {*wlan_id* | foreignAp}

Syntax Description

email-input	Configures a web captive portal using an e-mail address.
enable	Enables a web captive portal using an e-mail address.
disable	Disables a web captive portal using an e-mail address.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to configure a web captive portal using an e-mail address:

```
> config wlan security web-passthrough email-input enable 1
```

Related Commands

show wlan

config wlan security web-passthrough enable

To enable a web captive portal with no authentication required on the wireless LAN, use the **config wlan security web-passthrough enable** command.

config wlan security web-passthrough enable {*wlan_id* | **foreignAp**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.

Command Default

None.

Examples

This example shows how to enable a web captive portal with no authentication required on wireless LAN ID 1:

```
> config wlan security web-passthrough enable 1
```

Related Commands

show wlan

config wlan security wpa akm 802.1x

To configure authentication key-management (AKM) using 802.1X, use the **config wlan security wpa akm 802.1x** command.

config wlan security wpa akm 802.1x {enable | disable} *wlan_id*

Syntax Description

enable	Enables the 802.1X support.
disable	Disables the 802.1X support.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None

Examples

The following example shows how to configure authentication using 802.1X.

```
Device > config wlan security wpa akm 802.1x enable 1
```

Related Commands

show wlan

config wlan security wpa akm cckm

To configure authentication key-management using Cisco Centralized Key Management (CCKM), use the **config wlan security wpa akm cckm** command.

config wlan security wpa akm cckm {**enable** *wlan_id* | **disable** *wlan_id* | *timestamp-tolerance* }

Syntax Description

enable	Enables CCKM support.
disable	Disables CCKM support.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>timestamp-tolerance</i>	CCKM IE time-stamp tolerance. The range is between 1000 to 5000 milliseconds; the default is 1000 milliseconds.

Command Default

None

Examples

The following example shows how to configure authentication key-management using CCKM.

```
Device > config wlan security wpa akm cckm 1500
```

Related Commands

debug cckm
show wlan

config wlan security wpa akm ft

To configure authentication key-management using 802.11r fast transition 802.1X, use the **config wlan security wpa akm ft** command.

config wlan security wpa akm ft [**over-the-air** | **over-the-ds** | **psk** | [**reassociation-timeout** *seconds*]] {**enable** | **disable**} *wlan_id*

Syntax Description

over-the-air	(Optional) Configures 802.11r fast transition roaming over-the-air support.
over-the-ds	(Optional) Configures 802.11r fast transition roaming DS support.
psk	(Optional) Configures 802.11r fast transition PSK support.
reassociation-timeout	(Optional) Configures the reassociation deadline interval. The valid range is between 1 to 100 seconds. The default value is 20 seconds.
<i>seconds</i>	Reassociation deadline interval in seconds.
enable	Enables 802.11r fast transition 802.1X support.
disable	Disables 802.11r fast transition 802.1X support.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure authentication key-management using 802.11r fast transition:

```
> config wlan security wpa akm ft reassociation-timeout 25 1
```

Related Commands

show wlan

config wlan security wpa akm pmf

To configure Authenticated Key Management (AKM) of management frames, use the **config wlan security wpa akm pmf** command.

config wlan security wpa akm pmf {802.1x | psk} {enable | disable} *wlan_id*

Syntax Description

802.1x	Configures 802.1X authentication for protection of management frames (PMF).
psk	Configures preshared keys (PSK) for PMF.
enable	Enables 802.1X authentication or PSK for PMF.
disable	Disables 802.1X authentication or PSK for PMF.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

Disabled.

Usage Guidelines

802.11w has two new AKM suites: 00-0F-AC:5 or 00-0F-AC:6. You must enable WPA and then disable the WLAN to configure PMF on the WLAN.

Examples

This example shows how to enable 802.1X authentication for PMF in a WLAN:

```
> config wlan security wpa akm pmf 802.1x enable 1
```

Related Commands

show wlan
show client detail
config wlan security pmf
debug 11w-pmf

config wlan security wpa akm psk

To configure the Wi-Fi protected access (WPA) preshared key mode, use the **config wlan security wpa akm psk** command.

config wlan security wpa akm psk {**enable** | **disable** | **set-key** *key-format* *key*} *wlan_id*

Syntax Description

enable	Enables WPA-PSK.
disable	Disables WPA-PSK.
set-key	Configures a preshared key.
<i>key-format</i>	Specifies key format. Either ASCII or hexadecimal.
<i>key</i>	WPA preshared key.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure the WPA preshared key mode:

```
> config wlan security wpa akm psk disable 1
```

Related Commands

show wlan

config wlan security wpa disable

To disable WPA1, use the **config wlan security wpa disable** command.

config wlan security wpa disable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to disable WPA:

```
> config wlan security wpa disable 1
```

Related Commands

show wlan

config wlan security wpa enable

To enable WPA1, use the **config wlan security wpa enable** command.

config wlan security wpa enable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure the WPA on WLAN ID 1:

```
> config wlan security wpa enable 1
```

Related Commands

show wlan

config wlan security wpa ciphers

To configure the Wi-Fi protected authentication (WPA1) or Wi-Fi protected authentication (WPA2), use the **config wlan security wpa ciphers** command.

config wlan security wpa {wpa1 | wpa2} **ciphers** {aes | tkip} {enable | disable} *wlan_id*

Syntax Description

wpa1	Configures WPA1 support.
wpa2	Configures WPA2 support.
ciphers	Configures WPA ciphers.
aes	Configures AES encryption support.
tkip	Configures TKIP encryption support.
enable	Enables WPA AES/TKIP mode.
disable	Disables WPA AES/TKIP mode.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

If you are not specifying the WPA versions, it implies the following:

- If the cipher enabled is AES, you are configuring WPA2/AES.
- If the ciphers enabled is AES+TKIP, you are configuring WPA/TKIP, WPA2/AES, or WPA/TKIP.
- If the cipher enabled is TKIP, you are configuring WPA/TKIP or WPA2/TKIP.

Examples

This example shows how to encrypt the WPA:

```
> config wlan security wpa wpa1 ciphers aes enable 1
```

Related Commands

show wlan

config wlan security wpa gtk-random

To enable the randomization of group temporal keys (GTK) between access points and clients on a WLAN, use the **config wlan security wpa gtk-random** command.

config wlan security wpa gtk-random {enable | disable} *wlan_id*

Syntax Description

enable	Enables the randomization of GTK keys between the access point and clients.
disable	Disables the randomization of GTK keys between the access point and clients.
<i>wlan_id</i>	WLAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

When you enable this command, the clients in the Basic Service Set (BSS) get a unique GTK key. The clients do not receive multicast or broadcast traffic.

Examples

This example shows how to enable the GTK randomization for each client associated on a WLAN:

```
> config wlan security wpa gtk-random enable 3
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan hotspot dot11u
config wlan hotspot clear-all
config wlan hotspot msap

config wlan security wpa wpa1 disable

To disable WPA1, use the **config wlan security wpa wpa1 disable** command.

config wlan security wpa wpa1 disable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to disable WPA1:

```
> config wlan security wpa wpa1 disable 1
```

Related Commands

show wlan

config wlan security wpa wpa1 enable

To enable WPA1, use the **config wlan security wpa wpa1 enable** command.

config wlan security wpa wpa1 enable *wlan_id*

Syntax Description	
	<i>wlan_id</i> Wireless LAN identifier between 1 and 512.

Command Default	
	None.

Examples	
	This example shows how to enable WPA1: > config wlan security wpa wpa1 enable 1

Related Commands	
	show wlan

config wlan security wpa wpa2 disable

To disable WPA2, use the **config wlan security wpa wpa2 disable** command.

config wlan security wpa wpa2 disable *wlan_id*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to disable WPA2:

```
> config wlan security wpa wpa2 disable 1
```

Related Commands

show wlan

config wlan security wpa wpa2 enable

To enable WPA2, use the **config wlan security wpa wpa2 enable** command.

config wlan security wpa wpa2 enable *wlan_id*

Syntax Description	

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default	

None.

Examples	

This example shows how to enable WPA2:

```
> config wlan security wpa wpa2 enable 1
```

Related Commands	

show wlan

config wlan security wpa wpa2 cache

To configure caching methods on a WLAN, use the **config wlan security wpa wpa2 cache** command.

config wlan security wpa wpa2 cache sticky {enable | disable} wlan_id

Syntax Description

sticky	Configures Sticky Key Caching (SKC) roaming support on the WLAN.
enable	Enables SKC roaming support on the WLAN.
disable	Disables SKC roaming support on the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

In SKC (Sticky Key caching) also known as PKC (Pro Active Key caching), the client stores each Pairwise Master Key (PMK) ID (PMKID) against a Pairwise Master Key Security Association (PMKSA). When a client finds an AP for which it has a PMKSA, it sends the PMKID in the association request to the AP. If the PMKSA is alive in the AP, the AP provides support for fast roaming. In SKC, full authentication is done on each new AP to which the client associates and the client must keep the PMKSA associated with all APs.

Examples

This example shows how to enable SKC roaming support on a WLAN:

```
> config wlan security wpa wpa2 cache sticky enable 1
```

Related Commands

config wlan security wpa wpa2 enable
config wlan security wpa wpa2 disable
config wlan security wpa wpa2 ciphers
show wlan

config wlan security wpa wpa2 cache sticky

To configure Sticky PMKID Caching (SKC) on a WLAN, use the **config wlan security wpa wpa2 cache sticky** command.

config wlan security wpa wpa2 cache sticky {enable |disable} *wlan_id*

Syntax Description

enable	Enables SKC on a WLAN.
disable	Disables SKC on a WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).

Command Default

Disabled.

Usage Guidelines

Beginning in Release 7.2 and later releases, the controller supports Sticky PMKID Caching (SKC). With sticky PMKID caching, the client receives and stores a different PMKID for every AP it associates with. The APs also maintain a database of the PMKID issued to the client. In SKC also known as PKC (Pro Active Key caching), the client stores each Pairwise Master Key (PMK) ID (PMKID) against a Pairwise Master Key Security Association (PMKSA). When a client finds an AP for which it has the PMKSA, it sends the PMKID in the association request to the AP. If the PMKSA is alive in the AP, the AP provides support for fast roaming. In SKC, full authentication is done on each new AP to which the client associates and the client must keep the PMKSA associated with all APs. For SKC, PMKSA is a per AP cache that the client stores and PMKSA is precalculated based on the BSSID of the new AP.

- You cannot use SKC for large scale deployments as the controller supports SKC only up to eight APs.
- SKC does not work across controllers in a mobility group.
- SKC works only on WPA2-enabled WLANs.
- SKC works only on local mode APs.

Examples

This example shows how to enable Sticky PMKID Caching on WLAN 5:

```
> config wlan security wpa wpa2 cache sticky enable 5
```

Related Commands

```
config wlan security wpa wpa2 enable
config wlan security wpa wpa2 disable
config wlan security wpa wpa2 ciphers
show wlan
```

config wlan security wpa wpa2 ciphers

To configure WPA2 ciphers and enable or disable Advanced Encryption Standard (AES) or Temporal Key Integrity Protocol (TKIP) data encryption for WPA2, use the **config wlan security wpa wpa2 ciphers** command

config wlan security wpa wpa2 ciphers {aes | tkip} {enable | disable} *wlan_id*

Syntax Description

aes	Configures AES data encryption for WPA2.
tkip	Configures TKIP data encryption for WPA2.
enable	Enables AES or TKIP data encryption for WPA2.
disable	Disables AES or TKIP data encryption for WPA2.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

AES.

Examples

This example shows how to enable AES data encryption for WPA2:

```
> config wlan security wpa wpa2 ciphers aes enable 1
```

Related Commands

config wlan security wpa wpa2 enable
config wlan security wpa wpa2 disable
config wlan security wpa wpa2 cache
show wlan

config wlan sip-cac disassoc-client

To enable client disassociation in case of session initiation protocol (SIP) call admission control (CAC) failure, use the **config wlan sip-cac disassoc-client** command.

config wlan sip-cac disassoc-client {enable | disable} *wlan_id*

Syntax Description	enable	Enables a client disassociation on a SIP CAC failure.
	disable	Disables a client disassociation on a SIP CAC failure.
	<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default Disabled.

Examples This example shows how to enable a client disassociation on a SIP CAC failure where the WLAN ID is 1:

```
> config wlan sip-cac disassoc-client enable 1
```

Related Commands

- show wlan
- config wlan sip-cac send-486busy

config wlan sip-cac send-486busy

To configure sending session initiation protocol (SIP) 486 busy message if a SIP call admission control (CAC) failure occurs, use the **config wlan sip-cac send-486busy** command:

config wlan sip-cac send-486busy {enable | disable} *wlan_id*

Syntax Description

enable	Enables sending a SIP 486 busy message upon a SIP CAC failure.
disable	Disables sending a SIP 486 busy message upon a SIP CAC failure.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

Enabled.

Examples

This example shows how to enable sending a SIP 486 busy message upon a SIP CAC failure where the WLAN ID is 1:

```
> config wlan sip-cac send-busy486 enable 1
```

Related Commands

show wlan
config wlan sip-cac disassoc-client

config wlan static-ip tunneling

To configure static IP client tunneling support on a WLAN, use the **config wlan static-ip tunneling** command.

config wlan static-ip tunneling {enable | disable} *wlan_id*

Syntax Description

tunneling	Configures static IP client tunneling support on a WLAN.
enable	Enables static IP client tunneling support on a WLAN.
disable	Disables static IP client tunneling support on a WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None.

Examples

This example shows how to enable static IP client tunneling support for WLAN ID 3:

```
> config wlan static-ip tunneling enable 34
```

Related Commands

config wlan
show wlan

config wlan session-timeout

To change the timeout of wireless LAN clients, use the **config wlan session-timeout** command.

config wlan timeout {*wlan_id* | **foreignAp**} *seconds*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
foreignAp	Specifies third-party access points.
<i>seconds</i>	Timeout or session duration in seconds. A value of zero is equivalent to no timeout.

Command Default

None.

Examples

This example shows how to configure the client timeout to 6000 seconds for WLAN ID 1:

```
> config wlan session-timeout 1 6000
```

Related Commands

show wlan

config wlan user-idle-threshold

To configure the threshold data sent by the client during the idle timeout for client sessions for a WLAN, use the **config wlan user-idle-threshold** command.

config wlan user-idle-threshold *bytes wlan_id*

Syntax Description

<i>bytes</i>	Threshold data sent by the client during the idle timeout for the client session for a WLAN. If the client send traffic less than the defined threshold, the client is removed on timeout. The range is from 0 to 10000000 bytes.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

The default is 0 bytes.

Examples

This example shows how to configure the threshold data sent by the client during the idle timeout for client sessions for a WLAN:

```
> config wlan user-idle-threshold 100 1
```

Related Commands

config network usertimeout
config wlan usertimeout

config wlan usertimeout

To configure the timeout for idle client sessions for a WLAN, use the **config wlan usertimeout** command.

config wlan usertimeout *timeout wlan_id*

Syntax Description

<i>timeout</i>	Timeout for idle client sessions for a WLAN. If the client sends traffic less than the threshold, the client is removed on timeout. The range is from 15 to 100000 seconds.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

300 seconds.

Usage Guidelines

The timeout value that you configure here overrides the global timeout that you define using the command **config network usertimeout**.

Examples

This example shows how to configure the idle client sessions for a WLAN:

```
> config wlan usertimeout 100 1
```

Related Commands

config network usertimeout
config wlan user-idle-threshold

config wlan webauth-exclude

To release the guest user IP address when the web authentication policy time expires and exclude the guest user from acquiring an IP address for three minutes, use the **config wlan webauth-exclude** command.

config wlan webauth-exclude *wlan_id* {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier (1 to 512).
enable	Enables web authentication exclusion.
disable	Disables web authentication exclusion.

Command Default

Disabled.

Usage Guidelines

You can use this command for guest WLANs that are configured with web authentication.

This command is applicable when you configure the internal DHCP scope on the controller.

By default, when the web authentication timer expires for a guest user, the guest user can immediately reassociate with the same IP address before another guest user can acquire the IP address. If there are many guest users or limited IP address in the DHCP pool, some guest users might not be able to acquire an IP address.

When you enable this feature on the guest WLAN, the guest user's IP address is released when the web authentication policy time expires and the guest user is excluded from acquiring an IP address for three minutes. The IP address is available for another guest user to use. After three minutes, the excluded guest user can reassociate and acquire an IP address, if available.

Examples

This example shows how to enable the web authentication exclusion for WLAN ID 5:

```
> config wlan webauth-exclude 5 enable
```

Related Commands

config dhcp
show run-config
show wlan

config wlan wmm

To configure Wi-Fi Multimedia (WMM) mode on a wireless LAN, use the **config wlan wmm** command.

config wlan wmm {**allow** | **disable** | **require**} *wlan_id*

Syntax Description

allow	Allows WMM on the wireless LAN.
disable	Disables WMM on the wireless LAN.
require	Specifies that clients use WMM on the specified wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier (1 to 512).

Command Default

None.

Usage Guidelines

When the controller is in Layer 2 mode and WMM is enabled, you must put the access points on a trunk port in order to allow them to join the controller.

Examples

This example shows how to configure wireless LAN ID 1 to allow WMM:

```
> config wlan wmm allow 1
```

This example shows how to configure wireless LAN ID 1 to specify that clients use WMM:

```
> config wlan wmm require 1
```

Related Commands

show wlan

show run-config

clear Commands

This section lists the **clear** commands to clear existing configurations, log files, and other functions for WLANs.

clear ipv6 neighbor-binding

To clear the IPv6 neighbor binding table entries or counters, use the **clear ipv6 neighbor-binding** command.

clear ipv6 neighbor-binding {**table** {**mac** *mac_address* | **vlan** *vlan_id* | **port** *port* | **ipv6** *ipv6-address* | **all**} | **counters**}

Syntax Description

table	Clears the IPv6 neighbor binding table.
mac	Clears the neighbor binding table entries for a MAC address.
<i>mac_address</i>	MAC address of the client.
vlan	Clears the neighbor binding table entries for a VLAN.
<i>vlan_id</i>	VLAN identifier.
port	Clears the neighbor binding table entries for a port.
<i>port</i>	Port number.
ipv6	Clears the neighbor binding table entries for an IPv6 address.
<i>ipv6_address</i>	IPv6 address of the client.
all	Clears the entire neighbor binding table.
counters	Clears IPv6 neighbor binding counters.

Command Default

None.

Examples

This example shows how to clear the IPv6 neighbor binding table entries for a VLAN:

```
> clear ipv6 neighbor-binding table vlan 1
```

Related Commands

config ipv6
debug ipv6
show ipv6

debug Commands

This section lists the **debug** commands to manage debugging of WLANs managed by the controller.

**Caution**

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug 11w-pmf

To configure the debugging of 802.11w, use the **debug 11w-pmf** command.

debug 11w-pmf {all | events| keys} {enable | disable}

Syntax Description

all	Configures the debugging of all 802.11w messages.
keys	Configures the debugging of 802.11w keys.
events	Configures the debugging of 802.11w events.
enable	Enables the debugging of 802.1w options.
disable	Disables the debugging of 802.1w options.

Command Default

None.

Examples

This example shows how to enable the debugging of 802.11w keys:

```
> debug 11w-pmf keys enable
```

Related Commands

show wlan
show client detail
config wlan security pmf

debug call-control

To configure the debugging of the SIP call control settings, use the **debug call-control** command.

debug call-control {all | event} {enable | disable}

Syntax Description

all	Configures the debugging options for all SIP call control messages.
event	Configures the debugging options for SIP call control events.
enable	Enables the debugging of SIP call control messages or events.
disable	Disables the debugging of SIP call control messages or events.

Command Default

Disabled.

Examples

This example shows how to enable the debugging of all SIP call control messages:

```
> debug call-control all enable
```

debug client

To configure the debugging of a passive client that is associated correctly with the access point, use the **debug client** command.

debug client *mac_address*

Syntax Description

<i>mac_address</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to debug a passive client with MAC address 00:0d:28:f4:c0:45:

```
> debug client 00:0d:28:f4:c0:45
```

Related Commands

debug disable-all
show capwap reap association
show capwap reap status

debug dhcp

To configure the debugging of DHCP, use the **debug dhcp** command.

debug dhcp {message | packet} {enable | disable}

Syntax Description

message	Configures the debugging of DHCP error messages.
packet	Configures the debugging of DHCP packets.
enable	Enables the debugging DHCP messages or packets.
disable	Disables the debugging of DHCP messages or packets.

Command Default

None.

Examples

This example shows how to enable the debugging of DHCP messages:

```
> debug dhcp message enable
```

Related Commands

debug disable-all
config dhcp
config dhcp proxy
config interface dhcp
config wlan dhcp_server
debug dhcp service-port
show dhcp
show dhcp proxy

debug dhcp service-port

To enable or disable debugging of the Dynamic Host Configuration Protocol (DHCP) packets on the service port, use the **debug dhcp service-port** command.

debug dhcp service-port {enable | disable}

Syntax Description

enable	Enables the debugging of DHCP packets on the service port.
disable	Disables the debugging of DHCP packets on the service port.

Command Default

None.

Examples

This example shows how to enable the debugging of DHCP packets on a service port:

```
> debug dhcp service-port enable
```

Related Commands

debug disable-all
config dhcp
config dhcp proxy
config interface dhcp
config wlan dhcp_server
debug dhcp service-port
show dhcp
show dhcp proxy

debug hotspot events

To configure the debugging of HotSpot events, use the **debug hotspot events** command.

debug hotspot events {enable | disable}

Syntax Description

enable	Enables the debugging of HotSpot events.
disable	Disables the debugging of HotSpot events.

Command Default

None.

Examples

This example shows how to enable the debugging of HotSpot events:

```
> debug hotspot events enable
```

Related Commands

show wlan
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random
config wlan hotspot dot11u
config wlan hotspot clear-all
config wlan hotspot msap

debug hotspot packets

To configure the debugging of HotSpot packets, use the **debug hotspot packets** command.

debug hotspot packets {enable | disable}

Syntax Description

enable	Enables the debugging of HotSpot packets.
disable	Disables the debugging of HotSpot packets.

Command Default

None.

Examples

This example shows how to enable the debugging of HotSpot packets:

```
> debug hotspot packets enable
```

Related Commands

show wlan
debug hotspot events
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config ap hotspot venue
config advanced hotspot
config wlan security wpa gtk-random
config wlan hotspot dot11u
config wlan hotspot clear-all
config wlan hotspot msap

debug ipv6

To configure the debugging of IPv6 options, use the **debug ipv6** command.

debug ipv6 {all | bt | classifier | errors | events | filter | fsm | gleaner | hwapi | memory | ndsuppress | parser | policy | ra_throttler | switcher} {enable | disable}

Syntax Description

all	Configures the debugging of all IPv6 information.
bt	Configures the debugging of the IPv6 neighbor binding table.
classifier	Configures the debugging of the IPv6 packet classifiers.
errors	Configures the debugging of the IPv6 errors.
events	Configures the debugging of the IPv6 events.
filter	Configures filters for IPv6 debugs.
fsm	Configures the debugging of the IPv6 finite state machine (FSM).
gleaner	Configures the debugging of the IPv6 gleaner. Learning of entries is called gleaning.
hwapi	Configures the debugging of the IPv6 hardware APIs.
memory	Configures the debugging of the IPv6 binding table memory usage.
ndsuppress	Configures the debugging of the suppressed IPv6 neighbor discoveries.
parser	Configures the debugging of the IPv6 parser.
policy	Configures the debugging of the IPv6 policies.
ra_throttler	Configures the debugging of the IPv6 router advertising (RA) throttler.
switcher	Configures the debugging of the IPv6 switcher.
enable	Enables the debugging of the IPv6 options.
disable	Disables the debugging of the IPv6 options.

Command Default

None.

Examples

The following example shows how to configure the debugging of IPv6 policies.

```
Device > debug ipv6 policy enable
```

Related Commands

Command	Description
config ipv6 acl	
show ipv6 summary	Displays the IPv6 configuration settings.
config ipv6 disable	Disables IPv6 globally on the Cisco WLC.
config ipv6 enable	Enables IPv6 globally on the Cisco WLC.

debug profiling

To configure the debugging of client profiling, use the **debug profiling** command.

debug profiling {enable | disable}

Syntax Description

enable	Enables the debugging of client profiling (HTTP and DHCP profiling).
disable	Disables the debugging of client profiling (HTTP and DHCP profiling).

Command Default

Disabled.

Examples

This example shows how to enable the debugging of client profiling:

```
> debug profiling enable
```

Related Commands

config wlan profiling
show wlan

debug wcp

To configure the debugging of WLAN Control Protocol (WCP), use the **debug wcp** command.

debug wcp {events | packet} {enable | disable}

Syntax Description

events	Configures the debugging of WCP events.
packet	Configures the debugging of WCP packets.
enable	Enables the debugging of WCP settings.
disable	Disables the debugging of WCP settings.

Command Default

None.

Examples

This example shows how to enable the debugging of WCP settings:

```
> debug wcp packet enable
```

Related Commands

debug disable-all

test Commands

This section lists the **test** commands for WLANs.

test pmk-cache delete

To delete an entry in the Pairwise Master Key (PMK) cache from all Cisco wireless LAN controllers in the mobility group, use the **test pmk-cache delete** command.

test pmk-cache delete {all | *mac_address*}

Syntax Description

all	Deletes PMK cache entries from all Cisco wireless LAN controllers.
<i>mac_address</i>	MAC address of the Cisco wireless LAN controller from which PMK cache entries have to be deleted.

Command Default

None.

Examples

This example shows how to delete all entries in the PMK cache:

```
> test pmk-cache delete all
```

Related Commands

show pmk-cache



PART VI

Lightweight Access Point Commands

- [CLI Commands, page 1171](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 1171](#)
- [capwap ap Commands, page 1238](#)
- [config Commands, page 1249](#)
- [clear Commands, page 1375](#)
- [debug Commands, page 1380](#)
- [transfer download peer-start, page 1395](#)
- [transfer upload peer-start, page 1396](#)
- [Resetting the System Reboot Time, page 1396](#)
- [test Commands, page 1401](#)

show Commands

This section lists the **show** commands to display information about your configuration settings for access points.

show advanced backup-controller

To display a list of primary and secondary backup controllers, use the **show advanced backup-controller** command.

show advanced backup-controller

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the backup controller information:

```
> show advanced backup-controller
AP primary Backup Controller ..... controller 10.10.10.10
AP secondary Backup Controller ..... 0.0.0.0
```

Related Commands

- config advanced backup-controller primary**
- config advanced backup-controller secondary**

show advanced max-1x-sessions

To display the maximum number of simultaneous 802.1X sessions allowed per access point, use the **show advanced max-1x-sessions** command.

show advanced max-1x-sessions

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the maximum 802.1X sessions per access point:

```
> show advanced max-1x-sessions
Max 802.1x session per AP at a given time..... 0
```

Related Commands	show advanced statistics

show advanced probe

To display the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show advanced probe** command.

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the probe settings for the WLAN controller:

```
> show advanced probe
Probe request filtering..... Enabled
Probes fwd to controller per client per radio.... 12
Probe request rate-limiting interval..... 100 msec
```

Related Commands	config advanced probe filter config advanced probe limit

show advanced rate

To display whether control path rate limiting is enabled or disabled, use the **show advanced rate** command.

show advanced rate

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the switch control path rate limiting mode:

```
> show advanced rate
Control Path Rate Limiting..... Disabled
```

Related Commands

- config advanced rate**
- config advanced eap**

show advanced timers

To display the mobility anchor, authentication response, and rogue access point entry timers, use the **show advanced timers** command.

show advanced timers

Syntax Description This command has no arguments or keywords.

Command Default The defaults are shown in the “Examples” section.

Examples This example shows how to display the system timers setting:

```
> show advanced timers
Authentication Response Timeout (seconds)..... 10
Rogue Entry Timeout (seconds)..... 1200
AP Heart Beat Timeout (seconds)..... 30
AP Discovery Timeout (seconds)..... 10
AP Local mode Fast Heartbeat (seconds)..... disable
AP flexconnect mode Fast Heartbeat (seconds)..... disable
AP Primary Discovery Timeout (seconds)..... 120
```

Related Commands

- config advanced timers ap-discovery-timeout**
- config advanced timers ap-fast-heartbeat**
- config advanced timers ap-heartbeat-timeout**
- config advanced timers ap-primary-discovery-timeout**
- config advanced timers auth-timeout**
- config advanced timers eap-identity-request-delay**
- config advanced timers eap-timeout**

show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

show ap auto-rf 802.11 {a | b} cisco_ap

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to display auto-RF information for an access point:

```
> show ap auto-rf 802.11a AP1
Number Of Slots..... 2
AP Name..... AP03
MAC Address..... 00:0b:85:01:18:b7
Radio Type..... RADIO_TYPE_80211a
Noise Information
  Noise Profile..... PASSED
  Channel 36..... -88 dBm
  Channel 40..... -86 dBm
  Channel 44..... -87 dBm
  Channel 48..... -85 dBm
  Channel 52..... -84 dBm
  Channel 56..... -83 dBm
  Channel 60..... -84 dBm
  Channel 64..... -85 dBm
Interference Information
  Interference Profile..... PASSED
  Channel 36..... -66 dBm @ 1% busy
  Channel 40..... -128 dBm @ 0% busy
  Channel 44..... -128 dBm @ 0% busy
  Channel 48..... -128 dBm @ 0% busy
  Channel 52..... -128 dBm @ 0% busy
  Channel 56..... -73 dBm @ 1% busy
  Channel 60..... -55 dBm @ 1% busy
  Channel 64..... -69 dBm @ 1% busy
Rogue Histogram (20/40_ABOVE/40_BELOW)
  Channel 36..... 16/ 0/ 0
  Channel 40..... 28/ 0/ 0
  Channel 44..... 9/ 0/ 0
  Channel 48..... 9/ 0/ 0
  Channel 52..... 3/ 0/ 0
  Channel 56..... 4/ 0/ 0
  Channel 60..... 7/ 1/ 0
  Channel 64..... 2/ 0/ 0
Load Information
  Load Profile..... PASSED
  Receive Utilization..... 0%
  Transmit Utilization..... 0%
  Channel Utilization..... 1%
  Attached Clients..... 1 clients
Coverage Information
  Coverage Profile..... PASSED
  Failed Clients..... 0 clients
```

```

Client Signal Strengths
  RSSI -100 dBm..... 0 clients
  RSSI -92 dBm..... 0 clients
  RSSI -84 dBm..... 0 clients
  RSSI -76 dBm..... 0 clients
  RSSI -68 dBm..... 0 clients
  RSSI -60 dBm..... 0 clients
  RSSI -52 dBm..... 0 clients
Client Signal To Noise Ratios
  SNR 0 dBm..... 0 clients
  SNR 5 dBm..... 0 clients
  SNR 10 dBm..... 0 clients
  SNR 15 dBm..... 0 clients
  SNR 20 dBm..... 0 clients
  SNR 25 dBm..... 0 clients
  SNR 30 dBm..... 0 clients
  SNR 35 dBm..... 0 clients
  SNR 40 dBm..... 0 clients
  SNR 45 dBm..... 0 clients
Nearby RADs
  RAD 00:0b:85:01:05:08 slot 0..... -46 dBm on 10.1.30.170
  RAD 00:0b:85:01:12:65 slot 0..... -24 dBm on 10.1.30.170
Channel Assignment Information
  Current Channel Average Energy..... -86 dBm
  Previous Channel Average Energy..... -75 dBm
  Channel Change Count..... 109
  Last Channel Change Time..... Wed Sep 29 12:53e:34 2004
  Recommended Best Channel..... 44
RF Parameter Recommendations
  Power Level..... 1
  RTS/CTS Threshold..... 2347
  Fragmentation Threshold..... 2346
  Antenna Pattern..... 0

```


show ap ccx rm

To display an access point's Cisco Client eXtensions (CCX) radio management status information, use the **show ap ccx rm** command.

show ap ccx rm *ap_name* **status**

Syntax Description

<i>ap_name</i>	Specified access point name.
status	Displays the CCX radio management status information for an access point.

Command Default

None.

Examples

This example shows how to display the status of the CCX radio management:

```
> show ap ccx rm AP1240-21ac status
A Radio
Channel Load Request ..... Disabled
Noise Histogram Request ..... Disabled
Beacon Request ..... Disabled
Frame Request ..... Disabled
Interval ..... 60
Iteration ..... 10
G Radio
Channel Load Request ..... Disabled
Noise Histogram Request ..... Disabled
Beacon Request ..... Disabled
Frame Request ..... Disabled
Interval ..... 60
Iteration ..... 10
```

Related Commands

config ap

show ap cdp

To display the Cisco Discovery Protocol (CDP) information for an access point, use the **show ap cdp** command.

show ap cdp {**all** | **ap-name** *cisco_ap* | **neighbors** {**all** | **ap-name** *cisco_ap* | **detail** *cisco_ap*}}

Syntax Description

all	Displays the CDP status on all access points.
ap-name	Displays the CDP status for a specified access point.
<i>cisco_ap</i>	Specified access point name.
neighbors	Displays neighbors using CDP.
detail	Displays details about a specific access point neighbor using CDP.

Command Default

None.

Examples

This example shows how to display the CDP status of all access points:

```
> show ap cdp all
AP CDP State
AP Name          AP CDP State
-----
SB_RAP1          enable
SB_MAP1          enable
SB_MAP2          enable
SB_MAP3          enable
```

This example shows how to display the CDP status of a specified access point:

```
> show ap cdp ap-name SB_RAP1
AP CDP State
AP Name          AP CDP State
-----
AP CDP State.....Enabled
AP Interface-Based CDP state
  Ethernet 0.....Enabled
  Slot 0.....Enabled
  Slot 1.....Enabled
```

This example shows how to display details about all neighbors using CDP:

```
> show ap cdp neighbor all
AP Name      AP IP      Neighbor Name      Neighbor IP      Neighbor Port
-----
SB_RAP1      192.168.102.154  sjc14-41a-sw1      192.168.102.2    GigabitEthernet1/0/13
SB_RAP1      192.168.102.154  SB_MAP1             192.168.102.137  Virtual-Dot11Radio0
SB_MAP1      192.168.102.137  SB_RAP1             192.168.102.154  Virtual-Dot11Radio0
SB_MAP1      192.168.102.137  SB_MAP2             192.168.102.138  Virtual-Dot11Radio0
SB_MAP2      192.168.102.138  SB_MAP1             192.168.102.137  Virtual-Dot11Radio1
SB_MAP2      192.168.102.138  SB_MAP3             192.168.102.139  Virtual-Dot11Radio0
SB_MAP3      192.168.102.139  SB_MAP2             192.168.102.138  Virtual-Dot11Radio1
```

This example shows how to display details about a specific neighbor with a specified access point using CDP:

```
> show ap cdp neighbors ap-name SB_MAP2
```

AP Name	AP IP	Neighbor Name	Neighbor IP	Neighbor Port
SB_MAP2	192.168.102.138	SB_MAP1	192.168.102.137	Virtual-Dot11Radio1
SB_MAP2	192.168.102.138	SB_MAP3	192.168.102.139	Virtual-Dot11Radio0

This example shows how to display details about neighbors using CDP:

```
> show ap cdp neighbors detail SB_MAP2
AP Name:SB_MAP2
AP IP address:192.168.102.138
-----
Device ID: SB_MAP1
Entry address(es): 192.168.102.137
Platform: cisco AIR-LAP1522AG-A-K9 , Cap
Interface: Virtual-Dot11Radio0, Port ID (outgoing port): Virtual-Dot11Radio1
Holdtime : 180 sec
Version :
Cisco IOS Software, C1520 Software (C1520-K9W8-M), Experimental Version 12.4(200
81114:084420) [BLD-v124_18a_ja_throttle.20081114 208] Copyright (c) 1986-2008 by
Cisco Systems, Inc. Compiled Fri 14-Nov-08 23:08 by
advertisement version: 2
-----
Device ID: SB_MAP3
Entry address(es): 192.168.102.139
Platform: cisco AIR-LAP1522AG-A-K9 , Capabilities: Trans-Bridge
Interface: Virtual-Dot11Radio1, Port ID (outgoing port): Virtual-Dot11Radio0
Holdtime : 180 sec
Version :
Cisco IOS Software, C1520 Software (C1520-K9W8-M), Experimental Version 12.4(200
81114:084420) [BLD-v124_18a_ja_throttle.20081114 208] Copyright (c) 1986-2008 by
Cisco Systems, Inc. Compiled Fri 14-Nov-08 23:08 by
advertisement version: 2
```

Related Commands

```
config ap cdp
config cdp timer
```

show ap channel

To display the available channels for a specific mesh access point, use the **show ap channel** command.

show ap channel *ap_name*

Syntax Description

<i>ap_name</i>	Name of the mesh access point.

Command Default

None.

Examples

This example shows how to display the available channels for a particular access point:

```
> show ap channel AP47
 802.11b/g Current Channel .....1
Allowed Channel List.....1,2,3,4,5,6,7,8,9,10,11
802.11a Current Channel .....161
Allowed Channel List.....36,40,44,48,52,56,60,64,100,
.....104,108,112,116,132,136,140,
.....149,153,157,161
```

Related Commands

- config 802.11-a channel ap
- config 802.11h channelswitch
- config 802.11h setchannel

show ap config

To display the detailed configuration for a lightweight access point, use the **show ap config** command.

show ap config 802.11 {a | b} [summary] cisco_ap

Syntax	Description
802.11a	Specifies the 802.11a or 802.11b/g network.
802.11b	Specifies the 802.11b/g network.
summary	(Optional) Displays radio summary of all APs
<i>cisco_ap</i>	Lightweight access point name.

Command Default None.

Examples This example shows how to display the detailed configuration for an access point:

```
> show ap config 802.11a AP02
Cisco AP Identifier..... 0
Cisco AP Name..... AP02
Country code..... US - United States
Regulatory Domain allowed by Country..... 802.11bg:-A 802.11a:-A
AP Regulatory Domain..... Unconfigured
Switch Port Number ..... 1
MAC Address..... 00:0b:85:18:b6:50
IP Address Configuration..... DHCP
IP Address..... 1.100.49.240
IP NetMask..... 255.255.255.0
Gateway IP Addr..... 1.100.49.1
CAPWAP Path MTU..... 1485
Telnet State..... Disabled
Ssh State..... Disabled
Cisco AP Location..... default-location
Cisco AP Group Name..... default-group
Primary Cisco Switch..... Cisco_32:ab:63
Primary Cisco Switch IP Address..... Not Configured
Secondary Cisco Switch.....
Secondary Cisco Switch IP Address..... Not Configured
Tertiary Cisco Switch.....
Tertiary Cisco Switch IP Address..... Not Configured
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED
Mirroring Mode ..... Disabled
AP Mode ..... Sniffer
Public Safety ..... Global: Disabled, Local: Disabled
AP SubMode ..... Not Configured
Remote AP Debug ..... Disabled
Logging trap severity level ..... informational
Logging syslog facility ..... kern
S/W Version ..... 7.0.110.6
Boot Version ..... 12.4.18.0
Mini IOS Version ..... 3.0.51.0
Stats Reporting Period ..... 180
Stats Re--More-- or (q)uit
LED State..... Enabled
PoE Pre-Standard Switch..... Enabled
```

```

PoE Power Injector MAC Addr..... Disabled
Power Type/Mode..... Power injector / Normal mode
Number Of Slots..... 2
AP Model..... AIR-LAP1142N-A-K9
AP Image..... C1140-K9W8-M
IOS Version..... 12.4(20100502:031212)
Reset Button..... Enabled
AP Serial Number..... FTX1305S180
AP Certificate Type..... Manufacture Installed
AP User Mode..... AUTOMATIC
AP User Name..... Not Configured
AP Dot1x User Mode..... Not Configured
AP Dot1x User Name..... Not Configured
Cisco AP system logging host..... 255.255.255.255
AP Up Time..... 47 days, 23 h 47 m 47 s
AP LWAPP Up Time..... 47 days, 23 h 10 m 37 s
Join Date and Time..... Tue May 4 16:05:00 2010
Join Taken Time..... 0 days, 00 h 01 m 37 s
Attributes for Slot 1
    Radio Type..... RADIO_TYPE_80211n-5
    Radio Subband..... RADIO_SUBBAND_ALL
    Administrative State ..... ADMIN_ENABLED
    Operation State ..... UP
    Radio Role ..... ACCESS
    CellId ..... 0
Station Configuration
    Configuration ..... AUTOMATIC
    Number Of WLANs ..... 2
    Medium Occupancy Limit ..... 100
    CFP Period ..... 4
    CFP MaxDuration ..... 60
    BSSID ..... 00:24:97:88:99:60
Operation Rate Set
    6000 Kilo Bits..... MANDATORY
    9000 Kilo Bits..... SUPPORTED
    12000 Kilo Bits..... MANDATORY
    18000 Kilo Bits..... SUPPORTED
    24000 Kilo Bits..... MANDATORY
    36000 Kilo Bits..... SUPPORTED
    48000 Kilo Bits..... SUPPORTED
    54000 Kilo Bits..... SUPPORTED
MCS Set
    MCS 0..... SUPPORTED
    MCS 1..... SUPPORTED
    MCS 2..... SUPPORTED
    MCS 3..... SUPPORTED
    MCS 4..... SUPPORTED
    MCS 5..... SUPPORTED
    MCS 6..... SUPPORTED
    MCS 7..... SUPPORTED
    MCS 8..... SUPPORTED
    MCS 9..... SUPPORTED
    MCS 10..... SUPPORTED
    MCS 11..... SUPPORTED
    MCS 12..... SUPPORTED
    MCS 13..... SUPPORTED
    MCS 14..... SUPPORTED
    MCS 15..... SUPPORTED
Beacon Period ..... 100
Fragmentation Threshold ..... 2346
Multi Domain Capability Implemented ..... TRUE
Multi Domain Capability Enabled ..... TRUE
Country String ..... US
Multi Domain Capability
    Configuration ..... AUTOMATIC
    First Chan Num ..... 36
    Number Of Channels ..... 21
MAC Operation Parameters
    Configuration ..... AUTOMATIC
    Fragmentation Threshold ..... 2346
    Packet Retry Limit ..... 64
Tx Power
    Num Of Supported Power Levels ..... 6

```

```

Tx Power Level 1 ..... 14 dBm
Tx Power Level 2 ..... 11 dBm
Tx Power Level 3 ..... 8 dBm
Tx Power Level 4 ..... 5 dBm
Tx Power Level 5 ..... 2 dBm
Tx Power Level 6 ..... -1 dBm
Tx Power Configuration ..... AUTOMATIC
Current Tx Power Level ..... 0
Phy OFDM parameters
Configuration ..... AUTOMATIC
Current Channel ..... 36
Extension Channel ..... NONE
Channel Width..... 20 Mhz
Allowed Channel List..... 36,40,44,48,52,56,60,64,100,
..... 104,108,112,116,132,136,140,
..... 149,153,157,161,165
TI Threshold ..... -50
Legacy Tx Beamforming Configuration ..... AUTOMATIC
Legacy Tx Beamforming ..... DISABLED
Antenna Type..... INTERNAL_ANTENNA
Internal Antenna Gain (in .5 dBi units).... 6
Diversity..... DIVERSITY_ENABLED
802.11n Antennas
Tx
A..... ENABLED
B..... ENABLED
Rx
A..... ENABLED
B..... ENABLED
C..... ENABLED
Performance Profile Parameters
Configuration ..... AUTOMATIC
Interference threshold..... 10 %
Noise threshold..... -70 dBm
RF utilization threshold..... 80 %
Data-rate threshold..... 1000000 bps
Client threshold..... 12 clients
Coverage SNR threshold..... 16 dB
Coverage exception level..... 25 %
Client minimum exception level..... 3 clients
Rogue Containment Information
Containment Count..... 0
CleanAir Management Information
CleanAir Capable..... No
Radio Extended Configurations:
Buffer size .....30
Data-rate.....0
Beacon strt .....90 ms
Rx-Sensitivity SOP threshold ..... -80 dB
CCA threshold ..... -60 dB

```

This example shows how to display the detailed configuration for another access point:

```

> show ap config 802.11b AP02
Cisco AP Identifier..... 0
Cisco AP Name..... AP02
AP Regulatory Domain..... Unconfigured
Switch Port Number ..... 1
MAC Address..... 00:0b:85:18:b6:50
IP Address Configuration..... DHCP
IP Address..... 1.100.49.240
IP NetMask..... 255.255.255.0
Gateway IP Addr..... 1.100.49.1
Cisco AP Location..... default-location
Cisco AP Group Name..... default-group
Primary Cisco Switch..... Cisco_32:ab:63
Secondary Cisco Switch.....
Tertiary Cisco Switch.....
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED
Mirroring Mode ..... Disabled

```

```

AP Mode ..... Local
Remote AP Debug ..... Disabled
S/W Version ..... 3.1.61.0
Boot Version ..... 1.2.59.6
Stats Reporting Period ..... 180
LED State..... Enabled
ILP Pre Standard Switch..... Disabled
ILP Power Injector..... Disabled
Number Of Slots..... 2
AP Model..... AS-1200
AP Serial Number..... 044110223A
AP Certificate Type..... Manufacture Installed
Attributes for Slot 1
  Radio Type..... RADIO_TYPE_80211g
  Administrative State ..... ADMIN_ENABLED
  Operation State ..... UP
  CellId ..... 0
  Station Configuration
    Configuration ..... AUTOMATIC
    Number Of WLANs ..... 1
    Medium Occupancy Limit ..... 100
    CFP Period ..... 4
    CFP MaxDuration ..... 60
    BSSID ..... 00:0b:85:18:b6:50
    Operation Rate Set
      1000 Kilo Bits..... MANDATORY
      2000 Kilo Bits..... MANDATORY
      5500 Kilo Bits..... MANDATORY
      11000 Kilo Bits..... MANDATORY
      6000 Kilo Bits..... SUPPORTED
      9000 Kilo Bits..... SUPPORTED
      12000 Kilo Bits..... SUPPORTED
      18000 Kilo Bits..... SUPPORTED
      24000 Kilo Bits..... SUPPORTED
      36000 Kilo Bits..... SUPPORTED
      48000 Kilo Bits..... SUPPORTED
      54000 Kilo Bits..... SUPPORTED
    Beacon Period ..... 100
    DTIM Period ..... 1
    Fragmentation Threshold ..... 2346
    Multi Domain Capability Implemented ..... TRUE
    Multi Domain Capability Enabled ..... TRUE
    Country String ..... US
  Multi Domain Capability
    Configuration ..... AUTOMATIC
    First Chan Num ..... 1
    Number Of Channels ..... 11
  MAC Operation Parameters
    Configuration ..... AUTOMATIC
    RTS Threshold ..... 2347
    Short Retry Limit ..... 7
    Long Retry Limit ..... 4
    Fragmentation Threshold ..... 2346
    Maximum Tx MSDU Life Time ..... 512
    Maximum Rx Life Time..... 512
  Tx Power
    Num Of Supported Power Levels..... 5
    Tx Power Level 1 ..... 17 dBm
    Tx Power Level 2..... 14 dBm
    Tx Power Level 3..... 11 dBm
    Tx Power Level 4..... 8 dBm
    Tx Power Level 5..... 5 dBm
    Tx Power Configuration..... CUSTOMIZED
    Current Tx Power Level..... 5
  Phy OFDM parameters
    Configuration..... CUSTOMIZED
    Current Channel..... 1
    TI Threshold..... -50
    Legacy Tx Beamforming Configuration ..... CUSTOMIZED
    Legacy Tx Beamforming ..... ENABLED
    Antenna Type..... INTERNAL_ANTENNA
    Internal Antenna Gain (in5 dBm units)..... 11
    Diversity..... DIVERSITY_ENABLED

```



```

Performance Profile Parameters
Configuration..... AUTOMATIC
Interference threshold..... 10%
Noise threshold..... -70 dBm
RF utilization threshold..... 80%
Data-rate threshold..... 1000000 bps
Client threshold..... 12 clients
Coverage SNR threshold..... 12 dB
Coverage exception level..... 25%
Client minimum exception level..... 3 clients
Rogue Containment Information
Containment Count..... 0

```

This example shows how to display the general configuration of a Cisco access point:

```

> show ap config general cisco-ap
Cisco AP Identifier..... 9
Cisco AP Name..... cisco-ap
Country code..... US - United States
Regulatory Domain allowed by Country..... 802.11bg:-A 802.11a:-A
AP Country code..... US - United States
AP Regulatory Domain..... 802.11bg:-A 802.11a:-A
Switch Port Number ..... 1
MAC Address..... 12:12:12:12:12:12
IP Address Configuration..... DHCP
IP Address..... 10.10.10.21
IP NetMask..... 255.255.255.0
CAPWAP Path MTU..... 1485
Domain.....
Name Server.....
Telnet State..... Disabled
Ssh State..... Disabled
Cisco AP Location..... default location
Cisco AP Group Name..... default-group
Primary Cisco Switch Name..... 4404
Primary Cisco Switch IP Address..... 10.10.10.32
Secondary Cisco Switch Name.....
Secondary Cisco Switch IP Address..... Not Configured
Tertiary Cisco Switch Name..... 4404
Tertiary Cisco Switch IP Address..... 3.3.3.3
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED
Mirroring Mode ..... Disabled
AP Mode ..... Local
Public Safety ..... Global: Disabled, Local: Disabled
AP subMode ..... WIPS
Remote AP Debug ..... Disabled
S/W Version ..... 5.1.0.0
Boot Version ..... 12.4.10.0
Mini IOS Version ..... 0.0.0.0
Stats Reporting Period ..... 180
LED State..... Enabled
PoE Pre-Standard Switch..... Enabled
PoE Power Injector MAC Addr..... Disabled
Power Type/Mode..... PoE/Low Power (degraded mode)
Number Of Slots..... 2
AP Model..... AIR-LAP1252AG-A-K9
IOS Version..... 12.4(10:0)
Reset Button..... Enabled
AP Serial Number..... serial_number
AP Certificate Type..... Manufacture Installed
Management Frame Protection Validation..... Enabled (Global MFP Disabled)
AP User Mode..... CUSTOMIZED
AP username..... maria
AP Dot1x User Mode..... Not Configured
AP Dot1x username..... Not Configured
Cisco AP system logging host..... 255.255.255.255
AP Up Time..... 4 days, 06 h 17 m 22 s
AP LWAPP Up Time..... 4 days, 06 h 15 m 00 s
Join Date and Time..... Mon Mar 3 06:19:47 2008
Ethernet Port Duplex..... Auto
Ethernet Port Speed..... Auto

```

```
AP Link Latency..... Enabled
  Current Delay..... 0 ms
  Maximum Delay..... 240 ms
  Minimum Delay..... 0 ms
  Last updated (based on AP Up Time)..... 4 days, 06 h 17 m 20 s
Rogue Detection..... Enabled
AP TCP MSS Adjust..... Disabled
Mesh preferred parent..... 00:24:13:0f:92:00
```

Related Commands**config ap****config ap config global**

show ap config global

To display the global syslog server settings for all access points that join the controller, use the **show ap config global** command.

show ap config global

Syntax Description

This command has no arguments and keywords.

Examples

This example shows how to display global syslog server settings:

```
> show ap config global
AP global system logging host..... 255.255.255.255
```

Related Commands

config ap

show ap config

show ap core-dump

To display the memory core dump information for a lightweight access point, use the **show ap core-dump** command.

show ap core-dump *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to display memory core dump information:

```
> show ap core-dump AP02
Memory core dump is disabled.
```

Related Commands

config ap core-dump
show ap crash-file

show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

show ap crash-file

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the crash file generated by the access point:

```
> show ap crash-file
```

Related Commands	config ap crash-file clear-all config ap crash-file delete config ap crash-file get-crash-file config ap crash-file get-radio-core-dump

show ap data-plane

To display the data plane status for all access points or a specific access point, use the **show ap data-plane** command.

show ap data-plane {all | *cisco_ap*}

Syntax Description

all	Specifies all Cisco lightweight access points.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to display the data plane status of all access points:

```
> show ap data-plane all
Min Data      Data      Max Data      Last
AP Name      Round Trip  Round Trip    Round Trip    Update
-----
1130          0.000s      0.000s        0.002s        18:51:23
1240          0.000s      0.000s        0.000s        18:50:45
```

show ap ethernet tag

To display the VLAN tagging information of an Ethernet interface, use the **show ap ethernet tag** command.

show ap ethernet tag {**summary** | *cisco_ap*}

Syntax Description

summary	Displays the VLAN tagging information for all access points associated to the controller.
<i>cisco_ap</i>	Name of the Cisco lightweight access point. Displays the VLAN tagging information for a specific access point associated to the controller.

Command Default

None.

Usage Guidelines

If the access point is unable to route traffic or reach the controller using the specified trunk VLAN, it falls back to the untagged configuration. If the access point joins the controller using this fallback configuration, the controller sends a trap to a trap server such as the WCS, which indicates the failure of the trunk VLAN. In this scenario, the "Failover to untagged" message appears in show command output.

Examples

This example shows how to display the VLAN tagging information for all access points associated to the controller:

```
> show ap ethernet tag summary
```

```
AP Name                Vlan Tag Configuration
-----
AP2                    7          (Failover to untagged)
charan.AP1140.II      disabled
```

Related Commands

config ap ethernet
config ap ethernet duplex
config ap ethernet tag
show ap config general

show ap eventlog

To display the contents of the event log file for an access point that is joined to the controller, use the **show ap eventlog** command.

show ap eventlog *ap_name*

Syntax Description

<i>ap_name</i>	Event log for the specified access point.

Command Default

None.

Examples

This example shows how to display the event log of an access point:

```
> show ap eventlog ciscoAP
AP event log download has been initiated
Waiting for download to complete
AP event log download completed.
===== AP Event log Contents =====
*Feb 13 11:54:17.146: %CAPWAP-3-CLIENTEVENTLOG: AP event log has been cleared from the
contoller 'admin'
*Feb 13 11:54:32.874: *** Access point reloading. Reason: Reload Command ***
*Mar 1 00:00:39.134: %CDP_PD-4-POWER_OK: Full power - NEGOTIATED inline power source
*Mar 1 00:00:39.174: %LINK-3-UPDOWN: Interface Dot11Radio1, changed state to up
*Mar 1 00:00:39.211: %LINK-3-UPDOWN: Interface Dot11Radio0, changed state to up
*Mar 1 00:00:49.947: %CAPWAP-3-CLIENTEVENTLOG: Did not get vendor specific options from
DHCP.
...
```


show ap image

To display the detailed information about the predownloaded image for specified access points, use the **show ap image** command.

show ap image {*cisco_ap* | **all**}

Syntax Description

<i>cisco_ap</i>	Name of the lightweight access point.
all	Specifies all access points.



Note

If you have an AP that has the name *all*, it conflicts with the keyword **all** that specifies all access points. In this scenario, the keyword **all** takes precedence over the AP that is named *all*.

Examples

This example shows how to display images present on all access points:

```
> show ap image all
Total number of APs..... 7
Number of APs
Initiated..... 4
Predownloading..... 0
Completed predownloading..... 3
Not Supported..... 0
Failed to Predownload..... 0
AP Name   Primary Image  Backup Image  Status      Version Next  Retry Time
Retry Count
-----
AP1140-1  7.0.56.0          6.0.183.38   Complete    6.0.183.38   NA           NA
AP1140-2  7.0.56.0          6.0.183.58   Initiated    6.0.183.38   23:46:43
1
AP1130-2  7.0.56.0          6.0.183.38   Complete    6.0.183.38   NA
NA
AP1130-3  7.0.56.0          6.0.183.58   Initiated    6.0.183.38   23:43:25     1
AP1130-4  7.0.56.0          6.0.183.38   Complete    6.0.183.38   NA
NA
AP1130-5  7.0.56.0          6.0.183.58   Initiated    6.0.183.38   23:43:00     1
AP1130-6  7.0.56.0          6.0.183.58   Initiated    6.0.183.38   23:41:33
```

Related Commands

config ap image predownload

config ap image swap

show ap inventory

To display inventory information for an access point, use the **show ap inventory** command.

show ap inventory *ap_name*

Syntax Description

<i>ap_name</i>	Inventory for the specified access point.

Command Default

None.

Examples

This example shows how to display the inventory of an access point:

```
> show ap inventory test101
NAME: "test101"      , DESCR: "Cisco Wireless Access Point"
PID: AIR-LAP1131AG-A-K9  ,  VID: V01,  SN: FTX1123T2XX
```

show ap join stats detailed

To display all join-related statistics collected for a specific access point, use the **show ap join stats detailed** command.

show ap join stats detailed *ap_mac*

Syntax Description	
<i>ap_mac</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.

Command Default None.

Examples This example shows how to display join information for a specific access point trying to join the controller:

```
> show ap join stats detailed 00:0b:85:02:0d:20
Discovery phase statistics
- Discovery requests received..... 2
- Successful discovery responses sent..... 2
- Unsuccessful discovery request processing..... 0
- Reason for last unsuccessful discovery attempt..... Not applicable
- Time at last successful discovery attempt..... Aug 21 12:50:23:335
- Time at last unsuccessful discovery attempt..... Not applicable
Join phase statistics
- Join requests received..... 1
- Successful join responses sent..... 1
- Unsuccessful join request processing..... 1
- Reason for last unsuccessful join attempt.....RADIUS authorization is pending for
the AP
- Time at last successful join attempt..... Aug 21 12:50:34:481
- Time at last unsuccessful join attempt..... Aug 21 12:50:34:374
Configuration phase statistics
- Configuration requests received..... 1
- Successful configuration responses sent..... 1
- Unsuccessful configuration request processing..... 0
- Reason for last unsuccessful configuration attempt... Not applicable
- Time at last successful configuration attempt..... Aug 21 12:50:34:374
- Time at last unsuccessful configuration attempt..... Not applicable
Last AP message decryption failure details
- Reason for last message decryption failure..... Not applicable
Last AP disconnect details
- Reason for last AP connection failure..... Not applicable
Last join error summary
- Type of error that occurred last..... Lwapp join request rejected
- Reason for error that occurred last..... RADIUS authorization is pending for
the AP
- Time at which the last join error occurred..... Aug 21 12:50:34:374
```

Related Commands

- show ap join stats detailed**
- show ap join stats summary**
- show ap join stats summary all**

show ap join stats summary

To display the last join error detail for a specific access point, use the **show ap join stats summary** command.

show ap join stats summary *ap_mac*

Syntax Description

<i>ap_mac</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.

Command Default

None.

Usage Guidelines

To obtain the MAC address of the 802.11 radio interface, enter the **show interface** command on the access point.

Examples

This example shows how to display specific join information for an access point:

```
> show ap join stats summary 00:0b:85:02:0d:20
Is the AP currently connected to controller..... No
Time at which the AP joined this controller last time..... Aug 21 12:50:36:061
Type of error that occurred last..... Lwapp join request
rejected
Reason for error that occurred last..... RADIUS authorization
is pending for the AP
Time at which the last join error occurred..... Aug 21 12:50:34:374
```

Related Commands

show ap join stats detailed

show ap join stats summary all

show ap join stats summary all

To display the MAC addresses of all the access points that are joined to the controller or that have tried to join, use the **show ap join stats summary all** command.

show ap join stats summary all

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary of join information for all access points:

```
> show ap join stats summary all
Number of APs..... 4
Base Mac          AP EthernetMac      AP Name      IP Address      Status
00:0b:85:57:bc:c0  00:0b:85:57:bc:c0    AP1130       10.10.163.217   Joined
00:1c:0f:81:db:80  00:1c:63:23:ac:a0    AP1140       10.10.163.216   Not joined
00:1c:0f:81:fc:20  00:1b:d5:9f:7d:b2    AP1          10.10.163.215   Joined
00:21:1b:ea:36:60  00:0c:d4:8a:6b:c1    AP2          10.10.163.214   Not joined
```

Related Commands

- show ap join stats detailed**
- show ap join stats summary**

show ap led-state

To view the LED state of all access points or a specific access point, use the **show ap led-state** command.

show ap led-state {**all** | *cisco_ap*}

Syntax Description

all	Shows the LED state for all access points.
<i>cisco_ap</i>	Name of the access point whose LED state is to be shown.

Command Default

Enabled.

Examples

This example shows how to get the LED state of all access points:

```
> show ap led-state all
Global LED State: Enabled (default)
```

Related Commands

config ap led-state

show ap led-flash

To display the LED flash status of an access point, use the **show ap led-flash** command.

show ap led-flash *cisco_ap*

Syntax Description	
	<i>cisco_ap</i>
Command Default	None.
Examples	This example shows how to display the LED flash status of an access point: <pre>> show ap led-flash</pre>
Related Commands	config ap led-state flash config ap led-state

show ap link-encryption

To display the MAC addresses of all the access points that are joined to the controller or that have tried to join, use the **show ap link-encryption** command.

show ap link-encryption {all | *cisco_ap*}

Syntax Description

all	Specifies all access points.
<i>cisco_ap</i>	Name of the lightweight access point.

Command Default

None.

Examples

This example shows how to display the link encryption status of all access points:

```
> show ap link-encryption all
      Encryption  Dnstream  Upstream  Last
AP Name      State      Count      Count      Update
-----
1240          Dis        4406      237553     Never
1130          En         2484      276308     19:31
```

Related Commands

config ap link-encryption
config ap link-latency

show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

show ap monitor-mode summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display current channel-optimized monitor mode settings:

```
> show ap monitor-mode summary
AP Name           Ethernet MAC      Status      Scanning Channel List
-----
AP_004            xx:xx:xx:xx:xx:xx Tracking        1, 6, 11, 4
```

Related Commands

- config ap mode**
- config ap monitor-mode**

show ap packet-dump status

To display access point Packet Capture configurations, use the **show ap packet-dump status** command.

show ap packet-dump status

Syntax Description This command has no arguments or keywords.

Usage Guidelines Packet Capture does not work during intercontroller roaming.
The controller does not capture packets created in the radio firmware and sent out of the access point, such as the beacon or probe response. Only packets that flow through the Radio driver in the Tx path are captured.

Examples This example shows how to display the access point Packet Capture configurations:

```
> show ap packet-dump status
Packet Capture Status..... Stopped
FTP Server IP Address..... 0.0.0.0
FTP Server Path.....
FTP Server Username.....
FTP Server Password..... *****
Buffer Size for Capture..... 2048 KB
Packet Capture Time..... 45 Minutes
Packet Truncate Length..... Unspecified
Packet Capture Classifier..... None
```

Related Commands

- config ap packet-dump**
- debug ap packet-dump**

show ap retransmit

To display access point control packet retransmission parameters, use the **show ap retransmit** command.

show ap retransmit {all | *cisco_ap*}

Syntax Description

all	Specifies all access points.
<i>cisco_ap</i>	Name of the access point.

Command Default

None.

Examples

This example shows how to display the control packet retransmission parameters of all access points on a network:

```
> show ap retransmit all
Global control packet retransmit interval: 3 (default)
Global control packet retransmit count: 5 (default)
AP Name                Retransmit Interval  Retransmit count
-----
AP_004                  3 (default)         5 (WLC default),5 (AP default)
```

Related Commands

config ap retransmit interval

show ap stats

To display the statistics for a Cisco lightweight access point, use the **show ap stats** command.

show ap stats {**802.11** {**a** | **b**} | **wlan** | **ethernet summary**} *cisco_ap* [**tsm** {*client_mac* | **all**}]

Syntax Description

802.11a	Specifies the 802.11a network
802.11b	Specifies the 802.11b/g network.
wlan	Specifies WLAN statistics.
ethernet	Specifies AP ethernet interface statistics.
summary	Displays ethernet interface summary of all the connected Cisco access points.
<i>cisco_ap</i>	Name of the lightweight access point.
tsm	(Optional) Specifies the traffic stream metrics.
<i>client_mac</i>	(Optional) MAC address of the client.
all	(Optional) Specifies all access points.

Command Default

None.

Examples

This example shows how to display statistics of an access point for the 802.11b network:

```
> show ap stats 802.11a Ibiza
Number Of Slots..... 2
AP Name..... Ibiza
MAC Address..... 44:2b:03:9a:8a:73
Radio Type..... RADIO_TYPE_80211a
Stats Information
  Number of Users..... 0
  TxFragmentCount..... 84628
  MulticastTxFrameCnt..... 84628
  FailedCount..... 0
  RetryCount..... 0
  MultipleRetryCount..... 0
  FrameDuplicateCount..... 0
  RtsSuccessCount..... 1
  RtsFailureCount..... 0
  AckFailureCount..... 0
  RxIncompleteFragment..... 0
  MulticastRxFrameCnt..... 0
  FcsErrorCount..... 20348857
  TxFrameCount..... 84628
  WepUndecryptableCount..... 19907
  TxFramesDropped..... 0
Rate Limiting Stats:
```

```

Wlan 1:
  Number of Data Packets Received..... 592
  Number of Data Rx Packets Dropped..... 160
  Number of Data Bytes Received..... 160783
  Number of Data Rx Bytes Dropped..... 0
  Number of Realtime Packets Received..... 592
  Number of Realtime Rx Packets Dropped..... 0
  Number of Realtime Bytes Received..... 160783
  Number of Realtime Rx Bytes Dropped..... 0
  Number of Data Packets Sent..... 131
  Number of Data Tx Packets Dropped..... 0
  Number of Data Bytes Sent..... 23436
  Number of Data Tx Bytes Dropped..... 0
  Number of Realtime Packets Sent..... 131
  Number of Realtime Tx Packets Dropped..... 0
  Number of Realtime Bytes Sent..... 23436
  Number of Realtime Tx Bytes Dropped..... 0
Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw)..... 0
  Voice Roam Bandwidth in use(% of config bw).... 0
    Total channel MT free..... 0
    Total voice MT free..... 0
    Na Direct..... 0
    Na Roam..... 0
  Video Bandwidth in use(% of config bw)..... 0
  Video Roam Bandwidth in use(% of config bw).... 0
  Total BW in use for Voice(%)..... 0
  Total BW in use for SIP Preferred call(%)..... 0
WMM TSPEC CAC Call Stats
  Total num of voice calls in progress..... 0
  Num of roaming voice calls in progress..... 0
  Total Num of voice calls since AP joined..... 0
  Total Num of roaming calls since AP joined..... 0
  Total Num of exp bw requests received..... 0
  Total Num of exp bw requests admitted..... 0
  Num of voice calls rejected since AP joined.... 0
  Num of roam calls rejected since AP joined..... 0
  Num of calls rejected due to insufficient bw.... 0
  Num of calls rejected due to invalid params.... 0
  Num of calls rejected due to PHY rate..... 0
  Num of calls rejected due to QoS policy..... 0
SIP CAC Call Stats
  Total Num of calls in progress..... 0
  Num of roaming calls in progress..... 0
  Total Num of calls since AP joined..... 0
  Total Num of roaming calls since AP joined..... 0
  Total Num of Preferred calls received..... 0
  Total Num of Preferred calls accepted..... 0
  Total Num of ongoing Preferred calls..... 0
  Total Num of calls rejected(Insuff BW)..... 0
  Total Num of roam calls rejected(Insuff BW).... 0
WMM Video TSPEC CAC Call Stats
  Total num of video calls in progress..... 0
  Num of roaming video calls in progress..... 0
  Total Num of video calls since AP joined..... 0
  Total Num of video roaming calls since AP j.... 0
  Num of video calls rejected since AP joined.... 0
  Num of video roam calls rejected since AP j.... 0
  Num of video calls rejected due to insuffic.... 0
  Num of video calls rejected due to invalid .... 0
  Num of video calls rejected due to PHY rate.... 0
  Num of video calls rejected due to QoS poli.... 0
SIP Video CAC Call Stats
  Total Num of video calls in progress..... 0
  Num of video roaming calls in progress..... 0
  Total Num of video calls since AP joined..... 0
  Total Num of video roaming calls since AP j.... 0
  Total Num of video calls rejected(Insuff BW).... 0
  Total Num of video roam calls rejected(Insu.... 0
Band Select Stats
  Num of dual band client ..... 0
  Num of dual band client added..... 0
  Num of dual band client expired ..... 0

```

```
Num of dual band client replaced..... 0
Num of dual band client detected ..... 0
Num of suppressed client ..... 0
Num of suppressed client expired..... 0
Num of suppressed client replaced..... 0
```

Related Commands**config ap static-ip****config ap static-timer**

show ap summary

To display a summary of all lightweight access points attached to the controller, use the **show ap summary** command.

show ap summary [*cisco_ap*]

Syntax Description	<i>cisco_ap</i> (Optional) Type sequence of characters that make up the name of a specific AP or a group of APs, or enter a wild character search pattern.	
Command Default	None.	
Usage Guidelines	A list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the controller port number appears. When you specify	
Examples	This example shows how to display a summary of all connected access points: <pre>> show ap summary Number of APs..... 2 Global AP username..... user Global AP Dot1x username..... Not Configured Number of APs..... 2 Global AP username..... user Global AP Dot1x username..... Not Configured AP Name Slots AP Model Ethernet MAC Location Port Country Priority ----- wolverine 2 AIR-LAP1252AG-A-K9 00:1b:d5:13:39:74 Reception 1 US 3 ap:1120 1 AIR-LAP1121G-A-K9 00:1b:d5:a9:ad:08 Hall 235 1 US 1</pre>	
Related Commands	config ap	

show ap tcp-mss-adjust

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point, use the **show ap tcp-mss-adjust** command.

show ap tcp-mss-adjust {*cisco_ap* | **all**}

Syntax Description

<i>cisco_ap</i>	Specified lightweight access point name.
all	Specifies all access points.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Examples

This example shows how to display Transmission Control Protocol (TCP) maximum segment size (MSS) information of all access points:

```
> show ap tcp-mss-adjust all
AP Name          TCP State MSS Size
-----
AP-1140          enabled   536
AP-1240          disabled  -
AP-1130          disabled  -
```

Related Commands

config ap tcp-adjust-mss

show ap wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point, use the **show ap wlan** command.

show ap wlan 802.11 {a | b} *cisco_ap*

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b/g network.
<i>ap_name</i>	Lightweight access point name.

Command Default

None.

Examples

This example shows how to display BSSIDs of an access point for the 802.11b network:

```
> show ap wlan 802.11b AP01
Site Name..... MY_AP_GROUP1
Site Description..... MY_AP_GROUP1
WLAN ID      Interface      BSSID
-----
1            management    00:1c:0f:81:fc:20
2            dynamic      00:1c:0f:81:fc:21
```

Related Commands

config ap wlan

show auth-list

To display the access point authorization list, use the **show auth-list** command.

show auth-list

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the access point authorization list:

```
> show auth-list
Authorize APs against AAA..... disabled
Allow APs with Self-signed Certificate (SSC)... disabled
Mac Addr                Cert Type    Key Hash
-----
xx:xx:xx:xx:xx:xx      MIC
```

Related Commands

clear tacacs auth statistics

clear stats local-auth

config auth-list add

config auth-list ap-policy

config auth-list delete

show client ap

To display the clients on a Cisco lightweight access point, use the **show client ap** command.

show client ap 802.11 {a | b} cisco_ap

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Usage Guidelines

The **show client ap** command may list the status of automatically disabled clients. Use the **show exclusionlist** command to view clients on the exclusion list (blacklisted).

Examples

This example shows how to display client information on an access point:

```
> show client ap 802.11b AP1
MAC Address      AP Id  Status      WLAN Id  Authenticated
-----
xx:xx:xx:xx:xx:xx    1  Associated    1         No
```

Related Commands

show client detail
show client summary
show client username
show country
show exclusionlist

show boot

To display the primary and backup software build numbers with an indication of which is active, use the **show boot** command.

show boot

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines Each Cisco wireless LAN controller retains one primary and one backup operating system software load in nonvolatile RAM to allow controllers to boot off the primary load (default) or revert to the backup load when desired.

Examples This example shows how to display the default boot image information:

```
> show boot
Primary Boot Image..... 3.2.13.0 (active)
Backup Boot Image..... 3.2.15.0
```

Related Commands **config boot**

show call-control ap



Note

The **show call-control ap** command is applicable only for SIP based calls.

To see the metrics for successful calls or the traps generated for failed calls, use the **show call-control ap** command.

show call-control ap {802.11a | 802.11b} cisco_ap {metrics | traps}

Syntax Description

802.11a	Specifies the 802.11a network
802.11b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco access point name.
metrics	Specifies the call metrics information.
traps	Specifies the trap information for call control.

Command Default

None.

Examples

This example shows how to display the metrics for successful calls generated for an access point:

```
> show call-control ap 802.11a Cisco_AP metrics
Total Call Duration in Seconds..... 120
Number of Calls..... 10
Number of calls for given client is..... 1
```

This example shows how to display the metrics for the traps generated for an access point:

```
> show call-control ap 802.11a Cisco_AP traps
Number of traps sent in one min..... 2
Last SIP error code..... 404
Last sent trap timestamp..... Jun 20 10:05:06
```

Usage Guidelines

To aid in troubleshooting, the output of this command shows an error code for any failed calls. This table explains the possible error codes for failed calls.

Table 7: Error Codes for Failed VoIP Calls

Error Code	Integer	Description
1	unknown	Unknown error.
400	badRequest	The request could not be understood because of malformed syntax.

Error Code	Integer	Description
401	unauthorized	The request requires user authentication.
402	paymentRequired	Reserved for future use.
403	forbidden	The server understood the request but refuses to fulfill it.
404	notFound	The server has information that the user does not exist at the domain specified in the Request-URI.
405	methodNotAllowed	The method specified in the Request-Line is understood but not allowed for the address identified by the Request-URI.
406	notAcceptable	The resource identified by the request is only capable of generating response entities with content characteristics that are not acceptable according to the Accept header field sent in the request.
407	proxyAuthenticationRequired	The client must first authenticate with the proxy.
408	requestTimeout	The server could not produce a response within a suitable amount of time.
409	conflict	The request could not be completed due to a conflict with the current state of the resource.
410	gone	The requested resource is no longer available at the server, and no forwarding address is known.
411	lengthRequired	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
413	requestEntityTooLarge	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
414	requestURITooLarge	The server is refusing to service the request because the Request-URI is longer than the server is willing to interpret.
415	unsupportedMediaType	The server is refusing to service the request because the message body of the request is in a format not supported by the server for the requested method.
420	badExtension	The server did not understand the protocol extension specified in a Proxy-Require or Require header field.
480	temporarilyNotAvailable	The callee's end system was contacted successfully, but the callee is currently unavailable.

Error Code	Integer	Description
481	callLegDoesNotExist	The UAS received a request that does not match any existing dialog or transaction.
482	loopDetected	The server has detected a loop.
483	tooManyHops	The server received a request that contains a Max-Forwards header field with the value zero.
484	addressIncomplete	The server received a request with a Request-URI that was incomplete.
485	ambiguous	The Request-URI was ambiguous.
486	busy	The callee's end system was contacted successfully, but the callee is currently not willing or able to take additional calls at this end system.
500	internalServerError	The server encountered an unexpected condition that prevented it from fulfilling the request.
501	notImplemented	The server does not support the functionality required to fulfill the request.
502	badGateway	The server, while acting as a gateway or proxy, received an invalid response from the downstream server it accessed in attempting to fulfill the request.
503	serviceUnavailable	The server is temporarily unable to process the request because of a temporary overloading or maintenance of the server.
504	serverTimeout	The server did not receive a timely response from an external server it accessed in attempting to process the request.
505	versionNotSupported	The server does not support or refuses to support the SIP protocol version that was used in the request.
600	busyEverywhere	The callee's end system was contacted successfully, but the callee is busy or does not want to take the call at this time.
603	decline	The callee's machine was contacted successfully, but the user does not want to or cannot participate.
604	doesNotExistAnywhere	The server has information that the user indicated in the Request-URI does not exist anywhere.
606	notAcceptable	The user's agent was contacted successfully, but some aspects of the session description (such as the requested media, bandwidth, or addressing style) were not acceptable.

show country

To display the configured country and the radio types supported, use the **show country** command.

show country

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the configured countries and supported radio types:

```
> show country
Configured Country..... United States
Configured Country Codes
US - United States..... 802.11a / 802.11b / 802.11g
```

Related Commands

- config country**
- show country channels**
- show country supported**

show country channels

To display the radio channels supported in the configured country, use the **show country channels** command.

show country channels

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the auto-RF channels for the configured countries:

```
> show country channels
Configured Country..... United States
KEY: * = Channel is legal in this country and may be configured manually.
Configured Country..... United States
KEY: * = Channel is legal in this country and may be configured manually.
      A = Channel is the Auto-RF default in this country.
      . = Channel is not legal in this country.
      C = Channel has been configured for use by Auto-RF.
      x = Channel is available to be configured for use by Auto-RF.
-----:+++++-----
802.11BG :
Channels :          1 1 1 1 1
          : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----:+++++-----
      US : A * * * * A * * * * A . . .
-----:+++++-----
802.11A : 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Channels : 3 3 3 4 4 4 4 4 5 5 6 6 0 0 1 1 2 2 2 3 3 4 4 5 5 6 6
          : 4 6 8 0 2 4 6 8 2 6 0 4 0 4 8 2 6 0 4 8 2 6 0 9 3 7 1 5
-----:+++++-----
      US : . A . A . A . A A A A A * * * * * . . . * * * A A A A *
```

Related Commands

- config country**
- show country**
- show country supported**

show country supported

To display a list of the supported country options, use the **show country supported** command.

show country supported

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a list of all the supported countries:

```
> show country supported
Configured Country..... United States
Supported Country Codes
AR - Argentina..... 802.11a / 802.11b / 802.11g
AT - Austria..... 802.11a / 802.11b / 802.11g
AU - Australia..... 802.11a / 802.11b / 802.11g
BR - Brazil..... 802.11a / 802.11b / 802.11g
BE - Belgium..... 802.11a / 802.11b / 802.11g
BG - Bulgaria..... 802.11a / 802.11b / 802.11g
CA - Canada..... 802.11a / 802.11b / 802.11g
CH - Switzerland..... 802.11a / 802.11b / 802.11g
CL - Chile..... 802.11b / 802.11g
CN - China..... 802.11a / 802.11b / 802.11g
CO - Colombia..... 802.11b / 802.11g
CY - Cyprus..... 802.11a / 802.11b / 802.11g
CZ - Czech Republic..... 802.11a / 802.11b
DE - Germany..... 802.11a / 802.11b / 802.11g
DK - Denmark..... 802.11a / 802.11b / 802.11g
EE - Estonia..... 802.11a / 802.11b / 802.11g
ES - Spain..... 802.11a / 802.11b / 802.11g
FI - Finland..... 802.11a / 802.11b / 802.11g
FR - France..... 802.11a / 802.11b / 802.11g
GB - United Kingdom..... 802.11a / 802.11b / 802.11g
GI - Gibraltar..... 802.11a / 802.11b / 802.11g
GR - Greece..... 802.11a / 802.11b / 802.11g
HK - Hong Kong..... 802.11a / 802.11b / 802.11g
HU - Hungary..... 802.11a / 802.11b / 802.11g
ID - Indonesia..... 802.11b / 802.11g
IE - Ireland..... 802.11a / 802.11b / 802.11g
IN - India..... 802.11a / 802.11b / 802.11g
IL - Israel..... 802.11a / 802.11b / 802.11g
ILO - Israel (outdoor)..... 802.11b / 802.11g
IS - Iceland..... 802.11a / 802.11b / 802.11g
IT - Italy..... 802.11a / 802.11b / 802.11g
JP - Japan (J)..... 802.11a / 802.11b / 802.11g
J2 - Japan 2 (P)..... 802.11a / 802.11b / 802.11g
J3 - Japan 3 (U)..... 802.11a / 802.11b / 802.11g
KR - Korea Republic (C)..... 802.11a / 802.11b / 802.11g
KE - Korea Extended (K)..... 802.11a / 802.11b / 802.11g
LI - Liechtenstein..... 802.11a / 802.11b / 802.11g
LT - Lithuania..... 802.11a / 802.11b / 802.11g
LU - Luxembourg..... 802.11a / 802.11b / 802.11g
LV - Latvia..... 802.11a / 802.11b / 802.11g
MC - Monaco..... 802.11a / 802.11b / 802.11g
MT - Malta..... 802.11a / 802.11b / 802.11g
MX - Mexico..... 802.11a / 802.11b / 802.11g
MY - Malaysia..... 802.11a / 802.11b / 802.11g
NL - Netherlands..... 802.11a / 802.11b / 802.11g
NZ - New Zealand..... 802.11a / 802.11b / 802.11g
NO - Norway..... 802.11a / 802.11b / 802.11g
```

PA	- Panama.....	802.11b / 802.11g
PE	- Peru.....	802.11b / 802.11g
PH	- Philippines.....	802.11a / 802.11b / 802.11g
PL	- Poland.....	802.11a / 802.11b / 802.11g
PT	- Portugal.....	802.11a / 802.11b / 802.11g
RU	- Russian Federation.....	802.11a / 802.11b / 802.11g
RO	- Romania.....	802.11a / 802.11b / 802.11g
SA	- Saudi Arabia.....	802.11a / 802.11b / 802.11g
SE	- Sweden.....	802.11a / 802.11b / 802.11g
SG	- Singapore.....	802.11a / 802.11b / 802.11g
SI	- Slovenia.....	802.11a / 802.11b / 802.11g
SK	- Slovak Republic.....	802.11a / 802.11b / 802.11g
TH	- Thailand.....	802.11b / 802.11g
TR	- Turkey.....	802.11b / 802.11g
TW	- Taiwan.....	802.11a / 802.11b / 802.11g
UA	- Ukraine.....	802.11a / 802.11b / 802.11g
US	- United States.....	802.11a / 802.11b / 802.11g
USL	- United States (Legacy).....	802.11a / 802.11b / 802.11g
USX	- United States (US + chan165).....	802.11a / 802.11b / 802.11g
VE	- Venezuela.....	802.11b / 802.11g
ZA	- South Africa.....	802.11a / 802.11b / 802.11g

Related Commands**config country****show country channels****show country**

show dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show dtls connections** command.

show dtls connections

Syntax Description This command has no arguments or keywords.

Command Default None

Examples The following is a sample output of the **show dtls connections** command.

```
Device > show dtls connections
```

AP Name	Local Port	Peer IP	Peer Port	Ciphersuite
1130	Capwap_Ctrl	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1130	Capwap_Data	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1240	Capwap_Ctrl	1.100.163.209	59674	TLS_RSA_WITH_AES_128_CBC_SHA

Related Commands **debug dtls**

show known ap

To display known Cisco lightweight access point information, use the **show known ap** command.

show known ap {**summary** | **detailed** *MAC*}

Syntax Description

summary	Displays a list of all known access points.
detailed	Provides detailed information for all known access points.
<i>MAC</i>	MAC address of the known AP.

Command Default

None.

Examples

This example shows how to display a summary of all known access points:

```
> show known ap summary
MAC Address          State          # APs  # Clients  Last Heard
-----
```

Related Commands

config ap

show ipv6 ra-guard

To display the RA guard statistics, use the **show ipv6 ra-guard** command.

show ipv6 ra-guard {ap | wlc} summary

Syntax Description

ap	Displays Cisco access point details.
wlc	Displays Cisco controller details.
summary	Displays RA guard statistics.

Command Default

None.

Examples

This example shows how to display the RA guard statistics for an access point:

```
> show ipv6 ra-guard ap summary
IPv6 RA Guard on AP..... Enabled
RA Dropped per client:
MAC Address      AP Name          WLAN/GLAN      Number of RA Dropped
-----
00:40:96:b9:4b:89 Bhavik_1130_1_p13 2              19
-----
Total RA Dropped on AP..... 19
```

This example shows how to display the RA guard statistics for a controller:

```
> show ipv6 ra-guard wlc summary
IPv6 RA Guard on WLC..... Enabled
```

Related Commands

config ipv6 ra-guard

show msglog

To display the message logs written to the Cisco wireless LAN controller database, use the **show msglog** command.

show msglog

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines If there are more than 15 entries, you are prompted to display the messages shown in the example.

Examples This example shows how to display message logs:

```
> show msglog
Message Log Severity Level..... ERROR
Thu Aug 4 14:30:08 2005 [ERROR] spam_lrad.c 1540: AP 00:0b:85:18:b6:50 associated. Last
AP failure was due to Link Failure
Thu Aug 4 14:30:08 2005 [ERROR] spam_lrad.c 13840: Updating IP info for AP 00:
0b:85:18:b6:50 -- static 0, 1.100.49.240/255.255.255.0, gw 1.100.49.1
Thu Aug 4 14:29:32 2005 [ERROR] dhcpd.c 78: dhcp server: binding to 0.0.0.0
Thu Aug 4 14:29:32 2005 [ERROR] rrmgroup.c 733: Airewave Director: 802.11a switch group
reset
Thu Aug 4 14:29:32 2005 [ERROR] rrmgroup.c 733: Airewave Director: 802.11bg sw
itch group reset
Thu Aug 4 14:29:22 2005 [ERROR] sim.c 2841: Unable to get link state for primary port 0
of interface ap-manager
Thu Aug 4 14:29:22 2005 [ERROR] dtl_l2_dot1q.c 767: Unable to get USP
Thu Aug 4 14:29:22 2005 Previous message occurred 2 times
Thu Aug 4 14:29:14 2005 [CRITICAL] osapi_sem.c 794: Error! osapiMutexTake called with
NULL pointer: osapi_bsntime.c:927
Thu Aug 4 14:29:14 2005 [CRITICAL] osapi_sem.c 794: Error! osapiMutexTake called with
NULL pointer: osapi_bsntime.c:919
Thu Aug 4 14:29:14 2005 [CRITICAL] hwutils.c 1861: Security Module not found
Thu Aug 4 14:29:13 2005 [CRITICAL] bootos.c 791: Starting code...
```


show network summary

To display the network configuration of the Cisco wireless LAN controller, use the **show network summary** command.

show network summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display a summary configuration:

```
> show network summary
RF-Network Name..... RF
Web Mode..... Disable
Secure Web Mode..... Enable
Secure Web Mode Cipher-Option High..... Disable
Secure Web Mode Cipher-Option SSLv2..... Disable
Secure Web Mode RC4 Cipher Preference..... Disable
OCSP..... Disabled
OCSP responder URL.....
Secure Shell (ssh)..... Enable
Telnet..... Enable
Ethernet Multicast Mode..... Disable    Mode: Ucast
Ethernet Broadcast Mode..... Disable
Ethernet Multicast Forwarding..... Disable
Ethernet Broadcast Forwarding..... Disable
AP Multicast/Broadcast Mode..... Unicast
IGMP snooping..... Disabled
IGMP timeout..... 60 seconds
IGMP Query Interval..... 20 seconds
MLD snooping..... Disabled
MLD timeout..... 60 seconds
MLD query interval..... 20 seconds
User Idle Timeout..... 300 seconds
AP Join Priority..... Disable
ARP Idle Timeout..... 300 seconds
ARP Unicast Mode..... Disabled
Cisco AP Default Master..... Disable
Mgmt Via Wireless Interface..... Disable
Mgmt Via Dynamic Interface..... Disable
Bridge MAC filter Config..... Enable
Bridge Security Mode..... EAP
Over The Air Provisioning of AP's..... Enable
Apple Talk ..... Disable
Mesh Full Sector DFS..... Enable
AP Fallback ..... Disable
Web Auth CMCC Support ..... Disabled
Web Auth Redirect Ports ..... 80
Web Auth Proxy Redirect ..... Disable
Web Auth Captive-Bypass ..... Disable
Web Auth Secure Web ..... Enable
Fast SSID Change ..... Disabled
AP Discovery - NAT IP Only ..... Enabled
IP/MAC Addr Binding Check ..... Enabled
CCX-lite status ..... Disable
oep-600 dual-rlan-ports ..... Disable
oep-600 local-network ..... Enable
mDNS snooping..... Disabled
mDNS Query Interval..... 15 minutes
```

Related Commands

config network

show network multicast mgid summary

show network multicast mgid detail

show network

show redundancy summary

To display the redundancy summary information, use the **show redundancy summary** command.

show redundancy summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the redundancy summary information of the controller:

```
> show redundancy summary
Redundancy Mode = SSO DISABLED
  Local State = ACTIVE
  Peer State = N/A
    Unit = Primary
    Unit ID = 88:43:E1:7E:03:80
Redundancy State = N/A
  Mobility MAC = 88:43:E1:7E:03:80

Redundancy Management IP Address..... 9.4.92.12
Peer Redundancy Management IP Address..... 9.4.92.14
Redundancy Port IP Address..... 169.254.92.12
Peer Redundancy Port IP Address..... 169.254.92.14
```

Related Commands

- config redundancy mobilitymac**
- config redundancy interface address peer-service-port**
- config redundancy peer-route**
- config redundancy unit**
- config redundancy timer**
- show redundancy peer-route**
- show redundancy summary**
- debug rmgr**
- debug rsyncmgr**

show redundancy latency

To display the average latency to reach the management gateway and the peer redundancy management IP address, use the **show redundancy latency** command.

show redundancy latency

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the average latency to reach the management gateway and the peer redundancy management IP address:

```
> show redundancy latency
```

```
Network Latencies (RTT) for the Peer Reachability on the Redundancy Port in micro seconds
for the past 10 intervals
```

```
Peer Reachability Latency[ 1 ]           : 524 usecs
Peer Reachability Latency[ 2 ]           : 524 usecs
Peer Reachability Latency[ 3 ]           : 522 usecs
Peer Reachability Latency[ 4 ]           : 526 usecs
Peer Reachability Latency[ 5 ]           : 524 usecs
Peer Reachability Latency[ 6 ]           : 524 usecs
Peer Reachability Latency[ 7 ]           : 522 usecs
Peer Reachability Latency[ 8 ]           : 522 usecs
Peer Reachability Latency[ 9 ]           : 526 usecs
Peer Reachability Latency[ 10 ]          : 523 usecs
```

```
Network Latencies (RTT) for the Management Gateway Reachability in micro seconds for the
past 10 intervals
```

```
Gateway Reachability Latency[ 1 ]        : 1347 usecs
Gateway Reachability Latency[ 2 ]        : 2427 usecs
Gateway Reachability Latency[ 3 ]        : 1329 usecs
Gateway Reachability Latency[ 4 ]        : 2014 usecs
Gateway Reachability Latency[ 5 ]        : 2675 usecs
Gateway Reachability Latency[ 6 ]        : 731 usecs
Gateway Reachability Latency[ 7 ]        : 1882 usecs
Gateway Reachability Latency[ 8 ]        : 2853 usecs
Gateway Reachability Latency[ 9 ]        : 832 usecs
Gateway Reachability Latency[ 10 ]       : 3708 usecs
```

Related Commands

- show redundancy interfaces**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy interface address peer-service-port**

show redundancy interfaces

To display details of redundancy and service port IP addresses, use the **show redundancy interfaces** command.

show redundancy interfaces

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the redundancy and service port IP addresses information:

```
> show redundancy interfaces
```

```
Redundancy Management IP Address..... 9.4.120.5
Peer Redundancy Management IP Address..... 9.4.120.3
Redundancy Port IP Address..... 169.254.120.5
Peer Redundancy Port IP Address..... 169.254.120.3
Peer Service Port IP Address..... 10.104.175.189
```

Related Commands

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy interface address peer-service-port**
- config redundancy peer-route**

show redundancy mobilitymac

To display the High Availability (HA) mobility MAC address used to communicate with the peer, use the **show redundancy mobilitymac** command.

show redundancy mobilitymac

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the HA mobility MAC address used to communicate with the peer:

```
> show redundancy mobilitymac
ff:ff:ff:ff:ff:ff
```

Related Commands

- config redundancy mobilitymac**
- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- debug rfac**
- debug rmgr**
- debug rsyncmgr**

show redundancy peer-route summary

To display the routes assigned to the standby controller, use the **show redundancy peer-route summary** command.

show redundancy peer-route summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display all the configured routes of the standby controller:

```
> show redundancy peer-route summary
Number of Routes..... 1

Destination Network      Netmask      Gateway
-----
xxx.xxx.xxx.xxx          255.255.255.0      xxx.xxx.xxx.xxx
```

Related Commands

- show redundancy latency
- show redundancy summary
- show redundancy peer-route
- show redundancy statistics
- show redundancy timers
- show redundancy mobilitymac
- config redundancy peer-route

show redundancy statistics

To display the statistics information of the Redundancy Manager, use the **show redundancy statistics** command.

show redundancy statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines This command displays the statistics of different redundancy counters.

Local Physical Ports - Connectivity status of each physical port of the controller. 1 indicates that the port is up and 0 indicates that the port is down.

Peer Physical Ports - Connectivity status of each physical port of the peer controller. 1 indicates that the port is up and 0 indicates that the port is down.

Examples This example shows how to display the statistics information of the Redundancy Manager:

```
> show redundancy statistics

Redundancy Manager Statistics

Keep Alive Request Send Counter      : 16
Keep Alive Response Receive Counter  : 16

Keep Alive Request Receive Counter    : 500322
Keep Alive Response Send Counter     : 500322

Ping Request to Default GW Counter   : 63360
Ping Response from Default GW Counter : 63360

Ping Request to Peer Counter          : 12
Ping Response from Peer Counter       : 3

Keep Alive Loss Counter               : 0
Default GW Loss Counter               : 0

Local Physical Ports 1...8           : 10000000
Peer Physical Ports 1...8            : 10000000
```

Related Commands

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy timer peer-search-timer**
- config redundancy timer keep-alive-timer**

debug rfac
debug rmgr
debug rsyncmgr

show redundancy timers

To display details of the Redundancy Manager timers, use the **show redundancy timers** command.

show redundancy timers

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the details of the Redundancy Manager timers:

```
> show redundancy timers
      Keep Alive Timer           : 100 msec
      Peer Search Timer          : 120 sec
```

Related Commands

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- config redundancy timer peer-search-timer**
- config redundancy timer keep-alive-timer**
- debug rfac**
- debug rmgr**
- debug rsyncmgr**

show watchlist

To display the client watchlist, use the **show watchlist** command.

show watchlist

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the client watchlist information:

```
> show watchlist
client watchlist state is disabled
```

Related Commands

- config watchlist add**
- config watchlist delete**
- config watchlist disable**
- config watchlist enable**

capwap ap Commands

Use the **capwap ap** commands to configure CAPWAP access point settings.

capwap ap controller ip address

To configure the controller IP address into the CAPWAP access point from the access point's console port, use the **capwap ap controller ip address** command.

capwap ap controller ip address *controller_ip_address*

Syntax Description

controller_ip_address

IP address of the controller.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the controller IP address 10.23.90.81 into the CAPWAP access point:

```
> capwap ap controller ip address 10.23.90.81
```

Related Commands

capwap ap dot1x
capwap ap hostname
capwap ap ip address
capwap ap ip default-gateway
capwap ap log-server
capwap ap primary-base
capwap ap primed-timer
capwap ap secondary-base
capwap ap tertiary-base

capwap ap dot1x

To configure the dot1x username and password into the CAPWAP access point from the access point's console port, use the **capwap ap dot1x** command.

capwap ap dot1x username *user_name* **password** *password*

Syntax Description

user_name Dot1x username.

password Dot1x password.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the dot1x username ABC and password pass01:

```
> capwap ap dot1x username ABC password pass01
```

Related Commands

capwap ap controller ip address

capwap ap hostname

capwap ap ip address

capwap ap ip default-gateway

capwap ap log-server

capwap ap primary-base

capwap ap primed-timer

capwap ap secondary-base

capwap ap tertiary-base

capwap ap hostname

To configure the access point host name from the access point's console port, use the **capwap ap hostname** command.

capwap ap hostname *host_name*

Syntax Description

<i>host_name</i>	Hostname of the access point.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases. This command is available only for the Cisco Lightweight AP IOS Software recovery image (rcvk9w8) without any private-config. You can remove the private-config by using the **clear capwap private-config** command.

Examples

This example shows how to configure the hostname WLC into the capwap access point:

```
> capwap ap hostname WLC
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap ip address
capwap ap ip default-gateway
capwap ap log-server
capwap ap primary-base
capwap ap primed-timer
capwap ap secondary-base
capwap ap tertiary-base

capwap ap ip address

To configure the IP address into the CAPWAP access point from the access point's console port, use the **capwap ap ip address** command.

capwap ap ip address *ip_address*

Syntax Description

ip_address IP address.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the IP address 10.0.0.0.1 into capwap access point:

```
> capwap ap ip address 10.0.0.0.1
```

Related Commands

capwap ap controller ip address

capwap ap dot1x

capwap ap hostname

capwap ap ip default-gateway

capwap ap log-server

capwap ap ip address

capwap ap primary-base

capwap ap secondary-base

capwap ap tertiary-base

capwap ap ip default-gateway

To configure the default gateway from the access point's console port, use the **capwap ap ip default-gateway** command.

capwap ap ip default-gateway *default_gateway*

Syntax Description

default_gateway Default gateway address of the capwap access point.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the capwap access point with the default gateway address 10.0.0.1:

```
> capwap ap ip default-gateway 10.0.0.1
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap hostname
capwap ap ip address
capwap ap log-server
capwap ap primary-base
capwap ap primary-base
capwap ap secondary-base
capwap ap tertiary-base

capwap ap log-server

To configure the system log server to log all the capwap errors, use the **capwap ap log-server** command.

capwap ap log-server *ip_address*

Syntax Description

<i>ip_address</i>	IP address of the syslog server.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the syslog server with the IP address 10.0.0.1:

```
> capwap ap log-server 10.0.0.1
```

Related Commands

- capwap ap controller ip address
- capwap ap dot1x
- capwap ap ip address
- capwap ap hostname
- capwap ap ip default-gateway
- capwap ap log-server
- capwap ap primary-base
- capwap ap primary-base
- capwap ap secondary-base
- capwap ap tertiary-base

capwap ap primary-base

To configure the primary controller name and IP address into the capwap access point from the access point's console port, use the **capwap ap primary-base** command.

capwap ap primary-base *controller_name controller_ip_address*

Syntax Description

<i>controller_name</i>	Name of the primary controller.
<i>controller_ip_address</i>	IP address of the primary controller.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the primary controller name WLC1 and primary controller IP address 10.92.109.1 into the capwap access point:

```
> capwap ap primary-base WLC1 10.92.109.1
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap ip address
capwap ap hostname
capwap ap ip default-gateway
capwap ap log-server
capwap ap secondary-base
capwap ap tertiary-base

capwap ap primed-timer

To configure the primed timer into the CAPWAP access point, use the **capwap ap primed-timer** command.

capwap ap primed-timer {enable | disable}

Syntax Description

enable	Enables the primed timer settings
disable	Disables the primed timer settings.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

Examples

This example shows how to enable the primed-timer settings:

```
> capwap ap primed-timer enable
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap hostname
capwap ap ip default-gateway
capwap ap log-server
capwap ap ip address
capwap ap primary-base
capwap ap secondary-base
capwap ap tertiary-base

capwap ap secondary-base

To configure the name and IP address of the secondary Cisco WLC into the CAPWAP access point from the access point's console port, use the **capwap ap secondary-base** command.

capwap ap secondary-base *controller_name controller_ip_address*

Syntax Description

<i>controller_name</i>	Name of the secondary Cisco WLC.
<i>controller_ip_address</i>	IP address of the secondary Cisco WLC.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

Examples

This example shows how to configure the secondary Cisco WLC name as WLC2 and secondary Cisco WLC IP address 10.92.108.2 into the CAPWAP access point:

```
> capwap ap secondary-base WLC2 10.92.108.2
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap ip address
capwap ap hostname
capwap ap ip default-gateway
capwap ap log-server
capwap ap primary-base
capwap ap tertiary-base

capwap ap tertiary-base

To configure the name and IP address of the tertiary Cisco WLC into the CAPWAP access point from the access point's console port, use the **capwap ap tertiary-base** command.

capwap ap tertiary-base *controller_name controller_ip_address*

Syntax Description

<i>controller_name</i>	Name of the tertiary Cisco WLC.
<i>controller_ip_address</i>	IP address of the tertiary Cisco WLC.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

Examples

This example shows how to configure the tertiary Cisco WLC with the name WLC3 and secondary Cisco WLC IP address 10.80.72.2 into the CAPWAP access point:

```
> capwap ap tertiary-base WLC3 10.80.72.2
```

Related Commands

capwap ap controller ip address
capwap ap dot1x
capwap ap ip address
capwap ap hostname
capwap ap ip default-gateway
capwap ap log-server
capwap ap primary-base
capwap ap secondary-base

lwapp ap controller ip address

To configure the controller IP address into the FlexConnect access point from the access point's console port, use the **lwapp ap controller ip address** command.

lwapp ap controller ip address *ip_address*

Syntax Description

<i>ip_address</i>	IP address of the controller.

Command Default

None.

Usage Guidelines

This command must be entered from an access point's console port.

Prior to changing the FlexConnect configuration on an access point using the access point's console port, the access point must be in standalone mode (not connected to a controller) and you must remove the current LWAPP private configuration by using the **clear lwapp private-config** command.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

Examples

This example shows how to configure the controller IP address 10.92.109.1 into the FlexConnect access point:

```
> lwapp ap controller ip address 10.92.109.1
```

Related Commands

clear lwapp private-config
debug lwapp console cli

config Commands

This section lists the **config** commands to configure access points.

config 802.11-a antenna extAntGain

To configure the external antenna gain for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a antenna extAntGain** commands.

config {802.11-a49 | 802.11-a58} antenna extAntGain *ant_gain* *cisco_ap* {global | *channel_no*}

Syntax Description

802.11-a49	Specifies the 4.9-GHz public safety channel.
802.11-a58	Specifies the 5.8-GHz public safety channel.
<i>ant_gain</i>	Value in .5-dBi units (for instance, 2.5 dBi = 5).
<i>cisco_ap</i>	Name of the access point to which the command applies.
global	Specifies the antenna gain value to all channels.
<i>channel_no</i>	Antenna gain value for a specific channel.

Command Default

Disabled.

Usage Guidelines

Before you enter the **config 802.11-a antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11-a disable** command.

After you configure the external antenna gain, use the **config 802.11-a enable** command to reenable the 802.11 Cisco radio.

Examples

This example shows how to configure an 802.11-a49 external antenna gain of 10 dBi for AP1:

```
> config 802.11-a antenna extAntGain 10 AP1
```

Related Commands

config 802.11-a

config 802.11-a channel ap

config 802.11-a txpower ap

show 802.11a

config 802.11-a channel ap

To configure the channel properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a channel ap** command.

config {802.11-a49 | 802.11-a58} channel ap *cisco_ap* {**global** | *channel_no*}

Syntax Description		
802.11-a49		Specifies the 4.9-GHz public safety channel.
802.11-a58		Specifies the 5.8-GHz public safety channel.
<i>cisco_ap</i>		Name of the access point to which the command applies.
global		Enables the Dynamic Channel Assignment (DCA) on all 4.9-GHz and 5.8-GHz subband radios.
<i>channel_no</i>		Custom channel for a specific mesh access point. The range is 1 through 26, inclusive, for a 4.9-GHz band and 149 through 165, inclusive, for a 5.8-GHz band.

Command Default Disabled.

Examples This example shows how to set the channel properties:

```
> config 802.11-a channel ap
```

Related Commands

- config 802.11-a
- config 802.11-a antenna extAntGain
- config 802.11-a txpower ap

config 802.11-a txpower ap

To configure the transmission power properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a txpower ap** command.

config {802.11-a49 | 802.11-a58} txpower ap *cisco_ap* {**global** | *power_level*}

Syntax Description	802.11-a49	Specifies the 4.9-GHz public safety channel.
	802.11-a58	Specifies the 5.8-GHz public safety channel.
	txpower	Configures transmission power properties.
	ap	Configures access point channel settings.
	<i>cisco_ap</i>	Name of the access point to which the command applies.
	global	Applies the transmission power value to all channels.
	<i>power_level</i>	Transmission power value to the designated mesh access point. The range is from 1 to 5.

Command Default Disabled.

Examples This example shows how to configure an 802.11-a49 transmission power level of 4 for AP1:

```
> config 802.11-a txpower ap 4 AP1
```

Related Commands

- config 802.11-a
- config 802.11 channel ap
- config 802.11 antenna extAntGain

config 802.11 antenna diversity

To configure the diversity option for 802.11 antennas, use the **config 802.11 antenna diversity** command.

config 802.11 {a | b} antenna diversity {enable | sideA | sideB} *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the diversity.
sideA	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point left port.
sideB	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point right port.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to enable antenna diversity for AP01 on an 802.11b network:

```
> config 802.11a antenna diversity enable AP01
```

This example shows how to enable diversity for AP01 on an 802.11a network, using an external antenna connected to the Cisco lightweight access point left port (sideA):

```
> config 802.11a antenna diversity sideA AP01
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna mode
config 802.11 antenna selection
show 802.11a
show 802.11b

config 802.11 antenna extAntGain

To configure external antenna gain for an 802.11 network, use the **config 802.11 antenna extAntGain** command.

config 802.11 {a | b} antenna extAntGain *antenna_gain cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>antenna_gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Usage Guidelines

Before you enter the **config 802.11 antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11 disable** command.

After you configure the external antenna gain, use the **config 802.11 enable** command to enable the 802.11 Cisco radio.

Examples

This example shows how to configure an *802.11a* external antenna gain of *0.5 dBm* for *AP1*:

```
> config 802.11 antenna extAntGain 1 AP1
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna mode
config 802.11 antenna selection
show 802.11a
show 802.11b

config 802.11 antenna mode

To configure the Cisco lightweight access point to use one internal antenna for an 802.11 sectorized 180-degree coverage pattern or both internal antennas for an 802.11 360-degree omnidirectional pattern, use the **config 802.11 antenna mode** command.

```
config 802.11 {a | b} antenna mode {omni | sectorA | sectorB} cisco_ap
```

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
omni	Specifies to use both internal antennas.
sectorA	Specifies to use only the side A internal antenna.
sectorB	Specifies to use only the side B internal antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure access point AP01 antennas for a 360-degree omnidirectional pattern on an 802.11b network:

```
> config 802.11 antenna mode omni AP01
```

Related Commands

```
config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna diversity
config 802.11 antenna selection
show 802.11a
show 802.11b
```

config 802.11 antenna selection

To select the internal or external antenna selection for a Cisco lightweight access point on an 802.11 network, use the **config 802.11 antenna selection** command.

config 802.11 {a | b} antenna selection {internal | external} *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
internal	Specifies the internal antenna.
external	Specifies the external antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure access point AP02 on an 802.11b network to use the internal antenna:

```
> config 802.11a antenna selection internal AP02
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna mode
config 802.11 antenna diversity
show 802.11a
show 802.11b

config 802.11 beamforming

To enable or disable beamforming on the network or on individual radios, enter the **config 802.11 beamforming** command.

config 802.11 {a | b} beamforming {global | ap *ap_name*} {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Specifies all lightweight access points.
ap <i>ap_name</i>	Specifies the Cisco access point name.
enable	Enables beamforming.
disable	Disables beamforming.

Command Default

None.

Usage Guidelines

When you enable beamforming on the network, it is automatically enabled for all the radios applicable to that network type.

Follow these guidelines for using beamforming:

- Beamforming is supported only for legacy orthogonal frequency-division multiplexing (OFDM) data rates (6, 9, 12, 18, 24, 36, 48, and 54 mbps).



Note Beamforming is not supported for complementary-code keying (CCK) data rates (1, 2, 5.5, and 11 Mbps).

- Beamforming is supported only on access points that support 802.11n (AP1250 and AP1140).
- Two or more antennas must be enabled for transmission.
- All three antennas must be enabled for reception.
- OFDM rates must be enabled.

If the antenna configuration restricts operation to a single transmit antenna, or if OFDM rates are disabled, beamforming is not used.

Examples

This example shows how to enable beamforming on the 802.11a network:

```
> config 802.11 beamforming global enable
```

Related Commands

show ap config {802.11a | 802.11b}

show 802.11a

config 802.11b beaconperiod

config 802.11a disable

config 802.11a enable

config 802.11 disable

To disable radio transmission for an entire 802.11 network or for an individual Cisco radio, use the **config 802.11 disable** command.

config 802.11 {a | b} disable {network | cisco_ap}

Syntax Description

a	Configures the 802.11a radio.
b	Specifies the 802.11b/g network.
network	Disables transmission for the entire 802.11a network.
<i>cisco_ap</i>	Individual Cisco lightweight access point radio.

Command Default

The transmission is enabled for the entire network by default.

Usage Guidelines

Note

You must use this command to disable the network before using many config 802.11 commands.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to disable the entire 802.11a network:

```
> config 802.11a disable network
```

This example shows how to disable access point AP01 802.11b transmissions:

```
> config 802.11b disable AP01
```

Related Commands

show sysinfo
show 802.11a
config 802.11a enable
config 802.11b disable
config 802.11b enable
config 802.11a beaconperiod

config advanced 802.11 profile clients

To set the Cisco lightweight access point clients threshold between 1 and 75 clients, use the **config advanced 802.11 profile clients** command.

config advanced 802.11 {a | b} profile clients {global | cisco_ap} clients

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access points.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>clients</i>	802.11a Cisco lightweight access point client threshold between 1 and 75 clients.

Command Default

12 clients.

Examples

This example shows how to set all Cisco lightweight access point clients thresholds to 25 clients:

```
> config advanced 802.11 profile clients global 25
Global client count profile set.
```

This example shows how to set the AP1 clients threshold to 75 clients:

```
> config advanced 802.11 profile clients AP1 75
Global client count profile set.
```

Related Commands

show advanced 802.11a profile

config advanced 802.11b profile clients

config advanced 802.11 profile customize

To turn customizing on or off for an 802.11a Cisco lightweight access point performance profile, use the **config advanced 802.11 profile customize** command.

config advanced 802.11 {a | b} profile customize *cisco_ap* {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point.
on	Customizes performance profiles for this Cisco lightweight access point.
off	Uses global default performance profiles for this Cisco lightweight access point.

Command Default

Off.

Examples

This example shows how to turn performance profile customization on for 802.11a Cisco lightweight access point AP1:

```
> config advanced 802.11 profile customize AP1 on
```

Related Commands

show advanced 802.11 profile
config advanced 802.11b profile customize

config advanced 802.11 profile foreign

To set the foreign 802.11a transmitter interference threshold between 0 and 100 percent, use the **config advanced 802.11 profile foreign** command.

config advanced 802.11 {a | b} profile foreign {global | cisco_ap} percent

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access points.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a foreign 802.11a interference threshold between 0 and 100 percent.

Command Default

10.

Examples

This example shows how to set the foreign 802.11a transmitter interference threshold for all Cisco lightweight access points to 50 percent:

```
> config advanced 802.11a profile foreign global 50
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
> config advanced 802.11 profile foreign AP1 0
```

Related Commands

show advanced 802.11a profile

config advanced 802.11b profile foreign

config advanced 802.11 profile noise

To set the 802.11a foreign noise threshold between -127 and 0 dBm, use the **config advanced 802.11 profile noise** command.

config advanced 802.11 {a | b} profile noise {global | *cisco_ap*} dBm

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>dBm</i>	802.11a foreign noise threshold between -127 and 0 dBm.

Command Default

-70 dBm.

Examples

This example shows how to set the 802.11a foreign noise threshold for all Cisco lightweight access points to -127 dBm:

```
> config advanced 802.11a profile noise global -127
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
> config advanced 802.11a profile noise AP1 0
```

Related Commands

show advanced 802.11 profile

config advanced 802.11b profile noise

config advanced 802.11 profile throughput

To set the Cisco lightweight access point data-rate throughput threshold between 1000 and 10000000 bytes per second, use the **config advanced 802.11 profile throughput** command.

config advanced 802.11 {a | b} **profile throughput** {global | cisco_ap} *value*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>value</i>	802.11a Cisco lightweight access point throughput threshold between 1000 and 10000000 bytes per second.

Command Default

1,000,000 bytes per second.

Examples

This example shows how to set all Cisco lightweight access point data-rate thresholds to 1000 bytes per second:

```
> config advanced 802.11 profile throughput global 1000
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
> config advanced 802.11 profile throughput AP1 10000000
```

Related Commands

show advanced 802.11 profile

config advanced 802.11b profile data-rate

config advanced 802.11 profile utilization

To set the RF utilization threshold between 0 and 100 percent, use the **config advanced 802.11 profile utilization** command. The operating system generates a trap when this threshold is exceeded.

config advanced 802.11 {a | b} profile utilization {global | cisco_ap} percent

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures a global Cisco lightweight access point specific profile.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a RF utilization threshold between 0 and 100 percent.

Command Default

80 percent.

Examples

This example shows how to set the RF utilization threshold for all Cisco lightweight access points to 0 percent:

```
> config advanced 802.11 profile utilization global 0
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
> config advanced 802.11 profile utilization AP1 100
```

Related Commands

show advanced 802.11a profile
config advanced 802.11b profile utilization

config advanced backup-controller primary

To configure a primary backup controller for a specific controller, use the **config advanced backup-controller primary** command.

config advanced backup-controller primary *backup_controller_name* *backup_controller_ip_address*

Syntax Description

<i>backup_controller_name</i>	Name of the backup controller.
<i>backup_controller_ip_address</i>	IP address of the backup controller.

Command Default

None.

Usage Guidelines

To delete a primary backup controller entry, enter 0.0.0.0 for the controller IP address.

Examples

This example shows how to configure the primary backup controller:

```
> config advanced backup-controller primary Controller_1 10.10.10.10
```

Related Commands

show advanced backup-controller

config advanced backup-controller secondary

To configure a secondary backup controller for a specific controller, use the **config advanced backup-controller secondary** command.

config advanced backup-controller secondary *backup_controller_name backup_controller_ip_address*

Syntax Description

<i>backup_controller_name</i>	Name of the backup controller.
<i>backup_controller_ip_address</i>	IP address of the backup controller.

Command Default

None.

Usage Guidelines

To delete a secondary backup controller entry, enter 0.0.0.0 for the controller IP address.

Examples

This example shows how to configure a secondary backup controller:

```
> config advanced backup-controller secondary Controller_1 10.10.10.10
```

Related Commands

show advanced backup-controller

config advanced client-handoff

To set the client handoff to occur after a selected number of 802.11 data packet excessive retries, use the **config advanced client-handoff** command.

config advanced client-handoff *num_of_retries*

Syntax Description

<i>num_of_retries</i>	Number of excessive retries before client handoff (from 0 to 255).

Command Default

0 excessive retries (disabled).

Usage Guidelines

This command is supported only for the 1000/1510 series access points.

Examples

This example shows how to set the client handoff to 100 excessive retries:

```
> config advanced client-handoff 100
```

Related Commands

show advanced client-handoff

config advanced dot11-padding

To enable or disable over-the-air frame padding, use the **config advanced dot11-padding** command.

config advanced dot11-padding {enable | disable}

Syntax Description

enable	Enables the over-the-air frame padding.
disable	Disables the over-the-air frame padding.

Command Default

Disabled.

Examples

This example shows how to enable over-the-air frame padding:

```
> config advanced dot11-padding enable
```

Related Commands

debug dot11
debug dot11 mgmt interface
debug dot11 mgmt msg
debug dot11 mgmt ssid
debug dot11 mgmt state-machine
debug dot11 mgmt station
show advanced dot11-padding

config advanced assoc-limit

To configure the rate at which access point radios send association and authentication requests to the controller, use the **config advanced assoc-limit** command.

config advanced assoc-limit {**enable** [*number of associations per interval* | *interval*] | **disable**}

Syntax Description

enable	Enables the configuration of the association requests per access point.
disable	Disables the configuration of the association requests per access point.
<i>number of associations per interval</i>	(Optional) Number of association request per access point slot in a given interval. The range is from 1 to 100.
<i>interval</i>	(Optional) Association request limit interval. The range is from 100 to 10000 milliseconds.

Command Default

Disabled.

Usage Guidelines

When 200 or more wireless clients try to associate to a controller at the same time, the clients no longer become stuck in the DHCP_REQD state when you use the **config advanced assoc-limit** command to limit association requests from access points.

Examples

This example shows how to configure the number of association requests per access point slot in a given interval of 20 with the association request limit interval of 250:

```
> config advanced assoc-limit enable 20 250
```

config advanced max-1x-sessions

To configure the maximum number of simultaneous 802.1X sessions allowed per access point, use the **config advanced max-1x-sessions** command.

config advanced max-1x-sessions *no_of_sessions*

Syntax Description

<i>no_of_sessions</i>	Number of maximum 802.1x session initiation per AP at a time. The range is from 0 to 255, where 0 indicates unlimited.

Command Default

None.

Examples

This example shows how to configure the maximum number of simultaneous 802.1X sessions:

```
> config advanced max-1x-sessions 200
```

config advanced rate

To enable or disable switch control path rate limiting, use the **config advanced rate** command.

config advanced rate {enable | disable}

Syntax Description

enable	Enables the switch control path rate limiting feature.
disable	Disables the switch control path rate limiting feature.

Command Default

None.

Examples

This example shows how to enable switch control path rate limiting:

```
> config advanced rate enable
```

config advanced probe filter

To enable or disable the filtering of probe requests forwarded from an access point to the controller, use the **config advanced probe filter** command.

config advanced probe filter {enable | disable}

Syntax Description

enable	Enables the filtering of probe requests.
disable	Disables the filtering of probe requests.

Command Default

None.

Examples

This example shows how to enable the filtering of probe requests forwarded from an access point to the controller:

```
> config advanced probe filter enable
```

Related Commands

config advanced probe limit
config radius acct ipsec authentication
show advanced probe
show radius acct statistics

config advanced probe limit

To limit the number of probes sent to the WLAN controller per access point per client in a given interval, use the **config advanced probe limit** command.

config advanced probe limit *num_probes interval*

Syntax Description

<i>num_probes</i>	Number of probe requests (from 1 to 100) forwarded to the controller per client per access point radio in a given interval.
<i>interval</i>	Probe limit interval (from 100 to 10000 milliseconds).

Command Default

The default number of probe requests is 2. The default interval is 500 milliseconds.

Examples

This example shows how to set the number of probes per access point per client to 5 and the probe interval to 800 milliseconds:

```
> config advanced probe limit 5 800
```

Related Commands

config radius acct ipsec authentication
show advanced probe
show radius acct statistics

config advanced timers

To configure a system timer, use the **config advanced timers** command.

```
config advanced timers {ap-discovery-timeout discovery-timeout | ap-fast-heartbeat {local | flexconnect
| all} {enable | disable} fast_heartbeat_seconds | ap-heartbeat-timeout heartbeat_seconds |
ap-primary-discovery-timeout primary_discovery_timeout | ap-primed-join-timeout primed_join_timeout
| auth-timeout auth_timeout | pkt-fwd-watchdog {enable | disable} {watchdog_timer | default} |
eap-identity-request-delay eap_identity_request_delay | eap-timeout eap_timeout}
```

Syntax Description

ap-discovery-timeout	Configures Cisco lightweight access point discovery timeout value.
<i>discovery-timeout</i>	Cisco lightweight access point discovery timeout value. The range is from 1 to 10 seconds.
ap-fast-heartbeat	Configures the fast heartbeat timer, which reduces the amount of time it takes to detect a controller failure in access points.
local	Configures the fast heartbeat interval for access points in local mode only.
flexconnect	Configures the fast heartbeat interval for access points in FlexConnect mode only.
all	Configures the fast heartbeat interval for all the access points.
enable	Enables the fast heartbeat interval.
disable	Disables the fast heartbeat interval.
<i>fast_heartbeat_seconds</i>	Small heartbeat interval, which reduces the amount of time it takes to detect a controller failure. The range is from 1 to 10 seconds.
ap-heartbeat-timeout	Configures Cisco lightweight access point heartbeat timeout value.
<i>heartbeat_seconds</i>	Cisco lightweight access point heartbeat timeout value. The range is from 1 to 30 seconds. This value should be at least three times larger than the fast heartbeat timer.
ap-primary-discovery-timeout	Configures the access point primary discovery request timer.
<i>primary_discovery_timeout</i>	Access point primary discovery request timer. The range is from 30 to 3600 seconds.
ap-primed-join-timeout	Configures AP primed discovery timeout value.
<i>primed_join_timeout</i>	Access point primed discovery timeout value. The range is from 120 to 43200 seconds.
auth-timeout	Configures the authentication timeout.

<i>auth_timeout</i>	Authentication response timeout value, in seconds, from 10 to 600.
pkt-fwd-watchdog	Configures the packet forwarding watchdog timer to protect from fastpath deadlock.
<i>watchdog_timer</i>	Packet forwarding watchdog timer, in seconds. The range is from 60 to 300.
default	Configures the watchdog timer to the default value of 240 seconds.
eap-identity-request-delay	Configures the advanced Extensible Authentication Protocol (EAP) identity request delay, in seconds.
<i>eap_identity_request_delay</i>	Advanced EAP identity request delay, in seconds. The range is from 0 to 10.
eap-timeout	Configures the EAP expiration timeout.
<i>eap_timeout</i>	EAP timeout value, in seconds. The range is from 8 to 120.

Command Default

The default access point discovery timeout is 10 seconds.
 The default access point heartbeat timeout is 30 seconds.
 The default access point primary discovery request timer is 120 seconds.
 The default authentication timeout is 10 seconds.
 The default packet forwarding watchdog timer is 240 seconds.

Usage Guidelines

The Cisco lightweight access point discovery timeout indicates how often a Cisco WLC attempts to discover unconnected Cisco lightweight access points.
 The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keepalive signal to the Cisco WLC.

Examples

The following example shows how to configure an access point discovery timeout with a timeout value of 20:

```
Device > config advanced timers ap-discovery-timeout 20
```

The following example shows how to enable the fast heartbeat interval for an access point in FlexConnect mode:

```
Device > config advanced timers ap-fast-heartbeat flexconnect enable 8
```

The following example shows how to configure the authentication timeout to 20 seconds:

```
Device > config advanced timers auth-timeout 20
```

Related Commands show advanced timers

config ap

To enable or disable a Cisco lightweight access point or to add or delete a third-party (foreign) access point, use the **config ap** command.

config ap **{enable | disable}** *cisco_ap* **{add | delete}** *MAC* *port* **{enable | disable}** *IP_address*

Syntax Description

enable	Enables the Cisco lightweight access point.
disable	Disables the Cisco lightweight access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
add	Adds foreign access points.
delete	Deletes foreign access points.
<i>MAC</i>	MAC address of a foreign access point.
<i>port</i>	Port number through which the foreign access point can be reached.
<i>IP_address</i>	IP address of the foreign access point.

Command Default

None.

Examples

This example shows how to disable lightweight access point AP1:

```
> config ap disable AP1
```

This example shows how to add a foreign access point with MAC address 12:12:12:12:12:12 and IP address 192.12.12.1 from port 2033:

```
> config ap add 12:12:12:12:12:12 2033 enable 192.12.12.1
```

Related Commands

show ap

config ap autoconvert

To automatically convert all access points to a FlexConnect mode or monitor mode upon joining the Cisco WLC, use the **config ap autoconvert** command.

config ap autoconvert {flexconnect | monitor | disable}

Syntax Description

flexconnect	Configures all the access points automatically to FlexConnect mode.
monitor	Configures all the access points automatically to monitor mode.
disable	Disables the autoconvert option on the access points.

Command Default

None.

Usage Guidelines

When access points in local mode connect to a Cisco 7500 Series Wireless Controller, they do not serve clients. The access point details are available in the controller. To enable access points to serve clients or perform monitoring related tasks when connected to the Cisco 7500 Series Wireless Controller, the access points must be in FlexConnect mode or monitor mode.

Examples

This example shows how to automatically convert all access points to the FlexConnect mode:

```
> config ap autoconvert flexconnect
```

This example shows how to disable the autoconvert option on the APs:

```
> config ap autoconvert disable
```

Related Commands

config ap
show ap

config ap bhrate

To configure the Cisco bridge backhaul Tx rate, use the **config ap bhrate** command.

config ap bhrate {*rate* | **auto**} *cisco_ap*

Syntax Description

<i>rate</i>	Cisco bridge backhaul Tx rate in kbps. The valid values are 6000, 12000, 18000, 24000, 36000, 48000, and 54000.
auto	Configures the auto data rate.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

Auto.

Usage Guidelines

In previous software releases, the default value for the bridge data rate was 24000 (24 Mbps). In controller software release 6.0, the default value for the bridge data rate is **auto**. If you configured the default bridge data rate value (24000) in a previous controller software release, the bridge data rate is configured with the new default value (auto) when you upgrade to controller software release 6.0. However, if you configured a non default value (for example, 18000) in a previous controller software release, that configuration setting is preserved when you upgrade to Cisco WLC Release 6.0.

When the bridge data rate is set to **auto**, the mesh backhaul chooses the highest rate where the next higher rate cannot be used due to unsuitable conditions for that specific rate (and not because of conditions that affect all rates).

Examples

This example shows how to configure the Cisco bridge backhaul Tx rate to 54000 kbps:

```
> config ap bhrate 54000 AP01
```

Related Commands

config ap

config ap bridgegroupname

To set or delete a bridge group name on a Cisco lightweight access point, use the **config ap bridgegroupname** command.

config ap bridgegroupname {set *groupname* | delete} *cisco_ap*

Syntax Description

set	Sets a Cisco lightweight access point's bridge group name.
<i>groupname</i>	Bridge group name.
delete	Deletes a Cisco lightweight access point's bridge group name.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

None.

Usage Guidelines

Only access points with the same bridge group name can connect to each other. Changing the AP bridgegroupname may strand the bridge AP.

Examples

This example shows how to delete a bridge group name on Cisco access point's bridge group name AP02:

```
> config ap bridgegroupname delete AP02
Changing the AP's bridgegroupname may strand the bridge AP. Please continue with caution.
Changing the AP's bridgegroupname will also cause the AP to reboot.
Are you sure you want to continue? (y/n)
```

Related Commands

config ap

config ap bridging

To enable or disable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **config ap bridging** command.

config ap bridging {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the Ethernet-to-Ethernet bridging on a Cisco lightweight access point.
disable	Disables Ethernet-to-Ethernet bridging.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to enable bridging on an access point:

```
> config ap bridging enable nyc04-44-1240
```

This example shows how to disable bridging on an access point:

```
> config ap bridging disable nyc04-44-1240
```

Related Commands

config ap

config ap cdp

To enable or disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **config ap cdp** command.

config ap cdp {enable | disable | interface {ethernet *interface_number* | slot *slot_id*} } {cisco_ap | all}

Syntax Description

enable	Enables CDP on an access point.
disable	Disables CDP on an access point.
interface	Configures CDP in a specific interface.
ethernet	Configures CDP for an ethernet interface.
<i>interface_number</i>	Ethernet interface number between 0 and 3.
slot	Configures CDP for a radio interface.
<i>slot_id</i>	Slot number between 0 and 3.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
all	Specifies all access points.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

Enabled on radio interfaces of mesh APs and disabled on radio interfaces of non-mesh APs. Enabled on Ethernet interfaces of all APs.

Usage Guidelines

The **config ap cdp disable all** command disables CDP on all access points that are joined to the controller and all access points that join in the future. CDP remains disabled on both current and future access points even after the controller or access point reboots. To enable CDP, enter the **config ap cdp enable all** command.



Note

CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points joined to the controller, you may disable and then reenabling CDP on individual access points using the **config ap cdp {enable | disable} cisco_ap command**. After you disable CDP on all access points joined to the controller, you may not enable and then disable CDP on individual access points.

Examples

This example shows how to enable CDP on all access points:

```
> config ap cdp enable all
```

This example shows how to disable CDP on ap02 access point:

```
> config ap cdp disable ap02
```

This example shows how to enable CDP for Ethernet interface number 2 on all access points:

```
> config ap cdp ethernet 2 enable all
```

Related Commands

config cdp timer

show ap cdp

config ap core-dump

To configure a Cisco lightweight access point's memory core dump, use the **config ap core-dump** command.

config ap core-dump {disable | enable *tftp_server_ipaddress filename* {compress | uncompress} {*cisco_ap* | all}}

Syntax Description

enable	Enables the Cisco lightweight access point's memory core dump setting.
disable	Disables the Cisco lightweight access point's memory core dump setting.
<i>tftp_server_ipaddress</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point uses to label the core file.
compress	Compresses the core dump file.
uncompress	Uncompresses the core dump file.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
all	Specifies all access points.



Note

If an AP itself is configured with the name 'all', then the 'all access points' case takes precedence over the AP that is named 'all'.

Command Default

None.

Usage Guidelines

The access point must be able to reach the TFTP server.

Examples

This example shows how to configure and compress the core dump file:

```
> config ap core-dump enable 192.1.1.1 log compress AP02
```

Related Commands

config ap crash-file clear-all
config ap crash-file delete
config ap crash-file get-crash-file
config ap crash-file get-radio-core-dump
config ap port

config ap crash-file clear-all

To delete all crash and radio core dump files, use the **config ap crash-file clear-all** command.

config ap crash-file clear-all

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to delete all crash files:

```
> config ap crash-file clear-all
```

Related Commands

- config ap core-dump**
- config ap crash-file delete**
- config ap crash-file get-crash-file**
- config ap crash-file get-radio-core-dump**
- config ap port**

config ap crash-file delete

To delete a single crash or radio core dump file, use the **config ap crash-file delete** command.

config ap crash-file delete *filename*

Syntax Description

<i>filename</i>	Name of the file to delete.

Command Default

None.

Examples

This example shows how to delete crash file 1:

```
> config ap crash-file delete crash_file_1
```

Related Commands

config ap crash-file clear-all
config ap crash-file core-dump
config ap crash-file get-crash-file
config ap crash-file get-radio-core-dump
config ap port

config ap crash-file get-crash-file

To collect the latest crash data for a Cisco lightweight access point, use the **config ap crash-file get-crash-file** command.

config ap crash-file get-crash-file *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Usage Guidelines

Use the **transfer upload datatype** command to transfer the collected data to the Cisco wireless LAN controller.

Examples

This example shows how to collect the latest crash data for access point AP3:

```
> config ap crash-file get-crash-file AP3
```

Related Commands

config ap crash-file core-dump
config ap crash-file crash-file delete
config ap crash-file clear-all
config ap crash-file get-radio-core-dump
config ap port

config ap crash-file get-radio-core-dump

To get a Cisco lightweight access point's radio core dump, use the **config ap crash-file get-radio-core-dump** command.

config ap crash-file get-radio-core-dump *slot_id* *cisco_ap*

Syntax Description

<i>slot_id</i>	Slot ID (either 0 or 1).
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to collect the radio core dump for access point AP02 and slot 0:

```
> config ap crash-file get-radio-core-dump 0 AP02
```

Related Commands

config ap crash-file clear-all
config ap crash-file delete
config ap crash-file get-crash-file
config ap crash-file core-dump
config ap port

config ap dot1xuser

To configure the global authentication username and password for all access points currently joined to the controller as well as any access points that join the controller in the future, use the **config ap dot1xuser** command.

config ap dot1xuser add username *user* **password** *password* {**all** | *cisco_ap*}

Syntax Description

add username	Specifies to add a username.
<i>user</i>	Username.
password	Specifies to add a password.
<i>password</i>	Password.
<i>cisco_ap</i>	Specific access point.
all	Specifies all access points.

Command Default

None.

Usage Guidelines

You must enter a strong *password*. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not a word in any language.

You can set the values for a specific access point.

Examples

This example shows how to configure the global authentication username and password for all access points:

```
> config ap dot1xuser add username cisco123 password cisco2020 all
```

Related Commands

config ap dot1xuser delete
config ap dot1xuser disable
show ap summary

config ap dot1xuser delete

To force a specific access point to use the controller's global authentication settings, use the **config ap dot1xuser delete** command.

config ap dot1xuser delete *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Access point.

Command Default

None.

Examples

This example shows how to delete access point AP01 to use the controller's global authentication settings:

```
> config ap dot1xuser delete AP01
```

Related Commands

config ap dot1xuser
config ap dot1xuser disable
show ap summary

config ap dot1xuser disable

To disable authentication for all access points or for a specific access point, use the **config ap dot1xuser disable** command.

config ap dot1xuser disable {all | *cisco_ap*}

Syntax Description

disable	Disables authentication.
all	Specifies all access points.
<i>cisco_ap</i>	Access point.

Command Default

None.

Usage Guidelines

You can disable 802.1X authentication for a specific access point only if global 802.1X authentication is not enabled. If global 802.1X authentication is enabled, you can disable 802.1X for all access points only.

Examples

This example shows how to disable the authentication for access point *cisco_ap1*:

```
> config ap dot1xuser disable
```

Related Commands

config ap dot1xuser delete
config ap dot1xuser
show ap summary

config ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **config ap ethernet duplex** command.

config ap ethernet duplex [**auto** | **half** | **full**] **speed** [**auto** | **10** | **100** | **1000**] { **all** | *cisco_ap* }

Syntax Description

auto	(Optional) Specifies the Ethernet port duplex auto settings.
half	(Optional) Specifies the Ethernet port duplex half settings.
full	(Optional) Specifies the Ethernet port duplex full settings.
speed	Specifies the Ethernet port speed settings.
auto	(Optional) Specifies the Ethernet port speed to auto.
10	(Optional) Specifies the Ethernet port speed to 10 Mbps.
100	(Optional) Specifies the Ethernet port speed to 100 Mbps.
1000	(Optional) Specifies the Ethernet port speed to 1000 Mbps.
all	Specifies the Ethernet port setting for all connected access points.
<i>cisco_ap</i>	Cisco access point.

Command Default

None.

Examples

This example shows how to configure the Ethernet port duplex half settings as 10 Mbps for all access points:

```
> config ap ethernet duplex half speed 10 all
```

Related Commands

config ap ethernet
config ap ethernet tag
config ap
show ap summary

config ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **config ap ethernet duplex** command.

config ap ethernet duplex [**auto** | **half** | **full**] **speed** [**auto** | **10** | **100** | **1000**] { **all** | *cisco_ap*}

Syntax Description

auto	(Optional) Specifies the Ethernet port duplex auto settings.
half	(Optional) Specifies the Ethernet port duplex half settings.
full	(Optional) Specifies the Ethernet port duplex full settings.
speed	Specifies the Ethernet port speed settings.
auto	(Optional) Specifies the Ethernet port speed to auto.
10	(Optional) Specifies the Ethernet port speed to 10 Mbps.
100	(Optional) Specifies the Ethernet port speed to 100 Mbps.
1000	(Optional) Specifies the Ethernet port speed to 1000 Mbps.
all	Specifies the Ethernet port setting for all connected access points.
<i>cisco_ap</i>	Cisco access point.

Command Default

None.

Examples

This example shows how to configure the Ethernet port duplex half settings as 10 Mbps for all access points:

```
> config ap ethernet duplex half speed 10 all
```

Related Commands

config ap ethernet
config ap ethernet tag
config ap
show ap summary

config ap ethernet tag

To configure VLAN tagging of the Control and Provisioning of Wireless Access Points protocol (CAPWAP) packets, use the **config ap ethernet tag** command.

config ap ethernet tag {*id* *vlan_id* | **disable**} {*cisco_ap* | **all**}

Syntax Description		
id		Specifies the VLAN id.
<i>vlan_id</i>		ID of the trunk VLAN.
disable		Disables the VLAN tag feature. When you disable VLAN tagging, the access point untags the CAPWAP packets.
<i>cisco_ap</i>		Name of the Cisco AP.
all		Configures VLAN tagging on all the Cisco access points.

Command Default None.

Usage Guidelines

After you configure VLAN tagging, the configuration comes into effect only after the access point reboots. You cannot configure VLAN tagging on mesh access points.

If the access point is unable to route traffic or reach the controller using the specified trunk VLAN, it falls back to the untagged configuration. If the access point joins the controller using this fallback configuration, the controller sends a trap to a trap server such as the WCS, which indicates the failure of the trunk VLAN. In this scenario, the "Failover to untagged" message appears in show command output.

Examples This example shows how to configure VLAN tagging on a trunk VLAN:

```
> config ap ethernet tag 6 AP1
```

Related Commands

- config ap ethernet
- config ap ethernet duplex
- show ap ethernet tag
- show ap config general

config ap group-name

To specify a descriptive group name for a Cisco lightweight access point, use the **config ap group-name** command.

config ap group-name *groupname* *cisco_ap*

Syntax Description

<i>groupname</i>	Descriptive name for the access point group.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

Examples

This example shows how to configure a descriptive name for access point AP01:

```
> config ap group-name superusers AP01
```

Related Commands

config ap group-name
config wlan apgroup
show ap summary
show ap wlan

config ap hotspot

To configure HotSpot parameters on an access point, use the **config ap hotspot** command.

config ap hotspot venue {**type** *group_code type_code* | **name** {**add** *language_code venue_name* | **delete**}}
cisco_ap

Syntax Description

venue	Configures venue information for given AP group.

type	Configures the type of venue for given AP group.

<i>group_code</i>	Venue group information for given AP group.

The following options are available:

- 0—UNSPECIFIED
- 1—ASSEMBLY
- 2—BUSINESS
- 3—EDUCATIONAL
- 4—FACTORY-INDUSTRIAL
- 5—INSTITUTIONAL
- 6—MERCANTILE
- 7—RESIDENTIAL
- 8—STORAGE
- 9—UTILITY-MISC
- 10—VEHICULAR
- 11—OUTDOOR

type_code

Venue type information for the AP group.

For venue group 1 (ASSEMBLY), the following options are available:

- 0—UNSPECIFIED ASSEMBLY
- 1—ARENA
- 2—STADIUM
- 3—PASSENGER TERMINAL
- 4—AMPHITHEATER
- 5—AMUSEMENT PARK
- 6—PLACE OF WORSHIP
- 7—CONVENTION CENTER
- 8—LIBRARY
- 9—MUSEUM
- 10—RESTAURANT
- 11—THEATER
- 12—BAR
- 13—COFFEE SHOP
- 14—ZOO OR AQUARIUM
- 15—EMERGENCY COORDINATION CENTER

For venue group 2 (BUSINESS), the following options are available:

- 0—UNSPECIFIED BUSINESS
- 1—DOCTOR OR DENTIST OFFICE
- 2—BANK
- 3—FIRE STATION
- 4—POLICE STATION
- 6—POST OFFICE
- 7—PROFESSIONAL OFFICE
- 8—RESEARCH AND DEVELOPMENT FACILITY
- 9—ATTORNEY OFFICE

For venue group 3 (EDUCATIONAL), the following options are available:

- 0—UNSPECIFIED EDUCATIONAL
- 1—PRIMARY SCHOOL
- 2—SECONDARY SCHOOL

- 3—UNIVERSITY OR COLLEGE

For venue group 4 (FACTORY-INDUSTRIAL), the following options are available:

- 0—UNSPECIFIED FACTORY AND INDUSTRIAL
- 1—FACTORY

For venue group 5 (INSTITUTIONAL), the following options are available:

- 0—UNSPECIFIED INSTITUTIONAL
 - 1—HOSPITAL
 - 2—LONG-TERM CARE FACILITY
 - 3—ALCOHOL AND DRUG RE-HABILITATION CENTER
 - 4—GROUP HOME
 - 5 :PRISON OR JAIL
-

type_code

For venue group 6 (MERCANTILE), the following options are available:

- 0—UNSPECIFIED MERCANTILE
- 1—RETAIL STORE
- 2—GROCERY MARKET
- 3—AUTOMOTIVE SERVICE STATION
- 4—SHOPPING MALL
- 5—GAS STATION

For venue group 7 (RESIDENTIAL), the following options are available:

- 0—UNSPECIFIED RESIDENTIAL
- 1—PRIVATE RESIDENCE
- 2—HOTEL OR MOTEL
- 3—DORMITORY
- 4—BOARDING HOUSE

For venue group 8 (STORAGE), the option is:

- 0—UNSPECIFIED STORAGE

For venue group 9 (UTILITY-MISC), the option is:

- 0—UNSPECIFIED UTILITY AND MISCELLANEOUS

For venue group 10 (VEHICULAR), the following options are available:

- 0—UNSPECIFIED VEHICULAR
- 1—AUTOMOBILE OR TRUCK
- 2—AIRPLANE
- 3—BUS
- 4—FERRY
- 5—SHIP OR BOAT
- 6—TRAIN
- 7—MOTOR BIKE

For venue group 11 (OUTDOOR), the following options are available:

- 0—UNSPECIFIED OUTDOOR
- 1—MINI-MESH NETWORK
- 2—CITY PARK
- 3—REST AREA

- 4—TRAFFIC CONTROL
- 5—BUS STOP
- 6—KIOSK

name	Configures the name of venue for this access point.
<i>language_code</i>	ISO-639 encoded string defining the language used at the venue. This string is a three-character language code. For example, you can enter ENG for English.
<i>venue_name</i>	Venue name for this access point. This name is associated with the basic service set (BSS) and is used in cases where the SSID does not provide enough information about the venue. The venue name is case sensitive and can be up to 252 alphanumeric characters.
add	Adds the HotSpot venue name for this access point.
delete	Deletes the HotSpot venue name for this access point.
<i>cisco_ap</i>	Name of the Cisco access point.

Examples

This example shows how to configure the venue group as educational and venue type as university:

```
> config ap hotspot venue type 3 3
```

Related Commands

show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config wlan hotspot
config advanced hotspot
show advanced hotspot
config wlan security wpa gtk-random

config ap image predownload

To configure an image on a specified access point, use the **config ap image predownload** command.

config ap image predownload {**abort** | **primary** | **backup**} {*cisco_ap* | **all**}

Syntax Description

abort	Aborts the predownload image process.
primary	Predownloads an image to a Cisco access point from the controller's primary image.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
all	Specifies all access points to predownload an image.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Examples

This example shows how to predownload an image to an access point from the primary image:

```
> config ap image predownload primary all
```

Related Commands

config ap image swap
show ap image

config ap image swap

To swap an access point's primary and backup images, use the **config ap image swap** command.

config ap image swap {*cisco_ap* | **all**}

Syntax Description

<i>cisco_ap</i>	Name of a Cisco lightweight access point.
all	Specifies all access points to interchange the boot images.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Examples

This example shows how to swap an access point's primary and secondary images:

```
> config ap image swap all
```

Related Commands

config ap image predownload
show ap image

config ap led-state

To enable or disable the LED state for an access point or to configure the flashing of LEDs, use the **config ap led-state** command.

config ap led-state {enable | disable} {cisco_ap | all}

config ap led-state flash {seconds | indefinite | disable} {cisco_ap | dual-band}

Syntax Description

enable	Enables the access point's LED state.
disable	Disables the access point's LED state.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
flash	Configure the flashing of LEDs for an access point.
<i>seconds</i>	Duration that the LEDs have to flash. The range is from 1 to 3600 seconds.
indefinite	Configures indefinite flashing of the access point's LED.
dual-band	Configures the LED state for all dual-band access points.

Usage Guidelines

Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

LEDs on access points with dual-band radio module will flash green and blue when you execute the led state flash command.

Command Default

None.

Examples

This example shows how to enable the LED state for an access point:

```
> config ap led-state enable AP02
```

This example shows how to enable the flashing of LEDs for dual-band access points:

```
> config ap led-state flash 20 dual-band
```

Related Commands

config ap

config ap link-encryption

To enable or disable the Datagram Transport Layer Security (DTLS) data encryption for access points on the 5500 series controller, use the **config ap link-encryption** command.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

config ap link-encryption {enable | disable} {cisco_ap | all}

Syntax Description

enable	Enables the DTLS data encryption for access points.
disable	Disables the DTLS data encryption for access points.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
all	Specifies all access points.

Command Default

DTLS data encryption is enabled automatically for OfficeExtend access points but disabled by default for all other access points.

Usage Guidelines

Only Cisco 5500 Series Controllers support DTLS data encryption. This feature is not available on other controller platforms. If an access point with data encryption enabled tries to join any other controller, the access point joins the controller, but data packets are sent unencrypted.

Only Cisco 1130, 1140, 1240, and 1250 series access points support DTLS data encryption, and data-encrypted access points can join a Cisco 5500 Series Controller only if the wplus license is installed on the controller. If the wplus license is not installed, the access points cannot join the controller.

Examples

This example shows how to enable the data encryption for an access point:

```
> config ap link-encryption enable AP02
```

Related Commands

config ap
show dtls connections

config ap link-latency

To enable or disable link latency for a specific access point or for all access points currently associated to the controller, use the **config ap link-latency** command:



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

config ap link-latency {enable | disable | reset} {cisco_ap | all}

Syntax Description

enable	Enables the link latency for an access point.
disable	Disables the link latency for an access point.
reset	Resets all link latency for all access points.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
all	Specifies all access points.

Command Default

Link latency is disabled by default.

Usage Guidelines

This command enables or disables link latency only for access points that are currently joined to the controller. It does not apply to access points that join in the future.

Examples

This example shows how to enable the link latency for all access points:

```
> config ap link-latency enable all
```

Related Commands

show ap config

config ap location

To modify the descriptive location of a Cisco lightweight access point, use the **config ap location** command.

config ap location *location cisco_ap*

Syntax Description

<i>location</i>	Location name of the access point (enclosed by double quotation marks).
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

Examples

This example shows how to configure the descriptive location for access point AP1:

```
> config ap location "Building 1" AP1
```

Related Commands

show ap summary

config ap logging syslog level

To set the severity level for filtering syslog messages for a particular access point or for all access points, use the **config ap logging syslog level** command.

config ap logging syslog level *severity_level* {*cisco_ap* | **all**}

Syntax Description

severity_level

Severity levels are as follows:

- emergencies—Severity level 0
- alerts—Severity level 1
- critical—Severity level 2
- errors—Severity level 3
- warnings—Severity level 4
- notifications—Severity level 5
- informational—Severity level 6
- debugging—Severity level 7

cisco_ap

Cisco access point.

all

Specifies all access points.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Usage Guidelines

If you set a syslog level, only those messages whose severity is equal to or less than that level are sent to the access point. For example, if you set the syslog level to Warnings (severity level 4), only those messages whose severity is between 0 and 4 are sent to the access point.

Examples

This example shows how to set the severity for filtering syslog messages to 3:

```
> config ap logging syslog level 3
```

Related Commands

config logging syslog host

config logging syslog facility

show logging

config ap mgmtuser add

To configure username, password, and secret password for AP management, use the **config ap mgmtuser add** command.

config ap mgmtuser add username *AP_username* **password** *AP_password* **secret** *secret* {**all** | *cisco_ap*}

Syntax Description

username	Configures the username for AP management.
<i>AP_username</i>	Management username.
password	Configures the password for AP management.
<i>AP_password</i>	AP management password.
secret	Configures the secret password for privileged AP management.
<i>secret</i>	AP management secret password.
all	Applies configuration to every AP that does not have a specific username.
<i>cisco_ap</i>	Cisco access point.

Command Default

None.

Usage Guidelines

The following requirements are enforced on the password:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.
- No character in the password can be repeated more than three times consecutively.
- The password should not contain management username or reverse of username.
- The password should not contain words like Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting 1, |, or ! or substituting 0 for o or substituting \$ for s.

The following requirement is enforced on the secret password:

- The secret password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

Examples

This example shows how to add a username, password, and secret password for AP management:

```
> config ap mgmtuser add username acd password Arc_1234 secret Mid_45 all
```

Related Commands `config ap mgmtuser delete`

config ap mgmtuser delete

To force a specific access point to use the controller's global credentials, use the **config ap mgmtuser delete** command.

config ap mgmtuser delete *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Access point.

Command Default

None.

Examples

This example shows how to delete the credentials of an access point:

```
> config ap mgmtuser delete cisco_ap1
```

Related Commands

show ap summary

config ap mode

To change a Cisco WLC communication option for an individual Cisco lightweight access point, use the **config ap mode** command.

config ap mode {**bridge** | **flexconnect** {**submode** {**none** | **wips**} | **local** {**submode** {**none** | **wips**} | **reap** | **rogue** | **sniffer** | **se-connect** | **monitor** {**submode** {**none** | **wips**} } } *cisco_ap*

Syntax Description

bridge	Converts from a lightweight access point to a mesh access point (bridge mode).
flexconnect	Enables FlexConnect mode on an access point.
local	Converts from an indoor mesh access point (MAP or RAP) to a nonmesh lightweight access point (local mode).
reap	Enables remote edge access point mode on an access point.
rogue	Enables wired rogue detector mode on an access point.
sniffer	Enables wireless sniffer mode on an access point.
se-connect	Enables spectrum expert mode on an access point.
submode	(Optional) Configures wIPS submode on an access point.
none	Disables the wIPS on an access point.
wips	Enables the wIPS submode on an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

Local.

Usage Guidelines

The sniffer mode captures and forwards all the packets from the clients on that channel to a remote machine that runs AiroPeek or other supported packet analyzer software. It includes information on the timestamp, signal strength, packet size and so on.

Examples

This example shows how to set the controller to communicate with access point AP91 in bridge mode:

```
> config ap mode bridge AP91
```

This example shows how to set the controller to communicate with access point AP01 in local mode:

```
> config ap mode local AP01
```

This example shows how to set the controller to communicate with access point AP91 in remote office (REAP) mode:

```
> config ap mode flexconnect AP91
```

This example shows how to set the controller to communicate with access point AP91 in a wired rogue access point detector mode:

```
> config ap mode rogue AP91
```

This example shows how to set the controller to communicate with access point AP02 in wireless sniffer mode:

```
> config ap mode sniffer AP02
```

Related Commands

config 802.11 enable

config ap mode

config ap monitor-mode

show ap config

show ap monitor-mode summary

show wps wips statistics

config ap monitor-mode

To configure Cisco lightweight access point channel optimization, use the **config ap monitor-mode** command.

config ap monitor-mode {802.11b fast-channel | no-optimization | tracking-opt | wips-optimized} *cisco_ap*

Syntax Description		
802.11b fast-channel		Configures 802.11b scanning channels for a monitor-mode access point.
no-optimization		Specifies no channel scanning optimization for the access point.
tracking-opt		Enables tracking optimized channel scanning for the access point.
wips-optimized		Enables wIPS optimized channel scanning for the access point.
<i>cisco_ap</i>		Name of the Cisco lightweight access point.

Command Default None.

Examples This example shows how to configure a Cisco wireless intrusion prevention system (wIPS) monitor mode on access point AP01:

```
> config ap monitor-mode wips-optimized AP01
```

Related Commands

- config 802.11 enable
- config ap mode
- show wps wips summary
- show ap config
- show ap monitor-mode summary
- show wps wips statistics

config ap name

To modify the name of a Cisco lightweight access point, use the **config ap name** command.

config ap name *new_name old_name*

Syntax Description

<i>new_name</i>	Desired Cisco lightweight access point name.
<i>old_name</i>	Current Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to modify the name of access point AP1 to AP2:

```
> config ap name AP1 AP2
```

Related Commands

show ap config

config ap packet-dump

To configure the Packet Capture parameters on access points, use the **config ap packet-dump** command.

```
config ap packet-dump {buffer-size size | capture-time time | classifier {arp {enable | disable} | broadcast {enable | disable} | control {enable | disable} | data {enable | disable} | dot1x {enable | disable} | iapp {enable | disable} | ip {enable | disable} | management {enable | disable} | multicast {enable | disable} | tcp {enable | disable | port tcp_port } | udp {enable | disable | port udp_port } } | ftp server_ip | start mac_address cisco_ap | stop | truncate length}
```

Syntax Description

buffer-size	Configures the buffer size for Packet Capture in the access point.
<i>size</i>	Size of the buffer. The range is from 1024 to 4096 KB.
capture-time	Configures the timer value for Packet Capture.
<i>time</i>	Timer value for Packet Capture. The range is from 1 to 60 minutes.
classifier	Configures the classifier information for Packet Capture. You can specify the type of packets that needs to be captured.
arp	Captures ARP packets.
enable	Enables capture of ARP, broadcast, 802.11 control, 802.11 data, dot1x, Inter Access Point Protocol (IAPP), IP, 802.11 management, or multicast packets.
disable	Disables capture of ARP, broadcast, 802.11 control, 802.11 data, dot1x, IAPP, IP, 802.11 management, or multicast packets.
broadcast	Captures broadcast packets.
control	Captures 802.11 control packets.
data	Captures 802.11 data packets.
dot1x	Captures dot1x packets.
iapp	Captures IAPP packets.
ip	Captures IP packets.
management	Captures 802.11 management packets.
multicast	Captures multicast packets.
tcp	Captures TCP packets.
<i>tcp_port</i>	TCP port number. The range is from 1 to 65535.

udp	Captures TCP packets.
<i>udp_port</i>	UDP port number. The range is from 1 to 65535.
ftp	Configures FTP parameters for Packet Capture.
<i>server_ip</i>	FTP server IP address.
start	Starts Packet Capture from the access point.
<i>mac_address</i>	Client MAC Address for Packet Capture.
<i>cisco_ap</i>	Name of the Cisco access point.
stop	Stops Packet Capture from the access point.
truncate	Truncates the packet to the specified length during Packet Capture.
<i>length</i>	Length of the packet after truncation. The range is from 20 to 1500.

Command Default

The default buffer size is 2 MB. The default capture time is 10 mins.

Usage Guidelines

Packet Capture does not work during intercontroller roaming.

The controller does not capture packets created in the radio firmware and sent out of the access point, such as a beacon or probe response. Only packets that flow through the Radio driver in the Tx path will be captured.

Use the command **config ap packet-dump start** to start the Packet Capture from the access point. When you start Packet Capture, the controller sends a Control and Provisioning of Wireless Access Points protocol (CAPWAP) message to the access point to which the client is associated and captures packets. You must configure the FTP server and ensure that the client is associated to the access point before you start Packet Capture. If the client is not associated to the access point, you must specify the name of the access point.

Examples

This example shows how to start Packet Capture from an access point:

```
> config ap packet-dump start 00:0d:28:f4:c0:45 AP1
```

This example shows how to capture 802.11 control packets from an access point:

```
> config ap packet-dump classifier control enable
```

Related Commands

show ap packet-dump status

debug ap packet-dump

config ap port

To configure the port for a foreign access point, use the **config ap port** command.

config ap port *MAC port*

Syntax Description

<i>MAC</i>	Foreign access point MAC address.
<i>port</i>	Port number for accessing the foreign access point.

Command Default

None.

Examples

This example shows how to configure the port for a foreign access point MAC address:

```
> config ap port 12:12:12:12:12:12 20
```

Related Commands

config ap

config ap power injector

To configure the power injector state for an access point, use the **config ap power injector** command.

config ap power injector {enable | disable} {cisco_ap | all} {installed | override | switch_MAC}

Syntax Description

enable	Enables the power injector state for an access point.
disable	Disables the power injector state for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
all	Specifies all Cisco lightweight access points connected to the controller.
installed	Detects the MAC address of the current switch port that has a power injector.
override	Overrides the safety checks and assumes a power injector is always installed.
<i>switch_MAC</i>	MAC address of the switch port with an installed power injector.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Examples

This example shows how to enable the power injector state for all access points:

```
> config ap power injector enable all 12:12:12:12:12:12
```

Related Commands

config ap

config ap power pre-standard

To enable or disable the inline power Cisco pre-standard switch state for an access point, use the **config ap power pre-standard** command.

config ap power pre-standard {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the inline power Cisco pre-standard switch state for an access point.
disable	Disables the inline power Cisco pre-standard switch state for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

Disabled.

Examples

This example shows how to enable the inline power Cisco pre-standard switch state for access point AP02:

```
> config ap power pre-standard enable AP02
```

Related Commands

config ap

config ap primary-base

To set the Cisco lightweight access point primary Cisco wireless LAN controller, use the **config ap primary-base** command.

config ap primary-base *controller_name* *cisco_ap* [*controller_ip_address*]

Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional) If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
Note	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

Examples

This example shows how to set an access point primary Wireless LAN controller:

```
> config ap primary-base SW_1 AP2
```

Related Commands

show sysinfo
config sysname
config ap secondary-base
config ap tertiary-base

config ap priority

To assign a priority designation to an access point that allows it to reauthenticate after a controller failure by priority rather than on a first-come-until-full basis, use the **config ap priority** command.

config ap priority {1 | 2 | 3 | 4} *cisco_ap*

Syntax Description

1	Specifies low priority.
2	Specifies medium priority.
3	Specifies high priority.
4	Specifies the highest (critical) priority.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

1 - Low priority.

Usage Guidelines

In a failover situation, if the backup controller does not have enough ports to allow all the access points in the affected area to reauthenticate, it gives priority to higher-priority access points over lower-priority ones, even if it means replacing lower-priority access points.

Examples

This example shows how to assign a priority designation to access point AP02 that allows it to reauthenticate after a controller failure by assigning a reauthentication priority 3:

```
> config ap priority 3 AP02
```

Related Commands

config network ap-priority
show ap summary
show network summary

config ap reporting-period

To reset a Cisco lightweight access point, use the **config ap reporting-period** command.

config ap reporting-period *period*

Syntax Description

<i>period</i>	Time period in seconds between 10 and 120.

Command Default

None.

Examples

This example shows how to reset an access point reporting period to 120 seconds:

```
> config ap reporting-period 120
```

Related Commands

show ap config 802.11a

show ap config 802.11ab

config ap reset

To reset a Cisco lightweight access point, use the **config ap reset** command.

config ap reset *cisco_ap*

Syntax Description	

<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default	

None.

Examples	

This example shows how to reset an access point:

```
> config ap reset AP2
```

Related Commands	

show ap config

config ap retransmit interval

To configure the access point control packet retransmission interval, use the **config ap retransmit interval** command.

config ap retransmit interval *seconds* {**all** | *cisco_ap*}

Syntax Description

<i>seconds</i>	AP control packet retransmission timeout between 2 and 5 seconds.
all	Specifies all access points.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure the retransmission interval for all access points globally:

```
> config ap retransmit interval 4 all
```

Related Commands

show ap config

config ap retransmit count

To configure the access point control packet retransmission count, use the **config ap retransmit count** command.

config ap retransmit count *count* {**all** | *cisco_ap*}

Syntax Description

<i>count</i>	Number of times control packet will be retransmitted. The range is from 3 to 8.
all	Specifies all access points.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure the retransmission retry count for a specific access point:

```
> config ap retransmit count 6 cisco_ap
```

Related Commands

show ap config

config ap role

To specify the role of an access point in a mesh network, use the **config ap role** command.

config ap role {**rootAP** | **meshAP**} *cisco_ap*

Syntax Description

rootAP	Designates the mesh access point as a root access point (RAP).
meshAP	Designates the mesh access point as a mesh access point (MAP).
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

meshAP.

Usage Guidelines

Use the **meshAP** keyword if the access point has a wireless connection to the controller, or use the **rootAP** keyword if the access point has a wired connection to the controller. Changing the AP's role will cause the AP to reboot.

Examples

This example shows how to designate mesh access point AP02 as a root access point:

```
> config ap role rootAP AP02
Changing the AP's role will cause the AP to reboot.
Are you sure you want to continue? (y/n)
```

Related Commands

show ap config

config ap rst-button

To configure the Reset button for an access point, use the **config ap rst-button** command.

```
config ap rst-button {enable | disable} cisco_ap
```

Syntax Description

enable	Enables the Reset button for an access point.
disable	Disables the Reset button for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to configure the Reset button for access point AP03:

```
> config ap rst-button enable AP03
```

Related Commands

config ap

config ap secondary-base

To set the Cisco lightweight access point secondary Cisco wireless LAN controller, use the **config ap secondary-base** command.

config ap secondary-base *controller_name* *cisco_ap* [*controller_ip_address*]

Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional). If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
Note	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

Examples

This example shows how to set an access point secondary Cisco wireless controller:

```
> config ap secondary-base SW_1 AP2
```

Related Commands

show sysinfo
config sysname
config ap primary-base
config ap tertiary-base

config ap sniff

To enable or disable sniffing on an access point, use the **config ap sniff** command.

config ap sniff {802.11a | 802.11b} {enable *channel server_ip* | disable} *cisco_ap*

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b network.
enable	Enables sniffing on an access point.
<i>channel</i>	Channel to be sniffed.
<i>server_ip</i>	IP address of the remote machine running Omnippeek, Airopeek, AirMagnet, or Wireshark software.
disable	Disables sniffing on an access point.
<i>cisco_ap</i>	Access point configured as the sniffer.

Command Default

Channel 36.

Usage Guidelines

When the sniffer feature is enabled on an access point, it starts sniffing the signal on the given channel. It captures and forwards all the packets to the remote computer that runs Omnippeek, Airopeek, AirMagnet, or Wireshark software. It includes information on the timestamp, signal strength, packet size and so on.

Before an access point can act as a sniffer, a remote computer that runs one of the listed packet analyzers must be set up so that it can receive packets sent by the access point. After the Airopeek installation, copy the following .dll files to the location where airopeek is installed:

- socket.dll file to the Plug-ins folder (for example, C:\Program Files\WildPackets\AiroPeek\Plugins)
- socketres.dll file to the PluginRes folder (for example, C:\Program Files\WildPackets\AiroPeek\1033\PluginRes)

Examples

This example shows how to enable the sniffing on the 802.11a an access point from the primary Cisco WLC:

```
> config ap sniff 80211a enable 23 11.22.44.55 AP01
```

Related Commands

show ap config
config ap sniff 802.11b

config ap ssh

To enable Secure Shell (SSH) connectivity on an access point, use the **config ap ssh** command.

config ap ssh {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the SSH connectivity on an access point.
disable	Disables the SSH connectivity on an access point.
<i>cisco_ap</i>	Cisco access point name.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operation and in the event of a hardware reset.

Examples

This example shows how to enable SSH connectivity on access point Cisco_ap2:

```
> config ap ssh enable cisco_ap2
```

Related Commands

config ap
show ap stats
config network ssh

config ap static-ip

To configure Cisco lightweight access point static IP address settings, use the **config ap static-ip** command.

```
config ap static-ip {enable cisco_ap ip_address net_mask gateway | disable cisco_ap add {domain {cisco_ap | all} domain_name} | {nameserver {cisco_ap | all} dns_ip_address} | delete {domain | nameserver} {cisco_ap | all}}
```

Syntax Description

enable	Enables the Cisco lightweight access point static IP address.
disable	Disables the Cisco lightweight access point static IP address. The access point uses DHCP to get the IP address.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>ip_address</i>	Cisco lightweight access point IP address
<i>net_mask</i>	Cisco lightweight access point network mask.
<i>gateway</i>	IP address of the Cisco lightweight access point gateway.
add	Adds a domain or DNS server.
domain	Specifies the domain to which a specific access point or all access points belong.
all	Specifies all access points.
<i>domain_name</i>	Specifies a domain name.
nameserver	Specifies a DNS server so that a specific access point or all access points can discover the controller using DNS resolution.
<i>dns_ip_address</i>	DNS server IP address.
delete	Deletes a domain or DNS server.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Usage Guidelines

An access point cannot discover the controller using Domain Name System (DNS) resolution if a static IP address is configured for the access point, unless you specify a DNS server and the domain to which the access point belongs.

After you enter the IP, netmask, and gateway addresses, save your configuration to reboot the access point. After the access point rejoins the controller, you can enter the domain and DNS server information.

Examples

This example shows how to configure an access point static IP address:

```
> config ap static-ip enable AP2 1.1.1.1 255.255.255.0 209.165.200.254
```

Related Commands

show sysinfo
config sysname
config ap secondary-base
config ap primary-base

config ap stats-timer

To set the time in seconds that the Cisco lightweight access point sends its DOT11 statistics to the Cisco wireless LAN controller, use the **config ap stats-timer** command.

config ap stats-timer *period cisco_ap*

Syntax Description	<i>period</i>	Time in seconds from 0 to 65535. A zero value disables the timer.
	<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default 0 (disabled).

Usage Guidelines A value of 0 (zero) means that the Cisco lightweight access point does not send any DOT11 statistics. The acceptable range for the timer is from 0 to 65535 seconds, and the Cisco lightweight access point must be disabled to set this value.

Examples This example shows how to set the stats timer to 600 seconds for access point AP2:

```
> config ap stats-timer 600 AP2
```

Related Commands **config ap disable**

config ap syslog host global

To configure a global syslog server for all access points that join the controller, use the **config ap syslog host global** command.

config ap syslog host global *syslog_server_IP_address*

Syntax Description

<i>syslog_server_IP_address</i>	IP address of the syslog server.

Command Default

255.255.255.255.

Usage Guidelines

By default, the global syslog server IP address for all access points is 255.255.255.255. Make sure that the access points can reach the subnet on which the syslog server resides before configuring the syslog server on the controller. If the access points cannot reach this subnet, the access points are unable to send out syslog messages.

Examples

This example shows how to configure a global syslog server for all access points:

```
> config ap syslog host global 255.255.255.255
```

Related Commands

config ap syslog host specific
show ap
config global
show ap
config general

config ap syslog host specific

To configure a syslog server for a specific access point, use the **config ap syslog host specific** command.

config ap syslog host specific *cisco_ap syslog_server_IP_address*

Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point.
<i>syslog_server_IP_address</i>	IP address of the syslog server.

Command Default

0.0.0.0.

Usage Guidelines

By default, the syslog server IP address for each access point is 0.0.0.0, indicating that it is not yet set. When the default value is used, the global access point syslog server IP address is pushed to the access point.

Examples

This example shows how to configure a syslog server:

```
> config ap syslog host specific 0.0.0.0
```

Related Commands

config ap syslog host global
show ap config global
show ap config general

config ap tcp-adjust-mss

To enable or disable the TCP maximum segment size (MSS) on a particular access point or on all access points, use the **config ap tcp-adjust-mss** command.

config ap tcp-adjust-mss {**enable** | **disable**} {*cisco_ap* | **all**} *size*

Syntax Description

enable	Enables the TCP maximum segment size on an access point.
disable	Disables the TCP maximum segment size on an access point.
<i>cisco_ap</i>	Cisco access point name.
all	Specifies all access points.
<i>size</i>	Maximum segment size, from 536 to 1363 bytes.



Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

Command Default

None.

Usage Guidelines

When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the CAPWAP tunnel, the access point changes the MSS to the new configured value.

Examples

This example shows how to enable the TCP MSS on access point Cisco_ap1 with a segment size of 1200 bytes:

```
> config ap tcp-adjust-mss enable cisco_ap1 1200
```

Related Commands

show ap tcp-mss-adjust

config ap telnet

To enable Telnet connectivity on an access point, use the **config ap telnet** command.

config ap telnet {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the Telnet connectivity on an access point.
disable	Disables the Telnet connectivity on an access point.
<i>cisco_ap</i>	Cisco access point name.

Command Default

None.

Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operation and in the event of a hardware reset.

Examples

This example shows how to enable Telnet connectivity on access point cisco_ap1:

```
> config ap telnet enable cisco_ap1
```

This example shows how to disable Telnet connectivity on access point cisco_ap1:

```
> config ap telnet disable cisco_ap1
```

Related Commands

config ap
config network telnet
show ap config

config ap tertiary-base

To set the Cisco lightweight access point tertiary Cisco wireless LAN controller, use the **config ap tertiary-base** command.

config ap tertiary-base *controller_name* *cisco_ap* [*controller_ip_address*]

Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional) If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
Note	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

Command Default

None.

Usage Guidelines

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

Examples

This example shows how to set the access point tertiary wireless LAN controller:

```
> config ap tertiary-base SW_1 AP02
```

Related Commands

show sysinfo
config sysname
config ap secondary-base
config ap primary-base

config ap tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **config ap tftp-downgrade** command.

config ap tftp-downgrade {*tftp_ip_address* | *image_filename* | *ap_name*}

Syntax Description

<i>tftp_ip_address</i>	IP address of the TFTP server.
<i>image_filename</i>	Filename of the access point image file on the TFTP server.
<i>ap_name</i>	Access point name.

Command Default

None.

Examples

This example shows how to configure the settings for downgrading access point ap1240_102301:

```
> config ap tftp-downgrade 209.165.200.224 1238.tar ap1240_102301
```

Related Commands

show version
show running-config

config ap username

To assign a username and password to access either a specific access point or all access points, use the **config ap username** command.

config ap username *user_id* **password** *passwd* [**all** | *ap_name*]

Syntax Description

<i>user_id</i>	Administrator username.
<i>passwd</i>	Administrator password.
all	(Optional) Specifies all access points.
<i>ap_name</i>	Name of a specific access point.

Command Default

None.

Examples

This example shows how to assign a username and password to a specific access point:

```
> config ap username jack password blue la204
```

This example shows how to assign the same username and password to all access points:

```
> config ap username jack password blue all
```

config ap venue

To configure the venue information for 802.11u network on an access point, use the **config ap venue** command.

config ap venue {*add**venue_name venue-group venue-type lang-code cisco-ap* | *delete*}

Syntax Description

add	Adds venue information.
<i>venue_name</i>	Venue name.
<i>venue_group</i>	Venue group category. See the table below for details on venue group mappings.
<i>venue_type</i>	Venue type. This value depends on the venue-group specified. See the table below for venue group mappings.
<i>lang_code</i>	Language used. An ISO-14962-1997 encoded string that defines the language. This string is a three character language code. Enter the first three letters of the language in English (for example, eng for English).
<i>cisco_ap</i>	Name of the access point.
deletes	Deletes venue information.

Command Default

None.

Examples

The command shows how to set the venue details for an access point named cisco-ap1:

```
> config ap venue add test 11 34 eng cisco-ap1
```

This table lists the different venue types for each venue group.

Table 8: Venue Group Mapping

Venue Group Name	Value	Venue Type for Group
UNSPECIFIED	0	

Venue Group Name	Value	Venue Type for Group
ASSEMBLY	1	• 0—UNSPECIFIED ASSEMBLY • 1—ARENA • 2—STADIUM • 3—PASSENGER TERMINAL (E.G., AIRPORT, BUS, FERRY, TRAIN STATION) • 4—AMPHITHEATER • 5—AMUSEMENT PARK • 6—PLACE OF WORSHIP • 7—CONVENTION CENTER • 8—LIBRARY • 9—MUSEUM • 10—RESTAURANT • 11—THEATER • 12—BAR • 13—COFFEE SHOP • 14—ZOO OR AQUARIUM • 15—EMERGENCY COORDINATION CENTER
BUSINESS	2	• 0—UNSPECIFIED BUSINESS • 1—DOCTOR OR DENTIST OFFICE • 2—BANK • 3—FIRE STATION • 4—POLICE STATION • 6—POST OFFICE • 7—PROFESSIONAL OFFICE • 8—RESEARCH AND DEVELOPMENT FACILITY • 9—ATTORNEY OFFICE

Venue Group Name	Value	Venue Type for Group
EDUCATIONAL	3	• 0—UNSPECIFIED EDUCATIONAL • 1—SCHOOL, PRIMARY • 2—SCHOOL, SECONDARY • 3—UNIVERSITY OR COLLEGE
FACTORY-INDUSTRIAL	4	• 0—UNSPECIFIED FACTORY AND INDUSTRIAL • 1—FACTORY
INSTITUTIONAL	5	• 0—UNSPECIFIED INSTITUTIONAL • 1—HOSPITAL • 2—LONG-TERM CARE FACILITY (E.G., NURSING HOME, HOSPICE, ETC.) • 3—ALCOHOL AND DRUG RE-HABILITATION CENTER • 4—GROUP HOME • 5—PRISON OR JAIL
MERCANTILE	6	• 0—UNSPECIFIED MERCANTILE • 1—RETAIL STORE • 2—GROCERY MARKET • 3—AUTOMOTIVE SERVICE STATION • 4—SHOPPING MALL • 5—GAS STATION
RESIDENTIAL	7	• 0—UNSPECIFIED RESIDENTIAL • 1—PRIVATE RESIDENCE • 2—HOTEL OR MOTEL • 3—DORMITORY • 4—BOARDING HOUSE

Venue Group Name	Value	Venue Type for Group
STORAGE	8	UNSPECIFIED STORAGE
UTILITY-MISC	9	0—UNSPECIFIED UTILITY AND MISCELLANEOUS
VEHICULAR	10	• 0—UNSPECIFIED VEHICULAR • 1—AUTOMOBILE OR TRUCK • 2—AIRPLANE • 3—BUS • 4—FERRY • 5—SHIP OR BOAT • 6—TRAIN • 7—MOTOR BIKE
OUTDOOR	11	• 0—UNSPECIFIED OUTDOOR • 1—MUNI-MESH NETWORK • 2—CITY PARK • 3—REST AREA • 4—TRAFFIC CONTROL • 5—BUS STOP • 6—KIOSK

Related Commands

config wlan mobile-concierge dot11u
config wlan mobile-concierge hotspot2
config wlan mobile-concierge msap

config ap wlan

To enable or disable wireless LAN override for a Cisco lightweight access point radio, use the **config ap wlan** command.

config ap wlan {enable | disable} {802.11a | 802.11b} wlan_id cisco_ap

Syntax Description

enable	Enables the wireless LAN override on an access point.
disable	Disables the wireless LAN override on an access point.
802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b network.
<i>wlan_id</i>	Cisco wireless LAN controller ID assigned to a wireless LAN.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to enable wireless LAN override on the AP03 802.11a radio:

```
> config ap wlan 802.11a AP03
```

Related Commands

show ap wlan

config country

To configure the controller's country code, use the **config country** command.

config country *country_code*

Syntax Description

<i>country_code</i>	Two-letter or three-letter country code.

Command Default

us (country code of the United States of America).

Usage Guidelines

Cisco wireless LAN controllers must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.

You can use the **show country** command to display a list of supported countries.

Examples

This example shows how to configure the controller's country code to DE:

```
> config country DE
```

Related Commands

show country

config ipv6 ra-guard

To configure the filter for Router Advertisement (RA) packets that originate from a client on an AP, use the **config ipv6 ra-guard** command.

config ipv6 ra-guard ap {enable | disable}

Syntax Description	enable	Enables RA guard on an AP.
	disable	Disables RA guard on an AP.

Command Default None.

Examples This example shows how to enable IPv6 RA guard:

```
> config ipv6 ra-guard
```

Related Commands **show ipv6 ra-guard**

config known ap

To configure a known Cisco lightweight access point, use the **config known ap** command.

config known ap {add | alert | delete} *MAC*

Syntax Description

add	Adds a new known access point entry.
alert	Generates a trap upon detection of the access point.
delete	Deletes an existing known access point entry.
<i>MAC</i>	MAC address of the known Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to add a new access point entry ac:10:02:72:2f:bf on a known access point:

```
> config known ap add ac:10:02:72:2f:bf 12
```

Related Commands

config ap

config network allow-old-bridge-aps

To configure an old bridge access point's ability to associate with a switch, use the **config network allow-old-bridge-aps** command.

config network allow-old-bridge-aps {enable | disable}

Syntax Description

enable	Enables the switch association.
disable	Disables the switch association.

Command Default

Enabled.

Examples

This example shows how to configure an old bridge access point to associate with the switch:

```
> config network allow-old-bridge-aps enable
```

Related Commands

show network summary

config network ap-discovery

To enable or disable NAT IP in an AP discovery response, use the **config network ap-discovery** command.

config network ap-discovery nat-ip-only {enable | disable}

Syntax Description

enable	Enables use of NAT IP only in discovery response. This is the default.
disable	Enables use of both NAT IP and non NAT IP in discovery response.

Command Default

Enabled.

Usage Guidelines

If the **config interface nat-address management** command is set, this command controls which address(es) are sent in the CAPWAP discovery responses.

If all APs are on the outside of the NAT gateway of the controller, enter the **config network ap-discovery nat-ip-only enable** command, and only the management NAT address is sent.

If the controller has both APs on the outside and the inside of its NAT gateway, enter the **config network ap-discovery nat-ip-only disable** command, and both the management NAT address and the management inside address are sent. Ensure that you have entered the **config ap link-latency disable all** command to avoid stranding APs.

Examples

This example shows how to enable NAT IP in an AP discovery response:

```
> config network ap-discovery nat-ip-only enable
```


config network ap-fallback

To configure Cisco lightweight access point fallback, use the **config network ap-fallback** command.

config network ap-fallback {enable | disable}

Syntax Description

enable	Enables the Cisco lightweight access point fallback.
disable	Disables the Cisco lightweight access point fallback.

Command Default

Enabled.

Examples

This example shows how to enable the Cisco lightweight access point fallback:

```
> config network ap-fallback enable
```

Related Commands

show network summary

config network ap-priority

To enable or disable the option to prioritize lightweight access points so that after a controller failure they reauthenticate by priority rather than on a first-come-until-full basis, use the **config network ap-priority** command.

config network ap-priority {enable | disable}

Syntax Description

enable	Enables the lightweight access point priority reauthentication.
disable	Disables the lightweight access point priority reauthentication.

Command Default

Disabled.

Examples

This example shows how to enable the lightweight access point priority reauthorization:

```
> config network ap-priority enable
```

Related Commands

config ap priority
show ap summary
show network summary

config network apple-talk

To configure AppleTalk bridging, use the **config network apple-talk** command.

config network apple-talk {enable | disable}

Syntax Description

enable	Enables the AppleTalk bridging.
disable	Disables the AppleTalk bridging.

Command Default

None.

Examples

This example shows how to configure AppleTalk bridging:

```
> config network apple-talk enable
```

Related Commands

show network summary

config network bridging-shared-secret

To configure the bridging shared secret, use the **config network bridging-shared-secret** command.

config network bridging-shared-secret *shared_secret*

Syntax Description

<i>shared_secret</i>	Bridging shared secret string. The string can contain up to 10 bytes.

Command Default

Enabled.

Usage Guidelines

This command creates a secret that encrypts backhaul user data for the mesh access points that connect to the switch.

The zero-touch configuration must be enabled for this command to work.

Examples

This example shows how to configure the bridging shared secret string “shhh1”:

```
> config network bridging-shared-secret shhh1
```

Related Commands

show network summary

config network master-base

To enable or disable the Cisco wireless LAN controller as an access point default master, use the **config network master-base** command.

config network master-base {enable | disable}

Syntax Description

enable	Enables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.
disable	Disables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.

Command Default

None.

Usage Guidelines

This setting is only used upon network installation and should be disabled after the initial network configuration. Because the Master Cisco wireless LAN controller is normally not used in a deployed network, the Master Cisco wireless LAN controller setting can be saved from 6.0.199.0 or later releases.

Examples

This example shows how to enable the Cisco wireless LAN controller as a default master:

```
> config network master-base enable
```

config network oeap-600 dual-rlan-ports

To configure the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4, use the **config network oeap-600 dual-rlan-ports** command.

config network oeap-600 dual-rlan-ports {enable | disable}

Syntax Description

enable	Enables Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4.
disable	Resets the Ethernet port 3 Cisco OfficeExtend 600 Series access points to function as a local LAN port.

Command Default

Disabled.

Examples

This example shows how to enable the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port:

```
> config network oeap-600 dual-rlan-ports enable
```

Related Commands

show network summary

config network oeap-600 local-network

To configure access to the local network for the Cisco 600 Series OfficeExtend access points, use the **config network oeap-600 local-network** command.

config network oeap-600 local-network {enable | disable}

Syntax Description	enable	Enables access to the local network for the Cisco 600 Series OfficeExtend access points.
	disable	Disables access to the local network for the Cisco 600 Series OfficeExtend access points.

Command Default Disabled.

Examples This example shows how to enable access to the local network for the Cisco 600 Series OfficeExtend access points:

```
> config network oeap-600 local-network enable
```

Related Commands **show network summary**

config network otap-mode

To enable or disable over-the-air provisioning (OTAP) of Cisco lightweight access points, use the **config network otap-mode** command.

config network otap-mode {enable | disable}

Syntax Description

enable	Enables the OTAP provisioning.
disable	Disables the OTAP provisioning.

Command Default

Enabled.

Examples

This example shows how to disable the OTAP provisioning:

```
> config network otap-mode disable
```

Related Commands

show network summary

config network zero-config

To configure bridge access point ZeroConfig support, use the **config network zero-config** command.

config network zero-config {enable | disable}

Syntax Description

enable	Enables the bridge access point ZeroConfig support.
disable	Disables the bridge access point ZeroConfig support.

Command Default

Enabled.

Examples

This example shows how to enable the bridge access point ZeroConfig support:

```
> config network zero-config enable
```

Related Commands

show network summary

config redundancy interface address peer-service-port

To configure the service port IP and netmask of the peer or standby controller, use the **config redundancy interface address peer-service-port** command.

config redundancy interface address peer-service-port *ip_address netmask*

Syntax Description

<i>ip_address</i>	IP address of the peer service port.
<i>netmask</i>	Netmask of the peer service port.

Command Default

None.

Usage Guidelines

You can configure this command only from the Active controller. For the HA feature, the service port configurations are made per controller. You will lose these configurations if you change the mode from HA to non-HA and vice-versa.

Examples

This example shows how to configure the service port IP and netmask of the peer or standby controller:

```
> config redundancy interface address peer-service-port 11.22.44.55
```

Related Commands

config redundancy mode
config redundancy peer-route
config redundancy mobilitymac
config redundancy unit
config redundancy timer

config redundancy mobilitymac

To configure the HA mobility MAC address to be used as an identifier, use the **config redundancy mobilitymac** command.

config redundancy mobilitymac *mac_address*

Syntax Description	
<i>mac_address</i>	MAC address that is an identifier for the active and standby controller pair.

Command Default None.

Examples This example shows how to configure the HA mobility MAC address:

```
> config redundancy mobilitymac ff:ff:ff:ff:ff:ff
```

Related Commands

- config redundancy interface address peer-service-port
- config redundancy peer-route
- config redundancy unit
- config redundancy timer
- debug rfac
- debug rmgr
- debug rsyncmgr
- show redundancy mobilitymac
- show redundancy summary
- show redundancy peer-route
- show redundancy statistics
- show redundancy timers

config redundancy mode

To enable or disable redundancy or High Availability (HA), use the **config redundancy mode** command.

config redundancy mode {sso | nonedisable}

Syntax Description

sso	Enables a stateful switch over (SSO) or hot standby redundancy mode.
nonedisable	Disables redundancy mode.

Command Default

None.

Usage Guidelines

You must configure local and peer redundancy management IP addresses before you configure redundancy.

Examples

This example shows how to enable redundancy:

```
> config redundancy mode sso
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr

config redundancy peer-route

To configure the route configurations of the peer or standby controller, use the **config redundancy peer-route** command.

config redundancy peer-route {**add** | **delete**} *network_ip_address netmask gateway*

Syntax Description

add	Adds a network route.
delete	Deletes a network route specific to standby controller.
<i>network_ip_address</i>	Network IP address.
<i>netmask</i>	Subnet mask of the network.
<i>gateway</i>	IP address of the gateway for the route network.

Command Default

None.

Usage Guidelines

You can configure this command only from the Active controller. For the HA feature, the service port configurations are made per controller. You will loose these configurations if you change the mode from HA to non-HA and vice-versa.

Examples

This example shows how to configure route configurations of a peer or standby controller.

```
> config redundancy peer-route add 10.1.1.0 255.255.255.0 10.1.1.1
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy mode
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr

config redundancy timer keep-alive-timer

To configure the keep-alive timeout value, use the **config redundancy timer keep-alive-timer** command.

config redundancy timer keep-alive-timer *milliseconds*

Syntax Description

<i>milliseconds</i>	Keep-alive timeout value in milliseconds. The range is from 100 to 400 milliseconds.

Command Default

100 milliseconds.

Examples

This example shows how to configure the keep-alive timeout value:

```
> config redundancy timer keep-alive-timer 200
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer peer-search-timer
show redundancy timers
show redundancy summary
debug rmgr
debug rsyncmgr

config redundancy timer peer-search-timer

To configure the peer search timer, use the **config redundancy timer peer-search-timer** command.

config redundancy timer peer-search-timer *seconds*

Syntax Description	<i>seconds</i> Value of the peer search timer in seconds. The range is from 60 to 180 secs.
Command Default	120 seconds.
Usage Guidelines	You can use this command to configure the boot up role negotiation timeout value in seconds.
Examples	This example shows how to configure the redundancy peer search timer: <pre>> config redundancy timer peer-search-timer 100</pre>
Related Commands	config redundancy mobilitymac config redundancy interface address peer-service-port config redundancy peer-route config redundancy unit config redundancy timer keep-alive-timer show redundancy peer-route show redundancy summary debug rmgr debug rsyncmgr

config redundancy unit

To configure a controller as a primary or secondary controller, use the **config redundancy unit** command.

config redundancy unit {primary | secondary}

Syntax Description

primary	Configures the controller as the primary controller.
secondary	Configures the controller as the secondary controller.

Command Default

Primary.

Usage Guidelines

When you configure a controller as the secondary controller, it becomes the HA Stakable Unit (SKU) without any valid AP licenses.

Examples

This example shows how to configure a controller as the primary controller:

```
> config redundancy unit primary
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr

redundancy force-switchover

To trigger a manual switch over on the active Cisco WLC, use the **redundancy force-switchover** command.

redundancy force-switchover

Syntax Description This command has no arguments or keywords.

Command Default None.

Usage Guidelines When a manual switchover occurs, the active Cisco WLC reboots and the standby Cisco WLC takes over the network. A stateful switchover of access points (AP SSO) is supported. AP SSO ensures that the AP sessions are maintained after the standby Cisco WLC takes over and the APs switch over to the standby Cisco WLC. The clients on the active Cisco WLC deauthenticate and join the new active Cisco WLC.

Examples This example shows how to trigger a forceful switchover on the Cisco WLC:

```
> redundancy force-switchover
```

Related Commands

- config redundancy mobilitymac
- config redundancy interface address peer-service-port
- config redundancy peer-route
- config redundancy unit
- config redundancy timer
- show redundancy peer-route
- show redundancy summary
- debug rmgr
- debug rsyncmgr

config redundancy management-gateway-failover

To configure the failover of the management gateway, use the **config redundancy management-gateway-failover** command.

config redundancy management-gateway-failover {enable | disable}

Syntax Description

enable	Enables failover of the management gateway.
disable	Disables failover of the management gateway.

Command Default

None.

Usage Guidelines

Failover is supported only if redundancy management is mapped to the redundancy port.

Examples

This example shows how to enable failover of the management gateway:

```
> config redundancy management-gateway-failover enable
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr

config redundancy link-encryption

To encrypt the redundancy link, use the **config redundancy link-encryption** command.

config redundancy link-encryption {enable | disable}

Syntax Description

enable	Enables encryption of the redundancy link.
disable	Disables encryption of the redundancy link.

Command Default

None.

Usage Guidelines

Encryption of the redundancy link is not supported if the redundancy port is used as the redundancy management interface.

Examples

This example shows how to encrypt the redundancy link:

```
> config redundancy link-encryption enable
```

Related Commands

```
config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr
```

config slot

To configure various slot parameters, use the **config slot** command.

config slot *slot_id* {**enable** | **disable** | **channel ap** | **chan_width** | **txpower ap** | **antenna extAntGain** | **antenna_gain** | **rts**} *cisco_ap*

Syntax Description

<i>slot_id</i>	Slot downlink radio to which the channel is assigned.
enable	Enables the slot.
disable	Disables the slot.
channel	Configures the channel for the slot.
ap	Configures one 802.11a Cisco access point.
chan_width	Configures channel width for the slot.
txpower	Configures Tx power for the slot.
antenna	Configures the 802.11a antenna.
extAntGain	Configures the 802.11a external antenna gain.
<i>antenna_gain</i>	External antenna gain value in .5 dBi units (such as 2.5 dBi = 5).
rts	Configures RTS/CTS for an access point.
<i>cisco_ap</i>	Name of the Cisco access point on which the channel is configured.

Command Default

None.

Examples

This example shows how to enable slot 3 for the access point abc:

```
> config slot 3 enable abc
```

This example shows how to configure RTS for the access point abc:

```
> config slot 2 rts abc
```

Related Commands

show mesh ap
show mesh stats

config wgb vlan

To configure the Workgroup Bridge (WGB) VLAN client support, use the **config wgb vlan** command.

config wgb vlan {enable | disable}

Syntax Description

enable	Enables wired clients behind a WGB to connect to an anchor controller in a Data Management Zone (DMZ).
disable	Disables wired clients behind a WGB from connecting to an anchor controller in a DMZ.

Command Default

None.

Examples

This example shows how to enable WGB VLAN client support:

```
> config wgb vlan enable
```

clear Commands

This section lists the **clear** commands to clear existing configurations, log files, and other functions for access points .

clear ap-config

To clear (reset to the default values) a lightweight access point's configuration settings, use the **clear ap-config** command.

clear ap-config *ap_name*

Syntax Description

<i>ap_name</i>	Access point name.

Command Default

None.

Usage Guidelines

Entering this command does not clear the static IP address of the access point.

Examples

This example shows how to clear the access point's configuration settings for the access point named ap1240_322115:

```
> clear ap-config ap1240_322115
Clear ap-config will clear ap config and reboot the AP. Are you sure you want continue?
(y/n)
```

Related Commands

show ap config

clear ap-eventlog

To delete the existing event log and create an empty event log file for a specific access point or for all access points joined to the controller, use the **clear ap-eventlog** command.

clear ap-eventlog {*specific ap_name* | **all**}

Syntax Description

specific	Specifies a specific access point log file.
<i>ap_name</i>	Name of the access point for which the event log file will be emptied.
all	Deletes the event log for all access points joined to the controller.

Command Default

None.

Examples

This example shows how to delete the event log for all access points:

```
> clear ap-eventlog all
This will clear event log contents for all APs. Do you want continue? (y/n) :y
Any AP event log contents have been successfully cleared.
```

Related Commands

show ap eventlog

clear ap join stats

To clear the join statistics for all access points or for a specific access point, use the **clear ap join stats** command.

clear ap join stats {all | *ap_mac*}

Syntax Description

all	Specifies all access points.
<i>ap_mac</i>	Access point MAC address.

Command Default

None.

Examples

This example shows how to clear the join statistics of all the access points:

```
> clear ap join stats all
```

Related Commands

show ap config

clear ap tsm

To clear the Traffic Stream Metrics (TSM) statistics of clients associated to an access point, use the **clear ap tsm** command.

clear ap tsm {802.11a | 802.11b} *cisco_ap* **all**

Syntax Description	802.11a	Clears 802.11a TSM statistics of clients associated to an access point.
	802.11b	Clears 802.11b TSM statistics of clients associated to an access point.
	<i>cisco_ap</i>	Cisco lightweight access point.
	all	Clears TSM statistics of clients associated to the access point.

Command Default None.

Examples This example shows how to clear 802.11a TSM statistics for all clients of an access point:

```
> clear ap tsm 802.11a AP3600_1 all
```

clear lwapp private-config

To clear (reset to default values) an access point's current Lightweight Access Point Protocol (LWAPP) private configuration, which contains static IP addressing and controller IP address configurations, use the **clear lwapp private-config** command.

clear lwapp private-config

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Usage Guidelines

Enter the command on the access point console port.

Prior to changing the FlexConnect configuration on an access point using the access point's console port, the access point must be in standalone mode (not connected to a Cisco WLC) and you must remove the current LWAPP private configuration by using the **clear lwapp private-config** command.



Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

Examples

This example shows how to clear an access point's current LWAPP private configuration:

```
AP# clear lwapp private-config
removing the reap config file flash:/lwapp_reap.cfg
```

Related Commands

debug capwap
debug capwap reap
debug lwapp console cli
show capwap reap association
show capwap reap status

debug Commands

This section lists the **debug** commands to manage debugging of access points managed by the controller.



Caution

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug ap

To configure the remote debugging of Cisco lightweight access points or to remotely execute a command on a lightweight access point, use the **debug ap** command.

debug ap {**enable** | **disable** | **command** *cmd*} *cisco_ap*

Syntax Description

enable	Enables the debugging on a lightweight access point. Note The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
disable	Disables the debugging on a lightweight access point. Note The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
command	Specifies that a CLI command is to be executed on the access point.
<i>cmd</i>	Command to be executed. Note The command to be executed must be enclosed in double quotes, such as debug ap command "led flash 30" AP03 . The output of the command displays only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

Command Default

Disabled.

Examples

This example shows how to enable the remote debugging on access point AP01:

```
> debug ap enable AP01
```

This example shows how to execute the **config ap location** command on access point AP02:

```
> debug ap command "config ap location "Building 1" AP02"
```

This example shows how to execute the flash LED command on access point AP03:

```
> debug ap command "led flash 30" AP03
```

Related Commands

show sysinfo
config sysname

debug ap enable

To configure the remote debugging of Cisco lightweight access points or to remotely execute a command on a lightweight access point, use the **debug ap enable** command.

debug ap {**enable** | **disable** | **command** *cmd*} *cisco_ap*

Syntax Description

enable	Enables the remote debugging. Note The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
disable	Disables the remote debugging.
command	Specifies that a CLI command is to be executed on the access point.
<i>cmd</i>	Command to be executed. Note The command to be executed must be enclosed in double quotes, such as debug ap command "led flash 30" AP03 . The output of the command displays only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to enable the remote debugging on access point AP01:

```
> debug ap enable AP01
```

This example shows how to disable the remote debugging on access point AP02:

```
> debug ap disable AP02
```

This example shows how to execute the flash LED command on access point AP03:

```
> debug ap command "led flash 30" AP03
```

Related Commands

show sysinfo
config sysname

debug ap packet-dump

To configure the debugging of Packet Capture, use the **debug ap packet-dump** command.

debug ap packet-dump {enable | disable}

Syntax Description

enable	Enables the debugging of Packet Capture of an access point.
disable	Disables the debugging of Packet Capture of an access point.

Command Default

Disabled.

Usage Guidelines

Packet Capture does not work during inter-Cisco WLC roaming.

The Cisco WLC does not capture packets created in the radio firmware and sent out of the access point, such as beacon or probe response. Only packets that flow through the radio driver in the Tx path will be captured.

Examples

This example shows how to enable the debugging of Packet Capture from an access point:

```
> debug ap packet-dump enable
```

Related Commands

config ap packet-dump
show ap packet-dump status

debug ap show stats

To debug video messages and statistics of Cisco lightweight access points, use the **debug ap show stats** command.

debug ap show stats {**802.11a** | **802.11b**} *cisco_ap* {**tx-queue** | **packet** | **load** | **multicast** | **client** {*client_MAC* | **video** | **all**} | **video metrics**}

debug ap show stats video *cisco_ap* {**multicast mgid** *mgid_database_number* | **admission** | **bandwidth**}

Syntax Description

802.11a	Specifies the 802.11a network.
802.11b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.
tx-queue	Displays the transmit queue traffic statistics of the AP.
packet	Displays the packet statistics of the AP.
load	Displays the QoS Basic Service Set (QBSS) and other statistics of the AP.
multicast	Displays the multicast supported rate statistics of the AP.
client	Displays the specified client metric statistics.
<i>client_MAC</i>	MAC address of the client.
video	Displays video statistics of all clients on the AP.
all	Displays statistics of all clients on the AP.
video metrics	Displays the video metric statistics.
mgid	Displays detailed multicast information for a single multicast group ID (MGID).
<i>mgid_database_number</i>	Layer 2 MGID database number.
admission	Displays video admission control on the AP.
bandwidth	Displays video bandwidth on the AP.

Command Default

None.

Examples

This example shows how to troubleshoot the access point AP01's transmit queue traffic on an 802.11a network:

```
> debug ap show stats 802.11a AP01 tx-queue
```

This example shows how to troubleshoot the access point AP02's multicast supported rates on an 802.11b/g network:

```
> debug ap show stats 802.11b AP02 multicast
```

This example shows how to troubleshoot the metrics of a client identified by its MAC address, associated with the access point AP01 on an 802.11a network:

```
> debug ap show stats 802.11a AP01 client 00:40:96:a8:f7:98
```

This example shows how to troubleshoot the metrics of all clients associated with the access point AP01 on an 802.11a network:

```
> debug ap show stats 802.11a AP01 client all
```

Related Commands

debug ap show stats video

debug ap show stats video

To configure the debugging of video messages and statistics of Cisco lightweight access points, use the **debug ap show stats video** command.

debug ap show stats video *cisco_ap* {**multicast mgid** *mgid_value* | **admission** | **bandwidth**}

Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.
multicast mgid	Displays multicast database related information for the specified MGID of an access point.
<i>mgid_value</i>	Layer 2 MGID database number from 1 to 4095.
admission	Displays the video admission control.
bandwidth	Displays the video bandwidth.

Command Default

None.

Examples

This example shows how to configure the debugging of an access point AP01's multicast group that is identified by the group's Layer 2 MGID database number:

```
> debug ap show stats video AP01 multicast mgid 50
```

This example shows how to configure the debugging of an access point AP01's video bandwidth:

```
> debug ap show stats video AP01 bandwidth
```

Related Commands

debug ap show stats

debug capwap

To configure the debugging of Control and Provisioning of Wireless Access Points (CAPWAP) settings, use the **debug capwap** command.

debug capwap {**detail** | **dtls-keepalive** | **errors** | **events** | **hexdump** | **info** | **packet** | **payload**} {**enable** | **disable**}

Syntax Description

detail	Configures the debugging for CAPWAP detail settings.
dtls-keepalive	Configures the debugging for CAPWAP DTLS data keepalive packets settings.
errors	Configures the debugging for CAPWAP error settings.
events	Configures the debugging for CAPWAP events settings.
hexdump	Configures the debugging for CAPWAP hexadecimal dump settings.
info	Configures the debugging for CAPWAP info settings.
packet	Configures the debugging for CAPWAP packet settings.
payload	Configures the debugging for CAPWAP payload settings.
enable	Enables the debugging of the CAPWAP command.
disable	Disables the debugging of the CAPWAP command.

Command Default

None.

Examples

This example shows how to enable the debugging of CAPWAP details:

```
> debug capwap detail enable
```

Related Commands

clear lwapp private-config
debug disable-all
show capwap reap association
show capwap reap status

debug group

To configure the debugging of access point groups, use the **debug group** command.

debug group {enable | disable}

Syntax Description

enable	Enables the debugging of access point groups.
disable	Disables the debugging of access point groups.

Command Default

None.

Examples

This example shows how to enable the debugging of access point groups:

```
> debug group enable
```

Related Commands

config guest-lan nac
config wlan apgroup
config wlan nac

debug lwapp console cli

To configure the debugging of the access point console CLI, use the **debug lwapp console cli** command from the access point console port.

debug lwapp console cli

Syntax Description

This command has no arguments or keywords.

Command Default

None.

Usage Guidelines

This access point CLI command must be entered from the access point console port.

Examples

This example shows how to configure the debugging of the access point console:

```
AP# debug lwapp console cli
LWAPP console CLI allow/disallow debugging is on
```

Related Commands

debug disable-all

debug ap

clear lwapp private-config

debug redundancy-link-encryption

To configure the debugging of redundancy link encryption, use the **debug redundancy-link-encryption** command.

debug redundancy-link-encryption {all | detail | events | errors} {enable | disable}

Syntax Description

all	Configures the debugging of all redundancy link encryption logs.
detail	Configures the debugging of redundancy link encryption detail messages.
events	Configures the debugging of redundancy link encryption events.
errors	Configures the debugging of redundancy link encryption errors.
enable	Enables the debugging of redundancy link encryption.
disable	Disables the debugging of redundancy link encryption.

Command Default

None.

Examples

This example shows how to enable the debugging of all redundancy link encryption:

```
> debug redundancy-link-encryption all enable
```

Related Commands

config redundancy mobilitymac
config redundancy interface address peer-service-port
config redundancy peer-route
config redundancy unit
config redundancy timer
show redundancy peer-route
show redundancy summary
debug rmgr
debug rsyncmgr

debug rfac

To configure the debugging of the Redundancy Framework (RFAC), use the **debug rfac** command.

debug rfac {[packet | events | errors | detail] [enable | disable]}

Syntax Description

packet	Configures the debugging of Redundancy Framework packets.
events	Configures the debugging of Redundancy Framework events.
errors	Configures the debugging of Redundancy Framework errors.
detail	Configures the debugging of Redundancy Framework details.
enable	(Optional) Enables the debugging of Redundancy Framework.
disable	(Optional) Disables the debugging of Redundancy Framework.

Command Default

None.

Examples

This example shows how to enable the debugging of Redundancy Framework packets:

```
> debug rfac packet enable
```

Related Commands

debug rmgr
 debug rsyncmgr
 config interface address redundancy-management
 show redundancy summary

debug rmgr

To configure the debugging of Redundancy Manager (RMGR), use the **debug rmgr** command.

debug rmgr {**packet** | **events** | **errors** | **detail**} {**enable** | **disable**}

Syntax Description

packet	Configures the debugging of Redundancy Manager packets.
events	Configures the debugging of Redundancy Manager events.
errors	Configures the debugging of Redundancy Manager errors.
detail	Configures the debugging of Redundancy Manager details.
enable	Enables the debugging of Redundancy Manager.
disable	Disables the debugging of Redundancy Manager.

Command Default

None.

Usage Guidelines

Redundancy Manager determines the role of the Cisco WLCs, maintains the keepalive messages between the peers, and initiates the switchover.

Examples

This example shows how to enable the debugging of Redundancy Manager packets:

```
> debug rmgr packet enable
```

Related Commands

config interface address redundancy-management
debug rfac
debug rsyncmgr
show redundancy summary

debug rsyncmgr

To configure the debugging of the Redundancy Sync Manager (RSYNCMGR), use the **debug rsyncmgr** command.

debug rsyncmgr {**packet** | **events** | **errors** | **detail**} {**enable** | **disable**}}

Syntax Description

packet	Configures the debugging of Redundancy Sync Manager packets.
events	Configures the debugging of Redundancy Sync Manager events.
errors	Configures the debugging of Redundancy Sync Manager errors.
detail	Configures the debugging of Redundancy Sync Manager details.
enable	Enables the debugging of Redundancy Sync Manager.
disable	Stops the debugging Redundancy Sync Manager.

Command Default

None.

Usage Guidelines

Redundancy Synchronization Manager synchronizes the configurations of the active and standby Cisco WLCs.

Examples

This example shows how to enable the debugging of Redundancy Sync Manager packets:

```
> debug rsyncmgr packet enable
```

Related Commands

debug rfac
debug rmgr
config interface address redundancy-management
show redundancy summary

debug service ap-monitor

To debug the access point monitor service, use the **debug service ap-monitor** command.

debug service ap-monitor {all | error | event | nmosp | packet} {enable | disable}

Syntax Description

all	Configures the debugging of all access point status messages.
error	Configures the debugging of access point monitor error events.
event	Configures the debugging of access point monitor events.
nmosp	Configures the debugging of access point monitor Network Mobility Services Protocol (NMSP) events.
packet	Configures the debugging of access point monitor packets.
enable	Enables the debugging for access point monitor service.
disable	Disables the debugging for access point monitor service.

Command Default

None.

Examples

This example shows how to configure the debugging of access point monitor NMSP events:

```
> debug service ap-monitor events
```

Related Commands

debug disable-all
show snmp status

transfer download peer-start

To download a file to the peer controller, use the **transfer download peer-start** command.

transfer download peer-start

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples

This example shows how to start downloading a file to the peer controller:

```
> transfer download peer-start In commandTransferDownloadPeerStart

Mode.....TFTP
Data Type.....Login Banner
TFTP Server IP.....9.1.0.100
TFTP Packet Timeout.....6
TFTP Max Retries.....10
TFTP Path.....dhk/
TFTP Filename.....xyz

Are you sure you want to start download on standby? (y/N) y
In commandTransferDownloadPeerStart
In usmDbTransferDownStartSet... dir: 2 ---> Indicates L7_TRANSFER_DIRECTION_DOWN_STANDBY
usmDbTransferDownStartSet: SUCCESS
In commandTransferDownloadPeerStart

TFTP Config transfer starting.
In commandTransferDownloadPeerStart

% Error: Config file transfer failed - Error from server: File not found
```

Related Commands

clear transfer
 transfer upload filename
 transfer upload mode
 transfer upload pac
 transfer upload password
 transfer upload path
 transfer upload port
 transfer upload serverip
 transfer upload datatype
 transfer upload username
 transfer upload peer-start
 reset peer-start

transfer upload peer-start

To upload a file to the peer controller, use the **transfer upload peer-start** command.

transfer upload peer-start

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to start uploading a file to the peer controller:

```
> transfer upload peer-start
Mode..... FTP
FTP Server IP..... 209.165.201.1
FTP Server Port..... 21
FTP Path..... /builds/nimm/
FTP Filename..... AS_5500_7_4_1_20.aes
FTP Username..... wnbu
FTP Password..... *****
Data Type..... Error Log

Are you sure you want to start upload from standby? (y/N) n

Transfer Canceled
```

Related Commands

- clear transfer
- transfer upload filename
- transfer upload mode
- transfer upload pac
- transfer upload password
- transfer upload path
- transfer upload port
- transfer upload serverip
- transfer upload datatype
- transfer upload username
- transfer download peer-start

Resetting the System Reboot Time

Use the **reset** command to schedule a reboot of the controller and access points.

reset system at

To reset the system at a specified time, use the **reset system at** command.

reset system at YYYY-MM-DD HH:MM:SS image {no-swap|swap} reset-aps [save-config]

Syntax Description		
YYYY-MM-DD		Specifies the date.
HH: MM: SS		Specifies the time in a 24-hour format.
image		Configures the image to be rebooted.
swap		Changes the active boot image.
no-swap		Boots from the active image.
reset-aps		Resets all access points during the system reset.
save-config		(Optional) Saves the configuration before the system reset.

Command Default None.

Examples This example shows how to reset the system at 2010-03-29 and 12:01:01 time:

```
> reset system at 2010-03-29 12:01:01 image swap reset-aps save-config
```

Related Commands

- reset system notify-time
- reset system in

reset system in

To specify the amount of time delay before the devices reboot, use the **reset system in** command.

reset system in HH:MM:SS image {swap | no-swap} reset-aps save-config

Syntax Description

HH :MM :SS	Specifies a delay in duration.
image	Configures the image to be rebooted.
swap	Changes the active boot image.
no-swap	Boots from the active image.
reset-aps	Resets all access points during the system reset.
save-config	Saves the configuration before the system reset.

Command Default

None.

Examples

This example shows how to reset the system after a delay of 00:01:01:

```
> reset system in 00:01:01 image swap reset-aps save-config
```

Related Commands

reset system notify-time
reset system at

reset system cancel

To cancel a scheduled reset, use the **reset system cancel** command.

reset system cancel

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to cancel a scheduled reset:

```
> reset system cancel
```

Related Commands	reset system at reset system in reset system notify-time

reset system notify-time

To configure the trap generation prior to scheduled resets, use the **reset system notify-time** command.

reset system notify-time *minutes*

Syntax Description

minutes

Number of minutes before each scheduled reset at which to generate a trap.

Command Default

The default is 10 minutes.

Examples

This example shows how to configure the trap generation to 10 minutes before the scheduled resets:

```
> reset system notify-time 55
```

Related Commands

reset system in

reset system at

reset peer-system

To reset the peer controller, use the **reset peer-system** command.

reset peer-system

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to reset the peer controller: > reset peer-system

Related Commands	reset system notify-time reset system in

test Commands

This section lists the **test** commands for access points.

test ap pmtu

To enable or disable the Path Maximum Transmission Unit (PMTU) on the CAPWAP tunnel of a Cisco access point, use the **test ap** command.

test ap pmtu {enable | disable} *cisco_ap*

Syntax Description

enable	Disables PMTU on the CAPWAP tunnel of a Cisco access point.
disable	Enables PMTU on the CAPWAP tunnel of a Cisco access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to enable PMTU on the CAPWAP tunnel of a Cisco access point:

```
> test ap pmtu enable AP1600_1
```

Related Commands

test ap
test capwap
test ccx
test cleanair
test ftpstatus
test lic-agent
test license
test log
test make-space
test media
test reader
test redundancy
test rrm
test sip-cac-fail
test token-bucket
test wlan

test capwap

To configure an access point to send broadcast radio measurement requests to clients, or to enable the encryption of control packets that are sent between the access point and the controller, use the **test capwap** command.

test capwap {**message** *token cisco_ap* | **encr** *cisco_ap* {**enable** | **disable**}}

Syntax Description

message	Configures the access point to send a broadcast radio measurement requests to clients.
<i>token</i>	Time interval for the access point to send a broadcast radio measurement requests to clients.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
encr	Encrypts or decrypts the control packets that are sent between the access point and the controller.
enable	Enables the encryption or decryption of control packets that are sent between the access point and the controller.
disable	Disables the encryption or decryption of control packets that are sent between the access point and the controller.

Command Default

None.

Examples

This example shows how to enable encryption of control packets:

```
> test capwap encr A_1500_1 enable
```

Related Commands

test ap
test capwap
test ccx
test cleanair
test ftpstatus
test lic-agent
test license
test log
test make-space
test media
test reader

test redundancy

test rrm

test sip-cac-fail

test token-bucket

test wlan



PART VII

Mesh Access Point Commands

- [CLI Commands, page 1407](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points. This chapter describes the how to control and configure Mesh access points using the controller commands and contains the following sections:

- [show mesh Commands, page 1408](#)
- [config mesh Commands, page 1427](#)
- [debug Commands, page 1455](#)

show mesh Commands

Use the **show mesh** commands to see settings for outdoor and indoor mesh access points.

show mesh ap

To display settings for mesh access points, use the **show mesh ap** command.

show mesh ap {summary | tree}

Syntax Description

summary	Displays a summary of mesh access point information including the name, model, bridge virtual interface (BVI) MAC address, United States Computer Emergency Response Team (US-CERT) MAC address, hop, and bridge group name.
tree	Displays a summary of mesh access point information in a tree configuration, including the name, hop counter, link signal-to-noise ratio (SNR), and bridge group name.

Command Default

None.

Examples

This example shows how to display a summary format:

```
> show mesh ap summary
AP Name AP Model BVI MAC CERT MAC Hop Bridge Group Name
-----
SB_RAP1 AIR-LAP1522AG-A-K9 00:1d:71:0e:d0:00 00:1d:71:0e:d0:00 0 sbbox
SB_MAP1 AIR-LAP1522AG-A-K9 00:1d:71:0e:85:00 00:1d:71:0e:85:00 1 sbbox
SB_MAP2 AIR-LAP1522AG-A-K9 00:1b:d4:a7:8b:00 00:1b:d4:a7:8b:00 2 sbbox
SB_MAP3 AIR-LAP1522AG-A-K9 00:1d:71:0d:ee:00 00:1d:71:0d:ee:00 3 sbbox
Number of Mesh APs..... 4
Number of RAPs..... 1
Number of MAPs..... 3
```

This example shows how to display settings in a hierarchical (tree) format:

```
> show mesh ap tree
=====
|| AP Name [Hop Counter, Link SNR, Bridge Group Name] ||
=====
[Sector 1]
-----
SB_RAP1[0,0,sbox]
  |-SB_MAP1[1,32,sbox]
    |-SB_MAP2[2,27,sbox]
      |-SB_MAP3[3,30,sbox]
-----
Number of Mesh APs..... 4
Number of RAPs..... 1
Number of MAPs..... 3
-----
```

Related Commands

config mesh alarm
config mesh astools
config mesh battery-state

show mesh astools stats

To display antistranding statistics for outdoor mesh access points, use the **show mesh astools stats** command.

show mesh astools stats [*cisco_ap*]

Syntax Description

<i>cisco_ap</i>	(Optional) Antistranding feature statistics for a designated mesh access point.

Command Default

None.

Examples

This example shows how to display anti-stranding statistics on all outdoor mesh access points:

```
> show mesh astools stats
Total No of Aps stranded : 0
```

This example shows how to display anti-stranding statistics for access point *sb_map1*:

```
> show mesh astools stats sb_map1
Total No of Aps stranded : 0
```

Related Commands

show mesh config
config mesh astools
show mesh stats

show mesh backhaul

To check the current backhaul, use the **show mesh backhaul** command.

show mesh backhaul *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Name of the access point.

Command Default

None.

Examples

This example shows how to display the current backhaul:

> **show mesh backhaul**

If the current backhaul is 5 GHz, the output is as follows:

```
Basic Basic Attributes for Slot 0
  Radio Type..... RADIO_TYPE_80211g
  Radio Role..... DOWNLINK_ACCESS
  Administrative State ..... ADMIN_ENABLED
  Operation State ..... UP
  Current Tx Power Level ..... 1
If the current backhaul is 2.4 GHz, the output is as follows:
Basic Attributes for Slot 1
  Radio Type..... RADIO_TYPE_80211a
  Radio Subband..... RADIO_SUBBAND_ALL
  Radio Role..... DOWNLINK_ACCESS
  Administrative State ..... ADMIN_ENABLED
  Operation State ..... UP
  Current Tx Power Level ..... 1
  Current Channel ..... 165
  Antenna Type..... EXTERNAL_ANTENNA
  External Antenna Gain (in .5 dBm units).... 0
Current Channel.....6
Antenna Type.....External_ANTENNA
External Antenna Gain (in .5 dBm units).....0
```

Related Commands

show mesh config
config mesh astools
show mesh stats

show mesh cac

To display call admission control (CAC) topology and the bandwidth used or available in a mesh network, use the **show mesh cac** command.

show mesh cac {**summary** | {**bwused** {**voice** | **video**} | **access** | **callpath** | **rejected**} *cisco_ap*}

Syntax Description

summary	Displays the total number of voice calls and voice bandwidth used for each mesh access point.
bwused	Displays the bandwidth for a selected access point in a tree topology.
voice	Displays the mesh topology and the voice bandwidth used or available.
video	Displays the mesh topology and the video bandwidth used or available.
access	Displays access voice calls in progress in a tree topology.
callpath	Displays the call bandwidth distributed across the mesh tree.
rejected	Displays voice calls rejected for insufficient bandwidth in a tree topology.
<i>cisco_ap</i>	Mesh access point name.

Command Default

None.

Examples

This example shows how to display a summary of the call admission control settings:

```
> show mesh cac summary
AP Name           Slot#      Radio  BW Used/Max  Calls
-----
SB_RAP1           0          11b/g   0/23437      0
                  1          11a     0/23437      0
SB_MAP1           0          11b/g   0/23437      0
                  1          11a     0/23437      0
SB_MAP2           0          11b/g   0/23437      0
                  1          11a     0/23437      0
SB_MAP3           0          11b/g   0/23437      0
                  1          11a     0/23437      0
```

This example shows how to display the mesh topology and the voice bandwidth used or available:

```
> show mesh cac bwused voice SB_MAP1
AP Name           Slot#      Radio  BW Used/Max
-----
    SB_RAP1        0          11b/g   0/23437
                   1          11a     0/23437
|   SB_MAP1        0          11b/g   0/23437
                   1          11a     0/23437
||  SB_MAP2        0          11b/g   0/23437
                   1          11a     0/23437
||| SB_MAP3        0          11b/g   0/23437
                   1          11a     0/23437
```

This example shows how to display the access voice calls in progress in a tree topology:

```
> show mesh cac access 1524_Map1
  AP Name      Slot#  Radio  Calls
  -----
    1524_Rap      0    11b/g     0
                   1    11a     0
                   2    11a     0
|   1524_Map1      0    11b/g     0
                   1    11a     0
                   2    11a     0
||  1524_Map2      0    11b/g     0
                   1    11a     0
                   2    11a     0
```

Related Commands

```
config 802.11 cac video acm
config 802.11 cac video roam-bandwidth
config 802.11 cac video max-bandwidth
config 802.11 cac video tspec-inactivity-timeout
config 802.11 cac voice acm
config 802.11 cac voice roam-bandwidth
config 802.11 cac voice max-bandwidth
config 802.11 cac voice tspec-inactivity-timeout
config 802.11 cac voice load-based
debug cac voice
```

show mesh client-access

To display the backhaul client access configuration setting, use the **show mesh client-access** command.

show mesh client-access

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display backhaul client access configuration settings for a mesh access point:

```
> show mesh client-access
Backhaul with client access status: enabled
Backhaul with client access extended status(3 radio AP): disabled
```

Related Commands **config mesh client-access**

show mesh config

To display mesh configuration settings, use the **show mesh config** command.

show mesh config

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display global mesh configuration settings:

```
> show mesh config
Mesh Range..... 12000
Mesh Statistics update period..... 3 minutes
Backhaul with client access status..... disabled
Backhaul with extended client access status..... disabled
Background Scanning State..... enabled
Backhaul Amsdu State..... disabled
Mesh Security
  Security Mode..... EAP
  External-Auth..... disabled
  Use MAC Filter in External AAA server..... disabled
  Force External Authentication..... disabled
Mesh Alarm Criteria
  Max Hop Count..... 4
  Recommended Max Children for MAP..... 10
  Recommended Max Children for RAP..... 20
  Low Link SNR..... 12
  High Link SNR..... 60
  Max Association Number..... 10
  Association Interval..... 60 minutes
  Parent Change Numbers..... 3
  Parent Change Interval..... 60 minutes
Mesh Multicast Mode..... In-Out
Mesh Full Sector DFS..... enabled
Mesh Ethernet Bridging VLAN Transparent Mode..... disabled
Mesh DCA channels for serial backhaul APs..... enabled
Mesh Slot Bias..... enabled
```

Related Commands

- show mesh stats**
- show mgmtuser**
- config mesh alarm**

show mesh env

To display global or specific environment summary information for mesh networks, use the **show mesh env** command.

show mesh env {**summary** | *cisco_ap*}

Syntax Description

summary	Displays global environment summary information.
<i>cisco_ap</i>	Name of access point for which environment summary information is requested.

Command Default

None.

Examples

This example shows how to display global environment summary information:

```
> show mesh env summary
AP Name           Temperature (C)  Heater  Ethernet  Battery
-----
ap1130:5f:be:90    N/A             N/A     DOWN      N/A
AP1242:b2.31.ea    N/A             N/A     DOWN      N/A
AP1131:f2.8d.92    N/A             N/A     DOWN      N/A
AP1131:46f2.98ac   N/A             N/A     DOWN      N/A
ap1500:62:39:70    -36             OFF     UP         N/A
```

This example shows how to display an environment summary for an access point:

```
> show mesh env SB_RAP1
AP Name..... SB_RAP1
AP Model..... AIR-LAP1522AG-A-K9
AP Role..... RootAP
Temperature..... 21 C, 69 F
Heater..... OFF
Backhaul..... GigabitEthernet0
GigabitEthernet0 Status..... UP
    Duplex..... FULL
    Speed..... 100
    Rx Unicast Packets..... 114754
    Rx Non-Unicast Packets..... 1464
    Tx Unicast Packets..... 9630
    Tx Non-Unicast Packets..... 3331
GigabitEthernet1 Status..... DOWN
    POE Out..... OFF
Battery..... N/A
```

Related Commands

show mesh stats

show mesh neigh

To display summary or detailed information about the mesh neighbors for a specific mesh access point, use the **show mesh neigh** command.

show mesh neigh {**detail** | **summary**} {*cisco_ap* | **all**}

Syntax Description

detail	Displays the channel and signal-to-noise ratio (SNR) details between the designated mesh access point and its neighbor.
summary	Displays the mesh neighbors for a designated mesh access point.
<i>cisco_ap</i>	Cisco lightweight access point name.
all	Displays all access points.



Note

If an AP itself is configured with the **all** keyword, the **all** keyword access points take precedence over the AP that is named **all**.

Examples

This example shows how to display a neighbor summary of an access point:

```
> show mesh neigh summary RAP1
AP Name/Radio Mac Channel Rate Link-Snr Flags State
-----
00:1D:71:0F:CA:00 157 54 6 0x0 BEACON
00:1E:14:48:25:00 157 24 1 0x0 BEACON
MAP1-BB00 157 54 41 0x11 CHILD BEACON
```

This example shows how to display the detailed neighbor statistics of an access point:

```
> show mesh neigh detail RAP1
AP MAC : 00:1E:BD:1A:1A:00 AP Name: HOR1522_MINE06_MAP_S_Dyke
backhaul rate 54
FLAGS : 860 BEACON
worstDv 255, Ant 0, channel 153, biters 0, ppiters 0
Numroutes 0, snr 0, snrUp 8, snrDown 8, linkSnr 8
adjustedEase 0, unadjustedEase 0
txParent 0, rxParent 0
poorSnr 0
lastUpdate 2483353214 (Sun Aug 4 23:51:58 1912)
parentChange 0
Per antenna smoothed snr values: 0 0 0 0
Vector through 00:1E:BD:1A:1A:00
```

The following table lists the output flags displayed for the **show mesh neigh detail** command.

Table 9: Output Flags for the show mesh neigh detail command

Output Flag	Description
AP MAC	MAC address of a mesh neighbor for a designated mesh access point.
AP Name	Name of the mesh access point.
FLAGS	Describes adjacency. The possible values are as follows: • UPDATED—Recently updated neighbor. • NEIGH—One of the top neighbors. • EXCLUDED—Neighbor is currently excluded. • WASEXCLUDED—Neighbor was recently removed from the exclusion list. • PERMSNR—Permanent SNR neighbor. • CHILD—A child neighbor. • PARENT—A parent neighbor. • NEEDUPDATE—Not a current neighbor and needs an update. • BEACON—Heard a beacon from this neighbor. • ETHER—Ethernet neighbor.
worstDv	Worst distance vector through the neighbor.
Ant	Antenna on which the route was received.
channel	Channel of the neighbor.
biters	Number of black list timeouts left.
ppiters	Number of potential parent timeouts left.
Numroutes	Number of distance routes.
snr	Signal to Noise Ratio.
snrUp	SNR of the link to the AP.
snrDown	SNR of the link from the AP.
linkSnr	Calculated SNR of the link.
adjustedEase	Ease to the root AP through this AP. It is based on the current SNR and threshold SNR values.
unadjustedEase	Ease to the root AP through this AP after applying correct for number of hops.

Output Flag	Description
txParent	Packets sent to this node while it was a parent.
rxparent	Packets received from this node while it was a parent.
poorSnr	Packets with poor SNR received from a node.
lastUpdate	Timestamp of the last received message for this neighbor
parentChange	When this node last became parent.
per antenna smoother SNR values	SNR value is populated only for antenna 0.

Related Commands**show mesh config****show mesh env**

show mesh path

To display the channel and signal-to-noise ratio (SNR) details for a link between a mesh access point and its neighbor, use the **show mesh path** command.

show mesh path *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Mesh access point name.

Command Default

None.

Examples

This example shows how to display channel and SNR details for a designated link path:

```
> show mesh path mesh-45-rap1
AP Name/Radio Mac Channel Rate Link-Snr Flags State
-----
MAP1-BB00          157    54    32    0x0  UPDATED NEIGH PARENT BEACON
RAP1                157    54    37    0x0    BEACON
```

Related Commands

config mesh battery-state
config mesh client-access
config mesh range
config mesh linktest
show mesh stats
config mesh range
show mesh neigh

show mesh per-stats

To display the percentage of packet errors for packets transmitted by the neighbors of a specified mesh access point, use the **show mesh per-stats** command.

show mesh per-stats summary {*cisco_ap* | **all**}

Syntax Description

summary	Displays the packet error rate stats summary.
<i>cisco_ap</i>	Name of mesh access point.
all	Displays all mesh access points.



Note

If an AP itself is configured with the **all** keyword, the **all** keyword access points take precedence over the AP that is named **all**.

Usage Guidelines

The packet error rate percentage equals 1, which is the number of successfully transmitted packets divided by the number of total packets transmitted.

Examples

This example shows how to display the percentage of packet errors for packets transmitted by the neighbors to a mesh access point:

```
> show mesh per-stats summary ap_12
Neighbor MAC Address 00:0B:85:5F:FA:F0
Total Packets transmitted: 104833
Total Packets transmitted successfully: 104833
Total Packets retried for transmission: 33028
RTS Attempts: 0
RTS Success: 0
Neighbor MAC Address: 00:0B:85:80:ED:D0
Total Packets transmitted: 0
Total Packets transmitted successfully: 0
Total Packets retried for transmission: 0
Neighbor MAC Address: 00:17:94:FE:C3:5F
Total Packets transmitted: 0
Total Packets transmitted successfully: 0
Total Packets retried for transmission: 0
RTS Attempts: 0
RTS Success: 0
```

Related Commands

config mesh linkdata
config mesh range
show mesh stats
show mesh neigh
show mesh config

show mesh public-safety

To display 4.8-GHz public safety settings, use the **show mesh public-safety** command.

show mesh public-safety

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to view 4.8-GHz public safety settings:

```
> show mesh public-safety
Global Public Safety status: disabled
```

Related Commands

- config mesh public-safety**
- config mesh security**
- show mesh ap**
- show mesh security-stats**
- show mesh stats**

show mesh queue-stats

To display the number of packets in a client access queue by type for a particular mesh access point, use the **show mesh queue-stats** command.

show mesh queue-stats {*cisco_ap* | **all**}



Note

If an AP itself is configured with the **all** keyword, the **all** keyword access points take precedence over the AP that is named **all**.

Syntax Description

<i>cisco_ap</i>	Name of access point for which you want packet queue statistics.
all	Displays all access points.

Command Default

None.

Examples

This example shows how to display packet queue statistics for access point ap417:

```
> show mesh queue-stats ap417
Queue Type Overflows Peak length Average length
-----
Silver      0           1           0.000
Gold        0           4           0.004
Platinum    0           4           0.001
Bronze      0           0           0.000
Management 0           0           0.000
```

Related Commands

config mesh client-access
config mesh multicast
show mesh client-access
show mesh config
show mesh stats
show mesh config
show mesh stats
show mgmtuser

show mesh security-stats

To display packet error statistics for a specific access point, use the **show mesh security-stats** command.

show mesh security-stats {*cisco_ap* | **all**}

Syntax Description

<i>cisco_ap</i>	Name of access point for which you want packet error statistics.
all	Displays all access points.



Note

If an AP itself is configured with the **all** keyword, the **all** keyword access points take precedence over the AP that is named **all**.

Command Default

None.

Usage Guidelines

This command shows packet error statistics and a count of failures, timeouts, and successes with respect to associations and authentications as well as reassociations and reauthentications for the specified access point and its child.

Examples

This example shows how to display packet error statistics for access point ap417:

```
> show mesh security-stats ap417
AP MAC : 00:0B:85:5F:FA:F0
Packet/Error Statistics:
-----
x Packets 14, Rx Packets 19, Rx Error Packets 0
Parent-Side Statistics:
-----
Unknown Association Requests 0
Invalid Association Requests 0
Unknown Re-Authentication Requests 0
Invalid Re-Authentication Requests 0
Unknown Re-Association Requests 0
Invalid Re-Association Requests 0
Child-Side Statistics:
-----
Association Failures 0
Association Timeouts 0
Association Successes 0
Authentication Failures 0
Authentication Timeouts 0
Authentication Successes 0
Re-Association Failures 0
Re-Association Timeouts 0
Re-Association Successes 0
Re-Authentication Failures 0
Re-Authentication Timeouts 0
Re-Authentication Successes 0
```

Related Commands

`config mesh alarm`
`config mesh linkdata`
`config mesh linktest`
`config mesh security`

show mesh stats

To display the mesh statistics for a Cisco lightweight access point, use the **show mesh stats** command.

show mesh stats *cisco_ap*

Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to display statistics of an access point:

```
> show mesh stats RAP_AP1
RAP in state Maint
rxNeighReq 759978, rxNeighRsp 568673
txNeighReq 115433, txNeighRsp 759978
rxNeighUpd 8266447 txNeighUpd 693062
tnextchan 0, nextant 0, downAnt 0, downChan 0, curAnts 0
tnextNeigh 0, malformedNeighPackets 244, poorNeighSnr 27901
blacklistPackets 0, insufficientMemory 0
authenticationFailures 0
Parent Changes 1, Neighbor Timeouts 16625
```

Related Commands

- config mesh ethernet-bridging vlan-transparent**
- config mesh linkdata**
- config mesh linktest**
- config mesh security**
- show mesh security-stats**
- config mesh config**
- config mesh client-access**
- show mesh per-stats**
- show mesh queue-stats**

config mesh Commands

Use the **config mesh** commands to configure the mesh access points.

config mesh alarm

To configure alarm settings for outdoor mesh access points, use the **config mesh alarm** command.

config mesh alarm {**max-hop** | **max-children** | **low-snr** | **high-snr** | **association** | **parent-change count**} *value*

Syntax Description

max-hop	Sets the maximum number of hops before triggering an alarm for traffic over the mesh network. The range is from 1 to 16.
max-children	Sets the maximum number of mesh access points (MAPs) that can be assigned to a mesh router access point (RAP) before triggering an alarm. The range is from 1 to 16.
low-snr	Sets the low-end signal-to-noise ratio (SNR) value before triggering an alarm. The range is from 1 to 30.
high-snr	Sets the high-end SNR value before triggering an alarm. The range is from 1 to 30 (inclusive).
association	Sets the mesh alarm association count value before triggering an alarm. The range is from 1 to 30 (inclusive).
parent-change count	Sets the number of times a MAP can change its RAP association before triggering an alarm. The range is from 1 to 30 (inclusive).
<i>value</i>	Value above or below which an alarm is generated. The valid values vary for each command.

Command Default

See the “Syntax Description” section for command and argument value ranges.

Examples

This example shows how to set the maximum hops threshold to 8:

```
> config mesh alarm max-hop 8
```

This example shows how to set the upper SNR threshold to 25:

```
> config mesh alarm high-snr 25
```

Related Commands

config mesh client-access
config mesh ethernet-bridging vlan-transparent
config mesh full-sector-dfs
config mesh multicast

config mesh radius-server

config mesh security

config mesh slot-bias

show mesh security-stats

show mesh ap

config mesh slot-bias

show mesh stats

show mgmtuser

config mesh astools

To globally enable or disable the anti-stranding feature for outdoor mesh access points, use the **config mesh astools** command.

config mesh astools {enable | disable}

Syntax Description

enable	Enables this feature for all outdoor mesh access points.
disable	Disables this feature for all outdoor mesh access points.

Command Default

None.

Examples

This example shows how to enable anti-stranding on all outdoor mesh access points:

```
> config mesh astools enable
```

Related Commands

show mesh astools stats
show mesh config
show mesh security-stats
show mesh ap
config mesh slot-bias
show mesh stats
show mgmtuser

config mesh backhaul rate-adapt

To globally configure the backhaul Tx rate adaptation (universal access) settings for indoor and outdoor mesh access points, use the **config mesh backhaul rate-adapt** command.

config mesh backhaul rate-adapt [**all** | **bronze** | **silver** | **gold** | **platinum**] {**enable** | **disable**}

Syntax Description

all	(Optional) Grants universal access privileges on mesh access points.
bronze	(Optional) Grants background-level client access privileges on mesh access points.
silver	(Optional) Grants best effort-level client access privileges on mesh access points.
gold	(Optional) Grants video-level client access privileges on mesh access points.
platinum	(Optional) Grants voice-level client access privileges on mesh access points.
enable	Enables this backhaul access level for mesh access points.
disable	Disables this backhaul access level for mesh access points.

Command Default

Disabled.

Usage Guidelines

To use this command, mesh backhaul with client access must be enabled by using the **config mesh client-access** command.



Note

After this feature is enabled, all mesh access points reboot.

Examples

This example shows how to set the backhaul client access to the best-effort level:

```
> config mesh backhaul rate-adapt silver
```

Related Commands

show mesh config
show mesh ap
show mesh stats

config mesh backhaul slot

To configure the slot radio as a downlink backhaul, use the **config mesh backhaul slot** command.

config mesh backhaul slot *slot_id* {**enable** | **disable**} *cisco_ap*

Syntax Description

<i>slot_id</i>	Slot number between 0 and 2.
enable	Enables the entered slot radio as a downlink backhaul.
disable	Disables the entered slot radio as a downlink backhaul.
<i>cisco_ap</i>	Name of the Root AP of the sector on which the backhaul needs to be enabled or disabled.

Command Default

Disabled.

Usage Guidelines

For 2.4-GHz, only slot 0 and 1 are valid. If slot 0 is enabled, then slot 1 is automatically be disabled. If slot 0 is disabled, then slot 1 is automatically enabled. The **config mesh backhaul slot** command is applicable only to AP1522.

Examples

This example shows how to enable slot 1 as the preferred backhaul for the root AP myrootap1:

```
> config mesh backhaul slot 1 enable myrootap1
```

Related Commands

show mesh config
show mesh ap
show mesh stats

config mesh battery-state

To configure the battery state for Cisco Aironet 1520 series mesh access points, use the **config mesh battery-state** command.

config mesh battery-state {**enable** | **disable**} {**all** | *cisco_ap*}

Syntax Description

enable	Enables the battery-state for 1520 series mesh access points.
disable	Disables the battery-state for 1520 series mesh access points.
all	Applies this command to all mesh access points.
<i>cisco_ap</i>	Specific mesh access point.

Command Default

Disabled.

Examples

This example shows how to set the backhaul client access to the best-effort level:

```
> config mesh battery-state enable all
```

config mesh client-access

To enable or disable client access to the mesh backhaul on indoor and outdoor mesh access points, use the **config mesh client-access** command.

config mesh client-access {enable [extended] | disable}

Syntax Description

enable	Allows wireless client association over the mesh access point backhaul 802.11a radio.
extended	(Optional) Enables client access over both the backhaul radios for 1524 serial backhaul access points.
disable	Restricts the 802.11a radio to backhaul traffic, and allows client association only over the 802.11b/g radio.

Command Default

Disabled.

Usage Guidelines

Backhaul interfaces (802.11a radios) act as primary Ethernet interfaces. Backhauls function as trunks in the network and carry all VLAN traffic between the wireless and wired network. No configuration of primary Ethernet interfaces is required.

When this feature is enabled, Cisco Aironet 1520 series (152x) mesh access points allow wireless client association over the 802.11a radio, which implies that a 152x mesh access point can carry both backhaul traffic and 802.11a client traffic over the same 802.11a radio.

When this feature is disabled, the 152x carries backhaul traffic over the 802.11a radio and allows client association only over the 802.11b/g radio.

Examples

This example shows how to enable client access extended to allow a wireless client association over the 802.11a radio:

```
> config mesh client-access enable extended
Enabling client access on both backhaul slots
Same BSSIDs will be used on both slots
All Mesh AP will be rebooted
Are you sure you want to start? (y/N)Y
```

This example shows how to restrict a wireless client association to the 802.11b/g radio:

```
> config mesh client-access disable
All Mesh AP will be rebooted
Are you sure you want to start? (Y/N) Y
Backhaul with client access is cancelled.
```

Related Commands

show mesh config
show mesh ap

show mesh stats

show mesh client-access

config mesh ethernet-bridging vlan-transparent

To configure how a mesh access point handles VLAN tags for Ethernet bridged traffic, use the **config mesh ethernet-bridging vlan-transparent** command.

config mesh ethernet-bridging vlan-transparent {enable | disable}

Syntax Description

enable	Bridges packets as if they are untagged.
disable	Drops all tagged packets.

Command Default

Enabled.

Usage Guidelines

VLAN transparent is enabled as a default to ensure a smooth software upgrade from 4.1.192.xxM releases to release 5.2. Release 4.1.192.xxM does not support VLAN tagging.

Examples

This example shows how to configure Ethernet packets as untagged:

```
> config mesh ethernet-bridging vlan-transparent enable
```

This example shows how to drop tagged Ethernet packets:

```
> config mesh ethernet-bridging vlan-transparent disable
```

Related Commands

show mesh config
show mesh ap
show mesh stats
config mesh client-access
config mesh linkdata
config mesh linktest
config mesh multicast
show mesh client-access

config mesh full-sector-dfs

To globally enable or disable full-sector Dynamic Frequency Selection (DFS) on mesh access points, use the **config mesh full-sector-dfs** command.

config mesh full-sector-dfs {enable | disable}

Syntax Description	enable	Enables DFS for mesh access points.
	disable	Disables DFS for mesh access points.

Command Default None.

Usage Guidelines This command instructs the mesh sector to make a coordinated channel change on the detection of a radar signal. For example, if a mesh access point (MAP) detects a radar signal, the MAP will notify the root access point (RAP), and the RAP will initiate a sector change.

All MAPs and the RAP that belong to that sector go to a new channel, which lowers the probability of MAPs stranding when radar is detected on the current backhaul channel, and no other valid parent is available as backup.

Each sector change causes the network to be silent for 60 seconds (as dictated by the DFS standard).

It is expected that after a half hour, the RAP will go back to the previously configured channel, which means that if radar is frequently observed on a RAP's channel, it is important that you configure a different channel for that RAP to exclude the radar affected channel at the controller.

Examples This example shows to enable full-sector DFS on mesh access points:

```
> config mesh full-sector-dfs enable
```

Related Commands

- config mesh battery-state
- show mesh ap
- show mesh stats
- config mesh alarm
- config mesh linkdata
- config mesh linktest
- config mesh client-access
- config mesh range
- show mesh security-stats
- show mgmtuser

config mesh linkdata

To enable external MAC filtering of access points, use the **config mesh linkdata** command.

config mesh linkdata *destination_ap_name*

Syntax Description

<i>destination_ap_name</i>	Destination access point name for MAC address filtering.

Command Default

Disabled.

Usage Guidelines

Note

The **config mesh linktest** and **config mesh linkdata** commands are designed to be used together to verify information between a source and a destination access point. To get this information, first execute the **config mesh linktest** command with the access point that you want link data from in the *dest_ap* argument. When the command completes, enter the **config mesh linkdata** command and list the same destination access point, to display the link data will display (see example).

MAC filtering uses the local MAC filter on the controller by default.

When external MAC filter authorization is enabled, if the MAC address is not found in the local MAC filter, then the MAC address in the external RADIUS server is used.

MAC filtering protects your network against rogue mesh access points by preventing access points that are not defined on the external server from joining.

Before employing external authentication within the mesh network, the following configuration is required:

- The RADIUS server to be used as an AAA server must be configured on the controller.
- The controller must also be configured on the RADIUS server.
- The mesh access point configured for external authorization and authentication must be added to the user list of the RADIUS server.

Examples

This example shows how to enable external MAC address filtering on access point AP001d.710d.e300:

```
> config mesh linkdata MAP2-1-1522.7400 AP001d.710d.e300 18 100 1000 30
LinkTest started on source AP, test ID: 0
[00:1D:71:0E:74:00]->[00:1D:71:0D:E3:0F]
Test config: 1000 byte packets at 100 pps for 30 seconds, a-link rate 18 Mb/s
In progress: | | | | | | | | | | | | | | | | | |
LinkTest complete
Results
=====
txPkts: 2977
txBuffAllocErr: 0
txQFullErrs: 0
Total rx pkts heard at destination: 2977
rx pkts decoded correctly: 2977
err pkts: Total 0 (PHY 0 + CRC 0 + Unknown 0), TooBig 0, TooSmall 0
rx lost packets: 0 (incr for each pkt seq missed or out of order)
```

```

rx dup pkts:          0
rx out of order:      0
avgSNR:      30, high: 33, low: 3
SNR profile      [0dB...60dB]
    0             6             0             0             0
    0             0             1             2             77
    2888          3             0             0             0
    0             0             0             0             0
(>60dB)          0
avgNf:      -95, high: -67, low: -97
Noise Floor profile [-100dB...-40dB]
    0             2948          19             3             1
    0             0             0             0             0
    3             3             0             0             0
    0             0             0             0             0
(>-40dB)         0
avgRssi:      64, high: 68, low: 63
RSSI profile      [-100dB...-40dB]
    0             0             0             0             0
    0             0             0             0             0
    0             0             0             0             0
    0             0             0             0             0
(>-40dB)         2977
Summary PktFailedRate (Total pkts sent/recvd):          0.000%
Physical layer Error rate (Total pkts with errors/Total pkts heard): 0.000%

```

This example shows how to enable external MAC filtering on access point AP001d.71d.e300:

```
> config mesh linkdata AP001d.710d.e300
```

```

[SD:0,0,0(0,0,0), 0,0, 0,0]
[SD:1,105,0(0,0,0),30,704,95,707]
[SD:2,103,0(0,0,0),30,46,95,25]
[SD:3,105,0(0,0,0),30,73,95,29]
[SD:4,82,0(0,0,0),30,39,95,24]
[SD:5,82,0(0,0,0),30,60,95,26]
[SD:6,105,0(0,0,0),30,47,95,23]
[SD:7,103,0(0,0,0),30,51,95,24]
[SD:8,105,0(0,0,0),30,55,95,24]
[SD:9,103,0(0,0,0),30,740,95,749]
[SD:10,105,0(0,0,0),30,39,95,20]
[SD:11,104,0(0,0,0),30,58,95,23]
[SD:12,105,0(0,0,0),30,53,95,24]
[SD:13,103,0(0,0,0),30,64,95,43]
[SD:14,105,0(0,0,0),30,54,95,27]
[SD:15,103,0(0,0,0),31,51,95,24]
[SD:16,105,0(0,0,0),30,59,95,23]
[SD:17,104,0(0,0,0),30,53,95,25]
[SD:18,105,0(0,0,0),30,773,95,777]
[SD:19,103,0(0,0,0),30,745,95,736]
[SD:20,105,0(0,0,0),30,64,95,54]
[SD:21,103,0(0,0,0),30,747,95,751]
[SD:22,105,0(0,0,0),30,55,95,25]
[SD:23,104,0(0,0,0),30,52,95,35]
[SD:24,105,0(0,0,0),30,134,95,23]
[SD:25,103,0(0,0,0),30,110,95,76]
[SD:26,105,0(0,0,0),30,791,95,788]
[SD:27,103,0(0,0,0),30,53,95,23]
[SD:28,105,0(0,0,0),30,128,95,25]
[SD:29,104,0(0,0,0),30,49,95,24]
[SD:30,0,0(0,0,0), 0,0, 0,0]

```

Related Commands

show mesh config

show mesh ap

show mesh stats

config mesh client-access

config mesh alarm

config mesh linktest
config mesh multicast
show mesh client-access
config mesh ethernet-bridging vlan-transparent
config mesh radius-server

config mesh linktest

To verify client access between mesh access points, use the **config mesh linktest** command.

config mesh linktest *source_ap* {*dest_ap* | *dest_MAC*} *datarate* *packet_rate* *packet_size* *duration*

Syntax Description

<i>source_ap</i>	Source access point.
<i>dest_ap</i>	Destination access point.
<i>dest_MAC</i>	Destination MAC address.
<i>datarate</i>	• Data rate for 802.11a radios. Valid values are 6, 9, 11, 12, 18, 24, 36, 48 and 54 Mbps. • Data rate for 802.11b radios. Valid values are 6, 12, 18, 24, 36, 54, or 100 Mbps. • Data rate for 802.11n radios. Valid values are MCS rates between m0 to m15.
<i>packet_rate</i>	Number of packets per second. Valid range is 1 through 3000, but the recommended default is 100.
<i>packet_size</i>	(Optional) Packet size in bytes. If not specified, packet size defaults to 1500 bytes.
<i>duration</i>	(Optional) Duration of the test in seconds. Valid values are 10-300 seconds, inclusive. If not specified, duration defaults to 30 seconds.

Command Default

100 packets per second, 1500 bytes, 30 second duration.

Usage Guidelines

Note

The **config mesh linktest** and **config mesh linkdata** commands are designed to be used together to verify information between a source and a destination access point. To get this information, first enter the **config mesh linktest** command with the access point that you want link data from in the *dest_ap* argument. When the command completes, enter the **config mesh linkdata** command and list the same destination access point, to display the link data.

The following warning message appears when you run a linktest that might oversubscribe the link:

Warning! Data Rate (100 Mbps) is not enough to perform this link test on packet size (2000bytes) and (1000) packets per second. This may cause AP to disconnect or reboot. Are you sure you want to continue?

Examples

This example shows how to verify client access between mesh access points *SB_MAP1* and *SB_RAP2* at 36 Mbps, 20 fps, 100 frame size, and 15 second duration:

```
> config mesh linktest SB_MAP1 SB_RAP1 36 20 100 15
LinkTest started on source AP, test ID: 0
[00:1D:71:0E:85:00]->[00:1D:71:0E:D0:0F]
Test config: 100 byte packets at 20 pps for 15 seconds, a-link rate 36 Mb/s
In progress: | || || || || || |
LinkTest complete
Results
=====
txPkts:                290
txBuffAllocErr:        0
txQFullErrs:           0
Total rx pkts heard at destination:      290
rx pkts decoded correctly:
  err pkts: Total      0 (PHY 0 + CRC 0 + Unknown 0), TooBig 0, TooSmall 0
  rx lost packets:     0 (incr for each pkt seq missed or out of order)
  rx dup pkts:         0
  rx out of order:     0
avgSNR: 37, high: 40, low: 5
SNR profile [0dB...60dB]
    0      1      0      0      1
    3      0      1      0      2
    8     27    243      4      0
    0      0      0      0      0
(>60dB)    0
avgNf: -89, high: -58, low: -90
Noise Floor profile [-100dB...-40dB]
    0      0      0     145     126
   11      2      0      1      0
    3      0      1      0      1
    0      0      0      0      0
(>-40dB)    0
avgRssi: 51, high: 53, low: 50
RSSI profile [-100dB...-40dB]
    0      0      0      0      0
    0      0      0      0      0
    0      0      0      0      0
    0      7    283      0      0
(>-40dB)    0
Summary PktFailedRate (Total pkts sent/recvd): 0.000%
Physical layer Error rate (Total pkts with errors/Total pkts heard): 0.000%
The following table lists the output flags displayed for the config mesh linktest command.
```

Table 10: Output Flags for the Config Mesh Linktest Command

Output Flag	Description
txPkts	Number of packets sent by the source.
txBuffAllocErr	Number of linktest buffer allocation errors at the source (expected to be zero).
txQFullErrs	Number of linktest queue full errors at the source (expected to be zero).
Total rx pkts heard at destination	Number of linktest packets received at the destination (expected to be same as or close to the txPkts).
rx pkts decoded correctly	Number of linktest packets received and decoded correctly at the destination (expected to be same as close to txPkts).
err pkts: Total	Packet error statistics for linktest packets with errors.

Output Flag	Description
rx lost packets	Total number of linktest packets not received at the destination.
rx dup pkts	Total number of duplicate linktest packets received at the destination.
rx out of order	Total number of linktest packets received out of order at the destination.
avgNF	Average noise floor.
Noise Floor profile	Noise floor profile in dB and are negative numbers.
avgSNR	Average SNR values.
SNR profile [odb...60dB]	Histogram samples received between 0 to 60 dB. The different columns in the SNR profile is the number of packets falling under the bucket 0-3, 3-6, 6-9, up to 57-60.
avgRSSI	Average RSSI values. The average high and low RSSI values are positive numbers.
RSSI profile [-100dB...-40dB]	The RSSI profile in dB and are negative numbers.

Related Commands

config mesh battery-state
config mesh client-access
config mesh full-sector-dfs
config mesh linkdata
config mesh multicast
config mesh range
show mesh client-access
show mesh config
show mesh security-stats
show mesh stats

config mesh lsc

To configure a locally significant certificate (LSC) on mesh access points, use the **config mesh lsc** command.

config mesh lsc {enable | disable}

Syntax Description

enable	Enables an LSC on mesh access points.
disable	Disables an LSC on mesh access points.

Command Default

None.

Examples

This example shows how to enable LSC on mesh access points:

```
> config mesh lsc enable
```

Related Commands

config certificate lsc
show certificate lsc

config mesh multicast

To configure multicast mode settings to manage multicast transmissions within the mesh network, use the **config mesh multicast** command.

config mesh multicast {**regular** | **in** | **in-out**}

Syntax Description		
regular		Multicasts the video across the entire mesh network and all its segments by bridging-enabled root access points (RAPs) and mesh access points (MAPs).
in		Forwards the multicast video received from the Ethernet by a MAP to the RAP's Ethernet network. No additional forwarding occurs, which ensures that non-LWAPP multicasts received by the RAP are not sent back to the MAP Ethernet networks within the mesh network (their point of origin), and MAP-to-MAP multicasts do not occur because they are filtered out
in-out		Configures the RAP and MAP to multicast, but each in a different manner: If multicast packets are received at a MAP over Ethernet, they are sent to the RAP; however, they are not sent to other MAP Ethernets, and the MAP-to-MAP packets are filtered out of the multicast. If multicast packets are received at a RAP over Ethernet, they are sent to all the MAPs and their respective Ethernet networks. See the Usage Guidelines section for more information.

Command Default **In-out** mode.

Usage Guidelines

Multicast for mesh networks cannot be enabled using the controller GUI.

Mesh multicast modes determine how bridging-enabled access points mesh access points (MAPs) and root access points (RAPs) send multicasts among Ethernet LANs within a mesh network. Mesh multicast modes manage non-LWAPP multicast traffic only. LWAPP multicast traffic is governed by a different mechanism.

You can use the controller CLI to configure three mesh multicast modes to manage video camera broadcasts on all mesh access points. When enabled, these modes reduce unnecessary multicast transmissions within the mesh network and conserve backhaul bandwidth.

When using **in-out** mode, it is important to properly partition your network to ensure that a multicast sent by one RAP is not received by another RAP on the same Ethernet segment and then sent back into the network.



Note

If 802.11b clients need to receive CAPWAP multicasts, then multicast must be enabled globally on the controller as well as on the mesh network (by using the **config network multicast global** command). If multicast does not need to extend to 802.11b clients beyond the mesh network, you should disable the global multicast parameter.

Examples

This example shows how to multicast video across the entire mesh network and all its segments by bridging-enabled RAPs and MAPs:

```
> config mesh multicast regular
```

Related Commands

config mesh battery-state
config mesh client-access
config mesh linktest
show mesh ap
config network multicast global
show mesh config
show mesh stats

config mesh parent preferred

To configure a preferred parent for a mesh access point, use the **config mesh parent preferred** command.

config mesh parent preferred *cisco_ap* {*mac_address* | **none**}

Syntax Description

<i>cisco_ap</i>	Name of the child access point.
<i>mac_address</i>	MAC address of the preferred parent.
none	Clears the configured parent.

Command Default

None.

Usage Guidelines

A child AP selects the preferred parent based on the following conditions:

- The preferred parent is the best parent.
- The preferred parent has a link SNR of at least 20 dB (other parents, however good, are ignored).
- The preferred parent has a link SNR in the range of 12 dB and 20 dB, but no other parent is significantly better (that is, the SNR is more than 20 percent better). For an SNR lower than 12 dB, the configuration is ignored.
- The preferred parent is not blacklisted.
- The preferred parent is not in silent mode because of dynamic frequency selection (DFS).
- The preferred parent is in the same bridge group name (BGN). If the configured preferred parent is not in the same BGN and no other parent is available, the child joins the parent AP using the default BGN.

Examples

This example shows how to configure a preferred parent with the MAC address 00:21:1b:ea:36:60 for a mesh access point myap1:

```
> config mesh parent preferred myap1 00:21:1b:ea:36:60
```

This example shows how to clear a preferred parent with the MAC address 00:21:1b:ea:36:60 for a mesh access point myap1, by using the keyword none:

```
> config mesh parent preferred myap1 00:21:1b:ea:36:60 none
```

Related Commands

config mesh battery-state
config mesh client-access
config mesh linktest
show mesh ap
config network multicast global

show mesh config

show mesh stats

config mesh public-safety

To enable or disable the 4.9-GHz public safety band for mesh access points, use the **config mesh public-safety** command.

config mesh public-safety {enable | disable} {all | cisco_ap}

Syntax Description

enable	Enables the 4.9-GHz public safety band.
disable	Disables the 4.9-GHz public safety band.
all	Applies the command to all mesh access points.
<i>cisco_ap</i>	Specific mesh access point.

Command Default

Disabled.

Usage Guidelines

4.9 GHz is a licensed frequency band restricted to public-safety personnel.

Examples

This example shows how to enable the 4.9-GHz public safety band for all mesh access points:

```
> config mesh public-safety enable all
4.9GHz is a licensed frequency band in -A domain for public-safety usage
Are you sure you want to continue? (y/N) y
```

Related Commands

config mesh range
config mesh security
show mesh ap
show mesh public-safety
show mesh security-stats
show mesh config
show mesh stats

config mesh radius-server

To enable or disable external authentication for mesh access points, use the **config mesh radius-server** command.

config mesh radius-server *index* {**enable** | **disable**}

Syntax Description

<i>index</i>	RADIUS authentication method. Options are as follows: - Enter eap to designate Extensible Authentication Protocol (EAP) for the mesh RADIUS server setting. - Enter psk to designate Preshared Keys (PSKs) for the mesh RADIUS server setting.
enable	Enables the external authentication for mesh access points.
disable	Disables the external authentication for mesh access points.

Command Default

EAP is enabled by default.

Examples

This example shows how to enable external authentication for mesh access points:

```
> config mesh radius-server eap enable
```

Related Commands

config mesh alarm
config mesh security
show mesh ap
show mesh security-stats
show mesh stats

config mesh range

To globally set the maximum range between outdoor mesh root access points (RAPs) and mesh access points (MAPs), use the **config mesh range** command.

config mesh range [*distance*]

Syntax Description

<i>distance</i>	(Optional) Maximum operating range (150 to 132000 ft) of the mesh access point.

Command Default

12,000 feet.

Usage Guidelines

After this command is enabled, all outdoor mesh access points reboot. This command does not affect indoor access points.

Examples

This example shows how to set the range between an outdoor mesh RAP and a MAP:

```
> config mesh range 300
Command not applicable for indoor mesh. All outdoor Mesh APs will be rebooted
Are you sure you want to start? (y/N) y
```

Related Commands

- config mesh astools**
- config mesh ethernet-bridging vlan-transparent**
- show mesh ap**
- config mesh full-sector-dfs**
- config mesh linkdata**
- config mesh linktest**
- show mesh config**
- show mesh stats**

config mesh secondary-backhaul

To configure a secondary backhaul on the mesh network, use the **config mesh secondary-backhaul** command.

config mesh secondary-backhaul {enable [force-same-secondary-channel] | disable [rll-retransmit | rll-transmit]}

Syntax Description

enable	Enables the secondary backhaul configuration.
force-same-secondary-channel	(Optional) Enables secondary-backhaul mesh capability. Forces all access points rooted at the first hop node to have the same secondary channel and ignores the automatic or manual channel assignments for the mesh access points (MAPs) at the second hop and beyond.
disable	Specifies the secondary backhaul configuration is disabled.
rll-transmit	(Optional) Uses reliable link layer (RLL) at the second hop and beyond.
rll-retransmit	(Optional) Extends the number of RLL retry attempts in an effort to improve reliability.

Command Default

None.

Usage Guidelines

Note

The secondary backhaul access feature is not supported by Cisco 1520 and 1524 indoor mesh access points in the 5.2 release.

This command uses a secondary backhaul radio as a temporary path for traffic that cannot be sent on the primary backhaul due to intermittent interference.

Examples

This example shows how to enable a secondary backhaul radio and force all access points rooted at the first hop node to have the same secondary channel:

```
> config mesh secondary-backhaul enable force-same-secondary-channel
```

Related Commands

config mesh battery-state
config mesh backhaul slot
show mesh client-access
show mesh config
show mesh stats

config mesh security

To configure the security settings for mesh networks, use the **config mesh security** command.

config mesh security {{{rad-mac-filter | force-ext-auth} {enable | disable}} | eap | psk}

Syntax Description

rad-mac-filter	Enables a RADIUS MAC address filter for the mesh security setting.
force-ext-auth	Disables forced external authentication for the mesh security setting.
enable	Enables the setting.
disable	Disables the setting.
eap	Designates the Extensible Authentication Protocol (EAP) for the mesh security setting.
psk	Designates preshared keys (PSKs) for the mesh security setting.

Command Default

EAP.

Examples

This example shows how to configure EAP as the security option for all mesh access points:

```
> config mesh security eap
```

This example shows how to configure PSK as the security option for all mesh access points:

```
> config mesh security psk
```

Related Commands

config mesh alarm
config mesh client-access
show mesh ap
config mesh public-safety
show mesh security-stats
show mesh config
show mesh stats
config mesh radius-server
show mesh client-access

config mesh slot-bias

To enable or disable slot bias for serial backhaul mesh access points, use the **config mesh slot-bias** command.

config mesh slot-bias {enable | disable}

Syntax Description

enable	Enables slot bias for serial backhaul mesh APs.
disable	Disables slot bias for serial backhaul mesh APs.

Command Default

By default, slot bias is in enabled state.

Usage Guidelines

Follow these guidelines when using this command:

- The **config mesh slot-bias** command is a global command and therefore applicable to all 1524SB APs associated with the same controller.
- Slot bias is applicable only when both slot 1 and slot 2 are available. If a slot radio does not have a channel that is available because of dynamic frequency selection (DFS), the other slot takes up both the uplink and downlink roles.
- If slot 2 is not available because of hardware issues, slot bias functions normally. Corrective action should be taken by disabling the slot bias or fixing the antenna.

Examples

This example shows how to disable slot bias for serial backhaul mesh APs:

```
> config mesh slot-bias disable
```

Related Commands

config mesh alarm
config mesh client-access
show mesh ap
config mesh public-safety
show mesh security-stats
show mesh config
show mesh stats
config mesh radius-server
show mesh client-access

config lsc mesh

To enable the locally significant certificate (LSC) on mesh access points, use the **config lsc mesh** command.

config lsc mesh {enable | disable}

Syntax Description

enable	Enables LSC on mesh access points.
disable	Disables LSC on mesh access points.

Command Default

None.

Examples

This example shows how to enable LSC on mesh access point:

```
> config lsc mesh enable
```

Related Commands

show loginsession

debug Commands

This section describes the controller **debug** commands to troubleshoot Mesh access points.



Caution

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug mesh security

To configure the debugging of mesh security problems, use the **debug mesh security** command.

debug mesh security {all | events | errors} {enable | disable}

Syntax Description

all	Configures the debugging of all mesh security messages.
events	Configures the debugging of mesh security event messages.
errors	Configures the debugging of mesh security error messages.
enable	Enables the debugging of mesh security error messages.
disable	Disables the debugging of mesh security error messages.

Command Default

None.

Examples

This example shows how to enable the debugging of mesh security error messages:

```
> debug mesh security errors enable
```

Related Commands

config mesh security
show mesh security-stats



PART **VIII**

Radio Resource Management Commands

- [CLI Commands, page 1459](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 1459](#)
- [config Commands, page 1475](#)
- [Configuring 802.11k and Assisted Roaming, page 1559](#)
- [debug Commands, page 1563](#)

show Commands

This section lists the **show** commands to display information about your Radio Resource Management (RRM) configuration settings.

show 802.11 extended

To display access point radio extended configurations, use the **show 802.11 extended** command.

show 802.11 {a | b} extended

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>extended</i>	Displays the 802.11a/b radio extended configurations.

Command Default

None.

Examples

This example shows how to display radio extended configurations:

```
> show 802.11a extended
Default 802.11a band radio extended configurations:
    beacon period 300, range 60;
    multicast buffer 45, rate 200;
    RX SOP -80; CCA threshold -90;
AP0022.9090.b618 00:24:97:88:99:60
    beacon period 300, range 60; multicast buffer 45, rate 200;
    RX SOP -80; CCA threshold -77
AP0022.9090.bb3e 00:24:97:88:c5:d0
    beacon period 300, range 0; multicast buffer 0, rate 0;
    RX SOP -80; CCA threshold -0
ironRap.ddbf 00:17:df:36:dd:b0
    beacon period 300, range 0; multicast buffer 0, rate 0;
    RX SOP -80; CCA threshold -0
```

show advanced 802.11 channel

To display the automatic channel assignment configuration and statistics, use the **show advanced 802.11 channel** command.

show advanced 802.11 {a | b} channel

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the automatic channel assignment configuration and statistics:

```
> show advanced 802.11a channel
Automatic Channel Assignment
Channel Assignment Mode..... AUTO
Channel Update Interval..... 600 seconds [startup]
Anchor time (Hour of the day)..... 0
Channel Update Contribution..... SNI.
Channel Assignment Leader..... 00:1a:6d:dd:1e:40
Last Run..... 129 seconds ago
DCA Sensitivity Level: ..... STARTUP (5 dB)
DCA Minimum Energy Limit..... -95 dBm
Channel Energy Levels
  Minimum..... unknown
  Average..... unknown
  Maximum..... unknown
Channel Dwell Times
  Minimum..... unknown
  Average..... unknown
  Maximum..... unknown
Auto-RF Allowed Channel List..... 36,40,44,48,52,56,60,64,149,
  ..... 153,157,161
Auto-RF Unused Channel List..... 100,104,108,112,116,132,136,
  ..... 140,165,190,196
DCA Outdoor AP option..... Enabled
```

Related Commands

config advanced 802.11 channel add
config advanced 802.11 channel cleanair-event
config advanced 802.11 channel dca anchor-time
config advanced 802.11 channel dca chan-width-11n
config advanced 802.11 channel dca interval
config advanced 802.11 channel dca sensitivity
config advanced 802.11 channel foreign
config advanced 802.11 channel load

show advanced 802.11 coverage

To display the configuration and statistics for coverage hole detection, use the **show advanced 802.11 coverage** command.

show advanced 802.11 {a | b} coverage

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the statistics for coverage hole detection:

```
> show advanced 802.11a coverage
Coverage Hole Detection
 802.11a Coverage Hole Detection Mode..... Enabled
 802.11a Coverage Voice Packet Count..... 100 packets
 802.11a Coverage Voice Packet Percentage..... 50%
 802.11a Coverage Voice RSSI Threshold..... -80 dBm
 802.11a Coverage Data Packet Count..... 50 packets
 802.11a Coverage Data Packet Percentage..... 50%
 802.11a Coverage Data RSSI Threshold..... -80 dBm
 802.11a Global coverage exception level..... 25 %
 802.11a Global client minimum exception lev.... 3 clients
```

Related Commands

config advanced 802.11 coverage
config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate
config advanced 802.11 coverage level global
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage rssi-threshold
show advanced 802.11 coverage

show advanced 802.11 group

To display 802.11a or 802.11b Cisco radio RF grouping, use the **show advanced 802.11 group** command.

show advanced 802.11 {a | b} group

Syntax Description		
a		Specifies the 802.11a network.
b		Specifies the 802.11b/g network.

Command Default None.

Examples This example shows how to display Cisco radio RF group settings:

```
> show advanced 802.11a group
Radio RF Grouping
 802.11a Group Mode..... AUTO
 802.11a Group Update Interval..... 600 seconds
 802.11a Group Leader..... xx:xx:xx:xx:xx:xx
   802.11a Group Member..... xx:xx:xx:xx:xx:xx
 802.11a Last Run..... 133 seconds ago
```

Related Commands **config advanced 802.11 group-mode**

show advanced 802.11 l2roam

To display 802.11a or 802.11b/g Layer 2 client roaming information, use the **show advanced 802.11 l2roam** command.

show advanced 802.11 {a | b} l2roam {rf-param | statistics} mac_address

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
rf-param	Specifies the Layer 2 frequency parameters.
statistics	Specifies the Layer 2 client roaming statistics.
<i>mac_address</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to display 802.11b Layer 2 client roaming information:

```
> show advanced 802.11b l2roam rf-param

L2Roam 802.11bg RF Parameters.....
  Config Mode..... Default
  Minimum RSSI..... -85
  Roam Hysteresis..... 2
  Scan Threshold..... -72
  Transition time..... 5
```

Related Commands

config 802.11 l2roam rf-params

show advanced 802.11 logging

To display 802.11a or 802.11b RF event and performance logging, use the **show advanced 802.11 logging** command.

show advanced 802.11 {a | b} logging

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display 802.11b RF event and performance logging:

```
> show advanced 802.11b logging
RF Event and Performance Logging
Channel Update Logging..... Off
Coverage Profile Logging..... Off
Foreign Profile Logging..... Off
Load Profile Logging..... Off
Noise Profile Logging..... Off
Performance Profile Logging..... Off
TxPower Update Logging..... Off
```

Related Commands

config advanced 802.11 logging channel
config advanced 802.11 logging coverage
config advanced 802.11 logging foreign
config advanced 802.11 logging load
config advanced 802.11 logging noise
config advanced 802.11 logging performance
show advanced 802.11 channel

show advanced 802.11 monitor

To display the 802.11a or 802.11b default Cisco radio monitoring, use the **show advanced 802.11 monitor** command.

show advanced 802.11 {a | b} monitor

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the radio monitoring for the 802.11b network:

```
> show advanced 802.11b monitor
Default 802.11b AP monitoring
 802.11b Monitor Mode..... enable
 802.11b Monitor Channels..... Country channels
 802.11b RRM Neighbor Discovery Type..... Transparent
 802.11b AP Coverage Interval..... 180 seconds
 802.11b AP Load Interval..... 60 seconds
 802.11b AP Noise Interval..... 180 seconds
 802.11b AP Signal Strength Interval..... 60 seconds
```

Related Commands

config advanced 802.11 monitor load
config advanced 802.11 monitor mode
config advanced 802.11 monitor noise
config advanced 802.11 monitor signal

show advanced 802.11 profile

To display the 802.11a or 802.11b lightweight access point performance profiles, use the **show advanced 802.11 profile** command.

show advanced 802.11 {a | b} profile {global | cisco_ap}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Specifies all Cisco lightweight access points.
<i>cisco_ap</i>	Name of a specific Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
> show advanced 802.11 profile global
Default 802.11a AP performance profiles
 802.11a Global Interference threshold..... 10%
 802.11a Global noise threshold..... -70 dBm
 802.11a Global RF utilization threshold..... 80%
 802.11a Global throughput threshold..... 1000000 bps
 802.11a Global clients threshold..... 12 clients
 802.11a Global coverage threshold..... 12 dB
 802.11a Global coverage exception level..... 80%
 802.11a Global client minimum exception lev..... 3 clients
```

This example shows how to display the configuration and statistics of a specific access point profile:

```
> show advanced 802.11 profile AP1
Cisco AP performance profile not customized
```

This response indicates that the performance profile for this lightweight access point is using the global defaults and has not been individually configured.

Related Commands

config advanced 802.11 profile clients
config advanced 802.11 profile customize
config advanced 802.11 profile foreign
config advanced 802.11 profile noise

show advanced 802.11 receiver

To display the configuration and statistics of the 802.11a or 802.11b receiver, use the **show advanced 802.11 receiver** command.

show advanced 802.11 {a | b} receiver

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the configuration and statistics of the 802.11a network settings:

```
> show advanced 802.11 receiver
802.11a Receiver Settings
RxStart   : Signal Threshold..... 15
RxStart   : Signal Lamp Threshold..... 5
RxStart   : Preamble Power Threshold..... 2
RxReStart : Signal Jump Status..... Enabled
RxReStart : Signal Jump Threshold..... 10
TxStomp   : Low RSSI Status..... Enabled
TxStomp   : Low RSSI Threshold..... 30
TxStomp   : Wrong BSSID Status..... Enabled
TxStomp   : Wrong BSSID Data Only Status..... Enabled
RxAbort   : Raw Power Drop Status..... Disabled
RxAbort   : Raw Power Drop Threshold..... 10
RxAbort   : Low RSSI Status..... Disabled
RxAbort   : Low RSSI Threshold..... 0
RxAbort   : Wrong BSSID Status..... Disabled
RxAbort   : Wrong BSSID Data Only Status..... Disabled
```

Related Commands

config advanced 802.11 profile clients

show advanced 802.11 summary

To display the 802.11a or 802.11b Cisco lightweight access point name, channel, and transmit level summary, use the **show advanced 802.11 summary** command.

show advanced 802.11 {a | b} summary

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display a summary of the 802.11b access point settings:

```
> show advanced 802.11b summary
AP Name      MAC Address      Admin State  Operation State  Channel TxPower
-----
CJ-1240      00:21:1b:ea:36:60  ENABLED      UP                161      1 ( )
CJ-1130      00:1f:ca:cf:b6:60  ENABLED      UP                56*      1 (*)
```



Note

An asterisk (*) next to a channel number or power level indicates that it is being controlled by the global algorithm settings.

Related Commands

config advanced 802.11 7920VSIEConfig
config advanced 802.11 channel add
config advanced 802.11 channel

show advanced 802.11 txpower

To display the 802.11a or 802.11b automatic transmit power assignment, use the **show advanced 802.11 txpower** command.

show advanced 802.11 {a | b} txpower

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the configuration and statistics of the 802.11b transmit power cost:

```
> show advanced 802.11b txpower
Automatic Transmit Power Assignment
  Transmit Power Assignment Mode..... AUTO
  Transmit Power Update Interval..... 600 seconds
  Transmit Power Threshold..... -65 dBm
  Transmit Power Neighbor Count..... 3 APs
  Transmit Power Update Contribution..... SN.
  Transmit Power Assignment Leader..... xx:xx:xx:xx:xx:xx
  Last Run..... 384 seconds ago
```

Related Commands

config advanced 802.11 txpower-update

show advanced dot11-padding

To display the state of over-the-air frame padding on a wireless LAN controller, use the **show advanced dot11-padding** command.

show advanced dot11-padding

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to view the state of over-the-air frame padding:

```
> show advanced dot11-padding
dot11-padding..... Disabled
```

Related Commands	config advanced dot11-padding debug dot11 debug dot11 mgmt interface debug dot11 mgmt msg debug dot11 mgmt ssid debug dot11 mgmt state-machine debug dot11 mgmt station

show client ccx rm

To display Cisco Client eXtension (CCX) client radio management report information, use the **show client ccx rm** command.

show client ccx rm *client_MAC* {**status** | {**report** {**chan-load** | **noise-hist** | **frame** | **beacon** | **pathloss**}}}

Syntax Description

<i>client_MAC</i>	Client MAC address.
status	Displays the client CCX radio management status information.
report	Displays the client CCX radio management report.
chan-load	Displays radio management channel load reports.
noise-hist	Displays radio management noise histogram reports.
beacon	Displays radio management beacon load reports.
frame	Displays radio management frame reports.
pathloss	Displays radio management path loss reports.

Command Default

None.

Examples

This example shows how to display the client radio management status information:

```
> show client ccx rm 00:40:96:15:21:ac status
Client Mac Address..... 00:40:96:15:21:ac
Channel Load Request..... Enabled
Noise Histogram Request..... Enabled
Beacon Request..... Enabled
Frame Request..... Enabled
Interval..... 30
Iteration..... 10
```

This example shows how to display the client radio management load reports:

```
> show client ccx rm 00:40:96:15:21:ac report chan-load
Channel Load Report
Client Mac Address..... 00:40:96:ae:53:bc
Timestamp..... 788751121
Incapable Flag..... On
Refused Flag..... On
Chan CCA Busy Fraction
-----
1 194
2 86
3 103
```

```

4  0
5  178
6  82
7  103
8  95
9  13
10 222
11 75

```

This example shows how to display the client radio management noise histogram reports:

```

> show client ccx rm 00:40:96:15:21:ac report noise-hist
Noise Histogram Report
Client Mac Address..... 00:40:96:15:21:ac
Timestamp..... 4294967295
Incapable Flag..... Off
Refused Flag..... Off
Chan RPI0 RPI1 RPI2 RPI3 RPI4 RPI5 RPI6 RPI7

```

Related Commands

```

config client ccx default-gw-ping
config client ccx dhcp-test

```

show client location-calibration summary

To display client location calibration summary information, use the **show client location-calibration summary** command.

show client location-calibration summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the location calibration summary information:

```
> show client location-calibration summary
MAC Address Interval
-----
10:10:10:10:10:10 60
21:21:21:21:21:21 45
```

Related Commands

- show client summary**
- show client summary guest-lan**

show wps ap-authentication summary

To display the access point neighbor authentication configuration on the controller, use the **show wps ap-authentication summary** command.

show wps ap-authentication summary

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display a summary of the Wireless Protection System (WPS) access point neighbor authentication:

```
> show wps ap-authentication summary
AP neighbor authentication is <disabled>.
Authentication alarm threshold is 1.
RF-Network Name: <B1>
```

Related Commands	config wps ap-authentication

config Commands

This section lists the **config** commands to configure Radio Resource Management (RRM).

config 802.11-a

To enable or disable the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a** command.

config {**802.11-a49** | **802.11-a58**} {**enable** | **disable**} *cisco_ap*

Syntax Description	802.11-a49	Specifies the 4.9-GHz public safety channel.
	802.11-a58	Specifies the 5.8-GHz public safety channel.
	enable	Enables the use of this frequency on the designated access point.
	disable	Disables the use of this frequency on the designated access point.
	<i>cisco_ap</i>	Name of the access point to which the command applies.

Command Default Disabled.

Examples This example shows how to enable the 4.9-GHz public safety channel on ap_24 access point:

```
> config 802.11-a
```

Related Commands

- show mesh public-safety
- config 802.11-a antenna extAntGain
- config 802.11-a txpower ap
- config 802.11-a channel ap

config 802.11-a antenna extAntGain

To configure the external antenna gain for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a antenna extAntGain** commands.

config {802.11-a49 | 802.11-a58} antenna extAntGain *ant_gain* *cisco_ap* {global | *channel_no*}

Syntax Description		
802.11-a49		Specifies the 4.9-GHz public safety channel.
802.11-a58		Specifies the 5.8-GHz public safety channel.
<i>ant_gain</i>		Value in .5-dBi units (for instance, 2.5 dBi = 5).
<i>cisco_ap</i>		Name of the access point to which the command applies.
global		Specifies the antenna gain value to all channels.
<i>channel_no</i>		Antenna gain value for a specific channel.

Command Default Disabled.

Usage Guidelines

Before you enter the **config 802.11-a antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11-a disable** command.

After you configure the external antenna gain, use the **config 802.11-a enable** command to reenable the 802.11 Cisco radio.

Examples This example shows how to configure an 802.11-a49 external antenna gain of 10 dBi for AP1:

```
> config 802.11-a antenna extAntGain 10 AP1
```

Related Commands

- config 802.11-a
- config 802.11-a channel ap
- config 802.11-a txpower ap
- show 802.11a

config 802.11-a channel ap

To configure the channel properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a channel ap** command.

config {802.11-a49 | 802.11-a58} **channel ap** *cisco_ap* {**global** | *channel_no*}

Syntax Description

802.11-a49	Specifies the 4.9-GHz public safety channel.
802.11-a58	Specifies the 5.8-GHz public safety channel.
<i>cisco_ap</i>	Name of the access point to which the command applies.
global	Enables the Dynamic Channel Assignment (DCA) on all 4.9-GHz and 5.8-GHz subband radios.
<i>channel_no</i>	Custom channel for a specific mesh access point. The range is 1 through 26, inclusive, for a 4.9-GHz band and 149 through 165, inclusive, for a 5.8-GHz band.

Command Default

Disabled.

Examples

This example shows how to set the channel properties:

```
> config 802.11-a channel ap
```

Related Commands

config 802.11-a
config 802.11-a antenna extAntGain
config 802.11-a txpower ap

config 802.11-a txpower ap

To configure the transmission power properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a txpower ap** command.

config {802.11-a49 | 802.11-a58} txpower ap *cisco_ap* {global | *power_level*}

Syntax Description		
802.11-a49		Specifies the 4.9-GHz public safety channel.
802.11-a58		Specifies the 5.8-GHz public safety channel.
txpower		Configures transmission power properties.
ap		Configures access point channel settings.
<i>cisco_ap</i>		Name of the access point to which the command applies.
global		Applies the transmission power value to all channels.
<i>power_level</i>		Transmission power value to the designated mesh access point. The range is from 1 to 5.

Command Default Disabled.

Examples This example shows how to configure an 802.11-a49 transmission power level of 4 for AP1:

```
> config 802.11-a txpower ap 4 AP1
```

Related Commands

- config 802.11-a
- config 802.11 channel ap
- config 802.11 antenna extAntGain

config 802.11-abgn

To configure dual-band radio parameters on an access point, use the **config 802.11-abgn** command.

config 802.11-abgn {**cleanair** {**enable** | **disable**} {*cisco_ap* **band** *band*} | {**enable** | **disable**} {*cisco_ap*}}

Syntax Description

cleanair	Configures CleanAir on the dual-band radio.
enable	Enables CleanAir for both 2.4-GHz and 5-GHz radios.
disable	Disables CleanAir for both 2.4-GHz and 5-GHz radios.
<i>cisco_ap</i>	Name of the access point to which the command applies.
band	Configures the radio band.
<i>band</i>	Radio band that can be 2.4-GHz or 5-GHz.
enable	Enables the dual-band radio on an access point.
disable	Disables the dual-band radio on an access point.

Command Default

None.

Usage Guidelines

Only Cisco CleanAir-enabled access point radios can be configured for Cisco CleanAir.

Examples

This example shows how to enable Cisco CleanAir on an access point:

```
> config 802.11-abgn cleanair enable AP3600 band 5
```

Related Commands

config 802.11-a49
config 802.11-a58
config 802.11a
config 802.11b
config 802.11h

config 802.11b 11gSupport

To enable or disable the Cisco wireless LAN solution 802.11g network, use the **config 802.11b 11gSupport** command.

config 802.11b 11gSupport {enable | disable}

Syntax Description

enable	Enables the 802.11g network.
disable	Disables the 802.11g network.

Command Default

Enabled.

Usage Guidelines

Before you enter the **config 802.11b 11gSupport {enable | disable}** command, disable the 802.11 Cisco radio with the **config 802.11 disable** command.

After you configure the support for the 802.11g network, use the **config 802.11 enable** command to enable the 802.11 radio.



Note

To disable an 802.11a, 802.11b and/or 802.11g network for an individual wireless LAN, use the **config wlan radio** command.

Examples

This example shows how to enable the 802.11g network:

```
> config 802.11b 11gSupport enable
Changing the 11gSupport will cause all the APs to reboot when you enable 802.11b network.
Are you sure you want to continue? (y/n) n
11gSupport not changed!
```

Related Commands

show sysinfo
show 802.11b
config 802.11b enable
config wlan radio
config 802.11b disable
config 802.11a disable
config 802.11a enable

config 802.11b preamble

To change the 802.11b preamble as defined in subclause 18.2.2.2 to **long** (slower, but more reliable) or **short** (faster, but less reliable), use the **config 802.11b preamble** command.

config 802.11b preamble {long | short}

Syntax Description

long	Specifies the long 802.11b preamble.
short	Specifies the short 802.11b preamble.

Command Default

Short.

Usage Guidelines

Note

You must reboot the Cisco Wireless LAN Controller (reset system) with save to implement this command.

This parameter must be set to **long** to optimize this Cisco wireless LAN controller for some clients, including SpectraLink NetLink telephones.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to change the 802.11b preamble to short:

```
> config 802.11b preamble short
> (reset system with save)
```

Related Commands

show 802.11b

config 802.11h channelswitch

To configure a 802.11h channel switch announcement, use the **config 802.11h channelswitch** command.

config 802.11h channelswitch {*enable mode value* | **disable**}

Syntax Description

enable	Enables the 802.11h channel switch announcement.
<i>mode</i>	802.11h channel switch announcement mode.
<i>value</i>	802.11h channel announcement value.
disable	Disables the 802.11h channel switch announcement.

Command Default

None.

Examples

This example shows how to disable the 802.11h switch announcement:

```
> config 802.11h channelswitch disable
```

Related Commands

show 802.11h

config 802.11h powerconstraint

To configure the 802.11h power constraint value, use the **config 802.11h powerconstraint** command.

config 802.11h powerconstraint *value*

Syntax Description

<i>value</i>	802.11h power constraint value.

Command Default

None.

Examples

This example shows how to configure the 802.11h power constraint to 5:

```
> config 802.11h powerconstraint 5
```

Related Commands

show 802.11h

config 802.11h setchannel

To configure a new channel using 802.11h channel announcement, use the **config 802.11h setchannel** command.

config 802.11h setchannel *cisco_ap*

Syntax	Description
<i>cisco_ap</i>	Cisco lightweight access point name.

Command	Default
	None.

Examples
This example shows how to configure a new channel using the 802.11h channel: > config 802.11h setchannel ap02

Related Commands
show 802.11h

config 802.11 11nsupport

To enable 802.11n support on the network, use the **config 802.11 11nsupport** command.

config 802.11 {a | b} 11nsupport {enable | disable}

Syntax Description

a	Specifies the 802.11a network settings.
b	Specifies the 802.11b/g network settings.
enable	Enables the 802.11n support.
disable	Disables the 802.11n support.

Command Default

None.

Examples

This example shows how to enable the 802.11n support on an 802.11a network:

```
> config 802.11a 11nsupport enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11 11nsupport a-mpdu tx priority
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport a-mpdu tx priority

To specify the aggregation method used for 802.11n packets, use the **config 802.11 11nsupport a-mpdu tx priority** command.

config 802.11 {a | b} 11nsupport a-mpdu tx priority {0-7 | all} {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
0-7	Specifies the aggregated MAC protocol data unit priority level between 0 through 7.
all	Configures all of the priority levels at once.
enable	Specifies the traffic associated with the priority level uses A-MPDU transmission.
disable	Specifies the traffic associated with the priority level uses A-MSDU transmission.

Command Default

By default, Priority 0 is enabled.

Usage Guidelines

Aggregation is the process of grouping packet data frames together rather than transmitting them separately. Two aggregation methods are available: Aggregated MAC Protocol Data Unit (A-MPDU) and Aggregated MAC Service Data Unit (A-MSDU). A-MPDU is performed in the software whereas A-MSDU is performed in the hardware.

Aggregated MAC Protocol Data Unit priority levels assigned per traffic type are as follows:

- 1—Background
- 2—Spare
- 0—Best effort
- 3—Excellent effort
- 4—Controlled load
- 5—Video, less than 100-ms latency and jitter
- 6—Voice, less than 10-ms latency and jitter
- 7—Network control
- all—Configure all of the priority levels at once.



Note

Configure the priority levels to match the aggregation method used by the clients.

Examples

This example shows how to configure all the priority levels at once so that the traffic associated with the priority level uses A-MSDU transmission:

```
> config 802.11a 11nsupport a-mpdu tx priority all enable
```

Related Commands

config 802.11 11nsupport mcs tx

config 802.11a disable network

config 802.11a disable

config 802.11a channel ap

config 802.11a txpower ap

config 802.11 11nsupport a-mpdu tx scheduler

To configure the 802.11n-5 GHz A-MPDU transmit aggregation scheduler, use the **config 802.11 11nsupport a-mpdu tx scheduler** command.

config 802.11 {a | b} 11nsupport a-mpdu tx scheduler {enable | disable | timeout rt timeout-value}

Syntax Description	enable	Enables the 802.11n-5 GHz A-MPDU transmit aggregation scheduler.
	disable	Disables the 802.11n-5 GHz A-MPDU transmit aggregation scheduler.
	timeout rt	Configures the A-MPDU transmit aggregation scheduler realtime traffic timeout.
	<i>timeout-value</i>	Timeout value in milliseconds. The valid range is between 1 millisecond to 1000 milliseconds.

Command Default None.

Usage Guidelines Ensure that the 802.11 network is disabled before you enter this command.

Examples This example shows how to configure the A-MPDU transmit aggregation scheduler realtime traffic timeout of 100 milliseconds:

```
> config 802.11 11nsupport a-mpdu tx scheduler timeout rt 100
```

Related Commands

- config 802.11 11nsupport mcs tx
- config 802.11a disable network
- config 802.11a channel ap
- config 802.11a txpower ap
- config 802.11a chan_width

config 802.11 11nsupport antenna

To configure an access point to use a specific antenna, use the **config 802.11 11nsupport antenna** command.

config 802.11 {a | b} 11nsupport antenna *cisco_ap* {A | B | C | D} {enable | disable}

Syntax Description

a	Specifies the 802.11a/n network.
b	Specifies the 802.11b/g/n network.
<i>cisco_ap</i>	Access point.
A/B/C/D	Specifies an antenna port.
enable	Enables the configuration.
disable	Disables the configuration.

Command Default

None.

Examples

This example shows how to configure transmission to a single antenna for legacy orthogonal frequency-division multiplexing:

```
> config 802.11 11nsupport antenna AP1 C enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11nsupport guard-interval

To configure the guard interval, use the **config 802.11 11nsupport guard-interval** command.

config 802.11 {a | b} 11nsupport guard-interval {any | long}

Syntax Description

any	Enables either a short or a long guard interval.
long	Enables only a long guard interval.

Command Default

None.

Examples

This example shows how to configure a long guard interval:

```
> config 802.11 11nsupport guard-interval long
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 11n support mcs tx

To specify the modulation and coding scheme (MCS) rates at which data can be transmitted between the access point and the client, use the **config 802.11 11n support mcs tx** command.

config 802.11 {a | b} 11n support mcs tx {0-15} {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
11n support	Specifies support for 802.11n devices.
mcs tx	Specifies the modulation and coding scheme data rates as follows: • 0 (7 Mbps) • 1 (14 Mbps) • 2 (21 Mbps) • 3 (29 Mbps) • 4 (43 Mbps) • 5 (58 Mbps) • 6 (65 Mbps) • 7 (72 Mbps) • 8 (14 Mbps) • 9 (29 Mbps) • 10 (43 Mbps) • 11 (58 Mbps) • 12 (87 Mbps) • 13 (116 Mbps) • 14 (130 Mbps) • 15 (144 Mbps)
enable	Enables this configuration.
disable	Disables this configuration.

Command Default

None.

Examples

This example shows how to specify MCS rates:

```
> config 802.11a 11nsupport mcs tx 5 enable
```

Related Commands

- config 802.11 11nsupport
- config wlan wmm required
- config 802.11 11nsupport a-mpdu tx priority
- config 802.11a disable network
- config 802.11a disable
- config 802.11a channel ap
- config 802.11a txpower ap
- config 802.11a chan_width

config 802.11 11nsupport rifs

To configure the Reduced Interframe Space (RIFS) between data frames and its acknowledgment, use the **config 802.11 11nsupport rifs** command.

config 802.11 {a | b} 11nsupport rifs {enable | disable}

Syntax Description

enable	Enables RIFS for the 802.11 network.
disable	Disables RIFS for the 802.11 network.

Command Default

None.

Examples

This example shows how to enable RIFS:

```
> config 802.11a 11nsupport rifs enable
```

Related Commands

config 802.11 11nsupport mcs tx
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11a txpower ap
config 802.11a chan_width

config 802.11 antenna diversity

To configure the diversity option for 802.11 antennas, use the **config 802.11 antenna diversity** command.

config 802.11 {a | b} antenna diversity {enable | sideA | sideB} *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the diversity.
sideA	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point left port.
sideB	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point right port.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to enable antenna diversity for AP01 on an 802.11b network:

```
> config 802.11a antenna diversity enable AP01
```

This example shows how to enable diversity for AP01 on an 802.11a network, using an external antenna connected to the Cisco lightweight access point left port (sideA):

```
> config 802.11a antenna diversity sideA AP01
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna mode
config 802.11 antenna selection
show 802.11a
show 802.11b

config 802.11 antenna extAntGain

To configure external antenna gain for an 802.11 network, use the **config 802.11 antenna extAntGain** command.

config 802.11 {a | b} antenna extAntGain *antenna_gain cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>antenna_gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Usage Guidelines

Before you enter the **config 802.11 antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11 disable** command.

After you configure the external antenna gain, use the **config 802.11 enable** command to enable the 802.11 Cisco radio.

Examples

This example shows how to configure an *802.11a* external antenna gain of *0.5 dBm* for *AP1*:

```
> config 802.11 antenna extAntGain 1 AP1
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna mode
config 802.11 antenna selection
show 802.11a
show 802.11b

config 802.11 antenna mode

To configure the Cisco lightweight access point to use one internal antenna for an 802.11 sectorized 180-degree coverage pattern or both internal antennas for an 802.11 360-degree omnidirectional pattern, use the **config 802.11 antenna mode** command.

```
config 802.11 {a | b} antenna mode {omni | sectorA | sectorB} cisco_ap
```

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
omni	Specifies to use both internal antennas.
sectorA	Specifies to use only the side A internal antenna.
sectorB	Specifies to use only the side B internal antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure access point AP01 antennas for a 360-degree omnidirectional pattern on an 802.11b network:

```
> config 802.11 antenna mode omni AP01
```

Related Commands

```
config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna diversity
config 802.11 antenna selection
show 802.11a
show 802.11b
```

config 802.11 antenna selection

To select the internal or external antenna selection for a Cisco lightweight access point on an 802.11 network, use the **config 802.11 antenna selection** command.

config 802.11 {a | b} antenna selection {internal | external} *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
internal	Specifies the internal antenna.
external	Specifies the external antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to configure access point AP02 on an 802.11b network to use the internal antenna:

```
> config 802.11a antenna selection internal AP02
```

Related Commands

config 802.11 disable
config 802.11 enable
config 802.11 antenna extAntGain
config 802.11 antenna mode
config 802.11 antenna diversity
show 802.11a
show 802.11b

config 802.11 channel

To configure an 802.11 network or a single access point for automatic or manual channel selection, use the **config 802.11 channel** command.

config 802.11 {a | b} channel {global [auto | once | off | restart]} | ap {ap_name [global | channel]}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Specifies the 802.11a operating channel that is automatically set by RRM and overrides the existing configuration setting.
auto	(Optional) Specifies that the channel is automatically set by Radio Resource Management (RRM) for the 802.11a radio.
once	(Optional) Specifies that the channel is automatically set once by RRM.
off	(Optional) Specifies that the automatic channel selection by RRM is disabled.
restarts	(Optional) Restarts the aggressive DCA cycle.
<i>ap_name</i>	Access point name.
<i>channel</i>	Manual channel number to be used by the access point. The supported channels depend on the specific access point used and the regulatory region.

Command Default

None.

Usage Guidelines

When configuring 802.11 channels for a single lightweight access point, enter the **config 802.11 disable** command to disable the 802.11 network. Enter the **config 802.11 channel** command to set automatic channel selection by Radio Resource Management (RRM) or manually set the channel for the 802.11 radio, and enter the **config 802.11 enable** command to enable the 802.11 network.



Note

See the Channels and Maximum Power Settings for Cisco Aironet Lightweight Access Points document for the channels supported by your access point. The power levels and available channels are defined by the country code setting and are regulated on a country-by-country basis.

Examples

This example shows how to have RRM automatically configure the 802.11a channels for automatic channel configuration based on the availability and interference:

```
> config 802.11a channel global auto
```

This example shows how to configure the 802.11b channels one time based on the availability and interference:

```
> config 802.11b channel global once
```

This example shows how to turn 802.11a automatic channel configuration off:

```
> config 802.11a channel global off
```

This example shows how to configure the 802.11b channels in access point AP01 for automatic channel configuration:

```
> config 802.11b AP01 channel global
```

This example shows how to configure the 802.11a channel 36 in access point AP01 as the default channel:

```
> config 802.11a channel AP01 36
```

Related Commands

show 802.11a

show 802.11a disable

show 802.11a enable

show 802.11b channel

config country

config 802.11 channel ap

To set the operating radio channel for an access point, use the **config 802.11 channel ap** command.

config 802.11 {a | b} channel ap *cisco_ap* {**global** | *channel_no*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Name of the Cisco access point.
global	Enables auto-RF on the designated access point.
<i>channel_no</i>	Default channel from 1 to 26, inclusive.

Command Default

None.

Examples

This example shows how to enable auto-RF for access point AP01 on an 802.11b network:

```
> config 802.11b channel ap AP01 global
```

Related Commands

show 802.11a
show 802.11a disable
show 802.11a enable
config 802.11b channel
config country

config 802.11 chan_width

To configure the channel width for a particular access point, use the **config 802.11 chan_width** command.

config 802.11 {a | b} chan_width cisco_ap {20 | 40}

Syntax Description

a	Configures the 802.11a radio
b	Specifies the 802.11b/g radio.
<i>cisco_ap</i>	Access point.
20	Allows the radio to communicate using only 20-MHz channels. Choose this option for legacy 802.11a radios, 20-MHz 802.11n radios, or 40-MHz 802.11n radios that you want to operate using only 20-MHz channels.
40	Allows 40-MHz 802.11n radios to communicate using two adjacent 20-MHz channels bonded together.

Command Default

The default channel width is 20.

Usage Guidelines

This parameter can be configured only if the primary channel is statically assigned.



Caution

We recommend that you do not configure 40-MHz channels in the 2.4-GHz radio band because severe co-channel interference can occur.

Statically configuring an access point's radio for 20- or 40-MHz mode overrides the globally configured DCA channel width setting (configured by using the **config advanced 802.11 channel dca chan-width-11n** command). If you change the static configuration back to global on the access point radio, the global DCA configuration overrides the channel width configuration that the access point was previously using.

Examples

This example shows how to configure the channel width for access point AP01 on an 802.11 network using 40-MHz channels:

```
> config 802.11a chan_width AP01 40
```

Related Commands

config 802.11 11nsupport
config wlan wmm required

config 802.11 11nsupport a-mpdu tx priority
config 802.11a disable network
config 802.11a disable
config 802.11a channel ap
config 802.11b disable
config 802.11b channel ap
config 802.11a txpower ap

config 802.11 txPower

To configure the transmit power level for all access points or a single access point in an 802.11 network, use the **config 802.11 txPower** command.

config 802.11 {a | b} txPower {global {power_level | auto | max | min | once } | ap cisco_ap}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures the 802.11 transmit power level for all lightweight access points.
auto	(Optional) Specifies the power level is automatically set by Radio Resource Management (RRM) for the 802.11 Cisco radio.
once	(Optional) Specifies the power level is automatically set once by RRM.
<i>power_level</i>	(Optional) Manual Transmit power level number for the access point.
ap	Configures the 802.11 transmit power level for a specified lightweight access point.
<i>ap_name</i>	Access point name.

Command Default

The command default (**global**, **auto**) is for automatic configuration by RRM.

Usage Guidelines

The supported power levels depends on the specific access point used and the regulatory region. For example, the 1240 series access point supports eight levels and the 1200 series access point supports six levels. See the Channels and Maximum Power Settings for Cisco Aironet Lightweight Access Points document for the maximum transmit power limits for your access point. The power levels and available channels are defined by the country code setting and are regulated on a country-by-country basis.

Examples

This example shows how to automatically set the 802.11a radio transmit power level in all lightweight access points:

```
> config 802.11a txPower auto
```

This example shows how to manually set the 802.11b radio transmit power to level 5 for all lightweight access points:

```
> config 802.11b txPower global 5
```

This example shows how to automatically set the 802.11b radio transmit power for access point AP1:

```
> config 802.11b txPower AP1 global
```

This example shows how to manually set the 802.11a radio transmit power to power level 2 for access point AP1:

```
> config 802.11b txPower AP1 2
```

Related Commands

show ap config 802.11a

config 802.11b txPower

config advanced 802.11 7920VSIEConfig

To configure the Cisco unified wireless IP phone 7920 VISE parameters, use the **config advanced 802.11 7920VSIEConfig** command.

config advanced 802.11 {a | b} 7920VSIEConfig {call-admission-limit *limit* | G711-CU-Quantum *quantum*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
call-admission-limit	Configures the call admission limit for the 7920s.
G711-CU-Quantum	Configures the value supplied by the infrastructure indicating the current number of channel utilization units that would be used by a single G.711-20ms call.
<i>limit</i>	Call admission limit (from 0 to 255). The default value is 105.
<i>quantum</i>	G711 quantum value. The default value is 15.

Command Default

None.

Examples

This example shows how to configure the call admission limit for 7920 VISE parameters:

```
> config advanced 802.11 7920VSIEConfig call-admission-limit 4
```


config advanced 802.11 channel add

To add channel to the 802.11 networks auto RF channel list, use the **config advanced 802.11 channel add** command.

config advanced 802.11 {a | b} channel add *channel_number*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
add	Adds a channel to the 802.11 network auto RF channel list.
<i>channel_number</i>	Channel number to add to the 802.11 network auto RF channel list.

Command Default

None.

Examples

This example shows how to add a channel to the 802.11a network auto RF channel list:

```
> config advanced 802.11 channel add 132
```

Related Commands

show advanced 802.11a channel
config advanced 802.11b channel update

config advanced 802.11 channel cleanair-event

To configure CleanAir event driven Radio Resource Management (RRM) parameters for all 802.11 Cisco lightweight access points, use the **config advanced 802.11 channel cleanair-event** command.

config advanced 802.11 {a | b} channel cleanair-event {enable | disable | sensitivity [low | medium | high] | custom threshold *threshold_value*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the CleanAir event-driven RRM parameters.
disable	Disables the CleanAir event-driven RRM parameters.
sensitivity	Sets the sensitivity for CleanAir event-driven RRM.
low	(Optional) Specifies low sensitivity.
medium	(Optional) Specifies medium sensitivity
high	(Optional) Specifies high sensitivity
custom	Specifies custom sensitivity.
threshold	Specifies the EDRRM AQ threshold value.
<i>threshold_value</i>	Number of custom threshold.

Command Default

None.

Examples

This example shows how to enable the CleanAir event-driven RRM parameters:

```
> config advanced 802.11 channel cleanair-event enable
```

This example shows how to set the high sensitivity for CleanAir event-driven RRM:

```
> config advanced 802.11 channel cleanair-event sensitivity high
```

Related Commands

show advanced 802.11a channel

config advanced 802.11b channel update

config advanced 802.11 channel dca anchor-time

To specify the time of day when the Dynamic Channel Assignment (DCA) algorithm is to start, use the **config advanced 802.11 channel dca anchor-time** command.

config advanced 802.11 {a | b} channel dca anchor-time *value*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>value</i>	Hour of the time between 0 and 23. These values represent the hour from 12:00 a.m. to 11:00 p.m.

Command Default

None.

Examples

This example shows how to configure the time of delay when the DCA algorithm starts:

```
> config advanced 802.11 channel dca anchor-time 17
```

Related Commands

config advanced 802.11 channel dca interval
config advanced 802.11 channel dca sensitivity
config advanced 802.11 channel

config advanced 802.11 channel dca chan-width-11n

To configure the Dynamic Channel Assignment (DCA) channel width for all 802.11n radios in the 5-GHz band, use the **config advanced 802.11 channel dca chan-width-11n** command.

config advanced 802.11 {a | b} channel dca chan-width-11n {20 | 40}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
20	Sets the channel width for 802.11n radios to 20 MHz.
40	Sets the channel width for 802.11n radios to 40 MHz.

Command Default

The default channel width is 20.

Usage Guidelines

If you choose 40, be sure to set at least two adjacent channels in the **config advanced 802.11 channel {add | delete} channel_number** command (for example, a primary channel of 36 and an extension channel of 40). If you set only one channel, that channel is not used for the 40-MHz channel width.

To override the globally configured DCA channel width setting, you can statically configure an access point's radio for 20- or 40-MHz mode using the **config 802.11 chan_width** command. If you then change the static configuration to global on the access point radio, the global DCA configuration overrides the channel width configuration that the access point was previously using.

Examples

This example shows how to add a channel to the 802.11a network auto channel list:

```
> config advanced 802.11a channel dca chan-width-11n 40
```

Related Commands

config 802.11 chan_width
config advanced 802.11 dca interval
config advanced 802.11 dca sensitivity
show advanced 802.11 channel

config advanced 802.11 channel dca interval

To specify how often the Dynamic Channel Assignment (DCA) is allowed to run, use the **config advanced 802.11 channel dca interval** command.

config advanced 802.11 {a | b} channel dca interval *value*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>value</i>	Valid values are 0, 1, 2, 3, 4, 6, 8, 12, or 24 hours. 0 is 10 minutes (600 seconds).

Command Default

0 (10 minutes).

Usage Guidelines

If your controller supports only OfficeExtend access points, we recommend that you set the DCA interval to 6 hours for optimal performance. For deployments with a combination of OfficeExtend access points and local access points, the range of 10 minutes to 24 hours can be used.

Examples

This example shows how often the DCA algorithm is allowed to run:

```
> config advanced 802.11 channel dca interval 8
```

Related Commands

config advanced 802.11 dca anchor-time
config advanced 802.11 dca sensitivity
show advanced 802.11 channel

config advanced 802.11 channel dca min-metric

To configure the 5-GHz minimum RSSI energy metric for DCA, use the **config advanced 802.11 channel dca min-metric** command.

config advanced 802.11 {a | b} channel dca *RSSI_value*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>RSSI_value</i>	Minimum received signal strength indicator (RSSI) that is required for the DCA to trigger a channel change. The range is from -100 to -60 dBm.

Command Default

-95 dBm.

Examples

This example shows how to configure the minimum 5-GHz RSSI energy metric for DCA:

```
> config advanced 802.11a channel dca min-metric -80
```

In the above example, the RRM must detect an interference energy of at least -80 dBm in RSSI for the DCA to trigger a channel change.

Related Commands

config advanced 802.11 dca interval
config advanced 802.11 dca anchor-time
show advanced 802.11 channel

config advanced 802.11 channel dca sensitivity

To specify how sensitive the Dynamic Channel Assignment (DCA) algorithm is to environmental changes (for example, signal, load, noise, and interference) when determining whether or not to change channels, use the **config advanced 802.11 channel dca sensitivity** command.

config advanced 802.11 {a | b} channel dca sensitivity {low | medium | high}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
low	Specifies the DCA algorithm is not particularly sensitive to environmental changes. See the “Usage Guidelines” section for more information.
medium	Specifies the DCA algorithm is moderately sensitive to environmental changes. See the “Usage Guidelines” section for more information.
high	Specifies the DCA algorithm is highly sensitive to environmental changes. See the “Usage Guidelines” section for more information.

Command Default

None.

Usage Guidelines

The DCA sensitivity thresholds vary by radio band as shown in the table below.

To aid in troubleshooting, the output of this command shows an error code for any failed calls. This table explains the possible error codes for failed calls.

Table 11: DCA Sensitivity Thresholds

Sensitivity	2.4-GHz DCA Sensitivity Threshold	5-GHz DCA Sensitivity Threshold
High	5 dB	5 dB
Medium	15 dB	20 dB
Low	30 dB	35 dB

Examples

This example shows how to configure the value of DCA algorithm’s sensitivity to low:

```
> config advanced 802.11 channel dca sensitivity low
```

Related Commands

config advanced 802.11 dca interval

config advanced 802.11 dca anchor-time
show advanced 802.11 channel

config advanced 802.11 channel foreign

To have Radio Resource Management (RRM) consider or ignore foreign 802.11a interference avoidance in making channel selection updates for all 802.11a Cisco lightweight access points, use the **config advanced 802.11 channel foreign** command.

config advanced 802.11 {a | b} channel foreign {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the foreign access point 802.11a interference avoidance in the channel assignment.
disable	Disables the foreign access point 802.11a interference avoidance in the channel assignment.

Command Default

Enabled.

Examples

This example shows how to have RRM consider foreign 802.11a interference when making channel selection updates for all 802.11a Cisco lightweight access points:

```
> config advanced 802.11a channel foreign enable
```

Related Commands

show advanced 802.11a channel
config advanced 802.11b channel foreign

config advanced 802.11 channel load

To have Radio Resource Management (RRM) consider or ignore the traffic load in making channel selection updates for all 802.11a Cisco lightweight access points, use the **config advanced 802.11 channel load** command.

config advanced 802.11 {a | b} channel load {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the Cisco lightweight access point 802.11a load avoidance in the channel assignment.
disable	Disables the Cisco lightweight access point 802.11a load avoidance in the channel assignment.

Command Default

Disabled.

Examples

This example shows how to have RRM consider the traffic load when making channel selection updates for all 802.11a Cisco lightweight access points:

```
> config advanced 802.11 channel load enable
```

Related Commands

show advanced 802.11a channel
config advanced 802.11b channel load

config advanced 802.11 channel noise

To have Radio Resource Management (RRM) consider or ignore non-802.11a noise in making channel selection updates for all 802.11a Cisco lightweight access points, use the **config advanced 802.11 channel noise** command.

config advanced 802.11 {a | b} channel noise {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables non-802.11a noise avoidance in the channel assignment. or ignore.
disable	Disables the non-802.11a noise avoidance in the channel assignment.

Command Default

Disabled.

Examples

This example shows how to have RRM consider non-802.11a noise when making channel selection updates for all 802.11a Cisco lightweight access points:

```
> config advanced 802.11 channel noise enable
```

Related Commands

show advanced 802.11a channel
config advanced 802.11b channel noise

config advanced 802.11 channel outdoor-ap-dca

To enable or disable the controller to avoid checking the non-Dynamic Frequency Selection (DFS) channels, use the **config advanced 802.11 channel outdoor-ap-dca** command.

config advanced 802.11 {a | b} channel outdoor-ap-dca {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables 802.11 network DCA list option for outdoor access point.
disable	Disables 802.11 network DCA list option for outdoor access point.

Command Default

Disabled.

Usage Guidelines

The **config advanced 802.11 {a | b} channel outdoor-ap-dca {enable | disable}** command is applicable only for deployments having outdoor access points such as 1522 and 1524.

Examples

This example shows how to enable the 802.11a DCA list option for outdoor access point:

```
> config advanced 802.11a channel outdoor-ap-dca enable
```

Related Commands

show advanced 802.11a channel

config advanced 802.11b channel noise

config advanced 802.11 channel pda-prop

To enable or disable propagation of persistent devices, use the **config advanced 802.11 channel pda-prop** command.

config advanced 802.11 {a | b} channel pda-prop {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the 802.11 network DCA list option for the outdoor access point.
disable	Disables the 802.11 network DCA list option for the outdoor access point.

Command Default

Disabled.

Examples

This example shows how to enable or disable propagation of persistent devices:

```
> config advanced 802.11 channel pda-prop enable
```

config advanced 802.11 channel update

To have Radio Resource Management (RRM) initiate a channel selection update for all 802.11a Cisco lightweight access points, use the **config advanced 802.11 channel update** command.

config advanced 802.11 {a | b} channel update

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to initiate a channel selection update for all 802.11a network access points:

```
> config advanced 802.11a channel update
```

Related Commands

show advanced 802.11a channel

config advanced 802.11b channel update

config advanced 802.11 coverage

To enable or disable coverage hole detection, use the **config advanced 802.11 coverage** command.

config advanced 802.11 {a | b} coverage {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the coverage hole detection.
disable	Disables the coverage hole detection.

Command Default

Enabled.

Usage Guidelines

If you enable coverage hole detection, the Cisco WLC automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The Cisco WLC determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to enable coverage hole detection on an 802.11a network:

```
> config advanced 802.11a coverage enable
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate
config advanced 802.11 coverage level global
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage rssi-threshold

config advanced 802.11 coverage exception global

To specify the percentage of clients on an access point that are experiencing a low signal level but cannot roam to another access point, use the **config advanced 802.11 coverage exception global** command.

config advanced 802.11 {a | b} **coverage exception global** *percent*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>percent</i>	Percentage of clients. Valid values are from 0 to 100%.

Command Default

25%.

Usage Guidelines

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to specify the percentage of clients for all 802.11a access points that are experiencing a low signal level:

```
> config advanced 802.11 coverage exception global 50
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate
config advanced 802.11 coverage level global
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage rssi-threshold
config advanced 802.11 coverage

config advanced 802.11 coverage fail-rate

To specify the failure rate threshold for uplink data or voice packets, use the **config advanced 802.11 coverage fail-rate** command.

config advanced 802.11 {a | b} coverage {data | voice} fail-rate *percent*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
data	Specifies the threshold for data packets.
voice	Specifies the threshold for voice packets.
<i>percent</i>	Failure rate as a percentage. Valid values are from 1 to 100 percent.

Command Default

20.

Usage Guidelines

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to configure the threshold count for minimum uplink failures for data packets:

```
> config advanced 802.11 coverage fail-rate 80
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage level global
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage rssi-threshold
config advanced 802.11 coverage

config advanced 802.11 coverage level global

To specify the minimum number of clients on an access point with an received signal strength indication (RSSI) value at or below the data or voice RSSI threshold, use the **config advanced 802.11 coverage level global** command.

config advanced 802.11 {a | b} coverage level global *clients*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>clients</i>	Minimum number of clients. Valid values are from 1 to 75.

Command Default

3.

Usage Guidelines

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to specify the minimum number of clients on all 802.11a access points with an RSSI value at or below the RSSI threshold:

```
> config advanced 802.11 coverage level global 60
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage rssi-threshold
config advanced 802.11 coverage

config advanced 802.11 coverage packet-count

To specify the minimum failure count threshold for uplink data or voice packets, use the **config advanced 802.11 coverage packet-count** command.

config advanced 802.11 {a | b} coverage {data | voice} packet-count *packets*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
data	Specifies the threshold for data packets.
voice	Specifies the threshold for voice packets.
<i>packets</i>	Minimum number of packets. Valid values are from 1 to 255 packets.

Command Default

10.

Usage Guidelines

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to configure the failure count threshold for uplink data packets:

```
> config advanced 802.11 coverage packet-count 100
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate
config advanced 802.11 coverage level global
config advanced 802.11 coverage rssi-threshold
config advanced 802.11 coverage

config advanced 802.11 coverage rssi-threshold

To specify the minimum receive signal strength indication (RSSI) value for packets that are received by an access point, use the **config advanced 802.11 coverage rssi-threshold** command.

config advanced 802.11 {a | b} coverage {data | voice} rssi-threshold *rssi*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
data	Specifies the threshold for data packets.
voice	Specifies the threshold for voice packets.
<i>rssi</i>	Valid values are from –60 to –90 dBm.

Command Default

- Data packets: –80 dBm.
- Voice packets: –75 dBm.

Usage Guidelines

The *rssi* value that you enter is used to identify coverage holes (or areas of poor coverage) within your network. If the access point receives a packet in the data or voice queue with an RSSI value that is below the value that you enter, a potential coverage hole has been detected.

The access point takes RSSI measurements every 5 seconds and reports them to the controller in 90-second intervals.

If both the number and percentage of failed packets exceed the values that you entered in the **config advanced 802.11 coverage packet-count** and **config advanced 802.11 coverage fail-rate** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **config advanced 802.11 coverage level global** and **config advanced 802.11 coverage exception global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to configure the minimum receive signal strength indication threshold value for data packets that are received by an 802.11a access point:

```
> config advanced 802.11a coverage rssi-threshold -60
```

Related Commands

config advanced 802.11 coverage exception global
config advanced 802.11 coverage fail-rate

config advanced 802.11 coverage level global
config advanced 802.11 coverage packet-count
config advanced 802.11 coverage

config advanced 802.11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 802.11a network, use the **config advanced 802.11 edca-parameters** command.

config advanced 802.11 {a | b} edca-parameters {wmm-default | svp-voice | optimized-voice | optimized-video-voice | custom-voice}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.
svp-voice	Enables Spectralink voice priority parameters. Choose this option if Spectralink phones are deployed on your network to improve the quality of calls.
optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than Spectralink are deployed on your network.
optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network. Note If you deploy video services, admission control (ACM) must be disabled.
custom-voice	Enables custom voice EDCA parameters for 802.11a. The EDCA parameters under this option also match the 6.0 WMM EDCA parameters when this profile is applied.

Command Default

wmm-default

Examples

This example shows how to enable Spectralink voice priority parameters:

```
> config advanced 802.11 edca-parameters svp-voice
```

Related Commands

show 802.11a
config advanced 802.11b edca-parameters

config advanced 802.11 factory

To reset 802.11a advanced settings back to the factory defaults, use the **config advanced 802.11 factory** command.

config advanced 802.11 {a | b} factory

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to return all the 802.11a advanced settings to their factory defaults:

```
> config advanced 802.11a factory
```

Related Commands

show advanced 802.11a channel

config advanced 802.11 group-member

To configure members in 802.11 static RF group, use the **config advanced 802.11 group-member** command.

config advanced 802.11 {a | b} group-member {add | remove} controller controller-ip-address

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
add	Adds a controller to the static RF group.
remove	Removes a controller from the static RF group.
<i>controller</i>	Name of the controller to be added.
<i>controller-ip-address</i>	IP address of the controller to be added.

Command Default

None.

Examples

This example shows how to add a controller in the 802.11a automatic RF group:

```
> config advanced 802.11a group-member add cisco-controller 209.165.200.225
```

Related Commands

show advanced 802.11a group

config advanced 802.11 group-mode

config advanced 802.11 group-mode

To set the 802.11a automatic RF group selection mode on or off, use the **config advanced 802.11 group-mode** command.

config advanced 802.11 {a | b} group-mode {auto | leader | off | restart}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
auto	Sets the 802.11a RF group selection to automatic update mode.
leader	Sets the 802.11a RF group selection to static mode, and sets this controller as the group leader.
off	Sets the 802.11a RF group selection to off.
restart	Restarts the 802.11a RF group selection.

Command Default

Auto.

Examples

This example shows how to turn the 802.11a automatic RF group selection mode on:

```
> config advanced 802.11a group-mode auto
```

This example shows how to turn the 802.11a automatic RF group selection mode off:

```
> config advanced 802.11a group-mode off
```

Related Commands

show advanced 802.11a group
config advanced 802.11 group-member

config advanced 802.11 logging channel

To turn the channel change logging mode on or off, use the **config advanced 802.11 logging channel** command.

config advanced 802.11 {a | b} logging channel {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
logging channel	Logs channel changes.
on	Enables the 802.11 channel logging.
off	Disables 802.11 channel logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a logging channel selection mode on:

```
> config advanced 802.11a logging channel on
```

Related Commands

show advanced 802.11a logging
config advanced 802.11b logging channel

config advanced 802.11 logging coverage

To turn the coverage profile logging mode on or off, use the **config advanced 802.11 logging coverage** command.

config advanced 802.11 {a | b} logging coverage {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 coverage profile violation logging.
off	Disables the 802.11 coverage profile violation logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a coverage profile violation logging selection mode on:

```
> config advanced 802.11a logging coverage on
```

Related Commands

show advanced 802.11a logging
config advanced 802.11b logging coverage

config advanced 802.11 logging foreign

To turn the foreign interference profile logging mode on or off, use the **config advanced 802.11 logging foreign** command.

config advanced 802.11 {a | b} logging foreign {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 foreign interference profile violation logging.
off	Disables the 802.11 foreign interference profile violation logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a foreign interference profile violation logging selection mode on:

```
> config advanced 802.11a logging foreign on
```

Related Commands

show advanced 802.11a logging
config advanced 802.11b logging foreign

config advanced 802.11 logging load

To turn the 802.11a load profile logging mode on or off, use the **config advanced 802.11 logging load** command.

config advanced 802.11 {a | b} logging load {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 load profile violation logging.
off	Disables the 802.11 load profile violation logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a load profile logging mode on:

```
> config advanced 802.11 logging load on
```

Related Commands

show advanced 802.11a logging
config advanced 802.11b logging load

config advanced 802.11 logging noise

To turn the 802.11a noise profile logging mode on or off, use the **config advanced 802.11 logging noise** command.

config advanced 802.11 {a | b} logging noise {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 noise profile violation logging.
off	Disables the 802.11 noise profile violation logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a noise profile logging mode on:

```
> config advanced 802.11a logging noise on
```

Related Commands

show advanced 802.11a logging

config advanced 802.11b logging noise

config advanced 802.11 logging performance

To turn the 802.11a performance profile logging mode on or off, use the **config advanced 802.11 logging performance** command.

config advanced 802.11 {a | b} logging performance {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 performance profile violation logging.
off	Disables the 802.11 performance profile violation logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a performance profile logging mode on:

```
> config advanced 802.11a logging performance on
```

Related Commands

show advanced 802.11a logging
config advanced 802.11b logging performance

config advanced 802.11 logging txpower

To turn the 802.11a transmit power change logging mode on or off, use the **config advanced 802.11 logging txpower** command.

config advanced 802.11 {a | b} logging txpower {on | off}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
on	Enables the 802.11 transmit power change logging.
off	Disables the 802.11 transmit power change logging.

Command Default

Off (disabled).

Examples

This example shows how to turn the 802.11a transmit power change mode on:

```
> config advanced 802.11 logging txpower off
```

Related Commands

show advanced 802.11 logging
config advanced 802.11b logging power

config advanced 802.11 monitor channel-list

To set the 802.11a noise, interference, and rogue monitoring channel list, use the **config advanced 802.11 monitor channel-list** command.

config advanced 802.11 {a | b} monitor channel-list {all | country | dca}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
all	Monitors all channels.
country	Monitors the channels used in the configured country code.
dca	Monitors the channels used by the automatic channel assignment.

Command Default

Country.

Examples

This example shows how to monitor the channels used in the configured country:

```
> config advanced 802.11 monitor channel-list country
```

Related Commands

show advanced 802.11a monitor coverage

config advanced 802.11 monitor coverage

To set the coverage measurement interval between 60 and 3600 seconds, use the **config advanced 802.11 monitor coverage** command.

config advanced 802.11 {a | b} monitor coverage *seconds*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>seconds</i>	Coverage measurement interval between 60 and 3600 seconds.

Command Default

180 seconds.

Examples

This example shows how to set the coverage measurement interval to 60 seconds:

```
> config advanced 802.11 monitor coverage 60
```

Related Commands

show advanced 802.11a monitor
config advanced 802.11b monitor coverage

config advanced 802.11 monitor load

To set the load measurement interval between 60 and 3600 seconds, use the **config advanced 802.11 monitor load** command.

config advanced 802.11 {a | b} monitor load *seconds*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>seconds</i>	Load measurement interval between 60 and 3600 seconds.

Command Default

60 seconds.

Examples

This example shows how to set the load measurement interval to 60 seconds:

```
> config advanced 802.11 monitor load 60
```

Related Commands

show advanced 802.11a monitor
config advanced 802.11b monitor load

config advanced 802.11 monitor mode

To enable or disable 802.11a access point monitoring, use the **config advanced 802.11 monitor mode** command.

config advanced 802.11 {a | b} monitor mode {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the 802.11 access point monitoring.
disable	Disables the 802.11 access point monitoring.

Command Default

Enabled.

Examples

This example shows how to enable the 802.11a access point monitoring:

```
> config advanced 802.11a monitor mode enable
```

Related Commands

show advanced 802.11a monitor
config advanced 802.11b monitor mode

config advanced 802.11 monitor ndp-type

To configure the 802.11 access point radio resource management (RRM) Neighbor Discovery Protocol (NDP) type, use the **config advanced 802.11 monitor ndp-type** command:

config advanced 802.11 {a | b} monitor ndp-type {protected | transparent}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
protected	Specifies the Tx RRM protected NDP.
transparent	Specifies the Tx RRM transparent NDP.

Command Default

None.

Usage Guidelines

Before you configure the 802.11 access point RRM NDP type, ensure that you have disabled the network by entering the **config 802.11 disable network** command.

Examples

This example shows how to enable the 802.11a access point RRM NDP type as protected:

```
> config advanced 802.11 monitor ndp-type protected
```

Related Commands

config advanced 802.11 monitor
config advanced 802.11 monitor mode
config advanced 802.11 disable

config advanced 802.11 monitor noise

To set the 802.11a noise measurement interval between 60 and 3600 seconds, use the **config advanced 802.11 monitor noise** command.

config advanced 802.11 {a | b} monitor noise *seconds*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>seconds</i>	Noise measurement interval between 60 and 3600 seconds.

Command Default

180 seconds.

Examples

This example shows how to set the noise measurement interval to 120 seconds:

```
> config advanced 802.11 monitor noise 120
```

Related Commands

show advanced 802.11a monitor
config advanced 802.11b monitor noise

config advanced 802.11 monitor signal

To set the signal measurement interval between 60 and 3600 seconds, use the **config advanced 802.11 monitor signal** command.

config advanced 802.11 {a | b} monitor signal *seconds*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>seconds</i>	Signal measurement interval between 60 and 3600 seconds.

Command Default

60 seconds.

Examples

This example shows how to set the signal measurement interval to 120 seconds:

```
> config advanced 802.11 monitor signal 120
```

Related Commands

show advanced 802.11a monitor
config advanced 802.11b monitor signal

config advanced 802.11 profile foreign

To set the foreign 802.11a transmitter interference threshold between 0 and 100 percent, use the **config advanced 802.11 profile foreign** command.

config advanced 802.11 {a | b} profile foreign {global | cisco_ap} percent

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access points.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a foreign 802.11a interference threshold between 0 and 100 percent.

Command Default

10.

Examples

This example shows how to set the foreign 802.11a transmitter interference threshold for all Cisco lightweight access points to 50 percent:

```
> config advanced 802.11a profile foreign global 50
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
> config advanced 802.11 profile foreign AP1 0
```

Related Commands

show advanced 802.11a profile

config advanced 802.11b profile foreign

config advanced 802.11 profile noise

To set the 802.11a foreign noise threshold between -127 and 0 dBm, use the **config advanced 802.11 profile noise** command.

config advanced 802.11 {a | b} profile noise {global | *cisco_ap*} dBm

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>dBm</i>	802.11a foreign noise threshold between -127 and 0 dBm.

Command Default

-70 dBm.

Examples

This example shows how to set the 802.11a foreign noise threshold for all Cisco lightweight access points to -127 dBm:

```
> config advanced 802.11a profile noise global -127
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
> config advanced 802.11a profile noise AP1 0
```

Related Commands

show advanced 802.11 profile

config advanced 802.11b profile noise

config advanced 802.11 profile throughput

To set the Cisco lightweight access point data-rate throughput threshold between 1000 and 10000000 bytes per second, use the **config advanced 802.11 profile throughput** command.

config advanced 802.11 {a | b} **profile throughput** {global | cisco_ap} *value*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>value</i>	802.11a Cisco lightweight access point throughput threshold between 1000 and 10000000 bytes per second.

Command Default

1,000,000 bytes per second.

Examples

This example shows how to set all Cisco lightweight access point data-rate thresholds to 1000 bytes per second:

```
> config advanced 802.11 profile throughput global 1000
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
> config advanced 802.11 profile throughput AP1 10000000
```

Related Commands

show advanced 802.11 profile
config advanced 802.11b profile data-rate

config advanced 802.11 profile utilization

To set the RF utilization threshold between 0 and 100 percent, use the **config advanced 802.11 profile utilization** command. The operating system generates a trap when this threshold is exceeded.

config advanced 802.11 {a | b} profile utilization {global | cisco_ap} percent

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
global	Configures a global Cisco lightweight access point specific profile.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a RF utilization threshold between 0 and 100 percent.

Command Default

80 percent.

Examples

This example shows how to set the RF utilization threshold for all Cisco lightweight access points to 0 percent:

```
> config advanced 802.11 profile utilization global 0
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
> config advanced 802.11 profile utilization AP1 100
```

Related Commands

show advanced 802.11a profile
config advanced 802.11b profile utilization

config advanced 802.11 receiver

To set the advanced receiver configuration settings, use the **config advanced 802.11 receiver** command.

config advanced 802.11 {a | b} receiver {default | rxstart jumpThreshold value}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
receiver	Specifies the receiver configuration.
default	Specifies the default advanced receiver configuration.
rxstartjumpThreshold	Specifies the receiver start signal.
<i>value</i>	Jump threshold configuration value between 0 and 127.

Command Default

None.

Examples

This example shows how to prevent changes to receiver parameters while the network is enabled:

```
> config advanced 802.11 receiver default
```

Related Commands

config advanced 802.11b receiver

config advanced 802.11 tpc-version

To configure the Transmit Power Control (TPC) version for a radio, use the **config advanced 802.11 tpc-version** command.

config advanced 802.11 {a | b} tpc-version {1 | 2}

Syntax Description

1	Specifies the TPC version 1 that offers strong signal coverage and stability.
2	Specifies TPC version 2 is for scenarios where voice calls are extensively used. The Tx power is dynamically adjusted with the goal of minimum interference. It is suitable for dense networks. In this mode, there could be higher roaming delays and coverage hole incidents.

Command Default

The default TPC version for a radio is 1.

Examples

This example shows how to configure the TPC version as 1 for the 802.11a radio:

```
> config advanced 802.11a tpc-version 1
```

Related Commands

config advanced 802.11 tpcv1-thresh

config advanced 802.11 tpcv1-thresh

To configure the threshold for Transmit Power Control (TPC) version 1 of a radio, use the **config advanced 802.11 tpcv1-thresh** command.

config advanced 802.11 {a | b} tpcv1-thresh *threshold*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g/n network.
<i>threshold</i>	Threshold value between –50 dBm to –80 dBm.

Examples

This example shows how to configure the threshold as –60 dBm for TPC version 1 of the 802.11a radio:

```
> config advanced 802.11 tpcv1-thresh -60
```

Related Commands

config advanced 802.11 tpc-thresh
config advanced 802.11 tpcv2-thresh

config advanced 802.11 tpcv2-intense

To configure the computational intensity for Transmit Power Control (TPC) version 2 of a radio, use the **config advanced 802.11 tpcv2-intense** command.

config advanced 802.11 {a | b} tpcv2-intense *intensity*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g/n network.
<i>intensity</i>	Computational intensity value between 1 to 100.

Examples

This example shows how to configure the computational intensity as 50 for TPC version 2 of the 802.11a radio:

```
> config advanced 802.11 tpcv2-intense 50
```

Related Commands

config advanced 802.11 tpc-thresh
config advanced 802.11 tpcv2-thresh
config advanced 802.11 tpcv2-per-chan

config advanced 802.11 tpcv2-per-chan

To configure the Transmit Power Control Version 2 on a per-channel basis, use the **config advanced 802.11 tpcv2-per-chan** command.

config advanced 802.11 {a | b} tpcv2-per-chan {enable | disable}

Syntax Description

enable	Enables the configuration of TPC version 2 on a per-channel basis.
disable	Disables the configuration of TPC version 2 on a per-channel basis.

Examples

This example shows how to enable TPC version 2 on a per-channel basis for the 802.11a radio:

```
> config advanced 802.11 tpcv2-per-chan enable
```

Related Commands

config advanced 802.11 tpc-thresh
config advanced 802.11 tpcv2-thresh
config advanced 802.11 tpcv2-intense

config advanced 802.11 tpcv2-thresh

To configure the threshold for Transmit Power Control (TPC) version 2 of a radio, use the **config advanced 802.11 tpcv2-thresh** command.

config advanced 802.11 {a | b} tpcv2-thresh *threshold*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>threshold</i>	Threshold value between –50 dBm to –80 dBm.

Examples

This example shows how to configure the threshold as –60 dBm for TPC version 2 of the 802.11a radio:

```
> config advanced 802.11a tpcv2-thresh -60
```

Related Commands

config advanced 802.11 tpc-thresh
config advanced 802.11 tpcv1-thresh
config advanced 802.11 tpcv2-per-chan

config advanced 802.11 txpower-update

To initiate updates of the 802.11a transmit power for every Cisco lightweight access point, use the **config advanced 802.11 txpower-update** command.

config advanced 802.11 {a | b} txpower-update

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to initiate updates of 802.11a transmit power for an 802.11a access point:

```
> config advanced 802.11 txpower-update
```

Related Commands

config advance 802.11b txpower-update

config advanced dot11-padding

To enable or disable over-the-air frame padding, use the **config advanced dot11-padding** command.

config advanced dot11-padding {enable | disable}

Syntax Description

enable	Enables the over-the-air frame padding.
disable	Disables the over-the-air frame padding.

Command Default

Disabled.

Examples

This example shows how to enable over-the-air frame padding:

```
> config advanced dot11-padding enable
```

Related Commands

debug dot11
debug dot11 mgmt interface
debug dot11 mgmt msg
debug dot11 mgmt ssid
debug dot11 mgmt state-machine
debug dot11 mgmt station
show advanced dot11-padding

config client location-calibration

To configure link aggregation, use the **config client location-calibration** command.

config client location-calibration {**enable** *mac_address interval* | **disable** *mac_address*}

Syntax Description

enable	(Optional) Specifies that client location calibration is enabled.
<i>mac_address</i>	MAC address of the client.
<i>interval</i>	Measurement interval in seconds.
disable	(Optional) Specifies that client location calibration is disabled.

Command Default

None.

Examples

This example shows how to enable the client location calibration for the client 37:15:85:2a with a measurement interval of 45 seconds:

```
> config client location-calibration enable 37:15:86:2a:Bc:cf 45
```

Related Commands

show client location-calibration summary

config network rf-network-name

To set the RF-Network name, use the **config network rf-network-name** command.

config network rf-network-name *name*

Syntax Description	
<i>name</i>	RF-Network name. The name can contain up to 19 characters.

Command Default None.

Examples This example shows how to set the RF-network name to travelers:

```
> config network rf-network-name travelers
```

Related Commands `show network summary`

Configuring 802.11k and Assisted Roaming

This section lists the commands for configuring, displaying, and debugging 802.11k and assisted roaming settings on the controller.

config assisted-roaming

To configure assisted roaming parameters on the controller, use the **config assisted-roaming** command.

config assisted-roaming {**denial-maximum** *count* | **floor-bias** *RSSI* | **prediction-minimum** *number_of_APs*}

Syntax Description

denial-maximum	Configures the maximum number of counts for association denial.
<i>count</i>	Maximum number of times that a client is denied for association when the association request that was sent to an access point does not match any access point on the prediction list. The range is from 1 to 10.
floor-bias	Configures the RSSI bias for access points on the same floor.
<i>RSSI</i>	RSSI bias for access points on the same floor. The range is from 5 to 25. Access points on the same floor have more preference.
prediction-minimum	Configures the minimum number of optimized access points for the assisted roaming feature.
<i>number_of_APs</i>	Minimum number of optimized access points for the assisted roaming feature. The range is from 1 to 6. If the number of access points in the prediction assigned to the client is smaller than this number, the assisted roaming feature does not work.

Command Default

The default RSSI bias for access points on the same floor is 15 dBm.

Usage Guidelines

802.11k allows a client to request a neighbor report that contains information about known neighbor access points, which can be used for a service set transition. The neighbor list reduces the need for active and passive scanning.

Examples

This example shows how to configure the minimum number of optimized access points for the assisted roaming feature:

```
> config assisted-roaming prediction-minimum 4
```

Related Commands

config wlan assisted-roaming
show assisted-roaming
debug 11k

config wlan assisted-roaming

To configure assisted roaming on a WLAN, use the **config wlan assisted-roaming** command.

config wlan assisted-roaming {**neighbor-list** | **dual-list** | **prediction**} {**enable** | **disable**} *wlan_id*

Syntax Description

neighbor-list	Configures an 802.11k neighbor list for a WLAN.
dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
prediction	Configures an assisted roaming optimization prediction for a WLAN.
enable	Enables the configuration on the WLAN.
disable	Disables the configuration on the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).

Command Default

The 802.11k neighbor list is enabled for all WLANs.

By default, dual band list is enabled if the neighbor list feature is enabled for the WLAN.

Usage Guidelines

When you enable the assisted roaming prediction list, a warning appears and load balancing is disabled for the WLAN, if load balancing is already enabled on the WLAN.

Examples

This example shows how to enable an 802.11k neighbor list for a WLAN:

```
> config wlan assisted-roaming neighbor-list enable 1
```

Related Commands

config assisted-roaming
show assisted-roaming
debug 11k

show assisted-roaming

To display assisted roaming and 802.11k configurations, use the **show assisted-roaming** command.

show assisted-roaming

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display assisted roaming and 802.11k configurations:

```
> show assisted-roaming
Assisted Roaming and 80211k Information:
Floor RSSI Bias..... 15 dBm
Maximum Denial..... 2 counts
Minimum Optimized Neighbor Assigned..... 2 neighbors

Assisted Roaming Performance Chart:
Matching Assigned Neighbor..... [0] = 0
Matching Assigned Neighbor..... [1] = 0
Matching Assigned Neighbor..... [2] = 0
Matching Assigned Neighbor..... [3] = 0
Matching Assigned Neighbor..... [4] = 0
Matching Assigned Neighbor..... [5] = 0
Matching Assigned Neighbor..... [6] = 0
Matching Assigned Neighbor..... [7] = 0
No Matching Neighbor..... [8] = 0
No Neighbor Assigned..... [9] = 0
```

Related Commands

- config assisted-roaming**
- config wlan assisted-roaming**
- debug 11k**

debug 11k

To configure the debugging of 802.11k settings, use the **debug 11k** command.

debug 11k {all | detail | errors | events | history | optimization | simulation} {enable | disable}

Syntax Description

all	Configures the debugging of all 802.11k messages.
detail	Configures the debugging of 802.11k details.
errors	Configures the debugging of 802.11k errors.
events	Configures the debugging of all 802.11k events.
history	Configures the debugging of all 802.11k history. The Cisco WLC collects roam history of the client.
optimization	Configures the debugging of 802.11k optimizations. You can view optimization steps of neighbor lists.
simulation	Configures the debugging of 802.11k simulation data. You can view details of client roaming parameters and import them for offline simulation.
enable	Enables the 802.1k debugging.
disable	Disables the 802.1k debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of 802.11k simulation data:

```
> debug 11k simulation enable
```

Related Commands

config assisted-roaming
config wlan assisted-roaming
show assisted-roaming

debug Commands

This section lists the **debug** commands to manage Radio Resource Management (RRM) settings of the controller.

**Caution**

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug airewave-director

To configure the debugging of Airewave Director software, use the **debug airewave-director** command.

debug airewave-director {all | channel | detail | error | group | manager | message | packet | power | profile | radar | rf-change} {enable | disable}

Syntax Description		
	all	Configures the debugging of all Airewave Director logs.
	channel	Configures the debugging of the Airewave Director channel assignment protocol.
	detail	Configures the debugging of the Airewave Director detail logs.
	error	Configures the debugging of the Airewave Director error logs.
	group	Configures the debugging of the Airewave Director grouping protocol.
	manager	Configures the debugging of the Airewave Director manager.
	message	Configures the debugging of the Airewave Director messages.
	packet	Configures the debugging of the Airewave Director packets.
	power	Configures the debugging of the Airewave Director power assignment protocol and coverage hole detection.
	profile	Configures the debugging of the Airewave Director profile events.
	radar	Configures the debugging of the Airewave Director radar detection/avoidance protocol.
	rf-change	Configures the debugging of the Airewave Director rf changes.
	enable	Enables the Airewave Director debugging.
	disable	Disables the Airewave Director debugging.

Command Default None.

Examples

This example shows how to enable the debugging of Airewave Director profile events:

```
> debug airewave-director profile enable
```

Related Commands

debug disable-all
show sysinfo

debug dot11

To configure the debugging of 802.11 events, use the **debug dot11** command.

debug dot11 {all | load-balancing | management | mobile | nmsp | probe | rldp | rogue | state} {enable | disable}

Syntax Description

all	Configures the debugging of all 802.11 messages.
load-balancing	Configures the debugging of 802.11 load balancing events.
management	Configures the debugging of 802.11 MAC management messages.
mobile	Configures the debugging of 802.11 mobile events.
nmsp	Configures the debugging of the 802.11 NMSP interface events.
probe	Configures the debugging of probe.
rldp	Configures the debugging of 802.11 Rogue Location Discovery.
rogue	Configures the debugging of 802.11 rogue events.
state	Configures the debugging of 802.11 mobile state transitions.
enable	Enables the 802.11 debugging.
disable	Disables the 802.11 debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of 802.11 settings:

```
> debug dot11 state enable
> debug dot11 mobile enable
```

Related Commands

debug disable-all
 debug dot11 mgmt interface
 debug dot11 mgmt msg
 debug dot11 mgmt ssid
 debug dot11 mgmt state-machine
 debug dot11 mgmt station



PART IX

CleanAir Commands

- [CLI Commands, page 1571](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points. This section describes the Cisco CleanAir commands and contains the following sections:

- [show Commands, page 1571](#)
- [config Commands, page 1580](#)
- [test Commands, page 1589](#)

show Commands

This section lists the **show** commands to display information about the CleanAir configurations on the controller.

show 802.11 cleanair

To display the multicast-direct configuration state, use the **show 802.11 cleanair** command.

show 802.11 {a | b | h} cleanair config

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
config	Displays the network cleanair configuration.

Command Default

None.

Examples

This example shows how to display the 802.11a cleanair configuration:

```
> show 802.11a cleanair
Clean Air Solution..... Enabled
Air Quality Settings:
  Air Quality Reporting..... Enabled
  Air Quality Reporting Period (min)..... 15
  Air Quality Alarms..... Enabled
  Air Quality Alarm Threshold..... 35
Interference Device Settings:
Interference Device Types:
  TDD Transmitter..... Disabled
  Jammer..... Disabled
  Continuous Transmitter..... Disabled
  DECT-like Phone..... Disabled
  Video Camera..... Disabled
  WiFi Inverted..... Disabled
  WiFi Invalid Channel..... Disabled
  SuperAG..... Disabled
  Radar..... Disabled
  Canopy..... Disabled
  WiMax Mobile..... Disabled
  WiMax Fixed..... Disabled
Interference Device Alarms..... Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... Disabled
  Jammer..... Disabled
  Continuous Transmitter..... Disabled
  DECT-like Phone..... Disabled
  Video Camera..... Disabled
  WiFi Inverted..... Disabled
  WiFi Invalid Channel..... Disabled
  SuperAG..... Disabled
  Radar..... Disabled
  Canopy..... Disabled
  WiMax Mobile..... Disabled
  WiMax Fixed..... Disabled
CleanAir Event-driven RRM State..... Enabled
CleanAir Driven RRM Sensitivity..... Medium
CleanAir Persistent Devices state..... Disabled
Additional Clean Air Settings:
```

Related Commands

`config 802.11 cleanair alarm`
`config 802.11 cleanair device`
`config 802.11 cleanair air-quality summary`
`config 802.11 cleanair device ap`
`config 802.11 cleanair device type`

show 802.11 cleanair air-quality summary

To display the air quality summary information for the 802.11 networks, use the **show 802.11 cleanair air-quality summary** command.

show 802.11 {a | b | h} cleanair air-quality summary

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
summary	Displays a summary of 802.11 radio band air quality information.

Command Default

None.

Examples

This example shows how to display a summary of the air quality information for the 802.11a network:

```
> show 802.11a cleanair air-quality summary
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name           Channel  Avg AQ  Min AQ  Interferers  DFS
-----
CISCO_AP3500      36    95   70    0
CISCO_AP3500      40    93   75    0
```

Related Commands

config 802.11 cleanair alarm
config 802.11 cleanair device
config 802.11 cleanair
config 802.11 cleanair device ap
config 802.11 cleanair device type

show 802.11 cleanair air-quality worst

To display the worst air quality information for the 802.11 networks, use the **show 802.11 cleanair air-quality worst** command.

show 802.11 {a | b | h} cleanair air-quality worst

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
worst	Displays the worst air quality information for 802.11 networks.

Command Default

None.

Examples

This example shows how to display worst air quality information for the 802.11a network:

```
> show 802.11 cleanair air-quality worst
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name           Channel  Avg AQ  Min AQ  Interferers  DFS
-----
CISCO_AP3500      1    83   57    3    5
```

Related Commands

config 802.11 cleanair alarm

config 802.11 cleanair device

config 802.11 cleanair

config 802.11 cleanair device ap

config 802.11 cleanair device type

show 802.11 cleanair device ap

To display the information of the device access point on the 802.11 radio band, use the **show 802.11 cleanair device ap** command.

show 802.11 {a | b | h} cleanair device ap *cisco_ap*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
<i>cisco_ap</i>	Specified access point name.

Command Default

None.

Examples

This example shows how to display the device access point for the 802.11a network:

```
> show 802.11a cleanair device ap AP_3500
DC = Duty Cycle (%)
ISI = Interference Severity Index (1-Low Interference, 100-High Interference)
RSSI = Received Signal Strength Index (dBm)
DevID = Device ID
```

No	ClusterID	DevID	Type	AP Name	ISI	RSSI	DC	Channel
1	c2:f7:40:00:00:03	0x8001	DECT phone	CISCO_AP3500	1	-43	3	149,153,157,161
2	c2:f7:40:00:00:51	0x8002	Radar	CISCO_AP3500	1	-81	2	153,157,161,165
3	c2:f7:40:00:00:03	0x8005	Canopy	CISCO_AP3500	2	-62	2	153,157,161,165

Related Commands

config 802.11 cleanair alarm
config 802.11 cleanair device
config 802.11 cleanair
config 802.11 cleanair device air-quality summary
config 802.11 cleanair device type

show 802.11 cleanair device type

To display the information of all the interferers device type detected by a specific access point on the 802.11 radio band, use the **show 802.11 cleanair device type** command.

show 802.11 {a | b | h} cleanair device type *device_type*

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
h	Specifies the 802.11h network.
<i>device_type</i>	Interferer device type for a specified radio band. The device type is one of the following: • tdd-tx—Tdd-transmitter device information. • jammer—Jammer device information. • cont-tx—Continuous-transmitter devices information. • dect-like—Dect-like phone devices information. • video—Video devices information. • 802.11-inv—WiFi inverted devices information. • 802.11-nonstd—Nonstandard WiFi devices information. • superag—Superag devices information. • canopy—Canopy devices information. • wimax-mobile—WiMax mobile devices information. • wimax-fixed—WiMax fixed devices information.

Command Default

None.

Examples

This example shows how to display the information of all the interferers detected by a specified access point for the 802.11a network:

```
> show 802.11a cleanair device type canopy
DC = Duty Cycle (%)
ISI = Interference Severity Index (1-Low Interference, 100-High Interference)
RSSI = Received Signal Strength Index (dBm)
DevID = Device ID
No  ClusterID      DevID  Type      AP Name      ISI  RSSI  DC      Channel
-----
1c2:f7:40:00:00:03  0x8005 Canopy    CISCO_AP3500  2    -62    2    153,157,161,165
```

show advanced 802.11 channel

To display the automatic channel assignment configuration and statistics, use the **show advanced 802.11 channel** command.

show advanced 802.11 {a | b} channel

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to display the automatic channel assignment configuration and statistics:

```
> show advanced 802.11a channel
Automatic Channel Assignment
Channel Assignment Mode..... AUTO
Channel Update Interval..... 600 seconds [startup]
Anchor time (Hour of the day)..... 0
Channel Update Contribution..... SNI.
Channel Assignment Leader..... 00:1a:6d:dd:1e:40
Last Run..... 129 seconds ago
DCA Sensitivity Level: ..... STARTUP (5 dB)
DCA Minimum Energy Limit..... -95 dBm
Channel Energy Levels
  Minimum..... unknown
  Average..... unknown
  Maximum..... unknown
Channel Dwell Times
  Minimum..... unknown
  Average..... unknown
  Maximum..... unknown
Auto-RF Allowed Channel List..... 36,40,44,48,52,56,60,64,149,
..... 153,157,161
Auto-RF Unused Channel List..... 100,104,108,112,116,132,136,
..... 140,165,190,196
DCA Outdoor AP option..... Enabled
```

Related Commands

config advanced 802.11 channel add
config advanced 802.11 channel cleanair-event
config advanced 802.11 channel dca anchor-time
config advanced 802.11 channel dca chan-width-11n
config advanced 802.11 channel dca interval
config advanced 802.11 channel dca sensitivity
config advanced 802.11 channel foreign
config advanced 802.11 channel load

show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

show ap auto-rf 802.11 {a | b} cisco_ap

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.

Command Default

None.

Examples

This example shows how to display auto-RF information for an access point:

```
> show ap auto-rf 802.11a AP1
Number Of Slots..... 2
AP Name..... AP03
MAC Address..... 00:0b:85:01:18:b7
Radio Type..... RADIO_TYPE_80211a
Noise Information
  Noise Profile..... PASSED
  Channel 36..... -88 dBm
  Channel 40..... -86 dBm
  Channel 44..... -87 dBm
  Channel 48..... -85 dBm
  Channel 52..... -84 dBm
  Channel 56..... -83 dBm
  Channel 60..... -84 dBm
  Channel 64..... -85 dBm
Interference Information
  Interference Profile..... PASSED
  Channel 36..... -66 dBm @ 1% busy
  Channel 40..... -128 dBm @ 0% busy
  Channel 44..... -128 dBm @ 0% busy
  Channel 48..... -128 dBm @ 0% busy
  Channel 52..... -128 dBm @ 0% busy
  Channel 56..... -73 dBm @ 1% busy
  Channel 60..... -55 dBm @ 1% busy
  Channel 64..... -69 dBm @ 1% busy
Rogue Histogram (20/40_ABOVE/40_BELOW)
  Channel 36..... 16/ 0/ 0
  Channel 40..... 28/ 0/ 0
  Channel 44..... 9/ 0/ 0
  Channel 48..... 9/ 0/ 0
  Channel 52..... 3/ 0/ 0
  Channel 56..... 4/ 0/ 0
  Channel 60..... 7/ 1/ 0
  Channel 64..... 2/ 0/ 0
Load Information
  Load Profile..... PASSED
  Receive Utilization..... 0%
  Transmit Utilization..... 0%
  Channel Utilization..... 1%
  Attached Clients..... 1 clients
Coverage Information
  Coverage Profile..... PASSED
  Failed Clients..... 0 clients
```

```

Client Signal Strengths
  RSSI -100 dBm..... 0 clients
  RSSI -92 dBm..... 0 clients
  RSSI -84 dBm..... 0 clients
  RSSI -76 dBm..... 0 clients
  RSSI -68 dBm..... 0 clients
  RSSI -60 dBm..... 0 clients
  RSSI -52 dBm..... 0 clients
Client Signal To Noise Ratios
  SNR 0 dBm..... 0 clients
  SNR 5 dBm..... 0 clients
  SNR 10 dBm..... 0 clients
  SNR 15 dBm..... 0 clients
  SNR 20 dBm..... 0 clients
  SNR 25 dBm..... 0 clients
  SNR 30 dBm..... 0 clients
  SNR 35 dBm..... 0 clients
  SNR 40 dBm..... 0 clients
  SNR 45 dBm..... 0 clients
Nearby RADs
  RAD 00:0b:85:01:05:08 slot 0..... -46 dBm on 10.1.30.170
  RAD 00:0b:85:01:12:65 slot 0..... -24 dBm on 10.1.30.170
Channel Assignment Information
  Current Channel Average Energy..... -86 dBm
  Previous Channel Average Energy..... -75 dBm
  Channel Change Count..... 109
  Last Channel Change Time..... Wed Sep 29 12:53e:34 2004
  Recommended Best Channel..... 44
RF Parameter Recommendations
  Power Level..... 1
  RTS/CTS Threshold..... 2347
  Fragmentation Threshold..... 2346
  Antenna Pattern..... 0

```

config Commands

This section explains the **config** commands to configure CleanAir on the controller.

config 802.11 cleanair

To enable or disable CleanAir for the 802.11 a or 802.11 b/g network, use the **config 802.11 cleanair** command.

```
config 802.11 {a | b} cleanair {alarm {air-quality {disable | enable | threshold alarm_threshold } | device
{disable device_type | enable device_type | reporting {disable | enable} | unclassified {disable | enable
| threshold alarm_threshold }} | device {disable device_type | enable device_type | reporting {disable |
enable} | disable {network | cisco_ap} | enable {network | cisco_ap}}
```

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
alarm	Configure 5-GHz cleanair alarms.
air-quality	Configures the 5-GHz air quality alarm.
enable	Enables the CleanAir settings.
disable	Disables the CleanAir settings.
threshold	Configure the 5-GHz air quality alarm threshold.
<i>alarm_threshold</i>	Air quality alarm threshold (1 is bad air quality, and 100 is good air quality).
device	Configures the 5-GHz cleanair interference devices alarm.

<i>device_type</i>	Device types. The device types are as follows: • 802.11-nonstd—Devices using nonstandard Wi-Fi channels. • 802.11-inv—Devices using spectrally inverted Wi-Fi signals. • superag—802.11 SuperAG devices. • all —All interference device types. • cont-tx—Continuous Transmitter. • dect-like—Digital Enhanced Cordless Communication (DECT) like phone. • tdd-tx—TDD Transmitter. • jammer—Jammer. • canopy—Canopy devices. • video—Video cameras. • wimax-mobile—WiMax Mobile. • wimax-fixed—WiMax Fixed.
reporting	Configures the 5-GHz CleanAir interference devices alarm reporting.
unclassified	Configures the 5-GHz air quality alarm on exceeding unclassified category severity.
<i>network</i>	5-GHz Cisco APs.
<i>cisco_ap</i>	Name of the access point to which the command applies.

Command Default Disabled.

Examples This example shows how to enable the CleanAir settings on access point ap_24:

```
> config 802.11a cleanair enable ap_24
```

Related Commands `config 802.11 cleanair device`

config 802.11 cleanair device

To configure CleanAir interference device types, use the **config 802.11 cleanair device** command.

config 802.11 {a | b} cleanair device {enable | disable | reporting {enable | disable}} device_type

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the CleanAir reporting for the interference device type.
disable	Disables the CleanAir reporting for the interference device type.
reporting	Configures CleanAir interference device reporting.
enable	Enables the 5-GHz Cleanair interference devices reporting.
disable	Disables the 5-GHz Cleanair interference devices reporting.
<i>device_type</i>	Interference device type. The device type are as follows: • 802.11-nonstd—Devices using nonstandard WiFi channels. • 802.11-inv—Devices using spectrally inverted WiFi signals. • superag—802.11 SuperAG devices. • all —All interference device types. • cont-tx—Continuous Transmitter. • dect-like—Digital Enhanced Cordless Communication (DECT) like phone. • tdd-tx—TDD Transmitter. • jammer—Jammer. • canopy—Canopy devices. • video—Video cameras. • wimax-mobile—WiMax Mobile. • wimax-fixed—WiMax Fixed.

Command Default Disabled.

Examples This example shows how to enable the CleanAir reporting for the device type jammer:

```
> config 802.11a cleanair device enable jammer
```

This example shows how to disable the CleanAir reporting for the device type video:

```
> config 802.11a cleanair device disable video
```

This example shows how to enable the CleanAir interference device reporting:

```
> config 802.11a cleanair device reporting enable
```

Related Commands config 802.11 cleanair

config 802.11 cleanair alarm

To configure the triggering of the air quality alarms, use the **config 802.11 cleanair alarm** command.

```
config 802.11 {a | b} cleanair alarm {air-quality {disable | enable | threshold alarm_threshold} | device
{disable device_type | enable device_type | reporting {disable | enable} | unclassified {disable | enable
| threshold alarm_threshold }}
```

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
air-quality	Configures the 5-GHz air quality alarm.
disable	Disables the 5-GHz air quality alarm.
enable	Enables the 5-GHz air quality alarm.
threshold	Configures the 5-GHz air quality alarm threshold.
<i>alarm_threshold</i>	Air quality alarm threshold (1 is bad air quality, and 100 is good air quality).
device	Configures the 5-GHz cleanair interference devices alarm.
all	Configures all the device types at once.
reporting	Configures the 5-GHz CleanAir interference devices alarm reporting.
unclassified	Configures the 5-GHz air quality alarm on exceeding unclassified category severity.

<i>device_type</i>	Device types. The device types are as follows: • 802.11-nonstd—Devices using nonstandard Wi-Fi channels. • 802.11-inv—Devices using spectrally inverted Wi-Fi signals. • superag—802.11 SuperAG devices. • all —All interference device types. • cont-tx—Continuous Transmitter. • dect-like—Digital Enhanced Cordless Communication (DECT) like phone. • tdd-tx—TDD Transmitter. • jammer—Jammer. • canopy—Canopy devices. • video—Video cameras. • wimax-mobile—WiMax Mobile. • wimax-fixed—WiMax Fixed.

Command Default Enabled.

Examples This example shows how to enable the CleanAir alarm to monitor the air quality:

```
> config 802.11a cleanair alarm air-quality enable
```

This example shows how to enable the CleanAir alarm for the device type video:

```
> config 802.11a cleanair alarm device enable video
```

This example shows how to enable alarm reporting for the CleanAir interference devices:

```
> config 802.11a cleanair alarm device reporting enable
```

Related Commands `config 802.11 cleanair`

config advanced 802.11 channel cleanair-event

To configure CleanAir event driven Radio Resource Management (RRM) parameters for all 802.11 Cisco lightweight access points, use the **config advanced 802.11 channel cleanair-event** command.

config advanced 802.11 {a | b} channel cleanair-event {enable | disable | sensitivity [low | medium | high] | custom threshold *threshold_value*}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the CleanAir event-driven RRM parameters.
disable	Disables the CleanAir event-driven RRM parameters.
sensitivity	Sets the sensitivity for CleanAir event-driven RRM.
low	(Optional) Specifies low sensitivity.
medium	(Optional) Specifies medium sensitivity
high	(Optional) Specifies high sensitivity
custom	Specifies custom sensitivity.
threshold	Specifies the EDRRM AQ threshold value.
<i>threshold_value</i>	Number of custom threshold.

Command Default

None.

Examples

This example shows how to enable the CleanAir event-driven RRM parameters:

```
> config advanced 802.11 channel cleanair-event enable
```

This example shows how to set the high sensitivity for CleanAir event-driven RRM:

```
> config advanced 802.11 channel cleanair-event sensitivity high
```

Related Commands

show advanced 802.11a channel

config advanced 802.11b channel update

config advanced 802.11 channel pda-prop

To enable or disable propagation of persistent devices, use the **config advanced 802.11 channel pda-prop** command.

config advanced 802.11 {a | b} channel pda-prop {enable | disable}

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.
enable	Enables the 802.11 network DCA list option for the outdoor access point.
disable	Disables the 802.11 network DCA list option for the outdoor access point.

Command Default

Disabled.

Examples

This example shows how to enable or disable propagation of persistent devices:

```
> config advanced 802.11 channel pda-prop enable
```

config advanced 802.11 channel update

To have Radio Resource Management (RRM) initiate a channel selection update for all 802.11a Cisco lightweight access points, use the **config advanced 802.11 channel update** command.

config advanced 802.11 {a | b} channel update

Syntax Description

a	Specifies the 802.11a network.
b	Specifies the 802.11b/g network.

Command Default

None.

Examples

This example shows how to initiate a channel selection update for all 802.11a network access points:

```
> config advanced 802.11a channel update
```

Related Commands

show advanced 802.11a channel
config advanced 802.11b channel update

test Commands

This section lists the **test** commands for CleanAir.

test cleanair show

To display details of the CleanAir configuration, use the **test cleanair show** command.

test cleanair show {**aq all** | **idr** {**ap** *cisco_ap* | **all**} | **neighbors** *cisco_ap* | **summary** }

Syntax Description

aq all	Displays all air quality information.
idr	Displays the interference devices of the 802.11a/n and 802.11b/g/n radio bands for access points.
ap	Displays the interference devices of the 802.11a/n and 802.11b/g/n radio bands for an access point.
<i>cisco_ap</i>	Name of the Cisco access point
all	Displays the interference devices of the 802.11a/n and 802.11b/g/n radio bands for all access points.
neighbors	Displays the neighbors of an access point.
summary	Displays a summary of the CleanAir configuration.

Command Default

None.

Examples

This example shows how to display a summary of the CleanAir configuration:

```
> test cleanair show summary
CleanAir system info:
Supported spectrum MMAP number = 500
Supported spectrum LMAP number = 500
Allocated SI entries           = 0 of 500
Allocated IDR cluster entries  = 0 of 10000
Allocated IDR device entries   = 0 of 40000
Virtual device support is enabled
```

This example shows how to display the interference devices for an access point:

```
> test cleanair show idr ap AP_1240_floor1

Interference devices for AP_1240_floor1
Identified devices on slot 0
Identified devices on slot 1
```



PART **X**

FlexConnect Commands

- [CLI Commands, page 1593](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 1593](#)
- [config Commands, page 1600](#)
- [Integrated Management Module Commands in Cisco Flex 7500 Series Controllers, page 1629](#)
- [debug Commands, page 1635](#)

show Commands

show capwap reap association

To display the list of clients associated to an access point and their Service Set Identifiers (SSIDs), use the **show capwap reap association** command.

show capwap reap association

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display clients associated to an access point and their SSIDs:

```
> show capwap reap association
```

Related Commands

config flexconnect group

show capwap reap status

show capwap reap status

To display the status of the FlexConnect access point (connected or standalone), use the **show capwap reap status** command.

show capwap reap status

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to display the status of the FlexConnect access point:

```
> show capwap reap status
```

Related Commands	config flexconnect group show capwap reap association

show flexconnect acl detailed

To display a detailed summary of FlexConnect access control lists, use the **show flexconnect acl detailed** command.

show flexconnect acl detailed *acl-name*

Syntax Description	
	<i>acl-name</i> Name of the access control list.
Command Default	None.
Examples	This example shows how to display the FlexConnect detailed ACLs: <pre>> show flexconnect acl detailed acl-2</pre>

show flexconnect acl summary

To display a summary of all access control lists on FlexConnect access points, use the **show flexconnect acl summary** command.

show flexconnect acl summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the flexconnect acl summary:

```
> show flexconnect acl summary
ACL Name                               Status
-----
acl1                                   Modified
acl10                                  Modified
acl100                                 Modified
acl101                                 Modified
acl102                                 Modified
acl103                                 Modified
acl104                                 Modified
acl105                                 Modified
acl106                                 Modified
```

show flexconnect group detail

To display the details for a specific FlexConnect group, use the **show flexconnect group detail** command.

show flexconnect group detail *group_name*

Syntax Description

<i>group_name</i>	IP address of the FlexConnect group.

Command Default

None.

Examples

This example shows how to display the detailed information for a specific FlexConnect group:

```
> show flexconnect group detail 192.12.1.2
Number of Ap's in Group: 1
00:0a:b8:3b:0b:c2  AP1200    Joined
Group Radius Auth Servers:
  Primary Server Index ..... Disabled
  Secondary Server Index ..... Disabled
```

Related Commands

config flexconnect group
config flexconnect group summary

show flexconnect group summary

To display the current list of FlexConnect groups, use the **show flexconnect group summary** command.

show flexconnect group summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the current list of FlexConnect groups:

```
> show flexconnect group summary
flexconnect Group Summary:  Count 1
Group Name      #  APs
Group 1         1
```

Related Commands

- config flexconnect group**
- config flexconnect group detail**

show flexconnect office-extend

To display FlexConnect OfficeExtend access point information, use the **show flexconnect office-extend** command.

show flexconnect office-extend {summary | latency}

Syntax Description

summary	Displays a list of all OfficeExtend access points.
latency	Displays the link delay for OfficeExtend access points.

Command Default

None.

Examples

This example shows how to display information about the list of FlexConnect officeExtend access points:

```
> show flexconnect office-extend summary
Summary of OfficeExtend AP
AP Name           Ethernet MAC           Encryption  Join-Mode  Join-Time
-----
AP1130            00:22:90:e3:37:70      Enabled     Latency    Sun Jan 4 21:46:07 2009
AP1140            01:40:91:b5:31:70      Enabled     Latency    Sat Jan 3 19:30:25 2009
```

This example shows how to display the FlexConnect officeExtend access point's link delay:

```
> show flexconnect office-extend latency
Summary of OfficeExtend AP link latency
AP Name           Status  Current  Maximum  Minimum
-----
AP1130            Enabled 15 ms    45 ms    12 ms
AP1140            Enabled 14 ms    179 ms   12 ms
```

Related Commands

config flexconnect group
show flexconnect group detail

config Commands

config ap autoconvert

To automatically convert all access points to a FlexConnect mode or monitor mode upon joining the Cisco WLC, use the **config ap autoconvert** command.

config ap autoconvert {flexconnect | monitor | disable}

Syntax Description

flexconnect	Configures all the access points automatically to FlexConnect mode.
monitor	Configures all the access points automatically to monitor mode.
disable	Disables the autoconvert option on the access points.

Command Default

None.

Usage Guidelines

When access points in local mode connect to a Cisco 7500 Series Wireless Controller, they do not serve clients. The access point details are available in the controller. To enable access points to serve clients or perform monitoring related tasks when connected to the Cisco 7500 Series Wireless Controller, the access points must be in FlexConnect mode or monitor mode.

Examples

This example shows how to automatically convert all access points to the FlexConnect mode:

```
> config ap autoconvert flexconnect
```

This example shows how to disable the autoconvert option on the APs:

```
> config ap autoconvert disable
```

Related Commands

config ap
show ap

config ap flexconnect central-dhcp

To enable central-DHCP on a FlexConnect access point in a WLAN, use the **config ap flexconnect central-dhcp** command.

config ap flexconnect central-dhcp *wlan_id cisco_ap* [**add** | **delete**] {**enable** | **disable**} **override dns** {**enable** | **disable**} **nat-pat** {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
add	(Optional) Adds a new WLAN DHCP mapping.
delete	(Optional) Deletes a WLAN DHCP mapping.
enable	Enables central-DHCP on a FlexConnect access point. When you enable this feature, the DHCP packets received from the access point are centrally switched to the controller and then forwarded to the corresponding VLAN based on the AP and the SSID.
disable	Disables central-DHCP on a FlexConnect access point.
override dns	Overrides the DNS server address on the interface assigned by the controller. When you override DNS in centrally switched WLANs, the clients get their DNS server IP address from the AP and not from the controller.
enable	Enables the Override DNS feature on a FlexConnect access point.
disable	Disables the Override DNS feature on a FlexConnect access point.
nat-pat	Network Address Translation (NAT) and Port Address Translation (PAT) that you can enable or disable.
enable	Enables NAT-PAT on a FlexConnect access point.
disable	Deletes NAT-PAT on a FlexConnect access point.

Command Default

None.

Examples

This example shows how to enable central-DHCP, Override DNS, and NAT-PAT on a FlexConnect access point:

```
> config ap flexconnect central-dhcp 1 ap1250 enable override dns enable nat-pat enable
```


Related Commands

config ap flexconnect local-split
config ap flexconnect web-auth wlan
config ap flexconnect web-policy acl
config ap flexconnect radius
config ap flexconnect vlan add
config ap flexconnect vlan native
config ap flexconnect vlan wlan
config ap flexconnect vlan enable
config ap flexconnect vlan disable

config ap flexconnect local-split

To configure a local-split tunnel on a FlexConnect access point, use the **config ap flexconnect local-split** command.

config ap flexconnect local-split *wlan_id* *cisco_ap* { **enable** | **disable** } **acl** *acl_name*

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>cisco_ap</i>	Name of the FlexConnect access point.
enable	Enables local-split tunnel on a FlexConnect access point.
disable	Disables local-split tunnel feature on a FlexConnect access point.
acl	Configures a FlexConnect local-split access control list.
<i>acl_name</i>	Name of the FlexConnect access control list.

Command Default

None.

Usage Guidelines

This command allows you to configure a local-split tunnel in a centrally switched WLAN using a FlexConnect acl. A local split tunnel supports only for unicast Layer 4 IP traffic as NAT/PAT does not support multicast IP traffic.

Examples

This example shows how to configure a local-split tunnel using a FlexConnect acl:

```
> config ap flexconnect local-split 6 AP2 enable acl flex6
```

Related Commands

config ap flexconnect central-dhcp
config ap flexconnect vlan enable
config ap flexconnect web-auth
config ap flexconnect web-policy acl
config ap flexconnect radius
config ap flexconnect vlan add
config ap flexconnect vlan native
config ap flexconnect vlan wlan
config ap flexconnect vlan disable

config ap flexconnect radius auth set

To configure a primary or secondary RADIUS server for a specific FlexConnect access point, use the **config ap flexconnect radius auth set** command.

config ap flexconnect radius auth set {primary | secondary} *ip_address auth_port secret*

Syntax Description	primary	Specifies the primary RADIUS server for a specific FlexConnect access point.
	secondary	Specifies the secondary RADIUS server for a specific FlexConnect access point.
	<i>ip_address</i>	Name of the Cisco lightweight access point.
	<i>auth_port secret</i>	Name of the port.
	<i>secret</i>	RADIUS server secret.

Command Default None.

Examples This example shows how to configure a primary RADIUS server for a specific access point:
 > **config ap flexconnect radius auth set primary 192.12.12.1**

Related Commands

- config ap mode flexconnect vlan**
- config ap flexconnect vlan wlan**
- config ap flexconnect vlan native**

config ap flexconnect vlan

To enable or disable VLAN tagging for a FlexConnect access, use the **config ap flexconnect vlan** command.

config ap flexconnect vlan {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the access point's VLAN tagging.
disable	Disables the access point's VLAN tagging.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

Disabled. Once enabled, WLANs enabled for local switching inherit the VLAN assigned at the controller.

Examples

This example shows how to enable the access point's VLAN tagging for a FlexConnect access:

```
> config ap flexconnect vlan enable AP02
```

Related Commands

config ap mode flexconnect
config ap flexconnect radius auth set
config ap flexconnect vlan wlan
config ap flexconnect vlan native

config ap flexconnect vlan add

To add a VLAN to a FlexConnect access point, use the **config ap flexconnect vlan add** command.

config ap flexconnect vlan add *vlan-id acl in-acl out-acl cisco_ap*

Syntax Description

<i>vlan-id</i>	VLAN identifier.
<i>acl</i>	ACL name that contains up to 32 alphanumeric characters.
<i>in-acl</i>	Inbound ACL name that contains up to 32 alphanumeric characters.
<i>out-acl</i>	Outbound ACL name that contains up to 32 alphanumeric characters.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to configure the FlexConnect access point:

```
> config ap flexconnect vlan add 21 acl inacl1 outacl1 ap1
```

Related Commands

config ap mode flexconnect
config ap flexconnect radius auth set
config ap flexconnect vlan wlan
config ap flexconnect vlan native

config ap flexconnect vlan native

To configure a native VLAN for a FlexConnect access, use the **config ap flexconnect vlan native** command.

config ap flexconnect vlan native *vlan-id* *cisco_ap*

Syntax Description

<i>vlan-id</i>	VLAN identifier.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

None.

Examples

This example shows how to configure a native VLAN for a FlexConnect access point mode:

```
> config ap flexconnect vlan native 6 AP02
```

Related Commands

config ap mode flexconnect
config ap flexconnect radius auth set
config ap flexconnect vlan wlan

config ap flexconnect vlan wlan

To assign a VLAN ID to a FlexConnect access point, use the **config ap flexconnect vlan wlan** command.

config ap flexconnect vlan wlan *ip_address* *vlan-id* *cisco_ap*

Syntax Description

<i>ip_address</i>	Name of the Cisco lightweight access point.
<i>vlan-id</i>	VLAN identifier.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

Command Default

VLAN ID associated to the WLAN.

Examples

This example shows how to assign a VLAN ID to a FlexConnect access point:

```
> config ap flexconnect vlan wlan 192.12.12.1 6 AP02
```

Related Commands

config ap mode flexconnect
config ap flexconnect radius auth set
config ap flexconnect vlan
config ap flexconnect vlan native

config ap flexconnect web-auth

To configure a FlexConnect ACL for external web authentication in locally switched WLANs, use the **config ap flexconnect web-auth** command.

config ap flexconnect web-auth wlan *wlan_id* *cisco_ap* *acl_name* { **enable** | **disable** }

Syntax Description

wlan	Specifies the wireless LAN to be configured with a FlexConnect ACL.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).
<i>cisco_ap</i>	Name of the FlexConnect access point.
<i>acl_name</i>	Name of the FlexConnect ACL.
enable	Enables the FlexConnect ACL on the locally switched wireless LAN.
disable	Disables the FlexConnect ACL on the locally switched wireless LAN.

Command Default

Disabled.

Usage Guidelines

The FlexConnect ACLs that are specific to an AP have the highest priority. The FlexConnect ACLs that are specific to WLANs have the lowest priority.

Examples

This example shows how to enable FlexConnect ACL for external web authentication on WLAN 6:

```
> config ap flexconnect web-auth wlan 6 AP2 flexacl2 enable
```

Related Commands

config ap flexconnect central-dhcp
config ap flexconnect local-split
config ap flexconnect web-policy acl
config ap flexconnect radius
config ap flexconnect vlan add
config ap flexconnect vlan native
config ap flexconnect vlan wlan
config ap flexconnect vlan

config ap flexconnect web-policy acl

To configure a Web Policy FlexConnect ACL on an access point, use the **config ap flexconnect web-policy acl** command.

config ap flexconnect web-policy acl {add | delete} *acl_name*

Syntax Description

add	Adds a Web Policy FlexConnect ACL on an access point.
delete	Deletes Web Policy FlexConnect ACL on an access point.
<i>acl_name</i>	Name of the Web Policy FlexConnect ACL.

Command Default

None.

Examples

This example shows how to add a Web Policy FlexConnect ACL on an access point:

```
> config ap flexconnect web-policy acl add flexacl2
```

Related Commands

config ap flexconnect central-dhcp
config ap flexconnect vlan enable
config ap flexconnect local-split
config ap flexconnect web-auth
config ap flexconnect radius
config ap flexconnect vlan add
config ap flexconnect vlan native
config ap flexconnect vlan wlan
config ap flexconnect vlan disable

config flexconnect acl

To apply access control lists configured on a FlexConnect access point, use the **config flexconnect acl** command.

config flexconnect acl {**apply** | **create** | **delete**} *acl_name*

Syntax Description

apply	Applies an ACL to the data path.
create	Creates an ACL.
delete	Deletes an ACL.
<i>acl_name</i>	ACL name that contains up to 32 alphanumeric characters.

Examples

This example shows how to apply the ACL configured on a FlexConnect access point:

```
> config flexconnect acl apply acl1
```

config flexconnect acl rule

To configure access control list (ACL) rules on a FlexConnect access point, use the **config flexconnect acl rule** command.

```
config flexconnect aclrule {action rule_name rule_index {permit | deny} | add rule_name rule_index |
change index rule_name old_index new_index | delete rule_name rule_index | destination address rule_name
rule_index ip_address netmask | destination port range rule_name rule_index start_port end_port | direction
rule_name rule_index {in | out | any} | dscp rule_name rule_index dscp | protocol rule_name rule_index
protocol | source address rule_name rule_index ip_address netmask | source port range rule_name
rule_index start_port end_port | swap index rule_name index_1 index_2}
```

Syntax Description

action	Configures whether to permit or deny access.
<i>rule_name</i>	ACL name that contains up to 32 alphanumeric characters.
<i>rule_index</i>	Rule index between 1 and 32.
permit	Permits the rule action.
deny	Denies the rule action.
add	Adds a new rule.
change	Changes a rule's index.
index	Specifies a rule index.
delete	Deletes a rule.
destination address	Configures a rule's destination IP address and netmask.
<i>ip_address</i>	IP address of the rule.
<i>netmask</i>	Netmask of the rule.
<i>start_port</i>	Start port number (between 0 and 65535).
<i>end_port</i>	End port number (between 0 and 65535).
direction	Configures a rule's direction to in, out, or any.
in	Configures a rule's direction to in.
out	Configures a rule's direction to out.
any	Configures a rule's direction to any.
dscp	Configures a rule's DSCP.

<i>dscp</i>	Number between 0 and 63, or any .
protocol	Configures a rule's DSCP.
<i>protocol</i>	Number between 0 and 255, or any .
source address	Configures a rule's source IP address and netmask.
source port range	Configures a rule's source port range.
swap	Swaps two rules' indices.
<i>index_1</i>	The rule first index to swap.
<i>index_2</i>	The rule index to swap the first index with.

Command Default

None.

Examples

This example shows how to configure an ACL to permit access:

```
> config flexconnect acl rule action lab1 4 permit
```

Related Commands

config flexconnect acl
show flexconnect acl summary
show flexconnect group detail

config flexconnect group

To add, delete, or configure a FlexConnect group, use the **config flexconnect group** command.

```
config flexconnect group group_name {add | delete | ap {add | delete} ap_mac | radius {ap {authority
{id hex_id | info auth_info} | disable | eap-fast {enable | disable} | enable | leap {enable | disable} |
pac-timeout timeout | server-key {auto | key} | user {add {username password} | delete username}}} |
server auth {add | delete} {primary | secondary} IP_address auth_port secret} | predownload {disable |
enable} | master ap_name | slave {retry-count max_count | ap-name cisco_ap} | start {primary backup
abort} | local-split {wlan wlan_id acl acl_name {enable | disable}} | multicast overridden-interface
{enable | disable} | vlan {add vlan_id acl in-aclname out-aclname | delete vlan_id} | web-auth wlan wlan_id
acl acl_name {enable | disable} | web-policy acl {add | delete} acl_name}
```

Syntax Description

<i>group_name</i>	Group name.
add	Adds a FlexConnect group.
delete	Deletes a FlexConnect group.
ap	Adds or deletes an access point to a FlexConnect group.
add	Adds an access point to a FlexConnect group.
delete	Deletes an access point to a FlexConnect group.
<i>ap_mac</i>	MAC address of the access point.
radius	Configures the RADIUS server for client authentication for a FlexConnect group.
ap	Configures an access point based RADIUS server for client authentication for a FlexConnect group.
authority	Configures the Extensible Authentication Protocol-Flexible Authentication via Secure Tunneling (EAP-FAST) authority parameters.
id	Configures the authority identifier of the local EAP-FAST server.
<i>hex_id</i>	Authority identifier of the local EAP-FAST server in hexadecimal characters. You can enter up to 32 hexadecimal even number of characters.
info	Configures the authority identifier of the local EAP-FAST server in text format.

<i>auth_info</i>	Authority identifier of the local EAP-FAST server in text format.
disable	Disables an AP based RADIUS server.
eap-fast	Enables or disables Extensible Authentication Protocol-Flexible Authentication via Secure Tunneling (EAP-FAST) authentication.
enable	Enables EAP-FAST authentication.
disable	Disables EAP-FAST authentication.
enable	Enables AP based RADIUS Server.
leap	Enables or disables Lightweight Extensible Authentication Protocol (LEAP) authentication.
disable	Disables LEAP authentication.
enable	Enables LEAP authentication.
pac-timeout	Configures the EAP-FAST Protected Access Credential (PAC) timeout parameters.
<i>timeout</i>	PAC timeout in days. The range is from 2 to 4095. A value of 0 indicates that it is disabled.
server-key	Configures the EAP-FAST server key. The server key is used to encrypt and decrypt PACs.
auto	Automatically generates a random server key.
<i>key</i>	Key that disables efficient upgrade for a FlexConnect group.
user	Manages the user list at the AP-based RADIUS server.
add	Adds a user. You can configure a maximum of 100 users.
<i>username</i>	Username that is case-sensitive and alphanumeric and can be up to 24 characters.
<i>password</i>	Password of the user.
delete	Deletes a user.
server	Configures an external RADIUS server.
add	Adds an external RADIUS server.

delete	Deletes an external RADIUS server.
primary	Configures an external primary RADIUS server.
secondary	Configures an external secondary RADIUS server.
<i>IP_address</i>	IP address of the RADIUS server.
<i>auth_port</i>	Port address of the RADIUS server.
<i>secret</i>	Index of the RADIUS server.
predownload	Configures an efficient AP upgrade for the FlexConnect group. You can download an upgrade image to the access point from the controller without resetting the access point or losing network connectivity.
disable	Disables an efficient upgrade for a FlexConnect group.
enable	Enables an efficient upgrade for a FlexConnect group.
master	Manually designates an access point in the FlexConnect group as the master AP.
<i>ap_name</i>	Access point name.
slave	Manually designates an access point in the FlexConnect group as the slave AP.
retry-count	Configures the number of times the slave access point tries to predownload an image from the master.
<i>max_count</i>	Maximum number of times the slave access point tries to predownload an image from the master.
ap_name	Override the manually configured master.
<i>cisco_ap</i>	Name of the master access point.
start	Starts the predownload image upgrade for the FlexConnect group.
primary	Starts the predownload primary image upgrade for the FlexConnect group.

backup	Starts the predownload backup image upgrade for the FlexConnect group.
abort	Aborts the predownload image upgrade for the FlexConnect group.
local-split	Configures a local-split ACL on a FlexConnect AP group per WLAN.
wlan	Configures a WLAN for a local split ACL on a FlexConnect AP group.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).
acl	Configures a local split ACL on a FlexConnect AP group per WLAN.
<i>acl_name</i>	Name of the ACL.
multicast overridden-interface	Configures multicast across the Layer 2 broadcast domain on the overridden interface for locally switched clients.
vlan	Configures a VLAN to the FlexConnect group.
add	Adds a VLAN to the FlexConnect group.
<i>vlan_id</i>	VLAN identifier.
<i>in-acl</i>	Inbound ACL name that contains up to 32 alphanumeric characters.
<i>out-acl</i>	Outbound ACL name that contains up to 32 alphanumeric characters.
delete	Deletes a VLAN from the FlexConnect group.
web-auth	Configures a FlexConnect ACL for external web authentication.
wlan	Specifies the wireless LAN to be configured with a FlexConnect ACL.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).
<i>cisco_ap</i>	Name of the FlexConnect access point.
acl	Configures a FlexConnect ACLs.
web-policy	Configures a web policy FlexConnect ACL.

add	Adds a web policy FlexConnect ACL to the FlexConnect group.
delete	Deletes a web policy FlexConnect ACL from the FlexConnect group

Command Default

None.

Usage Guidelines

You can add up to 100 clients.

Beginning in Release 7.4 and later releases, the supported maximum number of RADIUS servers is 100.

Examples

This example shows how to add a FlexConnect group for MAC address 192.12.1.2:

```
> config flexconnect group 192.12.1.2 add
```

This example shows how to add a RADIUS server as a primary server for a FlexConnect group with the server index number 1:

```
> config flexconnect group 192.12.1.2 radius server add primary 1
```

This example shows how to enable a local split ACL on a FlexConnect AP group for a WLAN:

```
> config flexconnect group flexgroup1 local-split wlan 1 acl flexacl1 enable
```

Related Commands

config ap mode
config flexconnect join min-latency
config flexconnect office-extend
debug flexconnect group
show flexconnect group detail
show flexconnect group summary

config flexconnect group vlan

To configure VLAN for a FlexConnect group, use the **config flexconnect group vlan** command.

config flexconnect group *group_name* **vlan** {**add** *vlan-id* **acl** *in-aclname* *out-aclname* | **delete** *vlan-id*}

Syntax Description

<i>group_name</i>	FlexConnect group name.
add	Adds a VLAN for the FlexConnect group.
<i>vlan-id</i>	VLAN ID.
acl	Specifies an access control list.
<i>in-aclname</i>	In-bound ACL name.
<i>out-aclname</i>	Out-bound ACL name.
delete	Deletes a VLAN from the FlexConnect group.

Examples

This example shows how to add VLAN ID 1 for the FlexConnect group myflexacl where the in-bound ACL name is in-acl and the out-bound ACL is out-acl:

```
> config flexconnect group vlan myflexacl vlan add 1 acl in-acl out-acl
```

Related Commands

debug flexconnect group
show flexconnect group detail
show flexconnect group summary

config flexconnect group web-auth

To configure Web-Auth ACL for a FlexConnect group, use the **config flexconnect group web-auth** command.

config flexconnect group *group_name* **web-auth wlan** *wlan-id* **acl** *acl-name* {**enable** | **disable**}

Syntax Description

<i>group_name</i>	FlexConnect group name.
<i>wlan-id</i>	WLAN ID.
<i>acl-name</i>	ACL name.
enable	Enables the Web-Auth ACL for a FlexConnect group.
disable	Disables the Web-Auth ACL for a FlexConnect group.

Examples

This example shows how to enable Web-Auth ACL webauthacl for the FlexConnect group myflexacl on WLAN ID 1:

```
> config flexconnect group myflexacl web-auth wlan 1 acl webauthacl enable
```

Related Commands

debug flexconnect group
show flexconnect group detail
show flexconnect group summary

config flexconnect group web-policy

To configure Web Policy ACL for a FlexConnect group, use the **config flexconnect group web-policy** command.

config flexconnect group *group_name* **web-policy acl** {**add** | **delete**} *acl-name*

Syntax Description

<i>group_name</i>	FlexConnect group name.
add	Adds the Web Policy ACL.
delete	Deletes the Web Policy ACL.
<i>acl-name</i>	Name of the Web Policy ACL.

Examples

This example shows how to add the Web Policy ACL mywebpolicyacl to the FlexConnect group myflexacl:

```
> config flexconnect group myflexacl web-policy acl add mywebpolicyacl
```

Related Commands

debug flexconnect group
show flexconnect group detail
show flexconnect group summary

config flexconnect join min-latency

To enable or disable the access point to choose the controller with the least latency when joining, use the **config flexconnect join min-latency** command.

config flexconnect join min-latency {enable | disable} *cisco_ap*

Syntax Description

enable	Enables the access point to choose the controller with the least latency when joining.
disable	Disables the access point to choose the controller with the least latency when joining.
<i>cisco_ap</i>	Cisco lightweight access point.

Command Default

Disabled.

Usage Guidelines

When you enable this feature, the access point calculates the time between the discovery request and discovery response and joins the controller that responds first. This command is supported only on the following controller releases:

- Cisco 2500 Series Controller
- Cisco 5500 Series Controller
- Cisco Flex 7500 Series Controllers
- Cisco 8500 Series Controllers
- Cisco Wireless Services Module 2

This configuration overrides the HA setting on the controller, and is applicable only for OEAP access points.

Examples

This example shows how to enable the access point to choose the controller with the least latency when joining:

```
> config flexconnect join min-latency enable CISCO_AP
```

Related Commands

config ap mode
config flexconnect group
config flexconnect office-extend

config flexconnect office-extend

To configure an OfficeExtend access point, use the **config flexconnect office-extend** command.

config flexconnect office-extend {{enable | disable} *cisco_ap* | clear-personalssid-config *cisco_ap*}

Syntax Description

enable	Enables the OfficeExtend mode for an access point.
disable	Disables the OfficeExtend mode for an access point.
clear-personalssid-config	Clears only the access point's personal SSID.
<i>cisco_ap</i>	Cisco lightweight access point.

Command Default

OfficeExtend mode is enabled automatically when you enable FlexConnect mode on the access point.

Usage Guidelines

Currently, only Cisco Aironet 1130 series and 1140 series access points that are joined to a Cisco 5500 Series Controller with a WPlus license can be configured to operate as OfficeExtend access points.

Rogue detection is disabled automatically when you enable the OfficeExtend mode for an access point. OfficeExtend access points, which are deployed in a home environment, are likely to detect a large number of rogue devices. You can enable or disable rogue detection for a specific access point or for all access points by using the **config rogue detection** command.

DTLS data encryption is enabled automatically when you enable the OfficeExtend mode for an access point. However, you can enable or disable DTLS data encryption for a specific access point or for all access points by using the **config ap link-encryption** command.

Telnet and SSH access are disabled automatically when you enable the OfficeExtend mode for an access point. However, you can enable or disable Telnet or SSH access for a specific access point by using the **config ap telnet** or **config ap ssh** command.

Link latency is enabled automatically when you enable the OfficeExtend mode for an access point. However, you can enable or disable link latency for a specific access point or for all access points currently associated to the controller by using the **config ap link-latency** command.

Examples

This example shows how to enable the office-extend mode for the access point Cisco_ap:

```
> config flexconnect office-extend enable Cisco_ap
```

This example shows how to clear only the access point's personal SSID for the access point Cisco_ap:

```
> config flexconnect office-extend clear-personalssid-config Cisco_ap
```

Related Commands

show flexconnect group detail
show flexconnect group summary
debug flexconnect group

config wlan flexconnect ap-auth

To configure local authentication of clients associated with FlexConnect on a locally switched WLAN, use the **config wlan flexconnect ap-auth** command.

config wlan flexconnect ap-auth *wlan_id* {**enable** | **disable**}

Syntax Description

ap-auth	Configures local authentication of clients associated with an FlexConnect on a locally switched WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables AP authentication on a WLAN.
disable	Disables AP authentication on a WLAN.

Command Default

None.

Usage Guidelines

Local switching must be enabled on the WLAN where you want to configure local authentication of clients associated with FlexConnect.

Examples

This example shows how to enable authentication of clients associated with FlexConnect on a specified WLAN:

```
> config wlan flexconnect ap-auth 6 enable
```

Related Commands

config wlan flexconnect local-switching
show wlan

config wlan flexconnect learn-ipaddr

To enable or disable client IP address learning for the Cisco WLAN controller, use the **config wlan flexconnect learn-ipaddr** command.

config wlan flexconnect learn-ipaddr *wlan_id* {**enable** | **disable**}

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables client IP address learning on a wireless LAN.
disable	Disables client IP address learning on a wireless LAN.

Command Default

Disabled when the **config wlan flexconnect local-switching** command is disabled. Enabled when the **config wlan flexconnect local-switching** command is enabled.

Usage Guidelines

If the client is configured with Layer 2 encryption, the controller cannot learn the client IP address, and the controller will periodically drop the client. Disable this option to keep the client connection without waiting to learn the client IP address.



Note

The ability to disable IP address learning is not supported with FlexConnect central switching.

Examples

This example shows how to disable client IP address learning for WLAN 6:

```
> config wlan flexconnect learn-ipaddr disable 6
```

Related Commands

config wlan flexconnect local-switching
show wlan

config wlan flexconnect local-switching

To configure local switching, central DHCP, NAT-PAT, or the override DNS option on a FlexConnect WLAN, use the **config wlan flexconnect local switching** command.

```
config wlan flexconnect local-switching wlan_id {enable | disable} { {central-dhcp {enable | disable}
nat-pat {enable | disable} } | {override option dns { enable | disable} } }
```

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
enable	Enables local switching on a FlexConnect WLAN.
disable	Disables local switching on a FlexConnect WLAN.
central-dhcp	Configures central switching of DHCP packets on the local switching FlexConnect WLAN. When you enable this feature, the DHCP packets received from the AP are centrally switched to the controller and forwarded to the corresponding VLAN based on the AP and the SSID.
enable	Enables central DHCP on a FlexConnect WLAN.
disable	Disables central DHCP on a FlexConnect WLAN.
nat-pat	Configures Network Address Translation (NAT) and Port Address Translation (PAT) on the local switching FlexConnect WLAN.
enable	Enables NAT-PAT on the FlexConnect WLAN.
disable	Disables NAT-PAT on the FlexConnect WLAN.
override	Specifies the DHCP override options on the FlexConnect WLAN.
option dns	Specifies the override DNS option on the FlexConnect WLAN. When you override this option, the clients get their DNS server IP address from the AP, not from the controller.
enable	Enables the override DNS option on the FlexConnect WLAN.
disable	Disables the override DNS option on the FlexConnect WLAN.

Command Default

Disabled.

Usage Guidelines

When you enable the **config wlan flexconnect local-switching** command, the **config wlan flexconnect learn-ipaddr** command is enabled by default.

**Note**

The ability to disable IP address learning is not supported with FlexConnect central switching.

Examples

This example shows how to enable WLAN 6 for local switching and enable central DHCP and NAT-PAT:

```
> config wlan flexconnect local-switching 6 enable central-dhcp enable nat-pat enable
```

This example shows how to enable the override DNS option on WLAN 6:

```
> config wlan flexconnect local-switching 6 override option dns enable
```

Related Commands

config wlan flexconnect learn-ipaddr

config wlan flexconnect vlan-central-switching

config wlan flexconnect ap-auth

show wlan

config wlan flexconnect vlan-central-switching

To configure central switching on a locally switched WLAN, use the **config wlan flexconnect vlan-central-switching** command.

config wlan flexconnect vlan-central-switching *wlan_id* { **enable** | **disable** }

Syntax Description

<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
enable	Enables central switching on a locally switched wireless LAN.
disable	Disables central switching on a locally switched wireless LAN.

Command Default

Disabled.

Usage Guidelines

You must enable Flexconnect local switching to enable VLAN central switching. When you enable WLAN central switching, the access point bridges the traffic locally if the WLAN is configured on the local IEEE 802.1Q link. If the VLAN is not configured on the access point, the AP tunnels the traffic back to the controller and the controller bridges the traffic to the corresponding VLAN.

WLAN central switching does not support:

- FlexConnect local authentication.
- Layer 3 roaming of local switching client.

Examples

This example shows how to enable WLAN 6 for central switching:

```
> config wlan flexconnect vlan-central-switching 6 enable
```

Related Commands

config wlan flexconnect local-switching
show wlan

Integrated Management Module Commands in Cisco Flex 7500 Series Controllers

Use the **imm** commands to manage the Integrated Management Module (IMM) in the Cisco Flex 7500 Series Controllers.

imm address

To configure the static IP address of the IMM, use the **imm address** command.

imm address *ip-addr netmask gateway*

Syntax Description

<i>ip-addr</i>	IP address of the IMM
<i>netmask</i>	Netmask of the IMM
<i>gateway</i>	Gateway of the IMM

Command Default

None.

Examples

This example shows how to set the static IP address of an IMM:

```
> imm address 209.165.200.225 255.255.255.224 10.1.1.1
```

Related Commands

imm dhcp
imm mode
imm restart
imm username
imm summary

imm dhcp

To configure DHCP for the IMM, use the **imm dhcp** command.

imm dhcp {enable | disable | fallback}

Syntax Description

enable	Enables DHCP for the IMM
disable	Disables DHCP for the IMM
fallback	Enables DHCP for the IMM, but if it fails, then uses static IP of the IMM

Command Default

Enabled.

Examples

This example shows how to enable DHCP for the IMM:

```
> imm dhcp enable
```

Related Commands

imm address
imm mode
imm restart
imm username
imm summary

imm mode

To configure the IMM mode, use the **imm mode** command.

imm mode {shared | dedicated}

Syntax Description

shared	Sets IMM in shared mode
dedicated	Sets IMM in dedicated mode

Command Default

Dedicated.

Examples

This example shows how to set the IMM in shared mode:

```
> imm mode
```

Related Commands

imm dhcp
imm address
imm restart
imm username
imm summary

imm restart

To restart the IMM, use the **imm restart** command.

imm restart

Syntax Description	restart	Saves your settings and restarts the IMM
Command Default	None.	
Related Commands	imm dhcp imm mode imm address imm username imm summary	

imm summary

To view the IMM parameters, use the **imm summary** command.

imm summary

Syntax Description

summary	Lists the IMM parameters

Command Default

None.

Examples

This example shows a typical summary of the IMM:

```
> imm summary
User ID.....username1
Mode..... Shared
DHCP..... Enabled
IP Address..... 209.165.200.225
Subnet Mask..... 255.255.255.224
Gateway..... 10.1.1.1
```

Related Commands

imm dhcp
imm mode
imm restart
imm username
imm address

imm username

To configure the logon credentials for an IMM user, use the **imm username** command.

imm username *username password*

Syntax Description

<i>username</i>	Username for the user
<i>password</i>	Password for the user

Command Default

None.

Examples

This example shows how to set the logon credentials of an IMM user:

```
> imm username username1 password1
```

Related Commands

imm dhcp
imm mode
imm restart
imm address
imm summary

debug Commands

debug capwap reap

To configure the debugging of Control and Provisioning of Wireless Access Points (CAPWAP) settings on a FlexConnect access point, use the **debug capwap reap** command.

debug capwap reap [**mgmt** | **load**]

Syntax Description

mgmt	(Optional) Configures the debugging for client authentication and association messages.
load	(Optional) Configures the debugging for payload activities, which is useful when the FlexConnect access point boots up in standalone mode.

Command Default

None.

Examples

This example shows how to configure the debugging of FlexConnect client authentication and association messages:

```
> debug capwap reap mgmt
```

Related Commands

debug disable-all
clear lwapp private-config
show capwap reap association
show capwap reap status

debug dot11 mgmt interface

To debug 802.11 management interface events, use the **debug dot11 mgmt interface** command.

debug dot11 mgmt interface

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to debug 802.11 management interface events:

```
> debug dot11 mgmt interface
```

Related Commands

- debug disable-all**
- debug dot11**
- debug dot11 mgmt msg**
- debug dot11 mgmt ssid**
- debug dot11 mgmt state-machine**
- debug dot11 mgmt station**

debug dot11 mgmt msg

To debug 802.11 management messages, use the **debug dot11 mgmt msg** command.

debug dot11 mgmt msg

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to debug dot11 management messages:

```
> debug dot11 mgmt msg
```

Related Commands

- debug disable-all**
- debug dot11**
- debug dot11 mgmt msg**
- debug dot11 mgmt interface**
- debug dot11 mgmt ssid**
- debug dot11 mgmt state-machine**
- debug dot11 mgmt station**

debug dot11 mgmt ssid

To configure the debugging of 802.11 Service Set Identifier (SSID) management events, use the **debug dot11 mgmt ssid** command.

debug dot11 mgmt ssid

Syntax Description	This command has no arguments or keywords.

Command Default	None.

Examples	This example shows how to configure the debugging of 802.11 SSID management events:

```
> debug dot11 mgmt ssid
```

Related Commands	debug disable-all debug dot11 debug dot11 mgmt msg debug dot11 mgmt interface debug dot11 mgmt state-machine

debug dot11 mgmt state-machine

To configure the debugging of the 802.11 state machine, use the **debug dot11 mgmt state-machine** command.

debug dot11 mgmt state-machine

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to configure the debugging of 802.11 state machine:

```
> debug dot11 mgmt state-machine
```

Related Commands

- debug disable-all**
- debug dot11**
- debug dot11 mgmt msg**
- debug dot11 mgmt interface**
- debug dot11 mgmt state-machine**
- debug dot11 mgmt station**

debug dot11 mgmt station

To configure the debugging of the management station settings, use the **debug dot11 mgmt station** command.

debug dot11 mgmt station

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to configure the debugging of the management station settings:

```
> debug dot11 mgmt station
```

Related Commands

- debug disable-all**
- debug dot11**
- debug dot11 mgmt msg**
- debug dot11 mgmt ssid**
- debug dot11 mgmt state-machine**
- debug dot11 mgmt interface**

debug flexconnect aaa

To enable or disable the debugging of FlexConnect backup RADIUS server events or errors, use the **debug flexconnect aaa** command.

debug flexconnect aaa {event | error} {enable | disable}

Syntax Description

event	Configures the debugging for FlexConnect RADIUS server events.
error	Configures the debugging for FlexConnect RADIUS server errors.
enable	Enables the debugging of FlexConnect RADIUS server settings.
disable	Disables the debugging of FlexConnect RADIUS server settings.

Command Default

None.

Examples

This example shows how to enable the debugging of FlexConnect RADIUS server events:

```
> debug flexconnect aaa event enable
```

Related Commands

debug disable-all
debug flexconnect cckm
debug flexconnect group
debug flexconnect group detail
debug flexconnect group summary
show radius summary

debug flexconnect acl

To enable or disable the debugging of FlexConnect access control lists (ACLs), use the **debug flexconnect acl** command.

debug flexconnect acl {enable | disable}

Syntax Description

enable	Enables the debugging of FlexConnect ACLs.
disable	Disables the debugging of FlexConnect ACLs.

Command Default

None.

Examples

This example shows how to enable the debugging of FlexConnect ACLs:

```
> debug flexconnect acl enable
```

Related Commands

debug disable-all
debug flexconnect cckm
debug flexconnect group
debug flexconnect group detail
debug flexconnect group summary
show radius summary

debug flexconnect cckm

To enable or disable the debugging of FlexConnect Cisco Centralized Key Management (CCKM) fast roaming, use the **debug flexconnect cckm** command.

debug flexconnect cckm {enable | disable}

Syntax Description

enable	Enables the debugging of FlexConnect CCKM fast roaming settings.
disable	Disables the debugging of FlexConnect CCKM fast roaming settings.

Command Default

None.

Examples

This example shows how to enable the debugging of FlexConnect CCKM fast roaming events:

```
> debug flexconnect cckm event enable
```

Related Commands

debug disable-all
debug flexconnect aaa
debug flexconnect group
debug flexconnect group detail
debug flexconnect group summary
show radius summary

debug flexconnect group

To configure the debugging of FlexConnect access point groups, use the **debug flexconnect group** command.

debug flexconnect group {enable | disable}

Syntax Description

enable	Enables the debugging of FlexConnect access point groups.
disable	Disables the debugging of FlexConnect access point groups.

Command Default

None.

Examples

This example shows how to enable the debugging of FlexConnect access point groups:

```
> debug flexconnect group enable
```

Related Commands

debug disable-all
debug flexconnect aaa
debug flexconnect cckm
debug flexconnect group
debug flexconnect group detail
debug flexconnect group summary

debug pem

To configure the debugging of the access policy manager, use the **debug pem** command.

debug pem {events | state} {enable | disable}

Syntax Description

events	Configures the debugging of the policy manager events.
state	Configures the debugging of the policy manager state machine.
enable	Enables the debugging of the access policy manager.
disable	Disables the debugging of the access policy manager.

Command Default

None.

Examples

This example shows how to enable the debugging of the access policy manager:

```
> debug pem state enable
```

Related Commands

debug disable-all



PART **XI**

Mobility Commands

- [CLI Commands, page 1649](#)



CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 1649](#)
- [config Commands, page 1669](#)
- [clear, debug and ping Commands, page 1700](#)

show Commands

This section lists the **show** commands to display information about your mobility configuration settings.

show advanced client-handoff

To display the number of automatic client handoffs after retries, use the **show advanced client-handoff** command.

show advanced client-handoff

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the client auto handoff mode after excessive retries:

```
> show advanced client-handoff
Client auto handoff after retries..... 130
```

Related Commands

config advanced client-handoff
config advanced 802.11 summary

show l2tp

To display Layer 2 Tunneling Protocol (L2TP) sessions, use the **show l2tp** command.

show l2tp {**summary** | *ip_address*}

Syntax Description

summary	Displays all L2TP sessions.
<i>ip_address</i>	IP address.

Command Default

None.

Examples

This example shows how to display a summary of all L2TP sessions:

```
> show l2tp summary
LAC_IPaddr  LTid  LSid  RTid  RSid  ATid  ASid  State
-----
```

show logging

To display the syslog facility logging parameters and buffer contents, use the **show logging** command.

show logging

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the current settings and buffer content details:

```
> show logging
Logging to buffer :
- Logging of system messages to buffer :
  - Logging filter level..... errors
  - Number of system messages logged..... 67227
  - Number of system messages dropped..... 21136
- Logging of debug messages to buffer ..... Disabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
Logging to console :
- Logging of system messages to console :
  - Logging filter level..... errors
  - Number of system messages logged..... 0
  - Number of system messages dropped..... 88363
- Logging of debug messages to console ..... Enabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
Logging to syslog :
- Syslog facility..... local0
- Logging of system messages to syslog :
  - Logging filter level..... errors
  - Number of system messages logged..... 67227
  - Number of system messages dropped..... 21136
- Logging of debug messages to syslog ..... Disabled
  - Number of debug messages logged..... 0
  - Number of debug messages dropped..... 0
- Number of remote syslog hosts..... 0
  - Host 0..... Not Configured
  - Host 1..... Not Configured
  - Host 2..... Not Configured
Logging of traceback..... Disabled
Logging of process information..... Disabled
Logging of source file informational..... Enabled
Timestamping of messages.....
- Timestamping of system messages..... Enabled
  - Timestamp format..... Date and Time
- Timestamping of debug messages..... Enabled
  - Timestamp format..... Date and Time
Logging buffer (67227 logged, 21136 dropped)
*Apr 03 09:48:01.728: %MM-3-INVALID_PKT_RECVD: mm_listen.c:5508 Received an invalid
packet from 1.100.163.51. Source member:0.0.0.0. Source member unknown.
*Apr 03 09:47:34.194: %LWAPP-3-DECODE_ERR: spam_lrad.c:1271 Error decoding discovery
request from AP 00:13:5f:0e:d4:20
*Apr 03 09:47:34.194: %LWAPP-3-DISC_OTAP_ERR: spam_lrad.c:5554 Ignoring OTAP discovery
request from AP 00:13:5f:0e:d4:20, OTAP is disabled
Previous message occurred 2 times.
```

Related Commands **config logging syslog host**

config logging syslog facility

config logging syslog level

show mobility anchor

To display the wireless LAN anchor export list for the Cisco wireless LAN controller mobility groups or to display a list and status of controllers configured as mobility anchors for a specific WLAN or wired guest LAN, use the **show mobility anchor** command.

show mobility anchor [**wlan** *wlan_id* | **guest-lan** *guest_lan_id*]

Syntax Description

wlan	(Optional) Displays wireless LAN mobility group settings.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512 (inclusive).
guest-lan	(Optional) Displays guest LAN mobility group settings.
<i>guest_lan_id</i>	Guest LAN identifier from 1 to 5 (inclusive).

Command Default

None.

Usage Guidelines

The status field display (see example) shows one of the following values:

- UP—The controller is reachable and able to pass data.
- CNTRL_PATH_DOWN—The mpings failed. The controller cannot be reached through the control path and is considered failed.
- DATA_PATH_DOWN—The epings failed. The controller cannot be reached and is considered failed.
- CNTRL_DATA_PATH_DOWN—Both the mpings and epings failed. The controller cannot be reached and is considered failed.

Examples

This example shows how to display a mobility wireless LAN anchor list:

```
> show mobility anchor
Mobility Anchor Export List
WLAN ID      IP Address      Status
-----
12           192.168.0.15    UP
GLAN ID      IP Address      Status
-----
1            192.168.0.9     CNTRL_DATA_PATH_DOWN
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval

config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility foreign-map
show mobility summary

show mobility ap-list

To display the mobility AP list, use the **show mobility ap-list** command.

show mobility ap-list

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the mobility AP list:

```
> show mobility ap-list
AP Name                AP Radio MAC address    Controller    Learnt From
-----
AP30e4.dbc5.38ab       b8:62:1f:e5:33:10      9.7.104.10    Self
```

Related Commands

- config mobility group
- debug mobility
- show mobility anchor
- config wlan mobility foreign-map
- config mobility group member
- config wlan mobility anchor
- show mobility summary

show mobility foreign-map

To display a mobility wireless LAN foreign map list, use the **show mobility foreign-map** command.

show mobility foreign-map wlan *wlan_id*

Syntax Description

wlan	Displays the mobility WLAN foreign-map list.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to get a mobility wireless LAN foreign map list:

```
> show mobility foreign-map wlan 2
Mobility Foreign Map List
WLAN ID          Foreign MAC Address          Interface
-----          -
2                00:1b:d4:6b:87:20          dynamic-105
```

Related Commands

debug mobility
show mobility anchor
config wlan mobility foreign-map
config mobility group member
config wlan mobility anchor
show mobility summary

show mobility group member

To display the details of the mobility group members in the same domain, use the **show mobility group member** command.

show mobility group member hash

Syntax Description

hash	Displays the hash keys of the mobility group members in the same domain.

Command Default

None.

Examples

This example shows how to display the hash keys of the mobility group members:

```
> show mobility group member hash
Default Mobility Domain..... new-mob

  IP Address      Hash Key
-----
  9.2.115.68      a819d479dcfeb3e0974421b6e8335582263d9169
  9.6.99.10       0974421b6e8335582263d9169a819d479dcfeb3e
  9.7.7.7         feb3e0974421b6e8335582263d9169a819d479dc
```

Related Commands

show certificate ssc
show mobility group member
config certificate ssc
config mobility group member hash
debug mobility
show mobility anchor
config wlan mobility foreign-map
config mobility group member
config wlan mobility anchor
show mobility summary

show mobility statistics

To display the statistics information for the Cisco wireless LAN controller mobility groups, use the **show mobility statistics** command.

show mobility statistics

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display statistics of the mobility manager:

```
> show mobility statistics
Global Mobility Statistics
  Rx Errors..... 0
  Tx Errors..... 0
  Responses Retransmitted..... 0
  Handoff Requests Received..... 0
  Handoff End Requests Received..... 0
  State Transitions Disallowed..... 0
  Resource Unavailable..... 0
Mobility Initiator Statistics
  Handoff Requests Sent..... 0
  Handoff Replies Received..... 0
  Handoff as Local Received..... 2
  Handoff as Foreign Received..... 0
  Handoff Denys Received..... 0
  Anchor Request Sent..... 0
  Anchor Deny Received..... 0
  Anchor Grant Received..... 0
  Anchor Transfer Received..... 0
Mobility Responder Statistics
  Handoff Requests Ignored..... 0
  Ping Pong Handoff Requests Dropped..... 0
  Handoff Requests Dropped..... 0
  Handoff Requests Denied..... 0
  Client Handoff as Local..... 0
  Client Handoff as Foreign ..... 0
  Client Handoff Inter Group ..... 0
  Anchor Requests Received..... 0
  Anchor Requests Denied..... 0
  Anchor Requests Granted..... 0
  Anchor Transferred..... 0
```

Related Commands

- config mobility group anchor
- config mobility group domain
- config mobility group keepalive count
- config mobility group keepalive interval
- config mobility group member
- config mobility group multicast-address
- config mobility multicast-mode

config mobility secure-mode
config mobility statistics reset
debug mobility
show mobility anchor
show mobility summary

show mobility summary

To display the summary information for the Cisco WLC mobility groups, use the **show mobility summary** command.

show mobility summary

Syntax Description

This command has no arguments or keywords.

Command Default

None

Usage Guidelines

Some WLAN controllers may list no mobility security mode.

Examples

The following is a sample output of the **show mobility summary** command.

```
Device > show mobility summary

Symmetric Mobility Tunneling (current) ..... Disabled
Symmetric Mobility Tunneling (after reboot) ..... Disabled
Mobility Protocol Port..... 16666
Mobility Security Mode..... Disabled
Default Mobility Domain..... snmp_gui
Multicast Mode ..... Disabled
Mobility Domain ID for 802.11r..... 0x66bd
Mobility Keepalive Interval..... 10
Mobility Keepalive Count..... 3
Mobility Group Members Configured..... 1
Mobility Control Message DSCP Value..... 0
Controllers configured in the Mobility Group
MAC Address      IP Address      Group Name      Multicast IP      Status
00:1b:d4:6b:87:20  1.100.163.70    snmp_gui        0.0.0.0           Up
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor

show mobility statistics

show pmipv6 domain

To display the summary information of a PMIPv6 domain, use the **show pmipv6 domain** command.

show pmipv6 domain *domain_name* **profile** *profile_name*

Syntax Description

<i>domain_name</i>	Name of the PMIPv6 domain. The domain name can be up to 127 case-sensitive alphanumeric characters.
profile	Specifies the PMIPv6 profile.
<i>profile_name</i>	Name of the profile associated with the PMIPv6 domain. The profile name can be up to 127 case-sensitive alphanumeric characters.

Examples

This example shows how to display the summary information of a PMIPv6 domain:

```
> show pmipv6 domain floor1 profile profile1
NAI: @vodafone.com
APN: Vodafone
LMA: VodafoneLMA

NAI: *
APN: ciscoapn
LMA: ciscocolma
```

Related Commands

show pmipv6 profile summary
show wlan summary
show client summary
show mag globals
config wlan pmipv6 profile-name
config pmipv6 domain
config pmipv6 add profile

show pmipv6 mag bindings

To display the binding information of a Mobile Access Gateway (MAG), use the **show pmipv6 mag binding** command.

show pmipv6 mag bindings [*lma lma_name* | *nai nai_string*]

Syntax Description

lma	(Optional) Displays the binding details of the MAG to an Local Mobility Anchor (LMA).
<i>lma_name</i>	Name of the LMA. The LMA name is case-sensitive and can be up to 127 alphanumeric characters.
nai	(Optional) Displays the binding details of the MAG to a client.
<i>nai_string</i>	Network Access Identifier (NAI) of the client. The NAI is case-sensitive and can be up to 127 alphanumeric characters. You can use all special characters except a colon.

Examples

This example shows how to display the MAG bindings:

```
> show pmipv6 mag binding
[Binding][MN]: Domain: D1, Nai: MN1@cisco.com
[Binding][MN]: State: ACTIVE
[Binding][MN]: Interface: Management
[Binding][MN]: Hoa: 0xE0E0E02, att: 3, l1id: aabb.cc00.c800
[Binding][MN][LMA]: Id: LMA1
[Binding][MN][LMA]: lifetime: 3600
[Binding][MN][GREKEY]: Upstream: 102, Downstream: 1
```

Related Commands

show pmipv6 domain
show wlan summary
show client summary
show pmipv6 mag globals
show pmipv6 mag stats
config pmipv6 mag lma
config pmipv6 mag bri retries
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag binding maximum
config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time

config pmipv6 mag replay-protection

config pmipv6 mag bri delay

show pmipv6 mag globals

To display the global PMIPv6 parameters of the Mobile Access Gateway (MAG), use the **show pmipv6 mag globals** command.

show pmipv6 mag globals

Syntax Description

This command has no arguments or keywords.

Examples

This example shows how to display the global PMIPv6 parameters of a MAG:

```
> show pmipv6 mag globals
Domain : D1

MAG Identifier : M1
  MAG Interface           : Management
  Max Bindings            : 10000
  Registration Lifetime   : 3600 (sec)
  BRI Init-delay time     : 1000 (msec)
  BRI Max-delay time      : 2000 (msec)
  BRI Max retries         : 1
  Refresh time            : 300 (sec)
  Refresh RetxInit time   : 1000 (msec)
  Refresh RetxMax time    : 32000 (msec)
  Timestamp option        : Enabled
  Validity Window         : 7
Peer#1:
  LMA Name: AN-LMA-5K      LMA IP: 209.165.201.10
Peer#2:
  LMA Name: AN-LMA         LMA IP: 209.165.201.4
Peer#3:
  LMA Name: AN-LMA         LMA IP: 209.165.201.4
```

Related Commands

show pmipv6 domain
show wlan summary
show client summary
show pmipv6 mag stats
show pmipv6 mag bindings
config pmipv6 mag lma
config pmipv6 mag bri retries
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag binding maximum
config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag replay-protection
config pmipv6 mag bri delay

show pmipv6 mag stats

To display the statistics of the Mobile Access Gateway (MAG), use the **show pmipv6 mag stats** command.

show pmipv6 mag stats [**domain** *domain_name* **peer** *lma_name*]

Syntax Description

domain	(Optional) Displays the MAG statistics for a Local Mobility Anchor (LMA) in the domain.
<i>domain_name</i>	Name of the PMIPv6 domain. The domain name is case-sensitive and can be up to 127 alphanumeric characters.
peer	(Optional) Displays the MAG statistics for an LMA.
<i>lma_name</i>	Name of the LMA. The LMA name is case sensitive and can be up to 127 alphanumeric characters.

Usage Guidelines

This table lists the descriptions of the LMA statistics.

Table 12: Descriptions of the LMA Statistics:

LMA Statistics	Description
PBU Sent	Total number of Proxy Binding Updates (PBUs) sent to the LMA by the MAG. PBU is a request message sent by the MAG to a mobile node's LMA for establishing a binding between the mobile node's interface and its current care-of address (Proxy-CoA).
PBA Received	Total number of Proxy Binding Acknowledgements (PBAs) received by the MAG from the LMA. PBA is a reply message sent by an LMA in response to a PBU message that it receives from a MAG.
PBRI Sent	Total number of Proxy Binding Revocation Indications (PBRIs) sent by the MAG to the LMA.
PBRI Received	Total number of PBRIs received from the LMA by the MAG.
PBRA Sent	Total number of Proxy Binding Revocation Acknowledgements (PBRAs) sent by the MAG to the LMA.

LMA Statistics	Description
PBRA Received	Total number of PBRA's that the MAG receives from the LMA.
Number of Handoff	Number of handoffs between the MAG and the LMA.

Examples

This example shows how to display the LMA statistics:

```
> show pmipv6 mag stats
[M1]: Total Bindings      : 1
[M1]: PBU Sent           : 7
[M1]: PBA Rcvd           : 4
[M1]: PBRI Sent          : 0
[M1]: PBRI Rcvd          : 0
[M1]: PBRA Sent          : 0
[M1]: PBRA Rcvd          : 0
[M1]: No Of handoff      : 0
```

Related Commands

```
show pmipv6 domain
show wlan summary
show client summary
show pmipv6 mag globals
show pmipv6 mag bindings
config pmipv6 mag lma
config pmipv6 mag bri retries
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag binding maximum
config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag replay-protection
config pmipv6 mag bri delay
```

show pmipv6 profile summary

To display the summary of the PMIPv6 profiles, use the **show pmipv6 profile summary** command.

show pmipv6 profile summary

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to display the summary of the PMIPv6 profiles:

```
> show pmipv6 profile summary
Profile Name      WLAN IDS (Mapped)
-----
Group1           6
```

Related Commands

- show pmipv6 domain**
- show wlan summary**
- show client summary**
- show mag globals**
- config wlan pmipv6 profile-name**

config Commands

This section lists the **config** commands to configure mobility.

config mobility dscp

To configure the mobility intercontroller DSCP value, use the **config mobility dscp** command.

config mobility dscp *dscp_value*

Syntax Description

<i>dscp_value</i>	DSCP value ranging from 0 to 63.

Command Default

None.

Examples

This example shows how to configure the mobility intercontroller DSCP value to 40:

```
> config mobility dscp 40
```

Related Commands

- config guest-lan mobility anchor**
- config mobility group domain**
- config mobility group keepalive count**
- config mobility group keepalive interval**
- config mobility group member**
- config mobility group multicast-address**
- config mobility multicast-mode**
- config mobility secure-mode**
- config mobility statistics reset**
- config wlan mobility anchor**
- debug mobility**

config mobility group anchor

To create a new mobility anchor for the WLAN or wired guest LAN, enter, use the **config mobility group anchor** command.

config mobility group anchor {**add** | **delete**} {**wlan** *wlan_id* | **guest-lan** *guest_lan_id*} *anchor_ip*

Syntax Description

add	Adds or changes a mobility anchor to a wireless LAN.
delete	Deletes a mobility anchor from a wireless LAN.
wlan	Specifies the wireless LAN anchor settings.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512 (inclusive).
guest-lan	Specifies the guest LAN anchor settings.
<i>guest_lan_id</i>	Guest LAN identifier between 1 and 5 (inclusive).
<i>anchor_ip</i>	IP address of the anchor controller.

Command Default

None.

Usage Guidelines

The *wlan_id* or *guest_lan_id* must exist and be disabled.

Auto-anchor mobility is enabled for the WLAN or wired guest LAN when you configure the first mobility anchor. Deleting the last anchor disables the auto-anchor mobility feature and resumes normal mobility for new associations.

Examples

This example shows how to add a mobility anchor with the IP address 192.12.1.5 to a wireless LAN ID 2:

```
> config mobility group anchor add wlan 2 192.12.1.5
```

This example shows how to delete a mobility anchor with the IP address 193.13.1.15 from a wireless LAN:

```
> config mobility group anchor delete wlan 5 193.13.1.5
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address

config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config mobility group domain

To configure the mobility domain name, use the **config mobility group domain** command.

config mobility group domain *domain_name*

Syntax Description

<i>domain_name</i>	Domain name. The domain name can be up to 31 case-sensitive characters.

Command Default

None.

Examples

This example shows how to configure a mobility domain name lab1:

```
> config mobility group domain lab1
```

Related Commands

- config guest-lan mobility anchor
- config mobility group domain
- config mobility group keepalive count
- config mobility group keepalive interval
- config mobility group member
- config mobility group multicast-address
- config mobility multicast-mode
- config mobility secure-mode
- config mobility statistics reset
- config wlan mobility anchor
- debug mobility
- show mobility anchor
- show mobility statistics
- show mobility summary

config mobility group keepalive count

To configure the Cisco WLC to detect failed mobility group members (including anchor Cisco WLCs), use the **config mobility group keepalive count** command.

config mobility group keepalive count *count*

Syntax Description

<i>count</i>	Number of times that a ping request is sent to a mobility group member before the member is considered unreachable. The range is from 3 to 20. The default is 3.

Command Default

3.

Examples

This example shows how to specify the number of times a ping request is sent to a mobility group member before the member is considered unreachable to three counts:

```
> config mobility group keepalive count 3
```

Related Commands

- config guest-lan mobility anchor
- config mobility group domain
- config mobility group keepalive count
- config mobility group keepalive interval
- config mobility group member
- config mobility group multicast-address
- config mobility multicast-mode
- config mobility secure-mode
- config mobility statistics reset
- config wlan mobility anchor
- debug mobility
- show mobility anchor
- show mobility statistics
- show mobility summary

config mobility group keepalive interval

To configure the controller to detect failed mobility group members (including anchor controllers), use the **config mobility group keepalive** command.

config mobility group keepalive *interval*

Syntax Description	<i>interval</i>	Interval of time between each ping request sent to a mobility group member. The range is from 1 to 30 seconds. The default value is 10 seconds.

Command Default 10 seconds.

Examples This example shows how to specify the amount of time between each ping request sent to a mobility group member to 10 seconds:

```
> config mobility group keepalive 10
```

Related Commands

- config guest-lan mobility anchor
- config mobility group domain
- config mobility group keepalive count
- config mobility group keepalive interval
- config mobility group member
- config mobility group multicast-address
- config mobility multicast-mode
- config mobility secure-mode
- config mobility statistics reset
- config wlan mobility anchor
- debug mobility
- show mobility anchor
- show mobility statistics
- show mobility summary

config mobility group member

To add or delete users from the mobility group member list, use the **config mobility group member** command.

config mobility group member {**add** *MAC IP_address* [*group_name*] | **delete** *MAC IP_address* | **hash** *IP_address* {*key* | **none**}}

Syntax Description

add	Adds or changes a mobility group member to the list.
<i>MAC</i>	Member switch MAC address.
<i>IP_address</i>	Member switch IP address.
<i>group_name</i>	(Optional) Member switch group name (if different from the default group name).
delete	(Optional) Deletes a mobility group member from the list.
hash	Configures the hash key for authorization. You can configure the hash key only if the member is a virtual controller in the same domain.
<i>key</i>	Hash key of the virtual controller. For example, a819d479dcfeb3e0974421b6e8335582263d9169
none	Clears the previous hash key of the virtual controller.

Command Default

None.

Examples

This example shows how to add a mobility group member to the list:

```
> config mobility group member add 11:11:11:11:11:11 192.12.1.2
```

This example shows how to configure the hash key of a virtual controller in the same domain:

```
> config mobility group member hash 9.2.115.68 a819d479dcfeb3e0974421b6e8335582263d9169
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval

config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config mobility group multicast-address

To configure the multicast group IP address for nonlocal groups within the mobility list, use the **config mobility group multicast-address** command.

config mobility group multicast-address *group_name* *IP_address*

Syntax Description

<i>group_name</i>	Member switch group name (if different from the default group name).
<i>IP_address</i>	Member switch IP address.

Command Default

None.

Examples

This example shows how to configure the multicast group IP address 10.10.10.1 for a group named test:

```
> config mobility group multicast-address test 10.10.10.1
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config mobility multicast-mode

To enable or disable multicast mobility mode, use the **config mobility multicast-mode** command.

config mobility multicast-mode {enable | disable} *local_group_multicast_address*

Syntax Description

enable	Enables the multicast mode; the controller uses multicast mode to send Mobile Announce messages to the local group.
disable	Disables the multicast mode; the controller uses unicast mode to send the Mobile Announce messages to the local group.
<i>local_group_multicast_address</i>	IP address for the local mobility group.

Command Default

Disabled.

Examples

This example shows how to enable the multicast mobility mode for the local mobility group IP address 157.168.20.0:

```
> config mobility multicast-mode enable 157.168.20.0
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config mobility secure-mode

To configure the secure mode for mobility messages between Cisco wireless LAN controllers, use the **config mobility secure-mode** command.

config mobility secure-mode {enable | disable}

Syntax Description

enable	Enables the mobility group message security.
disable	Disables mobility group message security.

Command Default

None.

Examples

This example shows how to enable the secure mode for mobility messages:

```
> config mobility secure-mode enable
```

Related Commands

config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility statistics reset
config wlan mobility anchor
debug mobility
show mobility anchor
show mobility statistics
show mobility summary

config mobility statistics reset

To reset the mobility statistics, use the **config mobility statistics reset** command.

config mobility statistics reset

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to reset the mobility group statistics:

```
> config mobility statistics reset
```

Related Commands

- config mobility group anchor**
- config mobility group domain**
- config mobility group keepalive count**
- config mobility group keepalive interval**
- config mobility group member**
- config mobility group multicast-address**
- config mobility multicast-mode**
- config mobility secure-mode**
- config wlan mobility anchor**
- debug mobility**
- show mobility anchor**
- show mobility statistics**
- show mobility summary**

config pmipv6 domain

To configure PMIPv6 and to enable Mobile Access Gateway (MAG) functionality on the controller, use the **config pmipv6 domain** command.

config pmipv6 domain *domain_name*

Syntax Description

<i>domain_name</i>	Name of the PMIPv6 domain. The domain name can be up to 127 case-sensitive, alphanumeric characters.

Command Default

None.

Examples

This example shows how to configure a domain name for a PMIPv6 WLAN:

```
> config pmipv6 domain floor1
```

Related Commands

config pmipv6 add profile
config pmipv6 mag lma
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary

config pmipv6 add profile

To create a Proxy Mobility IPv6 (PMIPv6) profile for the WLAN, use the **config pmipv6 add profile** command. You can configure PMIPv6 profiles based on a realm or a service set identifier (SSID).

config pmipv6 add profile *profile_name* **nai** {*user@realm* | *@realm* | *} **lma** *lma_name* **apn** *apn_name*

Syntax Description

<i>profile_name</i>	Name of the profile. The profile name is case sensitive and can be up to 127 alphanumeric characters.
nai	Specifies the Network Access Identifier of the client.
<i>user@realm</i>	Network Access Identifier of the client in the format <i>user@realm</i> . The NAI name is case sensitive and can be up to 127 alphanumeric characters.
<i>@realm</i>	Network Access Identifier of the client in the format <i>@realm</i> .
*	All Network Access Identifiers. You can have profiles based on an SSID for all users.
lma	Specifies the Local Mobility Anchor (LMA).
<i>lma_name</i>	Name of LMA. The LMA name is case sensitive and can be up to 127 alphanumeric characters.
apn	Specifies the access point.
<i>ap_name</i>	Name of the access point. The access point name is case sensitive and can be up to 127 alphanumeric characters.

Command Default

None.

Usage Guidelines

This command is a prerequisite for using PMIPv6 configuration commands if the controller uses open authentication.

Examples

This example shows how to create a PMIPv6 profile:

```
> config pmipv6 add profile profile1 nai @vodafone.com lma vodfonelma apn vodafoneapn
```

Related Commands

config pmipv6 mag lma
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type

config wlan pmipv6 default-realm

config pmipv6 domain

show pmipv6 domain

show wlan summary

show client summary

config pmipv6 delete

To delete a Proxy Mobility IPv6 (PMIPv6) profile, domain, or Local Mobility Anchor (LMA), use the **config pmipv6 delete** command.

config pmipv6 delete {**profile** *profile_name* **nai** { *nai_id* | **all** } | **domain** *domain_name* | **lma** *lma_name*}

Syntax Description

profile	Specifies the PMIPv6 profile.
<i>profile_name</i>	Name of the PMIPv6 profile. The profile name is case sensitive and can be up to 127 alphanumeric characters.
nai	Specifies the Network Access Identifier (NAI) of a mobile client.
<i>nai_id</i>	Network Access Identifier of a mobile client. The NAI is case sensitive and can be up to 127 alphanumeric characters.
all	Specifies all NAIs. When you delete all NAIs, the profile is deleted.
domain	Specifies the PMIPv6 domain.
<i>domain_name</i>	Name of the PMIPv6 domain. The domain name is case sensitive and can be up to 127 alphanumeric characters.
lma	Specifies the LMA.
<i>lma_name</i>	Name of the LMA. The LMA name is case sensitive and can be up to 127 alphanumeric characters.

Command Default

None.

Examples

This example shows how to delete a domain:

```
> config pmipv6 delete lab1
```

Related Commands

```
config pmipv6 add profile
config pmipv6 mag lma
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary
```

config pmipv6 mag binding init-retx-time

To configure the initial timeout between the proxy binding updates (PBUs) when the Mobile Access Gateway (MAG) does not receive the proxy binding acknowledgements (PBAs), use the **config pmipv6 mag binding init-retx-time** command.

config pmipv6 mag binding init-retx-time *units*

Syntax Description

<i>units</i>	Initial timeout between the PBUs when the MAG does not receive the PBAs. The range is from 100 to 65535 seconds.

Command Default

1000 seconds.

Examples

This example shows how to configure the initial timeout between the PBUs when the MAG does not receive the PBAs:

```
> config pmipv6 mag binding init-retx-time 500
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag
config pmipv6 delete
config wlan pmipv6 profile_name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain

config pmipv6 mag binding lifetime

To configure the lifetime of the binding entries in the Mobile Access Gateway (MAG), use the **config pmipv6 mag binding lifetime** command.

config pmipv6 mag binding lifetime *units*

Syntax Description	<i>units</i> Lifetime of the binding entries in the MAG. The binding lifetime must be a multiple of 4 seconds. The range is from 10 to 65535 seconds.
Command Default	65535 seconds.
Usage Guidelines	You must configure a Proxy Mobility IPv6 (PMIPv6) domain before you configure the lifetime of the binding entries in the controller.
Examples	This example shows how to configure the lifetime of the binding entries in the controller: <pre>> config pmipv6 mag binding lifetime 5000</pre>
Related Commands	config pmipv6 mag binding lifetime config pmipv6 mag binding refresh-time config pmipv6 mag binding init-retx-time config pmipv6 mag binding max-ret-time config pmipv6 delete config wlan pmipv6 profile-name config wlan pmipv6 mobility-type config wlan pmipv6 default-realm config pmipv6 domain show pmipv6 domain show wlan summary show client summary

config pmipv6 mag binding max-retx-time

To configure the maximum timeout between the proxy binding updates (PBUs) when the Mobility Access Gateway (MAG) does not receive the proxy binding acknowledgements (PBAs), use the **config pmipv6 mag binding max-retx-time** command.

config pmipv6 mag binding max-retx-time *units*

Syntax Description

<i>units</i>	Maximum timeout between the PBUs when the MAG does not receive the PBAs. The range is from 100 to 65535 seconds.

Command Default

32000 seconds.

Examples

This example shows how to configure the maximum timeout between the PBUs when the MAG does not receive the PBAs:

```
> config pmipv6 mag binding max-retx-time 50
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding init-retx-time
config pmipv6 add
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain

config pmipv6 mag binding maximum

To configure the maximum number of binding entries in the Mobile Access Gateway (MAG), use the **config pmipv6 mag binding maximum** command.

config pmipv6 mag binding maximum *units*

Syntax Description	<i>units</i> Maximum number of binding entries in the MAG. This number indicates the maximum number of users connected to the MAG. The range is from 0 to 40000.
Command Default	10000.
Usage Guidelines	You must configure a Proxy Mobility IPv6 (PMIPv6) domain before you configure the maximum number of binding entries in the MAG.
Examples	This example shows how to configure the maximum number of binding entries in the MAG: <pre>> config pmipv6 mag binding maximum 20000</pre>
Related Commands	config pmipv6 mag binding lifetime config pmipv6 mag binding refresh-time config pmipv6 mag binding init-retx-time config pmipv6 mag binding max-ret-time config wlan pmipv6 profile-name config wlan pmipv6 mobility-type config wlan pmipv6 default-realm config pmipv6 domain show pmipv6 domain show wlan summary show client summary show mag globals

config pmipv6 mag binding refresh-time

To configure the refresh time of the binding entries in the MAG, use the **config pmipv6 mag binding refresh-time** command.

config pmipv6 mag binding refresh-time *units*

Syntax Description

<i>units</i>	Refresh time of the binding entries in the MAG. The binding refresh time must be a multiple of 4. The range is from 4 to 65535 seconds.

Command Default

300 seconds.

Usage Guidelines

You must configure a PMIPv6 domain before you configure the refresh time of the binding entries in the MAG.

Examples

This example shows how to configure the refresh time of the binding entries in the MAG:

```
> config pmipv6 mag binding refresh-time 500
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding maximum
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show pmipv6 domain
show wlan summary
show client summary

config pmipv6 mag bri delay

To configure the maximum or minimum amount of time that the MAG waits before retransmitting a Binding Revocation Indication (BRI) message, use the **config pmipv6 mag bri delay** command.

config pmipv6 mag bri delay {min | max} *time*

Syntax Description

min	Specifies the minimum amount of time that the MAG waits before retransmitting a BRI message.
max	Specifies the maximum amount of time that the MAG waits before retransmitting a BRI message.
<i>time</i>	Maximum or minimum amount of time that the Cisco WLC waits before retransmitting a BRI message. The range is from 500 to 65535 milliseconds.

Command Default

The default value of the maximum amount of time that the MAG waits before retransmitting a BRI message is 2 seconds.

The default value of the minimum amount of time that the MAG waits before retransmitting a BRI message is 1 second.

Examples

This example shows how to configure the minimum amount of time that the MAG waits before retransmitting a BRI message:

```
> config pmipv6 mag bri delay min 500
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag bri retries
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show pmipv6 domain
show wlan summary
show client summary
show mag globals

config pmipv6 mag bri retries

To configure the maximum number of times that the MAG retransmits the Binding Revocation Indication (BRI) message before receiving the Binding Revocation Acknowledgement (BRA) message, use the **config pmipv6 mag bri retries** command .

config pmipv6 mag bri retries *retries*

Syntax Description

<i>retries</i>	Maximum number of times that the MAG retransmits the BRI message before receiving the BRA message. The range is from 1 to 10 seconds.

Command Default

1 second.

Examples

This example shows how to configure the maximum number of times that the MAG retries:

```
> config pmipv6 mag bri retries 5
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 mag lma
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show pmipv6 domain
show wlan summary
show client summary
show mag globals

config pmipv6 mag lma

To configure a Local Mobility Anchor (LMA) with the Mobile Access Gateway (MAG), use the **config pmipv6 mag lma** command.

config pmipv6 mag lma *lma_name* **ipv4-address** *address*

Syntax Description

<i>lma_name</i>	Name of the LMA. The LMA name can be a NAI or a string that uniquely identifies the LMA.
ipv4-address	Specifies the IP address of the LMA.
<i>address</i>	IP address of the LMA.

Command Default

None.

Usage Guidelines

This command is a prerequisite to configure PMIPv6 parameters on the MAG.

Examples

This example shows how to configure an LMA with the MAG:

```
> config pmipv6 mag lma vodafonelma ipv4-address 209.165.200.254
```

Related Commands

config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
show pmipv6 mag stats
config pmipv6 delete
config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show pmipv6 domain
show wlan summary
show client summary
show mag globals

config pmipv6 mag replay-protection

To configure the maximum amount of time difference between the time stamp in the received proxy binding acknowledgement (PBA) and the current time of the day for replay protection, use the **config pmipv6 mag replay-protection** command.

```
config pmipv6 mag replay-protection { timestamp window time | sequence-no sequence | mobile-node-timestamp mobile_node_timestamp }
```

Syntax Description

timestamp	Specifies the time stamp of the PBA message.
window	Specifies the maximum time difference between the time stamp in the received PBA message and the current time of day.
<i>time</i>	Maximum time difference between the time stamp in the received PBA message and the current time of day. The range is from 1 to 300 milliseconds.
sequence-no	(Optional) Specifies the sequence number in a Proxy Binding Update message.
<i>sequence</i>	(Optional) Sequence number in the Proxy Binding Update message.
mobile_node_timestamp	(Optional) Specifies the time stamp of the mobile node.
<i>mobile_node_timestamp</i>	(Optional) Time stamp of the mobile node.

Command Default

300 milliseconds.

Usage Guidelines

This release supports only the time-stamp option.

Examples

This example shows how to configure the maximum amount of time difference in milliseconds between the time stamp in the received PBA message and the current time of day:

```
> config pmipv6 mag replay-protection timestamp window 200
```

Related Commands

```
config pmipv6 mag binding lifetime
config pmipv6 mag binding refresh-time
config pmipv6 mag binding init-retx-time
config pmipv6 mag binding max-ret-time
config pmipv6 add
config pmipv6 delete
```

```
config wlan pmipv6 profile-name  
config wlan pmipv6 mobility-type  
config wlan pmipv6 default-realm  
config pmipv6 domain
```

config wlan mobility anchor

To change the state of MAC filtering on a wireless LAN, use the **config wlan mobility anchor** command.

config wlan mobility anchor {**add** | **delete**} *wlan_id ip_address*

Syntax Description

add	Enables MAC filtering on a wireless LAN.
delete	Disables MAC filtering on a wireless LAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.
<i>ip_address</i>	Member switch IP address for anchoring the wireless LAN.

Command Default

None.

Examples

This example shows how to configure the mobility wireless LAN anchor list with WLAN ID 4 and IP address 192.168.0.14:6:

```
> config wlan mobility anchor add 4 192.168.0.14
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
debug mobility
show mobility anchor
show mobility statistics
show mobility summary
config wlan mobility foreign-map

config wlan mobility foreign-map

To configure interfaces or interface groups for foreign Cisco WLCs, use the **config wlan mobility foreign-map** command.

config wlan mobility foreign-map {add | delete} *wlan_id* *foreign_mac_address* {*interface_name* | *interface_group_name*}

Syntax Description

add	Adds an interface or interface group to the map of foreign controllers.
delete	Deletes an interface or interface group from the map of foreign controllers.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.
<i>foreign_mac_address</i>	Foreign switch MAC address on a WLAN.
<i>interface_name</i>	Interface name up to 32 alphanumeric characters.
<i>interface_group_name</i>	Interface group name up to 32 alphanumeric characters.

Command Default

None.

Examples

This example shows how to add an interface group for foreign Cisco WLCs with WLAN ID 4 and a foreign switch MAC address on WLAN 00:21:1b:ea:36:60:

```
> config wlan mobility foreign-map add 4 00:21:1b:ea:36:60 mygroup1
```

Related Commands

config wlan mobility anchor
config mobility group member
debug mobility
show mobility anchor
show mobility summary

config wlan pmipv6 default-realm

To configure a default realm for a PMIPv6 WLAN, use the **config wlan pmipv6 default-realm** command.

config wlan pmipv6 default-realm { *default-realm-name* | **none** } *wlan_id*

Syntax Description

<i>default-realm-name</i>	Default realm name for the WLAN.
none	Clears the realm name for the WLAN.
<i>wlan_id</i>	Wireless LAN identifier between 1 and 512.

Command Default

None.

Examples

This example shows how to configure a default realm name on a PMIPv6 WLAN:

```
> config wlan pmipv6 default-realm XYZ 6
```

Related Commands

config wlan pmipv6 profile-name
config wlan pmipv6 mobility-type
config pmipv6 domain
show wlan summary
show client summary

config wlan pmipv6 mobility-type

To configure the mobility type on a WLAN, use the **config wlan pmipv6 mobility-type** command.

config wlan pmipv6 mobility-type {none | pmipv6} { *wlan_id* | all }

Syntax Description

none	Configures a WLAN with Simple IP mobility.
pmipv6	Configures a WLAN with PMIPv6 mobility.
all	Enables the specified type of mobility for all WLANs.
<i>wlan_id</i>	WLAN identifier between 1 and 512.

Command Default

None.

Usage Guidelines

You must disable the WLAN when you configure the mobility type.

Examples

This example shows how to configure the mobility type as PMIPv6 on a WLAN:

```
> config wlan pmipv6 mobility-type pmipv6 16
```

Related Commands

config wlan pmipv6 profile-name
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary
show client summary

config wlan pmipv6 profile_name

To configure a profile name for the PMIPv6 WLAN, use the **config wlan pmipv6 profile_name** command.

config wlan pmipv6 profile_name *profile_name* *wlan_id*

Syntax Description

<i>profile_name</i>	Profile name for the PMIPv6 WLAN.
<i>wlan_id</i>	Wireless LAN identifier from 1 to 512.

Command Default

None.

Usage Guidelines

This command binds a profile name to the PMIPv6 WLAN or SSID. Each time that a mobile node associates with the controller, it uses the profile name and NAI in the trigger to the PMIPv6 module. The PMIPv6 module extracts all the profile specific parameters such as LMA IP, APN, and NAI and sends the PBU to the ASR5K.

Examples

This example shows how to create a profile named ABC01 on a PMIPv6 WLAN:

```
> config wlan pmipv6 profile_name ABC01 16
```

Related Commands

config wlan pmipv6 mobility-type
config wlan pmipv6 default-realm
config pmipv6 domain
show wlan summary

clear, debug and ping Commands

This section lists the **config** , **debug** , **ping** commands for mobility.

clear stats mobility

To clear mobility manager statistics, use the **clear stats mobility** command.

clear stats mobility

Syntax Description This command has no arguments or keywords.

Command Default None.

Examples This example shows how to clear mobility manager statistics:

```
> clear stats mobility
  Mobility stats cleared.
```

Related Commands

- clear transfer**
- clear download datatype**
- clear download filename**
- clear download mode**
- clear download serverip**
- clear download start**
- clear upload datatype**
- clear upload filename**
- clear upload mode**
- clear upload path**
- clear upload serverip**
- clear upload start**
- clear stats port**

debug dot11

To configure the debugging of 802.11 events, use the **debug dot11** command.

debug dot11 {all | load-balancing | management | mobile | nmosp | probe | rldp | rogue | state} {enable | disable}

Syntax Description

all	Configures the debugging of all 802.11 messages.
load-balancing	Configures the debugging of 802.11 load balancing events.
management	Configures the debugging of 802.11 MAC management messages.
mobile	Configures the debugging of 802.11 mobile events.
nmosp	Configures the debugging of the 802.11 NMSP interface events.
probe	Configures the debugging of probe.
rldp	Configures the debugging of 802.11 Rogue Location Discovery.
rogue	Configures the debugging of 802.11 rogue events.
state	Configures the debugging of 802.11 mobile state transitions.
enable	Enables the 802.11 debugging.
disable	Disables the 802.11 debugging.

Command Default

None.

Examples

This example shows how to enable the debugging of 802.11 settings:

```
> debug dot11 state enable
> debug dot11 mobile enable
```

Related Commands

```
debug disable-all
debug dot11 mgmt interface
debug dot11 mgmt msg
debug dot11 mgmt ssid
debug dot11 mgmt state-machine
debug dot11 mgmt station
```

debug client

To configure the debugging of a passive client that is associated correctly with the access point, use the **debug client** command.

debug client *mac_address*

Syntax Description

<i>mac_address</i>	MAC address of the client.

Command Default

None.

Examples

This example shows how to debug a passive client with MAC address 00:0d:28:f4:c0:45:

```
> debug client 00:0d:28:f4:c0:45
```

Related Commands

debug disable-all
show capwap reap association
show capwap reap status

debug mobility

To configure the debugging of wireless mobility, use the **debug mobility** command.

debug mobility {**ap-list** | **config** | **directory** | **dtls** | **handoff** | **keep-alive** | **multicast** | **packet** | **peer-ip** *IP-address* | **pmk** | **pmtu-discovery** | **redha**} {**enable** | **disable**}

Syntax Description

ap-list	Configures the debugging of wireless mobility access point list.
config	Configures the debugging of wireless mobility configuration.
directory	Configures the debugging of wireless mobility error messages.
dtls	Configures the debugging of wireless mobility Datagram Transport Layer Security (DTLS) options.
handoff	Configures the debugging of wireless mobility handoff messages.
keep-alive	Configures the debugging of wireless mobility CAPWAP data DTLS keep-alive packets.
multicast	Configures the debugging of multicast mobility packets.
packet	Configures the debugging of wireless mobility packets.
peer-ip	Configures IP address of the mobility peer for which incoming and outgoing mobility messages should be displayed.
<i>IP-address</i>	IP address of the mobility peer for which incoming and outgoing mobility messages should be displayed.
pmk	Configures the debugging of wireless mobility pairwise master key (PMK).
pmtu-discovery	Configures the debugging of the wireless mobility path MTU discovery.
redha	Configures the debugging of the multicast mobility high availability.

enable	Enables the debugging of the wireless mobility feature.
disable	Disables the debugging of the wireless mobility feature.

Command Default

None

Examples

The following example shows how to enable the debugging of wireless mobility packets.

```
Device > debug mobility handoff enable
```

Related Commands

config guest-lan mobility anchor
config mobility group domain
config mobility group keepalive count
config mobility group keepalive interval
config mobility group member
config mobility group multicast-address
config mobility multicast-mode
config mobility secure-mode
config mobility statistics reset
config wlan mobility anchor
show mobility anchor
show mobility statistics
show mobility summary

eping

To test the mobility Ethernet over IP (EoIP) data packet communication between two controllers, use the **eping** command.

eping *mobility_peer_IP_address*

Syntax Description

mobility_peer_IP_address IP address of a controller that belongs to a mobility group.

Command Default

None.

Usage Guidelines

This command tests the mobility data traffic over the management interface.



Note

This ping test is not Internet Control Message Protocol (ICMP) based. The term “ping” is used to indicate an echo request and an echo reply message.

Examples

This example shows how to test EoIP data packets and to set the IP address of a controller that belongs to a mobility group to 172.12.35.31:

```
> eping 172.12.35.31
```

Related Commands

mping
config logging buffered debugging
show logging
debug mobility handoff enable

mping

To test mobility UDP control packet communication between two controllers, use the **mping** command.

mping *mobility_peer_IP_address*

Syntax Description

<i>mobility_peer_IP_address</i>	IP address of a controller that belongs to a mobility group.

Command Default

None.

Usage Guidelines

This test runs over mobility UDP port 16666. It tests whether the mobility control packet can be reached over the management interface.



Note

This ping test is not Internet Control Message Protocol (ICMP) based. The term “ping” is used to indicate an echo request and an echo reply message.

Examples

This example shows how to test mobility UDP control packet communications and to set the IP address of a controller that belongs to a mobility group to 172.12.35.31:

```
> mping 172.12.35.31
```

Related Commands

eping
config logging buffered debugging
show logging
debug mobility handoff enable

