



## CLI Commands

---

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- [show Commands, page 1](#)
- [capwap ap Commands, page 68](#)
- [config Commands, page 79](#)
- [clear Commands, page 205](#)
- [debug Commands, page 210](#)
- [transfer download peer-start, page 225](#)
- [transfer upload peer-start, page 226](#)
- [Resetting the System Reboot Time, page 226](#)
- [test Commands, page 231](#)

## show Commands

This section lists the **show** commands to display information about your configuration settings for access points.

## show advanced backup-controller

To display a list of primary and secondary backup controllers, use the **show advanced backup-controller** command.

**show advanced backup-controller**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the backup controller information:

```
> show advanced backup-controller
AP primary Backup Controller ..... controller 10.10.10.10
AP secondary Backup Controller ..... 0.0.0.0
```

**Related Commands**

- config advanced backup-controller primary**
- config advanced backup-controller secondary**

## show advanced max-1x-sessions

To display the maximum number of simultaneous 802.1X sessions allowed per access point, use the **show advanced max-1x-sessions** command.

**show advanced max-1x-sessions**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the maximum 802.1X sessions per access point:
-----------------	---

```
> show advanced max-1x-sessions
Max 802.1x session per AP at a given time..... 0
```

<b>Related Commands</b>	<b>show advanced statistics</b>
-------------------------	---------------------------------

## show advanced probe

To display the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show advanced probe** command.

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the probe settings for the WLAN controller:
-----------------	---

```
> show advanced probe
Probe request filtering..... Enabled
Probes fwd to controller per client per radio.... 12
Probe request rate-limiting interval..... 100 msec
```

<b>Related Commands</b>	<b>config advanced probe filter</b> <b>config advanced probe limit</b>
-------------------------	---

## show advanced rate

To display whether control path rate limiting is enabled or disabled, use the **show advanced rate** command.

**show advanced rate**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the switch control path rate limiting mode:
-----------------	---

```
> show advanced rate
Control Path Rate Limiting..... Disabled
```

<b>Related Commands</b>	<b>config advanced rate</b> <b>config advanced eap</b>
-------------------------	---

## show advanced timers

To display the mobility anchor, authentication response, and rogue access point entry timers, use the **show advanced timers** command.

**show advanced timers**

### Syntax Description

This command has no arguments or keywords.

### Command Default

The defaults are shown in the “Examples” section.

### Examples

This example shows how to display the system timers setting:

```
> show advanced timers
Authentication Response Timeout (seconds)..... 10
Rogue Entry Timeout (seconds)..... 1200
AP Heart Beat Timeout (seconds)..... 30
AP Discovery Timeout (seconds)..... 10
AP Local mode Fast Heartbeat (seconds)..... disable
AP flexconnect mode Fast Heartbeat (seconds)..... disable
AP Primary Discovery Timeout (seconds)..... 120
```

### Related Commands

**config advanced timers ap-discovery-timeout**

**config advanced timers ap-fast-heartbeat**

**config advanced timers ap-heartbeat-timeout**

**config advanced timers ap-primary-discovery-timeout**

**config advanced timers auth-timeout**

**config advanced timers eap-identity-request-delay**

**config advanced timers eap-timeout**

## show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

**show ap auto-rf 802.11 {a | b} cisco\_ap**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to display auto-RF information for an access point:

```
> show ap auto-rf 802.11a AP1
Number Of Slots..... 2
AP Name..... AP03
MAC Address..... 00:0b:85:01:18:b7
Radio Type..... RADIO_TYPE_80211a
Noise Information
  Noise Profile..... PASSED
  Channel 36..... -88 dBm
  Channel 40..... -86 dBm
  Channel 44..... -87 dBm
  Channel 48..... -85 dBm
  Channel 52..... -84 dBm
  Channel 56..... -83 dBm
  Channel 60..... -84 dBm
  Channel 64..... -85 dBm
Interference Information
  Interference Profile..... PASSED
  Channel 36..... -66 dBm @ 1% busy
  Channel 40..... -128 dBm @ 0% busy
  Channel 44..... -128 dBm @ 0% busy
  Channel 48..... -128 dBm @ 0% busy
  Channel 52..... -128 dBm @ 0% busy
  Channel 56..... -73 dBm @ 1% busy
  Channel 60..... -55 dBm @ 1% busy
  Channel 64..... -69 dBm @ 1% busy
Rogue Histogram (20/40_ABOVE/40_BELOW)
  Channel 36..... 16/ 0/ 0
  Channel 40..... 28/ 0/ 0
  Channel 44..... 9/ 0/ 0
  Channel 48..... 9/ 0/ 0
  Channel 52..... 3/ 0/ 0
  Channel 56..... 4/ 0/ 0
  Channel 60..... 7/ 1/ 0
  Channel 64..... 2/ 0/ 0
Load Information
  Load Profile..... PASSED
  Receive Utilization..... 0%
  Transmit Utilization..... 0%
  Channel Utilization..... 1%
  Attached Clients..... 1 clients
Coverage Information
  Coverage Profile..... PASSED
```

## show ap auto-rf

```

Failed Clients..... 0 clients
Client Signal Strengths
RSSI -100 dBm..... 0 clients
RSSI -92 dBm..... 0 clients
RSSI -84 dBm..... 0 clients
RSSI -76 dBm..... 0 clients
RSSI -68 dBm..... 0 clients
RSSI -60 dBm..... 0 clients
RSSI -52 dBm..... 0 clients
Client Signal To Noise Ratios
SNR 0 dBm..... 0 clients
SNR 5 dBm..... 0 clients
SNR 10 dBm..... 0 clients
SNR 15 dBm..... 0 clients
SNR 20 dBm..... 0 clients
SNR 25 dBm..... 0 clients
SNR 30 dBm..... 0 clients
SNR 35 dBm..... 0 clients
SNR 40 dBm..... 0 clients
SNR 45 dBm..... 0 clients
Nearby RADs
RAD 00:0b:85:01:05:08 slot 0..... -46 dBm on 10.1.30.170
RAD 00:0b:85:01:12:65 slot 0..... -24 dBm on 10.1.30.170
Channel Assignment Information
Current Channel Average Energy..... -86 dBm
Previous Channel Average Energy..... -75 dBm
Channel Change Count..... 109
Last Channel Change Time..... Wed Sep 29 12:53e:34 2004
Recommended Best Channel..... 44
RF Parameter Recommendations
Power Level..... 1
RTS/CTS Threshold..... 2347
Fragmentation Threshold..... 2346
Antenna Pattern..... 0

```



## show ap ccx rm

To display an access point's Cisco Client eXtensions (CCX) radio management status information, use the **show ap ccx rm** command.

**show ap ccx rm** *ap\_name* **status**

### Syntax Description

<i>ap_name</i>	Specified access point name.
<b>status</b>	Displays the CCX radio management status information for an access point.

### Command Default

None.

### Examples

This example shows how to display the status of the CCX radio management:

```
> show ap ccx rm AP1240-21ac status
A Radio
Channel Load Request ..... Disabled
Noise Histogram Request ..... Disabled
Beacon Request ..... Disabled
Frame Request ..... Disabled
Interval ..... 60
Iteration ..... 10
G Radio
Channel Load Request ..... Disabled
Noise Histogram Request ..... Disabled
Beacon Request ..... Disabled
Frame Request ..... Disabled
Interval ..... 60
Iteration ..... 10
```

### Related Commands

**config ap**

## show ap cdp

To display the Cisco Discovery Protocol (CDP) information for an access point, use the **show ap cdp** command.

**show ap cdp** {**all** | **ap-name** *cisco\_ap* | **neighbors** {**all** | **ap-name** *cisco\_ap* | **detail** *cisco\_ap*}}

### Syntax Description

<b>all</b>	Displays the CDP status on all access points.
<b>ap-name</b>	Displays the CDP status for a specified access point.
<i>cisco_ap</i>	Specified access point name.
<b>neighbors</b>	Displays neighbors using CDP.
<b>detail</b>	Displays details about a specific access point neighbor using CDP.

### Command Default

None.

### Examples

This example shows how to display the CDP status of all access points:

```
> show ap cdp all
AP CDP State
AP Name          AP CDP State
-----
SB_RAP1          enable
SB_MAP1          enable
SB_MAP2          enable
SB_MAP3          enable
```

This example shows how to display the CDP status of a specified access point:

```
> show ap cdp ap-name SB_RAP1
AP CDP State
AP Name          AP CDP State
-----
AP CDP State.....Enabled
AP Interface-Based CDP state
  Ethernet 0.....Enabled
  Slot 0.....Enabled
  Slot 1.....Enabled
```

This example shows how to display details about all neighbors using CDP:

```
> show ap cdp neighbor all
AP Name      AP IP      Neighbor Name      Neighbor IP      Neighbor Port
-----
SB_RAP1      192.168.102.154  sjc14-41a-sw1      192.168.102.2    GigabitEthernet1/0/13
SB_RAP1      192.168.102.154  SB_MAP1            192.168.102.137  Virtual-Dot11Radio0
SB_MAP1      192.168.102.137  SB_RAP1            192.168.102.154  Virtual-Dot11Radio0
SB_MAP1      192.168.102.137  SB_MAP2            192.168.102.138  Virtual-Dot11Radio0
SB_MAP2      192.168.102.138  SB_MAP1            192.168.102.137  Virtual-Dot11Radio1
SB_MAP2      192.168.102.138  SB_MAP3            192.168.102.139  Virtual-Dot11Radio0
```

```
SB_MAP3      192.168.102.139  SB_MAP2      192.168.102.138  Virtual-Dot11Radio1
```

This example shows how to display details about a specific neighbor with a specified access point using CDP:

```
> show ap cdp neighbors ap-name SB_MAP2
AP Name      AP IP      Neighbor Name  Neighbor IP  Neighbor Port
-----
SB_MAP2      192.168.102.138  SB_MAP1      192.168.102.137  Virtual-Dot11Radio1
SB_MAP2      192.168.102.138  SB_MAP3      192.168.102.139  Virtual-Dot11Radio0
```

This example shows how to display details about neighbors using CDP:

```
> show ap cdp neighbors detail SB_MAP2
AP Name:SB_MAP2
AP IP address:192.168.102.138
-----
Device ID: SB_MAP1
Entry address(es): 192.168.102.137
Platform: cisco AIR-LAP1522AG-A-K9 , Cap
Interface: Virtual-Dot11Radio0, Port ID (outgoing port): Virtual-Dot11Radio1
Holdtime : 180 sec
Version :
Cisco IOS Software, C1520 Software (C1520-K9W8-M), Experimental Version 12.4(200
81114:084420) [BLD-v124_18a_ja_throttle.20081114 208] Copyright (c) 1986-2008 by
Cisco Systems, Inc. Compiled Fri 14-Nov-08 23:08 by
advertisement version: 2
-----
Device ID: SB_MAP3
Entry address(es): 192.168.102.139
Platform: cisco AIR-LAP1522AG-A-K9 , Capabilities: Trans-Bridge
Interface: Virtual-Dot11Radio1, Port ID (outgoing port): Virtual-Dot11Radio0
Holdtime : 180 sec
Version :
Cisco IOS Software, C1520 Software (C1520-K9W8-M), Experimental Version 12.4(200
81114:084420) [BLD-v124_18a_ja_throttle.20081114 208] Copyright (c) 1986-2008 by
Cisco Systems, Inc. Compiled Fri 14-Nov-08 23:08 by
advertisement version: 2
```

## Related Commands

```
config ap cdp
config cdp timer
```

## show ap channel

To display the available channels for a specific mesh access point, use the **show ap channel** command.

**show ap channel** *ap\_name*

### Syntax Description

<i>ap_name</i>	Name of the mesh access point.
----------------	--------------------------------

### Command Default

None.

### Examples

This example shows how to display the available channels for a particular access point:

```
> show ap channel AP47
 802.11b/g Current Channel .....1
Allowed Channel List.....1,2,3,4,5,6,7,8,9,10,11
 802.11a Current Channel .....161
Allowed Channel List.....36,40,44,48,52,56,60,64,100,
.....104,108,112,116,132,136,140,
.....149,153,157,161
```

### Related Commands

**config 802.11-a channel ap**  
**config 802.11h channelswitch**  
**config 802.11h setchannel**

## show ap config

To display the detailed configuration for a lightweight access point, use the **show ap config** command.

**show ap config 802.11 {a | b} [summary] *cisco\_ap***

Syntax Description		
<b>802.11a</b>		Specifies the 802.11a or 802.11b/g network.
<b>802.11b</b>		Specifies the 802.11b/g network.
<b>summary</b>		(Optional) Displays radio summary of all APs
<i>cisco_ap</i>		Lightweight access point name.

**Command Default** None.

**Examples** This example shows how to display the detailed configuration for an access point:

```
> show ap config 802.11a AP02
Cisco AP Identifier..... 0
Cisco AP Name..... AP02
Country code..... US - United States
Regulatory Domain allowed by Country..... 802.11bg:-A      802.11a:-A
AP Regulatory Domain..... Unconfigured
Switch Port Number ..... 1
MAC Address..... 00:0b:85:18:b6:50
IP Address Configuration..... DHCP
IP Address..... 1.100.49.240
IP NetMask..... 255.255.255.0
Gateway IP Addr..... 1.100.49.1
CAPWAP Path MTU..... 1485
Telnet State..... Disabled
Ssh State..... Disabled
Cisco AP Location..... default-location
Cisco AP Group Name..... default-group
Primary Cisco Switch..... Cisco_32:ab:63
Primary Cisco Switch IP Address..... Not Configured
Secondary Cisco Switch.....
Secondary Cisco Switch IP Address..... Not Configured
Tertiary Cisco Switch.....
Tertiary Cisco Switch IP Address..... Not Configured
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED
Mirroring Mode ..... Disabled
AP Mode ..... Sniffer
Public Safety ..... Global: Disabled, Local: Disabled
AP SubMode ..... Not Configured
Remote AP Debug ..... Disabled
Logging trap severity level ..... informational
Logging syslog facility ..... kern
S/W Version ..... 7.0.110.6
Boot Version ..... 12.4.18.0
Mini IOS Version ..... 3.0.51.0
Stats Reporting Period ..... 180
Stats Re--More-- or (q)uit
LED State..... Enabled
```

## show ap config

```

PoE Pre-Standard Switch..... Enabled
PoE Power Injector MAC Addr..... Disabled
Power Type/Mode..... Power injector / Normal mode
Number Of Slots..... 2
AP Model..... AIR-LAP1142N-A-K9
AP Image..... C1140-K9W8-M
IOS Version..... 12.4(20100502:031212)
Reset Button..... Enabled
AP Serial Number..... FTX1305S180
AP Certificate Type..... Manufacture Installed
AP User Mode..... AUTOMATIC
AP User Name..... Not Configured
AP Dot1x User Mode..... Not Configured
AP Dot1x User Name..... Not Configured
Cisco AP system logging host..... 255.255.255.255
AP Up Time..... 47 days, 23 h 47 m 47 s
AP LWAPP Up Time..... 47 days, 23 h 10 m 37 s
Join Date and Time..... Tue May 4 16:05:00 2010
Join Taken Time..... 0 days, 00 h 01 m 37 s
Attributes for Slot 1
  Radio Type..... RADIO_TYPE_80211n-5
  Radio Subband..... RADIO_SUBBAND_ALL
  Administrative State ..... ADMIN_ENABLED
  Operation State ..... UP
  Radio Role ..... ACCESS
  CellId ..... 0
Station Configuration
  Configuration ..... AUTOMATIC
  Number Of WLANs ..... 2
  Medium Occupancy Limit ..... 100
  CFP Period ..... 4
  CFP MaxDuration ..... 60
  BSSID ..... 00:24:97:88:99:60
Operation Rate Set
  6000 Kilo Bits..... MANDATORY
  9000 Kilo Bits..... SUPPORTED
  12000 Kilo Bits..... MANDATORY
  18000 Kilo Bits..... SUPPORTED
  24000 Kilo Bits..... MANDATORY
  36000 Kilo Bits..... SUPPORTED
  48000 Kilo Bits..... SUPPORTED
  54000 Kilo Bits..... SUPPORTED
MCS Set
  MCS 0..... SUPPORTED
  MCS 1..... SUPPORTED
  MCS 2..... SUPPORTED
  MCS 3..... SUPPORTED
  MCS 4..... SUPPORTED
  MCS 5..... SUPPORTED
  MCS 6..... SUPPORTED
  MCS 7..... SUPPORTED
  MCS 8..... SUPPORTED
  MCS 9..... SUPPORTED
  MCS 10..... SUPPORTED
  MCS 11..... SUPPORTED
  MCS 12..... SUPPORTED
  MCS 13..... SUPPORTED
  MCS 14..... SUPPORTED
  MCS 15..... SUPPORTED
Beacon Period ..... 100
Fragmentation Threshold ..... 2346
Multi Domain Capability Implemented ..... TRUE
Multi Domain Capability Enabled ..... TRUE
Country String ..... US
Multi Domain Capability
  Configuration ..... AUTOMATIC
  First Chan Num ..... 36
  Number Of Channels ..... 21
MAC Operation Parameters
  Configuration ..... AUTOMATIC
  Fragmentation Threshold ..... 2346
  Packet Retry Limit ..... 64
Tx Power

```

```

    Num Of Supported Power Levels ..... 6
    Tx Power Level 1 ..... 14 dBm
    Tx Power Level 2 ..... 11 dBm
    Tx Power Level 3 ..... 8 dBm
    Tx Power Level 4 ..... 5 dBm
    Tx Power Level 5 ..... 2 dBm
    Tx Power Level 6 ..... -1 dBm
    Tx Power Configuration ..... AUTOMATIC
    Current Tx Power Level ..... 0
Phy OFDM parameters
    Configuration ..... AUTOMATIC
    Current Channel ..... 36
    Extension Channel ..... NONE
    Channel Width..... 20 Mhz
    Allowed Channel List..... 36,40,44,48,52,56,60,64,100,
    ..... 104,108,112,116,132,136,140,
    ..... 149,153,157,161,165
    TI Threshold ..... -50
    Legacy Tx Beamforming Configuration ..... AUTOMATIC
    Legacy Tx Beamforming ..... DISABLED
    Antenna Type..... INTERNAL_ANTENNA
    Internal Antenna Gain (in .5 dBi units).... 6
    Diversity..... DIVERSITY_ENABLED
802.11n Antennas
    Tx
    A..... ENABLED
    B..... ENABLED
    Rx
    A..... ENABLED
    B..... ENABLED
    C..... ENABLED
Performance Profile Parameters
    Configuration ..... AUTOMATIC
    Interference threshold..... 10 %
    Noise threshold..... -70 dBm
    RF utilization threshold..... 80 %
    Data-rate threshold..... 1000000 bps
    Client threshold..... 12 clients
    Coverage SNR threshold..... 16 dB
    Coverage exception level..... 25 %
    Client minimum exception level..... 3 clients
Rogue Containment Information
    Containment Count..... 0
CleanAir Management Information
    CleanAir Capable..... No
Radio Extended Configurations:
    Buffer size .....30
    Data-rate.....0
    Beacon strt .....90 ms
    Rx-Sensitivity SOP threshold ..... -80 dB
    CCA threshold ..... -60 dB

```

This example shows how to display the detailed configuration for another access point:

```

> show ap config 802.11b AP02
Cisco AP Identifier..... 0
Cisco AP Name..... AP02
AP Regulatory Domain..... Unconfigured
Switch Port Number ..... 1
MAC Address..... 00:0b:85:18:b6:50
IP Address Configuration..... DHCP
IP Address..... 1.100.49.240
IP NetMask..... 255.255.255.0
Gateway IP Addr..... 1.100.49.1
Cisco AP Location..... default-location
Cisco AP Group Name..... default-group
Primary Cisco Switch..... Cisco_32:ab:63
Secondary Cisco Switch.....
Tertiary Cisco Switch.....
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED

```

## show ap config

```

Mirroring Mode ..... Disabled
AP Mode ..... Local
Remote AP Debug ..... Disabled
S/W Version ..... 3.1.61.0
Boot Version ..... 1.2.59.6
Stats Reporting Period ..... 180
LED State..... Enabled
ILP Pre Standard Switch..... Disabled
ILP Power Injector..... Disabled
Number Of Slots..... 2
AP Model..... AS-1200
AP Serial Number..... 044110223A
AP Certificate Type..... Manufacture Installed
Attributes for Slot 1
  Radio Type..... RADIO_TYPE_80211g
  Administrative State ..... ADMIN_ENABLED
  Operation State ..... UP
  CellId ..... 0
  Station Configuration
    Configuration ..... AUTOMATIC
    Number Of WLANs ..... 1
    Medium Occupancy Limit ..... 100
    CFP Period ..... 4
    CFP MaxDuration ..... 60
    BSSID ..... 00:0b:85:18:b6:50
    Operation Rate Set
      1000 Kilo Bits..... MANDATORY
      2000 Kilo Bits..... MANDATORY
      5500 Kilo Bits..... MANDATORY
      11000 Kilo Bits..... MANDATORY
      6000 Kilo Bits..... SUPPORTED
      9000 Kilo Bits..... SUPPORTED
      12000 Kilo Bits..... SUPPORTED
      18000 Kilo Bits..... SUPPORTED
      24000 Kilo Bits..... SUPPORTED
      36000 Kilo Bits..... SUPPORTED
      48000 Kilo Bits..... SUPPORTED
      54000 Kilo Bits..... SUPPORTED
    Beacon Period ..... 100
    DTIM Period ..... 1
    Fragmentation Threshold ..... 2346
    Multi Domain Capability Implemented ..... TRUE
    Multi Domain Capability Enabled ..... TRUE
    Country String ..... US
  Multi Domain Capability
    Configuration ..... AUTOMATIC
    First Chan Num ..... 1
    Number Of Channels ..... 11
  MAC Operation Parameters
    Configuration ..... AUTOMATIC
    RTS Threshold ..... 2347
    Short Retry Limit ..... 7
    Long Retry Limit ..... 4
    Fragmentation Threshold ..... 2346
    Maximum Tx MSDU Life Time ..... 512
    Maximum Rx Life Time..... 512
  Tx Power
    Num Of Supported Power Levels..... 5
    Tx Power Level 1 ..... 17 dBm
    Tx Power Level 2..... 14 dBm
    Tx Power Level 3..... 11 dBm
    Tx Power Level 4..... 8 dBm
    Tx Power Level 5..... 5 dBm
    Tx Power Configuration..... CUSTOMIZED
    Current Tx Power Level..... 5
  Phy OFDM parameters
    Configuration..... CUSTOMIZED
    Current Channel..... 1
    TI Threshold..... -50
    Legacy Tx Beamforming Configuration ..... CUSTOMIZED
    Legacy Tx Beamforming ..... ENABLED
    Antenna Type..... INTERNAL_ANTENNA
    Internal Antenna Gain (in5 dBm units)..... 11

```



```

Diversity..... DIVERSITY_ENABLED
Performance Profile Parameters
Configuration..... AUTOMATIC
Interference threshold..... 10%
Noise threshold..... -70 dBm
RF utilization threshold..... 80%
Data-rate threshold..... 1000000 bps
Client threshold..... 12 clients
Coverage SNR threshold..... 12 dB
Coverage exception level..... 25%
Client minimum exception level..... 3 clients
Rogue Containment Information
Containment Count..... 0

```

This example shows how to display the general configuration of a Cisco access point:

```

> show ap config general cisco-ap
Cisco AP Identifier..... 9
Cisco AP Name..... cisco-ap
Country code..... US - United States
Regulatory Domain allowed by Country..... 802.11bg:-A 802.11a:-A
AP Country code..... US - United States
AP Regulatory Domain..... 802.11bg:-A 802.11a:-A
Switch Port Number ..... 1
MAC Address..... 12:12:12:12:12:12
IP Address Configuration..... DHCP
IP Address..... 10.10.10.21
IP NetMask..... 255.255.255.0
CAPWAP Path MTU..... 1485
Domain.....
Name Server.....
Telnet State..... Disabled
Ssh State..... Disabled
Cisco AP Location..... default location
Cisco AP Group Name..... default-group
Primary Cisco Switch Name..... 4404
Primary Cisco Switch IP Address..... 10.10.10.32
Secondary Cisco Switch Name.....
Secondary Cisco Switch IP Address..... Not Configured
Tertiary Cisco Switch Name..... 4404
Tertiary Cisco Switch IP Address..... 3.3.3.3
Administrative State ..... ADMIN_ENABLED
Operation State ..... REGISTERED
Mirroring Mode ..... Disabled
AP Mode ..... Local
Public Safety ..... Global: Disabled, Local: Disabled
AP subMode ..... WIPS
Remote AP Debug ..... Disabled
S/W Version ..... 5.1.0.0
Boot Version ..... 12.4.10.0
Mini IOS Version ..... 0.0.0.0
Stats Reporting Period ..... 180
LED State..... Enabled
PoE Pre-Standard Switch..... Enabled
PoE Power Injector MAC Addr..... Disabled
Power Type/Mode..... PoE/Low Power (degraded mode)
Number Of Slots..... 2
AP Model..... AIR-LAP1252AG-A-K9
IOS Version..... 12.4(10:0)
Reset Button..... Enabled
AP Serial Number..... serial_number
AP Certificate Type..... Manufacture Installed
Management Frame Protection Validation..... Enabled (Global MFP Disabled)
AP User Mode..... CUSTOMIZED
AP username..... maria
AP Dot1x User Mode..... Not Configured
AP Dot1x username..... Not Configured
Cisco AP system logging host..... 255.255.255.255
AP Up Time..... 4 days, 06 h 17 m 22 s
AP LWAPP Up Time..... 4 days, 06 h 15 m 00 s
Join Date and Time..... Mon Mar 3 06:19:47 2008
Ethernet Port Duplex..... Auto

```

**show ap config**

```
Ethernet Port Speed..... Auto
AP Link Latency..... Enabled
  Current Delay..... 0 ms
  Maximum Delay..... 240 ms
  Minimum Delay..... 0 ms
  Last updated (based on AP Up Time)..... 4 days, 06 h 17 m 20 s
Rogue Detection..... Enabled
AP TCP MSS Adjust..... Disabled
Mesh preferred parent..... 00:24:13:0f:92:00
```

**Related Commands****config ap****config ap config global**

## show ap config global

To display the global syslog server settings for all access points that join the controller, use the **show ap config global** command.

**show ap config global**

### Syntax Description

This command has no arguments and keywords.

### Examples

This example shows how to display global syslog server settings:

```
> show ap config global
AP global system logging host..... 255.255.255.255
```

### Related Commands

**config ap**

**show ap config**

## show ap core-dump

To display the memory core dump information for a lightweight access point, use the **show ap core-dump** command.

**show ap core-dump** *cisco\_ap*

### Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.
-----------------	--------------------------------------

### Command Default

None.

### Examples

This example shows how to display memory core dump information:

```
> show ap core-dump AP02
Memory core dump is disabled.
```

### Related Commands

**config ap core-dump**  
**show ap crash-file**

## show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

**show ap crash-file**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the crash file generated by the access point:
-----------------	---

```
> show ap crash-file
```

<b>Related Commands</b>	<b>config ap crash-file clear-all</b> <b>config ap crash-file delete</b> <b>config ap crash-file get-crash-file</b> <b>config ap crash-file get-radio-core-dump</b>
-------------------------	--

## show ap data-plane

To display the data plane status for all access points or a specific access point, use the **show ap data-plane** command.

**show ap data-plane** {all | *cisco\_ap*}

### Syntax Description

**all** Specifies all Cisco lightweight access points.

*cisco\_ap* Name of a Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to display the data plane status of all access points:

```
> show ap data-plane all
Min Data      Data      Max Data      Last
AP Name      Round Trip  Round Trip    Round Trip    Update
-----
1130          0.000s      0.000s        0.002s        18:51:23
1240          0.000s      0.000s        0.000s        18:50:45
```

## show ap ethernet tag

To display the VLAN tagging information of an Ethernet interface, use the **show ap ethernet tag** command.

**show ap ethernet tag** {**summary** | *cisco\_ap*}

### Syntax Description

<b>summary</b>	Displays the VLAN tagging information for all access points associated to the controller.
<i>cisco_ap</i>	Name of the Cisco lightweight access point. Displays the VLAN tagging information for a specific access point associated to the controller.

### Command Default

None.

### Usage Guidelines

If the access point is unable to route traffic or reach the controller using the specified trunk VLAN, it falls back to the untagged configuration. If the access point joins the controller using this fallback configuration, the controller sends a trap to a trap server such as the WCS, which indicates the failure of the trunk VLAN. In this scenario, the "Failover to untagged" message appears in show command output.

### Examples

This example shows how to display the VLAN tagging information for all access points associated to the controller:

```
> show ap ethernet tag summary
```

AP Name	Vlan Tag Configuration
-----	-----
AP2	7 (Failover to untagged)
charan.AP1140.II	disabled

### Related Commands

**config ap ethernet**  
**config ap ethernet duplex**  
**config ap ethernet tag**  
**show ap config general**

## show ap eventlog

To display the contents of the event log file for an access point that is joined to the controller, use the **show ap eventlog** command.

**show ap eventlog** *ap\_name*

### Syntax Description

<i>ap_name</i>	Event log for the specified access point.
----------------	---

### Command Default

None.

### Examples

This example shows how to display the event log of an access point:

```
> show ap eventlog ciscoAP
AP event log download has been initiated
Waiting for download to complete
AP event log download completed.
===== AP Event log Contents =====
*Feb 13 11:54:17.146: %CAPWAP-3-CLIENTEVENTLOG: AP event log has been cleared from the
controller 'admin'
*Feb 13 11:54:32.874: *** Access point reloading. Reason: Reload Command ***
*Mar 1 00:00:39.134: %CDP_PD-4-POWER_OK: Full power - NEGOTIATED inline power source
*Mar 1 00:00:39.174: %LINK-3-UPDOWN: Interface Dot11Radio1, changed state to up
*Mar 1 00:00:39.211: %LINK-3-UPDOWN: Interface Dot11Radio0, changed state to up
*Mar 1 00:00:49.947: %CAPWAP-3-CLIENTEVENTLOG: Did not get vendor specific options from
DHCP.
...
```



## show ap image

To display the detailed information about the predownloaded image for specified access points, use the **show ap image** command.

**show ap image** {*cisco\_ap* | **all**}

### Syntax Description

<i>cisco_ap</i>	Name of the lightweight access point.
<b>all</b>	Specifies all access points.



### Note

If you have an AP that has the name *all*, it conflicts with the keyword **all** that specifies all access points. In this scenario, the keyword **all** takes precedence over the AP that is named *all*.

### Examples

This example shows how to display images present on all access points:

```
> show ap image all
Total number of APs..... 7
Number of APs
Initiated..... 4
Predownloading..... 0
Completed predownloading..... 3
Not Supported..... 0
Failed to Predownload..... 0
AP Name   Primary Image  Backup Image  Status           Version Next   Retry Time
Retry Count
-----
AP1140-1  7.0.56.0          6.0.183.38   Complete         6.0.183.38    NA           NA
AP1140-2  7.0.56.0          6.0.183.58   Initiated        6.0.183.38    23:46:43
1
AP1130-2  7.0.56.0          6.0.183.38   Complete         6.0.183.38    NA
NA
AP1130-3  7.0.56.0          6.0.183.58   Initiated        6.0.183.38    23:43:25    1
AP1130-4  7.0.56.0          6.0.183.38   Complete         6.0.183.38    NA
NA
AP1130-5  7.0.56.0          6.0.183.58   Initiated        6.0.183.38    23:43:00    1
AP1130-6  7.0.56.0          6.0.183.58   Initiated        6.0.183.38    23:41:33
```

### Related Commands

**config ap image predownload**

**config ap image swap**

## show ap inventory

To display inventory information for an access point, use the **show ap inventory** command.

**show ap inventory** *ap\_name*

### Syntax Description

<i>ap_name</i>	Inventory for the specified access point.
----------------	---

### Command Default

None.

### Examples

This example shows how to display the inventory of an access point:

```
> show ap inventory test101
NAME: "test101"      , DESCR: "Cisco Wireless Access Point"
PID: AIR-LAP1131AG-A-K9  ,  VID: V01,  SN: FTX1123T2XX
```

## show ap join stats detailed

To display all join-related statistics collected for a specific access point, use the **show ap join stats detailed** command.

**show ap join stats detailed** *ap\_mac*

### Syntax Description

<i>ap_mac</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.
---------------	---

### Command Default

None.

### Examples

This example shows how to display join information for a specific access point trying to join the controller:

```
> show ap join stats detailed 00:0b:85:02:0d:20
Discovery phase statistics
- Discovery requests received..... 2
- Successful discovery responses sent..... 2
- Unsuccessful discovery request processing..... 0
- Reason for last unsuccessful discovery attempt..... Not applicable
- Time at last successful discovery attempt..... Aug 21 12:50:23:335
- Time at last unsuccessful discovery attempt..... Not applicable
Join phase statistics
- Join requests received..... 1
- Successful join responses sent..... 1
- Unsuccessful join request processing..... 1
- Reason for last unsuccessful join attempt.....RADIUS authorization is pending for
the AP
- Time at last successful join attempt..... Aug 21 12:50:34:481
- Time at last unsuccessful join attempt..... Aug 21 12:50:34:374
Configuration phase statistics
- Configuration requests received..... 1
- Successful configuration responses sent..... 1
- Unsuccessful configuration request processing..... 0
- Reason for last unsuccessful configuration attempt... Not applicable
- Time at last successful configuration attempt..... Aug 21 12:50:34:374
- Time at last unsuccessful configuration attempt..... Not applicable
Last AP message decryption failure details
- Reason for last message decryption failure..... Not applicable
Last AP disconnect details
- Reason for last AP connection failure..... Not applicable
Last join error summary
- Type of error that occurred last..... Lwapp join request rejected
- Reason for error that occurred last..... RADIUS authorization is pending for
the AP
- Time at which the last join error occurred..... Aug 21 12:50:34:374
```

### Related Commands

**show ap join stats detailed**

**show ap join stats summary**

**show ap join stats summary all**

## show ap join stats summary

To display the last join error detail for a specific access point, use the **show ap join stats summary** command.

**show ap join stats summary** *ap\_mac*

### Syntax Description

<i>ap_mac</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.
---------------	---

### Command Default

None.

### Usage Guidelines

To obtain the MAC address of the 802.11 radio interface, enter the **show interface** command on the access point.

### Examples

This example shows how to display specific join information for an access point:

```
> show ap join stats summary 00:0b:85:02:0d:20
Is the AP currently connected to controller..... No
Time at which the AP joined this controller last time..... Aug 21 12:50:36:061
Type of error that occurred last..... Lwapp join request
rejected
Reason for error that occurred last..... RADIUS authorization
is pending for the AP
Time at which the last join error occurred..... Aug 21 12:50:34:374
```

### Related Commands

**show ap join stats detailed**  
**show ap join stats summary all**

## show ap join stats summary all

To display the MAC addresses of all the access points that are joined to the controller or that have tried to join, use the **show ap join stats summary all** command.

**show ap join stats summary all**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display a summary of join information for all access points:

```
> show ap join stats summary all
Number of APs..... 4
Base Mac          AP EthernetMac      AP Name      IP Address      Status
00:0b:85:57:bc:c0  00:0b:85:57:bc:c0    AP1130       10.10.163.217   Joined
00:1c:0f:81:db:80  00:1c:63:23:ac:a0    AP1140       10.10.163.216   Not joined
00:1c:0f:81:fc:20  00:1b:d5:9f:7d:b2    AP1          10.10.163.215   Joined
00:21:1b:ea:36:60  00:0c:d4:8a:6b:c1    AP2          10.10.163.214   Not joined
```

**Related Commands**

- show ap join stats detailed**
- show ap join stats summary**

## show ap led-state

To view the LED state of all access points or a specific access point, use the **show ap led-state** command.

**show ap led-state** {all | *cisco\_ap*}

### Syntax Description

<b>all</b>	Shows the LED state for all access points.
<i>cisco_ap</i>	Name of the access point whose LED state is to be shown.

### Command Default

Enabled.

### Examples

This example shows how to get the LED state of all access points:

```
> show ap led-state all
Global LED State: Enabled (default)
```

### Related Commands

**config ap led-state**

## show ap led-flash

To display the LED flash status of an access point, use the **show ap led-flash** command.

**show ap led-flash** *cisco\_ap*

<b>Syntax Description</b>	<i>cisco_ap</i>
---------------------------	-----------------

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the LED flash status of an access point: > <b>show ap led-flash</b>
-----------------	--

<b>Related Commands</b>	<b>config ap led-state flash</b> <b>config ap led-state</b>
-------------------------	--

## show ap link-encryption

To display the MAC addresses of all the access points that are joined to the controller or that have tried to join, use the **show ap link-encryption** command.

**show ap link-encryption** {all | *cisco\_ap*}

### Syntax Description

<b>all</b>	Specifies all access points.
<i>cisco_ap</i>	Name of the lightweight access point.

### Command Default

None.

### Examples

This example shows how to display the link encryption status of all access points:

```
> show ap link-encryption all
```

AP Name	Encryption State	Dnstream Count	Upstream Count	Last Update
1240	Dis	4406	237553	Never
1130	En	2484	276308	19:31

### Related Commands

**config ap link-encryption**  
**config ap link-latency**



## show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

**show ap monitor-mode summary**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display current channel-optimized monitor mode settings:

```
> show ap monitor-mode summary
AP Name           Ethernet MAC           Status           Scanning Channel List
-----
AP_004            xx:xx:xx:xx:xx:xx Tracking           1, 6, 11, 4
```

**Related Commands**

- config ap mode**
- config ap monitor-mode**

## show ap packet-dump status

To display access point Packet Capture configurations, use the **show ap packet-dump status** command.

### show ap packet-dump status

**Syntax Description** This command has no arguments or keywords.

**Usage Guidelines** Packet Capture does not work during intercontroller roaming.

The controller does not capture packets created in the radio firmware and sent out of the access point, such as the beacon or probe response. Only packets that flow through the Radio driver in the Tx path are captured.

**Examples** This example shows how to display the access point Packet Capture configurations:

```
> show ap packet-dump status
Packet Capture Status..... Stopped
FTP Server IP Address..... 0.0.0.0
FTP Server Path.....
FTP Server Username.....
FTP Server Password..... *****
Buffer Size for Capture..... 2048 KB
Packet Capture Time..... 45 Minutes
Packet Truncate Length..... Unspecified
Packet Capture Classifier..... None
```

**Related Commands**

- config ap packet-dump**
- debug ap packet-dump**

## show ap retransmit

To display access point control packet retransmission parameters, use the **show ap retransmit** command.

**show ap retransmit** {**all** | *cisco\_ap*}

### Syntax Description

<b>all</b>	Specifies all access points.
<i>cisco_ap</i>	Name of the access point.

### Command Default

None.

### Examples

This example shows how to display the control packet retransmission parameters of all access points on a network:

```
> show ap retransmit all
Global control packet retransmit interval: 3 (default)
Global control packet retransmit count: 5 (default)
AP Name           Retransmit Interval  Retransmit count
-----
AP_004             3 (default)          5 (WLC default),5 (AP default)
```

### Related Commands

**config ap retransmit interval**

## show ap stats

To display the statistics for a Cisco lightweight access point, use the **show ap stats** command.

**show ap stats {802.11 {a | b} | wlan | ethernet summary} cisco\_ap [tsm {client\_mac | all}]**

### Syntax Description

<b>802.11a</b>	Specifies the 802.11a network
<b>802.11b</b>	Specifies the 802.11b/g network.
<b>wlan</b>	Specifies WLAN statistics.
<b>ethernet</b>	Specifies AP ethernet interface statistics.
<b>summary</b>	Displays ethernet interface summary of all the connected Cisco access points.
<i>cisco_ap</i>	Name of the lightweight access point.
<b>tsm</b>	(Optional) Specifies the traffic stream metrics.
<i>client_mac</i>	(Optional) MAC address of the client.
<b>all</b>	(Optional) Specifies all access points.

### Command Default

None.

### Examples

This example shows how to display statistics of an access point for the 802.11b network:

```
> show ap stats 802.11a Ibiza

Number Of Slots..... 2
AP Name..... Ibiza
MAC Address..... 44:2b:03:9a:8a:73
Radio Type..... RADIO_TYPE_80211a
Stats Information
  Number of Users..... 0
  TxFragmentCount..... 84628
  MulticastTxFrameCnt..... 84628
  FailedCount..... 0
  RetryCount..... 0
  MultipleRetryCount..... 0
  FrameDuplicateCount..... 0
  RtsSuccessCount..... 1
  RtsFailureCount..... 0
  AckFailureCount..... 0
  RxIncompleteFragment..... 0
  MulticastRxFrameCnt..... 0
  FcsErrorCount..... 20348857
  TxFrameCount..... 84628
  WepUndecryptableCount..... 19907
  TxFramesDropped..... 0
```

```

Rate Limiting Stats:
  Wlan 1:
    Number of Data Packets Received..... 592
    Number of Data Rx Packets Dropped..... 160
    Number of Data Bytes Received..... 160783
    Number of Data Rx Bytes Dropped..... 0
    Number of Realtime Packets Received..... 592
    Number of Realtime Rx Packets Dropped..... 0
    Number of Realtime Bytes Received..... 160783
    Number of Realtime Rx Bytes Dropped..... 0
    Number of Data Packets Sent..... 131
    Number of Data Tx Packets Dropped..... 0
    Number of Data Bytes Sent..... 23436
    Number of Data Tx Bytes Dropped..... 0
    Number of Realtime Packets Sent..... 131
    Number of Realtime Tx Packets Dropped..... 0
    Number of Realtime Bytes Sent..... 23436
    Number of Realtime Tx Bytes Dropped..... 0
  Call Admission Control (CAC) Stats
    Voice Bandwidth in use(% of config bw)..... 0
    Voice Roam Bandwidth in use(% of config bw).... 0
    Total channel MT free..... 0
    Total voice MT free..... 0
    Na Direct..... 0
    Na Roam..... 0
    Video Bandwidth in use(% of config bw)..... 0
    Video Roam Bandwidth in use(% of config bw).... 0
    Total BW in use for Voice(%)..... 0
    Total BW in use for SIP Preferred call(%)..... 0
  WMM TSPEC CAC Call Stats
    Total num of voice calls in progress..... 0
    Num of roaming voice calls in progress..... 0
    Total Num of voice calls since AP joined..... 0
    Total Num of roaming calls since AP joined..... 0
    Total Num of exp bw requests received..... 0
    Total Num of exp bw requests admitted..... 0
    Num of voice calls rejected since AP joined.... 0
    Num of roam calls rejected since AP joined.... 0
    Num of calls rejected due to insufficient bw.... 0
    Num of calls rejected due to invalid params.... 0
    Num of calls rejected due to PHY rate..... 0
    Num of calls rejected due to QoS policy..... 0
  SIP CAC Call Stats
    Total Num of calls in progress..... 0
    Num of roaming calls in progress..... 0
    Total Num of calls since AP joined..... 0
    Total Num of roaming calls since AP joined..... 0
    Total Num of Preferred calls received..... 0
    Total Num of Preferred calls accepted..... 0
    Total Num of ongoing Preferred calls..... 0
    Total Num of calls rejected(Insuff BW)..... 0
    Total Num of roam calls rejected(Insuff BW).... 0
  WMM Video TSPEC CAC Call Stats
    Total num of video calls in progress..... 0
    Num of roaming video calls in progress..... 0
    Total Num of video calls since AP joined..... 0
    Total Num of video roaming calls since AP j.... 0
    Num of video calls rejected since AP joined.... 0
    Num of video roam calls rejected since AP j.... 0
    Num of video calls rejected due to insuffic.... 0
    Num of video calls rejected due to invalid .... 0
    Num of video calls rejected due to PHY rate.... 0
    Num of video calls rejected due to QoS poli.... 0
  SIP Video CAC Call Stats
    Total Num of video calls in progress..... 0
    Num of video roaming calls in progress..... 0
    Total Num of video calls since AP joined..... 0
    Total Num of video roaming calls since AP j.... 0
    Total Num of video calls rejected(Insuff BW.... 0
    Total Num of video roam calls rejected(Insu.... 0
  Band Select Stats
    Num of dual band client ..... 0
    Num of dual band client added..... 0

```

**show ap stats**

```
Num of dual band client expired ..... 0
Num of dual band client replaced..... 0
Num of dual band client detected ..... 0
Num of suppressed client ..... 0
Num of suppressed client expired..... 0
Num of suppressed client replaced..... 0
```

**Related Commands****config ap static-ip****config ap static-timer**

## show ap summary

To display a summary of all lightweight access points attached to the controller, use the **show ap summary** command.

**show ap summary** [*cisco\_ap*]

<b>Syntax Description</b>	<i>cisco_ap</i> (Optional) Type sequence of characters that make up the name of a specific AP or a group of APs, or enter a wild character search pattern.	
<b>Command Default</b>	None.	
<b>Usage Guidelines</b>	A list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the controller port number appears. When you specify	
<b>Examples</b>	This example shows how to display a summary of all connected access points: <pre>&gt; show ap summary Number of APs..... 2 Global AP username..... user Global AP Dot1x username..... Not Configured Number of APs..... 2 Global AP username..... user Global AP Dot1x username..... Not Configured AP Name    Slots    AP Model          Ethernet MAC      Location    Port Country  Priority ----- wolverine  2          AIR-LAP1252AG-A-K9  00:1b:d5:13:39:74 Reception    1    US        3 ap:1120    1          AIR-LAP1121G-A-K9   00:1b:d5:a9:ad:08 Hall 235     1    US        1</pre>	
<b>Related Commands</b>	config ap	

## show ap tcp-mss-adjust

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point, use the **show ap tcp-mss-adjust** command.

**show ap tcp-mss-adjust** {*cisco\_ap* | **all**}

### Syntax Description

<i>cisco_ap</i>	Specified lightweight access point name.
<b>all</b>	Specifies all access points.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Examples

This example shows how to display Transmission Control Protocol (TCP) maximum segment size (MSS) information of all access points:

```
> show ap tcp-mss-adjust all
AP Name      TCP State MSS Size
-----
AP-1140      enabled  536
AP-1240      disabled -
AP-1130      disabled -
```

### Related Commands

**config ap tcp-adjust-mss**



## show ap wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point, use the **show ap wlan** command.

**show ap wlan 802.11 {a | b} cisco\_ap**

### Syntax Description

<b>802.11a</b>	Specifies the 802.11a network.
<b>802.11b</b>	Specifies the 802.11b/g network.
<i>ap_name</i>	Lightweight access point name.

### Command Default

None.

### Examples

This example shows how to display BSSIDs of an access point for the 802.11b network:

```
> show ap wlan 802.11b AP01
Site Name..... MY_AP_GROUP1
Site Description..... MY_AP_GROUP1
WLAN ID      Interface      BSSID
-----
1            management    00:1c:0f:81:fc:20
2            dynamic      00:1c:0f:81:fc:21
```

### Related Commands

**config ap wlan**

## show auth-list

To display the access point authorization list, use the **show auth-list** command.

**show auth-list**

### Syntax Description

This command has no arguments or keywords.

### Examples

This example shows how to display the access point authorization list:

```
> show auth-list
Authorize APs against AAA..... disabled
Allow APs with Self-signed Certificate (SSC)... disabled
Mac Addr          Cert Type      Key Hash
-----
xx:xx:xx:xx:xx:xx  MIC
```

### Related Commands

**clear tacacs auth statistics**

**clear stats local-auth**

**config auth-list add**

**config auth-list ap-policy**

**config auth-list delete**

## show client ap

To display the clients on a Cisco lightweight access point, use the **show client ap** command.

**show client ap 802.11 {a | b} cisco\_ap**

### Syntax Description

<b>802.11a</b>	Specifies the 802.11a network.
<b>802.11b</b>	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Usage Guidelines

The **show client ap** command may list the status of automatically disabled clients. Use the **show exclusionlist** command to view clients on the exclusion list (blacklisted).

### Examples

This example shows how to display client information on an access point:

```
> show client ap 802.11b AP1
MAC Address      AP Id   Status      WLAN Id   Authenticated
-----
xx:xx:xx:xx:xx:xx    1   Associated    1           No
```

### Related Commands

**show client detail**  
**show client summary**  
**show client username**  
**show country**  
**show exclusionlist**

## show boot

To display the primary and backup software build numbers with an indication of which is active, use the **show boot** command.

**show boot**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Usage Guidelines** Each Cisco wireless LAN controller retains one primary and one backup operating system software load in nonvolatile RAM to allow controllers to boot off the primary load (default) or revert to the backup load when desired.

**Examples** This example shows how to display the default boot image information:

```
> show boot
Primary Boot Image..... 3.2.13.0 (active)
Backup Boot Image..... 3.2.15.0
```

**Related Commands** **config boot**

## show call-control ap

**Note**

The **show call-control ap** command is applicable only for SIP based calls.

To see the metrics for successful calls or the traps generated for failed calls, use the **show call-control ap** command.

**show call-control ap {802.11a | 802.11b} cisco\_ap {metrics | traps}**

**Syntax Description**

<b>802.11a</b>	Specifies the 802.11a network
<b>802.11b</b>	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco access point name.
<b>metrics</b>	Specifies the call metrics information.
<b>traps</b>	Specifies the trap information for call control.

**Command Default**

None.

**Examples**

This example shows how to display the metrics for successful calls generated for an access point:

```
> show call-control ap 802.11a Cisco_AP metrics
Total Call Duration in Seconds..... 120
Number of Calls..... 10
Number of calls for given client is..... 1
```

This example shows how to display the metrics for the traps generated for an access point:

```
> show call-control ap 802.11a Cisco_AP traps
Number of traps sent in one min..... 2
Last SIP error code..... 404
Last sent trap timestamp..... Jun 20 10:05:06
```

**Usage Guidelines**


To aid in troubleshooting, the output of this command shows an error code for any failed calls. This table explains the possible error codes for failed calls.

**Table 1: Error Codes for Failed VoIP Calls**

Error Code	Integer	Description
1	unknown	Unknown error.
400	badRequest	The request could not be understood because of malformed syntax.

Error Code	Integer	Description
401	unauthorized	The request requires user authentication.
402	paymentRequired	Reserved for future use.
403	forbidden	The server understood the request but refuses to fulfill it.
404	notFound	The server has information that the user does not exist at the domain specified in the Request-URI.
405	methodNotAllowed	The method specified in the Request-Line is understood but not allowed for the address identified by the Request-URI.
406	notAcceptable	The resource identified by the request is only capable of generating response entities with content characteristics that are not acceptable according to the Accept header field sent in the request.
407	proxyAuthenticationRequired	The client must first authenticate with the proxy.
408	requestTimeout	The server could not produce a response within a suitable amount of time.
409	conflict	The request could not be completed due to a conflict with the current state of the resource.
410	gone	The requested resource is no longer available at the server, and no forwarding address is known.
411	lengthRequired	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
413	requestEntityTooLarge	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
414	requestURITooLarge	The server is refusing to service the request because the Request-URI is longer than the server is willing to interpret.
415	unsupportedMediaType	The server is refusing to service the request because the message body of the request is in a format not supported by the server for the requested method.
420	badExtension	The server did not understand the protocol extension specified in a Proxy-Require or Require header field.
480	temporarilyNotAvailable	The callee's end system was contacted successfully, but the callee is currently unavailable.

Error Code	Integer	Description
481	callLegDoesNotExist	The UAS received a request that does not match any existing dialog or transaction.
482	loopDetected	The server has detected a loop.
483	tooManyHops	The server received a request that contains a Max-Forwards header field with the value zero.
484	addressIncomplete	The server received a request with a Request-URI that was incomplete.
485	ambiguous	The Request-URI was ambiguous.
486	busy	The callee's end system was contacted successfully, but the callee is currently not willing or able to take additional calls at this end system.
500	internalServerError	The server encountered an unexpected condition that prevented it from fulfilling the request.
501	notImplemented	The server does not support the functionality required to fulfill the request.
502	badGateway	The server, while acting as a gateway or proxy, received an invalid response from the downstream server it accessed in attempting to fulfill the request.
503	serviceUnavailable	The server is temporarily unable to process the request because of a temporary overloading or maintenance of the server.
504	serverTimeout	The server did not receive a timely response from an external server it accessed in attempting to process the request.
505	versionNotSupported	The server does not support or refuses to support the SIP protocol version that was used in the request.
600	busyEverywhere	The callee's end system was contacted successfully, but the callee is busy or does not want to take the call at this time.
603	decline	The callee's machine was contacted successfully, but the user does not want to or cannot participate.
604	doesNotExistAnywhere	The server has information that the user indicated in the Request-URI does not exist anywhere.
606	notAcceptable	The user's agent was contacted successfully, but some aspects of the session description (such as the requested media, bandwidth, or addressing style) were not acceptable.

 **show call-control ap**



## show country

To display the configured country and the radio types supported, use the **show country** command.

**show country**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the configured countries and supported radio types:

```
> show country
Configured Country..... United States
Configured Country Codes
US - United States..... 802.11a / 802.11b / 802.11g
```

**Related Commands**

- config country**
- show country channels**
- show country supported**

## show country channels

To display the radio channels supported in the configured country, use the **show country channels** command.

**show country channels**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the auto-RF channels for the configured countries:

```
> show country channels
Configured Country..... United States
KEY: * = Channel is legal in this country and may be configured manually.
Configured Country..... United States
KEY: * = Channel is legal in this country and may be configured manually.
      A = Channel is the Auto-RF default in this country.
      . = Channel is not legal in this country.
      C = Channel has been configured for use by Auto-RF.
      x = Channel is available to be configured for use by Auto-RF.
-----:+++++-----
802.11BG :
Channels :           1 1 1 1 1
          : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----:+++++-----
      US : A * * * * A * * * * A . . .
-----:+++++-----
802.11A : 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Channels : 3 3 3 4 4 4 4 4 5 5 6 6 0 0 1 1 2 2 3 3 4 4 5 5 6 6
          : 4 6 8 0 2 4 6 8 2 6 0 4 0 4 8 2 6 0 4 8 2 6 0 9 3 7 1 5
-----:+++++-----
      US : . A . A . A . A A A A * * * * * . . . * * * A A A A *
-----:+++++-----
```

**Related Commands**

- config country**
- show country**
- show country supported**

## show country supported

To display a list of the supported country options, use the **show country supported** command.

### show country supported

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display a list of all the supported countries:

```
> show country supported
Configured Country..... United States
Supported Country Codes
AR - Argentina..... 802.11a / 802.11b / 802.11g
AT - Austria..... 802.11a / 802.11b / 802.11g
AU - Australia..... 802.11a / 802.11b / 802.11g
BR - Brazil..... 802.11a / 802.11b / 802.11g
BE - Belgium..... 802.11a / 802.11b / 802.11g
BG - Bulgaria..... 802.11a / 802.11b / 802.11g
CA - Canada..... 802.11a / 802.11b / 802.11g
CH - Switzerland..... 802.11a / 802.11b / 802.11g
CL - Chile..... 802.11b / 802.11g
CN - China..... 802.11a / 802.11b / 802.11g
CO - Colombia..... 802.11b / 802.11g
CY - Cyprus..... 802.11a / 802.11b / 802.11g
CZ - Czech Republic..... 802.11a / 802.11b
DE - Germany..... 802.11a / 802.11b / 802.11g
DK - Denmark..... 802.11a / 802.11b / 802.11g
EE - Estonia..... 802.11a / 802.11b / 802.11g
ES - Spain..... 802.11a / 802.11b / 802.11g
FI - Finland..... 802.11a / 802.11b / 802.11g
FR - France..... 802.11a / 802.11b / 802.11g
GB - United Kingdom..... 802.11a / 802.11b / 802.11g
GI - Gibraltar..... 802.11a / 802.11b / 802.11g
GR - Greece..... 802.11a / 802.11b / 802.11g
HK - Hong Kong..... 802.11a / 802.11b / 802.11g
HU - Hungary..... 802.11a / 802.11b / 802.11g
ID - Indonesia..... 802.11b / 802.11g
IE - Ireland..... 802.11a / 802.11b / 802.11g
IN - India..... 802.11a / 802.11b / 802.11g
IL - Israel..... 802.11a / 802.11b / 802.11g
ILO - Israel (outdoor)..... 802.11b / 802.11g
IS - Iceland..... 802.11a / 802.11b / 802.11g
IT - Italy..... 802.11a / 802.11b / 802.11g
JP - Japan (J)..... 802.11a / 802.11b / 802.11g
J2 - Japan 2 (P)..... 802.11a / 802.11b / 802.11g
J3 - Japan 3 (U)..... 802.11a / 802.11b / 802.11g
KR - Korea Republic (C)..... 802.11a / 802.11b / 802.11g
KE - Korea Extended (K)..... 802.11a / 802.11b / 802.11g
LI - Liechtenstein..... 802.11a / 802.11b / 802.11g
LT - Lithuania..... 802.11a / 802.11b / 802.11g
LU - Luxembourg..... 802.11a / 802.11b / 802.11g
LV - Latvia..... 802.11a / 802.11b / 802.11g
MC - Monaco..... 802.11a / 802.11b / 802.11g
MT - Malta..... 802.11a / 802.11b / 802.11g
MX - Mexico..... 802.11a / 802.11b / 802.11g
MY - Malaysia..... 802.11a / 802.11b / 802.11g
NL - Netherlands..... 802.11a / 802.11b / 802.11g
NZ - New Zealand..... 802.11a / 802.11b / 802.11g
```

**show country supported**

```

NO - Norway..... 802.11a / 802.11b / 802.11g
PA - Panama..... 802.11b / 802.11g
PE - Peru..... 802.11b / 802.11g
PH - Philippines..... 802.11a / 802.11b / 802.11g
PL - Poland..... 802.11a / 802.11b / 802.11g
PT - Portugal..... 802.11a / 802.11b / 802.11g
RU - Russian Federation..... 802.11a / 802.11b / 802.11g
RO - Romania..... 802.11a / 802.11b / 802.11g
SA - Saudi Arabia..... 802.11a / 802.11b / 802.11g
SE - Sweden..... 802.11a / 802.11b / 802.11g
SG - Singapore..... 802.11a / 802.11b / 802.11g
SI - Slovenia..... 802.11a / 802.11b / 802.11g
SK - Slovak Republic..... 802.11a / 802.11b / 802.11g
TH - Thailand..... 802.11b / 802.11g
TR - Turkey..... 802.11b / 802.11g
TW - Taiwan..... 802.11a / 802.11b / 802.11g
UA - Ukraine..... 802.11a / 802.11b / 802.11g
US - United States..... 802.11a / 802.11b / 802.11g
USL - United States (Legacy)..... 802.11a / 802.11b / 802.11g
USX - United States (US + chan165)..... 802.11a / 802.11b / 802.11g
VE - Venezuela..... 802.11b / 802.11g
ZA - South Africa..... 802.11a / 802.11b / 802.11g

```

**Related Commands****config country****show country channels****show country**

## show dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show dtls connections** command.

### show dtls connections

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Examples** The following is a sample output of the **show dtls connections** command.

```
Device > show dtls connections
```

AP Name	Local Port	Peer IP	Peer Port	Ciphersuite
1130	Capwap_Ctrl	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1130	Capwap_Data	1.100.163.210	23678	TLS_RSA_WITH_AES_128_CBC_SHA
1240	Capwap_Ctrl	1.100.163.209	59674	TLS_RSA_WITH_AES_128_CBC_SHA

**Related Commands** **debug dtls**

## show known ap

To display known Cisco lightweight access point information, use the **show known ap** command.

**show known ap** {**summary** | **detailed** *MAC*}

### Syntax Description

<b>summary</b>	Displays a list of all known access points.
<b>detailed</b>	Provides detailed information for all known access points.
<i>MAC</i>	MAC address of the known AP.

### Command Default

None.

### Examples

This example shows how to display a summary of all known access points:

```
> show known ap summary
MAC Address      State      # APs  # Clients  Last Heard
-----
```

### Related Commands

**config ap**

## show ipv6 ra-guard

To display the RA guard statistics, use the **show ipv6 ra-guard** command.

**show ipv6 ra-guard {ap | wlc} summary**

### Syntax Description

<b>ap</b>	Displays Cisco access point details.
<b>wlc</b>	Displays Cisco controller details.
<b>summary</b>	Displays RA guard statistics.

### Command Default

None.

### Examples

This example shows how to display the RA guard statistics for an access point:

```
> show ipv6 ra-guard ap summary
IPv6 RA Guard on AP..... Enabled
RA Dropped per client:
MAC Address      AP Name          WLAN/GLAN      Number of RA Dropped
-----
00:40:96:b9:4b:89 Bhavik_1130_1_p13 2              19
-----
Total RA Dropped on AP..... 19
```

This example shows how to display the RA guard statistics for a controller:

```
> show ipv6 ra-guard wlc summary
IPv6 RA Guard on WLC..... Enabled
```

### Related Commands

**config ipv6 ra-guard**

## show msglog

To display the message logs written to the Cisco wireless LAN controller database, use the **show msglog** command.

### show msglog

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Usage Guidelines** If there are more than 15 entries, you are prompted to display the messages shown in the example.

**Examples** This example shows how to display message logs:

```
> show msglog
Message Log Severity Level..... ERROR
Thu Aug 4 14:30:08 2005 [ERROR] spam_lrad.c 1540: AP 00:0b:85:18:b6:50 associated. Last
AP failure was due to Link Failure
Thu Aug 4 14:30:08 2005 [ERROR] spam_lrad.c 13840: Updating IP info for AP 00:
0b:85:18:b6:50 -- static 0, 1.100.49.240/255.255.255.0, gw 1.100.49.1
Thu Aug 4 14:29:32 2005 [ERROR] dhcpd.c 78: dhcp server: binding to 0.0.0.0
Thu Aug 4 14:29:32 2005 [ERROR] rrmgroup.c 733: Airewave Director: 802.11a switch group
reset
Thu Aug 4 14:29:32 2005 [ERROR] rrmgroup.c 733: Airewave Director: 802.11bg sw
itch group reset
Thu Aug 4 14:29:22 2005 [ERROR] sim.c 2841: Unable to get link state for primary port 0
of interface ap-manager
Thu Aug 4 14:29:22 2005 [ERROR] dtl_l2_dot1q.c 767: Unable to get USP
Thu Aug 4 14:29:22 2005 Previous message occurred 2 times
Thu Aug 4 14:29:14 2005 [CRITICAL] osapi_sem.c 794: Error! osapiMutexTake called with
NULL pointer: osapi_bsntime.c:927
Thu Aug 4 14:29:14 2005 [CRITICAL] osapi_sem.c 794: Error! osapiMutexTake called with
NULL pointer: osapi_bsntime.c:919
Thu Aug 4 14:29:14 2005 [CRITICAL] hwutils.c 1861: Security Module not found
Thu Aug 4 14:29:13 2005 [CRITICAL] bootos.c 791: Starting code...
```



## show network summary

To display the network configuration of the Cisco wireless LAN controller, use the **show network summary** command.

### show network summary

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display a summary configuration:

```
> show network summary
RF-Network Name..... RF
Web Mode..... Disable
Secure Web Mode..... Enable
Secure Web Mode Cipher-Option High..... Disable
Secure Web Mode Cipher-Option SSLv2..... Disable
Secure Web Mode RC4 Cipher Preference..... Disable
OCSP..... Disabled
OCSP responder URL.....
Secure Shell (ssh)..... Enable
Telnet..... Enable
Ethernet Multicast Mode..... Disable      Mode: Ucast
Ethernet Broadcast Mode..... Disable
Ethernet Multicast Forwarding..... Disable
Ethernet Broadcast Forwarding..... Disable
AP Multicast/Broadcast Mode..... Unicast
IGMP snooping..... Disabled
IGMP timeout..... 60 seconds
IGMP Query Interval..... 20 seconds
MLD snooping..... Disabled
MLD timeout..... 60 seconds
MLD query interval..... 20 seconds
User Idle Timeout..... 300 seconds
AP Join Priority..... Disable
ARP Idle Timeout..... 300 seconds
ARP Unicast Mode..... Disabled
Cisco AP Default Master..... Disable
Mgmt Via Wireless Interface..... Disable
Mgmt Via Dynamic Interface..... Disable
Bridge MAC filter Config..... Enable
Bridge Security Mode..... EAP
Over The Air Provisioning of AP's..... Enable
Apple Talk ..... Disable
Mesh Full Sector DFS..... Enable
AP Fallback ..... Disable
Web Auth CMCC Support ..... Disabled
Web Auth Redirect Ports ..... 80
Web Auth Proxy Redirect ..... Disable
Web Auth Captive-Bypass ..... Disable
Web Auth Secure Web ..... Enable
Fast SSID Change ..... Disabled
AP Discovery - NAT IP Only ..... Enabled
IP/MAC Addr Binding Check ..... Enabled
CCX-lite status ..... Disable
oacp-600 dual-rlan-ports ..... Disable
oacp-600 local-network ..... Enable
mDNS snooping..... Disabled
```

mDNS Query Interval..... 15 minutes

**Related Commands**

**config network**

**show network multicast mgid summary**

**show network multicast mgid detail**

**show network**

## show redundancy summary

To display the redundancy summary information, use the **show redundancy summary** command.

**show redundancy summary**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the redundancy summary information of the controller:

```
> show redundancy summary
Redundancy Mode = SSO DISABLED
  Local State = ACTIVE
    Peer State = N/A
      Unit = Primary
        Unit ID = 88:43:E1:7E:03:80
Redundancy State = N/A
  Mobility MAC = 88:43:E1:7E:03:80

Redundancy Management IP Address..... 9.4.92.12
Peer Redundancy Management IP Address..... 9.4.92.14
Redundancy Port IP Address..... 169.254.92.12
Peer Redundancy Port IP Address..... 169.254.92.14
```

**Related Commands**

- config redundancy mobilitymac**
- config redundancy interface address peer-service-port**
- config redundancy peer-route**
- config redundancy unit**
- config redundancy timer**
- show redundancy peer-route**
- show redundancy summary**
- debug rmgr**
- debug rsyncmgr**

## show redundancy latency

To display the average latency to reach the management gateway and the peer redundancy management IP address, use the **show redundancy latency** command.

**show redundancy latency**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the average latency to reach the management gateway and the peer redundancy management IP address:

> **show redundancy latency**

Network Latencies (RTT) for the Peer Reachability on the Redundancy Port in micro seconds for the past 10 intervals

Peer Reachability Latency[ 1 ]	: 524 usecs
Peer Reachability Latency[ 2 ]	: 524 usecs
Peer Reachability Latency[ 3 ]	: 522 usecs
Peer Reachability Latency[ 4 ]	: 526 usecs
Peer Reachability Latency[ 5 ]	: 524 usecs
Peer Reachability Latency[ 6 ]	: 524 usecs
Peer Reachability Latency[ 7 ]	: 522 usecs
Peer Reachability Latency[ 8 ]	: 522 usecs
Peer Reachability Latency[ 9 ]	: 526 usecs
Peer Reachability Latency[ 10 ]	: 523 usecs

Network Latencies (RTT) for the Management Gateway Reachability in micro seconds for the past 10 intervals

Gateway Reachability Latency[ 1 ]	: 1347 usecs
Gateway Reachability Latency[ 2 ]	: 2427 usecs
Gateway Reachability Latency[ 3 ]	: 1329 usecs
Gateway Reachability Latency[ 4 ]	: 2014 usecs
Gateway Reachability Latency[ 5 ]	: 2675 usecs
Gateway Reachability Latency[ 6 ]	: 731 usecs
Gateway Reachability Latency[ 7 ]	: 1882 usecs
Gateway Reachability Latency[ 8 ]	: 2853 usecs
Gateway Reachability Latency[ 9 ]	: 832 usecs
Gateway Reachability Latency[ 10 ]	: 3708 usecs

**Related Commands**

- show redundancy interfaces**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy interface address peer-service-port**

## show redundancy interfaces

To display details of redundancy and service port IP addresses, use the **show redundancy interfaces** command.

**show redundancy interfaces**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the redundancy and service port IP addresses information:
-----------------	---

> **show redundancy interfaces**

```
Redundancy Management IP Address..... 9.4.120.5
Peer Redundancy Management IP Address..... 9.4.120.3
Redundancy Port IP Address..... 169.254.120.5
Peer Redundancy Port IP Address..... 169.254.120.3
Peer Service Port IP Address..... 10.104.175.189
```

<b>Related Commands</b>	<b>show redundancy latency</b>
	<b>show redundancy summary</b>
	<b>show redundancy peer-route</b>
	<b>show redundancy statistics</b>
	<b>show redundancy timers</b>
	<b>show redundancy mobilitymac</b>
	<b>config redundancy interface address peer-service-port</b>
	<b>config redundancy peer-route</b>

## show redundancy mobilitymac

To display the High Availability (HA) mobility MAC address used to communicate with the peer, use the **show redundancy mobilitymac** command.

**show redundancy mobilitymac**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the HA mobility MAC address used to communicate with the peer:

```
> show redundancy mobilitymac  
ff:ff:ff:ff:ff:ff
```

**Related Commands**

- config redundancy mobilitymac**
- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- debug rfac**
- debug rmgr**
- debug rsyncmgr**

## show redundancy peer-route summary

To display the routes assigned to the standby controller, use the **show redundancy peer-route summary** command.

**show redundancy peer-route summary**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display all the configured routes of the standby controller:

```
> show redundancy peer-route summary
Number of Routes..... 1

Destination Network      Netmask      Gateway
-----
xxx.xxx.xxx.xxx         255.255.255.0  xxx.xxx.xxx.xxx
```

**Related Commands**

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy peer-route**

## show redundancy statistics

To display the statistics information of the Redundancy Manager, use the **show redundancy statistics** command.

**show redundancy statistics**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Usage Guidelines** This command displays the statistics of different redundancy counters.

Local Physical Ports - Connectivity status of each physical port of the controller. 1 indicates that the port is up and 0 indicates that the port is down.

Peer Physical Ports - Connectivity status of each physical port of the peer controller. 1 indicates that the port is up and 0 indicates that the port is down.

**Examples** This example shows how to display the statistics information of the Redundancy Manager:

```
> show redundancy statistics

Redundancy Manager Statistics

Keep Alive Request Send Counter      : 16
Keep Alive Response Receive Counter  : 16

Keep Alive Request Receive Counter    : 500322
Keep Alive Response Send Counter     : 500322

Ping Request to Default GW Counter    : 63360
Ping Response from Default GW Counter : 63360

Ping Request to Peer Counter          : 12
Ping Response from Peer Counter       : 3

Keep Alive Loss Counter               : 0
Default GW Loss Counter               : 0

Local Physical Ports 1...8            : 10000000
Peer Physical Ports 1...8             : 10000000
```

**Related Commands**

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy timers**
- show redundancy mobilitymac**
- config redundancy timer peer-search-timer**



**config redundancy timer keep-alive-timer**

**debug rfac**

**debug rmgr**

**debug rsyncmgr**

## show redundancy timers

To display details of the Redundancy Manager timers, use the **show redundancy timers** command.

**show redundancy timers**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to display the details of the Redundancy Manager timers:

```
> show redundancy timers

      Keep Alive Timer           : 100 msec
      Peer Search Timer          : 120 sec
```

**Related Commands**

- show redundancy latency**
- show redundancy summary**
- show redundancy peer-route**
- show redundancy statistics**
- config redundancy timer peer-search-timer**
- config redundancy timer keep-alive-timer**
- debug rfac**
- debug rmgr**
- debug rsyncmgr**

## show watchlist

To display the client watchlist, use the **show watchlist** command.

**show watchlist**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to display the client watchlist information:
-----------------	---

```
> show watchlist
client watchlist state is disabled
```

<b>Related Commands</b>	<b>config watchlist add</b> <b>config watchlist delete</b> <b>config watchlist disable</b> <b>config watchlist enable</b>
-------------------------	--

## capwap ap Commands

Use the **capwap ap** commands to configure CAPWAP access point settings.

## capwap ap controller ip address

To configure the controller IP address into the CAPWAP access point from the access point's console port, use the **capwap ap controller ip address** command.

**capwap ap controller ip address** *controller\_ip\_address*

### Syntax Description

*controller\_ip\_address*

IP address of the controller.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the controller IP address 10.23.90.81 into the CAPWAP access point:

```
> capwap ap controller ip address 10.23.90.81
```

### Related Commands

capwap ap dot1x  
 capwap ap hostname  
 capwap ap ip address  
 capwap ap ip default-gateway  
 capwap ap log-server  
 capwap ap primary-base  
 capwap ap primed-timer  
 capwap ap secondary-base  
 capwap ap tertiary-base

## capwap ap dot1x

To configure the dot1x username and password into the CAPWAP access point from the access point's console port, use the **capwap ap dot1x** command.

**capwap ap dot1x username** *user\_name* **password** *password*

### Syntax Description

<i>user_name</i>	Dot1x username.
<i>password</i>	Dot1x password.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the dot1x username ABC and password pass01:

```
> capwap ap dot1x username ABC password pass01
```

### Related Commands

capwap ap controller ip address  
 capwap ap hostname  
 capwap ap ip address  
 capwap ap ip default-gateway  
 capwap ap log-server  
 capwap ap primary-base  
 capwap ap primed-timer  
 capwap ap secondary-base  
 capwap ap tertiary-base

## capwap ap hostname

To configure the access point host name from the access point's console port, use the **capwap ap hostname** command.

**capwap ap hostname** *host\_name*

### Syntax Description

<i>host_name</i>	Hostname of the access point.
------------------	-------------------------------

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases. This command is available only for the Cisco Lightweight AP IOS Software recovery image (rcvk9w8) without any private-config. You can remove the private-config by using the **clear capwap private-config** command.

### Examples

This example shows how to configure the hostname WLC into the capwap access point:

```
> capwap ap hostname WLC
```

### Related Commands

- capwap ap controller ip address**
- capwap ap dot1x**
- capwap ap ip address**
- capwap ap ip default-gateway**
- capwap ap log-server**
- capwap ap primary-base**
- capwap ap primed-timer**
- capwap ap secondary-base**
- capwap ap tertiary-base**

## capwap ap ip address

To configure the IP address into the CAPWAP access point from the access point's console port, use the **capwap ap ip address** command.

**capwap ap ip address** *ip\_address*

### Syntax Description

<i>ip_address</i>	IP address.
-------------------	-------------

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the IP address 10.0.0.0.1 into capwap access point:

```
> capwap ap ip address 10.0.0.0.1
```

### Related Commands

- capwap ap controller ip address**
- capwap ap dot1x**
- capwap ap hostname**
- capwap ap ip default-gateway**
- capwap ap log-server**
- capwap ap ip address**
- capwap ap primary-base**
- capwap ap secondary-base**
- capwap ap tertiary-base**



## capwap ap ip default-gateway

To configure the default gateway from the access point's console port, use the **capwap ap ip default-gateway** command.

**capwap ap ip default-gateway** *default\_gateway*

### Syntax Description

<i>default_gateway</i>	Default gateway address of the capwap access point.
------------------------	---

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the capwap access point with the default gateway address 10.0.0.1:

```
> capwap ap ip default-gateway 10.0.0.1
```

### Related Commands

- capwap ap controller ip address
- capwap ap dot1x
- capwap ap hostname
- capwap ap ip address
- capwap ap log-server
- capwap ap primary-base
- capwap ap primary-base
- capwap ap secondary-base
- capwap ap tertiary-base

## capwap ap log-server

To configure the system log server to log all the capwap errors, use the **capwap ap log-server** command.

**capwap ap log-server** *ip\_address*

### Syntax Description

<i>ip_address</i>	IP address of the syslog server.
-------------------	----------------------------------

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the syslog server with the IP address 10.0.0.1:

```
> capwap ap log-server 10.0.0.1
```

### Related Commands

- capwap ap controller ip address
- capwap ap dot1x
- capwap ap ip address
- capwap ap hostname
- capwap ap ip default-gateway
- capwap ap log-server
- capwap ap primary-base
- capwap ap primary-base
- capwap ap secondary-base
- capwap ap tertiary-base

## capwap ap primary-base

To configure the primary controller name and IP address into the capwap access point from the access point's console port, use the **capwap ap primary-base** command.

**capwap ap primary-base** *controller\_name controller\_ip\_address*

### Syntax Description

<i>controller_name</i>	Name of the primary controller.
<i>controller_ip_address</i>	IP address of the primary controller.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the primary controller name WLC1 and primary controller IP address 10.92.109.1 into the capwap access point:

```
> capwap ap primary-base WLC1 10.92.109.1
```

### Related Commands

**capwap ap controller ip address**  
**capwap ap dot1x**  
**capwap ap ip address**  
**capwap ap hostname**  
**capwap ap ip default-gateway**  
**capwap ap log-server**  
**capwap ap secondary-base**  
**capwap ap tertiary-base**

## capwap ap primed-timer

To configure the primed timer into the CAPWAP access point, use the **capwap ap primed-timer** command.

**capwap ap primed-timer {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the primed timer settings
<b>disable</b>	Disables the primed timer settings.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

### Examples

This example shows how to enable the primed-timer settings:

```
> capwap ap primed-timer enable
```

### Related Commands

**capwap ap controller ip address**  
**capwap ap dot1x**  
**capwap ap hostname**  
**capwap ap ip default-gateway**  
**capwap ap log-server**  
**capwap ap ip address**  
**capwap ap primary-base**  
**capwap ap secondary-base**  
**capwap ap tertiary-base**

## capwap ap secondary-base

To configure the name and IP address of the secondary Cisco WLC into the CAPWAP access point from the access point's console port, use the **capwap ap secondary-base** command.

**capwap ap secondary-base** *controller\_name controller\_ip\_address*

### Syntax Description

<i>controller_name</i>	Name of the secondary Cisco WLC.
<i>controller_ip_address</i>	IP address of the secondary Cisco WLC.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

### Examples

This example shows how to configure the secondary Cisco WLC name as WLC2 and secondary Cisco WLC IP address 10.92.108.2 into the CAPWAP access point:

```
> capwap ap secondary-base WLC2 10.92.108.2
```

### Related Commands

**capwap ap controller ip address**  
**capwap ap dot1x**  
**capwap ap ip address**  
**capwap ap hostname**  
**capwap ap ip default-gateway**  
**capwap ap log-server**  
**capwap ap primary-base**  
**capwap ap tertiary-base**

## capwap ap tertiary-base

To configure the name and IP address of the tertiary Cisco WLC into the CAPWAP access point from the access point's console port, use the **capwap ap tertiary-base** command.

**capwap ap tertiary-base** *controller\_name controller\_ip\_address*

### Syntax Description

<i>controller_name</i>	Name of the tertiary Cisco WLC.
<i>controller_ip_address</i>	IP address of the tertiary Cisco WLC.

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

### Examples

This example shows how to configure the tertiary Cisco WLC with the name WLC3 and secondary Cisco WLC IP address 10.80.72.2 into the CAPWAP access point:

```
> capwap ap tertiary-base WLC3 10.80.72.2
```

### Related Commands

**capwap ap controller ip address**  
**capwap ap dot1x**  
**capwap ap ip address**  
**capwap ap hostname**  
**capwap ap ip default-gateway**  
**capwap ap log-server**  
**capwap ap primary-base**  
**capwap ap secondary-base**

## lwapp ap controller ip address

To configure the controller IP address into the FlexConnect access point from the access point's console port, use the **lwapp ap controller ip address** command.

**lwapp ap controller ip address** *ip\_address*

### Syntax Description

<i>ip_address</i>	IP address of the controller.
-------------------	-------------------------------

### Command Default

None.

### Usage Guidelines

This command must be entered from an access point's console port.

Prior to changing the FlexConnect configuration on an access point using the access point's console port, the access point must be in standalone mode (not connected to a controller) and you must remove the current LWAPP private configuration by using the **clear lwapp private-config** command.



### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or higher releases.

### Examples

This example shows how to configure the controller IP address 10.92.109.1 into the FlexConnect access point:

```
> lwapp ap controller ip address 10.92.109.1
```

### Related Commands

**clear lwapp private-config**  
**debug lwapp console cli**

## config Commands

This section lists the **config** commands to configure access points.

## config 802.11-a antenna extAntGain

To configure the external antenna gain for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a antenna extAntGain** commands.

**config {802.11-a49 | 802.11-a58} antenna extAntGain *ant\_gain* *cisco\_ap* {global | *channel\_no*}**

### Syntax Description

<b>802.11-a49</b>	Specifies the 4.9-GHz public safety channel.
<b>802.11-a58</b>	Specifies the 5.8-GHz public safety channel.
<i>ant_gain</i>	Value in .5-dBi units (for instance, 2.5 dBi = 5).
<i>cisco_ap</i>	Name of the access point to which the command applies.
<b>global</b>	Specifies the antenna gain value to all channels.
<i>channel_no</i>	Antenna gain value for a specific channel.

### Command Default

Disabled.

### Usage Guidelines

Before you enter the **config 802.11-a antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11-a disable** command.

After you configure the external antenna gain, use the **config 802.11-a enable** command to reenable the 802.11 Cisco radio.

### Examples

This example shows how to configure an 802.11-a49 external antenna gain of 10 dBi for AP1:

```
> config 802.11-a antenna extAntGain 10 AP1
```

### Related Commands

**config 802.11-a**  
**config 802.11-a channel ap**  
**config 802.11-a txpower ap**  
**show 802.11a**



## config 802.11-a channel ap

To configure the channel properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a channel ap** command.

```
config {802.11-a49 | 802.11-a58} channel ap cisco_ap {global | channel_no}
```

Syntax Description		
<b>802.11-a49</b>		Specifies the 4.9-GHz public safety channel.
<b>802.11-a58</b>		Specifies the 5.8-GHz public safety channel.
<i>cisco_ap</i>		Name of the access point to which the command applies.
<b>global</b>		Enables the Dynamic Channel Assignment (DCA) on all 4.9-GHz and 5.8-GHz subband radios.
<i>channel_no</i>		Custom channel for a specific mesh access point. The range is 1 through 26, inclusive, for a 4.9-GHz band and 149 through 165, inclusive, for a 5.8-GHz band.

**Command Default** Disabled.

**Examples** This example shows how to set the channel properties:

```
> config 802.11-a channel ap
```

**Related Commands**

- config 802.11-a
- config 802.11-a antenna extAntGain
- config 802.11-a txpower ap

## config 802.11-a txpower ap

To configure the transmission power properties for the 4.9-GHz and 5.8-GHz public safety channels on an access point, use the **config 802.11-a txpower ap** command.

**config {802.11-a49 | 802.11-a58} txpower ap** *cisco\_ap* {**global** | *power\_level*}

<b>Syntax Description</b>	<b>802.11-a49</b>	Specifies the 4.9-GHz public safety channel.
	<b>802.11-a58</b>	Specifies the 5.8-GHz public safety channel.
	<b>txpower</b>	Configures transmission power properties.
	<b>ap</b>	Configures access point channel settings.
	<i>cisco_ap</i>	Name of the access point to which the command applies.
	<b>global</b>	Applies the transmission power value to all channels.
	<i>power_level</i>	Transmission power value to the designated mesh access point. The range is from 1 to 5.

**Command Default** Disabled.

**Examples** This example shows how to configure an 802.11-a49 transmission power level of 4 for AP1:

```
> config 802.11-a txpower ap 4 AP1
```

**Related Commands**

- config 802.11-a
- config 802.11 channel ap
- config 802.11 antenna extAntGain

## config 802.11 antenna diversity

To configure the diversity option for 802.11 antennas, use the **config 802.11 antenna diversity** command.

**config 802.11 {a | b} antenna diversity {enable | sideA | sideB} *cisco\_ap***

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>enable</b>	Enables the diversity.
<b>sideA</b>	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point left port.
<b>sideB</b>	Specifies the diversity between the internal antennas and an external antenna connected to the Cisco lightweight access point right port.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to enable antenna diversity for AP01 on an 802.11b network:

```
> config 802.11a antenna diversity enable AP01
```

This example shows how to enable diversity for AP01 on an 802.11a network, using an external antenna connected to the Cisco lightweight access point left port (sideA):

```
> config 802.11a antenna diversity sideA AP01
```

### Related Commands

**config 802.11 disable**  
**config 802.11 enable**  
**config 802.11 antenna extAntGain**  
**config 802.11 antenna mode**  
**config 802.11 antenna selection**  
**show 802.11a**  
**show 802.11b**

## config 802.11 antenna extAntGain

To configure external antenna gain for an 802.11 network, use the **config 802.11 antenna extAntGain** command.

**config 802.11 {a | b} antenna extAntGain** *antenna\_gain* *cisco\_ap*

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<i>antenna_gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Usage Guidelines

Before you enter the **config 802.11 antenna extAntGain** command, disable the 802.11 Cisco radio with the **config 802.11 disable** command.

After you configure the external antenna gain, use the **config 802.11 enable** command to enable the 802.11 Cisco radio.

### Examples

This example shows how to configure an *802.11a* external antenna gain of *0.5 dBm* for *AP1*:

```
> config 802.11 antenna extAntGain 1 AP1
```

### Related Commands

**config 802.11 disable**  
**config 802.11 enable**  
**config 802.11 antenna mode**  
**config 802.11 antenna selection**  
**show 802.11a**  
**show 802.11b**

## config 802.11 antenna mode

To configure the Cisco lightweight access point to use one internal antenna for an 802.11 sectorized 180-degree coverage pattern or both internal antennas for an 802.11 360-degree omnidirectional pattern, use the **config 802.11 antenna mode** command.

**config 802.11 {a | b} antenna mode {omni | sectorA | sectorB} *cisco\_ap***

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>omni</b>	Specifies to use both internal antennas.
<b>sectorA</b>	Specifies to use only the side A internal antenna.
<b>sectorB</b>	Specifies to use only the side B internal antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to configure access point AP01 antennas for a 360-degree omnidirectional pattern on an 802.11b network:

```
> config 802.11 antenna mode omni AP01
```

### Related Commands

**config 802.11 disable**  
**config 802.11 enable**  
**config 802.11 antenna extAntGain**  
**config 802.11 antenna diversity**  
**config 802.11 antenna selection**  
**show 802.11a**  
**show 802.11b**

## config 802.11 antenna selection

To select the internal or external antenna selection for a Cisco lightweight access point on an 802.11 network, use the **config 802.11 antenna selection** command.

**config 802.11 {a | b} antenna selection {internal | external} *cisco\_ap***

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>internal</b>	Specifies the internal antenna.
<b>external</b>	Specifies the external antenna.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to configure access point AP02 on an 802.11b network to use the internal antenna:

```
> config 802.11a antenna selection internal AP02
```

### Related Commands

**config 802.11 disable**  
**config 802.11 enable**  
**config 802.11 antenna extAntGain**  
**config 802.11 antenna mode**  
**config 802.11 antenna diversity**  
**show 802.11a**  
**show 802.11b**

## config 802.11 beamforming

To enable or disable beamforming on the network or on individual radios, enter the **config 802.11 beamforming** command.

**config 802.11 {a | b} beamforming {global | ap *ap\_name*} {enable | disable}**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Specifies all lightweight access points.
<b>ap <i>ap_name</i></b>	Specifies the Cisco access point name.
<b>enable</b>	Enables beamforming.
<b>disable</b>	Disables beamforming.

### Command Default

None.

### Usage Guidelines

When you enable beamforming on the network, it is automatically enabled for all the radios applicable to that network type.

Follow these guidelines for using beamforming:

- Beamforming is supported only for legacy orthogonal frequency-division multiplexing (OFDM) data rates (6, 9, 12, 18, 24, 36, 48, and 54 mbps).



#### Note

Beamforming is not supported for complementary-code keying (CCK) data rates (1, 2, 5.5, and 11 Mbps).

- Beamforming is supported only on access points that support 802.11n (AP1250 and AP1140).
- Two or more antennas must be enabled for transmission.
- All three antennas must be enabled for reception.
- OFDM rates must be enabled.

If the antenna configuration restricts operation to a single transmit antenna, or if OFDM rates are disabled, beamforming is not used.

**Examples**

This example shows how to enable beamforming on the 802.11a network:

```
> config 802.11 beamforming global enable
```

**Related Commands**

**show ap config {802.11a | 802.11b}**

**show 802.11a**

**config 802.11b beaconperiod**

**config 802.11a disable**

**config 802.11a enable**



## config 802.11 disable

To disable radio transmission for an entire 802.11 network or for an individual Cisco radio, use the **config 802.11 disable** command.

**config 802.11 {a | b} disable {network | cisco\_ap}**

### Syntax Description

<b>a</b>	Configures the 802.11a radio.
<b>b</b>	Specifies the 802.11b/g network.
<b>network</b>	Disables transmission for the entire 802.11a network.
<i>cisco_ap</i>	Individual Cisco lightweight access point radio.

### Command Default

The transmission is enabled for the entire network by default.

### Usage Guidelines



#### Note

You must use this command to disable the network before using many config 802.11 commands.

This command can be used any time that the CLI interface is active.

### Examples

This example shows how to disable the entire 802.11a network:

```
> config 802.11a disable network
```

This example shows how to disable access point AP01 802.11b transmissions:

```
> config 802.11b disable AP01
```

### Related Commands

**show sysinfo**  
**show 802.11a**  
**config 802.11a enable**  
**config 802.11b disable**  
**config 802.11b enable**  
**config 802.11a beaconperiod**

## config advanced 802.11 profile clients

To set the Cisco lightweight access point clients threshold between 1 and 75 clients, use the **config advanced 802.11 profile clients** command.

**config advanced 802.11 {a | b} profile clients {global | cisco\_ap} clients**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Configures all 802.11a Cisco lightweight access points.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>clients</i>	802.11a Cisco lightweight access point client threshold between 1 and 75 clients.

### Command Default

12 clients.

### Examples

This example shows how to set all Cisco lightweight access point clients thresholds to 25 clients:

```
> config advanced 802.11 profile clients global 25
Global client count profile set.
```

This example shows how to set the AP1 clients threshold to 75 clients:

```
> config advanced 802.11 profile clients AP1 75
Global client count profile set.
```

### Related Commands

**show advanced 802.11a profile**  
**config advanced 802.11b profile clients**

## config advanced 802.11 profile customize

To turn customizing on or off for an 802.11a Cisco lightweight access point performance profile, use the **config advanced 802.11 profile customize** command.

**config advanced 802.11 {a | b} profile customize** *cisco\_ap* {on | off}

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point.
<b>on</b>	Customizes performance profiles for this Cisco lightweight access point.
<b>off</b>	Uses global default performance profiles for this Cisco lightweight access point.

### Command Default

Off.

### Examples

This example shows how to turn performance profile customization on for 802.11a Cisco lightweight access point AP1:

```
> config advanced 802.11 profile customize AP1 on
```

### Related Commands

**show advanced 802.11 profile**  
**config advanced 802.11b profile customize**

## config advanced 802.11 profile foreign

To set the foreign 802.11a transmitter interference threshold between 0 and 100 percent, use the **config advanced 802.11 profile foreign** command.

**config advanced 802.11 {a | b} profile foreign {global | cisco\_ap} percent**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Configures all 802.11a Cisco lightweight access points.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a foreign 802.11a interference threshold between 0 and 100 percent.

### Command Default

10.

### Examples

This example shows how to set the foreign 802.11a transmitter interference threshold for all Cisco lightweight access points to 50 percent:

```
> config advanced 802.11a profile foreign global 50
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
> config advanced 802.11 profile foreign AP1 0
```

### Related Commands

**show advanced 802.11a profile**  
**config advanced 802.11b profile foreign**

## config advanced 802.11 profile noise

To set the 802.11a foreign noise threshold between -127 and 0 dBm, use the **config advanced 802.11 profile noise** command.

**config advanced 802.11 {a | b} profile noise {global | cisco\_ap} dBm**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>dBm</i>	802.11a foreign noise threshold between -127 and 0 dBm.

### Command Default

-70 dBm.

### Examples

This example shows how to set the 802.11a foreign noise threshold for all Cisco lightweight access points to -127 dBm:

```
> config advanced 802.11a profile noise global -127
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
> config advanced 802.11a profile noise AP1 0
```

### Related Commands

**show advanced 802.11 profile**  
**config advanced 802.11b profile noise**

## config advanced 802.11 profile throughput

To set the Cisco lightweight access point data-rate throughput threshold between 1000 and 10000000 bytes per second, use the **config advanced 802.11 profile throughput** command.

**config advanced 802.11 {a | b} profile throughput {global | cisco\_ap} value**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Configures all 802.11a Cisco lightweight access point specific profiles.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>value</i>	802.11a Cisco lightweight access point throughput threshold between 1000 and 10000000 bytes per second.

### Command Default

1,000,000 bytes per second.

### Examples

This example shows how to set all Cisco lightweight access point data-rate thresholds to 1000 bytes per second:

```
> config advanced 802.11 profile throughput global 1000
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
> config advanced 802.11 profile throughput AP1 10000000
```

### Related Commands

**show advanced 802.11 profile**  
**config advanced 802.11b profile data-rate**

## config advanced 802.11 profile utilization

To set the RF utilization threshold between 0 and 100 percent, use the **config advanced 802.11 profile utilization** command. The operating system generates a trap when this threshold is exceeded.

**config advanced 802.11 {a | b} profile utilization {global | *cisco\_ap*} percent**

### Syntax Description

<b>a</b>	Specifies the 802.11a network.
<b>b</b>	Specifies the 802.11b/g network.
<b>global</b>	Configures a global Cisco lightweight access point specific profile.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>percent</i>	802.11a RF utilization threshold between 0 and 100 percent.

### Command Default

80 percent.

### Examples

This example shows how to set the RF utilization threshold for all Cisco lightweight access points to 0 percent:

```
> config advanced 802.11 profile utilization global 0
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
> config advanced 802.11 profile utilization AP1 100
```

### Related Commands

**show advanced 802.11a profile**  
**config advanced 802.11b profile utilization**

## config advanced backup-controller primary

To configure a primary backup controller for a specific controller, use the **config advanced backup-controller primary** command.

**config advanced backup-controller primary** *backup\_controller\_name* *backup\_controller\_ip\_address*

### Syntax Description

<i>backup_controller_name</i>	Name of the backup controller.
<i>backup_controller_ip_address</i>	IP address of the backup controller.

### Command Default

None.

### Usage Guidelines

To delete a primary backup controller entry, enter 0.0.0.0 for the controller IP address.

### Examples

This example shows how to configure the primary backup controller:

```
> config advanced backup-controller primary Controller_1 10.10.10.10
```

### Related Commands

**show advanced backup-controller**



## config advanced backup-controller secondary

To configure a secondary backup controller for a specific controller, use the **config advanced backup-controller secondary** command.

**config advanced backup-controller secondary** *backup\_controller\_name backup\_controller\_ip\_address*

### Syntax Description

<i>backup_controller_name</i>	Name of the backup controller.
<i>backup_controller_ip_address</i>	IP address of the backup controller.

### Command Default

None.

### Usage Guidelines

To delete a secondary backup controller entry, enter 0.0.0.0 for the controller IP address.

### Examples

This example shows how to configure a secondary backup controller:

```
> config advanced backup-controller secondary Controller_1 10.10.10.10
```

### Related Commands

**show advanced backup-controller**

## config advanced client-handoff

To set the client handoff to occur after a selected number of 802.11 data packet excessive retries, use the **config advanced client-handoff** command.

**config advanced client-handoff** *num\_of\_retries*

### Syntax Description

<i>num_of_retries</i>	Number of excessive retries before client handoff (from 0 to 255).
-----------------------	--

### Command Default

0 excessive retries (disabled).

### Usage Guidelines

This command is supported only for the 1000/1510 series access points.

### Examples

This example shows how to set the client handoff to 100 excessive retries:

```
> config advanced client-handoff 100
```

### Related Commands

**show advanced client-handoff**

## config advanced dot11-padding

To enable or disable over-the-air frame padding, use the **config advanced dot11-padding** command.

**config advanced dot11-padding {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the over-the-air frame padding.
<b>disable</b>	Disables the over-the-air frame padding.

### Command Default

Disabled.

### Examples

This example shows how to enable over-the-air frame padding:

```
> config advanced dot11-padding enable
```

### Related Commands

**debug dot11**  
**debug dot11 mgmt interface**  
**debug dot11 mgmt msg**  
**debug dot11 mgmt ssid**  
**debug dot11 mgmt state-machine**  
**debug dot11 mgmt station**  
**show advanced dot11-padding**

## config advanced assoc-limit

To configure the rate at which access point radios send association and authentication requests to the controller, use the **config advanced assoc-limit** command.

**config advanced assoc-limit** {**enable** [*number of associations per interval* | *interval* ] | **disable**}

### Syntax Description

<b>enable</b>	Enables the configuration of the association requests per access point.
<b>disable</b>	Disables the configuration of the association requests per access point.
<i>number of associations per interval</i>	(Optional) Number of association request per access point slot in a given interval. The range is from 1 to 100.
<i>interval</i>	(Optional) Association request limit interval. The range is from 100 to 10000 milliseconds.

### Command Default

Disabled.

### Usage Guidelines

When 200 or more wireless clients try to associate to a controller at the same time, the clients no longer become stuck in the DHCP\_REQD state when you use the **config advanced assoc-limit** command to limit association requests from access points.

### Examples

This example shows how to configure the number of association requests per access point slot in a given interval of 20 with the association request limit interval of 250:

```
> config advanced assoc-limit enable 20 250
```

## config advanced max-1x-sessions

To configure the maximum number of simultaneous 802.1X sessions allowed per access point, use the **config advanced max-1x-sessions** command.

**config advanced max-1x-sessions** *no\_of\_sessions*

---

### Syntax Description

<i>no_of_sessions</i>	Number of maximum 802.1x session initiation per AP at a time. The range is from 0 to 255, where 0 indicates unlimited.
-----------------------	--

---

### Command Default

None.

### Examples

This example shows how to configure the maximum number of simultaneous 802.1X sessions:

```
> config advanced max-1x-sessions 200
```

## config advanced rate

To enable or disable switch control path rate limiting, use the **config advanced rate** command.

**config advanced rate {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the switch control path rate limiting feature.
<b>disable</b>	Disables the switch control path rate limiting feature.

### Command Default

None.

### Examples

This example shows how to enable switch control path rate limiting:

```
> config advanced rate enable
```

## config advanced probe filter

To enable or disable the filtering of probe requests forwarded from an access point to the controller, use the **config advanced probe filter** command.

**config advanced probe filter {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the filtering of probe requests.
<b>disable</b>	Disables the filtering of probe requests.

### Command Default

None.

### Examples

This example shows how to enable the filtering of probe requests forwarded from an access point to the controller:

```
> config advanced probe filter enable
```

### Related Commands

**config advanced probe limit**  
**config radius acct ipsec authentication**  
**show advanced probe**  
**show radius acct statistics**

## config advanced probe limit

To limit the number of probes sent to the WLAN controller per access point per client in a given interval, use the **config advanced probe limit** command.

**config advanced probe limit** *num\_probes interval*

### Syntax Description

<i>num_probes</i>	Number of probe requests (from 1 to 100) forwarded to the controller per client per access point radio in a given interval.
<i>interval</i>	Probe limit interval (from 100 to 10000 milliseconds).

### Command Default

The default number of probe requests is 2. The default interval is 500 milliseconds.

### Examples

This example shows how to set the number of probes per access point per client to 5 and the probe interval to 800 milliseconds:

```
> config advanced probe limit 5 800
```

### Related Commands

**config radius acct ipsec authentication**  
**show advanced probe**  
**show radius acct statistics**



## config advanced timers

To configure a system timer, use the **config advanced timers** command.

```
config advanced timers {ap-discovery-timeout discovery-timeout | ap-fast-heartbeat {local | flexconnect
| all} {enable | disable} fast_heartbeat_seconds | ap-heartbeat-timeout heartbeat_seconds |
ap-primary-discovery-timeout primary_discovery_timeout | ap-primed-join-timeout primed_join_timeout
| auth-timeout auth_timeout | pkt-fwd-watchdog {enable | disable} {watchdog_timer | default} |
eap-identity-request-delay eap_identity_request_delay | eap-timeout eap_timeout}
```

### Syntax Description

<b>ap-discovery-timeout</b>	Configures Cisco lightweight access point discovery timeout value.
<i>discovery-timeout</i>	Cisco lightweight access point discovery timeout value. The range is from 1 to 10 seconds.
<b>ap-fast-heartbeat</b>	Configures the fast heartbeat timer, which reduces the amount of time it takes to detect a controller failure in access points.
<b>local</b>	Configures the fast heartbeat interval for access points in local mode only.
<b>flexconnect</b>	Configures the fast heartbeat interval for access points in FlexConnect mode only.
<b>all</b>	Configures the fast heartbeat interval for all the access points.
<b>enable</b>	Enables the fast heartbeat interval.
<b>disable</b>	Disables the fast heartbeat interval.
<i>fast_heartbeat_seconds</i>	Small heartbeat interval, which reduces the amount of time it takes to detect a controller failure. The range is from 1 to 10 seconds.
<b>ap-heartbeat-timeout</b>	Configures Cisco lightweight access point heartbeat timeout value.
<i>heartbeat_seconds</i>	Cisco lightweight access point heartbeat timeout value. The range is from 1 to 30 seconds. This value should be at least three times larger than the fast heartbeat timer.
<b>ap-primary-discovery-timeout</b>	Configures the access point primary discovery request timer.
<i>primary_discovery_timeout</i>	Access point primary discovery request timer. The range is from 30 to 3600 seconds.
<b>ap-primed-join-timeout</b>	Configures AP primed discovery timeout value.
<i>primed_join_timeout</i>	Access point primed discovery timeout value. The range is from 120 to 43200 seconds.
<b>auth-timeout</b>	Configures the authentication timeout.

<i>auth_timeout</i>	Authentication response timeout value, in seconds, from 10 to 600.
<b>pkt-fwd-watchdog</b>	Configures the packet forwarding watchdog timer to protect from fastpath deadlock.
<i>watchdog_timer</i>	Packet forwarding watchdog timer, in seconds. The range is from 60 to 300.
<b>default</b>	Configures the watchdog timer to the default value of 240 seconds.
<b>eap-identity-request-delay</b>	Configures the advanced Extensible Authentication Protocol (EAP) identity request delay, in seconds.
<i>eap_identity_request_delay</i>	Advanced EAP identity request delay, in seconds. The range is from 0 to 10.
<b>eap-timeout</b>	Configures the EAP expiration timeout.
<i>eap_timeout</i>	EAP timeout value, in seconds. The range is from 8 to 120.

**Command Default**

The default access point discovery timeout is 10 seconds.  
 The default access point heartbeat timeout is 30 seconds.  
 The default access point primary discovery request timer is 120 seconds.  
 The default authentication timeout is 10 seconds.  
 The default packet forwarding watchdog timer is 240 seconds.

**Usage Guidelines**

The Cisco lightweight access point discovery timeout indicates how often a Cisco WLC attempts to discover unconnected Cisco lightweight access points.  
 The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keepalive signal to the Cisco WLC.

**Examples**

The following example shows how to configure an access point discovery timeout with a timeout value of 20:

```
Device > config advanced timers ap-discovery-timeout 20
```

The following example shows how to enable the fast heartbeat interval for an access point in FlexConnect mode:

```
Device > config advanced timers ap-fast-heartbeat flexconnect enable 8
```

The following example shows how to configure the authentication timeout to 20 seconds:

```
Device > config advanced timers auth-timeout 20
```

**Related Commands**    show advanced timers

## config ap

To enable or disable a Cisco lightweight access point or to add or delete a third-party (foreign) access point, use the **config ap** command.

**config ap** {{enable | disable} *cisco\_ap* | {add | delete} *MAC port* {enable | disable} *IP\_address*}

### Syntax Description

<b>enable</b>	Enables the Cisco lightweight access point.
<b>disable</b>	Disables the Cisco lightweight access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
<b>add</b>	Adds foreign access points.
<b>delete</b>	Deletes foreign access points.
<i>MAC</i>	MAC address of a foreign access point.
<i>port</i>	Port number through which the foreign access point can be reached.
<i>IP_address</i>	IP address of the foreign access point.

### Command Default

None.

### Examples

This example shows how to disable lightweight access point AP1:

```
> config ap disable AP1
```

This example shows how to add a foreign access point with MAC address 12:12:12:12:12:12 and IP address 192.12.12.1 from port 2033:

```
> config ap add 12:12:12:12:12:12 2033 enable 192.12.12.1
```

### Related Commands

**show ap**

## config ap autoconvert

To automatically convert all access points to a FlexConnect mode or monitor mode upon joining the Cisco WLC, use the **config ap autoconvert** command.

**config ap autoconvert {flexconnect | monitor | disable}**

### Syntax Description

<b>flexconnect</b>	Configures all the access points automatically to FlexConnect mode.
<b>monitor</b>	Configures all the access points automatically to monitor mode.
<b>disable</b>	Disables the autoconvert option on the access points.

### Command Default

None.

### Usage Guidelines

When access points in local mode connect to a Cisco 7500 Series Wireless Controller, they do not serve clients. The access point details are available in the controller. To enable access points to serve clients or perform monitoring related tasks when connected to the Cisco 7500 Series Wireless Controller, the access points must be in FlexConnect mode or monitor mode.

### Examples

This example shows how to automatically convert all access points to the FlexConnect mode:

```
> config ap autoconvert flexconnect
```

This example shows how to disable the autoconvert option on the APs:

```
> config ap autoconvert disable
```

### Related Commands

**config ap**  
**show ap**

## config ap bhrate

To configure the Cisco bridge backhaul Tx rate, use the **config ap bhrate** command.

**config ap bhrate** {*rate* | **auto**} *cisco\_ap*

### Syntax Description

<i>rate</i>	Cisco bridge backhaul Tx rate in kbps. The valid values are 6000, 12000, 18000, 24000, 36000, 48000, and 54000.
<b>auto</b>	Configures the auto data rate.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

### Command Default

Auto.

### Usage Guidelines

In previous software releases, the default value for the bridge data rate was 24000 (24 Mbps). In controller software release 6.0, the default value for the bridge data rate is **auto**. If you configured the default bridge data rate value (24000) in a previous controller software release, the bridge data rate is configured with the new default value (auto) when you upgrade to controller software release 6.0. However, if you configured a non default value (for example, 18000) in a previous controller software release, that configuration setting is preserved when you upgrade to Cisco WLC Release 6.0.

When the bridge data rate is set to **auto**, the mesh backhaul chooses the highest rate where the next higher rate cannot be used due to unsuitable conditions for that specific rate (and not because of conditions that affect all rates).

### Examples

This example shows how to configure the Cisco bridge backhaul Tx rate to 54000 kbps:

```
> config ap bhrate 54000 AP01
```

### Related Commands

**config ap**

## config ap bridgegroupname

To set or delete a bridge group name on a Cisco lightweight access point, use the **config ap bridgegroupname** command.

**config ap bridgegroupname** {set *groupname* | delete} *cisco\_ap*

### Syntax Description

<b>set</b>	Sets a Cisco lightweight access point's bridge group name.
<i>groupname</i>	Bridge group name.
<b>delete</b>	Deletes a Cisco lightweight access point's bridge group name.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

### Command Default

None.

### Usage Guidelines

Only access points with the same bridge group name can connect to each other. Changing the AP bridgegroupname may strand the bridge AP.

### Examples

This example shows how to delete a bridge group name on Cisco access point's bridge group name AP02:

```
> config ap bridgegroupname delete AP02
Changing the AP's bridgegroupname may strand the bridge AP. Please continue with caution.
Changing the AP's bridgegroupname will also cause the AP to reboot.
Are you sure you want to continue? (y/n)
```

### Related Commands

**config ap**

## config ap bridging

To enable or disable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **config ap bridging** command.

**config ap bridging** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the Ethernet-to-Ethernet bridging on a Cisco lightweight access point.
<b>disable</b>	Disables Ethernet-to-Ethernet bridging.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to enable bridging on an access point:

```
> config ap bridging enable nyc04-44-1240
```

This example shows how to disable bridging on an access point:

```
> config ap bridging disable nyc04-44-1240
```

### Related Commands

**config ap**



## config ap cdp

To enable or disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **config ap cdp** command.

**config ap cdp** {enable | disable | interface {ethernet *interface\_number* | slot *slot\_id*} } {*cisco\_ap* | all}

### Syntax Description

<b>enable</b>	Enables CDP on an access point.
<b>disable</b>	Disables CDP on an access point.
<b>interface</b>	Configures CDP in a specific interface.
<b>ethernet</b>	Configures CDP for an ethernet interface.
<i>interface_number</i>	Ethernet interface number between 0 and 3.
<b>slot</b>	Configures CDP for a radio interface.
<i>slot_id</i>	Slot number between 0 and 3.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>all</b>	Specifies all access points.



#### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

Enabled on radio interfaces of mesh APs and disabled on radio interfaces of non-mesh APs. Enabled on Ethernet interfaces of all APs.

### Usage Guidelines

The **config ap cdp disable all** command disables CDP on all access points that are joined to the controller and all access points that join in the future. CDP remains disabled on both current and future access points even after the controller or access point reboots. To enable CDP, enter the **config ap cdp enable all** command.



#### Note

CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points joined to the controller, you may disable and then reenabling CDP on individual access points using the **config ap cdp {enable | disable} cisco\_ap command**. After you disable CDP on all access points joined to the controller, you may not enable and then disable CDP on individual access points.

**Examples**

This example shows how to enable CDP on all access points:

```
> config ap cdp enable all
```

This example shows how to disable CDP on ap02 access point:

```
> config ap cdp disable ap02
```

This example shows how to enable CDP for Ethernet interface number 2 on all access points:

```
> config ap cdp ethernet 2 enable all
```

**Related Commands**

**config cdp timer**

**show ap cdp**

## config ap core-dump

To configure a Cisco lightweight access point's memory core dump, use the **config ap core-dump** command.

**config ap core-dump** {**disable** | **enable** *tftp\_server\_ipaddress filename* {**compress** | **uncompress**} {*cisco\_ap* | **all**}

### Syntax Description

<b>enable</b>	Enables the Cisco lightweight access point's memory core dump setting.
<b>disable</b>	Disables the Cisco lightweight access point's memory core dump setting.
<i>tftp_server_ipaddress</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point uses to label the core file.
<b>compress</b>	Compresses the core dump file.
<b>uncompress</b>	Uncompresses the core dump file.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>all</b>	Specifies all access points.



### Note

If an AP itself is configured with the name 'all', then the 'all access points' case takes precedence over the AP that is named 'all'.

### Command Default

None.

### Usage Guidelines

The access point must be able to reach the TFTP server.

### Examples

This example shows how to configure and compress the core dump file:

```
> config ap core-dump enable 192.1.1.1 log compress AP02
```

### Related Commands

**config ap crash-file clear-all**  
**config ap crash-file delete**  
**config ap crash-file get-crash-file**  
**config ap crash-file get-radio-core-dump**  
**config ap port**

## config ap crash-file clear-all

To delete all crash and radio core dump files, use the **config ap crash-file clear-all** command.

**config ap crash-file clear-all**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to delete all crash files:

```
> config ap crash-file clear-all
```

**Related Commands**

- config ap core-dump**
- config ap crash-file delete**
- config ap crash-file get-crash-file**
- config ap crash-file get-radio-core-dump**
- config ap port**

## config ap crash-file delete

To delete a single crash or radio core dump file, use the **config ap crash-file delete** command.

**config ap crash-file delete** *filename*

Syntax Description	
	<i>filename</i> Name of the file to delete.

Command Default	
	None.

Examples	
	This example shows how to delete crash file 1:  > config ap crash-file delete crash_file_1

Related Commands	
	config ap crash-file clear-all config ap crash-file core-dump config ap crash-file get-crash-file config ap crash-file get-radio-core-dump config ap port

## config ap crash-file get-crash-file

To collect the latest crash data for a Cisco lightweight access point, use the **config ap crash-file get-crash-file** command.

**config ap crash-file get-crash-file** *cisco\_ap*

### Syntax Description

<i>cisco_ap</i>	Name of the Cisco lightweight access point.
-----------------	---

### Command Default

None.

### Usage Guidelines

Use the **transfer upload datatype** command to transfer the collected data to the Cisco wireless LAN controller.

### Examples

This example shows how to collect the latest crash data for access point AP3:

```
> config ap crash-file get-crash-file AP3
```

### Related Commands

**config ap crash-file core-dump**  
**config ap crash-file crash-file delete**  
**config ap crash-file clear-all**  
**config ap crash-file get-radio-core-dump**  
**config ap port**

## config ap crash-file get-radio-core-dump

To get a Cisco lightweight access point's radio core dump, use the **config ap crash-file get-radio-core-dump** command.

**config ap crash-file get-radio-core-dump** *slot\_id* *cisco\_ap*

### Syntax Description

<i>slot_id</i>	Slot ID (either 0 or 1).
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to collect the radio core dump for access point AP02 and slot 0:

```
> config ap crash-file get-radio-core-dump 0 AP02
```

### Related Commands

**config ap crash-file clear-all**  
**config ap crash-file delete**  
**config ap crash-file get-crash-file**  
**config ap crash-file core-dump**  
**config ap port**

## config ap dot1xuser

To configure the global authentication username and password for all access points currently joined to the controller as well as any access points that join the controller in the future, use the **config ap dot1xuser** command.

**config ap dot1xuser add username** *user* **password** *password* {**all** | *cisco\_ap*}

### Syntax Description

<b>add username</b>	Specifies to add a username.
<i>user</i>	Username.
<b>password</b>	Specifies to add a password.
<i>password</i>	Password.
<i>cisco_ap</i>	Specific access point.
<b>all</b>	Specifies all access points.

### Command Default

None.

### Usage Guidelines

You must enter a strong *password*. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not a word in any language.

You can set the values for a specific access point.

### Examples

This example shows how to configure the global authentication username and password for all access points:

```
> config ap dot1xuser add username cisco123 password cisco2020 all
```

### Related Commands

**config ap dot1xuser delete**  
**config ap dot1xuser disable**  
**show ap summary**



## config ap dot1xuser delete

To force a specific access point to use the controller's global authentication settings, use the **config ap dot1xuser delete** command.

**config ap dot1xuser delete** *cisco\_ap*

### Syntax Description

<i>cisco_ap</i>	Access point.
-----------------	---------------

### Command Default

None.

### Examples

This example shows how to delete access point AP01 to use the controller's global authentication settings:

```
> config ap dot1xuser delete AP01
```

### Related Commands

**config ap dot1xuser**  
**config ap dot1xuser disable**  
**show ap summary**

## config ap dot1xuser disable

To disable authentication for all access points or for a specific access point, use the **config ap dot1xuser disable** command.

**config ap dot1xuser disable** {all | *cisco\_ap*}

### Syntax Description

<b>disable</b>	Disables authentication.
<b>all</b>	Specifies all access points.
<i>cisco_ap</i>	Access point.

### Command Default

None.

### Usage Guidelines

You can disable 802.1X authentication for a specific access point only if global 802.1X authentication is not enabled. If global 802.1X authentication is enabled, you can disable 802.1X for all access points only.

### Examples

This example shows how to disable the authentication for access point *cisco\_ap1*:

```
> config ap dot1xuser disable
```

### Related Commands

**config ap dot1xuser delete**  
**config ap dot1xuser**  
**show ap summary**

## config ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **config ap ethernet duplex** command.

**config ap ethernet duplex** [**auto** | **half** | **full**] **speed** [**auto** | **10** | **100** | **1000**] { **all** | *cisco\_ap* }

### Syntax Description

<b>auto</b>	(Optional) Specifies the Ethernet port duplex auto settings.
<b>half</b>	(Optional) Specifies the Ethernet port duplex half settings.
<b>full</b>	(Optional) Specifies the Ethernet port duplex full settings.
<b>speed</b>	Specifies the Ethernet port speed settings.
<b>auto</b>	(Optional) Specifies the Ethernet port speed to auto.
<b>10</b>	(Optional) Specifies the Ethernet port speed to 10 Mbps.
<b>100</b>	(Optional) Specifies the Ethernet port speed to 100 Mbps.
<b>1000</b>	(Optional) Specifies the Ethernet port speed to 1000 Mbps.
<b>all</b>	Specifies the Ethernet port setting for all connected access points.
<i>cisco_ap</i>	Cisco access point.

### Command Default

None.

### Examples

This example shows how to configure the Ethernet port duplex half settings as 10 Mbps for all access points:

```
> config ap ethernet duplex half speed 10 all
```

### Related Commands

**config ap ethernet**  
**config ap ethernet tag**  
**config ap**  
**show ap summary**

## config ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **config ap ethernet duplex** command.

**config ap ethernet duplex** [**auto** | **half** | **full**] **speed** [**auto** | **10** | **100** | **1000**] { **all** | *cisco\_ap* }

### Syntax Description

<b>auto</b>	(Optional) Specifies the Ethernet port duplex auto settings.
<b>half</b>	(Optional) Specifies the Ethernet port duplex half settings.
<b>full</b>	(Optional) Specifies the Ethernet port duplex full settings.
<b>speed</b>	Specifies the Ethernet port speed settings.
<b>auto</b>	(Optional) Specifies the Ethernet port speed to auto.
<b>10</b>	(Optional) Specifies the Ethernet port speed to 10 Mbps.
<b>100</b>	(Optional) Specifies the Ethernet port speed to 100 Mbps.
<b>1000</b>	(Optional) Specifies the Ethernet port speed to 1000 Mbps.
<b>all</b>	Specifies the Ethernet port setting for all connected access points.
<i>cisco_ap</i>	Cisco access point.

### Command Default

None.

### Examples

This example shows how to configure the Ethernet port duplex half settings as 10 Mbps for all access points:

```
> config ap ethernet duplex half speed 10 all
```

### Related Commands

**config ap ethernet**  
**config ap ethernet tag**  
**config ap**  
**show ap summary**

## config ap ethernet tag

To configure VLAN tagging of the Control and Provisioning of Wireless Access Points protocol (CAPWAP) packets, use the **config ap ethernet tag** command.

**config ap ethernet tag** {*id* *vlan\_id* | **disable**} {*cisco\_ap* | **all**}

Syntax Description		
<b>id</b>		Specifies the VLAN id.
<i>vlan_id</i>		ID of the trunk VLAN.
<b>disable</b>		Disables the VLAN tag feature. When you disable VLAN tagging, the access point untags the CAPWAP packets.
<i>cisco_ap</i>		Name of the Cisco AP.
<b>all</b>		Configures VLAN tagging on all the Cisco access points.

**Command Default** None.

**Usage Guidelines**

After you configure VLAN tagging, the configuration comes into effect only after the access point reboots. You cannot configure VLAN tagging on mesh access points.

If the access point is unable to route traffic or reach the controller using the specified trunk VLAN, it falls back to the untagged configuration. If the access point joins the controller using this fallback configuration, the controller sends a trap to a trap server such as the WCS, which indicates the failure of the trunk VLAN. In this scenario, the "Failover to untagged" message appears in show command output.

**Examples** This example shows how to configure VLAN tagging on a trunk VLAN:

```
> config ap ethernet tag 6 AP1
```

**Related Commands**

- config ap ethernet**
- config ap ethernet duplex**
- show ap ethernet tag**
- show ap config general**

## config ap group-name

To specify a descriptive group name for a Cisco lightweight access point, use the **config ap group-name** command.

**config ap group-name** *groupname* *cisco\_ap*

### Syntax Description

<i>groupname</i>	Descriptive name for the access point group.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

### Examples

This example shows how to configure a descriptive name for access point AP01:

```
> config ap group-name superusers AP01
```

### Related Commands

**config ap group-name**  
**config wlan apgroup**  
**show ap summary**  
**show ap wlan**

## config ap hotspot

To configure HotSpot parameters on an access point, use the **config ap hotspot** command.

**config ap hotspot venue** {**type** *group\_code type\_code* | **name** {**add** *language\_code venue\_name* | **delete**}}  
*cisco\_ap*

### Syntax Description

<b>venue</b>	Configures venue information for given AP group.
<b>type</b>	Configures the type of venue for given AP group.
<i>group_code</i>	<p>Venue group information for given AP group.</p> <p>The following options are available:</p> <ul style="list-style-type: none"><li>• 0—UNSPECIFIED</li><li>• 1—ASSEMBLY</li><li>• 2—BUSINESS</li><li>• 3—EDUCATIONAL</li><li>• 4—FACTORY-INDUSTRIAL</li><li>• 5—INSTITUTIONAL</li><li>• 6—MERCANTILE</li><li>• 7—RESIDENTIAL</li><li>• 8—STORAGE</li><li>• 9—UTILITY-MISC</li><li>• 10—VEHICULAR</li><li>• 11—OUTDOOR</li></ul>

---

*type\_code*



Venue type information for the AP group.

For venue group 1 (ASSEMBLY), the following options are available:

- 0—UNSPECIFIED ASSEMBLY
- 1—ARENA
- 2—STADIUM
- 3—PASSENGER TERMINAL
- 4—AMPHITHEATER
- 5—AMUSEMENT PARK
- 6—PLACE OF WORSHIP
- 7—CONVENTION CENTER
- 8—LIBRARY
- 9—MUSEUM
- 10—RESTAURANT
- 11—THEATER
- 12—BAR
- 13—COFFEE SHOP
- 14—ZOO OR AQUARIUM
- 15—EMERGENCY COORDINATION CENTER

For venue group 2 (BUSINESS), the following options are available:

- 0—UNSPECIFIED BUSINESS
- 1—DOCTOR OR DENTIST OFFICE
- 2—BANK
- 3—FIRE STATION
- 4—POLICE STATION
- 6—POST OFFICE
- 7—PROFESSIONAL OFFICE
- 8—RESEARCH AND DEVELOPMENT FACILITY
- 9—ATTORNEY OFFICE

For venue group 3 (EDUCATIONAL), the following options are available:

- 0—UNSPECIFIED EDUCATIONAL
- 1—PRIMARY SCHOOL
- 2—SECONDARY SCHOOL

- 3—UNIVERSITY OR COLLEGE

For venue group 4 (FACTORY-INDUSTRIAL), the following options are available:

- 0—UNSPECIFIED FACTORY AND INDUSTRIAL
- 1—FACTORY

For venue group 5 (INSTITUTIONAL), the following options are available:

- 0—UNSPECIFIED INSTITUTIONAL
  - 1—HOSPITAL
  - 2—LONG-TERM CARE FACILITY
  - 3—ALCOHOL AND DRUG RE-HABILITATION CENTER
  - 4—GROUP HOME
  - 5 :PRISON OR JAIL
-

---

*type\_code*

For venue group 6 (MERCANTILE), the following options are available:

- 0—UNSPECIFIED MERCANTILE
- 1—RETAIL STORE
- 2—GROCERY MARKET
- 3—AUTOMOTIVE SERVICE STATION
- 4—SHOPPING MALL
- 5—GAS STATION

For venue group 7 (RESIDENTIAL), the following options are available:

- 0—UNSPECIFIED RESIDENTIAL
- 1—PRIVATE RESIDENCE
- 2—HOTEL OR MOTEL
- 3—DORMITORY
- 4—BOARDING HOUSE

For venue group 8 (STORAGE), the option is:

- 0—UNSPECIFIED STORAGE

For venue group 9 (UTILITY-MISC), the option is:

- 0—UNSPECIFIED UTILITY AND MISCELLANEOUS

For venue group 10 (VEHICULAR), the following options are available:

- 0—UNSPECIFIED VEHICULAR
- 1—AUTOMOBILE OR TRUCK
- 2—AIRPLANE
- 3—BUS
- 4—FERRY
- 5—SHIP OR BOAT
- 6—TRAIN
- 7—MOTOR BIKE

For venue group 11 (OUTDOOR), the following options are available:

- 0—UNSPECIFIED OUTDOOR
- 1—MINI-MESH NETWORK
- 2—CITY PARK
- 3—REST AREA

- 4—TRAFFIC CONTROL
- 5—BUS STOP
- 6—KIOSK

<b>name</b>	Configures the name of venue for this access point.
<i>language_code</i>	ISO-639 encoded string defining the language used at the venue. This string is a three-character language code. For example, you can enter ENG for English.
<i>venue_name</i>	Venue name for this access point. This name is associated with the basic service set (BSS) and is used in cases where the SSID does not provide enough information about the venue. The venue name is case sensitive and can be up to 252 alphanumeric characters.
<b>add</b>	Adds the HotSpot venue name for this access point.
<b>delete</b>	Deletes the HotSpot venue name for this access point.
<i>cisco_ap</i>	Name of the Cisco access point.

### Examples

This example shows how to configure the venue group as educational and venue type as university:

```
> config ap hotspot venue type 3 3
```

### Related Commands

```
show wlan
debug hotspot events
debug hotspot packets
config wlan apgroup hotspot venue
config wlan apgroup hotspot operating-class
config wlan hotspot
config advanced hotspot
show advanced hotspot
config wlan security wpa gtk-random
```

## config ap image predownload

To configure an image on a specified access point, use the **config ap image predownload** command.

**config ap image predownload** {**abort** | **primary** | **backup**} {*cisco\_ap* | **all**}

### Syntax Description

<b>abort</b>	Aborts the predownload image process.
<b>primary</b>	Predownloads an image to a Cisco access point from the controller's primary image.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>all</b>	Specifies all access points to predownload an image.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

### Examples

This example shows how to predownload an image to an access point from the primary image:

```
> config ap image predownload primary all
```

### Related Commands

**config ap image swap**  
**show ap image**

## config ap image swap

To swap an access point's primary and backup images, use the **config ap image swap** command.

**config ap image swap** {*cisco\_ap* | **all**}

### Syntax Description

<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>all</b>	Specifies all access points to interchange the boot images.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

### Examples

This example shows how to swap an access point's primary and secondary images:

```
> config ap image swap all
```

### Related Commands

**config ap image predownload**  
**show ap image**

## config ap led-state

To enable or disable the LED state for an access point or to configure the flashing of LEDs, use the **config ap led-state** command.

**config ap led-state** {**enable** | **disable**} {*cisco\_ap* | **all**}

**config ap led-state flash** {*seconds* | **indefinite** | **disable**} {*cisco\_ap* | **dual-band**}

### Syntax Description

<b>enable</b>	Enables the access point's LED state.
<b>disable</b>	Disables the access point's LED state.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>flash</b>	Configure the flashing of LEDs for an access point.
<i>seconds</i>	Duration that the LEDs have to flash. The range is from 1 to 3600 seconds.
<b>indefinite</b>	Configures indefinite flashing of the access point's LED.
<b>dual-band</b>	Configures the LED state for all dual-band access points.

### Usage Guidelines

#### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

LEDs on access points with dual-band radio module will flash green and blue when you execute the led state flash command.

### Command Default

None.

### Examples

This example shows how to enable the LED state for an access point:

```
> config ap led-state enable AP02
```

This example shows how to enable the flashing of LEDs for dual-band access points:

```
> config ap led-state flash 20 dual-band
```

### Related Commands

**config ap**



## config ap link-encryption

To enable or disable the Datagram Transport Layer Security (DTLS) data encryption for access points on the 5500 series controller, use the **config ap link-encryption** command.

**Note**

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

**config ap link-encryption** {enable | disable} {cisco\_ap | all}

**Syntax Description**

<b>enable</b>	Enables the DTLS data encryption for access points.
<b>disable</b>	Disables the DTLS data encryption for access points.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.
<b>all</b>	Specifies all access points.

**Command Default**

DTLS data encryption is enabled automatically for OfficeExtend access points but disabled by default for all other access points.

**Usage Guidelines**

Only Cisco 5500 Series Controllers support DTLS data encryption. This feature is not available on other controller platforms. If an access point with data encryption enabled tries to join any other controller, the access point joins the controller, but data packets are sent unencrypted.

Only Cisco 1130, 1140, 1240, and 1250 series access points support DTLS data encryption, and data-encrypted access points can join a Cisco 5500 Series Controller only if the wplus license is installed on the controller. If the wplus license is not installed, the access points cannot join the controller.

**Examples**

This example shows how to enable the data encryption for an access point:

```
> config ap link-encryption enable AP02
```

**Related Commands**

**config ap**  
**show dtls connections**

## config ap link-latency

To enable or disable link latency for a specific access point or for all access points currently associated to the controller, use the **config ap link-latency** command:



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

**config ap link-latency** {**enable** | **disable** | **reset**} {*cisco\_ap* | **all**}

### Syntax Description

<b>enable</b>	Enables the link latency for an access point.
<b>disable</b>	Disables the link latency for an access point.
<b>reset</b>	Resets all link latency for all access points.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
<b>all</b>	Specifies all access points.

### Command Default

Link latency is disabled by default.

### Usage Guidelines

This command enables or disables link latency only for access points that are currently joined to the controller. It does not apply to access points that join in the future.

### Examples

This example shows how to enable the link latency for all access points:

```
> config ap link-latency enable all
```

### Related Commands

**show ap config**

## config ap location

To modify the descriptive location of a Cisco lightweight access point, use the **config ap location** command.

**config ap location** *location cisco\_ap*

### Syntax Description

<i>location</i>	Location name of the access point (enclosed by double quotation marks).
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

### Examples

This example shows how to configure the descriptive location for access point AP1:

```
> config ap location "Building 1" AP1
```

### Related Commands

**show ap summary**

## config ap logging syslog level

To set the severity level for filtering syslog messages for a particular access point or for all access points, use the **config ap logging syslog level** command.

**config ap logging syslog level** *severity\_level* {*cisco\_ap* | **all**}

### Syntax Description

*severity\_level*

Severity levels are as follows:

- emergencies—Severity level 0
- alerts—Severity level 1
- critical—Severity level 2
- errors—Severity level 3
- warnings—Severity level 4
- notifications—Severity level 5
- informational—Severity level 6
- debugging—Severity level 7

*cisco\_ap*

Cisco access point.

**all**

Specifies all access points.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

### Usage Guidelines

If you set a syslog level, only those messages whose severity is equal to or less than that level are sent to the access point. For example, if you set the syslog level to Warnings (severity level 4), only those messages whose severity is between 0 and 4 are sent to the access point.

### Examples

This example shows how to set the severity for filtering syslog messages to 3:

```
> config ap logging syslog level 3
```

### Related Commands

**config logging syslog host**

**config logging syslog facility**

**show logging**

## config ap mgmtuser add

To configure username, password, and secret password for AP management, use the **config ap mgmtuser add** command.

**config ap mgmtuser add username** *AP\_username* **password** *AP\_password* **secret** *secret* {**all** | *cisco\_ap*}

### Syntax Description

<b>username</b>	Configures the username for AP management.
<i>AP_username</i>	Management username.
<b>password</b>	Configures the password for AP management.
<i>AP_password</i>	AP management password.
<b>secret</b>	Configures the secret password for privileged AP management.
<i>secret</i>	AP managemetn secret password.
<b>all</b>	Applies configuration to every AP that does not have a specific username.
<i>cisco_ap</i>	Cisco access point.

### Command Default

None.

### Usage Guidelines

The following requirements are enforced on the password:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.
- No character in the password can be repeated more than three times consecutively.
- The password should not contain management username or reverse of username.
- The password should not contain words like Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting 1, |, or ! or substituting 0 for o or substituting \$ for s.

The following requirement is enforced on the secret password:

- The secret password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

### Examples

This example shows how to add a username, password, and secret password for AP management:

```
> config ap mgmtuser add username acd password Arc_1234 secret Mid_45 all
```

**Related Commands**    config ap mgmtuser delete

## config ap mgmtuser delete

To force a specific access point to use the controller's global credentials, use the **config ap mgmtuser delete** command.

**config ap mgmtuser delete** *cisco\_ap*

### Syntax Description

<i>cisco_ap</i>	Access point.
-----------------	---------------

### Command Default

None.

### Examples

This example shows how to delete the credentials of an access point:

```
> config ap mgmtuser delete cisco_ap1
```

### Related Commands

**show ap summary**



## config ap mode

To change a Cisco WLC communication option for an individual Cisco lightweight access point, use the **config ap mode** command.

**config ap mode** {**bridge** | **flexconnect** {**submode** {**none** | **wips**} | **local** {**submode** {**none** | **wips**} | **reap** | **rogue** | **sniffer** | **se-connect** | **monitor** {**submode** {**none** | **wips**} } } *cisco\_ap*

### Syntax Description

<b>bridge</b>	Converts from a lightweight access point to a mesh access point (bridge mode).
<b>flexconnect</b>	Enables FlexConnect mode on an access point.
<b>local</b>	Converts from an indoor mesh access point (MAP or RAP) to a nonmesh lightweight access point (local mode).
<b>reap</b>	Enables remote edge access point mode on an access point.
<b>rogue</b>	Enables wired rogue detector mode on an access point.
<b>sniffer</b>	Enables wireless sniffer mode on an access point.
<b>se-connect</b>	Enables spectrum expert mode on an access point.
<b>submode</b>	(Optional) Configures wIPS submode on an access point.
<b>none</b>	Disables the wIPS on an access point.
<b>wips</b>	Enables the wIPS submode on an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

Local.

### Usage Guidelines

The sniffer mode captures and forwards all the packets from the clients on that channel to a remote machine that runs AiroPeek or other supported packet analyzer software. It includes information on the timestamp, signal strength, packet size and so on.

### Examples

This example shows how to set the controller to communicate with access point AP91 in bridge mode:

```
> config ap mode bridge AP91
```

This example shows how to set the controller to communicate with access point AP01 in local mode:

```
> config ap mode local AP01
```

This example shows how to set the controller to communicate with access point AP91 in remote office (REAP) mode:

```
> config ap mode flexconnect AP91
```

This example shows how to set the controller to communicate with access point AP91 in a wired rogue access point detector mode:

```
> config ap mode rogue AP91
```

This example shows how to set the controller to communicate with access point AP02 in wireless sniffer mode:

```
> config ap mode sniffer AP02
```

#### Related Commands

**config 802.11 enable**

**config ap mode**

**config ap monitor-mode**

**show ap config**

**show ap monitor-mode summary**

**show wps wips statistics**

## config ap monitor-mode

To configure Cisco lightweight access point channel optimization, use the **config ap monitor-mode** command.

**config ap monitor-mode {802.11b fast-channel | no-optimization | tracking-opt | wips-optimized} *cisco\_ap***

### Syntax Description

<b>802.11b fast-channel</b>	Configures 802.11b scanning channels for a monitor-mode access point.
<b>no-optimization</b>	Specifies no channel scanning optimization for the access point.
<b>tracking-opt</b>	Enables tracking optimized channel scanning for the access point.
<b>wips-optimized</b>	Enables WIPS optimized channel scanning for the access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to configure a Cisco wireless intrusion prevention system (WIPS) monitor mode on access point AP01:

```
> config ap monitor-mode wips-optimized AP01
```

### Related Commands

**config 802.11 enable**  
**config ap mode**  
**show wps wips summary**  
**show ap config**  
**show ap monitor-mode summary**  
**show wps wips statistics**

## config ap name

To modify the name of a Cisco lightweight access point, use the **config ap name** command.

**config ap name** *new\_name old\_name*

### Syntax Description

<i>new_name</i>	Desired Cisco lightweight access point name.
<i>old_name</i>	Current Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to modify the name of access point AP1 to AP2:

```
> config ap name AP1 AP2
```

### Related Commands

**show ap config**

## config ap packet-dump

To configure the Packet Capture parameters on access points, use the **config ap packet-dump** command.

```
config ap packet-dump {buffer-size size | capture-time time | classifier {arp {enable | disable} | broadcast {enable | disable} | control {enable | disable} | data {enable | disable} | dot1x {enable | disable} | iapp {enable | disable} | ip {enable | disable} | management {enable | disable} | multicast {enable | disable} | tcp {enable | disable | port tcp_port } | udp {enable | disable | port udp_port } } | ftp server_ip | start mac_address cisco_ap | stop | truncate length}
```

### Syntax Description

<b>buffer-size</b>	Configures the buffer size for Packet Capture in the access point.
<i>size</i>	Size of the buffer. The range is from 1024 to 4096 KB.
<b>capture-time</b>	Configures the timer value for Packet Capture.
<i>time</i>	Timer value for Packet Capture. The range is from 1 to 60 minutes.
<b>classifier</b>	Configures the classifier information for Packet Capture. You can specify the type of packets that needs to be captured.
<b>arp</b>	Captures ARP packets.
<b>enable</b>	Enables capture of ARP, broadcast, 802.11 control, 802.11 data, dot1x, Inter Access Point Protocol (IAPP), IP, 802.11 management, or multicast packets.
<b>disable</b>	Disables capture of ARP, broadcast, 802.11 control, 802.11 data, dot1x, IAPP, IP, 802.11 management, or multicast packets.
<b>broadcast</b>	Captures broadcast packets.
<b>control</b>	Captures 802.11 control packets.
<b>data</b>	Captures 802.11 data packets.
<b>dot1x</b>	Captures dot1x packets.
<b>iapp</b>	Captures IAPP packets.
<b>ip</b>	Captures IP packets.
<b>management</b>	Captures 802.11 management packets.
<b>multicast</b>	Captures multicast packets.
<b>tcp</b>	Captures TCP packets.
<i>tcp_port</i>	TCP port number. The range is from 1 to 65535.

<b>udp</b>	Captures TCP packets.
<i>udp_port</i>	UDP port number. The range is from 1 to 65535.
<b>ftp</b>	Configures FTP parameters for Packet Capture.
<i>server_ip</i>	FTP server IP address.
<b>start</b>	Starts Packet Capture from the access point.
<i>mac_address</i>	Client MAC Address for Packet Capture.
<i>cisco_ap</i>	Name of the Cisco access point.
<b>stop</b>	Stops Packet Capture from the access point.
<b>truncate</b>	Truncates the packet to the specified length during Packet Capture.
<i>length</i>	Length of the packet after truncation. The range is from 20 to 1500.

**Command Default**

The default buffer size is 2 MB. The default capture time is 10 mins.

**Usage Guidelines**

Packet Capture does not work during intercontroller roaming.

The controller does not capture packets created in the radio firmware and sent out of the access point, such as a beacon or probe response. Only packets that flow through the Radio driver in the Tx path will be captured.

Use the command **config ap packet-dump start** to start the Packet Capture from the access point. When you start Packet Capture, the controller sends a Control and Provisioning of Wireless Access Points protocol (CAPWAP) message to the access point to which the client is associated and captures packets. You must configure the FTP server and ensure that the client is associated to the access point before you start Packet Capture. If the client is not associated to the access point, you must specify the name of the access point.

**Examples**

This example shows how to start Packet Capture from an access point:

```
> config ap packet-dump start 00:0d:28:f4:c0:45 AP1
```

This example shows how to capture 802.11 control packets from an access point:

```
> config ap packet-dump classifier control enable
```

**Related Commands**

**show ap packet-dump status**

**debug ap packet-dump**

## config ap port

To configure the port for a foreign access point, use the **config ap port** command.

**config ap port** *MAC port*

### Syntax Description

<i>MAC</i>	Foreign access point MAC address.
<i>port</i>	Port number for accessing the foreign access point.

### Command Default

None.

### Examples

This example shows how to configure the port for a foreign access point MAC address:

```
> config ap port 12:12:12:12:12:12 20
```

### Related Commands

**config ap**

## config ap power injector

To configure the power injector state for an access point, use the **config ap power injector** command.

**config ap power injector** {enable | disable} {cisco\_ap | all} {installed | override | switch\_MAC}

### Syntax Description

<b>enable</b>	Enables the power injector state for an access point.
<b>disable</b>	Disables the power injector state for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
<b>all</b>	Specifies all Cisco lightweight access points connected to the controller.
<b>installed</b>	Detects the MAC address of the current switch port that has a power injector.
<b>override</b>	Overrides the safety checks and assumes a power injector is always installed.
<i>switch_MAC</i>	MAC address of the switch port with an installed power injector.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

### Examples

This example shows how to enable the power injector state for all access points:

```
> config ap power injector enable all 12:12:12:12:12:12
```

### Related Commands

**config ap**



## config ap power pre-standard

To enable or disable the inline power Cisco pre-standard switch state for an access point, use the **config ap power pre-standard** command.

**config ap power pre-standard** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the inline power Cisco pre-standard switch state for an access point.
<b>disable</b>	Disables the inline power Cisco pre-standard switch state for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

Disabled.

### Examples

This example shows how to enable the inline power Cisco pre-standard switch state for access point AP02:

```
> config ap power pre-standard enable AP02
```

### Related Commands

config ap

## config ap primary-base

To set the Cisco lightweight access point primary Cisco wireless LAN controller, use the **config ap primary-base** command.

**config ap primary-base** *controller\_name* *cisco\_ap* [*controller\_ip\_address*]

### Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional) If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
<b>Note</b>	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

### Examples

This example shows how to set an access point primary Wireless LAN controller:

```
> config ap primary-base SW_1 AP2
```

### Related Commands

**show sysinfo**  
**config sysname**  
**config ap secondary-base**  
**config ap tertiary-base**

## config ap priority

To assign a priority designation to an access point that allows it to reauthenticate after a controller failure by priority rather than on a first-come-until-full basis, use the **config ap priority** command.

**config ap priority** {1 | 2 | 3 | 4} *cisco\_ap*

### Syntax Description

1	Specifies low priority.
2	Specifies medium priority.
3	Specifies high priority.
4	Specifies the highest (critical) priority.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

1 - Low priority.

### Usage Guidelines

In a failover situation, if the backup controller does not have enough ports to allow all the access points in the affected area to reauthenticate, it gives priority to higher-priority access points over lower-priority ones, even if it means replacing lower-priority access points.

### Examples

This example shows how to assign a priority designation to access point AP02 that allows it to reauthenticate after a controller failure by assigning a reauthentication priority 3:

```
> config ap priority 3 AP02
```

### Related Commands

**config network ap-priority**  
**show ap summary**  
**show network summary**

## config ap reporting-period

To reset a Cisco lightweight access point, use the **config ap reporting-period** command.

**config ap reporting-period** *period*

### Syntax Description

<i>period</i>	Time period in seconds between 10 and 120.
---------------	--

### Command Default

None.

### Examples

This example shows how to reset an access point reporting period to 120 seconds:

```
> config ap reporting-period 120
```

### Related Commands

**show ap config 802.11a**  
**show ap config 802.11ab**

## config ap reset

To reset a Cisco lightweight access point, use the **config ap reset** command.

**config ap reset** *cisco\_ap*

Syntax Description
--------------------

<i>cisco_ap</i>	Cisco lightweight access point name.
-----------------	--------------------------------------

Command Default
-----------------

None.
-------

Examples
----------

This example shows how to reset an access point:
--

```
> config ap reset AP2
```

Related Commands
------------------

show ap config
----------------

## config ap retransmit interval

To configure the access point control packet retransmission interval, use the **config ap retransmit interval** command.

**config ap retransmit interval** *seconds* {**all** | *cisco\_ap*}

### Syntax Description

<i>seconds</i>	AP control packet retransmission timeout between 2 and 5 seconds.
<b>all</b>	Specifies all access points.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to configure the retransmission interval for all access points globally:

```
> config ap retransmit interval 4 all
```

### Related Commands

**show ap config**

## config ap retransmit count

To configure the access point control packet retransmission count, use the **config ap retransmit count** command.

**config ap retransmit count** *count* {**all** | *cisco\_ap*}

### Syntax Description

<i>count</i>	Number of times control packet will be retransmitted. The range is from 3 to 8.
<b>all</b>	Specifies all access points.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to configure the retransmission retry count for a specific access point:

```
> config ap retransmit count 6 cisco_ap
```

### Related Commands

**show ap config**

## config ap role

To specify the role of an access point in a mesh network, use the **config ap role** command.

**config ap role** {**rootAP** | **meshAP**} *cisco\_ap*

### Syntax Description

<b>rootAP</b>	Designates the mesh access point as a root access point (RAP).
<b>meshAP</b>	Designates the mesh access point as a mesh access point (MAP).
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

**meshAP.**

### Usage Guidelines

Use the **meshAP** keyword if the access point has a wireless connection to the controller, or use the **rootAP** keyword if the access point has a wired connection to the controller. Changing the AP's role will cause the AP to reboot.

### Examples

This example shows how to designate mesh access point AP02 as a root access point:

```
> config ap role rootAP AP02
Changing the AP's role will cause the AP to reboot.
Are you sure you want to continue? (y/n)
```

### Related Commands

**show ap config**



## config ap rst-button

To configure the Reset button for an access point, use the **config ap rst-button** command.

**config ap rst-button** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the Reset button for an access point.
<b>disable</b>	Disables the Reset button for an access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to configure the Reset button for access point AP03:

```
> config ap rst-button enable AP03
```

### Related Commands

**config ap**

## config ap secondary-base

To set the Cisco lightweight access point secondary Cisco wireless LAN controller, use the **config ap secondary-base** command.

**config ap secondary-base** *controller\_name* *cisco\_ap* [*controller\_ip\_address*]

### Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional). If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
<b>Note</b>	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

### Examples

This example shows how to set an access point secondary Cisco wireless controller:

```
> config ap secondary-base SW_1 AP2
```

### Related Commands

**show sysinfo**  
**config sysname**  
**config ap primary-base**  
**config ap tertiary-base**

## config ap sniff

To enable or disable sniffing on an access point, use the **config ap sniff** command.

**config ap sniff {802.11a | 802.11b} {enable *channel server\_ip* | disable} *cisco\_ap***

### Syntax Description

<b>802.11a</b>	Specifies the 802.11a network.
<b>802.11b</b>	Specifies the 802.11b network.
<b>enable</b>	Enables sniffing on an access point.
<i>channel</i>	Channel to be sniffed.
<i>server_ip</i>	IP address of the remote machine running Omnippeek, Airopeek, AirMagnet, or Wireshark software.
<b>disable</b>	Disables sniffing on an access point.
<i>cisco_ap</i>	Access point configured as the sniffer.

### Command Default

Channel 36.

### Usage Guidelines

When the sniffer feature is enabled on an access point, it starts sniffing the signal on the given channel. It captures and forwards all the packets to the remote computer that runs Omnippeek, Airopeek, AirMagnet, or Wireshark software. It includes information on the timestamp, signal strength, packet size and so on.

Before an access point can act as a sniffer, a remote computer that runs one of the listed packet analyzers must be set up so that it can receive packets sent by the access point. After the Airopeek installation, copy the following .dll files to the location where airopeek is installed:

- socket.dll file to the Plug-ins folder (for example, C:\Program Files\WildPackets\AiroPeek\Plugins)
- socketres.dll file to the PluginRes folder (for example, C:\Program Files\WildPackets\AiroPeek\1033\PluginRes)

### Examples

This example shows how to enable the sniffing on the 802.11a an access point from the primary Cisco WLC:

```
> config ap sniff 80211a enable 23 11.22.44.55 AP01
```

### Related Commands

**show ap config**  
**config ap sniff 802.11b**

## config ap ssh

To enable Secure Shell (SSH) connectivity on an access point, use the **config ap ssh** command.

**config ap ssh** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the SSH connectivity on an access point.
<b>disable</b>	Disables the SSH connectivity on an access point.
<i>cisco_ap</i>	Cisco access point name.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operation and in the event of a hardware reset.

### Examples

This example shows how to enable SSH connectivity on access point Cisco\_ap2:

```
> config ap ssh enable cisco_ap2
```

### Related Commands

**config ap**  
**show ap stats**  
**config network ssh**

## config ap static-ip

To configure Cisco lightweight access point static IP address settings, use the **config ap static-ip** command.

```
config ap static-ip {enable cisco_ap ip_address net_mask gateway | disable cisco_ap add {domain {cisco_ap | all} domain_name} | {nameserver {cisco_ap | all} dns_ip_address} | delete {domain | nameserver} {cisco_ap | all}}
```

### Syntax Description

<b>enable</b>	Enables the Cisco lightweight access point static IP address.
<b>disable</b>	Disables the Cisco lightweight access point static IP address. The access point uses DHCP to get the IP address.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>ip_address</i>	Cisco lightweight access point IP address
<i>net_mask</i>	Cisco lightweight access point network mask.
<i>gateway</i>	IP address of the Cisco lightweight access point gateway.
<b>add</b>	Adds a domain or DNS server.
<b>domain</b>	Specifies the domain to which a specific access point or all access points belong.
<b>all</b>	Specifies all access points.
<i>domain_name</i>	Specifies a domain name.
<b>nameserver</b>	Specifies a DNS server so that a specific access point or all access points can discover the controller using DNS resolution.
<i>dns_ip_address</i>	DNS server IP address.
<b>delete</b>	Deletes a domain or DNS server.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

**Usage Guidelines**

An access point cannot discover the controller using Domain Name System (DNS) resolution if a static IP address is configured for the access point, unless you specify a DNS server and the domain to which the access point belongs.

After you enter the IP, netmask, and gateway addresses, save your configuration to reboot the access point. After the access point rejoins the controller, you can enter the domain and DNS server information.

**Examples**

This example shows how to configure an access point static IP address:

```
> config ap static-ip enable AP2 1.1.1.1 255.255.255.0 209.165.200.254
```

**Related Commands**

**show sysinfo**

**config sysname**

**config ap secondary-base**

**config ap primary-base**

## config ap stats-timer

To set the time in seconds that the Cisco lightweight access point sends its DOT11 statistics to the Cisco wireless LAN controller, use the **config ap stats-timer** command.

**config ap stats-timer** *period cisco\_ap*

### Syntax Description

<i>period</i>	Time in seconds from 0 to 65535. A zero value disables the timer.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

0 (disabled).

### Usage Guidelines

A value of 0 (zero) means that the Cisco lightweight access point does not send any DOT11 statistics. The acceptable range for the timer is from 0 to 65535 seconds, and the Cisco lightweight access point must be disabled to set this value.

### Examples

This example shows how to set the stats timer to 600 seconds for access point AP2:

```
> config ap stats-timer 600 AP2
```

### Related Commands

**config ap disable**

## config ap syslog host global

To configure a global syslog server for all access points that join the controller, use the **config ap syslog host global** command.

**config ap syslog host global** *syslog\_server\_IP\_address*

### Syntax Description

<i>syslog_server_IP_address</i>	IP address of the syslog server.
---------------------------------	----------------------------------

### Command Default

255.255.255.255.

### Usage Guidelines

By default, the global syslog server IP address for all access points is 255.255.255.255. Make sure that the access points can reach the subnet on which the syslog server resides before configuring the syslog server on the controller. If the access points cannot reach this subnet, the access points are unable to send out syslog messages.

### Examples

This example shows how to configure a global syslog server for all access points:

```
> config ap syslog host global 255.255.255.255
```

### Related Commands

**config ap syslog host specific**  
**show ap**  
**config global**  
**show ap**  
**config general**



## config ap syslog host specific

To configure a syslog server for a specific access point, use the **config ap syslog host specific** command.

**config ap syslog host specific** *cisco\_ap* *syslog\_server\_IP\_address*

### Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point.
<i>syslog_server_IP_address</i>	IP address of the syslog server.

### Command Default

0.0.0.0.

### Usage Guidelines

By default, the syslog server IP address for each access point is 0.0.0.0, indicating that it is not yet set. When the default value is used, the global access point syslog server IP address is pushed to the access point.

### Examples

This example shows how to configure a syslog server:

```
> config ap syslog host specific 0.0.0.0
```

### Related Commands

**config ap syslog host global**  
**show ap config global**  
**show ap config general**

## config ap tcp-adjust-mss

To enable or disable the TCP maximum segment size (MSS) on a particular access point or on all access points, use the **config ap tcp-adjust-mss** command.

**config ap tcp-adjust-mss** {enable | disable} {cisco\_ap | all} size

### Syntax Description

<b>enable</b>	Enables the TCP maximum segment size on an access point.
<b>disable</b>	Disables the TCP maximum segment size on an access point.
<i>cisco_ap</i>	Cisco access point name.
<b>all</b>	Specifies all access points.
<i>size</i>	Maximum segment size, from 536 to 1363 bytes.



### Note

If an AP itself is configured with the keyword **all**, the all access points case takes precedence over the AP that is with the keyword **all**.

### Command Default

None.

### Usage Guidelines

When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the CAPWAP tunnel, the access point changes the MSS to the new configured value.

### Examples

This example shows how to enable the TCP MSS on access point Cisco\_ap1 with a segment size of 1200 bytes:

```
> config ap tcp-adjust-mss enable cisco_ap1 1200
```

### Related Commands

**show ap tcp-mss-adjust**

## config ap telnet

To enable Telnet connectivity on an access point, use the **config ap telnet** command.

**config ap telnet** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the Telnet connectivity on an access point.
<b>disable</b>	Disables the Telnet connectivity on an access point.
<i>cisco_ap</i>	Cisco access point name.

### Command Default

None.

### Usage Guidelines

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operation and in the event of a hardware reset.

### Examples

This example shows how to enable Telnet connectivity on access point cisco\_ap1:

```
> config ap telnet enable cisco_ap1
```

This example shows how to disable Telnet connectivity on access point cisco\_ap1:

```
> config ap telnet disable cisco_ap1
```

### Related Commands

**config ap**  
**config network telnet**  
**show ap config**

## config ap tertiary-base

To set the Cisco lightweight access point tertiary Cisco wireless LAN controller, use the **config ap tertiary-base** command.

**config ap tertiary-base** *controller\_name* *cisco\_ap* [*controller\_ip\_address*]

### Syntax Description

<i>controller_name</i>	Name of the Cisco wireless LAN controller.
<i>cisco_ap</i>	Cisco lightweight access point name.
<i>controller_ip_address</i>	(Optional) If the backup controller is outside the mobility group to which the access point is connected, then you need to provide the IP address of the primary, secondary, or tertiary controller.
<b>Note</b>	For OfficeExtend access points, you must enter both the name and IP address of the controller. Otherwise, the access point cannot join this controller.

### Command Default

None.

### Usage Guidelines

OfficeExtend access points do not use the generic broadcast or over-the air (OTAP) discovery process to find a controller. You must configure one or more controllers because OfficeExtend access points try to connect only to their configured controllers.

The Cisco lightweight access point associates with this Cisco wireless LAN controller for all network operations and in the event of a hardware reset.

### Examples

This example shows how to set the access point tertiary wireless LAN controller:

```
> config ap tertiary-base SW_1 AP02
```

### Related Commands

**show sysinfo**  
**config sysname**  
**config ap secondary-base**  
**config ap primary-base**

## config ap tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **config ap tftp-downgrade** command.

**config ap tftp-downgrade** {*tftp\_ip\_address* | *image\_filename* | *ap\_name*}

### Syntax Description

<i>tftp_ip_address</i>	IP address of the TFTP server.
<i>image_filename</i>	Filename of the access point image file on the TFTP server.
<i>ap_name</i>	Access point name.

### Command Default

None.

### Examples

This example shows how to configure the settings for downgrading access point ap1240\_102301:

```
> config ap tftp-downgrade 209.165.200.224 1238.tar ap1240_102301
```

### Related Commands

**show version**  
**show running-config**

## config ap username

To assign a username and password to access either a specific access point or all access points, use the **config ap username** command.

**config ap username** *user\_id* **password** *passwd* [**all** | *ap\_name*]

### Syntax Description

<i>user_id</i>	Administrator username.
<i>passwd</i>	Administrator password.
<b>all</b>	(Optional) Specifies all access points.
<i>ap_name</i>	Name of a specific access point.

### Command Default

None.

### Examples

This example shows how to assign a username and password to a specific access point:

```
> config ap username jack password blue 1a204
```

This example shows how to assign the same username and password to all access points:

```
> config ap username jack password blue all
```

## config ap venue

To configure the venue information for 802.11u network on an access point, use the **config ap venue** command.

**config ap venue** {*add**venue\_name venue-group venue-type lang-code cisco-ap* | *delete*}

### Syntax Description

<b>add</b>	Adds venue information.
<i>venue_name</i>	Venue name.
<i>venue_group</i>	Venue group category. See the table below for details on venue group mappings.
<i>venue_type</i>	Venue type. This value depends on the venue-group specified. See the table below for venue group mappings.
<i>lang_code</i>	Language used. An ISO-14962-1997 encoded string that defines the language. This string is a three character language code. Enter the first three letters of the language in English (for example, eng for English).
<i>cisco_ap</i>	Name of the access point.
<b>deletes</b>	Deletes venue information.

### Command Default

None.

### Examples

The command shows how to set the venue details for an access point named cisco-ap1:

```
> config ap venue add test 11 34 eng cisco-ap1
```

This table lists the different venue types for each venue group.

**Table 2: Venue Group Mapping**

Venue Group Name	Value	Venue Type for Group
UNSPECIFIED	0	

Venue Group Name	Value	Venue Type for Group
ASSEMBLY	1	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED ASSEMBLY</li> <li>• 1—ARENA</li> <li>• 2—STADIUM</li> <li>• 3—PASSENGER TERMINAL (E.G., AIRPORT, BUS, FERRY, TRAIN STATION)</li> <li>• 4—AMPHITHEATER</li> <li>• 5—AMUSEMENT PARK</li> <li>• 6—PLACE OF WORSHIP</li> <li>• 7—CONVENTION CENTER</li> <li>• 8—LIBRARY</li> <li>• 9—MUSEUM</li> <li>• 10—RESTAURANT</li> <li>• 11—THEATER</li> <li>• 12—BAR</li> <li>• 13—COFFEE SHOP</li> <li>• 14—ZOO OR AQUARIUM</li> <li>• 15—EMERGENCY COORDINATION CENTER</li> </ul>
BUSINESS	2	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED BUSINESS</li> <li>• 1—DOCTOR OR DENTIST OFFICE</li> <li>• 2—BANK</li> <li>• 3—FIRE STATION</li> <li>• 4—POLICE STATION</li> <li>• 6—POST OFFICE</li> <li>• 7—PROFESSIONAL OFFICE</li> <li>• 8—RESEARCH AND DEVELOPMENT FACILITY</li> <li>• 9—ATTORNEY OFFICE</li> </ul>



Venue Group Name	Value	Venue Type for Group
EDUCATIONAL	3	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED EDUCATIONAL</li> <li>• 1—SCHOOL, PRIMARY</li> <li>• 2—SCHOOL, SECONDARY</li> <li>• 3—UNIVERSITY OR COLLEGE</li> </ul>
FACTORY-INDUSTRIAL	4	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED FACTORY AND INDUSTRIAL</li> <li>• 1—FACTORY</li> </ul>
INSTITUTIONAL	5	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED INSTITUTIONAL</li> <li>• 1—HOSPITAL</li> <li>• 2—LONG-TERM CARE FACILITY (E.G., NURSING HOME, HOSPICE, ETC.)</li> <li>• 3—ALCOHOL AND DRUG RE-HABILITATION CENTER</li> <li>• 4—GROUP HOME</li> <li>• 5—PRISON OR JAIL</li> </ul>
MERCANTILE	6	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED MERCANTILE</li> <li>• 1—RETAIL STORE</li> <li>• 2—GROCERY MARKET</li> <li>• 3—AUTOMOTIVE SERVICE STATION</li> <li>• 4—SHOPPING MALL</li> <li>• 5—GAS STATION</li> </ul>
RESIDENTIAL	7	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED RESIDENTIAL</li> <li>• 1—PRIVATE RESIDENCE</li> <li>• 2—HOTEL OR MOTEL</li> <li>• 3—DORMITORY</li> <li>• 4—BOARDING HOUSE</li> </ul>

Venue Group Name	Value	Venue Type for Group
STORAGE	8	UNSPECIFIED STORAGE
UTILITY-MISC	9	0—UNSPECIFIED UTILITY AND MISCELLANEOUS
VEHICULAR	10	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED VEHICULAR</li> <li>• 1—AUTOMOBILE OR TRUCK</li> <li>• 2—AIRPLANE</li> <li>• 3—BUS</li> <li>• 4—FERRY</li> <li>• 5—SHIP OR BOAT</li> <li>• 6—TRAIN</li> <li>• 7—MOTOR BIKE</li> </ul>
OUTDOOR	11	<ul style="list-style-type: none"> <li>• 0—UNSPECIFIED OUTDOOR</li> <li>• 1—MUNI-MESH NETWORK</li> <li>• 2—CITY PARK</li> <li>• 3—REST AREA</li> <li>• 4—TRAFFIC CONTROL</li> <li>• 5—BUS STOP</li> <li>• 6—KIOSK</li> </ul>

**Related Commands**

config wlan mobile-concierge dot11u  
 config wlan mobile-concierge hotspot2  
 config wlan mobile-concierge msap

## config ap wlan

To enable or disable wireless LAN override for a Cisco lightweight access point radio, use the **config ap wlan** command.

**config ap wlan** {enable | disable} {802.11a | 802.11b} *wlan\_id* *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the wireless LAN override on an access point.
<b>disable</b>	Disables the wireless LAN override on an access point.
<b>802.11a</b>	Specifies the 802.11a network.
<b>802.11b</b>	Specifies the 802.11b network.
<i>wlan_id</i>	Cisco wireless LAN controller ID assigned to a wireless LAN.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to enable wireless LAN override on the AP03 802.11a radio:

```
> config ap wlan 802.11a AP03
```

### Related Commands

**show ap wlan**

## config country

To configure the controller's country code, use the **config country** command.

**config country** *country\_code*

### Syntax Description

<i>country_code</i>	Two-letter or three-letter country code.
---------------------	--

### Command Default

*us* (country code of the United States of America).

### Usage Guidelines

Cisco wireless LAN controllers must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.

You can use the **show country** command to display a list of supported countries.

### Examples

This example shows how to configure the controller's country code to DE:

```
> config country DE
```

### Related Commands

**show country**

## config ipv6 ra-guard

To configure the filter for Router Advertisement (RA) packets that originate from a client on an AP, use the **config ipv6 ra-guard** command.

**config ipv6 ra-guard ap {enable | disable}**

### Syntax Description

<b>enable</b>	Enables RA guard on an AP.
<b>disable</b>	Disables RA guard on an AP.

### Command Default

None.

### Examples

This example shows how to enable IPv6 RA guard:

```
> config ipv6 ra-guard
```

### Related Commands

**show ipv6 ra-guard**

## config known ap

To configure a known Cisco lightweight access point, use the **config known ap** command.

**config known ap** {**add** | **alert** | **delete**} *MAC*

### Syntax Description

<b>add</b>	Adds a new known access point entry.
<b>alert</b>	Generates a trap upon detection of the access point.
<b>delete</b>	Deletes an existing known access point entry.
<i>MAC</i>	MAC address of the known Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to add a new access point entry ac:10:02:72:2f:bf on a known access point:

```
> config known ap add ac:10:02:72:2f:bf 12
```

### Related Commands

**config ap**

## config network allow-old-bridge-aps

To configure an old bridge access point's ability to associate with a switch, use the **config network allow-old-bridge-aps** command.

**config network allow-old-bridge-aps {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the switch association.
<b>disable</b>	Disables the switch association.

### Command Default

Enabled.

### Examples

This example shows how to configure an old bridge access point to associate with the switch:

```
> config network allow-old-bridge-aps enable
```

### Related Commands

**show network summary**

## config network ap-discovery

To enable or disable NAT IP in an AP discovery response, use the **config network ap-discovery** command.

**config network ap-discovery nat-ip-only {enable | disable}**

### Syntax Description

<b>enable</b>	Enables use of NAT IP only in discovery response. This is the default.
<b>disable</b>	Enables use of both NAT IP and non NAT IP in discovery response.

### Command Default

Enabled.

### Usage Guidelines

If the **config interface nat-address management** command is set, this command controls which address(es) are sent in the CAPWAP discovery responses.

If all APs are on the outside of the NAT gateway of the controller, enter the **config network ap-discovery nat-ip-only enable** command, and only the management NAT address is sent.

If the controller has both APs on the outside and the inside of its NAT gateway, enter the **config network ap-discovery nat-ip-only disable** command, and both the management NAT address and the management inside address are sent. Ensure that you have entered the **config ap link-latency disable all** command to avoid stranding APs.

### Examples

This example shows how to enable NAT IP in an AP discovery response:

```
> config network ap-discovery nat-ip-only enable
```



## config network ap-fallback

To configure Cisco lightweight access point fallback, use the **config network ap-fallback** command.

**config network ap-fallback {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the Cisco lightweight access point fallback.
<b>disable</b>	Disables the Cisco lightweight access point fallback.

### Command Default

Enabled.

### Examples

This example shows how to enable the Cisco lightweight access point fallback:

```
> config network ap-fallback enable
```

### Related Commands

**show network summary**

## config network ap-priority

To enable or disable the option to prioritize lightweight access points so that after a controller failure they reauthenticate by priority rather than on a first-come-until-full basis, use the **config network ap-priority** command.

**config network ap-priority** {enable | disable}

### Syntax Description

<b>enable</b>	Enables the lightweight access point priority reauthentication.
<b>disable</b>	Disables the lightweight access point priority reauthentication.

### Command Default

Disabled.

### Examples

This example shows how to enable the lightweight access point priority reauthorization:

```
> config network ap-priority enable
```

### Related Commands

**config ap priority**  
**show ap summary**  
**show network summary**

## config network apple-talk

To configure AppleTalk bridging, use the **config network apple-talk** command.

**config network apple-talk {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the AppleTalk bridging.
<b>disable</b>	Disables the AppleTalk bridging.

### Command Default

None.

### Examples

This example shows how to configure AppleTalk bridging:

```
> config network apple-talk enable
```

### Related Commands

**show network summary**

## config network bridging-shared-secret

To configure the bridging shared secret, use the **config network bridging-shared-secret** command.

**config network bridging-shared-secret** *shared\_secret*

### Syntax Description

<i>shared_secret</i>	Bridging shared secret string. The string can contain up to 10 bytes.
----------------------	---

### Command Default

Enabled.

### Usage Guidelines

This command creates a secret that encrypts backhaul user data for the mesh access points that connect to the switch.

The zero-touch configuration must be enabled for this command to work.

### Examples

This example shows how to configure the bridging shared secret string “shhh1”:

```
> config network bridging-shared-secret shhh1
```

### Related Commands

**show network summary**

## config network master-base

To enable or disable the Cisco wireless LAN controller as an access point default master, use the **config network master-base** command.

**config network master-base {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.
<b>disable</b>	Disables the Cisco wireless LAN controller acting as a Cisco lightweight access point default master.

### Command Default

None.

### Usage Guidelines

This setting is only used upon network installation and should be disabled after the initial network configuration. Because the Master Cisco wireless LAN controller is normally not used in a deployed network, the Master Cisco wireless LAN controller setting can be saved from 6.0.199.0 or later releases.

### Examples

This example shows how to enable the Cisco wireless LAN controller as a default master:

```
> config network master-base enable
```

## config network oeap-600 dual-rlan-ports

To configure the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4, use the **config network oeap-600 dual-rlan-ports** command.

**config network oeap-600 dual-rlan-ports** {enable | disable}

### Syntax Description

<b>enable</b>	Enables Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port in addition to port 4.
<b>disable</b>	Resets the Ethernet port 3 Cisco OfficeExtend 600 Series access points to function as a local LAN port.

### Command Default

Disabled.

### Examples

This example shows how to enable the Ethernet port 3 of Cisco OfficeExtend 600 Series access points to operate as a remote LAN port:

```
> config network oeap-600 dual-rlan-ports enable
```

### Related Commands

**show network summary**

## config network oeap-600 local-network

To configure access to the local network for the Cisco 600 Series OfficeExtend access points, use the **config network oeap-600 local-network** command.

**config network oeap-600 local-network {enable | disable}**

### Syntax Description

<b>enable</b>	Enables access to the local network for the Cisco 600 Series OfficeExtend access points.
<b>disable</b>	Disables access to the local network for the Cisco 600 Series OfficeExtend access points.

### Command Default

Disabled.

### Examples

This example shows how to enable access to the local network for the Cisco 600 Series OfficeExtend access points:

```
> config network oeap-600 local-network enable
```

### Related Commands

**show network summary**

## config network otap-mode

To enable or disable over-the-air provisioning (OTAP) of Cisco lightweight access points, use the **config network otap-mode** command.

**config network otap-mode {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the OTAP provisioning.
<b>disable</b>	Disables the OTAP provisioning.

### Command Default

Enabled.

### Examples

This example shows how to disable the OTAP provisioning:

```
> config network otap-mode disable
```

### Related Commands

**show network summary**



## config network zero-config

To configure bridge access point ZeroConfig support, use the **config network zero-config** command.

**config network zero-config {enable | disable}**

### Syntax Description

<b>enable</b>	Enables the bridge access point ZeroConfig support.
<b>disable</b>	Disables the bridge access point ZeroConfig support.

### Command Default

Enabled.

### Examples

This example shows how to enable the bridge access point ZeroConfig support:

```
> config network zero-config enable
```

### Related Commands

**show network summary**

## config redundancy interface address peer-service-port

To configure the service port IP and netmask of the peer or standby controller, use the **config redundancy interface address peer-service-port** command.

**config redundancy interface address peer-service-port** *ip\_address netmask*

### Syntax Description

<i>ip_address</i>	IP address of the peer service port.
<i>netmask</i>	Netmask of the peer service port.

### Command Default

None.

### Usage Guidelines

You can configure this command only from the Active controller. For the HA feature, the service port configurations are made per controller. You will lose these configurations if you change the mode from HA to non-HA and vice-versa.

### Examples

This example shows how to configure the service port IP and netmask of the peer or standby controller:

```
> config redundancy interface address peer-service-port 11.22.44.55
```

### Related Commands

**config redundancy mode**  
**config redundancy peer-route**  
**config redundancy mobilitymac**  
**config redundancy unit**  
**config redundancy timer**

## config redundancy mobilitymac

To configure the HA mobility MAC address to be used as an identifier, use the **config redundancy mobilitymac** command.

**config redundancy mobilitymac** *mac\_address*

---

### Syntax Description

*mac\_address*

MAC address that is an identifier for the active and standby controller pair.

---

### Command Default

None.

### Examples

This example shows how to configure the HA mobility MAC address:

```
> config redundancy mobilitymac ff:ff:ff:ff:ff:ff
```

### Related Commands

**config redundancy interface address peer-service-port**

**config redundancy peer-route**

**config redundancy unit**

**config redundancy timer**

**debug rfac**

**debug rmgr**

**debug rsyncmgr**

**show redundancy mobilitymac**

**show redundancy summary**

**show redundancy peer-route**

**show redundancy statistics**

**show redundancy timers**

## config redundancy mode

To enable or disable redundancy or High Availability (HA), use the **config redundancy mode** command.

**config redundancy mode {sso | nonedisable}**

### Syntax Description

<b>sso</b>	Enables a stateful switch over (SSO) or hot standby redundancy mode.
<b>nonedisable</b>	Disables redundancy mode.

### Command Default

None.

### Usage Guidelines

You must configure local and peer redundancy management IP addresses before you configure redundancy.

### Examples

This example shows how to enable redundancy:

```
> config redundancy mode sso
```

### Related Commands

**config redundancy mobilitymac**  
**config redundancy interface address peer-service-port**  
**config redundancy peer-route**  
**config redundancy unit**  
**config redundancy timer**  
**show redundancy peer-route**  
**show redundancy summary**  
**debug rmgr**  
**debug rsyncmgr**

## config redundancy peer-route

To configure the route configurations of the peer or standby controller, use the **config redundancy peer-route** command.

**config redundancy peer-route** {**add** | **delete**} *network\_ip\_address netmask gateway*

### Syntax Description

<b>add</b>	Adds a network route.
<b>delete</b>	Deletes a network route specific to standby controller.
<i>network_ip_address</i>	Network IP address.
<i>netmask</i>	Subnet mask of the network.
<i>gateway</i>	IP address of the gateway for the route network.

### Command Default

None.

### Usage Guidelines

You can configure this command only from the Active controller. For the HA feature, the service port configurations are made per controller. You will lose these configurations if you change the mode from HA to non-HA and vice-versa.

### Examples

This example shows how to configure route configurations of a peer or standby controller.

```
> config redundancy peer-route add 10.1.1.0 255.255.255.0 10.1.1.1
```

### Related Commands

**config redundancy mobilitymac**  
**config redundancy interface address peer-service-port**  
**config redundancy mode**  
**config redundancy unit**  
**config redundancy timer**  
**show redundancy peer-route**  
**show redundancy summary**  
**debug rmgr**  
**debug rsyncmgr**

## config redundancy timer keep-alive-timer

To configure the keep-alive timeout value, use the **config redundancy timer keep-alive-timer** command.

**config redundancy timer keep-alive-timer** *milliseconds*

### Syntax Description

<i>milliseconds</i>	Keep-alive timeout value in milliseconds. The range is from 100 to 400 milliseconds.
---------------------	--

### Command Default

100 milliseconds.

### Examples

This example shows how to configure the keep-alive timeout value:

```
> config redundancy timer keep-alive-timer 200
```

### Related Commands

**config redundancy mobilitymac**  
**config redundancy interface address peer-service-port**  
**config redundancy peer-route**  
**config redundancy unit**  
**config redundancy timer peer-search-timer**  
**show redundancy timers**  
**show redundancy summary**  
**debug rmgr**  
**debug rsyncmgr**

## config redundancy timer peer-search-timer

To configure the peer search timer, use the **config redundancy timer peer-search-timer** command.

**config redundancy timer peer-search-timer** *seconds*

Syntax Description	<i>seconds</i>	Value of the peer search timer in seconds. The range is from 60 to 180 secs.
--------------------	----------------	--

<b>Command Default</b>	120 seconds.
------------------------	--------------

<b>Usage Guidelines</b>	You can use this command to configure the boot up role negotiation timeout value in seconds.
-------------------------	--

<b>Examples</b>	This example shows how to configure the redundancy peer search timer: > <b>config redundancy timer peer-search-timer 100</b>
-----------------	---

<b>Related Commands</b>	<b>config redundancy mobilitymac</b> <b>config redundancy interface address peer-service-port</b> <b>config redundancy peer-route</b> <b>config redundancy unit</b> <b>config redundancy timer keep-alive-timer</b> <b>show redundancy peer-route</b> <b>show redundancy summary</b> <b>debug rmgr</b> <b>debug rsyncmgr</b>
-------------------------	--

## config redundancy unit

To configure a controller as a primary or secondary controller, use the **config redundancy unit** command.

**config redundancy unit {primary | secondary}**

### Syntax Description

<b>primary</b>	Configures the controller as the primary controller.
<b>secondary</b>	Configures the controller as the secondary controller.

### Command Default

Primary.

### Usage Guidelines

When you configure a controller as the secondary controller, it becomes the HA Stakable Unit (SKU) without any valid AP licenses.

### Examples

This example shows how to configure a controller as the primary controller:

```
> config redundancy unit primary
```

### Related Commands

**config redundancy mobilitymac**  
**config redundancy interface address peer-service-port**  
**config redundancy peer-route**  
**config redundancy unit**  
**config redundancy timer**  
**show redundancy peer-route**  
**show redundancy summary**  
**debug rmgr**  
**debug rsyncmgr**



## redundancy force-switchover

To trigger a manual switch over on the active Cisco WLC, use the **redundancy force-switchover** command.

**redundancy force-switchover**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Usage Guidelines** When a manual switchover occurs, the active Cisco WLC reboots and the standby Cisco WLC takes over the network. A stateful switchover of access points (AP SSO) is supported. AP SSO ensures that the AP sessions are maintained after the standby Cisco WLC takes over and the APs switch over to the standby Cisco WLC. The clients on the active Cisco WLC deauthenticate and join the new active Cisco WLC.

**Examples** This example shows how to trigger a forceful switchover on the Cisco WLC:

```
> redundancy force-switchover
```

**Related Commands**

- config redundancy mobilitymac**
- config redundancy interface address peer-service-port**
- config redundancy peer-route**
- config redundancy unit**
- config redundancy timer**
- show redundancy peer-route**
- show redundancy summary**
- debug rmgr**
- debug rsyncmgr**

## config redundancy management-gateway-failover

To configure the failover of the management gateway, use the **config redundancy management-gateway-failover** command.

**config redundancy management-gateway-failover {enable | disable}**

### Syntax Description

<b>enable</b>	Enables failover of the management gateway.
<b>disable</b>	Disables failover of the management gateway.

### Command Default

None.

### Usage Guidelines

Failover is supported only if redundancy management is mapped to the redundancy port.

### Examples

This example shows how to enable failover of the management gateway:

```
> config redundancy management-gateway-failover enable
```

### Related Commands

**config redundancy mobilitymac**  
**config redundancy interface address peer-service-port**  
**config redundancy peer-route**  
**config redundancy unit**  
**config redundancy timer**  
**show redundancy peer-route**  
**show redundancy summary**  
**debug rmgr**  
**debug rsyncmgr**

## config redundancy link-encryption

To encrypt the redundancy link, use the **config redundancy link-encryption** command.

**config redundancy link-encryption {enable | disable}**

<b>Syntax Description</b>	<b>enable</b>	Enables encryption of the redundancy link.
	<b>disable</b>	Disables encryption of the redundancy link.
<b>Command Default</b>	None.	
<b>Usage Guidelines</b>	Encryption of the redundancy link is not supported if the redundancy port is used as the redundancy management interface.	
<b>Examples</b>	This example shows how to encrypt the redundancy link: <pre>&gt; config redundancy link-encryption enable</pre>	
<b>Related Commands</b>	<b>config redundancy mobilitymac</b> <b>config redundancy interface address peer-service-port</b> <b>config redundancy peer-route</b> <b>config redundancy unit</b> <b>config redundancy timer</b> <b>show redundancy peer-route</b> <b>show redundancy summary</b> <b>debug rmgr</b> <b>debug rsyncmgr</b>	

## config slot

To configure various slot parameters, use the **config slot** command.

**config slot** *slot\_id* {**enable** | **disable** | **channel ap** | **chan\_width** | **txpower ap** | **antenna extAntGain** | **antenna\_gain** | **rts**} *cisco\_ap*

### Syntax Description

<i>slot_id</i>	Slot downlink radio to which the channel is assigned.
<b>enable</b>	Enables the slot.
<b>disable</b>	Disables the slot.
<b>channel</b>	Configures the channel for the slot.
<b>ap</b>	Configures one 802.11a Cisco access point.
<b>chan_width</b>	Configures channel width for the slot.
<b>txpower</b>	Configures Tx power for the slot.
<b>antenna</b>	Configures the 802.11a antenna.
<b>extAntGain</b>	Configures the 802.11a external antenna gain.
<i>antenna_gain</i>	External antenna gain value in .5 dBi units (such as 2.5 dBi = 5).
<b>rts</b>	Configures RTS/CTS for an access point.
<i>cisco_ap</i>	Name of the Cisco access point on which the channel is configured.

### Command Default

None.

### Examples

This example shows how to enable slot 3 for the access point abc:

```
> config slot 3 enable abc
```

This example shows how to configure RTS for the access point abc:

```
> config slot 2 rts abc
```

### Related Commands

**show mesh ap**  
**show mesh stats**

## config wgb vlan

To configure the Workgroup Bridge (WGB) VLAN client support, use the **config wgb vlan** command.

**config wgb vlan {enable | disable}**

Syntax	Description
<b>enable</b>	Enables wired clients behind a WGB to connect to an anchor controller in a Data Management Zone (DMZ).
<b>disable</b>	Disables wired clients behind a WGB from connecting to an anchor controller in a DMZ.

### Command Default

None.

### Examples

This example shows how to enable WGB VLAN client support:

```
> config wgb vlan enable
```

## clear Commands

This section lists the **clear** commands to clear existing configurations, log files, and other functions for access points .

## clear ap-config

To clear (reset to the default values) a lightweight access point's configuration settings, use the **clear ap-config** command.

**clear ap-config** *ap\_name*

### Syntax Description

<i>ap_name</i>	Access point name.
----------------	--------------------

### Command Default

None.

### Usage Guidelines

Entering this command does not clear the static IP address of the access point.

### Examples

This example shows how to clear the access point's configuration settings for the access point named ap1240\_322115:

```
> clear ap-config ap1240_322115
Clear ap-config will clear ap config and reboot the AP. Are you sure you want continue?
(y/n)
```

### Related Commands

**show ap config**

## clear ap-eventlog

To delete the existing event log and create an empty event log file for a specific access point or for all access points joined to the controller, use the **clear ap-eventlog** command.

**clear ap-eventlog** {specific *ap\_name* | all}

### Syntax Description

<b>specific</b>	Specifies a specific access point log file.
<i>ap_name</i>	Name of the access point for which the event log file will be emptied.
<b>all</b>	Deletes the event log for all access points joined to the controller.

### Command Default

None.

### Examples

This example shows how to delete the event log for all access points:

```
> clear ap-eventlog all
This will clear event log contents for all APs. Do you want continue? (y/n) :y
Any AP event log contents have been successfully cleared.
```

### Related Commands

**show ap eventlog**

## clear ap join stats

To clear the join statistics for all access points or for a specific access point, use the **clear ap join stats** command.

**clear ap join stats** {all | *ap\_mac*}

### Syntax Description

<b>all</b>	Specifies all access points.
------------	------------------------------

<i>ap_mac</i>	Access point MAC address.
---------------	---------------------------

### Command Default

None.

### Examples

This example shows how to clear the join statistics of all the access points:

```
> clear ap join stats all
```

### Related Commands

**show ap config**



## clear ap tsm

To clear the Traffic Stream Metrics (TSM) statistics of clients associated to an access point, use the **clear ap tsm** command.

```
clear ap tsm {802.11a | 802.11b} cisco_ap all
```

### Syntax Description

<b>802.11a</b>	Clears 802.11a TSM statistics of clients associated to an access point.
<b>802.11b</b>	Clears 802.11b TSM statistics of clients associated to an access point.
<i>cisco_ap</i>	Cisco lightweight access point.
<b>all</b>	Clears TSM statistics of clients associated to the access point.

### Command Default

None.

### Examples

This example shows how to clear 802.11a TSM statistics for all clients of an access point:

```
> clear ap tsm 802.11a AP3600_1 all
```

## clear lwapp private-config

To clear (reset to default values) an access point's current Lightweight Access Point Protocol (LWAPP) private configuration, which contains static IP addressing and controller IP address configurations, use the **clear lwapp private-config** command.

**clear lwapp private-config**

### Syntax Description

This command has no arguments or keywords.

### Command Default

None.

### Usage Guidelines

Enter the command on the access point console port.

Prior to changing the FlexConnect configuration on an access point using the access point's console port, the access point must be in standalone mode (not connected to a Cisco WLC ) and you must remove the current LWAPP private configuration by using the **clear lwapp private-config** command.



#### Note

The access point must be running Cisco IOS Release 12.3(11)JX1 or later releases.

### Examples

This example shows how to clear an access point's current LWAPP private configuration:

```
AP# clear lwapp private-config
removing the reap config file flash:/lwapp_reap.cfg
```

### Related Commands

**debug capwap**  
**debug capwap reap**  
**debug lwapp console cli**  
**show capwap reap association**  
**show capwap reap status**

## debug Commands

This section lists the **debug** commands to manage debugging of access points managed by the controller.



#### Caution

Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

## debug ap

To configure the remote debugging of Cisco lightweight access points or to remotely execute a command on a lightweight access point, use the **debug ap** command.

**debug ap** {enable | disable | command *cmd*} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the debugging on a lightweight access point.
	<b>Note</b> The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<b>disable</b>	Disables the debugging on a lightweight access point.
	<b>Note</b> The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<b>command</b>	Specifies that a CLI command is to be executed on the access point.
<i>cmd</i>	Command to be executed.
	<b>Note</b> The command to be executed must be enclosed in double quotes, such as <b>debug ap command "led flash 30" AP03</b> . The output of the command displays only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<i>cisco_ap</i>	Name of a Cisco lightweight access point.

### Command Default

Disabled.

### Examples

This example shows how to enable the remote debugging on access point AP01:

```
> debug ap enable AP01
```

This example shows how to execute the **config ap location** command on access point AP02:

```
> debug ap command "config ap location "Building 1" AP02"
```

This example shows how to execute the flash LED command on access point AP03:

```
> debug ap command "led flash 30" AP03
```

### Related Commands

**show sysinfo**  
**config sysname**

## debug ap enable

To configure the remote debugging of Cisco lightweight access points or to remotely execute a command on a lightweight access point, use the **debug ap enable** command.

**debug ap** {enable | disable | command *cmd*} *cisco\_ap*

### Syntax Description

<b>enable</b>	Enables the remote debugging.  <b>Note</b> The debugging information is displayed only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<b>disable</b>	Disables the remote debugging.
<b>command</b>	Specifies that a CLI command is to be executed on the access point.
<i>cmd</i>	Command to be executed.  <b>Note</b> The command to be executed must be enclosed in double quotes, such as <b>debug ap command "led flash 30" AP03</b> .  The output of the command displays only to the controller console and does not send output to a controller Telnet/SSH CLI session.
<i>cisco_ap</i>	Cisco lightweight access point name.

### Command Default

None.

### Examples

This example shows how to enable the remote debugging on access point AP01:

```
> debug ap enable AP01
```

This example shows how to disable the remote debugging on access point AP02:

```
> debug ap disable AP02
```

This example shows how to execute the flash LED command on access point AP03:

```
> debug ap command "led flash 30" AP03
```

### Related Commands

show sysinfo  
config sysname

## debug ap packet-dump

To configure the debugging of Packet Capture, use the **debug ap packet-dump** command.

**debug ap packet-dump {enable | disable}**

Syntax Description	<b>enable</b>	Enables the debugging of Packet Capture of an access point.
	<b>disable</b>	Disables the debugging of Packet Capture of an access point.

**Command Default** Disabled.

**Usage Guidelines** Packet Capture does not work during inter-Cisco WLC roaming.  
The Cisco WLC does not capture packets created in the radio firmware and sent out of the access point, such as beacon or probe response. Only packets that flow through the radio driver in the Tx path will be captured.

**Examples** This example shows how to enable the debugging of Packet Capture from an access point:  
> **debug ap packet-dump enable**

**Related Commands** **config ap packet-dump**  
**show ap packet-dump status**

## debug ap show stats

To debug video messages and statistics of Cisco lightweight access points, use the **debug ap show stats** command.

**debug ap show stats** {**802.11a** | **802.11b**} *cisco\_ap* {**tx-queue** | **packet** | **load** | **multicast** | **client** {*client\_MAC* | **video** | **all**} | **video metrics**}

**debug ap show stats video** *cisco\_ap* {**multicast mgid** *mgid\_database\_number* | **admission** | **bandwidth**}

### Syntax Description

<b>802.11a</b>	Specifies the 802.11a network.
<b>802.11b</b>	Specifies the 802.11b/g network.
<i>cisco_ap</i>	Cisco lightweight access point name.
<b>tx-queue</b>	Displays the transmit queue traffic statistics of the AP.
<b>packet</b>	Displays the packet statistics of the AP.
<b>load</b>	Displays the QoS Basic Service Set (QBSS) and other statistics of the AP.
<b>multicast</b>	Displays the multicast supported rate statistics of the AP.
<b>client</b>	Displays the specified client metric statistics.
<i>client_MAC</i>	MAC address of the client.
<b>video</b>	Displays video statistics of all clients on the AP.
<b>all</b>	Displays statistics of all clients on the AP.
<b>video metrics</b>	Displays the video metric statistics.
<b>mgid</b>	Displays detailed multicast information for a single multicast group ID (MGID).
<i>mgid_database_number</i>	Layer 2 MGID database number.
<b>admission</b>	Displays video admission control on the AP.
<b>bandwidth</b>	Displays video bandwidth on the AP.

### Command Default

None.

## Examples

This example shows how to troubleshoot the access point AP01's transmit queue traffic on an 802.11a network:

```
> debug ap show stats 802.11a AP01 tx-queue
```

This example shows how to troubleshoot the access point AP02's multicast supported rates on an 802.11b/g network:

```
> debug ap show stats 802.11b AP02 multicast
```

This example shows how to troubleshoot the metrics of a client identified by its MAC address, associated with the access point AP01 on an 802.11a network:

```
> debug ap show stats 802.11a AP01 client 00:40:96:a8:f7:98
```

This example shows how to troubleshoot the metrics of all clients associated with the access point AP01 on an 802.11a network:

```
> debug ap show stats 802.11a AP01 client all
```

## Related Commands

**debug ap show stats video**

## debug ap show stats video

To configure the debugging of video messages and statistics of Cisco lightweight access points, use the **debug ap show stats video** command.

**debug ap show stats video** *cisco\_ap* {**multicast mgid** *mgid\_value* | **admission** | **bandwidth**}

### Syntax Description

<i>cisco_ap</i>	Cisco lightweight access point name.
<b>multicast mgid</b>	Displays multicast database related information for the specified MGID of an access point.
<i>mgid_value</i>	Layer 2 MGID database number from 1 to 4095.
<b>admission</b>	Displays the video admission control.
<b>bandwidth</b>	Displays the video bandwidth.

### Command Default

None.

### Examples

This example shows how to configure the debugging of an access point AP01's multicast group that is identified by the group's Layer 2 MGID database number:

```
> debug ap show stats video AP01 multicast mgid 50
```

This example shows how to configure the debugging of an access point AP01's video bandwidth:

```
> debug ap show stats video AP01 bandwidth
```

### Related Commands

**debug ap show stats**



## debug capwap

To configure the debugging of Control and Provisioning of Wireless Access Points (CAPWAP) settings, use the **debug capwap** command.

**debug capwap** {**detail** | **dtls-keepalive** | **errors** | **events** | **hexdump** | **info** | **packet** | **payload**} {**enable** | **disable**}

### Syntax Description

<b>detail</b>	Configures the debugging for CAPWAP detail settings.
<b>dtls-keepalive</b>	Configures the debugging for CAPWAP DTLS data keepalive packets settings.
<b>errors</b>	Configures the debugging for CAPWAP error settings.
<b>events</b>	Configures the debugging for CAPWAP events settings.
<b>hexdump</b>	Configures the debugging for CAPWAP hexadecimal dump settings.
<b>info</b>	Configures the debugging for CAPWAP info settings.
<b>packet</b>	Configures the debugging for CAPWAP packet settings.
<b>payload</b>	Configures the debugging for CAPWAP payload settings.
<b>enable</b>	Enables the debugging of the CAPWAP command.
<b>disable</b>	Disables the debugging of the CAPWAP command.

### Command Default

None.

### Examples

This example shows how to enable the debugging of CAPWAP details:

```
> debug capwap detail enable
```

### Related Commands

**clear lwapp private-config**  
**debug disable-all**  
**show capwap reap association**  
**show capwap reap status**

## debug group

To configure the debugging of access point groups, use the **debug group** command.

**debug group** {enable | disable}

### Syntax Description

<b>enable</b>	Enables the debugging of access point groups.
<b>disable</b>	Disables the debugging of access point groups.

### Command Default

None.

### Examples

This example shows how to enable the debugging of access point groups:

```
> debug group enable
```

### Related Commands

**config guest-lan nac**  
**config wlan apgroup**  
**config wlan nac**

## debug lwapp console cli

To configure the debugging of the access point console CLI, use the **debug lwapp console cli** command from the access point console port.

**debug lwapp console cli**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Usage Guidelines** This access point CLI command must be entered from the access point console port.

**Examples** This example shows how to configure the debugging of the access point console:

```
AP# debug lwapp console cli
LWAPP console CLI allow/disallow debugging is on
```

**Related Commands**

- debug disable-all**
- debug ap**
- clear lwapp private-config**

## debug redundancy-link-encryption

To configure the debugging of redundancy link encryption, use the **debug redundancy-link-encryption** command.

**debug redundancy-link-encryption** {all | detail | events | errors} {enable | disable}

### Syntax Description

<b>all</b>	Configures the debugging of all redundancy link encryption logs.
<b>detail</b>	Configures the debugging of redundancy link encryption detail messages.
<b>events</b>	Configures the debugging of redundancy link encryption events.
<b>errors</b>	Configures the debugging of redundancy link encryption errors.
<b>enable</b>	Enables the debugging of redundancy link encryption.
<b>disable</b>	Disables the debugging of redundancy link encryption.

### Command Default

None.

### Examples

This example shows how to enable the debugging of all redundancy link encryption:

```
> debug redundancy-link-encryption all enable
```

### Related Commands

config redundancy mobilitymac  
 config redundancy interface address peer-service-port  
 config redundancy peer-route  
 config redundancy unit  
 config redundancy timer  
 show redundancy peer-route  
 show redundancy summary  
 debug rmgr  
 debug rsyncmgr

## debug rfac

To configure the debugging of the Redundancy Framework (RFAC), use the **debug rfac** command.

**debug rfac** {[packet | events | errors | detail] [enable | disable]}

### Syntax Description

<b>packet</b>	Configures the debugging of Redundancy Framework packets.
<b>events</b>	Configures the debugging of Redundancy Framework events.
<b>errors</b>	Configures the debugging of Redundancy Framework errors.
<b>detail</b>	Configures the debugging of Redundancy Framework details.
<b>enable</b>	(Optional) Enables the debugging of Redundancy Framework.
<b>disable</b>	(Optional) Disables the debugging of Redundancy Framework.

### Command Default

None.

### Examples

This example shows how to enable the debugging of Redundancy Framework packets:

```
> debug rfac packet enable
```

### Related Commands

**debug rmgr**  
**debug rsyncmgr**  
**config interface address redundancy-management**  
**show redundancy summary**

## debug rmgr

To configure the debugging of Redundancy Manager (RMGR), use the **debug rmgr** command.

**debug rmgr {packet | events | errors | detail} {enable | disable}**

### Syntax Description

<b>packet</b>	Configures the debugging of Redundancy Manager packets.
<b>events</b>	Configures the debugging of Redundancy Manager events.
<b>errors</b>	Configures the debugging of Redundancy Manager errors.
<b>detail</b>	Configures the debugging of Redundancy Manager details.
<b>enable</b>	Enables the debugging of Redundancy Manager.
<b>disable</b>	Disables the debugging of Redundancy Manager.

### Command Default

None.

### Usage Guidelines

Redundancy Manager determines the role of the Cisco WLCs, maintains the keepalive messages between the peers, and initiates the switchover.

### Examples

This example shows how to enable the debugging of Redundancy Manager packets:

```
> debug rmgr packet enable
```

### Related Commands

**config interface address redundancy-management**  
**debug rfac**  
**debug rsyncmgr**  
**show redundancy summary**

## debug rsyncmgr

To configure the debugging of the Redundancy Sync Manager (RSYNCMGR), use the **debug rsyncmgr** command.

**debug rsyncmgr** {packet | events | errors | detail} {enable | disable}

### Syntax Description

<b>packet</b>	Configures the debugging of Redundancy Sync Manager packets.
<b>events</b>	Configures the debugging of Redundancy Sync Manager events.
<b>errors</b>	Configures the debugging of Redundancy Sync Manager errors.
<b>detail</b>	Configures the debugging of Redundancy Sync Manager details.
<b>enable</b>	Enables the debugging of Redundancy Sync Manager.
<b>disable</b>	Stops the debugging Redundancy Sync Manager.

### Command Default

None.

### Usage Guidelines

Redundancy Synchronization Manager synchronizes the configurations of the active and standby Cisco WLCs.

### Examples

This example shows how to enable the debugging of Redundancy Sync Manager packets:

```
> debug rsyncmgr packet enable
```

### Related Commands

**debug rfac**  
**debug rmgr**  
**config interface address redundancy-management**  
**show redundancy summary**

## debug service ap-monitor

To debug the access point monitor service, use the **debug service ap-monitor** command.

**debug service ap-monitor** {all | error | event | nmosp | packet} {enable | disable}

### Syntax Description

<b>all</b>	Configures the debugging of all access point status messages.
<b>error</b>	Configures the debugging of access point monitor error events.
<b>event</b>	Configures the debugging of access point monitor events.
<b>nmosp</b>	Configures the debugging of access point monitor Network Mobility Services Protocol (NMSP) events.
<b>packet</b>	Configures the debugging of access point monitor packets.
<b>enable</b>	Enables the debugging for access point monitor service.
<b>disable</b>	Disables the debugging for access point monitor service.

### Command Default

None.

### Examples

This example shows how to configure the debugging of access point monitor NMSP events:

```
> debug service ap-monitor events
```

### Related Commands

**debug disable-all**  
**show snmp status**



# transfer download peer-start

To download a file to the peer controller, use the **transfer download peer-start** command.

**transfer download peer-start**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

## Examples

This example shows how to start downloading a file to the peer controller:

```
> transfer download peer-start In commandTransferDownloadPeerStart

Mode.....TFTP
Data Type.....Login Banner
TFTP Server IP.....9.1.0.100
TFTP Packet Timeout.....6
TFTP Max Retries.....10
TFTP Path.....dhk/
TFTP Filename.....xyz

Are you sure you want to start download on standby? (y/N) y
In commandTransferDownloadPeerStart
In usmDbTransferDownStartSet.. dir: 2 ---> Indicates L7_TRANSFER_DIRECTION_DOWN_STANDBY
usmDbTransferDownStartSet: SUCCESS
In commandTransferDownloadPeerStart

TFTP Config transfer starting.
In commandTransferDownloadPeerStart

% Error: Config file transfer failed - Error from server: File not found
```

## Related Commands

clear transfer  
 transfer upload filename  
 transfer upload mode  
 transfer upload pac  
 transfer upload password  
 transfer upload path  
 transfer upload port  
 transfer upload serverip  
 transfer upload datatype  
 transfer upload username  
 transfer upload peer-start  
 reset peer-start

## transfer upload peer-start

To upload a file to the peer controller, use the **transfer upload peer-start** command.

**transfer upload peer-start**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Examples** This example shows how to start uploading a file to the peer controller:

```
> transfer upload peer-start
Mode..... FTP
FTP Server IP..... 209.165.201.1
FTP Server Port..... 21
FTP Path..... /builds/nimm/
FTP Filename..... AS_5500_7_4_1_20.aes
FTP Username..... wnbu
FTP Password..... *****
Data Type..... Error Log

Are you sure you want to start upload from standby? (y/N) n

Transfer Canceled
```

**Related Commands**

- clear transfer**
- transfer upload filename**
- transfer upload mode**
- transfer upload pac**
- transfer upload password**
- transfer upload path**
- transfer upload port**
- transfer upload serverip**
- transfer upload datatype**
- transfer upload username**
- transfer download peer-start**

## Resetting the System Reboot Time

Use the **reset** command to schedule a reboot of the controller and access points.

## reset system at

To reset the system at a specified time, use the **reset system at** command.

**reset system at YYYY-MM-DD HH:MM:SS image {no-swap|swap} reset-aps [save-config]**

Syntax	Description
<b>YYYY-MM-DD</b>	Specifies the date.
<b>HH: MM: SS</b>	Specifies the time in a 24-hour format.
<b>image</b>	Configures the image to be rebooted.
<b>swap</b>	Changes the active boot image.
<b>no-swap</b>	Boots from the active image.
<b>reset-aps</b>	Resets all access points during the system reset.
<b>save-config</b>	(Optional) Saves the configuration before the system reset.

**Command Default** None.

**Examples** This example shows how to reset the system at 2010-03-29 and 12:01:01 time:

```
> reset system at 2010-03-29 12:01:01 image swap reset-aps save-config
```

**Related Commands**

- reset system notify-time
- reset system in

## reset system in

To specify the amount of time delay before the devices reboot, use the **reset system in** command.

**reset system in HH:MM:SS image {swap | no-swap} reset-aps save-config**

### Syntax Description

<b>HH :MM :SS</b>	Specifies a delay in duration.
<b>image</b>	Configures the image to be rebooted.
<b>swap</b>	Changes the active boot image.
<b>no-swap</b>	Boots from the active image.
<b>reset-aps</b>	Resets all access points during the system reset.
<b>save-config</b>	Saves the configuration before the system reset.

### Command Default

None.

### Examples

This example shows how to reset the system after a delay of 00:01:01:

```
> reset system in 00:01:01 image swap reset-aps save-config
```

### Related Commands

**reset system notify-time**

**reset system at**

## reset system cancel

To cancel a scheduled reset, use the **reset system cancel** command.

**reset system cancel**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to cancel a scheduled reset:
-----------------	---

```
> reset system cancel
```

<b>Related Commands</b>	<b>reset system at</b> <b>reset system in</b> <b>reset system notify-time</b>
-------------------------	---

## reset system notify-time

To configure the trap generation prior to scheduled resets, use the **reset system notify-time** command.

**reset system notify-time** *minutes*

### Syntax Description

<i>minutes</i>	Number of minutes before each scheduled reset at which to generate a trap.
----------------	--

### Command Default

The default is 10 minutes.

### Examples

This example shows how to configure the trap generation to 10 minutes before the scheduled resets:

```
> reset system notify-time 55
```

### Related Commands

**reset system in**  
**reset system at**

## reset peer-system

To reset the peer controller, use the **reset peer-system** command.

**reset peer-system**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None.
------------------------	-------

<b>Examples</b>	This example shows how to reset the peer controller: <pre>&gt; reset peer-system</pre>
-----------------	---

<b>Related Commands</b>	<b>reset system notify-time</b> <b>reset system in</b>
-------------------------	---

## test Commands

This section lists the **test** commands for access points.

## test ap pmtu

To enable or disable the Path Maximum Transmission Unit (PMTU) on the CAPWAP tunnel of a Cisco access point, use the **test ap** command.

**test ap pmtu** {enable | disable} *cisco\_ap*

### Syntax Description

<b>enable</b>	Disables PMTU on the CAPWAP tunnel of a Cisco access point.
<b>disable</b>	Enables PMTU on the CAPWAP tunnel of a Cisco access point.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.

### Command Default

None.

### Examples

This example shows how to enable PMTU on the CAPWAP tunnel of a Cisco access point:

```
> test ap pmtu enable AP1600_1
```

### Related Commands

**test ap**  
**test capwap**  
**test ccx**  
**test cleanair**  
**test ftpstatus**  
**test lic-agent**  
**test license**  
**test log**  
**test make-space**  
**test media**  
**test reader**  
**test redundancy**  
**test rrm**  
**test sip-cac-fail**  
**test token-bucket**  
**test wlan**



## test capwap

To configure an access point to send broadcast radio measurement requests to clients, or to enable the encryption of control packets that are sent between the access point and the controller, use the **test capwap** command.

**test capwap** {**message** *token cisco\_ap* | **encr** *cisco\_ap* {**enable** | **disable**}}

### Syntax Description

<b>message</b>	Configures the access point to send a broadcast radio measurement requests to clients.
<i>token</i>	Time interval for the access point to send a broadcast radio measurement requests to clients.
<i>cisco_ap</i>	Name of the Cisco lightweight access point.
<b>encr</b>	Encrypts or decrypts the control packets that are sent between the access point and the controller.
<b>enable</b>	Enables the encryption or decryption of control packets that are sent between the access point and the controller.
<b>disable</b>	Disables the encryption or decryption of control packets that are sent between the access point and the controller.

### Command Default

None.

### Examples

This example shows how to enable encryption of control packets:

```
> test capwap encr A_1500_1 enable
```

### Related Commands

**test ap**  
**test capwap**  
**test ccx**  
**test cleanair**  
**test ftpstatus**  
**test lic-agent**  
**test license**  
**test log**  
**test make-space**  
**test media**  
**test reader**

**test redundancy**

**test rrm**

**test sip-cac-fail**

**test token-bucket**

**test wlan**