



# CHAPTER 2

## Opening and using the IMM Web interface

---

The IMM combines service processor functions and a video controller in a single chip. To access the IMM remotely by using the IMM Web interface, you must first log in. This chapter describes the login procedures and the actions that you can perform from the IMM Web interface.

### Accessing the IMM Web interface

The IMM supports both static and Dynamic Host Configuration Protocol (DHCP) IP addressing. The default static IP address assigned to the IMM is 192.168.70.125. The IMM is initially configured to attempt to obtain an address from a DHCP server, and if it cannot, it uses the static IP address.

The IMM provides the choice of using a dedicated systems-management network connection or one that is shared with the server.

For setting up the IMM network connection, the approach depends on the product. For example, the Cisco Flex 7500 Series Wireless Controller provides a CLI command to configure IMM access, whereas the Cisco 3355 Mobility Services Engine provides a script (immconfig.sh). Refer to the product-specific configuration document for details.

### Logging in to the IMM

**Important:** The IMM is set initially with a user name of USERID and password of PASSW0RD (with a zero, not the letter O). This default user setting has Supervisor access. Change this default password during your initial configuration for enhanced security.

To access the IMM through the IMM Web interface, complete the following steps:

- 
- Step 1** Open a Web browser. In the address or URL field, type the IP address or host name of the IMM server to which you want to connect.

## Logging in to the IMM

**Login**

User Name

Password

- Step 2** Type your user name and password in the IMM Login window. If you are using the IMM for the first time, you can obtain your user name and password from your system administrator. All login attempts are documented in the event log. Depending on how your system administrator configured the user name, you might need to enter a new password. The default user name is USERID and the default password is PASSW0RD (with a zero).
- Step 3** On the Welcome Web page, select a timeout value from the drop-down list in the field that is provided. If your browser is inactive for that number of minutes, the IMM logs you off the Web interface.



**Note** Depending on how your system administrator configured the global login settings, the timeout value might be a fixed value.

**Welcome USERID.**  
Opening web session to 172.19.35.238

Your session will expire if no activity occurs for the specified timeout period. Then, you will be prompted to sign in again using your login ID and password. Select the desired timeout period below and click "Continue" to start your session.

Inactive session timeout value:

1 minute  
5 minutes  
10 minutes  
15 minutes  
20 minutes

**Note:** To ensure security and to prevent unauthorized access, always end your sessions using the "Log Off" option in the navigation panel.

© Copyright IBM Corp. 2007-2010. All rights reserved.

**Step 4** Click **Continue** to start the session.

The browser opens the System Status page, which gives you a quick view of the server status and the server health summary.

The screenshot shows the IMM Web interface with the title "Integrated Management Module". The left sidebar has a dark background with white text. It displays the server serial number "SN# KQ098M5" and a navigation menu with the following items:

- System
  - Monitors
  - System Status** (selected)
  - Virtual Light Path
  - Event Log
  - Vital Product Data
- Tasks
  - Power/Restart
  - Remote Control
  - PXE Network Boot
  - Firmware Update
- IMM Control
  - System Settings
  - Login Profiles
  - Alerts
  - Serial Port
  - Port Assignments
  - Network Interfaces
  - Network Protocols
  - Security
  - Configuration File
  - Restore Defaults
  - Restart IMM

At the bottom of the sidebar is a "Log Off" link. The main content area has a light gray background. It contains the following sections:

- System Status**: A section with a question mark icon. It says "The following links can be used to view status details." and lists several links: [System Health Summary](#), [Temperatures](#), [Voltages](#), [Fans](#), [View Latest OS Failure Screen](#), [Users Currently Logged in to the IMM](#), and [System Locator LED](#).
- System Health Summary**: A section with a question mark icon. It shows "Server power: Off" and "Server state: System power off/State unknown". Below this is a note: "Some of the monitored parameters are abnormal. Scroll down for details about temperatures, voltages and fan speeds." There is also a "Critical Events" section with one item: "Redundancy Lost for 'Power Group 1' has asserted".
- Environmentals**: A section with a question mark icon. It shows "Temperatures (°F/°C)". A table titled "Temperatures" is displayed with two rows: "Component" and "Ambient Temp". The "Value" column shows "73.40/ 23.00" and the "View Thresholds" column has a link "Thresholds".

For descriptions of the actions that you can perform from the links in the left navigation pane of the IMM Web interface, see “[IMM action descriptions](#)” section on page 2-3. Then, go to [Chapter 3, “Configuring the IMM”](#).

## IMM action descriptions

[Table 2-1](#) lists the actions that are available when you are logged in to the IMM.

**Table 2-1** **IMM Actions**

Link	Action	Description
System Status	View system health for a server, view the operating-system-failure screen capture, and view the users who are logged in to the IMM	You can monitor the server power and health state, and the temperature, voltage, and fan status of your server on the System Health page. You can also view the image of the last operating-system-failure screen capture and the users who are logged in to the IMM.
Virtual Light Path	View the name, color, and status of every LED on the server light path	The Virtual Light Path page displays the current status of the LEDs on the server.

**■ IMM action descriptions****Table 2-1** **IMM Actions (continued)**

<b>Link</b>	<b>Action</b>	<b>Description</b>
Event Log	View event logs for remote servers	The Event Log page contains entries that are currently stored in the chassis-event log. The log includes a text description of events that are reported by the BMC, plus information about all remote access attempts and configuration changes. All events in the log are time stamped, using the IMM date and time settings. Some events also generate alerts, if they are configured to do so on the Alerts page. You can sort and filter events in the event log.
Vital Product Data	View the server vital product data (VPD)	The IMM collects server information, server firmware information, and server component VPD. This data is available from the Vital Product Data page.
Power/Restart	Remotely turn on or restart a server	The IMM provides full remote power control over your server with power-on, power-off, and restart actions. In addition, power-on and restart statistics are captured and displayed to show server hardware availability.
Remote Control	Redirect the server video console and use your computer disk drive or disk image as a drive on the server	This feature is not supported.
PXE Network Boot	Change the host server startup (boot) sequence for the next restart to attempt a Preboot Execution Environment (PXE)/Dynamic Host Configuration Protocol (DHCP) network startup	This operation is not supported.
Firmware Update	Update the firmware on the IMM	Do not attempt to update the firmware on the system without proper directions from Cisco TAC. You should update the firmware, as directed by Cisco TAC, and with the firmware certified and released by Cisco. Failure to follow these guidelines can render your system inoperable.
System Settings	View and change the IMM server settings	You can configure the server location and general information, such as the name of the IMM, server timeout settings, and contact information for the IMM, from the System Settings page.
	Set the IMM clock	You can set the IMM clock that is used for time stamping the entries in the event log.
	Enable or disable the USB in-band interface	You can enable or disable the USB in-band (or LAN over USB) interface.   <b>Note</b> This operation is not supported on the Cisco Flex Series 7500 Wireless Controller.
Login Profiles	Configure the IMM login profiles and global login settings	You can define up to 12 login profiles that enable access to the IMM. You can also define global login settings that apply to all login profiles, including enabling Lightweight Directory Access Protocol (LDAP) server authentication and customizing the account security level.

**Table 2-1** IMM Actions (continued)

Link	Action	Description
Alerts	Configure remote alerts and remote alert recipients	You can configure the IMM to generate and forward alerts for different events. On the Alerts page, you can configure the alerts that are monitored and the recipients that are notified.
	Configure Simple Network Management Protocol (SNMP) events	 You can set the event categories for which SNMP traps are sent.
	Configure alert settings	You can establish global settings that apply to all remote alert recipients, such as the number of alert retries and the delay between the retries.
Serial Port	Configure the IMM serial port settings	Serial port is dedicated for the serial console redirection function. Therefore, it cannot be used for IMM.
Port Assignments	Change the port numbers of the IMM protocols	From the Port Assignments page, you can view and change the port numbers assigned to the IMM protocols (for example, HTTP, HTTPS, Telnet, and SNMP).
Network Interfaces	Configure the network interfaces of the IMM	From the Network Interfaces page, you can configure network-access settings for the Ethernet connection on the IMM.
Network Protocols	Configure the network protocols of the IMM	You can configure Simple Network Management Protocol (SNMP), Domain Name System (DNS), and Simple Mail Transfer Protocol (SMTP) settings that are used by the IMM from the Network Protocols page. You can also configure LDAP parameters.
Security	Configure the Secure Sockets Layer (SSL)	You can enable or disable SSL and manage the SSL certificates that are used. You can also enable or disable whether an SSL connection is used to connect to an LDAP server.
	Enable Secure Shell (SSH) access	You can enable SSH access to the IMM.
Configuration	Back up and restore the IMM configuration	You can back up, modify, and restore the configuration of the IMM, and view a configuration summary, from the Configuration File page.
Restore Default Settings	Restore the IMM default settings	<b>Attention:</b> When you click <b>Restore Defaults</b> , all of the modifications that you made to the IMM are lost. You can reset the configuration of the IMM to the factory defaults.
Restart IMM	Restart the IMM	You can restart the IMM.
Log off	Log off the IMM	You can log off your connection to the IMM.

You can click the **View Configuration Summary** link, which is in the top-right corner on most pages, to quickly view the configuration of the IMM.

■ IMM action descriptions