



Cisco Integrated Services Router Generation 2 Network Manageability Guide

First Published: October 8, 2009

Last Updated: February 4, 2011

This document provides information about new and changed Management Information Databases (MIBs), new Simple Network Management Protocol (SNMP) traps, new and critical system log(SYSLOG) messages, and new Cisco Internet Operating System (IOS) commands for the Integrated Services Router Generation 2 (ISR G2) routers. It also includes new commands that are critical to monitor the network, and information to diagnose and troubleshoot network problems.

In addition, this document provides information about Cisco tools, applications, and technologies for monitoring network performance and managing Cisco ISR G2 devices on the borderless network. These tools, applications, and technologies are designed to keep devices interacting in a secure and reliable fashion so network configurations and connectivity is maintained across network borders for the seamless delivery of voice- and video-ready applications and services.

Contents

- [About this Document, page 2](#)
- [Interface Numbering Scheme, page 2](#)
- [LED Indicators, page 4](#)
- [New MIBs, page 6](#)
- [Simple Network Management Protocol, page 13](#)
- [Critical SNMP Traps, page 13](#)
- [Critical Syslog Messages, page 14](#)
- [Network Management Tools, Applications, and Technologies, page 31](#)
- [Cisco IOS Command Reference, page 41](#)
- [Additional References, page 93](#)



Americas Headquarters:

Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

About this Document

The following topics cover network management features provided on the ISR G2 routers. It also provides information about Cisco tools, applications, and technologies that let you monitor network performance and manage devices on the borderless network.

Table 1 lists the topics in this document.

Table 1 **Document topics**

Topic	Description
Interface Numbering Scheme	Describes interface numbering on the ISR G2 platforms, command line syntax to configure the interface, and the physical slot and port assignments.
LED Indicators	Describes the LED status for modules and interfaces on the ISR G2 platforms.
New MIBs	Describes new and changed MIBs for the ISR G2 platforms.
Simple Network Management Protocol	Describes new and critical SNMP traps.
Critical Syslog Messages	Describes critical syslog messages for the ISR G2 platforms.
Network Management Tools, Applications, and Technologies	Provides links to documents that describe Cisco Network Management tools, applications, and technologies that are supported on ISR G2 platforms.
Cisco IOS Command Reference	Describes new commands released with the ISR G2s platforms.
Additional References	Provides additional network management resources.

Interface Numbering Scheme

Before you configure an interface, you must know the physical location of the module in the chassis, and the slot and port assignment. The interface numbering follows the three-tier interface numbering scheme.

This section provides a rough summary of the new slot numbering convention on the ISR G2 platform. For the specific slot numbering of each module, see the router's hardware installation guide.

- Motherboard is slot 0.
- Embedded Service Engine is slot 0.
- Service Module slots are numbered from 1 to 4.
- EHWICs are numbered from 0 to 3.
- ISM slot is 0.

Command Line Syntax

- Command line syntax for interfaces in the SM slot appears as follows, *interface name* **slot/port**
- Command line syntax for interfaces in the WIC slot of a SM follows, *interface name* **slot/subslot/port**

Table 2 describes the interface numbering scheme for modules in the Cisco 1900, 2901, 2911, 2921, 2951, 3925, 3925E, 3945, and 3945E ISR G2 platforms.

Table 2 **Interface Numbering Scheme**

Module	Cisco 1900	Cisco 2901	Cisco 2911 Cisco 2921	Cisco 2951 Cisco 3925 Cisco 3945	Cisco 3925E Cisco 3945E
Onboard GE ports	GigabitEthernet0/0 GigabitEthernet0/1	GigabitEthernet0/0 GigabitEthernet0/1	GigabitEthernet0/0 GigabitEthernet0/1	GigabitEthernet0/0 GigabitEthernet0/1 GigabitEthernet0/2	GigabitEthernet0/0 GigabitEthernet0/1 GigabitEthernet0/2 GigabitEthernet0/3
Onboard WLAN	Wlan-ap0	—	—	—	—
Onboard WLAN-GE switch port	Wlan-GigabitEthernet 0/0	—	—	—	—
Onboard ISM interface on the PCIe	ism 0/0	ism 0/0	ism 0/0	ism 0/0	N/A
Onboard ISM interface to the MGF switch	ism 0/1	ism 0/1	ism 0/1	ism 0/1	N/A
SM interface on the PCIe	sm 0/0	sm 0/0	sm 0/0	sm 0/0	sm 0/0
SM interface to the MGF	sm 0/1	sm 0/1	sm 0/1	sm 0/1	sm 0/1
Interfaces on (H/V)WIC	<int>0/0/<port> <int>0/1/<port>	<int>0/0/<port> <int>0/1/<port> <int>0/2/<port> <int>0/3/<port>	<int>0/0/<port> <int>0/1/<port> <int>0/2/<port> <int>0/3/<port>	<int>0/0/<port> <int>0/1/<port> <int>0/2/<port> <int>0/3/<port>	<int>0/0/<port> <int>0/1/<port> <int>0/2/<port>
Interfaces on DW-HWIC	<int>0/1/<port>	<int>0/1/<port> <int>0/3/<port>	<int>0/1/<port> <int>0/3/<port>	<int>0/1/<port> <int>0/3/<port>	<int>0/1/<port>
Interfaces on SM	—	—	<int>1/<port>	<int><1-2>/<port> ¹ <int><1-3>/<port> ² <int><1-4>/<port> ⁴	<int><1-2>/<port> ³ <int><1-4>/<port> ⁴
Interfaces on DW-SM	—	—	—	<int><2>/<port> ³ <int><4>/<port> ⁴	<int><4>/<port> ⁵ <int><4>/<port> ⁶
Interfaces on (H/V)WIC on SM	—	—	<int>1/<wic-slot>/<port>	<int><1-2>/<wic-slot>/<port> ⁷ <int><1-4>/<wic-slot>/<port> ⁸	<int><1-2>/<wic-slot>/<port> ⁹ <int><1-4>/<wic-slot>/<port> ¹⁰

1. Supports only Cisco 2951 platform.
2. Supports only Cisco 3925 and Cisco 3925E platforms.
3. Supports only Cisco 2951 and 3925 platforms.
4. Supports only Cisco 3945 platform.
5. Supports only Cisco 3945E platform.
6. Supports only Cisco 3925E platforms.
7. Supports only Cisco 3925 platform.
8. Supports only Cisco 3945 platform.
9. Supports only Cisco 3925E platform.
10. Supports only Cisco 3945E platform.

LED Indicators

This section provides an all inclusive list of LED indicators that appear on the modules and ISR G2 platforms that are noted in [Table 3](#), [Table 4](#), and [Table 5](#).



Note See your router's hardware installation guide for specific LEDs that appear on the platform that you purchased.

- [Indicators for Dual Color LEDs, page 4](#)
- [Indicators for Router LEDs, page 4](#)
- [Indicators for Service Module LEDs, page 6](#)

Table 3 *Indicators for Dual Color LEDs*

Color	Description
Off	Power off and the module is not installed
Green	Power on and the module is installed
Amber	Power on and the module is in failure status

Table 4 *Indicators for Router LEDs*

LED Label	Color	Description
SYS	Green	System is active
	Blinking Green	System is booting up
	Amber	System failed
	Blinking Amber	ROMMON failed
ACT	Green	Packet activity
	Blinking Green	
POE PWR	Green	IP phone power is available
	Amber	IP phone power is not available
RPS	Green	System is running on RPS power

Table 4 **Indicators for Router LEDs**

LED Label	Color	Description
SYS PWR1	Green	PSU1 active
	Amber	PSU1 is failed
POE PWR1	Green	POE PSU1 is available
	Amber	POE PSU1 is failed
SYS PWR2	Green	PSU2 is active
	Amber	PSU2 is failed
POE PWR2	Green	POE PSU2 is available
	Amber	POE PSU2 is failed
CON/AUX	Green	Indicates CON/AUX operation
USB CON	Green	Indicates USB Console operation
GE Link	Green	GE port link is up
GE Speed	Blinking Green	Indicates port speed
ISM	Green	ISM is active
	Amber	ISM is failed
PVDM	Green	PVDM is active
	Amber	PVDM is failed
HWIC	Green	HWIC is active
	Amber	HWIC is failed
2.4 GHz	Green	Radio1
5.8 GHz	Green	Radio2
Link	Green	Radio status.
Radio Card Present	Green	Card is present and enabled
	Amber	Reserved
CF	Amber	CF is present and failed
	Blinking Green & OFF	<ul style="list-style-type: none"> When you insert and remove the compact flash drive When you access the compact flash drive by using a software for reading and writing data
USB	Green	USB device is present and active
	Amber	USB device is present and failed
	Blinking Green & OFF	USB is ready for OIR removal
SM	Green	SM is present and active
	Amber	SM is present and failed
	Blinking Green & OFF	SM is ready for OIR removal
	OFF	SM is in shut mode (Energywise)

Table 4 Indicators for Router LEDs

LED Label	Color	Description
SFP	Amber	SFP is present and in failure mode
	OFF	SFP is not active and ready for OIR removal

Table 5 Indicators for Service Module LEDs

Configuration	Failure Condition	SM LED	SM Adaptor LED	NM LED	Description
SM Adaptor only	None	—	Amber	—	SM adaptor is plugged in at boot up and analyzed. If there is no NM, the adaptor is powered off.
SM Adaptor only	SM adaptor analyze fails	—	Amber	—	Quack or some other analyze failure detected. Console message is logged for errors. If there is no NM, the adaptor is powered off.
SM adaptor + NM	None	—	Green	Green	In working condition.
SM adaptor + NM	SM adaptor analyze fails	—	Amber	OFF	Quack, or some other analyze failure detected on the adaptor. After the Adaptor fails, the NM is not analyzed.
SM adaptor + NM	NM analyze fails	—	Amber	OFF	Quack, or some other analyze failure detected on the NM.
SM	None	Green	—	—	In working condition.
SM	SM analyze fails	Amber	—	—	Quack, or some other analyze failure detected on the SM.
SM	SM application failure	Green	—	—	SM application failure is not reflected on the SM LED. The SM should have specific LED indication for this event.

New MIBs

Cisco Integrated Services Router (ISR) G2 platforms support existing IOS SNMP MIBs, which are also supported in the legacy Integrated Services Router (ISR) platforms.


Note

This section only lists the new and changed MIBs for the ISR G2 platform.

- [Table 6](#) lists the CISCO-ENTITY-VENDOR-OID-MIBs
- [Table 7](#) lists the CISCO-PRODUCT-MIBs
- [Table 8](#) lists the CISCO-LICENSE-MGMT-MIBs

Table 6 CISCO-ENTITY-VENDORTYPE-OID-MIBs

Group	Object	Max Access	Description
cevChassisC1941	cevChassis 803	read only	Supports two EHWIC slots, one ISM and one WLAN slot, and two Gigabit Ethernet ports router.
cevChassisC2901	cevChassis 804	read only	Supports four EHWIC slots, one ISM slot, two PVDM slots, and two Gigabit Ethernet ports router.
cevChassisC2911	cevChassis 805	read only	Supports four EHWIC slots, one SM slot, one ISM slot, two PVDM slots, and three Gigabit Ethernet port router.
cevChassisC2921	cevChassis 806	read only	Supports four EHWIC slots, one SM or one DW-SM slot, one ISM slot, three PVDM slots, and three Gigabit Ethernet port router.
cevChassisC2951	cevChassis 807	read only	Supports four EHWIC slots, two SM or one DW-SM slot, one ISM slot, three PVDM slots, and three Gigabit Ethernet port router.
cevChassisC3925	cevChassis 808	read only	Supports four EHWIC slots, two SM or one SM with one DW-SM slot, one ISM slot, four PVDM slots, and three Gigabit Ethernet port router.
cevChassisC3945	cevChassis 809	read only	Supports four EHWIC slots, four SM or two SM with one DW-SM slot, one ISM slot, four PVDM slots, and three Gigabit Ethernet port router.
cevChassisC1941W	cevChassis 827	read only	Supports two EHWIC slots, one WLAN controller, two Gigabit Ethernet ports router.
cevCpu19412ge	cevModuleCpuType 160	read only	Cisco 1941 motherboard with two Gigabit Ethernet ports router.
cevCpu29012ge	cevModuleCpuType 161	read only	Cisco 2901 motherboard with two Gigabit Ethernet ports router.
cevCpu29113ge	cevModuleCpuType 162	read only	Cisco 2911 Motherboard with three Gigabit Ethernet ports router.
cevCpu29213ge	cevModuleCpuType 163	read only	Cisco 2921 Motherboard with three Gigabit Ethernet ports router.
cevCpu29513ge	cevModuleCpuType 164	read only	Cisco 2951 Motherboard with three Gigabit Ethernet ports router.
cevCpu39253ge	cevModuleCpuType 165	read only	Cisco 3925 Motherboard with three Gigabit Ethernet ports router.
cevCpu39453ge	cevModuleCpuType 166	read only	Cisco 3945 Motherboard with three Gigabit Ethernet ports router.
cevCpu1941w2ge	cevModuleCpuType 168	read only	Cisco 1941 Motherboard with two Gigabit Ethernet ports router and one WLAN Controller.
cevCpu3900SPE2004ge	cevModuleCpuType 179	read only	Cisco 3900 with SPE 200 Motherboard with four Gigabit Ethernet ports router.

Table 6 CISCO-ENTITY-VENDORTYPE-OID-MIBs

Group	Object	Max Access	Description
cevCpu3900SPE2504ge	cevModuleCpuType186	read only	Cisco 3900 with SPE 250 Motherboard with four Gigabit Ethernet ports router.
cevPowerSupplyC3900PWRPOE	cevPowerSupply235	read only	Cisco 3900 PoE Power Supply.
cevPowerSupplyC3900PWRAC	cevPowerSupply236	read only	Cisco 3900 AC Power Supply.
cevPowerSupplyC2921C2951PWRPOE	cevPowerSupply237	read only	Cisco 2921 C2951 PoE Power Supply.
cevPowerSupplyC2921C2951PWRAC	cevPowerSupply238	read only	Cisco 2921 and Cisco 2951 AC Power Supply.
cevPowerSupplyC2911PWRPOE	cevPowerSupply239	read only	Cisco 2911 PoE Power Supply.
cevPowerSupplyC2911PWRAC	cevPowerSupply240	read only	Cisco 2911 AC Power Supply.
cevPowerSupplyC2901PWRPOE	cevPowerSupply241	read only	Cisco 2901 PoE Power Supply.
cevPowerSupplyC2901PWRAC	cevPowerSupply242	read only	Cisco 1941 C2901 AC Power Supply.
cevPowerSupplyC1941PWRPOE	cevPowerSupply243	read only	Cisco 1941 PoE Power Supply.
cevPowerSupplyC3900PWRDC	cevPowerSupply244	read only	Cisco 3900 DC Power Supply.
cevPowerSupplyC2921C2951PWRDC	cevPowerSupply245	read only	Cisco 2921and Cisco 2951 DC Power Supply.
cevPowerSupplyC2911PWRDC	cevPowerSupply246	read only	Cisco 2911 DC Power Supply.
cevPowerSupplyC2921C2951RPSADPTR	cevPowerSupply247	read only	Cisco 2921 C2951 RPS adaptor.
cevPowerSupplyC2911RPSADPTR	cevPowerSupply248	read only	Cisco 2911 RPS adaptor.
cevPowerSupplyC1941PWRAC	cevPowerSupply271	read only	Cisco 1941 AC Power Supply.

Table 7 lists the CISCO-PRODUCT-MIBs

Table 7 CISCO-PRODUCT-MIBs

Group	Object	Max Access	Description
cisco3945K9	ciscoProducts 1041	read only	CISCO3945/K9 with SPE150 (three GE, four EHWIC, four DSP, four SM, 256MB CF, 1GB DRAM, IPB).
cisco3925K9	ciscoProducts 1042	read only	CISCO3925/K9 with SPE100(three GE, four EHWIC, four DSP, two SM, 256MB CF, 1GB DRAM, IPB).

Table 7 *CISCO-PRODUCT-MIBs*

Group	Object	Max Access	Description
cisco2951K9	ciscoProducts 1043	read only	CISCO2951/K9 with three GE, four EHWIC, three DSP, two SM, 256 MB CF, 512 MB DRAM, IPB.
cisco2921K9	ciscoProducts 1044	read only	CISCO2921/K9 with three GE, four EHWIC, three DSP, one SM, 256 MB CF, 512 MB DRAM, IPB.
cisco2911K9	ciscoProducts 1045	read only	CISCO2911/K9 with three GE, four EHWIC, two DSP, one SM, 256 MB CF, 512MB DRAM, IPB.
cisco2901K9	ciscoProducts 1046	read only	CISCO2901/K9 with two GE, four EHWIC, two DSP, 256 MB CF, 512 MBDRAM, IP BASE.
cisco1941K9	ciscoProducts 1047	read only	CISCO1941/K9 with two GE, two EHWIC, 256 MB CF, 256 MB DRAM, IP BASE.
cisco1941WAK9	ciscoProducts 1095	read only	CISCO1941W-A/K9 with 802.11 a/b/g/ n FCC compliant WLAN ISM.
cisco1941WNK9	ciscoProducts 1174	read only	CISCO1941W-N/K9 Router w/ 802.11 a/b/g/n Aus, NZ Compliant WLAN ISM.
cisco1941WPK9	ciscoProducts 1173	read only	CISCO1941W-P/K9 Router w/ 802.11 a/b/g/n Japan Compliant WLAN ISM.
cisco1941WEK9	ciscoProducts 1172	read only	CISCO1941W-E/K9 Router w/ 802.11 a/b/g/n ETSI Compliant WLAN ISM.
ciscoPwrC3900Poe	ciscoProducts 1071	read only	Cisco 3925/3945 AC Power Supply with Power Over Ethernet (PWR-3900-POE).
ciscoPwrC3900AC	ciscoProducts 1072	read only	Cisco 3925/3945 AC Power Supply (PWR-3900-AC).
ciscoPwrC2921C2951Poe	ciscoProducts 1073	read only	Cisco 2921/2951 AC Power Supply with Power Over Ethernet (PWR-2921-51-POE).
ciscoPwrC2921C2951AC	ciscoProducts 1074	read only	Cisco 2921/2951 AC Power Supply (PWR-2921-51-AC).
ciscoPwrC2911Poe	ciscoProducts 1075	read only	Cisco 2911 AC Power Supply with Power Over Ethernet (PWR-2911-POE).
ciscoPwrC2911AC	ciscoProducts 1076	read only	Cisco 2911 AC Power Supply (PWR-2911-AC).
ciscoPwrC2901Poe	ciscoProducts 1077	read only	Cisco 2901 AC Power Supply with Power Over Ethernet (PWR-2901-POE).
ciscoPwrC2901AC	ciscoProducts 1078	read only	Cisco 2901 AC Power Supply (PWR-2901-AC).
ciscoPwrC1941Poe	ciscoProducts 1079	read only	Cisco 1941 AC Power Supply with Power Over Ethernet (PWR-1941-POE).
ciscoPwrC3900DC	ciscoProducts 1080	read only	Cisco 3925/3945 DC Power Supply (PWR-3900-DC).
ciscoPwrC2921C2951DC	ciscoProducts 1081	read only	Cisco 2921/2951 DC Power Supply (PWR-2921-51-DC).
ciscoPwrC2911DC	ciscoProducts 1082	read only	Cisco 2911 DC power Supply (PWR-2911-DC).
ciscoRpsAdptrC2921C2951	ciscoProducts 1083	read only	Cisco 2921/2951 RPS Adaptor for use with external rps (RPS-ADPTR-2921-51).

Table 7 *CISCO-PRODUCT-MIBs*

Group	Object	Max Access	Description
ciscoRpsAdptrC2911	ciscoProducts 1084	read only	Cisco 2911 RPS Adaptor for use with external rps (RPS-ADPTR-2911).
cisco1941W	ciscoProducts 1095	read only	CISCO194W-A/K9 with 802.11 a/b/g/n FCC compliant WLAN ISM.
cisco3925SPE200	ciscoProducts 1144	read only	CISCO3925E/K9 with SPE 200 motherboard, with four GE, four EHWIC, three DSP, and two SM slots.
cisco3945SPE250	ciscoProducts 1145	read only	CISCO3945E/K9 with SPE 250 motherboard, with four GE, four EHWIC, three DSP, and four SM slots.
ciscoPwr1941AC	ciscoProducts1168	read only	Cisco 1941 AC Power Supply.

Table 8 lists the CISCO-LICENSE-MGMT-MIBs

Table 8 *CISCO-LICENSE-MGMT-MIBs*

License Feature	Object	Max Access	Description
Install License	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.
Clear License	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.
ReHost License	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.
Regenerate last rehost ticket	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.
Backup all licenses	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.
Generate and export EULA	clmgmtLicenseActionTable & clmgmtLicenseActionResultTable	read only	Table for invoking license management actions. Management application must create a row in this table to trigger any of the license management actions.

Table 8 *CISCO-LICENSE-MGMT-MIBs*

License Feature	Object	Max Access	Description
License Storage Info: Name, Size, Free	clmgmtLicenseStoreInfoTable & clmgmtLicenseDeviceInfoTable	read only	Table contains information about all the license stores allocated on the device.
License Information: Feature name, Version, Type, Counted, Validity Period, ValidityPeriod Remaining, Expired period, Max Usage count, Usage count remaining, EULA status, Comments, Status	clmgmtLicenseInfoTable	read only	Table contains information about all the licenses installed on the device.
Licensable Features in the image: Feature name, Version, ValidityPeriod remaining, WhatIsCounted	clmgmtLicensableFeatureTable	read only	This table contains a list of licensable features in the image. All the licensable features have an entry each in this table irrespective of whether they are using any licenses currently. Entries in this table are created by the agent, one for each licensable feature in the image. These entries remain in the table permanently and cannot be deleted. Management application cannot create or delete entries from this table.
DeviceCredentialsExport to a server/device	clmgmtDevCredExportActionTable	read only	This object contains appropriate value for clmgmtDevCredExportActionIndex that can be used to create an entry in clmgmtDevCredExportActionTable. The management application should read this object first and then use this as the value for clmgmtDevCredExportActionIndex to avoid collisions when creating entries in clmgmtDevCredExportActionTable.
NOTIFICATION: License Expired & Expiry warnings	clmgmtLicenseExpired & clmgmtLicenseExpiryWarning	read only	This object indicates whether the device should generate the notifications related to usage of licenses.
NOTIFICATION: Usage count exceeded & about to exceed warnings	clmgmtLicenseUsageCountExceeded & clmgmtLicenseUsageCountAboutToExceed	read only	This notification is sent when clmgmtLicenseUsageCountRemaining has reached clmgmtLicenseMaxUsageCount for a counting license.

Table 8 *CISCO-LICENSE-MGMT-MIBs*

License Feature	Object	Max Access	Description
NOTIFICATION: License installed, Cleared & Revoked	clmgmtLicenseInsta lled, clmgmtLicenseClea red & clmgmtLicenseRevo ked	read only	This notification is sent when a license is installed successfully.
NOTIFICATION: EULA Accepted	clmgmtLicenseEUL AAccepted	read only	A collection of notifications related to license deployment.
NOTIFICATION: LicenseNotEnforced	clmgmtLicenseNotE nforced	read only	A collection of notifications related to license errors.

**Note**

For a detailed explanation of the MIB and to download the MIB, see [SNMP Object Navigator](#).

Simple Network Management Protocol

SNMP is a manager-agent model that consists of the following elements:

- **SNMP manager**— Provides an interface between the human manager and the management system.
- **SNMP agent**— Provides an interface between the manager and the physical device being managed.

A database of management information, managed SNMP devices, and SNMP protocol are additional elements required for an SNMP managed network.

The SNMP agent exchanges network management information with the SNMP manager software that is running on a network management system (NMS).

An SNMP-managed network consists of the following items on the network:

- **Managed device**—A network node that contains an SNMP agent that resides on a managed network. Managed devices collect and store management information and use SNMP to make this information available to the NMS. Managed devices, sometimes called *network elements*, can include routers and access servers, switches and bridges, hubs, computer hosts, and printers.
- **Agent**—A network management software module that resides in a managed device. An agent has local knowledge of management information and translates that information into a form compatible with SNMP. The agent responds to requests for information and actions from the managed device. The agent controls access to the agent's MIB, the collection of objects that can be viewed or changed by the SNMP manager.
- **Network Management System (NMS)**—Executes applications that monitor and control managed devices. NMSs provide most of the processing and memory resources required for network management. Every managed network must have one or more NMS.

Critical SNMP Traps

SNMPv1 and SNMPv2c, and the associated MIBs, enable trap-directed notification.

If a manager is responsible for a large number of devices, and each device has a large number of objects, it is impractical for the manager to poll or request information from every object on every device. The solution in this case is to have each agent on the managed device notify the manager without solicitation. It does this by sending a message, or trap, of the event. This is known as *trap-directed notifications*.

After the manager receives the event, the manager displays it and can choose to take an action based on the event. For instance, to get a better understanding of the event, the manager can poll the agent directly, or poll other associated device agents.

Trap-directed notification can result in a substantial savings of network and agent resources by eliminating the need for excessive SNMP requests. However, it is not possible to totally eliminate SNMP polling. SNMP requests are required for discovery and topology changes. SNMP polling is also needed because a managed device agent cannot send a trap if the device has had a catastrophic outage.

For a management system to understand a trap sent by an agent, the management system must know what the object identifier (OID) defines. Therefore, it must have the MIB for that trap loaded. This provides the correct OID information so that the network management system can understand the traps that are sent.

For traps that are supported by Cisco devices in specific MIBs, refer to the [Cisco SNMP Object Navigator](#) tool.

[Table 9](#) lists the new and critical SNMP traps.

Table 9 **New and Critical SNMP Traps and MIBs**

Trap Name	MIB
ciscoEnvMonFanNotification	CISCO-ENVMON-MIB
ciscoEnvMonFanStatusChangeNotif	CISCO-ENVMON-MIB
ciscoEnvMonVoltStatusChangeNotif	CISCO-ENVMON-MIB
ciscoEnvMonTempStatusChangeNotif	CISCO-ENVMON-MIB
ciscoEnvMonSuppStatusChangeNotif	CISCO-ENVMON-MIB
clmgmtLicenseInstalled	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseCleared	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseExpired	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseExpiryWarning	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseUsageCountExceeded	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseUsageCountAboutToExceed	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseRevoked	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseEULAAccepted	CISCO-LICENSE-MGMT-MIB
clmgmtLicenseNotEnforced	CISCO-LICENSE-MGMT-MIB

**Note**

For detailed examples of traps sent by Cisco IOS, see [Understanding Simple Network Management Protocol \(SNMP\) Traps](#).

Critical Syslog Messages

Syslog is a method of collecting messages from devices and sending them to a server that is running a syslog daemon. Logging to a central syslog server helps to aggregate logs and alerts. Cisco devices can send their log messages to a Unix-style SYSLOG service. A SYSLOG service simply accepts messages and stores the messages in files or prints according to a simple configuration file. These messages are useful in routine troubleshooting and for incident handling.

Cisco devices have thousands of different messages that are sent to a central server (at the customer site) when an identified event occurs in the network. Events range from catastrophic (priority 0) to informational (priority 6).

The syslog daemon handles the recording of syslog messages and events in log files. The syslog message is composed of two main parts:

- Header—Contains the date and time information along with the IP address or the computer name from which the message has originated.
- Message—Includes the program or subsystem name and the message. The program or subsystem name and the message are separated by a colon.

**Note**

For additional information about syslog, see the [“Additional References” section on page 93](#).

Error Messages

The following are the critical syslog messages for the ISR G2 platform:

Error Message Could not init buffer pools

Explanation The driver failed to get a pool of buffers from IOS.

Recommended Action Could not init buffer pools. The driver failed to get a pool of buffers from IOS Software due to a bug - open a case with Development Engineering.

Error Message The Ethernet port initialization failed due to insufficient memory

Explanation The Ethernet port initialization failed due to insufficient memory.

Recommended Action The router requires more packet memory. Consider a software upgrade.

Error Message %s, PHY configuration failed

Explanation The Ethernet device driver tried to configure the Ethernet PHY device, but the PHY configuration failed.

Recommended Action The Ethernet device driver tried to configure the Ethernet PHY device, but the PHY configuration failed.

Error Message PLATFORM-2-NO_POLL_TIMER

Explanation The system cannot allocate a polling timer. The Voice DSP driver requests a hardware poll timer, but the system does not allocate the resource. As a result, the voice application does not function correctly.

Recommended Action This is a software error message. Reload your router to recover from this problem. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>.

With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at the following URL:
http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl.

If you still require assistance, open a case with the Technical Assistance Center via the Internet at the following URL:
<http://tools.cisco.com/ServiceRequestTool/create>,

Provide the information that you have gathered.

Error Message PLATFORM-1-SPUR_INT

Explanation The platform detected an unauthentic timer interrupt. An unexpected interrupt event was detected by your CPU. There is no interrupt service routine assigned to this interrupt.

Recommended Action If the error recurs, the system is in an unstable state. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PLATFORM-2-ISR_ERR_MSG

Explanation Detected ISR error, 0x%08lx, 0x%08lx. Platform interrupt service routine detects abnormal events.

Recommended Action This is a software error. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PLATFORM-0-PCIE_ERR

Explanation Detected PCIe error: 0x%08lx, 0x%08lx, 0x%08lx, 0x%08lx, 0x%08lx. System detects a severe PCIe error. For example, PCIe fatal error messages received by root complex.

Recommended Action This can be a hardware issue. This is a fatal error that cannot be recovered. Reset the system to resolve this problem. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PLATFORM-2-BOOT_BUS_ERR

Explanation Detected MIO boot bus error: 0x%08lx. Boot bus is one of the hardware units inside the processor. It connects to flash memory and compact flash for initial booting purpose. When the boot bus hardware unit encounters either address-decode or wait-mode error, the boot bus notifies the CPU.

Recommended Action This can be a hardware issue. This is a fatal error that cannot be recovered, reset the system to resolve this problem. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at

<http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PLATFORM-2-PHY_CONFIG

Explanation Onboard Gigabit Ethernet physical configuration failed. The Onboard Gigabit Ethernet device driver tries to configure the Ethernet PHY device, but the PHY configuration fails.

Recommended Action This is a transient error. Although a transient issue is possible, this condition is a software problem. In rare cases, a hardware failure of one specific component can cause this condition. Reload the system and try again. If the issue recurs, extract the debug information by issuing the **debug ethernet-interface** command before entering the configuration information. The output of the **C3900_ERRMSG_CLI_OUTPUT** commands are helpful to resolve the problem. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show logging** and **show tech-support** commands, and your pertinent troubleshooting logs.

Error Message PLATFORM-2-SM_ERROR

Explanation The Software attempts to access the Service Module slot which is not present on the IO Controller. This is caused by a software error where the software attempts to set the access for the Service Module slot that is not defined.

Recommended Action This is a serious error which is integral to the proper operation of the router. There is no recommended workaround. This is an unexpected internal software error. If the issue recurs, extract information by issuing the **show version**, **show run**, and **show platform** commands. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show version**, **show run**, and **show platform** commands; and your pertinent troubleshooting logs.

Error Message PLATFORM-0-SURPRISE_OIR

Explanation Non-managed online removal of card from the slot. The service module is unexpectedly removed from the slot, while the service module is online.

Recommended Action Unexpected online removal of the service module is not supported. The managed Online Insertion and Removal (OIR) command should be used before removing the online service module. Use the **hw-module slot [n] stop** command before removing the online service

module. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PLATFORM-0-NM_REMOVED_SM2NM

Explanation The network module is removed from the SM2NM adapter.

Recommended Action For online insertion and removal, the network module must be removed with the SM2NM adapter. Use the managed OIR command for both the online removal of the network module and the SM2NM adapter. Use the **hw-module slot [n] stop** command before removing the service module and the SM2NM adapter. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-1-POWER_WARNING

Explanation An error has occurred in the power supply.

Recommended Action Make sure that the power supply is connected to the input source. Also, check whether the power supply unit and redundant power supply are supported by this router. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-POWER_OVERTEMP_SHUTDOWN

Explanation Temperature exceeds the threshold limit. If the high temperature condition is not resolved, the power supply will automatically shut down.

Recommended Action To prevent the damage caused by over heating, save the system configuration and power down the system. This problem can be caused by an operational environment or faulty components. If this warning recurs after disconnecting the power supply, replace the hardware. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-POWER_OVERTEMP

Explanation Temperature exceeds the threshold. The system power supply temperature exceeds critical temperature threshold. Resolve the system cooling to prevent system damage.

Recommended Action To prevent the damage caused by over heating, save the system configuration and power down the system. This problem can be caused by an operational environment or faulty components. If this warning recurs after disconnecting the power supply, replace the hardware.

Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-FAN_TRAY_MISSING

Explanation Fan tray is removed. To prevent the system from overheating, reinsert the fan tray. The environmental monitor cannot detect fan tray on system chassis.

Recommended Action Make sure that the fan tray is properly inserted. If the problem persists, replace the fan tray. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-SYSTEM_FAN_FAILED

Explanation System fan is not rotating.

Recommended Action Make sure that the fan power cable is properly attached to the mainboard fan tray power connector. If problem persists, replace the system fan. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-ONE_FAN_FAILED

Explanation Fan is running at low RPM. One of the fans in the system is not rotating and all other fans are rotating at high speed.

Recommended Action Make sure that the fan power cable is properly attached to the mainboard fan tray power connector. If problem persists, replace the Fan Tray or the system fan. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-MULTI_FAN_FAILED

Explanation Multiple fans are running at low RPM. Multiple fan failures detected and some of the fans in the system are rotating at high speed.

Recommended Action Make sure that the fan power cable is properly attached to the mainboard fan tray power connector. If problem persists, replace the fan tray. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-1-NO_PROCESS

Explanation Failed to create environmental monitor process.

Recommended Action The amount of memory available in the router may not be sufficient. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-1-CPU_CRITICAL_OVERTEMP

Explanation CPU temperature exceeds the threshold limit. To prevent system damage, resolve the problem in the system cooling process.

Recommended Action To prevent the damage caused by over heating, save the system configuration and power down the system. The system CPU temperature has exceeded the maximum threshold. This problem can be caused by an operational environment or faulty components. If this warning reoccurs after powering down system, replace the hardware. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message ENVMON-2-IN_OUTLET_OVERTEMP

Explanation The temperature of the system sensor exceeds the threshold limit. To prevent system damage, resolve the problem in the system cooling process.

Recommended Action To prevent the damage caused by over heating, resolve the problem in the system cooling process or power down the system. The system temperature has exceeded the maximum threshold. This problem can be caused by an operational environment or faulty components. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. If this warning reoccurs, replace the hardware. If this warning reoccurs after you power down the system, replace the hardware. If you still require assistance, open a case with the Technical

Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD_SFP-1-FAILURE

Explanation Transceiver module SFP is failed in port.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD_SFP-1-NOT_IDENTIFIED

Explanation Unidentified transceiver module in port.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message NVRAM-2-NO_GOOD_SECTORS

Explanation No good sectors in the region.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message NVRAM-2-INIT_STAT_ERASE_FAILED

Explanation Status sector erase failed during initialization.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying

information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message NVRAM-2-INIT_STAT_FAILED

Explanation Status sector initialization failed.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message NVRAM-2-ERASE_INT_LEVEL

Explanation Erase function called with interrupt level.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PQ3_TSEC-1-GRSFAIL

Explanation The software failed to perform Graceful Receive Stop (GRS) on the Ethernet/Fast Ethernet/Gigabit Ethernet interface. This happens while throttling the interface due to excess traffic.

Recommended Action This is a software error and the interface can stop functioning properly. The interface can be restored by resetting the interface. You can reset the interface by issuing the **shut** followed by the **no shut** command on the interface. Important information of the interface can be obtained by issuing the **show controllers** command on the interface on which the error occurred. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **shut**, **no shut**, and **show controllers** commands; and your pertinent troubleshooting logs.

Error Message HDV2-1-INITIALIZATION

Explanation The HDV2 port module in the given slot does not initialize correctly. The voice ports or interfaces do not function properly.

Recommended Action Reload the router. After reloading the router, if the HDV2 fails to initialize, make sure that a valid HDV2 is plugged into the slot. **Reset** the module, if necessary. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MRVL_GE_PHY-2-READ

Explanation An attempt to read the contents of a register associate with the gigabit ethernet hardware was unsuccessful. This may result in failure to setup the Gigabit-ethernet correctly, and possibly network outage. This implies a bigger problem in hardware.

Recommended Action Reload the router. After reloading the router, if the system fails, then this is an indication of a hardware issue. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show controllers** command on all GigE ports and your pertinent troubleshooting logs.

Error Message XFR_GE_PHY-2-PAGE_RESET

Explanation Marvel Phy Page reset to page zero failed. If PHY behavior is not guaranteed to work properly, the subsequent operation is set on wrong pages and it can lead to unexpected behavior.

Recommended Action Use the **shut** and **no shut** commands on the interface for which the page selection fails. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **shut** and **no shut** command, and your pertinent troubleshooting logs.

Error Message MGF-2-INTERNAL

Explanation Multi-Gigabit Fabric Internal Error: An internal error occurred.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_UPGRADE_FAIL

Explanation A FPGA Image upgrade is aborted due to read or write failure.

Recommended Action Power cycle the system and try the operation again. If the same issue is encountered. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_UNCOMPRESS_FAIL

Explanation A software error occurred and unable to uncompress the new FPGA image.

Recommended Action Power cycle the system and try the operation again. If the same issue is encountered. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_SECTOR_ERASE_FAIL

Explanation An FPGA image upgrade is aborted, since it was unable to erase the sector.

Recommended Action Power cycle the system and try the operation again. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require

assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_COMPARE_FAIL

Explanation An FPGA image upgrade was aborted, as the read and the write options did not match.

Recommended Action Power cycle the system and try the operation again. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_ACTIVATE_FAIL

Explanation An FPGA image upgrade is unsuccessful.

Recommended Action Power cycle the system and try the operation again. If the same issue is encountered. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message PSE_HW-3-PSE2_FPGA_INVALID_FLASH

Explanation An FPGA Image upgrade is aborted due to invalid flash detected.

Recommended Action Power cycle the system and try the operation again. If the same issue is encountered. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message WLAN_AP_INTF-1-CREATE_INTERFACE

Explanation User cannot access the console of the embedded AP module. The creation of the wlan-ap0 interface failed. This is because of the interface internal hardware and software failures.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message WLAN_AP_SM-1-INITFAIL

Explanation The registration of the embedded AP with the RBCP/SMM failed. This is because of the internal errors.

Recommended Action Make sure that the interface is not in shut down state. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message SSLVPN-1-LICENSE_EXPIRED

Explanation IOS SSLVPN evaluation license has expired.

Recommended Action IOS SSLVPN evaluation license has expired and a new license needs to be obtained. Existing user sessions continue until they are closed and no new sessions are allowed. See <http://www.cisco.com/go/sslvpn> for instructions on how to obtain a IOS SSLVPN license. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-1-UNKNOWN_WIC

Explanation WIC card in location has an unknown ID.

Recommended Action The software does not recognize the type of WIC card plugged into the port module. Check the part number on the WIC card to verify that the WIC card is supported on the IOS release. Verify that WIC supported is this network module with this IOS release. Collect the output of the **show version**, **show platform**, **show diag** commands. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at

<http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show version**, **show platform**, and **show diag** commands and your pertinent troubleshooting logs.

Error Message MAINBOARD-2-SCCFAIL

Explanation Failed to start SCC for port on interface.

Recommended Action The software failed to initialize and restart a Serial Communication Controller (SCC) of the indicated serial interface. Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-INVALID_TXRX

Explanation The software does not support different tx speed and rx speed.

Recommended Action Configure the tx speed and rx speed to be equal. This message does not indicate an error in IOS. The tx speed and rx speed are configured incorrectly. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-0-ECC_MULTIPLE

Explanation An uncorrectable multiple bit error has occurred in DRAM.

Recommended Action This may be a transient error if the memory is corrupt and unstable. The router forces a reload. If it does not recur, no further action is required. Transient errors can occur due to unusual environmental conditions. If the problem recurs, replace the DRAM or mainboard. The debug information can be obtained by issuing the **show platform error**, **show version**, **show run**, and **show platform** commands. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show platform error**, **show version**, **show platform**, and **show diag** commands; and your pertinent troubleshooting logs.

Error Message MAINBOARD-2-PARITY

Explanation An uncorrectable parity error has occurred in the component.

Recommended Action An internal component experienced a parity error. To restore data integrity, the router should be reloaded. If the event recurs repeatedly, then replace the mainboard to fix the hardware problem. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-SCC_STI_ERR

Explanation An error has occurred in the SCC STI.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-SCC_RAM_PARITY_ERR

Explanation An uncorrectable parity error has occurred in the SCC.

Recommended Action The SCC experienced a parity error. To restore data integrity, the router should be reloaded. If the event recurs repeatedly, then replace the mainboard to fix the hardware problem. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-HDLC_ERR

Explanation An error has occurred in HDLC gasket.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-HDLC_STI_ERR

Explanation .An error has occurred in the HDLC STI gasket.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message MAINBOARD-2-HWIC_CRC_ERR

Explanation A CRC error has occurred in HWIC gasket.

Recommended Action Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Toolkit at http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl. If you still require assistance, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the information that you have gathered.

Error Message LICENSE-1-EXPIRING

Explanation If the evaluation license expiration period is less than four weeks, the system displays the expiration warning message *LICENSE-1-EXPIRING* once a week. If the evaluation license expiration period is less than one week, the system displays the expiration warning message *LICENSE-1-EXPIRING* daily. If the evaluation license expiration period is less than one day, the system displays the expiration warning message *LICENSE-1-EXPIRING* every hour.

Recommended Action If this message recurs, customer should buy the license for the feature from Cisco because the feature does not run after the license expires.

Error Message LICENSE-1-EXPIRED

Explanation If the evaluation license expiry period is zero minute and zero second (which means license expired), the system displays the expiration warning message *LICENSE-1-EXPIRED* every five minutes until you reload the system.

Recommended Action If this message recurs, customer should buy the license from Cisco because the feature will does not run.

Error Message LICENSE-1-ENFORCEMENT

Explanation If the evaluation license expiry period is zero minute and zero second (which means the license has expired), the system displays the expiry warning message *LICENSE-1-ENFORCEMENT* every ten minutes until you reload the system.

Explanation It is recommended to buy and install the license for the feature immediately. If you are seeing this message after installation, open a case with the Technical Assistance Center via the Internet at <http://tools.cisco.com/ServiceRequestTool/create>, or contact your Cisco technical support representative and provide the representative with the output from the **show license file** and **show license detail** commands.

Error Message LICENSE-1-VALIDITY_ENDING

Explanation License for the feature specified expires at the specified time.

Recommended Action If this message recurs, the customer should buy the license for the feature from Cisco because the feature does not run after license Validity Ended.

Error Message LICENSE-1-VALIDITY_EXT_ENDING

Explanation License for the feature specified is running in grace period.

Recommended Action If this message recurs, customer should buy license for the feature from Cisco since feature will not run after license Validity Ended.

Error Message LICENSE-1-VALIDITY_ENDED

Explanation The license for the feature specified has expired.

Recommended Action If this message recurs, customer should buy the license for the feature from Cisco because the feature does not run after license Validity Ended.

Network Management Tools, Applications, and Technologies

Cisco provides tools, applications, and technologies for monitoring network performance and managing Cisco ISR Generation 2 (ISR G2) devices on the borderless network. These tools, applications, and technologies are designed to keep devices interacting in a secure and reliable fashion so network configurations and connectivity is maintained across network borders for the seamless delivery of voice- and video-ready applications and services.

For a summary of the management capabilities that are supported on ISR G2 platforms, see *Cisco ISR G2 Management Overview*:

http://www.cisco.com/en/US/prod/collateral/routers/ps10538/white_paper_c78_556613_ps10536_Products_White_Paper.html

For detailed information about tools, applications, and technologies supported on Cisco ISR G2 platforms, see the following sections:

- [XML Programmatic Interface, page 31](#)
- [TR-069 Agent, page 32](#)
- [Embedded Event Manager \(EEM\), page 32](#)
- [Cisco Networking Services \(CNS\) Agent, page 33](#)
- [IOS IP SLA, page 34](#)
- [Netflow, page 34](#)
- [Cisco Licensing Manager, page 35](#)
- [Cisco Configuration Professional, page 35](#)
- [CiscoWorks, page 35](#)
 - [Cisco View, page 35](#)
 - [Campus Manager, page 36](#)
 - [Resource Manager, page 36](#)
 - [Device Fault Manager, page 37](#)
 - [Network Compliance Manager, page 37](#)
 - [QoS Policy Manager, page 37](#)
- [Cisco Security Manager, page 38](#)
- [Cisco Security Monitoring, Analysis, and Response System, page 39](#)
- [Cisco Unified Service Statistics Manager, page 39](#)
- [Cisco Unified Service Monitor, page 40](#)

XML Programmatic Interface

In a network management context, a programmatic interface (PI) is an interface for management applications to control and monitor networking devices. It is crafted specifically to meet the needs of network management applications. This is in contrast to a command line interface (CLI), which is intended and crafted for human operators.

Likewise, the Cisco E-DI provides an XML PI based on the NETCONF configuration protocol (draft-ietf-netconf-prot-07.txt). Cisco E-DI acts as the NETCONF agent on behalf of a managed device. NETCONF specifies the protocol operations. Currently, the device data model used in an operation is not specified by the protocol. Cisco E-DI defines the device data model based on the device command structure. The data models are described in XML schema definition (XSD) files.

Some users have management applications using the XML-based data model and script-based tools using CLI. To accommodate users who continue using the CLI rather than the XML command model, the PI operations allow the transport of CLI commands and responses.

For details about how to use the XML data mode and CLI mode in NETCONF operations, see the *XML Programmatic Interface* module and *CLI Mode* module in *Cisco Enhanced Device Interface Programmer's Guide*, 2.2.

http://www.cisco.com/en/US/docs/net_mgmt/enhanced_device_interface/2.2/developer/guide/edi_pg_2_2.html

TR-069 Agent

The digital subscriber line (DSL) Forum's TR-069, CPE WAN Management Protocol (CWMP), is used for communications between a customer premise equipment (CPE) and an auto-configuration server (ACS). The TR-069 Agent feature manages a collection of CPEs, with the primary capability for auto-configuration and dynamic service provisioning, software image management, status and performance monitoring and diagnostics.

The TR-069 Agent allows an ACS to provision a CPE or collection of CPEs. The provisioning mechanism includes specific provisioning parameters and a general mechanism for adding vendor-specific provisioning capabilities as needed. The identification mechanisms included in the protocol allow CPE provisioning based on either the requirements of each specific CPE or on collective criteria such as the CPE vendor, model or software version, or another criteria.

The provisioning mechanism allows CPE provisioning at the time of the initial connection to the broadband has access network and the ability to reprovision at any subsequent time. This includes support for asynchronous ACS-initiated reprovisioning of a CPE.

The TR-069 Agent also supports image upgrade, configuration application, file downloads, configuration and log file uploads, and CPE monitoring.

For information about how to configure and enable the agent, see the *TR-069 Agent* document:

http://www.cisco.com/en/US/docs/ios/bbdsi/configuration/guide/bba_tr069_agent.html#wp1053996

Embedded Event Manager (EEM)

Embedded Event Manager (EEM) is a distributed and customized approach to event detection and recovery offered directly in a Cisco IOS device. EEM offers the ability to monitor events and take informational, corrective, or any desired EEM action when the monitored events occur or when a threshold is reached. An EEM policy is an entity that defines an event and the actions to be taken when that event occurs.

Event tracking and management has traditionally been performed by devices external to the networking device. Embedded Event Manager (EEM) is designed to offer event management capability within Cisco IOS devices. This on-device event management is useful because not all event management can be performed off the router. Some problems compromise communication between the router and the external network management device. Capturing the state of the router during an incident is invaluable

when taking immediate recovery actions and gathering information to perform root-cause analysis. Network availability is also improved if automatic recovery actions are performed without the need to perform a full reboot of the routing device.

EEM uses a policy-driven framework that supports in-box monitoring of different components of the system with the help of software agents known as event detectors. Event publishers screen events and publish them when there is a match on an event specification that is provided by the event subscriber. Event detectors notify the EEM server when an event of interest occurs. The EEM policies that are configured using the Cisco IOS command-line interface (CLI) then implement recovery on the basis of the current state of the system and the actions specified in the policy for the given event.

EEM offers the ability to monitor events and take informational or corrective action when the monitored events occur or when a threshold is reached. An EEM policy is an entity that defines an event and the actions to be taken when that event occurs. There are two types of EEM policies: an applet or a script. An applet is a simple form of policy that is defined within the CLI configuration. A script is a form of policy that is written in Tool Command Language (Tcl).

For details about configuring policies, see the *Embedded Event Manager* module in the *Cisco IOS Network Management Configuration Guide, Release 12.4T*:

http://www.cisco.com/en/US/docs/ios/netmgmt/configuration/guide/12_4t/nm_12_4t_book.html

Cisco Networking Services (CNS) Agent

Cisco Networking Services (CNS) Agent is a foundation technology for linking users to networking services and provides the infrastructure for the automated configuration of large numbers of network devices. Many IP networks are complex with many devices, and each device must be configured individually. When standard configurations do not exist or have been modified, the time involved in initial installation and subsequent upgrading is considerable. The volume of smaller, more standardized, customer networks is also growing faster than the number of available network engineers. Internet service providers (ISPs) now need a method for sending out partial configurations to introduce new services. To address all these issues, CNS has been designed to provide "plug-and-play" network services using a central directory service and distributed agents. CNS features include CNS configuration and event agents and a Flow-Through Provisioning structure. The configuration and event agents use a CNS configuration engine to provide methods for automating initial Cisco IOS device configurations, incremental configurations, and synchronized configuration updates, and the configuration engine reports the status of the configuration load as an event to which a network monitoring or workflow application can subscribe. The CNS Flow-Through Provisioning uses the CNS configuration and event agents to provide an automated workflow, eliminating the need for an onsite technician.

The CNS configuration agent is involved in the initial configuration and subsequent partial configurations on a Cisco IOS device. To activate the CNS configuration agent, enter any of the **cns config** CLI commands.

To activate the CNS agent in the infrastructure, see the *Configuring Cisco Networking Services* module in the *Cisco IOS Network Management Configuration Guide, Release 12.4T*,

http://www.cisco.com/en/US/docs/ios/netmgmt/configuration/guide/12_4t/nm_12_4t_book.html

IOS IP SLA

Cisco IOS IP Service Level Agreements (SLAs) allow users to monitor network performance between Cisco routers, or from a Cisco router to a remote IP device.

Cisco IOS IP SLAs capabilities include:

- Voice-over-IP (VoIP), video, and VPN network monitoring
- SLA monitoring
- Network performance monitoring and network performance visibility
- IP service network health readiness or assessment
- Edge-to-edge network availability monitoring
- Troubleshooting of network operation
- Multiprotocol Label Switching (MPLS) network monitoring

For technology information and troubleshooting and alerts, see the *Cisco IOS IP Service Level Agreements Introduction* at the following URL on Cisco.com.

http://www.cisco.com/en/US/tech/tk920/tsd_technology_support_sub-protocol_home.html

Netflow

NetFlow services consist of high-performance IP switching features that capture a rich set of traffic statistics exported from routers and switches while they perform their switching functions. The exported NetFlow data consists of traffic flows, which are unidirectional sequences of packets between a particular source device and destination device that share the same protocol and transport-layer information. The captured traffic statistics can be used for a wide variety of purposes, such as network analysis and planning, network management, accounting, billing, and data mining.

Because of their unidirectional nature, flows from a client to a server are differentiated from flows from the server to the client. Flows are also differentiated on the basis of protocol. For example, Hypertext Transfer Protocol (HTTP) Web packets from a particular source host to a particular destination host constitute a separate flow from File Transfer Protocol (FTP) file transfer packets between the same pair of hosts.

Routers and switches identify flows by looking for the following fields within IP packets:

- Source IP address
- Destination IP address
- Source port number
- Destination port number
- Protocol type
- Type of service (ToS)
- Input interface

For details about how to configure the collector, see the *Configuring NetFlow Collector* module in the *NetFlow Collector Installation and Configuration Guide*:

http://www.cisco.com/en/US/docs/net_mgmt/netflow_collection_engine/6.0/tier_one/installation/guide/install_1.html

Cisco Licensing Manager

For a network-wide deployment, the Cisco License Manager can automate all license-related work flows by securely communicating with the licensing back-end fulfillment systems at Cisco.com and deploying the obtained licenses to managed devices on a network-wide basis. The application also keeps an inventory of deployed licenses and generates license reports.

Cisco License Manager is available at no cost and can be downloaded by registered Cisco.com users from <http://www.cisco.com/go/clm>.

For additional information on Cisco License Manager see the *Cisco Software Activation Conceptual Overview* chapter in the *Cisco IOS Software Activation Configuration Guide* and the documents at http://www.cisco.com/en/US/products/ps7138/tsd_products_support_series_home.html.

Cisco Configuration Professional

Cisco Configuration Professional (Cisco CP), or Cisco Configuration Professional Express (Cisco CP Express), is a GUI-based LAN configuration tool for the router. The software and documentation is available on Cisco.com at <http://www.cisco.com/go/ciscocp>.

The tool provides easy-to-use wizards that assist you in the configuration of the system. Cisco CP Express is included on the system's compact flash (unless it is not selected during the ordering process) and it is a lightweight version of Cisco CP. You can use Cisco CP Express to configure basic security and routing features on the router's LAN and WAN interfaces.

For start up information, See *Cisco CP Quick Start Guide*:

http://www.cisco.com/en/US/products/ps9422/tsd_products_support_series_home.html

CiscoWorks

CiscoWorks includes components that let you manage devices on the network.

- [Cisco View, page 35](#)
- [Cisco View, page 35](#)
- [Resource Manager, page 36](#)
- [Device Fault Manager, page 37](#)
- [Network Compliance Manager, page 37](#)
- [QoS Policy Manager, page 37](#)

Cisco View

CiscoView is a graphical SNMP-based device management tool that provides real-time views of networked Cisco Systems devices. These views deliver a continuously updated physical and logical picture of device configuration and performance conditions. Simultaneous views are also available for multiple device sessions.

Use CiscoView to:

- View a graphical representation of the device, including component (interface, card, power supply, LED) status.
- Configure parameters for devices, cards, and interfaces.

- Monitor real-time statistics for interfaces, resource utilization, and device performance.
- Set user preferences.
- Perform device-specific operations as defined in each device package.
- Manage groups of stackable devices.

For details about how to use this management tool, see the *User Guide for CiscoView 6.1.9 (With LMS 3.2)* on Cisco.com: http://www.cisco.com/en/US/products/ps7198/products_user_guide_list.html

Campus Manager

Campus Manager is an integral component of CiscoWorks LAN Management Solution. As an enterprise solution to network management, Campus Manager provides a suite of web-based network management tools that enable administrators to obtain various types of graphical views of their network topology and end-user information. It also reports network inconsistencies, anomalies, and configuration errors in the discovered network.

Campus Manager provides advanced capabilities to manage Spanning-Tree protocols, and a user friendly interface for creating, modifying, or deleting VLANs, LANEs, or assigning switch ports to VLANs. Campus Manager is based on a client-server architecture that connects multiple web-based clients to a server on the network.

For details about how to use these tools, see the *User Guide for Campus Manager 5.1 (With LMS 3.1)* on Cisco.com:

http://www.cisco.com/en/US/docs/net_mgmt/ciscoverks_campus_manager/5.1/user/guide/CampusHelp.html

Resource Manager

The Resource Manager Essentials (RME) suite is part of the CiscoWorks family of products. It is an Enterprise solution to network management. RME is a powerful suite of Web-based applications offering network management solutions for Cisco switches, access servers, and routers.

The Resource Manager Essentials browser interface allows easy access to information critical to network uptime and simplifies time-consuming administrative tasks.

RME is based on a client/server architecture that connects multiple web-based clients to a server on the network. As the number of network devices increases, additional servers or collection points can be added to manage network growth with minimal impact on the client browser application.

Taking advantage of the scalability inherent in the intranet architecture, RME supports multiple users anywhere on the network. The web-based infrastructure gives network operators, administrators, technicians, Help Desk staff, IS managers, and end users access to network management tools, applications, and services.

RME allows the network administrators to view and update the status and configuration of all Cisco devices from anywhere on the network through a standard Web browser as the RME client.

RME maintains a database of current network information. It can generate a variety of reports that can be used for troubleshooting and capacity planning. When devices are initially added to the RME, the network administrator can schedule RME to periodically retrieve and update device information, such as hardware, software, and configuration files, to ensure that the most current network information is stored.

RME applications provide the network monitoring and fault information you need for tracking devices that are critical to network uptime. They also provide tools that you can use to rapidly and reliably deploy Cisco software images and view configurations of Cisco routers and switches.

RME applications, together with links to Cisco.com service and support, automate software maintenance to help you maintain and control your Enterprise network.

For details about how to configure the RME client, see the *User Guide for CiscoWorks Resource Manager Essentials 4.3 (with LMS 3.2)* on Cisco.com:

http://www.cisco.com/en/US/docs/net_mgmt/cisoworks_resource_manager_essentials/4.3/user/guide/rme_ug.html

Device Fault Manager

Device Fault Manager (DFM) assists network operations personnel monitor and display the operational health of the network, analyze events that occur in these environments, determine when a probable fault has occurred, and notify users of alert conditions through an online display and through other notification services.

DFM performs the following tasks after you import a device:

- Obtains basic information from the Device and Credentials Repository (DCR).
- Discovers the device.
- Assigns the device to system-defined groups.
- Starts to poll the device.

You can see alerts for a device on the Alerts and Activities display when events occur on the device. You can see the polling and threshold group that DFM uses for DFM polling parameters and threshold values for the device on the Polling Parameters Summary and Thresholds Summary pages.

For directions on how to import a device and start polling, see the *User Guide for Device Fault Manager 3.2 (With LMS 3.2)* on Cisco.com:

http://www.cisco.com/en/US/docs/net_mgmt/cisoworks_device_fault_manager/3.2/user/guide/dfm32_ug_Book.html

Network Compliance Manager

CiscoWorks Network Compliance Manager (NCM) tracks and regulates configuration and software changes throughout a multi-vendor network infrastructure. It provides visibility into network changes and can track compliance with a broad variety of regulatory, IT, corporate governance, and technology requirements. CiscoWorks NCM helps IT staff identify and correct trends that could lead to problems such as network instability and service interruption.

See the *CiscoWorks Network Compliance Manager* documentation on Cisco.com at the following URL, http://www.cisco.com/en/US/products/ps6923/tsd_products_support_series_home.html.

QoS Policy Manager

CiscoWorks QoS Policy Manager (QPM) provides a scalable platform for defining, applying, and monitoring QoS policy on a system-wide basis for Cisco devices, including routers and switches.

QPM enables you to baseline profile network traffic, create QoS policies at an abstract level, control the deployment of policies, and then monitor QoS to verify intended results. As a centralized tool QPM is used to monitor and provision QoS for groups of interfaces and devices.

QPM provides a web-based intuitive user interface to define QoS policies, and translates those policies into the device's command line interface (CLI) commands.

QPM runs on the CiscoWorks Common Services server, which provides the infrastructure required by QPM to run from the CiscoWorks Home page environment, and also provides management of user roles and privileges, allowing you to control who gets access to specific tasks in QPM.

For information about applying policies, see the *CiscoWorks QoS Policy Manager* documentation on Cisco.com, http://www.cisco.com/en/US/docs/net_mgmt/cisoworks_qos_policy_manager/4.0/user/guide/qpm40ug.html

Cisco Security Manager

Cisco Security Manager is an enterprise-class management application designed to configure firewall, VPN, and intrusion prevention (IPS) security services on Cisco network and security devices. Cisco Security Manager can be used in networks of all sizes—from small networks to large networks consisting of thousands of devices—by using policy-based management techniques.

Cisco Security Manager works in conjunction with the [Cisco Security Monitoring, Analysis, and Response System, page 39](#). Used together, these two products provide a comprehensive network security management solution that addresses configuration management, security monitoring, analysis, and mitigation.

- Firewall Management—Device-agnostic, unified interface for managing firewall rules across different Cisco devices supporting the firewall feature set; flexible rule specification methods for improved productivity and organization of rules; powerful toolset to identify configuration errors and optimize firewall rules
- VPN Management—VPN Wizard for rapid, simple definition of site-to-site and remote access VPNs
- IPS Management—Comprehensive solution for configuration management of all Cisco IPS technologies and automation of signature updates
- Policy-based Management—Ability to define aspects of a device's configuration into a named, shareable policy, which can be re-used across multiple devices; support for policy hierarchies to allow logical structuring and maximum re-usability
- Rich-client Graphical User Interface—Integrated, easy-to-use interface providing multiple views optimized around specific configuration tasks; device-centric view, map-centric view, and policy-centric view
- Workflow—Approval framework, whereby proposed configuration changes and deployments can be reviewed and approved
- Role-based Access Control—Integration with Cisco ACS for granular, role-based access control to devices and management functions
- Flexible Deployment Options—Support for various methods of deploying configuration changes such as direct to device, to file, or using call-home based techniques
- Integration with Cisco Security MARS—Cross-correlation between firewall rules and related events and between IPS signatures and related events

To learn more about the product, see the Cisco Security Manager page on Cisco.com, https://www.cisco.com/en/US/prod/collateral/vpndevc/ps5739/ps6498/product_bulletin_c25-546732.html

Cisco Security Monitoring, Analysis, and Response System

Cisco Security Monitoring, Analysis, and Response System (MARS) provides security monitoring for network devices and host applications supporting both Cisco and other vendors. Security monitoring with MARS greatly reduces false positives by providing an end-to-end topological view of the network, which helps improve threat identification, mitigation responses, and compliance.

The features of Cisco Security MARS follow:

- "Learns" the topology, configuration and behavior of your environment.
- Automatically updates knowledge of new Cisco IPS signatures, for up-to-the minute reporting on your environment.
- Promotes awareness of environmental anomalies with network behavior analysis using NetFlow and syslog.
- Provides access to audit compliance reports with more than 150 ready-to-use customizable reports.
- Makes precise recommendations for threat mitigation, including the ability to visualize the attack path and identify the source of the threat with detailed topological graphs that simplify security response at Layer 2 and Layer 3.
- Integrates with Cisco Security Manager to correlate security events with the configured firewall rules and intrusion prevention system (IPS) signatures that can affect the security event.

To learn more about the product, see *Cisco Install and Setup Guide for Cisco Security MARS, Release 4.3.x* on Cisco.com,

http://www.cisco.com/en/US/docs/security/security_management/cs-mars/4.3/installation/guide/IG_43X.html.

Cisco Unified Service Statistics Manager

Cisco Unified Service Statistics Manager (Service Statistics Manager) is a product from Cisco Unified Communications Management Suite that collects and stores short-term operational data to perform longer-term analysis of IP telephony service quality, service availability, call volume, service trends, and resource utilization. Service Statistics Manager does the following:

- Extracts data collected by Cisco Unified Operations Manager (Operations Manager) and Cisco Unified Service Monitor (Service Monitor) and stores this short-term data in the Service Statistics Manager database. Operations Manager and Service Monitor collect Cisco Unified Communications statistics from various Cisco devices and systems.
- Analyzes the stored data and generates out-of-the box reports designed for users in executive, operations, capacity planning, and network administration roles.

Depending on your license level, Service Statistics Manager lets you define Service Level Agreements (SLAs) as well as measure and verify them based on collected statistics.

Service Statistics Manager Components

When you install Service Statistics Manager, the following components are installed:

- Service Statistics Manager
 - Application server with the database and the backend processes that analyze data and creates reports.
 - Web server that lets you access a user interface and view reports.

- SSM Agent—Obtains data for Service Statistics Manager on the Operations Manager or Service Monitor system where it is installed.
- SSM Administration Console—Manages groups, users, and roles. Only a user with admin privilege can log into this console.

See the *Quick Start Guide for Cisco Unified Service Statistics Manager 1.2* on Cisco.com, http://www.cisco.com/en/US/docs/net_mgmt/cisco_unified_service_statistics_manager/1.2/quick/guide/QuickStartGuideCiscoUnifiedServiceStatisticsManager1_2.html#wp40781.

Cisco Unified Service Monitor

Cisco Unified Service Monitor (Service Monitor) is a product from the Cisco Unified Communications Management Suite that receives and analyzes Mean Opinion Scores (MOSs) from Cisco Unified Communications Manager (Unified Communications Manager) clusters and sensors—Cisco 1040 Sensors (Cisco 1040s) and Cisco Network Analysis Modules (NAMs)—sending traps when violations occur.

For configuration information, see the *User Guide for Cisco Unified Service Monitor* on Cisco.com, http://cisco.com/en/US/docs/net_mgmt/cisco_unified_service_monitor/2.2/user/guide/UserGuideforCiscoUnifiedServiceMonitor2_2.html.

Cisco Unified Provisioning Manager

Provisioning Manager is a product from the Cisco Unified Communications Management Suite. It provides provisioning for Cisco Unified Communications initial deployments and implementations, and then remains deployed to provide ongoing operational provisioning and activation services for individual subscriber changes. Provisioning Manager provides a single, consolidated view of subscribers across the organization. It provides a set of business-level management abstractions, which are policy-driven through the use of automation, for managing subscriber services across the Cisco Unified Communications infrastructure.

For configuration information, see the *User Guide for Cisco Unified Provisioning Manager 1.3.1* on Cisco.com, http://www.cisco.com/en/US/docs/net_mgmt/cisco_unified_provisioning_manager/1.3.1/user/guide/cupm_UG.html

Cisco Unified Operations Manager

Cisco Unified Operations Manager is a member of the Cisco Unified Communications family of products, which provides a comprehensive and efficient solution for network management, provisioning, and monitoring of Cisco Unified Communications deployments.

Operations Manager monitors and evaluates the current status of both the IP communications infrastructure and the underlying transport infrastructure in your network. Operations Manager uses open interfaces such as Simple Network Management Protocol (SNMP) and Hypertext Transfer Protocol (HTTP) to remotely poll data from different devices in the IP communications deployment.

For configuration information, see the *User Guide for Cisco Unified Operations Manager 2.2* on Cisco.com, http://www.cisco.com/en/US/docs/net_mgmt/cisco_unified_operations_manager/2.2/user/guide/OM_user_guide.html

Cisco IOS Command Reference

The following commands are introduced or modified in the ISR G2 platform.

- [crypto engine accelerator bandwidth-allocation ssl](#), page 42
- [hw-module sm oir-start](#), page 44
- [hw-module sm oir-stop](#), page 45
- [license boot module technology-package](#), page 46
- [license feature snasw](#), page 48
- [media-type auto-failover](#), page 49
- [mode border-element](#), page 51
- [show license udi modules](#), page 53
- [show platform cerm-information](#), page 54
- [show platform cf](#), page 56
- [show platform dma](#), page 58
- [show platform error](#), page 60
- [show platform gpio](#), page 62
- [show platform discover-devices](#), page 64
- [show platform hw-module-power](#), page 66
- [show platform interrupt](#), page 68
- [show platform io-controller](#), page 71
- [show platform led](#), page 74
- [show platform mgf](#), page 76
- [show platform nvram](#), page 79
- [show platform tlb](#), page 81
- [show platform trace](#), page 83
- [show platform uarts](#), page 85
- [show platform smbdev](#), page 87
- [show platform versions](#), page 89
- [show platform watchdog](#), page 91

crypto engine accelerator bandwidth-allocation ssl

To enable or disable hardware acceleration of SSLVPN on the router, use the **crypto engine accelerator bandwidth-allocation ssl** command in global configuration mode.

crypto engine accelerator bandwidth-allocation ssl [fair | none]

Cisco 3900 Series Integrated Services Routers

- C3925E
- C3945E

Syntax Description

fair	Enables SSL acceleration
none	Disables SSL acceleration

Command Default

Disabled

Command Modes

Global configuration mode

Command History

Release	Modification
15.1(1)T	This command was introduced for Cisco 3900 ISRs with Services Performance Engine 200 or Services Performance Engine 250.

Usage Guidelines

Cisco 3900 series ISRs with either Services Performance Engine 200 (C3900-SPE200/K9) or Services Performance Engine 250 (C3900-SPE250/K9) have an onboard cryptographic accelerator that is shared between SSLVPN and IPSec protocols. By default, acceleration of SSL is disabled so IPSec protocol performance is maximized. Use the **crypto engine accelerator bandwidth-allocation ssl fair** command in global configuration mode to set up the router as an SSLVPN gateway with this feature.

The following example shows how to enable the SSLVPN feature on the router.

```
Router# config t
Router(config)#crypto engine accelerator bandwidth-allocation ssl fair
```

Feature Verification

To confirm the SSLVPN feature has been enabled, enter the **show crypto engine configuration | inc SSL** command from EXEC mode. The following example shows the output when you verify the SSLVPN feature has been enabled.

```
Router# show crypto engine configuration | inc SSL
      SSL Acceleration:  Yes
Router#
```

Likewise, the following example shows the output when the SSLVPN feature is not enabled.

```
Router# show crypto engine configuration | inc SSL
      SSL Acceleration:  No
Router#
```

Related Commands

Command	Description
show crypto engine accelerator statistic	Displays current run-time statistics and error counters for the cryptographic engine.
show crypto engine configuration	Displays configuration information for the router's onboard hardware accelerator engine.

hw-module sm oir-start

To restart a module when the module is not removed after issuing the hardware module removal command, use the **hw-module sm oir-start** command in the privileged EXEC mode. Use the **no** form of this command to stop the restart process of the module.

hw-module sm *slot number* oir-start

Syntax Description	<i>slot number</i> Defines the slot number.					
Command Default	No default behavior or values.					
Command Modes	Privileged EXEC (#)					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>15.0(1)M</td><td>This command was introduced.</td></tr></table>		Release	Modification	15.0(1)M	This command was introduced.
Release	Modification					
15.0(1)M	This command was introduced.					
Usage Guidelines	Use the hw-module sm oir-start command to restart the module when the module is not removed.					
Examples	<p>The following example shows how the hw-module sm oir-start command is used at the router prompt.</p> <pre>Router#hw-module sm 1 oir-start</pre>					
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>hw-module sm oir-stop</td><td>Stops the module before the online removal of the module.</td></tr></table>		Command	Description	hw-module sm oir-stop	Stops the module before the online removal of the module.
Command	Description					
hw-module sm oir-stop	Stops the module before the online removal of the module.					

hw-module sm oir-stop

To shutdown the module before removing the module when it is online, use the **hw-module sm oir-stop** command in the privileged EXEC mode. Use the **no** form of this command to disable the online removal of the module.

hw-module sm *slot number* **oir-stop**

no hw-module sm *slot number* **oir-stop**

Syntax Description

<i>slot number</i>	Defines the slot number.
--------------------	--------------------------

Command Default

No default behavior or values.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.0(1)M	This command was introduced.

Usage Guidelines

Use the **hw-module sm oir-stop** command to remove a module online.

Examples

The following example shows how the **hw-module sm oir-stop** command is used at the router prompt.

```
Router#hw-module sm 1 oir-stop
```

Related Commands

Command	Description
hw-module sm oir-start	Restarts the module.

license boot module technology-package

To upgrade or downgrade a software license, or to enable or disable an evaluation license, use the **license boot module technology** command in global configuration mode.

license boot module *module-name* **technology-package** *package-name* {**disable**}

no license boot module *module-name* **technology-package** *package-name* {**disable**}

Syntax Description

<i>module-name</i>	Router to be configured (for example, c3900).
<i>package-name</i>	Package or feature set the given module should boot (for example, data).
disable	Disables the package or feature set.

Command Modes

Global configuration mode.

Command History

Release	Modification
15.0(1)M	This command was introduced for the Cisco 3900 Series, 2900 Series, and the 1900 Series Integrated Services Router platforms.

Usage Guidelines

The **license boot module technology-package** command is used for the following purposes:

- Downgrade or upgrade licenses
- Enable or disable an evaluation or extension license
- Clear an upgrade license

This command forces the licensing infrastructure to boot the configured license level instead of the license hierarchy maintained by the licensing infrastructure for a given module.

1. When rebooting the router, the licensing infrastructure checks the configuration in the startup-config/rommon for any licenses. If there is a license, the router boots with that license. If there is no license in the configuration, the licensing infrastructure follows the image hierarchy to check for licenses.
2. If the forced boot evaluation license expires then the licensing infrastructure will follow the regular hierarchy to check for licenses.
3. If the configured boot license is already expired, then the licensing infrastructure will follow the hierarchy to check for licenses.

To make the evaluation license inactive, use the **no license boot module technology** command. To re-activate the evaluation license, use the **license boot module technology** command.

Examples

The following example shows how to enable an evaluation license:

```
Router(config)# license boot module c3900 technology-package data
```

The following example shows how to make an evaluation license inactive:

```
Router(config)# no license boot module c3900 technology-package data
```

Related Commands

Command	Description
license install	Installs a license stored in a license file on a device.
license save	Saves a copy of a permanent license in a specified license file.

license feature snasw

To activate the SNA switching feature license with the data technology-package, use the **license feature snasw** command in the Configuration mode. Use the **no** form of this command to deactivate the SNA switching feature.

license feature snasw

no license feature snasw

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Configuration

Command History

Release	Modification
15.0(1)M	This command was introduced.

Usage Guidelines

Use the **license feature snasw** command to activate the SNA switching feature.

Examples

The following example shows how the **license feature snasw** command is used at the router prompt.

```
Router#enable
Router#configure terminal
Router(config)#license feature snasw
```

Related Commands

Command	Description
hw-module sm oir-start	Enables or disable the evaluation licenses.

media-type auto-failover

To assign primary and secondary failover media on the GE-SFP port enter the **media-type auto-failover** command in interface configuration mode. To automatically detect which media is connected, use the **no** form of this command.

media-type {sfp | rj45} auto-failover

no media-type

Syntax Description	sfp	Designates the SFP port as the primary media.
	rj45	Designates the RJ45 port as the primary media
	auto-failover	Configures the port with the primary media for automatic failover from SFP to RJ45 or vice-versa when the system goes down, reloads, and is unable to bring up primary media.

Command Default	No media-type. The primary media is not configured.
------------------------	---

Command Modes	Interface configuration mode.
----------------------	-------------------------------

Command History	Release	Modification
	15.0 (1) M	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to configure the primary media as RJ45 and the secondary failover media as SFP:
-----------------	---

Router(config-if)# **media-type rj45 auto-failover**

The following example shows how to configure the primary media as SFP and the secondary failover media as RJ45:

Router(config-if)# **media-type sfp auto-failover**

The following example shows how to configure the router to automatically detect which media is connected:

Router(config-if)# **no media-type**

Related Commands	
-------------------------	--

Command	Description
media-type sfp	Specifies an SFP physical connection.
media-type rj45	Specifies an RJ-45 physical connection.

mode border-element

To enable the set of commands used in border-element configuration on the Cisco 2900 and Cisco 3900 series platforms, use the **mode border-element** command in voice service configuration mode. To disable the set of commands used in border-element configuration, use the **no** form of this command.

mode border-element

no mode border-element

Syntax Description

This command has no arguments or keywords.

Command Default

The **mode border-element** command is disabled by default, so the commands specific to border-element configuration are unavailable on the Cisco 2900 and Cisco 3900 series platforms.

Command Modes

Voice service configuration (conf-voi-serv)

Command History

Release	Modification
15.0(1)M	This command was introduced.

Usage Guidelines

Use this command to enable the commands used in border-element configuration on Cisco 2900 and Cisco 3900 series platforms with a universal feature set. These commands are part of the **media** command. For more information about these commands, see the **media** command in the *Cisco IOS Voice Command Reference*.

If the **mode border-element** command is not entered, border-element-related commands are not available for Cisco Unified Border Element voice connections on the Cisco 2900 and Cisco 3900 series platforms with a universal feature set. The **mode border-element** command is not available on any other platforms.

For the **mode border-element** or the **no mode border-element** command to take effect, you need to save the running-config file and reload the router after you enter the command. The command-line interface (CLI) displays the following reminder after the command is entered:

You need to save and reload the router for this configuration change to be effective.

If you do not reload the router, the **mode border-element** or **no mode border-element** command does not take effect, and the availability of the commands used in border-element configuration is not affected.



Note

The **show running-config** command displays the **mode border-element** or **no mode border-element** command in its output, even if a reload has not been done and either command is not in effect.

Examples

The following example shows how to configure mode border-element and media-monitoring capability for a maximum of 200 Cisco Unified Border Element calls:

```
Router(config)# voice service voip
Router(conf-voi-serv)# mode border-element
Router(conf-voi-serv)# media monitoring 200
```

The following example shows how to configure the **media transcoder** command for high density on all VoIP calls:

```
Router(config)# voice service voip
Router(conf-voi-serv)# mode border-element
Router(conf-voi-serv)# media transcoder high-density
```

The following example shows how to configure the mode border-element and media flow-around for all VoIP calls:

```
Router(config)# voice service voip
Router(conf-voi-serv)# mode border-element
Router(conf-voi-serv)# media flow-around
```

Related Commands

Command	Description
codec (voice port)	Specifies voice compression.
codec complexity	Specifies call density and codec complexity based on the codec used.
media	Enables media packets to pass directly between the endpoints without the intervention of the IP-to-IP gateway and enables the incoming and outgoing IP-IP call gain/loss feature for audio call scoring on either the incoming dial peer or the outgoing dial peer.
show dial peer voice	Displays the codec setting for dial peers.
show running-config	Displays the contents of the currently running configuration file on the router.

show license udi modules

To display the udi license information, use the **show license udi modules** command in privileged EXEC mode.

show license udi modules

Syntax Description	module	Indicates the module.
--------------------	--------	-----------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the udi license information.
------------------	--

Examples	The following is sample output for the show license udi modules command:
----------	---

```
Router#show license udi modules
```

```
Location#                               UDI (PID:SN)
-----
Motherboard                             C3900-SPE150/K9:FHH12250057
SM slot 1                               NME-16ES-1G-P :FOC1112093C
SM slot 2                               NM-1A-OC3-POM:FOC12054B2C
```

Related Commands	Command	Description
	hw-module sm oir-start	Enables or disable the evaluation licenses.
	hw-module sm oir-start	Activates the SNA switching feature license.

show platform cerm-information

To display the platform CERM information, use the **show platform cerm-information** command in privileged EXEC mode.

show platform cerm-information

Syntax Description	cerm-information	Displays Crypto Export Restrictions Manager (CERM) information.
--------------------	------------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the CERM related information.
------------------	---

Examples The following is sample output for the **show platform cerm-information** command:

```
Router#show platform cerm-information
```

```
Crypto Export Restrictions Manager(CERM) Information:
CERM functionality: ENABLED
```

```
-----
Resource                                Maximum Limit      Available
-----
Tx Bandwidth(in kbps)                   0                   0
Rx Bandwidth(in kbps)                   0                   0
Number of tunnels                        0                   0
Number of TLS sessions                  0                   0
```

```
Resource reservation information:
```

```
-----
Client      Tx Bandwidth  Rx Bandwidth  Tunnels  TLS Sessions
            (in kbps)  (in kbps)
-----
VOICE       0             0             0         0
IPSEC       0             0             0         0
SSLVPN      0             0             0         0
```

```
Statistics information:
Failed tunnels      : 0
Failed sessions    : 0
Failed tx bandwidth: 0
Failed rx bandwidth: 0
Failed encrypt pkts: 0
Failed decrypt pkts: 0
Failed encrypt pkt bytes: 0
Failed decrypt pkt bytes: 0
Passed encrypt pkts: 0
```

```

Passed decrypt pkts: 0
Passed encrypt pkt bytes: 0
Passed decrypt pkt bytes: 0

```

Table 10 describes the significant fields shown in the display.

Table 10 *show platform cerm-information Field Descriptions*

Field	Description
Resource	Displays the resources.
Maximum Limit	Indicates the maximum limit of the available resource.
Available	Indicates the resource status.

Related Commands

Command	Description
show platform dma	Show DMA-related information.
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform discover-devices	Displays pci devices information.
show platform io-controller	Displays io-controller information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform cf

To display the platform compact flash information, use the **show platform cf** command in privileged EXEC mode.

show platform cf

Syntax Description	cf	Shows CF support-related information.
--------------------	----	---------------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the CF support-related information.
------------------	---

Examples The following is sample output for the **show platform cf** command:

```
Router#show platform cf
```

```
Platform Support status of Compact Flash:
=====
CF flash0: Compact Flash plugged in is Supported.
CF flash1: Compact Flash not plugged in.
```

[Table 11](#) describes the significant fields shown in the display.

Table 11 *show platform cf Field Descriptions*

Field	Description
Platform	Displays the available platforms.
Support Status of Compact Flash	Displays the compact flash plug in status.

Related Commands

Command	Description
show platform cf	Shows CF support-related information.
show platform dma	Show DMA-related information.
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform discover-devices	Displays pci devices information.

Command	Description
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform io-controller	Displays io-controller information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform dma

To display the DMA-related information, use the **show platform dma** command in privileged EXEC mode.

show platform dma

Syntax Description	dma	Shows DMA-related information.
--------------------	-----	--------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the DMA-related information.
------------------	--

Examples	The following is sample output for the show platform dma command:
----------	--

```
Router#show platform dma
```

```
DMA entries :
=====
vc  (load)      complete    consolidate exhaust    ch  (load)      shared
[pak coalesce engine]
0  (0  /255 ) 15257930    90739763    0          0  (0 /63)    yes
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform discover-devices	Displays pci devices information.
	show platform io-controller	Displays io-controller information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.

Command	Description
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform error

To display the platform errors, use the **show platform error** command in privileged EXEC mode.

show platform error

Syntax Description	error	Displays platform errors.
--------------------	-------	---------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the platform errors.
------------------	--

Examples	The following is sample output for the show platform error command:
----------	--

```
Router#show platform error
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform discover-devices	Displays pci devices information.
	show platform io-controller	Displays io-controller information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.
	show platform trace	Displays platform CPU trace buffer content.
	show platform uarts	Displays console/aux registers.
	show platform versions	Displays versions/revisions of various modules.

Command	Description
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform gpio

To display the CPU-GPIO information, use the **show platform gpio** command in Privileged EXEC mode.

show platform gpio

Syntax Description	gpio	Displays CPU-GPIO information.
--------------------	------	--------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the CPU-GPIO information.
------------------	---

Examples	The following is sample output for the show platform gpio command:
----------	---

```
Router#show platform gpio
```

```
CPU GPIO Information :
=====
```

```

                Pins: [0(DSR)  1(DTR)  4(USR)  5(DFLT) 6(MOD)  7(ZER)]
Dir  (0xDF80FC00) = 0x40000000 [0      1      0      0      0      0] [0=In
p, 1=Out]
Data (0xDF80FC08) = 0xBC000000 [1      0      1      1      0      0]
IMR  (0xDF80FC10) = 0x80000000 [Bit Value 0 = Disabled; 1 = Enabled]
ODR  (0xDF80FC04) = 0x00000000 [Bit Value 0 = normal; 1 = drain]
IER  (0xDF80FC0C) = 0x00000000
ICR  (0xDF80FC14) = 0x00000000
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform error	Displays platform errors.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform discover-devices	Displays pci devices information.
	show platform io-controller	Displays io-controller information.

Command	Description
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform discover-devices

To display PCI device information, use the **show platform discover-devices** command in privileged EXEC mode.

show platform discover-devices

Command Modes

Privileged EXEC

Command History

Release	Modification
15.1(1)T	This command was introduced for Cisco 3925E and Cisco 3945E Integrated Services Routers Generation 2 (ISR G2).

Usage Guidelines

Use the **show platform discover-devices** command to display information about PCI devices on the router. The output shows the device name, interface slot and port, and detailed hardware information.

Examples

The following is sample output for the **show platform discover-devices** command:

Router#**show platform discover-devices**

```
Discovered PCI device GE 0/0, GE 0/1
  root_port=2, bus_no=1, device_no=0, func_no=0, root_device_id=2
  DeviceID=0x10C9, VendorID=0x8086, Command=0x0146, Status=0x0010
  Class=0x02/0x00/0x00, Revision=0x01, LatencyTimer=0x00, CacheLineSize=0x10
  BaseAddr0=0xFD220000, BaseAddr1=0x00000000
```

```
Discovered PCI device GE 0/2, GE 0/3
  root_port=3, bus_no=2, device_no=0, func_no=0, root_device_id=3
  DeviceID=0x10C9, VendorID=0x8086, Command=0x0146, Status=0x0010
  Class=0x02/0x00/0x00, Revision=0x01, LatencyTimer=0x00, CacheLineSize=0x10
  BaseAddr0=0xFD120000, BaseAddr1=0x00000000
```

```
Discovered PCI device PLX:
  root_port=6, bus_no=37, device_no=0, func_no=0, root_device_id=6
  DeviceID=0x8509, VendorID=0x10B5, Command=0x0007, Status=0x0010
  Class=0x06/0x04/0x00, Revision=0xAA, LatencyTimer=0x00, CacheLineSize=0x10
  BaseAddr0=0xF8F00000, BaseAddr1=0x00000000
  SecLat=0x00, SubBus=53, SecBus=38, PrimBus=37
  MemLimit=0xF8F0, MemBase=0xF100, PrefMemLimit=0x0001, PrefMemBase=0xFFFF1
```

```
Discovered PCI device PLX:
  root_port=6, bus_no=38, device_no=1, func_no=0, root_device_id=6
  DeviceID=0x8509, VendorID=0x10B5, Command=0x0007, Status=0x0010
  Class=0x06/0x04/0x00, Revision=0xAA, LatencyTimer=0x00, CacheLineSize=0x10
  BaseAddr0=0x00000000, BaseAddr1=0x00000000
  SecLat=0x00, SubBus=40, SecBus=39, PrimBus=38
  MemLimit=0xF2F0, MemBase=0xF100, PrefMemLimit=0x0001, PrefMemBase=0xFFFF1
  PLX port=1
```


Related Commands

Command	Description
show platform cf	Shows CF support-related information.
show platform dma	Show DMA-related information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform io-controller	Displays IO-controller information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform mgf	Shows multi-gigabit fabric information.

show platform hw-module-power

To display power settings of the service modules, use the **show platform hw-module-power** command in privileged EXEC mode.

show platform hw-module-power

Syntax Description	hw-module-power	Displays power settings of service modules.
--------------------	-----------------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the power settings of the service modules.
------------------	--

Examples The following is sample output for the **show platform hw-module-power** command:

```
Router# show platform hw-module-power
Slot 2
  Levels supported 0x401 :  SHUT FULL
  CURRENT level   : 10 (FULL)
  Privileged level : 10 (FULL)
  Transitions    : Successful Unsuccessful
  SHUT           : 0          0
  FULL           : 0          0

ISM:
  Slot 0
    Levels supported 0x401 :  SHUT FULL
    CURRENT level   : 10 (FULL)
    Privileged level : 10 (FULL)
    Transitions    : Successful Unsuccessful
    SHUT           : 0          0
    FULL           : 0          0

PVDM:
  Slot 0/0
    Levels supported 0x441 :  SHUT FRUGAL FULL
    CURRENT level   : 10 (FULL)
    Privileged level : 10 (FULL)
    Transitions    : Successful Unsuccessful
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.

Command	Description
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information
show platform interrupt	Shows Interrupt-related information.
show platform io-controller	Displays io-controller information.
show platform discover-devices	Displays pci devices information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform interrupt

To display the interrupt-related information, use the **show platform interrupt** command in privileged EXEC mode.

show platform interrupt

Syntax Description	interrupt	Displays interrupt-related information.
--------------------	-----------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the interrupt-related information.
------------------	--

Examples	The following is sample output for the show platform interrupt command:
----------	--

```
Router#show platform interrupt
Interrupts:
=====
Assigned Handlers...
  Vect  Handler    # of Ints   Name
    2   04148130    87680     FPGA Interrupt
    5   0418C0AC      76     USB Host controller interrupt
   16   040F0AD8      0     c1800_l2_cache_interrupt
   18   041478D8      0     DRAM Error Int Handler
   20   0411B904   15258670    DMA Ch 1 Int Handler
   21   0411B904      0     DMA Ch 2 Int Handler
   22   0411B904      0     DMA Ch 3 Int Handler
   23   0411B904      0     DMA Ch 4 Int Handler
   25   0412ABFC      0     PCIe Root Complex 2
   26   0412ABFC      0     PCIe Root Complex 1
   29   0417D1AC   60138792    pq3 tsec1 tx interrupt
   30   0417D1AC    301070    pq3 tsec1 rx interrupt
   31   0417D1AC      0     pq3 tsec3 tx interrupt
   32   0417D1AC      0     pq3 tsec3 rx interrupt
   33   0417D1AC      0     pq3 tsec3 error interrupt
   34   0417D1AC      0     pq3 tsec1 error interrupt
   35   0417D1AC      0     pq3 tsec2 tx interrupt
   36   0417D1AC      5     pq3 tsec2 rx interrupt
   37   0417D1AC    31440    pq3 tsec4 tx interrupt
   38   0417D1AC    29991    pq3 tsec4 rx interrupt
   39   0417D1AC      0     pq3 tsec4 error interrupt
   40   0417D1AC      0     pq3 tsec2 error interrupt
   42   04103AE4    1946     16552 Con/Aux Interrupt
   45   086F9B88      0     SEC Interrupt Handler
   47   04148150      1     GPIO Interrupt
   76   0411B904      0     DMA 2 Ch 1 Int Handler
   77   0411B904      0     DMA 2 Ch 2 Int Handler
```

```

78 0411B904      0 DMA 2 Ch 3 Int Handler
79 0411B904      0 DMA 2 Ch 4 Int Handler
80 048FFCE0 20287003 M8500_TIMER_INTERRUPT
81 049001D8 23114586 C3900_POLL_TIMER_INTERRUPT
83 040F06C4      0 Timebase Reference Interrupt
96 0412D37C 16220 Network I/O Int Handler
97 0412D444      0 Network Management Int Handler
99 0412D5C8 7910 ISM I/O Int Handler
100 0412D680      0 SM1 I/O Int Handler
101 0412D74C 33058502 SM2 I/O Int Handler
102 0412D818      0 SM3 I/O Int Handler
103 0412D8E4 5413 SM4 I/O Int Handler

```

IOS Priority Masks mapped to internal levels...

```

Level 0 = [ 00000001 ]
Level 1 = [ 00000003 ]
Level 2 = [ 00000005 ]
Level 3 = [ 00000007 ]
Level 4 = [ 00000009 ]
Level 5 = [ 0000000B ]
Level 6 = [ 0000000D ]
Level 7 = [ 0000000F ]

```

CTPR = 00000001 Current Level = 00

Interrupt Throttling:

```

Throttle Count      =      0   Timer Count          =      0
Netint(usec)        =    20000 Netint Mask(usec)     =    1000
Real Netint(usec)    =     4000 Real Netint Mask(usec) =     200
Active              =      0   Configured            =      1
Longest IRQ(usec)    =    2152

```

MSI Interrupt info:

=====

```

MSI 0, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x0, slot 0, IO_Count
roller, NETIO, number 0
MSI 1, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x1, slot 0, IO_Count
roller, NETIO, number 1
MSI 2, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x2, slot 0, IO_Count
roller, NETIO, number 2
MSI 3, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x3, slot 0, IO_Count
roller, NETIO, number 3
MSI 4, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x4, slot 0, IO_Count
roller, NETIO, number 4
MSI 5, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x5, slot 0, IO_Count
roller, NETIO, number 5
MSI 6, name: wic_mbrd_hdlc_intr, hdlr 0x437F1BC, cnt 0, ctx 0x6, slot 0, IO_Count
MSI 167, name: PSE2 FPGA Err Inter, hdlr 0x40DF520, cnt 0, ctx 0x11F9D36C, slot
2, SM, NETIO, number 7
MSI 201, name: SM2NM - NM removal, hdlr 0x41198C4, cnt 0, ctx 0x3, slot 3, NM, N
ETIO, number 6
MSI 207, name: hdv2_interrupt, hdlr 0x75EF62C, cnt 0, ctx 0x3, slot 3, NM, NETIO
, number 0
MSI 233, name: SM2NM - NM removal, hdlr 0x41198C4, cnt 0, ctx 0x4, slot 4, NM, N
ETIO, number 6
MSI 239, name: pse_interrupt, hdlr 0x40D37C0, cnt 5413, ctx 0x4, slot 4, NM, NET
IO, number 0

```

Debug counters/Info:

```
unreg_msi_int_cnt 0
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform io-controller	Displays io-controller information.
	show platform discover-devices	Displays pci devices information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.
	show platform trace	Displays platform CPU trace buffer content.
	show platform uarts	Displays console/aux registers.
	show platform versions	Displays versions/revisions of various modules.
	show platform smbdev	Shows smbus slave devices.
	show platform watchdog	Displays watchdog-related information.

show platform io-controller

To display the io-controller information, use the **show platform io-controller** command in privileged EXEC mode.

show platform io-controller

Syntax Description	io-controller	Displays io-controller information.
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	15.0(1)M	This command was introduced.
Usage Guidelines	This command displays io-controller information.	

Examples

The following is sample output for the **show platform io-controller** command:

```
Router#show platform io-controller
io-controller global register (addr 0xEC900400):
  jtag_id                (addr 0xEC900400): 0x10316447
  revision_id            (addr 0xEC900404): 0x47410101
  diag_echo              (addr 0xEC900408): 0xFFFFFFFF
  software_memory_bist   (addr 0xEC90040C): 0x00000004
  five_mhz_prescale      (addr 0xEC900410): 0x00000072
  reset_sampled_inputs   (addr 0xEC900414): 0x00000000
  slew_rate_control_gpio1 (addr 0xEC900420): 0x0000FFFF
  slew_rate_control_gpio0 (addr 0xEC900424): 0xFFFFFFFF
  slew_rate_control_pvdmm (addr 0xEC900428): 0x000FFFFF
  slew_rate_control_slowgpio (addr 0xEC90042C): 0x0000003F
  slew_rate_control_wic0  (addr 0xEC900430): 0x003FFFFF
  slew_rate_control_wic1  (addr 0xEC900434): 0x003FFFFF
  slew_rate_control_wic2  (addr 0xEC900438): 0x003FFFFF
  slew_rate_control_wic3  (addr 0xEC90043C): 0x003FFFFF
  wic_spi_control0        (addr 0xEC900440): 0x2455077F
  wic_spi_control1        (addr 0xEC900444): 0x00000000

io-controller gpio (addr 0xEC900200):
  in_out_config2          (addr 0xEC900204): 0x40154415
  in_out_config1          (addr 0xEC900208): 0x44155145
  in_out_config0          (addr 0xEC90020C): 0x14504015
  polarity_ctrl1          (addr 0xEC900210): 0x0000C0C0
  polarity_ctrl0          (addr 0xEC900214): 0xC0DB6FC0
  debounce_ctrl1          (addr 0xEC900218): 0x00000000
  debounce_ctrl0          (addr 0xEC90021C): 0x00249000
  debounce_time5          (addr 0xEC900220): 0x00000000
  debounce_time4          (addr 0xEC900224): 0x00000000
  debounce_time3          (addr 0xEC900228): 0x00000000
  debounce_time2          (addr 0xEC90022C): 0x0000C351
  debounce_time1          (addr 0xEC900230): 0x0000C351
```

show platform io-controller

```

debounce_time0                (addr 0xEC900234): 0x00000000
reg_input_value1              (addr 0xEC900238): 0x0000382C
reg_input_value0              (addr 0xEC90023C): 0x2C00222C
reg_output_value1             (addr 0xEC900240): 0x00000024
reg_output_value0             (addr 0xEC900244): 0x24002004
intr_type2                    (addr 0xEC90024C): 0xEFFFFFFF
intr_type1                    (addr 0xEC900250): 0xEFFFFFFF
intr_type0                    (addr 0xEC900254): 0xBEFEFFFF
latch_unlatch_intr1          (addr 0xEC900258): 0x00000000
latch_unlatch_intr0          (addr 0xEC90025C): 0x00249000
err_intr_status1              (addr 0xEC900260): 0x00000000
err_intr_status0              (addr 0xEC900264): 0x00000000
mgmt_intr_status1             (addr 0xEC900268): 0x00000000
mgmt_intr_status0             (addr 0xEC90026C): 0x00000000
ntwk_intr_status1             (addr 0xEC900270): 0x00000000
ntwk_intr_status0             (addr 0xEC900274): 0x00000000
err_intr_enable1              (addr 0xEC900278): 0x00000040
err_intr_enable0              (addr 0xEC90027C): 0x00249000
mgmt_intr_enable1             (addr 0xEC900280): 0x00000000
mgmt_intr_enable0             (addr 0xEC900284): 0x00000000
ntwk_intr_enable1             (addr 0xEC900288): 0x00000000
ntwk_intr_enable0             (addr 0xEC90028C): 0x00000000
intr_test1                    (addr 0xEC900290): 0x00000000
intr_test0                    (addr 0xEC900294): 0x00000000
slow_output1                  (addr 0xEC9002A0): 0x00000080
slow_output0                  (addr 0xEC9002A4): 0xA06810A0
slow_input1                   (addr 0xEC9002A8): 0x00000000
slow_input0                   (addr 0xEC9002AC): 0x0000FF8F
slow_shift_reg_config         (addr 0xEC9002B0): 0x0000813E
slow_debounce_ctrl1           (addr 0xEC9002B8): 0x00000000
slow_debounce_ctrl0           (addr 0xEC9002BC): 0x00000000
slow_debounce_time5           (addr 0xEC9002C8): 0x00000000

```

Related Commands

Command	Description
show platform cf	Shows CF support-related information.
show platform dma	Show DMA-related information.
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform discover-devices	Displays pci devices information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.

Command	Description
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform led

To display the LED-related information, use the **show platform led** command in privileged EXEC mode.

show platform led

Syntax Description	led	Shows LED-related information.
--------------------	-----	--------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the LED-related information.
------------------	--

Examples The following is sample output for the **show platform led** command:

```
Router#show platform led
LEDs : SYSTEM ACTIVITY POE BOOST PS2 PS1
STATUS: GREEN OFF AMBER OFF AMBER OFF

CFLASH and ISM : CF0 CF1 ISM
LED STATUS : OFF OFF GREEN

DSP LED : PVDM0 PVDM1 PVDM2 PVDM3
STATUS : AMBER AMBER GREEN OFF

PORTS : GE0/0 GE0/1 GE0/2 SFP1 SFP2
LINK/ENABLE LED : GREEN OFF OFF OFF OFF
SPEED LED : 100Mb/s OFF OFF OFF OFF

LEDs : USB RJ45
STATUS: OFF GREEN
```

[Table 10](#) describes the significant fields shown in the display.

Table 12 *show platform led Field Descriptions*

Field	Description
LEDs Status	Displays the LED status.
CFlash and ISM LED Status	Displays the CFlash and ISM LED status.
DSP LED Status	Displays the DSP LED status.

Related Commands	Command	Description
	show platform cf	Shows CF support related information.
	show platform dma	Show DMA-related information
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform io-controller	Displays io-controller information.
	show platform discover-devices	Displays pci devices information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.
	show platform trace	Displays platform CPU trace buffer content.
	show platform uarts	Displays console/aux registers.
	show platform versions	Displays versions/revisions of various modules.
	show platform smbdev	Shows smbus slave devices.
	show platform watchdog	Displays watchdog-related information.

show platform mgf

To show the details of the multi-gigabit fabric, use the **show platform mgf** command in privileged EXEC mode.

show platform mgf [*module* | *statistics* | *controller* {**cpu**}]

Syntax Description

<i>module</i>	Shows details of the modules registered to the backplane switch manager (BPSM).
<i>statistics</i>	Displays the multi-gigabit fabric's packet statistics.
<i>controller</i>	Displays controller statistics.
cpu	Displays the multi-gigabit fabric's cpu port statistics.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
15.0(1)M	This command was introduced for the Cisco 3900 Series, 2900 Series, and 1900 Series Integrated Services Routers (ISRs).

Usage Guidelines

To show the details of the multi-gigabit fabric, use the **show platform mgf** command in privileged EXEC mode. Or, enter the **show platform mgf** command and press Enter to display VLAN and slot assignments on the router. An asterisk next to the slot indicates that the vlan is the slot's default VLAN. The following example displays output from a Cisco 3945 ISR.



Note VLAN1 is the default when no other VLAN are listed.

```
Router# show platform mgf
VLAN    Slots
-----
1       ISM*, EHWIC-0*, EHWIC-1*, EHWIC-2*, EHWIC-3*
        PVDM-0*, PVDM-1*, PVDM-2*, PVDM-3*, SM-1*
        SM-2*, SM-3*, SM-4*
```

Examples

The following example displays the output for the **show platform backplane module** command when entered on a Cisco 3945 ISR. [Table 13 on page 77](#) displays the information code that appears in the output.

```
Router# show platform mgf module
Registered Module Information
Code:  NR - Not Registered, TM - Trust Mode, SP - Scheduling Profile
        BL - Buffer Level, TR - Traffic Rate, PT - Pause Threshold

slot    vlan    type/ID      TM      SP      BL      TR      PT
```

```

-----
ISM      NR
EHWIC-0  NR
EHWIC-1  NR
EHWIC-2  NR
EHWIC-3  NR
PVDM-0   NR
PVDM-1   NR
PVDM-2   NR
PVDM-3   NR
SM-1     1      SM/6      UP      1      high    1000    high
SM-2     1      SM/6      UP      1      high    1000    high
SM-3     NR
SM-4     NR

```

Table 13 Show Platform Backplane Module Information Code

Code	Description
NR	Not registered
TM	Trust mode
SP	Scheduling profile
BL	Buffer level
TR	Traffic rate
PT	Pause threshold

The following example displays output for the **show platform backplane statistics** command when entered on a Cisco 1941 ISR.

```
Router# show platform mgf statistics
```

```
Interface statistics for slot: ISM (port 1)
```

```

-----
30 second input rate 0 packets/sec
30 second output rate 0 packets/sec
0 packets input, 0 bytes, 0 overruns
Received 0 broadcasts, 0 multicast, 0 unicast 0 runts, 0 giants, 0 jabbers 0 input errors,
0 CRC, 0 fragments, 0 pause input 0 packets output, 0 bytes, 0 underruns 0 broadcast, 0
multicast, 0 unicast 0 late collisions, 0 collisions, 0 deferred 0 bad bytes received, 0
multiple, 0 pause output

```

```
Interface statistics for slot: EHWIC-0 (port 2)
```

```

-----
30 second input rate 13844 packets/sec
30 second output rate 13844 packets/sec
3955600345 packets input, 1596845471340 bytes, 26682 overruns Received 0 broadcasts, 0
multicast, 3955600345 unicast 0 runts, 0 giants, 0 jabbers 0 input errors, 0 CRC, 0
fragments, 0 pause input
3955738564 packets output, 1596886171288 bytes, 0 underruns 0 broadcast, 0 multicast,
3955738564 unicast 0 late collisions, 0 collisions, 0 deferred 0 bad bytes received, 0
multiple, 94883 pause output

```

```
Interface statistics for slot: EHWIC-1 (port 3)
```

```

-----
30 second input rate 13844 packets/sec
30 second output rate 13844 packets/sec

```

show platform mgf

```
3955973016 packets input, 1598763291608 bytes, 26684 overruns Received 0 broadcasts, 0
multicast, 3955973016 unicast 0 runts, 0 giants, 0 jabbers 0 input errors, 0 CRC, 0
fragments, 0 pause input 3955781430 packets output, 1598708166660 bytes, 0 underruns 0
broadcast, 0 multicast, 3955781430 unicast 0 late collisions, 0 collisions, 0 deferred 0
bad bytes received, 0 multiple, 94987 pause output
```

The following example displays output for the **show platform backplane statistics cpu** command when entered on a Cisco 3945 ISR.

```
Router# show platform mgf statistics cpu
Backplane-GigabitEthernet0/3 is up, line protocol is up
  Hardware is PQ3_TSEC, address is 001b.5428.d403 (bia 001b.5428.d403)
  MTU 9600 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Full-duplex, 1000Mb/s, media type is internal
  output flow-control is unsupported, input flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
    0 watchdog, 0 multicast, 0 pause input
    0 input packets with dribble condition detected
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 unknown protocol drops
    0 babbles, 0 late collision, 0 deferred
    0 lost carrier, 0 no carrier, 0 pause output
    0 output buffer failures, 0 output buffers swapped out Interface statistics for CPU:
(port 0)
-----
30 second input rate 0 packets/sec
30 second output rate 0 packets/sec
0 packets input, 0 bytes, 0 overruns
Received 0 broadcasts, 0 multicast, 0 unicast 0 runts, 0 giants, 0 jabbers 0 input errors,
0 CRC, 0 fragments, 0 pause input 0 packets output, 0 bytes, 0 underruns 0 broadcast, 0
multicast, 0 unicast 0 late collisions, 0 collisions, 0 deferred 0 bad bytes received, 0
multiple, 0 pause output
```

Related Commands

Command	Description
show platform	To display platform information, use the show platform command in privileged EXEC mode.

show platform nvram

To display the NVRAM-related information, use the **show platform nvram** command in privileged EXEC mode.

show platform nvram

Syntax Description	nvram	Displays NVRAM-related information.
--------------------	--------------	-------------------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the NVRAM-related information.
------------------	--

Examples	The following is sample output for the show platform nvram command:
----------	--

```
Router#show platform nvram
NVRAM Information
=====
Stats/Counter :
-----
    Current Addr   : Primary 0xFE000000 (0), Backup 0xFE180000 (12)
    Write Erase Cnt: Primary 129, Backup 130, Stat 0
    Status : Primary 1, Backup 1, EEP State 1, NVR State 1
    State  : 18 (Stat Update Done)
    Write Mem ID   : 770
    Block Magic    : 0xF0A55A0F

Runtime stats :
-----
    Next Free Addr : Primary 0xFE040000 (2), Backup 0xFE1C0000 (14)
    Stats Addr     : Current 0xFE389030 (24), Next Free 0xFE389060 (24)
    Last Write done by PID : 108

Duration (millisec) :
-----
    Primary : Erase 1056, Write 1088
    Backup  : Erase 1092, Write 1124
    Stat    : Erase 0, Write 0
    Total Time : 4624, HWM Total Time 4648
    I2C (Size,Time,1=write) : (1, 20, 1), (1, 16, 1), (1, 16, 1), (1, 16, 1),
                                (1, 20, 1), (1, 16, 1), (1, 16, 1), (1, 16, 1), (4, 16, 1)
    ,
                                (48, 104, 1), (48, 8, 0),

Statistics :
-----
```

```

Sector Erase : Failed 0, Retry failed 0
Primary Write Failed : Config 0, Magic 0, No Addr 0
Backup Write Failed : Config 0, Magic 0, No Addr 0
Stats Failed : Write NV 0, Read back 0, No Addr 0, Write EEPROM 0
Eeprom Write : Failed 0, Retry failed 0
Eeprom Read Failed 0
Eeprom Readback Failed 0
Write Failed (Primary/Backup/Stat) : (0/0/0)
Primary Read failed due to : CRC 0, Magic 0
Backup Read failed due to : CRC 0, Magic 0
Privileged NVRAM State : 18 (Stat Update Done)
Privileged EEP State : 18 (Stat Update Done)

```

```
RAM pointer = 0x1294C00
```

Related Commands

Command	Description
show platform cf	Shows CF support-related information.
show platform dma	Show DMA related information.
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform discover-devices	Displays pci devices information.
show platform io-controller	Displays io-controller information.
show platform led	Shows LED-related information.
show platform mgf	Shows Multi-gigabit Frabric related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform tlb

To display the TLB information, use the **show platform tlb** command in privileged EXEC mode.

show platform tlb

Syntax Description	tlb	Displays TLB information.
--------------------	-----	---------------------------

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the TLD information.
------------------	--

Examples	The following is sample output for the show platform command:
----------	--

```
Router#show platform tlb
```

```
TLB entries :
```

```
=====
```

tlb no.	size	paddr	vaddr	w	i	m	g	e	perm
1 0	16 MB	0x00FF000000	0xFF000000	B			G	B	0x0033
1 1	16 MB	0x00FF000000	0xFE000000	B	I		G	B	0x000F
1 2	16 MB	0x00DF000000	0xDF000000	B	I		G	B	0x000F
1 3	256MB	0x00E0000000	0xE0000000	B	I		G	B	0x000F
1 4	16 MB	0x0000000000	0x00000000	B		C	G	B	0x003F
1 5	64 MB	0x0004000000	0x04000000	B		C		B	0x0033
1 6	64 MB	0x0008000000	0x08000000	B		C		B	0x0033
1 7	64 MB	0x000C000000	0x0C000000	B		C	G	B	0x0003
1 8	256MB	0x0010000000	0x10000000	B		C	G	B	0x000F
1 9	256MB	0x0020000000	0x20000000	B		C	G	B	0x000F
1 10	256MB	0x0030000000	0x30000000	B		C	G	B	0x000F
1 11	16 MB	0x0001000000	0x01000000	B		C	G	B	0x000F
1 12	16 MB	0x0002000000	0x02000000	B		C	G	B	0x000F
1 13	16 MB	0x0003000000	0x03000000	B		C	G	B	0x000F
1 14		(not in use)							
1 15		(not in use)							

```
.text: 73 MB [0x04000000 - 0x0893CD3C]
.rodata: 30 MB [0x0C000000 - 0x0DED3A83]
.rwdata: 23 MB [0x10000000 - 0x11770ACC]
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.

Command	Description
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform io-controller	Displays io-controller information.
show platform discover-devices	Displays pci devices information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays console/aux registers.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog related information.

show platform trace

To display the platform CPU trace buffer content, use the **show platform trace** command in privileged EXEC mode.

show platform trace

Syntax Description	trace	Displays platform CPU trace buffer content.
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	15.0(1)M	This command was introduced.
Usage Guidelines	This command displays the platform CPU trace buffer content.	
Examples	<p>The following is sample output for the show platform trace command:</p> <pre>Router#show platform trace</pre>	
Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform io-controller	Displays io-controller information.
	show platform discover-devices	Displays pci devices information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.
	show platform uarts	Displays console/aux registers.
	show platform versions	Displays versions/revisions of various modules.

■ show platform trace

Command	Description
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform uarts

To display the console / auxiliary registers, use the **show platform uarts** command in privileged EXEC mode.

show platform uarts

Syntax Description	uarts Displays console/aux registers.						
Command Modes	Privileged EXEC (#)						
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>15.0(1)M</td><td>This command was introduced.</td></tr> </table>	Release	Modification	15.0(1)M	This command was introduced.		
Release	Modification						
15.0(1)M	This command was introduced.						
Usage Guidelines	This command displays the console / auxiliary registers.						
Examples	<p>The following is sample output for the show platform uarts command:</p> <pre>Router#show platform uarts UART Information: ===== AUX (Uart 0) Port Registers: ----- SR: 0x00 IER: 0x0D IIR: 0xC1 LCR: 0x07 MCR: 0x03 LSR: 0x60 MSR: 0x00 FCR: 0xC1 Parity Error = 0, Framing Error = 0, Receive Error = 0 Outcount = 0, TotalOut = 39, Incount = 0, Total In = 0 Overrun = 0, Overflow = 0 Brk Character: Received 0, Brk Processed 0 Console (Uart 1) Port Registers: ----- SR: 0x11 IER: 0x0D IIR: 0xC1 LCR: 0x07 MCR: 0x03 LSR: 0x60 MSR: 0x10 FCR: 0xC1 Parity Error = 0, Framing Error = 0, Receive Error = 0 Outcount = 0, TotalOut = 23358, Incount = 0, Total In = 407 Overrun = 0, Overflow = 0 Brk Character: Received 0, Brk Processed 0</pre>						
Related Commands	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>show platform cf</td><td>Shows CF support-related information.</td></tr> <tr> <td>show platform dma</td><td>Show DMA-related information.</td></tr> </table>	Command	Description	show platform cf	Shows CF support-related information.	show platform dma	Show DMA-related information.
Command	Description						
show platform cf	Shows CF support-related information.						
show platform dma	Show DMA-related information.						

Command	Description
show platform error	Displays platform errors.
show platform gpio	Displays CPU-GPIO information.
show platform hw-module-power	Displays power settings of service modules.
show platform interrupt	Shows Interrupt-related information.
show platform discover-devices	Displays pci devices information.
show platform io-controller	Displays io-controller information.
show platform led	Shows LED-related information.
show platform nvram	Displays NVRAM-related information.
show platform tlb	Shows TLB information.
show platform trace	Displays platform CPU trace buffer content.
show platform versions	Displays versions/revisions of various modules.
show platform smbdev	Shows smbus slave devices.
show platform watchdog	Displays watchdog-related information.

show platform smbdev

To display the smbus slave devices, use the **show platform smbdev** command in privileged EXEC mode.

show platform smbdev

Command Modes Privileged EXEC

Command History	Release	Modification
	15.0(1)T	This command was introduced for Cisco 3925E and Cisco 3945E Integrated Services Routers Generation 2 (ISR G2).

Usage Guidelines Use the **show platform smbdev** command to display smbus slave devices on the motherboard. The output shows the device id, addresses, name, and function.

Examples The following is sample output for the **show platform smbdev** command:

```
Router#show platform smbdev
```

```
Smbus slave devices:
id: 0  addr: 44 (88) ICH9[ICH9 device]
id: 1  addr: 60 (C0) MCH[MCH device]
id: 2  addr: 8  (10) Nitrox[Nitrox security]
id: 3  addr: 71 (E2) Mux0[I2C MUX 0: PCA9495]
    [mux0:0] id: 4  addr: 58 (B0) Goofy[Goofy debug port]
    [mux0:0] id: 5  addr: 4A (94) MPtemp[Mid Plane Temperature Sensor]
    [mux0:0] id: 6  addr: 51 (A2) MPCook[Mid Plane Cookie]
    [mux0:0] id: 7  addr: 40 (80) MCU[Environment MCU controller]
    [mux0:0] id: 8  addr: 57 (AE) EEPROM[EEPROM]
    [mux0:0] id: 9  addr: 4E (9C) CPutmp[LM75 CPU ambient temperature sensor]
    [mux0:1] id: 10 addr: 34 (68) PwrSeq[Power Sequencer R5F21262SNFP]
    [mux0:1] id: 11 addr: 33 (66) usbC[USB console CY7C64215]
    [mux0:1] id: 12 addr: 63 (C6) usbCAp[USB console app CY7C64215]
    [mux0:1] id: 13 addr: 68 (D0) RTC[Real time clock DS1337C]
    [mux0:1] id: 14 addr: 4C (98) clk1[Clock 1 ICS844S24161 Goofy clocks]
    [mux0:1] id: 15 addr: 38 (70) plx[PLX PEX8509]
    [mux0:1] id: 16 addr: 70 (E0) Mux1[I2C MUX 1: PCA9495]
        [mux0:1 mux1:0] id: 17 addr: 49 (92) ps1tmp[PSU temperature sensor LM75]
        [mux0:1 mux1:0] id: 18 addr: 52 (A4) ps1Cook[PSU cookie]
        [mux0:1 mux1:0] id: 19 addr: 53 (A6) pwr1ob[Power OBFL cookie]
        [mux0:1 mux1:1] id: 20 addr: 49 (92) ps1tmp[PSU temperature sensor LM75]
        [mux0:1 mux1:1] id: 21 addr: 52 (A4) ps2Cook[PSU cookie]
        [mux0:1 mux1:1] id: 22 addr: 53 (A6) pwr2ob[Power OBFL cookie]
        [mux0:1 mux1:2] id: 23 addr: 50 (A0) sfp1[SFP 1]
        [mux0:1 mux1:3] id: 24 addr: 50 (A0) sfp2[SFP 2]
    [mux0:2] id: 25 addr: 69 (D2) clk2[Clock 2 CK505 Intel Clock]
    [mux0:2] id: 26 addr: 6E (DC) clkCpu[CPU Clock buffer]
    [mux0:3] id: 27 addr: 6E (DC) clkPCI[PCIE clock buffer for PCIe]
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform io-controller	Displays IO-controller information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform versions	Displays versions/revisions of various modules.
	show platform discover-devices	Displays PCI device information.

show platform versions

To display the versions / revisions of various modules, use the **show platform versions** command in privileged EXEC mode.

show platform versions

Syntax Description	versions	Displays versions/revisions of various modules.
--------------------	----------	---

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the versions / revisions of various modules.
------------------	--

Examples	The following is sample output for the show platform versions command:
----------	---

```
Router#show platform versions
```

```
Platform Revisions/Versions :
=====
```

```
FPGA      : 5.00    [Val = 0x500]
Board Rev  : 0      [Val = 0x8;  Type = 8]
Env Rev    : 4.4    [Val = 0x404, Bit 15 = 0]
PSEQ Rev   : 3.01   [Val = 0x301]
Rework Rev : REV2F CPU1.1
I/O Ctl Nm : GA 1.1 [Val = 0x47410101]
I/O Ctl Ver: 1      [Val = 0x10316447]
CPU Name   : MPC8572E
CPU Ver    : 1.1    [Val = SVR:0x80E80011]
Core Rev   : 3.0    [Val = PVR:0x80210030]
USB Con BL : 1.01   (Boot Loader)
USB Con FW : 1.10   (Application Firmware)
USB Con FWU: 2.02   (Application Firmware Upgrade)
```

```
IOS      :
Cisco IOS Software, C3900 Software (C3900-UNIVERSALK9-M), Version 12.4(24.6)M0.3, INTERIM
SOFTWARE
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2009 by Cisco Systems, Inc.
Compiled Sun 13-Sep-09 21:09 by stshen
```

```
ROMMON (Readonly) :
System Bootstrap, Version 15.0(1r)M1, RELEASE SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 2009 by cisco Systems, Inc.
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform discover-devices	Displays pci devices information.
	show platform io-controller	Displays io-controller information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.
	show platform trace	Displays platform CPU trace buffer content.
	show platform uarts	Displays console/aux registers.
	show platform watchdog	Displays watchdog related information.

show platform watchdog

To display the watchdog-related information, use the **show platform watchdog** command in privileged EXEC mode.

show platform watchdog

Syntax Description	watchdog	Displays watchdog-related information.
--------------------	----------	--

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
	15.0(1)M	This command was introduced.

Usage Guidelines	This command displays the watchdog-related information.
------------------	---

Examples	The following is sample output for the show platform watchdog command:
----------	---

```
Router#show platform watchdog
Watchdog Information:
=====
Critical input and watchdog timer interrupt: enabled
Watchdog: Interrupt disabled, Next watchdog enabled, Event not occurred
          Reset control: Second timeout generates machine check
          Reset status: No watchdog timer reset will occur
          Length: 913 ms
Decrementer: interrupt disabled, event occurred
```

Related Commands	Command	Description
	show platform cf	Shows CF support-related information.
	show platform dma	Show DMA-related information.
	show platform error	Displays platform errors.
	show platform gpio	Displays CPU-GPIO information.
	show platform hw-module-power	Displays power settings of service modules.
	show platform interrupt	Shows Interrupt-related information.
	show platform io-controller	Displays io-controller information.
	show platform led	Shows LED-related information.
	show platform nvram	Displays NVRAM-related information.
	show platform tlb	Shows TLB information.

Command	Description
show platform trace	Displays platform CPU trace buffer content.
show platform uarts	Displays Console/Aux registers.
show platform versions	Displays versions/revisions of various modules.

Additional References

The following websites describes additional information about network management.

- The Output Interpreter website is a troubleshooting website that reports potential problems by analyzing supported **show** command output. You must be a registered Cisco.com user to access this document. To visit the Output Interpreter website, go to this URL:
<https://www.cisco.com/cgi-bin/Support/OutputInterpreter/home.pl>
- The Error Message Decoder website allows you to determine the explanation and recommended action for an existing Cisco syslog message. You must be a registered Cisco.com user to access this document. To visit the Error Message Decoder website, go to this URL:
<http://www.cisco.com/cgi-bin/Support/Errordecoder/home.pl>
- You can find information about MIBs and OIDs at the Cisco IOS MIB Locator and SNMP Object Identifier website. The MIB Locator finds MIBs in Cisco IOS software releases. The SNMP Object Navigator translates OID's into SNMP names. To visit the Cisco IOS MIB Locator and SNMP Object Identifier website, go to this URL:
<http://tools.cisco.com/ITDIT/MIBS/servlet/index>
- The *SNMP Inform Requests* document provides information about how users configure routers to send informs and traps on a Cisco router. To see the *SNMP Inform Requests* document, go to this URL:
http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/snmpinfrm.html
- The *Traps Sent with SNMP-Server Enabled Traps Configured* document provides information about traps that are enabled on a Cisco device. To see *The Traps Sent with SNMP-Server Enabled Traps Configured* document, go to this URL:
http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a008021de3e.shtml
- “Configuring SNMP Support” is a chapter in the *Cisco IOS Configuration Fundamentals Configuration Guide* that provides information about SNMP and Cisco MIB configuration. To see the “Configuring SNMP Support” chapter go to this URL:
http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/fcf014.html
- The TAC FAQ sheet *SNMP: Frequently Asked Questions About MIBs* provides information about the evolution of Cisco MIBs and how to determine which MIBs are supported by a Cisco device. You must be a registered Cisco.com user to access this document. To see the TAC FAQ sheet *SNMP: Frequently Asked Questions About MIBs*, go to this URL:
http://www.cisco.com/en/US/customer/tech/tk648/tk362/technologies_q_and_a_item09186a0080094bc0.shtml
- You can find information about which MIBs are supported by which Cisco products at the Network Management Software website. To visit the Network Management Software website, go to this URL:
<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>
- The *Cisco IOS Management for High Availability Networking: Best Practices White Paper* provides information about Cisco IOS syslog and problem management. To see the *Cisco IOS Management for High Availability Networking: Best Practices White Paper*, go to this URL:
http://www.cisco.com/en/US/tech/tk869/tk769/technologies_white_paper09186a00800a998b.shtml

- The *Cisco IOS System Message Guide* provides information about Cisco IOS syslog messages. To see the *Cisco IOS System Message Guide*, go to this URL:

http://www.cisco.com/en/US/docs/ios/12_2sx/system/messages/122sxsms.html

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.