



INDEX

A

Add SDR [8-6](#)
Add SEL Entry [8-4](#)
alerts, Call Home [4-1](#)
Audience [ii-i](#)

B

BIOS message format [7-2](#)
BIOS messages and codes [7-2](#)
BIOS message severities [7-1](#)
BMC commands [8-3](#)
BMC messages description [8-1](#)

C

Call Home Faults [4-1](#)
Cisco BIOS messages and codes [7-6](#)
Cisco UCS Manager CLI
 faults [1-6](#)
 FSM [1-8](#)
Cisco UCS Manager GUI
 faults [1-5](#)
 FSM [1-7](#)
cleared [1-2](#)
Clear SDR Repository [8-6](#)
Clear SEL [8-4](#)
CLI
 faults [1-6](#)
 FSM [1-8](#)
condition [1-2](#)
configuration fault type [1-3](#)

connectivity fault type [1-3](#)
critical [1-2](#)

D

Delete SDR [8-6](#)
Delete SEL Entry [8-4](#)
discovery [5-1](#)

E

Enter SDR Repository Update Mode [8-7](#)
environment fault type [1-3](#)
equipment fault type [1-3](#)
error messages [9-1](#)
Event Receiver commands [8-7](#)
event receiver device [8-3](#)
Exit SDR Repository Update Mode [8-7](#)

F

fault collection policy [1-1, 1-5](#)
faults
 about [1-1](#)
 active state [1-4](#)
 Call Home [4-1](#)
 Cisco UCS Manager CLI [1-6](#)
 Cisco UCS Manager GUI [1-5](#)
 fault collection policy [1-5](#)
 initial setup [5-1](#)
 lifecycle [1-4](#)
 properties [1-3](#)
 retention [1-4](#)

Send document comments to ucs-docfeedback@cisco.com

severities [1-2](#)

states [1-4, 1-5](#)

types [1-3](#)

Faults tab [1-5](#)

Fault Summary area [1-5](#)

fault types

configuration [1-3](#)

connectivity [1-3](#)

environment [1-3](#)

equipment [1-3](#)

fsm [1-3](#)

management [1-3](#)

network [1-3](#)

operational [1-3](#)

server [1-3](#)

finite state machine

See FSM

flapping [1-5](#)

FSM

about [1-6](#)

Cisco UCS Manager CLI [1-8](#)

Cisco UCS Manager GUI [1-7](#)

dynamic view [1-7](#)

purpose [1-7](#)

static view [1-8](#)

fsm, fault type [1-3](#)

G

Get Auxiliary Log Status [8-5](#)

Get Event Receiver [8-7](#)

Get SDR [8-6](#)

Get SDR Repository Allocation Info [8-6](#)

Get SDR Repository Info [8-5](#)

Get SDR Repository Time [8-7](#)

Get SEL Allocation Info [8-4](#)

Get SEL Entry [8-4](#)

Get SEL Info [8-3](#)

Get SEL Time [8-4](#)

GUI

faults [1-5](#)

FSM [1-7](#)

info [1-2](#)

initial setup [5-1](#)

interval

retention [1-4](#)

L

lifecycle, faults [1-4](#)

M

major [1-2](#)

management fault type [1-3](#)

minor [1-2](#)

N

network fault type [1-3](#)

O

operational fault type [1-3](#)

P

Partial Add SDR [8-6](#)

Partial Add SEL Entry [8-4](#)

Platform Event Message [8-7](#)

policies, fault [1-5](#)

POST error messages and handling [7-1](#)

properties

faults [1-3](#)

Send document comments to ucs-docfeedback@cisco.com

R

related documentation [ii-ii](#)
 Reserve SDR Repository [8-6](#)
 Reserve SEL [8-4](#)
 retention interval [1-4](#)
 Run Initialization Agent [8-7](#)

S

SDR command [8-5, 8-6, 8-7](#)
 sdr repositories, modal and non-modal [8-2](#)
 SDR repository interface [8-2](#)
 SEL command [8-3, 8-4, 8-5](#)
 SEL event record format [8-1](#)
 SEL file description [6-1](#)
 SEL policy description [6-2](#)
 SEL record examples [8-8](#)
 sensor data record device [8-2](#)
 sensor initialization agent [8-2](#)
 server fault type [1-3](#)
 Set Auxiliar Log Status [8-5](#)
 Set Event Receiver [8-7](#)
 Set SDR Repository Time [8-7](#)
 Set SEL Time [8-5](#)
 severities
 cleared [1-2](#)
 condition [1-2](#)
 critical [1-2](#)
 info [1-2](#)
 major [1-2](#)
 minor [1-2](#)
 warning [1-2](#)
 show fault [1-6](#)
 show fault detail [1-6](#)
 Smart Call Home faults [4-1](#)
 soaking [1-5](#)
 states
 flapping [1-5](#)

soaking [1-5](#)

system event log description [6-1](#)

T

transient faults [5-1](#)

W

warning [1-2](#)

Send document comments to ucs-docfeedback@cisco.com