



INDEX

A

- accessibility features [1-6](#)
- Alarm configuration, described [3-1](#)
- Alarm definitions
 - catalog descriptions [4-2](#)
 - creating user-defined [4-1](#)
 - described [4-1](#)
 - searching and viewing
 - procedure [4-1](#)
 - searching for [4-1](#)
 - viewing [4-1](#)
- Alarms
 - configuring, procedure [3-1](#)
 - destinations [3-2](#)
 - destination settings [3-2](#)
 - event levels [3-3](#)
 - event level settings [3-3](#)
 - Event Viewer [3-2](#)
 - SDI trace library [3-2](#)
 - SDL trace library [3-2](#)
 - Syslog [3-2](#)
 - updating, procedure [3-1](#)
- alert central, accessing [8-1](#)
- alert notification
 - configuring parameters for counter (table) [9-5](#)
 - e-mail for counter [9-4](#)
 - message [9-4](#)
 - schedule [9-4](#)
 - thresholds [9-4](#)
- alert notification, configuring [8-6](#)
- alerts
 - accessing alert central [8-1](#)

- configuring actions [8-6](#)
- configuring e-mail for [8-6](#)
- setting properties [8-3](#)
- suspending [8-5](#)

C

- category
 - adding [7-14](#)
 - deleting [7-15](#)
 - renaming [7-14](#)
- Cisco Unified CallManager, service [5-1](#)
- CLI
 - starting services [2-3](#)
 - stopping services [2-3](#)
- community string [15-1](#)
- configuration profile
 - adding [7-6](#)
 - deleting [7-7](#)
 - restoring [7-6](#)
 - using default [7-5](#)
- Control Center
 - starting services [2-2](#)
 - stopping services [2-2](#)
 - viewing status [2-2](#)
- conventions [xi](#)
- counters
 - alert notification parameters (table) [9-5](#)
 - configuring alert notification for [9-4](#)
 - data sample, configuring [9-9](#)
 - data sample parameters (table) [9-9](#)
 - viewing data [9-10](#)
 - zooming [9-7](#)

CTI
 finding CTI devices [7-10](#)

D

data sample
 configuring parameters (table) [9-9](#)

debug trace levels
 defined [5-4](#)

document
 audience [x](#)
 conventions [xi](#)
 organization [x](#)
 purpose [ix](#)

documentation
 related [xi](#)

E

e-mail configuration
 alerts [8-6](#)

error codes [1-5](#)

event levels for alarms [3-3](#)

F

feature services
 activating [2-1](#)
 deactivating [2-1](#)
 starting [2-2](#)
 stopping [2-2](#)
 viewing status [2-2](#)

H

HTTPS
 overview (IE) [1-3](#)
 saving certificate to trusted folder (IE) [1-3](#)

saving certificate to trusted folder (Netscape) [1-4](#)

I

informs
 V1/V2 [15-3](#)
 V3 [16-3](#)

L

Log Partition Monitoring
 configuring [12-1, 13-1](#)

M

MIB2
 configuring system group [17-1](#)

monitoring
 CTI devices [7-10](#)
 gateways [7-10](#)
 H.323 devices [7-10](#)
 hunt list [7-10](#)
 media resources [7-10](#)
 phones [7-10](#)
 predefined objects [7-7](#)
 services [7-7](#)
 SIP trunk [7-10](#)
 voice-mail devices [7-10](#)

N

network services
 starting [2-2](#)
 stopping [2-2](#)
 viewing status [2-2](#)

notification destination
 V1/V2 [15-3](#)
 V3 [16-3](#)

NT Event Viewer [3-2](#)

O

organization [x](#)

overview

- accessing error codes [1-5](#)
- accessing interface [1-2](#)
- accessing online help [1-5](#)
- icons in interface (table) [1-5](#)
- serviceability [1-1](#)
- verifying version [1-5](#)

P

performance counter

- adding a counter instance [9-4](#)
- removing [9-3](#)

performance counters

- displaying in chart format [9-1](#)
- displaying in table format [9-1](#)

performance monitoring

- configuring alert notification for counters [9-4](#)
- viewing counter data [9-10](#)

plugins

- accessing [12-1](#)
- downloading [12-1](#)

polling rate [7-13](#)

predefined objects

- monitoring [7-7](#)

Q

Q931 Translator, using [10-17](#)

R

Real-Time Monitoring Tool

alert notification

- configuring for a counter [9-4](#)

alerts

- accessing alert central [8-1](#)
- configuring alert actions [8-6](#)
- configuring e-mail for [8-6](#)
- setting properties [8-3](#)
- suspending [8-5](#)

category

- adding [7-14](#)
- deleting [7-15](#)
- renaming [7-14](#)

collecting a crash dump [10-12](#)

collecting traces [10-3](#)

collecting traces using the query wizard [10-5](#)

collecting traces using the schedule collection option [10-9](#)

configuration profile

- adding [7-6](#)
- deleting [7-7](#)
- restoring [7-6](#)
- using default [7-5](#)

counters

- data sample [9-9](#)
- displaying property description [9-8](#)
- viewing data [9-10](#)
- zooming [9-7](#)

data samples [9-9](#)

deleting scheduled collections [10-12](#)

displaying trace and log central options [10-2](#)

e-mail notification, configuring [7-5](#)

finding

- devices [7-10](#)

installing [7-1](#)

loading [7-3](#)

monitoring

- call processing [7-7](#)
- CTIManager [7-7](#)
- devices [7-7](#)

- predefined objects [7-7](#)
- server [7-7](#)
- services [7-7](#)
- summary [7-7](#)
- monitoring predefined objects [7-7](#)
- monitoring summary [7-7](#)
- polling rate, configuring [7-13](#)
- related topics for trace collection [10-22](#)
- SysLog Viewer [11-1](#)
- uninstalling [7-3](#)
- updating trace configuration settings [10-22](#)
- upgrading [7-2](#)
- using [7-3](#)
- using the real time trace option [10-19](#)
- using the real time trace option, monitor user event [10-20](#)
- using the real time trace option, view real time data [10-19](#)
- viewing
 - device properties [7-13](#)
 - phone information [7-12](#)
- viewing trace collection status [10-12](#)
- viewing trace files using the local browse option [10-14](#)
- viewing trace files using the remote browse option [10-15](#)
- zooming a counter [9-7](#)
- related documentation [xi](#)

S

- security
 - HTTPS for IE [1-3](#)
 - HTTPS for Netscape [1-4](#)
- server authentication certificates
 - importing using the trace collection option [10-2](#)
- serviceability
 - accessing [1-2](#)
 - accessing error codes [1-5](#)
 - icons (table) [1-5](#)

- introduction [1-1](#)
- overview [1-1](#)
- verifying version [1-5](#)
- Serviceability Reports Archive
 - configuration [14-5](#)
- service activation
 - activating [2-1](#)
 - deactivating [2-1](#)
- services
 - activating [2-1](#)
 - deactivating [2-1](#)
 - monitoring [7-7](#)
 - starting [2-2](#)
 - stopping [2-2](#)
 - viewing status [2-2](#)

- Simple Network Management Protocol
 - configuring community string [15-1](#)
 - configuring MIB2 system group [17-1](#)
 - configuring user (V3) [16-1](#)
 - informs (V1/V2) [15-3](#)
 - notification destination (V1/V2) [15-3](#)
 - notification destination (V3) [16-3](#)
 - traps (V1/2) [15-3](#)

- SNMP
 - configuring community string [15-1](#)
 - configuring MIB2 system group [17-1](#)
 - configuring user (V3) [16-1](#)
 - informs (V1/V2) [15-3](#)
 - notification destination (V1/V2) [15-3](#)
 - notification destination (V3) [16-3](#)
 - traps (V1/V2) [15-3](#)

- SysLog Viewer [11-1](#)

T

- Trace
 - collection
 - collecting crash dump option [10-12](#)
 - collecting files option [10-3](#)

- configuration, described [10-1](#)
- deleting scheduled collections [10-12](#)
- displaying options [10-2](#)
- list of topics [10-1](#)
- related topics [10-22](#)
- schedule collection option [10-9](#)
- using the local browse option [10-14](#)
- using the query wizard option [10-5](#)
- using the real time trace option [10-19](#)
- using the real time trace option, monitor user event [10-20](#)
- using the real time trace option, view real time data [10-19](#)
- using the remote browse option [10-15](#)
- viewing status [10-12](#)

configuration

- described [5-1](#)
- list of topics [5-1](#)

configuring [5-1](#)

- debug trace levels for services [5-4](#)
- debug trace levels for servlets [5-4](#)
- device name based trace monitoring [5-1](#)

log files

- output settings [5-5](#)

traps

- V1/V2 [15-3](#)
- V3 [16-3](#)

Troubleshooting Trace Setting

- configuration [6-1](#)

U

- user-defined alarm descriptions [4-1](#)

Z

- zooming a counter [9-7](#)

