



## INDEX

---

### A

Activate/Deactivate button, toggling **2-2, 2-3**

Activate CLI command **2-2, 2-3**

---

### B

batch file

example **1-4**

for CLI commands **1-3**

using **1-3**

---

### C

case insensitivity, for CLI commands **2-2**

caution, described **ix**

channel

*See* PTT channel

Cisco CallManager

documentation **viii**

Cisco CallManager Express

documentation **viii**

Cisco IOS

documentation **ix**

Cisco IP Phones

documentation **viii**

Cisco Land Mobile Radio (LMR)

documentation **viii**

Cisco Security Agent

documentation **ix**

CLI

about **1-1**

issuing commands **1-1, 1-2**

CLI command

Activate **2-2, 2-3**

case insensitivity **2-2**

IsActive **2-2, 2-4**

IsEnabled **2-2, 2-5**

IsLatch **2-2, 2-6**

issuing **1-1, 1-2**

IsTxMuted **2-3, 2-7**

Play **2-3, 2-7**

return code **1-3**

command

*See* CLI command

Command Line Interface

*See* CLI

conventions, document **ix**

---

## D

documentation  
Cisco CallManager [viii](#)  
Cisco CallManager Express [viii](#)  
Cisco IOS [ix](#)  
Cisco IP Phones [viii](#)  
Cisco Land Mobile Radio (LMR) [viii](#)  
Cisco Security Agent [ix](#)  
conventions [ix](#)  
MCS servers [viii](#)

---

## E

ERRORLEVEL environment variable [1-3](#)

---

I  
IsActive CLI command [2-2, 2-4](#)  
IsEnabled CLI command [2-2, 2-5](#)  
IsLatch CLI command [2-2, 2-6](#)  
IsTxMuted CLI command [2-3, 2-7](#)

---

## M

MCS servers  
documentation [viii](#)

---

## N

note, described [ix](#)

---

## P

Play CLI command [2-3, 2-7](#)  
PMC  
active PTT channel [2-2, 2-4](#)  
affected by CLI command [1-2](#)  
configured PTT channel [2-7](#)  
enabled PTT channel [2-2, 2-5](#)  
issuing CLI command to [1-2](#)  
muted [2-3](#)

PTT button  
state [2-2, 2-6](#)  
PTT channel  
active [2-2, 2-4](#)  
configured [2-7](#)  
enabled [2-2, 2-5](#)  
muted [2-3](#)

Push-to-Talk Management Center  
*See* PMC

---

## R

return code  
about [1-3](#)  
for IsAvtive command [2-5](#)

for IsEnabled command [2-6](#)  
for IsLatch command [2-6](#)  
for IsTxMuted command [2-7](#)  
in ERRORLEVEL environment variable [1-3](#)  
obtaining through batch file [1-4](#)

---

## **W**

wave file, playing on PTT channel [2-3, 2-7](#)

