



---

## Numerics

404 or 500 error after logging in to Administration Console [3-9](#)

---

## A

Administration Console

browser guidelines [3-3](#)

cannot log in with ipics user ID [3-25](#)

cannot perform tasks [3-13](#)

changes not saved when multiple users are configuring [3-21](#)

not functioning [3-13](#)

---

## B

browser

refreshing window [3-15](#)

troubleshooting access to the server [3-4](#)

browser guidelines [3-3](#)

---

## C

cablelength router command [3-52](#)

CallManager

*See* Cisco Unified CallManager

CallManager Express

*See* Cisco Unified CallManager Express

call waiting, dial-in calls disconnect after using [3-33](#)

cannot deactivate

stopping state, in RMS [3-57](#)

cannot log in to administration console [3-25](#)

caution, described [xvii](#)

caveats

application troubleshooting [4-29](#)

CLI commands [4-12](#)

troubleshooting [4-29](#)

VPN client [4-16](#)

changing IP address, troubleshooting problems [3-23](#)

changing server IP address [5-2](#)

channel

choosing codec [3-50, 3-51](#)

Cisco Unified IP Phone cannot access [3-16](#)

feedback noise [3-46](#)

PMC deactivates by itself [3-46](#)

troubleshooting access to multiple channels [3-42](#)

troubleshooting multicast address problems [3-42](#)

## channels

- connectivity failure indicator [4-25](#)

- visual indicators

- connectivity failure [4-25](#)

- characters, language, incorrect display [3-19](#)

- checking status of the license manager [2-9](#)

- Cisco IOS, documentation [xv](#)

- Cisco IPICS Activity Log [6-2](#)

- Cisco IPICS IP Policy Engine

- See* policy engine

- Cisco IPICS operating system

- See* operating system, Cisco IPICS

- Cisco IP Phone

- See* Cisco Unified IP Phone

- Cisco Land Mobile Radio (LMR),  
documentation [xv](#)

- Cisco Media Convergence Server (MCS),  
documentation [xiv](#)

- Cisco Security Agent (CSA)

- checking status [5-7](#)

- documentation [xv](#), [6-15](#)

- logs [6-14](#)

- Security Events Log, opening [6-14](#)

- starting [2-17](#), [5-7](#)

- starting, stopping, and restarting [5-7](#)

- stopping [2-17](#), [5-7](#)

- Cisco Unified CallManager

- documentation [xiv](#)

- Cisco Unified CallManager Express,  
documentation [xiv](#)

- Cisco Unified IP Phone

- cannot access channel [3-16](#)

- cannot communicate with PMCs in a  
channel [3-47](#)

- documentation [xv](#)

- no power [3-47](#)

- troubleshooting power problems [3-47](#)

- voice quality issues with policy engine  
dial-in or dial-out calls [3-51](#)

- clear counters router command [3-52](#)

- clear line router command [3-59](#)

- clock source router command [3-52](#)

- codec, voice quality and [3-50](#), [3-51](#)

- command, server

- enableuser [5-4](#)

- modify\_ip [5-2](#)

- reset\_pw [5-5](#)

- service ciscosec [5-7](#)

- service ippe\_dial\_engine [5-8](#)

- service ipics [5-7](#)

- service ipics\_db [5-7](#)

- service ipics\_lm [5-8](#)

- service ipics\_tomcat [5-8](#)

- Command failed error [3-19](#)

- commands

- modify\_ip [3-23](#)

- communication issue

- PMCs and Cisco Unified IP Phones cannot  
communicate on a channel [3-47](#)

- some PMCs cannot talk on channel [3-43](#)

- VTG participants cannot hear each other [3-43](#)
- communication issues, VTGs and SIP
  - PMCs [3-51](#)
- connectivity indicators
  - SIP-based remote connections [4-25](#)
- controller, limiting number of DS0s [3-57](#)
- conventions, document [xvii](#)
- csalog log file [6-2](#)

## D

- database server
  - checking status [2-6, 5-7](#)
  - manually starting [3-7](#)
  - performing procedures [2-6](#)
  - restarting [2-7](#)
  - starting [2-8, 5-7](#)
  - stopping [2-7, 2-8](#)
  - troubleshooting [3-13](#)
- db-maintenance.log file, about [6-2](#)
- deactivating RMS, to edit router details [3-60](#)
- deactivation fails for RMS [3-57](#)
- debugging
  - PMC [6-9](#)
  - using CLI-based tools and service
    - commands [5-1](#)
  - using log files [6-1](#)
- diagnostics.log file [6-2](#)
- dial engine
  - checking status [2-12, 5-8](#)
  - error after uploading prompts [3-31](#)
  - performing service procedures [2-12](#)
  - restarting [2-14](#)
  - starting [2-14](#)
  - starting and stopping [5-8](#)
  - stopping [2-13](#)
  - voice quality problems [3-51](#)
- dial engine, starting and stopping [5-8](#)
- dial-in calls
  - disconnect after using hold or call waiting
    - feature [3-33](#)
  - do not connect [3-33](#)
- dial-out invites do not connect [3-35](#)
- dial-out notifications do not connect [3-36, 3-38](#)
- disabled user, enabling with enableuser
  - command [5-4](#)
- documentation
  - Cisco IOS [xv](#)
  - Cisco Land Mobile Radio (LMR) [xv](#)
  - Cisco Media Convergence Server (MCS) [xiv](#)
  - Cisco Security Agent [xv, 6-15](#)
  - Cisco Unified CallManager [xiv](#)
  - Cisco Unified CallManager Express [xiv](#)
  - Cisco Unified IP Phone [xv](#)
  - conventions [xvii](#)
- double-byte language support [4-26](#)
- DS0, limiting number on router [3-57](#)
- DSCP [3-49](#)
- DSPs, insufficient [3-43](#)

---

**E**

- echoes, in conferences [3-63](#)
- e-mail, outgoing notifications do not connect [3-36, 3-38](#)
- enableuser command [5-4](#)
- enabling a disabled user with enableuser command [5-4](#)
- encrypted file system [4-5](#)
- error
  - 404 or 500, in browser [3-9](#)
  - authorization after changing ipics user password [3-25](#)
  - command failed [3-19](#)
  - PMC gets unknown response [3-20](#)
  - undefined javascript [3-19](#)
- error messages [4-29](#)

---

**F**

- feedback
  - in conferences [3-63](#)
  - on VTG or channel [3-46](#)
- finding troubleshooting information [1-1](#)
- footswitch
  - troubleshooting [4-7](#)

---

**G**

- G.711 codec, voice quality and [3-50](#)

- G.729 codec, voice quality and [3-50](#)
- G711 codec, voice quality and [3-51](#)
- G729 codec, voice quality and [3-51](#)

---

**H**

- headset
  - resolving headset issues [4-11](#)
- hold, dial-in calls disconnect after using [3-33](#)
- host mismatch error, troubleshooting [3-23](#)

---

**I**

- IE publisher error [4-15](#)
- information
  - finding Cisco IPICS troubleshooting [1-1](#)
  - informix user, resetting password [3-13, 5-5](#)
  - install.log file [6-3](#)
  - installation, troubleshooting [3-1](#)
  - installation log file [4-3](#)
- Internet Explorer
  - browser error [3-9](#)
  - refreshing browser window [3-15](#)
  - troubleshooting browser access to the server [3-4](#)
- Internet Explorer browser guidelines [3-3](#)
- invitations, dial-out invites do not connect [3-35](#)
- IP address
  - changing [5-2](#)

- troubleshooting problems after
    - changing [3-23](#)
    - verifying Cisco IPICS [3-7](#)
  - ipics.log file [6-3](#)
  - ipics\_audit.log file [6-3](#)
  - ipics\_rms.log file [6-3](#)
  - ipicsadmin user, resetting password [3-26, 5-5](#)
  - ipics user, resetting password [5-5](#)
  - IP multicast, finding troubleshooting information [xvi](#)
  - IP Phone
    - See* Cisco Unified IP Phone
- 
- J**
- javascript error, troubleshooting
    - undefined [3-19](#)
- 
- L**
- language characters, incorrect display [3-19](#)
  - license
    - troubleshooting after changing IP address [3-23](#)
    - troubleshooting installation [3-23](#)
  - license, Cisco IPICS
    - troubleshooting installation [3-23](#)
  - license manager
    - checking status [2-9, 5-8](#)
    - restarting [2-10, 5-8](#)
    - starting [2-11, 5-8](#)
    - stopping [5-8](#)
  - lmgrd.log file [6-4](#)
  - location
    - incorrectly configured [3-16](#)
  - locked user, unlocking with enableuser command [5-4](#)
  - log files
    - Cisco IPICS Activity Log [6-2](#)
    - Cisco Security Agent (CSA) [6-14](#)
    - csalog [6-2](#)
    - db-maintenance [6-2](#)
    - diagnostics.log [6-2](#)
    - install.log [6-3](#)
    - ipics.log [6-3](#)
    - ipics\_audit.log [6-3](#)
    - ipics\_rms.log [6-3](#)
    - lmgrd.log [6-4](#)
    - PMC, modifying levels [6-6](#)
  - login, cannot log in after changing password [3-25](#)
  - loopback, indicator lights for [3-62](#)
- 
- M**
- Media category, PMC DebugLog.txt [6-8, 6-12](#)
  - Microsoft QoS Packet Scheduler [3-49](#)
  - modify\_ip command [3-23, 5-2](#)
  - multicast
    - finding troubleshooting information [xvi](#)
    - troubleshooting problems [3-42](#)

**N**

network processes, starting and stopping with CLI commands [5-7](#)

no prompt router command [3-59](#)

note, described [xvii](#)

notifications, dial-out notifications do not connect [3-36, 3-38](#)

**O**

one-way audio between PMC and Cisco Unified IP Phone [3-47](#)

one-way audio issues [4-11](#)

operating system, Cisco IPICS

- checking database status [2-6](#)
- checking tomcat service status [2-2](#)
- database procedures [2-6](#)
- database server procedures [2-6](#)
- restarting database [2-7](#)
- starting database [2-8](#)
- starting tomcat service [2-4, 2-5](#)
- stopping
  - tomcat service [2-3](#)
  - tomcat service procedures [2-2](#)

ops views, dial-out notifications do not work between ops views [3-38](#)

**P**

packets, IP marked incorrectly [3-49](#)

Packet Scheduler, Microsoft QoS [3-49](#)

password

- changing, for root user [3-28, 5-5](#)
- resetting
  - for informix user [3-26, 5-5](#)
  - for ipicsadmin user [3-26, 5-5](#)
  - for ipics user [3-25, 5-5](#)

PIM, sparse and sparse-dense modes [3-43](#)

ping command, using to verify Cisco IPICS IP address [3-7](#)

pins, mapping for a T1 on router [3-63](#)

PMC

- cannot communicate with IP Phones in a channel [3-47](#)

caveats

- application troubleshooting [4-29](#)
- CLI commands [4-12](#)
- VPN client [4-16](#)

- deactivates channel by itself [3-46](#)

- poor voice quality [3-50](#)

- SIP-connected voice communication interrupted [3-51](#)

- some cannot communicate on channel [3-43](#)

troubleshooting

- application [4-1](#)
- audio and headset issues [4-11](#)
- audio settings [4-7](#)
- caveats [4-29](#)
- channel activation issues [4-24](#)
- Cisco Security Agent [4-9](#)

- codec misconfiguration [4-25](#)
- coexistence [4-10](#)
- configuration file changes [4-6](#)
- connectivity issues [4-15](#)
- DNS issues [4-24](#)
- error messages [4-29](#)
- execution [4-2](#)
- footswitch device [4-7](#)
- generating a PMC installation log file [4-3](#)
- headset [4-8](#)
- headset issues [4-12](#)
- high latency, low bandwidth links [4-23](#)
- microphone [4-9](#)
- multicast connections [4-20](#)
- offline mode [4-21](#)
- one-way audio [4-11](#)
- one-way audio issues [4-12](#)
- optional settings menu [4-6](#)
- publisher error [4-15](#)
- resolving IP address changes [4-13](#)
- right-to-left and double-byte language support [4-26](#)
- RMS connectivity [4-22](#)
- satellite connectivity [4-23](#)
- unknown response error [3-20](#)
- using an encrypted file system [4-5](#)
- voice quality [4-14](#)
- VPN issues [4-16](#)
- VTG not appearing on [3-16](#)
- Windows XP firewall [4-18](#)
- winsock corruption [4-21](#)
- users are not logged out after terminating session [3-44](#)
- using debugging log level [6-9](#)
- voice quality degrades for SIP user [3-49](#)
- PMC DebugLog.txt [6-7](#), [6-10](#)
- PMC log levels, modifying [6-6](#)
- PoE module [3-47](#)
- policy, VTG not activating in [3-15](#)
- policy engine
  - cannot communicate with the prompt manager [3-32](#)
  - checking dial engine status [2-12](#)
  - performing dial engine service procedures [2-12](#)
  - restarting dial engine [2-14](#)
  - starting and stopping [5-7](#)
  - starting the dial engine [2-14](#)
  - stopping dial engine [2-13](#)
  - voice quality problems from dial engine [3-51](#)
- processes, Cisco IPICS, starting and stopping [5-7](#)
- prompt manager error messages [3-32](#)
- prompts, error after uploading [3-31](#)

---

## Q

- QoS, Microsoft Packet Scheduler [3-49](#)

**R**

- recovering a deleted user with system administrator privileges [3-22](#)
- refreshing browser window [3-15](#)
- reset\_pw command [5-5](#)
- resetting passwords, for ipics, ipicsadmin, informix and root users [5-5](#)
- restarting
  - database [2-7, 5-7](#)
  - dial engine [2-14](#)
  - license manager [2-10, 5-8](#)
  - tomcat service [5-8](#)
- restore, PMC gets error after [3-20](#)
- right-to-left language support [4-26](#)
- RMS [3-57](#)
  - configuration, long wait after restarting Cisco IPICS [3-57](#)
  - deactivating [3-60](#)
  - failing [3-59](#)
  - limiting DS0s on router [3-57](#)
  - log entries [6-3](#)
  - no loopbacks displayed on new [3-60](#)
  - PMC connectivity to the RMS [4-11](#)
  - SIP-based connectivity [4-24](#)
  - troubleshooting connectivity issues [4-22](#)
  - unrecognized T1 ports [3-61](#)
  - updating login information causes unreachable state [3-60](#)
- root user
  - resetting password [5-5](#)
- router
  - clear line command [3-59](#)
  - configuration shows wrong information [3-63](#)
  - insufficient DSPs on [3-43](#)
  - IOS software version [3-47](#)
  - long delays between pressing PMC PTT button and media establishment [3-65](#)
  - long wait for restart after configuring [3-57](#)
  - mapping pins for T1 [3-63](#)
  - no green indicator lights [3-62](#)
  - no loopbacks displayed on new RMS [3-60](#)
  - no prompt command [3-59](#)
  - PIM modes [3-43](#)
  - PoE module [3-47](#)
  - show users command [3-59](#)
  - slow VTG activation [3-59](#)
  - T1 configuration [3-52](#)
  - unreachable state [3-59, 3-60](#)
  - updating configuration in Cisco IPICS [3-63](#)
  - VTY lines [3-59](#)
- router media service
  - See* RMS

**S**

- Security Events Log, Cisco Security Agent, opening [6-14](#)
- server, database
  - checking status [2-6](#)
  - manually starting [3-7](#)

- restarting [2-7](#)
  - starting [2-8](#)
  - stopping [2-7, 2-8](#)
  - service ciscosec command [5-7](#)
  - service ipics\_db command [5-7](#)
  - service ipics\_lm command [5-8](#)
  - service ipics\_tomcat command [5-8](#)
  - service ipics command [5-7](#)
  - service ippe\_dial\_engine command [5-8](#)
  - Show Configuration feature [3-63](#)
  - show controllers router command, sample output [3-55](#)
  - show users router command [3-59](#)
  - Signaling category, PMC DebugLog.txt [6-8, 6-11](#)
  - SIP-based connection
    - connection failure [4-25](#)
  - spoken name prompt file, error after uploading [3-31](#)
  - starting
    - dial engine [2-14](#)
  - starting Cisco Security Agent [2-17](#)
  - starting database server [2-8](#)
  - starting the license manager [2-11](#)
  - starting tomcat service [2-4, 2-5](#)
  - status
    - checking database server [2-6, 5-7](#)
    - checking dial engine [5-8](#)
    - checking license manager [5-8](#)
    - checking policy engine [5-7](#)
    - checking tomcat service [2-2, 5-8](#)
  - stopping
    - Cisco Security Agent [2-17, 5-7](#)
    - database server [2-7, 2-8, 5-7](#)
    - dial engine [2-13, 5-8](#)
    - license manager [5-8](#)
    - policy engine [5-7](#)
    - tomcat service [5-8](#)
  - stopping tomcat service [2-3](#)
  - system administrator user, recovering a deleted user [3-22](#)
- 
- ## T
- T1
    - configuration [3-52](#)
    - loopbacks not displayed on new RMS [3-60](#)
    - mapping pins on router [3-63](#)
    - unrecognized ports [3-61](#)
  - TAC Case Collection Tool [4-14](#)
  - tomcat service
    - checking status [2-2, 3-4, 5-7, 5-8](#)
    - performing procedures [2-2](#)
    - restarting [3-5, 3-21](#)
    - starting [2-4, 2-5, 5-7, 5-8](#)
    - stopping [2-3, 5-7, 5-8](#)
  - troubleshooting
    - 404 or 500 error in browser
      - 404 error [3-9](#)
    - Administration Console not functioning [3-13](#)

- authorization error after changing password [3-25](#)
- cannot reach server from browser [3-4](#)
- Cisco Unified IP Phone cannot access channel [3-16](#)
- Command failed error [3-19](#)
- communication disrupted [3-51](#)
- configuration changes not saved when multiple users are configuring [3-21](#)
- connectivity between Cisco Unified Wireless IP Phone 7920 models [3-48](#)
- database stopped [3-13](#)
- dial engine voice quality [3-51](#)
- dial-in call cannot reconnect after using call waiting feature [3-33](#)
- dial-in call disconnects after placing on hold [3-33](#)
- dial-in calls [3-33](#)
- dial-out invites [3-35](#)
- dial-out notifications [3-36](#), [3-38](#)
- displaying loopbacks in Add Router window [3-60](#)
- feedback noise on VTG, channel [3-46](#)
- host mismatch error [3-23](#)
- installation issues [3-1](#)
- IP multicast information [xvi](#)
- language characters display incorrectly [3-19](#)
- license installation [3-23](#)
- login problems from browser [3-4](#)
- multicast problems [3-42](#)
- new RMS has no loopbacks [3-60](#)
- no green lights on router [3-62](#)
- non-activating policy [3-15](#)
- no power to Cisco Unified IP Phones [3-47](#)
- no table data [3-19](#)
- password problems, ipicsadmin or informix user [3-26](#)
- password problems for ipics user [3-25](#)
- password problems for root user [3-28](#)
- PMC deactivates channel by itself [3-46](#)
- PMCs cannot communicate on channel [3-43](#)
- PMC users not logged out after terminating session [3-44](#)
- policy engine voice quality [3-51](#)
- poor PMC voice quality [3-50](#)
- poor voice quality for SIP-based PMC [3-49](#)
- power for Cisco Unified IP Phones [3-47](#)
- RMS fails [3-59](#)
- router configuration long delays between pressing PMC PTT button and media establishment [3-65](#)
- router configuration shows wrong information [3-63](#)
- slow VTG activation [3-59](#)
- tomcat service not running [3-4](#)
- undefined javascript error [3-19](#)
- unreachable RMS state after updating login [3-60](#)
- unreachable router state [3-59](#)
- unresponsive Cisco IP Phone channel [3-16](#)
- unresponsive PMC channel [3-43](#)

- using CLI-based tools and service commands [5-1](#)
- using log files [6-1](#)
- voice loops in conferences [3-63](#)
- VTG activating itself [3-15](#)
- VTG feedback [3-46](#)
- VTG not appearing on PMC [3-16](#)
- VTG participants cannot communicate [3-43](#)
- troubleshooting the PMC application [4-1](#)

## U

---

- unlocking a locked-out user [5-4](#)
- unlocking a locked user with enableuser command [5-4](#)
- unreachable state on router [3-59, 3-60](#)
- Update Configuration feature [3-63](#)
- user ID, two for same user [3-16](#)
- user interface, PMC debug log information [6-7, 6-10](#)

## V

---

- voice, poor quality from policy engine dial-in or dial-out calls [3-51](#)
- voice, poor quality on PMC [3-50](#)
- voice, poor quality with dial engine calls [3-51](#)
- voice loops [3-63](#)
- voice quality
  - finding troubleshooting information for [xvi](#)
  - issues [4-14](#)

## VTG

- activates by itself [3-15](#)
- feedback noise [3-46](#)
- not activating in policy [3-15](#)
- not appearing on PMC [3-16](#)
- participants cannot hear each other [3-43](#)
- slow activation [3-59](#)
- voice interruptions [3-51](#)
- VTY lines [3-59](#)

