



## INDEX

---

### A

- Activate/Deactivate button, toggling [2-2, 2-3](#)
- Activate CLI command [2-2, 2-3](#)

---

### B

- batch file
  - example [1-4](#)
  - for CLI commands [1-3](#)
  - using [1-3](#)

---

### C

- case insensitivity, for CLI commands [2-2](#)
- caution, described [x](#)
- channel
  - See* PTT channel
- Cisco CallManager
  - documentation [viii](#)
- Cisco CallManager Express
  - documentation [viii](#)
- Cisco IOS
  - documentation [ix](#)

- Cisco IP Phones
  - documentation [viii](#)
- Cisco Land Mobile Radio (LMR)
  - documentation [ix](#)
- Cisco Security Agent
  - documentation [ix](#)
- CLI
  - about [1-1](#)
  - issuing commands [1-1, 1-2](#)
- CLI command
  - Activate [2-2, 2-3](#)
  - case insensitivity [2-2](#)
  - IsActive [2-2, 2-4](#)
  - IsEnabled [2-2, 2-5](#)
  - IsLatch [2-2, 2-6](#)
  - issuing [1-1, 1-2](#)
  - IsTxMuted [2-2, 2-6](#)
  - Play [2-2, 2-7](#)
  - return code [1-3](#)
- command
  - See* CLI command
- Command Line Interface
  - See* CLI
- conventions, document [x](#)

---

**D**

## documentation

- Cisco CallManager [viii](#)
- Cisco CallManager Express [viii](#)
- Cisco IOS [ix](#)
- Cisco IP Phones [viii](#)
- Cisco Land Mobile Radio (LMR) [ix](#)
- Cisco Security Agent [ix](#)
- conventions [x](#)
- MCS servers [viii](#)

---

**E**

- ERRORLEVEL environment variable [1-3](#)

---

**I**

- IsActive CLI command [2-2, 2-4](#)
- IsEnabled CLI command [2-2, 2-5](#)
- IsLatch CLI command [2-2, 2-6](#)
- IsTxMuted CLI command [2-2, 2-6](#)

---

**M**

## MCS servers

- documentation [viii](#)

---

**N**

- note, described [x](#)

---

**P**

- Play CLI command [2-2, 2-7](#)

## PMC

- active PTT channel [2-2, 2-4](#)
- affected by CLI command [1-2](#)
- configured PTT channel [2-6](#)
- enabled PTT channel [2-2, 2-5](#)
- issuing CLI command to [1-2](#)
- muted [2-2](#)

## PTT button

- state [2-2, 2-6](#)

## PTT channel

- active [2-2, 2-4](#)
- configured [2-6](#)
- enabled [2-2, 2-5](#)
- muted [2-2](#)

## Push-to-Talk Management Center

*See* PMC

---

**R**

## return code

- about [1-3](#)
- for IsActive command [2-5](#)

for IsEnabled command [2-5](#)  
for IsLatch command [2-6](#)  
for IsTxMuted command [2-7](#)  
in ERRORLEVEL environment  
variable [1-3](#)  
obtaining through batch file [1-4](#)

---

## W

wave file, playing on PTT channel [2-2,2-7](#)