



Preface

This command reference describes the Cisco IOS XR Interfaces commands. The preface for the *Interface and Hardware Component Command Reference for Cisco NCS 6000 Series Routers* contains the following sections:

- [Changes to this Document, page i](#)
- [Obtaining Documentation and Submitting a Service Request, page i](#)

Changes to this Document

This section lists the technical changes made to this document since it was first published.

Table 1: Changes to this Document

Revision	Date	Change Summary
OL-30975-02	January 2014	Republished with documentation updates for Cisco IOS XR Release 5.0.1 features.
OL-30975-01	November 2013	Initial Release of this document.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation*, at: <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

