

## **Preface**

This guide consists of information regarding the commands for NetFlow in Cisco IOS XR Software. For more information about the NetFlow over BVI feature, see the *Configuring NetFlow* module in the *Netflow Configuration Guide for Cisco NCS 6000 Series Routers*.

The preface consists of these sections:

- Changes to This Document, page i
- Obtaining Documentation and Submitting a Service Request, page i

## **Changes to This Document**

This table lists the changes made to this document since it was first printed.

Table 1: Changes to This Document

Revision	Date	Change Summary
OL-30985-01	November 2013	Initial release of this document.

## **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation*, at: http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

**Obtaining Documentation and Submitting a Service Request**