



Mapping Topics from VPN 3000 Series Concentrators to ASDM

The following tables map the VPN 3000 Concentrator tasks to the Adaptive Security Device Manager paths:

- [Table A-1, “Navigation Map for Configuration Tasks”](#)
- [Table A-2, “Navigation Map for Administration Tasks”](#)
- [Table A-3, “Monitoring Tasks”](#)

Table A-1 **Navigation Map for Configuration Tasks**

VPN 3000 Task	Topic	ASDM Path
Using the VPN 3000 Management application	Not applicable	ASDM Online Help > Welcome to ASDM
Configuring Interfaces	Not applicable	Configuration > Features > Interfaces > Add
	power	Enable Interface/Dedicate to management only
	Ethernet	Hardware Port
	General parameters	VLAN ID/Sub-interface ID
Configuring Servers	AAA Servers	Configuration > Features > Properties > AAA Setup > AAA Server Groups
	authentication, authorization, and accounting	Configuration > Features > Device Administration > AAA Access
	DHCP	Configuration > Features > Properties > DHCP Services > DHCP Server and DHCP Relay
	DNS	Configuration > Features > Properties > DNS Client
	NTP	Configuration > Features > Device Administration > Administration > NTP
	External servers (TACACS and RADIUS)	Configuration > Features > Properties > AAA Setup > AAA Server Groups > Add AAA Server Group (Protocol list box)
Configuring Address Management	Not applicable	Configuration > Features > VPN > IP Address Management
	Assignment	Assignment
	Pools	IP Pools

Table A-1 Navigation Map for Configuration Tasks (continued)

VPN 3000 Task	Topic	ASDM Path
Configuring Tunneling and IPSec	PPTP	Not applicable
	IPSec site-to-site	Configuration > Features > VPN > IPSec and Configuration > Features > VPN > VPN General > Tunnel Group (and Group Policy)
	IKE proposals	Configuration > Features > VPN > IKE > Policies
	NAT-Transparency	Configuration > Features > VPN > IKE > Global Parameters (NAT Transparency group box)
	Alerts	Configuration > Features > VPN > IKE > Global Parameters
Configuring WebVPN	Not applicable	Configuration > Features > VPN > WebVPN
Configuring IP Routing	Not applicable	Configuration > Features > Routing
	Static routes	Configuration > Features > Routing > Static Route
	Default gateways (“Tunnel Default Gateway”)	Configuration > Features > Routing > Static Route
	OSPF	Configuration > Features > Routing > OSPF
	DHCP	Configuration > Features > Properties > DHCP Services
	Redundancy	Configuration > Features > Properties > Failover
	RRI	Configuration > Features > VPN > Tunnel Policy > Add > Advanced Settings > Enable Reverse Route Injection
Configuring Management Protocols	Not applicable	Not applicable
	FTP	Tools > File Transfer
	HTTP/HTTPS	Configuration > Features > Properties > HTTP/HTTPS
	TFTP	Configuration > Features > Device Administration > Administration > TFTP Server
	Telnet	Configuration > Features > Device Administration > Administration > Telnet
	SNMP	Configuration > Features > Device Administration > Administration > SNMP
	SSL	Configuration > Features > Properties > SSL
	SSH	Configuration > Features > Device Administration > Administration > Secure Shell
	XML	Not applicable

Table A-1 **Navigation Map for Configuration Tasks (continued)**

VPN 3000 Task	Topic	ASDM Path
Configuring Event Reporting	Event classes--list	Configuration > Features > Properties > Logging
	Event security levels--list	Event Lists
	Event log	Syslog Setup
	General or default handling of events	Configuration > Properties > Logging > Logging Setup
	FTP information for automatic backup	
	Classes for special handling	
	Trap destinations for SNMP management	
	Syslog servers	Configuration > Properties > Logging > E-Mail Setup
	SMTP servers for email recipients	
Configuring System Information and Parameters	Not applicable	Configuration > Features > Device Administration > Administration
	Identification	Configuration > Features > Device Administration > Administration > Device
	Time and date	Configuration > Features > Device Administration > Administration > Clock
	Sessions - Maximum active IPSec connections - Maximum active WebVPN connections	Configuration > Features > VPN > VPN General > VPN System Options
	Authentication (global parameters)	Configuration > Features > Device Administration > Administration > AAA Access
Configuring Client Update	Not applicable	Configuration > Features > VPN > VPN General > Client Update
Configuring Load Balancing	Not applicable	Configuration > Features > VPN > Load Balancing
Configuring User Management	Not applicable	Configuration > Features > Device Administration > Administration > User Accounts
	Users	Configuration > Features > Device Administration > Administration > User Accounts
	Base Group	Not applicable
	Groups	Configuration > Features > VPN > VPN General > Group Policy and Configuration > Features > VPN > VPN General > Tunnel Group

Table A-1 Navigation Map for Configuration Tasks (continued)

VPN 3000 Task	Topic	ASDM Path
Configuring Policy Management	Access hours	Configuration > Features > Security Policy
	Traffic management	Access Rules
	• Network lists	AAA Rules
	• Rules	Filter Rules
	• SAs	Service Policy Rules
	• Filters	
	• Bandwidth	
	NAT Policy	Configuration > Features > NAT
	Certificate group matching	Configuration > Features > VPN > IKE > Certificate Group Matching
	• Policy (for group derivation)	• Policy
	• Rules	• Rules
	HTTP and HTTPS	Configuration > Features > Properties > HTTP/HTTPS
	SSL	Configuration > Features > Properties > SSL
Configuring Web VPN	Not applicable	Configuration > Features > VPN > WebVPN
	Access	WebVPN Access
	Servers and URLs	Servers and URLs
	Port Forwarding	Port Forwarding
	Home Page	Homepage
	Proxies	Proxies
	AAA	WebVPN AAA
	NetBios Servers	NetBIOS Servers
	ACLs	ACLs

Table A-2 Navigation Map for Administration Tasks

VPN 3000 Task	Topic	ASDM Path
Viewing statistics for all active sessions	Not applicable	Monitoring > Features > VPN and Monitoring > Features Administration
	Updating the display	Click Refresh
Updating the ASA system software	Not applicable	Tools > Upload Image From Local PC
Updating the VPN Client software	Not applicable	Configuration > Features > VPN > VPN General > Client Update
Shutting down and/or rebooting the system	Not applicable	Tools > System Reload
Viewing the reboot status	Not applicable	Tools > System Reload
Using the Ping utility	Not applicable	Tools > Ping

Table A-2 **Navigation Map for Administration Tasks (continued)**

VPN 3000 Task	Topic	ASDM Path
Configuring and controlling administrative access rights	Configure administrator usernames, access, and rights	Configuration > Features > Device Administration > Administration > AAA Access
	Configure ACLs for administrators	
	Configure access settings	
	Configure AAA servers for admin users	Configuration > Features > Properties > AAA Setup > AAA Servers
	Managing files in flash memory on the device	Tools > File Management
	Swap backup and boot configuration files	Tools > Upload Image from Local PC
	Transfer files using TFTP	Tools > File Transfer > TFTP
	Send a file using HTTP	Tools > File Transfer > HTTP
	Export the configuration to an XML file	Not applicable
Enrolling for and Managing Certificates (PKI)	Enrolling for a certificate	Configuration > Features > Device Administration > Certificate Keypair Trustpoint Authentication Enrollment Import Certificate Manage Certificate
	Obtaining an SSL certificate	
	Enabling CRL checking and caching	
	Enabling digital certificates for remote access connections	
	Enabling digital certificates for site-to-site connections	
	Deleting digital certificates	
	Managing certificates	
	- Enrolling identity and SSL certificates - Installing certificates once enrolled	
	Configuring SCEP parameters	
	Viewing CRL cache	
	Viewing certificate information	
	Configuring a CA certificate	
	Renewing a certificate	
	Managing enrollment requests	

Table A-3 **Monitoring Tasks**

VPN 3000 Task	Topic	ASDM Path
Monitoring the routing table (routes and protocols)	Not applicable	Monitoring > Features > Routing > Routes Monitoring > Features > Routing > OSPF LSAs Monitoring > Features > Routing > OSPF Neighbors
Viewing dynamic filters and rules	Not applicable	Configuration > Features > Security Policy
Viewing the event log	Not applicable	Monitoring > Features > Logging > Live Log
Viewing system status and memory status	Not applicable	Monitoring > Features > Administration > System Graphs
Displaying information about all active sessions	Not applicable	Monitoring > Features > VPN > VPN Statistics > Sessions Monitoring > Features > VPN > VPN Statistics > L2TP Sessions
Gathering Statistics	Not applicable	Monitoring > Features
	Accounting	Monitoring > Features > Administration > AAA Servers
	Address pools	
	Administrative AAA	Monitoring > Features > Administration > AAA Servers
	Authentication	Monitoring > Features > Administration > Authenticated Users
	Authorization	Monitoring > Features > Administration > AAA Servers
	Bandwidth management	Monitoring > Features > Administration > System Graphs
	Compression	Not applicable
	DHCP	Monitoring > Features > Interfaces > DHCP
	DNS	Monitoring > Features > Administration > DNS Cache
	Events	Monitoring > Features > Logging > Live Log
	Filtering	Not applicable
	HTTP	Monitoring > Features > VPN > VPN Statistics > Protocol Statistics
	IPSec	
	L2TP	
	Load balancing	
	NAT	
	PPTP	Not applicable
	SSH	Monitoring > Features > Administration > Secure Shell Sessions
	SSL	Monitoring > Features > Administration > ASDM > HTTPS Sessions
	Telnet	Monitoring > Features > Administration > Telnet Sessions
	VRRP	Not applicable