



## INDEX

---

### B

battery **4-3**  
remove **4-3**  
replace **4-4**

---

### C

chassis  
rack-mount **3-7**  
rack mount tray **3-8**  
security bracket **3-9**  
wall-mount **3-5**  
chassis covers  
removing **4-2**  
replace **4-3**  
Cisco warranty **2-1**

---

### D

desktop cable lock **3-4**  
install **3-4**

---

### E

electrostatic discharge  
see ESD

ESD  
preventing **2-3, 4-1**

---

### F

failover **1-3**

FIPS enclosure **3-11**

install **3-11**  
tamper labels **3-12**  
wall-mount **3-11**

---

### I

installing cables **3-1**  
console port **3-3**  
ethernet ports **3-2**

---

### L

LED  
front panel LEDs **1-1**  
LINK LED **3-2**  
power LED **3-3**  
rear panel LEDs **1-2**  
SSC LEDs **4-5**

---

### M

memory **4-6**  
DIMM **4-7**  
DRAM memory **1-3**  
flash memory **1-3**

---

### P

PoE **1-2, 3-2**  
power supplies  
considerations **2-4**

---

---

## R

RJ-45 connector

pinouts **1-4**

---

## S

Security Services Card (SSC) **4-4**

install **4-5**

replace **4-6**

site environment **2-3**

---

## W

Warning

AC Power **1-ix**

Blank Faceplates **1-viii**

Chassis **1-viii**

Circuit Breaker **1-ix**

Cover Panels **1-viii**

Ground Conductor **1-viii**

Grounded Equipment **1-x**

Instructions **1-vii**

Jewelry **1-vii**

Lightning **1-vii**

power Supply **1-vii**

Product Disposal **1-viii**

Rack-Mounting **1-viii**

SELV **1-viii**

Short-Circuit **1-viii, 1-ix**

TN Power **1-ix**

Wrist Strap **1-vii**