Syslog Messages

This chapter lists the messages in numerical order.

Note When a number is skipped in a sequence, the message is no longer in the ASA code.

For information about how to configure logging, SNMP, and NetFlow, see the CLI configuration guide.

Table 1-1 lists the message classes and the ranges of message IDs that are associated with each class. The valid range for message IDs is between 100000 and 999999.

Table 1-1 Syslog Message Classes and Associated Message ID Numbers

Class	Definition	Syslog Message ID Numbers
aaa, auth	User Authentication	109, 113
acl	Access Lists	106
appfw	Application Firewall	415
bridge	Transparent Firewall	110, 220
ca	PKI Certification Authority	717
citrix	Web VPN	723
clst	Clustering	747
cmgr	Card Management	323
config	Command Interface	111, 112, 208, 308
cts	Cisco TrustSec	776
dap	Dynamic Access Policies	734
eap, eapoudp	Network Admission Control	333, 334
eigrp	EIGRP Routing	336
email	E-mail Proxy	719
envmon	Environment Monitoring	735
ha	High Availability (Failover)	101, 102, 103, 104, 105, 210, 311, 709, 727
id	Identity-based Firewall	746
ids	Intrusion Detection System	400, 733
ikev2	IKEv2 Toolkit	750, 751, 752

Table 1-1 Syslog Message Classes and Associated Message ID Numbers (continued)

Class	Definition	Syslog Message ID Numbers
ip	IP Stack	209, 215, 313, 317, 408
ipaa	IP Address Assignment	735
ips	Intrusion Protection System	400, 401, 420
ipv6	IPv6	325
l4tm	Blacklists, Whitelists, and Graylists	338
lb	Load Balancing	728
lic	Licensing	444
nac policy	Network Admission Control Policy	731
nac settings	Network Admission Control Settings	732
nap	Network Access Point	713
np	Network Processor	319
npssl	NP SSL	725
ospf	OSPF Routing	318, 409, 503, 613
passwd	Password Encryption	742
pp	Phone Proxy	337
rip	RIP Routing	107, 312
rm	Resource Manager	321
sch	Smart Call Home	120
session	User Session	106, 108, 201, 202, 204, 302, 303, 304, 305, 314, 405, 406, 407, 500, 502, 607, 608, 609, 616, 620, 703, 710
snmp	SNMP	212
ssafe	ScanSafe	775
ssl	Secure Socket Layer	725
sts	Service Tag Switching	779
svc	SSL VPN Client	722
sys	System	199, 211, 214, 216, 306, 307, 315, 414, 604, 605, 606, 610, 612, 614, 615,701, 711, 741
td	Threat Detection	733
tre	Transactional Rule Engine	780
vipr	UC-IME	339
vn	VLAN Mapping	730
vpdn	PPTP and L2TP Sessions	213, 403, 603
vpn	IKE and IPsec	316, 320, 402, 404, 501, 602, 702, 713, 714, 715
vpnc	VPN Client	611
vpnfo	VPN Failover	720
vpnlb	VPN Load Balancing	718
vxlan	VXLAN	778

Table 1-1 Syslog Message Classes and Associated Message ID Numbers (continued)

Class	Definition	Syslog Message ID Numbers
webfo	Web-based Failover	721
webvpn	Web-based VPN	716
xlate	NAT and PAT	305

This chapter includes the following sections:

- Messages 101001 to 199021, page 1-3
- Messages 201002 to 219002, page 1-78
- Messages 302003 to 339009, page 1-100
- Messages 400000 to 450001, page 1-191
- Messages 500001 to 509001, page 1-274
- Messages 602101 to 634001, page 1-291
- Messages 701001 to 780004, page 1-329

Messages 101001 to 199021

This section includes messages from 101001 to 199021.

101001

Error Message `%ASA-1-101001: (Primary) Failover cable OK.`

Explanation The failover cable is present and functioning correctly. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

101002

Error Message `%ASA-1-101002: (Primary) Bad failover cable.`

Explanation The failover cable is present, but not functioning correctly. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Replace the failover cable.

101003, 101004

Error Message `%ASA-1-101003: (Primary) Failover cable not connected (this unit).`

Error Message `%ASA-1-101004: (Primary) Failover cable not connected (other unit).`

Explanation Failover mode is enabled, but the failover cable is not connected to one unit of the failover pair. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Connect the failover cable to both units of the failover pair.

101005

Error Message `%ASA-1-101005: (Primary) Error reading failover cable status.`

Explanation The failover cable is connected, but the primary unit is unable to determine its status.

Recommended Action Replace the cable.

103001

Error Message `%ASA-1-103001: (Primary) No response from other firewall (reason code = code).`

Explanation The primary unit is unable to communicate with the secondary unit over the failover cable. Primary can also be listed as Secondary for the secondary unit. Table 1-2 lists the reason codes and the descriptions to determine why the failover occurred.

Table 1-2 Reason Codes

Reason Code	Description
1	The local unit is not receiving the hello packet on the failover LAN interface when LAN failover occurs or on the serial failover cable when serial failover occurs, and declares that the peer is down.
2	An interface did not pass one of the four failover tests, which are as follows: 1) Link Up, 2) Monitor for Network Traffic, 3) ARP, and 4) Broadcast Ping.
3	No proper ACK for 15+ seconds after a command was sent on the serial cable.
4	The failover LAN interface is down, and other data interfaces are not responding to additional interface testing. In addition, the local unit is declaring that the peer is down.
5	The standby peer went down during the configuration synchronization process.

Recommended Action Verify that the failover cable is connected correctly and both units have the same hardware, software, and configuration. If the problem persists, contact the Cisco TAC.

103002

Error Message `%ASA-1-103002: (Primary) Other firewall network interface` *`interface_number`* `OK.`

Explanation The primary unit has detected that the network interface on the secondary unit is okay. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

103003

Error Message `%ASA-1-103003: (Primary) Other firewall network interface` *`interface_number`* `failed.`

Explanation The primary unit has detected a bad network interface on the secondary unit. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Check the network connections on the secondary unit and the network hub connection. If necessary, replace the failed network interface.

103004

Error Message `%ASA-1-103004: (Primary) Other firewall reports this firewall failed. Reason:` *`reason-string`*

Explanation The primary unit received a message from the secondary unit indicating that the primary unit has failed. Primary can also be listed as Secondary for the secondary unit. The reason can be one of the following:

- Missed poll packets on failover command interface exceeded threshold.
- LAN failover interface failed.
- Peer failed to enter Standby Ready state.
- Failed to complete configuration replication. This firewall's configuration may be out of sync.
- Failover message transmit failure and no ACK for busy condition received.

Recommended Action Verify the status of the primary unit.

103005

Error Message `%ASA-1-103005: (Primary) Other firewall reporting failure. Reason: SSM card failure`

Explanation The secondary unit has reported an SSM card failure to the primary unit. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Verify the status of the secondary unit.

103006

Error Message `%ASA-1-103006: (Primary|Secondary) Mate version ver_num is not compatible with ours ver_num`

Explanation The ASA has detected a peer unit that is running a version that is different than the local unit and is not compatible with the HA Hitless Upgrade feature.

- *ver_num*—Version number

Recommended Action Install the same or a compatible version image on both units.

103007

Error Message `%ASA-1-103007: (Primary|Secondary) Mate version ver_num is not identical with ours ver_num`

Explanation The ASA has detected that the peer unit is running a version that is not identical, but supports Hitless Upgrade and is compatible with the local unit. The system performance may be degraded because the image version is not identical, and the ASA may develop a stability issue if the nonidentical image runs for an extended period.

- *ver_num*—Version number

Recommended Action Install the same image version on both units as soon as possible.

104001, 104002

Error Message `%ASA-1-104001: (Primary) Switching to ACTIVE (cause: string).`

Error Message `%ASA-1-104002: (Primary) Switching to STANDBY (cause: string).`

Explanation You have forced the failover pair to switch roles, either by entering the **failover active** command on the standby unit, or the **no failover active** command on the active unit. Primary can also be listed as Secondary for the secondary unit. Possible values for the *string* variable are as follows:

- state check
- bad/incomplete config
- ifc [interface] check, mate is healthier
- the other side wants me to standby
- in failed state, cannot be active
- switch to failed state
- other unit set to active by CLI config command fail active

Recommended Action If the message occurs because of manual intervention, no action is required. Otherwise, use the cause reported by the secondary unit to verify the status of both units of the pair.

104003

Error Message `%ASA-1-104003: (Primary) Switching to FAILED.`

Explanation The primary unit has failed.

Recommended Action Check the messages for the primary unit for an indication of the nature of the problem (see message 104001). Primary can also be listed as Secondary for the secondary unit.

104004

Error Message `%ASA-1-104004: (Primary) Switching to OK.`

Explanation A previously failed unit reports that it is operating again. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

105001

Error Message `%ASA-1-105001: (Primary) Disabling failover.`

Explanation In version 7.x and later, this message may indicate the following: failover has been automatically disabled because of a mode mismatch (single or multiple), a license mismatch (encryption or context), or a hardware difference (one unit has an IPS SSM installed, and its peer has a CSC SSM installed). Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

105002

Error Message `%ASA-1-105002: (Primary) Enabling failover.`

Explanation You have used the **failover** command with no arguments on the console, after having previously disabled failover. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

105003

Error Message `%ASA-1-105003: (Primary) Monitoring on interface` *`interface_name`* `waiting`

Explanation The ASA is testing the specified network interface with the other unit of the failover pair. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required. The ASA monitors its network interfaces frequently during normal operation.

105004

Error Message `%ASA-1-105004: (Primary) Monitoring on interface` *`interface_name`* `normal`

Explanation The test of the specified network interface was successful. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

105005

Error Message `%ASA-1-105005: (Primary) Lost Failover communications with mate on interface interface_name.`

Explanation One unit of the failover pair can no longer communicate with the other unit of the pair. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Verify that the network connected to the specified interface is functioning correctly.

105006, 105007

Error Message `%ASA-1-105006: (Primary) Link status Up on interface interface_name.`

Error Message `%ASA-1-105007: (Primary) Link status Down on interface interface_name.`

Explanation The results of monitoring the link status of the specified interface have been reported. Primary can also be listed as Secondary for the secondary unit.

Recommended Action If the link status is down, verify that the network connected to the specified interface is operating correctly.

105008

Error Message `%ASA-1-105008: (Primary) Testing interface interface_name.`

Explanation Testing of a specified network interface has occurred. This testing is performed only if the ASA fails to receive a message from the standby unit on that interface after the expected interval. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

105009

Error Message `%ASA-1-105009: (Primary) Testing on interface interface_name {Passed|Failed}.`

Explanation The result (either Passed or Failed) of a previous interface test has been reported. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required if the result is Passed. If the result is Failed, you should check the network cable connection to both failover units, that the network itself is functioning correctly, and verify the status of the standby unit.

105010

Error Message `%ASA-3-105010: (Primary) Failover message block alloc failed`

Explanation Block memory was depleted. This is a transient message and the ASA should recover. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Use the **show blocks** command to monitor the current block memory.

105011

Error Message `%ASA-1-105011: (Primary) Failover cable communication failure`

Explanation The failover cable is not permitting communication between the primary and secondary units. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Ensure that the cable is connected correctly.

105020

Error Message `%ASA-1-105020: (Primary) Incomplete/slow config replication`

Explanation When a failover occurs, the active ASA detects a partial configuration in memory. Normally, this is caused by an interruption in the replication service. Primary can also be listed as Secondary for the secondary unit.

Recommended Action After the ASA detects the failover, the ASA automatically reboots and loads the configuration from flash memory and/or resynchronizes with another ASA. If failovers occurs continuously, check the failover configuration and make sure that both ASAs can communicate with each other.

105021

Error Message `%ASA-1-105021: (`*`failover_unit`*`) Standby unit failed to sync due to a locked `*`context_name`*` config. Lock held by `*`lock_owner_name`*

Explanation During configuration synchronization, a standby unit will reload itself if some other process locks the configuration for more than five minutes, which prevents the failover process from applying the new configuration. This can occur when an administrator pages through a running configuration on the standby unit while configuration synchronization is in process. See also the **show running-config** command in privileged EXEC mode and the **pager lines** *num* command in global configuration mode in the *Cisco ASA 5500 Series Command Reference*.

Recommended Action Avoid viewing or modifying the configuration on the standby unit when it first boots up and is in the process of establishing a failover connection with the active unit.

105031

Error Message `%ASA-1-105031: Failover LAN interface is up`

Explanation The LAN failover interface link is up.

Recommended Action None required.

105032

Error Message `%ASA-1-105032: LAN Failover interface is down`

Explanation The LAN failover interface link is down.

Recommended Action Check the connectivity of the LAN failover interface. Make sure that the speed or duplex setting is correct.

105034

Error Message `%ASA-1-105034: Receive a LAN_FAILOVER_UP message from peer.`

Explanation The peer has just booted and sent the initial contact message.

Recommended Action None required.

105035

Error Message `%ASA-1-105035: Receive a LAN failover interface down msg from peer.`

Explanation The peer LAN failover interface link is down. The unit switches to active mode if it is in standby mode.

Recommended Action Check the connectivity of the peer LAN failover interface.

105036

Error Message `%ASA-1-105036: dropped a LAN Failover command message.`

Explanation The ASA dropped an unacknowledged LAN failover command message, indicating a connectivity problem exists on the LAN failover interface.

Recommended Action Check that the LAN interface cable is connected.

105037

Error Message `%ASA-1-105037: The primary and standby units are switching back and forth as the active unit.`

Explanation The primary and standby units are switching back and forth as the active unit, indicating a LAN failover connectivity problem or software bug exists.

Recommended Action Make sure that the LAN interface cable is connected.

105038

Error Message `%ASA-1-105038: (Primary) Interface count mismatch`

Explanation When a failover occurs, the active ASA detects a partial configuration in memory. Normally, this is caused by an interruption in the replication service. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Once the failover is detected by the ASA, the ASA automatically reboots and loads the configuration from flash memory and/or resynchronizes with another ASA. If failovers occur continuously, check the failover configuration and make sure that both ASAs can communicate with each other.

105039

Error Message `%ASA-1-105039: (Primary) Unable to verify the Interface count with mate. Failover may be disabled in mate.`

Explanation Failover initially verifies that the number of interfaces configured on the primary and secondary ASAs are the same. This message indicates that the primary ASA is not able to verify the number of interfaces configured on the secondary ASA. This message indicates that the primary ASA is not able to communicate with the secondary ASA over the failover interface. Primary can also be listed as Secondary for the secondary unit.

Recommended Action Verify the failover LAN, interface configuration, and status on the primary and secondary ASAs. Make sure that the secondary ASA is running the ASA application and that failover is enabled.

105040

Error Message `%ASA-1-105040: (Primary) Mate failover version is not compatible.`

Explanation The primary and secondary ASAs should run the same failover software version to act as a failover pair. This message indicates that the secondary ASA failover software version is not compatible with the primary ASA. Failover is disabled on the primary ASA. Primary can also be listed as Secondary for the secondary ASA.

Recommended Action Maintain consistent software versions between the primary and secondary ASAs to enable failover.

105042

Error Message `%ASA-1-105042: (Primary) Failover interface OK`

Explanation The LAN failover interface link is up.

Explanation The interface used to send failover messages to the secondary ASA is functioning. Primary can also be listed as Secondary for the secondary ASA.

Recommended Action None required.

105043

Error Message `%ASA-1-105043: (Primary) Failover interface failed`

Explanation The LAN failover interface link is down.

Recommended Action Check the connectivity of the LAN failover interface. Make sure that the speed or duplex setting is correct.

105044

Error Message `%ASA-1-105044: (Primary) Mate operational mode` *`mode`* `is not compatible with my mode` *`mode`*`.`

Explanation When the operational mode (single or multiple) does not match between failover peers, failover will be disabled.

Recommended Action Configure the failover peers to have the same operational mode, and then reenable failover.

105045

Error Message `%ASA-1-105045: (Primary) Mate license (number contexts) is not compatible with my license (number contexts).`

Explanation When the feature licenses do not match between failover peers, failover will be disabled.

Recommended Action Configure the failover peers to have the same feature license, and then reenable failover.

105046

Error Message `%ASA-1-105046 (Primary|Secondary) Mate has a different chassis`

Explanation Two failover units have a different type of chassis. For example, one has a three-slot chassis; the other has a six-slot chassis.

Recommended Action Make sure that the two failover units are the same.

105047

Error Message `%ASA-1-105047: Mate has a io_card_name1 card in slot slot_number which is different from my io_card_name2`

Explanation The two failover units have different types of cards in their respective slots.

Recommended Action Make sure that the card configurations for the failover units are the same.

105048

Error Message `%ASA-1-105048: (unit) Mate's service module (application) is different from mine (application)`

Explanation The failover process detected that different applications are running on the service modules in the active and standby units. The two failover units are incompatible if different service modules are used.

- *unit*—Primary or secondary
- *application*—The name of the application, such as InterScan Security Card

Recommended Action Make sure that both units have identical service modules before trying to reenable failover.

106001

Error Message `%ASA-2-106001: Inbound TCP connection denied from IP_address/port to IP_address/port flags tcp_flags on interface interface_name`

Explanation An attempt was made to connect to an inside address is denied by the security policy that is defined for the specified traffic type. The IP address displayed is the real IP address instead of the IP address that appears through NAT. Possible *tcp_flags* values correspond to the flags in the TCP header that were present when the connection was denied. For example, a TCP packet arrived for which no connection state exists in the ASA, and it was dropped. The *tcp_flags* in this packet are FIN and ACK.

The *tcp_flags* are as follows:

- ACK—The acknowledgment number was received
- FIN—Data was sent
- PSH—The receiver passed data to the application
- RST—The connection was reset
- SYN—Sequence numbers were synchronized to start a connection
- URG—The urgent pointer was declared valid

Recommended Action None required.

106002

Error Message `%ASA-2-106002: protocol Connection denied by outbound list acl_ID src inside_address dest outside_address`

Explanation The specified connection failed because of an **outbound deny** command. The *protocol* variable can be ICMP, TCP, or UDP.

Recommended Action Use the **show outbound** command to check outbound lists.

106006

Error Message `%ASA-2-106006: Deny inbound UDP from outside_address/outside_port to inside_address/inside_port on interface interface_name.`

Explanation An inbound UDP packet was denied by the security policy that is defined for the specified traffic type.

Recommended Action None required.

106007

Error Message %ASA-2-106007: Deny inbound UDP from *outside_address/outside_port* to *inside_address/inside_port* due to DNS {Response|Query}.

Explanation A UDP packet containing a DNS query or response was denied.

Recommended Action If the inside port number is 53, the inside host probably is set up as a caching name server. Add an **access-list** command statement to permit traffic on UDP port 53 and a translation entry for the inside host. If the outside port number is 53, a DNS server was probably too slow to respond, and the query was answered by another server.

106010

Error Message %ASA-3-106010: Deny inbound *protocol src* [*interface_name*: *source_address/source_port*] [([*idfw_user* | *FQDN_string*], *sg_info*)] *dst* [*interface_name*: *dest_address/dest_port*}[([*idfw_user* | *FQDN_string*], *sg_info*)]

Explanation An inbound connection was denied by your security policy.

Recommended Action Modify the security policy if traffic should be permitted. If the message occurs at regular intervals, contact the remote peer administrator.

106011

Error Message %ASA-3-106011: Deny inbound (No xlate) *string*

Explanation The message appears under normal traffic conditions if there are internal users that are accessing the Internet through a web browser. Any time a connection is reset, when the host at the end of the connection sends a packet after the ASA receives the connection reset, this message appears. It can typically be ignored.

Recommended Action Prevent this message from getting logged to the syslog server by entering the **no logging message 106011** command.

106012

Error Message %ASA-6-106012: Deny IP from *IP_address* to *IP_address*, IP options *hex*.

Explanation An IP packet was seen with IP options. Because IP options are considered a security risk, the packet was discarded.

Recommended Action Contact the remote host system administrator to determine the problem. Check the local site for loose source routing or strict source routing.

106013

Error Message %ASA-2-106013: Dropping echo request from *IP_address* to PAT address *IP_address*

Explanation The ASA discarded an inbound ICMP Echo Request packet with a destination address that corresponds to a PAT global address. The inbound packet is discarded because it cannot specify which PAT host should receive the packet.

Recommended Action None required.

106014

Error Message %ASA-3-106014: Deny inbound icmp *src interface_name*: *IP_address* [([*idfw_user* | *FQDN_string*], *sg_info*)] *dst interface_name*: *IP_address* [([*idfw_user* | *FQDN_string*], *sg_info*)] (type *dec*, code *dec*)

Explanation The ASA denied any inbound ICMP packet access. By default, all ICMP packets are denied access unless specifically allowed.

Recommended Action None required.

106015

Error Message %ASA-6-106015: Deny TCP (no connection) from *IP_address*/*port* to *IP_address*/*port* flags *tcp_flags* on interface *interface_name*.

Explanation The ASA discarded a TCP packet that has no associated connection in the ASA connection table. The ASA looks for a SYN flag in the packet, which indicates a request to establish a new connection. If the SYN flag is not set, and there is no existing connection, the ASA discards the packet.

Recommended Action None required unless the ASA receives a large volume of these invalid TCP packets. If this is the case, trace the packets to the source and determine the reason these packets were sent.

106016

Error Message `%ASA-2-106016: Deny IP spoof from (IP_address) to IP_address on interface interface_name.`

Explanation A packet arrived at the ASA interface that has a destination IP address of 0.0.0.0 and a destination MAC address of the ASA interface. In addition, this message is generated when the ASA discarded a packet with an invalid source address, which may include one of the following or some other invalid address:

- Loopback network (127.0.0.0)
- Broadcast (limited, net-directed, subnet-directed, and all-subnets-directed)
- The destination host (land.c)

To further enhance spoof packet detection, use the **icmp** command to configure the ASA to discard packets with source addresses belonging to the internal network, because the **access-list** command has been deprecated and is no longer guaranteed to work correctly.

Recommended Action Determine if an external user is trying to compromise the protected network. Check for misconfigured clients.

106017

Error Message `%ASA-2-106017: Deny IP due to Land Attack from IP_address to IP_address`

Explanation The ASA received a packet with the IP source address equal to the IP destination, and the destination port equal to the source port. This message indicates a spoofed packet that is designed to attack systems. This attack is referred to as a Land Attack.

Recommended Action If this message persists, an attack may be in progress. The packet does not provide enough information to determine where the attack originates.

106018

Error Message `%ASA-2-106018: ICMP packet type ICMP_type denied by outbound list acl_ID src inside_address dest outside_address`

Explanation The outgoing ICMP packet with the specified ICMP from local host (*inside_address*) to the foreign host (*outside_address*) was denied by the outbound ACL list.

Recommended Action None required.

106020

Error Message `%ASA-2-106020: Deny IP teardrop fragment (size = number, offset = number) from IP_address to IP_address`

Explanation The ASA discarded an IP packet with a teardrop signature containing either a small offset or fragment overlapping. This is a hostile event that circumvents the ASA or an Intrusion Detection System.

Recommended Action Contact the remote peer administrator or escalate this issue according to your security policy.

106021

Error Message `%ASA-1-106021: Deny protocol reverse path check from source_address to dest_address on interface interface_name`

Explanation An attack is in progress. Someone is attempting to spoof an IP address on an inbound connection. Unicast RPF, also known as reverse route lookup, detected a packet that does not have a source address represented by a route and assumes that it is part of an attack on your ASA.

This message appears when you have enabled Unicast RPF with the **ip verify reverse-path** command. This feature works on packets input to an interface; if it is configured on the outside, then the ASA checks packets arriving from the outside.

The ASA looks up a route based on the source_address. If an entry is not found and a route is not defined, then this message appears and the connection is dropped.

If there is a route, the ASA checks which interface it corresponds to. If the packet arrived on another interface, it is either a spoof or there is an asymmetric routing environment that has more than one path to a destination. The ASA does not support asymmetric routing.

If the ASA is configured on an internal interface, it checks static **route** command statements or RIP, and if the source_address is not found, then an internal user is spoofing their address.

Recommended Action Even though an attack is in progress, if this feature is enabled, no user action is required. The ASA repels the attack.

106022

Error Message `%ASA-1-106022: Deny protocol connection spoof from source_address to dest_address on interface interface_name`

Explanation A packet matching a connection arrived on a different interface from the interface on which the connection began. In addition, the **ip verify reverse-path** command is not configured.

For example, if a user starts a connection on the inside interface, but the ASA detects the same connection arriving on a perimeter interface, the ASA has more than one path to a destination. This is known as asymmetric routing and is not supported on the ASA.

An attacker also might be attempting to append packets from one connection to another as a way to break into the ASA. In either case, the ASA shows this message and drops the connection.

Recommended Action Check that the routing is not asymmetric.

106023

Error Message `%ASA-4-106023: Deny protocol src [interface_name:source_address/source_port] [([idfw_user|FQDN_string], sg_info)] dst interface_name:dest_address/dest_port [([idfw_user|FQDN_string], sg_info)] [type {string}, code {code}] by access_group acl_ID [0x8ed66b60, 0xf8852875]`

Explanation A real IP packet was denied by the ACL. This message appears even if you do not have the **log** option enabled for an ACL. The IP address is the real IP address instead of the values that display through NAT. Both user identity information and FQDN information is provided for the IP addresses if a matched one is found. The ASA logs either identity information (domain\user) or FQDN (if the username is not available). If the identity information or FQDN is available, the ASA logs this information for both the source and destination.

Recommended Action If messages persist from the same source address, a footprinting or port scanning attempt might be occurring. Contact the remote host administrator.

106024

Error Message `%ASA-2-106024: Access rules memory exhausted`

Explanation The access list compilation process has run out of memory. All configuration information that has been added since the last successful access list was removed from the ASA, and the most recently compiled set of access lists will continue to be used.

Recommended Action Access lists, AAA, ICMP, SSH, Telnet, and other rule types are stored and compiled as access list rule types. Remove some of these rule types so that others can be added.

106025, 106026

Error Message `%ASA-6-106025: Failed to determine the security context for the packet:sourceVlan:source_address dest_address source_port dest_port protocol`

Error Message `%ASA-6-106026: Failed to determine the security context for the packet:sourceVlan:source_address dest_address source_port dest_port protocol`

Explanation The security context of the packet in multiple context mode cannot be determined. Both messages can be generated for IP packets being dropped in either router and transparent mode.

Recommended Action None required.

106027

Error Message `%ASA-4-106027:Failed to determine the security context for the packet:vlansource Vlan#:ethertype src sourceMAC dst destMAC`

Explanation The security context of the packet in multiple context mode cannot be determined. This message is generated for non-IP packets being dropped in transparent mode only.

Recommended Action None required.

106100

Error Message `%ASA-6-106100: access-list acl_ID {permitted | denied | est-allowed} protocol interface_name/source_address(source_port) (idfw_user, sg_info) interface_name/dest_address(dest_port) (idfw_user, sg_info) hit-cnt number ({first hit | number-second interval}) hash codes`

Explanation The initial occurrence or the total number of occurrences during an interval are listed. This message provides more information than message 106023, which only logs denied packets, and does not include the hit count or a configurable level.

When an access-list line has the *log* argument, it is expected that this message ID might be triggered because of a nonsynchronized packet reaching the ASA and being evaluated by the access list. For example, if an ACK packet is received on the ASA (for which no TCP connection exists in the connection table), the ASA might generate message 106100, indicating that the packet was permitted; however, the packet is later correctly dropped because of no matching connection.

The following list describes the message values:

- permitted | denied | est-allowed—These values specify if the packet was permitted or denied by the ACL. If the value is est-allowed, the packet was denied by the ACL but was allowed for an already established session (for example, an internal user is allowed to accesss the Internet, and responding packets that would normally be denied by the ACL are accepted).
- *protocol*—TCP, UDP, ICMP, or an IP protocol number.
- *interface_name*—The interface name for the source or destination of the logged flow. The VLAN interfaces are supported.
- *source_address*—The source IP address of the logged flow. The IP address is the real IP address instead of the values that display through NAT.
- *dest_address*—The destination IP address of the logged flow. The IP address is the real IP address instead of the values that display through NAT.
- *source_port*—The source port of the logged flow (TCP or UDP). For ICMP, the number after the source port is the message type.
- *idfw_user*—The user identity username, including the domain name that is added to the existing syslog when the ASA can find the username for the IP address.
- *sg_info*—The security group tag that is added to the syslog when the ASA can find a security group tag for the IP address. The security group name is displayed with the security group tag, if available.

- *dest_port*—The destination port of the logged flow (TCP or UDP). For ICMP, the number after the destination port is the ICMP message code, which is available for some message types. For type 8, it is always 0. For a list of ICMP message types, see the following URL: http://www.iana.org/assignments/icmp-parameters/icmp-parameters.xml.
- hit-cnt *number*—The number of times this flow was permitted or denied by this ACL entry in the configured time interval. The value is 1 when the ASA generates the first message for this flow.
- first hit—The first message generated for this flow.
- *number*-second interval—The interval in which the hit count is accumulated. Set this interval using the **access-list** command with the **interval** option.
- hash codes—Two are always printed for the object group ACE and the constituent regular ACE. Values are determined on which ACE that the packet hit. To display these hash codes, enter the **show-access list** command.

Recommended Action None required.

106101

Error Message `%ASA-1-106101 The number of ACL log deny-flows has reached limit (number).`

Explanation If you configured the **log** option for an ACL **deny** statement (**access-list** *id* **deny** command), and a traffic flow matches the ACL statement, the ASA caches the flow information. This message indicates that the number of matching flows that are cached on the ASA exceeds the user-configured limit (using the **access-list deny-flow-max** command). This message might be generated as a result of a DoS attack.

- *number*—The limit configured using the **access-list deny-flow-max** command

Recommended Action None required.

106102

Error Message `%ASA-6-106102: access-list acl_ID {permitted|denied} protocol for user username interface_name/source_address source_port interface_name/dest_address dest_port hit-cnt number {first hit|number-second interval} hash codes`

Explanation A packet was either permitted or denied by an access-list that was applied through a VPN filter. This message is the VPN/AAA filter equivalent of message 106100.

Recommended Action None required.

106103

Error Message `%ASA-4-106103: access-list acl_ID denied protocol for user username interface_name/source_address source_port interface_name/dest_address dest_port hit-cnt number first hit hash codes`

Explanation A packet was denied by an access-list that was applied through a VPN filter. This message is the VPN/AAA filter equivalent of message106023.

Recommended Action None required.

107001

Error Message `%ASA-1-107001: RIP auth failed from IP_address: version=number, type=string, mode=string, sequence=number on interface interface_name`

Explanation The ASA received a RIP reply message with bad authentication. This message might be caused by a misconfiguration on the router or the ASA or by an unsuccessful attempt to attack the routing table of the ASA.

Recommended Action This message indicates a possible attack and should be monitored. If you are not familiar with the source IP address listed in this message, change your RIP authentication keys between trusted entities. An attacker might be trying to determine the existing keys.

107002

Error Message `%ASA-1-107002: RIP pkt failed from IP_address: version=number on interface interface_name`

Explanation A router bug, a packet with non-RFC values inside, or a malformed entry may have caused this message to appear. This should not happen, and may be an attempt to exploit the routing table of the ASA.

Recommended Action This message indicates a possible attack and should be monitored. The packet has passed authentication, if enabled, and bad data is in the packet. Monitor the situation and change the keys if there are any doubts about the originator of the packet.

108002

Error Message `%ASA-2-108002: SMTP replaced string: out source_address in inside_address data: string`

Explanation A Mail Guard (SMTP) message has been generated by the **inspect esmtp** command. The ASA has replaced an invalid character in an e-mail address with a space.

Recommended Action None required.

108003

Error Message `%ASA-2-108003: Terminating ESMTP/SMTP connection; malicious pattern detected in the mail address from source_interface:source_address/source_port to dest_interface:dest_address/dset_port. Data:string`

Explanation The ASA has detected a malicious pattern in an e-mail address and drops the connection. An attack is in progress.

Recommended Action None required.

108004

Error Message `%ASA-4-108004: action_class: action ESMTP req_resp from src_ifc:sip|sport to dest_ifc:dip|dport;further_info`

Explanation An ESMTP classification is performed on an ESMTP message, and the specified criteria are satisfied. The configured action is taken.

- *action_class*—The class of action: ESMTP Classification for ESMTP match commands; ESMTP Parameter for parameter commands
- *action*—Action taken: Dropped, Dropped connection for, Reset connection for, or Masked header flags for
- *req_resp*—Request or Response
- *src_ifc*—Source interface name
- *sip|sport*—Source IP address or source port
- *dest_ifc*—Destination interface name
- *dip|dport*—Destination IP address or destination port
- *further info*—One of the following:

  For a single match command: matched Class *id*: *match_command* (for example, matched Class 1234: match body length 100).

  For parameter commands: *parameter-command*: *descriptive-message* (for example, mail-relay: No Mail Relay allowed)

Recommended Action None required.

108005

Error Message `%ASA-6-108005: action_class: Received ESMTP req_resp from src_ifc:sip|sport to dest_ifc:dip|dport;further_info`

Explanation An ESMTP classification is performed on an ESMTP message, and the specified criteria are satisfied. The standalone log action is taken.

- *action_class*—The class of action: ESMTP Classification for ESMTP match commands; ESMTP Parameter for parameter commands
- *req_resp*—Request or Response
- *src_ifc*—Source interface name
- *sip|sport*—Source IP address or source port
- *dest_ifc*—Destination interface name
- *dip|dport*—Destination IP address or destination port
- *further info*—One of the following:

  For a single match command: matched Class *id*: *match_command* (for example, matched Class 1234: match body length 100)

  For parameter commands (commands under the parameter section): *parameter-command*: *descriptive-message* (for example, mail-relay: No Mail Relay allowed)

Recommended Action None required.

108006

Error Message `%ASA-7-108006: Detected ESMTP size violation from src_ifc:sip|sport to dest_ifc:dip|dport;declared size is: decl_size, actual size is act_size.`

Explanation This event is generated when an ESMTP message size exceeds the size declared in the RCPT command.

- *src_ifc*—Source interface name
- *sip|sport*—Source IP address or source port
- *dest_ifc*—Destination interface name
- *dip|dport*—Destination IP address or destination port
- *decl_size*—Declared size
- *act_size*—Actual size

Recommended Action None required.

108007

Error Message `%ASA-6-108007: TLS started on ESMTP session between client client-side interface-name: client IP address/client port and server server-side interface-name: server IP address/server port`

Explanation On an ESMTP connection, the server has responded with a 220 reply code to the client STARTTLS command. The ESMTP inspection engine no longer inspects the traffic on this connection.

- *client-side interface-name*—The name for the interface that faces the client side
- *client IP address*—The IP address of the client
- *client port*—The TCP port number for the client
- *server-side interface-name*—The name for the interface that faces the server side
- *server IP address*—The IP address of the server
- *server port*—The TCP port number for the server

Recommended Action Log and review the message. Check whether the ESMTP policy map associated with this connection has the allow-tls action log setting. If not, contact the Cisco TAC.

109001

Error Message `%ASA-6-109001: Auth start for user user from inside_address/inside_port to outside_address/outside_port`

Explanation The ASA is configured for AAA and detects an authentication request by the specified user.

Recommended Action None required.

109002

Error Message `%ASA-6-109002: Auth from inside_address/inside_port to outside_address/outside_port failed (server IP_address failed) on interface interface_name.`

Explanation An authentication request failed because the specified authentication server cannot be contacted by the module.

Recommended Action Check that the authentication daemon is running on the specified authentication server.

109003

Error Message %ASA-6-109003: Auth from *inside_address* to *outside_address*/*outside_port* failed (all servers failed) on interface *interface_name*, so marking all servers ACTIVE again.

Explanation No authentication server can be found.

Recommended Action Ping the authentication servers from the ASA. Make sure that the daemons are running.

109005

Error Message %ASA-6-109005: Authentication succeeded for user *user* from *inside_address*/*inside_port* to *outside_address*/*outside_port* on interface *interface_name*.

Explanation The specified authentication request succeeded.

Recommended Action None required.

109006

Error Message %ASA-6-109006: Authentication failed for user *user* from *inside_address*/*inside_port* to *outside_address*/*outside_port* on interface *interface_name*.

Explanation The specified authentication request failed, possibly because of an incorrect password.

Recommended Action None required.

109007

Error Message %ASA-6-109007: Authorization permitted for user *user* from *inside_address*/*inside_port* to *outside_address*/*outside_port* on interface *interface_name*.

Explanation The specified authorization request succeeded.

Recommended Action None required.

109008

Error Message `%ASA-6-109008: Authorization denied for user` *`user`* `from` *`outside_address`*`/`*`outside_port`* `to` *`inside_address`*`/` *`inside_port`* `on interface` *`interface_name`*`.`

Explanation A user is not authorized to access the specified address, possibly because of an incorrect password.

Recommended Action None required.

109010

Error Message `%ASA-3-109010: Auth from` *`inside_address`*`/`*`inside_port`* `to` *`outside_address`*`/`*`outside_port`* `failed (too many pending auths) on interface` *`interface_name`*`.`

Explanation An authentication request cannot be processed because the server has too many requests pending.

Recommended Action Check to see if the authentication server is too slow to respond to authentication requests. Enable the Flood Defender feature with the **floodguard enable** command.

109011

Error Message `%ASA-2-109011: Authen Session Start: user '`*`user`*`', sid` *`number`*

Explanation An authentication session started between the host and the ASA and has not yet completed.

Recommended Action None required.

109012

Error Message `%ASA-5-109012: Authen Session End: user '`*`user`*`', sid` *`number`*`, elapsed` *`number`* `seconds`

Explanation The authentication cache has timed out. Users must reauthenticate on their next connection. You can change the duration of this timer with the **timeout uauth** command.

Recommended Action None required.

109013

Error Message `%ASA-3-109013: User must authenticate before using this service`

Explanation The user must be authenticated before using the service.

Recommended Action Authenticate using FTP, Telnet, or HTTP before using the service.

109014

Error Message `%ASA-7-109014: A non-Telnet connection was denied to the configured virtual Telnet IP address.`

Explanation A request to authenticate did not have a corresponding request for authorization.

Recommended Action Ensure that both the **aaa authentication** and **aaa authorization** command statements are included in the configuration.

109016

Error Message `%ASA-3-109016: Can't find authorization ACL` *`acl_ID`* `for user '`*`user`*`'`

Explanation The specified on the AAA server for this user does not exist on the ASA. This error can occur if you configure the AAA server before you configure the ASA. The Vendor-Specific Attribute (VSA) on your AAA server might be one of the following values:

- acl=acl_ID
- shell:acl=acl_ID
- ACS:CiscoSecured-Defined-ACL=acl_ID

Recommended Action Add the ACL to the ASA, making sure to use the same name specified on the AAA server.

109017

Error Message `%ASA-4-109017: User at` *`IP_address`* `exceeded auth proxy connection limit (max)`

Explanation A user has exceeded the user authentication proxy limit, and has opened too many connections to the proxy.

Recommended Action Increase the proxy limit by entering the **proxy-limit** *proxy_limit* command, or ask the user to close unused connections. If the error persists, it may indicate a possible DoS attack.

109018

Error Message `%ASA-3-109018: Downloaded ACL acl_ID is empty`

Explanation The downloaded authorization has no ACEs. This situation might be caused by misspelling the attribute string *ip:inacl#* or omitting the **access-list** command.

```
junk:junk# 1=permit tcp any any eq junk ip:inacl#1="
```

Recommended Action Correct the ACL components that have the indicated error on the AAA server.

109019

Error Message `%ASA-3-109019: Downloaded ACL acl_ID has parsing error; ACE string`

Explanation An error occurred during parsing the sequence number NNN in the attribute string ip:inacl#NNN= of a downloaded authorization. The reasons include: - missing = - contains nonnumeric, nonpace characters between # and = - NNN is greater than 999999999.

```
ip:inacl# 1 permit tcp any any
ip:inacl# 1junk2=permit tcp any any
ip:inacl# 1000000000=permit tcp any any
```

Recommended Action Correct the ACL element that has the indicated error on the AAA server.

109020

Error Message `%ASA-3-109020: Downloaded ACL has config error; ACE`

Explanation One of the components of the downloaded authorization has a configuration error. The entire text of the element is included in the message. This message is usually caused by an invalid **access-list** command statement.

Recommended Action Correct the ACL component that has the indicated error on the AAA server.

109021

Error Message `%ASA-7-109021: Uauth null proxy error`

Explanation An internal user authentication error has occurred.

Recommended Action None required. However, if this error appears repeatedly, contact the Cisco TAC.

109022

Error Message `%ASA-4-109022: exceeded HTTPS proxy process limit`

Explanation For each HTTPS authentication, the ASA dedicates a process to service the authentication request. When the number of concurrently running processes exceeds the system-imposed limit, the ASA does not perform the authentication, and this message appears.

Recommended Action None required.

109023

Error Message `%ASA-3-109023: User from source_address/source_port to dest_address/dest_port on interface outside_interface must authenticate before using this service.`

Explanation Based on the configured policies, you need to be authenticated before you can use this service port.

Recommended Action Authenticate using Telnet, FTP, or HTTP before attempting to use this service port.

109024

Error Message `%ASA-6-109024: Authorization denied from source_address/source_port to dest_address/dest_port (not authenticated) on interface interface_name using protocol`

Explanation The ASA is configured for AAA and a user attempted to make a TCP connection across the ASA without prior authentication.

Recommended Action None required.

109025

Error Message `%ASA-6-109025: Authorization denied (acl=acl_ID) for user 'user' from source_address/source_port to dest_address/dest_port on interface interface_name using protocol`

Explanation The check failed. The check either matched a deny or did not match anything, such as an implicit deny. The connection was denied by the user acl_ID, which was defined according to the AAA authorization policy on the Cisco Secure Access Control Server (ACS).

Recommended Action None required.

109026

Error Message `%ASA-3-109026: [aaa protocol] Invalid reply digest received; shared server key may be mismatched.`

Explanation The response from the AAA server cannot be validated. The configured server key is probably incorrect. This message may be generated during transactions with RADIUS or TACACS+ servers.

Recommended Action Verify that the server key, configured using the **aaa-server** command, is correct.

109027

Error Message `%ASA-4-109027: [aaa protocol] Unable to decipher response message Server = server_IP_address, User = user`

Explanation The response from the AAA server cannot be validated. The configured server key is probably incorrect. This message may be displayed during transactions with RADIUS or TACACS+ servers. The server_IP_address is the IP address of the relevant AAA server. The user is the user name associated with the connection.

Recommended Action Verify that the server key, configured using the **aaa-server** command, is correct.

109028

Error Message `%ASA-4-109028: aaa bypassed for same-security traffic from ingress_interface:source_address/source_port to egress_interface:dest_address/dest_port`

Explanation AAA is being bypassed for same security traffic that matches a configured AAA rule. This can only occur when traffic passes between two interfaces that have the same configured security level, when the same security traffic is permitted, and if the AAA configuration uses the include or exclude syntax.

Recommended Action None required.

109029

Error Message `%ASA-5-109029: Parsing downloaded ACL: string`

Explanation A syntax error occurred while parsing an access list that was downloaded from a RADIUS server during user authentication.

- *string*—An error message detailing the syntax error that prevented the access list from parsing correctly

Recommended Action Use the information presented in this message to identify and correct the syntax error in the access list definition within the RADIUS server configuration.

109030

Error Message `%ASA-4-109030: Autodetect ACL convert wildcard did not convert ACL access_list source|dest netmask netmask.`

Explanation A dynamic ACL that is configured on a RADIUS server is not converted by the mechanism for automatically detecting wildcard netmasks. The problem occurs because this mechanism cannot determine if the netmask is a wildcard or a normal netmask.

- *access_list*—The access list that cannot be converted
- *source*—The source IP address
- *dest*—The destination IP address
- *netmask*—The subnet mask for the destination or source address in dotted-decimal notation

Recommended Action Check the access list netmask on the RADIUS server for the wildcard configuration. If the netmask is supposed to be a wildcard, and if all access list netmasks on that server are wildcards, then use the wildcard setting for **acl-netmask-convert** for the AAA server. Otherwise, change the netmask to a normal netmask or to a wildcard netmask that does not contain holes (that is, where the netmask presents consecutive binary 1s. For example, 00000000.00000000.00011111.11111111 or hex 0.0.31.255). If the mask is supposed to be normal and all access list netmasks on that server are normal, then use the normal setting for **acl-netmask-convert** for the AAA server.

109031

Error Message `%ASA-4-109031: NT Domain Authentication Failed: rejecting guest login for username.`

Explanation A user has tried to authenticate to an NT domain that was configured for guest account access and the username is not a valid username on the NT server. The connection is denied.

Recommended Action If the user is a valid user, add an account to the NT server. If the user is not allowed access, no action is required.

109032

Error Message `%ASA-3-109032: Unable to install ACL access_list, downloaded for user username; Error in ACE: ace.`

Explanation The ASA received an access control list from a RADIUS server to apply to a user connection, but an entry in the list contains a syntax error. Th euse of a list containing an error could result in the violation of a security policy, so the ASA failed to authenticate the user.

- *access_list*—The name assigned to the dynamic access list as it would appear in the output of the **show access-list** command
- *username*—The name of the user whose connection will be subject to this access list
- *ace*—The access list entry that was being processed when the error was detected

Recommended Action Correct the access list definition in the RADIUS server configuration.

109033

Error Message `%ASA-4-109033: Authentication failed for admin user user from src_IP. Interactive challenge processing is not supported for protocol connections`

Explanation AAA challenge processing was triggered during authentication of an administrative connection, but the ASA cannot initiate interactive challenge processing with the client application. When this occurs, the authentication attempt will be rejected and the connection denied.

- *user*—The name of the user being authenticated
- *src_IP*—The IP address of the client host
- *protocol*—The client connection protocol (SSH v1 or administrative HTTP)

Recommended Action Reconfigure AAA so that challenge processing does not occur for these connection types. This generally means to avoid authenticating these connection types to RSA SecurID servers or to any token-based AAA server via RADIUS.

109034

Error Message `%ASA-4-109034: Authentication failed for network user user from src_IP/port to dst_IP/port. Interactive challenge processing is not supported for protocol connections`

Explanation AAA challenge processing was triggered during authentication of a network connection, but the ASA cannot initiate interactive challenge processing with the client application. When this occurs, the authentication attempt will be rejected and the connection denied.

- *user*—The name of the user being authenticated
- *src_IP/port*—The IP address and port of the client host
- *dst_IP/port*—The IP address and port of the server to which the client is attempting to connect

- *protocol*—The client connection protocol (for example, FTP)

Recommended Action Reconfigure AAA so that challenge processing does not occur for these connection types. This generally means to avoid authenticating these connection types to RSA SecurID servers or to any token-based AAA server via RADIUS.

109036

Error Message `%ASA-6-109036: Exceeded 1000 attribute values for the attribute name attribute for user username.`

Explanation The LDAP response message contains an attribute that has more than 1000 values.

- *attribute_name*—The LDAP attribute name
- *username*—The username at login

Recommended Action None required.

109037

Error Message `%ASA-3-109037: Exceeded 5000 attribute values for the attribute name attribute for user username.`

Explanation The ASA supports multiple values of the same attribute received from a AAA server. If the AAA server sends a response containing more than 5000 values for the same attribute, then the ASA treats this response message as being malformed and rejects the authentication. This condition has only been seen in lab environments using specialized test tools. It is unlikely that the condition would occur in a real-world production network.

- *attribute_name*—The LDAP attribute name
- *username*—The username at login

Recommended Action Capture the authentication traffic between the ASA and AAA server using a protocol sniffer (such as WireShark), then forward the trace file to the Cisco TAC for analysis.

109038

Error Message `%ASA-3-109038: Attribute internal-attribute-name value string-from-server from AAA server could not be parsed as a type internal-attribute-name string representation of the attribute name`

Explanation The AAA subsystem tried to parse an attribute from the AAA server into an internal representation and failed.

- *string-from-server*—String received from the AAA server, truncated to 40 characters.

- *type*—The type of the specified attribute

Recommended Action Verify that the attribute is being generated correctly on the AAA server. For additional information, use the **debug ldap** and **debug radius** commands.

109039

Error Message `%ASA-5-109039: AAA Authentication:Dropping an unsupported IPv6/IP46/IP64 packet from lifc:laddr to fifc:faddr`

Explanation A packet containing IPv6 addresses or IPv4 addresses translated to IPv6 addresses by NAT requires AAA authentication or authorization. AAA authentication and authorization do not support IPv6 addresses. The packet is dropped.

- *lifc*—The ingress interface
- *laddr*—The source IP address
- *fifc*—The egress interface
- *faddr*—The destination IP address after NAT translation, if any

Recommended Action None required.

109100

Error Message `%ASA-6-109100: Received CoA update from coa-source-ip for user username, with session ID: audit-session-id, changing authorization attributes`

Explanation The ASA has successfully processed the CoA policy update request from *coa-source-ip* for user *username* with session id *audit-session-id*. This syslog message is generated after a change of authorization policy update has been received by the ASA, validated and applied. In a non-error case, this is the only syslog message that is generated when a change of authorization is received and processed.

- *coa-source-ip*—Originating IP address of the change of authorization request
- *username*—User whose session is being changed
- *audit-session-id*—The global ID of the session being modified

Recommended Action None required.

109101

Error Message `%ASA-6-109101: Received CoA disconnect request from coa-source-ip for user username, with audit-session-id: audit-session-id`

Explanation The ASA has received a correctly formatted Disconnect-Request for an active VPN session and has successfully terminated the connection.

- *coa-source-ip*—Originating IP address of the change of authorization request

- *username*—User whose session is being changed
- *audit-session-id*—The global ID of the session being modified

Recommended Action None required.

109102

Error Message `%ASA-4-109102: Received CoA action-type from coa-source-ip, but cannot find named session audit-session-id`

Explanation The ASA has received a valid change of authorization request, but the session ID specified in the request does not match any active sessions on the ASA. This could be the result of the change of authorization server attempting to issue a change of authorization on a session that has already been closed by the user.

- *action-type*—The requested change of authorization action (update or disconnect)
- *coa-source-ip*—Originating IP address of the change of authorization request
- *audit-session-id*—The global ID of the session being modified

Recommended Action None required.

109103

Error Message `%ASA-3-109103: CoA action-type from coa-source-ip failed for user username, with session ID: audit-session-id.`

Explanation The ASA has received a correctly formatted change of authorization request, but was unable to process it successfully.

- *action-type*—The requested change of authorization action (update or disconnect)
- *coa-source-ip*—Originating IP address of the change of authorization request
- *username*—User whose session is being changed
- *audit-session-id*—The global ID of the session being modified

Recommended Action Investigate the relevant VPN subsystem logs to determine why the updated attributes could not be applied or why the session could not be terminated.

109104

Error Message `%ASA-3-109104: CoA action-type from coa-source-ip failed for user username, session ID: audit-session-id. Action not supported.`

Explanation The ASA has received a correctly formatted change of authorization request, but did not process it because the indicated action is not supported by the ASA.

- *action-type*—The requested change of authorization action (update or disconnect)

- *coa-source-ip*—Originating IP address of the change of authorization request
- *username*—User whose session is being changed
- *audit-session-id*—The global ID of the session being modified

Recommended Action None required.

110002

Error Message `%ASA-6-110002: Failed to locate egress interface for` *`protocol`* `from` *`src interface`*`:`*`src IP/src port`* `to` *`dest IP/dest port`*

Explanation .An error occurred when the ASA tried to find the interface through which to send the packet.

- *protocol*—The protocol of the packet
- *src interface*—The interface from which the packet was received
- *src IP*—The source IP address of the packet
- *src port*—The source port number
- *dest IP*—The destination IP address of the packet
- *dest port*—The destination port number

Recommended Action Copy the error message, the configuration, and any details about the events leading up to the error, and contact Cisco TAC.

110003

Error Message `%ASA-6-110003: Routing failed to locate next-hop for protocol from` *`src interface`*`:`*`src IP/src port`* `to` *`dest interface`*`:`*`dest IP/dest port`*

Explanation .An error occurred when the ASA tried to find the next hop on an interface routing table.

- *protocol*—The protocol of the packet
- *src interface*—The interface from which the packet was received
- *src IP*—The source IP address of the packet
- *src port*—The source port number
- *dest IP*—The destination IP address of the packet
- *dest port*—The destination port number

Recommended Action Copy the error message, the configuration, and any details about the events leading up to the error, and contact Cisco TAC. During debugging, use the **show asp table routing** command to view the routing table details.

111001

Error Message `%ASA-5-111001: Begin configuration: IP_address writing to device`

Explanation You have entered the **write** command to store your configuration on a *device* (either floppy, flash memory, TFTP, the failover standby unit, or the console terminal). The *IP_address* indicates whether the login was made at the console port or with a Telnet connection.

Recommended Action None required.

111002

Error Message `%ASA-5-111002: Begin configuration: IP_address reading from device`

Explanation You have entered the **read** command to read your configuration from a *device* (either floppy disk, flash memory, TFTP, the failover standby unit, or the console terminal). The *IP_address* indicates whether the login was made at the console port or with a Telnet connection.

Recommended Action None required.

111003

Error Message `%ASA-5-111003: IP_address Erase configuration`

Explanation You have erased the contents of flash memory by entering the **write erase** command at the console. The *IP_address* value indicates whether the login was made at the console port or through a Telnet connection.

Recommended Action After erasing the configuration, reconfigure the ASA and save the new configuration. Alternatively, you can restore information from a configuration that was previously saved, either on a floppy disk or on a TFTP server elsewhere on the network.

111004

Error Message `%ASA-5-111004: IP_address end configuration: {FAILED|OK}`

Explanation You have entered the **config floppy/memory/ network** command or the **write floppy/memory/network/standby** command. The *IP_address* value indicates whether the login was made at the console port or through a Telnet connection.

Recommended Action None required if the message ends with OK. If the message indicates a failure, try to fix the problem. For example, if writing to a floppy disk, ensure that the floppy disk is not write protected; if writing to a TFTP server, ensure that the server is up.

111005

Error Message `%ASA-5-111005: IP_address end configuration: OK`

Explanation You have exited the configuration mode. The *IP_address* value indicates whether the login was made at the console port or through a Telnet connection.

Recommended Action None required.

111007

Error Message `%ASA-5-111007: Begin configuration: IP_address reading from device.`

Explanation You have entered the **reload** or **configure** command to read in a configuration. The *device* text can be floppy, memory, net, standby, or terminal. The *IP_address* value indicates whether the login was made at the console port or through a Telnet connection.

Recommended Action None required.

111008

Error Message `%ASA-5-111008: User user executed the command string`

Explanation The user entered any command, with the exception of a **show** command.

Recommended Action None required.

111009

Error Message `%ASA-7-111009:User user executed cmd:string`

Explanation The user entered a command that does not modify the configuration. This message appears only for **show** commands.

Recommended Action None required.

111010

Error Message `%ASA-5-111010: User username, running application-name from IP ip addr, executed cmd`

Explanation A user made a configuration change.

- *username*—The user making the configuration change

- *application-name*—The application that the user is running
- *ip addr*—The IP address of the management station
- *cmd*—The command that the user has executed

Recommended Action None required.

111111

Error Message `%ASA-1-111111 error_message`

Explanation A system or infrastructure error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

112001

Error Message `%ASA-2-112001: (string:dec) Clear complete.`

Explanation A request to clear the module configuration was completed. The source file and line number are identified.

Recommended Action None required.

113001

Error Message `%ASA-3-113001: Unable to open AAA session. Session limit [limit] reached.`

Explanation The AAA operation on an IPsec tunnel or WebVPN connection cannot be performed because of the unavailability of AAA resources. The *limit* value indicates the maximum number of concurrent AAA transactions.

Recommended Action Reduce the demand for AAA resources, if possible.

113003

Error Message `%ASA-6-113003: AAA group policy for user user is being set to policy_name.`

Explanation The group policy that is associated with the tunnel group is being overridden with a user-specific policy, *policy_name*. The *policy_name* is specified using the **username** command when LOCAL authentication is configured or is returned in the RADIUS CLASS attribute when RADIUS authentication is configured.

Recommended Action None required.

113004

Error Message `%ASA-6-113004: AAA user aaa_type Successful: server = server_IP_address, User = user`

Explanation The AAA operation on an IPsec or WebVPN connection has been completed successfully. The AAA types are authentication, authorization, or accounting. The *server_IP_address* is the IP address of the relevant AAA server. The *user* is the user name associated with the connection.

Recommended Action None required.

113005

Error Message `%ASA-6-113005: AAA user authentication Rejected: reason = string: server = server_IP_address, User = user: user IP = user_ip`

Explanation An authentication or authorization request for a user associated with an IPsec or WebVPN connection has been rejected. Details of why the request was rejected are provided in the *string* field. The *server_IP_address* field is the IP address of the relevant AAA server. The *user* field is the username associated with the connection. The *user_ip* field is the IP address of the user who initiated the authentication or authorization request.

Recommended Action None required.

113006

Error Message `%ASA-6-113006: User user locked out on exceeding number successive failed authentication attempts`

Explanation A locally configured user is being locked out. This happens when a configured number of consecutive authentication failures have occurred for this user and indicates that all future authentication attempts by this user will be rejected until an administrator unlocks the user using the

clear aaa local user lockout command. The *user* is the user that is now locked, and the *number* is the consecutive failure threshold configured using the **aaa local authentication attempts max-fail** command.

Recommended Action Try unlocking the user using the **clear_aaa_local_user_lockout** command or adjusting the maximum number of consecutive authentication failures that are tolerated.

113007

Error Message `%ASA-6-113007: User user unlocked by administrator`

Explanation A locally configured user that was locked out after exceeding the maximum number of consecutive authentication failures set by using the **aaa local authentication attempts max-fail** command has been unlocked by the indicated administrator.

Recommended Action None required.

113008

Error Message `%ASA-6-113008: AAA transaction status ACCEPT: user = user`

Explanation The AAA transaction for a user associated with an IPsec or WebVPN connection was completed successfully. The user is the username associated with the connection.

Recommended Action None required.

113009

Error Message `%ASA-6-113009: AAA retrieved default group policy policy for user user`

Explanation The authentication or authorization of an IPsec or WebVPN connection has occurred. The attributes of the group policy that were specified with the **tunnel-group** or **webvpn** commands have been retrieved.

Recommended Action None required.

113010

Error Message `%ASA-6-113010: AAA challenge received for user user from server server_IP_address`

Explanation The authentication of an IPsec connection has occurred with a SecurID server. The user will be prompted to provide further information before being authenticated.

- *user*—The username associated with the connection

- *server _IP_address*—The IP address of the relevant AAA server

Recommended Action None required.

113011

Error Message `%ASA-6-113011: AAA retrieved user specific group policy` *`policy`* `for user` *`user`*

Explanation The authentication or authorization of an IPsec or WebVPN connection has occurred. The attributes of the group policy that was specified with the **tunnel-group** or **webvpn** commands have been retrieved.

Recommended Action None required.

113012

Error Message `%ASA-6-113012: AAA user authentication Successful: local database: user = user`

Explanation The user associated with a IPsec or WebVPN connection has been successfully authenticated to the local user database.

- *user*—The username associated with the connection

Recommended Action None required.

113013

Error Message `%ASA-6-113013: AAA unable to complete the request Error: reason = reason: user = user`

Explanation The AAA transaction for a user associated with an IPsec or WebVPN connection has failed because of an error or has been rejected because of a policy violation.

- *reason*—The reason details
- *user*—The username associated with the connection

Recommended Action None required.

113014

Error Message `%ASA-6-113014: AAA authentication server not accessible: server = server_IP_address: user = user`

Explanation The device was unable to communicate with the configured AAA server during the AAA transaction associated with an IPsec or WebVPN connection. This may or may not result in a failure of the user connection attempt depending on the backup servers configured in the *aaa-server* group and the availability of those servers.

Recommended Action Verify connectivity with the configured AAA servers.

113015

Error Message `%ASA-6-113015: AAA user authentication Rejected: reason = reason: local database: user = user: user IP = user_ip`

Explanation A request for authentication to the local user database for a user associated with an IPsec or WebVPN connection has been rejected.

- *reason*—The details of why the request was rejected
- *user*—The username associated with the connection
- *user_ip* —The IP address of the user who initiated the authentication or authorization request

Recommended Action None required.

113016

Error Message `%ASA-6-113016: AAA credentials rejected: reason = reason: server = server_IP_address: user = user: user IP = user_ip`

Explanation The AAA transaction for a user associated with an IPsec or WebVPN connection has failed because of an error or rejected due to a policy violation.

- *reason*—The details of why the request was rejected
- *server_IP_address*—The IP address of the relevant AAA server
- *user*—The username associated with the connection
- *user_ip* —The IP address of the user who initiated the authentication or authorization request

Recommended Action None required.

113017

Error Message `%ASA-6-113017: AAA credentials rejected: reason = reason: local database: user = user: user IP = user_ip`

Explanation The AAA transaction for a user associated with an IPsec or WebVPN connection has failed because of an error or rejected because of a policy violation. This event only appears when the AAA transaction is with the local user database rather than with an external AAA server.

- *reason*—The details of why the request was rejected
- *user*—The username associated with the connection
- *user_ip* —The IP address of the user who initiated the authentication or authorization request

Recommended Action None required.

113018

Error Message `%ASA-3-113018: User: user, Unsupported downloaded ACL Entry: ACL_entry, Action: action`

Explanation An ACL entry in unsupported format was downloaded from the authentication server. The following list describes the message values:

- *user*—User trying to log in
- *ACL_entry*—Unsupported ACL entry downloaded from the authentication server
- *action*—Action taken when encountering the unsupported ACL entry

Recommended Action The ACL entry on the authentication server has to be changed by the administrator to conform to the supported ACL entry formats.

113019

Error Message `%ASA-4-113019: Group = group, Username = username, IP = peer_address, Session disconnected. Session Type: type, Duration: duration, Bytes xmt: count, Bytes rcv: count, Reason: reason`

Explanation An indication of when and why the longest idle user is disconnected.

- *group*—Group name
- *username*—Username
- *IP*—Peer address
- *Session Type*—Session type (for example, IPsec or UDP)
- *duration*—Connection duration in hours, minutes, and seconds
- *Bytes xmt*—Number of bytes transmitted
- *Bytes rcv*—Number of bytes received

- *reason*—Reason for disconnection:

  User Requested

  Lost Carrier

  Lost Service

  Idle Timeout

  Max time exceeded

  Administrator Reset

  Administrator Reboot

  Administrator Shutdown

  Port Error

  NAS Error

  NAS Request

  NAS Reboot

  Port unneeded

  Connection preempted. Indicates that the allowed number of simultaneous (same user) logins has been exceeded. To resolve this problem, increase the number of simultaneous logins or have users only log in once with a given username and password.

  Port Suspended

  Service Unavailable

  Callback

  User error

  Host Requested

  SA Expired

  IKE Delete

  Bandwidth Management Error

  Certificate Expired

  Phase 2 Mismatch

  Firewall Mismatch

  Peer Address Changed

  ACL Parse Error

  Phase 2 Error

  Configuration Error

  Peer Reconnected

  Internal Error

  Crypto map policy not found

  L2TP initiated

  VLAN Mapping Error

  NAC-Policy Error

Dynamic Access Policy terminate

Client type not supported

Unknown

Recommended Action Unless the reason indicates a problem, then no action is required.

113020

Error Message `%ASA-3-113020: Kerberos error: Clock skew with server ip_address greater than 300 seconds`

Explanation Authentication for an IPsec or WebVPN user through a Kerberos server has failed because the clocks on the ASA and the server are more than five minutes (300 seconds) apart. When this occurs, the connection attempt is rejected.

- *ip_address*—The IP address of the Kerberos server

Recommended Action Synchronize the clocks on the ASA and the Kerberos server.

113021

Error Message `%ASA-3-113021: Attempted console login failed. User username did NOT have appropriate Admin Rights.`

Explanation A user has tried to access the management console and was denied.

- *username*—The username entered by the user

Recommended Action If the user is a newly added admin rights user, check that the service type (LOCAL or RADIUS authentication server) for that user is set to allow access:

- nas-prompt—Allows login to the console and exec privileges at the required level, but not enable (configuration modification) access
- admin—Allows all access and can be further constrained by command privileges

Otherwise, the user is inappropriately trying to access the management console; the action to be taken should be consistent with company policy for these matters.

113022

Error Message `%ASA-2-113022: AAA Marking RADIUS server servername in aaa-server group AAA-Using-DNS as FAILED`

Explanation The ASA has tried an authentication, authorization, or accounting request to the AAA server and did not receive a response within the configured timeout window. The AAA server will be marked as failed and has been removed from service.

- *protocol*—The type of authentication protocol, which can be one of the following:

- RADIUS
- TACACS+
- NT
- RSA SecurID
- Kerberos
- LDAP

- *ip-addr*—The IP address of the AAA server
- *tag*—The server group name

Recommended Action Verify that the AAA server is online and is accessible from the ASA.

113023

Error Message `%ASA-2-113023: AAA Marking protocol server ip-addr in server group tag as ACTIVE`

Explanation The ASA has reactivated the AAA server that was previously marked as failed. The AAA server is now available to service AAA requests.

- *protocol*—The type of authentication protocol, which can be one of the following:
  - RADIUS
  - TACACS+
  - NT
  - RSA SecurID
  - Kerberos
  - LDAP
- *ip-addr*—The IP address of the AAA server
- *tag*—The server group name

Recommended Action None required.

113024

Error Message `%ASA-5-113024: Group tg: Authenticating type connection from ip with username, user_name, from client certificate`

Explanation The prefill username feature overrides the username with one derived from the client certificate for use in AAA.

- *tg*—The tunnel group
- *type*—The type of connection (ssl-client or clientless)
- *ip*—The IP address of the connecting user

- *user_name*—The name extracted from the client certificate for use in AAA

Recommended Action None required.

113025

Error Message `%ASA-5-113025: Group tg: fields Could not authenticate connection type connection from ip`

Explanation A username cannot be successfully extracted from the certificate.

- *tg*—The tunnel group
- *fields*—The DN fields being searched for
- *connection type*—The type of connection (SSL client or clientless)
- *ip*—The IP address of the connecting user

Recommended Action The administrator should check that the **authentication aaa certificate**, **ssl certificate-authentication**, and **authorization-dn-attributes** keywords have been set correctly.

113026

Error Message `%ASA-4-113026: Error error while executing Lua script for group tunnel group`

Explanation An error occurred while extracting a username from the client certificate for use in AAA. This message is only generated when the username-from-certificate use-script option is enabled.

- *error*—Error string returned from the Lua environment
- *tunnel group*—The tunnel group attempting to extract a username from a certificate

Recommended Action Examine the script being used by the username-from-certificate use-script option for errors.

113027

Error Message `%ASA-2-113027: Error activating tunnel-group scripts`

Explanation The script file cannot be loaded successfully. No tunnel groups using the username-from-certificate use-script option work correctly.

Recommended Action The administrator should check the script file for errors using ASDM. Use the **debug aaa** command to obtain a more detailed error message that may be useful.

113028

Error Message `%ASA-7-113028: Extraction of username from VPN client certificate has string. [Request num]`

Explanation The processing request of a username from a certificate is running or has finished.

- *num*—The ID of the request (the value of the pointer to the fiber), which is a monotonically increasing number.
- *string*—The status message, which can one of the following:

  - been requested

  - started

  - finished with error

  - finished successfully

  - completed

Recommended Action None required.

113029

Error Message `%ASA-4-113029: Group group User user IP ipaddr Session could not be established: session limit of num reached`

Explanation The user session cannot be established because the current number of sessions exceeds the maximum session load.

Recommended Action Increase the configured limit, if possible, to create a load-balanced cluster.

113030

Error Message `%ASA-4-113030: Group group User user IP ipaddr User ACL acl from AAA doesn't exist on the device, terminating connection.`

Explanation The specified ACL was not found on the ASA.

- *group*—The name of the group
- *user*—The name of the user
- *ipaddr*—The IP address
- *acl*—The name of the ACL

Recommended Action Modify the configuration to add the specified ACL or to correct the ACL name.

113031

Error Message `%ASA-4-113031: Group group User user IP ipaddr AnyConnect vpn-filter filter is an IPv6 ACL; ACL not applied.`

Explanation The type of ACL to be applied is incorrect. An IPv6 ACL has been configured as an IPv4 ACL through the **vpn-filter** command.

- *group*—The group policy name of the user
- *user*—The username
- *ipaddr*—The public (not assigned) IP address of the user
- *filter*—The name of the VPN filter

Recommended Action Validate the VPN filter and IPv6 VPN filter configurations on the ASA, and the filter parameters on the AAA (RADIUS) server. Make sure that the correct type of ACL is specified.

113032

Error Message `%ASA-4-113032: Group group User user IP ipaddr AnyConnect ipv6-vpn-filter filter is an IPv4 ACL; ACL not applied.`

Explanation The type of ACL to be applied is incorrect. An IPv4 ACL has been configured as an IPv6 ACL through the **ipv6-vpn-filter** command.

- *group*—The group policy name of the user
- *user*—The username
- *ipaddr*—The public (not assigned) IP address of the user
- *filter*—The name of the VPN filter

Recommended Action Validate the VPN filter and IPv6 VPN filter configurations on the ASA and the filter parameters on the AAA (RADIUS) server. Make sure that the correct type of ACL is specified.

113033

Error Message `%ASA-6-113033: Group group User user IP ipaddr AnyConnect session not allowed. ACL parse error.`

Explanation The WebVPN session for the specified user in this group is not allowed because the associated ACL did not parse. The user will not be allowed to log in via WebVPN until this error has been corrected.

- *group*—The group policy name of the user
- *user*—The username

- *ipaddr*—The public (not assigned) IP address of the user

Recommended Action Correct the WebVPN ACL.

113034

Error Message `%ASA-4-113034: Group group User user IP ipaddr User ACL acl from AAA ignored, AV-PAIR ACL used instead.`

Explanation The specified ACL was not used because a Cisco AV-PAIR ACL was used.

- *group*—The name of the group
- *user*—The name of the user
- *ipaddr*—The IP address
- *acl*—The name of the ACL

Recommended Action Determine the correct ACL to use and correct the configuration.

113035

Error Message `%ASA-4-113035: Group group User user IP ipaddr Session terminated: AnyConnect not enabled or invalid AnyConnect image on the ASA.`

Explanation The user logged in via the AnyConnect client. The SVC service is not enabled globally, or the SVC image is invalid or corrupted. The session connection has been terminated.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *iaddrp*—The IP address of the user who is trying to connect

Recommended Action Enable the SVC globally using the **svc-enable** command. Validate the integrity and versions of the SVC images by reloading new images using the **svc image** command.

113036

Error Message `%ASA-4-113036: Group group User user IP ipaddr AAA parameter name value invalid.`

Explanation The given parameter has a bad value. The value is not shown because it might be very long.

- *group*—The name of the group
- *user*—The name of the user
- *ipadddr*—The IP address

- *name*—The name of the parameter

Recommended Action Modify the configuration to correct the indicated parameter.

113037

Error Message `%ASA-6-113037: Reboot pending, new sessions disabled. Denied user login.`

Explanation A user was unable to log in to WebVPN because the ASA is in the process of rebooting.

Recommended Action None required.

113038

Error Message `%ASA-4-113038: Group group User user IP ipaddr Unable to create AnyConnect parent session.`

Explanation The AnyConnect session was not created for the user in the specified group because of resource issues. For example, the user may have reached the maximum login limit.

- *group*—The name of the group
- *user*—The name of the user
- *ipadddr*—The IP address

Recommended Action None required.

113039

Error Message `%ASA-6-113039: Group group User user IP ipaddr AnyConnect parent session started.`

Explanation The AnyConnect session has started for the user in this group at the specified IP address. When the user logs in via the AnyConnect login page, the AnyConnect session starts.

- *group*—The name of the group
- *user*—The name of the user
- *ipadddr*—The IP address

Recommended Action None required.

113040

Error Message `%ASA-4-113040: Terminating the VPN connection attempt from attempted group. Reason: This connection is group locked to locked group.`

Explanation The tunnel group over which the connection is attempted is not the same as the tunnel group set in the group lock.

- *attempted group*—The tunnel group over which the connection came in
- *locked group*—The tunnel group that the connection is locked or restricted to

Recommended Action Check the group-lock value in the group policy or the user attributes.

114001

Error Message `%ASA-1-114001: Failed to initialize 4GE SSM I/O card (error error_string).`

Explanation The system failed to initialize a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114002

Error Message `%ASA-1-114002: Failed to initialize SFP in 4GE SSM I/O card (error error_string).`

Explanation The system failed to initialize an SFP connector in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114003

Error Message `%ASA-1-114003: Failed to run cached commands in 4GE SSM I/O card (error error_string).`

Explanation The system failed to run cached commands in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

- I2C_HOST_BUSY_ERROR
- I2C_UNPOPULATED_ERROR
- I2C_SMBUS_UNSUPPORT
- I2C_BYTE_COUNT_ERROR
- I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114004

Error Message `%ASA-6-114004: 4GE SSM I/O Initialization start.`

Explanation he user has been notified that a 4GE SSM I/O initialization is starting.

- *syslog_id*—Message identifier

Recommended Action None required.

114005

Error Message `%ASA-6-114005: 4GE SSM I/O Initialization end.`

Explanation The user has been notified that an 4GE SSM I/O initialization is finished.

- *syslog_id*—Message identifier

Recommended Action None required.

114006

Error Message `%ASA-3-114006: Failed to get port statistics in 4GE SSM I/O card (error` *`error_string`*`).`

Explanation The ASA failed to obtain port statistics in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

- I2C_BUS_TRANSACTION_ERROR
- I2C_CHKSUM_ERROR
- I2C_TIMEOUT_ERROR
- I2C_BUS_COLLISION_ERROR
- I2C_HOST_BUSY_ERROR
- I2C_UNPOPULATED_ERROR
- I2C_SMBUS_UNSUPPORT
- I2C_BYTE_COUNT_ERROR
- I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114007

Error Message `%ASA-3-114007: Failed to get current msr in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to obtain the current module status register information in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.

3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114008

Error Message `%ASA-3-114008: Failed to enable port after link is up in 4GE SSM I/O card due to either I2C serial bus access error or switch access error.`

Explanation The ASA failed to enable a port after the link transition to Up state is detected in a 4GE SSM I/O card because of either an I2C serial bus access error or a switch access error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114009

Error Message `%ASA-3-114009: Failed to set multicast address in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the multicast address in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

- I2C_BUS_TRANSACTION_ERROR
- I2C_CHKSUM_ERROR
- I2C_TIMEOUT_ERROR
- I2C_BUS_COLLISION_ERROR
- I2C_HOST_BUSY_ERROR
- I2C_UNPOPULATED_ERROR
- I2C_SMBUS_UNSUPPORT
- I2C_BYTE_COUNT_ERROR
- I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114010

Error Message `%ASA-3-114010: Failed to set multicast hardware address in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the multicast hardware address in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.

2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114011

Error Message `%ASA-3-114011: Failed to delete multicast address in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to delete the multicast address in a 4GE SSM I/O card because of either an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114012

Error Message `%ASA-3-114012: Failed to delete multicast hardware address in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to delete the multicast hardware address in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier

- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114013

Error Message `%ASA-3-114013: Failed to set mac address table in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the MAC address table in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.

2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114014

Error Message `%ASA-3-114014: Failed to set mac address in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the MAC address in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114015

Error Message `%ASA-3-114015: Failed to set mode in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set individual or promiscuous mode in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier

- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114016

Error Message `%ASA-3-114016: Failed to set multicast mode in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the multicast mode in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.

2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114017

Error Message `%ASA-3-114017: Failed to get link status in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to obtain link status in a 4GE SSM I/O card because of an I2C serial bus access error or a switch access error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Notify the system administrator.
2. Log and review the messages and the errors associated with the event.
3. Reboot the software running on the ASA.
4. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
5. If the problem persists, contact the Cisco TAC.

114018

Error Message `%ASA-3-114018: Failed to set port speed in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the port speed in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier

- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114019

Error Message `%ASA-3-114019: Failed to set media type in 4GE SSM I/O card (error error_string).`

Explanation The ASA failed to set the media type in a 4GE SSM I/O card because of an I2C error or a switch initialization error.

- *syslog_id*—Message identifier
- *error_string*—An I2C serial bus error or a switch access error, which is a decimal error code. The following are the I2C serial bus errors:

  - I2C_BUS_TRANSACTION_ERROR

  - I2C_CHKSUM_ERROR

  - I2C_TIMEOUT_ERROR

  - I2C_BUS_COLLISION_ERROR

  - I2C_HOST_BUSY_ERROR

  - I2C_UNPOPULATED_ERROR

  - I2C_SMBUS_UNSUPPORT

  - I2C_BYTE_COUNT_ERROR

  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event.

2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

114020

Error Message `%ASA-3-114020: Port link speed is unknown in` 4GE SSM `I/O card.`

Explanation The ASA cannot detect the port link speed in a 4GE SSM I/O card.

Recommended Action Perform the following steps:

1. Log and review the messages associated with the event.
2. Reset the 4GE SSM I/O card and observe whether or not the software automatically recovers from the event.
3. If the software does not recover automatically, power cycle the device. When you turn off the power, make sure you wait several seconds before you turn the power on.
4. If the problem persists, contact the Cisco TAC.

114021

Error Message `%ASA-3-114021: Failed to set multicast address table in 4GE SSM I/O card due to` *`error`*`.`

Explanation The ASA failed to set the multicast address table in the 4GE SSM I/O card because of either an I2C serial bus access error or a switch access error.

- *error*—A switch access error (a decimal error code) or an I2C serial bus error. Possible I2C serial bus errors include:

  - I2C_BUS_TRANSACTION_ERROR
  - I2C_CHKSUM_ERROR
  - I2C_TIMEOUT_ERROR
  - I2C_BUS_COLLISION_ERROR
  - I2C_HOST_BUSY_ERROR
  - I2C_UNPOPULATED_ERROR
  - I2C_SMBUS_UNSUPPORT
  - I2C_BYTE_COUNT_ERROR
  - I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages associated with the event.
2. Try to reboot the ASA.

3. If the software does not recover automatically, power cycle the device. When you turn off the power, make sure you wait several seconds before you turn the power on.
4. If the problem persists, contact the Cisco TAC.

114022

Error Message `%ASA-3-114022: Failed to pass broadcast traffic in 4GE SSM I/O card due to error_string`

Explanation The ASA failed to pass broadcast traffic in the 4GE SSM I/O card because of a switch access error.

- *error_string*—A switch access error, which will be a decimal error code

Recommended Action Perform the following steps:

1. Log the message and errors surrounding the event.
2. Retrieve the ssm4ge_dump file from the compact flash, and send it to Cisco TAC.
3. Contact Cisco TAC with the information collected in Steps 1 and 2.

Note The 4GE SSM will be automatically reset and recover.

114023

Error Message `%ASA-3-114023: Failed to cache/flush mac table in 4GE SSM I/O card due to error_string.`

Explanation A failure to cache or flush the MAC table in a 4GE SSM I/O card occurred because of an I2C serial bus access error or a switch access error. This message rarely occurs.

- *error_string*— Either an I2C serial bus error (see the second bullet for possible values) or a switch access error (which is a decimal error code).
- I2C serial bus errors are as follows:

  I2C_BUS_TRANSACTION_ERROR

  I2C_CHKSUM_ERROR

  I2C_TIMEOUT_ERROR

  I2C_BUS_COLLISION_ERROR

  I2C_HOST_BUSY_ERROR

  I2C_UNPOPULATED_ERROR

  I2C_SMBUS_UNSUPPORT

  I2C_BYTE_COUNT_ERROR

I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log the syslog message and the errors surrounding the event.
2. Try to software reboot the ASA.
3. Power cycle the ASA.

Note When you turn off the power, make sure that you wait several seconds before powering on again. After you complete steps 1-3, if the problem persists, contact the Cisco TAC and provide the information described in step 1. You may need to RMA the ASA.

115000

Error Message `%ASA-2-115000: Critical assertion in process: process name fiber: fiber name, component: component name, subcomponent: subcomponent name, file: filename, line: line number, cond: condition`

Explanation The critical assertion has gone off and is used during development in checked builds only, but never in production builds.

- *process name*— The name of the process
- *fiber name* —The name of the fiber
- *component name*—The name of the specified component
- *subcomponent name*—The name of the specified subcomponent
- *filename*—The name of the specified file
- *line number*—The line number for the specified line
- *condition*—The specified condition

Recommended Action A high priority defect should be filed, the reason for the assertion should be investigated, and the problem corrected.

115001

Error Message `%ASA-3-115001: Error in process: process name fiber: fiber name, component: component name, subcomponent: subcomponent name, file: filename, line: line number, cond: condition`

Explanation An error assertion has gone off and is used during development in checked builds only, but never in production builds.

- *process name*— The name of the process
- *fiber name* —The name of the fiber
- *component name*—The name of the specified component
- *subcomponent name*—The name of the specified subcomponent

- *filename*—The name of the specified file
- *line number*—The line number for the specified line
- *condition*—The specified condition

Recommended Action A defect should be filed, the reason for the assertion should be investigated, and the problem fixed.

115002

Error Message `%ASA-4-115002: Warning in process: process name fiber: fiber name, component: component name, subcomponent: subcomponent name, file: filename, line: line number, cond: condition`

Explanation A warning assertion has gone off and is used during development in checked builds only, but never in production builds.

- *process name*— The name of the process
- *fiber name* —The name of the fiber
- *component name*—The name of the specified component
- *subcomponent name*—The name of the specified subcomponent
- *filename*—The name of the specified file
- *line number*—The line number for the specified line
- *condition*—The specified condition

Recommended Action The reason for the assertion should be investigated and if a problem is found, a defect should be filed, and the problem corrected.

120001

Error Message `%ASA-5-120001: Smart Call-Home Module is started.`

Explanation The Smart Call-Home module started successfully after system bootup and failover in a stable state, and is ready to process Smart-Call Home events.

Recommended Action None required.

120002

Error Message `%ASA-5-120002: Smart Call-Home Module is terminated.`

Explanation When the Smart Call-Home module is disabled, it is then terminated.

Recommended Action None required.

120003

Error Message `%ASA-6-120003: Process event group title`

Explanation The Smart Call-Home module retrieved an event from the queue to process.

- *group*—The event group, which may be the following: inventory, configuration, diagnostic, environment, snapshot, telemetry, threat, and test.
- *title*—The event title

Recommended Action None required.

120004

Error Message `%ASA-4-120004: Event group title is dropped. Reason reason`

Explanation A Smart Call-Home event was dropped. The event may have been dropped because of an internal error, the event queue is full, or the Smart Call-Home module was disabled after the message was generated, but before it was processed.

- *group*—The event group, which can be any of the following: inventory, configuration, diagnostic, environment, snapshot, telemetry, threat, and test.
- *title*—The event title
- *reason*—The drop reason, which can any of the following:

  Internal Error—Various internal system errors occurred, such as being out of memory or parsing a CLI failed.

  Queue Full—The number of events reached the configured limit.

  Cancelled—The event was cancelled because the Smart Call-Home module is disabled.

Recommended Action If the drop reason is Queue Full, try to increase the event queue size and the rate-limit configuration to avoid event queue buildup. If the drop reason is Internal Error, turn on debugging by entering the **debug sch fail** command to obtain more detailed debugging information.

120005

Error Message `%ASA-4-120005: Message group to destination is dropped. Reason reason`

Explanation A Smart Call-Home message was dropped. The message may have been dropped because of an internal error, a network error, or the Smart Call-Home module was disabled after the message was generated, but before it was delivered.

- *group*—The event group, which can be any of the following: inventory, configuration, diagnostic, environment, snapshot, telemetry, threat, and test.
- *destination*—The e-mail or URL destination
- *reason*—The drop reason, which can any of the following:

Internal Error—Various internal system errors occurred.

Delivery Failed—The packets cannot be delivered because a network error occurred.

Cancelled—The event was cancelled because the Smart Call-Home module is disabled.

Recommended Action If the drop reason is Delivery Failed, the message is dropped after three unsuccessful retransmissions, or because the error is local (such as no route to destination). Search message 120006 for the delivery failure reason, or turn on debugging by entering the **debug sch fail** command to obtain more detailed debugging information.

120006

Error Message `%ASA-4-120006: Delivering message` *`group`* `to` *`destination`* `failed. Reason` *`reason`*

Explanation An error occurred while the Smart Call Home module tried to deliver a message. The error may be transient. The message is not dropped when message 120006 is generated. The message may be queued for retransmission. The message is only dropped when message 120005 is generated.

- *group*—The event group, which can be any of the following: inventory, configuration, diagnostic, environment, snapshot, telemetry, threat, and test
- *destination*—The e-mail or URL destination
- *reason*—The failure reason

Recommended Action Check the error reason in the message. If the reason is NO_ROUTE, INVALID_ADDRESS, or INVALID_URL, check the system configuration, DNS, and the name setting.

120007

Error Message `%ASA-6-120007: Message` *`group`* `to` *`destination`* `delivered.`

Explanation A Smart Call Home message was successfully delivered.

- *group*—The event group, which can be any of the following: inventory, configuration, diagnostic, environment, snapshot, telemetry, threat, and test
- *destination*—The e-mail or URL destination

Recommended Action None required.

120008

Error Message `%ASA-5-120008: SCH client client is activated.`

Explanation The Smart Call Home module is enabled, an event group is also enabled, and that event group is subscribed to by at least one active profile. If these conditions are met, then all clients of that group will be activated.

- *client*—The name of the Smart Call Home client

Recommended Action None required.

120009

Error Message `%ASA-5-120009: SCH client client is deactivated.`

Explanation The Smart Call Home module is disabled, an event group is enabled, or an event group is no longer subscribed to by any active profile. If these conditions are met, clients of that event group will be deactivated.

- *client*—The name of the Smart Call Home client

Recommended Action None required.

120010

Error Message `%ASA-3-120010: Notify command command to SCH client client failed. Reason reason.`

Explanation The Smart Call Home module notified Smart Call Home clients of certain events through the callback function. If the client does not interpret the command correctly, does not understand the command, or cannot process the command, an error will be returned.

- *command*—ENABLE, DISABLE, or READY
- *client*—The name of the Smart Call Home client
- *reason*—The reason for failure

Recommended Action Turn on debugging by entering the **debug sch fail** command to obtain more detailed debugging information.

120012

Error Message `%ASA-5-120012: User username chose to choice call-home anonymous reporting at the prompt.`

Explanation The administrator was notified that a user has responded to the Smart Call Home prompt to enable, disable, or postpone anonymous reporting.

- *username*—The user who responded to the prompt
- *choice*—The available entries are enable, disable, or postpone

Recommended Action To enable anonymous reporting in the future, enter the **call-home reporting anonymous** command. To disable anonymous reporting, enter the **no call-home reporting anonymous** command.

199001

Error Message `%ASA-5-199001: Reload command executed from Telnet (remote IP_address).`

Explanation The address of the host that is initiating an ASA reboot with the **reload** command has been recorded.

Recommended Action None required.

199002

Error Message `%ASA-6-199002: startup completed. Beginning operation.`

Explanation The ASA finished its initial boot and the flash memory reading sequence, and is ready to begin operating normally.

Note You cannot block this message by using the **no logging message** command.

Recommended Action None required.

199003

Error Message `%ASA-6-199003: Reducing link MTU dec.`

Explanation The ASA received a packet from the outside network that uses a larger MTU than the inside network. The ASA then sent an ICMP message to the outside host to negotiate an appropriate MTU. The log message includes the sequence number of the ICMP message.

Recommended Action None required.

199005

Error Message `%ASA-6-199005: Startup begin`

Explanation The ASA started.

Recommended Action None required.

199010

Error Message `%ASA-1-199010: Signal 11 caught in process/fiber(rtcli async executor process)/(rtcli async executor) at address 0xf132e03b, corrective action at 0xca1961a0`

Explanation The system has recovered from a serious error.

Recommended Action Contact the Cisco TAC.

199011

Error Message `%ASA-2-199011: Close on bad channel in process/fiber` *`process/fiber`*`, channel ID` *`p`*`, channel state` *`s process/fiber`* `name of the process/fiber that caused the bad channel close operation.`

Explanation An unexpected channel close condition has been detected.

- *p*—The channel ID
- *process/fiber*—The name of the process/fiber that caused the bad channel close operation
- *s*—The channel state

Recommended Action Contact the Cisco TAC and attach a log file.

199012

Error Message `%ASA-1-1199012: Stack smash during new_stack_call in process/fiber` *`process/fiber`*`, call target` *`f`*`, stack size` *`s`*`,` *`process/fiber`* `name of the process/fiber that caused the stack smash`

Explanation A stack smash condition has been detected.

- *f*—The target of the new_stack_call
- *process/fiber*—The name of the process/fiber that caused the stack smash
- *s*—The new stack size specified in new_stack_call

Recommended Action Contact the Cisco TAC and attach a log file.

199013

Error Message `%ASA-1-199013: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The alert syslog passed verbatim from an external process

Recommended Action Contact the Cisco TAC.

199014

Error Message `%ASA-2-199014: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The critical syslog passed verbatim from an external process

Recommended Action Contact the Cisco TAC.

199015

Error Message `%ASA-3-199015: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The error syslog passed verbatim from an external process

Recommended Action Contact the Cisco TAC.

199016

Error Message `%ASA-4-199016: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The warning syslog passed verbatim from an external process

Recommended Action Contact the Cisco TAC.

199017

Error Message `%ASA-5-199017: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The notification syslog passed verbatim from an external process

Recommended Action None required.

199018

Error Message `%ASA-6-199018: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The informational syslog passed verbatim from an external process

Recommended Action None required.

199019

Error Message `%ASA-7-199019: syslog`

Explanation A variable syslog was generated by an assistive process.

- *syslog*—The debugging syslog passed verbatim from an external process

Recommended Action None required.

199020

Error Message `%ASA-2-199020: System memory utilization has reached X%. System will reload if memory usage reaches the configured trigger level of Y%.`

Explanation The system memory utilization has reached 80% of the system memory watchdog facility's configured value.

Recommended Action Reduce system memory utilization by reducing traffic load, removing traffic inspections, reducing the number of ACL entries, and so on. If a memory leak is suspected, contact Cisco TAC.

199021

Error Message `%ASA-1-199021: System memory utilization has reached the configured watchdog trigger level of Y%. System will now reload`

Explanation .The system memory utilization has reached 100% of the system memory watchdog facility's configured value. The system will automatically reload.

Recommended Action Reduce system memory utilization by reducing traffic load, removing traffic inspections, reducing the number of ACL entries, and so on. If a memory leak is suspected, contact Cisco TAC.

Messages 201002 to 219002

This section includes messages from 201002 to 219002.

201002

Error Message `%ASA-3-201002: Too many TCP connections on {static|xlate} global_address! econns nconns`

Explanation The maximum number of TCP connections to the specified global address was exceeded.

- *econns*—The maximum number of embryonic connections
- *nconns*—The maximum number of connections permitted for the static or xlate global address

Recommended Action Use the **show static** or **show nat** command to check the limit imposed on connections to a static address. The limit is configurable.

201003

Error Message `%ASA-2-201003: Embryonic limit exceeded nconns/elimit for outside_address/outside_port (global_address) inside_address/inside_port on interface interface_name`

Explanation The number of embryonic connections from the specified foreign address with the specified static global address to the specified local address exceeds the embryonic limit. When the limit on embryonic connections to the ASA is reached, the ASA attempts to accept them anyway, but puts a time limit on the connections. This situation allows some connections to succeed even if the ASA is very busy. This message indicates a more serious overload than message 201002, which can be caused by a SYN attack, or by a very heavy load of legitimate traffic.

- *nconns*—The maximum number of embryonic connections received

- *elimit*—The maximum number of embryonic connections specified in the **static** or **nat** command

Recommended Action Use the **show static** command to check the limit imposed on embryonic connections to a static address.

201004

Error Message `%ASA-3-201004: Too many UDP connections on {static|xlate} global_address!udp connections limit`

Explanation The maximum number of UDP connections to the specified global address was exceeded.

- *udp conn limit*—The maximum number of UDP connections permitted for the static address or translation

Recommended Action Use the **show static** or **show nat** command to check the limit imposed on connections to a static address. You can configure the limit.

201005

Error Message `%ASA-3-201005: FTP data connection failed for IP_address IP_address`

Explanation The ASA cannot allocate a structure to track the data connection for FTP because of insufficient memory.

Recommended Action Reduce the amount of memory usage or purchase additional memory.

201006

Error Message `%ASA-3-201006: RCMD backconnection failed for IP_address/port.`

Explanation The ASA cannot preallocate connections for inbound standard output for **rsh** commands because of insufficient memory.

Recommended Action Check the **rsh** client version; the ASA only supports the Berkeley **rsh** client version. You can also reduce the amount of memory usage, or purchase additional memory.

201008

Error Message `%ASA-3-201008: Disallowing new connections.`

Explanation You have enabled TCP system log messaging and the syslog server cannot be reached, or when using the ASA syslog server (PFSS) and the disk on the Windows NT system is full, or when the auto-update timeout is configured and the auto-update server is not reachable.

Recommended Action Disable TCP syslog messaging. If using PFSS, free up space on the Windows NT system where PFSS resides. Also, make sure that the syslog server is up and you can ping the host from the ASA console. Then restart TCP system message logging to allow traffic. If the Auto Update Server has not been contacted for a certain period of time, enter the **[no] auto-update timeout period** command to have it stop sending packets.

201009

Error Message `%ASA-3-201009: TCP connection limit of` *`number`* `for host` *`IP_address`* `on` *`interface_name`* `exceeded`

Explanation The maximum number of connections to the specified static address was exceeded.

- *number*—The maximum of connections permitted for the host
- *IP_address*—The host IP address
- *interface_name*—The name of the interface to which the host is connected

Recommended Action Use the **show static** and **show nat** commands to check the limit imposed on connections to an address. The limit is configurable.

201010

Error Message `%ASA-6-201010: Embryonic connection limit exceeded` *`econns/limit`* `for` *`dir`* `packet from` *`source_address/source_port`* `to` *`dest_address/dest_port`* `on interface` *`interface_name`*

Explanation An attempt to establish a TCP connection failed because of an exceeded embryonic connection limit, which was configured with the **set connection embryonic-conn-max** MPC command for a traffic class.

- *econns*—The current count of embryonic connections associated to the configured traffic class
- *limit*—The configured embryonic connection limit for the traffic class
- *dir*—input: The first packet that initiates the connection is an input packet on the interface *interface_name* output: The first packet that initiates the connection is an output packet on the interface *interface_name*
- *source_address/source_port*—The source real IP address and the source port of the packet initiating the connection

- *dest_address/dest_port*—The destination real IP address and the destination port of the packet initiating the connection
- *interface_name*—The name of the interface on which the policy limit is enforced

Recommended Action None required.

201011

Error Message `%ASA-3-201011: Connection limit exceeded cnt/limit for dir packet from sip/sport to dip/dport on interface if_name.`

Explanation A new connection through the ASA resulted in exceeding at least one of the configured maximum connection limits. This message applies both to connection limits configured using a **static** command, or to those configured using Cisco Modular Policy Framework. The new connection will not be allowed through the ASA until one of the existing connections is torn down, which brings the current connection count below the configured maximum.

- *cnt*—Current connection count
- *limit*—Configured connection limit
- *dir*—Direction of traffic, inbound or outbound
- *sip*—Source real IP address
- *sport*—Source port
- *dip*—Destination real IP address
- *dport*—Destination port
- *if_name*—Name of the interface on which the traffic was received

Recommended Action None required.

201012

Error Message `%ASA-6-201012: Per-client embryonic connection limit exceeded curr num/limit for [input|output] packet from IP_address/ port to ip/port on interface interface_name`

Explanation An attempt to establish a TCP connection failed because the per-client embryonic connection limit was exceeded. By default, this message is rate limited to 1 message every 10 seconds.

- *curr num*—The current number
- *limit*—The configured limit
- [input|output]—Input or output packet on interface *interface_name*
- *IP_address*—Real IP address
- *port*—TCP or UDP port

- *interface_name*—The name of the interface on which the policy is applied

Recommended Action When the limit is reached, any new connection request will be proxied by the ASA to prevent a SYN flood attack. The ASA will only connect to the server if the client is able to finish the three-way handshake. This usually does not affect the end user or the application. However, if this creates a problem for any application that has a legitimate need for a higher number of embryonic connections, you can adjust the setting by entering the **set connection per-client-embryonic-max** command.

201013

Error Message `%ASA-3-201013: Per-client connection limit exceeded curr num/limit for [input|output] packet from ip/port to ip/port on interface interface_name`

Explanation A connection was rejected because the per-client connection limit was exceeded.

- *curr num*—The current number
- *limit*—The configured limit
- [input|output]—The input or output packet on interface *interface_name*
- *ip*—The real IP address
- *port*—The TCP or UDP port
- *interface_name*—The name of the interface on which the policy is applied

Recommended Action When the limit is reached, any new connection request will be silently dropped. Normally an application will retry the connection, which will cause a delay or even a timeout if all retries also fail. If an application has a legitimate need for a higher number of concurrent connections, you can adjust the setting by entering the **set connection per-client-max** command.

202001

Error Message `%ASA-3-202001: Out of address translation slots!`

Explanation The ASA has no more address translation slots available.

Recommended Action Check the size of the global pool compared to the number of inside network clients. A PAT address may be necessary. Alternatively, shorten the timeout interval of translates and connections. This error message can also be caused by insufficient memory; reduce the amount of memory usage, or purchase additional memory, if possible.

202005

Error Message `%ASA-3-202005: Non-embryonic in embryonic list outside_address/outside_port inside_address/inside_port`

Explanation A connection object (xlate) is in the wrong list.

Recommended Action Contact the Cisco TAC.

202010

Error Message `%ASA-3-202010: [NAT | PAT] pool exhausted for pool-name, port range [1-511 | 512-1023 | 1024-65535]. Unable to create protocol connection from in-interface:src-ip/src-port to out-interface:dst-ip/dst-port`

- *pool-name*—The name of the NAT or PAT pool
- *protocol*—The protocol used to create the connection
- *in-interface*—The ingress interface
- *src-ip*—The source IP address
- *src-port*—The source port
- *out-interface*—The egress interface
- *dest-ip*—The destination IP address
- *dst-port*—The destination port

Explanation The ASA has no more address translation pools available.

Recommended Action Use the **show nat pool** and **show nat detail** commands to determine why all addresses and ports in the pool are used up. If this occurs under normal conditions, then add additional IP addresses to the NAT/PAT pool.

208005

Error Message `%ASA-3-208005: (function:line_num) clear command return code`

Explanation The ASA received a nonzero value (an internal error) when attempting to clear the configuration in flash memory. The message includes the reporting subroutine filename and line number.

Recommended Action For performance reasons, the end host should be configured not to inject IP fragments. This configuration change is probably because of NFS. Set the read and write size equal to the interface MTU for NFS.

209003

Error Message `%ASA-4-209003: Fragment database limit of number exceeded: src = source_address, dest = dest_address, proto = protocol, id = number`

Explanation Too many IP fragments are currently awaiting reassembly. By default, the maximum number of fragments is 200 (to raise the maximum, see the **fragment size** command in the command reference). The ASA limits the number of IP fragments that can be concurrently reassembled. This restriction prevents memory depletion at the ASA under abnormal network conditions. In general, fragmented traffic should be a small percentage of the total traffic mix. An exception is in a network environment with NFS over UDP where a large percentage is fragmented traffic; if this type of traffic is relayed through the ASA, consider using NFS over TCP instead. To prevent fragmentation, see the **sysopt connection tcpmss** *bytes* command in the command reference.

Recommended Action If this message persists, a denial of service (DoS) attack might be in progress. Contact the remote peer administrator or upstream provider.

209004

Error Message `%ASA-4-209004: Invalid IP fragment, size = bytes exceeds maximum size = bytes: src = source_address, dest = dest_address, proto = protocol, id = number`

Explanation An IP fragment is malformed. The total size of the reassembled IP packet exceeds the maximum possible size of 65,535 bytes.

Recommended Action A possible intrusion event may be in progress. If this message persists, contact the remote peer administrator or upstream provider.

209005

Error Message `%ASA-4-209005: Discard IP fragment set with more than number elements: src = Too many elements are in a fragment set.`

Explanation The ASA disallows any IP packet that is fragmented into more than 24 fragments. For more information, see the **fragment** command in the command reference.

Recommended Action A possible intrusion event may be in progress. If the message persists, contact the remote peer administrator or upstream provider. You can change the number of fragments per packet by using the **fragment chain** *xxx interface_name* command.

210001

Error Message `%ASA-3-210001: LU sw_module_name error = number`

Explanation A Stateful Failover error occurred.

Recommended Action If this error persists after traffic lessens through the ASA, report this error to the Cisco TAC.

210002

Error Message `%ASA-3-210002: LU allocate block (bytes) failed.`

Explanation Stateful Failover cannot allocate a block of memory to transmit stateful information to the standby ASA.

Recommended Action Check the failover interface using the **show interface** command to make sure its transmit is normal. Also check the current block memory using the **show block** command. If current available count is 0 within any of the blocks of memory, then reload the ASA software to recover the lost blocks of memory.

210003

Error Message `%ASA-3-210003: Unknown LU Object number`

Explanation Stateful Failover received an unsupported Logical Update object and was unable to process it. This can be caused by corrupted memory, LAN transmissions, and other events.

Recommended Action If you see this error infrequently, then no action is required. If this error occurs frequently, check the Stateful Failover link LAN connection. If the error was not caused by a faulty failover link LAN connection, determine if an external user is trying to compromise the protected network. Also check for misconfigured clients.

210005

Error Message `%ASA-3-210005: LU allocate connection failed`

Explanation Stateful Failover cannot allocate a new connection on the standby unit. This may be caused by little or no RAM memory available within the ASA.

Recommended Action Check the available memory using the **show memory** command to make sure that the ASA has free memory. If there is no available memory, add more physical memory to the ASA.

210006

Error Message `%ASA-3-210006: LU look NAT for IP_address failed`

Explanation Stateful Failover was unable to locate a NAT group for the IP address on the standby unit. The active and standby ASAs may be out-of-sync with each other.

Recommended Action Use the **write standby** command on the active unit to synchronize system memory with the standby unit.

210007

Error Message `%ASA-3-210007: LU allocate xlate failed`

Explanation Stateful Failover failed to allocate a translation slot record.

Recommended Action Check the available memory by using the **show memory** command to make sure that the ASA has free memory available. If no memory is available, add more memory.

210008

Error Message `%ASA-3-210008: LU no xlate for inside_address/inside_port outside_address/outside_port`

Explanation The ASA cannot find a translation slot record for a Stateful Failover connection; as a result, the ASA cannot process the connection information.

Recommended Action Use the **write standby** command on the active unit to synchronize system memory between the active and standby units.

210010

Error Message `%ASA-3-210010: LU make UDP connection for outside_address:outside_port inside_address:inside_port failed`

Explanation Stateful Failover was unable to allocate a new record for a UDP connection.

Recommended Action Check the available memory by using the **show memory** command to make sure that the ASA has free memory available. If no memory is available, add more memory.

210020

Error Message `%ASA-3-210020: LU PAT port port reserve failed`

Explanation Stateful Failover is unable to allocate a specific PAT address that is in use.

Recommended Action Use the **write standby** command on the active unit to synchronize system memory between the active and standby units.

210021

Error Message `%ASA-3-210021: LU create static xlate global_address ifc interface_name failed`

Explanation Stateful Failover is unable to create a translation slot.

Recommended Action Enter the **write standby** command on the active unit to synchronize system memory between the active and standby units.

210022

Error Message `%ASA-6-210022: LU missed number updates`

Explanation Stateful Failover assigns a sequence number for each record sent to the standby unit. When a received record sequence number is out of sequence with the last updated record, the information in between is assumed to be lost, and this error message is sent as a result.

Recommended Action Unless LAN interruptions occur, check the available memory on both ASA units to ensure that enough memory is available to process the stateful information. Use the **show failover** command to monitor the quality of stateful information updates.

211001

Error Message `%ASA-3-211001: Memory allocation Error`

Explanation The ASA failed to allocate RAM system memory.

Recommended Action If this message occurs periodically, it can be ignored. If it repeats frequently, contact the Cisco TAC.

211003

Error Message `%ASA-3-211003: Error in computed percentage CPU usage value`

Explanation The percentage of CPU usage is greater than 100 percent.

Recommended Action If this message occurs periodically, it can be ignored. If it repeats frequently, contact the Cisco TAC.

211004

Error Message `%ASA-1-211004: WARNING: Minimum Memory Requirement for ASA version ver not met for ASA image. min MB required, actual MB found.`

Explanation The ASA does not meet the minimum memory requirements for this version. A memory upgrade is required. If a memory upgrade is not immediately available, then downgrade the ASA to Version 8.2(1) or lower. Continuing to run an 8.3 image without meeting the minimum memory requirements is not supported and may result in critical system failures.

- *ver*—Running image version number
- *min*—Minimum required amount of RAM to run the installed image. The available memory upgrade PID numbers are as follows:

  ASA5505-MEM-512=

  ASA5510-MEM-1GB=

  ASA5520-MEM-2GB=

  ASA5540-MEM-2GB=
- *actual*—Amount of RAM currently installed in the system

Recommended Action Install the required amount of RAM. Use the memory upgrade PID numbers to order the required amount of RAM.

212001

Error Message `%ASA-3-212001: Unable to open SNMP channel (UDP port port) on interface interface_number, error code = code`

Explanation The ASA is unable to receive SNMP requests destined for the ASA from SNMP management stations located on this interface. The SNMP traffic passing through the ASA on any interface is not affected. The error codes are as follows:

- An error code of -1 indicates that the ASA cannot open the SNMP transport for the interface. This can occur when the user attempts to change the port on which SNMP accepts queries to one that is already in use by another feature. In this case, the port used by SNMP will be reset to the default port for incoming SNMP queries (UDP 161).

- An error code of -2 indicates that the ASA cannot bind the SNMP transport for the interface.

Recommended Action After the ASA reclaims some of its resources when traffic is lighter, reenter the **snmp-server host** command for that interface.

212002

Error Message `%ASA-3-212002: Unable to open SNMP trap channel (UDP port port) on interface interface_number, error code = code`

Explanation The ASA is unable to send its SNMP traps from the ASA to SNMP management stations located on this interface. The SNMP traffic passing through the ASA on any interface is not affected. The error codes are as follows:

- An error code of -1 indicates that the ASA cannot open the SNMP trap transport for the interface.
- An error code of -2 indicates that the ASA cannot bind the SNMP trap transport for the interface.
- An error code of -3 indicates that the ASA cannot set the trap channel as write-only.

Recommended Action After the ASA reclaims some of its resources when traffic is lighter, reenter the **snmp-server host** command for that interface.

212003

Error Message `%ASA-3-212003: Unable to receive an SNMP request on interface interface_number, error code = code, will try again.`

Explanation An internal error occurred in receiving an SNMP request destined for the ASA on the specified interface. The error codes are as follows:

- An error code of -1 indicates that the ASA cannot find a supported transport type for the interface.
- An error code of -5 indicates that the ASA received no data from the UDP channel for the interface.
- An error code of -7 indicates that the ASA received an incoming request that exceeded the supported buffer size.
- An error code of -14 indicates that the ASA cannot determine the source IP address from the UDP channel.
- An error code of -22 indicates that the ASA received an invalid parameter.

Recommended Action None required. The ASA SNMP agent goes back to wait for the next SNMP request.

212004

Error Message `%ASA-3-212004: Unable to send an SNMP response to IP Address IP_address Port port interface interface_number, error code = code`

Explanation An internal error occurred in sending an SNMP response from the ASA to the specified host on the specified interface. The error codes are as follows:

- An error code of -1 indicates that the ASA cannot find a supported transport type for the interface.
- An error code of -2 indicates that the ASA sent an invalid parameter.
- An error code of -3 indicates that the ASA was unable to set the destination IP address in the UDP channel.
- An error code of -4 indicates that the ASA sent a PDU length that exceeded the supported UDP segment size.
- An error code of -5 indicates that the ASA was unable to allocate a system block to construct the PDU.

Recommended Action None required.

212005

Error Message `%ASA-3-212005: incoming SNMP request (number bytes) on interface interface_name exceeds data buffer size, discarding this SNMP request.`

Explanation The length of the incoming SNMP request that is destined for the ASA exceeds the size of the internal data buffer (512 bytes) used for storing the request during internal processing. The ASA is unable to process this request. The SNMP traffic passing through the ASA on any interface is not affected.

Recommended Action Have the SNMP management station resend the request with a shorter length. For example, instead of querying multiple MIB variables in one request, try querying only one MIB variable in a request. You may need to modify the configuration of the SNMP manager software.

212006

Error Message `%ASA-3-212006: Dropping SNMP request from src_addr/src_port to ifc:dst_addr/dst_port because: reason username`

Explanation The ASA cannot process the SNMP request being sent to it for the following reasons:

- user not found—The username cannot be located in the local SNMP user database.
- username exceeds maximum length—The username embedded in the PDU exceeds the maximum length allowed by the SNMP RFCs.
- authentication algorithm failure—An authentication failure caused by an invalid password or a packet authenticated using the incorrect algorithm.

- privacy algorithm failure—A privacy failure caused by an invalid password or a packet encrypted using the incorrect algorithm.
- error decrypting request—An error occurred in the platform crypto module decrypting the user request.
- error encrypting response—An error occurred in the platform crypto module encrypting the user response or trap notification.
- engineBoots has reached maximum value—The engineBoots variable has reached the maximum allowed value. For more information, see message 212011.

Note The username appears after each reason listed.

Recommended Action Check the ASA SNMP server settings and confirm that the NMS configuration is using the expected user, authentication, and encryption settings. Enter the **show crypto accelerator statistics** command to isolate errors in the platform crypto module.

212009

Error Message `%ASA-5-212009: Configuration request for SNMP group groupname failed. User username, reason.`

Explanation A user has tried to change the SNMP server group configuration. One or more users that refer to the group have insufficient settings to comply with the requested group changes.

- *groupname*—A string that represents the group name
- *username*—A string that represents the username
- *reason*—A string that represents one of the following reasons:

  - *missing auth-password*—A user has tried to add authentication to the group, and the user has not specified an authentication password

  - *missing priv-password*—A user has tried to add privacy to the group, and the user has not specified an encryption password

  - *reference group intended for removal*—A user has tried to remove a group that has users belonging to it

Recommended Action The user must update the indicated user configurations before changing the group or removing indicated users, and then add them again after making changes to the group.

212010

Error Message `%ASA-3-212010: Configuration request for SNMP user %s failed. Host %s reason.`

Explanation A user has tried to change the SNMP server user configuration by removing one or more hosts that reference the user. One message is generated per host.

- *%s*—A string that represents the username or hostname

- *reason*—A string the represents the following reason:

  - *references user intended for removal*—The name of the user to be removed from the host.

Recommended Action The user must either update the indicated host configuration before changing a user or remove the indicated hosts, then add them again after making changes to the user.

212011

Error Message `%ASA-3-212011: SNMP engineBoots is set to maximum value. Reason: %s User intervention necessary.`

For example:

```
%ASA-3-212011: SNMP engineBoots is set to maximum value. Reason: error accessing
persistent data. User intervention necessary.
```

Explanation The device has rebooted 214783647 times, which is the maximum allowed value of the engineBoots variable, or an error reading the persistent value from flash memory has occurred. The engineBoots value is stored in flash memory in the flash:/snmp/*ctx-name* file, where *ctx-name* is the name of the context. In single mode, the name of this file is flash:/snmp/single_vf. In multi-mode, the name of the file for the admin context is flash:/snmp/admin. During a reboot, if the device is unable to read from the file or write to the file, the engineBoots value is set to the maximum.

- *%s*—A string that represents the reason that the engineBoots value is set to the maximum allowed value. The two valid strings are “device reboots” and “error accessing persistent data.”

Recommended Action For the first string, the administrator must delete all SNMP Version 3 users and add them again to reset the engineBoots variable to 1. All subsequent Version 3 queries will fail until all users have been removed. For the second string, the administrator must delete the context-specific file, then delete all SNMP Version users, and add them again to reset the engineBoots variable to 1. All subsequent Version 3 queries will fail until all users have been removed.

212012

Error Message `%ASA-3-212012: Unable to write SNMP engine data to persistent storage.`

Explanation The SNMP engine data is written to the file, flash:/snmp/*context-name*. For example: in single mode, the data is written to the file, flash:/snmp/single_vf. In the admin context in multi-mode, the file is written to the directory, flash:/snmp/admin. The error may be caused by a failure to create the flash:/snmp directory or the flash:/snmp/*context-name* file. The error may also be caused by a failure to write to the file.

Recommended Action The system administrator should remove the flash:/snmp/*context-name* file, then remove all SNMP Version 3 users, and add them again. This procedure should recreate the flash:/snmp/*context-name* file. If the problem persists, the system administrator should try reformatting the flash.

213001

Error Message `%ASA-3-213001: PPTP control daemon socket io string, errno = number.`

Explanation An internal TCP socket I/O error occurred.

Recommended Action Contact the Cisco TAC.

213002

Error Message `%ASA-3-213002: PPTP tunnel hashtable insert failed, peer = IP_address.`

Explanation An internal software error occurred while creating a new PPTP tunnel.

Recommended Action Contact the Cisco TAC.

213003

Error Message `%ASA-3-213003: PPP virtual interface interface_number isn't opened.`

Explanation An internal software error occurred while closing a PPP virtual interface.

Recommended Action Contact the Cisco TAC.

213004

Error Message `%ASA-3-213004: PPP virtual interface interface_number client ip allocation failed.`

Explanation An internal software error occurred while allocating an IP address to the PPTP client when the IP local address pool was depleted.

Recommended Action Consider allocating a larger pool with the **ip local pool** command.

213005

Error Message `%ASA-3-213005%: Dynamic-Access-Policy action (DAP) action aborted`

Explanation The DAP is dynamically created by selecting configured access policies based on the authorization rights of the user and the posture assessment results of the remote endpoint device. The resulting dynamic policy indicates that the session should be terminated.

Recommended Action None required.

213006

Error Message `%ASA-3-213006%: Unable to read dynamic access policy record.`

Explanation There was either an error in retrieving the DAP policy record data, or the action configuration was missing.

Recommended Action A configuration change might have resulted in deleting a DAP record. Use ASDM to recreate the DAP record.

214001

Error Message `%ASA-2-214001: Terminating manager session from IP_address on interface interface_name. Reason: incoming encrypted data (number bytes) longer than number bytes`

Explanation An incoming encrypted data packet destined for the ASA management port indicates a packet length exceeding the specified upper limit. This may be a hostile event. The ASA immediately terminates this management connection.

Recommended Action Ensure that the management connection was initiated by Cisco Secure Policy Manager.

215001

Error Message `%ASA-2-215001:Bad route_compress() call, sdb = number`

Explanation An internal software error occurred.

Recommended Action Contact the Cisco TAC.

217001

Error Message `%ASA-2-217001: No memory for string in string`

Explanation An operation failed because of low memory.

Recommended Action If sufficient memory exists, then send the error message, the configuration, and any details about the events leading up to the error to the Cisco TAC.

216001

Error Message `%ASA-n-216001: internal error in: function: message`

Explanation Various internal errors have occurred that should not appear during normal operation. The severity level varies depending on the cause of the message.

- *n*—The message severity
- *function*—The affected component
- *message*—A message describing the cause of the problem

Recommended Action Search the Bug Toolkit for the specific text message and try to use the Output Interpreter to resolve the problem. If the problem persists, contact the Cisco TAC.

216002

Error Message `ASA-3-216002: Unexpected event (major: major_id, minor: minor_id) received by task_string in function at line: line_num`

Explanation A task registers for event notification, but the task cannot handle the specific event. Events that can be watched include those associated with queues, booleans, and timer services. If any of the registered events occur, the scheduler wakes up the task to process the event. This message is generated if an unexpected event woke up the task, but it does not know how to handle the event.

If an event is left unprocessed, it can wake up the task very often to make sure that it is processed, but this should not occur under normal conditions. If this message appears, it does not necessarily mean the device is unusable, but something unusual has occurred and needs to be investigated.

- *major_id*—Event identifier
- *minor_id*— Event identifier
- *task_string*—Custom string passed by the task to identify itself
- *function*—The function that received the unexpected event
- *line_num* —Line number in the code

Recommended Action If the problem persists, contact the Cisco TAC.

216003

Error Message `%ASA-3-216003: Unrecognized timer timer_ptr, timer_id received by task_string in function at line: line_num`

Explanation An unexpected timer event woke up the task, but the task does not know how to handle the event. A task can register a set of timer services with the scheduler. If any of the timers expire, the scheduler wakes up the task to take action. This message is generated if the task is awakened by an unrecognized timer event.

An expired timer, if left unprocessed, wakes up the task continuously to make sure that it is processed, and this is undesirable. This should not occur under normal conditions. If this message appears, it does not necessarily mean the device is unusable, but something unusual has occurred and needs to be investigated.

- *timer_ptr*—Pointer to the timer
- *timer_id*—Timer identifier
- *task_string*—Custom string passed by the task to identify itself
- *function*—The function that received the unexpected event
- *line_num*—Line number in the code

Recommended Action If the problem persists, contact the Cisco TAC.

216004

Error Message `%ASA-4-216004:prevented: error in function at file(line) - stack trace`

Explanation An internal logic error has occurred, which should not occur during normal operation.

- *error*—Internal logic error. Possible errors include the following:
  - Exception
  - Dereferencing null pointer
  - Array index out of bounds
  - Invalid buffer size
  - Writing from input
  - Source and destination overlap
  - Invalid date
  - Access offset from array indices
- *function*—The calling function that generated the error
- *file(line)*—The file and line number that generated the error
- *stack trace*—Full call stack traceback, starting with the calling function. For example: (“0x001010a4 0x00304e58 0x00670060 0x00130b04”)

Recommended Action If the problem persists, contact the Cisco TAC.

216005

Error Message `%ASA-1-216005: ERROR: Duplex-mismatch on interface_name resulted in transmitter lockup. A soft reset of the switch was performed.`

Explanation A duplex mismatch on the port caused a problem in which the port can no longer transmit packets. This condition was detected, and the switch was reset to autorecover. This message applies only to the ASA 5505.

- *interface_name*—The interface name that was locked up

Recommended Action A duplex mismatch exists between the specified port and the ASA 5505 that is connected to it. Correct the duplex mismatch by either setting both devices to autorecover, or hard coding the duplex mismatch for both devices to be the same.

218001

Error Message `%ASA-2-218001: Failed Identification Test in slot# [fail#/res].`

Explanation The module in *slot#* of the ASA cannot be identified as a genuine Cisco product. Cisco warranties and support programs apply only to genuine Cisco products. If Cisco determines that the cause of a support issue is related to non-Cisco memory, SSM modules, SSC modules, or other modules, Cisco may deny support under your warranty or under a Cisco support program such as SmartNet.

Recommended Action If this message recurs, copy it exactly as it appears on the console or in the system log. Research and try to resolve the error using the Output Interpreter. Also perform a search with the Bug Toolkit. If the problem persists, contact the Cisco TAC.

218002

Error Message `%ASA-2-218002: Module (slot#) is a registered proto-type for Cisco Lab use only, and not certified for live network operation.`

Explanation The hardware in the specified location is a prototype module that came from a Cisco lab.

Recommended Action If this message reoccurs, copy it exactly as it appears on the console or in the system log. Research and try to resolve the error using the Output Interpreter. Also perform a search with the Bug Toolkit. If the problem persists, contact the Cisco TAC.

218003

Error Message `%ASA-2-218003: Module Version in slot# is obsolete. The module in slot = slot# is obsolete and must be returned via RMA to Cisco Manufacturing. If it is a lab unit, it must be returned to Proto Services for upgrade.`

Explanation Obsolete hardware has been detected or the **show module** command has been run for the module. This message is generated once per minute after it first appears.

Recommended Action If this message recurs, copy it exactly as it appears on the console or in the system log. Research and try to resolve the error using the Output Interpreter. Also perform a search with the Bug Toolkit. If the problem persists, contact the Cisco TAC.

218004

Error Message `%ASA-2-218004: Failed Identification Test in slot# [fail#/res]`

Explanation Aproblem occurred while identifying hardware in the specified location.

Recommended Action If this message recurs, copy it exactly as it appears on the console or in the system log. Research and try to resolve the error using the Output Interpreter. Also perform a search with the Bug Toolkit. If the problem persists, contact the Cisco TAC.

219002

Error Message `%ASA-3-219002: I2C_API_name error, slot = slot_number, device = device_number, address = address, byte count = count. Reason: reason_string`

Explanation The I2C serial bus API has failed because of a hardware or software problem.

- *I2C_API_name*—The I2C API that failed, which can be one of the following:
  - I2C_read_byte_w_wait()
  - I2C_read_word_w_wait()
  - I2C_read_block_w_wait()
  - I2C_write_byte_w_wait()
  - I2C_write_word_w_wait()
  - I2C_write_block_w_wait()
  - I2C_read_byte_w_suspend()
  - I2C_read_word_w_suspend()
  - I2C_read_block_w_suspend()
  - I2C_write_byte_w_suspend()
  - I2C_write_word_w_suspend()
  - I2C_write_block_w_suspend()

- *slot_number*—The hexadecimal number of the slot where the I/O operation that generated the message occurred. The slot number cannot be unique to a slot in the chassis. Depending on the chassis, two different slots might have the same I2C slot number. Also, the value is not necessarily less than or equal to the number of slots. The value depends on the way the I2C hardware is wired.
- *device_number*—The hexadecimal number of the device on the slot for which the I/O operation was performed
- *address*—The hexadecimal address of the device on which the I/O operation occurred
- *byte_count*—The byte count in decimal format of the I/O operation
- *error_string*—The reason for the error, which can be one of the following:

– I2C_BUS_TRANSACTION_ERROR
– I2C_CHKSUM_ERROR
– I2C_TIMEOUT_ERROR
– I2C_BUS_COLLISION_ERROR
– I2C_HOST_BUSY_ERROR
– I2C_UNPOPULATED_ERROR
– I2C_SMBUS_UNSUPPORT
– I2C_BYTE_COUNT_ERROR
– I2C_DATA_PTR_ERROR

Recommended Action Perform the following steps:

1. Log and review the messages and the errors associated with the event. If the message does not occur continuously and disappears after a few minutes, it might be because the I2C serial bus is busy.
2. Reboot the software running on the ASA.
3. Power cycle the device. When you turn off the power, make sure that you wait several seconds before turning the power on.
4. If the problem persists, contact the Cisco TAC.

Messages 302003 to 339009

This section includes messages from 302003 to 339009.

302003

Error Message `%ASA-6-302003: Built H245 connection for foreign_address` *`outside_address/outside_port`* `local_address` *`inside_address/inside_port`*

Explanation An H.245 connection has been started from the *outside_address* to the *inside_address*. The ASA has detected the use of an Intel Internet Phone. The foreign port (*outside_port*) only appears on connections from outside the ASA. The local port value (*inside_port*) only appears on connections that were started on an internal interface.

Recommended Action None required.

302004

Error Message `%ASA-6-302004: Pre-allocate H323 UDP backconnection for foreign_address` *`outside_address/outside_port`* `to local_address` *`inside_address/inside_port`*

Explanation An H.323 UDP back connection has been preallocated to the foreign address (*outside_address)* from the local address (*inside_address)*. The ASA has detected the use of an Intel Internet Phone. The foreign port (*outside_port*) only appears on connections from outside the ASA. The local port value (*inside_port*) only appears on connections that were started on an internal interface.

Recommended Action None required.

302010

Error Message `%ASA-6-302010:` *`connections`* `in use,` *`connections`* `most used`

Explanation A TCP connection has restarted.

- *connections*—The number of connections

Recommended Action None required.

302012

Error Message `%ASA-6-302012: Pre-allocate H225 Call Signalling Connection for faddr IP_address/port to laddr IP_address`

Explanation An H.225 secondary channel has been preallocated.

Recommended Action None required.

302013

Error Message `%ASA-6-302013: Built {inbound|outbound} TCP connection_id for interface:real-address/real-port (mapped-address/mapped-port) [(idfw_user)] to interface:real-address/real-port (mapped-address/mapped-port) [(idfw_user)] [(user)]`

Explanation A TCP connection slot between two hosts was created.

- *connection_id* —A unique identifier
- *interface*, *real-address*, *real-port*—The actual sockets
- *mapped-address, mapped-port*—The mapped sockets
- *user*—The AAA name of the user
- *idfw_user*—The name of the identity firewall user

If inbound is specified, the original control connection was initiated from the outside. For example, for FTP, all data transfer channels are inbound if the original control channel is inbound. If outbound is specified, the original control connection was initiated from the inside.

Recommended Action None required.

302014

Error Message `%ASA-6-302014: Teardown TCP connection id for interface:real-address/real-port [(idfw_user)] to interface:real-address/real-port [(idfw_user)] duration hh:mm:ss bytes bytes [reason] [(user)]`

Explanation A TCP connection between two hosts was deleted. The following list describes the message values:

- *id* —A unique identifier
- *interface, real-address, real-port*—The actual socket
- *duration*—The lifetime of the connection
- *bytes*—The data transfer of the connection
- *user*—The AAA name of the user
- *idfw_user*—The name of the identity firewall user

- *reason*—The action that causes the connection to terminate. Set the *reason* variable to one of the TCP termination reasons listed in Table 1-3.

Table 1-3 TCP Termination Reasons

Reason	Description
Conn-timeout	The connection ended when a flow is closed because of the expiration of its inactivity timer.
Deny Terminate	Flow was terminated by application inspection.
Failover primary closed	The standby unit in a failover pair deleted a connection because of a message received from the active unit.
FIN Timeout	Force termination after 10 minutes awaiting the last ACK or after half-closed timeout.
Flow closed by inspection	Flow was terminated by the inspection feature.
Flow terminated by IPS	Flow was terminated by IPS.
Flow reset by IPS	Flow was reset by IPS.
Flow terminated by TCP Intercept	Flow was terminated by TCP Intercept.
Flow timed out	Flow has timed out.
Flow timed out with reset	Flow has timed out, but was reset.
Flow is a loopback	Flow is a loopback.
Free the flow created as result of packet injection	The connection was built because the packet tracer feature sent a simulated packet through the ASA.
Invalid SYN	The SYN packet was not valid.
Idle Timeout	The connection timed out because it was idle longer than the timeout value.
IPS fail-close	Flow was terminated because the IPS card is down.
No valid adjacency	This counter is incremented when the ASA tried to obtain an adjacency and could not obtain the MAC address for the next hop. The packet is dropped.
Pinhole Timeout	The counter is incremented to report that the ASA opened a secondary flow, but no packets passed through this flow within the timeout interval, and so it was removed. An example of a secondary flow is the FTP data channel that is created after successful negotiation on the FTP control channel.
Route change	When the ASA adds a lower cost (better metric) route, packets arriving that match the new route cause their existing connection to be torn down after the user-configured timeout (floating-conn) value. Subsequent packets rebuild the connection out of the interface with the better metric. To prevent the addition of lower cost routes from affecting active flows, you can set the floating-conn configuration timeout value to 0:0:0.
SYN Control	A back channel initiation occurred from the wrong side.
SYN Timeout	Force termination after 30 seconds, awaiting three-way handshake completion.
TCP bad retransmission	The connection was terminated because of a bad TCP retransmission.

Table 1-3 TCP Termination Reasons (continued)

Reason	Description
TCP FINs	A normal close-down sequence occurred. The IP address follows the reason.
TCP Invalid SYN	Invalid TCP SYN packet.
TCP Reset - APPLIANCE	The flow is closed when a TCP reset is generated by the ASA.
TCP Reset - I	Reset was from the inside.
TCP Reset - O	Reset was from the outside.
TCP segment partial overlap	A partially overlapping segment was detected.
TCP unexpected window size variation	A connection was terminated due to variation in the TCP window size.
Tunnel has been torn down	Flow was terminated because the tunnel is down.
Unauth Deny	An authorization was denied by a URL filter.
Unknown	An unknown error has occurred.
Xlate Clear	A command line was removed.

Recommended Action None required.

302015

Error Message `%ASA-6-302015: Built {inbound|outbound} UDP connection` *`number`* `for` *`interface_name`*`:`*`real_address`*`/`*`real_port`* `(`*`mapped_address`*`/`*`mapped_port`*`) [(`*`idfw_user`*`)] to` *`interface_name`*`:`*`real_address`*`/`*`real_port`* `(`*`mapped_address`*`/`*`mapped_port`*`)[(`*`idfw_user`*`)] [(`*`user`*`)]`

Explanation A UDP connection slot between two hosts was created. The following list describes the message values:

- *number*—A unique identifier
- *interface, real_address, real_port*—The actual sockets
- *mapped_address and mapped_port*—The mapped sockets
- *user*—The AAA name of the user
- *idfw_user*—The name of the identity firewall user

If inbound is specified, then the original control connection is initiated from the outside. For example, for UDP, all data transfer channels are inbound if the original control channel is inbound. If outbound is specified, then the original control connection is initiated from the inside.

Recommended Action None required.

302016

Error Message `%ASA-6-302016: Teardown UDP connection number for interface:real-address/real-port [(idfw_user)] to interface:real-address/real-port [(idfw_user)] duration hh:mm:ss bytes bytes [(user)]`

Explanation A UDP connection slot between two hosts was deleted. The following list describes the message values:

- *number*—A unique identifier
- *interface, real_address, real_port*—The actual sockets
- *time*—The lifetime of the connection
- *bytes*—The data transfer of the connection
- *id—A* unique identifier
- *interface, real-address, real-port*—The actual sockets
- *duration*—The lifetime of the connection
- *bytes*—The data transfer of the connection
- *user*—The AAA name of the user
- *idfw_user*—The name of the identity firewall user

Recommended Action None required.

302017

Error Message `%ASA-6-302017: Built {inbound|outbound} GRE connection id from interface:real_address (translated_address) [(idfw_user)] to interface:real_address/real_cid (translated_address/translated_cid) [(idfw_user)] [(user)`

Explanation A GRE connection slot between two hosts was created. The *id* is an unique identifier. The *interface, real_address, real_cid* tuple identifies the one of the two simplex PPTP GRE streams. The parenthetical *translated_address*, *translated_cid* tuple identifies the translated value with NAT.

If inbound is indicated, then the connection can only be used inbound. If outbound is indicated, then the connection can only be used for outbound. The following list describes the message values:

- *id*—Unique number identifying the connection
- *inbound*—Control connection is for inbound PPTP GRE flow
- *outbound*—Control connection is for outbound PPTP GRE flow
- *interface_name*—The interface name
- *real_address*—IP address of the actual host
- *real_cid*—Untranslated call ID for the connection
- *translated_address*—IP address after translation

- *translated_cid*—Translated call
- *user*—AAA user name
- *idfw_user*—The name of the identity firewall user

Recommended Action None required.

302018

Error Message `%ASA-6-302018: Teardown GRE connection id from interface:real_address (translated_address) [(idfw_user)] to interface:real_address/real_cid (translated_address/translated_cid) [(idfw_user)] duration hh:mm:ss bytes bytes [(user)]`

Explanation A GRE connection slot between two hosts was deleted. The *interface, real_address, real_port* tuples identify the actual sockets. *Duration* identifies the lifetime of the connection. The following list describes the message values:

- *id*—Unique number identifying the connection
- *interface*—The interface name
- *real_address*—IP address of the actual host
- *real_port*—Port number of the actual host.
- *hh:mm:ss*—Time in hour:minute:second format
- *bytes*—Number of PPP bytes transferred in the GRE session
- *reason*—Reason why the connection was terminated
- *user*—AAA user name
- *idfw_user*—The name of the identity firewall user

Recommended Action None required.

302019

Error Message `%ASA-3-302019: H.323 library_name ASN Library failed to initialize, error code number`

Explanation The specified ASN library that the ASA uses for decoding the H.323 messages failed to initialize; the ASA cannot decode or inspect the arriving H.323 packet. The ASA allows the H.323 packet to pass through without any modification. When the next H.323 message arrives, the ASA tries to initialize the library again.

Recommended Action If this message is generated consistently for a particular library, contact the Cisco TAC and provide them with all log messages (preferably with timestamps).

302020

Error Message `%ASA-6-302020: Built {in | out}bound ICMP connection for faddr {faddr | icmp_seq_num} [(idfw_user)] gaddr {gaddr | cmp_type} laddr laddr [(idfw_user)]`

Explanation An ICMP session was established in the fast-path when stateful ICMP was enabled using the **inspect icmp** command.

Recommended Action None required.

302021

Error Message `%ASA-6-302021: Teardown ICMP connection for faddr {faddr | icmp_seq_num} [(idfw_user)] gaddr {gaddr | cmp_type} laddr laddr [(idfw_user)]`

Explanation An ICMP session is removed in the fast-path when stateful ICMP is enabled using the **inspect icmp** command.

Recommended Action None required.

302033

Error Message `%ASA-6-302033:Pre-allocated H323 GUP Connection for faddr interface:foreign address/foreign-port to laddr interface:local-address/local-port`

Explanation A GUP connection was started from the foreign address to the local address. The foreign port (outside port) only appears on connections from outside the security device. The local port value (inside port) only appears on connections started on an internal interface.

- *interface*—The interface name
- *foreign-address*—IP address of the foreign host
- *foreign-port*—Port number of the foreign host
- *local-address*—IP address of the local host
- *local-port*—Port number of the local host

Recommended Action None required.

302034

Error Message `%ASA-4-302034: Unable to pre-allocate H323 GUP Connection for faddr` *interface*`:`*foreign address*`/`*foreign-port* `to laddr` *interface*`:`*local-address*`/`*local-port*

Explanation The module failed to allocate RAM system memory while starting a connection or has no more address translation slots available.

- *interface*—The interface name
- *foreign-address*—IP address of the foreign host
- *foreign-port*—Port number of the foreign host
- *local-address*—IP address of the local host
- *local-port*—Port number of the local host

Recommended Action If this message occurs periodically, it can be ignored. If it repeats frequently, contact the Cisco TAC. You can check the size of the global pool compared to the number of inside network clients. Alternatively, shorten the timeout interval of translations and connections. This message may also be caused by insufficient memory; try reducing the amount of memory usage, or purchasing additional memory.

302302

Error Message `%ASA-3-302302: ACL = deny; no sa created`

Explanation IPsec proxy mismatches have occurred. Proxy hosts for the negotiated SA correspond to a deny access-list command policy.

Recommended Action Check the **access-list** command statement in the configuration. Contact the administrator for the peer.

302303

Error Message `%ASA-6-302303: Built TCP state-bypass connection` *conn_id* `from` *initiator_interface*`:`*real_ip*`/`*real_port*`(`*mapped_ip*`/`*mapped_port*`) to` *responder_interface*`:`*real_ip*`/`*real_port* `(`*mapped_ip*`/`*mapped_port*`)`

Explanation A new TCP connection has been created, and this connection is a TCP-state-bypass connection. This type of connection bypasses all the TCP state checks and additional security checks and inspections.

Recommended Action If you need to secure TCP traffic with all the normal TCP state checks as well as all other security checks and inspections, you can use the **no set connection advanced-options tcp-state-bypass** command to disable this feature for TCP traffic.

302304

Error Message `%ASA-6-302304: Teardown TCP state-bypass connection conn_id from initiator_interface:ip/port to responder_interface:ip/port duration, bytes, teardown reason.`

Explanation A new TCP connection has been torn down, and this connection is a TCP-state-bypass connection. This type of connection bypasses all the TCP state checks and additional security checks and inspections.

- *duration*—The duration of the TCP connection
- *bytes*—The total number of bytes transmitted over the TCP connection
- *teardown reason*—The reason for the teardown of the TCP connection

Recommended Action If you need to secure TCP traffic with all the normal TCP state checks as well as all other security checks and inspections, you can use the **no set connection advanced-options tcp-state-bypass** command to disable this feature for TCP traffic.

303002

Error Message `%ASA-6-303002: FTP connection from src_ifc:src_ip/src_port to dst_ifc:dst_ip/dst_port, user username action file filename`

Explanation A client has uploaded or downloaded a file from the FTP server.

- *src_ifc*—The interface where the client resides.
- *src_ip*—The IP address of the client.
- *src_port*—The client port.
- *dst_ifc*—The interface where the server resides.
- *dst_ip*—The IP address of the FTP server.
- *dst_port*—The server port.
- *username*—The FTP username.
- *action*—The stored or retrieved actions.
- *filename*—The file stored or retrieved.

Recommended Action None required.

303004

Error Message `%ASA-5-303004: FTP cmd_string command unsupported - failed strict inspection, terminating connection from source_interface:source_address/source_port to dest_interface:dest_address/dest_interface`

Explanation Strict FTP inspection on FTP traffic has been used, and an FTP request message contains a command that is not recognized by the device.

Recommended Action None required.

303005

Error Message `%ASA-5-303005: Strict FTP inspection matched match_string in policy-map policy-name, action_string from src_ifc:sip/sport to dest_ifc:dip/dport`

Explanation When FTP inspection matches any of the following configured values: filename, file type, request command, server, or username, then the action specified by the *action_string* in this message occurs.

- *match_string*—The match clause in the policy map
- *policy-name*—The policy map that matched
- *action_string*—The action to take; for example, Reset Connection
- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port

Recommended Action None required.

304001

Error Message `%ASA-5-304001: user@source_address [(idfw_user)] Accessed URL dest_address: url.`

Explanation The specified host tried to access the specified URL.

Recommended Action None required.

304002

Error Message `%ASA-5-304002: Access denied URL chars SRC IP_address [(idfw_user)] DEST IP_address: chars`

Explanation Access from the source address to the specified URL or FTP site was denied.

Recommended Action None required.

304003

Error Message `%ASA-3-304003: URL Server IP_address timed out URL url`

Explanation A URL server timed out.

Recommended Action None required.

304004

Error Message `%ASA-6-304004: URL Server IP_address request failed URL url`

Explanation A Websense server request failed.

Recommended Action None required.

304005

Error Message `%ASA-7-304005: URL Server IP_address request pending URL url`

Explanation A Websense server request is pending.

Recommended Action None required.

304006

Error Message `%ASA-3-304006: URL Server IP_address not responding`

Explanation The Websense server is unavailable for access, and the ASA attempts to either try to access the same server if it is the only server installed, or another server if there is more than one.

Recommended Action None required.

304007

Error Message `%ASA-2-304007: URL Server IP_address not responding, ENTERING ALLOW mode.`

Explanation You used the **allow** option of the **filter** command, and the Websense servers are not responding. The ASA allows all web requests to continue without filtering while the servers are not available.

Recommended Action None required.

304008

Error Message `%ASA-2-304008: LEAVING ALLOW mode, URL Server is up.`

Explanation You used the **allow** option of the **filter** command, and the ASA receives a response message from a Websense server that previously was not responding. With this response message, the ASA exits the allow mode, which enables the URL filtering feature again.

Recommended Action None required.

304009

Error Message `%ASA-7-304009: Ran out of buffer blocks specified by url-block command`

Explanation The URL pending buffer block is running out of space.

Recommended Action Change the buffer block size by entering the **url-block block** *block_size* command.

305005

Error Message `%ASA-3-305005: No translation group found for protocol src interface_name: source_address/source_port [(idfw_user)] dst interface_name: dest_address/dest_port [(idfw_user)]`

Explanation A packet does not match any of the outbound **nat** command rules. If NAT is not configured for the specified source and destination systems, the message will be generated frequently.

Recommended Action This message indicates a configuration error. If dynamic NAT is desired for the source host, ensure that the **nat** command matches the source IP address. If static NAT is desired for the source host, ensure that the local IP address of the **static** command matches. If no NAT is desired for the source host, check the ACL bound to the NAT 0 ACL.

305006

Error Message `%ASA-3-305006: {outbound static|identity|portmap|regular) translation creation failed for` *`protocol`* `src` *`interface_name:source_address/source_port`* `[(`*`idfw_user`*`)] dst` *`interface_name:dest_address/dest_port`* `[(`*`idfw_user`*`)]`

Explanation A protocol (UDP, TCP, or ICMP) failed to create a translation through the ASA. The ASA does not allow packets through that are destined for network or broadcast addresses. The ASA provides this checking for addresses that are explicitly identified with **static** commands. For inbound traffic, the ASA denies translations for an IP address identified as a network or broadcast address.

The ASA does not apply PAT to all ICMP message types; it only applies PAT ICMP echo and echo-reply packets (types 8 and 0). Specifically, only ICMP echo or echo-reply packets create a PAT translation. As a result, when the other ICMP messages types are dropped, this message is generated.

The ASA uses the global IP address and mask from configured **static** commands to differentiate regular IP addresses from network or broadcast IP addresses. If the global IP address is a valid network address with a matching network mask, then the ASA does not create a translation for network or broadcast IP addresses with inbound packets.

For example:

```
static (inside,outside) 10.2.2.128 10.1.1.128 netmask 255.255.255.128
```

The ASA responds to global address 10.2.2.128 as a network address and to 10.2.2.255 as the broadcast address. Without an existing translation, the ASA denies inbound packets destined for 10.2.2.128 or 10.2.2.255, and logs this message.

When the suspected IP address is a host IP address, configure a separate **static** command with a host mask in front of the subnet **static** command (the first match rule for **static** commands). The following **static** commands cause the ASA to respond to 10.2.2.128 as a host address:

```
static (inside,outside) 10.2.2.128 10.2.2.128 netmask 255.255.255.255
static (inside,outside) 10.2.2.128 10.2.2.128 netmask 255.255.255.128
```

The translation may be created by traffic started from the inside host with the IP address in question. Because the ASA views a network or broadcast IP address as a host IP address with an overlapped subnet static configuration, the network address translation for both **static** commands must be the same.

Recommended Action None required.

305007

Error Message `%ASA-6-305007: addrpool_free(): Orphan IP` *`IP_address`* `on interface` *`interface_number`*

Explanation The ASA has attempted to translate an address that it cannot find in any of its global pools. The ASA assumes that the address was deleted and drops the request.

Recommended Action None required.

305008

Error Message `%ASA-3-305008: Free unallocated global IP address.`

Explanation The ASA kernel detected an inconsistency condition when trying to free an unallocated global IP address back to the address pool. This abnormal condition may occur if the ASA is running a Stateful Failover setup, and some of the internal states are momentarily out of sync between the active unit and the standby unit. This condition is not catastrophic, and the synchronization recovers automatically.

Recommended Action If the problem persists, contact the Cisco TAC.

305009

Error Message `%ASA-6-305009: Built {dynamic|static} translation from interface_name [(acl-name)]:real_address [(idfw_user)] to interface_name:mapped_address`

Explanation An address translation slot was created. The slot translates the source address from the local side to the global side. In reverse, the slot translates the destination address from the global side to the local side.

Recommended Action None required.

305010

Error Message `%ASA-6-305010: Teardown {dynamic|static} translation from interface_name:real_address [(idfw_user)] to interface_name:mapped_address duration time`

Explanation The address translation slot was deleted.

Recommended Action None required.

305011

Error Message `%ASA-6-305011: Built {dynamic|static} {TCP|UDP|ICMP} translation from interface_name:real_address/real_port [(idfw_user)] to interface_name:mapped_address/mapped_port`

Explanation A TCP, UDP, or ICMP address translation slot was created. The slot translates the source socket from the local side to the global side. In reverse, the slot translates the destination socket from the global side to the local side.

Recommended Action None required.

305012

Error Message `%ASA-6-305012: Teardown {dynamic|static} {TCP|UDP|ICMP} translation from interface_name [(acl-name)]:real_address/{real_port|real_ICMP_ID} [(idfw_user)] to interface_name:mapped_address/{mapped_port|mapped_ICMP_ID} duration time`

Explanation The address translation slot was deleted.

Recommended Action None required.

305013

Error Message `%ASA-5-305013: Asymmetric NAT rules matched for forward and reverse flows; Connection protocol src interface_name:source_address/source_port [(idfw_user)] dst interface_name:dst_address/dst_port [(idfw_user)] denied due to NAT reverse path failure.`

Explanation An attempt to connect to a mapped host using its actual address was rejected.

Recommended Action When not on the same interface as the host using NAT, use the mapped address instead of the actual address to connect to the host. In addition, enable the **inspect** command if the application embeds the IP address.

308001

Error Message `%ASA-6-308001: console enable password incorrect for number tries (from IP_address)`

Explanation This is a ASA management message. This message appears after the specified number of times a user incorrectly types the password to enter privileged mode. The maximum is three attempts.

Recommended Action Verify the password and try again.

308002

Error Message `%ASA-4-308002: static global_address inside_address netmask netmask overlapped with global_address inside_address`

Explanation The IP addresses in one or more **static** command statements overlap. *global_address* is the global address, which is the address on the lower security interface, and *inside_address* is the local address, which is the address on the higher security-level interface.

Recommended Action Use the **show static** command to view the **static** command statements in your configuration and fix the commands that overlap. The most common overlap occurs if you specify a network address such as 10.1.1.0, and in another **static** command you specify a host within that range, such as 10.1.1.5.

311001

Error Message `%ASA-6-311001: LU loading standby start`

Explanation Stateful Failover update information was sent to the standby ASA when the standby ASA is first to be online.

Recommended Action None required.

311002

Error Message `%ASA-6-311002: LU loading standby end`

Explanation Stateful Failover update information stopped sending to the standby ASA.

Recommended Action None required.

311003

Error Message `%ASA-6-311003: LU recv thread up`

Explanation An update acknowledgment was received from the standby ASA.

Recommended Action None required.

311004

Error Message `%ASA-6-311004: LU xmit thread up`

Explanation A Stateful Failover update was transmitted to the standby ASA.

Recommended Action None required.

312001

Error Message `%ASA-6-312001: RIP hdr failed from IP_address: cmd=string, version=number domain=string on interface interface_name`

Explanation The ASA received a RIP message with an operation code other than reply, the message has a version number different from what is expected on this interface, and the routing domain entry was nonzero. Another RIP device may not be configured correctly to communicate with the ASA.

Recommended Action None required.

313001

Error Message `%ASA-3-313001: Denied ICMP type=number, code=code from IP_address on interface interface_name`

Explanation When using the **icmp** command with an access list, if the first matched entry is a permit entry, the ICMP packet continues processing. If the first matched entry is a deny entry, or an entry is not matched, the ASA discards the ICMP packet and generates this message. The **icmp** command enables or disables pinging to an interface. With pinging disabled, the ASA cannot be detected on the network. This feature is also referred to as configurable proxy pinging.

Recommended Action Contact the administrator of the peer device.

313004

Error Message `%ASA-4-313004:Denied ICMP type=icmp_type, from source_address on interface interface_name to dest_address:no matching session`

Explanation ICMP packets were dropped by the ASA because of security checks added by the stateful ICMP feature that are usually either ICMP echo replies without a valid echo request already passed across the ASA or ICMP error messages not related to any TCP, UDP, or ICMP session already established in the ASA.

Recommended Action None required.

313005

Error Message %ASA-4-313005: No matching connection for ICMP error message: *icmp_msg_info* on *interface_name* interface. Original IP payload: *embedded_frame_info icmp_msg_info* = icmp *src src_interface_name*:*src_address* [([*idfw_user* | *FQDN_string*], *sg_info*)] *dst dest_interface_name*:*dest_address* [([*idfw_user* | *FQDN_string*], *sg_info*)] (type *icmp_type*, code *icmp_code*) *embedded_frame_info* = prot *src source_address*/*source_port* [([*idfw_user* | *FQDN_string*], *sg_info*)] *dst dest_address*/*dest_port* [(*idfw_user*|*FQDN_string*), *sg_info*]

Explanation ICMP error packets were dropped by the ASA because the ICMP error messages are not related to any session already established in the ASA.

Recommended Action If the cause is an attack, you can deny the host by using ACLs.

313008

Error Message %ASA-3-313008: Denied ICMPv6 type=*number*, code=*code* from *IP_address* on interface *interface_name*

Explanation When using the **icmp** command with an access list, if the first matched entry is a permit entry, the ICMPv6 packet continues processing. If the first matched entry is a deny entry, or an entry is not matched, the ASA discards the ICMPv6 packet and generates this message.

The **icmp** command enables or disables pinging to an interface. When pinging is disabled, the ASA is undetectable on the network. This feature is also referred to as "configurable proxy pinging."

Recommended Action Contact the administrator of the peer device.

313009

Error Message %ASA-4-313009: Denied invalid ICMP code *icmp-code*, for *src-ifc*:*src-address*/*src-port* (mapped-src-address/mapped-src-port) to *dest-ifc*:*dest-address*/*dest-port* (mapped-dest-address/mapped-dest-port) [*user*], ICMP id *icmp-id*, ICMP type *icmp-type*

Explanation An ICMP echo request/reply packet was received with a malformed code(non-zero).

Recommended Action If it is an intermittent event, no action is required. If the cause is an attack, you can deny the host using the ACLs.

314001

Error Message `%ASA-6-314001: Pre-allocated RTSP UDP backconnection for src_intf:src_IP to dst_intf:dst_IP/dst_port.`

Explanation The ASA opened a UDP media channel for the RTSP client that was receiving data from the server.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *dst_intf*—Destination interface name
- *dst_IP*—Destination IP address
- *dst_port*—Destination port

Recommended Action None required.

314002

Error Message `%ASA-6-314002: RTSP failed to allocate UDP media connection from src_intf:src_IP to dst_intf:dst_IP/dst_port: reason_string.`

Explanation The ASA cannot open a new pinhole for the media channel.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *dst_intf*—Destination interface name
- *dst_IP*—Destination IP address
- *dst_port*—Destination port
- *reason_string*—Pinhole already exists/Unknown

Recommended Action If the reason is unknown, check the free memory available by running the **show memory** command, or the number of connections used by running the **show conn** command, because the ASA is low on memory.

314003

Error Message `%ASA-6-314003: Dropped RTSP traffic from src_intf:src_ip due to: reason.`

Explanation The RTSP message violated the user-configured RTSP security policy, either because it contains a port from the reserve port range, or it contains a URL with a length greater than the maximum limit allowed.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *reason*—The reasons may be one of the following:

- Endpoint negotiating media ports in the reserved port range from 0 to 1024
- URL length of *url length* bytes exceeds the maximum *url length limit* bytes

Recommended Action Investigate why the RTSP client sends messages that violate the security policy. If the requested URL is legitimate, you can relax the policy by specifying a longer URL length limit in the RTSP policy map.

314004

Error Message `%ASA-6-314004: RTSP client src_intf:src_IP accessed RTSP URL RTSP URL`

Explanation An RTSP client tried to access an RTSP server.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *RTSP URL*—RTSP server URL

Recommended Action None required.

314005

Error Message `%ASA-6-314005: RTSP client src_intf:src_IP denied access to URL RTSP_URL.`

Explanation An RTSP client tried to access a prohibited site.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *RTSP_URL*—RTSP server URL

Recommended Action None required.

314006

Error Message `%ASA-6-314006: RTSP client src_intf:src_IP exceeds configured rate limit of rate for request_method messages.`

Explanation A specific RTSP request message exceeded the configured rate limit of RTSP policy.

- *src_intf*—Source interface name
- *src_IP*—Source interface IP address
- *rate*—Configured rate limit

- *request_method*—Type of request message

Recommended Action Investigate why the specific RTSP request message from the client exceeded the rate limit.

315004

Error Message `%ASA-3-315004: Fail to establish SSH session because RSA host key retrieval failed.`

Explanation The ASA cannot find the RSA host key, which is required for establishing an SSH session. The ASA host key may be absent because it was not generated or because the license for this ASA does not allow DES or 3DES encryption.

Recommended Action From the ASA console, enter the **show crypto key mypubkey rsa** command to verify that the RSA host key is present. If the host key is not present, enter the **show version** command to verify that DES or 3DES is allowed. If an RSA host key is present, restart the SSH session. To generate the RSA host key, enter the **crypto key mypubkey rsa** command.

315011

Error Message `%ASA-6-315011: SSH session from IP_address on interface interface_name for user user disconnected by SSH server, reason: reason`

Explanation An SSH session has ended. If a user enters **quit** or **exit**, the **terminated normally** message appears. If the session disconnected for another reason, the text describes the reason. Table 1-4 lists the possible reasons why a session disconnected.

Table 1-4 SSH Disconnect Reasons

Text String	Explanation	Action
Bad checkbytes	A mismatch was detected in the check bytes during an SSH key exchange.	Restart the SSH session.
CRC check failed	The CRC value computed for a particular packet does not match the CRC value embedded in the packet; the packet is bad.	None required. If this message persists, call Cisco TAC.
Decryption failure	Decryption of an SSH session key failed during an SSH key exchange.	Check the RSA host key and try again.
Format error	A nonprotocol version message was received during an SSH version exchange.	Check the SSH client, to ensure it is a supported version.
Internal error	This message indicates either an error internal to SSH on the ASA or an RSA key may not have been entered on the ASA or cannot be retrieved.	From the ASA console, enter the **show crypto key mypubkey rsa** command to verify that the RSA host key is present. If the host key is not present, enter the **show version** command to verify that DES or 3DES is allowed. If an RSA host key is present, restart the SSH session. To generate the RSA host key, enter the **crypto key mypubkey rsa** command.
Invalid cipher type	The SSH client requested an unsupported cipher.	Enter the **show version** command to determine which features your license supports, then reconfigure the SSH client to use the supported cipher.
Invalid message length	The length of SSH message arriving at the ASA exceeds 262,144 bytes or is shorter than 4096 bytes. The data may be corrupted.	None required.
Invalid message type	The ASA received a non-SSH message, or an unsupported or unwanted SSH message.	Check whether the peer is an SSH client. If it is a client supporting SSHv1, and this message persists, from the ASA serial console enter the **debug ssh** command and capture the debugging messages. Then contact the Cisco TAC.

Table 1-4 SSH Disconnect Reasons (continued)

Text String	Explanation	Action
Out of memory	This message appears when the ASA cannot allocate memory for use by the SSH server, probably when the ASA is busy with high traffic.	Restart the SSH session later.
Rejected by server	User authentication failed.	Ask the user to verify username and password.
Reset by client	An SSH client sent the SSH_MSG_DISCONNECT message to the ASA.	None required.
status code: *hex* (*hex*)	Users closed the SSH client window (running on Windows) instead of entering **quit** or **exit** at the SSH console.	None required. Encourage users to exit the client gracefully instead of just exiting.
Terminated by operator	The SSH session was terminated by entering the **ssh disconnect** command at the ASA console.	None required.
Time-out activated	The SSH session timed out because the duration specified by the **ssh timeout** command was exceeded.	Restart the SSH connection. You can use the **ssh timeout** command to increase the default value of 5 minutes up to 60 minutes if required.

Recommended Action None required.

316001

Error Message `%ASA-3-316001: Denied new tunnel to IP_address. VPN peer limit (platform_vpn_peer_limit) exceeded`

Explanation If more VPN tunnels (ISAKMP/IPsec) are concurrently trying to be established than are supported by the platform VPN peer limit, then the excess tunnels are aborted.

Recommended Action None required.

316002

Error Message `%ASA-3-316002: VPN Handle error: protocol=protocol, src in_if_num:src_addr, dst out_if_num:dst_addr`

Explanation The ASA cannot create a VPN handle, because the VPN handle already exists.

- *protocol*—The protocol of the VPN flow
- *in_if_num*—The ingress interface number of the VPN flow
- *src_addr*—The source IP address of the VPN flow

- *out_if_num*—The egress interface number of the VPN flow
- *dst_addr*—The destination IP address of the VPN flow

Recommended Action This message may occur during normal operation; however, if the message occurs repeatedly and a major malfunction of VPN-based applications occurs, a software defect may be the cause. Enter the following commands to collect more information and contact the Cisco TAC to investigate the issue further:

```
capture name type asp-drop vpn-handle-error
show asp table classify crypto detail
show asp table vpn-context
```

317001

Error Message `%ASA-3-317001: No memory available for limit_slow`

Explanation The requested operation failed because of a low-memory condition.

Recommended Action Reduce other system activity to ease memory demands. If conditions warrant, upgrade to a larger memory configuration.

317002

Error Message `%ASA-3-317002: Bad path index of number for IP_address, number max`

Explanation A software error occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

317003

Error Message `%ASA-3-317003: IP routing table creation failure - reason`

Explanation An internal software error occurred, which prevented the creation of a new IP routing table.

Recommended Action Copy the message exactly as it appears, and report it to Cisco TAC.

317004

Error Message `%ASA-3-317004: IP routing table limit warning`

Explanation The number of routes in the named IP routing table has reached the configured warning limit.

Recommended Action Reduce the number of routes in the table, or reconfigure the limit.

317005

Error Message `%ASA-3-317005: IP routing table limit exceeded - reason, IP_address netmask`

Explanation Additional routes will be added to the table.

Recommended Action Reduce the number of routes in the table, or reconfigure the limit.

317006

Error Message `%ASA-3-317006: Pdb index error pdb, pdb_index, pdb_type`

Explanation The index into the PDB is out of range.

- *pdb*—Protocol Descriptor Block, the descriptor of the PDB index error
- *pdb_index*—The PDB index identifier
- *pdb_type*—The type of the PDB index error

Recommended Action If the problem persists, copy the error message exactly as it appears on the console or in the system log, contact the Cisco TAC, and provide the representative with the collected information.

317007

Error Message `%ASA-6-317007: Added route_type route dest_address netmask via gateway_address [distance/metric] on interface_name route_type`

Explanation A new route has been added to the routing table.

Routing protocol type:

C – connected, S – static, I – IGRP, R – RIP, M – mobile

B – BGP, D – EIGRP, EX - EIGRP external, O - OSPF

IA - OSPF inter area, N1 - OSPF NSSA external type 1

N2 - OSPF NSSA external type 2, E1 - OSPF external type 1

E2 - OSPF external type 2, E – EGP, i - IS-IS, L1 - IS-IS level-1

L2 - IS-IS level-2, ia - IS-IS inter area

- *dest_address*—The destination network for this route
- *netmask*—The netmask for the destination network
- *gateway_address*—The address of the gateway by which the destination network is reached
- *distance*—Administrative distance for this route
- *metric*—Metric for this route
- *interface_name*—Network interface name through which the traffic is routed

Recommended Action None required.

317008

Error Message `%ASA-6-317007: Deleted route_type route dest_address netmask via gateway_address [distance/metric] on interface_name route_type`

Explanation A new route has been deleted from the routing table.

Routing protocol type:

C – connected, S – static, I – IGRP, R – RIP, M – mobile

B – BGP, D – EIGRP, EX - EIGRP external, O - OSPF

IA - OSPF inter area, N1 - OSPF NSSA external type 1

N2 - OSPF NSSA external type 2, E1 - OSPF external type 1

E2 - OSPF external type 2, E – EGP, i - IS-IS, L1 - IS-IS level-1

L2 - IS-IS level-2, ia - IS-IS inter area

- *dest_address*—The destination network for this route
- *netmask*—The netmask for the destination network
- *gateway_address*—The address of the gateway by which the destination network is reached
- *distance*—Administrative distance for this route
- *metric*—Metric for this route
- *interface_name*—Network interface name through which the traffic is routed

Recommended Action None required.

318001

Error Message `%ASA-3-318001: Internal error: reason`

Explanation An internal software error occurred. This message occurs at five-second intervals.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

318002

Error Message `%ASA-3-318002: Flagged as being an ABR without a backbone area`

Explanation The router was flagged as an area border router without a backbone area configured in the router. This message occurs at five-second intervals.

Recommended Action Restart the OSPF process.

318003

Error Message `%ASA-3-318003: Reached unknown state in neighbor state machine`

Explanation An internal software error occurred. This message occurs at five-second intervals.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

318004

Error Message `%ASA-3-318004: area` *`string`* `lsid` *`IP_address`* `mask` *`netmask`* `adv IP_address type` *`number`*

Explanation The OSPF process had a problem locating the link state advertisement, which might lead to a memory leak.

Recommended Action If the problem persists, contact the Cisco TAC.

318005

Error Message `%ASA-3-318005: lsid` *`ip_address`* `adv` *`IP_address`* `type` *`number`* `gateway` *`gateway_address`* `metric` *`number`* `network` *`IP_address`* `mask` *`netmask`* `protocol` *`hex`* `attr` *`hex`* `net-metric` *`number`*

Explanation OSPF found an inconsistency between its database and the IP routing table.

Recommended Action If the problem persists, contact the Cisco TAC.

318006

Error Message `%ASA-3-318006: if` *`interface_name`* `if_state` *`number`*

Explanation An internal error occurred.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

318007

Error Message `%ASA-3-318007: OSPF is enabled on interface_name during idb initialization`

Explanation An internal error occurred.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

318008

Error Message `%ASA-3-318008: OSPF process number is changing router-id. Reconfigure virtual link neighbors with our new router-id`

Explanation The OSPF process is being reset, and it is going to select a new router ID. This action will bring down all virtual links.

Recommended Action Change the virtual link configuration on all of the virtual link neighbors to reflect the new router ID.

318009

Error Message `%ASA-3-318009: OSPF: Attempted reference of stale data encountered in function, line: line_num`

Explanation OSPF is running and has tried to reference some related data structures that have been removed elsewhere. Clearing interface and router configurations may resolve the problem. However, if this message appears, some sequence of steps caused premature deletion of data structures and this needs to be investigated.

- *function*—The function that received the unexpected event
- *line_num* —Line number in the code

Recommended Action If the problem persists, contact the Cisco TAC.

318101

Error Message `%ASA-3-318101: Internal error: REASON`

Explanation An internal software error has occurred.

- *REASON*—The detailed cause of the event

Recommended Action None required.

318102

Error Message `%ASA-3-318102: Flagged as being an ABR without a backbone area`

Explanation The router was flagged as an Area Border Router (ABR) without a backbone area in the router.

Recommended Action Restart the OSPF process.

318103

Error Message `%ASA-3-318103: Reached unknown state in neighbor state machine`

Explanation An internal software error has occurred.

Recommended Action None required.

318104

Error Message `%ASA-3-318104: DB already exist: area AREA_ID_STR lsid i adv i type 0x x`

Explanation OSPF has a problem locating the LSA, which could lead to a memory leak.

- *AREA_ID_STR*—A string representing the area
- *i*—An integer value
- *x*—A hexadecimal representation of an integer value

Recommended Action None required.

318105

Error Message `%ASA-3-318105: lsid i adv i type 0x x gateway i metric d network i mask i protocol #x attr #x net-metric d`

Explanation OSPF found an inconsistency between its database and the IP routing table.

- *i*—An integer value
- *x*—A hexadecimal representation of an integer value
- *d*—A number

Recommended Action None required.

318106

Error Message `%ASA-3-318106: if IF_NAME if_state d`

Explanation An internal error has occurred.

- *IF_NAME*—The name of the affected interface
- *d*—A number

Recommended Action None required.

318107

Error Message `%ASA-3-318107: OSPF is enabled on IF_NAME during idb initialization`

Explanation An internal error has occurred.

- *IF_NAME*—The name of the affected interface

Recommended Action None required.

318108

Error Message `%ASA-3-318108: OSPF process d is changing router-id. Reconfigure virtual link neighbors with our new router-id`

Explanation The OSPF process is being reset, and it is going to select a new router ID, which brings down all virtual links. To make them work again, you need to change the virtual link configuration on all virtual link neighbors.

- *d*—A number representing the process ID

Recommended Action Change the virtual link configuration on all the virtual link neighbors to include the new router ID.

318109

Error Message `%ASA-3-318109: OSPFv3 has received an unexpected message: 0x / 0x`

Explanation OSPFv3 has received an unexpected interprocess message.

- *x*—A hexadecimal representation of an integer value

Recommended Action None required.

318110

Error Message `%ASA-3-318110: Invalid encrypted key s.`

Explanation The specified encrypted key is not valid.

- *s*—A string representing the encrypted key

Recommended Action Either specify a clear text key and enter the **service password-encryption** command for encryption, or ensure that the specified encrypted key is valid. If the specified encrypted key is not valid, an error message appears during system configuration.

318111

Error Message `%ASA-3-318111: SPI u is already in use with ospf process d`

Explanation An attempt was made to use a SPI that has already been used.

- *u*—A number representing the SPI
- *d*—A number representing the process ID

Recommended Action Choose a different SPI.

318112

Error Message `%ASA-3-318112: SPI u is already in use by a process other than ospf process d.`

Explanation An attempt was made to use a SPI that has already been used.

- *u*—A number representing the SPI
- *d*—A number representing the process ID

Recommended Action Choose a different SPI. Enter the **show crypto ipv6 ipsec sa** command to view a list of SPIs that are already being used.

318113

Error Message `%ASA-3-318113: s s is already configured with SPI u.`

Explanation An attempt was made to use a SPI that has already been used.

- *s*—A string representing an interface
- *u*—A number representing the SPI

Recommended Action Unconfigure the SPI first, or choose a different one.

318114

Error Message `%ASA-3-318114: The key length used with SPI u is not valid`

Explanation The key length was incorrect.

- *u*—A number representing the SPI

Recommended Action Choose a valid IPsec key. An IPsec authentication key must be 32 (MD5) or 40 (SHA-1) hexidecimal digits long.

318115

Error Message `%ASA-3-318115: s error occured when attempting to create an IPsec policy for SPI u`

Explanation An IPsec API (internal) error has occurred.

- *s*—A string representing the error
- *u*—A number representing the SPI

Recommended Action None required.

318116

Error Message `%ASA-3-318116: SPI u is not being used by ospf process d.`

Explanation An attempt was made to unconfigure a SPI that is not being used with OSPFv3.

- *u*—A number representing the SPI
- *d*—A number representing the process ID

Recommended Action Enter a **show** command to see which SPIs are used by OSPFv3.

318117

Error Message `%ASA-3-318117: The policy for SPI u could not be removed because it is in use.`

Explanation An attempt was made to remove the policy for the indicated SPI, but the policy was still being used by a secure socket.

- *u*—A number representing the SPI

Recommended Action None required.

318118

Error Message `%ASA-3-318118: s error occured when attemtping to remove the IPsec policy with SPI u`

Explanation An IPsec API (internal) error has occurred.

- *s*—A string representing the specified error
- *u*—A number representing the SPI

Recommended Action None required.

318119

Error Message `%ASA-3-318119: Unable to close secure socket with SPI u on interface s`

Explanation An IPsec API (internal) error has occurred.

- *u*—A number representing the SPI
- *s*—A string representing the specified interface

Recommended Action None required.

318120

Error Message `%ASA-3-318120: OSPFv3 was unable to register with IPsec`

Explanation An internal error has occurred.

Recommended Action None required.

318121

Error Message `%ASA-3-318121: IPsec reported a GENERAL ERROR: message s, count d`

Explanation An internal error has occurred.

- *s*—A string representing the specified message
- *d*—A number representing the total number of generated messages

Recommended Action None required.

318122

Error Message `%ASA-3-318122: IPsec sent a s message s to OSPFv3 for interface s. Recovery attempt d`

Explanation An internal error has occurred. The system is trying to reopen the secure socket and to recover.

- *s*—A string representing the specified message and specified interface
- *d*—A number representing the total number of recovery attempts

Recommended Action None required.

318123

Error Message `%ASA-3-318123: IPsec sent a s message s to OSPFv3 for interface IF_NAME. Recovery aborted`

Explanation An internal error has occurred. The maximum number of recovery attempts has been exceeded.

- *s*—A string representing the specified message
- *IF_NAME*—The specified interface

Recommended Action None required.

318125

Error Message `%ASA-3-318125: Init failed for interface IF_NAME`

Explanation The interface initialization failed. Possible reasons include the following:

- The area to which the interface is being attached is being deleted.
- It was not possible to create the link scope database.
- It was not possible to create a neighbor datablock for the local router.

Recommended Action Remove the configuration command that initializes the interface and then try it again.

318126

Error Message `%ASA-3-318126: Interface IF_NAME is attached to more than one area`

Explanation The interface is on the interface list for an area other than the one to which the interface links.

- *IF_NAME*—The specified interface

Recommended Action None required.

318127

Error Message `%ASA-3-318127: Could not allocate or find the neighbor`

Explanation An internal error has occurred.

Recommended Action None required.

319001

Error Message `%ASA-3-319001: Acknowledge for arp update for IP address dest_address not received (number).`

Explanation The ARP process in the ASA lost internal synchronization because the ASA was overloaded.

Recommended Action None required. The failure is only temporary. Check the average load of the ASA and make sure that it is not used beyond its capabilities.

319002

Error Message `%ASA-3-319002: Acknowledge for route update for IP address dest_address not received (number).`

Explanation The routing module in the ASA lost internal synchronization because the ASA was overloaded.

Recommended Action None required. The failure is only temporary. Check the average load of the ASA and make sure that it is not used beyond its capabilities.

319003

Error Message `%ASA-3-319003: Arp update for IP address address to NPn failed.`

Explanation When an ARP entry has to be updated, a message is sent to the network processor (NP) in order to update the internal ARP table. If the module is experiencing high utilization of memory or if the internal table is full, the message to the NP may be rejected and this message generated.

Recommended Action Verify if the ARP table is full. If it is not full, check the load of the module by reviewing the CPU utilization and connections per second. If CPU utilization is high and/or there is a large number of connections per second, normal operations will resume when the load returns to normal.

319004

Error Message `%ASA-3-319004: Route update for IP address dest_address failed (number).`

Explanation The routing module in the ASA lost internal synchronization because the system was overloaded.

Recommended Action None required. The failure is only temporary. Check the average load of the system and make sure that it is not used beyond its capabilities.

320001

Error Message `%ASA-3-320001: The subject name of the peer cert is not allowed for connection`

Explanation When the ASA is an easy VPN remote device or server, the peer certificate includes asubject name that does not match the output of the **ca verifycertdn** command. A man-in-the-middle attack might be occurring, where a device spoofs the peer IP address and tries to intercept a VPN connection from the ASA.

Recommended Action None required.

321001

Error Message `%ASA-5-321001: Resource var1 limit of var2 reached.`

Explanation A configured resource usage or rate limit for the indicated resource was reached.

Recommended Action None required.

321002

Error Message `%ASA-5-321002: Resource var1 rate limit of var2 reached.`

Explanation A configured resource usage or rate limit for the indicated resource was reached.

Recommended Action None required.

321003

Error Message `%ASA-6-321003: Resource var1 log level of var2 reached.`

Explanation A configured resource usage or rate logging level for the indicated resource was reached.

Recommended Action None required.

321004

Error Message `%ASA-6-321004: Resource var1 rate log level of var2 reached`

Explanation A configured resource usage or rate logging level for the indicated resource was reached.

Recommended Action None required.

321005

Error Message `%ASA-2-321005: System CPU utilization reached utilization %`

Explanation The system CPU utilization has reached 95 percent or more and remains at this level for five minutes.

- *utilization %*—The percentage of CPU being used

Recommended Action If this message occurs periodically, you can ignore it. If it repeats frequently, check the output of the **show cpu** command and verify the CPU usage. If it is high, contact the Cisco TAC.

321006

Error Message `%ASA-2-321006: System memory usage reached utilization %`

Explanation The system memory usage has reached 80 percent or more and remains at this level for five minutes.

- *utilization %*—The percentage of CPU being used

Recommended Action If this message occurs periodically, you can ignore it. If it repeats frequently, check the output of the **show memory** command and verify the memory usage. If it is high, contact the Cisco TAC.

321007

Error Message `%ASA-3-321007: System is low on free memory blocks of size block_size (free_blocks CNT out of max_blocks MAX)`

Explanation The system is low on free blocks of memory. Running out of blocks may result in traffic disruption.

- *block_size*—The block size of memory (for example, 4, 1550, 8192)
- *free_blocks*—The number of free blocks, as shown in the CNT column after using the **show blocks** command
- *max_blocks*—The maximum number of blocks that the system can allocate, as shown in the MAX column after using the **show blocks** command

Recommended Action Use the **show blocks** command to monitor the amount of free blocks in the CNT column of the output for the indicated block size. If the CNT column remains zero, or very close to it for an extended period of time, then the ASA may be overloaded or running into another issue that needs additional investigation.

322001

Error Message `%ASA-3-322001: Deny MAC address MAC_address, possible spoof attempt on interface interface`

Explanation The ASA received a packet from the offending MAC address on the specified interface, but the source MAC address in the packet is statically bound to another interface in the configuration. Either a MAC-spoofing attack or a misconfiguration may be the cause.

Recommended Action Check the configuration and take appropriate action by either finding the offending host or correcting the configuration.

322002

Error Message `%ASA-3-322002: ARP inspection check failed for arp {request|response} received from host MAC_address on interface interface. This host is advertising MAC Address MAC_address_1 for IP Address IP_address, which is {statically|dynamically} bound to MAC Address MAC_address_2.`

Explanation If the ARP inspection module is enabled, it checks whether a new ARP entry advertised in the packet conforms to the statically configured or dynamically learned IP-MAC address binding before forwarding ARP packets across the ASA. If this check fails, the ARP inspection module drops the ARP packet and generates this message. This situation may be caused by either ARP spoofing attacks in the network or an invalid configuration (IP-MAC binding).

Recommended Action If the cause is an attack, you can deny the host using the ACLs. If the cause is an invalid configuration, correct the binding.

322003

Error Message `%ASA-3-322003:ARP inspection check failed for arp {request|response} received from host MAC_address on interface interface. This host is advertising MAC Address MAC_address_1 for IP Address IP_address, which is not bound to any MAC Address.`

Explanation If the ARP inspection module is enabled, it checks whether a new ARP entry advertised in the packet conforms to the statically configured IP-MAC address binding before forwarding ARP packets across the ASA. If this check fails, the ARP inspection module drops the ARP packet and generates this message. This situation may be caused by either ARP spoofing attacks in the network or an invalid configuration (IP-MAC binding).

Recommended Action If the cause is an attack, you can deny the host using the ACLs. If the cause is an invalid configuration, correct the binding.

322004

Error Message `%ASA-6-322004: No management IP address configured for transparent firewall. Dropping protocol protocol packet from interface_in:source_address/source_port to interface_out:dest_address/dest_port`

Explanation The ASA dropped a packet because no management IP address was configured in the transparent mode.

- *protocol*—Protocol string or value
- *interface_in*—Input interface name
- *source_address*—Source IP address of the packet
- *source_port*—Source port of the packet
- *interface_out*—Output interface name
- *dest_address*—Destination IP address of the packet

- *dest_port*—Destination port of the packet

Recommended Action Configure the device with the management IP address and mask values.

323001

Error Message `%ASA-3-323001: Module module_id experienced a control channel communications failure.`

Error Message `%ASA-3-323001: Module in slot slot_num experienced a control channel communications failure.`

Explanation The ASA is unable to communicate via control channel with the module installed (in the specified slot).

- *module_id*—For a software services module, specifies the services module name.
- *slot_num*—For a hardware services module, specifies the slot in which the failure occurred. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.

Recommended Action If the problem persists, contact the Cisco TAC.

323002

Error Message `%ASA-3-323002: Module module_id is not able to shut down, shut down request not answered.`

Error Message `%ASA-3-323002: Module in slot slot_num is not able to shut down, shut down request not answered.`

Explanation The module installed did not respond to a shutdown request.

- *module_id*—For a software services module, specifies the service module name.
- *slot_num*—For a hardware services module, specifies the slot in which the failure occurred. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.

Recommended Action If the problem persists, contact the Cisco TAC.

323003

Error Message `%ASA-3-323003: Module module_id is not able to reload, reload request not answered.`

Error Message `%ASA-3-323003: Module in slot slotnum is not able to reload, reload request not answered.`

Explanation The module installed did not respond to a reload request.

- *module_id*—For a software services module, specifies the service module name.
- *slot_num*—For a hardware services module, specifies the slot in which the failure occurred. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.

Recommended Action If the problem persists, contact the Cisco TAC.

323004

Error Message `%ASA-3-323004: Module string one failed to write software newver (currently ver), reason. Hw-module reset is required before further use.`

Explanation The module failed to accept a software version, and will be transitioned to an UNRESPONSIVE state. The module is not usable until the software is updated.

- *string one*—The text string that specifies the module
- *newver*—The new version number of software that was not successfully written to the module (for example, 1.0(1)0)
- *ver*—The current version number of the software on the module (for example, 1.0(1)0)
- *reason*—The reason the new version cannot be written to the module. The possible values for *reason* include the following:

  - write failure

  - failed to create a thread to write the image

Recommended Action If the module software cannot be updated, it will not be usable. If the problem persists, contact the Cisco TAC.

323005

Error Message `%ASA-3-323005: Module module_id can not be started completely`

Error Message `%ASA-3-323005: Module in slot slot_num can not be started completely`

Explanation This message indicates that the module can not be started completely. The module will remain in the UNRESPONSIVE state until this condition is corrected. A module that is not fully seated in the slot is the most likely cause.

- *module_id*—For a software services module, specifies the service module name.
- *slot_num*—For a hardware services module, specifies the slot number that contains the module.

Recommended Action Verify that the module is fully seated and check to see if any status LEDs on the module are on. It may take a minute after fully reseating the module for the ASA to recognize that it is powered up. If this message appears after verifying that the module is seated and after resetting the module using either the **sw-module module** *service-module-name* **reset** command or the **hw-module module** *slotnum* **reset** command, contact the Cisco TAC.

323006

Error Message `%ASA-1-323006: Module ips experienced a data channel communication failure, data channel is DOWN.`

Explanation A data channel communication failure occurred and the ASA was unable to forward traffic to the services module. This failure triggers a failover when the failure occurs on the active ASA in an HA configuration. The failure also results in the configured fail open or fail closed policy being enforced on traffic that would normally be sent to the services module. This message is generated whenever a communication problem over the ASA dataplane occurs between the system module and the services module, which can be caused when the services module stops, resets, is removed or disabled.

Recommended Action For software services modules such as IPS, recover the module using the **sw-module module ips recover** command. For hardware services modules, if this message is not the result of the SSM reloading or resetting and the corresponding syslog message 505010 is not seen after the SSM returns to an UP state, reset the module using the **hw-module module 1 reset** command.

323007

Error Message `%ASA-3-323007: Module in slot slot experienced a firware failure and the recovery is in progress.`

Explanation An ASA with a 4GE-SSM installed experienced a short power surge, then rebooted. As a result, the 4GE-SSM may come online in an unresponsive state. The ASA has detected that the 4GE-SSM is unresponsive, and automatically restarts the 4GE-SSM.

Recommended Action None required.

324000

Error Message `%ASA-3-324000: Drop GTPv version message msg_type from source_interface:source_address/source_port to dest_interface:dest_address/dest_port Reason: reason`

Explanation The packet being processed did not meet the filtering requirements as described in the *reason* variable and is being dropped.

Recommended Action None required.

324001

Error Message `%ASA-3-324001: GTPv0 packet parsing error from source_interface:source_address/source_port to dest_interface:dest_address/dest_port, TID: tid_value, Reason: reason`

Explanation There was an error processing the packet. The following are possible reasons:

- Mandatory IE is missing
- Mandatory IE incorrect
- IE out of sequence
- Invalid message format.
- Optional IE incorrect
- Invalid TEID
- Unknown IE
- Bad length field
- Unknown GTP message.
- Message too short
- Unexpected message seen
- Null TID

- Version not supported

Recommended Action If this message is seen periodically, it can be ignored. If it is seen frequently, then the endpoint may be sending out bad packets as part of an attack.

324002

Error Message `%ASA-3-324002: No PDP[MCB] exists to process GTPv0 msg_type from source_interface:source_address/source_port to dest_interface:dest_address/dest_port, TID: tid_value`

Explanation If this message was preceded by message 321100, memory allocation error, the message indicates that there were not enough resources to create the PDP context. If not, it was not preceded by message 321100. For version 0, it indicates that the corresponding PDP context cannot be found. For version 1, if this message was preceded by message 324001, then a packet processing error occurred, and the operation stopped.

Recommended Action If the problem persists, determine why the source is sending packets without a valid PDP context.

324003

Error Message `%ASA-3-324003: No matching request to process GTPv version msg_type from source_interface:source_address/source_port to source_interface:dest_address/dest_port`

Explanation The response received does not have a matching request in the request queue and should not be processed further.

Recommended Action If this message is seen periodically, it can be ignored. But if it is seen frequently, then the endpoint may be sending out bad packets as part of an attack.

324004

Error Message `%ASA-3-324004: GTP packet with version%d from source_interface:source_address/source_port to dest_interface:dest_address/dest_port is not supported`

Explanation The packet being processed has a version other than the currently supported version, which is 0 or 1. If the version number printed out is an incorrect number and is seen frequently, then the endpoint may be sending out bad packets as part of an attack.

Recommended Action None required.

324005

Error Message `%ASA-3-324005: Unable to create tunnel from source_interface:source_address/source_port to dest_interface:dest_address/dest_port`

Explanation An error occurred while trying to create the tunnel for the transport protocol data units.

Recommended Action If this message occurs periodically, it can be ignored. If it repeats frequently, contact the Cisco TAC.

324006

Error Message `%ASA-3-324006:GSN IP_address tunnel limit tunnel_limit exceeded, PDP Context TID tid failed`

Explanation The GPRS support node sending the request has exceeded the maximum allowed tunnels created, so no tunnel will be created.

Recommended Action Check to see whether the tunnel limit should be increased or if there is a possible attack on the network.

324007

Error Message `%ASA-3-324007: Unable to create GTP connection for response from source_address/0 to dest_address/dest_port`

Explanation An error occurred while trying to create the tunnel for the transport protocol data units for a differentsServicing GPRS support node or gateway GPRS support node.

Recommended Action Check debugging messages to see why the connection was not created correctly. If the problem persists, contact the Cisco TAC.

324008

Error Message `%ASA-3-324008: No PDP exists to update the data sgsn [ggsn] PDPMCB Info REID: teid_value, Request TEID; teid_value, Local GSN: IPaddress (VPIfNum), Remove GSN: IPaddress (VPIfNum)`

Explanation When a GTP HA message is received on the standby unit to update the PDP with data sgsn/ggsn PDPMCB information, the PDP is not found because of a previous PDP update message that was not successfully delivered or successfully processed on the standby unit.

Recommended Action If this message occurs periodically, you can ignore it. If it occurs frequently, contact the Cisco TAC.

324300

Error Message `%ASA-3-324300: Radius Accounting Request from from_addr has an incorrect request authenticator`

Explanation When a shared secret is configured for a host, the request authenticator is verified with that secret. If it fails, it is logged and packet processing stops.

- *from_addr*—The IP address of the host sending the RADIUS accounting request

Recommended Action Check to see that the correct shared secret was configured. If it is, double-check the source of the packet to make sure that it was not spoofed.

324301

Error Message `%ASA-3-324301: Radius Accounting Request has a bad header length hdr_len, packet length pkt_len`

Explanation The accounting request message has a header length that is not the same as the actual packet length, so packet processing stops.

- *hdr_len*—The length indicated in the request header
- *pkt_len*—The actual packet length

Recommended Action Make sure the packet was not spoofed. If the packet is legitimate, then capture the packet and make sure the header length is incorrect, as indicated by the message. If the header length is correct, and if the problem persists, contact the Cisco TAC.

325001

Error Message `%ASA-3-325001: Router ipv6_address on interface has conflicting ND (Neighbor Discovery) settings`

Explanation Another router on the link sent router advertisements with conflicting parameters.

- *ipv6_address*—IPv6 address of the other router
- *interface*—Interface name of the link with the other router

Recommended Action Verify that all IPv6 routers on the link have the same parameters in the router advertisement for *hop_limit*, *managed_config_flag*, *other_config_flag*, *reachable_time* and *ns_interval*, and that preferred and valid lifetimes for the same prefix, advertised by several routers, are the same. To list the parameters per interface, enter the **show ipv6** *interface* command.

325002

Error Message `%ASA-4-325002: Duplicate address ipv6_address/MAC_address on interface`

Explanation Another system is using your IPv6 address.

- *ipv6_address*—The IPv6 address of the other router
- *MAC_address*—The MAC address of the other system, if known; otherwise, it is considered unknown.
- *interface*—The interface name of the link with the other system

Recommended Action Change the IPv6 address of one of the two systems.

325004

Error Message `%ASA-4-325004: IPv6 Extension Header hdr_type action configuration. protocol from src_int:src_ipv6_addr/src_port to dst_interface: dst_ipv6_addr/dst_port.`

Explanation A user has configured one or multiple actions over the specified IPv6 header extension.

- *hdr_type*—Can be one of the following values:

  ah—Configured action over the AH extension header

  count—Configured action over the number of extension headers

  destination-option—Configured action over the destination option extension header

  esp—Configured action over the ESP extension header

  fragment—Configured action over the fragment extension header

  hop-by-hop—Configured action over the hop-by-hop extension header

  routing-address count—Configured action over the number of addresses in the routing extension header

  routing-type—Configured action over the routing type extension header

- *action*—Can be one of the following values:

  denied—The packet is denied.

  denied/logged—The packet is denied and logged.

  logged—The packet is logged.

Recommended Action If the configured action is not expected, under the **policy-map** command, check the action in the **match header extension_header_type** command and the **parameters** command, and make the correct changes. For example:

```
hostname (config)# policy-map type inspect ipv6 pname
hostname (config-pmap)# parameters
hostname (config-pmap-p)# no match header extension_header_type ! to remove the
configuration
hostname (config-pmap-p)# no drop ! so packets with the specified
extension_header_type are not dropped
```

```
hostname (config-pmap-p)# no log ! so packets with the specified extension_header_type
are not logged
hostname (config-pmap-p)# no drop log ! so packets with the specified
extension_header_type are not dropped or logged
```

325005

Error Message `%ASA-4-325005: Invalid IPv6 Extension Header Content: string. detail regarding protocol, ingress and egress interface`

Explanation An IPv6 packet with a bad extension header has been detected.

- *string*—Can be one of the following values:
  - wrong extension header order
  - duplicate extension header
  - routing extension header

Recommended Action Configure the **capture** command to record the dropped packet, then analyze the cause of the dropped packet. If the validity check of the IPv6 extension header can be ignored, disable the validity check in the IPv6 policy map by entering the following commands:

```
hostname (config)# policy-map type inspect ipv6 policy_name
hostname (config-pmap)# parameters
hostname (config-pmap-p)# no verify-header type
```

325006

Error Message `%ASA-4-325006: IPv6 Extension Header not in order: Type hdr_type occurs after Type hdr_type. TCP prot from inside src_int: src_ipv6_addr/src_port to dst_interface:dst_ipv6_addr/dst_port`

Explanation An IPv6 packet with out-of-order extension headers has been detected.

Recommended Action Configure the **capture** command to record the dropped packet, then analyze the extension header order of the dropped packet. If out-of-order header extensions are allowed, disable the out-of-order check in the IPv6 type policy map by entering the following commands:

```
hostname (config)# policy-map type inspect ipv6 policy_name
hostname (config-pmap)# parameters
hostname (config-pmap-p)# no verify-header order
```

326001

Error Message `%ASA-3-326001: Unexpected error in the timer library: error_message`

Explanation A managed timer event was received without a context or a correct type, or no handler exists. Alternatively, if the number of events queued exceeds a system limit, an attempt to process them will occur at a later time.

Recommended Action If the problem persists, contact the Cisco TAC.

326002

Error Message `%ASA-3-326002: Error in error_message: error_message`

Explanation The IGMP process failed to shut down upon request. Events that are performed in preparation for this shutdown may be out-of-sync.

Recommended Action If the problem persists, contact the Cisco TAC.

326004

Error Message `%ASA-3-326004: An internal error occurred while processing a packet queue`

Explanation The IGMP packet queue received a signal without a packet.

Recommended Action If the problem persists, contact the Cisco TAC.

326005

Error Message `%ASA-3-326005: Mrib notification failed for (IP_address, IP_address)`

Explanation A packet triggering a data-driven event was received, and the attempt to notify the MRIB failed.

Recommended Action If the problem persists, contact the Cisco TAC.

326006

Error Message `%ASA-3-326006: Entry-creation failed for (IP_address, IP_address)`

Explanation The MFIB received an entry update from the MRIB, but failed to create the entry related to the addresses displayed. The probable cause is insufficient memory.

Recommended Action If the problem persists, contact the Cisco TAC.

326007

Error Message `%ASA-3-326007: Entry-update failed for (IP_address, IP_address)`

Explanation The MFIB received an interface update from the MRIB, but failed to create the interface related to the addresses displayed. The probable cause is insufficient memory.

Recommended Action If the problem persists, contact the Cisco TAC.

326008

Error Message `%ASA-3-326008: MRIB registration failed`

Explanation The MFIB failed to register with the MRIB.

Recommended Action If the problem persists, contact the Cisco TAC.

326009

Error Message `%ASA-3-326009: MRIB connection-open failed`

Explanation The MFIB failed to open a connection to the MRIB.

Recommended Action If the problem persists, contact the Cisco TAC.

326010

Error Message `%ASA-3-326010: MRIB unbind failed`

Explanation The MFIB failed to unbind from the MRIB.

Recommended Action If the problem persists, contact the Cisco TAC.

326011

Error Message %ASA-3-326011: MRIB table deletion failed

Explanation The MFIB failed to retrieve the table that was supposed to be deleted.

Recommended Action If the problem persists, contact the Cisco TAC.

326012

Error Message %ASA-3-326012: Initialization of *string* functionality failed

Explanation The initialization of a specified functionality failed. This component might still operate without the functionality.

Recommended Action If the problem persists, contact the Cisco TAC.

326013

Error Message %ASA-3-326013: Internal error: *string* in *string* line *%d* (*%s*)

Explanation A fundamental error occurred in the MRIB.

Recommended Action If the problem persists, contact the Cisco TAC.

326014

Error Message %ASA-3-326014: Initialization failed: error_message *error_message*

Explanation The MRIB failed to initialize.

Recommended Action If the problem persists, contact the Cisco TAC.

326015

Error Message %ASA-3-326015: Communication error: error_message *error_message*

Explanation The MRIB received a malformed update.

Recommended Action If the problem persists, contact the Cisco TAC.

326016

Error Message `%ASA-3-326016: Failed to set un-numbered interface for interface_name (string)`

Explanation The PIM tunnel is not usable without a source address. This situation occurs because a numbered interface cannot be found, or because of an internal error.

Recommended Action If the problem persists, contact the Cisco TAC.

326017

Error Message `%ASA-3-326017: Interface Manager error - string in string: string`

Explanation An error occurred while creating a PIM tunnel interface.

Recommended Action If the problem persists, contact the Cisco TAC.

326019

Error Message `%ASA-3-326019: string in string: string`

Explanation An error occurred while creating a PIM RP tunnel interface.

Recommended Action If the problem persists, contact the Cisco TAC.

326020

Error Message `%ASA-3-326020: List error in string: string`

Explanation An error occurred while processing a PIM interface list.

Recommended Action If the problem persists, contact the Cisco TAC.

326021

Error Message `%ASA-3-326021: Error in string: string`

Explanation An error occurred while setting the SRC of a PIM tunnel interface.

Recommended Action If the problem persists, contact the Cisco TAC.

326022

Error Message %ASA-3-326022: Error in *string*: *string*

Explanation The PIM process failed to shut down upon request. Events that are performed in preparation for this shutdown may be out-of-sync.

Recommended Action If the problem persists, contact the Cisco TAC.

326023

Error Message %ASA-3-326023: *string* - *IP_address*: *string*

Explanation An error occurred while processing a PIM group range.

Recommended Action If the problem persists, contact the Cisco TAC.

326024

Error Message %ASA-3-326024: An internal error occurred while processing a packet queue.

Explanation The PIM packet queue received a signal without a packet.

Recommended Action If the problem persists, contact the Cisco TAC.

326025

Error Message %ASA-3-326025: *string*

Explanation An internal error occurred while trying to send a message. Events scheduled to occur on the receipt of a message, such as deletion of the PIM tunnel IDB, may not occur.

Recommended Action If the problem persists, contact the Cisco TAC.

326026

Error Message %ASA-3-326026: Server unexpected error: *error_message*

Explanation The MRIB failed to register a client.

Recommended Action If the problem persists, contact the Cisco TAC.

326027

Error Message `%ASA-3-326027: Corrupted update: error_message`

Explanation The MRIB received a corrupt update.

Recommended Action If the problem persists, contact the Cisco TAC.

326028

Error Message `%ASA-3-326028: Asynchronous error: error_message`

Explanation An unhandled asynchronous error occurred in the MRIB API.

Recommended Action If the problem persists, contact the Cisco TAC.

327001

Error Message `%ASA-3-327001: IP SLA Monitor: Cannot create a new process`

Explanation The IP SLA monitor was unable to start a new process.

Recommended Action Check the system memory. If memory is low, then this is probably the cause. Try to reenter the commands when memory is available. If the problem persists, contact the Cisco TAC.

327002

Error Message `%ASA-3-327002: IP SLA Monitor: Failed to initialize, IP SLA Monitor functionality will not work`

Explanation The IP SLA monitor failed to initialize. This condition is caused by either the timer wheel function failing to initialize or a process not being created. Sufficient memory is probably not available to complete the task.

Recommended Action Check the system memory. If memory is low, then this is probably the cause. Try to reenter the commands when memory is available. If the problem persists, contact the Cisco TAC.

327003

Error Message `%ASA-3-327003: IP SLA Monitor: Generic Timer wheel timer functionality failed to initialize`

Explanation The IP SLA monitor cannot initialize the timer wheel.

Recommended Action Check the system memory. If memory is low, then the timer wheel function did not initialize. Try to reenter the commands when memory is available. If the problem persists, contact the Cisco TAC.

328001

Error Message `%ASA-3-328001: Attempt made to overwrite a set stub function in string.`

Explanation A single function can be set as a callback for when a stub with a check registry is invoked. An attempt to set a new callback failed because a callback function has already been set.

- *string*—The name of the function

Recommended Action If the problem persists, contact the Cisco TAC.

328002

Error Message `%ASA-3-328002: Attempt made in string to register with out of bounds key`

Explanation In the FASTCASE registry, the key has to be smaller than the size specified when the registry was created. An attempt was made to register with a key out-of-bounds.

Recommended Action Copy the error message exactly as it appears, and report it to the Cisco TAC.

329001

Error Message `%ASA-3-329001: The string0 subblock named string1 was not removed`

Explanation A software error has occurred. IDB subblocks cannot be removed.

- *string0*—SWIDB or HWIDB
- *string1*—The name of the subblock

Recommended Action If the problem persists, contact the Cisco TAC.

331001

Error Message `ASA-3-331001: Dynamic DNS Update for 'fqdn_name' = ip_address failed`

Explanation The dynamic DNS subsystem failed to update the resource records on the DNS server. This failure might occur if the ASA is unable to contact the DNS server or the DNS service is not running on the destination system.

- *fqdn_name*—The fully qualified domain name for which the DNS update was attempted
- *ip_address*—The IP address of the DNS update

Recommended Action Make sure that a DNS server is configured and reachable by the ASA. If the problem persists, contact the Cisco TAC.

331002

Error Message `ASA-5-331002: Dynamic DNS type RR for ('fqdn_name' - ip_address | ip_address - 'fqdn_name') successfully updated in DNS server dns_server_ip`

Explanation A dynamic DNS update succeeded in the DNS server.

- *type*—The type of resource record, which may be A or PTR
- *fqdn_name*—The fully qualified domain name for which the DNS update was attempted
- *ip_address*—The IP address of the DNS update
- *dns_server_ip*—The IP address of the DNS server

Recommended Action None required.

332001

Error Message `%ASA-3-332001: Unable to open cache discovery socket, WCCP V2 closing down.`

Explanation An internal error that indicates the WCCP process was unable to open the UDP socket used to listen for protocol messages from caches.

Recommended Action Ensure that the IP configuration is correct and that at least one IP address has been configured.

332002

Error Message `%ASA-3-332002: Unable to allocate message buffer, WCCP V2 closing down.`

Explanation An internal error that indicates the WCCP process was unable to allocate memory to hold incoming protocol messages.

Recommended Action Ensure that enough memory is available for all processes.

332003

Error Message `%ASA-5-332003: Web Cache IP_address/service_ID acquired`

Explanation A service from the web cache of the ASA was acquired.

- *IP_address*—The IP address of the web cache
- *service_ID*—The WCCP service identifier

Recommended Action None required.

332004

Error Message `%ASA-1-332004: Web Cache IP_address/service_ID lost`

Explanation A service from the web cache of the ASA was lost.

- *IP_address*—The IP address of the web cache
- *service_ID*—The WCCP service identifier

Recommended Action Verify operation of the specified web cache.

333001

Error Message `%ASA-6-333001: EAP association initiated - context: EAP-context`

Explanation An EAP association has been initiated with a remote host.

- *EAP-context*—A unique identifier for the EAP session, displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action None required.

333002

Error Message `%ASA-5-333002: Timeout waiting for EAP response - context:EAP-context`

Explanation A timeout occurred while waiting for an EAP response.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action None required.

333003

Error Message `%ASA-6-333003: EAP association terminated - context:EAP-context`

Explanation The EAP association has been terminated with the remote host.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action None required.

333004

Error Message `%ASA-7-333004: EAP-SQ response invalid - context:EAP-context`

Explanation The EAP-Status Query response failed basic packet validation.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333005

Error Message `%ASA-7-333005: EAP-SQ response contains invalid TLV(s) - context:EAP-context`

Explanation The EAP-Status Query response has one or more invalid TLVs.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333006

Error Message `%ASA-7-333006: EAP-SQ response with missing TLV(s) - context:EAP-context`

Explanation The EAP-Status Query response is missing one or more mandatory TLVs.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333007

Error Message `%ASA-7-333007: EAP-SQ response TLV has invalid length - context:EAP-context`

Explanation The EAP-Status Query response includes a TLV with an invalid length.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333008

Error Message `%ASA-7-333008: EAP-SQ response has invalid nonce TLV - context:EAP-context`

Explanation The EAP-Status Query response includes an invalid nonce TLV.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333009

Error Message `%ASA-6-333009:` EAP-SQ response MAC TLV is invalid - `context:EAP-context`

Explanation The EAP-Status Query response includes a MAC that does not match the calculated MAC.

- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit hexadecimal number (for example, 0x2D890AE0)

Recommended Action If the problem persists, contact the Cisco TAC.

333010

Error Message `%ASA-5-333010: EAP-SQ response Validation Flags TLV indicates PV request - context:EAP-context`

Explanation The EAP-Status Query response includes a validation flags TLV, which indicates that the peer requested a full posture validation.

Recommended Action None required .

334001

Error Message `%ASA-6-334001: EAPoUDP association initiated - host-address`

Explanation An EAPoUDP association has been initiated with a remote host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334002

Error Message `%ASA-5-334002: EAPoUDP association successfully established - host-address`

Explanation An EAPoUDP association has been successfully established with the host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334003

Error Message `%ASA-5-334003:` EAPoUDP association failed to establish - *host-address*

Explanation An EAPoUDP association has failed to establish with the host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action Verify the configuration of the Cisco Secure Access Control Server.

334004

Error Message `%ASA-6-334004: Authentication request for NAC Clientless host - host-address`

Explanation An authentication request was made for a NAC clientless host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334005

Error Message `%ASA-5-334005: Host put into NAC Hold state - host-address`

Explanation The NAC session for the host was put into the Hold state.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334006

Error Message `%ASA-5-334006: EAPoUDP failed to get a response from host - host-address`

Explanation An EAPoUDP response was not received from the host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334007

Error Message `%ASA-6-334007: EAPoUDP association terminated - host-address`

Explanation An EAPoUDP association has terminated with the host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

334008

Error Message `%ASA-6-334008: NAC EAP association initiated - host-address, EAP context: EAP-context`

Explanation EAPoUDP has initiated EAP with the host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)
- *EAP-context*—A unique identifier for the EAP session displayed as an eight-digit, hexadecimal number (for example, 0x2D890AE0)

Recommended Action None required.

334009

Error Message `%ASA-6-334009: Audit request for NAC Clientless host - Assigned_IP.`

Explanation An audit request is being sent for the specified assigned IP address.

- *Assigned_IP*—The IP address assigned to the client

Recommended Action None required.

335001

Error Message `%ASA-6-335001: NAC session initialized - host-address`

Explanation A NAC session has started for a remote host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.86.7.101)

Recommended Action None required.

335002

Error Message `%ASA-5-335002: Host is on the NAC Exception List - host-address, OS: oper-sys`

Explanation The client is on the NAC Exception List and is therefore not subject to posture validation.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)
- *oper-sys*—The operating system (for example, Windows XP) of the host

Recommended Action None required.

335003

Error Message `%ASA-5-335003: NAC Default ACL applied, ACL:`*`ACL-name - host-address`*

Explanation The NAC default ACL has been applied for the client.

- *ACL-name*—The name of the ACL being applied
- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335004

Error Message `%ASA-6-335004: NAC is disabled for host - `*`host-address`*

Explanation NAC is disabled for the remote host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335004

Error Message `%ASA-6-335004: NAC is disabled for host - `*`host-address`*

Explanation NAC is disabled for the remote host.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335005

Error Message `%ASA-4-335005: NAC Downloaded ACL parse failure - `*`host-address`*

Explanation Parsing of a downloaded ACL failed.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action Verify the configuration of the Cisco Secure Access Control Server.

335006

Error Message `%ASA-6-335006: NAC Applying ACL: ACL-name - host-address`

Explanation The name of the ACL that is being applied as a result of NAC posture validation.

- *ACL-name*—The name of the ACL being applied
- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335007

Error Message `%ASA-7-335007: NAC Default ACL not configured - host-address`

Explanation A NAC default ACL has not been configured.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335008

Error Message `%ASA-5-335008: NAC IPsec terminate from dynamic ACL: ACL-name - host-address`

Explanation A dynamic ACL obtained as a result of PV requires IPsec termination.

- *ACL-name*—The name of the ACL being applied
- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335009

Error Message `%ASA-6-335009: NAC Revalidate request by administrative action - host-address`

Explanation A NAC Revalidate action was requested by the administrator.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335010

Error Message `%ASA-6-335010: NAC Revalidate All request by administrative action - num sessions`

Explanation A NAC Revalidate All action was requested by the administrator.

- *num*—A decimal integer that indicates the number of sessions to be revalidated

Recommended Action None required.

335011

Error Message `%ASA-6-335011: NAC Revalidate Group request by administrative action for group-name group - num sessions`

Explanation A NAC Revalidate Group action was requested by the administrator.

- *group-name*—The VPN group name
- *num*—A decimal integer that indicates the number of sessions to be revalidated

Recommended Action None required.

335012

Error Message `%ASA-6-335012: NAC Initialize request by administrative action - host-address`

Explanation A NAC Initialize action was requested by the administrator.

- *host-address*—The IP address of the host in dotted decimal format (for example, 10.1.1.1)

Recommended Action None required.

335013

Error Message `%ASA-6-335013: NAC Initialize All request by administrative action - num sessions`

Explanation A NAC Initialize All action was requested by the administrator.

- *num*—A decimal integer that indicates the number of sessions to be revalidated

Recommended Action None required.

335014

Error Message `%ASA-6-335014: NAC Initialize Group request by administrative action for group-name group - num sessions`

Explanation A NAC Initialize Group action was requested by the administrator.

- *group-name*—The VPN group name
- *num*—A decimal integer that indicates the number of sessions to be revalidated

Recommended Action None required.

336001

Error Message `%ASA-3-336001 Route desination_network stuck-in-active state in EIGRP-ddb_name as_num. Cleaning up`

Explanation The SIA state means that an EIGRP router has not received a reply to a query from one or more neighbors within the time allotted (approximately three minutes). When this happens, EIGRP clears the neighbors that did not send a reply and logs an error message for the route that became active.

- *destination_network*—The route that became active
- *ddb_name*—IPv4
- *as_num*—The EIGRP router

Recommended Action Check to see why the router did not get a response from all of its neighbors and why the route disappeared.

336002

Error Message `%ASA-3-336002: Handle handle_id is not allocated in pool.`

Explanation The EIGRP router is unable to find the handle for the next hop.

- *handle_id*—The identity of the missing handle

Recommended Action If the problem persists, contact the Cisco TAC.

336003

Error Message `%ASA-3-336003: No buffers available for bytes byte packet`

Explanation The DUAL software was unable to allocate a packet buffer. The ASA may be out of memory.

- *bytes*—Number of bytes in the packet

Recommended Action Check to see if the ASA is out of memory by entering the **show mem** or **show tech** command. If the problem persists, contact the Cisco TAC.

336004

Error Message `%ASA-3-336004: Negative refcount in pakdesc pakdesc.`

Explanation The reference count packet count became negative.

- *pakdesc*—Packet identifier

Recommended Action If the problem persists, contact the Cisco TAC.

336005

Error Message `%ASA-3-336005: Flow control error, error, on interface_name.`

Explanation The interface is flow blocked for multicast. Qelm is the queue element, and in this case, the last multicast packet on the queue for this particular interface.

- *error*—Error statement: Qelm on flow ready
- *interface_name*—Name of the interface on which the error occurred

Recommended Action If the problem persists, contact the Cisco TAC.

336006

Error Message `%ASA-3-336006: num peers exist on IIDB interface_name.`

Explanation Peers still exist on a particular interface during or after cleanup of the IDB of the EIGRP.

- *num*—The number of peers
- *interface_name*—The interface name

Recommended Action If the problem persists, contact the Cisco TAC.

336007

Error Message `%ASA-3-336007: Anchor count negative`

Explanation An error occurred and the count of the anchor became negative when it was released.

Recommended Action If the problem persists, contact the Cisco TAC.

336008

Error Message `%ASA-3-336008: Lingering DRDB deleting IIDB, dest network, nexthop address (interface), origin origin_str`

Explanation An interface is being deleted and some lingering DRDB exists.

- *network*—The destination network
- *address*—The nexthop address
- *interface*—The nexthop interface
- *origin_str*—String defining the origin

Recommended Action If the problem persists, contact the Cisco TAC.

336009

Error Message `%ASA-3-336009 ddb_name as_id: Internal Error`

Explanation An internal error occurred.

- *ddb_name*—PDM name (for example, IPv4 PDM)
- *as_id*—Autonomous system ID

Recommended Action If the problem persists, contact the Cisco TAC.

336010

Error Message `%ASA-5-336010 EIGRP-ddb_name tableid as_id: Neighbor address (%interface) is event_msg: msg`

Explanation A neighbor went up or down.

- *ddb_name*—IPv4
- *tableid*— Internal ID for the RIB
- *as_id*—Autonomous system ID
- *address*—IP address of the neighbor

- *interface*—Name of the interface
- *event_msg*— Event that is occurring for the neighbor (that is, up or down)
- *msg*—Reason for the event. Possible *event_msg* and *msg* value pairs include:
  - resync: peer graceful-restart
  - down: holding timer expired
  - up: new adjacency
  - down: Auth failure
  - down: Stuck in Active
  - down: Interface PEER-TERMINATION received
  - down: K-value mismatch
  - down: Peer Termination received
  - down: stuck in INIT state
  - down: peer info changed
  - down: summary configured
  - down: Max hopcount changed
  - down: metric changed
  - down: [No reason]

Recommended Action Check to see why the link on the neighbor is going down or is flapping. This may be a sign of a problem, or a problem may occur because of this.

336011

Error Message `%ASA-6-336011: event event`

Explanation A dual event occurred. The events can be one of the following:

- Redist rt change
- SIA Query while Active

Recommended Action If the problem persists, contact the Cisco TAC.

336012

Error Message `%ASA-3-336012: Interface interface_names going down and neighbor_links links exist`

Explanation An interface is going down or is being removed from routing through IGRP, but not all links (neighbors) have been removed from the topology table.

Recommended Action If the problem persists, contact the Cisco TAC.

336013

Error Message `%ASA-3-336013: Route iproute, iproute_successors successors, db_successors rdbs`

Explanation A hardware or software error occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

336014

Error Message `%ASA-3-336014: "EIGRP_PDM_Process_name, event_log"`

Explanation A hardware or software error occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

336015

Error Message `%ASA-3-336015: "Unable to open socket for AS as_number"`

Explanation A hardware or software error occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

336016

Error Message `%ASA-3-336016: Unknown timer type timer_type expiration`

Explanation A hardware or software error occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

336019

Error Message `%ASA-3-336019: process_name as_number: prefix_source threshold prefix level (prefix_threshold) reached`

Explanation The number of prefixes in the topology database has reached the configured or default threshold level. The prefix source may be any of the following:

- Neighbor
- Redistributed

- Aggregate

Recommended Action Use the **show eigrp accounting** command to obtain details about the source of the prefixes and take corrective action.

337001

Error Message `%ASA-3-337001: Phone Proxy SRTP: Encryption failed on packet from` *`in_ifc`*`:`*`src_ip`*`/`*`src_port`* `to` *`out_ifc`*`:`*`dest_ip`*`/`*`dest_port`*

Explanation The crypto hardware was unable to do SRTP encryption.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If this message persists, call the Cisco TAC to debug the crypto hardware to determine why SRTP encryption is failing.

337002

Error Message `%ASA-3-337002: Phone Proxy SRTP: Decryption failed on packet from` *`in_ifc`*`:`*`src_ip`*`/`*`src_port`* `to` *`out_ifc`*`:`*`dest_ip`*`/`*`dest_port`*

Explanation The crypto hardware was unable to do SRTP decryption.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If this message persists, call the Cisco TAC to debug the crypto hardware to determine why SRTP decryption is failing.

337003

Error Message `%ASA-3-337003: Phone Proxy SRTP: Authentication tag generation failed on packet from` *`in_ifc`*`:`*`src_ip`*`/`*`src_port`* `to` *`out_ifc`*`:`*`dest_ip`*`/`*`dest_port`*

Explanation The authentication tag generation failed in the crypto hardware.

- *in_ifc*—The input interface

- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If this message persists, call the Cisco TAC to debug the crypto hardware to determine why SRTP generation of the authentication tag is failing.

337004

Error Message `%ASA-3-337004: Phone Proxy SRTP: Authentication tag validation failed on packet from in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port`

Explanation The computed authentication tag is not the same as the authentication tag in the packet.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action Check to see whether an attack is underway.

337005

Error Message `%ASA-4-337005: Phone Proxy SRTP: Media session not found for media_term_ip/media_term_port for packet from in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port`

Explanation The ASA received an SRTP or RTP packet that was destined to go to the media termination IP address and port, but the corresponding media session to process this packet was not found.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If this message occurs at the end of the call, it is considered normal because the signaling messages may have released the media session, but the endpoint is continuing to send a few SRTP or RTP packets. If this message occurs for an odd-numbered media termination port, the endpoint is sending RTCP, which must be disabled from the CUCM. If this message happens

continuously for a call, debug the signaling message transaction either using phone proxy debug commands or capture commands to determine if the signaling messages are being modified with the media termination IP address and port.

337006

Error Message `%ASA-3-337006: Phone Proxy SRTP: Failed to sign file filename requested by UDP client cifc:caddr/cport for sifc:saddr/sport`

Explanation The crypto hardware was unable to perform encryption and create a signature for a file.

- *filename*—The name of the file
- *sifc*—The server interface
- *saddr*—The server IP address
- *sport*—The server port
- *cifc*—The client interface
- *caddr*—The client IP address
- *cport*—The client port

Recommended Action If this message persists, check associated messages for other errors related to the crypto hardware engine.

337007

Error Message `%ASA-3-337007: Phone Proxy SRTP: Failed to find configuration file filename for UDP client cifc:caddr/cport by server sifc:saddr/sport`

Explanation The CUCM returns the File Not Found error when a phone requests its configuration file.

- *filename*—The name of the file
- *sifc*—The server interface
- *saddr*—The server IP address
- *sport*—The server port
- *cifc*—The client interface
- *caddr*—The client IP address
- *cport*—The client port

Recommended Action Check to make sure that this phone has been configured on the CUCM.

337008

Error Message `%ASA-3-337008: Phone Proxy: Unable to allocate media port from media-termination address phone_proxy_ifc:media_term_IP for client_ifc:client_IP/client_port; call failed.`

Explanation The ASA cannot find a port to allocate for media when creating a new media session. This message may occur because the user has not provided a large enough range of ports for phone proxy use, which is determined in the **media-termination address** command, or that all available ports are already being used.

- *media-termination address*—The media termination address
- *phone_proxy_ifc*—The media termination interface name (identity)
- *media_term_ip*—The media termination IP address
- *client_ifc*—The client interface name
- *client_ip*—The client IP address
- *client_port*—The client port

Recommended Action Check the phone-proxy configuration to see the range of media ports specified and allocate a larger range of media ports if the range was too small, provided the security policy allows it. The default port range is 16384-32767.

337009

Error Message `%ASA-3-337009: Unable to create secure phone entry, interface:IPaddr is already configured for the same MAC mac_addr.`

Explanation You tried to register the same secure phone with a different IP address. Because an entry for the MAC address with the old IP address was already made, you cannot have multiple entries with the same MAC address and different IP addresses.

- *interface*—The interface name from which the previous entry is registered
- *ipaddr*—The IP address of the existing secure phone entry
- *mac_addr*—The MAC address of the phone

Recommended Action Check the output of the **show phone-proxy secure-phones** command. Use the **clear** command to clear the entry that is causing the issue, then register the phone with the new IP address.

338001

Error Message %ASA-4-338001: Dynamic filter monitored blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port*, (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *domain name*, threat-level: *level_value*, category: *category_name*

Explanation Traffic from a blacklisted domain in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command to automatically drop such traffic.

338002

Error Message %ASA-4-338002: Dynamic filter monitored blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *domain name*, threat-level: *level_value*, category: *category_name*

Explanation Traffic to a blacklisted domain name in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command to automatically drop such traffic.

338003

Error Message %ASA-4-338003: Dynamic filter monitored blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port)* to *out_interface*:*dest_ip_addr*/*dest_port*, (*mapped-ip*/*mapped-port),* source *malicious address* resolved from *local or dynamic* list: *ip address/netmask,* threat-level: *level_value,* category: *category_name*

Explanation Traffic from a blacklisted IP address in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command to automatically drop such traffic.

338004

Error Message %ASA-4-338004: Dynamic filter monitored blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *ip address/netmask,* threat-level: *level_value,* category: *category_name*

Explanation Traffic to a blacklisted IP address in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command to automatically drop such traffic.

338005

Error Message %ASA-4-338005: Dynamic filter dropped blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *domain name,* threat-level: *level_value,* category: *category_name*

Explanation Traffic from a black-listed domain name in the dynamic filter database was denied. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action None required.

338006

Error Message %ASA-4-338006: Dynamic filter dropped blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *domain name,* threat-level: *level_value,* category: *category_name*

Explanation Traffic to a blacklisted domain name in the dynamic filter database was denied. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action None required.

338007

Error Message %ASA-4-338007: Dynamic filter dropped blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *ip address/netmask,* threat-level: *level_value,* category: *category_name*

Explanation Traffic from a blacklisted IP address in the dynamic filter database was denied. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action None required.

338008

Error Message %ASA-4-338008: Dynamic filter dropped blacklisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *ip address/netmask,* threat-level: *level_value,* category: *category_name*

Explanation Traffic to a blacklisted IP address in the dynamic filter database was denied. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action None required.

338101

Error Message %ASA-4-338101: Dynamic filter *action* whitelisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port*, (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *domain name*

Explanation Traffic from a whitelisted domain in the dynamic filter database has appeared.

Recommended Action None required.

338102

Error Message %ASA-4-338102: Dynamic filter *action* whitelisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *domain name*

Explanation Traffic to a whitelisted domain name in the dynamic filter database has appeared.

Recommended Action None required.

338103

Error Message %ASA-4-338103: Dynamic filter *action* whitelisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port*, (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *ip address/netmask*

Explanation Traffic from a whitelisted IP address in the dynamic filter database has appeared.

Recommended Action None required.

338104

Error Message %ASA-4-338104: Dynamic filter *action* whitelisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *ip address/netmask*

Explanation Traffic to a whitelisted IP address in the dynamic filter database has appeared.

Recommended Action None required.

338201

Error Message %ASA-4-338201: Dynamic filter monitored greylisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port*, (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *domain name*, threat-level: *level_value*, category: *category_name*

Explanation Traffic from a greylisted domain in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command and the **dynamic-filter ambiguous-is-black** command to automatically drop such traffic.

338202

Error Message %ASA-4-338202: Dynamic filter monitored greylisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *domain name*, threat-level: *level_value*, category: *category_name*

Explanation Traffic to a greylisted domain name in the dynamic filter database has appeared. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site has been logged. Use the internal IP address to trace the infected machine, or enter the **dynamic-filter drop blacklist** command and the **dynamic-filter ambiguous-is-black** command to automatically drop such traffic.

338203

Error Message %ASA-4-338203: Dynamic filter dropped greylisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), source *malicious address* resolved from *local or dynamic* list: *domain name,* threat-level: *level_value,* category: *category_name*

Explanation Traffic from a greylisted domain name in the dynamic filter database was denied; however, the malicious IP address was also resolved to domain names that are unknown to the dynamic filter database. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site was dropped. If you do not want to automatically drop greylisted traffic whose IP address matches both blacklisted domain names and unknown domain names, disable the **dynamic-filter ambiguous-is-black** command.

338204

Error Message %ASA-4-338204: Dynamic filter dropped greylisted *protocol* traffic from *in_interface*:*src_ip_addr*/*src_port* (*mapped-ip*/*mapped-port*) to *out_interface*:*dest_ip_addr*/*dest_port* (*mapped-ip*/*mapped-port*), destination *malicious address* resolved from *local or dynamic* list: *domain name,* threat-level: *level_value,* category: *category_name*

Explanation Traffic to a greylisted domain name in the dynamic filter database was denied; however, the malicious IP address was also resolved to domain names that are unknown to the dynamic filter database. The threat level is a string that shows one of the following values: none, very-low, low, moderate, high, and very-high. The category is a string that shows the reason why a domain name is blacklisted (for example, botnet, Trojan, and spyware).

Recommended Action Access to a malicious site was dropped. If you do not want to automatically drop greylisted traffic whose IP address matches both blacklisted domain names and unknown domain names, disable the **dynamic-filter ambiguous-is-black** command.

338301

Error Message %ASA-4-338301: Intercepted DNS reply for domain *name* from *in_interface*:*src_ip_addr*/*src_port* to *out_interface*:*dest_ip_addr*/*dest_port*, matched *list*

Explanation A DNS reply that was present in an administrator whitelist, blacklist, or IronPort list was intercepted.

- *name*—The domain name
- *list*—The list that includes the domain name, administrator whitelist, blacklist, or IronPort list

Recommended Action None required.

338302

Error Message `%ASA-5-338302: Address ipaddr discovered for domain name from list, Adding rule`

Explanation An IP address that was discovered from a DNS reply to the dynamic filter rule table was added.

- *ipaddr*—The IP address from the DNS reply
- *name*—The domain name
- *list*—The list that includes the domain name, administrator blacklist, or IronPort list

Recommended Action None required.

338303

Error Message `%ASA-5-338303: Address ipaddr (name) timed out, Removing rule`

Explanation An IP address that was discovered from the dynamic filter rule table was removed.

- *ipaddr*—The IP address from the DNS reply
- *name*—The domain name

Recommended Action None required.

338304

Error Message `%ASA-6-338304: Successfully downloaded dynamic filter data file from updater server url`

Explanation A new version of the data file has been downloaded.

- *url*—The URL of the updater server

Recommended Action None required.

338305

Error Message `%ASA-3-338305: Failed to download dynamic filter data file from updater server url`

Explanation The dynamic filter database has failed to download.

- *url*—The URL of the updater server

Recommended Action Make sure that you have a DNS configuration on the ASA so that the updater server URL can be resolved. If you cannot ping the server from the ASA, check with your network administrator for the correct network connection and routing configuration. If you are still having problems, contact the Cisco TAC.

338306

Error Message `%ASA-3-338306: Failed to authenticate with dynamic filter updater server url`

Explanation The ASA failed to authenticate with the dynamic filter updater server.

- *url*—The URL of the updater server

Recommended Action Contact the Cisco TAC.

338307

Error Message `%ASA-3-338307: Failed to decrypt downloaded dynamic filter database file`

Explanation The downloaded dynamic filter database file failed to decrypt.

Recommended Action Contact the Cisco TAC.

338308

Error Message `%ASA-5-338308: Dynamic filter updater server dynamically changed from old_server_host: old_server_port to new_server_host: new_server_port`

Explanation The ASA was directed to a new updater server host or port.

- *old_server_host*:*old_server_port*—The previous updater server host and port
- *new_server_host*:*new_server_port*—The new updater server host and port

Recommended Action None required.

338309

Error Message `%ASA-3-338309: The license on this ASA does not support dynamic filter updater feature.`

Explanation The dynamic filter updater is a licensed feature; however, the license on the ASA does not support this feature.

Recommended Action None required.

338310

Error Message `%ASA-3-338310: Failed to update from dynamic filter updater server` *`url`*`, reason:` *`reason string`*

Explanation The ASA failed to receive an update from the dynamic filter updater server.

- *url*—The URL of the updater server
- *reason string*—The reason for the failure, which can be one of the following:
  - Failed to connect to updater server
  - Received invalid server response
  - Received invalid server manifest
  - Error in stored update file information
  - Script error
  - Function call error
  - Out of memory

Recommended Action Check the network connection to the server. Try to ping the server URL, which is shown in the output of the **show dynamic-filter updater-client** command. Make sure that the port is allowed through your network. If the network connection is not the problem, contact your network administrator.

339001

Error Message `%ASA-3-339001: UC-IME-SIG: Ticket not found in SIP %s from %s:%A/%d to %s:%A/%d, packet dropped`

Explanation For UC-IME SIP signaling, all dialog-forming SIP messages received from the outside must include the X-Cisco-ViPR-Ticket header. If this header is missing from the message, the message will be dropped during SIP inspection. This header is only required when an existing SIP session (as determined by current SIP inspection rules) cannot be found for the message being inspected.

- *%s*—SIP message name (INVITE or REFER)
- *%s*—Source interface name (inside or outside)

- *%A*—Source IP address
- *%d*—Source port
- *%s*—Destination interface name (inside or outside)
- *%A*—Destination IP address
- *%d*—Destination port

Recommended Action Check to see if UC-IME calls are being spoofed.

339002

Error Message `%ASA-3-339002: UC-IME-SIG: Invalid ticket in SIP %s from %s:%A/%d to %s:%A/%d, packet dropped, %s`

Explanation When UC-IME ticket inspection and validation are performed, several data checks for timestamp validity and epoch matching, among others, are performed. If any of these checks fail, the SIP message or packet will be dropped.

- *%s*—SIP message name (INVITE or REFER)
- *%s*—Source interface name (inside or outside)
- *%A*—Source IP address
- *%d*—Source port
- *%s*—Destination interface name (inside or outside)
- *%A*—Destination IP address
- *%d*—Destination port
- *%s*—Additional description or data about the error condition

Recommended Action Check to see if UC-IME calls are being spoofed. Turn on UC-IME debug tracing to obtain more details about the error condition.

339003

Error Message `%ASA-3-339003: UC-IME-SIG: Non-dialog forming SIP %s received from %s:%A/%d to %s:%A/%d, packet dropped`

Explanation When a SIP message is inspected by the UC-IME feature, checks are performed to see if the message belongs to an existing SIP session. In a non-UC-IME scenario, a SIP request received will create a SIP session (if permitted by a configured policy). However, for the UC-IME feature, nondialog-creating SIP messages are not permitted to create a SIP session in the ASA and are dropped.

- *%s*—SIP message name (INVITE or REFER)
- *%s*—Source interface name (inside or outside)
- *%A*—Source IP address
- *%d*—Source port

- *%s*—Destination interface name (inside or outside)
- *%A*—Destination IP address
- *%d*—Destination port

Recommended Action Check to see if UC-IME calls are being spoofed.

339004

Error Message `%ASA-3-339004: UC-IME-SIG: Dropping SIP %s received from %s:%A/%d to %s:%A/%d, route header validation failed, %s`

Explanation When an outbound SIP message is inspected by the UC-IME feature, the domain name included in the SIP route header is compared to the TLS certificate domain name. This comparison allows the UC-IME feature on the ASA to determine whether or not the SIP message is actually terminating at the intended enterprise. If a mismatch occurs, it implies that the remote end is not serving that domain, and the SIP session should be terminated.

- *%s*—SIP message name (INVITE or REFER)
- *%s*—Source interface name (inside or outside)
- *%A*—Source IP address
- *%d*—Source port
- *%s*—Destination interface name (inside or outside)
- *%A*—Destination IP address
- *%d*—Destination port
- *%s*—Additional description or data about the error condition (for example, the domain names received)

Recommended Action Check to see if the remote enterprise is attempting to hijack UC-IME calls.

339005

Error Message `%ASA-3-339005: UC-IME-SIG: Message received from %s:%A/%d to %s:%A/%d does not contain SRTP, message dropped`

Explanation For UC-IME SIP signaling, SIP messages received that have media content from the outside need to be SRTP. If this content is not SRTP, the message will be dropped during SIP inspection.

- *%s*—Source interface name (inside or outside)
- *%A*—Source IP address
- *%d*—Source port
- *%s*—Destination interface name (inside or outside)
- *%A*—Destination IP address

- *%d*—Destination port

Recommended Action None required.

339006

Error Message `%ASA-3-339006: UC-IME-Offpath: Failed to map remote UCM address %A:%d on %s interface, request from local UCM %A:%d on %s interface, reason %s`

Explanation For the UC-IME mapping service to work correctly, a correct configuration of global NAT must be in place. If a misconfiguration is detected, a message will be generated to inform the administrator. At the same time, all requests from UCM clients must conform to the mapping service stun message format. All nonconforming requests will be dropped silently, and a message will be generated to notify the administrator about this occurrence.

- *%A*—Remote UCM IP address
- *%d*—Remote UCM port
- *%s*—Interface for the remote UCM IP address or port address
- *%A*—Local UCM IP address (used for the mapping service connection)
- *%d*—Local UCM port (used for the mapping service connection)
- *%s*—Interface for the local UCM IP address or port address
- *%s*—Failure reason

Recommended Action Check to see if the UC-IME Offpath and the UCM Offpath are configured correctly.

339007

Error Message `%ASA-6-339007: UC-IME-Offpath: Mapped address %A:%d on %s interface for remote UCM %A:%d on %s interface, request from local UCM %A:%d on %s interface`

Explanation UC-IME mapping service calls are tracked based on the mapping service client (UCM) address (IP:port) and remote UCM address (IP:port). The administrator may use this information to help debug an offpath UC-IME call.

- *%A*—Mapped IP address
- *%d*—Mapped port
- *%s*—Interface for the mapped IP address or port address
- *%A*—Remote UCM IP address
- *%d*—Remote UCM port
- *%s*—Interface for the remote UCM IP address or port address
- *%A*—Local UCM IP address (used for the mapping-service connection)
- *%d*—Local UCM port (used for the mapping-service connection)

- *%s*—Interface for the local UCM IP address or port address

Recommended Action None required.

339008

Error Message `%ASA-6-339008: UC-IME-Media: Media session with Call-ID %s and Session-ID %s terminated. RTP monitoring parameters: Failover state: %s, Refer msgs sent: %d, Codec payload format: %s, RTP ptime (ms): %d, Max RBLR pct(x100): %d, Max ITE count in 8 secs: %d, Max BLS (ms): %d, Max span PDV (usec): %d, Min span PDV (usec): %d, Mov avg span PDV (usec): %d, Total ITE count: %d, Total sec count: %d, Concealed sec count: %d, Severely concealed sec count: %d, Max call interval (ms): %d`

Explanation UC-IME media session termination is tracked based on the Call ID or Session ID. This message is triggered at the end of a media session. The parameters returned by the RTP monitoring algorithm are included so that an administrator can adjust sensitivity parameters to improve the quality of service for a call.

- *%s*—Failover state, which can be one of the following:
  - No error, for an active session
  - No media at startup timer expired
  - Error in received sequence numbering
  - Both ITE and BLS thresholds exceeded
  - BLS threshold exceeded within Burst Interval
  - RBLR threshold exceeded within last 8 sec
  - Combination (> 3/4 RBLR + > 3/4 BLS) failover
  - No media since last received packet exceeded
  - ITE threshold exceeded
- *%s*—Codec payload format:, which can be one of the following:
  - UNKNOWN
  - G722
  - PCMU
  - PCMA
  - iLBC
  - iSAC

Recommended Action None required.

339009

Error Message `%ASA-6-339009: UC-IME: Ticket Password changed. Please update the same on UC-IME server.`

Explanation The ASA administrator is allowed to change the ticket password without knowing the old password. This message is generated to ensure that the administrator is aware of this change. The message also serves as a reminder to the administrator that if the UC-IME password is changed on the ASA, it should also be changed on the UC-IME server for everything to function correctly.

Recommended Action Verify that the ticket password has been changed on the UC-IME server to match the value configured on the ASA.

340001

Error Message `%ASA-3-340001: Loopback-proxy error: error_string context id context_id, context type = version/request_type/address_type client socket (internal)= client_address_internal/client_port_internal server socket (internal)= server_address_internal/server_port_internal server socket (external)= server_address_external/server_port_external remote socket (external)= remote_address_external/remote_port_external`

Explanation Loopback proxy allows third-party applications running on the ASA to access the network. The loopback proxy encountered an error.

- *context_id*—A unique, 32-bit context ID that is generated for each loopback client proxy request
- *version*—The protocol version
- *request_type*—The type of request, which can be one of the following: TC (TCP connection), TB (TCP bind), or UA (UDP association)
- *address_type*—The types of addresses, which can be one of the following: IP4 (IPv4), IP6 (IPv6), or DNS (domain name service)
- *client_address_internal/server_address_internal*—The addresses that the loopback client and the loopback server used for communication
- *client_port_internal/server_port_internal*—The ports that the loopback client and the loopback server used for communication
- *server_address_external/remote_address_external*—The addresses that the loopback server and the remote host used for communication
- *server_port_external/remote_port_external*—The ports that the loopback server and the remote host used for communication
- *error_string*—The error string that may help troubleshoot the problem

Recommended Action Copy the syslog message and contact the Cisco TAC.

340002

Error Message `%ASA-6-340002: Loopback-proxy info: error_string context id context_id, context type = version/request_type/address_type client socket (internal)= client_address_internal/client_port_internal server socket (internal)= server_address_internal/server_port_internal server socket (external)= server_address_external/server_port_external remote socket (external)= remote_address_external/remote_port_external`

Explanation Loopback proxy allows third-party applications running on the ASA to access the network. The loopback proxy generated debugging information for use in troubleshooting.

- *context_id*—A unique, 32-bit context ID that is generated for each loopback client proxy request
- *version*—The protocol version
- *request_type*—The type of request, which can be one of the following: TC (TCP connection), TB (TCP bind), or UA (UDP association)
- *address_type*—The types of addresses, which can be one of the following: IP4 (IPv4), IP6 (IPv6), or DNS (domain name service)
- *client_address_internal/server_address_internal*—The addresses that the loopback client and the loopback server used for communication
- *client_port_internal/server_port_internal*—The ports that the loopback client and the loopback server used for communication
- *server_address_external/remote_address_external*—The addresses that the loopback server and the remote host used for communication
- *server_port_external/remote_port_external*—The ports that the loopback server and the remote host used for communication
- *error_string*—The error string that may help troubleshoot the problem

Recommended Action Copy the syslog message and contact the Cisco TAC.

341001

Error Message `%ASA-6-341001: Policy Agent started successfully for VNMC vnmc_ip_addr`

Explanation The policy agent processes (DME, ducatiAG, and commonAG) started successfully.

- *vnmc_ip_addr*—-The IP address of the VNMC server

Recommended Action None.

341002

Error Message `%ASA-6-341002: Policy Agent stopped successfully for VNMC vnmc_ip_addr`

Explanation The policy agent processes (DME, ducatiAG, and commonAG) were stopped.

- *vnmc_ip_addr*—-The IP address of the VNMC server

Recommended Action None.

341003

Error Message `%ASA-3-341003: Policy Agent failed to start for VNMC vnmc_ip_addr`

Explanation The policy agent failed to start.

- *vnmc_ip_addr*—-The IP address of the VNMC server

Recommended Action Check for console history and the disk0:/pa/log/vnm_pa_error_status for error messages. To retry starting the policy agent, issue the **registration host** command again.

341004

Error Message `%ASA-3-341004: Storage device not available: Attempt to shutdown module %s failed.`

Explanation All SSDs have failed or been removed with the system in Up state. The system has attempted to shut down the software module, but that attempt has failed.

- *%s*—The software module (for example, cxsc)

Recommended Action Replace the remved or failed drive and reload the ASA.

341005

Error Message `%ASA-3-341005: Storage device not available. Shutdown issued for module %s.`

Explanation All SSDs have failed or been removed with the system in Up state. The system is shutting down the software module.

- *%s*—The software module (for example, cxsc)

Recommended Action Replace the removed or failed drive and reload the software module.

341006

Error Message `%ASA-3-341006: Storage device not available. Failed to stop recovery of module %s.`

Explanation All SSDs have failed or been removed with the system in recorvery state. The system attempted to stop the recover, but that attempt failed.

- *%s*—The software module (for example, cxsc)

Recommended Action Replace the removed or failed drive and reload the ASA.

341007

Error Message `%ASA-3-341007: Storage device not available. Further recovery of module %s was stopped. This may take several minutes to complete.`

Explanation All SSDs have failed or been removed with the system in recovery state. The system is stopping the recovery of the softwaremodule.

- *%s*—The software module (for example, cxsc)

Recommended Action Replace the removed or failed drive and reload the software module.

341008

Error Message `%ASA-3-341008: Storage device not found. Auto-boot of module %s cancelled. Install drive and reload to try again.`

Explanation After getting the system into Up state, all SSDs have failed or been removed before reloading the system. Because the default action during boot is to auto-boot the software module, that action is blocked because there is no storage device available.

Recommended Action Replace the removed or failed drive and reload the software module.

341010

Error Message `%ASA-6-341010: Storage device with serial number ser_no [inserted into | removed from] bay bay_no`

Explanation The ASA has detected insertion or removal events and generates this syslog message immediately.

Recommended Action None required.

341011

Error Message `%ASA-3-341011: Storage device with serial number ser_no in bay bay_no faulty.`

Explanation The ASA polls the hard disk drive (HDD) health status every 10 minutes and generates this syslog message if the HDD is in a failed state.

Recommended Action None required.

Messages 400000 to 450001

This section includes messages from 400000 to 450001.

4000*nn*

Error Message `%ASA-4-4000nn: IPS:number string from IP_address to IP_address on interface interface_name`

Explanation Messages 400000 through 400051 are Cisco Intrusion Prevention Service signature messages.

Recommended Action See the *Cisco Intrusion Prevention Service User Guide* on Cisco.com.

Not all signature messages are supported by the ASA in this release. IPS messages all start with 4-4000*nn* and have the following format:

number The signature number. For more information, see the *Cisco Intrusion Prevention Service User Guide* on Cisco.com.

string The signature message—approximately the same as the NetRanger signature message.

IP_address The local to remote address to which the signature applies.

interface_name The name of the interface on which the signature originated.

For example:

```
%ASA-4-400013 IPS:2003 ICMP redirect from 10.4.1.2 to 10.2.1.1 on interface dmz
%ASA-4-400032 IPS:4051 UDP Snork attack from 10.1.1.1 to 192.168.1.1 on interface outside
```

Table 1-5 lists the supported signature messages.

Table 1-5 IPS Syslog Messages

Message Number	Signature ID	Signature Title	Signature Type
400000	1000	IP options-Bad Option List	Informational
400001	1001	IP options-Record Packet Route	Informational
400002	1002	IP options-Timestamp	Informational
400003	1003	IP options-Security	Informational
400004	1004	IP options-Loose Source Route	Informational
400005	1005	IP options-SATNET ID	Informational
400006	1006	IP options-Strict Source Route	Informational
400007	1100	IP Fragment Attack	Attack
400008	1102	IP Impossible Packet	Attack
400009	1103	IP Fragments Overlap	Attack
400010	2000	ICMP Echo Reply	Informational
400011	2001	ICMP Host Unreachable	Informational
400012	2002	ICMP Source Quench	Informational
400013	2003	ICMP Redirect	Informational
400014	2004	ICMP Echo Request	Informational
400015	2005	ICMP Time Exceeded for a Datagram	Informational
400016	2006	ICMP Parameter Problem on Datagram	Informational
400017	2007	ICMP Timestamp Request	Informational
400018	2008	ICMP Timestamp Reply	Informational
400019	2009	ICMP Information Request	Informational
400020	2010	ICMP Information Reply	Informational
400021	2011	ICMP Address Mask Request	Informational
400022	2012	ICMP Address Mask Reply	Informational

Table 1-5 IPS Syslog Messages (continued)

Message Number	Signature ID	Signature Title	Signature Type
400023	2150	Fragmented ICMP Traffic	Attack
400024	2151	Large ICMP Traffic	Attack
400025	2154	Ping of Death Attack	Attack
400026	3040	TCP NULL flags	Attack
400027	3041	TCP SYN+FIN flags	Attack
400028	3042	TCP FIN only flags	Attack
400029	3153	FTP Improper Address Specified	Informational
400030	3154	FTP Improper Port Specified	Informational
400031	4050	UDP Bomb attack	Attack
400032	4051	UDP Snork attack	Attack
400033	4052	UDP Chargen DoS attack	Attack
400034	6050	DNS HINFO Request	Informational
400035	6051	DNS Zone Transfer	Informational
400036	6052	DNS Zone Transfer from High Port	Informational
400037	6053	DNS Request for All Records	Informational
400038	6100	RPC Port Registration	Informational
400039	6101	RPC Port Unregistration	Informational
400040	6102	RPC Dump	Informational
400041	6103	Proxied RPC Request	Attack
400042	6150	ypserv (YP server daemon) Portmap Request	Informational
400043	6151	ypbind (YP bind daemon) Portmap Request	Informational
400044	6152	yppasswdd (YP password daemon) Portmap Request	Informational
400045	6153	ypupdated (YP update daemon) Portmap Request	Informational
400046	6154	ypxfrd (YP transfer daemon) Portmap Request	Informational
400047	6155	mountd (mount daemon) Portmap Request	Informational
400048	6175	rexd (remote execution daemon) Portmap Request	Informational
400049	6180	rexd (remote execution daemon) Attempt	Informational
400050	6190	statd Buffer Overflow	Attack

401001

Error Message `%ASA-4-401001: Shuns cleared`

Explanation The **clear shun** command was entered to remove existing shuns from memory. An institution to keep a record of shunning activity was allowed.

Recommended Action None required.

401002

Error Message `%ASA-4-401002: Shun added: IP_address` *`IP_address`* `port` *`port`*

Explanation A **shun** command was entered, where the first IP address is the shunned host. The other addresses and ports are optional and are used to terminate the connection if available. An institution to keep a record of shunning activity was allowed.

Recommended Action None required.

401003

Error Message `%ASA-4-401003: Shun deleted:` *`IP_address`*

Explanation A single shunned host was removed from the shun database. An institution to keep a record of shunning activity was allowed.

Recommended Action None required.

401004

Error Message `%ASA-4-401004: Shunned packet:` *`IP_address`* `=` *`IP_address`* `on interface` *`interface_name`*

Explanation A packet was dropped because the host defined by IP SRC is a host in the shun database. A shunned host cannot pass traffic on the interface on which it is shunned. For example, an external host on the Internet can be shunned on the outside interface. A record of the activity of shunned hosts was provided. This message and message %ASA-4-401005 can be used to evaluate further risk concerning this host.

Recommended Action None required.

401005

Error Message `%ASA-4-401005: Shun add failed: unable to allocate resources for IP_address IP_address port port`

Explanation The ASA is out of memory; a shun cannot be applied.

Recommended Action The Cisco IPS should continue to attempt to apply this rule. Try to reclaim memory and reapply a shun manually, or wait for the Cisco IPS to do this.

402114

Error Message `%ASA-4-402114: IPSEC: Received an protocol packet (SPI=spi, sequence number=seq_num) from remote_IP to local_IP with an invalid SPI.`

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *local_IP*—IP address of the local endpoint of the tunnel

Explanation An IPsec packet was received that specifies an SPI that does not exist in the SA database. This may be a temporary condition caused by slight differences in aging of SAs between the IPsec peers, or it may be because the local SAs have been cleared. It may also indicate incorrect packets sent by the IPsec peer, which may be part of an attack. This message is rate limited to no more than one message every five seconds.

Recommended Action The peer may not acknowledge that the local SAs have been cleared. If a new connection is established from the local router, the two peers may then reestablish connection successfully. Otherwise, if the problem occurs for more than a brief period, either attempt to establish a new connection or contact the peer administrator.

402115

Error Message `%ASA-4-402115: IPSEC: Received a packet from remote_IP to local_IP containing act_prot data instead of exp_prot data.`

Explanation An IPsec packet was received that is missing the expected ESP header. The peer is sending packets that do not match the negotiated security policy, which may indicate an attack. This message is rate limited to no more than one message every five seconds.

- *remote_IP*—IP address of the remote endpoint of the tunnel
- *local_IP*—IP address of the local endpoint of the tunnel
- *act_prot*—Received IPsec protocol

- *exp_prot*—Expected IPsec protocol

Recommended Action Contact the administrator of the peer.

402116

Error Message `%ASA-4-402116: IPSEC: Received an protocol packet (SPI=spi, sequence number=seq_num) from remote_IP (username) to local_IP. The decapsulated inner packet doesn't match the negotiated policy in the SA. The packet specifies its destination as pkt_daddr, its source as pkt_saddr, and its protocol as pkt_prot. The SA specifies its local proxy as id_daddr/id_dmask/id_dprot/id_dport and its remote proxy as id_saddr/id_smask/id_sprot/id_sport.`

Explanation A decapsulated IPsec packet does not match the negotiated identity. The peer is sending other traffic through this security association, which may be caused by a security association selection error by the peer, or it may be part of an attack. This message is rate limited to no more than one message every five seconds.

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *local_IP*—IP address of the local endpoint of the tunnel
- *pkt_daddr*—Destination address from the decapsulated packet
- *pkt_saddr*—Source address from the decapsulated packet
- *pkt_prot*—Transport protocol from the decapsulated packet
- *id_daddr*—Local proxy IP address
- *id_dmask*—Local proxy IP subnet mask
- *id_dprot*—Local proxy transport protocol
- *id_dport*—Local proxy port
- *id_saddr*—Remote proxy IP address
- *id_smask*—Remote proxy IP subnet mask
- *id_sprot*—Remote proxy transport protocol
- *id_sport*—Remote proxy port

Recommended Action Contact the administrator of the peer and compare policy settings.

402117

Error Message `%ASA-4-402117: IPSEC: Received a non-IPsec (protocol) packet from remote_IP to local_IP.`

Explanation The received packet matched the crypto map ACL, but it is not IPsec-encapsulated. The IPsec peer is sending unencapsulated packets. This error can occur because of a policy setup error on the peer. For example, the firewall may be configured to only accept encrypted Telnet traffic to the outside interface port 23. If you attempt to use Telnet without IPsec encryption to access the outside interface on port 23, this message appears, but not with Telnet or traffic to the outside interface on ports other than 23. This error can also indicate an attack. This message is not generated except under these conditions (for example, it is not generated for traffic to the ASA interfaces themselves). See messages 710001, 710002, and 710003, which track TCP and UDP requests. This message is rate limited to no more than one message every five seconds.

- *protocol*—IPsec protocol
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *local_IP*—IP address of the local endpoint of the tunnel

Recommended Action Contact the administrator of the peer to compare policy settings.

402118

Error Message `%ASA-4-402118: IPSEC: Received an protocol packet (SPI=spi, sequence number seq_num) from remote_IP (username) to local_IP containing an illegal IP fragment of length frag_len with offset frag_offset.`

Explanation A decapsulatd IPsec packet included an IP fragment with an offset less than or equal to 128 bytes. The latest version of the security architecture for IP RFC recommends 128 bytes as the minimum IP fragment offset to prevent reassembly attacks. This may be part of an attack. This message is rate limited to no more than one message every five seconds.

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *local_IP*—IP address of the local endpoint of the tunnel
- *frag_len*—IP fragment length
- *frag_offset*—IP fragment offset in bytes

Recommended Action Contact the administrator of the remote peer to compare policy settings.

402119

Error Message `%ASA-4-402119: IPSEC: Received an protocol packet (SPI=spi, sequence number=seq_num) from remote_IP (username) to local_IP that failed anti-replay checking.`

Explanation An IPsec packet was received with an invalid sequence number. The peer is sending packets including sequence numbers that may have been previously used. This message indicates that an IPsec packet has been received with a sequence number outside of the acceptable window. This packet will be dropped by IPsec as part of a possible attack. This message is rate limited to no more than one message every five seconds.

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *local_IP*—IP address of the local endpoint of the tunnel

Recommended Action Contact the administrator of the peer.

402120

Error Message `%ASA-4-402120: IPSEC: Received an protocol packet (SPI=spi, sequence number=seq_num) from remote_IP (username) to local_IP that failed authentication.`

Explanation An IPsec packet was received and failed authentication. The packet is dropped. The packet may have been corrupted in transit, or the peer may be sending invalid IPsec packets, which may indicate an attack if many of these packets were received from the same peer. This message is rate limited to no more than one message every five seconds.

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *remote_IP*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *local_IP*—IP address of the local endpoint of the tunnel

Recommended Action Contact the administrator of the remote peer if many failed packets were received.

402121

Error Message `%ASA-4-402121: IPSEC: Received an protocol packet (SPI=spi, sequence number=seq_num) from peer_addr (username) to lcl_addr that was dropped by IPsec (drop_reason).`

Explanation An IPsec packet to be decapsulated was received and subsequently dropped by the IPsec subsystem. This may indicate a problem with the ASA configuration or with the ASA itself.

- *protocol*—IPsec protocol
- *spi*—IPsec Security Parameter Index
- *seq_num*—IPsec sequence number
- *peer_addr*—IP address of the remote endpoint of the tunnel
- *username*—Username associated with the IPsec tunnel
- *lcl_addr*—IP address of the local endpoint of the tunnel
- *drop_reason*—Reason that the packet was dropped

Recommended Action If the problem persists, contact the Cisco TAC.

402122

Error Message `%ASA-4-402122: Received a cleartext packet from src_addr to dest_addr that was to be encapsulated in IPsec that was dropped by IPsec (drop_reason).`

Explanation A packet to be encapsulated in IPsec was received and subsequently dropped by the IPsec subsystem. This may indicate a problem with the ASA configuration or with the ASA itself.

- *src_addr*—Source IP address
- *dest_addr*—Destination IP address
- *drop_reason*—Reason that the packet was dropped

Recommended Action If the problem persists, contact the Cisco TAC.

402123

Error Message `%ASA-4-402123: CRYPTO: The accel_type hardware accelerator encountered an error (code=error_string) while executing crypto command command.`

Explanation An error was detected while running a crypto command with a hardware accelerator, which may indicate a problem with the accelerator. This type of error may occur for a variety of reasons, and this message supplements the crypto accelerator counters to help determine the cause.

- *accel_type*—Hardware accelerator type
- *error_string*—Code indicating the type of error

- *command*—Crypto command that generated the error

Recommended Action If the problem persists, contact the Cisco TAC.

402124

Error Message `%ASA-4-402124: CRYPTO: The ASA hardware accelerator encountered an error (Hardware error address, Core, Hardware error code, IstatReg, PciErrReg, CoreErrStat, CoreErrAddr, Doorbell Size, DoorBell Outstanding, SWReset).`

Explanation The crypto hardware chip has reported a fatal error, indicating that the chip is inoperable. The information from this message captures the details to allow further analysis of the problem. The crypto chip is reset when this condition is detected to unobtrusively allow the ASA to continue functioning. Also, the crypto environment at the time this issue is detected is written to a crypto archive directory on flash to provide further debugging information. Various parameters related to the crypto hardware are included in this message, as follows:

- HWErrAddr—Hardware address (set by crypto chip)
- Core—Crypto core experiencing the error
- HwErrCode—Hardware error code (set by crypto chip)
- IstatReg—Interrupt status register (set by crypto chip)
- PciErrReg—PCI error register (set by crypto chip)
- CoreErrStat—Core error status (set by crypto chip)
- CoreErrAddr—Core error address (set by crypto chip)
- Doorbell Size—Maximum crypto commands allowed
- DoorBell Outstanding—Crypto commands outstanding
- SWReset—Number of crypto chip resets since boot

Recommended Action Forward the message information to the Cisco TAC for further analysis.

402125

Error Message `%ASA-4-402125: The ASA hardware accelerator` *`ring`* `timed out (`*`parameters`*`).`

Explanation The crypto driver has detected that either the IPSEC descriptor ring or SSL/Admin descriptor ring is no longer progressing, meaning the crypto chip no longer appears to be functioning. The crypto chip is reset when this condition is detected to unobtrusively allow the ASA to continue functioning. Also, the crypto environment at the time this issue was detected was written to a crypto archive directory on flash to provide further debugging information.

- *ring*—IPSEC or Admin ring
- *parameters*—Include the following:

  - Desc—Descriptor address

  - CtrlStat—Control/status value

- ResultP—Success pointer
- ResultVal—Success value
- Cmd—Crypto command
- CmdSize—Command size
- Param—Command parameters
- Dlen—Data length
- DataP—Data pointer
- CtxtP—VPN context pointer
- SWReset—Number of crypto chip resets since boot

Recommended Action Forward the message information to the Cisco TAC for further analysis.

402126

Error Message `%ASA-4-402126: CRYPTO: The ASA created Crypto Archive File` *`Archive Filename`* `as a Soft Reset was necessary. Please forward this archived information to Cisco.`

Explanation A functional problem with the hardware crypto chip was detected (see syslog messages 402124 and 402125). To further debug the crypto problem, a crypto archive file was generated that included the current crypto hardware environment (hardware registers and crypto description entries). At boot time, a crypto_archive directory was automatically created on the flash file system (if it did not exist previously). A maximum of two crypto archive files are allowed to exist in this directory.

- *Archive Filename*—The name of the crypto archive file name. The crypto archive file names are of the form, crypto_arch_x.bin, where x = (1 or 2).

Recommended Action Forward the crypto archive files to the Cisco TAC for further analysis.

402127

Error Message `%ASA-4-402127: CRYPTO: The ASA is skipping the writing of latest Crypto Archive File as the maximum # of files,` *`max_number,`* `allowed have been written to` *`archive_directory`*`. Please archive & remove files from` *`Archive Directory`* `if you want more Crypto Archive Files saved.`

Explanation A functional problem with the hardware crypto chip was detected (see messages 4402124 and 4402125). This message indicates a crypto archive file was not written, because the maximum number of crypto archive files already existed.

- *max_number*—Maximum number of files allowed in the archive directory; currently set to two
- *archive_directory*—Name of the archive directory

Recommended Action Forward previously generated crypto archive files to the Cisco TAC. Remove the previously generated archive file(s) so that more can be written (if deemed necessary).

402128

Error Message `%ASA-5-402128: CRYPTO: An attempt to allocate a large memory block failed, size: size, limit: limit`

Explanation An SSL connection is attempting to use more memory than allowed. The request has been denied.

- *size*—The size of the memory block being allocated
- *limit*—The maximum size of allocated memory permitted

Recommended Action If this message persists, an SSL denial of service attack may be in progress. Contact the remote peer administrator or upstream provider.

402129

Error Message `%ASA-6-402129: CRYPTO: An attempt to release a DMA memory block failed, location: address`

Explanation An internal software error has occurred.

- *address*—The address being freed

Recommended Action Contact the Cisco TAC for assistance.

402130

Error Message `%ASA-6-402130: CRYPTO: Received an ESP packet (SPI = 0x54A5C634, sequence number=0x7B) from 75.2.96.101 (user=user) to 85.2.96.10 with incorrect IPsec padding.`

Explanation The ASA crypto hardware accelerator detected an IPsec packet with invalid padding. The ATT VPN client sometimes pads IPsec packets incorrectly.

- *SPI*—The SPI associated with the packet
- *sequence number*—The sequence number associated with the packet
- *user*—Username string
- *padding*—Padding data from the packet

Recommended Action While this message is None required and does not indicate a problem with the ASA, customers using the ATT VPN client may wish to upgrade their VPN client software.

402131

Error Message `%ASA-4-402131: CRYPTO: status changing the accel_instance hardware accelerator's configuration bias from old_config_bias to new_config_bias.`

Explanation The hardware accelerator configuration has been changed on the ASA. Some ASA platforms have multiple hardware accelerators. One syslog message is generated for each hardware accelerator change.

- *status*—Indicates success or failure
- *accel_instance*—The instance of the hardware accelerator
- *old_config_bias*—The old configuration
- *new_config_bias*—The new configuration

Recommended Action If any of the accelerators fails when attempting to change its configuration, collect logging information and contact the Cisco TAC. If a failure occurs, the software will retry the configuration change multiple times. The software will fall back to the original configuration bias if the retry attempts fail. If multiple attempts to reconfigure the hardware accelerator fail, it may indicate a hardware failure.

402140

Error Message `%ASA-3-402140: CRYPTO: RSA key generation error: modulus len len`

Explanation An error occurred during an RSA public key pair generation.

- *len*—The prime modulus length in bits

Recommended Action Contact the Cisco TAC for assistance.

402141

Error Message `%ASA-3-402141: CRYPTO: Key zeroization error: key set type, reason reason`

Explanation An error occurred during an RSA public key pair generation.

- *type*—The key set type, which can be any of the following: DH, RSA, DSA, or unknown
- *reason*—The unexpected crypto session type

Recommended Action Contact the Cisco TAC for assistance.

402142

Error Message `%ASA-3-402142: CRYPTO: Bulk data op error: algorithm alg, mode mode`

Explanation An error occurred during a symmetric key operation.

- *op*—The operation, which can be either encryption or decryption
- *alg*—The encryption algorithm, which can be any of the following: DES, 3DES, AES, or RC4
- *mode*—The mode, which can be any of the following: CBC, CTR, CFB, ECB, stateful-RC4, or stateless-RC4

Recommended Action Contact the Cisco TAC for assistance.

402143

Error Message `%ASA-3-402143: CRYPTO: alg type key op`

Explanation An error occurred during an asymmetric key operation.

- *alg*—The encryption algorithm, which can be either RSA or DSA
- *type*—The key type, which can be either public or private
- *op*—The operation, which can be either encryption or decryption

Recommended Action Contact the Cisco TAC for assistance.

402144

Error Message `%ASA-3-402144: CRYPTO: Digital signature error: signature algorithm sig, hash algorithm hash`

Explanation An error occurred during digital signature generation.

- *sig*—The signature algorithm, which can be either RSA or DSA
- *hash*—The hash algorithm, which can be any of the following: MD5, SHA1, SHA256, SHA384, or SHA512

Recommended Action Contact the Cisco TAC for assistance.

402145

Error Message `%ASA-3-402145: CRYPTO: Hash generation error: algorithm hash`

Explanation A hash generation error occurred.

- *hash*—The hash algorithm, which can be any of the following: MD5, SHA1, SHA256, SHA384, or SHA512

Recommended Action Contact the Cisco TAC for assistance.

402146

Error Message `%ASA-3-402146: CRYPTO: Keyed hash generation error: algorithm hash, key len len`

Explanation A keyed hash generation error occurred.

- *hash*—The hash algorithm, which can be any of the following: MD5, SHA1, SHA256, SHA384, or SHA512
- *len*—The key length in bits

Recommended Action Contact the Cisco TAC for assistance.

402147

Error Message `%ASA-3-402147: CRYPTO: HMAC generation error: algorithm alg`

Explanation An HMAC generation error occurred.

- *alg*—The HMAC algorithm, which can be any of the following: HMAC-MD5, HMAC-SHA1, HMAC-SHA2, or AES-XCBC

Recommended Action Contact the Cisco TAC for assistance.

402148

Error Message `%ASA-3-402148: CRYPTO: Random Number Generator error`

Explanation A random number generator error occurred.

Recommended Action Contact the Cisco TAC for assistance.

403101

Error Message `%ASA-4-403101: PPTP session state not established, but received an XGRE packet, tunnel_id=`*`number`*`, session_id=`*`number`*

Explanation The ASA received a PPTP XGRE packet without a corresponding control connection session.

Recommended Action If the problem persists, contact the Cisco TAC.

403102

Error Message `%ASA-4-403102: PPP virtual interface `*`interface_name`*` rcvd pkt with invalid protocol: `*`protocol`*`, reason: `*`reason`*`.`

Explanation The module received an XGRE encapsulated PPP packet with an invalid protocol field.

Recommended Action If the problem persists, contact the Cisco TAC.

403103

Error Message `%ASA-4-403103: PPP virtual interface max connections reached.`

Explanation The module cannot accept additional PPTP connections.Connections are allocated as soon as they are available.

Recommended Action None required.

403104

Error Message `%ASA-4-403104: PPP virtual interface `*`interface_name`*` requires mschap for MPPE.`

Explanation The MPPE was configured, but MS-CHAP authentication was not.

Recommended Action Add MS-CHAP authentication with the **vpdn group** *group_name* **ppp authentication** command.

403106

Error Message `%ASA-4-403106: PPP virtual interface interface_name requires RADIUS for MPPE.`

Explanation The MPPE was configured, but RADIUS authentication was not.

Recommended Action Add RADIUS authentication with the **vpdn group** *group_name* **ppp authentication** command.

403107

Error Message `%ASA-4-403107: PPP virtual interface interface_name missing aaa server group info`

Explanation The AAA server configuration information cannot be found.

Recommended Action Add the AAA server information with the **vpdn group** *group_name* **client authentication aaa** *aaa_server_group* command.

403108

Error Message `%ASA-4-403108: PPP virtual interface interface_name missing client ip address option`

Explanation The client IP address pool information is missing.

Recommended Action Add IP address pool information with the **vpdn group** *group_name* **client configuration address local** *address_pool_name* command.

403109

Error Message `%ASA-4-403109: Rec'd packet not an PPTP packet. (ip) dest_address=dest_address, src_addr= source_address, data: string.`

Explanation The module received a spoofed PPTP packet, which may indicate a hostile event.

Recommended Action Contact the administrator of the peer to check the PPTP configuration settings.

403110

Error Message `%ASA-4-403110: PPP virtual interface interface_name, user: user missing MPPE key from aaa server.`

Explanation The AAA server was not returning the MPPE key attributes required to set up the MPPE encryption policy.

Recommended Action Check the AAA server configuration. If the AAA server cannot return MPPE key attributes, use local authentication instead by entering the **vpdn group** *group_name* **client authentication local** command.

403500

Error Message `%ASA-6-403500: PPPoE - Service name 'any' not received in PADO. Intf:interface_name AC:ac_name.`

Explanation The ASA requested the PPPoE service *any* from the access controller at the Internet service provider. The response from the service provider includes other services, but does not include the service *any*. This is a discrepancy in the implementation of the protocol. The PADO packet is processed normally, and connection negotiations continue.

Recommended Action None required.

403501

Error Message `%ASA-3-403501: PPPoE - Bad host-unique in PADO - packet dropped. Intf:interface_name AC:ac_name`

Explanation The ASA sent an identifier called the host-unique value to the access controller. The access controller responded with a different host-unique value. The ASA was unable to identify the corresponding connection request for this response. The packet was dropped, and connection negotiations were discontinued.

Recommended Action Contact the Internet service provider. Either the access controller at the service provider is mishandling the host-unique value, or the PADO packet is being forged.

403502

Error Message `%ASA-3-403502: PPPoE - Bad host-unique in PADS - dropping packet. Intf:`*`interface_name`* `AC:`*`ac_name`*

Explanation The ASA sent an identifier called the host-unique value to the access controller. The access controller responded with a different host-unique value. The ASA was unable to identify the corresponding connection request for this response. The packet was dropped, and connection negotiations were discontinued.

Recommended Action Contact the Internet service provider. Either the access controller at the service provider is mishandling the host-unique value, or the PADO packet is being forged.

403503

Error Message `%ASA-3-403503: PPPoE:PPP link down:`*`reason`*

Explanation The PPP link has gone down. There are many reasons why this can happen. The first format will display a reason if PPP provides one.

Recommended Action Check the network link to ensure that the link is connected. The access concentrator may be down. Make sure that your authentication protocol matches the access concentrator and that your name and password are correct. Verify this information with your ISP or network support person.

403504

Error Message `%ASA-3-403504: PPPoE:No 'vpdn group `*`group_name`*`' for PPPoE is created`

Explanation PPPoE requires a dial-out configuration before starting a PPPoE session. In general, the configuration should specify a dialing policy, the PPP authentication, the username, and a password. The following example configures the ASA for PPPoE dialout. The **my-username** and **my-password** commands are used to authenticate the access concentrator, using PAP if necessary.

For example:

```
hostname# vpdn group my-pppoe request dialout pppoe
hostname# vpdn group my-pppoe ppp authentication pap
hostname# vpdn group my-pppoe localname my-username
hostname# vpdn username my-username password my-password
hostname# ip address outside pppoe setroute
```

Recommended Action Configure a VPDN group for PPPoE.

403505

Error Message `%ASA-4-403505: PPPoE:PPP - Unable to set default route to IP_address at interface_name`

Explanation This message is usually followed by the message, default route already exists.

Recommended Action Remove the current default route or remove the *setroute* parameter so that there is no conflict between PPPoE and the manually configured route.

403506

Error Message `%ASA-4-403506: PPPoE:failed to assign PPP IP_address netmask netmask at interface_name`

Explanation This message is followed by one of the followings messages: subnet is the same as interface, or on failover channel.

Recommended Action In the first case, change the address causing the conflict. In the second case, configure the PPPoE on an interface other than the failover interface.

403507

Error Message `%ASA-3-403507: PPPoE:PPPoE client on interface interface failed to locate PPPoE vpdn group group_name`

Explanation You can configure the PPPoE client on an interface to use a particular VPDN group by entering the **pppoe client vpdn group** *group_name* command. If a PPPoE VPDN group of the configured name was not located during system startup, this message is generated.

- *interface*—The interface on which the PPPoE client failed
- *group_name* —The VPDN group name of the PPPoe client on the interface

Recommended Action Perform the following steps:

1. Add the required VPDN group by entering the **vpdn group** *group_name* command. Request dialout PPPoE in global configuration mode, and add all the group properties.
2. Remove the **pppoe client vpdn group** *group_name* command from the interface indicated. In this case, the PPPoE client will attempt to use the first PPPoE VPDN group defined.

Note All changes take effect only after the PPPoE client on the interface is restarted by entering the **ip address pppoe** command.

405001

Error Message `%ASA-4-405001: Received ARP {request | response} collision from IP_address/MAC_address on interface interface_name to IP_address/MAC_address on interface interface_name`

Explanation The ASA received an ARP packet, and the MAC address in the packet differs from the ARP cache entry.

Recommended Action This traffic might be legitimate, or it might indicate that an ARP poisoning attack is in progress. Check the source MAC address to determine where the packets are coming from and to see if they belong to a valid host.

405003

Error Message `%ASA-4-405003: IP address collision detected between host IP_address at MAC_address and interface interface_name, MAC_address.`

Explanation A client IP address in the network is the same as the ASA interface IP address.

Recommended Action Change the IP address of the client.

405101

Error Message `%ASA-4-405101: Unable to Pre-allocate H225 Call Signalling Connection for foreign_address outside_address[/outside_port] to local_address inside_address[/inside_port]`

Explanation The module failed to allocate RAM system memory while starting a connection or has no more address translation slots available.

Recommended Action If this message occurs periodically, it can be ignored. You can check the size of the global pool compared to the number of inside network clients. A PAT address may be necessary. Alternatively, shorten the timeout interval of translates and connections. This error message may also be caused by insufficient memory; try reducing the amount of memory usage, or purchasing additional memory. If the problem persists, contact the Cisco TAC.

405002

Error Message `%ASA-4-405002: Received mac mismatch collision from IP_address/MAC_address for authenticated host`

Explanation This packet appears for one of the following conditions:

- The ASA received a packet with the same IP address, but a different MAC address from one of its uauth entries.

- You configured the **vpnclient mac-exempt** command on the ASA, and the ASA received a packet with an exempt MAC address, but a different IP address from the corresponding uauth entry.

Recommended Action This traffic might be legitimate, or it might indicate that a spoofing attack is in progress. Check the source MAC address and IP address to determine where the packets are coming from and if they belong to a valid host.

405101

Error Message `%ASA-4-405101: Unable to Pre-allocate H225 Call Signalling Connection for foreign_address outside_address[/outside_port] to local_address inside_address[/inside_port]`

Explanation The ASA failed to allocate RAM system memory while starting a connection or has no more address translation slots available.

Recommended Action Check the size of the global pool compared to the number of inside network clients. A PAT address may be necessary. Alternatively, shorten the timeout interval of translations and connections. Also, reduce the amount of memory usage, or purchase additional memory. If this message occurs periodically, it can be ignored. If the problem persists, contact the Cisco TAC.

405102

Error Message `%ASA-4-405102: Unable to Pre-allocate H245 Connection for foreign_address outside_address[/outside_port] to local_address inside_address[/inside_port]`

Explanation The ASA failed to allocate RAM system memory while starting a connection or has no more address translation slots available.

Recommended Action Check the size of the global pool compared to the number of inside network clients. A PAT address may be necessary. Alternatively, shorten the timeout interval of translations and connections. In addition, reduce the amount of memory usage, or purchase additional memory. If this message occurs periodically, it can be ignored. If the problem persists, contact the Cisco TAC.

405103

Error Message `%ASA-4-405103: H225 message from source_address/source_port to dest_address/dest_port contains bad protocol discriminator hex`

Explanation The ASA is expecting the protocol discriminator, 0x08, but it received something other than 0x08. The endpoint may be sending a bad packet, or received a message segment other than the first segment. The packet is allowed through.

Recommended Action None required.

405104

Error Message `%ASA-4-405104: H225 message received from outside_address/outside_port to inside_address/inside_port before SETUP`

Explanation An H.225 message was received out of order, before the initial SETUP message, which is not allowed. The ASA must receive an initial SETUP message for that H.225 call signalling channel before accepting any other H.225 messages.

Recommended Action None required.

405105

Error Message `%ASA-4-405105: H323 RAS message AdmissionConfirm received from source_address/source_port to dest_address/dest_port without an AdmissionRequest`

Explanation A gatekeeper has sent an ACF, but the ASA did not send an ARQ to the gatekeeper.

Recommended Action Check the gatekeeper with the specified *source_address* to determine why it sent an ACF without receiving an ARQ from the ASA.

405106

Error Message `%ASA-4-405106: H323 num channel is not created from %I/%d to %I/%d %s`

Explanation The ASA tried to create a match condition on the H.323 media-type channel. See the **match media-type** command for more information.

Recommended Action None required.

405107

Error Message `%ASA-4-405107: H245 Tunnel is detected and connection dropped from %I/%d to %I/%d %s`

Explanation An H.323 connection has been dropped because of an attempted H.245 tunnel control during call setup. See the **h245-tunnel-block** command for more information.

Recommended Action None required.

405201

Error Message `%ASA-4-405201: ILS ILS_message_type from inside_interface:source_IP_address to outside_interface:/destination_IP_address has wrong embedded address embedded_IP_address`

Explanation The embedded address in the ILS packet payload was not the same as the source IP address of the IP packet header.

Recommended Action Check the host specified with the *source_IP_address* to determine why it sent an ILS packet with an incorrect embedded IP address.

405300

Error Message `%ASA-4-405300: Radius Accounting Request received from from_addr is not allowed`

Explanation The accounting request came from a host that was not configured in the policy map. The message is logged and processing stops.

- *from_addr*—The IP address of the host sending the request

Recommended Action If the host was configured to send RADIUS accounting messages to the ASA, make sure that it was configured in the correct policy map that was applied to the service policy. If the host was not configured to send RADIUS accounting messages to the ASA, then check to see why the messages are being sent. If the messages are illegitimate, then create the proper ACLs to drop the packets.

405301

Error Message `%ASA-4-405301: Attribute attribute_number does not match for user user_ip`

Explanation When the **validate-attribute** command was entered, the attribute values stored in the accounting request start received do not match those stored in the entry, if it exists.

- *attribute_number*—The RADIUS attribute to be validated with RADIUS accounting. Values range from 1 to 191. Vendor-specific attributes are not supported.
- *user_ip*—The IP address (framed IP attribute) of the user.

Recommended Action None required.

406001

Error Message `%ASA-4-406001: FTP port command low port: IP_address/port to IP_address on interface interface_name`

Explanation A client entered an FTP port command and supplied a port less than 1024 (in the well-known port range usually devoted to server ports). This is indicative of an attempt to avert the site security policy. The ASA drops the packet, terminates the connection, and logs the event.

Recommended Action None required.

406002

Error Message `%ASA-4-406002: FTP port command different address: IP_address(IP_address) to IP_address on interface interface_name`

Explanation A client entered an FTP port command and supplied an address other than the address used in the connection. An attempt to avert the site security policy occurred. For example, an attacker might attempt to hijack an FTP session by changing the packet on the way, and putting different source information instead of the correct source information. The ASA drops the packet, terminates the connection, and logs the event. The address in parentheses is the address from the port command.

Recommended Action None required.

407001

Error Message `%ASA-4-407001: Deny traffic for local-host interface_name:inside_address, license limit of number exceeded`

Explanation The host limit was exceeded. An inside host is counted toward the limit when one of the following conditions is true:

- The inside host has forwarded traffic through the ASA within the last five minutes.
- The inside host has reserved an xlate connection or user authentication at the ASA.

Recommended Action The host limit is enforced on the low-end platforms. Use the **show version** command to view the host limit. Use the **show local-host** command to view the current active hosts and the inside users that have sessions at the ASA. To forcefully disconnect one or more users, use the **clear local-host** command. To expire the inside users more quickly from the limit, set the xlate, connection, and uauth timeouts to the recommended values or lower. (See Table 1-6.)

Table 1-6 Timeouts and Recommended Values

Timeout	Recommended Value
xlate	00:05:00 (five minutes)

Table 1-6 Timeouts and Recommended Values

Timeout	Recommended Value
conn	00:01:00 (one hour)
uauth	00:05:00 (five minutes)

407002

Error Message `%ASA-4-407002: Embryonic limit nconns/elimit for through connections exceeded.outside_address/outside_port to global_address (inside_address)/inside_port on interface interface_name`

Explanation The number of connections from a specified foreign address over a specified global address to the specified local address exceeded the maximum embryonic limit for that static. The ASA tries to accept the connection if it can allocate memory for that connection. It proxies on behalf of the local host and sends a SYN_ACK packet to the foreign host. The ASA retains pertinent state information, drops the packet, and waits for the acknowledgment from the client. The message might indicate legitimate traffic or that a DoS attack is in progress.

Recommended Action Check the source address to determine where the packets are coming from and whether or not a valid host is sending them.

407003

Error Message `%ASA-4-407003: Established limit for RPC services exceeded number`

Explanation The ASA tried to open a new hole for a pair of RPC servers or services that have already been configured after the maximum number of holes has been met.

Recommended Action Wait for other holes to be closed (through associated timeout expiration), or limit the number of active pairs of servers or services.

408001

Error Message `%ASA-4-408001: IP route counter negative - reason, IP_address Attempt: number`

Explanation An attempt to decrement the IP route counter into a negative value failed.

Recommended Action Enter the **clear ip route** command to reset the route counter. If the problem persists, contact the Cisco TAC.

408002

Error Message `%ASA-4-408002: ospf process id route type update address1 netmask1 [distance1/metric1] via source IP:interface1 address2 netmask2 [distance2/metric2] interface2`

Explanation A network update was received from a different interface with the same distance and a better metric than the existing route. The new route overrides the existing route that was installed through another interface. The new route is for redundancy purposes only and means that a path has shifted in the network. This change must be controlled through topology and redistribution. Any existing connections affected by this change are probably disabled and will time out. This path shift only occurs if the network topology has been specifically designed to support path redundancy, in which case it is expected.

Recommended Action None required.

408003

Error Message `%ASA-4-408003: can't track this type of object hex`

Explanation A component of the tracking system has encountered an object type that is not supported by the component. A STATE object was expected.

- *hex*—A hexidecimal value(s) depicting variable value(s) or addresses in memory

Recommended Action Reconfigure the track object to make it a STATE object.

409001

Error Message `%ASA-4-409001: Database scanner: external LSA IP_address netmask is lost, reinstalls`

Explanation The software detected an unexpected condition. The router will take corrective action and continue.

Recommended Action None required.

409002

Error Message `%ASA-4-409002: db_free: external LSA IP_address netmask`

Explanation An internal software error occurred.

Recommended Action None required.

409003

Error Message `%ASA-4-409003: Received invalid packet: reason from IP_address, interface_name`

Explanation An invalid OSPF packet was received. Details are included in the error message. The cause might be an incorrect OSPF configuration or an internal error in the sender.

Recommended Action Check the OSPF configuration of the receiver and the sender configuration for inconsistency.

409004

Error Message `%ASA-4-409004: Received reason from unknown neighbor IP_address`

Explanation The OSPF hello, database description, or database request packet was received, but the router cannot identify the sender.

Recommended Action None required.

409005

Error Message `%ASA-4-409005: Invalid length number in OSPF packet from IP_address (ID IP_address), interface_name`

Explanation The ASA received an OSPF packet with a field length of less than normal header size or that was inconsistent with the size of the IP packet in which it arrived. This indicates a configuration error in the sender of the packet.

Recommended Action From a neighboring address, locate the problem router and reboot it.

409006

Error Message `%ASA-4-409006: Invalid lsa: reason Type number, LSID IP_address from IP_address, IP_address, interface_name`

Explanation The router received an LSA with an invalid LSA type. The cause is either memory corruption or unexpected behavior on a router.

Recommended Action From a neighboring address, locate the problem router and reboot it. If the problem persists, contact the Cisco TAC.

409007

Error Message `%ASA-4-409007: Found LSA with the same host bit set but using different mask LSA ID IP_address netmask New: Destination IP_address netmask`

Explanation An internal software error occurred.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

409008

Error Message `%ASA-4-409008: Found generating default LSA with non-zero mask LSA type: number Mask: netmask metric: number area: string`

Explanation The router tried to generate a default LSA with an incorrect mask and possibly incorrect metric because an internal software error occurred.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

409009

Error Message `%ASA-4-409009: OSPF process number cannot start. There must be at least one up IP interface, for OSPF to use as router ID`

Explanation OSPF failed while attempting to allocate a router ID from the IP address of one of its interfaces.

Recommended Action Make sure that there is at least one interface that is up and has a valid IP address. If there are multiple OSPF processes running on the router, each requires a unique router ID. You must have enough interfaces up so that each of them can obtain a router ID.

409010

Error Message `%ASA-4-409010: Virtual link information found in non-backbone area: string`

Explanation An internal error occurred.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

409011

Error Message `%ASA-4-409011: OSPF detected duplicate router-id IP_address from IP_address on interface interface_name`

Explanation OSPF received a hello packet from a neighbor that has the same router ID as this routing process. A full adjacency cannot be established.

Recommended Action The OSPF router ID should be unique. Change the neighbor router ID.

409012

Error Message `%ASA-4-409012: Detected router with duplicate router ID IP_address in area string`

Explanation OSPF received a hello packet from a neighbor that has the same router ID as this routing process. A full adjacency cannot be established.

Recommended Action The OSPF router ID should be unique. Change the neighbor router ID.

409013

Error Message `%ASA-4-409013: Detected router with duplicate router ID IP_address in Type-4 LSA advertised by IP_address`

Explanation OSPF received a hello packet from a neighbor that has the same router ID as this routing process. A full adjacency cannot be established.

Recommended Action The OSPF router ID should be unique. Change the neighbor router ID.

409023

Error Message `%ASA-4-409023: Attempting AAA Fallback method method_name for request_type request for user user:Auth-server group server_tag unreachable`

Explanation An authentication or authorization attempt to an external server has failed and will be performed using the local user database.

- *aaa_operation*—Either authentication or authorization
- *username*—The user associated with the connection
- *server_group*—The name of the AAA server whose servers were unreachable

Recommended Action Investigate any connectivity problems with the AAA servers configured in the first method. Ping the authentication servers from the ASA. Make sure that the daemons are running on the AAA server.

409101

Error Message %ASA-4-409101: Received invalid packet: *s* from *P*, *s*

Explanation An invalid OSPF packet was received. Details are included in the error message. The cause might be a misconfigured OSPF or an internal error in the sender.

Recommended Action Check the OSPF configuration of the receiver and the sender for inconsistencies.

409102

Error Message %ASA-4-409102: Received packet with incorrect area from *P*, *s*, area *AREA_ID_STR*, packet area *AREA_ID_STR*

Explanation An OSPF packet was received with an area ID in its header that does not match the area of this interface.

Recommended Action Check the OSPF configuration of the receiver and the sender for inconsistencies.

409103

Error Message %ASA-4-409103: Received *s* from unknown neighbor *i*

Explanation An OSPF hello, database description, or database request packet was received, but the router could not identify the sender.

Recommended Action None required.

409104

Error Message %ASA-4-409104: Invalid length *d* in OSPF packet type *d* from P (ID *i*), *s*

Explanation The system received an OSPF packet with a length field of less than normal header size or inconsistent with the size of the IP packet in which it arrived. An error in the sender of the packet has occurred.

Recommended Action None required.

409105

Error Message `%ASA-4-409105: Invalid lsa: s: Type 0x x, Length 0x x, LSID u from i`

Explanation The router received an LSA with invalid data. The LSA includes an invalid LSA type, incorrect checksum, or incorrect length, which is caused by either memory corruption or unexpected behavior on a router.

Recommended Action From a neighboring address, locate the problem routerand do the following:

- Collect a running configuration of the router by entering the **show running-config** command.
- Enter the **show ipv6 ospf database** command to gather data that may help identify the nature of the error.
- Enter the **show ipv6 ospf database** *link-state-id* command. The *link-state-id* argument is the IP address of the invalid LSA.
- Enter the **show logging** command to gather data that may help identify the nature of the error.
- Reboot the router.

If you cannot determine the nature of the error from the collected information, contact the Cisco TAC and provide the gathered information.

409106

Error Message `%ASA-4-409106: Found generating default LSA with non-zero mask LSA type: 0x x Mask: i metric: lu area: AREA_ID_STR`

Explanation The router tried to generate the default LSA with the incorrect mask and possibly an incorrect metric because of an internal software error.

Recommended Action None required.

409107

Error Message `%ASA-4-409107: OSPFv3 process d could not pick a router-id, please configure manually`

Explanation OSPFv3 failed while attempting to allocate a router ID from the IP address of one of its interfaces.

Recommended Action Make sure that there is at least one interface that is up and has a valid IP address. If there are multiple OSPF processes running on the router, each requires a unique router ID. You must have enough up interfaces so that each of them can obtain a router ID.

409108

Error Message `%ASA-4-409108: Virtual link information found in non-backbone area: AREA_ID_STR`

Explanation An internal error has occurred.

Recommended Action None required.

409109

Error Message `%ASA-4-409109: OSPF detected duplicate router-id i from P on interface IF_NAME`

Explanation OSPF received a hello packet from a neighbor that has the same router ID as this routing process. A full adjacency cannot be established. The OSPF router ID should be unique.

Recommended Action Change the neighbor router ID.

409110

Error Message `%ASA-4-409110: Detected router with duplicate router ID i in area AREA_ID_STR`

Explanation OSPF received a hello packet from a neighbor that has the same router ID as this routing process. A full adjacency cannot be established. The OSPF router ID should be unique.

Recommended Action Change the neighbor router ID.

409111

Error Message `%ASA-4-409111: Multiple interfaces (IF_NAME/IF_NAME) on a single link detected.`

Explanation OSPFv3 enabled on multiple interfaces that are on the same link is not supported.

Recommended Action OSPFv3 should be disabled or made passive on all except one of the interfaces.

409112

Error Message `%ASA-4-409112: Packet not written to the output queue`

Explanation An internal error has occurred.

Recommended Action None required.

409113

Error Message `%ASA-4-409113: Doubly linked list linkage is NULL`

Explanation An internal error has occurred.

Recommended Action None required.

409114

Error Message `%ASA-4-409114: Doubly linked list prev linkage is NULL` *x*

Explanation An internal error has occurred.

Recommended Action None required.

409115

Error Message `%ASA-4-409115: Unrecognized timer` *d* `in OSPF` *s*

Explanation An internal error has occurred.

Recommended Action None required.

409116

Error Message `%ASA-4-409116: Error for timer` *d* `in OSPF process` *s*

Explanation An internal error has occurred.

Recommended Action None required.

409117

Error Message `%ASA-4-409117: Can't find LSA database type x, area AREA_ID_STR, interface x`

Explanation An internal error has occurred.

Recommended Action None required.

409118

Error Message `%ASA-4-409118: Could not allocate DBD packet`

Explanation An internal error has occurred.

Recommended Action None required.

409119

Error Message `%ASA-4-409119: Invalid build flag x for LSA i, type 0x x`

Explanation An internal error has occurred.

Recommended Action None required.

409120

Error Message `%ASA-4-409120: Router-ID i is in use by ospf process d`

Explanation The ASA attempted to assign a router ID that is in use by another process.

Recommended Action Configure another router ID for one of the processes.

409121

Error Message `%ASA-4-409121: Router is currently an ASBR while having only one area which is a stub area`

Explanation An ASBR must be attached to an area that can carry AS External or NSSA LSAs.

Recommended Action Make the area to which the router is attached into an NSSA or regular area.

409122

Error Message `%ASA-4-409122: Could not select a global IPv6 address. Virtual links require at least one global IPv6 address.`

Explanation A virtual link was configured. For the virtual link to function, a global IPv6 address must be available. However, no global IPv6 address could be found on the router.

Recommended Action Configure a global IPv6 address on an interface on this router.

409123

Error Message `%ASA-4-409123: Neighbor command allowed only on NBMA networks`

Explanation The **neighbor** command is allowed only on NBMA networks.

Recommended Action Check the configuration options for the **neighbor** command, and correct the options or the network type for the neighbor interface.

409125

Error Message `%ASA-4-409125: Can not use configured neighbor: poll and priority options are allowed only for a NBMA network`

Explanation The configured neighbor was found on a point-to-multipoint network and either the poll or priority option was configured. These options are only allowed on NBMA type networks.

Recommended Action Check the configuration options for the **neighbor** command, and correct the options or the network type for the neighbor interface.

409128

Error Message `%ASA-4-409128: OSPFv3-`*`d`*` Area `*`AREA_ID_STR`*`: Router `*`i`*` originating invalid type 0x `*`x`*` LSA, ID `*`u`*`, Metric `*`d`*` on Link ID `*`d`*` Link Type `*`d`*

Explanation The router indicated in this message has originated an LSA with an invalid metric. If this is a router LSA and the link metric is zero, a risk of routing loops and traffic loss exists in the network.

Recommended Action Configure a valid metric for the given LSA type and link type on the router that originated the reported LSA.

410001

Error Message `%ASA-4-410001: UDP DNS request from source_interface:source_address/source_port to dest_interface:dest_address/dest_port; (label length | domain-name length) 52 bytes exceeds remaining packet length of 44 bytes.`

Explanation The domain-name length exceeds 255 bytes in a UDP DNS packet. See RFC 1035, Section 3.1 for more information.

Recommended Action None required.

410002

Error Message `%ASA-2-410002: Dropped num DNS responses with mis-matched id in the past sec second(s): from src_ifc:sip/sport to dest_ifc:dip/dport`

Explanation The ASA detects an excess number of DNS responses with a mismatched DNS identifier. A high rate of mismatched DNS identifiers might indicate an attack on the cache. The threshold is set by the **id-mismatch** DNS policy-map parameter submode command.

- *num*—The number of ID mismatch instances as configured by the **id-mismatch** command
- *sec*—The duration in seconds as configured by the **id-mismatch** command
- *src_ifc*—The source interface name at which the DNS message is received with a mismatched DNS identifier
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port

Recommended Action Check the IP address and port in the message to trace the source of the attack. You can configure ACLs to block traffic permanently from the source.

410003

Error Message `%ASA-4-410003: action_class: action DNS query_response from src_ifc:sip/sport to dest_ifc:dip/dport; further_info`

Explanation A DNS classification was performed on a DNS message and the specified criteria were satisfied. As a result, the configured action occurs.

- *action_class*—The DNS Classification action class
- *action*—The action taken: Dropped, Dropped (no TSIG), or Masked header flags for
- *query_response*—Either query or response

- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port
- *further_info*—One of the following: matched Class id: *class_name*, matched Class id: *match_command* (for a standalone **match** command), or TSIG resource record not present (for messages generated by the **tsig enforced** command)

Recommended Action None required.

410004

Error Message `%ASA-6-410004: action_class: action DNS query_response from src_ifc:sip/sport to dest_ifc:dip/dport; further_info`

Explanation A DNS classification was performed on a DNS message and the specified criteria were satisfied.

- *action_class*—The DNS Classification action class
- *action*—The action taken: Received or Received (no TSIG)
- *query_response*—Either query or response
- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port
- *further_info*—One of the following: matched Class id: *class_name*, matched Class id: *match_command* (for a standalone **match** command), or TSIG resource record not present (for messages generated by the **tsig enforced** command)

Recommended Action None required.

411001

Error Message `%ASA-4-411001: Line protocol on interface` *`interface_name`* `changed state to up`

Explanation The status of the line protocol has changed from down to up. If *interface_name* is a logical interface name such as inside and outside, this message indicates that the logical interface line protocol has changed from down to up. If *interface_name* is a physical interface name such as Ethernet0 and GigabitEthernet0/1, this message indicates that the physical interface line protocol has changed from down to up.

Recommended Action None required.

411002

Error Message `%ASA-4-411002:Line protocol on interface interface_name changed state to down`

Explanation The status of the line protocol has changed from up to down. If *interface_name* is a logical interface name such as inside and outside, this message indicates that the logical interface line protocol has changed from up to down. In this case, the physical interface line protocol status is not affected. If *interface_name* is a physical interface name such as Ethernet0 and GigabitEthernet0/1, this message indicates that the physical interface line protocol has changed from up to down.

Recommended Action If this is an unexpected event on the interface, check the physical line.

411003

Error Message `%ASA-4-411003: Configuration status on interface interface_name changed state to downup`

Explanation The configuration status of the interface has changed from down to up.

Recommended Action If this is an unexpected event, check the physical line.

411004

Error Message `%ASA-4-411004: Configuration status on interface interface_name changed state to up`

Explanation The configuration status of the interface has changed from down to up.

Recommended Action None required.

411005

Error Message `%ASA-4-411005: Interface variable 1 experienced a hardware transmit hang. The interface has been reset.`

Explanation The interface experienced a hardware transmit freeze that required a reset of the Ethernet controller to restore the interface to full operation. This is a known issue with Gigabit interfaces on ASA 5510, ASA 5520, ASA 5540, and ASA 5550 ASAs.

- *variable 1*—The interface name, such as GigabitEthernet0/0

Recommended Action None required.

412001

Error Message `%ASA-4-412001:MAC MAC_address moved from interface_1 to interface_2`

Explanation A host move was detected from one module interface to another. In a transparent ASA, mapping between the host (MAC) and ASA port is maintained in a Layer 2 forwarding table. The table dynamically binds packet source MAC addresses to an ASA port. In this process, whenever movement of a host from one interface to another interface is detected, this message is generated.

Recommended Action The host move might be valid or might be an attempt to spoof host MACs on other interfaces. If it is a MAC spoof attempt, you can either locate vulnerable hosts on your network and remove them or configure static MAC entries, which will not allow MAC address and port binding to change. If it is a genuine host move, no action is required.

412002

Error Message `%ASA-4-412002:Detected bridge table full while inserting MAC MAC_address on interface interface. Number of entries = num`

Explanation The bridge table was full and an attempt was made to add one more entry. The ASA maintains a separate Layer 2 forwarding table per context and the message is generated whenever a context exceeds its size limit. The MAC address will be added, but it will replace the oldest existing dynamic entry (if available) in the table. This might be an attempted attack.

Recommended Action Make sure that the new bridge table entries are valid. In case of attack, use EtherType ACLs to control access to vulnerable hosts.

413001

Error Message `%ASA-4-413001: Module module_id is not able to shut down. Module Error: errnum message`

Explanation The module identified by *module_id* was not able to comply with a request from the ASA system module to shut down. It may be performing a task that cannot be interrupted, such as a software upgrade. The *errnum* and *message* text describes the reason why the module cannot shut down, and the recommended corrective action.

Recommended Action Wait for the task on the module to complete before shutting down the module, or use the **session** command to access the CLI on the module, and stop the task that is preventing the module from shutting down.

413002

Error Message `%ASA-4-413002: Module module_id is not able to reload. Module Error: errnum message`

Explanation The module identified by *module_id* was not able to comply with a request from the ASA module to reload. It may be performing a task that cannot be interrupted, such as a software upgrade. The *errnum* and *message* text describes the reason why the module cannot reload, and the recommended corrective action.

Recommended Action Wait for the task on the module to complete before reloading the module, or use the **session** command to access the CLI on the module and stop the task that is preventing the module from reloading.

413003

Error Message `%ASA-4-413003: Module string one is not a recognized type`

Explanation A module was detected that is not recognized as a valid module type.

Recommended Action Upgrade to a version of ASA software that supports the module type installed.

413004

Error Message `%ASA-4-413004: Module string one failed to write software newver (currently ver), reason. Trying again.`

Explanation The module failed to accept a software version, and will be transitioned to an UNRESPONSIVE state. Another attempt will be made to update the module software.

- *string one*—The text string that specifies the module
- *newver*—The new version number of software that was not successfully written to the module (for example, 1.0(1)0)
- *ver*—The current version number of the software on the module (for example, 1.0(1)0)
- *reason*—The reason the new version cannot be written to the module. The possible values for *reason* include the following:

  - write failure

  - failed to create a thread to write the image

Recommended Action None required. Subsequent attempts will either generate a message indicating a successful update or failure. You may verify the module transitions to UP after a subsequent update attempt by using the **show module** command.

413005

Error Message `%ASA-4-413005: Module module_id, application is not supported app_name version app_vers type app_type`

Error Message `%ASA-4-413005: Module prod_id in slot slot_num, application is not supported app_name version app_vers type app_type`

Explanation The module installed in slot *slot_num* was running an unsupported application version or type.

- *module_id*—The name of the software services module
- *prod_id*—Product ID string
- *slot_num*—The slot number in which the module is installed. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.
- *app_name*—Application name (string)
- *app_vers*—Application version (string)
- *app_type*—Application type (decimal)

Recommended Action If the problem persists, contact the Cisco TAC.

413006

Error Message `%ASA-4-413006: prod-id Module software version mismatch; slot slot is prod-id version running-vers. Slot slot prod-id requires required-vers.`

Explanation The version of software running on the module in slot *slot* was not the version required by another module.

- *slot*—Slot 0 indicates the system main board. Slot 1 indicates the module installed in the expansion slot.
- *prod_id*—Product ID string for the device installed in slot *slot*
- *running_vers*—Version of software currently running on the module installed in slot *slot*
- *required_vers*—Version of software required by the module in slot *slot*

Recommended Action If the problem persists, contact the Cisco TAC.

413007

Error Message `%ASA-1-413007: An unsupported ASA and IPS configuration is installed. mpc_description with ips_description is not supported.`

Explanation An unsupported ASA and IPS configuration has been detected during IPS SSP setup for slot 1. The ASA should continue to function normally with an unsupported configuration.

- *mpc_description*—A description string for the ASA model, which can be one of the following: ASA5585-SSP-10, ASA5585-SSP-20, ASA5585-SSP-40, ASA5585-SSP-60, ASA5585-SSP-10-K7, ASA5585-SSP-20-K7, ASA5585-SSP-40-K7, ASA5585-SSP-60-K7.
- *ips_description*—A description string for the IPS SSP model, which can be one of the following: ASA5585-SSP-IPS10, ASA5585-SSP-IPS20, ASA5585-SSP-IPS40, ASA5585-SSP-IPS60, ASA5585-SSP-P10K7, ASA5585-SSP-P20K7, ASA5585-SSP-P40K7, ASA5585-SSP-P60K7.

Recommended Action None required.

413008

Error Message `%ASA-1-413008: An unsupported combination of the power supply module and the fan module is detected. Two power supply modules are recommended when using ASA 10G and IPS 10G SSPs simultaneously`

Explanation Only one power supply and one fan module are inserted when an ASA 10G SSP and IPS 10G SSP are present.

Recommended Action When using an ASA 10G SSP and IPS 10G SSP, insert two power supplies instead of one fan module and one power supply module.

414001

Error Message `%ASA-3-414001: Failed to save logging buffer using file name filename to FTP server ftp_server_address on interface interface_name: [fail_reason]`

Explanation The logging module failed to save the logging buffer to an external FTP server.

Recommended Action Take applicable actions based on the failed reason:

- Protocol error—Make sure no connectivity issue exists between the FTP server and ASA, and that the FTP sever can accept the FTP port command and PUT requests.
- Invalid username or password—Make sure that the configured FTP client username and password are correct.
- All other errors—If the problem persists, contact the Cisco TAC.

414002

Error Message `%ASA-3-414002: Failed to save logging buffer to flash:/syslog directory using file name: filename: [fail_reason]`

Explanation The logging module failed to save the logging buffer to system flash.

Recommended Action If the failed reason is caused by insufficient space, check the flash free space, and make sure that the configured limits of the **logging flash-size** command are set correctly. If the error is a flash file system I/O error, then contact the Cisco TAC for assistance.

414003

Error Message `%ASA-3-414003: TCP Syslog Server intf: IP_Address/port not responding. New connections are [permitted|denied] based on logging permit-hostdown policy.`

Explanation The TCP syslog server for remote host logging was successful, is connected to the server, and new connections are permitted or denied based on the logging permit-hostdown policy. If the logging permit-hostdown policy is configured, a new connection is permitted. If not configured, a new connection is denied.

- *intf*—Interface of the ASA to which the server is connected
- *IP_Address*—IP address of the remote TCP syslog server
- *port*—Port of the remote TCP syslog server

Recommended Action Validate that the configured TCP syslog server is up. To permit new connections, configure the logging permit-hostdown policy. To deny new connections, do not configure the logging permit-hostdown policy.

414004

Error Message `%ASA-6-414004: TCP Syslog Server intf: IP_Address/port - Connection restored`

Explanation A retry to the TCP syslog server has been successful, and the connection has been established. This message is the first to reach the syslog server after a successful connection.

- *intf*—Interface of the ASA to which the server is connected
- *IP_Address*—IP address of the remote TCP syslog server
- *port*—Port of the remote TCP syslog server

Recommended Action None required.

414005

Error Message `%ASA-3-414005: TCP Syslog Server intf: IP_Address/port connected, New connections are permitted based on logging permit-hostdown policy`

Explanation The TCP syslog server for remote host logging was successful, is connected to the server, and new connections are permitted based on the logging permit-hostdown policy. If the logging permit-hostdown policy is configured, a new connection is permitted.

- *intf*—Interface of the ASA to which the server is connected
- *IP_Address*—IP address of the remote TCP syslog server
- *port*—Port of the remote TCP syslog server

Recommended Action None required.

414006

Error Message `%ASA-3-414006: TCP Syslog Server configured and logging queue is full. New connections denied based on logging permit-hostdown policy.`

Explanation The logging queue is close to reaching the configured limit, so there is a risk that syslog messages will be discarded.

Recommended Action See the "Configuring the Logging Queue" section in the CLI configuration guide for information about how to tune the queue size to avoid this situation. If you want to deny new connections in this case, use the **no logging permit-hostdown** command. If you want to allow new connections in this case, use the **logging permit-hostdown** command.

414007

Error Message `%ASA-6-414007: TCP Syslog Server connection restored. New connections are allowed.`

Explanation The TCP syslog server for remote host logging was successfully connected and new connections are permitted.

Recommended Action None required.

414008

Error Message `%ASA-6-414008: New connections are now allowed due to change of logging permit-hostdown policy.`

Explanation An administrator changed the logging permit-hostdown policy by entering the **logging permit-hostdown** command at a time when new connections are being denied. Due to this change of policy, new connections will be allowed.

Recommended Action None required.

415001

Error Message `%ASA-6-415001: HTTP - matched matched_string in policy-map map_name, header field count exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation This message is generated when one of the following occurs:

- The total number of fields in the HTTP header exceeds the user-configured number of header fields. The relevant command is: **match** {**request** | **response**} **header count** *num*.
- The appearance of a specified field in the HTTP header exceeds the user-configured number for this header field. The relevant command is: **match** {**request** | **response**} **header** *header-name* **count** *num*.
- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.
- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header** command to reconfigure the HTTP header field value.

415002

Error Message `%ASA-6-415002: HTTP - matched matched_string in policy-map map_name, header field length exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The specified HTTP header field length exceeded the user-configured length.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping connection or Resetting connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header** *header_name* **length gt** *num* command to change the HTTP header field length.

415003

Error Message `%ASA-6-415003: HTTP - matched matched_string in policy-map map_name, body length exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The length of the message body exceeded the user-configured length.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **body length gt** *num* command to change the length of the message body.

415004

Error Message `%ASA-5-415004: HTTP - matched matched_string in policy-map map_name, content-type verification failed connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The magic number in the body of the HTTP message is not the correct magic number for the MIME-type specified in the content-type field in the HTTP message header.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match {request | response} header content-type violation** command to correct the error.

415005

Error Message `%ASA-5-415005: HTTP - matched matched_string in policy-map map_name, URI length exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The length of the URI exceeded the user-configured length.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match request uri length gt** *num* command to change the length of the URI.

415006

Error Message `%ASA-5-415006: HTTP - matched matched_string in policy-map map_name, URI matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The URI matched the regular expression that the user configured. See the **match request uri regex** {*regex-name* | **class** *class-name*} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415007

Error Message `%ASA-5-415007: HTTP - matched matched_string in policy-map map_name, Body matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The message body matched the regular expression that the user configured. See the **match** {**request** | **response**} **body regex** {*regex-name* | **class** *class-name*} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415008

Error Message `%ASA-5-415008: HTTP - matched matched_string in policy-map map_name, header matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation A value in a user-specified field in the message header matched the regular expression that the user configured. See the **match** {**request** | **response** } **header** *header-field-name* {*regex-name* | **class** *class-name*} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415009

Error Message `%ASA-5-415009: HTTP - matched matched_string in policy-map map_name, method matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The HTTP method matched the user-configured regular expression. See the **match request method** {*regex-name* | **class** *class-name*} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415010

Error Message %ASA-5-415010: matched *matched_string* in policy-map *map_name*, transfer encoding matched *connection_action* from *int_type*:*IP_address*/*port_num* to *int_type*:*IP_address*/*port_num*

Explanation The value in the transfer encoding field matched the user-configured regular expression or keyword. See the **match** {**request** | **response**} **header transfer-encoding** {{*regex-name* | **class** *class-name*} | **keyword**} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.
- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415011

Error Message `%ASA-5-415011: HTTP - policy-map map_name:Protocol violation connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The HTTP parser cannot detect a valid HTTP message in the first few bytes of an HTTP message.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **protocol-violation action** {**drop** | **reset**} **log** command to correct the problem.

415012

Error Message `%ASA-5-415012: HTTP - matched matched_string in policy-map map_name, Unknown mime-type connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The content-type field did not contain a MIME type that matches a built-in MIME type.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header content-type unknown** command to correct the problem.

415013

Error Message `%ASA-5-415013: HTTP - policy-map map-name:Malformed chunked encoding connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation A chunked encoding was malformed, and the HTTP message cannot be parsed. In addition, logging for the **protocol-violation** command was configured.

- *map-name*— The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **protocol-violation action** {**drop** | **reset**} **log** command to correct the problem.

415014

Error Message `%ASA-5-415014: HTTP - matched matched_string in policy-map map_name, Mime-type in response wasn't found in the accept-types of the request connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The MIME type in an HTTP response was not in the accept field of the request.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface

- *port_num*—The port number

Recommended Action Enter the **match req-resp content-type mismatch** command to correct the problem.

415015

Error Message `%ASA-5-415015: HTTP - matched matched_string in policy-map map_name, transfer-encoding unknown connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation An empty transfer encoding occurred.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header transfer-encoding empty** command to correct the problem.

415016

Error Message `%ASA-4-415016: policy-map map_name:Maximum number of unanswered HTTP requests exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The number of unanswered HTTP requests exceeded the internal number of requests allowed.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **protocol-violation action** {**drop** | **reset**} **log** command to correct the problem.

415017

Error Message `%ASA-6-415017: HTTP - matched_string in policy-map map_name, arguments matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation A pattern in the arguments matches the user-configured regular expression or keyword. See the **match request args regex** {*regex-name* | **class** *class-name*} command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415018

Error Message `%ASA-5-415018: HTTP - matched matched_string in policy-map map_name, Header length exceeded connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The total header length exceeded the user-configured length for the header.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header length gt** *num* command to reduce the length of the header.

415019

Error Message `%ASA-5-415019: HTTP - matched matched_string in policy-map map_name, status line matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation The status line in a response matched a user-configured regular expression. See the **match response status-line regex** {*regex-name* | **class** *class-name* } command for more information.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action None required.

415020

Error Message `%ASA-5-415020: HTTP - matched matched_string in policy-map map_name, a non-ASCII character was matched connection_action from int_type:IP_address/port_num to int_type:IP_address/port_num`

Explanation A non-ASCII character was found.

- *matched_string*—The matched string is one of the following:

  - The class map ID, followed by the name of the class map. This string appears when the class map is user configured.

  - The actual **match** command that initiated the message. This string appears when the class map is internal.

- *map_name*—The name of the policy map
- *connection_action*—Dropping the connection or resetting the connection
- *interface_type*—The type of interface (for example, DMZ or outside)
- *IP_address*—The IP address of the interface
- *port_num*—The port number

Recommended Action Enter the **match** {**request** | **response**} **header non-ascii** command to correct the problem.

416001

Error Message `%ASA-4-416001: Dropped UDP SNMP packet from source_interface:source_IP/source_port to dest_interface:dest_address/dest_port; version (prot_version) is not allowed through the firewall`

Explanation An SNMP packet was denied passage through the ASA because of a bad packet format or because the *prot_version* is not allowed through the ASA. The *prot_version* parameter can be one of the following values: 1, 2, 2c, or 3.

Recommended Action Change the settings for SNMP inspection using the **snmp-map** command, which allows the user to permit or deny specific protocol versions.

417001

Error Message `%ASA-4-417001: Unexpected event received: number`

Explanation A process received a signal, but no handler was found for the event.

Recommended Action If the problem persists, contact the Cisco TAC.

417004

Error Message `%ASA-4-417004: Filter violation error: conn number (string:string) in string`

Explanation A client tried to modify a route attribute that the client does not own.

Recommended Action If the problem persists, contact the Cisco TAC.

417006

Error Message `%ASA-4-417006: No memory for string) in string. Handling: string`

Explanation An operation failed because of low memory, but will be handled with another mechanism.

Recommended Action If the problem persists, contact the Cisco TAC.

418001

Error Message `%ASA-4-418001: Through-the-device packet to/from management-only network is denied: protocol_string from interface_name IP_address (port) [([idfw_user|FQDN_string], sg_info)] to interface_name IP_address (port) [(idfw_user|FQDN_string), sg_info]`

Explanation A packet from the specified source to the destination was dropped because it is traversing the ASA to and from the management-only network.

- *protocol_string*—TCP, UDP, ICMP, or protocol ID as a number in decimal
- *interface_name*— Interface name
- *IP_address*—IP address
- *port*—Port number
- *sg_info*—Security group name or tag for the specified IP address

Recommended Action Determine who is generating this packet and why.

419001

Error Message `%ASA-4-419001: Dropping TCP packet from src_ifc:src_IP/src_port to dest_ifc:dest_IP/dest_port, reason: MSS exceeded, MSS size, data size`

Explanation The length of the TCP packet exceeded the MSS advertised in the three-way handshake.

- *src_ifc*—Input interface name
- *src_IP*—The source IP address of the packet
- *src_port*—The source port of the packet
- *dest_ifc*—The output interface name
- *dest_IP*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If there is a need to allow packets that exceed the MSS, create a TCP map using the **exceed-mss** command, as in the following example:

```
hostname# access-list http-list permit tcp any host server_ip eq 80

hostname# class-map http
hostname# match access-list http-list

hostname# tcp-map tmap
hostname# exceed-mss allow

hostname# policy-map global_policy
hostname# class http
hostname# set connection advanced-options tmap
```

419002

Error Message `%ASA-4-419002: Received duplicate TCP SYN from` *`in_interface`*`:`*`src_address`*`/`*`src_port`* `to` *`out_interface`*`:`*`dest_address`*`/`*`dest_port`* `with different initial sequence number.`

Explanation A duplicate TCP SYN was received during the three-way-handshake that has a different initial sequence number from the SYN that opened the embryonic connection. This may indicate that SYNs are being spoofed. This message occurs in Release 7.0.4.1 and later.

- *in_interface*—The input interface
- *src_address*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_interface*—The output interface
- *dest_address*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action None required.

419003

Error Message `%ASA-4-419003: Cleared TCP urgent flag from` *`out_ifc`*`:`*`src_ip`*`/`*`src_port`* `to` *`in_ifc`*`:`*`dest_ip`*`/`*`dest_port`*`.`

Explanation A duplicate TCP SYN was received during the three-way-handshake that has a different initial sequence number from the SYN that opened the embryonic connection. This may indicate that SYNs are being spoofed. This message occurs in Release 7.0.4.1 and later.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

Recommended Action If you need to keep the urgent flag in TCP headers, use the **urgent-flag allow** command in TCP map configuration mode.

420001

Error Message `%ASA-3-420001: IPS card not up and fail-close mode used, dropping ICMP packet ifc_in:SIP to ifc_out:DIP (type ICMP_TYPE, code ICMP_CODE)`

For example:

```
%ASA-3-420001: IPS card not up and fail-close mode used, dropping TCP packet
from ifc_in:SIP/SPORT to ifc_out:DIP/DPORT\n
%ASA-3-420001: IPS card not up and fail-close mode used, dropping UDP packet
from ifc_in:SIP/SPORT to ifc_out:DIP/DPORT\n
%ASA-3-420001: IPS card not up and fail-close mode used, dropping protocol
protocol packet from ifc_in:SIP to ifc_out:DIP\n
```

Explanation Packets are dropped when the IPS fail-close mode is used, and the IPS card is not up. This message is rate limited.

- *ifc_in*—Input interface name
- *ifc_out*—Output interface name
- *SIP*—Source IP of the packet
- *SPORT* —Source port of the packet
- *DIP*—Destination IP of the packet
- *DPORT* —Destination port of the packet
- *ICMP_TYPE*—Type of the ICMP packet
- *ICMP_CODE*—Code of the ICMP packet

Recommended Action Bring up the IPS card.

420002

Error Message `%ASA-4-420002: IPS requested to drop ICMP packets ifc_in:SIP to ifc_out:DIP (type ICMP_TYPE, code ICMP_CODE)`

For example:

```
%ASA-4-420002: IPS requested to drop TCP packet from ifc_in:SIP/SPORT to
ifc_out:DIP/DPORT\n
%ASA-4-420002: IPS requested to drop UDP packet from ifc_in:SIP/SPORT to
ifc_out:DIP/DPORT\n
%ASA-4-420002: IPS requested to drop protocol packet from ifc_in:SIP to ifc_out:DIP\n
```

Explanation IPS requested that the packet be dropped.

- *ifc_in*—Input interface name
- *ifc_out*—Output interface name
- *SIP*—Source IP of the packet
- *SPORT* —Source port of the packet
- *DIP*—Destination IP of the packet

- *DPORT* —Destination port of the packet
- *ICMP_TYPE*—Type of the ICMP packet
- *ICMP_CODE*—Code of the ICMP packet

Recommended Action None required.

420003

Error Message `%ASA-4-420003: IPS requested to reset TCP connection from ifc_in:SIP/SPORT to ifc_out:DIP/DPORT`

Explanation IPS requested a reset of a TCP connection.

- *ifc_in*—Input interface name
- *ifc_out*—Output interface name
- *SIP*—Source IP of the packet
- *SPORT* —Source port of the packet
- *DIP*—Destination IP of the packet
- *DPORT* —Destination port of the packet

Recommended Action None required.

420004

Error Message `%ASA-6-420004: Virtual Sensor sensor_name was added on the AIP SSM`

Explanation A virtual sensor was added on the AIP SSM card.

- *n*—Card number

Recommended Action None required.

420005

Error Message `%ASA-6-420005: Virtual Sensor sensor_name was deleted from the AIP SSM`

Explanation A virtual sensor was deleted from the AIP SSM card.

- *n*—Card number

Recommended Action None required.

420006

Error Message `%ASA-3-420006: Virtual Sensor not present and fail-close mode used, dropping protocol packet from ifc_in:SIP/SPORT to ifc_out:DIP/DPORT`

Explanation Packets are dropped when the IPS fail-close mode is used, and the virtual sensor used for the packet is not present.

- *protocol*—Protocol used to send the packet
- *ifc_in*—Input interface name
- *ifc_out*—Output interface name
- *SIP*—Source IP address of the packet
- *SPORT*—Source port of the packet
- *DIP*—Destination IP address of the packet
- *DPORT*—Destination port of the packet

Recommended Action Add the virtual sensor.

420007

Error Message `%ASA-4-420007: application-string cannot be enabled for the module in slot slot_id. The module's current software version does not support this feature. Please upgrade the software on the module in slot slot_id to support this feature. Received backplane header version version_number, required backplane header version version_number or higher.`

Explanation This message is generated by any new feature in the ASA that needs a corresponding software version in the SSM or SSC hardware module. The message is sent each time that the ASA module manager detects state changes in the SSM or SSC hardware module.

- *application-string*—The name of the application (for example, Promiscuous IDS)
- *slot_id*—The module identifier, which is 1 for the current ASA
- *version_number*—The version number of the message header between the ASA and the IPS application

Recommended Action Load the SSM or SSC hardware module with the correct software images that support the designated application.

420008

Error Message `%ASA-3-420008: IPS module license disabled and fail-close mode used, dropping packet.`

Explanation The IPS module license has been disabled and when the fail-close mode is configured, all traffic destined for the IPS module will be dropped. You can check the status of the license by using the **show activation-key** command.

Recommended Action Use the **activation-key** command to apply an activation key that has the IPS license enabled.

421001

Error Message `%ASA-3-421001: TCP|UDP flow from interface_name:IP_address/port to interface_name:IP_address/port is dropped because application has failed.`

Explanation A packet was dropped because the CSC SSM application failed. By default, this message is rate limited to 1 message every 10 seconds.

- *interface_name*—The interface name
- *IP_address*—The IP address
- *port*—The port number
- *application*—The CSC SSM is the only application supported in the current release

Recommended Action Determine the problem with the service module.

421002

Error Message `%ASA-6-421002: TCP|UDP flow from interface_name:IP_address/port to interface_name:IP_address/port bypassed application checking because the protocol is not supported.`

Explanation The connection bypassed service module security checking because the protocol that it is using cannot be scanned by the service module. For example, the CSC SSM is not capable of scanning Telnet traffic. If the user configures Telnet traffic to be scanned, the traffic will bypass the scanning service. By default, this message is rate limited to 1 message every 10 seconds.

- *IP_address*—The IP address
- *port*—The port number
- *interface_name*—The name of the interface on which the policy is applied
- *application*—The CSC SSM is the only application supported in the current release

Recommended Action The configuration should be modified to only include protocols that are supported by the service module.

421003

Error Message `%ASA-3-421003: Invalid data plane encapsulation.`

Explanation A packet injected by the service module did not have the correct data plane header. Packets exchanged on the data backplane adhere to a Cisco proprietary protocol called ASDP. Any packet that does not have the proper ASDP header is dropped.

Recommended Action Use the **capture** *name* **type asp-drop** [**ssm-asdp-invalid-encap**] command to capture the offending packets and contact the Cisco TAC.

421004

Error Message `%ASA-7-421004: Failed to inject {TCP|UDP} packet from IP_address/port to IP_address/port`

Explanation The ASA has failed to inject a packet as instructed by the service module. This may happen if the ASA tries to inject a packet into a flow that has already been released or when the ASA maintains its connection table independently from the service module. Normally it will not cause any problem.

- *IP_address*—The IP address
- *port*—The port number

Recommended Action If ASA performance is affected, or if the problem persists, contact the Cisco TAC.

421005

Error Message `%ASA-6-421005: interface_name:IP_address is counted as a user of application`

Explanation A host has been counted toward the license limit. The specified host was counted as a user of *application*. The total number of users in 24 hours is calculated at midnight for license validation.

- *interface_name*—The interface name
- *IP_address*—The IP address
- *application*—The CSC SSM

Recommended Action None required. However, if the overall count exceeds the user license that you have purchased, contact the Cisco TAC to upgrade your license.

421006

Error Message `%ASA-6-421006: There are number users of application accounted during the past 24 hours.`

Explanation The total number of users who have used an application for the past 24 hours have been identified. This message is generated every 24 hours to give the total number of hosts that have used services provided by the service module.

- *application*—The CSC SSM

Recommended Action None required. However, if the overall count exceeds the user license that you have purchased, contact the Cisco TAC to upgrade your license.

421007

Error Message `%ASA-3-421007: TCP|UDP flow from interface_name:IP_address/port to interface_name:IP_address/port is skipped because application has failed.`

Explanation A flow was skipped because the service module application has failed. By default, this message is rate limited to 1 message every 10 seconds.

- *IP_address*—The IP address
- *port*—The port number
- *interface_name*—The name of the interface on which the policy is applied
- *application*—The CSC SSM

Recommended Action Determine the problem with the service module.

422004

Error Message `%ASA-4-422004: IP SLA Monitor number0: Duplicate event received. Event number number1`

Explanation The IP SLA monitor process has received a duplicate event. Currently, this message applies to destroy events. Only one destroy request will be applied. This is only a warning message.

- *number0*—The SLA operation number
- *number1*—The SLA operation event ID

Recommended Action If this recurs, enter the **show sla monitor configuration** *SLA_operation_id* command and copy the output of the command. Copy the message as it appears on the console or in the system log. Then contact the Cisco TAC and provide the representative with the information that you have, along with information about the application that is configuring and polling the SLA probes.

422005

Error Message `%ASA-4-422005: IP SLA Monitor Probe(s) could not be scheduled because clock is not set.`

Explanation One or more IP SLA monitor probes cannot be scheduled because the system clock was not set.

Recommended Action Make sure that the system clock is functional by using NTP or another mechanism.

422006

Error Message `%ASA-4-422006: IP SLA Monitor Probe` *`number`*`:` *`string`*

Explanation The IP SLA monitor probe cannot be scheduled. Either the configured starting time has already occurred or the starting time is invalid.

- *number*—The SLA operation ID
- *string*—A string describing the error

Recommended Action Reschedule the failed probe with a valid start time.

423001

Error Message `%ASA-4-423001: {Allowed | Dropped} invalid NBNS` *`pkt_type_name`* `with` *`error_reason_str`* `from` *`ifc_name`*`:`*`ip_address`*`/`*`port`* `to` *`ifc_name`*`:`*`ip_address`*`/`*`port`*`.`

Explanation The NBNS packet format is incorrect.

Recommended Action None required.

423002

Error Message `%ASA-4-423002: {Allowed | Dropped} mismatched NBNS` *`pkt_type_name`* `with` *`error_reason_str`* `from` *`ifc_name`*`:`*`ip_address`*`/`*`port`* `to` *`ifc_name`*`:`*`ip_address`*`/`*`port`*`.`

Explanation An NBNS ID mismatch occurred.

Recommended Action None required.

423003

Error Message %ASA-4-423003: {Allowed | Dropped} invalid NBDGM *pkt_type_name* with *error_reason_str* from *ifc_name*:*ip_address*/*port* to *ifc_name*:*ip_address*/*port*.

Explanation The NBDGM packet format is incorrect.

Recommended Action None required.

423004

Error Message %ASA-4-423004: {Allowed | Dropped} mismatched NBDGM *pkt_type_name* with *error_reason_str* from *ifc_name*:*ip_address*/*port* to *ifc_name*:*ip_address*/*port*.

Explanation An NBDGM ID mismatch occurred.

Recommended Action None required.

423005

Error Message %ASA-4-423005: {Allowed | Dropped} NBDGM *pkt_type_name* fragment with *error_reason_str* from *ifc_name*:*ip_address*/*port* to *ifc_name*:*ip_address*/*port*.

Explanation The NBDGM fragment format is incorrect.

Recommended Action None required.

424001

Error Message `%ASA-4-424001: Packet denied protocol_string intf_in:src_ip/src_port [([idfw_user | FQDN_string], sg_info)] intf_out:dst_ip/dst_port[([idfw_user | FQDN_string], sg_info)]. [Ingress|Egress] interface is in a backup state.`

Explanation A packet was dropped because it was traversing the ASA to or from a redundant interface. Interface functionality is limited on low-end platforms. The interface specified by the **backup interface** command can only be a backup for the primary interface configured. If the default route to the primary interface is up, any traffic through the ASA from the backup interface will be denied. Conversely, if the default route to the primary interface is down, traffic through the ASA from the primary interface will be denied.

- *protocol_string*—The protocol string; for example, TCP or protocol ID (a decimal number)
- *intf_in*—The input interface name
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *intf_out*—The output interface name
- *dst_ip*—The destination IP address of the packet
- *dst_port*—The destination port of the packet
- *sg_info*—The security group name or tag for the specified IP address

Recommended Action Determine the source of the denied packet.

424002

Error Message `%ASA-4-424002: Connection to the backup interface is denied: protocol_string intf:src_ip/src_port intf:dst_ip/dst_port`

Explanation A connection was dropped because it is in a backup state. Interface functionality is limited on low-end platforms. The backup interface can only be a backup for the primary interface specified by the **backup interface** command. If the default route to the primary interface is up, any connection to the ASA through the backup interface will be denied. Conversely, if the default route to the primary interface is down, connections to the ASA through the primary interface will be denied.

- *protocol_string*—The protocol string; for example, TCP or protocol ID (a decimal number)
- *intf_in*—The input interface name
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *intf_out*—The output interface name
- *dst_ip*—The destination IP address of the packet
- *dst_port*—The destination port of the packet

Recommended Action Determine the source of the denied packet.

425001

Error Message `%ASA-6-425001 Redundant interface redundant_interface_name created.`

Explanation The specified redundant interface was created in the configuration.

- *redundant_interface_name*—Redundant interface name

Recommended Action None required.

425002

Error Message `%ASA-6-425002 Redundant interface redundant_interface_name removed.`

Explanation The specified redundant interface was removed from the configuration.

- *redundant_interface_name*—Redundant interface name

Recommended Action None required.

425003

Error Message `%ASA-6-425003 Interface interface_name added into redundant interface redundant_interface_name.`

Explanation The specified physical interface was added to the specified redundant interface as a member interface.

- *interface_name*—An interface name
- *redundant_interface_name*—Redundant interface name

Recommended Action None required.

425004

Error Message `%ASA-6-425004 Interface interface_name removed from redundant interface redundant_interface_name.`

Explanation The specified redundant interface was removed from the specified redundant interface.

- *interface_name*—An interface name
- *redundant_interface_name*—Redundant interface name

Recommended Action None required.

425005

Error Message `%ASA-5-425005 Interface interface_name become active in redundant interface redundant_interface_name`

Explanation Within a redundant interface, one member interface is the active member. Traffic only passes through the active member interface. The specified physical interface became the active member of the specified redundant interface. Member interface switchover occurs when one of the following is true:

- The **redundant-interface interface-name active-member interface-name** command was executed.
- The active member interface is down, while the standby member interface is up.
- The standby member interface comes up (from down), while the active member interface remains down.

- *interface_name*—An interface name
- *redundant_interface_name*—Redundant interface name

Recommended Action Check the status of the member interfaces.

425006

Error Message `%ASA-3-425006 Redundant interface redundant_interface_name switch active member to interface_name failed.`

Explanation An error occurred when member interface switchover was attempted.

- *redundant_interface_name*—Redundant interface name
- *interface_name*—An interface name

Recommended Action If the problem persists, contact the Cisco TAC.

426001

Error Message `%ASA-6-426001: PORT-CHANNEL:Interface ifc_name bundled into EtherChannel interface Port-channel num`

Explanation The **interface port-channel** *num* or the **channel-group** *num* **mode** *mode* command has been used on a nonexistent port channel.

- *ifc_name*—The EtherChannel interface name
- *num*—The port channel number

Recommended Action None required.

426002

Error Message `%ASA-6-426002: PORT-CHANNEL:Interface ifc_name unbundled from EtherChannel interface Port-channel num`

Explanation The **no interface port-channel** *num* command has been used.

- *ifc_name*—The EtherChannel interface name
- *num*—The port channel number

Recommended Action None required.

426003

Error Message `%ASA-6-426003: PORT-CHANNEL:Interface ifc_name1 has become standby in EtherChannel interface Port-channel num`

Explanation The **channel-group** *num* **mode** *mode* command has been used.

- *ifc_name1*—The EtherChannel interface name
- *num*—The port channel number

Recommended Action None required.

426004

Error Message `%ASA-4-426004: PORT-CHANNEL: Interface ifc_name1 is not compatible with ifc_name and will be suspended (speed of ifc_name1 is X Mbps, Y is 1000 Mbps).`

Error Message `%ASA-4-426004: Interface ifc_name1 is not compatible with ifc_name1 and will be suspended (ifc_name1 is Full-duplex, ifc_name1 is Half-duplex)`

Explanation The **channel-group** *num* **mode** *mode* command is executed on a physical interface and there is a speed or duplex mismatch of this physical interface with that of the port channel.

- *ifc_name*—The interface that is being added to the port channel
- *ifc_name1*—The interface that is already in the port channel and in a bundled state

Recommended Action Do one of the following:

- Change the speed of the physical interface to that of the port channel and execute the **channel-group** *num* **mode** *mode* command again.
- Leave the member interface in a suspended state. When the last active member is removed, then that member will try to reestablish LACP on the suspended member.

426101

Error Message `%ASA-6-426101: PORT-CHANNEL:Interface ifc_name is allowed to bundle into EtherChannel interface port-channel id by CLACP`

Explanation A port has been bundled in a span-cluster channel group.

Recommended Action None required.

426102

Error Message `%ASA-6-426102: PORT-CHANNEL:Interface ifc_name is moved to standby in EtherChannel interface port-channel id by CLACP`

Explanation A port has been moved to hot-standby state in a span-cluster channel group.

Recommended Action None required.

426103

Error Message `%ASA-6-426103: PORT-CHANNEL:Interface ifc_name is selected to move from standby to bundle in EtherChannel interface port-channel id by CLACP`

Explanation A standby port has been selected to move to bundled state in a span-cluster channel group.

Recommended Action None required.

426104

Error Message `%ASA-6-426104: PORT-CHANNEL:Interface ifc_name is unselected in EtherChannel interface port-channel id by CLACP`

Explanation A bundled port has been unbundled in a span-cluster channel group to obtain space for other ports to be bundled.

Recommended Action None required.

428002

Error Message `%ASA-6-428002: WAAS confirmed from in_interface:src_ip_addr/src_port to out_interface:dest_ip_addr/dest_port, inspection services bypassed on this connection.`

Explanation WAAS optimization was detected on a connection. All layer 7 inspection services, including IPS, are bypassed on WAAS-optimized connections.

Recommended Action No action is required if the network includes WAE devices; otherwise, the network administrator should investigate the use of the WAAS option on this connection.

429001

Error Message `%ASA-3-429001: CXSC card not up and fail-close mode used. Dropping protocol packet from interface_name:ip_address/port to interface_name:ip_address/port`

Explanation Data has been dropped because an SSP is down and a fail-close policy exists.

Recommended Action Check the status of the service module and contact the Cisco TAC for assistance, if necessary.

429002

Error Message `%ASA-4-429002: CXSC service card requested to drop protocol packet from interface_name:ip_address/port to interface_name:ip_address/port`

Explanation The CXSC SSP requested that the ASA drop a packet of a connection.

Recommended Action None.

429003

Error Message `%ASA-4-429003: CXSC service card requested to reset TCP connection from interface_name:ip_addr/port to interface_name:ip_addr/port`

Explanation The CXSC SSP requested that the ASA reset a TCP connection.

Recommended Action None required.

429004

Error Message `%ASA-3-429004: Unable to set up authentication-proxy rule for the cx action on interface interface_name for policy_type service-policy.`

Explanation The ASA could not set up to-the-box rules for authentication proxy with the CXSC action because of some internal errors, such as insufficient memory.

Recommended Action This error should not occur. Contact the Cisco TAC.for assistance.

429005

Error Message `%ASA-6-429005: Set up authentication-proxy protocol_type rule for the CXSC action on interface interface_name for traffic destined to ip_address/port for policy_type service-policy.`

Explanation The ASA successfully set up to-the-box rules for authentication proxy with the CXSC action.

Recommended Action None.

429006

Error Message `%ASA-6-429006: Cleaned up authentication-proxy rule for the CXSC action on interface interface_name for traffic destined to ip_address for policy_type service-policy.`

Explanation The ASA successfully cleaned up to-the-box rules for authentication proxy with the CXSC action.

Recommended Action None.

429007

Error Message `%ASA-4-429007: CXSC redirect will override Scansafe redirect for flow from interface_name:ip_address/port to interface_name:ip_address/port with username`

Explanation A flow matches both CXSC and Scansafe redirects. The message indicates that the CXSC redirect overrides the Scansafe redirect for the displayed flow.

Recommended Action If this is unwanted behavior, then reconfigure the policy to ensure that no overlap of CXSC and Scansafe redirection occurs for the same flow.

429008

Error Message `%ASA-4-429008: Unable to respond to VPN query from CX for session 0x%x. Reason %s`

Explanation The CX sent a VPN session query to the ASA, but it did not respond either because of an invalid session ID or another reason. Valid reasons can be any of the following:

- TLV length is invalid
- TLV memory allocation failed
- VPN session query message enqueue failed
- VPN session ID is invalid

Recommended Action None required.

431001

Error Message `%ASA-4-431001: RTP conformance: Dropping RTP packet from in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, Drop reason: drop_reason value`

Explanation The RTP packet was dropped.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet
- *drop_reason*—One of the following drop reasons:
  - Incorrect version *value*—The version number from the packet is incorrect.
  - Invalid payload-type *value*—The payload type from the packet is invalid.
  - Incorrect SSRC *value*—The SSRC from the packet is incorrect.
  - Out-of-range sequence number *value* sequence number from the packet.
  - Out of sequence in packet in probation *value* sequence number from the packet.

Recommended Action Examine the dropped RTP packets to determine which field the RTP source is setting incorrectly. Also examine the source to verify that it is legitimate and not an attacker trying to misuse an opening in the ASA.

431002

Error Message `%ASA-4-431002: RTCP conformance: Dropping RTCP packet from in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, Drop reason: drop_reason value`

Explanation The RTCP packet was dropped.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet
- *drop_reason*—One of the following drop reasons:

  - Incorrect version *value*—The version number from the packet is incorrect.

  - Invalid payload-type *value*—The payload type from the packet is incorrect.

Recommended Action Examine the dropped RTP packets to determine which field the RTP source is setting incorrectly. Also examine the source to verify that it is legitimate and not an attacker trying to misuse an opening in the ASA.

444004

Error Message `%ASA-2-444004: Temporary license key key has expired. Applying permanent license key permkey`

Explanation The temporary license that was installed has expired. The features that the license provided are no longer available.

- *key*—The temporary activation key
- *permkey*—The permanent activation key

Recommended Action A permanent license should be purchased and installed.

444005

Error Message `%ASA-4-444005: Timebased activation key activation-key will expire in num days`

Explanation This message is generated every 24 hours, indicating that the temporary license will expire in the number of days specified. After that date, the features that the license provided will no longer be available.

- *activation-key*—The temporary activation key

- *num*—The number of days left until expiration

Recommended Action If the amount of time remaining is less than 30 days, you should purchase another time-based activation key before the temporary license runs out.

444007

Error Message `%ASA-2-444007: Timebased activation key activation-key has expired. Reverting to [permanent | timebased] license key. The following features will be affected: feature, feature`

Explanation The time-based activation key has expired. The specified features that the license provided are no longer available.

- *activation-key*—The temporary activation key
- *feature*—The name of the licensed feature being affected

Recommended Action You must purchase another time-based activation key as soon as possible to prevent service disruption for the features specified.

444008

Error Message `%ASA-4-444008: %s license has expired, and the system is scheduled to reload in x days. Apply a new activation key to enable %s license and prevent the automatic reload.`

Explanation The specific license has expired, which will cause the system to reload in x days. Apply a new activation key to enable the specific license and prevent automatic reload.

Recommended Action Apply a new activation key to enable the specific license and prevent automatic reload.

444009

Error Message `%ASA-2-444009: %s license has expired 30 days ago. The system will now reload.`

Explanation The specific license expired 30 days ago. The system will reload.

Recommended Action None required.

444100

Error Message `%ASA-5-444100: Shared request request failed. Reason: reason`

Explanation A shared license client request was unsuccessfully sent or processed by the server.

- *request*—Valid requests are:
  - get AnyConnect Premium
  - release AnyConnect Premium
  - transfer AnyConnect Premium
- *reason*—The reason that the request failed. Valid reasons are:
  - connection failed to server
  - version not supported by server
  - message signature invalid
  - client ID unknown by server
  - server is not active
  - license capacity reached

Recommended Action None required.

444101

Error Message `%ASA-5-444101: Shared license service is active. License server address: address`

Explanation The shared license server has become active.

- *address*—The license server IPv4 or IPv6 address

Recommended Action None required.

444102

Error Message `%ASA-2-444102: Shared license service inactive. License server is not responding.`

Explanation The shared license service was inactive because the license server was not responding. The ASA failed to register with the shared license server.

Recommended Action Verify that the license server address, secret, and port are configured correctly.

444103

Error Message `%ASA-6-444103: Shared licensetype license usage is over 90% capacity.`

Explanation The shared license usage on the network is over 90 percent capacity.

- *licensetype*—AnyConnect Premium

Recommended Action None required.

444104

Error Message `%ASA-6-444104: Shared licensetype license availability: value.`

Explanation The shared license availability on the network appeared.

- *licensetype*—AnyConnect Premium
- *value*—The license availability

Recommended Action None required.

444105

Error Message `%ASA-2-444105: Released value shared licensetype license(s). License server has been unreachable for 24 hours.`

Explanation The shared license server has been unreachable for 24 hours, and all shared licenses that have been acquired by the ASA have been released. The ASA failed to register with the license server.

- *licensetype*—AnyConnect Premium
- *value*—The license availability

Recommended Action Verify the connectivity to the license server, and that the configuration has not been changed on the license server.

444106

Error Message `%ASA-4-444106: Shared license backup server address is not available.`

Explanation The shared license backup server is not reachable. License server information is not synchronized with the backup device.

- *address*—The IPv4 or IPv6 address of the backup license server

Recommended Action None required.

444107

Error Message `%ASA-6-444107: Shared license service status on interface ifname.`

Explanation The shared license service has been enabled or disabled on the specified interface.

- *ifname*—The interface name.
- *status*—The status of the license server. Valid values are enabled or disabled.

Recommended Action None required.

444108

Error Message `%ASA-6-444108: Shared license state client id id.`

Explanation The multi-site license client ID has registered or expired with the server.

- *id*—The ID of the client
- *state*—The state of the license server. Valid values are registered or expired.

Recommended Action None required.

444109

Error Message `%ASA-4-444109: Shared license backup server role changed to state.`

Explanation The shared backup license server role has changed.

- *state*—The state of the license server. Valid values are active or inactive.

Recommended Action None required.

444110

Error Message `%ASA-4-444110: Shared license server backup has days remaining as active license server.`

Explanation The shared backup license server is in an active role and remains active for a specified number of days. The ASA failed to register with the license server, and needs to register with the primary license server soon.

- *days*—The number of days left as the active license server

Recommended Action Verify that the license server is online and reachable by the ASA.

444111

Error Message `%ASA-2-444111: Shared license backup service has been terminated due to the primary license server address being unavailable for more than days days. The license server needs to be brought back online to continue using shared licensing.`

Explanation The shared backup license server active time has expired. The primary server needs to go online in order for the shared license service to continue.

- *address*—The IPv4 or IPv6 address of the license server
- *days*—The number of days that the license server has been unavailable

Recommended Action Register with the primary license server in order to continue using the shared license service.

446001

Error Message `%ASA-4-446001: Maximum TLS Proxy session limit of max_sess reached.`

Explanation A configured maximum session limit for TLS proxy was reached. New sessions beyond the limit were denied.

- *max_sess*—The currently effective maximum session limit

Recommended Action If more TLS sessions are needed, use the **tls-proxy maximum-sessions max_sess** command to increase the limit. Alternatively, you can use the **tls-proxy proxy_name** and **tls-proxy maximum-sessions max_sess** commands, and then reboot for the commands to take effect.

446003

Error Message `%ASA-4-446003: Denied TLS Proxy session from src_int:src_ip/src_port to dst_int:dst_ip/dst_port, UC-IME license is disabled.`

Explanation The UC-IME license is either on or off. Once enabled, UC-IME can use any number of available TLS sessions, according to the ASA limit and the K8 export limit.

- *src_int*—The source interface name (inside or outside)
- *src_ip*—The source IP address
- *src_port*—The source port
- *dst_int*—The destination interface name (inside or outside)
- *dst_ip*—The destination IP address
- *dst_port*—The destination port

Recommended Action Check to see if UC-IME is disabled. If so, activate it.

447001

Error Message `%ASA-4-447001: ASP DP to CP queue_name was full. Queue length length, limit limit`

Explanation This message indicates a particular data path (DP) to control point (CP) event queue is full, and one or more multiple enqueue actions have failed. If the event contains a packet block, such as for CP application inspection, the packet will be dropped by the DP, and a counter from the **show asp drop** command will increment. If the event is for punt to CP, a typical counter is the Punt no memory ASP-drop counter.

- *queue*—The name of the DP-CP event queue.
- *length*—The current number of events on the queue.
- *limit*—The maximum number of events that are allowed on the queue.

Recommended Action The queue-full condition reflects the fact that the load on the CP has exceeded the CP processing ability, which may or may not be a temporary condition. You should consider reducing the feature load on the CP if this message appears repeatedly. Use the **show asp event dp-cp** command to identify the features that contribute the most load on the event queue.

448001

Error Message `%ASA-4-448001: Denied SRTP crypto session setup on flow from src_int:src_ip/src_port to dst_int:dst_ip/dst_port, licensed K8 SRTP crypto session of limit exceeded`

Explanation For a K8 platform, the limit of 250 SRTP crypto sessions is enforced. Each pair of SRTP encrypt or decrypt sessions is counted as one SRTP crypto session. A call is counted toward this limit only when encryption or decryption is required for a medium, which means that if the pass-through is set for the call, even if both legs use SRTP, they are not counted toward this limit.

- *src_int*—The source interface name (inside or outside)
- *src_ip*—The source IP address
- *src_port*—The source port
- *dst_int*—The destination interface name (inside or outside)
- *dst_ip*—The destination IP address
- *dst_port*—The destination port
- *limit*—The K8 limit of SRTP crypto sessions (250)

Note The K8 license limit applies to both UC and UC-IME calls.

Recommended Action None required. You can set up new SRTP crypto sessions only when existing SRTP crypto sessions have been released.

450001

Error Message `ASA-4-450001: Deny traffic for protocol protocol_id src interface_name:IP_address/port dst interface_name:IP_address/port, licensed host limit of num exceeded.`

Explanation The licensed host limit was exceeded. This message applies to the ASA 5505 ASA only.

- *protocol_id*—The protocol ID number
- *interface_name*—The interface associated with the sender or receiver of the packet
- *IP_address*—The IP address of the sender/receiver of the packet
- *port*—The port number of the packet transmitted
- *num*—The maximum host limit value

Recommended Action None required.

Messages 500001 to 509001

This section includes messages from 500001 to 509001.

500001

Error Message `%ASA-5-500001: ActiveX content modified src IP_address dest IP_address on interface interface_name.`

Explanation You have turned on the **activex** option using the **filter** command, and the ASA detected an ActiveX object. The **activex** option allows the ASA to filter out ActiveX contents by modifying it so that it no longer is tagged as an HTML object.

Recommended Action None required.

500002

Error Message `%ASA-5-500002: Java content modified src IP_address dest IP_address on interface interface_name.`

Explanation You have turned on the **java** option using the **filter** command, and the ASA detected an Java applet. The **java** option allows the ASA to filter out Java contents by modifying it so that it no longer is tagged as an HTML object.

Recommended Action None required.

500003

Error Message `%ASA-5-500003: Bad TCP hdr length (hdrlen=bytes, pktlen=bytes) from source_address/source_port to dest_address/dest_port, flags: tcp_flags, on interface interface_name`

Explanation A header length in TCP was incorrect. Some operating systems do not handle TCP resets (RSTs) correctly when responding to a connection request to a disabled socket. If a client tries to connect to an FTP server outside the ASA and the FTP server is not listening, then it sends an RST. Some operating systems send incorrect TCP header lengths, which causes this problem. UDP uses ICMP port unreachable messages.

The TCP header length may indicate that it is larger than the packet length, which results in a negative number of bytes being transferred. A negative number appears by a message as an unsigned number, which makes it appear much larger than it would be normally; for example, it may show 4 GB transferred in one second. This message should occur infrequently.

Recommended Action None required.

500004

Error Message `%ASA-4-500004: Invalid transport field for protocol=protocol, from source_address/source_port to dest_address/dest_port`

Explanation An invalid transport number was used, in which the source or destination port number for a protocol is zero. The *protocol* value is 6 for TCP and 17 for UDP.

Recommended Action If these messages persist, contact the administrator of the peer.

500005

Error Message `%ASA-3-500005: connection terminated for protocol from in_ifc_name:src_adddress/src_port to out_ifc_name:dest_address/dest_port due to invalid combination of inspections on same flow. Inspect inspect_name is not compatible with filter filter_name.`

Explanation A connection matched with single or multiple inspection and/or single or multiple filter features that are not allowed to be applied to the same connection.

- *protocol*—The protocol that the connection was using
- *in_ifc_name*—The input interface name
- *src_address*—The source IP address of the connection
- *src_port*—The source port of the connection
- *out_ifc_name*—The output interface name
- *dest_address*—The destination IP address of the connection
- *dest_port*—The destination port of the packet

- *inspect_name*—The inspect or filter feature name
- *filter_name*—The filter feature name

Recommended Action Review the **class-map**, **policy-map**, **service-policy**, and/or **filter** command configurations that are causing the referenced inspection and/or filter features that are matched for the connection. The rules for inspection and filter feature combinations for a connection are as follows:

– The **inspect http [http-policy-map]** and/or **filter url** and/or **filter java** and/or **filter activex** commands are valid.

– The **inspect ftp [ftp-policy-map]** and/or **filter ftp** commands are valid.

– The **filter https** command with any other **inspect** command or **filter** command is not valid.

Besides these listed combinations, any other inspection and/or filter feature combinations are not valid.

501101

Error Message `%ASA-5-501101: User transitioning priv level`

Explanation The privilege level of a command was changed.

Recommended Action None required.

502101

Error Message `%ASA-5-502101: New user added to local dbase: Uname: user Priv: privilege_level Encpass: string`

Explanation A new username record was created, which included the username, privilege level, and encrypted password.

Recommended Action None required.

502102

Error Message `%ASA-5-502102: User deleted from local dbase: Uname: user Priv: privilege_level Encpass: string`

Explanation A username record was deleted, which included the username, privilege level, and encrypted password.

Recommended Action None required.

502103

Error Message `%ASA-5-502103: User priv level changed: Uname: user From: privilege_level To: privilege_level`

Explanation The privilege level of a user changed.

Recommended Action None required.

502111

Error Message `%ASA-5-502111: New group policy added: name: policy_name Type: policy_type`

Explanation A group policy was configured using the **group-policy** CLI command.

- *policy_name*—The name of the group policy
- *policy_type*—Either internal or external

Recommended Action None required.

502112

Error Message `%ASA-5-502112: Group policy deleted: name: policy_name Type: policy_type`

Explanation A group policy has been removed using the **group-policy** CLI command.

- *policy_name*—The name of the group policy
- *policy_type*—Either internal or external

Recommended Action None required.

503001

Error Message `%ASA-5-503001: Process number, Nbr IP_address on interface_name from string to string, reason`

Explanation An OSPFv2 neighbor has changed its state. The message describes the change and the reason for it. This message appears only if the **log-adjacency-changes** command is configured for the OSPF process.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

503101

Error Message `%ASA-5-503101: Process d, Nbr i on s from s to s, s`

Explanation An OSPFv3 neighbor has changed its state. The message describes the change and the reason for it. This message appears only if the **log-adjacency-changes** command is configured for the OSPF process.

Recommended Action None required.

504001

Error Message `%ASA-5-504001: Security context context_name was added to the system`

Explanation A security context was successfully added to the ASA.

Recommended Action None required.

504002

Error Message `%ASA-5-504002: Security context context_name was removed from the system`

Explanation A security context was successfully removed from the ASA.

Recommended Action None required.

505001

Error Message `%ASA-5-505001: Module string one is shutting down. Please wait...`

Explanation A module is being shut down.

Recommended Action None required.

505002

Error Message `%ASA-5-505002: Module ips is reloading. Please wait...`

Explanation An IPS module is being reloaded.

Recommended Action None required.

505003

Error Message `%ASA-5-505003: Module string one is resetting. Please wait...`

Explanation A module is being reset.

Recommended Action None required.

505004

Error Message `%ASA-5-505004: Module string one shutdown is complete.`

Explanation A module has been shut down.

Recommended Action None required.

505005

Error Message `%ASA-5-505005: Module ips is initializing control communication. Please wait...`

Explanation An IPS module has been detected, and the ASA is initializing control channel communication with it.

Recommended Action None required.

505006

Error Message `%ASA-5-505006: Module string one is Up.`

Explanation A module has completed control channel initialization and is in the UP state.

Recommended Action None required.

505007

Error Message `%ASA-5-505007: Module module_id is recovering. Please wait...`

Error Message `%ASA-5-505007: Module prod_id in slot slot_num is recovering. Please wait...`

Explanation A software module is being recovered with the **sw-module module** *service-module-name* **recover boot** command, or a hardware module is being recovered with the **hw-module module** *slotnum* **recover boot** command.

- *module_id*—The name of the software services module.
- *prod_id*—The product ID string.
- *slot_num*—The slot in which the hardware services module is installed. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.

Recommended Action None required.

505008

Error Message `%ASA-5-505008: Module module_id software is being updated to newver (currently ver)`

Error Message `%ASA-5-505008: Module module_id in slot slot_num software is being updated to newver (currently ver)`

Explanation The services module software is being upgraded. The update is proceeding normally.

- *module_id*—The name of the software services module
- *slot_num*—The slot number that contains the hardware services module
- *newver*—The new version number of software that was not successfully written to the module (for example, 1.0(1)0)
- *ver*—The current version number of the software on the module (for example, 1.0(1)0)

Recommended Action None required.

505009

Error Message `%ASA-5-505009: Module string one software was updated to newver`

Explanation The 4GE SSM module software was successfully upgraded.

- *string one*—The text string that specifies the module
- *newver*—The new version number of software that was not successfully written to the module (for example, 1.0(1)0)

- *ver*—The current version number of the software on the module (for example, 1.0(1)0)

Recommended Action None required.

505010

Error Message `%ASA-5-505010: Module in slot slot removed.`

Explanation An SSM was removed from the ASA chassis.

- *slot*—The slot from which the SSM was removed

Recommended Action None required.

505011

Error Message `%ASA-1-505011: Module ips, data channel communication is UP.`

Explanation The data channel communication recovered from a DOWN state.

Recommended Action None required.

505012

Error Message `%ASA-5-505012: Module module_id, application stopped application, version version`

Error Message `%ASA-5-505012: Module prod_id in slot slot_num, application stopped application, version version`

Explanation An application was stopped or removed from a services module. This may occur when the services module upgraded an application or when an application on the services module was stopped or uninstalled.

- *module_id*—The name of the software services module
- *prod_id*—The product ID string for the device installed in the hardwre services module
- *slot_num*—The slot in which the application was stopped
- *application*—The name of the application stopped
- *version*—The application version stopped

Recommended Action If an upgrade was not occurring on the 4GE SSM or the application was not intentionally stopped or uninstalled, review the logs from the 4GE SSM to determine why the application stopped.

505013

Error Message `%ASA-5-505013: Module module_id application changed from: application version version to: newapplication version newversion.`

Error Message `%ASA-5-505013: Module prod_id in slot slot_nunm application changed from: application version version to: newapplication version newversion.`

Explanation An application version changed, such as after an upgrade. A software update for the application on the services module is complete.

- *module_id*—The name of the software services module
- *application*—The name of the application that was upgraded
- *version*—The application version that was upgraded
- *prod_id*—The product ID string for the device installed in the hardware services module
- *slot_num*—The slot in which the application was upgraded
- *application*—The name of the application that was upgraded
- *version*—The application version that was upgraded
- *newapplication*—The new application name
- *newversion*—The new application version

Recommended Action Verify that the upgrade was expected and that the new version is correct.

505014

Error Message `%ASA-1-505014: Module module_id, application down name, version version reason`

Error Message `%ASA-1-505014: Module prod_id in slot slot_num, application down name, version version reason`

Explanation The application running on the module is disabled.

- *module_id*—The name of the software services module
- *prod_id*—The product ID string for the device installed in the hardware services module
- *slot_num*—The slot in which the application was disabled. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.
- *name*—Application name (string)
- *application*—The name of the application that was upgraded
- *version*—The application version (string)
- *reason*—Failure reason (string)

Recommended Action If the problem persists, contact the Cisco TAC.

505015

Error Message `%ASA-1-505015: Module module_id, application up application, version version`

Error Message `%ASA-1-505015: Module prod_id in slot slot_num, application up application, version version`

Explanation The application running on the SSM in slot *slot_num* is up and running.

- *module_id*—The name of the software services module
- *prod_id*—The product ID string for the device installed in the hardware services module
- *slot_num*—The slot in which the application is running. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.
- *application*—The application name (string)
- *version*—The application version (string)

Recommended Action None required.

505016

Error Message `%ASA-3-505016: Module module_id application changed from: name version version state state to: name version state state.`

Error Message `%ASA-3-505016: Module prod_id in slot slot_num application changed from: name version version state state to: name version state state.`

Explanation The application version or a name change was detected.

- *module_id*—The name of the software services module
- *prod_id*—The product ID string for the device installed in the hardware services module
- *slot_num*—The slot in which the application changed. Slot 0 indicates the system main board, and slot 1 indicates the module installed in the expansion slot.
- *name*—Application name (string)
- *version*—The application version (string)
- *state*—Application state (string)
- *application*—The name of the application that changed

Recommended Action Verify that the change was expected and that the new version is correct.

506001

Error Message `%ASA-5-506001: event_source_string event_string`

Explanation The status of a file system has changed. The event and the source of the event that caused a file system to become available or unavailable appear. Examples of sources and events that can cause a file system status change are as follows:

- External CompactFlash removed
- External CompactFlash inserted
- External CompactFlash unknown event

Recommended Action None required.

507001

Error Message `%ASA-5-507001: Terminating TCP-Proxy connection from interface_inside:source_address/source_port to interface_outside:dest_address/dest_port - reassembly limit of limit bytes exceeded`

Explanation The assembly buffer limit was exceeded during TCP segment reassembly.

- *source_address/source_port*—The source IP address and the source port of the packet initiating the connection
- *dest_address/dest_port*—The destination IP address and the destination port of the packet initiating the connection
- *interface_inside*—The name of the interface on which the packet which initiated the connection arrives
- *interface_outside*—The name of the interface on which the packet which initiated the connection exits
- *limit*—The configured embryonic connection limit for the traffic class

Recommended Action None required.

507002

Error Message `%ASA-4-507002: Data copy in proxy-mode exceeded the buffer limit`

Explanation An operational error occurred during processing of a fragmented TCP message.

Recommended Action None required.

507003

Error Message `%ASA-3-507003: The flow of type protocol from the originating interface: src_ip/src_port to dest_if:dest_ip/dest_port terminated by inspection engine, reason-`

Explanation The TCP proxy or session API terminated a connection for various reasons, which are provided in the message.

- *protocol*—The protocol for the flow
- *src_ip*—The source IP address for the flow
- *src_port*—The name of the source port for the flow
- *dest_if*—The destination interface for the flow
- *dest_ip*—The destination IP address for the flow
- *dest_port*—The destination port for the flow
- *reason*—The description of why the flow is being terminated by the inspection engine. Valid reasons include:
  - Failed to create flow
  - Failed to initialize session API
  - Filter rules installed/matched are incompatible
  - Failed to consolidate new buffer data with original
  - Reset unconditionally
  - Reset based on “service reset inbound” configuration
  - Disconnected, dropped packet
  - Packet length changed
  - Reset reflected back to sender
  - Proxy inspector reset unconditionally
  - Proxy inspector drop reset
  - Proxy inspector received data after FIN
  - Proxy inspector disconnected, dropped packet
  - Inspector reset unconditionally
  - Inspector drop reset
  - Inspector received data after FIN
  - Inspector disconnected, dropped packet
  - Could not buffer unprocessed data
  - Session API proxy forward failed
  - Conversion of inspect data to session data failed
  - SSL channel for TLS proxy is closed

Recommended Action None required.

508001

Error Message `%ASA-5-508001: DCERPC message_type non-standard version_type version version_number from src_if:src_ip/src_port to dest_if:dest_ip/dest_port, terminating connection.`

Explanation During DCERPC inspection, a message header included a nonstandard major or minor version.

- *message_type*—The DCERPC message type
- *version_type*—The version type, which can be major or minor
- *version_number*—The nonstandard version in the message header

Recommended Action If this is a valid version, and the problem persists, contact the Cisco TAC.

508002

Error Message `%ASA-5-508002: DCERPC response has low endpoint port port_number from src_if:src_ip/src_port to dest_if:dest_ip/dest_port, terminating connection.`

Explanation During DCERPC inspection, a response message included an endpoint port number less than 1024 (in the range of well-known server ports).

Recommended Action None required.

509001

Error Message `%ASA-5-509001: Connection attempt from src_intf:src_ip/src_port [([idfw_user | FQDN_string], sg_info)] to dst_intf:dst_ip/dst_port [([idfw_user | FQDN_string], sg_info)] was prevented by "no forward" command.`

Explanation The **no forward interface** command was entered to block traffic from the source interface to the destination interface given in the message. This command is required on low-end platforms to allow the creation of interfaces beyond the licensed limit.

- *src_intf*—The name of the source interface to which the **no forward interface** command restriction applies
- *dst_intf*—The name of the destination interface to which the **no forward interface** command restriction applies
- *sg_info*—The security group name or tag for the specified IP address

Recommended Action Upgrade the license to remove the requirement of this command on low-end platforms, then remove the command from the configuration.

520001

Error Message `%ASA-3-520001: error_string`

Explanation A malloc failure occurred in ID Manager. The errror string can be either of the following:

- Malloc failure—id_reserve
- Malloc failure—id_get

Recommended Action Contact the Cisco TAC.

520002

Error Message `%ASA-3-520002: bad new ID table size`

Explanation A bad new table request to the ID Manager occurred.

Recommended Action Contact the Cisco TAC.

520003

Error Message `%ASA-3-520003: bad id in error_string (id: 0xid_num)`

Explanation An ID Manager error occurred. The error string may be any of the following:

- id_create_new_table (no more entries allowed)
- id_destroy_table (bad table ID)
- id_reserve
- id_reserve (bad ID)
- id_reserve: ID out of range
- id_reserve (unassigned table ID)
- id_get (bad table ID)
- id_get (unassigned table ID)
- id_get (out of IDs!)
- id_to_ptr
- id_to_ptr (bad ID)
- id_to_ptr (bad table ID)
- id_get_next_id_ptr (bad table ID)
- id_delete
- id_delete (bad ID)

- id_delete (bad table key)

Recommended Action Contact the Cisco TAC.

520004

Error Message `%ASA-3-520004: error_string`

Explanation An id_get was attempted at the interrupt level.

Recommended Action Contact the Cisco TAC.

520005

Error Message `%ASA-3-520005: error_string`

Explanation An internal error occurred with the ID Manager.

Recommended Action Contact the Cisco TAC.

520010

Error Message `%ASA-3-520010: Bad queue elem - qelem_ptr: flink flink_ptr, blink blink_ptr, flink-blink flink_blink_ptr, blink-flink blink_flink_ptr`

Explanation An internal software error occurred, which can be any of the following:

- *qelem_ptr*—A pointer to the queue data structure
- *flink_ptr*—A pointer to the forward element of the queue data structure
- *blink_ptr*—A pointer to the backward element of the queue data structure
- *flink_blink_ptr*—A pointer to the forward element's backward pointer of the queue data structure
- *blink_flink_ptr*—A pointer to the backward element's forward pointer of the queue data structure

Recommended Action Contact the Cisco TAC.

520011

Error Message `%ASA-3-520011: Null queue elem`

Explanation An internal software error occurred.

Recommended Action Contact the Cisco TAC.

520013

Error Message `%ASA-3-520013: Regular expression access check with bad list acl_ID`

Explanation A pointer to an access list is invalid.

Recommended Action The event that caused this message to be issued should not have occurred. It can mean that one or more data structures have been overwritten. If this message recurs, and you decide to report it to your TAC representative, you should copy the text of the message exactly as it appears and include the associated stack trace. Because access list corruption may have occurred, a TAC representative should verify that access lists are functioning correctly.

520020

Error Message `%ASA-3-520020: No memory available`

Explanation The system is out of memory.

Recommended Action Try one of the following actions to correct the problem:

- Reduce the number of routes accepted by this router.
- Upgrade hardware.
- Use a smaller subset image on run-from-RAM platforms.

520021

Error Message `%ASA-3-520021: Error deleting trie entry, error_message`

Explanation A software programming error occurred. The error message can be any of the following:

- Inconsistent annotation
- Couldn't find our annotation
- Couldn't find deletion target

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

520022

Error Message `%ASA-3-520022: Error adding mask entry, error_message`

Explanation A software or hardware error occurred. The error message can be any of the following:

- Mask already in tree
- Mask for route not entered

- Non-unique normal route, mask not entered

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

520023

Error Message `%ASA-3-520023: Invalid pointer to head of tree, 0x` *radix_node_ptr*

Explanation A software programming error occurred.

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

520024

Error Message `%ASA-3-520024: Orphaned mask #radix_mask_ptr, refcount= radix_mask_ptr's ref count at # radix_node_address, next=# radix_node_next`

Explanation A software error occurred.

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

520025

Error Message `%ASA-3-520025: No memory for radix initialization: error_msg`

Explanation The system ran out of memory during initialization. This should only occur if an image is too large for the existing dynamic memory. The error message can be either of the following:

- Initializing leaf nodes
- Mask housekeeping

Recommended Action Use a smaller subset image or upgrade hardware.

Messages 602101 to 634001

This section includes messages from 602101 to 634001.

602101

Error Message `%ASA-6-602101: PMTU-D packet` *`number`* `bytes greater than effective mtu` *`number`* `dest_addr=`*`dest_address`*`, src_addr=`*`source_address`*`, prot=`*`protocol`*

Explanation The ASA sent an ICMP destination unreachable message and fragmentation is needed, but the don't-fragment bit has been set.

Recommended Action Make sure that the data is sent correctly.

602103

Error Message `%ASA-6-602103: IPSEC: Received an ICMP Destination Unreachable from` *`src_addr`* `with suggested PMTU of` *`rcvd_mtu`*`; PMTU updated for SA with peer` *`peer_addr`*`, SPI` *`spi`*`, tunnel name` *`username`*`, old PMTU` *`old_mtu`*`, new PMTU` *`new_mtu`*`.`

Explanation The MTU of an SA was changed. When a packet is received for an IPsec tunnel, the corresponding SA is located and the MTU is updated based on the MTU suggested in the ICMP packet. If the suggested MTU is greater than 0 but less than 256, then the new MTU is set to 256. If the suggested MTU is 0, the old MTU is reduced by 256 or it is set to 256—whichever value is greater. If the suggested MTU is greater than 256, then the new MTU is set to the suggested value.

- *src_addr*—IP address of the PMTU sender
- *rcvd_mtu*—Suggested MTU received in the PMTU message
- *peer_addr*—IP address of the IPsec peer
- *spi*—IPsec Security Parameter Index
- *username*—Username associated with the IPsec tunnel
- *old_mtu*—Previous MTU associated with the IPsec tunnel
- *new_mtu*—New MTU associated with the IPsec tunnel

Recommended Action None required.

602104

Error Message `%ASA-6-602104: IPSEC: Received an ICMP Destination Unreachable from src_addr, PMTU is unchanged because suggested PMTU of rcvd_mtu is equal to or greater than the current PMTU of curr_mtu, for SA with peer peer_addr, SPI spi, tunnel name username.`

Explanation An ICMP message was received indicating that a packet sent over an IPsec tunnel exceeded the path MTU, and the suggested MTU was greater than or equal to the current MTU. Because the MTU value is already correct, no MTU adjustment is made. This may happen when multiple PMTU messages are received from different intermediate stations, and the MTU is adjusted before the current PMTU message is processed.

- *src_addr*—IP address of the PMTU sender
- *rcvd_mtu*—Suggested MTU received in the PMTU message
- *curr_mtu*—Current MTU associated with the IPsec tunnel
- *peer_addr*—IP address of the IPsec peer
- *spi*—IPsec Security Parameter Index
- *username*—Username associated with the IPsec tunnel

Recommended Action None required.

602303

Error Message `%ASA-6-602303: IPSEC: An direction tunnel_type SA (SPI=spi) between local_IP and remote_IP (username) has been created.`

Explanation A new SA was created.

- *direction*—SA direction (inbound or outbound)
- *tunnel_type*—SA type (remote access or L2L)
- *spi*—IPsec Security Parameter Index
- *local_IP*—IP address of the tunnel local endpoint
- *remote_IP*—IP address of the tunnel remote endpoint
- *username*—Username associated with the IPsec tunnel

Recommended Action None required.

602304

Error Message `%ASA-6-602304: IPSEC: An direction tunnel_type SA (SPI=spi) between local_IP and remote_IP (username) has been deleted.`

Explanation An SA was deleted.

- *direction*—SA direction (inbound or outbound)
- *tunnel_type*—SA type (remote access or L2L)
- *spi*—IPsec Security Parameter Index
- *local_IP*—IP address of the tunnel local endpoint
- *remote_IP*—IP address of the tunnel remote endpoint
- *username*—Username associated with the IPsec tunnel

Recommended Action None required.

602305

Error Message `%ASA-3-602305: IPSEC: SA creation error, source source address, destination destination address, reason error string`

Explanation An error has occurred while creating an IPsec security association.

Recommended Action This is typically a transient error condition. If this message occurs consistently, contact the Cisco TAC.

603101

Error Message `%ASA-6-603101: PPTP received out of seq or duplicate pkt, tnl_id=number, sess_id=number, seq=number.`

Explanation The ASA received a PPTP packet that was out of sequence or duplicated.

Recommended Action If the packet count is high, contact the peer administrator to check the client PPTP configuration.

603102

Error Message `%ASA-6-603102: PPP virtual interface interface_name - user: user aaa authentication started.`

Explanation The ASA sent an authentication request to the AAA server.

Recommended Action None required.

603103

Error Message %ASA-6-603103: PPP virtual interface *interface_name* - user: *user* aaa authentication *status*

Explanation The ASA received an authentication response from the AAA server.

Recommended Action None required.

603104

Error Message %ASA-6-603104: PPTP Tunnel created, tunnel_id is *number*, remote_peer_ip is *remote_address*, ppp_virtual_interface_id is *number*, client_dynamic_ip is *IP_address*, username is *user*, MPPE_key_strength is *string*

Explanation A PPTP tunnel was created.

Recommended Action None required.

603105

Error Message %ASA-6-603105: PPTP Tunnel deleted, tunnel_id = *number*, remote_peer_ip= *remote_address*

Explanation A PPTP tunnel was deleted.

Recommended Action None required.

603106

Error Message %ASA-6-603106: L2TP Tunnel created, tunnel_id is *number*, remote_peer_ip is *remote_address*, ppp_virtual_interface_id is *number*, client_dynamic_ip is *IP_address*, username is *user*

Explanation An L2TP tunnel was created.

Recommended Action None required.

603107

Error Message `%ASA-6-603107: L2TP Tunnel deleted, tunnel_id = number, remote_peer_ip = remote_address`

Explanation An L2TP tunnel was deleted.

Recommended Action None required.

603108

Error Message `%ASA-6-603108: Built PPTP Tunnel at interface_name, tunnel-id = number, remote-peer = IP_address, virtual-interface = number, client-dynamic-ip = IP_address, username = user, MPPE-key-strength = number`

Explanation A new PPPoE tunnel was created.

Recommended Action None required.

603109

Error Message `%ASA-6-603109: Teardown PPPOE Tunnel at interface_name, tunnel-id = number, remote-peer = IP_address`

Explanation A new PPPoE tunnel was deleted.

Recommended Action None required.

603110

Error Message `%ASA-4-603110: Failed to establish L2TP session, tunnel_id = tunnel_id, remote_peer_ip = peer_ip, user = username. Multiple sessions per tunnel are not supported`

Explanation An attempt to establish a second session was detected and denied. Cisco does not support multiple L2TP sessions per tunnel.

- *tunnel_id*—The L2TP tunnel ID
- *peer_ip*—The peer IP address
- *username*—The name of the authenticated user

Recommended Action None required.

604101

Error Message `%ASA-6-604101: DHCP client interface interface_name: Allocated ip = IP_address, mask = netmask, gw = gateway_address`

Explanation The ASA DHCP client successfully obtained an IP address from a DHCP server. The **dhcpc** command statement allows the ASA to obtain an IP address and network mask for a network interface from a DHCP server, as well as a default route. The default route statement uses the gateway address as the address of the default router.

Recommended Action None required.

604102

Error Message `%ASA-6-604102: DHCP client interface interface_name: address released`

Explanation The ASA DHCP client released an allocated IP address back to the DHCP server.

Recommended Action None required.

604103

Error Message `%ASA-6-604103: DHCP daemon interface interface_name: address granted MAC_address (IP_address)`

Explanation The ASA DHCP server granted an IP address to an external client.

Recommended Action None required.

604104

Error Message `%ASA-6-604104: DHCP daemon interface interface_name: address released build_number (IP_address)`

Explanation An external client released an IP address back to the ASA DHCP server.

Recommended Action None required.

604105

Error Message `%ASA-4-604105: DHCPD: Unable to send DHCP reply to client` *`hardware_address`* `on interface` *`interface_name`*`. Reply exceeds options field size (`*`options_field_size`*`) by` *`number_of_octets`* `octets.`

Explanation An administrator can configure the DHCP options to return to the DHCP client. Depending on the options that the DHCP client requests, the DHCP options for the offer could exceed the message length limits. A DHCP offer cannot be sent, because it will not fit within the message limits.

- *hardware_address*—The hardware address of the requesting client.
- *interface_name*—The interface to which server messages are being sent and received
- *options_field_size*—The maximum options field length. The default is 312 octets, which includes 4 octets to terminate.
- *number_of_octets*—The number of exceeded octets.

Recommended Action Reduce the size or number of configured DHCP options.

605004

Error Message `%ASA-6-605004: Login denied from` *`source-address/source-port`* `to` *`interface:destination/service`* `for user "`*`username`*`"`

The following form of the message appears when the user attempts to log in to the console:

```
Login denied from serial to console for user "username"
```

Explanation An incorrect login attempt or a failed login to the ASA occurred. For all logins, three attempts are allowed per session, and the session is terminated after three incorrect attempts. For SSH and Telnet logins, this message is generated after the third failed attempt or if the TCP session is terminated after one or more failed attempts. For other types of management sessions, this message is generated after every failed attempt.

- *source-address*—Source address of the login attempt
- *source-port*—Source port of the login attempt
- *interface*—Destination management interface
- *destination*—Destination IP address
- *service*—Destination service
- *username* —Destination management interface

Recommended Action If this message appears infrequently, no action is required. If this message appears frequently, it may indicate an attack. Communicate with the user to verify the username and password.

605005

Error Message `%ASA-6-605005: Login permitted from source-address/source-port to interface:destination/service for user "username"`

The following form of the message appears when the user logs in to the console:

```
Login permitted from serial to console for user "username"
```

Explanation A user was authenticated successfully, and a management session started.

- *source-address*—Source address of the login attempt
- *source-port*—Source port of the login attempt
- *interface*—Destination management interface
- *destination*—Destination IP address
- *service*—Destination service
- *username*—Destination management interface

Recommended Action None required.

606001

Error Message `%ASA-6-606001: ASDM session number number from IP_address started`

Explanation An administrator has been authenticated successfully, and an ASDM session started.

Recommended Action None required.

606002

Error Message `%ASA-6-606002: ASDM session number number from IP_address ended`

Explanation An ASDM session ended.

Recommended Action None required.

606003

Error Message `%ASA-6-606003: ASDM logging session number id from IP_address started id session ID assigned`

Explanation An ASDM logging connection was started by a remote management client.

- *IP_address*—IP address of the remote management client

Recommended Action None required.

606004

Error Message `%ASA-6-606004: ASDM logging session number id from IP_address ended`

Explanation An ASDM logging connection was terminated.

- *id*—Session ID assigned
- *IP_address*—IP address of remote management client

Recommended Action None required.

607001

Error Message `%ASA-6-607001: Pre-allocate SIP connection_type secondary channel for interface_name:IP_address/port to interface_name:IP_address from string message`

Explanation The **fixup sip** command preallocated a SIP connection after inspecting a SIP message. The *connection_type* is one of the following strings:

- SIGNALLING UDP
- SIGNALLING TCP
- SUBSCRIBE UDP
- SUBSCRIBE TCP
- Via UDP
- Route
- RTP
- RTCP

Recommended Action None required.

607002

Error Message `%ASA-4-607002: action_class: action SIP req_resp req_resp_info from src_ifc:sip/sport to dest_ifc:dip/dport; further_info`

Explanation A SIP classification was performed on a SIP message, and the specified criteria were satisfied. As a result, the configured action occurs.

- *action_class*—The class of the action: SIP Classification for SIP match commands or SIP Parameter for parameter commands
- *action*—The action taken: Dropped, Dropped connection for, Reset connection for, or Masked header flags for
- *req_resp*—Request or Response
- *req_resp_info*—The SIP method name if the type is Request: INVITE or CANCEL. The SIP response code if the type is Response: 100, 183, 200.
- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port
- *further_info*—More information appears for SIP match and SIP parameter commands, as follows:

  For SIP match commands:

  matched Class *id*: *class-name*

  For example:

  ```
  matched Class 1234: my_class
  ```

  For SIP parameter commands:

  parameter-command: *descriptive-message*

  For example:

  ```
  strict-header-validation: Mandatory header field Via is missing
  state-checking: Message CANCEL is not permitted to create a Dialog.
  ```

Recommended Action None required.

607003

Error Message `%ASA-6-607003: action_class: Received SIP req_resp req_resp_info from src_ifc:sip/sport to dest_ifc:dip/dport; further_info`

Explanation A SIP classification was performed on a SIP message, and the specified criteria were satisfied. As a result, the standalone log action occurs.

- *action_class*—SIP classification for SIP match commands or SIP parameter for parameter commands
- *req_resp*—Request or Response
- *req_resp_info*—The SIP method name if the type is Request: INVITE or CANCEL. The SIP response code if the type is Response: 100, 183, 200.
- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address.
- *dport*—The destination port.
- *further_info*—More information appears for SIP match and SIP parameter commands, as follows:

  For SIP match commands:

  matched Class *id*: *class-name*

  For example:

  ```
  matched Class 1234: my_class
  ```

  For SIP parameter commands:

  parameter-command: *descriptive-message*

  For example:

  ```
  strict-header-validation: Mandatory header field Via is missing
  state-checking: Message CANCEL is not permitted to create a Dialog.
  ```

Recommended Action None required.

608001

Error Message `%ASA-6-608001: Pre-allocate Skinny connection_type secondary channel for interface_name:IP_address to interface_name:IP_address from string message`

Explanation The **inspect skinny** command preallocated a Skinny connection after inspecting a Skinny message. The *connection_type* is one of the following strings:

- SIGNALLING UDP
- SIGNALLING TCP

- SUBSCRIBE UDP
- SUBSCRIBE TCP
- Via UDP
- Route
- RTP
- RTCP

Recommended Action None required.

608002

Error Message `%ASA-4-608002: Dropping Skinny message for in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, SCCPPrefix length value too small`

Explanation A Skinny (SSCP) message was received with an SCCP prefix length less than the minimum length configured.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet
- *value*—The SCCP prefix length of the packet

Recommended Action If the SCCP message is valid, then customize the Skinny policy map to increase the minimum length value of the SSCP prefix.

608003

Error Message `%ASA-4-608003: Dropping Skinny message for in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, SCCPPrefix length value too large`

Explanation A Skinny (SSCP) message was received with an SCCP prefix length greater than the maximum length configured.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet

- *value*—The SCCP prefix length of the packet

Recommended Action If the SCCP message is valid, then customize the Skinny policy map to increase the maximum length value of the SCCP prefix.

608004

Error Message `%ASA-4-608004: Dropping Skinny message for in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, message id value not allowed`

Explanation This SCCP message ID is not allowed.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet
- *value*—The SCCP prefix length of the packet

Recommended Action If the SCCP messages should be allowed, then customize the Skinny policy map to allow them.

608005

Error Message `%ASA-4-608005: Dropping Skinny message for in_ifc:src_ip/src_port to out_ifc:dest_ip/dest_port, message id value registration not complete`

Explanation This SCCP message ID is not allowed, because the endpoint did not complete registration.

- *in_ifc*—The input interface
- *src_ip*—The source IP address of the packet
- *src_port*—The source port of the packet
- *out_ifc*—The output interface
- *dest_ip*—The destination IP address of the packet
- *dest_port*—The destination port of the packet
- *value*—The SCCP prefix length of the packet

Recommended Action If the SCCP messages that are being dropped are valid, then customize the Skinny policy map to disable registration enforcement.

609001

Error Message `%ASA-7-609001: Built local-host interface_name:IP_address`

Explanation A network state container was reserved for host *IP_address* connected to interface *interface_name*.

Recommended Action None required.

609002

Error Message `%ASA-7-609002: Teardown local-host interface_name:IP_address duration time`

Explanation A network state container for host *IP_address* connected to interface *interface_name* was removed.

Recommended Action None required.

610001

Error Message `%ASA-3-610001: NTP daemon interface interface_name: Packet denied from IP_address`

Explanation An NTP packet was received from a host that does not match one of the configured NTP servers. The ASA is only an NTP client; it is not a time server and does not respond to NTP requests.

Recommended Action None required.

610002

Error Message `%ASA-3-610002: NTP daemon interface interface_name: Authentication failed for packet from IP_address`

Explanation The received NTP packet failed the authentication check.

Recommended Action Make sure that both the ASA and the NTP server are set to use authentication, and the same key number and value.

610101

Error Message `%ASA-6-610101: Authorization failed: Cmd: command Cmdtype: command_modifier`

Explanation Command authorization failed for the specified command. The *command_modifier* is one of the following strings:

- **cmd** (this string means the command has no modifier)
- **clear**
- **no**
- **show**

Explanation If the ASA encounters any other value other than the four command types listed, the message "unknown command type" appears.

Recommended Action None required.

611101

Error Message `%ASA-6-611101: User authentication succeeded: Uname: user`

Explanation User authentication succeeded when accessing the ASA.

Recommended Action None required.

611102

Error Message `%ASA-6-611102: User authentication failed: Uname: user`

Explanation User authentication failed when attempting to access the ASA.

Recommended Action None required.

611103

Error Message `%ASA-5-611103: User logged out: Uname: user`

Explanation The specified user logged out.

Recommended Action None required.

611104

Error Message `%ASA-5-611104: Serial console idle timeout exceeded`

Explanation The configured idle timeout for the ASA serial console was exceeded because of no user activity.

Recommended Action None required.

611301

Error Message `%ASA-6-611301: VPNClient: NAT configured for Client Mode with no split tunneling: NAT address: mapped_address`

Explanation The VPN client policy for client mode with no split tunneling was installed.

Recommended Action None required.

611302

Error Message `%ASA-6-611302: VPNClient: NAT exemption configured for Network Extension Mode with no split tunneling`

Explanation The VPN client policy for network extension mode with no split tunneling was installed.

Recommended Action None required.

611303

Error Message `%ASA-6-611303: VPNClient: NAT configured for Client Mode with split tunneling: NAT address: mapped_address Split Tunnel Networks: IP_address/netmask IP_address/netmask`

Explanation The VPN client policy for client mode with split tunneling was installed.

Recommended Action None required.

611304

Error Message `%ASA-6-611304: VPNClient: NAT exemption configured for Network Extension Mode with split tunneling: Split Tunnel Networks: IP_address/netmask IP_address/netmask`

Explanation The VPN client policy for network extension mode with split tunneling was installed.

Recommended Action None required.

611305

Error Message `%ASA-6-611305: VPNClient: DHCP Policy installed: Primary DNS: IP_address Secondary DNS: IP_address Primary WINS: IP_address Secondary WINS: IP_address`

Explanation The VPN client policy for DHCP was installed.

Recommended Action None required.

611306

Error Message `%ASA-6-611306: VPNClient: Perfect Forward Secrecy Policy installed`

Explanation Perfect forward secrecy was configured as part of the VPN client download policy.

Recommended Action None required.

611307

Error Message `%ASA-6-611307: VPNClient: Head end: IP_address`

Explanation The VPN client is connected to the specified headend.

Recommended Action None required.

611308

Error Message `%ASA-6-611308: VPNClient: Split DNS Policy installed: List of domains: string string`

Explanation A split DNS policy was installed as part of the VPN client downloaded policy.

Recommended Action None required.

611309

Error Message `%ASA-6-611309: VPNClient: Disconnecting from head end and uninstalling previously downloaded policy: Head End: IP_address`

Explanation A VPN client is disconnecting and uninstalling a previously installed policy.

Recommended Action None required.

611310

Error Message `%ASA-6-611310: VNPClient: XAUTH Succeeded: Peer: IP_address`

Explanation The VPN client Xauth succeeded with the specified headend.

Recommended Action None required.

611311

Error Message `%ASA-6-611311: VNPClient: XAUTH Failed: Peer: IP_address`

Explanation The VPN client Xauth failed with the specified headend.

Recommended Action None required.

611312

Error Message `%ASA-6-611312: VPNClient: Backup Server List: reason`

Explanation When the ASA is an Easy VPN remote device, the Easy VPN server downloaded a list of backup servers to the ASA. This list overrides any backup servers that you have configured locally. If the downloaded list is empty, then the ASA uses no backup servers. The *reason* is one of the following messages:

- A list of backup server IP addresses
- Received NULL list. Deleting current backup servers

Recommended Action None required.

611313

Error Message `%ASA-3-611313: VPNClient: Backup Server List Error: reason`

Explanation When the ASA is an Easy VPN remote device, and the Easy VPN server downloads a backup server list to the ASA, the list includes an invalid IP address or a hostname. The ASA does not support DNS, and therefore does not support hostnames for servers, unless you manually map a name to an IP address using the **name** command.

Recommended Action On the Easy VPN server, make sure that the server IP addresses are correct, and configure the servers as IP addresses instead of hostnames. If you must use hostnames on the server, use the **name** command on the Easy VPN remote device to map the IP addresses to names.

611314

Error Message `%ASA-6-611314: VPNClient: Load Balancing Cluster with Virtual IP: IP_address has redirected the to server IP_address`

Explanation When the ASA is an Easy VPN remote device, the master server of the load balancing cluster redirected the ASA to connect to a particular server.

Recommended Action None required.

611315

Error Message `%ASA-6-611315: VPNClient: Disconnecting from Load Balancing Cluster member IP_address`

Explanation When the ASA is an Easy VPN remote device, it disconnected from a load balancing cluster server.

Recommended Action None required.

611316

Error Message `%ASA-6-611316: VPNClient: Secure Unit Authentication Enabled`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy enabled SUA.

Recommended Action None required.

611317

Error Message `%ASA-6-611317: VPNClient: Secure Unit Authentication Disabled`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy disabled SUA.

Recommended Action None required.

611318

Error Message `%ASA-6-611318: VPNClient: User Authentication Enabled: Auth Server IP: IP_address Auth Server Port: port Idle Timeout: time`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy enabled IUA for users on the ASA inside network.

- *IP_address*—The server IP address to which the ASA sends authentication requests.
- *port*—The server port to which the ASA sends authentication requests
- *time*—The idle timeout value for authentication credentials

Recommended Action None required.

611319

Error Message `%ASA-6-611319: VPNClient: User Authentication Disabled`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy disabled IUA for users on the ASA inside network.

Recommended Action None required.

611320

Error Message `%ASA-6-611320: VPNClient: Device Pass Thru Enabled`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy enabled device pass-through. The device pass-through feature allows devices that cannot perform authentication (such as an IP phone) to be exempt from authentication when IUA is enabled. If the Easy VPN server enabled this feature, you can specify the devices that should be exempt from authentication (IUA) using the **vpnclient mac-exempt** command on the ASA.

Recommended Action None required.

611321

Error Message `%ASA-6-611321: VPNClient: Device Pass Thru Disabled`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy disabled device pass-through.

Recommended Action None required.

611322

Error Message `%ASA-6-611322: VPNClient: Extended XAUTH conversation initiated when SUA disabled`

Explanation When the ASA is an Easy VPN remote device and the downloaded VPN policy disabled SUA, the Easy VPN server uses two-factor/SecurID/cryptocard-based authentication mechansims to authenticate the ASA using XAUTH.

Recommended Action If you want the Easy VPN remote device to be authenticated using two-factor/SecureID/cryptocard-based authentication mechanisms, enable SUA on the server.

611323

Error Message `%ASA-6-611323: VPNClient: Duplicate split nw entry`

Explanation When the ASA is an Easy VPN remote device, the downloaded VPN policy included duplicate split network entries. An entry is considered a duplicate if it matches both the network address and the network mask.

Recommended Action Remove duplicate split network entries from the VPN policy on the Easy VPN server.

612001

Error Message `%ASA-5-612001: Auto Update succeeded:`*`filename`*`, version:`*`number`*

Explanation An update from an Auto Update server was successful. The *filename* variable is **image**, **ASDM file**, or **configuration**. The **version** *number* variable is the version number of the update.

Recommended Action None required.

612002

Error Message `%ASA-4-612002: Auto Update failed:filename, version:number, reason:reason`

Explanation An update from an Auto Update server failed.

- *filename*—Either an image file, an ASDM file, or a configuration file.
- *number*—The version number of the update.
- *reason*—The failure reason, which may be one of the following:
  - Failover module failed to open stream buffer
  - Failover module failed to write data to stream buffer
  - Failover module failed to perform control operation on stream buffer
  - Failover module failed to open flash file
  - Failover module failed to write data to flash
  - Failover module operation timeout
  - Failover command link is down
  - Failover resource is not available
  - Invalid failover state on mate
  - Failover module encountered file transfer data corruption
  - Failover active state change
  - Failover command EXEC failed
  - The image cannot run on current system
  - Unsupported file type

Recommended Action Check the configuration of the Auto Update server. Check to see if the standby unit is in the failed state. If the Auto Update server is configured correctly, and the standby unit is not in the failed state, contact the Cisco TAC.

612003

Error Message `%ASA-4-612003:Auto Update failed to contact:url, reason:reason`

Explanation The Auto Update daemon was unable to contact the specified URL *url*, which can be the URL of the Auto Update server or one of the file server URLs returned by the Auto Update server. The *reason* field describes why the contact failed. Possible reasons for the failure include no response from the server, authentication failed, or a file was not found.

Recommended Action Check the configuration of the Auto Update server.

613001

Error Message %ASA-6-613001: Checksum Failure in database in area *string* Link State Id *IP_address* Old Checksum *number* New Checksum *number*

Explanation OSPF has detected a checksum error in the database because of memory corruption.

Recommended Action Restart the OSPF process.

613002

Error Message %ASA-6-613002: interface *interface_name* has zero bandwidth

Explanation The interface reported its bandwidth as zero.

Recommended Action Copy the message exactly as it appears, and report it to the Cisco TAC.

613003

Error Message %ASA-6-613003: *IP_address netmask* changed from area *string* to area *string*

Explanation An OSPF configuration change has caused a network range to change areas.

Recommended Action Reconfigure OSPF with the correct network range.

613004

Error Message %ASA-3-613004: Internal error: memory allocation failure

Explanation An internal software error occurred.

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

613005

Error Message %ASA-3-613005: Flagged as being an ABR without a backbone area

Explanation The router was flagged as an Area Border Router (ABR) without a backbone area in the router.

Recommended Action Restart the OSPF process.

613006

Error Message `%ASA-3-613006: Reached unknown state in neighbor state machine`

Explanation An internal software error in this router has resulted in an invalid neighbor state during database exchange.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error and submit them to Cisco TAC.

613007

Error Message `%ASA-3-613007: area string lsid IP_address mask netmask type number`

Explanation OSPF is trying to add an existing LSA to the database.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error and submit them to Cisco TAC.

613008

Error Message `%ASA-3-613008: if inside if_state number`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error and submit them to Cisco TAC.

613011

Error Message `%ASA-3-613011: OSPF process number is changing router-id. Reconfigure virtual link neighbors with our new router-id`

Explanation An OSPF process is being reset, and it is going to select a new router ID. This action brings down all virtual links. To make them work again, the virtual link configuration needs to be changed on all virtual link neighbors.

Recommended Action Change the virtual link configuration on all the virtual link neighbors to reflect the new router ID.

613013

Error Message `%ASA-3-613013: OSPF LSID IP_address adv IP_address type number gateway IP_address metric number forwarding addr route IP_address/mask type number has no corresponding LSA`

Explanation OSPF found inconsistency between its database and the IP routing table.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613014

Error Message `%ASA-6-613014: Base topology enabled on interface string attached to MTR compatible mode area string`

Explanation OSPF interfaces attached to MTR-compatible OSPF areas require the base topology to be enabled.

Recommended Action None.

613015

Error Message `%ASA-4-613015: Process 1 flushes LSA ID IP_address type-number adv-rtr IP_address in area mask`

Explanation A router is extensively re-originating or flushing the LSA reported by this error message.

Recommended Action If this router is flushing the network LSA, it means the router received a network LSA whose LSA ID conflicts with the IP address of one of the router's interfaces and flushed the LSA out of the network. For OSPF to function correctly, the IP addresses of transit networks must be unique. Conflicting routers are the router reporting this error message and the router with the OSPF router ID reported as adv-rtr in this message. If this router is re-originating an LSA, it is highly probable that some other router is flushing this LSA out of the network. Find that router and avoid the conflict. The conflict for a Type-2 LSA may be due to a duplicate LSA ID. For a Type-5 LSA, it may be a duplicate router ID on the router reporting this error message and on the routers connected to a different area. In an unstable network, this message may also warn of extensive re-origination of the LSA for some other reason. Contact Cisco TAC to investigate this type of case.

613016

Error Message `%ASA-3-613016: Area string router-LSA of length number bytes plus update overhead bytes is too large to flood.`

Explanation The router tried to build a router-LSA that is larger than the huge system buffer size or the OSPF protocol imposed maximum.

Recommended Action If the reported total length (LSA size plus overhead) is larger than the huge system buffer size but less than 65535 bytes (the OSPF protocol imposed maximum), you may increase the huge system buffer size. If the reported total length is greater than 65535, you need to decrease the number of OSPF interfaces in the reported area.

613017

Error Message `%ASA-4-613017: Bad LSA mask: Type number, LSID IP_address Mask` *`mask`* `from IP_address`

Explanation The router received an LSA with an invalid LSA mask because of an incorrect configuration from the LSA originator. As a result, this route is not installed in the routing table.

Recommended Action Find the originating router of the LSA with the bad mask, then correct any misconfiguration of this LSA's network. For further debugging, call Cisco TAC for assistance.

613018

Error Message `%ASA-4-613018: Maximum number of non self-generated LSA has been exceeded "OSPF number" - number LSAs`

Explanation The maximum number of non self-generated LSAs has been exceeded.

Recommended Action Check whether or not a router in the network is generating a large number of LSAs as a result of a misconfiguration.

613019

Error Message `%ASA-4-613019: Threshold for maximum number of non self-generated LSA has been reached "OSPF number" - number LSAs`

Explanation The threshold for the maximum number of non self-generated LSAs has been reached.

Recommended Action Check whether or not a router in the network is generating a large number of LSAs as a result of a misconfiguration.

613021

Error Message `%ASA-4-613021: Packet not written to the output queue`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613022

Error Message `%ASA-4-613022: Doubly linked list linkage is NULL`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613023

Error Message `%ASA-4-613023: Doubly linked list prev linkage is NULL number`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613024

Error Message `%ASA-4-613024: Unrecognized timer number in OSPF string`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613025

Error Message `%ASA-4-613025: Invalid build flag number for LSA IP_address, type number`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613026

Error Message `%ASA-4-613026: Can not allocate memory for area structure`

Explanation An internal error occurred.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613027

Error Message `%ASA-6-613027: OSPF process number removed from interface interface_name`

Explanation The OSPF process was removed from the interface because of an IP VRF.

Recommended Action None.

613028

Error Message `%ASA-6-613028: Unrecognized virtual interface intetface_name. Treat it as loopback stub route`

Explanation The virtual interface type was not recognized by OSPF, so it is treated as a loopback interface stub route.

Recommended Action None.

613029

Error Message `%ASA-3-613029: Router-ID IP_address is in use by ospf process number`

Explanation The ASA attempted to assign a router ID that is in use by another process.

Recommended Action Configure another router ID for one of the processes.

613030

Error Message `%ASA-4-613030: Router is currently an ASBR while having only one area which is a stub area`

Explanation An ASBR must be attached to an area that can carry AS external or NSSA LSAs.

Recommended Action Make the area to which the router is attached into an NSSA or regular area.

613031

Error Message `%ASA-4-613031: No IP address for interface inside`

Explanation The interface is not point-to-point and is unnumbered.

Recommended Action Change the interface type or give the interface an IP address.

613032

Error Message `%ASA-3-613032: Init failed for interface inside, area is being deleted. Try again.`

Explanation The interface initialization failed. The possible reasons include the following:

- The area to which the interface is being attached is being deleted.
- It was not possible to create a neighbor datablock for the local router.

Recommended Action Remove the configuration command that covers the interface and then try it again.

613033

Error Message `%ASA-3-613033: Interface inside is attached to more than one area`

Explanation The interface is on the interface list for an area other than the one to which the interface links.

Recommended Action Copy the error message, the configuration and any details about the events leading up to this error, and submit them to Cisco TAC.

613034

Error Message `%ASA-3-613034: Neighbor IP_address not configured`

Explanation The configured neighbor options are not valid.

Recommended Action Check the configuration options for the **neighbor** command and correct the options or the network type for the neighbor's interface.

613035

Error Message `%ASA-3-613035: Could not allocate or find neighbor IP_address`

Explanation An internal error occurred.

Recommended Action Copy the error message exactly as it appears, and report it to Cisco TAC.

613036

Error Message `%ASA-4-613036: Can not use configured neighbor: cost and database-filter options are allowed only for a point-to-multipoint network`

Explanation The configured neighbor was found on an NBMA network and either the cost or database-filter option was configured. These options are only allowed on point-to-multipoint type networks.

Recommended Action Check the configuration options for the **neighbor** command and correct the options or the network type for the neighbor's interface.

613037

Error Message `%ASA-4-613037: Can not use configured neighbor: poll and priority options are allowed only for a NBMA network`

Explanation The configured neighbor was found on a point-to-multipoint network and either the poll or priority option was configured. These options are only allowed on NBMA-type networks.

Recommended Action Check the configuration options for the **neighbor** command and correct the options or the network type for the neighbor's interface.

613038

Error Message `%ASA-4-613038: Can not use configured neighbor: cost or database-filter option is required for point-to-multipoint broadcast network`

Explanation The configured neighbor was found on a point-to-multipoint broadcast network. Either the **cost** or **database-filter** option needs to be configured.

Recommended Action Check the configuration options for the **neighbor** command and correct the options or the network type for the neighbor's interface.

613039

Error Message `%ASA-4-613039: Can not use configured neighbor: neighbor command is allowed only on NBMA and point-to-multipoint networks`

Explanation The configured neighbor was found on a network for which the network type was neither NBMA nor point-to-multipoint.

Recommended Action None.

613040

Error Message `%ASA-4-613040: OSPF-1 Area string: Router IP_address originating invalid type number LSA, ID IP_address, Metric number on Link ID IP_address Link Type number`

Explanation The router indicated in this message has originated an LSA with an invalid metric. If this is a router LSA and the link metric is zero, a risk of routing loops and traffic loss in the network exists.

Recommended Action Configure a valid metric for the given LSA type and link type on the router originating on the reported LSA.

613041

Error Message `%ASA-6-613041: OSPF-100 Areav string: LSA ID IP_address, Type number, Adv-rtr IP_address, LSA counter DoNotAge`

Explanation An internal error has corrected itself. There is no operational effect related to this error message.

Recommended Action Check the system memory. If memory is low, then the timer wheel functionality did not initialize. Try to reenter the commands when memory is available. If there is sufficient memory, then contact the Cisco TAC and provide output from the **show memory**, **show processes**, and **show tech-support ospf** commands.

613042

Error Message `%ASA-4-613042: OSPF process number lacks forwarding address for type 7 LSA IP_address in NSSA string - P-bit cleared`

Explanation There is no viable forwarding address in the NSSA area. As a result, the P-bit must be cleared and the Type 7 LSA is not translated into a Type 5 LSA by the NSSA translator. See RFC 3101.

Recommended Action Configure at least one interface in the NSSA with an advertised IP address. A loopback is preferable because an advertisement does not depend on the underlying layer 2 state.

613043

Error Message `%ASA-6-613043:`

Explanation A negative database reference count occurred.

Recommended Action Check the system memory. If memory is low, then the timer wheel functionality did not initialize. Try to reenter the commands when memory is available. If there is sufficient memory, then contact the Cisco TAC and provide output from the **show memory**, **show processes**, and **show tech-support ospf** commands.

613101

Error Message `%ASA-6-613101: Checksum Failure in database in area` *`s`*`\n Link State Id` *`i`* `Old Checksum #`*`x`* `New Checksum #`*`x`*`\n`

Explanation OSPF has detected a checksum error in the database because of memory corruption.

Recommended Action Restart the OSPF process.

613102

Error Message %ASA-6-613102: interface *s* has zero bandwidth

Explanation The interface reports its bandwidth as zero.

Recommended Action None required.

613103

Error Message %ASA-6-613103: *i m* changed from area *AREA_ID_STR* to area *AREA_ID_STR*

Explanation An OSPF configuration change has caused a network range to change areas.

Recommended Action None required.

613104

Error Message %ASA-6-613104: Unrecognized virtual interface *IF_NAME*.

Explanation The virtual interface type was not recognized by OSPFv3, so it is treated as a loopback interface stub route.

Recommended Action None required.

614001

Error Message %ASA-6-614001: Split DNS: request patched from server: *IP_address* to server: *IP_address*

Explanation Split DNS is redirecting DNS queries from the original destination server to the primary enterprise DNS server.

Recommended Action None required.

614002

Error Message %ASA-6-614002: Split DNS: reply from server:*IP_address* reverse patched back to original server:*IP_address*

Explanation Split DNS is redirecting DNS queries from the enterprise DNS server to the original destination server.

Recommended Action None required.

615001

Error Message %ASA-6-615001: vlan number not available for firewall interface

Explanation The switch removed the VLAN from the ASA.

Recommended Action None required.

615002

Error Message %ASA-6-615002: vlan number available for firewall interface

Explanation The switch added the VLAN to the ASA.

Recommended Action None required.

616001

Error Message %ASA-6-616001:Pre-allocate MGCP *data_channel* connection for *inside_interface*:*inside_address* to *outside_interface*:*outside_address*/*port* from *message_type message*

Explanation An MGCP data channel connection, RTP, or RTCP was preallocated. The message text also specifies which message has triggered the connection preallocation.

Recommended Action None required.

617001

Error Message %ASA-6-617001: GTPv *version msg_type* from *source_interface*:*source_address*/*source_port* not accepted by *source_interface*:*dest_address*/*dest_port*

Explanation A request was not accepted by the peer, which is usually seen with a Create PDP Context request.

Recommended Action None required.

617002

Error Message %ASA-6-617002: Removing v1 PDP Context with TID *tid* from GGSN *IP_address* and SGSN *IP_address*, Reason: *reason* or Removing v1 *primary|secondary* PDP Context with TID *tid* from GGSN *IP_address* and SGSN *IP_address*, Reason: *reason*

Explanation A PDP context was removed from the database either because it expired, a Delete PDP Context Request/Response was exchanged, or a user removed it using the CLI.

Recommended Action None required.

617003

Error Message %ASA-6-617003: GTP Tunnel created from *source_interface*:*source_address*/*source_port* to *source_interface*:*dest_address*/*dest_port*

Explanation A GTP tunnel was created after receiving a Create PDP Context Response that accepted the request.

Recommended Action None required.

617004

Error Message %ASA-6-617004: GTP connection created for response from *source_interface*:*source_address*/*0* to *source_interface*:*dest_address*/*dest_port*

Explanation The SGSN or GGSN signaling address in the Create PDP Context Request or Response, respectively, was different from the SGSN/GGSN sending it.

Recommended Action None required.

617100

Error Message ASA-6-617100: Teardown *num_conns* connection(s) for user *user_ip*

Explanation The connections for this user were torn down because either a RADIUS accounting stop or RADIUS accounting start was received, which includes attributes that were configured in the policy map for a match. The attributes did not match those stored for the user entry, if the user entry exists.

- *num_conns*—The number of connections torn down
- *user_ip*—The IP address (framed IP attribute) of the user

Recommended Action None required.

620001

Error Message `%ASA-6-620001: Pre-allocate CTIQBE {RTP | RTCP} secondary channel for interface_name:outside_address[/outside_port] to interface_name:inside_address[/inside_port] from CTIQBE_message_name message`

Explanation The ASA preallocated a connection object for the specified CTIQBE media traffic. This message is rate limited to one message every 10 seconds.

Recommended Action None required.

620002

Error Message `%ASA-4-620002: Unsupported CTIQBE version: hex: from interface_name:IP_address/port to interface_name:IP_address/port`

Explanation The ASA received a CTIQBE message with an unsupported version number, and dropped the packet. This message is rate limited to one message every 10 seconds.

Recommended Action If the version number captured in the log message is unreasonably large (greater than 10), the packet may be malformed, a non-CTIQBE packet, or corrupted before it arrives at the ASA. We recommend that you determine the source of the packets. If the version number is reasonably small (less than or equal to 10), then contact the Cisco TAC to see if a new ASA image that supports this CTIQBE version is available.

621001

Error Message `%ASA-6-621001: Interface interface_name does not support multicast, not enabled`

Explanation An attempt was made to enable PIM on an interface that does not support multicast.

Recommended Action If the problem persists, contact the Cisco TAC.

621002

Error Message `%ASA-6-621002: Interface interface_name does not support multicast, not enabled`

Explanation An attempt was made to enable IGMP on an interface that does not support multicast.

Recommended Action If the problem persists, contact the Cisco TAC.

621003

Error Message `%ASA-6-621003: The event queue size has exceeded number`

Explanation The number of event managers created has exceeded the expected amount.

Recommended Action If the problem persists, contact the Cisco TAC.

621006

Error Message `%ASA-6-621006: Mrib disconnected, (IP_address,IP_address) event cancelled`

Explanation A packet triggering a data-driven event was received, but the connection to the MRIB was down. The notification was cancelled.

Recommended Action If the problem persists, contact the Cisco TAC.

621007

Error Message `%ASA-6-621007: Bad register from interface_name:IP_address to IP_address for (IP_address, IP_address)`

Explanation A PIM router configured as a rendezvous point or with NAT has received a PIM register packet from another PIM router. The data encapsulated in this packet is invalid.

Recommended Action The sending router is erroneously sending non-RFC registers. Upgrade the sending router.

622001

Error Message `%ASA-6-622001: string tracked route network mask address, distance number, table string, on interface interface-name`

Explanation A tracked route has been added to or removed from a routing table, which means that the state of the tracked object has changed from up or down.

- *string*—Adding or Removing
- *network*—The network address
- *mask*—The network mask
- *address*—The gateway address
- *number*—The route administrative distance
- *string*—The routing table name

- *interface-name*—The interface name as specified by the **nameif** command

Recommended Action None required.

622101

Error Message `%ASA-6-622101: Starting regex table compilation for match_command; table entries = regex_num entries`

Explanation Information on the background activities of regex compilation appear.

- *match_command*—The match command to which the regex table is associated
- *regex_num*—The number of regex entries to be compiled

Recommended Action None required.

622102

Error Message `%ASA-6-622102: Completed regex table compilation for match_command; table size = num bytes`

Explanation Information on the background activities of the regex compilation appear.

- *match_command*—The match command to which the regex table is associated
- *num*—The size, in bytes, of the compiled table

Recommended Action None required.

634001

Error Message `%ASA-6-634001: DAP: User user, Addr ipaddr, Connection connection; The following DAP records were selected for this connection: DAP Record names`

Explanation The DAP records selected for the connection appear.

- *user*—The authenticated username
- *ipaddr*—The IP address of the remote client
- *connection*—The type of client connection:
  - IPsec—IPsec connection
  - AnyConnect—AnyConnect connection
  - Clientless—Web browser connection
  - Cut-Through-Proxy—Cut-Through-Proxy connection
  - L2TP—L2TP client connection

- *DAP record names*—The comma-separated list of the DAP record names

Recommended Action None required.

Messages 701001 to 780004

This section includes messages from 701001 to 780004.

Most of the ISAKMP messages have a common set of prepended objects to help identify the tunnel. These objects precede the descriptive text of a message when available. If the object is not known at the time the message is generated, the specific *heading* = *value* combination will not be displayed.

The objects will be prepended as follows:

Group = *groupname*, Username = *user*, IP = *IP_address*,...

Where the Group identifies the tunnel group, the Username is the username from the local database or AAA server, and the IP address is the public IP address of the remote access client or L2L peer.

701001

Error Message `%ASA-7-701001: alloc_user() out of Tcp_user objects`

Explanation A AAA message that appears if the user authentication rate is too high for the module to handle new AAA requests.

Recommended Action Enable Flood Defender with the **floodguard enable** command.

701002

Error Message `%ASA-7-701002: alloc_user() out of Tcp_proxy objects`

Explanation A AAA message that appears if the user authentication rate is too high for the module to handle new AAA requests.

Recommended Action Enable Flood Defender with the **floodguard enable** command.

702305

Error Message `%ASA-3-702305: IPSEC: An direction tunnel_type SA (SPI=spi) between local_IP and remote_IP (username) is rekeying due to sequence number rollover.`

Explanation More than four billion packets have been received in the IPsec tunnel, and a new tunnel is being negotiated.

- *direction*—SA direction (inbound or outbound)
- *tunnel_type*—SA type (remote access or L2L)

- *spi*—IPsec Security Parameter Index
- *local_IP*—IP address of the tunnel local endpoint
- *remote_IP*—IP address of the tunnel remote endpoint
- *username*—Username associated with the IPsec tunnel

Recommended Action Contact the peer administrator to compare the SA lifetime setting.

702307

Error Message `%ASA-7-702307: IPSEC: An direction tunnel_type SA (SPI=spi) between local_IP and remote_IP (username) is rekeying due to data rollover.`

Explanation An SA data life span expired. An IPsec SA is rekeying as a result of the amount of data transmitted with that SA. This information is useful for debugging rekeying issues.

- *direction*—SA direction (inbound or outbound)
- *tunnel_type*—SA type (remote access or L2L)
- *spi*—IPsec Security Parameter Index
- *local_IP*—IP address of the tunnel local endpoint
- *remote_IP*—IP address of the tunnel remote endpoint
- *username*—Username associated with the IPsec tunnel

Recommended Action None required.

703001

Error Message `%ASA-7-703001: H.225 message received from interface_name:IP_address/port to interface_name:IP_address/port is using an unsupported version number`

Explanation The ASA received an H.323 packet with an unsupported version number. The ASA might reencode the protocol version field of the packet to the highest supported version.

Recommended Action Use the version of H.323 that the ASA supports in the VoIP network.

703002

Error Message `%ASA-7-703002: Received H.225 Release Complete with newConnectionNeeded for interface_name:IP_address to interface_name:IP_address/port`

Explanation The ASA received the specified H.225 message, and the ASA opened a new signaling connection object for the two specified H.323 endpoints.

Recommended Action None required.

709001, 709002

Error Message `%ASA-7-709001: FO replication failed: cmd=`*`command`* `returned=`*`code`*

Error Message `%ASA-7-709002: FO unreplicable: cmd=`*`command`*

Explanation Failover messages that only appear during the development debugging and testing phases.

Recommended Action None required.

709003

Error Message `%ASA-1-709003: (Primary) Beginning configuration replication: Sending to mate.`

Explanation A failover message that appears when the active unit starts replicating its configuration to the standby unit. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

709004

Error Message `%ASA-1-709004: (Primary) End Configuration Replication (ACT)`

Explanation A failover message that appears when the active unit completes replication of its configuration on the standby unit. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

709005

Error Message `%ASA-1-709005: (Primary) Beginning configuration replication: Receiving from mate.`

Explanation The standby ASA received the first part of the configuration replication from the active ASA. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

709006

Error Message `%ASA-1-709006: (Primary) End Configuration Replication (STB)`

Explanation A failover message that appears when the standby unit completes replication of a configuration sent by the active unit. Primary can also be listed as Secondary for the secondary unit.

Recommended Action None required.

709007

Error Message `%ASA-2-709007: Configuration replication failed for command` *`command`*

Explanation A failover message that appears when the standby unit is unable to complete replication of a configuration sent by the active unit. The command that caused the failure appears at the end of the message.

Recommended Action If the problem persists, contact the Cisco TAC.

710001

Error Message `%ASA-7-710001: TCP access requested from` *`source_address/source_port`* `to` *`interface_name:dest_address/service`*

Explanation The first TCP packet destined to the ASA requests to establish a TCP session. This packet is the first SYN packet of the three-way handshake. This message appears when the respective (Telnet, HTTP, or SSH) has permitted the packet. However, the SYN cookie verification is not yet completed and no state is reserved.

Recommended Action None required.

710002

Error Message `%ASA-7-710002: {TCP|UDP} access permitted from` *`source_address/source_port`* `to` *`interface_name:dest_address/service`*

Explanation For a TCP connection, the second TCP packet destined for the ASA requested to establish a TCP session. This packet is the final ACK of the three-way handshake. The respective (Telnet, HTTP, or SSH) has permitted the packet. Also, the SYN cookie verification was successful and the state is reserved for the TCP session.

For a UDP connection, the connection was permitted. For example, the module received an SNMP request from an authorized SNMP management station, and the request has been processed. This message is rate limited to one message every 10 seconds.

Recommended Action None required.

710003

Error Message `%ASA-3-710003: {TCP|UDP} access denied by ACL from source_IP/source_port to interface_name:dest_IP/service`

Explanation The ASA denied an attempt to connect to the interface service. For example, the ASA received an SNMP request from an unauthorized SNMP management station. If this message appears frequently, it can indicate an attack.

For example:

```
%ASA-3-710003: UDP access denied by ACL from 95.1.1.14/5000 to outside:95.1.1.13/1005
```

Recommended Action Use the **show run http**, **show run ssh**, or **show run telnet** commands to verify that the ASA is configured to permit the service access from the host or network.

710004

Error Message `%ASA-7-710004: TCP connection limit exceeded from Src_ip/Src_port to In_name:Dest_ip/Dest_port (current connections/connection limit = Curr_conn/Conn_lmt)`

Explanation The maximum number of ASA management connections for the service was exceeded. The ASA permits at most five concurrent management connections per management service. Alternatively, an error may have occurred in the to-the-box connection counter.

- *Src_ip*—The source IP address of the packet
- *Src_por*t—The source port of the packet
- *In_ifc*—The input interface
- *Dest_ip*—The destination IP address of the packet
- *Dest_port*—The destination port of the packet
- *Curr_conn*—The number of current to-the-box admin connections
- *Conn_lmt*—The connection limit

Recommended Action From the console, use the **kill** command to release the unwanted session. If the message was generated because of an error in the to-the-box counter, run the **show conn all** command to display connection details.

710005

Error Message `%ASA-7-710005: {TCP|UDP} request discarded from source_address/source_port to interface_name:dest_address/service`

Explanation The ASA does not have a UDP server that services the UDP request. Also, a TCP packet that does not belong to any session on the ASA may have been discarded. In addition, this message appears (with the SNMP service) when the ASA receives an SNMP request with an empty payload, even if it is from an authorized host. When the service is SNMP, this message occurs a maximum of once every 10 seconds so that the log receiver is not overwhelmed.

Recommended Action In networks that use broadcasting services such as DHCP, RIP, or NetBIOS extensively, the frequency of this message can be high. If this message appears in excessive numbers, it may indicate an attack.

710006

Error Message `%ASA-7-710006: protocol request discarded from source_address to interface_name:dest_address`

Explanation The ASA does not have an IP server that services the IP protocol request; for example, the ASA receives IP packets that are not TCP or UDP, and the ASA cannot service the request.

Recommended Action In networks that use broadcasting services such as DHCP, RIP, or NetBIOS extensively, the frequency of this message can be high. If this message appears in excessive numbers, it may indicate an attack.

710007

Error Message `%ASA-7-710007: NAT-T keepalive received from 86.1.161.1/1028 to outside:86:1.129.1/4500`

Explanation The ASA received NAT-T keepalive messages.

Recommended Action None required.

711001

Error Message `%ASA-7-711001: debug_trace_msg`

Explanation You have entered the **logging debug-trace** command for the logging feature. When the **logging debug-trace** command is enabled, all debugging messages will be redirected to the message for processing. For security reasons, the message output must be encrypted or sent over a secure out-of-band network.

Recommended Action None required.

711002

Error Message `%ASA-4-711002: Task ran for elapsed_time msecs, process = process_name, PC = PC Tracebeback = traceback`

Explanation A process used the CPU for more than 100 milliseconds. This message is used for debugging CPU purposes, and can appear once every five seconds for each offending process.

- *PC*—Instruction pointer of the CPU hogging process
- *traceback*—Stack trace of the CPU hogging process, which can include up to 12 addresses

Recommended Action None required.

711003

Error Message `ASA-7-711003: Unknown/Invalid interface identifier(vpifnum) detected.`

Explanation An internal inconsistency that should not occur during normal operation has occurred. However, this message is not harmful if it rarely occurs. If it occurs frequently, it might be worthwhile debugging.

- *vpifnum*—The 32-bit value corresponding to the interface

Recommended Action If the problem persists, contact the Cisco TAC.

711004

Error Message `%ASA-4-711004: Task ran for msec msec, Process = process_name, PC = pc, Call stack = call stack`

Explanation A process used the CPU for more than 100 milliseconds. This message is used for debugging CPU purposes, and can appear once every five seconds for each offending process.

- *msec*—Length of the detected CPU hog in milliseconds
- *process_name*—Name of the hogging process
- *pc*—Instruction pointer of the CPU hogging process
- *call stack*—Stack trace of the CPU hogging process, which can include up to 12 addresses

Recommended Action None required.

711005

Error Message `%ASA-5-711005: Traceback: call_stack`

Explanation An internal software error that should not occur has occurred. The device can usually recover from this error, and no harmful effect to the device results.

- *call_stack*—The EIPs of the call stack

Recommended Action Contact the Cisco TAC.

711006

Error Message `%ASA-7-711006: CPU profiling has started for n-samples samples. Reason: reason-string.`

Explanation CPU profiling has started.

- *n-samples*—The specified number of CPU profiling samples
- *reason-string*—The possible values are:

  "CPU utilization passed *cpu-utilization%*"

  "Process process-name CPU utilization passed *cpu-utilization%*"

  "None specified"

Recommended Action Collect CPU profiling results and provide them to Cisco TAC.

713004

Error Message `%ASA-3-713004: device scheduled for reboot or shutdown, IKE key acquire message on interface interface num, for Peer IP_address ignored`

Explanation The ASA has received an IKE packet from a remote entity trying to initiate a tunnel. Because the ASA is scheduled for a reboot or shutdown, it does not allow any more tunnels to be established. The IKE packet is ignored and dropped.

Recommended Action None required.

713201

Error Message `%ASA-5-713201: Duplicate Phase Phase packet detected. Action`

Explanation The ASA has received a duplicate of a previous Phase 1 or Phase 2 packet, and will transmit the last message. A network performance or connectivity issue may have occurred, in which the peer is not receiving sent packets in a timely manner.

- *Phase*—Phase 1 or 2

- *Action*—Retransmitting last packet, or No last packet to transmit.

Recommended Action Verify network performance or connectivity.

713202

Error Message `%ASA-6-713202: Duplicate IP_addr packet detected.`

Explanation The ASA has received a duplicate first packet for a tunnel that the ASA is already aware of and negotiating, which indicates that the ASA probably received a retransmission of a packet from the peer.

- *IP_addr*—The IP address of the peer from which the duplicate first packet was received

Recommended Action None required, unless the connection attempt is failing. If this is the case, debug further and diagnose the problem.

713006

Error Message `%ASA-5-713006: Failed to obtain state for message Id message_number, Peer Address: IP_address`

Explanation The ASA does not know about the received message ID. The message ID is used to identify a specific IKE Phase 2 negotiation. An error condition on the ASA may have occurred, and may indicate that the two IKE peers are out-of-sync.

Recommended Action None required.

713008

Error Message `%ASA-3-713008: Key ID in ID payload too big for pre-shared IKE tunnel`

Explanation A key ID value was received in the ID payload, which was longer than the maximum allowed size of a group name for this IKE session using preshared keys authentication. This is an invalid value, and the session is rejected. Note that the key ID specified would never work because a group name of that size cannot be created in the ASA.

Recommended Action Make sure that the client peer (most likely an Altiga remote access client) specifies a valid group name. Notify the user to change the incorrect group name on the client. The current maximum length for a group name is 32 characters.

713009

Error Message `%ASA-3-713009: OU in DN in ID payload too big for Certs IKE tunnel`

Explanation An OU value in the DN was received in the ID payload, which was longer than the maximum allowed size of a group name for this IKE session using Certs authentication. This OU is skipped, and another OU or other criteria may find a matching group.

Recommended Action For the client to be able to use an OU to find a group in the ASA, the group name must be a valid length. The current maximum length of a group name is 32 characters.

713010

Error Message `%ASA-5-713010: IKE area: failed to find centry for message Id message_number`

Explanation An attempt was made to locate a conn_entry (IKE phase 2 structure that corresponds to an IPsec SA) using the unique message ID, which failed. The internal structure was not found, which may occur if a session was terminated in a nonstandard way, but it is more likely that an internal error occurred.

Recommended Action If this problem persists, investigate the peer.

713012

Error Message `%ASA-3-713012: Unknown protocol (protocol). Not adding SA w/spi=SPI value`

Explanation An illegal or unsupported IPsec protocol has been received from the peer.

Recommended Action Check the ISAKMP Phase 2 configuration on the peer(s) to make sure it is compatible with the ASA.

713014

Error Message `%ASA-3-713014: Unknown Domain of Interpretation (DOI): DOI value`

Explanation The ISAKMP DOI received from the peer is unsupported.

Recommended Action Check the ISAKMP DOI configuration on the peer.

713016

Error Message %ASA-3-713016: Unknown identification type, Phase *1 or 2*, Type *ID_Type*

Explanation The ID received from the peer is unknown. The ID can be an unfamiliar valid ID or an invalid or corrupted ID.

Recommended Action Check the configuration on the headend and peer.

713017

Error Message %ASA-3-713017: Identification type not supported, Phase *1 or 2*, Type *ID_Type*

Explanation The Phase 1 or Phase 2 ID received from the peer is legal, but not supported.

Recommended Action Check the configuration on the headend and peer.

713018

Error Message %ASA-3-713018: Unknown ID type during find of group name for certs, Type *ID_Type*

Explanation Tn internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713020

Error Message %ASA-3-713020: No Group found by matching OU(s) from ID payload: *OU_value*

Explanation Tn internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713022

Error Message `%ASA-3-713022: No Group found matching peer_ID or IP_address for Pre-shared key peer IP_address`

Explanation No group exists in the group database with the same name as the value (key ID or IP address) specified by the peer.

Recommended Action Verify the configuration on the peer.

713024

Error Message `%ASA-7-713024: Group group IP ip Received local Proxy Host data in ID Payload: Address IP_address, Protocol protocol, Port port`

Explanation The ASA has received the Phase 2 local proxy ID payload from the remote peer.

Recommended Action None required.

713025

Error Message `%ASA-7-713025: Received remote Proxy Host data in ID Payload: Address IP_address, Protocol protocol, Port port`

Explanation The ASA has received the Phase 2 local proxy ID payload from the remote peer.

Recommended Action None required.

713028

Error Message `%ASA-7-713028: Received local Proxy Range data in ID Payload: Addresses IP_address - IP_address, Protocol protocol, Port port`

Explanation The ASA has received the Phase 2 local proxy ID payload of the remote peer, which includes an IP address range.

Recommended Action None required.

713029

Error Message `%ASA-7-713029: Received remote Proxy Range data in ID Payload: Addresses IP_address - IP_address, Protocol protocol, Port port`

Explanation The ASA has received the Phase 2 local proxy ID payload of the remote peer, which includes an IP address range.

Recommended Action None required.

713032

Error Message `%ASA-3-713032: Received invalid local Proxy Range IP_address - IP_address`

Explanation The local ID payload included the range ID type, and the specified low address was not less than the high address. A configuration problem may exist.

Recommended Action Check the configuration of ISAKMP Phase 2 parameters.

713033

Error Message `%ASA-3-713033: Received invalid remote Proxy Range IP_address - IP_address`

Explanation The remote ID payload included the range ID type, and the specified low address was not less than the high address. A configuration problem may exist.

Recommended Action Check the configuration of ISAKMP Phase 2 parameters.

713034

Error Message `%ASA-7-713034: Received local IP Proxy Subnet data in ID Payload: Address IP_address, Mask netmask, Protocol protocol, Port port`

Explanation The local IP proxy subnet data has been received in the Phase 2 ID payload.

Recommended Action None required.

713035

Error Message %ASA-7-713035: Group *group* IP *ip* Received remote IP Proxy Subnet data in ID Payload: Address *IP_address*, Mask *netmask*, Protocol *protocol*, Port *port*

Explanation The remote IP proxy subnet data has been received in the Phase 2 ID payload.

Recommended Action None required.

713039

Error Message %ASA-7-713039: Send failure: Bytes (*number*), Peer: *IP_address*

Explanation An internal software error has occurred, and the ISAKMP packet cannot be transmitted.

Recommended Action If the problem persists, contact the Cisco TAC.

713040

Error Message %ASA-7-713040: Could not find connection entry and can not encrypt: msgid *message_number*

Explanation An internal software error has occurred, and a Phase 2 data structure cannot be found.

Recommended Action If the problem persists, contact the Cisco TAC.

713041

Error Message %ASA-5-713041: IKE Initiator: *new or rekey* Phase *1 or 2*, Intf *interface_number*, IKE Peer *IP_address* local Proxy Address *IP_address*, remote Proxy Address *IP_address*, Crypto map (*crypto map tag*)

Explanation The ASA is negotiating a tunnel as the initiator.

Recommended Action None required.

713042

Error Message %ASA-3-713042: IKE Initiator unable to find policy: Intf *interface_number*, Src: *source_address*, Dst: *dest_address*

Explanation The IPsec fast path processed a packet that triggered IKE, but the IKE policy lookup failed. This error may be timing related. The ACLs that triggered IKE might have been deleted before IKE processed the initiation request. This problem will most likely correct itself.

Recommended Action If the condition persists, check the L2L configuration, paying special attention to the type of ACL associated with crypto maps.

713043

Error Message %ASA-3-713043: Cookie/peer address *IP_address* session already in progress

Explanation IKE has been triggered again while the original tunnel is in progress.

Recommended Action None required.

713048

Error Message %ASA-3-713048: Error processing payload: Payload ID: *id*

Explanation A packet has been received with a payload that cannot be processed.

Recommended Action If this problem persists, a misconfiguration may exist on the peer.

713049

Error Message %ASA-5-713049: Security negotiation complete for *tunnel_type* type (*group_name*) *Initiator/Responder*, Inbound SPI = *SPI*, Outbound SPI = *SPI*

Explanation An IPsec tunnel has been started.

Recommended Action None required.

713050

Error Message `%ASA-5-713050: Connection terminated for peer IP_address. Reason: termination reason Remote Proxy IP_address, Local Proxy IP_address`

Explanation An IPsec tunnel has been terminated. Possible termination reasons include:

- IPsec SA Idle Timeout
- IPsec SA Max Time Exceeded
- Administrator Reset
- Administrator Reboot
- Administrator Shutdown
- Session Disconnected
- Session Error Terminated
- Peer Terminate

Recommended Action None required.

713052

Error Message `%ASA-7-713052: User (user) authenticated.`

Explanation The remote access user was authenticated.

Recommended Action None required.

713056

Error Message `%ASA-3-713056: Tunnel rejected: SA (SA_name) not found for group (group_name)!`

Explanation The IPsec SA was not found.

Recommended Action If this is a remote access tunnel, check the group and user configuration, and verify that a tunnel group and group policy have been configured for the specific user group. For externally authenticated users and groups, check the returned authentication attributes.

713060

Error Message `%ASA-3-713060: Tunnel Rejected: User (user) not member of group (group_name), group-lock check failed.`

Explanation The user is configured for a different group than what was sent in the IPsec negotiation.

Recommended Action If you are using the Cisco VPN client and preshared keys, make sure that the group configured on the client is the same as the group associated with the user on the ASA. If you are using digital certificates, the group is dictated either by the OU field of the certificate, or the user automatically defaults to the remote access default group.

713061

Error Message `%ASA-3-713061: Tunnel rejected: Crypto Map Policy not found for Src:source_address, Dst: dest_address!`

Explanation The ASA was not able to find security policy information for the private networks or hosts indicated in the message. These networks or hosts were sent by the initiator and do not match any crypto ACLs at the ASA. This is most likely a misconfiguration.

Recommended Action Check the protected network configuration in the crypto ACLs on both sides and make sure that the local net on the initiator is the remote net on the responder and vice-versa. Pay special attention to wildcard masks, and host addresses versus network addresses. Non-Cisco implementations may have the private addresses labeled as proxy addresses or red networks.

713062

Error Message `%ASA-3-713062: IKE Peer address same as our interface address IP_address`

Explanation The IP address configured as the IKE peer is the same as the IP address configured on one of the ASA IP interfaces.

Recommended Action Check the L2L and IP interface configurations.

713063

Error Message `%ASA-3-713063: IKE Peer address not configured for destination IP_address`

Explanation The IKE peer address is not configured for an L2L tunnel.

Recommended Action Check the L2L configuration.

713065

Error Message `%ASA-3-713065: IKE Remote Peer did not negotiate the following: proposal attribute`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713066

Error Message `%ASA-7-713066: IKE Remote Peer configured for SA: SA_name`

Explanation The crypto policy settings of the peer have been configured.

Recommended Action None required.

713068

Error Message `%ASA-5-713068: Received non-routine Notify message: notify_type (notify_value)`

Explanation Notification messages that caused this event are not explicitly handled in the notify processing code.

Recommended Action Examine the specific reason to determine the action to take. Many notification messages indicate a configuration mismatch between the IKE peers.

713072

Error Message `%ASA-3-713072: Password for user (user) too long, truncating to number characters`

Explanation The password of the user is too long.

Recommended Action Correct password lengths on the authentication server.

713073

Error Message `%ASA-5-713073: Responder forcing change of` *`Phase 1/Phase 2`* `rekeying duration from` *`larger_value`* `to` *`smaller_value`* `seconds`

Explanation Rekeying durations are always set to the lower of the values proposed by IKE peers. The value of the initiator is the lower one.

Recommended Action None required.

713074

Error Message `%ASA-5-713074: Responder forcing change of IPsec rekeying duration from` *`larger_value`* `to` *`smaller_value`* `Kbs`

Explanation Rekeying durations are always set to the lower of the values proposed by IKE peers. The value of the initiator is the lower one.

Recommended Action None required.

713075

Error Message `%ASA-5-713075: Overriding Initiator's IPsec rekeying duration from` *`larger_value`* `to` *`smaller_value`* `seconds`

Explanation Rekeying durations are always set to the lower of the values proposed by IKE peers. The value of the responder is the lower one.

Recommended Action None required.

713076

Error Message `%ASA-5-713076: Overriding Initiator's IPsec rekeying duration from` *`larger_value`* `to` *`smaller_value`* `Kbs`

Explanation Rekeying durations are always set to the lower of the values proposed by IKE peers. The value of the responder is the lower one.

Recommended Action None required.

713078

Error Message `%ASA-2-713078: Temp buffer for building mode config attributes exceeded: bufsize` *`available_size`*, `used` *`value`*

Explanation An internal software error has occurred while processing modecfg attributes.

Recommended Action Disable any unnecessary tunnel group attributes, or shorten any text messages that are excessively long. If the problem persists, contact the Cisco TAC.

713081

Error Message `%ASA-3-713081: Unsupported certificate encoding type` *`encoding_type`*

Explanation One of the loaded certificates is unreadable, and may be an unsupported encoding scheme.

Recommended Action Check the configuration of digital certificates and trustpoints.

713082

Error Message `%ASA-3-713082: Failed to retrieve identity certificate`

Explanation The identity certificate for this tunnel cannot be found.

Recommended Action Check the configuration of digital certificates and trustpoints.

713083

Error Message `%ASA-3-713083: Invalid certificate handle`

Explanation The identity certificate for this tunnel cannot be found.

Recommended Action Check the configuration of digital certificates and trustpoints.

713084

Error Message `%ASA-3-713084: Received invalid phase 1 port value (port) in ID payload`

Explanation The port value received in the IKE phase 1 ID payload was incorrect. Acceptable values are 0 or 500 (ISAKMP is also known as IKE).

Recommended Action Make sure that a peer conforms to the IKE standards to avoid a network problem resulting in corrupted packets.

713085

Error Message `%ASA-3-713085: Received invalid phase 1 protocol (protocol) in ID payload`

Explanation The protocol value received in the IKE phase 1 ID payload was incorrect. Acceptable values are 0 or 17 (UDP).

Recommended Action Make sure that a peer conforms to the IKE standards to avoid a network problem resulting in corrupted packets.

713086

Error Message `%ASA-3-713086: Received unexpected Certificate payload Possible invalid Auth Method (Auth method (auth numerical value))`

Explanation A certificate payload was received, but our internal certificate handle indicates that we do not have an identity certificate. The certificate handle was not obtained through a normal enrollment method. One likely reason this can happen is that the authentication method is not made through RSA or DSS signatures, although the IKE SA negotiation should fail if each side is misconfigured.

Recommended Action Check the trustpoint and ISAKMP configuration settings on the ASA and its peer.

713088

Error Message `%ASA-3-713088: Set Cert filehandle failure: no IPsec SA in group group_name`

Explanation The tunnel group cannot be found, based on the digital certificate information.

Recommended Action Verify that the tunnel group is set up correctly to handle the certificate information of the peer.

713092

Error Message `%ASA-5-713092: Failure during phase 1 rekeying attempt due to collision`

Explanation An internal software error has occurred. This is often a benign event.

Recommended Action If the problem persists, contact the Cisco TAC.

713094

Error Message `%ASA-7-713094: Cert validation failure: handle invalid for` *`Main/Aggressive Mode Initiator/Responder`*`!`

Explanation An internal software error has occurred.

Recommended Action You may have to reenroll the trustpoint. If the problem persists, contact the Cisco TAC.

713098

Error Message `%ASA-3-713098: Aborting: No identity cert specified in IPsec SA (`*`SA_name`*`)!`

Explanation An attempt was made to establish a certificate-based IKE session, but no identity certificate has been specified in the crypto policy.

Recommended Action Specify the identity certificate or trustpoint that you want to transmit to peers.

713099

Error Message `%ASA-7-713099: Tunnel Rejected: Received NONCE length` *`number`* `is out of range!`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713102

Error Message `%ASA-3-713102: Phase 1 ID Data length` *`number`* `too long - reject tunnel!`

Explanation IKE has received an ID payload that includes an identification data field of 2 K or larger.

Recommended Action None required.

713103

Error Message `%ASA-7-713103: Invalid (NULL) secret key detected while computing hash`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713104

Error Message `%ASA-7-713104: Attempt to get Phase 1 ID data failed while` *`hash computation`*

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713105

Error Message `%ASA-3-713105: Zero length data in ID payload received during phase` *`1 or 2`* `processing`

Explanation A peer sent an ID payload without including any ID data, which is invalid.

Recommended Action Check the configuration of the peer.

713107

Error Message `%ASA-3-713107: IP_Address request attempt failed!`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713109

Error Message `%ASA-3-713109: Unable to process the received peer certificate`

Explanation The ASA was unable to process the certificate received from the remote peer, which can occur if the certificate data was malformed (for example, if the public key size is larger than 4096 bits) or if the data in the certificate cannot be stored by the ASA.

Recommended Action Try to reestablish the connection using a different certificate on the remote peer.

713112

Error Message `%ASA-3-713112: Failed to process CONNECTED notify (SPI SPI_value)!`

Explanation The ASA was unable to successfully process the notification payload that included the CONNECTED notify type. This may occur if the IKE phase 2 structure cannot be found using the SPI to locate it, or the commit bit had not been set in the received ISAKMP header. The latter case may indicate a nonconforming IKE peer.

Recommended Action If the problem persists, check the configuration of the peer and/or disable commit bit processing.

713113

Error Message `%ASA-7-713113: Deleting IKE SA with associated IPsec connection entries. IKE peer: IP_address, SA address: internal_SA_address, tunnel count: count`

Explanation An IKE SA is being deleted with a nonzero tunnel count, which means that either the IKE SA tunnel count has lost synchronization with the associated connection entries or the associated connection cookie fields for the entries have lost synchronization with the cookie fields of the IKE SA to which the connection entry points. If this occurs, the IKE SA and its associated data structures will not be freed, so that the entries that may point to it will not have a stale pointer.

Recommended Action None required. Error recovery is built-in.

713114

Error Message `%ASA-7-713114: Connection entry (conn entry internal address) points to IKE SA (SA_internal_address) for peer IP_address, but cookies don't match`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713115

Error Message `%ASA-5-713115: Client rejected NAT enabled IPsec request, falling back to standard IPsec`

Explanation The client rejected an attempt by the ASA to use IPsec over UDP. IPsec over UDP is used to allow multiple clients to establish simultaneous tunnels to the ASA through a NAT device. The client may have rejected the request, either because it does not support this feature or because it is configured not to use it.

Recommended Action Verify the configuration on the headend and peer.

713117

Error Message %ASA-7-713117: Received Invalid SPI notify (SPI *SPI_Value*)!

Explanation The IPsec SA identified by the SPI value is no longer active on the remote peer, which might indicate that the remote peer has rebooted or been reset.

Recommended Action This problem should correct itself once DPDs recognize that the peer no longer has the appropriate SAs established. If DPD is not enabled, this may require you to manually reestablish the affected tunnel.

713118

Error Message %ASA-3-713118: Detected invalid Diffie-Helmann *group_descriptor group_number*, in *IKE area*

Explanation The *group_descriptor* field included an unsupported value. Currently we support only groups 1, 2, 5, and 7. In the case of a centry, the *group_descriptor* field may also be set to 0 to indicate that perfect forward secrecy is disabled.

Recommended Action Check the peer Diffie-Hellman configuration.

713119

Error Message %ASA-5-713119: Group *group* IP *ip* PHASE 1 COMPLETED

Explanation IKE Phase 1 has completed successfully.

Recommended Action None required.

713120

Error Message %ASA-5-713120: PHASE 2 COMPLETED (msgid=*msg_id*)

Explanation IKE Phase 2 has completed successfully.

Recommended Action None required.

713121

Error Message `%ASA-7-713121: Keep-alive type for this connection: keepalive_type`

Explanation The type of keepalive mechanism that is being used for this tunnel is specified.

Recommended Action None required.

713122

Error Message `%ASA-3-713122: Keep-alives configured keepalive_type but peer IP_address support keep-alives (type = keepalive_type)`

Explanation Keepalives were configured on or off for this device, but the IKE peer does or does not support keepalives.

Recommended Action No action is required if this configuration is intentional. If it is not intentional, change the keepalive configuration on both devices.

713123

Error Message `%ASA-3-713123: IKE lost contact with remote peer, deleting connection (keepalive type: keepalive_type)`

Explanation The remote IKE peer did not respond to keepalives within the expected window of time, so the connection to the IKE peer was terminated. The message includes the keepalive mechanism used.

Recommended Action None required.

713124

Error Message `%ASA-3-713124: Received DPD sequence number rcv_sequence_# in DPD Action, description expected seq #`

Explanation The remote IKE peer sent a DPD with a sequence number that did not match the expected sequence number. The packet is discarded. This might indicate a packet loss problem with the network.

Recommended Action None required.

713127

Error Message `%ASA-3-713127: Xauth required but selected Proposal does not support xauth, Check priorities of ike xauth proposals in ike proposal list`

Explanation The peer wanted to perform a XAUTH, but the ASA did not choose the XAUTH IKE proposal.

Recommended Action Check the priorities of the IKE xauth proposals in the IKE proposal list.

713128

Error Message `%ASA-6-713128: Connection attempt to VCPIP redirected to VCA peer` *`IP_address`* `via load balancing`

Explanation A connection attempt has been made to the VCPIP and has been redirected to a less loaded peer using load balancing.

Recommended Action None required.

713129

Error Message `%ASA-3-713129: Received unexpected Transaction Exchange payload type:` *`payload_id`*

Explanation An unexpected payload has been received during XAUTH or Mode Cfg, which may indicate that the two peers are out-of-sync, that the XAUTH or Mode Cfg versions do not match, or that the remote peer is not complying with the appropriate RFCs.

Recommended Action Verify the configuration between peers.

713130

Error Message `%ASA-5-713130: Received unsupported transaction mode attribute:` *`attribute id`*

Explanation The device received a request for a valid transaction mode attribute (XAUTH or Mode Cfg) that is currently not supported. This is generally a benign condition.

Recommended Action None required.

713131

Error Message `%ASA-5-713131: Received unknown transaction mode attribute: attribute_id`

Explanation The ASA has received a request for a transaction mode attribute (XAUTH or Mode Cfg) that is outside the range of known attributes. The attribute may be valid but only supported in later versions of configuration mode, or the peer may be sending an illegal or proprietary value. This should not cause connectivity problems, but may affect the functionality of the peer.

Recommended Action None required.

713132

Error Message `%ASA-3-713132: Cannot obtain an IP_address for remote peer`

Explanation A request for an IP address for a remote access client from the internal utility that provides these addresses cannot be satisfied.

Recommended Action Check the configuration of IP address assignment methods.

713133

Error Message `%ASA-3-713133: Mismatch: Overriding phase 2 DH Group(DH group DH group_id) with phase 1 group(DH group DH group_number`

Explanation The configured Phase 2 PFS Group differed from the DH group that was negotiated for Phase 1.

Recommended Action None required.

713134

Error Message `%ASA-3-713134: Mismatch: P1 Authentication algorithm in the crypto map entry different from negotiated algorithm for the L2L connection`

Explanation The configured LAN-to-LAN proposal is different from the one accepted for the LAN-to-LAN connection. Depending on which side is the initiator, different proposals will be used.

Recommended Action None required.

713135

Error Message `%ASA-5-713135: message received, redirecting tunnel to IP_address.`

Explanation The tunnel is being redirected because of load balancing on the remote ASA. A REDIRECT_CONNECTION notify packet was received.

Recommended Action None required.

713136

Error Message `%ASA-5-713136: IKE session establishment timed out [IKE_state_name], aborting!`

Explanation The Reaper has detected an ASA stuck in an inactive state. The Reaper will try to remove the inactive ASA.

Recommended Action None required.

713137

Error Message `%ASA-5-713137: Reaper overriding refCnt [ref_count] and tunnelCnt [tunnel_count] -- deleting SA!`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713138

Error Message `%ASA-3-713138: Group group_name not found and BASE GROUP default preshared key not configured`

Explanation No group exists in the group database with the same name as the IP address of the peer. In Main Mode, the ASA will fall back and try to use the default preshared key configured in one of the default groups. The default preshared key is not configured.

Recommended Action Verify the configuration of the preshared keys.

713139

Error Message %ASA-5-713139: *group_name* not found, using BASE GROUP default preshared key

Explanation No tunnel group exists in the group database with the same name as the IP address of the peer. In Main Mode, the ASA will fall back and use the default preshared key configured in the default group.

Recommended Action None required.

713140

Error Message %ASA-3-713140: Split Tunneling Policy requires network list but none configured

Explanation The split tunneling policy is set to either split tunneling or to allow local LAN access. A split tunneling ACL must be defined to represent the information required by the VPN client.

Recommended Action Check the configuration of the ACLs.

713141

Error Message %ASA-3-713141: Client-reported firewall does not match configured firewall: *action* tunnel. Received -- Vendor: *vendor(id)*, Product *product(id)*, Caps: *capability_value*. Expected -- Vendor: *vendor(id)*, Product: *product(id)*, Caps: *capability_value*

Explanation The ASA installed on the client does not match the configured required ASA. This message lists the actual and expected values, and whether the tunnel is terminated or allowed.

Recommended Action You may need to install a different personal ASA on the client or change the configuration on the ASA.

713142

Error Message %ASA-3-713142: Client did not report firewall in use, but there is a configured firewall: *action* tunnel. Expected -- Vendor: *vendor(id)*, Product *product(id)*, Caps: *capability_value*

Explanation The client did not report an ASA in use using ModeCfg, but one is required. The event lists the expected values and whether the tunnel is terminated or allowed. Note that the number following the product string is a bitmask of all of the allowed products.

Recommended Action You may need to install a different personal ASA on the client or change the configuration on the ASA.

713143

Error Message %ASA-7-713143: Processing firewall record. Vendor: *vendor(id)*, Product: *product(id)*, Caps: *capability_value*, Version Number: *version_number*, Version String: *version_text*

Explanation Debugging information about the ASA installed on the client appears.

Recommended Action None required.

713144

Error Message %ASA-5-713144: Ignoring received malformed firewall record; reason - *error_reason* TLV type *attribute_value correction*

Explanation Bad ASA information was received from the client.

Recommended Action Check the personal configuration on the client and the ASA.

713145

Error Message %ASA-6-713145: Detected Hardware Client in network extension mode, adding static route for address: *IP_address*, mask: *netmask*

Explanation A tunnel with a hardware client in network extension mode has been negotiated, and a static route is being added for the private network behind the hardware client. This configuration enables the ASA to make the remote network known to all the routers on the private side of the headend.

Recommended Action None required.

713146

Error Message %ASA-3-713146: Could not add route for Hardware Client in network extension mode, address: *IP_address*, mask: *netmask*

Explanation An internal software error has occurred. A tunnel with a hardware client in network extension mode has been negotiated, and an attempt to add the static route for the private network behind the hardware client failed. The routing table may be full, or a possible addressing error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713147

Error Message `%ASA-6-713147: Terminating tunnel to Hardware Client in network extension mode, deleting static route for address: IP_address, mask: netmask`

Explanation A tunnel to a hardware client in network extension mode is being removed, and the static route for the private network is being deleted behind the hardware client.

Recommended Action None required.

713148

Error Message `%ASA-5-713148: Terminating tunnel to Hardware Client in network extension mode, unable to delete static route for address: IP_address, mask: netmask`

Explanation While a tunnel to a hardware client in network extension mode was being removed, a route to the private network behind the hardware client cannot be deleted. This might indicate an addressing or software problem.

Recommended Action Check the routing table to ensure that the route is not there. If it is, it may have to be removed manually, but only if the tunnel to the hardware client has been completely removed.

713149

Error Message `%ASA-3-713149: Hardware client security attribute attribute_name was enabled but not requested.`

Explanation The headend ASA has the specified hardware client security attribute enabled, but the attribute was not requested by the VPN 3002 hardware client.

Recommended Action Check the configuration on the hardware client.

713152

Error Message `%ASA-3-713152: Unable to obtain any rules from filter ACL_tag to send to client for CPP, terminating connection.`

Explanation The client is required to use CPP to provision its ASA, but the headend device was unable to obtain any ACLs to send to the client. This is probably due to a misconfiguration.

Recommended Action Check the ACLs specified for CPP in the group policy for the client.

713154

Error Message %ASA-4-713154: DNS lookup for *peer_description* Server [*server_name*] failed!

Explanation This message appears when a DNS lookup for the specified server has not been resolved.

Recommended Action Check the DNS server configuration on the ASA. Also check the DNS server to ensure that it is operational and has hostname to IP address mapping.

713155

Error Message %ASA-5-713155: DNS lookup for Primary VPN Server [*server_name*] successfully resolved after a previous failure. Resetting any Backup Server init.

Explanation A previous DNS lookup failure for the primary server might have caused the ASA to initialize a backup peer. This message indicates that a later DNS lookup on the primary server finally succeeded and is resetting any backup server initializations. A tunnel initiated after this point will be aimed at the primary server.

Recommended Action None required.

713156

Error Message %ASA-5-713156: Initializing Backup Server [*server_name* or *IP_address*]

Explanation The client is failing over to a backup server, or a failed DNS lookup for the primary server caused the ASA to initialize a backup server. A tunnel initiated after this point will be aimed at the specified backup server.

Recommended Action None required.

713157

Error Message %ASA-4-713157: Timed out on initial contact to server [*server_name or IP_address*] Tunnel could not be established.

Explanation The client tried to initiate a tunnel by sending out IKE MSG1, but did not receive a response from the ASA on the other end. If backup servers are available, the client will attempt to connect to one of them.

Recommended Action Verify connectivity to the headend ASA.

713158

Error Message `%ASA-5-713158: Client rejected NAT enabled IPsec Over UDP request, falling back to IPsec Over TCP`

Explanation The client is configured to use IPsec over TCP. The client rejected the attempt by the ASA to use IPsec over UDP.

Recommended Action If TCP is desired, no action is required. Otherwise, check the client configuration.

713159

Error Message `%ASA-3-713159: TCP Connection to Firewall Server has been lost, restricted tunnels are now allowed full network access`

Explanation The TCP connection to the ASA server was lost for a certain reason, such as the server has rebooted, a network problem has occurred, or an SSL mismatch has occurred.

Recommended Action If the server connection was lost after the initial connection was made, then the server and network connections must be checked. If the initial connection is lost immediately, this might indicate an SSL authentication problem.

713160

Error Message `%ASA-7-713160: Remote user (session Id - id) has been granted access by the Firewall Server`

Explanation Normal authentication of the remote user to the ASA server has occurred.

Recommended Action None required.

713161

Error Message `%ASA-3-713161: Remote user (session Id - id) network access has been restricted by the Firewall Server`

Explanation The ASA server has sent the ASA a message indicating that this user must be restricted. There are several reasons for this, including ASA software upgrades or changes in permissions. The ASA server will transition the user back into full access mode as soon as the operation has been completed.

Recommended Action No action is required unless the user is never transitioned back into full access state. If this does not happen, refer to the ASA server for more information on the operation that is being performed and the state of the ASA software running on the remote machine.

713162

Error Message `%ASA-3-713162: Remote user (session Id - id) has been rejected by the Firewall Server`

Explanation The ASA server has rejected this user.

Recommended Action Check the policy information on the ASA server to make sure that the user is configured correctly.

713163

Error Message `%ASA-3-713163: Remote user (session Id - id) has been terminated by the Firewall Server`

Explanation The ASA server has terminated this user session, which can occur if the integrity agent stops running on the client machine or if the security policy is modified by the remote user in any way.

Recommended Action Verify that the ASA software on the client machine is still running and that the policy is correct.

713164

Error Message `%ASA-7-713164: The Firewall Server has requested a list of active user sessions`

Explanation The ASA server will request the session information if it detects that it has stale data or if it loses the session data (because of a reboot).

Recommended Action None required.

713165

Error Message `%ASA-3-713165: Client IKE Auth mode differs from the group's configured Auth mode`

Explanation The client negotiated with preshared keys while its tunnel group points to a policy that is configured to use digital certificates.

Recommended Action Check the client configuration.

713166

Error Message `%ASA-3-713166: Headend security gateway has failed our user authentication attempt - check configured username and password`

Explanation The hardware client has failed extended authentication. This is most likely a username and password problem or an authentication server issue.

Recommended Action Verify that the configured username and password values on each side match. Also verify that the authentication server at the headend is operational.

713167

Error Message `%ASA-3-713167: Remote peer has failed user authentication - check configured username and password`

Explanation The remote user has failed to extend authentication. This is most likely a username or password problem, or an authentication server issue.

Recommended Action Verify that the configured username and password values on each side match. Also verify that the authentication server being used to authenticate the remote user is operational.

713168

Error Message `%ASA-3-713168: Re-auth enabled, but tunnel must be authenticated interactively!`

Explanation Reauthentication on rekeying has been enabled, but the tunnel authentication requires manual intervention.

Recommended Action If manual intervention is desired, no action is required. Otherwise, check the interactive authentication configuration.

713169

Error Message `%ASA-7-713169: IKE Received delete for rekeyed SA IKE peer: IP_address, SA address: internal_SA_address, tunnelCnt: tunnel_count`

Explanation IKE has received a delete message from the remote peer to delete its old IKE SA after a rekey has completed.

Recommended Action None required.

713170

Error Message `%ASA-7-713170: Group` *group* `IP` *ip* `IKE Received delete for rekeyed centry IKE peer:` *IP_address*`, centry address:` *internal_address*`, msgid:` *id*

Explanation IKE has received a delete message from the remote peer to delete its old centry after Phase 2 rekeying is completed.

Recommended Action None required.

713171

Error Message `%ASA-7-713171: NAT-Traversal sending NAT-Original-Address payload`

Explanation UDP-Encapsulated-Transport was either proposed or selected during Phase 2. Send this payload for NAT-Traversal in this case.

Recommended Action None required.

713172

Error Message `%ASA-6-713172: Automatic NAT Detection Status: Remote end` *is*|*is not* `behind a NAT device This end` *is*|*is not* `behind a NAT device`

Explanation NAT-Traversal auto-detected NAT.

Recommended Action None required.

713174

Error Message `%ASA-3-713174: Hardware Client connection rejected! Network Extension Mode is not allowed for this group!`

Explanation A hardware client is attempting to tunnel in using network extension mode, but network extension mode is not allowed.

Recommended Action Verify the configuration of the network extension mode versus PAT mode.

713176

Error Message `%ASA-2-713176: Device_type memory resources are critical, IKE key acquire message on interface interface_number, for Peer IP_address ignored`

Explanation The ASA is processing data intended to trigger an IPsec tunnel to the indicated peer. Because memory resources are at a critical state, it is not initiating any more tunnels. The data packet has been ignored and dropped.

Recommended Action If condition persists, verify that the ASA is efficiently configured. An ASA with increased memory may be required for this application.

713177

Error Message `%ASA-6-713177: Received remote Proxy Host FQDN in ID Payload: Host Name: host_name Address IP_address, Protocol protocol, Port port`

Explanation A Phase 2 ID payload containing an FQDN has been received from the peer.

Recommended Action None required.

713178

Error Message `%ASA-5-713178: IKE Initiator received a packet from its peer without a Responder cookie`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713179

Error Message `%ASA-5-713179: IKE AM Initiator received a packet from its peer without a payload_type payload`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713182

Error Message `%ASA-3-713182: IKE could not recognize the version of the client! IPsec Fragmentation Policy will be ignored for this connection!`

Explanation An internal software error has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

713184

Error Message `%ASA-6-713184: Client Type: Client_type Client Application Version: Application_version_string`

Explanation The client operating system and application version appear. If the information is not available, then N/A will be indicated.

Recommended Action None required.

713185

Error Message `%ASA-3-713185: Error: Username too long - connection aborted`

Explanation The client returned an invalid length username, and the tunnel was torn down.

Recommended Action Check the username and make changes, if necessary.

713186

Error Message `%ASA-3-713186: Invalid secondary domain name list received from the authentication server. List Received: list_text Character index (value) is illegal`

Explanation An invalid secondary domain name list was received from an external RADIUS authentication server. When split tunnelling is used, this list identifies the domains that the client should resolve through the tunnel.

Recommended Action Correct the specification of the Secondary-Domain-Name-List attribute (vendor-specific attribute 29) on the RADIUS server. The list must be specified as a comma-delimited list of domain names. Domain names may include only alphanumeric characters, a hyphen, an underscore, and a period.

713187

Error Message `%ASA-7-713187: Tunnel Rejected: IKE peer does not match remote peer as defined in L2L policy IKE peer address: IP_address, Remote peer address: IP_address`

Explanation The IKE peer that is attempting to bring up this tunnel is not the one that is configured in the ISAKMP configuration that is bound to the received remote subnet.

Recommended Action Verify that L2L settings are correct on the headend and peer.

713189

Error Message `%ASA-3-713189: Attempted to assign network or broadcast IP_address, removing (IP_address) from pool.`

Explanation The IP address from the pool is either the network or broadcast address for this subnet. This address will be marked as unavailable.

Recommended Action This error is generally benign, but the IP address pool configuration should be checked.

713190

Error Message `%ASA-7-713190: Got bad refCnt (ref_count_value) assigning IP_address (IP_address)`

Explanation The reference counter for this SA is invalid.

Recommended Action None required.

713191

Error Message `%ASA-3-713191: Maximum concurrent IKE negotiations exceeded!`

Explanation To minimize CPU-intensive cryptographic calculations, the ASA limits the number of connection negotiations in progress. When a new negotiation is requested and the ASA is already at its limit, the new negotiation is rejected. When an existing connection negotiation completes, new connection negotiation will again be permitted.

Recommended Action See the **crypto ikev1 limit max-in-negotiation-sa** command. Increasing the limit can degrade performance..

713193

Error Message `%ASA-3-713193: Received packet with missing payload, Expected payload: payload_id`

Explanation The ASA received an encrypted or unencrypted packet of the specified exchange type that had one or more missing payloads. This usually indicates a problem on the peer.

Recommended Action Verify that the peer is sending valid IKE messages.

713194

Error Message `%ASA-3-713194: Sending IKE|IPsec Delete With Reason message: termination_reason`

Explanation A delete message with a termination reason code was received.

Recommended Action None required.

713195

Error Message `%ASA-3-713195: Tunnel rejected: Originate-Only: Cannot accept incoming tunnel yet!`

Explanation The originate-only peer can accept incoming connections only after it brings up the first P2 tunnel. At that point, data from either direction can initiate additional Phase 2 tunnels.

Recommended Action If a different behavior is desired, the originate-only configuration needs to be revised.

713196

Error Message `%ASA-5-713196: Remote L2L Peer IP_address initiated a tunnel with same outer and inner addresses. Peer could be Originate Only - Possible misconfiguration!`

Explanation The remote L2L peer has initiated a public-public tunnel. The remote L2L peer expects a response from the peer at the other end, but does not receive one, because of a possible misconfiguration.

Recommended Action Check the L2L configuration on both sides.

713197

Error Message `%ASA-5-713197: The configured Confidence Interval of number seconds is invalid for this tunnel_type connection. Enforcing the second default.`

Explanation The configured confidence interval in the group is outside of the valid range.

Recommended Action Check the confidence setting in the group to make sure it is within the valid range.

713198

Error Message `%ASA-3-713198: User Authorization failed: user User authorization failed. Username could not be found in the certificate`

Explanation A reason string that states that a username cannot be found in the certificate appears.

Recommended Action Check the group configuration and client authorization.

713199

Error Message `%ASA-5-713199: Reaper corrected an SA that has not decremented the concurrent IKE negotiations counter (counter_value)!`

Explanation The Reaper corrected an internal software error.

Recommended Action If the problem persists, contact the Cisco TAC.

713203

Error Message `%ASA-3-713203: IKE Receiver: Error reading from socket.`

Explanation An error occurred while reading a received IKE packet. This is generally an internal error and might indicate a software problem.

Recommended Action This problem is usually benign, and the system will correct itself. If the problem persists, contact the Cisco TAC.

713204

Error Message `%ASA-7-713204: Adding static route for client address: IP_address`

Explanation This message indicates that a route to the peer-assigned address or to the networks protected by a hardware client was added to the routing table.

Recommended Action None required.

713205

Error Message `%ASA-3-713205: Could not add static route for client address: IP_address`

Explanation An attempt to add a route to the client-assigned address or to the networks protected by a hardware client failed. This might indicate duplicate routes in the routing table or a corrupted network address. The duplicate routes might be caused by routes that were not cleaned up correctly or by having multiple clients sharing networks or addresses.

Recommended Action Check the IP local pool configuration as well as any other IP address-assigning mechanism being used (for example, DHCP or RADIUS). Make sure that routes are being cleared from the routing table. Also check the configuration of networks and/or addresses on the peer.

713206

Error Message `%ASA-3-713206: Tunnel Rejected: Conflicting protocols specified by tunnel-group and group-policy`

Explanation A tunnel was dropped because the allowed tunnel specified in the group policy was different from the allowed tunnel in the tunnel group configuration.

Recommended Action Check the tunnel group and group policy configuration.

713208

Error Message `%ASA-3-713208: Cannot create dynamic rule for Backup L2L entry rule rule_id`

Explanation A failure occurred in creating the ACLs that trigger IKE and allow IPsec data to be processed properly. The failure was specific to the backup L2L configuration, which may indicate a configuration error, a capacity error, or an internal software error.

Recommended Action If the ASA is running the maximum number of connections and VPN tunnels, there may be a memory issue. If not, check the backup L2L and crypto map configurations, specifically the ACLs associated with the crypto maps.

713209

Error Message `%ASA-3-713209: Cannot delete dynamic rule for Backup L2L entry` *`rule id`*

Explanation A failure occurred in deleting the ACLs that trigger IKE and allow IPsec data to be processed correctly. The failure was specific to the backup L2L configuration. This may indicate an internal software error.

Recommended Action If the problem persists, contact the Cisco TAC.

713210

Error Message `%ASA-3-713210: Cannot create dynamic map for Backup L2L entry` *`rule_id`*

Explanation A failure occurred in creating a run-time instance of the dynamic crypto map associated with backup L2L configuration. This may indicate a configuration error, a capacity error, or an internal software error.

Recommended Action If the ASA is running the maximum number of connections and VPN tunnels, there may be a memory issue. If not, check the backup L2L and crypto map configurations, and specifically the ACLs associated with the crypto maps.

713211

Error Message `%ASA-6-713211: Adding static route for L2L peer coming in on a dynamic map. address:` *`IP_address`*`, mask:` *`netmask`*

Explanation The ASA is adding a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

Recommended Action None required.

713212

Error Message `%ASA-3-713212: Could not add route for L2L peer coming in on a dynamic map. address:` *`IP_address`*`, mask:` *`netmask`*

Explanation The ASA failed while attempting to add a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel. This might indicate duplicate routes, a full routing table, or a failure of the ASA to remove previously used routes.

Recommended Action Check the routing table to make sure there is room for additional routes and that obsolete routes are not present. If the table is full or includes obsolete routes, remove the routes and try again. If the problem persists, contact the Cisco TAC.

713213

Error Message `%ASA-6-713213: Deleting static route for L2L peer that came in on a dynamic map. address: IP_address, mask: netmask`

Explanation The ASA is deleting a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

Recommended Action None required.

713214

Error Message `%ASA-3-713214: Could not delete route for L2L peer that came in on a dynamic map. address: IP_address, mask: netmask`

Explanation The ASA experienced a failure while deleting a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel. The route may have already been deleted,or an internal software error has occurred.

Recommended Action If the route has already been deleted, the condition is benign and the device will function normally. If the problem persists or can be linked to routing issues over VPN tunnels, then check the routing and addressing portions of the VPN L2L configuration. Check the reverse route injection and the ACLs associated with the appropriate crypto map. If the problem persists, contact the Cisco TAC.

713215

Error Message `%ASA-6-713215: No match against Client Type and Version rules. Client: type version is/is not allowed by default`

Explanation The client type and the version of a client did not match any of the rules configured on the ASA. The default action appears.

Recommended Action Determine what the default action and deployment requirements are, and make the applicable changes.

713216

Error Message `%ASA-5-713216: Rule: action [Client type]: version Client: type version allowed/not allowed`

Explanation The client type and the version of a client have matched one of the rules. The results of the match and the rule are displayed.

Recommended Action Determine what the deployment requirements are, and make the appropriate changes.

713217

Error Message `%ASA-3-713217: Skipping unrecognized rule: action: action client type: client_type client version: client_version`

Explanation A malformed client type and version rule exist. The required format is *action client type | client version action.* Either permit or deny *client type* and *client version* are displayed under Session Management. Only one wildcard per parameter (*) is supported.

Recommended Action Correct the rule.

713218

Error Message `%ASA-3-713218: Tunnel Rejected: Client Type or Version not allowed.`

Explanation The client was denied access according to the configured rules.

Recommended Action None required.

713219

Error Message `%ASA-6-713219: Queuing KEY-ACQUIRE messages to be processed when P1 SA is complete.`

Explanation Phase 2 messages are being enqueued after Phase 1 completes.

Recommended Action None required.

713220

Error Message %ASA-6-713220: De-queuing KEY-ACQUIRE messages that were left pending.

Explanation Queued Phase 2 messages are being processed.

Recommended Action None required.

713221

Error Message %ASA-7-713221: Static Crypto Map check, checking map = *crypto_map_tag*, seq = *seq_number...*

Explanation The ASA is iterating through the crypto maps looking for configuration information.

Recommended Action None required.

713222

Error Message %ASA-7-713222: Group *group* Username *username* IP *ip* Static Crypto Map check, map = *crypto_map_tag*, seq = *seq_number*, ACL does not match proxy IDs src:*source_address* dst:*dest_address*

Explanation While iterating through the configured crypto maps, the ASA cannot match any of the associated ACLs. This generally means that an ACL was misconfigured.

Recommended Action Check the ACLs associated with this tunnel peer, and make sure that they specify the appropriate private networks from both sides of the VPN tunnel.

713223

Error Message %ASA-7-713223: Static Crypto Map check, map = *crypto_map_tag*, seq = *seq_number*, no ACL configured

Explanation The crypto map associated with this peer is not linked to an ACL.

Recommended Action Make sure an ACL associated with this crypto map exists, and that the ACL includes the appropriate private addresses or network from both sides of the VPN tunnel.

713224

Error Message `%ASA-7-713224: Static Crypto Map Check by-passed: Crypto map entry incomplete!`

Explanation The crypto map associated with this VPN tunnel is missing critical information.

Recommended Action Verify that the crypto map is configured correctly with both the VPN peer, a transform set, and an associated ACL.

713225

Error Message `%ASA-7-713225: [IKEv1], Static Crypto Map check, map map_name, seq = sequence_number is a successful match`

Explanation The ASA found a valid matching crypto map for this VPN tunnel.

Recommended Action None required.

713226

Error Message `%ASA-3-713226: Connection failed with peer IP_address, no trust-point defined in tunnel-group tunnel_group`

Explanation When the device is configured to use digital certificates, a trustpoint must be specified in the configuration. When the trustpoint is missing from the configuration, this message is generated to flag an error.

- *IP_address*—IP address of the peer
- *tunnel_group*—Tunnel group for which the trustpoint was missing in the configuration

Recommended Action The administrator of the device has to specify a trustpoint in the configuration.

713227

Error Message `%ASA-3-713227: Rejecting new IPsec SA negotiation for peer Peer_address. A negotiation was already in progress for local Proxy Local_address/Local_netmask, remote Proxy Remote_address/Remote_netmask`

Explanation When establishing a Phase SA, the ASA will reject a new Phase 2 matching this proxy.

Recommended Action None required.

713228

Error Message `%ASA-6-713228: Group = group, Username = uname, IP = remote_IP_address Assigned private IP address assigned_private_IP to remote user`

Explanation IKE obtained a private IP address for the client from DHCP or from the address pool.

- *group*—The name of the group
- *uname*—The name of the user
- *remote_IP_address*—The IP address of the remote client
- *assigned_private_IP*—The client IP address assigned by DHCP or from the local address pool

Recommended Action None required.

713229

Error Message `%ASA-5-713229: Auto Update - Notification to client client_ip of update string: message_string.`

Explanation A VPN remote access client is notified that updated software is available for download. The remote client user is responsible for choosing to update the client access software.

- *client_ip*—The IP address of the remote client
- *message_string*—The message text sent to the remote client

Recommended Action None required.

713230

Error Message `%ASA-3-713230 Internal Error, ike_lock trying to lock bit that is already locked for type type`

Explanation An internal error occurred, which is reporting that the IKE subsystem is attempting to lock memory that has already been locked. This indicates errors on semaphores that are used to protect memory violations for IKE SAs. This message does not indicate that anything is seriously wrong. However, an unexpected event has occurred, and steps are automatically being taken for recovery.

- *type*—String that describes the type of semaphore that had a locking issue

Recommended Action If the problem persists, contact the Cisco TAC.

713231

Error Message `%ASA-3-713231 Internal Error, ike_lock trying to unlock bit that is not locked for type` *`type`*

Explanation An internal error has occurred, which is reporting that the IKE subsystem is attempting to unlock memory that is not currently locked. This indicates errors on semaphores that are used to protect memory violations for IKE SAs. This message does not indicate that anything is seriously wrong. However, an unexpected event has occurred, and steps are automatically being taken for recovery.

- *type*—String that describes the type of semaphore that had a locking issue

Recommended Action If the problem persists, contact the Cisco TAC.

713232

Error Message `%ASA-3-713232 SA lock refCnt =` *`value`*`, bitmask =` *`hexvalue`*`, p1_decrypt_cb =` *`value`*`, qm_decrypt_cb =` *`value`*`, qm_hash_cb =` *`value`*`, qm_spi_ok_cb =` *`value`*`, qm_dh_cb =` *`value`*`, qm_secret_key_cb =` *`value`*`, qm_encrypt_cb =` *`value`*

Explanation All the IKE SA are locked, and a possible error has been detected. This message reports errors on semaphores that are used to protect memory violations for IKE SAs.

- *value*—Decimal value
- *hexvalue*—Hexadecimal value

Recommended Action If the problem persists, contact the Cisco TAC.

713233

Error Message `%ASA-7-713233: (VPN-`*`unit`*`) Remote network (`*`remote network`*`) validated for network extension mode.`

Explanation The remote network received during the Phase 2 negotiation was validated. The message indicates the results of the remote network check during Phase 2 negotiations for Network Extension Mode clients. This is part of an existing feature that prevents users from misconfiguring their hardware client network (for example, configuring overlapping networks or the same network on multiple clients).

- *remote network*—Subnet address and subnet mask from Phase 2 proxy

Recommended Action None required.

713234

Error Message `%ASA-7-713234: (VPN-unit) Remote network (remote network) from network extension mode client mismatches AAA configuration (aaa network).`

Explanation The remote network received during the Phase 2 negotiation does not match the framed-ip-address and framed-subnet-mask that were returned from the AAA server for this session.

- *remote network*—Subnet address and subnet mask from Phase 2 proxy
- *aaa network*—Subnet address and subnet mask configured through AAA

Recommended Action Do one of the following:

- Check the address assignment for this user and group, then check the network configuration on the HW client, and correct any inconsistencies.
- Disable address assignment for this user and group.

713235

Error Message `%ASA-6-713235: Attempt to send an IKE packet from standby unit. Dropping the packet!`

Explanation Normally, IKE packets should never be sent from the standby unit to the remote peer. If such an attempt is made, an internal logic error may have occurred. The packet never leaves the standby unit because of protective code. This message facilitates debugging.

Recommended Action None required.

713236

Error Message `%ASA-7-713236: IKE_DECODE tx/rx Message (msgid=msgid) with payloads:payload1 (payload1_len) + payload2 (payload2_len)...total length: tlen`

Explanation IKE sent or received various messages.

The following example shows the output when IKE receives a message with an 8-byte hash payload, an 11-byte notify payload, and two 13-byte vendor-specific payloads:

```
%ASA-7-713236: IKE_DECODE RECEIVED Message msgid=0) with payloads: HDR + HASH (8) +
NOTIFY (11) + VENDOR (13) + VENDOR (13) + NONE (0)
```

Recommended Action None required.

713237

Error Message `%ASA-5-713237: ACL update (access_list) received during re-key re-authentication will not be applied to the tunnel.`

Explanation The Phase 1 rekey of a remote access IPsec tunnel appears under the following conditions:

- The tunnel is configured to reauthenticate the user when the tunnel is rekeyed.
- The RADIUS server returns an access list or a reference to a locally configured access list that is different from the one that was returned when the tunnel was first established.

Under these conditions, the ASA ignores the new access list and this message is generated.

- *access_list*—Name associated with the static or dynamic access list, as displayed in the output of the **show access-list** command

Recommended Action IPsec users must reconnect for new user-specific access lists to take effect.

713238

Error Message `%ASA-3-713238: Invalid source proxy address: 0.0.0.0! Check private address on remote client`

Explanation The private side address of a network extension mode client came across as 0.0.0.0. This usually indicates that no IP address was set on the private interface of the hardware client.

Recommended Action Verify the configuration of the remote client.

713239

Error Message `%ASA-4-713239: IP_Address: Tunnel Rejected: The maximum tunnel count allowed has been reached`

Explanation An attempt to create a tunnel has occurred after the maximum number of tunnels allowed has been reached.

- *IP_Address*—The IP address of the peer

Recommended Action None required.

713240

Error Message `%ASA-4-713240: Received DH key with bad length: received length=rlength expected length=elength`

Explanation A Diffie-Hellman key with the incorrect length was received from the peer.

- *rlength*—The length of the DH key that was received
- *elength*—The expected length (based on the DH key size)

Recommended Action None required.

713241

Error Message `%ASA-4-713241: IE Browser Proxy Method setting_number is Invalid`

Explanation An invalid proxy setting was found during ModeCfg processing. P1 negotiation will fail.

Recommended Action Check the **msie-proxy method** command settings (a subcommand of the **group-policy** command), which should conform to one of the following: [**auto-detect | no-modify | no-proxy | use-server**]. Any other value or no value is incorrect. Try resetting the **msie-proxy method** command settings. If the problem persists, contact the Cisco TAC.

713242

Error Message `%ASA-4-713242: Remote user is authenticated using Hybrid Authentication. Not starting IKE rekey.`

Explanation The ASA has detected a request to start an IKE rekey for a tunnel configured to use Hybrid Xauth, but the rekey was not started. The ASA will wait for the client to detect and initiate an IKE rekey.

Recommended Action None required.

713243

Error Message `%ASA-4-713243: META-DATA Unable to find the requested certificate`

Explanation The IKE peer requested a certificate from the cert-req payload. However, no valid identity certificate issued by the requested DN was found.

Recommended Action Perform the following steps:

1. Check the identity certificates.
2. Enroll or import the desired certificate.

3. Enable certificate debugging for more details.

713244

Error Message `%ASA-4-713244: META-DATA Received Legacy Authentication Method(LAM) type type is different from the last type received type.`

Explanation The LAM attribute type received differs from the last type received. The type must be consistent throughout the user authentication process. The user authentication process cannot proceed, and the VPN connection will not be established.

- *type*—The LAM type

Recommended Action If the problem persists, contact the Cisco TAC.

713245

Error Message `%ASA-4-713245: META-DATA Unknown Legacy Authentication Method(LAM) type type received.`

Explanation An unsupported LAM type was received during the CRACK challenge or response user authentication process. The user authentication process cannot proceed, and the VPN connection will not be established.

- *type*—The LAM type

Recommended Action If the problem persists, contact the Cisco TAC.

713246

Error Message `%ASA-4-713246: META-DATA Unknown Legacy Authentication Method(LAM) attribute type type received.`

Explanation The ASA received an unknown LAM attribute type, which should not cause connectivity problems, but might affect the functionality of the peer.

- *type*—The LAM attribute type

Recommended Action None required.

713247

Error Message `%ASA-4-713247: META-DATA Unexpected error: in Next Card Code mode while not doing SDI.`

Explanation An unexpected error occurred during state processing.

Recommended Action If the problem persists, contact the Cisco TAC.

713248

Error Message `%ASA-5-713248: META-DATA Rekey initiation is being disabled during CRACK authentication.`

Explanation When an IKE SA is negotiated using the CRACK authentication method, the Phase 1 SA rekey timer at the headend expired before a successful rekey. Because the remote client is always the initiator of the exchange when using the CRACK authentication method, the headend will not initiate the rekey. Unless the remote peer initiates a successful rekey before the IKE SA expires, the connection will come down upon IKE SA expiration.

Recommended Action None required.

713249

Error Message `%ASA-4-713249: META-DATA Received unsupported authentication results: result`

Explanation While negotiating an IKE SA using the CRACK authentication method, the IKE subsystem received a result that is not supported during CRACK authentication from the authentication subsystem. The user authentication fails, and the VPN connection is torn down.

- *result*—The result returned from the authentication subsystem

Recommended Action If the problem persists, contact the Cisco TAC.

713250

Error Message `%ASA-5-713250: META-DATA Received unknown Internal Address attribute: attribute`

Explanation The ASA received a request for an internal address attribute that is not recognizable. The attribute might be valid, but not currently supported, or the peer might be sending an illegal value. This should not cause connectivity problems, but might affect the functionality of the peer.

Recommended Action None required.

713251

Error Message `%ASA-4-713251: META-DATA Received authentication failure message`

Explanation The ASA received a notification message that indicated an authentication failure while an IKE SA is negotiated using the CRACK authentication method. The connection is torn down.

Recommended Action None required.

713252

Error Message `%ASA-5-713252: Group = group, Username = user, IP = ip, Integrity Firewall Server is not available. VPN Tunnel creation rejected for client.`

Explanation When the group policy is configured to require the client to authenticate with a Zonelab Integrity Server, the server might need to be connected to the concentrator depending on the failure policy configured. If the fail policy is to reject the client connection, this message is generated when a Zonelab Integrity Server is not connected to the ASA at the time the client is connecting.

- *group*—The tunnel group to which the remote access user is connecting
- *user*—The remote access user
- *ip*—The IP address of the remote access user

Recommended Action Check that the configurations on the concentrator and the Zonelab Integrity Server match. Then verify that communication exists between the concentrator and the Zonelab Integrity Server.

713253

Error Message `%ASA-5-713253: Group = group, Username = user, IP = ip, Integrity Firewall Server is not available. Entering ALLOW mode. VPN Tunnel created for client.`

Explanation When the group policy is configured to require a client to authenticate with a Zonelab Integrity Server, the server might need to be connected to the concentrator, depending on the failure policy configured. If the failure policy is to accept the client connection, and provide unrestricted network access, this message is generated when a Zonelab Integrity Server is not connected to the ASA at the time the client is connecting.

- *group*—The tunnel group to which the remote access user is connecting
- *user*—The remote access user
- *ip*—The IP address of the remote access user

Recommended Action Check that the configurations on the ASA and the Zonelab Integrity Server match, and verify that communication exists between the ASA and the Zonelab Integrity Server.

713254

Error Message `%ASA-3-713254: Group = groupname, Username = username, IP = peerip, Invalid IPsec/UDP port = portnum, valid range is minport - maxport, except port 4500, which is reserved for IPsec/NAT-T`

Explanation You cannot use UDP port 4500 for IPsec/UDP connections, because it is reserved for IPsec or NAT-T connections. The CLI does not allow this configuration for local groups. This message should only occur for externally defined groups.

- *groupname*—The name of the user group
- *username*—The name of the user
- *peerip*—The IP address of the client
- *portnum*—The IPsec/UDP port number on the external server
- *minport*—The minimum valid port number for a user-configurable port, which is 4001
- *maxport*—The maximum valid port number for a user-configurable port, which is 49151

Recommended Action Change the IPsec or UDP port number on the external server to another port number. Valid port numbers are 4001 to 49151.

713255

Error Message `%ASA-4-713255: IP = peer-IP, Received ISAKMP Aggressive Mode message 1 with unknown tunnel group name group-name`

Explanation An unknown tunnel group was specified in ISAKMP Aggressive Mode message 1.

- *peer-ip*—The address of the peer
- *group-name*—The group name specified by the peer

Recommended Action Check the tunnel group and client configurations to make sure that they are valid.

713256

Error Message `%ASA-6-713256: IP = peer-IP, Sending spoofed ISAKMP Aggressive Mode message 2 due to receipt of unknown tunnel group. Aborting connection.`

Explanation When the peer specifies an invalid tunnel group, the ASA will still send message 2 to prevent the peer from gleaning tunnel group information.

- *peer-ip*—The address of the peer

Recommended Action None required.

713257

Error Message `%ASA-5-713257: Phase var1 failure: Mismatched attribute types for class var2: Rcv'd: var3 Cfg'd: var4`

Explanation An ASA has acted as the responder in a LAN-to-LAN connection. It indicates that the ASA crypto configuration does not match the configuration of the initiator. The message specifies during which phase the mismatch occurred, and which attributes both the responder and the initiator had that were different.

- *var1*—The phase during which the mismatch occurred
- *var2*—The class to which the attributes that do not match belong
- *var3*—The attribute received from the initiator
- *var4*—The attribute configured

Recommended Action Check the crypto configuration on both of the LAN-to-LAN devices for inconsistencies. In particular, if a mismatch between UDP-Tunnel (NAT-T) and something else is reported, check the crypto maps. If one configuration has NAT-T disabled on the matched crypto map and the other does not, this will cause a failure.

713258

Error Message `%ASA-3-713258: IP = var1, Attempting to establish a phase2 tunnel on var2 interface but phase1 tunnel is on var3 interface. Tearing down old phase1 tunnel due to a potential routing change.`

Explanation The ASA tries to establish a Phase 2 tunnel on an interface, and a Phase 1 tunnel already exists on a different interface. The existing Phase 1 tunnel is torn down to allow the establishment of a new tunnel on the new interface.

- *var1*—The IP address of the peer
- *var2*—The interface on which the ASA is trying to establish a Phase 2 tunnel
- *var3*—The interface on which the Phase 1 tunnel exists

Recommended Action Check whether or not the route of the peer has changed. If the route has not changed, a possible misconfiguration may exist.

713259

Error Message `%ASA-5-713259: Group = groupname, Username = username, IP = peerIP, Session is being torn down. Reason: reason`

Explanation The termination reason for the ISAKMP session appears, which occurs when the session is torn down through session management.

- *groupname*—The tunnel group of the session being terminated
- *username*—The username of the session being terminated

- *peerIP*—The peer address of the session being terminated
- *reason*—The RADIUS termination reason of the session being terminated. Reasons include the following:

  - Port Preempted (simultaneous logins)

  - Idle Timeout

  - Max Time Exceeded

  - Administrator Reset

Recommended Action None required.

713260

Error Message `%ASA-3-713260: Output interface %d to peer was not found`

Explanation When trying to create a Phase 1 SA, the interface database could not be found for the interface ID.

Recommended Action If the problem persists, contact the Cisco TAC.

713261

Error Message `%ASA-3-713261: IPV6 address on output interface %d was not found`

Explanation When trying to create a Phase 1 SA, no IPv6 address is specified on the local interface.

Recommended Action For information about how to set up an IPv6 address on a desired interface, see the "Configuring IPv6 Addressing" section in the CLI configuration guide.

713262

Error Message `%ASA-3-713262: Rejecting new IPSec SA negotiation for peer Peer_address. A negotiation was already in progress for local Proxy Local_address/Local_prefix_len, remote Proxy Remote_address/Remote_prefix_len`

Explanation When establishing a Phase SA, the ASA will reject a new Phase 2 SA matching this proxy.

- *Peer_address*—The new address attempting to intiate Phase 2 with a proxy matching an existing negotiation
- *Local_address*—The address of the previous local peer currently negotiating Phase 2
- *Local_prefix_len*—The length of the subnet prefix according to CIDR notation
- *Remote_address*—The address of the proxy

- *Remote_prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action None required.

713263

Error Message `%ASA-7-713263: Received local IP Proxy Subnet data in ID Payload: Address IP_address, Mask /prefix_len, Protocol protocol, Port port`

Explanation The ASA is adding a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation
- *protocol*— The proxy protocol
- *port*—The proxy port

Recommended Action None required.

713264

Error Message `%ASA-7-713264: Received local IP Proxy Subnet data in ID Payload: Address IP_address, Mask/prefix_len, Protocol protocol, Port port {"Received remote IP Proxy Subnet data in ID Payload: Address %a, Mask/%d, Protocol %u, Port %u"}`

Explanation The ASA is adding a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation
- *protocol*— The proxy protocol
- *port*—The proxy port

Recommended Action None required.

713265

Error Message `%ASA-6-713265: Adding static route for L2L peer coming in on a dynamic map. address: IP_address, mask: /prefix_len`

Explanation The ASA is adding a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action None required.

713266

Error Message `%ASA-3-713266: Could not add route for L2L peer coming in on a dynamic map. address: IP_address, mask: /prefix_len`

Explanation The ASA failed while attempting to add a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel. This might indicate duplicate routes, a full IPv6 routing table, or a failure of the ASA to remove previously used routes.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action Check the IPv6 routing table to make sure there is room for additional routes, and that obsolete routes are not present. If the table is full or includes obsolete routes, remove the routes and try again. If the problem persists, contact the Cisco TAC.

713267

Error Message `%ASA-6-713267: Deleting static route for L2L peer that came in on a dynamic map. address: IP_address, mask: /prefix_len`

Explanation The ASA failed while attempting to add a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action None required.

713268

Error Message `%ASA-3-713268: Could not delete route for L2L peer that came in on a dynamic map. address: IP_address, mask: /prefix_len`

Explanation The ASA experienced a failure while deleting a route for the private address or networks of the peer. In this case, the peer is either a client or a L2L peer with an unknown address. Both of these cases use dynamic crypto maps to allow the tunnel. The route may have already been deleted, or an internal software error has occurred.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action If the route has already been deleted, the condition is benign and the device will function normally. If the problem persists or can be linked to routing issues over VPN tunnels, then check the routing and addressing portions of the VPN L2L configuration. Also check the reverse route injection and the ACLs associated with the appropriate crypto map. If the problem persists, contact the Cisco TAC.

713269

Error Message `%ASA-6-713269: Detected Hardware Client in network extension mode, adding static route for address: IP_address, mask: /prefix_len`

Explanation A tunnel with a hardware client in network extension mode has been negotiated, and a static route is being added for the private network behind the hardware client. This configuration enables the ASA to make the remote network known to all the routers on the private side of the headend.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action None required.

713270

Error Message `%ASA-3-713270: Could not add route for Hardware Client in network extension mode,  address: IP_address, mask: /prefix_len`

Explanation An internal software error has occurred. A tunnel with a hardware client in network extension mode has been negotiated, and an attempt to add the static route for the private network behind the hardware client failed. The IPv6 routing table may be full, or a possible addressing error has occurred.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action If the problem persists, contact the Cisco TAC.

713271

Error Message `%ASA-6-713271: Terminating tunnel to Hardware Client in network extension mode, deleting static route for address: IP_address, mask:/prefix_len`

Explanation A tunnel to a hardware client in network extension mode is being removed, and the static route for the private network is being deleted behind the hardware client.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action None required.

713272

Error Message `%ASA-3-713272: Terminating tunnel to Hardware Client in network extension mode, unable to delete static route for address: IP_address, mask: /prefix_len`

Explanation While a tunnel to a hardware client in network extension mode was being removed, a route to the private network behind the hardware client cannot be deleted. This might indicate an addressing or software problem.

- *IP_address*—The base IP address of the destination network of the peer
- *prefix_len*—The length of the subnet prefix according to CIDR notation

Recommended Action Check the IPv6 routing table to ensure that the route is not there. If it is, it may have to be removed manually, but only if the tunnel to the hardware client has been completely removed.

713273

Error Message `%ASA-7-713273: Deleting static route for client address: IP_Address IP_Address address of client whose route is being removed`

Explanation A route to the peer-assigned address or the networks protected by a hardware client were removed from the routing table.

Recommended Action None required.

713274

Error Message `%ASA-3-713274: Could not delete static route for client address: IP_Address IP_Address address of client whose route is being removed`

Explanation While a tunnel to an IPsec client was being removed, its entry in the routing table could not be removed. This condition may indicate a networking or software problem.

Recommended Action Check the routing table to make sure that the route does not exist. If it does, it may need to be removed manually, but only if the tunnel has been closed successfully.

713900

Error Message `%ASA-1-713900: Descriptive_event_string.`

Explanation A serious event or failure has occurred. For example, the ASA is trying to generate a Phase 2 deletion, but the SPI did not match any of the existing Phase 2 SAs.

Recommended Action In the example described, both peers are deleting Phase 2 SAs at the same time. In this case, it is a benign error and can be ignored. If the error is persistent and results in negative side effects such as dropped tunnels or device reboots, it may reflect a software failure. In this case, copy the error message exactly as it appears on the console or in the system log, and then contact the Cisco TAC for further assistance.

713901

Error Message `%ASA-2-713901: Descriptive_event_string.`

Explanation An error has occurred, which may be the result of a configuration error on the headend or remote access client. The event string provides details about the error that occurred.

Recommended Action You may need to troubleshoot the message to determine what caused the error. Check the ISAKMP and crypto map configuration on both peers.

713902

Error Message `%ASA-3-713902: Descriptive_event_string.`

Explanation An error has occurred, which may be the result of a configuration error either on the headend or remote access client.

Recommended Action It might be necessary to troubleshoot the configuration to determine the cause of the error. Check the ISAKMP and crypto map configuration on both peers.

713903

Error Message %ASA-4-713903: *Descriptive_event_string*.

Explanation A warning appears, which may be the result of unexpected behavior of a peer (such as a loss of connectivity). For example:

```
%ASA-4-713903: Group = IPSecGroup. IP = 70.172.17.23, Error: Unable to remove
PeerTblEntry.
```

An IPsec connection attempt failed (for example, in an authentication failure) that was caused by an incorrectly typed password or the inadvertent disconnection of an IPsec client during authentication.

Recommended Action None required.

713904

Error Message %ASA-5-713904: *Descriptive_event_string*.

Explanation Notification status information appears, which is used to track events that have occurred.

Recommended Action None required.

713905

Error Message %ASA-6-713905: *Descriptive_event_string*.

Explanation Information status details appear, which are used to track events that have occurred.

Recommended Action None required.

713906

Error Message %ASA-7-713906: *Descriptive_event_string*.

Explanation Debugging status information appears, which is used to track events that have occurred.

Recommended Action None required.

714001

Error Message %ASA-7-714001: *description_of_event_or_packet*

Explanation A description of an IKE protocol event or packet was provided.

Recommended Action None required.

714002

Error Message %ASA-7-714002: IKE Initiator starting QM: msg id = *message_number*

Explanation The ASA has sent the first packet of the Quick mode exchange as the Phase 2 initiator.

Recommended Action None required.

714003

Error Message %ASA-7-714003: IKE Responder starting QM: msg id = *message_number*

Explanation The ASA has received the first packet of the Quick mode exchange as the Phase 2 responder.

Recommended Action None required.

714004

Error Message %ASA-7-714004: IKE Initiator sending 1st QM pkt: msg id = *message_number*

Explanation The protocol of the first Quick Mode packet was decoded.

Recommended Action None required.

714005

Error Message %ASA-7-714005: IKE Responder sending 2nd QM pkt: msg id = *message_number*

Explanation The protocol of the second Quick Mode packet was decoded.

Recommended Action None required.

714006

Error Message `%ASA-7-714006: IKE Initiator sending 3rd QM pkt: msg id = message_number`

Explanation The protocol of the third Quick Mode packet was decoded.

Recommended Action None required.

714007

Error Message `%ASA-7-714007: IKE Initiator sending Initial Contact`

Explanation The ASA is building and sending the initial contact payload.

Recommended Action None required.

714011

Error Message `%ASA-7-714011: Description of received ID values`

Explanation The ASA received the displayed ID information during the negotiation.

Recommended Action None required.

715001

Error Message `%ASA-7-715001: Descriptive statement`

Explanation A description of an event or problem encountered by the ASA appears.

Recommended Action The action depends on the description.

715004

Error Message `%ASA-7-715004: subroutine name() Q Send failure: RetCode (return_code)`

Explanation An internal error occurred when attempting to put messages in a queue.

Recommended Action This is often a benign condition. If the problem persists, contact the Cisco TAC.

715005

Error Message %ASA-7-715005: subroutine *name*() Bad message code: Code (*message_code*)

Explanation An internal subroutine received a bad message code.

Recommended Action This is often a benign condition. If the problem persists, contact the Cisco TAC.

715006

Error Message %ASA-7-715006: IKE got SPI from key engine: SPI = *SPI_value*

Explanation The IKE subsystem received an SPI value from IPsec.

Recommended Action None required.

715007

Error Message %ASA-7-715007: IKE got a KEY_ADD msg for SA: SPI = *SPI_value*

Explanation IKE has completed tunnel negotiation and has successfully loaded the appropriate encryption and hashing keys for IPsec use.

Recommended Action None required.

715008

Error Message %ASA-7-715008: Could not delete SA *SA_address*, refCnt = *number*, caller = *calling_subroutine_address*

Explanation The calling subroutine cannot delete the IPsec SA. This might indicate a reference count problem.

Recommended Action If the number of stale SAs grows as a result of this event, contact the Cisco TAC.

715009

Error Message %ASA-7-715009: IKE Deleting SA: Remote Proxy *IP_address*, Local Proxy *IP_address*

Explanation SA is being deleted with the listed proxy addresses.

Recommended Action None required.

715013

Error Message `%ASA-7-715013: Tunnel negotiation in progress for destination IP_address, discarding data`

Explanation IKE is in the process of establishing a tunnel for this data. All packets to be protected by this tunnel will be dropped until the tunnel is fully established.

Recommended Action None required.

715019

Error Message `%ASA-7-715019: Group group Username username IP ip IKEGetUserAttributes: Attribute name = name`

Explanation The *modecfg* attribute name and value pair being processed by the ASA appear.

Recommended Action None required.

715020

Error Message `%ASA-7-715020: construct_cfg_set: Attribute name = name`

Explanation The *modecfg* attribute name and value pair being transmitted by the ASA appear.

Recommended Action None required.

715021

Error Message `%ASA-7-715021: Delay Quick Mode processing, Cert/Trans Exch/RM DSID in progress`

Explanation Quick mode processing is being delayed until all Phase 1 processing has been completed (for transaction mode).

Recommended Action None required.

715022

Error Message %ASA-7-715022: Resume Quick Mode processing, Cert/Trans Exch/RM DSID completed

Explanation Phase 1 processing has completed, and quick mode is being resumed.

Recommended Action None required.

715027

Error Message %ASA-7-715027: IPsec SA Proposal # *chosen_proposal*, Transform # *chosen_transform* acceptable Matches global IPsec SA entry # *crypto_map_index*

Explanation The indicated IPsec SA proposal and transform were selected from the payloads that the responder received. This data can be useful when attempting to debug IKE negotiation issues.

Recommended Action None required.

715028

Error Message %ASA-7-715028: IKE SA Proposal # 1, Transform # *chosen_transform* acceptable Matches global IKE entry # *crypto_map_index*

Explanation The indicated IKE SA transform was selected from the payloads that the responder received. This data can be useful when attempting to debug IKE negotiation issues.

Recommended Action None required.

715033

Error Message %ASA-7-715033: Processing CONNECTED notify (MsgId *message_number*)

Explanation The ASA is processing a message containing a notify payload with the notify type CONNECTED (16384). The CONNECTED notify type is used to complete the commit bit processing and should be included in the fourth overall quick mode packet, which is sent from the responder to the initiator.

Recommended Action None required.

715034

Error Message %ASA-7-715034: *action* IOS keep alive payload: proposal=*time 1*/*time 2* sec.

Explanation Processing for sending or receiving a keepalive payload message is being performed.

Recommended Action None required.

715035

Error Message %ASA-7-715035: Starting IOS keepalive monitor: *seconds* sec.

Explanation The keepalive timer will monitor for a variable number of seconds for keepalive messages.

Recommended Action None required.

715036

Error Message %ASA-7-715036: Sending keep-alive of type *notify_type* (seq number *number*)

Explanation Processing for sending a keepalive notify message is being performed.

Recommended Action None required.

715037

Error Message %ASA-7-715037: Unknown IOS Vendor ID version: *major.minor.variance*

Explanation The capabilities of this version of the Cisco IOS are not known.

Recommended Action There may be interoperability issues with features such as IKE keepalives. If the problem persists, contact the Cisco TAC.

715038

Error Message %ASA-7-715038: *action Spoofing_information* Vendor ID payload (version: *major.minor.variance*, capabilities: *value*)

Explanation Processing for the Cisco IOS vendor ID payload has been performed. The action being performed might be Altiga spoofing the Cisco IOS.

Recommended Action None required.

715039

Error Message %ASA-7-715039: Unexpected cleanup of tunnel table entry during SA delete.

Explanation An entry in the IKE tunnel table was never removed when the SA was freed. This indicates a defect in the state machine.

Recommended Action If the problem persists, contact the Cisco TAC.

715040

Error Message %ASA-7-715040: Deleting active auth handle during SA deletion: handle = *internal_authentication_handle*

Explanation The authentication handle was still active during SA deletion. This is part of cleanup recovery during the error condition.

Recommended Action None required.

715041

Error Message %ASA-7-715041: Received keep-alive of type *keepalive_type*, not the negotiated type

Explanation A keepalive of the type indicated in the message was received unexpectedly.

Recommended Action Check the keepalive configuration on both peers.

715042

Error Message `%ASA-7-715042: IKE received response of type failure_type to a request from the IP_address utility`

Explanation A request for an IP address for a remote access client from the internal utility that provides these addresses cannot be satisfied. Variable text in the message string indicates more specifically what went wrong.

Recommended Action Check the IP address assignment configuration and adjust accordingly.

715044

Error Message `%ASA-7-715044: Ignoring Keepalive payload from vendor not support KeepAlive capability`

Explanation A Cisco IOS keepalive payload from a vendor was received without keepalive capabilities being set. The payload is ignored.

Recommended Action None required.

715045

Error Message `%ASA-7-715045: ERROR: malformed Keepalive payload`

Explanation A malformed keepalive payload has been received. The payload is ignored.

Recommended Action None required.

715046

Error Message `%ASA-7-715046: Group = groupname, Username = username, IP = IP_address, constructing payload_description payload`

Explanation An IP address from a remote client for a specific group and user shows details about the IKE payload being constructed.

Recommended Action None required.

715047

Error Message `%ASA-7-715047: processing payload_description payload`

Explanation Details of the IKE payload received and being processed appear.

Recommended Action None required.

715048

Error Message `%ASA-7-715048: Send VID_type VID`

Explanation The type of vendor ID payload being sent appears.

Recommended Action None required.

715049

Error Message `%ASA-7-715049: Received VID_type VID`

Explanation The type of vendor ID payload received appears.

Recommended Action None required.

715050

Error Message `%ASA-7-715050: Claims to be IOS but failed authentication`

Explanation The vendor ID received looks like a Cisco IOS VID, but does not match *hmac_sha*.

Recommended Action Check the vendor ID configuration on both peers. If this issue affects interoperability and the problem persists, contact the Cisco TAC.

715051

Error Message `%ASA-7-715051: Received unexpected TLV type TLV_type while processing FWTYPE ModeCfg Reply`

Explanation An unknown TLV was received in an ASA record while an FWTYPE ModeCfg Reply was being processed. The TLV will be discarded. This might occur either because of packet corruption or because the connecting client supports a later version of the ASA protocol.

Recommended Action Check the personal FW installed on the Cisco VPN client and the personal firewall configuration on the ASA. This may also indicate a version mismatch between the VPN client and the ASA.

715052

Error Message `%ASA-7-715052: Old P1 SA is being deleted but new SA is DEAD, cannot transition centries`

Explanation The old P1 SA is being deleted, but has no new SA to transition to because it was marked for deletion as well. This generally indicates that the two IKE peers are out-of-sync with each other and may be using different rekey times. The problem should correct itself, but there may be some small amount of data loss until a fresh P1 SA is reestablished.

Recommended Action None required.

715053

Error Message `%ASA-7-715053: MODE_CFG: Received request for attribute_info!`

Explanation The ASA received a mode configuration message requesting the specified attribute.

Recommended Action None required.

715054

Error Message `%ASA-7-715054: MODE_CFG: Received attribute_name reply: value`

Explanation The ASA received a mode configuration reply message from the remote peer.

Recommended Action None required.

715055

Error Message `%ASA-7-715055: Send attribute_name`

Explanation The ASA sent a mode configuration message to the remote peer.

Recommended Action None required.

715056

Error Message `%ASA-7-715056: Client is configured for TCP_transparency`

Explanation Because the remote end (client) is configured for IPsec over TCP, the headend ASA must not negotiate IPsec over UDP or IPsec over NAT-T with the client.

Recommended Action The NAT transparency configuration may require adjustment of one of the peers if the tunnel does not come up.

715057

Error Message `%ASA-7-715057: Auto-detected a NAT device with NAT-Traversal. Ignoring IPsec-over-UDP configuration.`

Explanation IPsec-over-UDP mode configuration information will not be exchanged because NAT-Traversal was detected.

Recommended Action None required.

715058

Error Message `%ASA-7-715058: NAT-Discovery payloads missing. Aborting NAT-Traversal.`

Explanation The remote end did not provide NAT-Discovery payloads required for NAT-Traversal after exchanging NAT-Traversal VIDs. At least two NAT-Discovery payloads must be received.

Recommended Action This may indicate a nonconforming NAT-T implementation. If the offending peer is a Cisco product and the problem persists, contact the Cisco TAC. If the offending peer is not a Cisco product, then contact the manufacturer support team.

715059

Error Message `%ASA-7-715059: Proposing/Selecting only UDP-Encapsulated-Tunnel and UDP-Encapsulated-Transport modes defined by NAT-Traversal`

Explanation You need to use these modes instead of the usual transport and tunnel modes defined in the SA to successfully negotiate NAT-Traversal.

Recommended Action None required.

715060

Error Message `%ASA-7-715060: Dropped received IKE fragment. Reason:` *reason*

Explanation The reason for dropping the fragment appears.

Recommended Action The recommended action depends on the drop reason, but might indicate a problem with an intervening NAT device or a nonconforming peer.

715061

Error Message `%ASA-7-715061: Rcv'd fragment from a new fragmentation set. Deleting any old fragments.`

Explanation A resend of the same packet occurred, but fragmented to a different MTU, or another packet altogether.

Recommended Action None required.

715062

Error Message `%ASA-7-715062: Error assembling fragments! Fragment numbers are non-continuous.`

Explanation There is a gap in fragment numbers.

Recommended Action This might indicate a network problem. If the condition persists and results in dropped tunnels or prevents certain peers from negotiating with the ASA, contact the Cisco TAC.

715063

Error Message `%ASA-7-715063: Successfully assembled an encrypted pkt from rcv'd fragments!`

Explanation Assembly for a fragmented packet that was received was successful.

Recommended Action None required.

715064

Error Message `%ASA-7-715064 -- IKE Peer included IKE fragmentation capability flags: Main Mode: true/false Aggressive Mode: true/false`

Explanation The peer supports IKE fragmentation based on the information provided in the message.

Recommended Action None required.

715065

Error Message `%ASA-7-715065: IKE state_machine subtype FSM error history (struct data_structure_address) state, event: state/event pairs`

Explanation A Phase 1 error occurred and the *state*, *event* history pairs will be displayed in reverse chronological order.

Recommended Action Most of these errors are benign. If the problem persists, contact the Cisco TAC.

715066

Error Message `%ASA-7-715066: Can't load an IPsec SA! The corresponding IKE SA contains an invalid logical ID.`

Explanation The logical ID in the IKE SA is NULL. The Phase II negotiation will be torn down.

Recommended Action An internal error has occurred. If the problem persists, contact the Cisco TAC.

715067

Error Message `%ASA-7-715067: QM IsRekeyed: existing sa from different peer, rejecting new sa`

Explanation The LAN-TO-LAN SA that is being established already exists, that is, an SA with the same remote network, but is sourced from a different peer. This new SA will be deleted, because this is not a legal configuration.

Recommended Action Check the LAN-TO-LAN configuration on all associated peers. Specifically, multiple peers should not be sharing private networks.

715068

Error Message `%ASA-7-715068: QM IsRekeyed: duplicate sa found by` *`address`*`, deleting old sa`

Explanation The remote access SA that is being established already exists, that is, an SA with the same remote network, but is sourced from a different peer. The old SA will be deleted, because the peer may have changed its IP address.

Recommended Action This may be a benign condition, especially if a client tunnel was terminated abruptly. If the problem persists, contact the Cisco TAC.

715069

Error Message `%ASA-7-715069: Invalid ESP SPI size of` *`SPI_size`*

Explanation The ASA received an IPsec SA proposal with an invalid ESP SPI size. This proposal will be skipped.

Recommended Action Generally, this is a benign condition but might indicate that a peer may be nonconforming. If the problem persists, contact the Cisco TAC.

715070

Error Message `%ASA-7-715070: Invalid IPComp SPI size of` *`SPI_size`*

Explanation The ASA received an IPsec SA proposal with an invalid IPComp SPI size. This proposal will be skipped.

Recommended Action Generally, this is a benign condition but might indicate that a peer is nonconforming. If the problem persists, contact the Cisco TAC.

715071

Error Message `%ASA-7-715071: AH proposal not supported`

Explanation The IPsec AH proposal is not supported. This proposal will be skipped.

Recommended Action None required.

715072

Error Message `%ASA-7-715072: Received proposal with unknown protocol ID` *`protocol_ID`*

Explanation The ASA received an IPsec SA proposal with an unknown protocol ID. This proposal will be skipped.

Recommended Action Generally, this is a benign condition, but might indicate that a peer is nonconforming. If the problem persists, contact the Cisco TAC.

715074

Error Message `%ASA-7-715074: Could not retrieve authentication attributes for peer` *`IP_address`*

Explanation The ASA cannot get authorization information for the remote user.

Recommended Action Make sure that authentication and authorization settings have been configured correctly. If the problem persists, contact the Cisco TAC.

715075

Error Message `%ASA-7-715075: Group =` *`group_name`*`, IP =` *`IP_address`* `Received keep-alive of type` *`message_type`* `(seq number` *`number`*`)`

Explanation This message is paired with DPD R-U-THERE message 715036, which logs the DPD sending messages.

- *group_name*—The VPN group name of the peer
- *IP_address*—IP address of the VPN peer
- *message_type*—The message type (DPD R-U-THERE or DPD R-U-THERE-ACK)
- *number*—The DPD sequence number

Two possible cases:

- Received peer sending DPD R-U-THERE message
- Received peer reply DPD R-U-THERE-ACK message

Be aware of the following:

- The DPD R-U-THERE message is received and its sequence number matches the outgoing DPD reply messages.

  If the ASA sends a DPD R-U-THERE-ACK message without first receiving a DPD R-U-THERE message from the peer, it is likely experiencing a security breech.

- The received DPD R-U-THERE-ACK message's sequence number is matched with previously sent DPD messages.

  If the ASA did not receive a DPD R-U-THERE-ACK message within a reasonable amount of time after sending a DPD R-U-THERE message to the peer, the tunnel is most likely down.

Recommended Action None required.

715076

Error Message `%ASA-7-715076: Computing hash for ISAKMP`

Explanation IKE computed various hash values.

This object will be prepended as follows:

Group = *groupname*, Username = *username*, IP = *ip_address*...

Recommended Action None required.

715077

Error Message `%ASA-7-715077: Pitcher: msg string, spi spi`

Explanation Various messages have been sent to IKE.

msg_string can be one of the following:

- Received a key acquire message
- Received SPI for nonexistent SA
- Received key delete msg
- Received KEY_UPDATE
- Received KEY_REKEY_IB
- Received KEY_REKEY_OB
- Received KEY_SA_ACTIVE
- Could not find IKE SA to activate IPSEC (OB)
- Could not find IKE SA to rekey IPSEC (OB)
- KEY_SA_ACTIVE no centry found
- KEY_ADD centry not found
- KEY_UPDATE centry not found

This object will be prepended as follows:

Group = *groupname*, Username = *username*, IP = *ip_address*,...

Recommended Action None required.

715080

Error Message `%ASA-7-715080: VPN: Starting P2 rekey timer: 28800 seconds.`

Explanation An IKE rekey timer has started.

Recommended Action None required.

716001

Error Message `%ASA-6-716001: Group group User user IP ip WebVPN session started.`

Explanation The WebVPN session has started for the user in this group at the specified IP address. When the user logs in via the WebVPN login page, the WebVPN session starts.

Recommended Action None required.

716002

Error Message `%ASA-6-716002: Group GroupPolicy User username IP ip WebVPN session terminated: User requested.`

Explanation The WebVPN session has been terminated by a user request. Possible reasons include:

- Lost carrier
- Lost service
- Idle timeout
- Max time exceeded
- Administrator reset
- Administrator reboot
- Administrator shutdown
- Port error
- NAS error
- NAS request
- NAS reboot
- Port unneeded

- Port preempted. This reason indicates that the allowed number of simultaneous (same user) logins has been exceeded. To resolve this problem, increase the number of simultaneous logins or have users only log in once with a given username and password.
- Port suspended
- Service unavailable
- Callback
- User error
- Host requested
- Bandwidth management error
- ACL parse error
- VPN simultaneous logins limit specified in the group policy
- Unknown

Recommended Action Unless the reason indicates a problem, then no action is required.

716003

Error Message `%ASA-6-716003: Group group User user IP ip WebVPN access "GRANTED: url"`

Explanation The WebVPN user in this group at the specified IP address has been granted access to this URL. The user access to various locations can be controlled using WebVPN-specific ACLs.

Recommended Action None required.

716004

Error Message `%ASA-6-716004: Group group User user WebVPN access DENIED to specified location: url`

Explanation The WebVPN user in this group has been denied access to this URL. The WebVPN user access to various locations can be controlled using WebVPN-specific ACLs. In this case, a particular entry is denying access to this URL.

Recommended Action None required.

716005

Error Message `%ASA-6-716005: Group group User user WebVPN ACL Parse Error: reason`

Explanation The ACL for the WebVPN user in the specified group failed to parse correctly.

Recommended Action Correct the WebVPN ACL.

716006

Error Message `%ASA-6-716006: Group name User user WebVPN session terminated. Idle timeout.`

Explanation The WebVPN session was not created for the user in the specified group because the VPN tunnel protocol is not set to WebVPN.

Recommended Action None required.

716007

Error Message `%ASA-4-716007: Group group User user WebVPN Unable to create session.`

Explanation The WebVPN session was not created for the user in the specified group because of resource issues. For example, the user may have reached the maximum login limit.

Recommended Action None required.

716008

Error Message `%ASA-7-716008: WebVPN ACL: action`

Explanation The WebVPN ACL has begun performing an action (for example, begin parsing).

Recommended Action None required.

716009

Error Message `%ASA-6-716009: Group group User user WebVPN session not allowed. WebVPN ACL parse error.`

Explanation The WebVPN session for the specified user in this group is not allowed because the associated ACL did not parse. The user will not be allowed to log in via WebVPN until this error has been corrected.

Recommended Action Correct the WebVPN ACL.

716010

Error Message `%ASA-7-716010: Group group User user Browse network.`

Explanation The WebVPN user in the specified group browsed the network.

Recommended Action None required.

716011

Error Message `%ASA-7-716011: Group group User user Browse domain domain.`

Explanation The WebVPN specified user in this group browsed the specified domain.

Recommended Action None required.

716012

Error Message `%ASA-7-716012: Group group User user Browse directory directory.`

Explanation The specified WebVPN user browsed the specified directory.

Recommended Action None required.

716013

Error Message `%ASA-7-716013: Group group User user Close file filename.`

Explanation The specified WebVPN user closed the specified file.

Recommended Action None required.

716014

Error Message `%ASA-7-716014: Group group User user View file filename.`

Explanation The specified WebVPN user viewed the specified file.

Recommended Action None required.

716015

Error Message %ASA-7-716015: Group *group* User *user* Remove file *filename*.

Explanation The WebVPN user in the specified group removed the specified file.

Recommended Action None required.

716016

Error Message %ASA-7-716016: Group *group* User *user* Rename file *old_filename* to *new_filename*.

Explanation The specified WebVPN user renamed the specified file.

Recommended Action None required.

716017

Error Message %ASA-7-716017: Group *group* User *user* Modify file *filename*.

Explanation The specified WebVPN user modified the specified file.

Recommended Action None required.

716018

Error Message %ASA-7-716018: Group *group* User *user* Create file *filename*.

Explanation The specified WebVPN user created the specified file.

Recommended Action None required.

716019

Error Message %ASA-7-716019: Group *group* User *user* Create directory *directory*.

Explanation The specified WebVPN user created the specified directory.

Recommended Action None required.

716020

Error Message `%ASA-7-716020: Group group User user Remove directory directory.`

Explanation The specified WebVPN user removed the specified directory.

Recommended Action None required.

716021

Error Message `%ASA-7-716021: File access DENIED, filename.`

Explanation The specified WebVPN user was denied access to the specified file.

Recommended Action None required.

716022

Error Message `%ASA-4-716022: Unable to connect to proxy server reason.`

Explanation The WebVPN HTTP/HTTPS redirect failed for the specified reason.

Recommended Action Check the HTTP/HTTPS proxy configuration.

716023

Error Message `%ASA-4-716023: Group name User user Session could not be established: session limit of maximum_sessions reached.`

Explanation The user session cannot be established because the current number of sessions exceeds the maximum session load.

Recommended Action Increase the configured limit, if possible, to create a load-balanced cluster.

716024

Error Message `%ASA-7-716024: Group name User user Unable to browse the network.Error: description`

Explanation The user was unable to browse the Windows network using the CIFS protocol, as indicated by the description. For example, "Unable to contact necessary server" indicates that the remote server is unavailable or unreachable. This might be a transient condition or may require further troubleshooting.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA.

716025

Error Message `%ASA-7-716025: Group name User user Unable to browse domain domain. Error: description`

Explanation The user was unable to browse the remote domain using the CIFS protocol.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Check the NetBIOS name server configuration on the ASA.

716026

Error Message `%ASA-7-716026: Group name User user Unable to browse directory directory. Error: description`

Explanation The user was unable to browse the remote directory using the CIFS protocol.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA.

716027

Error Message `%ASA-7-716027: Group name User user Unable to view file filename. Error: description`

Explanation The user was unable to view the remote file using the CIFS protocol.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA.

716028

Error Message `%ASA-7-716028: Group name User user Unable to remove file filename. Error: description`

Explanation The user was unable to remove the remote file using the CIFS protocol, probably caused by a lack of file permissions.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA and the file permissions.

716029

Error Message `%ASA-7-716029: Group name User user Unable to rename file filename. Error: description`

Explanation The user was unable to rename the remote file using the CIFS protocol, probably caused by lack of file permissions.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA and the file permissions.

716030

Error Message `%ASA-7-716030: Group name User user Unable to modify file filename. Error: description`

Explanation A problem occurred when a user attempted to modify an existing file using the CIFS protocol, probably caused by a lack of file permissions.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA and the file permissions.

716031

Error Message `%ASA-7-716031: Group name User user Unable to create file filename. Error: description`

Explanation A problem occurred when a user attempted to create a file using the CIFS protocol, probably caused by a file permissions problem.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA and the file permissions.

716032

Error Message `%ASA-7-716032: Group name User user Unable to create folder folder. Error: description`

Explanation A problem occurred when a user attempted to create a folder using the CIFS protocol, probably caused by a file permissions problem.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA and the file permissions.

716033

Error Message `%ASA-7-716033: Group name User user Unable to remove folder folder. Error: description`

Explanation A problem occurred when a user of the CIFS protocol attempted to remove a folder, which probably occurred because of a permissions problem or a problem communicating with the server on which the file resides.

Recommended Action Check the connectivity between the WebVPN device and the server being accessed by the CIFS protocol. Also check the NetBIOS name server configuration on the ASA.

716034

Error Message `%ASA-7-716034: Group name User user Unable to write to file filename.`

Explanation A problem occurred when a user attempted to write to a file using the CIFS protocol, probably caused by a permissions problem or a problem communicating with the server on which the file resides.

Recommended Action None required.

716035

Error Message `%ASA-7-716035: Group name User user Unable to read file filename.`

Explanation A problem occurred when a user of the CIFS protocol tried to read a file, probably caused by a file permissions problem.

Recommended Action Check the file permissions.

716036

Error Message `%ASA-7-716036: Group name User user File Access: User user logged into the server server.`

Explanation A user successfully logged into the server using the CIFS protocol

Recommended Action None required.

716037

Error Message `%ASA-7-716037: Group name User user File Access: User user failed to login into the server server.`

Explanation A user attempted to log in to a server using the CIFS protocol, but was unsuccessful.

Recommended Action Verify that the user entered the correct username and password.

716038

Error Message `%ASA-6-716038: Group group User user IP ip Authentication: successful, Session Type: WebVPN.`

Explanation Before a WebVPN session can start, the user must be authenticated successfully by a local or remote server (for example, RADIUS or TACACS+).

Recommended Action None required.

716039

Error Message `%ASA-6-716039: Authentication: rejected, group = name user = user, Session Type: %s`

Explanation Before a WebVPN session starts, the user must be authenticated successfully by a local or remote server (for example, RADIUS or TACACS+). In this case, the user credentials (username and password) either did not match, or the user does not have permission to start a WebVPN session.

- *%s*—The session type, which can be either WebVPN or admin

Recommended Action Verify the user credentials on the local or remote server and that WebVPN is configured for the user.

716040

Error Message `%ASA-6-716040: Reboot pending, new sessions disabled. Denied user login.`

Explanation A user was unable to log in to WebVPN because the ASA is in the process of rebooting.

- *user*—The session user

Recommended Action None required.

716041

Error Message `%ASA-6-716041: access-list acl_ID action url url hit_cnt count`

Explanation The WebVPN URL named *acl_ID* has been hit *count* times for location *url,* whose *action* is permitted or denied.

- *acl_ID*—The WebVPN URL ACL
- *count*—The number of times the URL was accessed
- *url*—The URL that was accessed
- *action*—The user action

Recommended Action None required.

716042

Error Message `%ASA-6-716042: access-list acl_ID action tcp source_interface/source_address (source_port) - dest_interface/dest_address(dest_port) hit-cnt count`

Explanation The WebVPN TCP named *acl_ID* has been hit *count* times for packet received on the source interface *source_interface*/*source_address* and source port *source_port* forwarded to *dest_interface*/*dest_address* destination *dest_port,* whose *action* is permitted or denied.

- *count*—The number of times the ACL was accessed
- *source_interface*—The source interface
- *source_address*—The source IP address
- *source_port*—The source port
- *dest_interface*—The destination interface
- *dest_address*—The destination IP address
- *action*—The user action

Recommended Action None required.

716043

Error Message `%ASA-6-716043 Group group-name, User user-name, IP IP_address: WebVPN Port Forwarding Java applet started. Created new hosts file mappings.`

Explanation The user has launched a TCP port-forwarding applet from a WebVPN session.

- *group-name*—Group name associated with the session
- *user-name*—Username associated with the session
- *IP_address*—Source IP address associated with the session

Recommended Action None required.

716044

Error Message `%ASA-4-716044: Group group-name User user-name IP IP_address AAA parameter param-name value param-value out of range.`

Explanation The given parameter has a bad value.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address
- *param-name*—The name of the parameter

- *param-value*—The value of the parameter

Recommended Action Modify the configuration to correct the indicated parameter. If the parameter is vlan or nac-settings, verify that it is correctly configured on the AAA server and the ASA.

716045

Error Message `%ASA-4-716045: Group group-name User user-name IP IP_address AAA parameter param-name value invalid.`

Explanation The given parameter has a bad value. The value is not shown because it might be very long.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address
- *param-name*—The name of the parameter

Recommended Action Modify the configuration to correct the indicated parameter.

716046

Error Message `%ASA-4-716046: Group group-name User user-name IP IP_address User ACL access-list-name from AAA doesn't exist on the device, terminating connection.`

Explanation The specified ACL was not found on the ASA.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address
- *access-list-name*—The name of the ACL

Recommended Action Modify the configuration to add the specified ACL or to correct the ACL name.

716047

Error Message `%ASA-4-716047: Group group-name User user-name IP IP_address User ACL access-list-name from AAA ignored, AV-PAIR ACL used instead.`

Explanation The specified ACL was not used because a Cisco AV-PAIR ACL was used.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

- *access-list-name*—The name of the ACL

Recommended Action Determine the correct ACL to use and correct the configuration.

716048

Error Message `%ASA-4-716048: Group group-name User user-name IP IP_address No memory to parse ACL.`

Explanation There was not enough memory to parse the ACL.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Purchase more memory, upgrade the ASA, or reduce the load on it.

716049

Error Message `%ASA-6-716049: Group group-name User user-name IP IP_address Empty SVC ACL.`

Explanation The ACL to be used by the client was empty.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Determine the correct ACL to use and modify the configuration.

716050

Error Message `%ASA-6-716050: Error adding to ACL: ace_command_line`

Explanation The ACL entry had a syntax error.

- *ace_command_line*—The ACL entry that is causing the error

Recommended Action Correct the downloadable ACL configuration.

716051

Error Message `%ASA-6-716051: Group group-name User user-name IP IP_address Error adding dynamic ACL for user.`

Explanation There is not enough memory to perform the action.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Purchase more memory, upgrade the ASA, or reduce the load on it.

716052

Error Message `%ASA-4-716052: Group group-name User user-name IP IP_address Pending session terminated.`

Explanation A user did not complete login and the pending session was terminated. This may be due to an SVC that was unable to connect.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Check the user PC for SVC compatibility.

716053

Error Message `%ASA-5-716053: SSO Server added: name: name Type: type`

Explanation The SSO server name of the specified type has been configured.

- *name*—The name of the server
- *type*—The type of the server (the only server type is SiteMinder)

Recommended Action None required.

716054

Error Message `%ASA-5-716054: SSO Server deleted: name: name Type: type`

Explanation The SSO server name of the specified type has been removed from the configuration.

- *name*—The name of the server

- *type*—The type of server (the only server type is SiteMinder)

Recommended Action None required.

716055

Error Message `%ASA-6-716055: Group group-name User user-name IP IP_address Authentication to SSO server name: name type type succeeded`

Explanation The WebVPN user has been successfully authenticated to the SSO server.

- *group-name*—The group name
- *user-name*—The username
- *IP_address*—The IP address of the server
- *name*—The name of the server
- *type*—The type of server (the only server type is SiteMinder)

Recommended Action None required.

716056

Error Message `%ASA-3-716056: Group group-name User user-name IP IP_address Authentication to SSO server name: name type type failed reason: reason`

Explanation The WebVPN user failed to authenticate to the SSO server.

- *group-name*—The group name
- *user-name*—The username
- *IP_address*—The IP address of the server
- *name*—The name of the server
- *type*—The type of server (the only server type is SiteMinder)
- *reason*—The reason for the authentication failure

Recommended Action Either the user or the ASA administrator needs to correct the problem, depending on the reason for the failure.

716057

Error Message `%ASA-3-716057: Group group User user IP ip Session terminated, no type license available.`

Explanation A user has attempted to connect to the ASA using a client that is not licensed. This message may also occur if a temporary license has expired.

- *group*—The group policy that the user logged in with

- *user*—The name of the user
- *IP*—The IP address of the user
- *type*—The type of license requested, which can be one of the following:

  - AnyConnect Mobile

  - LinkSys Phone

  - The type of license requested by the client (if other than the AnyConnect Mobile or LinkSys Phone)

  - Unknown

Recommended Action A permanent license with the appropriate feature should be purchased and installed.

716058

Error Message `%ASA-6-716058: Group group User user IP ip AnyConnect session lost connection. Waiting to resume.`

Explanation The SSL tunnel was dropped and the AnyConnect session enters the inactive state, which can be caused by a hibernating host, a standby host, or a loss of network connectivity.

- *group*—The tunnel group name associated with the AnyConnect session
- *user*—The name of the user associated with the session
- *ip*—The source IP address of the session

Recommended Action None required.

716059

Error Message `%ASA-6-716059: Group group User user IP ip AnyConnect session resumed. Connection from ip2.`

Explanation An AnyConnect session resumed from the inactive state.

- *group*—The tunnel group name associated with the AnyConnect session
- *user*—The name of the user associated with the session
- *ip*—The source IP address of the session
- *ip2*—The source IP address of the host on which the session is resumed

Recommended Action None required.

716060

Error Message `%ASA-6-716060: Group group User user IP ip Terminated AnyConnect session in inactive state to accept a new connection. License limit reached.`

Explanation An AnyConnect session in the inactive state was logged out to allow a new incoming SSL VPN (AnyConnect or clientless) connection.

- *group*—The tunnel group name associated with the AnyConnect session
- *user*—The name of the user associated with the session
- *ip*—The source IP address of the session

Recommended Action None required.

716061

Error Message `%ASA-3-716061: Group DfltGrpPolicy User user IP ip addr IPv6 User Filter tempipv6 configured for AnyConnect. This setting has been deprecated, terminating connection`

Explanation The IPv6 VPN filter has been deprecated and if it is configured instead of a unified filter for IPv6 traffic access control, the connection will be terminated.

Recommended Action Configure a unified filter with IPv6 entries to control IPv6 traffic for the user.

716500

Error Message `%ASA-2-716500: internal error in: function: Fiber library cannot locate AK47 instance`

Explanation The fiber library cannot locate the application kernel layer 4 to 7 instance.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716501

Error Message `%ASA-2-716501: internal error in: function: Fiber library cannot attach AK47 instance`

Explanation The fiber library cannot attach the application kernel layer 4 to 7 instance.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716502

Error Message `%ASA-2-716502: internal error in: function: Fiber library cannot allocate default arena`

Explanation The fiber library cannot allocate the default arena.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716503

Error Message `%ASA-2-716503: internal error in: function: Fiber library cannot allocate fiber descriptors pool`

Explanation The fiber library cannot allocate the fiber descriptors pool.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716504

Error Message `%ASA-2-716504: internal error in: function: Fiber library cannot allocate fiber stacks pool`

Explanation The fiber library cannot allocate the fiber stack pool.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716505

Error Message `%ASA-2-716505: internal error in: function: Fiber has joined fiber in unfinished state`

Explanation The fiber has joined fiber in an unfinished state.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716506

Error Message `%ASA-2-716506: UNICORN_SYSLOGID_JOINED_UNEXPECTED_FIBER`

Explanation An internal fiber library was generated.

Recommended Action Contact the Cisco TAC.

716507

Error Message `%ASA-1-716507: Fiber scheduler has reached unreachable code. Cannot continue, terminating.`

Explanation The ASA has experienced an unexpected error and has recovered.

Recommended Action Check for high CPU usage or CPU hogs, and potential memory leaks. If the problem persists, contact the Cisco TAC.

716508

Error Message `%ASA-1-716508: internal error in: function: Fiber scheduler is scheduling rotten fiber. Cannot continuing terminating`

Explanation The fiber scheduler is scheduling rotten fiber, so it cannot continue terminating.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716509

Error Message `%ASA-1-716509:internal error in: function: Fiber scheduler is scheduling alien fiber. Cannot continue terminating`

Explanation The fiber scheduler is scheduling alien fiber, so it cannot continue terminating.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716510

Error Message `%ASA-1-716510:internal error in: function: Fiber scheduler is scheduling finished fiber. Cannot continue terminating`

Explanation The fiber scheduler is scheduling finished fiber, so it cannot continue terminating.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716512

Error Message %ASA-2-716512:internal error in: *function*: Fiber has joined fiber waited upon by someone else

Explanation The fiber has joined fiber that is waited upon by someone else.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716513

Error Message %ASA-2-716513: internal error in: *function*: Fiber in callback blocked on other channel

Explanation The fiber in the callback was blocked on the other channel.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716515

Error Message %ASA-2-716515:internal error in: *function*: OCCAM failed to allocate memory for AK47 instance

Explanation The OCCAM failed to allocate memory for the AK47 instance.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716516

Error Message %ASA-1-716516: internal error in: *function*: OCCAM has corrupted ROL array. Cannot continue terminating

Explanation The OCCAM has a corrupted ROL array, so it cannot continue terminating.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716517

Error Message %ASA-2-716517: internal error in: *function*: OCCAM cached block has no associated arena

Explanation The OCCAM cached block has no associated arena.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716518

Error Message `%ASA-2-716518: internal error in: function: OCCAM pool has no associated arena`

Explanation The OCCAM pool has no associated arena.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716519

Error Message `%ASA-1-716519: internal error in: function: OCCAM has corrupted pool list. Cannot continue terminating`

Explanation The OCCAM has a corrupted pool list, so it cannot continue terminating.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716520

Error Message `%ASA-2-716520:internal error in: function: OCCAM pool has no block list`

Explanation The OCCAM pool has no block list.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716521

Error Message `%ASA-2-716521: internal error in: function: OCCAM no realloc allowed in named pool`

Explanation The OCCAM did not allow reallocation in the named pool.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716522

Error Message `%ASA-2-716522: internal error in: function: OCCAM corrupted standalone block`

Explanation The OCCAM has a corrupted standalone block.

Recommended Action To determine the cause of the problem, contact the Cisco TAC.

716525

Error Message `%ASA-2-716525: UNICORN_SYSLOGID_SAL_CLOSE_PRIVDATA_CHANGED`

Explanation An internal SAL error has occurred.

Recommended Action Contact the Cisco TAC.

716526

Error Message `%ASA-2-716526: UNICORN_SYSLOGID_PERM_STORAGE_SERVER_LOAD_FAIL`

Explanation A failure in the mounting of the permanent storage server directory occurred.

Recommended Action Contact the Cisco TAC.

716527

Error Message `%ASA-2-716527: UNICORN_SYSLOGID_PERM_STORAGE_SERVER_STORE_FAIL`

Explanation A failure in the mounting of the permanent storage file occurred.

Recommended Action Contact the Cisco TAC.

716528

Error Message `%ASA-1-716528: Unexpected fiber scheduler error; possible out-of-memory condition`

Explanation The ASA has experienced an unexpected error and has recovered.

Recommended Action Check for high CPU usage or CPU hogs, and potential memory leaks. If the problem persists, contact the Cisco TAC.

716600

Error Message `%ASA-3-716600: Rejected` *`size-recv`* `KB Hostscan data from IP` *`src-ip`*`. Hostscan results exceed` *`default`* `|` *`configured`* `limit of` *`size-conf`* `KB.`

Explanation When the size of the received Hostscan data exceeds the limit configured on the ASA, the data is discarded.

- *size-recv*—Size of received Hostscan data in kilobytes
- *src-ip*—Source IP address

- *default | configured*—Keyword specifying whether the value of the Hostscan data limit is the default or configured by the administrator
- *size-conf*—Configured upper limit on the size of the Hostscan data that the ASA accepts from clients

Recommended Action Contact Cisco TAC to increase the upper limit on the size of Hostscan data that the ASA accepts from clients.

716601

Error Message `%ASA-3-716601: Rejected size-recv KB Hostscan data from IP src-ip. System-wide limit on the amount of Hostscan data stored on ASA exceeds the limit of data-max KB.`

Explanation When the amount of Hostscan data stored on the ASA exceeds the limit, new Hostscan results are rejected.

- *size-recv*—Size of received Hostscan data in kilobytes
- *src-ip*—Source IP address
- *data-max*—Limit on the amount of Hostscan results to be stored by the ASA in kilobytes

Recommended Action Contact Cisco TAC to change the limit on stored Hostscan data.

716602

Error Message `%ASA-3-716602: Memory allocation error. Rejected size-recv KB Hostscan data from IP src-ip.`

Explanation An error occurred while memory was being allocated for Hostscan data.

- *size-recv*—Size of received Hostscan data in kilobytes
- *src-ip*—Source IP address

Recommended Action Set the Hostscan limit to the default value if it is configured. If the problem persists, contact Cisco TAC.

716603

Error Message `%ASA-7-716603: Received size-recv KB Hostscan data from IP src-ip.`

Explanation The Hostscan data of a specified size was successfully received.

- *size-recv*—Size of received Hostscan data in kilobytes
- *src-ip*—Source IP address

Recommended Action None required.

717001

Error Message `%ASA-3-717001: Querying keypair failed.`

Explanation A required keypair was not found during an enrollment request.

Recommended Action Verify that a valid keypair exists in the trustpoint configuration, then resubmit the enrollment request.

717002

Error Message `%ASA-3-717002: Certificate enrollment failed for trustpoint` *`trustpoint_name`*`. Reason:` *`reason_string`*`.`

Explanation An enrollment request for this trustpoint has failed.

- *trustpoint name*—Trustpoint name that the enrollment request was for
- *reason_string*—The reason the enrollment request failed

Recommended Action Check the CA server for the failure reason.

717003

Error Message `%ASA-6-717003: Certificate received from Certificate Authority for trustpoint` *`trustpoint_name`*`.`

Explanation A certificate was successfully received from the CA for this trustpoint.

- *trustpoint_name*—Trustpoint name

Recommended Action None required

717004

Error Message `%ASA-6-717004: PKCS #12 export failed for trustpoint` *`trustpoint_name`*`.`

Explanation The trustpoint failed to export, because of one of the following: only a CA certificate exists, and an identity certificate does not exist for the trustpoint, or a required keypair is missing.

- *trustpoint_name*—Trustpoint name

Recommended Action Make sure that required certificates and keypairs are present for the given trustpoint.

717005

Error Message `%ASA-6-717005: PKCS #12 export succeeded for trustpoint trustpoint_name.`

Explanation The trustpoint was successfully exported.

- *trustpoint_name*—Trustpoint name

Recommended Action None required

717006

Error Message `%ASA-6-717006: PKCS #12 import failed for trustpoint trustpoint_name.`

Explanation Import of the requested trustpoint failed to be processed.

- *trustpoint_name*—Trustpoint name

Recommended Action Verify the integrity of the imported data. Then make sure that the entire pkcs12 record is correctly pasted, and reimport the data.

717007

Error Message `%ASA-6-717007: PKCS #12 import succeeded for trustpoint trustpoint_name.`

Explanation Import of the requested trustpoint was successfully completed.

- *trustpoint_name*—Trustpoint name

Recommended Action None required.

717008

Error Message `%ASA-2-717008: Insufficient memory to process_requiring_memory.`

Explanation An internal error occurred while attempting to allocate memory for the process that reqires memory. Other processes may experience problems allocating memory and prevent further processing.

- *process_requiring_memory*—The specified process that requires memoryr

Recommended Action Collect memory statistics and logs for further debugging and reload the ASA.

717009

Error Message `%ASA-3-717009: Certificate validation failed. Reason: reason_string.`

Explanation A certificate validation failed, which might be caused by a validation attempt of a revoked certificate, invalid certificate attributes, or configuration issues.

- *reason_string*—The reason that the certificate validation failed

Recommended Action Make sure the configuration has a valid trustpoint configured for validation if the reason indicates that no suitable trustpoints were found. Check the ASA time to ensure that it is accurate relative to the certificate authority time. Check the reason for the failure and correct any issues that are indicated.

717010

Error Message `%ASA-3-717010: CRL polling failed for trustpoint trustpoint_name.`

Explanation .CRL polling has failed and may cause connections to be denied if CRL checking is required.

- *trustpoint_name*—The name of the trustpoint that requested the CRL

Recommended Action Verify that connectivity exists with the configured CRL distribution point and make sure that manual CRL retrieval also functions correctly.

717011

Error Message `%ASA-2-717011: Unexpected event event event_ID`

Explanation An event that is not expected under normal conditions has occurred.

Recommended Action If the problem persists, contact the Cisco TAC.

717012

Error Message `%ASA-3-717012: Failed to refresh CRL cache entry from the server for trustpoint trustpoint_name at time_of_failure`

Explanation An attempt to refresh a cached CRL entry has failed for the specified trustpoint at the indicated time of failure. This may result in obsolete CRLs on the ASA, which may cause connections that require a valid CRL to be denied.

- *trustpoint_name*—The name of the trustpoint

- *time_of_failure*—The time of failure

Recommended Action Check connectivity issues to the server, such as a downed network or server. Try to retrieve the CRL manually using the **crypto ca crl retrieve** command.

717013

Error Message `%ASA-5-717013: Removing a cached CRL to accommodate an incoming CRL. Issuer: issuer`

Explanation When the device is configured to authenticate IPsec tunnels using digital certificates, CRLs may be cached in memory to avoid requiring a CRL download during each connection. If the cache fills to the point where an incoming CRL cannot be accommodated, older CRLs will be removed until the required space is made available. This message is generated for each purged CRL.

- *issuer*—The name of the device that removes cached CRLs

Recommended Action None required.

717014

Error Message `%ASA-5-717014: Unable to cache a CRL received from CDP due to size limitations (CRL size = size, available cache space = space)`

Explanation When the device is configured to authenticate IPsec tunnels using digital certificates, CRLs may be cached in memory to avoid requiring a CRL download during each connection. This message is generated if a received CRL is too large to fit in the cache. Large CRLs are still supported even though they are not cached. This means that the CRL will be downloaded with each IPsec connection, which may affect performance during IPsec connection bursts.

Recommended Action None required.

717015

Error Message `%ASA-3-717015: CRL received from issuer is too large to process (CRL size = crl_size, maximum CRL size = max_crl_size)`

Explanation An IPsec connection caused a CRL that is larger than the maximum permitted CRL size to be downloaded. This error condition causes the connection to fail. This message is rate limited to one message every 10 seconds.

Recommended Action Scalability is perhaps the most significant drawback to the CRL method of revocation checking. To solve this problem, the only options are to investigate a CA-based solution to reduce the CRL size or configure the ASA not to require CRL validation.

717016

Error Message `%ASA-6-717016: Removing expired CRL from the CRL cache. Issuer: issuer`

Explanation When the ASA is configured to authenticate IPsec tunnels using digital certificates, CRLs may be cached in memory to avoid requiring a CRL download during each connection. This message is generated when either the CA specified expiration time or the configured cache time has lapsed and the CRL is removed from the cache.

Recommended Action None required.

717017

Error Message `%ASA-3-717017: Failed to query CA certificate for trustpoint trustpoint_name from enrollment_url`

Explanation An error occurred when an attempt was made to authenticate a trustpoint by requesting a CA certificate from a certificate authority.

Recommended Action Make sure that an enrollment URL is configured with this trustpoint, ensure connectivity with the CA server, then retry the request.

717018

Error Message `%ASA-3-717018: CRL received from issuer has too many entries to process (number of entries = number_of_entries, maximum number allowed = max_allowed)`

Explanation An IPsec connection caused a CRL that includes more revocation entries than can be supported to be downloaded. This is an error condition that will cause the connection to fail. This message is rate limited to one message every 10 seconds.

- *issuer*—The X.500 name of the CRLs issuer
- *number_of_entries*—The number of revocation entries in the received CRL
- *max_allowed*—The maximum number of CRL entries that the ASA supports

Recommended Action Scalability is perhaps the most significant drawback to the CRL method of revocation checking. The only options to solve this problem are to investigate a CA-based solution to reduce the CRL size or configure the ASA not to require CRL validation.

717019

Error Message `%ASA-3-717019: Failed to insert CRL for trustpoint trustpoint_name. Reason: failure_reason.`

Explanation A CRL is retrieved, but found to be invalid and cannot be inserted into the cache because of the *failure_reason*.

- *trustpoint_name*—The name of the trustpoint that requested the CRL
- *failure_reason*—The reason that the CRL failed to be inserted into cache

Recommended Action Make sure that the current ASA time is correct relative to the CA time. If the NextUpdate field is missing, configure the trustpoint to ignore the NextUpdate field.

717020

Error Message `%ASA-3-717020: Failed to install device certificate for trustpoint label. Reason: reason string.`

Explanation A failure occurred while trying to enroll or import an enrolled certificate into a trustpoint.

- *label*—Label of the trustpoint that failed to install the enrolled ASA certificate
- *reason_string*—The reason that the certificate cannot be verified

Recommended Action Use the failure reason to remedy the cause of failure and retry the enrollment. Common failures are due to invalid certificates being imported into the ASA or a mismatch of the public key included in the enrolled certificate with the keypair referenced in the trustpoint.

717021

Error Message `%ASA-3-717021: Certificate data could not be verified. Locate Reason: reason_string serial number: serial number, subject name: subject name, key length key length bits.`

Explanation An attempt to verify the certificate that is identified by the serial number and subject name was unsuccessful for the specified reason. When verifying certificate data using the signature, several errors can occur that should be logged, including invalid key types and unsupported key size.

- *reason_string*—The reason that the certificate cannot be verified
- *serial number*—Serial number of the certificate that is being verified
- *subject name*—Subject name included in the certificate that is being verified
- *key length*—The number of bits in the key used to sign this certificate

Recommended Action Check the specified certificate to ensure that it is valid, that it includes a valid key type, and that it does not exceed the maximum supported key size.

717022

Error Message `%ASA-6-717022: Certificate was successfully validated. certificate_identifiers`

Explanation The identified certificate was successfully validated.

- *certificate_identifiers*—Information to identify the certificate that was validated successfully, which might include a reason, serial number, subject name, and additional information

Recommended Action None required.

717023

Error Message `%ASA-3-717023: SSL failed to set device certificate for trustpoint trustpoint name. Reason: reason_string.`

Explanation A failure occurred while trying to set an ASA certificate for the given trustpoint for authenticating the SSL connection.

- *trustpoint name*—Name of the trustpoint for which SSL failed to set an ASA certificate
- *reason_string*—Reason indicating why the ASA certificate cannot be set

Recommended Action Resolve the issue indicated by the reason reported for the failure by doing the following:

- Make sure that the specified trustpoint is enrolled and has an ASA certificate.
- Make sure the ASA certificate is valid.
- Reenroll the trustpoint, if required.

717024

Error Message `%ASA-7-717024: Checking CRL from trustpoint: trustpoint name for purpose`

Explanation A CRL is being retrieved.

- *trustpoint name*—Name of the trustpoint for which the CRL is being retrieved
- *purpose*—Reason that the CRL is being retrieved

Recommended Action None required.

717025

Error Message `%ASA-7-717025: Validating certificate chain containing` *`number of certs`* `certificate(s).`

Explanation A certificate chain is being validated.

- *number of certs*—Number of certificates in the chain

Recommended Action None required.

717026

Error Message `%ASA-4-717026: Name lookup failed for hostname` *`hostname`* `during PKI operation.`

Explanation The given hostname cannot be resolved while attempting a PKI operation.

- *hostname*—The hostname that failed to resolve

Recommended Action Check the configuration and the DNS server entries for the given hostname to make sure that it can be resolved. Then retry the operation.

717027

Error Message `%ASA-3-717027: Certificate chain failed validation.` *`reason_string`*`.`

Explanation A certificate chain cannot be validated.

- *reason_string*—Reason for the failure to validate the certificate chain

Recommended Action Resolve the issue noted by the reason and retry the validation attempt by performing any of the following actions:

- Make sure that connectivity to a CA is available if CRL checking is required.
- Make sure that a trustpoint is authenticated and available for validation.
- Make sure that the identity certificate within the chain is valid based on the validity dates.
- Make sure that the certificate is not revoked.

717028

Error Message `%ASA-6-717028: Certificate chain was successfully validated` *`additional info`*`.`

Explanation A certificate chain was successfully validated.

- *additional info*—More information for how the certificate chain was validated (for example, "with warning" indicates that a CRL check was not performed)

Recommended Action None required.

717029

Error Message `%ASA-7-717029: Identified client certificate within certificate chain. serial number:` *`serial_number`*`, subject name:` *`subject_name`*`.`

Explanation The certificate specified as the client certificate is identified.

- *serial_number*—Serial number of the certificate that is identified as the client certificate
- *subject_name*—Subject name included in the certificate that is identified as the client certificate

Recommended Action None required.

717030

Error Message `%ASA-7-717030: Found a suitable trustpoint` *`trustpoint name`* `to validate certificate.`

Explanation A suitable or usable trustpoint is found that can be used to validate the certificate.

- *trustpoint name*—Trustpoint that will be used to validate the certificate

Recommended Action None required.

717031

Error Message `%ASA-4-717031: Failed to find a suitable trustpoint for the issuer:` *`issuer`* `Reason:` *`reason_string`*

Explanation A usable trustpoint cannot be found. During certificate validation, a suitable trustpoint must be available in order to validate a certificate.

- *issuer* —Issuer of the certificate that was being validated

- *reason_string*—The reason that a suitable trustpoint cannot be found

Recommended Action Resolve the issue indicated in the reason by checking the configuration to make sure that a trustpoint is configured, authenticated, and enrolled. Also make sure that the configuration allows for specific types of certificates, such as identity certificates.

717033

Error Message `%ASA-6-717033: OCSP response status - Successful.`

Explanation An OCSP status check response was received successfully.

Recommended Action None required.

717034

Error Message `%ASA-7-717034: No-check extension found in certificate. OCSP check bypassed.`

Explanation An OCSP responder certificate was received that includes an "id-pkix-ocsp-nocheck" extension, which allows this certificate to be validated without an OCSP status check.

Recommended Action None required.

717035

Error Message `%ASA-4-717035: OCSP status is being checked for certificate. certificate_identifier.`

Explanation The certificate for which an OCSP status check occurs is identified.

- *certificate_identifier*—Information that identifies the certificate being processed by the certificate map rules

Recommended Action None required.

717036

Error Message `ASA-7-717036: Looking for a tunnel group match based on certificate maps for peer certificate with certificate_identifier.`

Explanation The peer certificate identified by the certificate identifier is being processed through the configured certificate maps to attempt a possible tunnel group match.

- *certificate_identifier*—Information that identifies the certificate being processed by the certificate map rules

Recommended Action None required.

717037

Error Message `%ASA-4-717037: Tunnel group search using certificate maps failed for peer certificate: certificate_identifier.`

Explanation The peer certificate identified by the certificate identifier was processed through the configured certificate maps to attempt a possible tunnel group match, but no match can be found.

- *certificate_identifier*—Information that identifies the certificate being processed by the certificate map rules

Recommended Action Make sure that the warning is expected based on the received peer certificate and the configured crypto CA certificate map rules.

717038

Error Message `%ASA-7-717038: Tunnel group match found. Tunnel Group: tunnel_group_name, Peer certificate: certificate_identifier.`

Explanation The peer certificate identified by the certificate identifier was processed by the configured certificate maps, and a match was found to the tunnel group.

- *certificate_identifier*—Information that identifies the certificate being processed by the certificate map rules
- *tunnel_group_name*—The name of the tunnel group matched by the certificate map rules

Recommended Action None required.

717039

Error Message `%ASA-3-717039: Local CA Server internal error detected: error.`

Explanation An internal processing error has occurred with the local CA server.

- *error*—Error string

Recommended Action Based on the error, take the necessary steps to resolve the issue. Currently, the possible errors include:

- CA key does not exist—Make sure that the CA key is present, or restore the key from a backup, if necessary.
- Failed to rollover expired CA certificate—Make sure that the clock is correct and that the CA certificate is expired, then restart the CA server to try to reissue the certificate.
- Failed to generate self-signed certificate for Local CA Server certificate rollover upon expiration—Make sure that the clock is correct and that the CA certificate is about to expire, then restart the CA server to try to reissue the certificate.
- Failed to configure Local CA Server—Turn on debugging and try to configure the CA server again to determine the cause of the failure.
- Invalid issuer name configured—Change the issuer name DN to a valid DN string.

717040

Error Message `%ASA-2-717040: Local CA Server has failed and is being disabled. Reason: reason.`

Explanation The local CA server is being disabled because of an error.

- *reason*—Reason string

  Currently, the possible errors include:

- Storage down—Make sure that storage is accessible, and reenable the CA server by using the **no shut** command.

Recommended Action Based on the reason, take the necessary steps to resolve the issue.

717041

Error Message `%ASA-7-717041: Local CA Server event: event info.`

Explanation Event details that have occurred on the CA server are reported to allow you to track or debug the CA server health, including when the CA server is created, enabled, or disabled, or when the CA server certificate is rolled over.

- *event info*—Details of the event that occurred

Recommended Action None required.

717042

Error Message `%ASA-3-717042: Failed to enable Local CA Server.Reason: reason.`

Explanation Errors occurred when an attempt was made to enable the local CA server.

- *reason*—Reason that the local CA server failed to enable

Recommended Action Resolve the issue encountered that is reported in the reason string. Currently, the possible reasons include:

- Failed to create server trustpoint
- Failed to create server keypair
- Time has not been set
- Failed to init storage
- Storage not accessible
- Failed to validate self-signed CA certificate
- Failed to generate self-signed CA certificate
- CA certificate has expired
- Failed to generate CRL
- Failed to archive CA key and certificate
- Failed to generate empty user or certificate database file
- Failed to load user or certificate database file

717043

Error Message `%ASA-6-717043: Local CA Server certificate enrollment related info for user: user. Info: info.`

Explanation Enrollment-related activities for a user are being monitored. The username and specific enrollment information are reported so that enrollments, e-mail invitation generation, and renewal reminder generation can be monitored.

- *user*—Username about whom the enrollment information log is being generated
- *info*—Enrollment information string

Recommended Action None required.

717044

Error Message `%ASA-3-717044: Local CA server certificate enrollment related error for user: user. Error: error.`

Explanation Errors that occur in the processing of certificate enrollment are reported, which may include errors in notifying users via e-mail for renewal reminders, errors during issuance of a certificate to complete enrollment, invalid username or OTP, and expired enrollment attempts.

- *user*—Username for whom the enrollment error log is being generated
- *error*—Enrollment error

Recommended Action If the error does not provide enough information to diagnose and resolve the issue, turn on debugging and try enrollment again.

717045

Error Message `%ASA-7-717045:Local CA Server CRL info: info`

Explanation The CRL file is monitored when it is generated and regenerated.

- *info*—Informational string of the CRL event

Recommended Action None required.

717046

Error Message `%ASA-3-717046: Local CA Server CRL error: error.`

Explanation Errors that are encountered while trying to generate and reissue the local CA server CRL file are reported.

- *error*—Error string

Recommended Action Take appropriate action to resolve the reported issue, which may include verifying that storage is accessible, and that the CRL file is valid in storage and signed by the existing local CA server.

717047

Error Message `%ASA-6-717047: Revoked certificate issued to user: username, with serial number serial number.`

Explanation Any certificates issued by the local CA server that have been revoked are being monitored.

- *username*—Username of the owner of the certificate that is being revoked

- *serial number*—Serial number of the certificate that has been revoked

Recommended Action None required.

717048

Error Message `%ASA-6-717048: Unrevoked certificate issued to user: username, with serial number serial number.`

Explanation Any certificates that were issued by the local CA server that were previously revoked, and that are now being unrevoked and removed from the CRL are being monitored.

- *username*—Username of the owner of the certificate that is being unrevoked
- *serial number*—Serial number of the certificate that has been unrevoked

Recommended Action None required.

717049

Error Message `%ASA-1-717049: Local CA Server certificate is due to expire in number days and a replacement certificate is available for export.`

Explanation The administrator is alerted to an upcoming CA certificate expiration so that the administrator can take action to export the replacement certificate to all ASAs that will require the new certificate.

- *number*—The number of days before the local CA server certificate expires

Recommended Action To avoid certificate validation failures on any ASAs that require the local CA server certificate, action should be taken before the actual expiration of the current local CA server certificate, which is indicated by the *number* value. Note that the local CA server does not require any action because the CA certificate will be replaced automatically. Use the **show crypto ca server certificate** command to view the replacement or rollover local CA server certificate and copy it for import into any ASA that will require the new certificate.

717050

Error Message `%ASA-5-717050: SCEP Proxy: Processed request type type from IP client ip address, User username, TunnelGroup tunnel_group name, GroupPolicy group-policy name to CA IP ca ip address`

Explanation The SCEP proxy received a message and relayed it to the CA. The response from the CA is relayed back to the client.

- *type*—The request type string that is received by the SCEP proxy, which can be one of the following SCEP message types: PKIOperation, GetCACaps, GetCACert, GetNextCACert, and GetCACertChain.
- *client ip address*—The source IP address of the request received

- *username*—The username that is associated with the VPN session in which the SCEP request is received
- *tunnel-group name*—The tunnel group that is associated with the VPN session in which the SCEP request is received
- *group-policy name*—The group policy that is associated with the VPN session in which the SCEP request is received
- *ca ip address*—The IP address of the CA that is configured in the group policy

Recommended Action None required.

717051

Error Message `%ASA-3-717051: SCEP Proxy: Denied processing the request type type received from IP client ip address, User username, TunnelGroup tunnel group name, GroupPolicy group policy name to CA ca ip address. Reason: msg`

Explanation The SCEP proxy denied processing of the request, which may be caused by a misconfiguration, an error condition in the proxy, or an invalid request.

- *type*—The request type string that is received by the SCEP proxy, which can be one of the following SCEP message types: PKIOperation, GetCACaps, GetCACert, GetNextCACert, and GetCACertChain.
- *client ip address*—The source IP address of the request received
- *username*—The username that is associated with the VPN session in which the SCEP request is received
- *tunnel-group name*—The tunnel group that is associated with the VPN session in which the SCEP request is received
- *group-policy name*—The group policy that is associated with the VPN session in which the SCEP request is received
- *ca ip address*—The IP address of the CA that is configured in the group policy
- *msg*—The reason string that explains the reason or error for why the request processing is denied

Recommended Action Identify the cause from the reason printed. If the reason indicates that the request is invalid, check the CA URL configuration. Otherwise, confirm that the tunnel group is enabled for SCEP enrollment and debug further by using the **debug crypto ca scep-proxy** command.

718001

Error Message `%ASA-7-718001: Internal interprocess communication queue send failure: code` *`error_code`*

Explanation An internal software error has occurred while attempting to enqueue a message on the VPN load balancing queue.

Recommended Action This is generally a benign condition. If the problem persists, contact the Cisco TAC.

718002

Error Message `%ASA-5-718002: Create peer` *`IP_address`* `failure, already at maximum of` *`number_of_peers`*

Explanation The maximum number of load-balancing peers has been exceeded. The new peer is ignored.

Recommended Action Check your load balancing and network configuration to ensure that the number of load-balancing peers does not exceed the maximum allowed.

718003

Error Message `%ASA-6-718003: Got unknown peer message` *`message_number`* `from` *`IP_address`*`, local version` *`version_number`*`, remote version` *`version_number`*

Explanation An unrecognized load-balancing message was received from one of the load-balancing peers. This may indicate a version mismatch between peers, but is most likely caused by an internal software error.

Recommended Action Verify that all load-balancing peers are compatible. If they are and this condition persists or is linked to undesirable behavior, contact the Cisco TAC.

718004

Error Message `%ASA-6-718004: Got unknown internal message` *`message_number`*

Explanation An internal software error occurred.

Recommended Action This is generally a benign condition. If the problem persists, contact the Cisco TAC.

718005

Error Message %ASA-5-718005: Fail to send to *IP_address*, port *port*

Explanation An internal software error occurred during packet transmission on the load-balancing socket. This mght indicate a network problem.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718006

Error Message %ASA-5-718006: Invalid load balancing state transition [cur=*state_number*][event=*event_number*]

Explanation A state machine error has occurred. This might indicate an internal software error.

Recommended Action This is generally a benign condition. If the problem persists, contact the Cisco TAC.

718007

Error Message %ASA-5-718007: Socket open failure *failure_code*

Explanation An error occurred when the load-balancing socket tried to open. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718008

Error Message %ASA-5-718008: Socket bind failure *failure_code*

Explanation An error occurred when the ASA tried to bind to the load-balancing socket. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718009

Error Message `%ASA-5-718009: Send HELLO response failure to IP_address`

Explanation An error occurred when the ASA tried to send a hello response message to one of the load-balancing peers. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718010

Error Message `%ASA-5-718010: Sent HELLO response to IP_address`

Explanation The ASA transmitted a hello response message to a load-balancing peer.

Recommended Action None required.

718011

Error Message `%ASA-5-718011: Send HELLO request failure to IP_address`

Explanation An error occurred when the ASA tried to send a hello request message to one of the load-balancing peers. This may indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718012

Error Message `%ASA-5-718012: Sent HELLO request to IP_address`

Explanation The ASA transmitted a hello request message to a load-balancing peer.

Recommended Action None required.

718013

Error Message %ASA-6-718013: Peer *IP_address* is not answering HELLO

Explanation The load-balancing peer is not answering a hello request message.

Recommended Action Check the status of the load-balancing SSF peer and the network connections.

718014

Error Message %ASA-5-718014: Master peer *IP_address* is not answering HELLO

Explanation The load balancing master peer is not answering the hello request message.

Recommended Action Check the status of the load balancing SSF master peer and the network connections.

718015

Error Message %ASA-5-718015: Received HELLO request from *IP_address*

Explanation The ASA received a hello request message from the load balancing peer.

Recommended Action None required.

718016

Error Message %ASA-5-718016: Received HELLO response from *IP_address*

Explanation The ASA received a Hello Response packet from a load balancing peer.

Recommended Action None required.

718017

Error Message %ASA-7-718017: Got timeout for unknown peer *IP_address* msg type *message_type*

Explanation The ASA processed a timeout for an unknown peer. The message was ignored because the peer may have already been removed from the active list.

Recommended Action If the message persists or is linked to undesirable behavior, check the load balancing peers and verify that all are configured correctly.

718018

Error Message `%ASA-7-718018: Send KEEPALIVE request failure to IP_address`

Explanation An error has occurred while attempting to send a Keepalive Request message to one of the load balancing peers. This t indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718019

Error Message `%ASA-7-718019: Sent KEEPALIVE request to IP_address`

Explanation The ASA transmitted a Keepalive Request message to a load balancing peer.

Recommended Action None required.

718020

Error Message `%ASA-7-718020: Send KEEPALIVE response failure to IP_address`

Explanation An error has occurred while attempting to send a Keepalive Response message to one of the load balancing peers. This may indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718021

Error Message `%ASA-7-718021: Sent KEEPALIVE response to IP_address`

Explanation The ASA transmitted a Keepalive Response message to a load balancing peer.

Recommended Action None required.

718022

Error Message `%ASA-7-718022: Received KEEPALIVE request from IP_address`

Explanation The ASA received a Keepalive Request message from a load balancing peer.

Recommended Action None required.

718023

Error Message `%ASA-7-718023: Received KEEPALIVE response from IP_address`

Explanation The ASA received a Keepalive Response message from a load balancing peer.

Recommended Action None required.

718024

Error Message `%ASA-5-718024: Send CFG UPDATE failure to IP_address`

Explanation An error has occurred while attempting to send a Configuration Update message to one of the load balancing peers. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718025

Error Message `%ASA-7-718025: Sent CFG UPDATE to IP_address`

Explanation The ASA transmitted a Configuration Update message to a load balancing peer.

Recommended Action None required.

718026

Error Message `%ASA-7-718026: Received CFG UPDATE from IP_address`

Explanation The ASA received a Configuration Update message from a load balancing peer.

Recommended Action None required.

718027

Error Message `%ASA-6-718027: Received unexpected KEEPALIVE request from IP_address`

Explanation The ASA received an unexpected Keepalive request message from a load balancing peer.

Recommended Action If the problem persists or is linked with undesirable behavior, verify that all load balancing peers are configured and discovered correctly.

718028

Error Message `%ASA-5-718028: Send OOS indicator failure to IP_address`

Explanation An error has occurred while attempting to send an OOS indicator message to one of the load balancing peers. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA and verify that interfaces are active and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718029

Error Message `%ASA-7-718029: Sent OOS indicator to IP_address`

Explanation The ASA transmitted an OOS indicator message to a load balancing peer.

Recommended Action None required.

718030

Error Message `%ASA-6-718030: Received planned OOS from IP_address`

Explanation The ASA received a planned OOS message from a load balancing peer.

Recommended Action None required.

718031

Error Message %ASA-5-718031: Received OOS obituary for *IP_address*

Explanation The ASA received an OOS obituary message from a load balancing peer.

Recommended Action None required.

718032

Error Message %ASA-5-718032: Received OOS indicator from *IP_address*

Explanation The ASA received an OOS indicator message from a load balancing peer.

Recommended Action None required.

718033

Error Message %ASA-5-718033: Send TOPOLOGY indicator failure to *IP_address*

Explanation An error has occurred while attempting to send a Topology indicator message to one of the load balancing peers. This might indicate a network problem or an internal software error.

Recommended Action Check the network-based configuration on the ASA. and verify that interfaces are active, and protocol data is flowing through the ASA. If the problem persists, contact the Cisco TAC.

718034

Error Message %ASA-7-718034: Sent TOPOLOGY indicator to *IP_address*

Explanation The ASA sent a Topology indicator message to a load balancing peer.

Recommended Action None required.

718035

Error Message %ASA-7-718035: Received TOPOLOGY indicator from *IP_address*

Explanation The ASA received a Topology indicator message from a load balancing peer.

Recommended Action None required.

718036

Error Message `%ASA-7-718036: Process timeout for req-type type_value, exid exchange_ID, peer IP_address`

Explanation The ASA processed a peer timeout.

Recommended Action Verify that the peer should have been timed out. If not, check the load balancing peer configuration and the network connection between the peer and the ASA.

718037

Error Message `%ASA-6-718037: Master processed number_of_timeouts timeouts`

Explanation The ASA in the master role processed the specified number of peer timeouts.

Recommended Action Verify that the timeouts are legitimate. If not, check the peer load balancing configuration and the network connection between the peer and the ASA.

718038

Error Message `%ASA-6-718038: Slave processed number_of_timeouts timeouts`

Explanation The ASA in the slave role processed the specified number of peer timeouts.

Recommended Action Verify that the timeouts are legitimate. If not, check the peer load balancing configuration and the network connection between the peer and the ASA.

718039

Error Message `%ASA-6-718039: Process dead peer IP_address`

Explanation The ASA has detected a dead peer.

Recommended Action Verify that the dead peer detection is legitimate. If not, check the peer load balancing configuration and the network connection between the peer and the ASA.

718040

Error Message %ASA-6-718040: Timed-out exchange ID *exchange_ID* not found

Explanation The ASA has detected a dead peer, but the exchange ID is not recognized.

Recommended Action None required.

718041

Error Message %ASA-7-718041: Timeout [msgType=*type*] processed with no callback

Explanation The ASA has detected a dead peer, but a call back was not used in the processing.

Recommended Action None required.

718042

Error Message %ASA-5-718042: Unable to ARP for *IP_address*

Explanation The ASA experienced an ARP failure when attempting to contact a peer.

Recommended Action Verify that the network is operational and that all peers can communicate with each other.

718043

Error Message %ASA-5-718043: Updating/removing duplicate peer entry *IP_address*

Explanation The ASA found and is removing a duplicate peer entry.

Recommended Action None required.

718044

Error Message %ASA-5-718044: Deleted peer *IP_address*

Explanation The ASA is deleting a load balancing peer.

Recommended Action None required.

718045

Error Message `%ASA-5-718045: Created peer IP_address`

Explanation The ASA has detected a load balancing peer.

Recommended Action None required.

718046

Error Message `%ASA-7-718046: Create group policy policy_name`

Explanation The ASA has created a group policy to securely communicate with the load balancing peers.

Recommended Action None required.

718047

Error Message `%ASA-7-718047: Fail to create group policy policy_name`

Explanation The ASA experienced a failure when attempting to create a group policy for securing the communication between load balancing peers.

Recommended Action Verify that the load balancing configuration is correct.

718048

Error Message `%ASA-5-718048: Create of secure tunnel failure for peer IP_address`

Explanation The ASA experienced a failure when attempting to establish an IPsec tunnel to a load balancing peer.

Recommended Action Verify that the load balancing configuration is correct and that the network is operational.

718049

Error Message `%ASA-7-718049: Created secure tunnel to peer IP_address`

Explanation The ASA successfully established an IPsec tunnel to a load balancing peer.

Recommended Action None required.

718050

Error Message `%ASA-5-718050: Delete of secure tunnel failure for peer IP_address`

Explanation The ASA experienced a failure when attempting to terminate an IPsec tunnel to a load balancing peer.

Recommended Action Verify that the load balancing configuration is correct and that the network is operational.

718051

Error Message `%ASA-6-718051: Deleted secure tunnel to peer IP_address`

Explanation The ASA successfully terminated an IPsec tunnel to a load balancing peer.

Recommended Action None required.

718052

Error Message `%ASA-5-718052: Received GRAT-ARP from duplicate master MAC_address`

Explanation The ASA received a gratuitous ARP from a duplicate master.

Recommended Action Check the load balancing configuration and verify that the network is operational.

718053

Error Message `%ASA-5-718053: Detected duplicate master, mastership stolen MAC_address`

Explanation The ASA detected a duplicate master and a stolen master.

Recommended Action Check the load balancing configuration and verify that the network is operational.

718054

Error Message `%ASA-5-718054: Detected duplicate master` *`MAC_address`* `and going to SLAVE`

Explanation The ASA detected a duplicate master and is switching to slave mode.

Recommended Action Check the load balancing configuration and verify that the network is operational.

718055

Error Message `%ASA-5-718055: Detected duplicate master` *`MAC_address`* `and staying MASTER`

Explanation The ASA detected a duplicate master and is staying in slave mode.

Recommended Action Check the load balancing configuration and verify that the network is operational.

718056

Error Message `%ASA-7-718056: Deleted Master peer, IP` *`IP_address`*

Explanation The ASA deleted the load balancing master from its internal tables.

Recommended Action None required.

718057

Error Message `%ASA-5-718057: Queue send failure from ISR, msg type` *`failure_code`*

Explanation An internal software error has occurred while attempting to enqueue a message on the VPN load balancing queue from an Interrupt Service Routing.

Recommended Action This is generally a benign condition. If the problem persists, contact the Cisco TAC.

718058

Error Message %ASA-7-718058: State machine return code: *action_routine*, *return_code*

Explanation The return codes of action routines belonging to the load balancing finite state machine are being traced.

Recommended Action None required.

718059

Error Message %ASA-7-718059: State machine function trace: state=*state_name*, event=*event_name*, func=*action_routine*

Explanation The events and states of the load balancing finite state machine are being traced.

Recommended Action None required.

718060

Error Message %ASA-5-718060: Inbound socket select fail: context=*context_ID*.

Explanation The socket select call returned an error and the socket cannot be read. This might indicate an internal software error.

Recommended Action If the problem persists, contact the Cisco TAC.

718061

Error Message %ASA-5-718061: Inbound socket read fail: context=*context_ID*.

Explanation The socket read failed after data was detected through the select call. This might indicate an internal software error.

Recommended Action If the problem persists, contact the Cisco TAC.

718062

Error Message %ASA-5-718062: Inbound thread is awake (context=*context_ID*).

Explanation The load balancing process is awakened and begins processing.

Recommended Action None required.

718063

Error Message %ASA-5-718063: Interface *interface_name* is down.

Explanation The load balancing process found the interface down.

Recommended Action Check the interface configuration to make sure that the interface is operational.

718064

Error Message %ASA-5-718064: Admin. interface *interface_name* is down.

Explanation The load balancing process found the administrative interface down.

Recommended Action Check the administrative interface configuration to make sure that the interface is operational.

718065

Error Message %ASA-5-718065: Cannot continue to run (public=*up/down*, private=*up/down*, enable=*LB_state*, master=*IP_address*, session=*Enable/Disable*).

Explanation The load balancing process can not run because all prerequisite conditions have not been met. The prerequisite conditions are two active interfaces and load balancing enabled.

Recommended Action Check the interface configuration to make sure at least two interfaces are operational and load balancing is enabled.

718066

Error Message %ASA-5-718066: Cannot add secondary address to interface *interface_name*, ip *IP_address*.

Explanation Load balancing requires a secondary address to be added to the outside interface. A failure occurred in adding that secondary address.

Recommended Action Check the address being used as the secondary address and make sure that it is valid and unique. Check the configuration of the outside interface.

718067

Error Message `%ASA-5-718067: Cannot delete secondary address to interface interface_name, ip IP_address.`

Explanation The deletion of the secondary address failed, which might indicate an addressing problem or an internal software error.

Recommended Action Check the addressing information of the outside interface and make sure that the secondary address is valid and unique. If the problem persists, contact the Cisco TAC.

718068

Error Message `%ASA-5-718068: Start VPN Load Balancing in context context_ID.`

Explanation The load balancing process has been started and initialized.

Recommended Action None required.

718069

Error Message `%ASA-5-718069: Stop VPN Load Balancing in context context_ID.`

Explanation The load balancing process has been stopped.

Recommended Action None required.

718070

Error Message `%ASA-5-718070: Reset VPN Load Balancing in context context_ID.`

Explanation The LB process has been reset.

Recommended Action None required.

718071

Error Message `%ASA-5-718071: Terminate VPN Load Balancing in context context_ID.`

Explanation The LB process has been terminated.

Recommended Action None required.

718072

Error Message `%ASA-5-718072: Becoming master of Load Balancing in context context_ID.`

Explanation The ASA has become the LB master.

Recommended Action None required.

718073

Error Message `%ASA-5-718073: Becoming slave of Load Balancing in context context_ID.`

Explanation The ASA has become the LB slave.

Recommended Action None required.

718074

Error Message `%ASA-5-718074: Fail to create access list for peer context_ID.`

Explanation ACLs are used to create secure tunnels over which the LB peers can communicate. The ASA was unable to create one of these ACLs. This might indicate an addressing problem or an internal software problem.

Recommended Action Check the addressing information of the inside interface on all peers and ensure that all peers are discovered correctly. If the problem persists, contact the Cisco TAC.

718075

Error Message `%ASA-5-718075: Peer IP_address access list not set.`

Explanation While removing a secure tunnel, the ASA detected a peer entry that did not have an associated ACL.

Recommended Action None required.

718076

Error Message `%ASA-5-718076: Fail to create tunnel group for peer IP_address.`

Explanation The ASA experienced a failure when trying to create a tunnel group for securing the communication between load balancing peers.

Recommended Action Verify that the load balancing configuration is correct.

718077

Error Message `%ASA-5-718077: Fail to delete tunnel group for peer IP_address.`

Explanation The ASA experienced a failure when attempting to delete a tunnel group for securing the communication between load balancing peers.

Recommended Action None required.

718078

Error Message `%ASA-5-718078: Fail to create crypto map for peer IP_address.`

Explanation The ASA experienced a failure when attempting to create a crypto map for securing the communication between load balancing peers.

Recommended Action Verify that the load balancing configuration is correct.

718079

Error Message `%ASA-5-718079: Fail to delete crypto map for peer IP_address.`

Explanation The ASA experienced a failure when attempting to delete a crypto map for securing the communication between load balancing peers.

Recommended Action None required.

718080

Error Message `%ASA-5-718080: Fail to create crypto policy for peer IP_address.`

Explanation The ASA experienced a failure when attempting to create a transform set to be used in securing the communication between load balancing peers. This might indicate an internal software problem.

Recommended Action If the problem persists, contact the Cisco TAC.

718081

Error Message `%ASA-5-718081: Fail to delete crypto policy for peer IP_address.`

Explanation The ASA experienced a failure when attempting to delete a transform set used in securing the communication between load balancing peers.

Recommended Action None required.

718082

Error Message `%ASA-5-718082: Fail to create crypto ipsec for peer IP_address.`

Explanation When cluster encryption for VPN load balancing is enabled, the VPN load balancing device creates a set of site-to-site tunnels for every other device in the load balancing cluster. For each tunnel, a set of crypto parameters (access list, crypto maps, and transform set) is created dynamically. One or more crypto parameters failed to be created or configured.

- *IP_address*—The IP address of the remote peer

Recommended Action Examine the message for other entries specific to the type of crypto parameters that failed to be created.

718083

Error Message `%ASA-5-718083: Fail to delete crypto ipsec for peer IP_address.`

Explanation When the local VPN load balancing device is removed from the cluster, crypto parameters are removed. One or more crypto parameters failed to be deleted.

- *IP_address*—The IP address of the remote peer

Recommended Action Examine the message for other entries specific to the type of crypto parameters that failed to be deleted.

718084

Error Message `%ASA-5-718084: Public/cluster IP not on the same subnet: public IP_address, mask netmask, cluster IP_address`

Explanation The cluster IP address is not on the same network as the outside interface of the ASA.

Recommended Action Make sure that both the cluster (or virtual) IP address and the outside interface address are on the same network.

718085

Error Message `%ASA-5-718085: Interface interface_name has no IP address defined.`

Explanation The interface does not have an IP address configured.

Recommended Action Configure an IP address for the interface.

718086

Error Message `%ASA-5-718086: Fail to install LB NP rules: type rule_type, dst interface_name, port port.`

Explanation The ASA experienced a failure when attempting to create a SoftNP ACL rule to be used in securing the communication between load balancing peers. This may indicate an internal software problem.

Recommended Action If the problem persists, contact the Cisco TAC.

718087

Error Message `%ASA-5-718087: Fail to delete LB NP rules: type rule_type, rule rule_ID.`

Explanation The ASA experienced a failure when attempting to delete the SoftNP ACL rule used in securing the communication between load balancing peers.

Recommended Action None required.

718088

Error Message `%ASA-7-718088: Possible VPN LB misconfiguration. Offending device MAC MAC_address.`

Explanation The presence of a duplicate master indicates that one of the load balancing peers may be misconfigured.

Recommended Action Check the load balancing configuration on all peers, but pay special attention to the peer identified.

719001

Error Message `%ASA-6-719001: Email Proxy session could not be established: session limit of maximum_sessions has been reached.`

Explanation The incoming e-mail proxy session cannot be established because the maximum session limit has been reached.

- *maximum_sessions*—The maximum session number

Recommended Action None required.

719002

Error Message `%ASA-3-719002: Email Proxy session pointer from source_address has been terminated due to reason error.`

Explanation The session has been terminated because of an error. The possible errors are failure to add a session to the session database, failure to allocate memory, and failure to write data to a channel.

- *pointer*—The session pointer
- *source_address*—The e-mail proxy client IP address
- *reason*—The error type

Recommended Action None required.

719003

Error Message `%ASA-6-719003: Email Proxy session pointer resources have been freed for source_address.`

Explanation The dynamic allocated session structure has been freed and set to NULL after the session terminated.

- *pointer*—The session pointer

- *source_address*—The e-mail proxy client IP address

Recommended Action None required.

719004

Error Message `%ASA-6-719004: Email Proxy session pointer has been successfully established for source_address.`

Explanation A new incoming e-mail client session has been established.

Recommended Action None required.

719005

Error Message `%ASA-7-719005: FSM NAME has been created using protocol for session pointer from source_address.`

Explanation The FSM has been created for an incoming new session.

- *NAME*—The FSM instance name for the session
- *protocol*—The e-mail protocol type (for example, POP3, IMAP, and SMTP)
- *pointer*—The session pointer
- *source_address*–The e-mail proxy client IP address

Recommended Action None required.

719006

Error Message `%ASA-7-719006: Email Proxy session pointer has timed out for source_address because of network congestion.`

Explanation Network congestion is occurring, and data cannot be sent to either an e-mail client or an e-mail server. This condition starts the block timer. After the block timer is timed out, the session expires.

- *pointer*—The session pointer
- *source_address*–The e-mail proxy client IP address

Recommended Action Retry the operation after a few minutes.

719007

Error Message `%ASA-7-719007: Email Proxy session pointer cannot be found for source_address.`

Explanation A matching session cannot be found in the session database. The session pointer is bad.

- *pointer*—The session pointer
- *source_address*–The e-mail proxy client IP address

Recommended Action None required.

719008

Error Message `%ASA-3-719008: Email Proxy service is shutting down.`

Explanation The e-mail proxy is disabled. All resources are cleaned up, and all threads are terminated.

Recommended Action None required.

719009

Error Message `%ASA-7-719009: Email Proxy service is starting.`

Explanation The e-mail proxy is enabled.

Recommended Action None required.

719010

Error Message `%ASA-6-719010: protocol Email Proxy feature is disabled on interface interface_name.`

Explanation The e-mail proxy feature is disabled on a specific entry point, invoked from the CLI. This is the main off switch for the user. When all protocols are turned off for all interfaces, the main shut-down routine is invoked to clean up global resources and threads.

- *protocol*—The e-mail proxy protocol type (for example, POP3, IMAP, and SMTP)
- *interface_name* —The ASA interface name

Recommended Action None required.

719011

Error Message `%ASA-6-719011: Protocol Email Proxy feature is enabled on interface interface_name.`

Explanation The e-mail proxy feature is enabled on a specific entry point, invoked from the CLI. This is the main on switch for the user. When it is first used, the main startup routine is invoked to allocate global resources and threads. Subsequent calls only need to start listening threads for the particular protocol.

- *protocol*—The e-mail proxy protocol type (for example, POP3, IMAP, and SMTP)
- *interface_name* —The ASA interface name

Recommended Action None required.

719012

Error Message `%ASA-6-719012: Email Proxy server listening on port port for mail protocol protocol.`

Explanation A listening channel is opened for a specific protocol on a configured port and has added it to a TCP select group.

- *port*—The configured port number
- *protocol*—The e-mail proxy protocol type (for example, POP3, IMAP, and SMTP)

Recommended Action None required.

719013

Error Message `%ASA-6-719013: Email Proxy server closing port port for mail protocol protocol.`

Explanation A listening channel is closed for a specific protocol on a configured port and has removed it from the TCP select group.

- *port*—The configured port number
- *protocol*—The e-mail proxy protocol type (for example, POP3, IMAP, and SMTP)

Recommended Action None required.

719014

Error Message `%ASA-5-719014: Email Proxy is changing listen port from old_port to new_port for mail protocol protocol.`

Explanation A change is signaled in the listening port for the specified protocol. All enabled interfaces for that port have their listening channels closed and have restarted listening on the new port. This action is invoked from the CLI.

- *old_port*—The previously configured port number
- *new_port* —The newly configured port number
- *protocol*—The e-mail proxy protocol type (for example, POP3, IMAP, and SMTP)

Recommended Action None required.

719015

Error Message `%ASA-7-719015: Parsed emailproxy session pointer from source_address username: mailuser = mail_user, vpnuser = VPN_user, mailserver = server`

Explanation The username string is received from the client in the format vpnuser (name delimiter) mailuser (server delimiter) mailserver (for example: xxx:yyy@cisco.com). The name delimiter is optional. When the delimiter is not there, the VPN username and mail username are the same. The server delimiter is optional. When it is not present, the default configured mail server will be used.

- *pointer*—The session pointer
- *source_address*—The e-mail proxy client IP address
- *mail_user*—The e-mail account username
- *VPN_user*—The WebVPN username
- *server*—The e-mail server

Recommended Action None required.

719016

Error Message `%ASA-7-719016: Parsed emailproxy session pointer from source_address password: mailpass = ******, vpnpass= ******`

Explanation The password string is received from the client in the format, vpnpass (name delimiter) mailpass (for example: xxx:yyy). The name delimiter is optional. When it is not present, the VPN password and mail password are the same.

- *pointer*—The session pointer
- *source_address*—The e-mail proxy client IP address

Recommended Action None required.

719017

Error Message `%ASA-6-719017: WebVPN user: vpnuser invalid dynamic ACL.`

Explanation The WebVPN session is aborted because the ACL has failed to parse for this user. The ACL determines what the user restrictions are on e-mail account access. The ACL is downloaded from the AAA server. Because of this error, it is unsafe to proceed with login.

- *vpnuser*—The WebVPN username

Recommended Action Check the AAA server and fix the dynamic ACL for this user.

719018

Error Message `%ASA-6-719018: WebVPN user: vpnuser ACL ID acl_ID not found`

Explanation The ACL cannot be found at the local maintained ACL list. The ACL determines what the user restrictions are on e-mail account access. The ACL is configured locally. Because of this error, you cannot be authorized to proceed.

- *vpnuser*—The WebVPN username
- *acl_ID*—The local configured ACL identification string

Recommended Action Check the local ACL configuration.

719019

Error Message `%ASA-6-719019: WebVPN user: vpnuser authorization failed.`

Explanation The ACL determines what the user restrictions are on e-mail account access. The user cannot access the e-mail account because the authorization check fails.

- *vpnuser*—The WebVPN username

Recommended Action None required.

719020

Error Message `%ASA-6-719020: WebVPN user vpnuser authorization completed successfully.`

Explanation The ACL determines what the user restrictions are on e-mail account access. The user is authorized to access the e-mail account.

- *vpnuser*—The WebVPN username

Recommended Action None required.

719021

Error Message `%ASA-6-719021: WebVPN user: vpnuser is not checked against ACL.`

Explanation The ACL determines what the user restrictions are on e-mail account access. The authorization checking using the ACL is not enabled.

- *vpnuser*—The WebVPN username

Recommended Action Enable the ACL checking feature, if necessary.

719022

Error Message `%ASA-6-719022: WebVPN user vpnuser has been authenticated.`

Explanation The username is authenticated by the AAA server.

- *vpnuser*—The WebVPN username

Recommended Action None required.

719023

Error Message `%ASA-6-719023: WebVPN user vpnuser has not been successfully authenticated. Access denied.`

Explanation The username is denied by the AAA server. The session will be aborted. The user is not allowed to access the e-mail account.

- *vpnuser*—The WebVPN username

Recommended Action None required.

719024

Error Message `%ASA-6-719024: Email Proxy piggyback auth fail: session = pointer user=vpnuser addr=source_address`

Explanation The Piggyback authentication is using an established WebVPN session to verify the username and IP address matching in the WebVPN session database. This is based on the assumption that the WebVPN session and e-mail proxy session are initiated by the same user, and a WebVPN session is already established. Because the authentication has failed, the session will be aborted. The user is not allowed to access the e-mail account.

- *pointer*—The session pointer
- *vpnuser*—The WebVPN username

- *source_address*—The client IP address

Recommended Action None required.

719025

Error Message `%ASA-6-719025: Email Proxy DNS name resolution failed for hostname.`

Explanation The hostname cannot be resolved with the IP address because it is not valid, or no DNS server is available.

- *hostname*—The hostname that needs to be resolved

Recommended Action Check DNS server availability and whether or not the configured mail server name is valid.

719026

Error Message `%ASA-6-719026: Email Proxy DNS name hostname resolved to IP_address.`

Explanation The hostname has successfully been resolved with the IP address.

- *hostname*—The hostname that needs to be resolved
- *IP_address*—The IP address resolved from the configured mail server name

Recommended Action None required.

720001

Error Message `%ASA-4-720001: (VPN-unit) Failed to initialize with Chunk Manager.`

Explanation The VPN failover subsystem fails to initialize with the memory buffer management subsystem. A system-wide problem has occurred, and the VPN failover subsystem cannot be started.

- *unit*—Either Primary or Secondary

Recommended Action Examine the messages for any sign of system-level initialization problems.

720002

Error Message `%ASA-6-720002: (VPN-unit) Starting VPN Stateful Failover Subsystem...`

Explanation The VPN failover subsystem is starting and booting up.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720003

Error Message `%ASA-6-720003: (VPN-unit) Initialization of VPN Stateful Failover Component completed successfully`

Explanation The VPN failover subsystem initialization is completed at boot time.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720004

Error Message `%ASA-6-720004: (VPN-unit) VPN failover main thread started.`

Explanation The VPN failover main processing thread is started at boot time.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720005

Error Message `%ASA-6-720005: (VPN-unit) VPN failover timer thread started.`

Explanation The VPN failover timer processing thread is started at boot time.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720006

Error Message `%ASA-6-720006: (VPN-unit) VPN failover sync thread started.`

Explanation The VPN failover bulk synchronization processing thread is started at boot time.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720007

Error Message `%ASA-4-720007: (VPN-unit) Failed to allocate chunk from Chunk Manager.`

Explanation The set of preallocated memory buffers is running out. The ASA has a resource issue. The ASA may be under heavy load when too many messages are being processed.

- *unit*—Either Primary or Secondary

Recommended Action This condition may be improved later when the VPN failover subsystem processes outstanding messages and frees up previously allocated memory.

720008

Error Message `%ASA-4-720008: (VPN-unit) Failed to register to High Availability Framework.`

Explanation The VPN failover subsystem failed to register to the core failover subsystem. The VPN failover subsystem cannot be started, which may be caused by initialization problems of other subsystems.

- *unit*—Either Primary or Secondary

Recommended Action Search the message for any sign of system-wide initialization problems.

720009

Error Message `%ASA-4-720009: (VPN-unit) Failed to create version control block.`

Explanation The VPN failover subsystem failed to create a version control block. This step is required for the VPN failover subsystem to find out the backward compatible firmware versions for the current release. The VPN failover subsystem cannot be started, which may be caused by initialization problems of other subsystems.

- *unit*—Either Primary or Secondary

Recommended Action Search the message for any sign of system-wide initialization problems.

720010

Error Message `%ASA-6-720010: (VPN-unit) VPN failover client is being disabled`

Explanation An operator enabled failover without defining a failover key. In order to use a VPN failover, a failover key must be defined.

- *unit*—Either Primary or Secondary

Recommended Action Use the **failover key** command to define a shared secret key between the active and standby units.

720011

Error Message `%ASA-4-720011: (VPN-unit) Failed to allocate memory`

Explanation The VPN failover subsystem cannot allocate a memory buffer, which indicates a system-wide resource problem. The ASA may be under heavy load.

- *unit*—Either Primary or Secondary

Recommended Action This condition may be improved later when you reduce the load on the ASA by reducing incoming traffic. By reducing incoming traffic, memory allocated for processing the existing work load will be available, and the ASA may return to normal operation.

720012

Error Message `%ASA-6-720012: (VPN-unit) Failed to update IPsec failover runtime data on the standby unit.`

Explanation The VPN failover subsystem cannot update IPsec-related runtime data because the corresponding IPsec tunnel has been deleted on the standby unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720013

Error Message `%ASA-4-720013: (VPN-unit) Failed to insert certificate in trustpoint trustpoint_name`

Explanation The VPN failover subsystem tried to insert a certificate in the trustpoint.

- *unit*—Either Primary or Secondary
- *trustpoint_name*—The name of the trustpoint

Recommended Action Check the certificate content to determine if it is invalid.

720014

Error Message `%ASA-6-720014: (VPN-unit) Phase 2 connection entry (msg_id=message_number, my cookie=mine, his cookie=his) contains no SA list.`

Explanation No security association is linked to the Phase 2 connection entry.

- *unit*—Either Primary or Secondary
- *message_number*—The message ID of the Phase 2 connection entry
- *mine*—The My Phase 1 cookie
- *his*—The peer Phase 1 cookie

Recommended Action None required.

720015

Error Message `%ASA-6-720015: (VPN-unit) Cannot found Phase 1 SA for Phase 2 connection entry (msg_id=message_number,my cookie=mine, his cookie=his).`

Explanation The corresponding Phase 1 security association for the given Phase 2 connection entry cannot be found.

- *unit*—Either Primary or Secondary
- *message_number*—The message ID of the Phase 2 connection entry
- *mine*—The My Phase 1 cookie
- *his*—The peer Phase 1 cookie

Recommended Action None required.

720016

Error Message `%ASA-5-720016: (VPN-unit) Failed to initialize default timer #index.`

Explanation The VPN failover subsystem failed to initialize the given timer event. The VPN failover subsystem cannot be started at boot time.

- *unit*—Either Primary or Secondary
- *index*—The internal index of the timer event

Recommended Action Search the message for any sign of system-wide initialization problems.

720017

Error Message `%ASA-5-720017: (VPN-unit) Failed to update LB runtime data`

Explanation The VPN failover subsystem failed to update the VPN load balancing runtime data.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720018

Error Message `%ASA-5-720018: (VPN-unit) Failed to get a buffer from the underlying core high availability subsystem. Error code code.`

Explanation The ASA may be under heavy load. The VPN failover subsystem failed to obtain a failover buffer.

- *unit*—Either Primary or Secondary
- *code*—The error code returned by the high-availability subsystem

Recommended Action Decrease the amount of incoming traffic to improve the current load condition. With decreased incoming traffic, the ASA will free up memory allocated for processing the incoming load.

720019

Error Message `%ASA-5-720019: (VPN-unit) Failed to update cTCP statistics.`

Explanation The VPN failover subsystem failed to update the IPsec/cTCP-related statistics.

- *unit*—Either Primary or Secondary

Recommended Action None required. Updates are sent periodically, so the standby unit IPsec/cTCP statistics should be updated with the next update message.

720020

Error Message `%ASA-5-720020: (VPN-unit) Failed to send type timer message.`

Explanation The VPN failover subsystem failed to send a periodic timer message to the standby unit.

- *unit*—Either Primary or Secondary
- *type*—The type of timer message

Recommended Action None required. The periodic timer message will be resent during the next timeout.

720021

Error Message `%ASA-5-720021: (VPN-unit) HA non-block send failed for peer msg message_number. HA error code.`

Explanation The VPN failover subsystem failed to send a nonblock message. This is a temporary condition caused by the ASA being under load or out of resources.

- *unit*—Either Primary or Secondary
- *message_number*—The ID number of the peer message
- *code*—The error return code

Recommended Action The condition will improve as more resources become available to the ASA.

720022

Error Message `%ASA-4-720022: (VPN-unit) Cannot find trustpoint trustpoint`

Explanation An error occurred when the VPN failover subsystem tried to look up a trustpoint by name.

- *unit*—Either Primary or Secondary
- *trustpoint*—The name of the trustpoint.

Recommended Action The trustpoint may be deleted by an operator.

720023

Error Message `%ASA-6-720023: (VPN-unit) HA status callback: Peer is not present.`

Explanation The VPN failover subsystem is notified by the core failover subsystem when the local ASA detected that a peer is available or becomes unavailable.

- *unit*—Either Primary or Secondary
- *not*—Either “not” or left blank

Recommended Action None required.

720024

Error Message `%ASA-6-720024: (VPN-unit) HA status callback: Control channel is status.`

Explanation The failover control channel is either up or down. The failover control channel is defined by the **failover link** and **show failover** commands, which indicate whether the failover link channel is up or down.

- *unit*—Either Primary or Secondary
- *status*— Up or Down

Recommended Action None required.

720025

Error Message `%ASA-6-720025: (VPN-unit) HA status callback: Data channel is status.`

Explanation The failover data channel is up or down.

- *unit*—Either Primary or Secondary
- *status*—Up or Down

Recommended Action None required.

720026

Error Message `%ASA-6-720026: (VPN-unit) HA status callback: Current progression is being aborted.`

Explanation An operator or other external condition has occurred and has caused the current failover progression to abort before the failover peer agrees on the role (either active or standby). For example, when the **failover active** command is entered on the standby unit during the negotiation, or when the active unit is being rebooted.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720027

Error Message `%ASA-6-720027: (VPN-unit) HA status callback: My state state.`

Explanation The state of the local failover device is changed.

- *unit*—Either Primary or Secondary

- *state*—Current state of the local failover device

Recommended Action None required.

720028

Error Message `%ASA-6-720028: (VPN-unit) HA status callback: Peer state state.`

Explanation The current state of the failover peer is reported.

- *unit*—Either Primary or Secondary
- *state*—Current state of the failover peer

Recommended Action None required.

720029

Error Message `%ASA-6-720029: (VPN-unit) HA status callback: Start VPN bulk sync state.`

Explanation The active unit is ready to send all the state information to the standby unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720030

Error Message `%ASA-6-720030: (VPN-unit) HA status callback: Stop bulk sync state.`

Explanation The active unit finished sending all the state information to the standby unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720031

Error Message `%ASA-7-720031: (VPN-unit) HA status callback: Invalid event received. event=event_ID.`

Explanation The VPN failover subsystem received an invalid callback event from the underlying failover subsystem.

- *unit*—Either Primary or Secondary

- *event_ID*—The invalid event ID received

Recommended Action None required.

720032

Error Message `%ASA-6-720032: (VPN-unit) HA status callback: id=ID, seq=sequence_#, grp=group, event=event, op=operand, my=my_state, peer=peer_state.`

Explanation The VPN failover subsystem indicated that a status update was notified by the underlying failover subsystem.

- *unit*—Either Primary or Secondary
- *ID*—Client ID number
- *sequence_#*—Sequence number
- *group*—Group ID
- *event*—Current event
- *operand*—Current operand
- *my_state*—The system current state
- *peer_state*—The current state of the peer

Recommended Action None required.

720033

Error Message `%ASA-4-720033: (VPN-unit) Failed to queue add to message queue.`

Explanation System resources may be running low. An error occurred when the VPN failover subsystem tried to queue an internal message. This may be a temporary condition indicating that the ASA is under heavy load, and the VPN failover subsystem cannot allocate resource to handle incoming traffic.

- *unit*—Either Primary or Secondary

Recommended Action This error condition may disappear if the current load of the ASA is reduced, and additional system resources become available for processing new messages again.

720034

Error Message `%ASA-7-720034: (VPN-unit) Invalid type (type) for message handler.`

Explanation An error occurred when the VPN failover subsystem tried to process an invalid message type.

- *unit*—Either Primary or Secondary

- *type*—Message type

Recommended Action None required.

720035

Error Message `%ASA-5-720035: (VPN-unit) Fail to look up CTCP flow handle`

Explanation The cTCP flow may be deleted on the standby unit before the VPN failover subsystem tries to do a lookup.

- *unit*—Either Primary or Secondary

Recommended Action Look for any sign of cTCP flow deletion in the message to determine the reason (for example, idle timeout) why the flow was deleted.

720036

Error Message `%ASA-5-720036: (VPN-unit) Failed to process state update message from the active peer.`

Explanation An error occurred when the VPN failover subsystem tried to process a state update message received by the standby unit.

- *unit* - Either Primary or Secondary

Recommended Action None required. This may be a temporary condition because of the current load or low system resources.

720037

Error Message `%ASA-6-720037: (VPN-unit) HA progression callback: id=id,seq=sequence_number,grp=group,event=event,op=operand, my=my_state,peer=peer_state.`

Explanation The status of the current failover progression is reported.

- *unit*—Either Primary or Secondary
- *id*—Client ID
- *sequence_number*—Sequence number
- *group*—Group ID
- *event*—Current event
- *operand*—Current operand
- *my_state*—Current state of the ASA

- *peer_state*—Current state of the peer

Recommended Action None required.

720038

Error Message `%ASA-4-720038: (VPN-unit) Corrupted message from active unit.`

Explanation The standby unit received a corrupted message from the active unit. Messages from the active unit are corrupted, which may be caused by incompatible firmware running between the active and standby units. The local unit has become the active unit of the failover pair.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720039

Error Message `%ASA-6-720039: (VPN-unit) VPN failover client is transitioning to active state`

Explanation The local unit has become the active unit of the failover pair.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720040

Error Message `%ASA-6-720040: (VPN-unit) VPN failover client is transitioning to standby state.`

Explanation The local unit has become the standby unit of the failover pair.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720041

Error Message `%ASA-7-720041: (VPN-unit) Sending type message id to standby unit`

Explanation A message has been sent from the active unit to the standby unit.

- *unit*—Either Primary or Secondary
- *type*—Message type

- *id*—Identifier for the message

Recommended Action None required.

720042

Error Message `%ASA-7-720042: (VPN-unit) Receiving type message id from active unit`

Explanation A message has been received from the active unit by the standby unit.

- *unit*—Either Primary or Secondary
- *type*—Message type
- *id*—Identifier for the message

Recommended Action None required.

720043

Error Message `%ASA-4-720043: (VPN-unit) Failed to send type message id to standby unit`

Explanation An error occurred when the VPN failover subsystem tried to send a message from the active unit to the standby unit. The error may be caused by message 720018, in which the core failover subsystem runs out of failover buffer or the failover LAN link is down.

- *unit*—Either Primary or Secondary
- *type*—Message type
- *id*—Identifier for the message

Recommended Action Use the **show failover** command to see if the failover pair is running correctly and the failover LAN link is up.

720044

Error Message `%ASA-4-720044: (VPN-unit) Failed to receive message from active unit`

Explanation An error occurred when the VPN failover subsystem tried to receive a message on the standby unit. The error may be caused by a corrupted message or an inadequate amount of memory allocated for storing the incoming message.

- *unit*—Either Primary or Secondary

Recommended Action Use the **show failover** command and look for receive errors to determine if this is a VPN failover-specific problem or a general failover issue. Corrupted messages may be caused by incompatible firmware versions running on the active and standby units. Use the **show memory** command to determine if a low memory condition exists.

720045

Error Message `%ASA-6-720045: (VPN-unit) Start bulk syncing of state information on standby unit.`

Explanation The standby unit has been notified to start receiving bulk synchronization information from the active unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720046

Error Message `%ASA-6-720046: (VPN-unit) End bulk syncing of state information on standby unit`

Explanation The standby unit has been notified that bulk synchronization from the active unit is completed.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720047

Error Message `%ASA-4-720047: (VPN-unit) Failed to sync SDI node secret file for server IP_address on the standby unit.`

Explanation An error occurred when the VPN failover subsystem tried to synchronize a node secret file for the SDI server on the standby unit. The SDI node secret file is stored in flash. The error may indicate that the flash file system is full or corrupted.

- *unit*—Either Primary or Secondary
- *IP_address*—IP address of the server

Recommended Action Use the **dir** command to display the flash contents. The node secret file has the filename, *ip*.sdi.

720048

Error Message `%ASA-7-720048: (VPN-unit) FSM action trace begin: state=state, last event=event, func=function.`

Explanation A VPN failover subsystem finite state machine function has started.

- *unit*—Either Primary or Secondary

- *state*—Current state
- *event*—Last event
- *function*—Current executing function

Recommended Action None required.

720049

Error Message `%ASA-7-720049: (VPN-unit) FSM action trace end: state=state, last event=event, return=return, func=function.`

Explanation A VPN failover subsystem finite state machine function has finished.

- *unit*—Either Primary or Secondary
- *state*—Current state
- *event*—Last event
- *return*—Return code
- *function*—Current executing function

Recommended Action None required.

720050

Error Message `%ASA-7-720050: (VPN-unit) Failed to remove timer. ID = id.`

Explanation A timer cannot be removed from the timer processing thread.

- *unit*—Either Primary or Secondary
- *id*—Timer ID

Recommended Action None required.

720051

Error Message `%ASA-4-720051: (VPN-unit) Failed to add new SDI node secret file for server id on the standby unit.`

Explanation An error occurred when the VPN failover subsystem tried to add a node secret file for the SDI server on the standby unit. The SDI node secret file is stored in flash. The error may indicate that the flash file system is full or corrupted.

- *unit*—Either Primary or Secondary

- *id*—IP address of the SDI server

Recommended Action Use the **dir** command to display the flash contents. The node secret file has the filename, *ip*.sdi.

720052

Error Message `%ASA-4-720052: (VPN-unit) Failed to delete SDI node secret file for server id on the standby unit.`

Explanation An error occurred when the VPN failover subsystem tried to delete a node secret file on the active unit. The node secret file being deleted may not exist in the flash file system, or there was problem reading the flash file system.

- *unit*—Either Primary or Secondary
- *IP_address*—IP address of the SDI server

Recommended Action Use the **dir** command to display the flash contents. The node secret file has the filename, *ip*.sdi.

720053

Error Message `%ASA-4-720053: (VPN-unit) Failed to add cTCP IKE rule during bulk sync, peer=IP_address, port=port`

Explanation An error occurred when the VPN failover subsystem tried to load a cTCP IKE rule on the standby unit during bulk synchronization. The standby unit may be under heavy load, and the new IKE rule request may time out before completion.

- *unit*—Either Primary or Secondary
- *IP_address*—Peer IP address
- *port*—Peer port number

Recommended Action None required.

720054

Error Message `%ASA-4-720054: (VPN-unit) Failed to add new cTCP record, peer=IP_address, port=port.`

Explanation A cTCP record is replicated to the standby unit and cannot be updated. The corresponding IPsec over cTCP tunnel may not be functioning after failover. The cTCP database may be full, or a record with the same peer IP address and port number exists already.

- *unit*—Either Primary or Secondary
- *IP_address*—Peer IP address

- *port*—Peer port number

Recommended Action This may be a temporary condition and may improve when the existing cTCP tunnel is restored.

720055

Error Message `%ASA-4-720055: (VPN-unit) VPN Stateful failover can only be run in single/non-transparent mode.`

Explanation The VPN subsystem does not start unless it is running in single (nontransparent) mode.

- *unit*—Either Primary or Secondary

Recommended Action Configure the ASA for the appropriate mode to support VPN failover and restart the ASA.

720056

Error Message `%ASA-6-720056: (VPN-unit) VPN Stateful failover Message Thread is being disabled.`

Explanation The VPN failover subsystem main message processing thread is disabled when you have tried to enable failover, but a failover key is not defined. A failover key is required for VPN failover.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720057

Error Message `%ASA-6-720057: (VPN-unit) VPN Stateful failover Message Thread is enabled.`

Explanation The VPN failover subsystem main message processing thread is enabled when failover is enabled and a failover key is defined.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720058

Error Message `%ASA-6-720058: (VPN-unit) VPN Stateful failover Timer Thread is disabled.`

Explanation The VPN failover subsystem main timer processing thread is disabled when the failover key is not defined and failover is enabled.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720059

Error Message `%ASA-6-720059: (VPN-unit) VPN Stateful failover Timer Thread is enabled.`

Explanation The VPN failover subsystem main timer processing thread is enabled when the failover key is defined and failover is enabled.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720060

Error Message `%ASA-6-720060: (VPN-unit) VPN Stateful failover Sync Thread is disabled.`

Explanation The VPN failover subsystem main bulk synchronization processing thread is disabled when failover is enabled, but the failover key is not defined.

- *unit*—Either Primary or Secondary.

Recommended Action None required.

720061

Error Message `%ASA-6-720061: (VPN-unit) VPN Stateful failover Sync Thread is enabled.`

Explanation The VPN failover subsystem main bulk synchronization processing thread is enabled when failover is enabled and the failover key is defined.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720062

Error Message `%ASA-6-720062: (VPN-unit) Active unit started bulk sync of state information to standby unit.`

Explanation The VPN failover subsystem active unit has started bulk synchronization of state information to the standby unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720063

Error Message `%ASA-6-720063: (VPN-unit) Active unit completed bulk sync of state information to standby.`

Explanation The VPN failover subsystem active unit has completed bulk synchronization of state information to the standby unit.

- *unit*—Either Primary or Secondary

Recommended Action None required.

720064

Error Message `%ASA-4-720064: (VPN-unit) Failed to update cTCP database record for peer=IP_address, port=port during bulk sync.`

Explanation An error occurred while the VPN failover subsystem attempted to update an existing cTCP record during bulk synchronization. The cTCP record may have been deleted from the cTCP database on the standby unit and cannot be found.

- *unit*—Either Primary or Secondary
- *IP_address*—Peer IP address
- *port*—Peer port number

Recommended Action Search in the message.

720065

Error Message `%ASA-4-720065: (VPN-unit) Failed to add new cTCP IKE rule, peer=peer, port=port.`

Explanation An error occurred when the VPN failover subsystem tried to add a new IKE rule for the cTCP database entry on the standby unit. The ASA may be under heavy load, and the request for adding a cTCP IKE rule timed out and was never completed.

- *unit*—Either Primary or Secondary
- *IP_address*—Peer IP address
- *port*—Peer port number

Recommended Action This may be a temporary condition.

720066

Error Message `%ASA-4-720066: (VPN-unit) Failed to activate IKE database.`

Explanation An error occurred when the VPN failover subsystem tried to activate the IKE security association database while the standby unit was transitioning to the active state. There may be resource-related issues on the standby unit that prevent the IKE security association database from activating.

- *unit*—Either Primary or Secondary

Recommended Action Use the **show failover** command to see if the failover pair is still working correctly and/or look for other IKE-related errors in the message.

720067

Error Message `%ASA-4-720067: (VPN-unit) Failed to deactivate IKE database.`

Explanation An error occurred when the VPN failover subsystem tried to deactivate the IKE security association database while the active unit was transitioning to the standby state. There may be resource-related issues on the active unit that prevent the IKE security association database from deactivating.

- *unit*—Either Primary or Secondary

Recommended Action Use the **show failover** command to see if the failover pair is still working correctly and/or look for IKE-related errors in the message.

720068

Error Message `%ASA-4-720068: (VPN-unit) Failed to parse peer message.`

Explanation An error occurred when the VPN failover subsystem tried to parse a peer message received on the standby unit. The peer message received on the standby unit cannot be parsed.

- *unit*—Either Primary or Secondary

Recommended Action Make sure that both active and standby units are running the same version of firmware. Also, use the **show failover** command to ensure that the failover pair is still working correctly.

720069

Error Message `%ASA-4-720069: (VPN-unit) Failed to activate cTCP database.`

Explanation An error occurred when the VPN failover subsystem tried to activate the cTCP database while the standby unit was transitioning to the active state. There may be resource-related issues on the standby unit that prevent the cTCP database from activating.

- *unit*—Either Primary or Secondary

Recommended Action Use the **show failover** command to see if the failover pair is still working correctly and/or look for other cTCP related errors in the message.

720070

Error Message `%ASA-4-720070: (VPN-unit) Failed to deactivate cTCP database.`

Explanation An error occurred when the VPN failover subsystem tried to deactivate the cTCP database while the active unit was transitioning to the standby state. There may be resource-related issues on the active unit that prevent the cTCP database from deactivating.

- *unit*—Either Primary or Secondary.

Recommended Action Use the **show failover** command to see if the failover pair is still working correctly and/or look for cTCP related errors in the message.

720071

Error Message `%ASA-5-720071: (VPN-unit) Failed to update cTCP dynamic data.`

Explanation An error occurred while the VPN failover subsystem tried to update cTCP dynamic data.

- *unit*—Either Primary or Secondary.

Recommended Action This may be a temporary condition. Because this is a periodic update, wait to see if the same error recurs. Also, look for other failover-related messages in the message.

720072

Error Message `%ASA-5-720072: Timeout waiting for Integrity Firewall Server [interface,ip] to become available.`

Explanation The Zonelab Integrity Server cannot reestablish a connection before timeout. In an active/standby failover setup, the SSL connection between a Zonelab Integrity Server and the ASA needs to be reestablished after a failover.

- *interface*—The interface to which the Zonelab Integrity Server is connected
- *ip*—The IP address of the Zonelab Integrity Server

Recommended Action Check that the configuration on the ASA and the Zonelab Integrity Server match, and verify communication between the ASA and the Zonelab Integrity Server.

720073

Error Message `%ASA-4-720073: (VPN-unit) Fail to insert certificate in trustpoint trustpoint on the standby unit.`

Explanation An error occurred when the VPN failover subsystem tried to insert a certificate in the trustpoint. This error may be caused by invalid content of the certificate.

- *unit*—Either Primary or Secondary
- *trustpoint*—Name of the trustpoint

Recommended Action Use the **write standby** command on the active unit to replicate the certificate to the standby unit manually. Search in the message to see if there are any failover or PKI-related errors.

721001

Error Message `%ASA-6-721001: (device) WebVPN Failover SubSystem started successfully.(device) either WebVPN-primary or WebVPN-secondary.`

Explanation The WebVPN failover subsystem in the current failover unit, either primary or secondary, has been started successfully.

- *(device)*—Either the WebVPN primary or the WebVPN secondary device

Recommended Action None required.

721002

Error Message `%ASA-6-721002: (device) HA status change: event event, my state my_state, peer state peer.`

Explanation The WebVPN failover subsystem receives status notification from the core HA component periodically. The incoming event, the new state of the local ASA, and the new state of the failover peer are reported.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *event*—New HA event
- *my_state*—The new state of the local ASA
- *peer*—The new state of the peer

Recommended Action None required.

721003

Error Message `%ASA-6-721003: (device) HA progression change: event event, my state my_state, peer state peer.`

Explanation The WebVPN failover subsystem transitions from one state to another state based on the event notified by the core HA component. The incoming event, the new state of the local ASA, and the new state of the failover peer are being reported.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *event*—New HA event
- *my_state*—The new state of the local ASA
- *peer*—The new state of the peer

Recommended Action None required.

721004

Error Message `%ASA-6-721004: (device) Create access list list_name on standby unit.`

Explanation A WebVPN-specific access list is replicated from the active unit to the standby unit. A successful installation of the WebVPN access list on the standby unit has occurred.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—The access list name

Recommended Action None required.

721005

Error Message `%ASA-6-721005: (device) Fail to create access list list_name on standby unit.`

Explanation When a WebVPN-specific access list is installed on the active unit, a copy is installed on the standby unit. The access list failed to be installed on the standby unit. The access list may have existed on the standby unit already.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—Name of the access list that failed to install on the standby unit

Recommended Action Use the **show access-list** command on both the active and standby units. Compare the content of the output and determine whether there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721006

Error Message `%ASA-6-721006: (device) Update access list list_name on standby unit.`

Explanation The content of the access list has been updated on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN- econdary ASA
- *list_name*—Name of the access list that was updated

Recommended Action None required.

721007

Error Message `%ASA-4-721007: (device) Fail to update access list list_name on standby unit.`

Explanation An error occurred while the standby unit tried to update a WebVPN-specific access list. The access list cannot be located on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN-= secondary ASA
- *list_name*—Name of the access list that was not updated

Recommended Action Use a **show access-list** command on both the active and standby units. Compare the content of the output and determine whether or not there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721008

Error Message `%ASA-6-721008: (device) Delete access list list_name on standby unit.`

Explanation When a WebVPN-specific access list is removed from the active unit, a message is sent to the standby unit requesting that the same access list be removed. As a result, a WebVPN-specific access list has been removed from the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—Name of the access list that was removed

Recommended Action None required.

721009

Error Message `%ASA-6-721009: (device) Fail to delete access list list_name on standby unit.`

Explanation When a WebVPN-specific access list is removed on the active unit, a message is sent to the standby unit requesting the same access list be removed. An error condition occurred when an attempt was made to remove the corresponding access list on the standby unit. The access list did not exist on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—Name of the access list that was deleted

Recommended Action Use a **show access-list** command on both the active and standby units. Compare the content of the output and determine whether there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721010

Error Message `%ASA-6-721010: (device) Add access list rule list_name, line line_no on standby unit.`

Explanation When an access list rule is added to the active unit, the same rule is added on the standby unit. A new access list rule was added successfully on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—Name of the access list that was deleted
- *line_no*—Line number of the rule added to the access list

Recommended Action None required.

721011

Error Message `%ASA-4-721011: (device) Fail to add access list rule list_name, line line_no on standby unit.`

Explanation When an access list rule is added to the active unit, an attempt is made to add the same access list rule to the standby unit. An error occurred when an attempt is made to add a new access list rule to the standby unit. The same access list rule may exist on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *list_name*—Name of the access list that was deleted
- *line_no*—Line number of the rule added to the access list

Recommended Action Use a **show access-list** command on both the active and standby units. Compare the content of the output and determine if there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721012

Error Message `%ASA-6-721012: (device) Enable APCF XML file file_name on the standby unit.`

Explanation When an APCF XML file is installed on the active unit, an attempt is made to install the same file on the standby unit. An APCF XML file was installed successfully on the standby unit. Use the **dir** command on the standby unit to show that the XML file exists in the flash file system.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *file_name*—Name of the XML file on the flash file system

Recommended Action None required.

721013

Error Message `%ASA-4-721013: (device) Fail to enable APCF XML file file_name on the standby unit.`

Explanation When an APCF XML file is installed on the active unit, an attempt is made to install the same file on the standby unit. An APCF XML file failed to install on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *file_name*—Name of the XML file on the flash file system

Recommended Action Use a **dir** command on both the active and standby unit. Compare the directory listing and determine if there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721014

Error Message `%ASA-6-721014: (device) Disable APCF XML file file_name on the standby unit.`

Explanation When an APCF XML file is removed on the active unit, an attempt is made to remove the same file on the standby unit. An APCF XML file was removed from the standby unit successfully.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *file_name*—Name of the XML file on the flash file system

Recommended Action None required.

721015

Error Message `%ASA-4-721015: (device) Fail to disable APCF XML file file_name on the standby unit.`

Explanation When an APCF XML file is removed on the active unit, an attempt is made to remove the same file on the standby unit. An error occurred when an attempt was made to remove an APCF XML file from the standby unit. The file may not be installed on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *file_name*—Name of the XML file on the flash file system

Recommended Action Use a **show running-config webvpn** command to make sure the APCF XML file of interest is not enabled. As long as it is not enabled, you may ignore this message. Otherwise, try to disable the file by using the **no apcf *file_name*** command in the webvpn configuration submode.

721016

Error Message `%ASA-6-721016: (device) WebVPN session for client user user_name, IP ip_address has been created.`

Explanation A remote WebVPN user has logged in successfully and the login information has been installed on the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *user_name*—Name of the user
- *ip_address*—IP address of the remote user

Recommended Action None required.

721017

Error Message `%ASA-4-721017: (device) Fail to create WebVPN session for user user_name, IP ip_address.`

Explanation When a WebVPN user logs in to the active unit, the login information is replicated to the standby unit. An error occurred while replicating the login information to the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *user_name*—Name of the user
- *ip_address*—IP address of the remote user

Recommended Action Use the **show vpn-sessiondb detail webvpn** command for a regular WebVPN user, or the **show vpn-sessiondb detail svc** command for a WebVPN SVC user on both the active and standby units. Compare the entries and determine whether the same user session record appears on both ASAs. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

721018

Error Message `%ASA-6-721018: (device) WebVPN session for client user user_name, IP ip_address has been deleted.`

Explanation When a WebVPN user logs out on the active unit, a logout message is sent to the standby unit to remove the user session from the standby unit. A WebVPN user record was removed from the standby unit successfully.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *user_name*—Name of the user
- *ip_address*—IP address of the remote user

Recommended Action None required.

721019

Error Message `%ASA-4-721019: (device) Fail to delete WebVPN session for client user user_name, IP ip_address.`

Explanation When a WebVPN user logs out on the active unit, a logout message is sent to the standby unit to remove the user session from the standby unit. An error occurred when an attempt was made to remove a WebVPN user record from the standby unit.

- *(device)*—Either the WebVPN primary or the WebVPN secondary ASA
- *user_name*—Name of the user
- *ip_address*—IP address of the remote user

Recommended Action Use the **show vpn-sessiondb detail webvpn** command for a regular WebVPN user, or the **show vpn-sessiondb detail svc** command for a WebVPN SVC user on both the active and standby units. Check whether there is any discrepancy. Resynchronize the standby unit, if needed, by using the **write standby** command on the active unit.

722001

Error Message `%ASA-4-722001: IP IP_address Error parsing SVC connect request.`

Explanation The request from the SVC was invalid.

Recommended Action Research as necessary to determine if this error was caused by a defect in the SVC, an incompatible SVC version, or an attack against the device.

722002

Error Message `%ASA-4-722002: IP IP_address Error consolidating SVC connect request.`

Explanation There is not enough memory to perform the action.

Recommended Action Purchase more memory, upgrade the device, or reduce the load on the device.

722003

Error Message `%ASA-4-722003: IP IP_address Error authenticating SVC connect request.`

Explanation The user took too long to download and connect.

Recommended Action Increase the timeouts for session idle and maximum connect time.

722004

Error Message `%ASA-4-722004: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `Error responding to SVC connect request.`

Explanation There is not enough memory to perform the action.

Recommended Action Purchase more memory, upgrade the device, or reduce the load on the device.

722005

Error Message `%ASA-5-722005: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `Unable to update session information for SVC connection.`

Explanation There is not enough memory to perform the action.

Recommended Action Purchase more memory, upgrade the device, or reduce the load on the device.

722006

Error Message `%ASA-5-722006: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `Invalid address` *`IP_address`* `assigned to SVC connection.`

Explanation An invalid address was assigned to the user.

Recommended Action Verify and correct the address assignment, if possible. Otherwise, notify your network administrator or escalate this issue according to your security policy. For additional assistance, contact the Cisco TAC.

722007

Error Message `%ASA-3-722007: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/ERROR:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused

- *message*—A text message from the SVC

Recommended Action None required.

722008

Error Message `%ASA-3-722008: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/ERROR:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722009

Error Message `%ASA-3-722009: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/ERROR:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722010

Error Message `%ASA-5-722010: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/NOTICE:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722011

Error Message `%ASA-5-722011: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/NOTICE:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722012

Error Message `%ASA-5-722012: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/INFO:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout

- 17—Closed due to error
- 18—Closed due to rekey
- 1-15, 19-31—Reserved and unused

- *message*—A text message from the SVC

Recommended Action None required.

722013

Error Message `%ASA-6-722013: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/INFO:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722014

Error Message `%ASA-6-722014: Group` *`group`* `User` *`user-name`* `IP` *`IP_address`* `SVC Message:` *`type-num`*`/INFO:` *`message`*

Explanation The SVC issued a message.

- *type-num*— A number from 0 to 31 indicating a message type. Message types are as follows:
  - 0—Normal.
  - 16—Logout
  - 17—Closed due to error
  - 18—Closed due to rekey
  - 1-15, 19-31—Reserved and unused
- *message*—A text message from the SVC

Recommended Action None required.

722015

Error Message `%ASA-4-722015: Group group User user-name IP IP_address Unknown SVC frame type: type-num`

Explanation The SVC sent an invalid frame type to the device, which might be caused by an SVC version incompatibility.

- *type-num*—The number identifier of the frame type

Recommended Action Verify the SVC version.

722016

Error Message `%ASA-4-722016: Group group User user-name IP IP_address Bad SVC frame length: length expected: expected-length`

Explanation The expected amount of data was not available from the SVC, which might be caused by an SVC version incompatibility.

Recommended Action Verify the SVC version.

722017

Error Message `%ASA-4-722017: Group group User user-name IP IP_address Bad SVC framing: 525446, reserved: 0`

Explanation The SVC sent a badly framed datagram, which might be caused by an SVC version incompatibility.

Recommended Action Verify the SVC version.

722018

Error Message `%ASA-4-722018: Group group User user-name IP IP_address Bad SVC protocol version: version, expected: expected-version`

Explanation The SVC sent a version unknown to the device, which might be caused by an SVC version incompatibility.

Recommended Action Verify the SVC version.

722019

Error Message %ASA-4-722019: Group *group* User *user-name* IP *IP_address* Not enough data for an SVC header: *length*

Explanation The expected amount of data was not available from the SVC, which might be caused by an SVC version incompatibility.

Recommended Action Verify the SVC version.

722020

Error Message %ASA-3-722020: TunnelGroup *tunnel_group* GroupPolicy *group_policy* User *user-name* IP *IP_address* No address available for SVC connection

Explanation Address assignment failed for the AnyConnect session. No IP addresses are available.

- *tunnel_group*—The name of the tunnel group that the user was assigned to or used to log in
- *group_policy*—The name of the group policy that the user was assigned to
- *user-name*—The name of the user with which this message is associated
- *IP_address*—The public IP (Internet) address of the client machine

Recommended Action Check the configuration listed in the **ip local ip** command to see if enough addresses exist in the pools that have been assigned to the tunnel group and the group policy. Check the DHCP configuration and status. Check the address assignment configuration. Enable IPAA syslog messages to determine why the AnyConnect client cannot obtain an IP address.

722021

Error Message %ASA-3-722021: Group *group* User *user-name* IP *IP_address* Unable to start compression due to lack of memory resources

Explanation There is not enough memory to perform the action.

Recommended Action Purchase more memory, upgrade the device, or reduce the load on the device.

722022

Error Message %ASA-6-722022: Group *group-name* User *user-name* IP *addr* (TCP | UDP) connection established (with | without) compression

Explanation The TCP or UDP connection was established with or without compression.

Recommended Action None required.

722023

Error Message `%ASA-6-722023: Group group User user-name IP IP_address SVC connection terminated {with|without} compression`

Explanation The SVC terminated either with or without compression.

Recommended Action None required.

722024

Error Message `%ASA-6-722024: SVC Global Compression Enabled`

Explanation Subsequent SVC connections will be allowed to perform tunnel compression if SVC compression is enabled in the corresponding user or group configuration.

Recommended Action None required.

722025

Error Message `%ASA-6-722025: SVC Global Compression Disabled`

Explanation Subsequent SVC connections will not be allowed to perform tunnel compression.

Recommended Action None required.

722026

Error Message `%ASA-6-722026: Group group User user-name IP IP_address SVC compression history reset`

Explanation A compression error occurred. The SVC and the ASA corrected it.

Recommended Action None required.

722027

Error Message `%ASA-6-722027: Group group User user-name IP IP_address SVC decompression history reset`

Explanation A decompression error occurred. The SVC and the ASA corrected it.

Recommended Action None required.

722028

Error Message %ASA-5-722028: Group *group* User *user-name* IP *IP_address* Stale SVC connection closed.

Explanation An unused SVC connection was closed.

Recommended Action None required. However, the client may be having trouble connecting if multiple connections are established. The SVC log should be examined.

722029

Error Message %ASA-7-722029: Group *group* User *user-name* IP *IP_address* SVC Session Termination: Conns: *connections*, DPD Conns: *DPD_conns*, Comp resets: *compression_resets*, Dcmp resets: *decompression_resets*

Explanation The number of connections, reconnections, and resets that have occurred are reported. If *connections* is greater than 1 or the number of *DPD_conns*, *compression_resets,* or *decompression_resets* is greater than 0, it may indicate network reliability problems, which may be beyond the control of the ASA administrator. If there are many connections or DPD connections, the user may be having problems connecting and may experience poor performance.

- *connections*—The total number of connections during this session (one is normal)
- *DPD_conns*—The number of reconnections due to DPD
- *compression_resets*—The number of compression history resets
- *decompression_resets*—The number of decompression history resets

Recommended Action The SVC log should be examined. You may want to research and take appropriate action to resolve possible network reliability problems.

722030

Error Message %ASA-7-722030: Group *group* User *user-name* IP *IP_address* SVC Session Termination: In: *data_bytes* (+*ctrl_bytes*) bytes, *data_pkts* (+*ctrl_pkts*) packets, *drop_pkts* drops

Explanation End-of-session statistics are being recorded.

- *data_bytes*—The number of inbound (from SVC) data bytes
- *ctrl_bytes*—The number of inbound control bytes
- *data_pkts*—The number of inbound data packets
- *ctrl_pkts*—The number of inbound control packets
- *drop_pkts*—The number of inbound packets that were dropped

Recommended Action None required.

722031

Error Message `%ASA-7-722031: Group group User user-name IP IP_address SVC Session Termination: Out: data_bytes (+ctrl_bytes) bytes, data_pkts (+ctrl_pkts) packets, drop_pkts drops.`

Explanation End-of-session statistics are being recorded.

- *data_bytes*—The number of outbound (to SVC) data bytes
- *ctrl_bytes*—The number of outbound control bytes
- *data_pkts*—The number of outbound data packets
- *ctrl_pkts*—The number of outbound control packets
- *ctrl_pkts*—The number of outbound packets that were dropped

Recommended Action None required.

722032

Error Message `%ASA-5-722032: Group group User user-name IP IP_address New SVC connection replacing old connection.`

Explanation A new SVC connection is replacing an existing one. You may be having trouble connecting.

Recommended Action Examine the SVC log.

722033

Error Message `%ASA-5-722033: Group group User user-name IP IP_address First SVC connection established for SVC session.`

Explanation The first SVC connection was established for the SVC session.

Recommended Action None required.

722034

Error Message `%ASA-5-722034: Group group User user-name IP IP_address New SVC connection, no existing connection.`

Explanation A reconnection attempt has occurred. An SVC connection is replacing a previously closed connection. There is no existing connection for this session because the connection was already dropped by the SVC or the ASA. You may be having trouble connecting.

Recommended Action Examine the ASA log and SVC log.

722035

Error Message `%ASA-3-722035: Group group User user-name IP IP_address Transmitting large packet length (threshold +num).`

Explanation A large packet was sent to the client. The source of the packet may not be aware of the MTU of the client.

- *length*—The length of the large packet
- +*num*—The threshold

Recommended Action None required.

722036

Error Message `%ASA-3-722036: Group group User user-name IP IP_address Received large packet length (threshold +num).`

Explanation A large packet was sent to the client. The packets that were arriving on the ASA had the DF bit set, and the ASA was unable to fragment it.

- *length*—The length of the large packet
- +*num*—The threshold

Recommended Action Enter the **anyconnect ssl df-bit-ignore enable** command under the group policy to allow the ASA to fragment the packets arriving with the DF bit set.

722037

Error Message `%ASA-5-722037: Group group User user-name IP IP_address SVC closing connection: reason.`

Explanation An SVC connection was terminated for the given reason. This behavior may be normal, or you may be having trouble connecting.

- *reason*—The reason that the SVC connection was terminated

Recommended Action Examine the SVC log.

722038

Error Message `%ASA-5-722038: Group group-name User user-name IP IP_address SVC terminating session: reason.`

Explanation An SVC session was terminated for the given reason. This behavior may be normal, or you may be having trouble connecting.

- *reason*—The reason that the SVC session was terminated

Recommended Action Examine the SVC log if the reason for termination was unexpected.

722039

Error Message `%ASA-4-722039: Group group, User user, IP ip, SVC vpn-filter acl is an IPv6 ACL; ACL not applied.`

Explanation The type of ACL to be applied is incorrect. An IPv6 ACL has been configured as an IPv4 ACL through the **vpn-filter** command.

- *group*—The group policy name of the user
- *user*—The username
- *ip*—The public (not assigned) IP address of the user
- *acl*—The name of the invalid ACL

Recommended Action Validate the VPN filter and IPv6 VPN filter configurations on the ASA, and the filter parameters on the AAA (RADIUS) server. Make sure that the correct type of ACL is specified.

722040

Error Message `%ASA-4-722040: Group group, User user, IP ip, SVC 'ipv6-vpn-filter acl' is an IPv4 ACL; ACL not applied`

Explanation The type of ACL to be applied is incorrect. An IPv4 ACL has been configured as an IPv6 ACL through the **ipv6-vpn-filter** command.

- *group*—The group policy name of the user
- *user*—The username
- *ip*—The public (not assigned) IP address of the user
- *acl*—The name of the invalid ACL

Recommended Action Validate the VPN filter and IPv6 VPN filter configurations on the ASA and the filter parameters on the AAA (RADIUS) server. Make sure that the correct type of ACL is specified.

722041

Error Message `%ASA-4-722041: TunnelGroup tunnel_group GroupPolicy group_policy User username IP peer_address No IPv6 address available for SVC connection.`

Explanation An IPv6 address was not available for assignment to the remote SVC client.

- *n*—The SVC connection identifier

Recommended Action Augment or create an IPv6 address pool, if desired.

722042

Error Message `%ASA-4-722042: Group group User user IP ip Invalid Cisco SSL Tunneling Protocol version.`

Explanation An invalid SVC or AnyConnect client is trying to connect.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Validate that the SVC or AnyConnect client is compatible with the ASA.

722043

Error Message `%ASA-5-722043: Group group User user IP ip DTLS disabled: unable to negotiate cipher.`

Explanation The DTLS (UDP transport) cannot be established. The SSL encryption configuration was probably changed.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Revert the SSL encryption configuration. Make sure there is at least one block cipher (AES, DES, or 3DES) in the SSL encryption configuration.

722044

Error Message `%ASA-5-722044: Group` *`group`* `User` *`user`* `IP` *`ip`* `Unable to request` *`ver`* `address for SSL tunnel.`

Explanation An IP address cannot be requested because of low memory on the ASA.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect
- *ver*—Either IPv4 or IPv6, based on the IP address version being requested

Recommended Action Reduce the load on the ASA or add more memory.

722045

Error Message `%ASA-3-722045: Connection terminated: no SSL tunnel initialization data.`

Explanation Data to establish a connection is missing. This is a defect in the ASA software.

Recommended Action Contact the Cisco TAC for assistance.

722046

Error Message `%ASA-3-722046: Group` *`group`* `User` *`user`* `IP` *`ip`* `Session terminated: unable to establish tunnel.`

Explanation The ASA cannot set up connection parameters. This is a defect in the ASA software.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Contact the Cisco TAC for assistance.

722047

Error Message `%ASA-4-722047: Group group User user IP ip Tunnel terminated: SVC not enabled or invalid SVC image on the ASA.`

Explanation The user logged in via the web browser and tried to start the SVC or AnyConnect client. The SVC service is not enabled globally, or the SVC image is invalid or corrupted. The tunnel connection has been terminated, but the clientless connection remains.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Enable the SVC globally using the **svc enable** command. Validate the integrity of versions of the SVC images by reloading new images using the **svc image** command.

722048

Error Message `%ASA-4-722048: Group group User user IP ip Tunnel terminated: SVC not enabled for the user.`

Explanation The user logged in via the web browser, and tried to start the SVC or AnyConnect client. The SVC service is not enabled for this user. The tunnel connection has been terminated, but the clientless connection remains.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Enable the service for this user using the **group-policy** and **username** commands.

722049

Error Message `%ASA-4-722049: Group group User user IP ip Session terminated: SVC not enabled or invalid image on the ASA.`

Explanation The user logged in via the AnyConnect client. The SVC service is not enabled globally, or the SVC image is invalid or corrupted. The session connection has been terminated.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Enable the SVC globally using the **svc-enable** command. Validate the integrity and versions of the SVC images by reloading new images using the **svc image** command.

722050

Error Message `%ASA-4-722050: Group group User user IP ip Session terminated: SVC not enabled for the user.`

Explanation The user logged in through the AnyConnect client. The SVC service is not enabled for this user. The session connection has been terminated.

- *group*—The name of the group policy with which the user is trying to connect
- *user*—The name of the user who is trying to connect
- *ip*—The IP address of the user who is trying to connect

Recommended Action Enable the service for this user using the **group-policy** and **username** commands.

722051

Error Message `%ASA-6-722051: Group group-policy User username IP public-ip IPv4 Address assigned-ip IPv6 Address assigned-ip assigned to session`

Explanation The specified address has been assigned to the given user.

- *group-policy*—The group policy that allowed the user to gain access
- *username*—The name of the user
- *public-ip*—The public IP address of the connected client
- *assigned-ip*—The IPv4 or IPv6 address that is assigned to the client

Recommended Action None required.

722053

Error Message `%ASA-6-722053: Group g User u IP ip Unknown client user-agent connection.`

Explanation An unknown or unsupported SSL VPN client has connected to the ASA. Older clients include the Cisco SVC and the Cisco AnyConnect client earlier than Version 2.3.1.

- *g*—The group policy under which the user logged in
- *u*—The name of the user
- *ip*—The IP address of the client
- *user-agent*—The user agent (usually includes the version) received from the client

Recommended Action Upgrade to a supported Cisco SSL VPN client.

723001

Error Message `%ASA-6-723001: Group group-name, User user-name, IP IP_address: WebVPN Citrix ICA connection connection is up.`

Explanation The Citrix connection is up.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user
- *connection*—The Citrix connection identifier

Recommended Action None required.

723002

Error Message `%ASA-6-723002: Group group-name, User user-name, IP IP_address: WebVPN Citrix ICA connection connection is down.`

Explanation The Citrix connection is down.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user
- *connection*—The Citrix connection identifier

Recommended Action No action is required when the Citrix ICA connection is terminated intentionally by the client, the server, or the ASA administrator. However, if this is not the case, verify that the WebVPN session in which the Citrix ICA connection is set up is still active. If it is inactive, then receiving this message is normal. If the WebVPN session is still active, verify that the ICA client and Citrix server both work correctly and that there is no error displayed. If not, bring either or both up or respond to any error. If this message is still received, contact the Cisco TAC and provide the following information:

- Network topology
- Delay and packet loss
- Citrix server configuration
- Citrix ICA client information
- Steps to reproduce the problem
- Complete text of all associated messages

723003

Error Message `%ASA-7-723003: No memory for WebVPN Citrix ICA connection` *`connection`*`.`

Explanation The ASA is running out of memory. The Citrix connection was rejected.

- *connection*—The Citrix connection identifier

Recommended Action Verify that the ASA is working correctly. Pay special attention to memory and buffer usage. If the ASA is under heavy load, buy more memory and upgrade the ASA or reduce the load on the ASA. If the problem persists, contact the Cisco TAC.

723004

Error Message `%ASA-7-723004: WebVPN Citrix encountered bad flow control` *`flow`*`.`

Explanation The ASA encountered an internal flow control mismatch, which can be caused by massive data flow, such as might occur during stress testing or with a high volume of ICA connections.

Recommended Action Reduce ICA connectivity to the ASA. If the problem persists, contact the Cisco TAC.

723005

Error Message `%ASA-7-723005: No channel to set up WebVPN Citrix ICA connection.`

Explanation The ASA was unable to create a new channel for Citrix.

Recommended Action Verify that the Citrix ICA client and the Citrix server are still alive. If not, bring them back up and retest. Check the ASA load, paying special attention to memory and buffer usage. If the ASA is under heavy load, upgrade the ASA, add memory, or reduce the load. If the problem persists, contact the Cisco TAC.

723006

Error Message `%ASA-7-723006: WebVPN Citrix SOCKS errors.`

Explanation An internal Citrix SOCKS error has occurred on the ASA.

Recommended Action Verify that the Citrix ICA client is working correctly. In addition, check the network connection status between the Citrix ICA client and the ASA, paying attention to packet loss. Resolve any abnormal network conditions. If the problem persists, contact the Cisco TAC.

723007

Error Message `%ASA-7-723007: WebVPN Citrix ICA connection connection list is broken.`

Explanation The ASA internal Citrix connection list is broken.

- *connection*—The Citrix connection identifier

Recommended Action Verify that the ASA is working correctly, paying special attention to memory and buffer usage. If the ASA is under heavy load, upgrade the ASA, add memory, or reduce the load. If the problem persists, contact the Cisco TAC.

723008

Error Message `%ASA-7-723008: WebVPN Citrix ICA SOCKS Server server is invalid.`

Explanation An attempt was made to access a Citrix Socks server that does not exist.

- *server*—The Citrix server identifier

Recommended Action Verify that the ASA is working correctly. Note whether or not there is any memory or buffer leakage. If this issue occurs frequently, capture information about memory usage, network topology, and the conditions during which this message is received. Send this information to the Cisco TAC for review. Make sure that the WebVPN session is still up while this message is being received. If not, determine the reason that the WebVPN session is down. If the ASA is under heavy load, upgrade the ASA, add memory, or reduce the load. If the problem persists, contact the Cisco TAC.

723009

Error Message `%ASA-7-723009: Group group-name, User user-name, IP IP_address: WebVPN Citrix received data on invalid connection connection.`

Explanation Data was received on a Citrix connection that does not exist.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user
- *connection*—The Citrix connection identifier

Recommended Action The original published Citrix application connection was probably terminated, and the remaining active published applications lost connectivity. Restart all published applications to generate a new Citrix ICA tunnel. If the ASA is under heavy load, upgrade the ASA, add memory, or reduce the load. If the problem persists, contact the Cisco TAC.

723010

Error Message `%ASA-7-723010: Group group-name, User user-name, IP IP_address: WebVPN Citrix received closing channel channel for invalid connection connection.`

Explanation An abort was received on a nonexistent Citrix connection, which can be caused by massive data flow (such as stress testing) or a high volume of ICA connections, especially during network delay or packet loss.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user
- channel—The Citrix channel identifier
- *connection*—The Citrix connection identifier

Recommended Action Reduce the number of ICA connections to the ASA, obtain more memory for the ASA, or resolve the network problems.

723011

Error Message `%ASA-7-723011: Group group-name, User user-name, IP IP_address: WebVPN Citrix receives bad SOCKS socks message length msg-length. Expected length is exp-msg-length.`

Explanation The Citrix SOCKS message length is incorrect.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user

Recommended Action Verify that the Citrix ICA client is working correctly. In addition, check the network connection status between the ICA client and the ASA, paying attention to packet loss. After resolving any abnormal network conditions, if the problem still exists, contact the Cisco TAC.

723012

Error Message `%ASA-7-723012: Group group-name, User user-name, IP IP_address: WebVPN Citrix received bad SOCKS socks message format.`

Explanation The Citrix SOCKS message format is incorrect.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user

- *IP_address*—The IP address of the Citrix user

Recommended Action Verify that the Citrix ICA client is working correctly. In addition, check the network connection status between the ICA client and the ASA, paying attention to packet loss. After resolving any abnormal network conditions, if the problem still exists, contact the Cisco TAC.

723013

Error Message `%ASA-7-723013: WebVPN Citrix encountered invalid connection connection during periodic timeout.`

Explanation The ASA internal Citrix timer has expired, and the Citrix connection is invalid.

- *connection*—The Citrix connection identifier

Recommended Action Check the network connection between the Citrix ICA client and the ASA, and between the ASA and the Citrix server. Resolve any abnormal network conditions, especially delay and packet loss. Verify that the ASA works correctly, paying special attention to memory or buffer problems. If the ASA is under heavy load, obtain more memory, upgrade the ASA, or reduce the load. If the problem persists, contact the Cisco TAC.

723014

Error Message `%ASA-7-723014: Group group-name, User user-name, IP IP_address: WebVPN Citrix TCP connection connection to server server on channel channel initiated.`

Explanation The ASA internal Citrix Secure Gateway is connected to the Citrix server.

- *group-name*—The name of the Citrix group
- *user-name*—The name of the Citrix user
- *IP_address*—The IP address of the Citrix user
- *connection*—The connection name
- server—The Citrix server identifier
- channel—The Citrix channel identifier (hexadecimal)

Recommended Action None required.

724001

Error Message `%ASA-4-724001: Group group-name User user-name IP IP_address WebVPN session not allowed. Unable to determine if Cisco Secure Desktop was running on the client's workstation.`

Explanation The session was not allowed because an error occurred during processing of the CSD Host Integrity Check results on the ASA.

- *group-name*—The name of the group

- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Determine whether the client firewall is truncating long URLs. Uninstall CSD from the client and reconnect to the ASA.

724002

Error Message `%ASA-4-724002: Group group-name User user-name IP IP_address WebVPN session not terminated. Cisco Secure Desktop was not running on the client's workstation.`

Explanation CSD is not running on the client machine.

- *group-name*—The name of the group
- *user-name*—The name of the user
- *IP_address*—The IP address

Recommended Action Verify that the end user can install and run CSD on the client machine.

725001

Error Message `%ASA-6-725001 Starting SSL handshake with remote_device interface_name: IP_address/port for SSL_version session.`

Explanation The SSL handshake has started with the remote device.

- *remote_device*—Either the server or the client, depending on the device that initiated the connection
- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number
- *SSL_version*—The SSL version for the SSL handshake (SSLv3 or TLSv1)

Recommended Action None required.

725002

Error Message `%ASA-6-725002 Device completed SSL handshake with remote_device interface_name: IP_address/port`

Explanation The SSL handshake has completed successfully with the remote device.

- *remote_device*—Either the server or the client, depending on the device that initiated the connection

- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number

Recommended Action None required.

725003

Error Message `%ASA-6-725003 SSL client interface_name: IP_address/port request to resume previous session.`

Explanation The remote device is trying to resume a previous SSL session.

- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number

Recommended Action None required.

725004

Error Message `%ASA-6-725004 Device requesting certificate from SSL client interface_name: IP_address/port for authentication.`

Explanation The ASA has requested a client certificate for authentication.

- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number

Recommended Action None required.

725005

Error Message `%ASA-6-725005 SSL server interface_name: IP_address/port requesting our device certificate for authentication.`

Explanation The server has requested the certificate of the ASA for authentication.

- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number

Recommended Action None required.

725006

Error Message `%ASA-6-725006 Device failed SSL handshake with` *`remote_device interface_name`*`: IP_address/port`

Explanation The SSL handshake with the remote device has failed.

- *remote_device*—Either the server or the client, depending on the device that initiates the connection
- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IPv4 or IPv6 address
- *port*—The remote device IP port number

Recommended Action Look for syslog message 725014, which indicates the reason for the failure.

725007

Error Message `%ASA-6-725007 SSL session with` *`remote_device interface_name`*`: IP_address/port terminated.`

Explanation The SSL session has terminated.

- *remote_device*—Either the server or the client, depending on the device that initiates the connection
- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IP address
- *port*—The remote device IP port number

Recommended Action None required.

725008

Error Message `%ASA-7-725008 SSL client` *`interface_name`*`: IP_address/port proposes the following` *`number`* `cipher(s).`

Explanation The number of ciphers proposed by the remote SSL device are listed.

- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IP address
- *port*—The remote device IP port number
- *number*—The number of ciphers in the proposal

Recommended Action None required.

725009

Error Message `%ASA-7-725009 Device proposes the following number cipher(s) to SSL server interface_name: IP_address/port.`

Explanation The number of ciphers proposed to the SSL server are listed.

- *number*—The number of ciphers in the proposal
- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IP address
- *port*—The remote device IP port number

Recommended Action None required.

725010

Error Message `%ASA-7-725010 Device supports the following number cipher(s).`

Explanation The number of ciphers supported by the ASA for an SSL session are listed.

- *number*—The number of supported ciphers

Recommended Action None required.

725011

Error Message `%ASA-7-725011 Cipher[order]: cipher_name`

Explanation Always following messages 725008, 725009, and 725010, this message indicates the cipher name and its order of preference.

- *order*—The order of the cipher in the cipher list
- *cipher_name*—The name of the cipher from the cipher list

Recommended Action None required.

725012

Error Message `%ASA-7-725012 Device chooses cipher: cipher_name for SSL session with client interface_name:IP_address/port`

Explanation The cipher that was chosen by the Cisco device for the SSL session is listed.

- *cipher_name*—The name of the cipher from the cipher list
- *interface_name*—The interface that the SSL session is using

- *IP_address*—The remote device IP address
- *port*—The remote device IP port number

Recommended Action None required.

725013

Error Message `%ASA-7-725013 SSL Server interface_name:IP_address/port chooses cipher: cipher_name`

Explanation The cipher that was chosen by the server for the SSL session is identified.

- *cipher_name*—The name of the cipher from the cipher list
- *interface_name*—The interface that the SSL session is using
- *IP_address*—The remote device IP address
- *port*—The remote device IP port number

Recommended Action None required.

725014

Error Message `%ASA-7-725014 SSL lib error. Function: function Reason: reason`

Explanation The reason for failure of the SSL handshake is indicated.

- *function*—The function name where the failure is reported
- *reason*—The description of the failure condition

Recommended Action Include this message when reporting any SSL-related issue to the Cisco TAC.

725015

Error Message `%ASA-3-725015 Error verifying client certificate. Public key size in client certificate exceeds the maximum supported key size.`

Explanation The verification of an SSL client certificate failed because of an unsupported (large) key size.

Recommended Action Use client certificates with key sizes that are less than or equal to 4096 bits.

726001

Error Message `%ASA-6-726001: Inspected im_protocol im_service Session between Client im_client_1 and im_client_2 Packet flow from src_ifc:/sip/sport to dest_ifc:/dip/dport Action: action Matched Class class_map_id class_map_name`

Explanation An IM inspection was performed on an IM message and the specified criteria were satisfied. The configured action is taken.

- *im_protocol*—MSN IM or Yahoo IM
- *im_service*—The IM services, such as chat, conference, file transfer, voice, video, games, or unknown
- *im_client_1*, *im_client_2*—The client peers that are using the IM service in the session: *client_login_name* or "?"
- *src_ifc*—The source interface name
- *sip*—The source IP address
- *sport*—The source port
- *dest_ifc*—The destination interface name
- *dip*—The destination IP address
- *dport*—The destination port
- *action*—The action taken: reset connection, dropped connection, or received
- *class_map_id*—The matched class-map ID
- *class_map_name*—The matched class-map name

Recommended Action None required.

730001

Error Message `%ASA-7-730001 Group groupname, User username, IP ipaddr: VLAN MAPPING to VLAN vlanid`

Explanation VLAN mapping succeeded.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action None required.

730002

Error Message `%ASA-7-730002 Group groupname, User username, IP ipaddr: VLAN MAPPING to VLAN vlanid failed`

Explanation VLAN mapping failed.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action Verify that all the VLAN mapping-related configurations are correct, and that the VLAN ID is valid.

730003

Error Message `%ASA-7-730003: NACApp sets IP ipaddr VLAN to vlanid`

Explanation ASA receives an SNMP set message from NACApp to set the new VLAN ID for the session.

- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action None required

730004

Error Message `%ASA-6-730004: Group groupname User username IP ipaddr VLAN ID vlanid from AAA ignored.`

Explanation The VLAN ID received from AAA is different from the current one in use, and it is ignored for the current session.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action If the newly received VLAN ID must be used, then the current session needs to be torn down. Otherwise, no action is required.

730005

Error Message `%ASA-6-730005: Group groupname User username IP ipaddr VLAN ID vlanid from AAA is invalid.`

Explanation The VLAN ID received from AAA is invalid.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action Verify the VLAN ID configurations on the AAA server and ASA are both correct.

730006

Error Message `%ASA-7-730006: Group groupname, User username, IP ipaddr: is on NACApp AUTH VLAN vlanid.`

Explanation The session is under NACApp posture assessment.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action None required.

730007

Error Message `%ASA-7-73007: Group groupname, User username, IP ipaddr: changed VLAN to <%s> ID vlanid`

Explanation NACApp (Cisco NAC appliance) posture assessment is done with the session, the VLAN is changed from AUTH VLAN to a new VLAN.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- `%s`—A string
- *vlanid*— The VLAN ID that is used for the VLAN mapping session

Recommended Action None required.

730008

Error Message `%ASA-6-730008: Group groupname, User username, IP ipaddr, VLAN MAPPING timeout waiting NACApp.`

Explanation NACApp (Cisco NAC appliance) posture assessment takes longer than the timeout value configured.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session

Recommended Action Check the status of the NACApp setup.

730009

Error Message `%ASA-5-730009: Group groupname, User username, IP ipaddr, CAS casaddr, capacity exceeded, terminating connection.`

Explanation The load capacity of the NACApp (Cisco NAC appliance) CAS is exeeceded, the new incoming session that uses it is terminating.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *casaddr*—The IP Address of CAS (Clean Access Server)

Recommended Action Review and revise planning for how many groups, and which groups, are associated with the CAS to ensure that its load capacity is not exceeded.

730010

Error Message `%ASA-7-730010: Group groupname, User username, IP ipaddr, VLAN Mapping is enabled on VLAN vlanid.`

Explanation VLAN mapping is enabled in the session.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *vlanid*—The VLAN ID that is used for the VLAN mapping session

Recommended Action None required.

731001

Error Message `%ASA-6-731001: NAC policy added: name: policyname Type: policytype.`

Explanation A new NAC-policy has been added to the ASA.

- *policyname*—The NAC policy name
- *policytype*—The type of NAC policy

Recommended Action None required.

731002

Error Message `%ASA-6-731002: NAC policy deleted: name: policyname Type: policytype.`

Explanation A NAC policy has been removed from the ASA.

- *policyname*—The NAC policy name
- *policytype*—The type of NAC policy

Recommended Action None required.

731003

Error Message `%ASA-6-731003: nac-policy unused: name: policyname Type: policytype.`

Explanation The NAC policy is unused because there is an existing NAC policy with the same name, but a different type.

- *policyname*—The NAC policy name
- *policytype*—The type of NAC policy

Recommended Action If the new NAC policy must be used, the existing NAC policy must be removed first. Otherwise, no action is required.

732001

Error Message `%ASA-6-732001: Group groupname, User username, IP ipaddr, Fail to parse NAC-SETTINGS nac-settings-id, terminating connection.`

Explanation The ASA cannot apply the NAC settings because no memory is available.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session

- *nac-settings-id*— The ID that is used for the NAC filter

Recommended Action Upgrade the ASA memory. Resolve any errors in the log before this problem occurs. If the problem persists, contact the Cisco TAC.

732002

Error Message `%ASA-6-732002: Group groupname, User username, IP ipaddr, NAC-SETTINGS settingsid from AAA ignored, existing NAC-SETTINGS settingsid_inuse used instead.`

Explanation The NAC settings ID cannot be applied because there is a different one for the session.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *settingsid*— The settings ID, which should be a NAC policy name
- *settingsid_inuse*— The NAC settings ID that is currently in use

Recommended Action If the new NAC settings ID must be applied, then all the active sessions that use it must be torn down first. Otherwise, no action is required.

732003

Error Message `%ASA-6-732003: Group groupname, User username, IP ipaddr, NAC-SETTINGS nac-settings-id from AAA is invalid, terminating connection.`

Explanation The NAC settings received from AAA are invalid.

- *groupname*—The group name
- *username*—The username
- *ipaddr*—The IP address of this session
- *nac-settings-id*— The ID that is used for the NAC filter

Recommended Action Verify that the NAC settings configurations on the AAA server and ASA are both correct.

733100

Error Message `%ASA-4-733100: Object drop rate rate_ID exceeded. Current burst rate is rate_val per second, max configured rate is rate_val; Current average rate is rate_val per second, max configured rate is rate_val; Cumulative total count is total_cnt`

Explanation The specified object in the message has exceeded the specified burst threshold rate or average threshold rate. The object can be a drop activity of a host, TCP/UDP port, IP protocol, or various drops caused by potential attacks. The ASA may be under attack.

- *Object*—The general or particular source of a drop rate count, which might include the following:

  - Firewall

  - Bad pkts

  - Rate limit

  - DoS attck

  - ACL drop

  - Conn limit

  - ICMP attk

  - Scanning

  - SYN attck

  - Inspect

  - Interface

  (A citation of a particular interface object might take a number of forms. For example, you might see 80/HTTP, which would signify port 80, with the well-known protocol HTTP.)

- *rate_ID*—The configured rate that is being exceeded. Most objects can be configured with up to three different rates for different intervals.
- *rate_val*—A particular rate value.
- *total_cnt*—The total count since the object was created or cleared.

The following three examples show how these variables occur:

– For an interface drop caused by a CPU or bus limitation:

```
%ASA-4-733100: [Interface] drop rate 1 exceeded. Current burst rate is 1 per
second, max configured rate is 8000; Current average rate is 2030 per second, max
configured rate is 2000; Cumulative total count is 3930654."
```

– For a scanning drop caused by potential attacks:

```
ASA-4-733100: [Scanning] drop rate-1 exceeded. Current burst rate is 10 per
second_max configured rate is 10; Current average rate is 245 per second_max
configured rate is 5; Cumulative total count is 147409 (35 instances received)
```

– For bad packets caused by potential attacks:

```
%ASA-4-733100: [Bad pkts] drop rate 1 exceeded. Current burst rate is 0 per
second, max configured rate is 400; Current average rate is 760 per second, max
configured rate is 100; Cumulative total count is 1938933
```

– Because of the scanning rate configured and the **threat-detection rate scanning-rate 3600 average-rate 15** command:

```
%ASA-4-733100: [144.60.88.2] drop rate-2 exceeded. Current burst rate is 0 per
second, max configured rate is 8; Current average rate is 5 per second, max
configured rate is 4; Cumulative total count is 38086
```

Recommended Action Perform the following steps according to the specified object type that appears in the message:

1. If the object in the message is one of the following:

– Firewall
– Bad pkts
– Rate limit
– DoS attck
– ACL drop
– Conn limit
– ICMP attck
– Scanning
– SYN attck
– Inspect
– Interface

Check whether the drop rate is acceptable for the running environment.

2. Adjust the threshold rate of the particular drop to an appropriate value by using the **threat-detection rate** xxx command, where *xxx* is one of the following:

– acl-drop
– bad-packet-drop
– conn-limit-drop
– dos-drop
– fw-drop
– icmp-drop
– inspect-drop
– interface-drop
– scanning-threat
– syn-attack

3. If the object in the message is a TCP or UDP port, an IP address, or a host drop, check whether or not the drop rate is acceptable for the running environment.
4. Adjust the threshold rate of the particular drop to an appropriate value by using the **threat-detection rate bad-packet-drop** command.

Note If you do not want the drop rate exceed warning to appear, you can disable it by using the **no threat-detection basic-threat** command.

733101

Error Message `%ASA-4-733101: Object objectIP (is targeted|is attacking). Current burst rate is rate_val per second, max configured rate is rate_val; Current average rate is rate_val per second, max configured rate is rate_val; Cumulative total count is total_cnt.`

Explanation The ASA detected that a specific host (or several hosts in the same 1024-node subnet) is either scanning the network (attacking), or is being scanned (targeted).

- *object*—Attacker or target (a specific host or several hosts in the same 1024-node subnet)
- *objectIP*—The IP address of the scanning attacker or scanned target
- *rate_val*—A particular rate value
- *total_cnt*—The total count

The following two examples show how these variables occur:

```
%ASA-4-733101: Subnet 100.0.0.0 is targeted. Current burst rate is 200 per second, max
configured rate is 0; Current average rate is 0 per second, max configured rate is 0;
Cumulative total count is 2028.

%ASA-4-733101: Host 175.0.0.1 is attacking. Current burst rate is 200 per second, max
configured rate is 0; Current average rate is 0 per second, max configured rate is 0;
Cumulative total count is 2024
```

Recommended Action For the specific host or subnet, use the **show threat-detection statistics host ip-address ip-mask** command to check the overall situation and then adjust the threshold rate of the scanning threat to the appropriate value. After the appropriate value is determined, an optional action can be taken to shun those host attackers (not subnet attacker) by configuring the **threat-detection scanning-threat shun-host** command. You may specify certain hosts or object groups in the shun-host except list. For more information, see the CLI configuration guide. If scanning detection is not desirable, you can disable this feature by using the **no threat-detection scanning** command.

733102

Error Message `%ASA-4-733102:Threat-detection adds host %I to shun list`

Explanation A host has been shunned by the threat detection engine. When the **threat-detection scanning-threat shun** command is configured, the attacking hosts will be shunned by the threat detection engine.

- *%I*—A particular hostname

The following message shows how this command was implemented:

```
%ASA-4-733102: Threat-detection add host 11.1.1.40 to shun list
```

Recommended Action To investigate whether the shunned host is an actual attacker, use the **threat-detection statistics host ip-address** command. If the shunned host is not an attacker, you can remove the shunned host from the threat detection engine by using the **clear threat-detection shun ip address** command. To remove all shunned hosts from the threat detection engine, use the **clear shun** command.

If you receive this message because an inappropriate threshold rate has been set to trigger the threat detection engine, then adjust the threshold rate by using the **threat-detection rate scanning-threat rate-interval x average-rate y burst-rate z** command.

733103

Error Message `%ASA-4-733103: Threat-detection removes host %I from shun list`

Explanation A host has been shunned by the threat detection engine. When you use the **clear-threat-detection shun** command, the specified host will be removed from the shunned list.

- *%I*—A particular hostname

The following message shows how this command is implemented:

```
%ASA-4-733103: Threat-detection removes host 11.1.1.40 from shun list
```

Recommended Action None required.

733104

Error Message `%ASA-4-733104: TD_SYSLOG_TCP_INTERCEPT_AVERAGE_RATE_EXCEED`

Explanation The ASA is under Syn flood attack and protected by the TCP intercept mechanism, if the average rate for intercepted attacks exceeds the configured threshold. The message is showing which server is under attack and where the attacks are coming from.

Recommended Action Write an ACL to filter out the attacks.

733105

Error Message `%ASA-4-733105: TD_SYSLOG_TCP_INTERCEPT_BURST_RATE_EXCEED`

Explanation The ASA is under Syn flood attack and protected by the TCP intercept mechanism, if the burst rate for intercepted attacks exceeds the configured threshold. The message is showing which server is under attack and where the attacks are coming from.

Recommended Action Write an ACL to filter out the attacks.

734001

Error Message `%ASA-6-734001: DAP: User user, Addr ipaddr, Connection connection: The following DAP records were selected for this connection: DAP record names`

Explanation The DAP records that were selected for the connection are listed.

- *user*—The authenticated username
- *ipaddr*—The IP address of the remote client
- *connection*—The type of client connection, which can be one of the following:
  - IPsec
  - AnyConnect
  - Clientless (web browser)
  - Cut-Through-Proxy
  - L2TP
- *DAP record names*—The comma-separated list of the DAP record names

Recommended Action None required.

734002

Error Message `%ASA-5-734002: DAP: User user, Addr ipaddr: Connection terrminated by the following DAP records: DAP record names`

Explanation The DAP records that terminated the connection are listed.

- *user*—The authenticated username
- *ipaddr*—The IP address of the remote client
- *DAP record names*—The comma-separated list of the DAP record names

Recommended Action None required.

734003

Error Message `%ASA-7-734003: DAP: User name, Addr ipaddr: Session Attribute: attr name/value`

Explanation The AAA and endpoint session attributes that are associated with the connection are listed.

- *user*—The authenticated username
- *ipaddr*—The IP address of the remote client
- *attr/value*—The AAA or endpoint attribute name and value

Recommended Action None required.

734004

Error Message `%ASA-3-734004: DAP: Processing error: Code number`

Explanation A DAP processing error occurred.

- *number*—The internal error code

Recommended Action Provide the Cisco TAC with the message and information about the conditions that generated the error.

734005

Error Message `%ASA-6-734005: DAP: User user, Addr ip: Administrative Message: custom message`

Explanation DAP CheckAndMsg is configured to generate a custom message that is configured by the ASA administrator.

- *user*—The username being used for the connection
- *ip*—The IP address of the endpoint
- *custom message*—The custom message configured in CheckAndMsg

Recommended Action None required.

735001

Error Message `%ASA-1-735001 IPMI: Cooling Fan var1: OK`

Explanation A cooling fan has been restored to normal operation.

- *var1*—The device number markings

Recommended Action None required.

735002

Error Message `%ASA-1-735002 IPMI: Cooling Fan var1: Failure Detected`

Explanation A cooling fan has failed.

- *var1*—The device number markings

Recommended Action Perform the following steps:

1. Check for obstructions that would prevent the fan from rotating.
2. Replace the cooling fan.

3. If the problem persists, record the message as it appears and contact the Cisco TAC.

735003

Error Message `%ASA-1-735003 IPMI: Power Supply var1: OK`

Explanation A power supply has been restored to normal operation.

- *var1*—The device number markings

Recommended Action None required.

735004

Error Message `%ASA-1-735004 IPMI: Power Supply var1: Failure Detected`

Explanation AC power has been lost, or the power supply has failed.

- *var1*—The device number markings

Recommended Action Perform the following steps:

1. Check for AC power failure.
2. Replace the power supply.
3. If the problem persists, record the message as it appears and contact the Cisco TAC.

735005

Error Message `%ASA-1-735005 IPMI: Power Supply Unit Redundancy OK`

Explanation Power supply unit redundancy has been restored.

Recommended Action None required.

735006

Error Message `%ASA-1-735006 IPMI: Power Supply Unit Redundancy Lost`

Explanation A power supply failure occurred. Power supply unit redundancy has been lost, but the ASA is functioning normally with minimum resources. Any further failures will result in an ASA shutdown.

Recommended Action To regain full redundancy, perform the following steps:

1. Check for AC power failure.
2. Replace the power supply.

3. If the problem persists, record the message as it appears and contact the Cisco TAC.

735007

Error Message `%ASA-1-735007 IPMI: CPU var1: Temp: var2 var3, Critical`

Explanation The CPU has reached a critical temperature.

- *var1*—The device number markings
- *var2*—The temperature value
- *var3*—Temperature value units (C, F)

Recommended Action Record the message as it appears and contact the Cisco TAC.

735008

Error Message `%ASA-1-735008 IPMI: Chassis Ambient var1: Temp: var2 var3, Critical`

Explanation A chassis ambient temperature sensor has reached a critical level.

- *var1*—The device number markings
- *var2*—The temperature value
- *var3*—Temperature value units (C, F)

Recommended Action Record the message as it appears and contact the Cisco TAC.

735009

Error Message `%ASA-2-735009: IPMI: Environment Monitoring has failed initialization and configuration. Environment Monitoring is not running.`

Explanation Environment monitoring has experienced a fatal error during initialization and was unable to continue.

Recommended Action Collect the output of the **show environment** and **debug ipmi** commands. Record the message as it appears and contact the Cisco TAC.

735010

Error Message `%ASA-3-735010: IPMI: Environment Monitoring has failed to update one or more of its records.`

Explanation Environment monitoring has experienced an error that temporarily prevented it from updating one or more of its records.

Recommended Action If this message appears repeatedly, collect the output from the **show environment driver** and **debug ipmi** commands. Record the message as it appears and contact the Cisco TAC.

735011

Error Message `%ASA-1-735011: Power Supply var1: Fan OK`

Explanation The power supply fan has returned to a working operating state.

- *var1*— Fan number

Recommended Action None required.

735012

Error Message `%ASA-1-735012: Power Supply var1: Fan Failure Detected`

Explanation The power supply fan has failed.

- *var1*— Fan number

Recommended Action Contact Cisco TAC to troubleshoot the failure. Power down the unit until this failure is resolved.

735013

Error Message `%ASA-1-735013: Voltage Channel var1: Voltage OK`

Explanation A voltage channel has returned to a normal operating level.

- *var1*— Voltage channel number

Recommended Action None required.

735014

Error Message `%ASA-1-735014: Voltage Channel var1: Voltage Critical`

Explanation A voltage channel has changed to a critical level.

- *var1*— Voltage channel number

Recommended Action Contact Cisco TAC to troubleshoot the failure. Power down the unit until this failure is resolved.

735015

Error Message `%ASA-4-735015: CPU var1: Temp: var2 var3, Warm`

Explanation The CPU temperature is warmer than the normal operating range.

- *var1*—CPU Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action Continue to monitor this component to ensure that it does not reach a critical temperature.

735016

Error Message `%ASA-4-735016: Chassis Ambient var1: Temp: var2 var3, Warm`

Explanation The chassis temperature is warmer than the normal operating range.

- *var1*—Chassis Sensor Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action Continue to monitor this component to ensure that it does not reach a critical temperature.

735017

Error Message `%ASA-1-735017: Power Supply var1: Temp: var2 var3, OK`

Explanation The power supply temperature has returned to a normal operating temperature.

- *var1*—Power Supply Number
- *var2*—Temperature Value

- *var3*—Units

Recommended Action None required.

735018

Error Message `%ASA-4-735018: Power Supply var1: Temp: var2 var3, Critical`

Explanation The power supply has reached a critical operating temperature.

- *var1*—Power Supply Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action Contact Cisco TAC to troubleshoot the failure. Power down the unit until this failure is resolved.

735019

Error Message `%ASA-4-735019: Power Supply var1: Temp: var2 var3, Warm`

Explanation The power supply temperature is warmer than the normal operating range.

- *var1*—Power Supply Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action Continue to monitor this component to ensure that it does not reach a critical temperature.

735020

Error Message `%ASA-1-735020: CPU var1: Temp: var2 var3 OK`

Explanation The CPU temperature has returned to the normal operating temperature.

- *var1*—CPU Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action None required.

735021

Error Message `%ASA-1-735021: Chassis var1: Temp: var2 var3 OK`

Explanation The chassis temperature has returned to the normal operating temperature.

- *var1*—Chassis Sensor Number
- *var2*—Temperature Value
- *var3*—Units

Recommended Action None required.

735022

Error Message `%ASA-1-735022: CPU# is running beyond the max thermal operating temperature and the device will be shutting down immediately to prevent permanent damage to the CPU.`

Explanation The ASA has detected a CPU running beyond the maximum thermal operating temperature, and will shut down immediately after detection.

Recommended Action The chassis and CPU need to be inspected immediately for ventilation issues.

735023

Error Message `%ASA-2-735023: ASA was previously shutdown due to the CPU complex running beyond the maximum thermal operating temperature. The chassis needs to be inspected immediately for ventilation issues.`

Explanation At boot time, the ASA detected a shutdown that occurred because a CPU was running beyond the maximum safe operating temperature. Using the **show environment** command will indicate that this event has occurred.

Recommended Action The chassis need to be inspected immediately for ventilation issues.

735024

Error Message `%ASA-1-735024: IO Hub var1: Temp: var2 var3, OK`

Explanation The IO hub temperature has returned to the normal operating temperature.

- *ar1* - IO hub number
- *var2* - Temperature value

- *var3* – Units

Recommended Action None required.

735025

Error Message `%ASA-1-735025: IO Hub var1: Temp: var2 var3, Critical`

Explanation The IO hub temperature has a critical temperature.

- *ar1* - IO hub number
- *var2* - Temperature value
- *var3* – Units

Recommended Action Record the message as it appears and contact the Cisco TAC.

735026

Error Message `%ASA-4-735026: IO Hub var1: Temp: var2 var3, Warm`

Explanation The IO hub temperature is warmer than the normal operating range.

- *ar1* - IO hub number
- *var2* - Temperature value
- *var3* – Units

Recommended Action Continue to monitor this component to ensure that it does not reach a critical temperature.

735027

Error Message `%ASA-1-735027: CPU cpu_num Voltage Regulator is running beyond the max thermal operating temperature and the device will be shutting down immediately. The chassis and CPU need to be inspected immediately for ventilation issues.`

Explanation The ASA has detected a CPU voltage regulator running beyond the maximum thermal operating temperature, and shuts down immediately after detection.

- *cpu_num*—The number to identify which CPU voltage regulator experienced the thermal event

Recommended Action The chassis and CPU need to be inspected immediately for ventilation issues.

735028

Error Message `%ASA-2-735028: ASA was previously shutdown due to a CPU Voltage Regulator running beyond the max thermal operating temperature. The chassis and CPU need to be inspected immediately for ventilation issues.`

Explanation At boot time, the ASA detected a shutdown that occurred because of a CPU voltage regulator running beyond the maximum safe operating temperature. Enter the **show environment** command to indicate that this event has occurred.

Recommended Action The chassis and CPU need to be inspected immediately for ventilation issues.

735029

Error Message `%ASA-1-735029: IO Hub is running beyond the max thermal operating temperature and the device will be shutting down immediately to prevent permanent damage to the circuit.`

Explanation The ASA has detected that the IO hub is running beyond the maximum thermal operating temperature, and will shut down immediately after detection.

Recommended Action The chassis and IO hub need to be inspected immediately for ventilation issues.

736001

Error Message `%ASA-2-736001: Unable to allocate enough memory at boot for jumbo-frame reservation. Jumbo-frame support has been disabled.`

Explanation Insufficient memory has been detected when jumbo frame support was being configured. As a result, jumbo-frame support was disabled.

Recommended Action Try reenabling jumbo frame support using the **jumbo-frame reservation** command. Save the running configuration and reboot the ASA. If the problem persists, contact the Cisco TAC.

737001

Error Message `%ASA-7-737001: IPAA: Received message` *`message-type`*

Explanation The IP address assignment process received a message.

- *message-type*—The message received by the IP address assignment process

Recommended Action None required.

737002

Error Message `%ASA-3-737002: IPAA: Received unknown message num variables`

Explanation The IP address assignment process received a message.

- *num*—The identifier of the message received by the IP address assignment process

Recommended Action None required.

737003

Error Message `%ASA-5-737003: IPAA: DHCP configured, no viable servers found for tunnel-group tunnel-group`

Explanation The DHCP server configuration for the given tunnel group is not valid.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action Validate the DHCP configuration for the tunnel group. Make sure that the DHCP server is online.

737004

Error Message `%ASA-5-737004: IPAA: DHCP configured, request failed for tunnel-group 'tunnel-group'`

Explanation The DHCP server configuration for the given tunnel group is not valid.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action Validate the DHCP configuration for the tunnel group. Make sure that the DHCP server is online.

737005

Error Message `%ASA-6-737005: IPAA: DHCP configured, request succeeded for tunnel-group tunnel-group`

Explanation The DHCP server request has succeeded.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action None required.

737006

Error Message `%ASA-6-737006: IPAA: Local pool request succeeded for tunnel-group tunnel-group`

Explanation The local pool request has succeeded.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action None required.

737007

Error Message `%ASA-5-737007: IPAA: Local pool request failed for tunnel-group tunnel-group`

Explanation The local pool request has failed. The pool assigned to the tunnel group may be exhausted.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action Validate the IP local pool configuration by using the **show ip local pool** command.

737008

Error Message `%ASA-5-737008: IPAA: 'tunnel-group' not found`

Explanation The tunnel group was not found when trying to acquire an IP address for configuration. A software defect may cause this message to be generated.

- *tunnel-group*—The tunnel group that IP address assignment is using for configuration

Recommended Action Check the tunnel group configuration. Contact the Cisco TAC and report the issue.

737009

Error Message `%ASA-6-737009: IPAA: AAA assigned address ip-address, request failed`

Explanation The remote access client software requested the use of a particular address. The request to the AAA server to use this address failed. The address may be in use.

- *ip-address*—The IPv4 or IPv6 address that the client requested

Recommended Action Check the AAA server status and the status of IP local pools.

737010

Error Message `%ASA-6-737010: IPAA: AAA assigned address ip-address, request succeeded`

Explanation The remote access client software requested the use of a particular address and successfully received this address.

- *ip-address*—The IPv4 or IPv6 address that the client requested

Recommended Action None required.

737011

Error Message `%ASA-5-737011: IPAA: AAA assigned ip-address, not permitted, retrying`

Explanation The remote access client software requested the use of a particular address. The **vpn-addr-assign aaa** command is not configured. An alternatively configured address assignment method will be used.

- *ip-address*—The IPv4 or IPv6 address that the client requested

Recommended Action If you want to permit clients to specify their own address, enable the **vpn-addr-assign aaa** command.

737012

Error Message `%ASA-4-737012: IPAA: Address assignment failed`

Explanation The remote access client software request of a particular address failed.

- *ip-address*—The IP address that the client requested

Recommended Action If using IP local pools, validate the local pool configuration. If using AAA, validate the configuration and status of the AAA server. If using DHCP, validate the configuration and status of the DHCP server. Increase the logging level (use notification or informational) to obtain additional messages to identify the reason for the failure.

737013

Error Message `%ASA-4-737013: IPAA: Error freeing address ip-address, not found`

Explanation The ASA tried to free an address, but it was not on the allocated list because of a recent configuration change.

- *ip-address*—The IPv4 or IPv6 address to be released

Recommended Action Validate your address assignment configuration. If this message recurs, it might be due to a software defect. Contact the Cisco TAC and report the issue.

737014

Error Message `%ASA-6-737014: IPAA: Freeing AAA address ip-address`

Explanation The ASA successfully released the IP address assigned through AAA.

- *ip-address*—The IPv4 or IPv6 address to be released

Recommended Action None required.

737015

Error Message `%ASA-6-737015: IPAA: Freeing DHCP address ip-address`

Explanation The ASA successfully released the IP address assigned through DHCP.

- *ip-address*—The IP address to be released

Recommended Action None required.

737016

Error Message `%ASA-6-737016: IPAA: Freeing local pool address ip-address`

Explanation The ASA successfully released the IP address assigned through local pools.

- *ip-address*—The IPv4 or IPv6 address to be released

Recommended Action None required.

737017

Error Message `%ASA-6-737017: IPAA: DHCP request attempt num succeeded`

Explanation The ASA successfully sent a request to a DHCP server.

- *num*—The attempt number

Recommended Action None required.

737018

Error Message `%ASA-5-737018: IPAA: DHCP request attempt num failed`

Explanation The ASA failed to send a request to a DHCP server.

- *num*—The attempt number

Recommended Action Validate the DHCP configuration and connectivity to the DHCP server.

737019

Error Message `%ASA-4-737019: IPAA: Unable to get address from group-policy or tunnel-group local pools`

Explanation The ASA failed to acquire an address from the local pools configured on the group policy or tunnel group. The local pools may be exhausted.

Recommended Action Validate the local pool configuration and status. Validate the group policy and tunnel group configuration of local pools.

737023

Error Message `%ASA-5-737023: IPAA: Unable to allocate memory to store local pool address ip-address`

Explanation The ASA is low on memory.

- *ip-address*—The IP address that was acquired

Recommended Action The ASA may be overloaded and need more memory, or there may be a memory leak caused by a software defect. Contact the Cisco TAC and report the issue.

737024

Error Message `%ASA-5-737024: IPAA: Client requested address ip-address, already in use, retrying`

Explanation The client requested an IP address that is already in use. The request will be tried using a new IP address.

- *ip-address*—The IP address that the client requested

Recommended Action None required.

737025

Error Message `%ASA-5-737025: IPAA: Duplicate local pool address found, ip-address in quarantine`

Explanation The IP address that was to be given to the client is already in use. The IP address has been removed from the pool and will not be reused.

- *ip-address*—The IP address that was acquired

Recommended Action Validate the local pool configuration; there may be an overlap caused by a software defect. Contact the Cisco TAC and report the issue.

737026

Error Message `%ASA-6-737026: IPAA: Client assigned ip-address from local pool`

Explanation The client has assigned the given address from a local pool.

- *ip-address*—The IP address that was assigned to the client

Recommended Action None required.

737027

Error Message `%ASA-3-737027: IPAA: No data for address request`

Explanation A software defect has been found.

Recommended Action Contact the Cisco TAC and report the issue.

737028

Error Message `%ASA-4-737028: IPAA: Unable to send ip-address to standby: communication failure`

Explanation The active ASA was unable to communicate with the standby ASA. The failover pair may be out-of-sync.

- *ip-address*—The IP address that was assigned to the client

Recommended Action Validate the failover configuration and status.

737029

Error Message `%ASA-6-737029: IPAA: Added ip-address to standby`

Explanation The standby ASA accepted the IP address assignment.

- *ip-address*—The IP address that was assigned to the client

Recommended Action None required.

737030

Error Message `%ASA-4-737030: IPAA: Unable to send ip-address to standby: address in use`

Explanation The standby ASA has the given address already in use when the active ASA attempted to acquire it. The failover pair may be out-of-sync.

- *ip-address*—The IP address that was assigned to the client

Recommended Action Validate the failover configuration and status.

737031

Error Message `%ASA-6-737031: IPAA: Removed ip-address from standby`

Explanation The standby ASA cleared the IP address assignment.

- *ip-address*—The IP address that was assigned to the client

Recommended Action None required.

737032

Error Message `%ASA-4-737032: IPAA: Unable to remove ip-address from standby: address not found`

Explanation The standby ASA did not have an IP address in use when the active ASA attempted to release it. The failover pair may be out-of-sync.

- *ip-address*—The IP address that was assigned to the client

Recommended Action Validate the failover configuration and status.

737033

Error Message `%ASA-4-737033: IPAA: Unable to assign addr_allocator provided IP address ip_addr to client. This IP address has already been assigned by previous_addr_allocator`

Explanation The address assigned by the AAA/DHCP/local pool is already in use.

- *addr_allocator*—The DHCP/AAA/local pool
- *ip_addr*—The IP address allocated by the DHCP/AAA/local pool
- *previous_ addr_allocator*—The address allocater that already assigned the IP address (local pool, AAA, or DHCP)

Recommended Action Validate the AAA/DHCP/local pool address configurations. Overlap may occur.

741000

Error Message `%ASA-6-741000: Coredump filesystem image created on variable 1 -size variable 2 MB`

Explanation A core dump file system was successfully created. The file system is used to manage core dumps by capping the amount of disk space that core dumps may use.

- *variable 1*—The file system on which the core dumps are placed (for example, disk0:, disk1:, and flash:)
- *variable 2*—The size of the created core dump file system in MB

Recommended Action Make sure that you save your configuration after creating the core dump file system.

741001

Error Message `%ASA-6-741001: Coredump filesystem image on variable 1 - resized from variable 2 MB to variable 3 MB`

Explanation The core dump file system has been successfully resized.

- *variable 1*—The file system on which the core dumps are placed
- *variable 2*—The size of the previous core dump file system in MB
- *variable 3*—The size of the current, newly resized core dump file system in MB

Recommended Action Make sure that you save your configuration after resizing the core dump file system. Resizing the core dump file system deletes the contents of the existing core dump file system. As a result, make sure that you archive any information before you resize the core dump file system.

741002

Error Message `%ASA-6-741002: Coredump log and filesystem contents cleared on variable 1`

Explanation All core dumps have been deleted from the core dump file system, and the core dump log has been cleared. The core dump file system and coredump log are always synchronized with each other.

- *variable 1*—The file system on which the core dumps are placed (for example, disk0:, disk1:,and flash:)

Recommended Action None required. You can clear the core dump file system to reset it to a known state using the **clear coredump** command.

741003

Error Message `%ASA-6-741003: Coredump filesystem and its contents removed on variable 1`

Explanation The core dump file system and its contents have been removed, and the core dump feature has been disabled.

- *variable 1*—The file system on which the core dumps are placed (for example, disk0:, disk1:,and flash:)

Recommended Action Make sure that you save your configuration after the core dump feature has been disabled.

741004

Error Message `%ASA-6-741004: Coredump configuration reset to default values`

Explanation The core dump configuration has been reset to its default value, which is disabled.

Recommended Action Make sure that you save your configuration after the core dump feature has been disabled.

741005

Error Message `%ASA-4-741005: Coredump operation` *`variable 1`* `failed with error` *`variable 2 variable 3`*

Explanation An error occurred during the performance of a core dump-related operation.

- *variable 1*—This variable may have the following values:
  - CREATE_FSYS—An error occurred when creating the core dump file system.
  - CLEAR_LOG—An error occurred when clearing the core dump log.
  - DELETE_FSYS—An error occurred when deleting the core dump file system.
  - CLEAR_FSYS—An error occurred when removing the contents of the core dump file system.
  - MOUNT_FSYS—An error occurred when mounting the core dump file system.
- *variable 2*—The decimal number that provides additional information about the cause of the error specified in *variable 1*.
- *variable 3*—The descriptive ASCII string associated with *variable 2*. The ASCII string can have the following values:
  - coredump files already exist
  - unable to create coredump filesystem
  - unable to create loopback device
  - filesystem type not supported
  - unable to delete the coredump filesystem
  - unable to delete loopback device
  - unable to unmount coredump filesystem
  - unable to mount coredump filesystem
  - unable to mount loopback device
  - unable to clear coredump filesystem
  - coredump filesystem not found
  - requested coredump filesystem too big
  - coredump operation aborted by administrator
  - coredump command execution failed
  - coredump IFS error encountered

- coredump, unidentified error encountered

Recommended Action Make sure that the core dump feature is disabled in the configuration, and send the message to the Cisco TAC for further analysis.

741006

Error Message `%ASA-4-741006: Unable to write Coredump Helper configuration, reason` *`variable 1`*

Explanation An error occurred when writing to the coredump helper configuration file. This error occurs only if disk0: is full. The configuration file is located in disk0:.coredumpinfo/coredump.cfg.

- *variable 1*—This variable includes a basic file system-related string that indicates why the writing of the core dump helper configuration file failed.

Recommended Action Disable the core dump feature, remove unneeded items from disk0:, and then reenable core dumps, if desired.

742001

Error Message `%ASA-3-742001: failed to read master key for password encryption from persistent store`

Explanation An attempt to read the master password encryption key from the nonvolatile memory after bootup failed. Encrypted passwords in the configuration are not decrypted unless the master key is set to the correct value using the **key config-key password encryption** command.

Recommended Action If there are encrypted passwords in the configuration that must be used, set the master key to the previous value used to encrypt the password using the **key config-key password encryption** command. If there are no encrypted passwords or they can be discarded, set a new master key. If password encryption is not used, no action is required.

742002

Error Message `%ASA-3-742002: failed to set master key for password encryption`

Explanation An attempt to read the **key config-key password encryption** command failed. The error may be caused by the following reasons:

- Configuration from a nonsecure terminal (for example, over a Telnet connection) was made.
- Failover is enabled, but it does not use an encrypted link.
- Another user is setting the key at the same time.
- When trying to change the key, the old key is incorrect.
- The key is too small to be secure.

Other reasons for the error may be valid. In these cases, the actual error is printed in response to the command.

Recommended Action Correct the problem indicated in the command response.

742003

Error Message `%ASA-3-742003: failed to save master key for password encryption, reason` *`reason_text`*

Explanation An attempt to save the master key to nonvolatile memory failed. The actual reason is specified by the *reason_text* parameter. The reason can be an out-of-memory condition, or the nonvolatile store can be inconsistent.

Recommended Action If the problem persists, reformat the nonvolatile store that is used to save the key by using the **write erase** command. Before performing this step, make sure that you back up the out-of-the-box configuration. Then reenter the **write erase** command.

742004

Error Message `%ASA-3-742004: failed to sync master key for password encryption, reason` *`reason_text`*

Explanation An attempt to synchronize the master key to the peer failed. The actual reason is specified by the *reason_text* parameter.

Recommended Action Try to correct the problem specified in the *reason_text* parameter.

742005

Error Message `%ASA-3-742005: cipher text enc_pass is not compatible with the configured master key or the cipher text has been tampered with`

Explanation An attempt to decrypt a password failed. The password may have been encrypted using a master key that is different from the current master key, or the encrypted password has been changed from its original form.

Recommended Action If the correct master key is not being used, correct the problem. If the encrypted password has been modified, reapply the configuration in question with a new password.

742006

Error Message `%ASA-3-742006: password decryption failed due to unavailable memory`

Explanation An attempt to decrypt a password failed because no memory was available. Features using this password will not work as desired.

Recommended Action Correct the memory problem.

742007

Error Message `%ASA-3-742007: password encryption failed due to unavailable memory`

Explanation An attempt to encrypt a password failed because no memory was available. Passwords may be left in clear text form in the configuration.

Recommended Action Correct the memory problem, and reapply the configuration that failed password encryption.

742008

Error Message `%ASA-3-742008: password` *`enc_pass`* `decryption failed due to decoding error`

Explanation Password decryption failed because of decoding errors, which may occur if the encrypted password has been modified after being encrypted.

Recommended Action Reapply the configuration in question with a clear text password.

742009

Error Message `%ASA-3-742009: password encryption failed due to decoding error`

Explanation Password encryption failed because of decoding errors, which may be an internal software error.

Recommended Action Reapply the configuration in question with a clear text password. If the problem persists, contact the Cisco TAC.

742010

Error Message `%ASA-3-742010: encrypted password enc_pass is not well formed`

Explanation The encrypted password provided in the command is not well formed. The password may not be a valid, encrypted password, or it may have been modified since it was encrypted.

- *reason_text*—A string that represents the actual cause of the failure
- *enc_pass*—The encrypted password that is related to the issue

Recommended Action Reapply the configuration in question with a clear text password.

743000

Error Message `%ASA-1-743000: The PCI device with vendor ID: vendor_id device ID: device_id located at bus:device.function bus_num:dev_num, func_num has a link link_attr_name of actual_link_attr_val when it should have a link link_attr_name of expected_link_attr_val.`

Explanation A PCI device in the system is not configured correctly, which may result in the system not performing at its optimum level.

Recommended Action Collect the output of the **show controller pci detail** command, and contact the Cisco TAC.

743001

Error Message `%ASA-1-743001: Backplane health monitoring detected link failure`

Explanation A hardware failure has probably occurred and has been detected on one of the links between the ASA Services Module and the switch chassis.

Recommended Action Contact the Cisco TAC.

743002

Error Message `%ASA-1-743002: Backplane health monitoring detected link OK`

Explanation A link has been restored between the ASA Services Module and the switch chassis. However, the failure and subsequent recovery probably indicates a hardware failure.

Recommended Action Contact the Cisco TAC.

743004

Error Message `%ASA-1-743004: System is not fully operational - PCI device with vendor ID vendor_id (vendor_name), device ID device_id (device_name) not found`

Explanation A PCI device in the system that is needed for it to be fully operational was not found.

- *vendor_id*—Hexadecimal value that identifies the device vendor
- *vendor_name*—Text string that identifies the vendor name
- *device_id*—Hexadecimal value that identifies the vendor device
- *device_name*—Text string that identifies the device name

Recommended Action Collect the output of the **show controller pci detail** command and contact the Cisco TAC.

743010

Error Message `%ASA-3-743010: EOBC RPC server failed to start for client module client name.`

Explanation The service failed to start for a particular client of the EOBC RPC service on the server.

Recommended Action Call the Cisco TAC.

743011

Error Message `%ASA-3-743011: EOBC RPC call failed, return code code string.`

Explanation The EOBC RPC client failed to make an RPC to the intended server.

Recommended Action Call the Cisco TAC.

746001

Error Message `%ASA-6-746001: user-identity: activated import user groups | activated host names | user-to-IP address databases download started`

Explanation A database (user groups, hostnames, or IP addresses) download has started.

Recommended Action None required.

746002

Error Message %ASA-6-746002: user-identity: *activated import user groups | activated host names | user-to-IP address databases* download complete

Explanation A database (user groups, hostnames, or IP addresses) download has completed.

Recommended Action None required.

746003

Error Message %ASA-3-746003: user-identity: *activated import user groups | activated host names | user-to-IP address databases* download failed - *reason*

Explanation A database (user groups, hostnames, or IP addresses) download has failed because of a timeout.

Recommended Action Check the off-box AD agent status. If the AD agent is down, resolve that issue first. If the AD agent is up and running, try to download the database again. If the problem persists, contact the Cisco TAC.

746004

Error Message %ASA-4-746004: user identity: Total number of activated user groups exceeds the *max_groups* groups for this platform.

Explanation The total number of activated user groups exceeds the maximum number of 256 user groups for this platform.

Recommended Action Too many user groups have been configured and activated. Reduce the number of configured user groups. Run the **clear user-identity user no-policy-activated** command to release user records that have not been activated in any policy. Run the **show user-identity user all** command to check the total number of users in the database.

746005

Error Message %ASA-3-746005: user-identity: The AD Agent *AD agent IP address* cannot be reached - *reason* [*action*]

Explanation The ASA cannot reach the AD agent. There has been no response from the AD agent, or the RADIUS registration failed because the buffer was too small.

Recommended Action Check the network connection between the AD agent and the ASA. Try to reach another AD agent, if one is configured and available. If the problem persists, contact the Cisco TAC.

746006

Error Message `%ASA-4-746006: user-identity: Out of sync with AD Agent, start bulk download`

Explanation The AD agent cannot update the IP-user mapping events on the ASA and the AD agent event log overflows, which causes inconsistency between the AD agent and the ASA IP-user database.

Recommended Action None required. If this message persists, check the connection between the AD agent and the ASA.

746007

Error Message `%ASA-5-746007: user-identity: NetBIOS response failed from User` *`user_name`* `at` *`user_ip`*

Explanation No NetBIOS response was received for the number of retries made.

Recommended Action None required.

746008

Error Message `%ASA-6-746008: user-identity: NetBIOS Probe Process started`

Explanation The NetBIOS process has started.

Recommended Action None required.

746009

Error Message `%ASA-6-746009: user-identity: NetBIOS Probe Process stopped`

Explanation The NetBIOS process has stopped.

Recommended Action None required.

746010

Error Message `%ASA-3-746010: user-identity: update import-user` *domain_name*`\\`*group_name* `- Import Failed [`*reason*`]`

Explanation Entering the **user-identity update import-user username** command failed to update a user element. Reasons for failure include the following: timeout, partial update, import aborted, group does not exist, or no reason given.

Recommended Action If the reason for failure does not exist, verify that the group name is correct in the policy. Otherwise, check the connectivity between the ASA and the AD server.

746011

Error Message `%ASA-4-746011: Total number of users created exceeds the maximum number of` *max_users* `for this platform.`

Explanation The AD group has more than the hard-coded maximum number (64000) of levels. Too many users have been configured in the activated policy.

Recommended Action Change your policies so that the number of configured users and users under configured groups does not exceed the limit.

746012

Error Message `%ASA-5-746012: user-identity: Add IP-User mapping IP Address -` *domain_name*`\`*user_name result - reason*

Explanation A new user-IP mapping has been added to the user-to-IP address mapping database. The status of the operation (success or failure) is indicated. The success reason is VPN user. The failure reasons include the following: Maximum user limit reached and Duplicated address.

Recommended Action None required.

746013

Error Message `%ASA-5-746013: user-identity: Delete IP-User mapping IP Address -` *domain_name*`\`*user_name result - reason*

Explanation A change has been made to the user-to-IP address mapping database. The status of the operation (success or failure) is indicated. The success reasons include the following: Inactive timeout, NetBIOS probing failed, PIP notification, VPN user logout, Cut-through-proxy user logout, and MAC address mismatch. The failure reason is PIP notification.

Recommended Action None required.

746014

Error Message %ASA-5-746014: user-identity: [FQDN] *fqdn* address *IP Address* obsolete.

Explanation A fully qualified domain name has become obsolete.

Recommended Action None required.

746015

Error Message %ASA-5-746015: user-identity: FQDN] *fqdn* resolved *IP address*.

Explanation A fully qualified domain name lookup has succeeded.

Recommended Action None required.

746016

Error Message %ASA-3-746016: user-identity: DNS lookup failed, reason: reason

Explanation A DNS lookup has failed. Failure reasons include timeout, unresolvable, and no memory.

Recommended Action Verify that the FQDN is valid, and that the DNS server is reachable from the ASA. If the problem persists, contact the Cisco TAC.

746017

Error Message %ASA-6-746017: user-identity: Update import-user *domain_name**group_name*

Explanation The **user-identity update import-user** command has been issued.

Recommended Action None required.

746018

Error Message %ASA-6-746018: user-identity: Update import-user *domain_name**group_name* done

Explanation The **user-identity update import-user** command has been issued, and the import has been completed successfully.

Recommended Action None requried.

746019

Error Message %ASA-3-746019: user-identity: *Update|Remove* AD Agent *AD agent IP Address* IP-user mapping *user_IP - domain_name\user_name* failed

Explanation The ASA failed to update or remove an IP-user mapping on the AD agent.

Recommended Action Check the status of the AD agent and the connectivity between the ASA and the AD agent. If the problem persists, contact the Cisco TAC.

747001

Error Message %ASA-3-747001: Clustering: Recovered from state machine event queue depleted. Event (*event-id*, *ptr-in-hex*, *ptr-in-hex*) dropped. Current state *state-name*, stack *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*

Explanation The cluster FSM event queue is full, and a new event has been dropped.

Recommended Action None.

747002

Error Message %ASA-5-747002: Clustering: Recovered from state machine dropped event (*event-id*, *ptr-in-hex*, *ptr-in-hex*). Intended state: *state-name*. Current state: *state-name*.

Explanation The cluster FSM received an event that is incompatible with the current state.

Recommended Action None.

747003

Error Message %ASA-5-747003: Clustering: Recovered from state machine failure to process event (*event-id*, *ptr-in-hex*, *ptr-in-hex*) at state *state-name*.

Explanation The cluster FSM failed to process an event for all reasons given.

Recommended Action None.

747004

Error Message %ASA-6-747004: Clustering: state machine changed from state *state-name* to *state-name*.

Explanation The cluster FSM has progressed to a new state.

Recommended Action None.

747005

Error Message %ASA-7-747005: Clustering: State machine notify event *event-name* (*event-id*, *ptr-in-hex*, *ptr-in-hex*)

Explanation The cluster FSM has notified clients about an event.

Recommended Action None.

747006

Error Message %ASA-7-747006: Clustering: State machine is at state *state-name*

Explanation The cluster FSM moved to a stable state; that is, Disabled, Slave, or Master.

Recommended Action None.

747007

Error Message %ASA-5-747007: Clustering: Recovered from finding stray config sync thread, stack *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*, *ptr-in-hex*.

Explanation Astray configuration sync thread has been detected.

Recommended Action None.

747008

Error Message `%ASA-4-747008: Clustering: New cluster member name with serial number serial-number-A rejected due to name conflict with existing unit with serial number serial-number-B.`

Explanation The same unit name has been configured on multiple units.

Recommended Action None.

747009

Error Message `%ASA-2-747009: Clustering: Fatal error due to failure to create RPC server for module module name.`

Explanation The ASA failed to create an RPC server.

Recommended Action Disable clustering on this unit and try to re-enable it. Contact the Cisco TAC if the problem persists.

747010

Error Message `%ASA-3-747010: Clustering: RPC call failed, message message-name, return code code-value.`

Explanation An RPC call failure has occurred. The system tries to recover from the failure.

Recommended Action None.

747011

Error Message `%ASA-2-747011: Clustering: Memory allocation error.`

Explanation A memory allocation failure occurred in clustering.

Recommended Action Disable clustering on this unit and try to re-enable it. If the problem persists, check the memory usage on the ASA.

747012

Error Message %ASA-3-747012: Clustering: Failed to replicate global object id *hex-id-value* in domain *domain-name* to peer *unit-name*, continuing operation.

Explanation A global object ID replication failure has occurred.

Recommended Action None.

747013

Error Message %ASA-3-747013: Clustering: Failed to remove global object id *hex-id-value* in domain *domain-name* from peer *unit-name*, continuing operation.

Explanation A global object ID removal failure has occurred.

Recommended Action None.

747014

Error Message %ASA-3-747014: Clustering: Failed to install global object id *hex-id-value* in domain *domain-name*, continuing operation.

Explanation A global object ID installation failure has occurred.

Recommended Action None.

747015

Error Message %ASA-4-747015: Clustering: Forcing stray member *unit-name* to leave the cluster.

Explanation A stray cluster member has been found.

Recommended Action None.

747016

Error Message `%ASA-4-747016: Clustering: Found a split cluster with both unit-name-A and unit-name-B as master units. Master role retained by unit-name-A, unit-name-B will leave, then join as a slave.`

Explanation A split cluster has been found.

Recommended Action None.

747017

Error Message `%ASA-4-747017: Clustering: Failed to enroll unit unit-name due to maximum member limit limit-value reached.`

Explanation The ASA failed to enroll a new unit because the maximum member limit has been reached.

Recommended Action None.

747018

Error Message `%ASA-3-747018: Clustering: State progression failed due to timeout in module module-name.`

Explanation The cluster FSM progression has timed out.

Recommended Action None.

747019

Error Message `%ASA-4-747019: Clustering: New cluster member name rejected due to Cluster Control Link IP subnet mismatch (ip-address/ip-mask on new unit, ip-address/ip-mask on local unit).`

Explanation The master unit found that a new joining unit has an incompatible cluster interface IP address.

Recommended Action None.

747020

Error Message `%ASA-4-747020: Clustering: New cluster member unit-name rejected due to encryption license mismatch.`

Explanation The master unit found that a new joining unit has an incompatible encryption license.

Recommended Action None.

747021

Error Message `%ASA-3-747021: Clustering: Master unit unit-name is quitting due to interface health check failure on interface-name.`

Explanation The master unit has disabled clustering because of an interface health check failure.

Recommended Action None.

747022

Error Message `%ASA-3-747022: Clustering: Asking slave unit unit-name to quit because it failed interface health check x times, rejoin will be attempted after y min. Failed interface: interface-name.`

Explanation This syslog message occurs when the maximum number of rejoin attempts has not been exceeded. A slave unit has disabled clustering because of an interface health check failure for the specified amount of time. This unit will re-enable itself automatically after the specified amount of time (ms).

Recommended Action None.

747023

Error Message `%ASA-3-747023: Clustering: Master unit unit-name is quitting due to card name card health check failure, and master Security Service Card state is state-name.`

Explanation The master unit has disabled clustering because of a Security Service Card health check failure.

Recommended Action None.

747024

Error Message `%ASA-3-747024: Clustering: Asking slave unit unit-name to quit due to card name card health check failure, and its Security Service Card state is state-name.`

Explanation A slave unit has disabled clustering because of a Security Service Card health check failure.

Recommended Action None.

747025

Error Message `%ASA-4-747025: Clustering: New cluster member unit-name rejected due to firewall mode mismatch.`

Explanation A master unit found a joining unit that has an incompatible firewall mode.

Recommended Action None.

747026

Error Message `%ASA-4-747026: Clustering: New cluster member unit-name rejected due to cluster interface name mismatch (ifc-name on new unit, ifc-name on local unit).`

Explanation A master unit found a joining unit that has an incompatible cluster control link interface name.

Recommended Action None.

747027

Error Message `%ASA-4-747027: Clustering: Failed to enroll unit unit-name due to insufficient size of cluster pool pool-name in context-name.`

Explanation A master unit could not enroll a joining unit because of the size limit of the minimal cluster pool configured.

Recommended Action None.

747028

Error Message `%ASA-4-747028: Clustering: New cluster member unit-name rejected due to interface mode mismatch (mode-name on new unit, mode-name on local unit).`

Explanation A master unit found a joining unit that has an incompatible interface-mode, either spanned or individual.

Recommended Action None.

747029

Error Message `%ASA-4-747029: Clustering: Unit unit-name is quitting due to Cluster Control Link down.`

Explanation A unit disabled clustering because of a cluster interface failure.

Recommended Action None.

747030

Error Message `%ASA-3-747030: Clustering: Asking slave unit unit-name to quit because it failed interface health check x times (last failure on interface-name), Clustering must be manually enabled on the unit to re-join.`

Explanation An interface health check has failed and the maximum number of rejoin attempts has been exceeded. A slave unit has disabled clustering because of an interface health check failure.

Recommended Action None.

747031

Error Message `%ASA-3-747031: Clustering: Platform mismatch between cluster master (platform-type) and joining unit unit-name (platform-type). unit-name aborting cluster join.`

Explanation The joining unit's platform type does not match with that of the cluster master.

- *unit-name*—Name of the unit in the cluster bootstrap
- *platform-type*—Type of ASA platform

Recommended Action Make sure that the joining unit has the same platform type as that of the cluster master.

747032

Error Message `%ASA-3-747032: Clustering: Service module mismatch between cluster master (module-name) and joining unit unit-name (module-name)in slot slot-number. unit-name aborting cluster join.`

Explanation The joining unit's external modules are not consistent (module type and order in which they are installed) with those on the cluster master.

- *module-name*—Name of the external module
- *unit-name*—Name of the unit in the cluster bootstrap
- *slot-number*—The number of the slot in which the mismatch occurred

Recommended Action Make sure that the modules installed on the joining unit are of the same type and are in the same order as they are in the cluster master.

747033

Error Message `%ASA-3-747033: Clustering: Interface mismatch between cluster master and joining unit unit-name. unit-name aborting cluster join.`

Explanation The joining unit's interfaces are not the same as those on the cluster master.

- *unit-name*—Name of the unit in the cluster bootstrap

Recommended Action Make sure that the interfaces available on the joining unit are the same as those on the cluster master.

750001

Error Message `%ASA-5-750001: Local:local IP:local port Remote:remote IP: remote port Username: username Received request to request an IPsec tunnel; local traffic selector = local selectors: range, protocol, port range; remote traffic selector = remote selectors: range, protocol, port range`

Explanation A request is being made for an operation on the IPsec tunnel such as a rekey, a request to establish a connection, and so on.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known, or the tunnel group
- *local selectors*—Locally configured traffic selectors or proxies that are being used for this IPsec tunnel

- *remote selectors*—Remote peers requested traffic selectors or proxies for this IPsec tunnel

Recommended Action None required.

750002

Error Message `%ASA-5-750002: Local:`*`local IP`*`:`*`local port`* `Remote:` *`remote IP`*`:` *`remote port`* `Username:` *`username`* `Received a IKE_INIT_SA request`

Explanation An incoming tunnel or SA initiation request (IKE_INIT_SA request) has been received.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known, or the tunnel group

Recommended Action None required.

750003

Error Message `%ASA-4-750003: Local:` *`local IP:local port`* `Remote:` *`remote IP:remote port`* `Username:` *`username`* `Negotiation aborted due to ERROR:` *`error`*

Explanation The negotiation of an SA was aborted because of the provided error reason.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet
- *error*—Error reason for aborting the negotiation

Recommended Action Review the syslog and follow the flow of the logs to determine if this syslog is the final in the exchange and if it is the cause of a potential failure or a transient error that was renegotiated through. For example, a peer may suggest a DH group via the KE payload that is not configured that causes an initial request to fail, but the correct DH group is communicated so that the peer can come back with the correct group in a new request.

750004

Error Message `%ASA-5-750004: Local: local IP: local port Remote: remote IP: remote port Username: username Sending COOKIE challenge to throttle possible DoS`

Explanation An incoming connection request was challenged with a cookie based on the cookie challenge thresholds that are configured to prevent a possible DoS attack.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet

Recommended Action None required.

750005

Error Message `%ASA-5-750005: Local: local IP: local port Remote: remote IP: remote port Username: username IPsec rekey collision detected. I am lowest nonce initiator, deleting SA with inbound SPI SPI`

Explanation A rekey collision was detected (both peers trying to initiate a rekey at the same time), and it was resolved by keeping the one initiated by this ASA because it had the lowest nonce. This action caused the indicated SA referenced by the SPI to be deleted.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet
- *SPI*—SPI handle of the SA being deleted by resolving the rekey collision that was detected

Recommended Action None required.

750006

Error Message `%ASA-5-750006: Local: local IP: local port Remote: remote IP: remote port Username: username SA UP. Reason: reason`

Explanation An SA came up for the given reason, such as for a newly established connection or a rekey.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from

- *username*—Username of the requester for remote access, if known yet
- *reason*—Reason that the SA came into the UP state

Recommended Action None required.

750007

Error Message `%ASA-5-750007: Local: local IP: local port Remote: remote IP: remote port Username: username SA DOWN. Reason: reason`

Explanation An SA was torn down or deleted for the given reason, such as a request by the peer, operator request (via an administrator action), rekey, and so on.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet
- *reason*—Reason that the SA came into the DOWN state

Recommended Action None required.

750008

Error Message `%ASA-5-750008: Local: local IP: local port Remote: remote IP: remote port Username: username SA rejected due to system resource low`

Explanation An SA request was rejected to alleviate a low system resource condition.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet

Recommended Action Check CAC settings for IKEv2 to determine if this is expected behavior based on configured thresholds; otherwise, if the condition persists, investigate further to alleviate the issue.

750009

Error Message `%ASA-5-750009: Local: local IP: local port Remote: remote IP: remote port Username: username SA request rejected due to CAC limit reached: Rejection reason: reason`

Explanation A Connection Admission Control (CAC) limiting threshold was reached, which caused the SA request to be rejected.

- *local IP:local port*— Local IP address for this request. The ASA IP address and port number used for this connection
- *remote IP:remote port*— Remote IP address for this request. Peer IP address and port number that the connection is coming from
- *username*—Username of the requester for remote access, if known yet
- *reason*—Reason that the SA was rejected

Recommended Action Check CAC settings for IKEv2 to determine if this is expected behavior based on configured thresholds; otherwise, if the condition persists, investigate further to alleviate the issue.

750010

Error Message `%ASA-5-750010: Local: local-ip Remote: remote-ip Username:username IKEv2 local throttle-request queue depth threshold of threshold reached; increase the window size on peer peer for better performance`

- *local-ip*—Local peer IP address
- *remote-ip*—Remote peer IP address
- *username*—Username of the requester for remote access or tunnel group name for L2L, if known yet
- *threshold*—Queue depth threshold of the local throttle-request queue reached
- *peer*—Remote peer IP address

Explanation The ASA overflowed its throttle request queue to the specified peer, indicating that the peer is slow. The throttle request queue holds requests destined for the peer, which cannot be sent immediately because the maximum number of requests allowed to be in-flight based on the IKEv2 window size were already in-flight. As in-flight requests are completed, requests are pulled off of the throttle request queue and sent to the peer. If the peer is not processing these requests quickly, the throttle queue backs up.

Recommended Action If possible, increase the IKEv2 window size on the remote peer to allow more concurrent requests to be in-flight, which may improve performance.

Note The ASA does not currently support an increased IKEv2 window size setting.

750011

Error Message `%ASA-3-750011: Tunnel Rejected: Selected IKEv2 encryption algorithm (IKEV2 encry algo) is not strong enough to secure proposed IPSEC encryption algorithm (IPSEC encry algo).`

Explanation The tunnel was rejected because the selected IKEv2 encryption algorithm is not strong enough to secure the proposed IPSEC encryption algorithm.

Recommended Action Configure a stronger IKEv2 encryption algorithm to match or exceed the strength of the IPsec child SA encryption algorithm.

750012

Error Message `%ASA-4-750012: Selected IKEv2 encryption algorithm (IKEV2 encry algo) is not strong enough to secure proposed IPSEC encryption algorithm (IPSEC encry algo).`

Explanation The selected IKEv2 encryption algorithm is not strong enough to secure the proposed IPSEC encryption algorithm.

Recommended Action Configure a stronger IKEv2 encryption algorithm to match or exceed the strength of the IPsec child SA encryption algorithm.

751001

Error Message `%ASA-3-751001: Local: localIP:port Remote:remoteIP:port Username: username/group Failed to complete Diffie-Hellman operation. Error: error`

Explanation A failure to complete a Diffie-Hellman operation occurred, as indicated by the error.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *error*—The error string that indicates the specific error

Recommended Action A low memory issue or other internal error that should be resolved has occurred. If it persists, use the memory tracking tool to isolate the issue.

751002

Error Message `%ASA-3-751002: Local: localIP:port Remote:remoteIP:port Username: username/group No preshared key or trustpoint configured for self in tunnel group group`

Explanation The ASA was unable to find any type of authentication information in the tunnel group that it could use to authenticate itself to the peer.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *group*—The name of the tunnel group

Recommended Action Check the tunnel group configuration, and configure a preshared key or certificate for self-authentication in the indicated tunnel group.

751003

Error Message `%ASA-7-751003: Local: localIP:port Remote:remoteIP:port Username: username/group Need to send a DPD message to peer`

Explanation Dead peer detection needs to be performed for the specified peer to determine if it is still alive. The ASA may have terminated a connection to the peer.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

Recommended Action None required.

751004

Error Message `%ASA-3-751004: Local: localIP:port Remote:remoteIP:port Username: username/group No remote authentication method configured for peer in tunnel group group`

Explanation A method to authenticate the remote peer was not found in the configuration to allow the connection.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

- *group*—The name of the tunnel group

Recommended Action Check the configuration to make sure that a valid remote peer authentication setting is present.

751005

Error Message `%ASA-3-751005: Local: localIP:port Remote:remoteIP:port Username: username/group AnyConnect client reconnect authentication failed. Session ID: sessionID, Error: error`

Explanation A failure occurred during an AnyConnect client reconnection attempt using the session token.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *sessionID*—The session ID used to try to reconnect
- *error*—The error string to indicate the specific error that occurred during the reconnection attempt

Recommended Action Take action according to the error specified, if necessary. The error may indicate that a session was removed instead of remaining in resume state because a client disconnect was detected or sessions were cleared on the ASA. If necessary, also compare this message to the event logs on the Anyconnect client.

751006

Error Message `%ASA-3-751006: Local: localIP:port Remote:remoteIP:port Username: username/group Certificate authentication failed. Error: error`

Explanation A failure related to certificate authentication occurred.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *error*—The error string to indicate the specific certificate authentication failure

Recommended Action Take action according to the error specified, if necessary. Check the certificate trustpoint configuration and make sure that the necessary CA certificate exists to be able to correctly verify client certificate chains. Use the **debug crypto ca** commands to isolate the failure.

751007

Error Message `%ASA-5-751007: Local: localIP:port Remote:remoteIP:port Username: username/group Configured attribute not supported for IKEv2. Attribute: attribute`

Explanation A configured attribute could not be applied to the IKE version 2 connection because it is not supported for IKE version 2 connections.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *attribute*—The attribute that is configured to be applied

Recommended Action None required, To eliminate this message from being generated, you can remove the IKE version 2 configuration setting.

751008

Error Message `%ASA-3-751008: Local: localIP:port Remote:remoteIP:port Username: username/group Group=group, Tunnel rejected: IKEv2 not enabled in group policy`

Explanation IKE version 2 is not allowed based on the enabled protocols for the indicated group to which a connection attempt was mapped, and the connection was rejected.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *group*—The tunnel group used for connection

Recommended Action Check the group policy VPN tunnel protocol setting and enable IKE version 2, if desired.

751009

Error Message `%ASA-3-751009: Local: localIP:port Remote:remoteIP:port Username: username/group Unable to find tunnel group for peer.`

Explanation A tunnel group could not be found for the peer.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

Recommended Action Check the configuration and tunnel group mapping rules, then configure them to allow the peer to land on a configured group.

751010

Error Message `%ASA-3-751010: Local: localIP:port Remote:remoteIP:port Username: username/group Unable to determine self-authentication method. No crypto map setting or tunnel group found.`

Explanation A method for authenticating the ASA to the peer could not be found in either the tunnel group or crypto map.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

Recommended Action Check the configuration, and configure a self-authentication method in the crypto map for the initiator L2L or in the applicable tunnel group.

751011

Error Message `%ASA-3-751011: Local: localIP:port Remote:remoteIP:port Username: username/group Failed user authentication. Error: error`

Explanation A failure occured during user authentication within EAP for an IKE version 2 remote access connection.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *error*—The error string that indicates the specific error

Recommended Action Make sure that the correct authentication credentials were provided and debug further to determine the exact cause of failure, if necessary.

751012

Error Message `%ASA-3-751012: Local: localIP:port Remote:remoteIP:port Username: username/group Failure occurred during Configuration Mode processing. Error: error`

Explanation A failure occurred during configuration mode processing while settings were being applied to the connection.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

- *error*—The error string that indicates the specific error

Recommended Action Take action based on the indicated error. Use the **debug crypto ikev2** commands to determine the cause of the failure, or debug the indicated subsystem that is specified by the error, if necessary.

751013

Error Message `%ASA-3-751013: Local: localIP:port Remote:remoteIP:port Username: username/group Failed to process Configuration Payload request for attribute attribute ID. Error: error`

Explanation The Configuration Payload request failed to process and generate a Configuration Payload response for an attribute that was requested by the peer.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *attribute ID*— The attribute ID on which the failure occurred
- *error*—The error string that indicates the specific error

Recommended Action A memory error, configuration error, or another type of error has occurred. Use the **debug crypto ikev2** commands to help isolate the cause of the failure.

751014

Error Message `%ASA-4-751014: Local: localIP:port Remote remoteIP:port Username: username/group Warning Configuration Payload request for attribute attribute ID could not be processed. Error: error`

Explanation A warning occurred while processing a CP request to generate a CP response for a requested attribute.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *attribute ID*— The attribute ID on which the failure occurred
- *error*—The error string that indicates the specific error

Recommended Action Take action based on the attribute indicated in the warning and the indicated warning message. For example, a newer client is being used with an older ASA image, which does not understand a new attribute that has been added to the client. An upgrade of the ASA image may be necessary to allow the attribute to be processed.

751015

Error Message `%ASA-4-751015: Local: localIP:port Remote remoteIP:port Username: username/group SA request rejected by CAC. Reason: reason`

Explanation The connection was rejected by the call admission control to protect the ASA based on configured thresholds or conditions indicated by the reason listed.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *reason*—The reason that the SA request was rejected

Recommended Action Check the reason and resolve the condition if a new connection should have been accepted or change the configured thresholds.

751016

Error Message `%ASA-4-751016: Local: localIP:port Remote remoteIP:port Username: username/group L2L peer initiated a tunnel with the same outer and inner addresses. Peer could be Originate only - Possible misconfiguration!`

Explanation The peer may be configured for originate-only connections based on the received outer and inner IP addresses for the tunnel.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt

Recommended Action Check the L2L peer configuration.

751017

Error Message `%ASA-3-751017: Local: localIP:port Remote remoteIP:port Username: username/group Configuration Error error description`

Explanation An error in the configuration that prevented the connection has been detected.

- *localIP:port*—The local IP address and port number
- *remoteIP:port*—The remote IP address and port number
- *username/group*—The username or group associated with this connection attempt
- *error description*—A brief description of the configuration error

Recommended Action Correct the configuration based on the indicated error.

751018

Error Message `%ASA-3-751018: Terminating the VPN connection attempt from attempted group. Reason: This connection is group locked to locked group.`

Explanation The tunnel group over which the connection is attempted is not the same as the tunnel group set in the group lock.

- *attempted group*—The tunnel group over which the connection came in
- *locked group*—The tunnel group that the connection is locked or restricted to

Recommended Action Check the group-lock value in the group policy or the user attributes.

751019

Error Message `%ASA-4-751019: Local:LocalAddr Remote:RemoteAddr Username:username Failed to obtain an licenseType license. Maximum license limit limit exceeded.`

Explanation A session creation failed because the maximum license limit was exceeded, which caused a failure to either initiate or respond to a tunnel request.

- *LocalAddr*—Local address for this connection attempt
- *RemoteAddr*—Remote peer address for this connection attempt
- *username*—Username for the peer attempting the connection
- *licenseType*— License type that was exceeded (other VPN or AnyConnect Premium/Essentials)
- *limit*—Number of licenses allowed and was exceeded

Recommended Action Make sure that enough licenses are available for all allowed users and/or obtain more licenses to allow the rejected connections. For multiple context mode, allow more licenses for the context that reported the failure, if necessary.

751020

Error Message `%ASA-3-751020: Local:%A:%u Remote:%A:%u Username:%s An %s remote access connection failed. Attempting to use an NSA Suite B crypto algorithm (%s) without an AnyConnect Premium license.`

Explanation An IKEv2 remote access tunnel could not be created because of an NSA Suite B ASA license restriction, or an AnyConnect Premium license was applied but explicitly disabled with the **anyconnect-essentials** command in the webvpn configuration mode.

Recommended Action Make sure that either an AnyConnect Premium license is installed on the ASA or that no NSA Suite B crypto algorithms are configured in the remote access IKEv2 policies or IPsec proposals.

751021

Error Message `%ASA-4-751021: Local:variable 1:variable 2 Remote:variable 3:variable 4 Username:variable 5 variable 6 with variable 7 encryption is not supported with this version of the AnyConnect Client. Please upgrade to the latest Anyconnect Client.`

Explanation An out-of-date AnyConnect client tried to connect to an ASA that has IKEv2 with AES-GCM encryption policy configured.

- *variable 1*—Local IP address
- *variable 2*—Local port
- *variable 3*—Remote client IP address
- *variable 4*—Remote client port
- *variable 5*—Username of the AnyConnect client (may be unknown because this occurs before the user enters a username)
- *variable 6*—Connection protocol type (IKEv1, IKEv2)
- *variable 7*—Combined mode encryption type (AES-GCM, AES-GCM 256)

Recommended Action Upgrade the AnyConnect client to the latest version to use IKEv2 with AES-GCM encryption.

751022

Error Message `%ASA-3-751022: Local: local-ip Remote: remote-ip Username:username Tunnel rejected: Crypto Map Policy not found for remote traffic selector rem-ts-start/rem-ts-end/rem-ts.startport/rem-ts.endport/rem-ts.protocol local traffic selector local-ts-start/local-ts-end/ local-ts.startport/local-ts.endport/local-ts.protocol!`

Explanation The ASA was not able to find security policy information for the private networks or hosts indicated in the message. These networks or hosts were sent by the initiator and do not match any crypto ACLs at the ASA. This is most likely a misconfiguration.

- *local-ip*—Local peer IP address
- *remote-ip*—Remote peer IP address
- *username*—Username of the requester for remote access, if known yet
- *rem-ts-start*—Remote traffic selector start address
- *rem-ts-end*—Remote traffic selector end address
- *rem-ts.startport*—Remote traffic selector start port
- *rem-ts.endport*—Remote traffic selector end port
- *rem-ts.protocol*—Remote traffic selector protocol
- *local-ts-start*—Local traffic selector start address
- *local-ts-end*—Local traffic selector end address
- *local-ts.startport*—Local traffic selector start port

- *local-ts.endport*—Local traffic selector end port
- *local-ts.protocol*—Local traffic selector protocol

Recommended Action Check the protected network configuration in the crypto ACLs on both sides and make sure that the local network on the initiator is the remote network on the responder and vice-versa. Pay special attention to wildcard masks and host addresses as compared to network addresses. Non-Cisco implementations may have the private addresses labeled as proxy addresses or "red" networks.

751023

Error Message `%ASA-6-751023: Local a:p Remote: a:p Username:n Unknown client connection`

Explanation An unknown non-Cisco IKEv2 client has connected to the ASA.

- *n*—The group or username (depending on context)
- *a*—An IP address
- *p*—The port number
- *ua*—The user-agent presented by the client to the ASA

Recommended Action Upgrade to a Cisco-supported IKEv2 client.

751024

Error Message `%ASA-3-751024: Local:ip-addr Remote:ip-addr Username:username IKEv2 IPv6 User Filter tempipv6 configured. This setting has been deprecated, terminating connection`

Explanation The IPv6 VPN filter has been deprecated and if it is configured instead of a unified filter for IPv6 traffic access control, the connection will be terminated.

Recommended Action Configure a unified filter with IPv6 entries to control IPv6 traffic for the user.

752001

Error Message `%ASA-2-752001: Tunnel Manager received invalid parameter to remove record`

Explanation A failure to remove a record from the tunnel manager that might prevent future tunnels to the same peer from initiating has occurred.

Recommended Action Reloading the device will remove the record, but if the error persists or recurs, perform additional debugging of the specific tunnel attempt.

752002

Error Message `%ASA-7-752002: Tunnel Manager Removed entry. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation An entry to initiate a tunnel was successfully removed.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action None required.

752003

Error Message `%ASA-5-752003: Tunnel Manager dispatching a KEY_ACQUIRE message to IKEv2. Map Tag = mapTag. Map Sequence Number = mapSeq`

Explanation An attempt is being made to initiate an IKEv2 tunnel that was based on the crypto map indicated.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action None required.

752004

Error Message `%ASA-5-752004: Tunnel Manager dispatching a KEY_ACQUIRE message to IKEv1. Map Tag = mapTag. Map Sequence Number = mapSeq`

Explanation An attempt is being made to initiate an IKEv1 tunnel that was based on the crypto map indicated.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action None required.

752005

Error Message `%ASA-2-752005: Tunnel Manager failed to dispatch a KEY_ACQUIRE message. Memory may be low. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation An attempt to dispatch a tunnel initiation attempt failed because of an internal error, such as a memory allocation failure.

- *mapTag*—Name of the crypto map for which the initiation entry was removed

- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action Use the memory tracking tools and additional debugging to isolate the issue.

752006

Error Message `%ASA-3-752006: Tunnel Manager failed to dispatch a KEY_ACQUIRE message. Probable mis-configuration of the crypto map or tunnel-group. Map Tag = Tag. Map Sequence Number = num, SRC Addr: address port: port Dst Addr: address port: port.`

Explanation An attempt to dispatch a tunnel initiation attempt failed because of a configuration error of the indicated crypto map or associated tunnel group.

- *Tag*—Name of the crypto map for which the initiation entry was removed
- *num*—Sequence number of the crypto map for which the initiation entry was removed
- *address*—The source IP address or destination IP address
- *port*—The source port number or destination port number

Recommended Action Check the configuration of the tunnel group and crypto map indicated to make sure that it is complete.

752007

Error Message `%ASA-3-752007: Tunnel Manager failed to dispatch a KEY_ACQUIRE message. Entry already in Tunnel Manager. Map Tag = mapTag. Map Sequence Number = mapSeq`

Explanation An attempt was made to re-add an existing entry into the tunnel manager.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action If the issue persists, make sure that the configuration of the peer will allow the tunnel, and debug further to make sure that the tunnel manager entries are being added and removed correctly during tunnel initiation and successful or failed initiation attempts. Debug IKE version 2 or IKE version 1 connections further, because they may still be in the process of creating the tunnel.

752008

Error Message `%ASA-7-752008: Duplicate entry already in Tunnel Manager`

Explanation A duplicate request to initiate a tunnel was made, and the tunnel manager is already attempting to initiate the tunnel.

Recommended Action None required. If the issue persists, either IKE version 1 or IKE version 2 may have attempted a tunnel initiation and not have timed out yet. Debug further using the applicable commands to make sure that the tunnel manager entry is removed after successful or failed initiation attempts.

752009

Error Message `%ASA-4-752009: IKEv2 Doesn't support Multiple Peers`

Explanation An attempt to initiate a tunnel with IKE version 2 failed because the crypto map is configured with multiple peers, which is not supported for IKE version 2. Only IKE version 1 supports multiple peers.

Recommended Action Check the configuration to make sure that multiple peers are not expected for IKE version 2 site-to-site initiation.

752010

Error Message `%ASA-4-752010: IKEv2 Doesn't have a proposal specified`

Explanation No IPsec proposal was found to be able to initiate an IKE version 2 tunnel .

Recommended Action Check the configuration, then configure an IKE version 2 proposal that can be used to initiate the tunnel, if necessary.

752011

Error Message `%ASA-4-752011: IKEv1 Doesn't have a transform set specified`

Explanation No IKE version 1 transform set was found to be able to initiate an IKE version 2 tunnel.

Recommended Action Check the configuration, then configure an IKE version 2 transform set that can be used to initiate the tunnel, if necessary.

752012

Error Message `%ASA-4-752012: IKEv protocol was unsuccessful at setting up a tunnel. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation The indicated protocol failed to initiate a tunnel using the configured crypto map.

- *protocol*—IKE version number 1 or 2 for IKEv1 or IKEv2
- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action Check the configuration, then debug further within the indicated protocol to determine the cause of the failed tunnel attempt.

752013

Error Message `%ASA-4-752013: Tunnel Manager dispatching a KEY_ACQUIRE message to IKEv2 after a failed attempt. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation The tunnel manager is attempting to initiate the tunnel again after it failed.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action Check the configuration, and make sure that the crypto maps are correctly configured. Then determine if the tunnel is successfully created on the second attempt.

752014

Error Message `%ASA-4-752014: Tunnel Manager dispatching a KEY_ACQUIRE message to IKEv1 after a failed attempt. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation The tunnel manager is falling back and attempting to initiate the tunnel using IKE version 1 after the tunnel failed.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action Check the configuration, and make sure that the crypto maps are correctly configured. Then determine if the tunnel is successfully created on the second attempt.

752015

Error Message `%ASA-3-752015: Tunnel Manager has failed to establish an L2L SA. All configured IKE versions failed to establish the tunnel. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation An attempt to bring up an L2L tunnel to a peer failed after trying with all configured protocols.

- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action Check the configuration, and make sure that the crypto maps are correctly configured. Debug the individual protocols to isolate the cause of the failure.

752016

Error Message `%ASA-5-752016: IKEv protocol was successful at setting up a tunnel. Map Tag = mapTag. Map Sequence Number = mapSeq.`

Explanation The indicated protocol (IKE version 1 or IKE version 2) successfully created an L2L tunnel.

- *protocol*—IKE version number 1 or 2 for IKEv1 or IKEv2
- *mapTag*—Name of the crypto map for which the initiation entry was removed
- *mapSeq*—Sequence number of the crypto map for which the initiation entry was removed

Recommended Action None required.

752017

Error Message `%ASA-4-752017: IKEv2 Backup L2L tunnel initiation denied on interface interface matching crypto map name, sequence number number. Unsupported configuration.`

Explanation The ASA uses IKEv1 to initiate the connection because IKEv2 does not support the backup L2L feature.

Recommended Action None required if IKEv1 is enabled. You must enable IKEv1 to use the backup L2L feature.

766001

Error Message `%ASA-3-766001: CTS SXP: Configured source IP source ip error`

Explanation An error occurred while using this configured source IP address to set up an SXP connection.

- *source ip*—IPv4 or IPv6 source address
- *error*—Detailed message regarding what type of error occurs while using the configured address to set up the SXP connection, which can be one of the following:
  - Does not belong to this device.
  - Does not match outbound interface IP address.

Recommended Action Reconfigure the SXP connection to have a valid source IP address. Alternatively, unconfigure the source IP address and let the device select the correct source IP address based on a route lookup.

766002

Error Message `%ASA-3-766002: CTS SXP: Invalid message from peer peer IP: error`

Explanation An error occurred while parsing an SXP message.

- *peer IP*—IPv4 or IPv6 peer address
- *error*— Description of message parsing problem

Recommended Action Contact the Cisco TAC for assistance.

766003

Error Message `%ASA-3-766003: CTS SXP: Connection with peer peer IP failed: error`

Explanation An SXP configuration error occurred. The connection cannot be set up correctly.

- *peer IP*—IPv4 or IPv6 peer address
- *error*— Description of SXP configuration problem. The error can be one of the following values:
  - Mode mismatch with received one.
  - Does not exist.
  - With the same peer, but different source IP address exists.
  - Version mismatch with received one.
  - Received binding update while in speaker mode.

Recommended Action Make sure that the connection configurations on both ends have the correct mode and IP addresses.

766004

Error Message `%ASA-3-766004: CTS SXP: Fail to start listening socket after TCP process restart.`

Explanation The SXP on this device cannot accept SXP connection setup requests from remote devices, because it cannot update the binding manager.

Recommended Action Disable and reenable the SXP feature to see if the listening socket can be restarted.

766005

Error Message `%ASA-3-766005: CTS SXP: Binding` *`Binding IP - SGname(SGT)`* `from` *`peer IP instance connection instance num error.`*

Explanation An SXP binding update error has occurred.

- *Binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *peer IP*—IPv4 or IPv6 peer address that sent the binding
- *connection instance num*—Instance number of the SXP connection from which the binding came
- *error*—Detailed message about the binding error

Recommended Action Contact the Cisco TAC for assistance.

766006

Error Message `%ASA-3-766006: CTS SXP: Internal error:` *`error`*

Explanation The CTS SXP system encountered an internal failure.

- *error*—Detailed message about the SXP internal error, which can be one of the following:
  - Source IP address of existing SXP connection cannot change.
  - Password type of existing connection cannot change.
  - Connection mode is the same as the existing configuration.
  - IP address does not exist.

Recommended Action Contact the Cisco TAC for assistance.

766007

Error Message `%ASA-3-766007: CTS SXP: Connection with peer peer IP (instance connection instance num) state changed from original state to Off.`

Explanation The CTS SXP system encountered an internal failure, because the SXP connection with the specified instance number changed its state to off.

- *peer IP*—IPv4 or IPv6 peer address
- *connection instance num*—SXP connection instance number
- *original state*—Original connection state

Recommended Action None required.

766008

Error Message `%ASA-6-766008: CTS SXP: Connection with peer IP (instance connection instance num) state changed from original state to final state.`

Explanation The SXP connection with the specified instance number changed state.

- *peer IP*—IPv4 or IPv6 peer address
- *source IP*—IPv4 or IPv6 source address
- *connection instance num*—SXP connection instance number
- *original state*—Original connection state
- *final state*—Final connection state, which can be any state except the Off state.

Recommended Action .None required.

766009

Error Message `%ASA-5-766009: CTS SXP: password changed.`

Explanation The SXP system password has been changed.

Recommended Action None required.

766010

Error Message `%ASA-5-766010: CTS SXP: SXP default source IP is changed original source IP final source IP.`

Explanation The SXP default source IP address has been changed on this device.

- *original source IP*—IPv4 or IPv6 original default source IP address

- *final source IP*—IPv4 or IPv6 final default source IP address

Recommended Action None required.

766011

Error Message `%ASA-5-766011: CTS SXP: operational state.`

Explanation The SXP feature has changed operational state and works only when the feature is enabled.

- *operational state*—Flags the state whether CTS SXP is enabled or disabled.

Recommended Action None required.

766012

Error Message `%ASA-7-766012: CTS SXP: timer name timer started for connection with peer peer IP.`

Explanation The specified SXP timer started.

- *peer IP*—IPv4 or IPv6 peer address. For timers that are not triggered by connection-based events, that is, the retry open timer, a default IP address of 0.0.0.0 is used.
- *timer name*—Timer name

Recommended Action None required.

766013

Error Message `%ASA-7-766013: CTS SXP: timer name timer stopped for connection with peer peer IP.`

Explanation The specified SXP timer stopped.

- *peer IP*—IPv4 or IPv6 peer address. For timers that are not triggered by connection-based events, that is, the retry open timer, a default IP address of 0.0.0.0 is used.
- *timer name*—Timer name

Recommended Action None required.

766014

Error Message `%ASA-7-766014: CTS SXP: SXP received binding forwarding request (action) binding binding IP - SGname(SGT).`

Explanation The SXP received a binding forwarding request. The request comes from the binding manager when it wants SXP to broadcast the latest net binding changes within the binding manager.

- *action*—Add or delete operation
- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.

Recommended Action None required.

766015

Error Message `%ASA-7-766015: CTS SXP: Binding binding IP - SGname(SGT) is forwarded to peer peer IP (instance connection instance num).`

Explanation The SXP forwarded binding to the peer.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *peer IP*—IPv4 or IPv6 peer address
- *connection instance num*—SXP connection instance number

Recommended Action None required.

766016

Error Message `%ASA-7-766016: CTS SXP: Binding binding IP - SGName(SGT) from peer peer IP (instance binding's connection instance num) changed from old instance: old instance num, old sgt: old SGName(SGT).`

Explanation Binding changed in the SXP database.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *peer IP*—Binding source IPv4 or IPv6 address
- *binding's connection instance num*—SXP connection instance number
- *old instance num*—Old connection instance number on which the binding was learned

- *old SGName* (*SGT*)—Binding old SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.

Recommended Action None required.

766017

Error Message `%ASA-7-766017: CTS SXP: Binding binding IP - SGname(SGT) from peer peer IP (instance connection instance num) deleted in SXP database.`

Explanation Binding was deleted in the SXP database.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *peer IP*—Binding source IPv4 or IPv6 peer address
- *connection instance num*—SXP connection instance number

Recommended Action None required.

766018

Error Message `%ASA-7-766018: CTS SXP: Binding binding IP - SGname(SGT) from peer peer IP (instance connection instance num) added in SXP database.`

Explanation Binding was aded in the SXP database.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *peer IP*—Binding source IPv4 or IPv6 peer address
- *connection instance num*—SXP connection instance number

Recommended Action None required.

766019

Error Message `%ASA-7-766019: CTS SXP: Binding binding IP - SGname(SGT) action taken. Update binding manager.`

Explanation The SXP updated the binding manager with the binding change.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.

- *action taken*—Action taken, which can be one of the following: added, deleted, or changed.

Recommended Action None required.

766020

Error Message `%ASA-3-766020: CTS SXP: Unable to locate egress interface to peer peer IP.`

Explanation The ASA cannot locate the egress interface to the SXP peer.

- *binding IP*—IPv4 or IPv6 address

Recommended Action Make sure that the SXP peer is routable from the device.

766201

Error Message `%ASA-4-766201: CTS PAC: CTS PAC for Server IP_address, A-ID PAC issuer name will expire in number days`

Explanation A CTS PAC is nearing its expiration date.

Recommended Action Obtain a new PAC and import it.

766202

Error Message `%ASA-3-766202: CTS PAC for Server IP_address, A-ID PAC issuer name has expired`

Explanation A CTS PAC has expired.

Recommended Action Obtain a new PAC and import it.

766203

Error Message `%ASA-3-766203: Unable to retrieve CTS Environment data due to: reason`

Explanation The ASA was unable to retrieve the CTS environment data and SGT name table for one of the following reasons:

- PAC has expired
- PAC data not available
- Error response from ISE
- Unable to retrieve server secret from the PAC

- Database error
- Invalid SG info value received
- Unable to add SG tag to database
- Error closing database
- Database update aborted

Recommended Action If this message persists, contact the Cisco TAC for assistance.

766204

Error Message `%ASA-3-766204: CTS Environment data has expired`

Explanation The CTS environmentThe CTS environment data and SGT name table have expired, which is likely to occur after unresolved environment data retrieval failures have occurred.

Recommended Action If this message persists, contact the Cisco TAC for assistance.

766251

Error Message `%ASA-6-766251: CTS SGT-MAP: Binding` *`binding IP - SGname(SGT)`* `from` *`source name`* `added to binding manager.`

Explanation Binding from the specified source was added to the binding manager.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *source name*—Name of the contributing source. Currently, SXP is the only contributing source.

Recommended Action None required.

766252

Error Message `%ASA-5-766252: CTS SGT-MAP: CTS SGT-MAP: Binding` *`binding IP - SGname(SGT)`* `from` *`source name`* `deleted from binding manager.`

Explanation Binding from the specified source was deleted from the binding manager.

Explanation Binding from the specified source was added to the binding manager.

- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.

- *source name*—Name of the contributing source. Currently, SXP is the only contributing source.

Recommended Action None required.

766253

Error Message `%ASA-6-766253: CTS SGT-MAP: Binding binding IP - new SGname(SGT) from new source name changed from old sgt: old SGname(SGT) from old source old source name.`

Explanation A particular IP to SGT binding has changed in the binding manager.

- *binding IP*—IPv4 or IPv6 binding address
- *new SGname* (*SGT*)—New binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *new source name*—Name of the new contributing source. Currently, SXP is the only contributing source.
- *old SGname* (*SGT*)—Old binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *old source name*—Name of the old contributing source. Currently, SXP is the only contributing source.

Recommended Action None required.

766254

Error Message `%ASA-3-766254: CTS SGT-MAP: Binding manager unable to action binding binding IP - SGname(SGT) from source name.`

Explanation The binding manager cannot insert, delete, or update the binding

- *action*—Binding manager operation. Either insert, delete or update.
- *binding IP*—IPv4 or IPv6 binding address
- *SGname* (*SGT*)—Binding SGT information. Has the following format if SGname is available: *SGname* (*SGT*) and the following format if SGname is unavailable: *SGT*.
- *source name*—Name of the contributing source. Currently, SXP is the only contributing source.

Recommended Action Contact the Cisco TAC for assistance.

766301

Error Message `%ASA-7-766301: CTS Policy: Security-group tag sgt is mapped to security-group name "sgname"`

Explanation The security group tag referenced in the policy is known and the lookup in the security group table is successful. As a result, the tag name mapping is derived.

- *sgt*—Security group tag referenced in the policy
- *sgname*—Security group name mapping derived from the table

Recommended Action None required.

766302

Error Message `%ASA-7-766302: CTS Policy: Unknown security-group tag sgt referenced in policies`

Explanation The security group tag referenced in the policy was unknown and the lookup in the security group table failed. However, the policy referencing the tag can still be enforced.

- *sgt*—Security group tag referenced in the policy

Recommended Action Check to see if the security group tag exists in the ISE. If the tag exists, it will become known after the next refresh. If the tag does not exist in the ISE, consider removing all associated policies on the ASA.

766303

Error Message `%ASA-6-766303: CTS Policy: Security-group name "sgname" is resolved to security-group tag sgt`

Explanation The securitygroup name referenced in the policy was resolved and the lookup in the security group table was successful. As a result, the tag derived from the table is used for policy enforcement.

- *sgname*—Security group name referenced in the policy
- *sgt*—Security group tag mapping derived from the table

Recommended Action None required.

766304

Error Message `%ASA-4-766304: CTS Policy: Unresolved security-group name "sgname" referenced, policies based on this name will be inactive`

Explanation The securitygroup name referenced in the policy cannot be resolved to a tag and the lookup in the security group table failed. AS a result, the policy referencing the name is inactive, but remains in the configuration.

- *sgname*—Security group name referenced in the policy

Recommended Action Check to see if the security group name exists in the ISE. If the name exists, the table can be refreshed so the name gets resolved and policies can be enforced. If the name does not exist in the ISE, consider removing all associated policies on the ASA.

766305

Error Message `%ASA-4-766305: CTS Policy: Security-group table cleared, all polices referencing security-group names will be deactivated`

Explanation The security group table downloaded from the ISE is cleared on the ASA and policies based on security group tags continue to be enforced. However, policies based on names become inactive, but remain in the configuration.

Recommended Action Refresh the securitygroup table on the ASA so all policies based on security group names can be enforced.

766307

Error Message `%ASA-7-766307: CTS Policy: Security-group name for security-group tag sgt renamed from old_sgname" to "new_sgname"`

Explanation In the newly downloaded security group table on the ASA, a change in the security group name for a security group tag was detected; however, there was no change in policy status.

- *sgt*—Security group tag referenced in the policy
- *old_sgname*—Old security group name
- *new_sgname*—New security group name

Recommended Action None required.

766308

Error Message `%ASA-7-766308: CTS Policy: Previously unknown security-group tag sgt is now mapped to security-group name "sgname"`

Explanation In the newly downloaded security group table on the ASA, a previously unknown security group tag was found in the table; however, there was no change in policy status.

- *sgt*—Security group tag referenced in the policy
- *sgname*—Security group name derived from the new security group table

Recommended Action None required.

766309

Error Message `%ASA-5-766309: CTS Policy: Previously known security-group tag sgt is now unknown`

Explanation In the newly downloaded security group table on the ASA, a previously known security group tag no longer exists. There is no change in policy status, and the policy can still be enforced.

- *sgt*—Security group tag referenced in the policy

Recommended Action If the security group tag does not exist in the new table, the security group has been removed in the ISE. Consider removing all policies that reference the tag.

766310

Error Message `%ASA-5-766310: CTS Policy: Security-group name "sgname" remapped from security-group tag old_sgt to new_sgt`

Explanation In the newly downloaded security group table on the ASA, a change in the security group tag for a security group name was detected. All policies referencing the name are updated to reflect the new tag, and policies are enforced based on the new tag.

- *sgname*—Security group name referenced in the policy
- *old_sgt*—Old security group tag
- *new_sgt*—New security group tag

Recommended Action Because of the change in tag value, make sure that the configured policies are still accurate.

766311

Error Message `%ASA-6-766311: CTS Policy: Previously unresolved security-group name "sgname" is now resolved to security-group tag sgt`

Explanation In the newly downloaded security group table on the ASA, a previously unresolved security group name was resolved to a tag, and the new tag can be used to enforce policies.

- *sgname*—Security group name referenced in the policy
- *sgt*—Security group tag derived from the new security group table

Recommended Action None required.

766312

Error Message `%ASA-4-766312: CTS Policy: Previously resolved security-group name "sgname" is now unresolved, policies based on this name will be deactivated`

Explanation In the newly downloaded security group table on the ASA, a previously resolved security group name no longer exists. As a result, all policies based on this security group name become inactive, but remain in the configuration.

- *sgname*—Security group name referenced in the policy

Recommended Action If the security group name does not exist in the new table, the security group has been removed in the ISE. Check the policy configuration on the ASA, consider removing policies referencing the name.

766313

Error Message `%ASA-3-766313: CTS Policy: Failure to update policies for security-group "sgname"-sgt`

Explanation An error was encountered in updating the policies. Policy enforcement will continue based on old tag values and is no longer accurate.

- *sgname*—Security group name that has a change in tag value
- *sgt*—New security group tag value

Recommended Action To reflect the correct tag value, remove all policies referencing the security group name and reapply them. If the error persists, contact the Cisco TAC for assistance.

767001

Error Message `%ASA-6-767001: Inspect-name: Dropping an unsupported IPv6/IP46/IP64 packet from interface:IP Addr to interface:IP Addr (fail-close)`

Explanation A fail-close option was set for a service policy, and a particular inspect received an IPv6, IP64, or IP46 packet. Based on the fail-close option setting, this syslog message is generated and the packet is dropped.

Recommended Action None required.

768001

Error Message `%ASA-3-768001: QUOTA: resource utilization is high: requested req, current curr, warning level level`

Explanation A system resource allocation level has reached its warning threshold. In the case of a management session, the resource is simultaneous administrative sessions.

- *resource*—The name of the system resource; in this case, it is a management session.
- *req*—The number requested; for a management session, it is always 1.
- *curr*—The current number allocated; equals *level* for a management session
- *level*—The warning threshold, which is 90 percent of the configured limit

Recommended Action None required.

768002

Error Message `%ASA-3-768002: QUOTA: resource quota exceeded: requested req, current curr, limit limit`

Explanation A request for a system resource would have exceeded its configured limit and was denied. In the case of a management session, the maximum number of simultaneous administrative sessions on the system has been reached.

- *resource*—The name of the system resource; in this case, it is a management session.
- *req*—The number requested; for a management session, it is always 1.
- *curr*—The current number allocated; equals *level* for a management session
- *limit*—The configured resource limit

Recommended Action None required.

768003

Error Message `%ASA-4-768003: SSH: connection timed out: username` *`username`*`, IP` *`ip`*

Explanation An SSH session was disconnected because of inactivity.

- *username*—The name of the user
- *ip*—The IP address of the user

Recommended Action None required.

769001

Error Message `%ASA-5-769001: UPDATE: ASA image` *`src`* `was added to system boot list`

Explanation The system image has been updated. The name of a file previously downloaded onto the system has been added to the system boot list.

- *src*—The name or URL of the source image file

Recommended Action None required.

769002

Error Message `%ASA-5-769002: UPDATE: ASA image` *`src`* `was copied to` *`dest`*

Explanation The system image has been updated. An image file has been copied onto the system.

- *src*—The name or URL of the source image file
- *dest*—The name of the destination image file

Recommended Action None required.

769003

Error Message `%ASA-5-769003: UPDATE: ASA image` *`src`* `was renamed to` *`dest`*

Explanation The system image has been updated. An existing image file has been renamed to an image file name in the system boot list.

- *src*—The name or URL of the source image file
- *dest*—The name of the destination image file

Recommended Action None required.

769004

Error Message `%ASA-5-769004: UPDATE: ASA image checksum error copying src to dest`

Explanation The image verification test failed during the copying of an image file.

- *src*—The file name or URL of the source image file
- *dest*—The file name of the destination image file

Recommended Action Try to update using another source image file.

770001

Error Message `%ASA-4-770001: Resource resource allocation is more than the permitted list of limit for this platform. If this condition persists, the ASA will be rebooted.`

Explanation The CPU or memory resource allocation for the ASA virtual machine has exceeded the allowed limit for this platform. This condition does not occur unless the setting for the ASA virtual machine has been changed from that specified in the software downloaded from Cisco.

Recommended Action To continue ASA operation, change the CPU or memory resource allocation of the virtual machine to what was specified with the software downloaded from Cisco or to the resource limits specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

770002

Error Message `%ASA-1-770002: Resource resource allocation is more than the permitted limit for this platform. ASA will be rebooted.`

Explanation The CPU or memory resource allocation for the ASA virtual machine has exceeded the allowed limit for this platform. This condition does not occur unless the setting for the ASA virtual machine has been changed from that specified in the software downloaded from Cisco. The ASA will continue to reboot if the resource allocation is not changed.

Recommended Action Change the CPU or memory reosurce allocation to the virtual machine to what was specified with the software downloaded from Cisco or to the resource limits specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

770003

Error Message `%ASA-4-770003: Resource resource allocation is less than the minimum requirement of value for this platform. If this condition persists, performance will be lower than normal.`

Explanation The CPU or memory resource allocation to the ASA virtual machine is less than the minimum requirement for this platform. If this condition persists, performance will be lower than normal.

Recommended Action To continue ASA operation, change the CPU or memory reosurce allocation of the virtual machine to what was specified with the software downloaded from Cisco or see the memory limit and CPU reservation settings specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

770001

Error Message `%ASA-4-770001: Resource resource allocation is more than the permitted list of limit for this platform. If this condition persists, the ASA will be rebooted.`

Explanation The CPU or memory resource allocation for the ASA virtual machine has exceeded the allowed limit for this platform. This condition does not occur unless the setting for the ASA virtual machine has been changed from that specified in the software downloaded from Cisco.

Recommended Action To continue ASA operation, change the CPU or memory resource allocation of the virtual machine to what was specified with the software downloaded from Cisco or to the resource limits specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

770002

Error Message `%ASA-1-770002: Resource resource allocation is more than the permitted limit for this platform. ASA will be rebooted.`

Explanation The CPU or memory resource allocation for the ASA virtual machine has exceeded the allowed limit for this platform. This condition does not occur unless the setting for the ASA virtual machine has been changed from that specified in the software downloaded from Cisco. The ASA will continue to reboot if the resource allocation is not changed.

Recommended Action Change the CPU or memory reosurce allocation to the virtual machine to what was specified with the software downloaded from Cisco or to the resource limits specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

770003

Error Message `%ASA-4-770003: Resource resource allocation is less than the minimum requirement of value for this platform. If this condition persists, performance will be lower than normal.`

Explanation The CPU or memory resource allocation to the ASA virtual machine is less than the minimum requirement for this platform. If this condition persists, performance will be lower than normal.

Recommended Action To continue ASA operation, change the CPU or memory reosurce allocation of the virtual machine to what was specified with the software downloaded from Cisco or see the memory limit and CPU reservation settings specified in the *Cisco ASA 1000V CLI Configuration Guide* for this platform.

771001

Error Message `%ASA-5-771001: CLOCK: System clock set, source: src, before: time, after: time`

Explanation The system clock was set from a local source.

- *src*—The time protocol, which can be any of the following: NTP, SNTP, VINES, or the RFC-868 time protocol
- *ip*—The IP address of the time server
- *time*—The time string in the form, “Sun Apr 1 12:34:56.789 EDT 2012”

Recommended Action None required.

771002

Error Message `%ASA-5-771002: CLOCK: System clock set, source: src, IP ip, before: time, after: time`

Explanation The system clock was set from a remote source.

- *src*—The time source, which can be either manual or hardware calendar
- *ip*—The IP address of the time server
- *time*—The time string in the form, “Sun Apr 1 12:34:56.789 EDT 2012”

Recommended Action None required.

772002

Error Message `%ASA-3-772002: PASSWORD: console login warning, user username, cause: password expired`

Explanation A user logged into the system console with an expired password, which is permitted to avoid system lockout.

- *username*—The name of the user

Recommended Action The user should change the login password.

772003

Error Message `%ASA-2-772003: PASSWORD: session login failed, user username, IP ip, cause: password expired`

Explanation A user logged tried to log into the system with an expired password and was denied access.

- *session*—The session type, which can be SSH or Telnet
- *username*—The name of the user
- *ip*—The IP address of the user

Recommended Action If the user has authorized access, an administrator must change the password for the user. Unauthorized access attempts should trigger an appropriate response, for example. traffic from that IP address can be blocked.

772004

Error Message `%ASA-3-772004: PASSWORD: session login failed, user username, IP ip, cause: password expired`

Explanation A user logged tried to log into the system with an expired password and was denied access.

- *session*—The session type, which is ASDM
- *username*—The name of the user
- *ip*—The IP address of the user

Recommended Action If the user has authorized access, an administrator must change the password for the user. Unauthorized access attempts should trigger an appropriate response, for example. traffic from that IP address can be blocked.

772005

Error Message `%ASA-6-772005: REAUTH: user username passed authentication`

Explanation The user authenticated successfully after changing the password.

- *username*—The name of the user

Recommended Action None required.

772006

Error Message `%ASA-2-772006: REAUTH: user username failed authentication`

Explanation The user entered the wrong password while trying to change it. As a result, the password was not changed.

- *username*—The name of the user

Recommended Action The user should retry changing the password using the **change-password** command.

774001

Error Message `%ASA-2-774001: POST: unspecified error`

Explanation The crypto service provider failed the power on self-test.

Recommended Action Contact the Cisco TAC.

774002

Error Message `%ASA-2-774002: POST: error err, func func, engine eng, algorithm alg, mode mode, dir dir, key len len`

Explanation The crypto service provider failed the power on self-test.

- *err*—The failure cause
- *func*—The function
- *eng*—The engine, which can be NPX, Nlite, or software
- *alg*—The algorithm, which can be any of the following: RSA, DSA, DES, 3DES, AES, RC4, MD5, SHA1, SHA256, SHA386, SHA512, HMAC-MD5, HMAC-SHA1, HMAC-SHA2, or AES-XCBC
- *mode*—The mode, which can be any of the following: none, CBC, CTR, CFB, ECB, stateful-RC4, or stateless-RC4

- *dir*—Either encryption or decryption
- *len*—The key length in bits

Recommended Action Contact the Cisco TAC.

775001

Error Message `%ASA-6-775001: Scansafe: protocol connection conn_id from interface_name:real_address/real_port [(idfw_user)] to interface_name:real_address/real_port redirected to server_interface_name:server_ip_address`

Explanation A ScanSafe server is configured, and traffic matches a policy that has been configured to redirect the connection to the ScanSafe server for content scanning and other malware protection services.

Recommended Action None required.

775002

Error Message `%ASA-4-775002: Reason - protocol connection conn_id from interface_name:real_address/real_port [(idfw_user)] to interface_name:real_address/real_port is action locally`

Explanation If the source IP address and port of the new ScanSafe redirected connection matches the existing connection, then the ASA drops the new connection and this syslog message is generated.

- *Reason* —Duplicate connection with same source *address* and port *port*

Recommended Action Make sure of all of the following:

- The ScanSafe license key is configured.
- The public key is configured.
- The ScanSafe server is reachable by the ASA.
- The maximum number of connections has not been reached.

Note Configuring PAT and ScanSafe on a single connection are not recommended.

775003

Error Message %ASA-6-775003: Scansafe:*protocol* connection *conn_id* from *interface_name*:*real_address*/*real_port* [(*idfw_user*)] to *interface_name*:*real_address*/*real_port* is whitelisted.

Explanation The traffic has been matched and does not need to be redirected to the ScanSafe server for content scanning, but can be sent directly to the intended web server.

Recommended Action None required.

775004

Error Message %ASA-4-775004: Scansafe: Primary server *ip_address* is not reachable

Explanation The primary ScanSafe server is not reachable on either of the configured HTTP or HTTPS ports.

Recommended Action None required.

775005

Error Message %ASA-6-775005: Scansafe: Primary server *ip_address* is reachable now

Explanation The primary ScanSafe server is reachable on both of the configured HTTP and HTTPS ports.

Recommended Action None required.

775006

Error Message %ASA-6-775006: Primary server *interface*:*ip_address* is not reachable and backup server *interface*:*ip_address* is now active

Explanation If the primary ScanSafe server becomes unreachable, the ASA checks the connectivity to the configured backup ScanSafe server; if the backup server is reachable, it becomes the active server.

Recommended Action None required.

775007

Error Message `%ASA-2-775007: Scansafe: Primary server_interface_name:server_ip_address and backup server_interface_name:server_ip_address servers are not reachable.`

Explanation Neither the primary nor backup ScanSafe server is reachable. Based on the configured default action(fail_close or fail_open), traffic is getting dropped or sent to the web server without being redirected.

Recommended Action If both the ScanSafe servers are not reachable, you can change the ScanSafe configuration to fail_open to send traffic to the web server without having it redirected to the ScanSafe server. This configuration changes the default action to permit.

778001

Error Message `%ASA-6-778001: VXLAN: Invalid VXLAN segment-id segment-id for protocol from ifc-name:(IP-address/port) to ifc-name:(IP-address/port).`

Explanation The ASA tries to create an inner connection for a VXLAN packet, but the VXLAN packet has an invalid segment ID.

Recommended Action None required.

778002

Error Message `%ASA-6-778002: VXLAN: There is no VNI interface for segment-id segment-id.`

Explanation A decapsulated ingress VXLAN packet is discarded, because the segment ID in the VXLAN header does not match the segment ID of any VNI interface configured on the ASA.

Recommended Action None required.

778003

Error Message `%ASA-6-778003: VXLAN: Invalid VXLAN segment-id segment-id for protocol from ifc-name:(IP-address/port) to ifc-name:(IP-address/port) in FP.`

Explanation The ASA Fast Path sees a VXLAN packet with an invalid segment ID.

Recommended Action Check the VNI interface segment ID configurations to see if the dropped packet has the VXLAN segment ID that does not match any VNI segment ID configuration.

778004

Error Message %ASA-6-778004: VXLAN: Invalid VXLAN header for *protocol* from *ifc-name*:(IP-address/port) to *ifc-name*:(IP-address/port) in FP.

Explanation The ASA VTEP sees a VXLAN packet with an invalid VXLAN header.

Recommended Action None required.

778005

Error Message %ASA-6-778005: VXLAN: Packet with VXLAN segment-id *segment-id* from *ifc-name* is denied by FP L2 check.

Explanation A VXLAN packet is denied by a Fast Path L2 check.

Recommended Action Check the VNI interface segment ID configurations to see if the dropped packet has the VXLAN segment ID that does not match any VNI segment ID configuration. Check to see i f the STS table has an entry that matches the dropped packet's segment ID.

778006

Error Message %ASA-6-778006: VXLAN: Invalid VXLAN UDP checksum from *ifc-name*:(IP-address/port) to *ifc-name*:(IP-address/port) in FP.

Explanation The ASA VTEP received a VXLAN packet with an invalid UDP checksum value.

Recommended Action None required.

778007

Error Message %ASA-6-778007: VXLAN: Packet from *ifc-name*:IP-address/port to IP-address/port was discarded due to invalid NVE peer.

Explanation The ASA VTEP received a VXLAN packet from an IP address that is different from the configured NVE peer.

Recommended Action None required.

779001

Error Message %ASA-6-779001: STS: Out-tag lookup failed for in-tag *segment-id* of *protocol* from *ifc-name*:*IP-address*/*port* to *IP-address*/*port*.

Explanation The ASA tries to create a connection for a VXLAN packet, but failed to use the STS lookup table to locate the out-tag for the in-tag (segment ID) in the VXLAN packet.

Recommended Action None required.

779002

Error Message %ASA-6-779002: STS: STS and NAT locate different egress interface for segment-id *segment-id*, *protocol* from *ifc-name*:*IP-address*/*port* to *IP-address*/*port*

Explanation The ASA tries to create a connection for a VXLAN packet, but the STS lookup table and NAT policy locate a different egress interface.

Recommended Action None required.

779003

Error Message %ASA-3-779003: STS: Failed to read tag-switching table - *reason*

Explanation The ASA tried to read the tag-switching table, but failed.

Recommended Action None required.

779004

Error Message %ASA-3-779004: STS: Failed to write tag-switching table - *reason*

Explanation The ASA tried to write to the tag-switching table, but failed.

Recommended Action None required.

779005

Error Message `%ASA-3-779005: STS: Failed to parse tag-switching request from http - reason`

Explanation The ASA tried to parse the HTTP request to see what to do on the tag-switching table, but failed.

Recommended Action None required.

779006

Error Message `%ASA-3-779006: STS: Failed to save tag-switching table to flash - reason`

Explanation The ASA tried to save the tag-switching table to flash memory, but failed.

Recommended Action None required.

779007

Error Message `%ASA-3-779007: STS: Failed to replicate tag-switching table to peer - reason`

Explanation The ASA attempts to replicate the tag-switching table to the failover standby unit or clustering slave units, but failed to do so.

Recommended Action None required.

780001

Error Message `%ASA-6-780001: RULE ENGINE: Started compilation for access-group transaction - description of the transaction.`

Explanation The rule engine has started compilation for an access group transaction. The description of the transaction is the command line input of the access group itself.

Recommended Action None required.

780002

Error Message `%ASA-6-780002: RULE ENGINE: Finished compilation for access-group transaction - description of the transaction.`

Explanation The rule engine has finished compilation for a transaction. Taking access group as an example, the description of the transaction is the command line input of the access group itself.

Recommended Action None required.

780003

Error Message `%ASA-6-780003: RULE ENGINE: Started compilation for nat transaction - description of the transaction.`

Explanation The rule engine has started compilation for a NAT transaction. The description of the transaction is the command line input of the **nat** command itself.

Recommended Action None required.

780004

Error Message `%ASA-6-780004: RULE ENGINE: Finished compilation for nat transaction - description of the transaction.`

Explanation The rule engine has finished compilation for a NAT transaction. The description of the transaction is the command line input of the **nat** command itself.

Recommended Action None required.