



INDEX

Numerics

802.1x Wired Client [4-4](#), [9-1](#)

- administrative version [9-4](#)
- administrator's main window [9-8](#)
- authentication methods [9-16](#)
- authentication policies [9-24](#)
- authentication policy summary [9-12](#)
- authentication retries [9-34](#)
- automatically establish machine connection [9-27](#)
- changing authentication profile [9-44](#)
- changing deployment packages [9-44](#)
- client version [9-4](#)
- connection status description [9-8](#)
- connection status details [9-10](#)
- connection status window [9-14](#)
- creating authentication policies [9-26](#)
- creating authentication profiles [9-35](#)
- creating machine and user authentication deployment package [9-38](#)
- creating machine only authentication deployment package [9-40](#)
- creating user authentication deployment package [9-36](#)

- credential revalidation [9-23](#)
- credentials expiring [9-23](#)
- deploying end-user 802.1x wired clients [9-35](#)
- deploying trusted servers [9-31](#)
- description [9-1](#)
- enabling connection status [9-9](#)
- features [9-3](#)
- forcing credential revalidation [9-23](#)
- installing [4-17](#)
- installing authentication profiles [9-43](#)
- installing deployment packages [9-43](#)
- installing server certificates for machine connection [9-42](#)
- installing server certificates for user connection [9-43](#)
- launching client [9-11](#)
- logging [10-1](#)
- Machine Auth (Boot-time) [9-28](#)
- Machine Auth (Logon time) [9-28](#)
- machine authentication description [9-16](#)
- machine authentication only [9-27](#)
- machine authentication requirements [9-16](#)
- machine certificate credentials [9-22](#)
- machine connections after PAC [9-19](#)

- machine connections before PAC [9-18](#)
- machine credentials [9-21](#)
- machine SID credentials [9-22](#)
- main window description [9-7](#)
- manually connecting to a port [9-12](#)
- manually disconnecting from a port [9-12](#)
- network adapter information box [9-11](#)
- network configuration summary window [9-13](#)
- networks.xml file [9-25, 9-26](#)
- opening client [9-11](#)
- overview [9-16](#)
- overview of EAP-FAST connections [9-17, 9-18](#)
- policy.xml file [9-24, 9-26](#)
- request password [9-27](#)
- role in NAC [9-1](#)
- send anonymous in clear [9-33](#)
- sent username in clear [9-33](#)
- station policy window [9-26](#)
- system report [10-1, 10-15, 10-16](#)
- technical log [10-1, 10-2](#)
- technical log content [10-5](#)
- technical log format [10-3](#)
- troubleshooting [10-1](#)
- trusted server validation [9-29](#)
- user and machine authentication description [9-16](#)
- user authentication description [9-16](#)
- user certificate credentials [9-20, 9-21](#)

- user connections after PAC [9-18](#)
- user connections before PAC [9-17](#)
- user credential provisioning [9-20](#)
- user credentials [9-20](#)
- user credentials area [9-27](#)
- user identity protection [9-32](#)
- user interface [9-4, 9-26](#)
- user password credentials [9-20, 9-21](#)
- use single sign-on [9-27](#)
- viewing access device status [9-13](#)
- Windows operating system support [4-3](#)
- Windows service [4-30](#)

A

ACS

- see Cisco Secure Access Control Server

- asynchronous status query [5-19](#)

- authentication profiles

- adding to custom installation [4-25](#)

- authentication servers [1-2](#)

B

- browser auto-launch feature [5-24](#)

C

- Certificate DN matching [5-25](#)

certificates

- ACS root certificate [8-3](#)
- adding to custom installation [2-6, 3-13, 4-24](#)
- certificate formats allowed [8-3](#)
- certificate utility [8-3](#)
- clearing Linux certificate store [8-9](#)
- clearing Mac OS X certificate store [8-10](#)
- converting DER to PEM format [8-14](#)
- ctaCert.exe utility [8-3](#)
- CTA supported certificates [8-3](#)
- deleting from Linux certificate store [8-8](#)
- deleting from Mac OS X certificate store [8-7](#)
- DN matching [5-25](#)
- for machine and user authentication [8-13](#)
- for machine authentication [8-10](#)
- for user authentication [8-12](#)
- importing user certificate [8-12](#)
- installing [8-3, 8-4](#)
- installing on Linux [8-4](#)
- installing on Mac OS X [8-4](#)
- installing on Windows [8-5](#)
- listing certificates in Linux certificate store [8-6](#)
- listing certificates in store [8-6](#)
- obtaining from Cisco Secure ACS [8-3](#)
- updating [8-3, 8-4](#)
- updating on Linux [8-4](#)
- updating on Mac OS X [8-4](#)
- updating on Windows [8-5](#)

- use with Cisco Trust Agent [8-1](#)

certificate utility

- about [8-3](#)
- adding certificate to Windows store [8-5](#)
- command parameters in Windows [8-5](#)
- deleting certificates in Mac OS X store [8-9](#)
- Linux operating system
 - clearing all certificates from store [8-9](#)
 - deleting certificates from store [8-8](#)
 - listing certificates in store [8-6](#)
- listing certificates in store [8-6](#)
- Mac OS X
 - clearing all certificates from store [8-10](#)
 - listing certificates in store [8-7](#)
- using on Linux [8-6](#)
- using on Windows [8-5](#)

Cisco Secure Access Control Server (ACS) [xi, 1-2](#)

- certificates [8-1](#)
- managing stale posture data [11-22](#)
- role in NAC [1-2](#)
- role in posture validation [1-2 to 1-4](#)
- write_time_stamp.ini file [11-23](#)

Cisco Security Agent (CSA) [1-2](#)

- role in NAC [1-2](#)
- used to install CTA [B-1](#)

ciscotouser

- permissions for posture scripts [11-15](#)

Cisco Trust Agent (CSA)

- use of certificates [8-1](#)

Cisco Trust Agent (CTA) [xi](#)802.1x Wired Client [9-1](#)additional features [4-4](#)alternate methods of installing [B-1](#)configuring [5-1](#)deployment options [1-5](#)installing on Linux operating systems [2-1](#)installing on Mac OS X [3-1](#)installing on Windows operating systems [4-1](#)installing using Cisco Security Agent [B-1](#)

Linux daemons

ctad [2-8](#)ctaeoud [2-9](#)ctalogd [2-9](#)ctapsd [2-9](#)logging [6-1](#)

Mac OS X daemons

ctad [3-16](#)ctaeoud [3-16](#)ctalogd [3-16](#)ctapsd [3-16](#)open-source license acknowledgement [C-1](#)overview [1-1](#)purpose [xi](#)role in NAC [1-1](#)role in posture validation [1-2 to 1-4](#)scripting interface [11-1](#)statistics utility [A-1](#)supplicant [9-1](#)use of posture plugins [7-1](#)

Windows daemons

Cisco Posture Server Daemon [4-30](#)Cisco Systems Inc. CTA Posture State Daemon [4-30](#)Cisco Trust Agent EoU Daemon [4-30](#)Cisco Trust Agent Logger Daemon [4-30](#)Clickable URL feature [5-23](#)clogcli utility [6-4](#)clearing current log files [6-5](#)collecting log files [6-10](#)commands [6-5](#)disabling logging [6-5](#)enabling logging [6-6](#)location on Linux operating system [6-4](#)location on Mac OS X [6-4](#)location on Windows operating system [6-4](#)logging level explanation [6-11](#)running [6-5](#)setting log file location [6-7](#)setting logging level [6-8](#)zipit command [6-10](#)

configuration files

ctad.ini file [5-2](#)ctalogd.ini file [6-13](#)configuring Cisco Trust Agent [5-1, 5-16, 5-17, 5-18, 5-19](#)behavior of posture notifications [5-7](#)blocking or non-blocking plugins [5-5](#)

- clearing or saving old posture notifications [5-10](#)
- configuring status query timer [5-6](#)
- ctad.ini file [5-2](#)
- ctalogd.ini file [6-4](#)
- defining communication port for EAPoUDP [5-6](#)
- displaying posture messages in GUI [5-9](#)
- display time of pop-up notifications [5-9](#)
- distinguished name matching [5-11](#)
- distinguished name matching parameters [5-11](#)
- EAP over UDP communication [5-12](#)
- EAP over UDP session idle timeout [5-7](#)
- editing the ctad.ini file [5-3](#)
- enabling or disabling pop-up posture messages [5-8](#)
- font used to display messages in terminal [5-10](#)
- for Windows XP SP-2 or SP-3 firewall [5-7](#)
- logging [6-4](#)
- maximum EAP over UDP sessions [5-7](#)
- notification pop-up modality [5-8](#)
- parameter descriptions [5-4](#)
- pop-up notifications received before logon [5-9](#)
- posture plugin interaction with CTA [5-13](#)
- posture plugins [5-13](#)
- posture pop-up notifications [5-20](#), [5-23](#)
- posture pop-up notifications on Linux [5-21](#)
- posture pop-up notifications on Mac OS X [5-22](#)
- posture pop-up notifications on Windows [5-20](#)
- query plugin for posture status [5-19](#)
- receive posture message after obtaining IP address [5-8](#)
- saving posture notifications [5-9](#)
- scripting interface parameter [5-11](#)
- setting application-specific posture message [5-6](#)
- setting browser path on Linux [5-10](#)
- setting default posture message size [5-6](#)
- time before posture database record is outdated [5-11](#)
- timeout for non-blocking plugins [5-5](#)
- user notifications [5-20](#), [5-23](#)
- user notifications on Linux [5-21](#)
- user notifications on Mac OS X [5-22](#)
- user notifications on Windows [5-20](#)
- Windows
 - SysModal parameter [5-21](#)
- CSA
 - see Cisco Security Agent
- ctacert utility
 - See certificate utility
- ctad.ini file
 - [EAPoUDP] section description [5-6](#)
 - [Scripting_Interface] section [5-11](#)
 - [ServerCertDNVerification] section [5-11](#), [5-25](#)

- [UserNotifies] section [5-7](#)
- about [5-2](#)
- adding to custom installation [2-7, 3-13, 4-25](#)
- configuring Validation-Flag TLV [5-4](#)
- ctad-temp.ini [5-2](#)
- delta_stale [11-21](#)
- editing [5-3](#)
- location [5-2](#)
- parameter descriptions [5-4](#)
 - BootTimeUDPExemptions [5-7](#)
 - BrowserPath [5-10](#)
 - ClearOldNotification [5-10](#)
 - delta_stale [5-11](#)
 - DisplayType [5-9](#)
 - EnableLogonNotifies [5-9](#)
 - EnableNotifies [5-8](#)
 - EnableVFT [5-4](#)
 - LocalPort [5-6](#)
 - LogonMsgTimeout [5-9](#)
 - MaxSessions [5-7](#)
 - MsgTimeout [5-9](#)
 - PPInterfaceType [5-5](#)
 - PPMsgSize [5-6](#)
 - PPWaitTimeout [5-5](#)
 - Rule X [5-11](#)
 - SessionIdleTimeout [5-7](#)
 - SQTimer [5-6](#)
 - SysModal [5-8](#)
 - TermFont [5-10](#)
 - TotalRules [5-11](#)
 - userActionDelayTimeout [5-8](#)
- ctad-temp.ini file
 - See ctad.ini file
- ctalogd.ini file
 - [LogLevel] section [5-24](#)
 - adding to custom installation [2-7, 4-25](#)
 - including in custom installation [3-13](#)
- ctalogd-temp.ini file [6-13](#)
 - example of [6-13](#)
 - location on Linux operating system [6-13](#)
 - location on Mac OS X [6-13](#)
 - location on Windows operating system [6-13](#)
 - See also ctalogd.ini file
- CTA posture plugin [7-2, 7-5](#)
 - application posture-token attribute [7-6](#)
 - attributes of [7-6](#)
 - for Linux operating system [7-6](#)
 - for Mac OS X [7-6](#)
 - for Windows operating system [7-6](#)
 - kernel-version attribute [7-6](#)
 - machine posture state attribute [7-6, 7-8](#)
 - operating system attribute [7-7](#)
 - operating system version attribute [7-7](#)
 - operating system release attribute [7-6](#)
 - posture agent name attribute [7-7](#)
 - posture agent version attribute [7-7](#)
 - posture message attribute [7-8](#)
 - posture token attribute [7-8](#)

- ctascriptPP.dll [11-1](#)
 - description of [11-5](#)
 - ctascriptpp.so [11-1](#)
 - description of [11-5](#)
 - ctasi [11-1](#)
 - invoked by posture script [11-18](#)
 - location of executable on Linux [11-19](#)
 - location of executable on Mac OS X [11-19](#)
 - ctasi.exe [11-1](#)
 - location on Windows [11-19](#)
 - ctastat utility
 - identifying CTA information [A-3](#)
 - identifying session information [A-3](#)
 - output [A-3](#)
 - overview [A-1](#)
 - running on Linux [A-2](#)
 - running on Mac OS X [A-2](#)
 - running on Windows [A-2](#)
 - sample output [A-4](#)
 - customized installation
 - deployment considerations [1-5](#)
 - Linux operating system [2-5](#)
 - benefits of [2-6](#)
 - including certificates [2-6](#)
 - including ctad.ini file [2-7](#)
 - including ctalogd.ini file [2-7](#)
 - including posture plugins [2-7](#)
 - Mac OS X
 - benefits of [3-12](#)
 - ctad.ini file [3-13](#)
 - including certificates [3-13](#)
 - including ctad.ini file [3-13](#)
 - including ctalogd.ini file [3-13](#)
 - including posture plugins [3-13](#)
 - Windows operating system [4-22, 4-24](#)
 - 802_1x directory [4-25](#)
 - benefits of [4-24](#)
 - including authentication profiles [4-25](#)
 - including certificates [4-24](#)
 - including ctad.ini file [4-25](#)
 - including ctalogd.ini file [4-25](#)
 - including plugins [4-24](#)
 - installation directory [4-24](#)
 - install customized package [4-25](#)
-
- ## D
- delta_stale parameter [11-21](#)
 - deploying Cisco Trust Agent [1-5, 2-3](#)
 - benefit of custom package [2-3](#)
 - initial deployment options [2-3](#)
 - distinguished name matching
 - See DN matching
 - DN matching
 - about [5-25, 8-14](#)
 - about rules [8-14](#)
 - attributes supported [5-26](#)
 - issuer attributes [5-26](#)

parameters in ctad.ini file [5-11](#)

rule length [5-25](#)

rules [5-25](#)

sub-rule operators [5-25](#)

sub-rules [5-25](#)

when occurs [8-14](#)

documentation

additional reading [xiv](#)

text conventions [xiii](#)

E

EAP-FAST connections

machine credentials context [9-18](#)

overview [9-17, 9-18](#)

user logon context [9-17](#)

EAP over UDP

configuring communication [5-12](#)

configuring communication port [5-6](#)

H

host posture plugin [7-2](#)

attributes of [7-3](#)

Linux package attribute [7-3](#)

Linux package information [7-4](#)

location on Linux [7-2](#)

location on Mac OS X [7-2](#)

location on Windows [7-2](#)

MAC address attribute [7-3](#)

MAC address information [7-3](#)

machine name attribute [7-3](#)

Mac OS X package attribute [7-3](#)

Mac OS X package information [7-5](#)

Windows hot fix attribute [7-3](#)

Windows service pack attribute [7-3](#)

installation files

Linux operating system [2-3](#)

Mac OS X operating system [3-3](#)

Windows operating system

CTA with 802.1x Wired Client [4-5](#)

CTA without 802.1x Wired Client [4-5](#)

discontinued versions [4-5](#)

installation procedures

Linux operating system [2-4](#)

accepting EULA [2-4](#)

command line procedure [2-5](#)

customized installation [2-5](#)

extracting install file [2-4](#)

general instructions [2-4](#)

package information [2-9](#)

uninstalling CTA [2-9](#)

upgrading CTA [2-7](#)

verifying installation [2-8](#)

Mac OS X [3-3, 3-16](#)

- accepting EULA [3-4](#)
- command line procedure [3-4](#)
- extracting install file [3-4](#)
- general instructions [3-3](#)
- installation wizard [3-6](#)
- repairing [3-14](#)
- uninstalling scripting interface [3-17](#)
- upgrading [3-14](#)
- verifying installation [3-16](#)
- Windows operating system [4-5](#)
 - accepting EULA [4-6](#)
 - custom installation package [4-22](#)
 - customized installation [4-24](#)
 - extracting MSI file [4-6](#)
 - general instructions [4-6](#)
 - installation directory [4-24](#)
 - installation wizard [4-11, 4-13](#)
 - install customized package [4-25](#)
 - installing 802.1x Wired Client [4-17](#)
 - installing scripting interface [4-17](#)
 - uninstalling [4-31](#)
 - upgrading [4-27](#)
 - upgrading from CTA 1.0 [4-27](#)
 - upgrading from CTA 2.0 [4-28](#)
 - upgrading from CTA 2.0.1 [4-29](#)
 - using MSI commands [4-7](#)
 - verify CTA installation [4-30](#)

L

- licenses
 - for open-source software [C-1](#)
- log files
 - about [6-2](#)
 - collecting all log files [6-10](#)
 - creating [6-2](#)
 - format [6-3](#)
 - location on Linux operating systems [6-2](#)
 - location on Mac OS X [6-2](#)
 - location on Windows operating systems [6-2](#)
 - naming convention [6-3](#)
 - persistence [6-4](#)
 - taking up disk space [6-4](#)
- logging
 - about CTA logging [6-2](#)
 - Cisco Trust Agent [6-1](#)
 - clearing current log files [6-5](#)
 - clogcli utility [6-4, 6-5](#)
 - collecting all log files [6-10](#)
 - configuring for large deployments [6-11](#)
 - ctalogd-temp.ini file [6-13](#)
 - default setting [6-1](#)
 - disabling logging [6-5](#)
 - enabling logging [6-6](#)
 - log files [6-2](#)
 - logging level explanation [6-11](#)
 - notifications [5-24](#)

running [6-5](#)
 setting log file location [6-7](#)
 setting logging level [6-8](#)

M

machine and user authentication
 configuring by using certificates [8-13](#)
 machine authentication
 configuring by using certificates [8-10](#)
 requesting machine certificate [8-11](#)

N

NAC-L2-IP method [5-12](#)
 NAC-L3-IP method [5-12](#)
 NAD
 See network access device
 network access device (NAD) [xi, 1-2](#)
 role in NAC [1-2](#)
 role in posture validation [1-2 to 1-4](#)
 Network Admission Control (NAC) [xi](#)
 objective of [1-1](#)
 overview [1-1](#)
 network client
 definition of [1-5](#)
 network clients [1-1](#)
 notifications
 logging [5-24](#)

posture [7-1](#)

O

open source
 software licenses [C-1](#)
 open-source software
 license acknowledgement [C-1](#)

P

posture credentials [xi, 7-1](#)
 relayed by scripting interface [11-3](#)
 transfer from plugin to CTA to ACS [7-1](#)
 posture data file [11-3, 11-7](#)
 attribute definitions [11-11](#)
 creating files for Linux [11-8](#)
 creating files for Mac OS X [11-8](#)
 creating files for Windows [11-9](#)
 description of [11-7](#)
 location on Linux [11-8](#)
 location on Mac OS X [11-8](#)
 location on Windows [11-9](#)
 requirements of [11-8](#)
 sample [11-9](#)
 syntax for attribute datatype values [11-12](#)
 syntax of [11-8](#)
 posture notifications

- clearing or saving old posture notifications [5-10](#)
- configuring browser auto-launch feature [5-23](#)
- configuring clickable URL feature [5-23](#)
- configuring display time of pop-up notifications [5-9](#)
- configuring pop-up notifications received before login [5-9](#)
- configuring pop-up window [5-8](#)
- displaying posture messages in GUI [5-9](#)
- enabling or disabling pop-up message [5-8](#)
- font used to display messages in terminal [5-10](#)
- how they are sent [5-20](#)
- pop-up box modality [5-8](#)
- pop-up message parameters [5-7](#)
- saving pop-up notifications [5-9](#)
- setting browser path on Linux [5-10](#)
- posture plugins
 - adding to custom installation [2-7, 3-13, 4-24](#)
 - application posture-token attribute [7-6](#)
 - application-specific posture message size [5-17](#)
 - asynchronous status query [5-19](#)
 - configuring application-specific message size [5-6](#)
 - configuring application-specific posture message size [5-17](#)
 - configuring blocking or non-blocking interface [5-5, 5-13](#)
 - configuring default message size [5-16](#)
 - configuring default posture message size [5-6](#)
 - configuring host posture plugin message size [5-18](#)
 - configuring interaction with CTA [5-13](#)
 - configuring status query timer [5-6](#)
 - configuring Symantec posture plugin message size [5-19](#)
 - configuring timeout for non-blicking plugins [5-5](#)
 - configuring to query for status change [5-19](#)
 - CTA posture plugin [7-2, 7-5](#)
 - default message size [5-16](#)
 - definition of [7-1](#)
 - example of blocking and non-blocking interface [5-14](#)
 - host posture plugin [7-2](#)
 - host posture plugin message size [5-18](#)
 - installation process overview [7-9](#)
 - installed by default [7-2](#)
 - installing [7-9](#)
 - kernel-version attribute [7-6](#)
 - Linux host [7-2](#)
 - Linux installation directory [7-9](#)
 - Linux package attribute [7-3](#)
 - MAC address attribute [7-3](#)
 - machine name attribute [7-3](#)
 - machine posture state attribute [7-6, 7-8](#)
 - Mac OS X host [7-2](#)
 - Mac OS X installation directory [7-9](#)
 - Mac OS X package attribute [7-3](#)

- operating system attribute [7-7](#)
- operating system release attribute [7-6](#)
- operating system version number attribute [7-7](#)
- posture agent name attribute [7-7](#)
- posture agent version attribute [7-7](#)
- posture message attribute [7-8](#)
- quarantined plugin [7-10](#)
- scripting interface [11-3](#)
- scripting interface plugin [7-9](#)
- script substituting as [7-9](#)
- system posture token attribute [7-8](#)
- upgrading [7-9](#)
- Windows host [7-2](#)
- Windows hot fix attribute [7-3](#)
- Windows installation directory [7-9](#)
- Windows service pack attribute [7-3](#)
- posture scripts [11-3, 11-7](#)
 - ciscotouser [11-15](#)
 - invoking ctasi [11-18](#)
 - location for new scripts [11-14](#)
 - registering [11-14](#)
 - requirements of [11-7](#)
 - user permissions [11-15](#)
- posture token
 - definition of [7-1](#)
- posture validation [1-1](#)
 - authentication servers [1-2](#)
 - components of [1-1](#)
 - definition of [1-1](#)

- network clients [1-1](#)
- posture validation servers [1-2](#)
- process [1-2 to 1-4](#)
- posture validation servers [1-2](#)
 - role in NAC [1-2](#)

R

- repairing CTA
 - Mac OS X [3-14](#)
 - Windows [4-8](#)

S

- scripting interface [4-4](#)
 - adding attributes to ACS [11-15](#)
 - asynchronous status change notification [11-20](#)
 - creating posture data files [11-8, 11-9](#)
 - ctascript.so [11-1](#)
 - ctascriptPP.dll [11-1](#)
 - ctasi [11-1](#)
 - ctasi.exe [11-1](#)
 - executable file [11-4](#)
 - file name conventions [11-1](#)
 - information file [11-3, 11-5](#)
 - information file parameter descriptions [11-6](#)
 - installing [2-3, 3-5, 3-10, 4-17](#)
 - interaction with CTA [11-1](#)

- invoking ctasi executable [11-18](#)
- invoking on Linux [11-19](#)
- invoking on Mac OS X [11-19](#)
- invoking on Windows [11-18](#)
- making it accept the posture data file [11-19](#)
- making it ignore the posture data file [11-19](#)
- managing stale posture data [11-21](#)
- overview [11-3](#)
- posture data file [11-3](#), [11-7](#)
- posture data file attributes [11-11](#)
- posture plugin [7-9](#), [11-3](#)
- posture plugin description [11-5](#)
- posture scripts [11-3](#), [11-7](#)
- posture-validation attribute definition file [11-16](#)
- registering posture scripts [11-14](#)
- relaying posture credentials [11-3](#)
- reporting status change at layer 2 [11-20](#)
- reporting status change at layer 3 [11-20](#)
- role in NAC [11-1](#)
- sample posture data file [11-9](#)
- stale posture data [11-20](#)
- status change [11-20](#)
- syntax for attribute datatype values [11-12](#)
- uninstalling [3-17](#)
- scripting interface posture plugin [7-9](#)
 - description of [11-5](#)
- supplicant
 - logging [10-1](#)
 - See 802.1x Wired Client

- system requirements
 - Linux installer [2-2](#)
 - Linux operating system [2-2](#)
 - hard disk space [2-2](#)
 - listening port [2-3](#)
 - memory [2-3](#)
 - operating systems version [2-2](#)
 - processor [2-2](#)
 - Mac OS X [3-2](#)
 - hard disk space [3-2](#)
 - listening port [3-2](#)
 - memory [3-2](#)
 - operating systems version [3-2](#)
 - processor [3-2](#)
 - Windows operating system [4-2](#)
 - hard disk space [4-2](#)
 - installer [4-2](#)
 - listening port [4-2](#)
 - memory [4-2](#)
 - processor [4-2](#)
- system requirements [4-2](#)

T

- Text conventions [xiii](#)
- transport layer security (TLS) [5-25](#)

U

uninstalling CTA

- Linux operating system [2-9](#)
- Mac OS X [3-16](#)
- Windows operating system [4-31](#)

upgrading CTA

- compatibility of authentication profiles from CTA 2.0 [4-28](#)
- Linux operating system [2-7](#)
- Mac OS X [3-14](#)
- Windows operating system
 - from CTA 1.0 [4-27](#)
 - from CTA 2.0 [4-28](#)
 - from CTA 2.0.1 [4-29](#)

user authentication

- configuring by using certificates [8-12](#)
- importing user certificate [8-12](#)

user credentials

- expiring [9-23](#)
- forcing revalidation [9-23](#)

user notifications

- logging notifications [5-24](#)
- posture notifications [7-1](#)

installing [4-7](#)

installing optional features [4-9](#)

quiet mode [4-11](#)

reboot options [4-11](#)

reinstalling or repairing [4-8](#)

uninstalling [4-8](#)

Windows operating systems

- support for 802.1x Wired Client [4-3](#)
- support for CTA [4-3](#)

W

Windows MSI commands

[4-7](#)

- changing installation directory [4-10](#)