



A

add, edit active directory servers [3-6](#)
 add, edit consumer device [3-4](#)
 add, edit syslog servers [3-11](#)
 adding administrator [3-19](#)
 AD machines [1-4](#)
 AD requirements [2-4](#)

B

browser support [3-1](#)

C

cautions

description [ii-x](#)

commands

configuration

backup-staging-url [4-82](#)
 cdp holdtime [4-82](#)
 cdp run [4-83](#)
 cdp timer [4-84](#)
 clock timezone [4-85](#)
 do [4-87](#)
 end [4-90](#)
 exit [4-90](#)
 hostname [4-91](#)
 icmp echo [4-92](#)
 interface [4-92](#)
 ip address [4-97](#)
 ip default-gateway [4-98](#)
 ip domain-name [4-98](#)

ip name-server [4-99](#)
 ip route [4-100](#)
 ipv6 autoconfig [4-93](#)
 ipv6 dhcp [4-95](#)
 kron occurrence [4-101](#)
 kron policy-list [4-102](#)
 logging [4-103](#)
 ntp authenticate [4-106](#)
 ntp authentication [4-105](#)
 ntp authentication-key [4-107](#)
 ntp server [4-108](#)
 ntp trusted-key [4-110](#)
 password-policy [4-111](#)
 repository [4-112](#)
 service [4-114](#)
 shutdown [4-115](#)
 snmp-server community [4-116](#)
 snmp-server contact [4-117](#)
 snmp-server host [4-118](#)
 snmp-server location [4-118](#)
 username [4-119](#)

EXEC

application install [4-2](#)
 application remove [4-3](#)
 application reset-config [4-4](#)
 application reset-passwd [4-6](#)
 application start [4-7](#)
 application stop [4-8](#)
 application upgrade [4-9](#)
 backup [4-10](#)
 backup-logs [4-11](#)
 clock [4-12](#)
 configure [4-13](#)

REVIEW DRAFT—CISCO CONFIDENTIAL

- copy [4-14](#)
 - debug [4-17](#)
 - delete [4-20](#)
 - dir [4-21](#)
 - exit [4-23](#)
 - forceout [4-24](#)
 - halt [4-24](#)
 - help [4-25](#)
 - mkdir [4-26](#)
 - nslookup [4-27](#)
 - patch install [4-28](#)
 - patch remove [4-29](#)
 - ping6 [4-31](#)
 - reload [4-33](#)
 - restore [4-34](#)
 - rmdir [4-35](#)
 - show [4-36, 4-48](#)
 - ssh [4-38](#)
 - tech [4-39](#)
 - telnet [4-40](#)
 - terminal length [4-41](#)
 - terminal session-timeout [4-42](#)
 - terminal session-welcome [4-42](#)
 - terminal terminal-type [4-43](#)
 - traceroute [4-44](#)
 - undebug [4-44](#)
 - write [4-46](#)
 - show
 - show application [4-48](#)
 - show backup history [4-50](#)
 - show cdp [4-51](#)
 - show clock [4-52](#)
 - show cpu [4-53](#)
 - show disks [4-55](#)
 - show icmp-status [4-57](#)
 - show interface [4-58](#)
 - show inventory [4-60](#)
 - show logging [4-61](#)
 - show logins [4-63](#)
 - show memory [4-64](#)
 - show ntp [4-65](#)
 - show process [4-67](#)
 - show repository [4-69](#)
 - show restore [4-70](#)
 - show running-configuration [4-70](#)
 - show startup-configuration [4-72](#)
 - show tech-support [4-73](#)
 - show terminal [4-75](#)
 - show timezone [4-76](#)
 - show timezones [4-76](#)
 - show udi [4-78](#)
 - show uptime [4-78](#)
 - show users [4-79](#)
 - show version [4-80](#)
 - configuration commands [4-81](#)
 - configure
 - ISE to forward user login events [3-13](#)
 - connectivity requirements [2-3](#)
 - consumer device [1-3](#)
-
- ## D
-
- dashboard [3-3](#)
-
- ## E
-
- EXEC commands [4-2](#)
-
- ## H
-
- hardware requirements [2-2](#)
-
- ## I
-
- import active directory server [3-8](#)
 - installing CDA [2-13](#)
 - IP-to-User identity mapping [3-16](#)

REVIEW DRAFT—CISCO CONFIDENTIAL

L

live logs [3-21](#)
logging in [3-2](#)
log level settings [3-15](#)

M

mapping filters [3-18](#)

N

note, description of [ii-xi](#)

O

overview [1-2](#)

P

password policy [3-20](#)
performance and scalability [1-6](#)

S

session timeout [3-21](#)
show commands [4-36, 4-48](#)
supported operating systems [2-1](#)
syslog servers [1-6](#)

T

timesaver, description of [ii-xi](#)

REVIEW DRAFT – CISCO CONFIDENTIAL