



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
aaa authorization network command [2-5](#)
AAA methods [2-3](#)
abort command [2-740](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-136](#)
 MAC, displaying [2-509](#)
access list, IPv6 [2-201](#)
access map configuration mode [2-258](#)
access mode [2-682](#)
access ports [2-682](#)
ACEs [2-80](#), [2-326](#)
ACLs
 deny [2-78](#)
 displaying [2-374](#)
 for non-IP protocols [2-238](#)
 IP [2-136](#)
 matching [2-258](#)
 on Layer 2 interfaces [2-136](#)
 permit [2-324](#)
action command [2-6](#)
aggregate-port learner [2-313](#)
allowed VLANs [2-702](#)
apply command [2-740](#)
archive copy-sw command [2-8](#)
archive download-sw command [2-11](#)

archive tar command [2-15](#)
archive upload-sw command [2-18](#)
arp access-list command [2-20](#)
authentication failed VLAN
 See dot1x auth-fail vlan
auth-fail max-attempts
 See dot1x auth-fail max-attempts
auth-fail vlan
 See dot1x auth-fail vlan
authorization state of controlled port [2-111](#)
autonegotiation of duplex mode [2-117](#)
auto qos voip command [2-22](#)

B

BackboneFast, for STP [2-609](#)
backup interfaces
 configuring [2-677](#)
 displaying [2-436](#)
boot (boot loader) command [A-2](#)
boot auto-copy-sw command [2-26](#)
boot auto-download-sw command [2-27](#)
boot config-file command [2-29](#)
boot enable-break command [2-30](#)
boot helper command [2-31](#)
boot helper-config file command [2-32](#)
booting
 Cisco IOS image [2-35](#)
 displaying environment variables [2-383](#)
 interrupting [2-30](#)
 manually [2-33](#)

boot loader

accessing [A-1](#)

booting

Cisco IOS image [A-2](#)helper image [2-31](#)

directories

creating [A-15](#)displaying a list of [A-7](#)removing [A-19](#)

displaying

available commands [A-12](#)memory heap utilization [A-13](#)version [A-26](#)

environment variables

described [A-20](#)displaying settings [A-20](#)location of [A-21](#)setting [A-20](#)unsetting [A-24](#)

files

copying [A-5](#)deleting [A-6](#)displaying a list of [A-7](#)displaying the contents of [A-4, A-16, A-23](#)renaming [A-17](#)

file system

formatting [A-10](#)initializing flash [A-9](#)running a consistency check [A-11](#)prompt [A-1](#)resetting the system [A-18](#)boot manual command [2-33](#)boot private-config-file command [2-34](#)boot system command [2-35](#)BPDU filtering, for spanning tree [2-610, 2-644](#)BPDU guard, for spanning tree [2-612, 2-644](#)broadcast storm control [2-665](#)**C**cat (boot loader) command [A-4](#)CDP, enabling protocol tunneling for [2-219](#)channel-group command [2-37](#)channel-protocol command [2-41](#)

Cisco SoftPhone

auto-QoS configuration [2-22](#)trusting packets sent from [2-299](#)class command [2-42](#)class-map command [2-44](#)

class maps

creating [2-44](#)defining the match criteria [2-260](#)displaying [2-388](#)

class of service

See CoS

clear dot1x command [2-46](#)clear eap command [2-47](#)clear errdisable interface [2-48](#)clear ip arp inspection log command [2-49](#)clear ip arp inspection statistics command [2-50](#)clear ipc command [2-53](#)clear ip dhcp snooping database command [2-51](#)clear l2protocol-tunnel counters command [2-54](#)clear lacp command [2-55](#)clear logging command [2-56](#)clear mac address-table command [2-57, 2-58](#)clear pagp command [2-59](#)clear port-security command [2-60](#)clear spanning-tree counters command [2-62](#)clear spanning-tree detected-protocols command [2-63](#)clear vmpls statistics command [2-64](#)clear vtp counters command [2-65](#)command modes defined [1-2](#)

configuration files

password recovery disable considerations [A-1](#)specifying the name [2-29, 2-34](#)configuring multiple interfaces [2-132](#)

config-vlan mode

commands [2-726](#)

description [1-5](#)

entering [2-725](#)

summary [1-2](#)

copy (boot loader) command [A-5](#)

copy logging onboard command [2-66](#)

CoS

assigning default value to incoming packets [2-269](#)

assigning to Layer 2 protocol packets [2-222](#)

overriding the incoming value [2-269](#)

CoS-to-DSCP map [2-273](#)

CPU ASIC statistics, displaying [2-389](#)

crashinfo files [2-123](#)

D

debug auto qos command [B-2](#)

debug backup command [B-4](#)

debug dot1x command [B-5](#)

debug dtp command [B-6](#)

debug eap command [B-7](#)

debug etherchannel command [B-8](#)

debug fastethernet command [B-9](#)

debug interface command [B-12](#)

debug ip dhcp snooping command [B-10](#)

debug ip igmp filter command [B-13](#)

debug ip igmp max-groups command [B-14](#)

debug ip igmp snooping command [B-15](#)

debug ip verify source packet command [B-11](#)

debug lacp command [B-16](#)

debug mac-notification command [B-17](#)

debug matm command [B-18](#)

debug matm move update command [B-19](#)

debug monitor command [B-20](#)

debug mvrdbg command [B-21](#)

debug nvram command [B-22](#)

debug pagp command [B-23](#)

debug platform acl command [B-24](#)

debug platform backup interface command [B-26](#)

debug platform cli-redirection main command [B-27](#)

debug platform configuration command [B-28](#)

debug platform cpu-queues command [B-29](#)

debug platform device-manager command [B-31](#)

debug platform dot1x command [B-32](#)

debug platform etherchannel command [B-33](#)

debug platform fallback-bridging command [B-34](#)

debug platform forw-tcam command [B-35](#)

debug platform ip arp inspection command [B-36](#)

debug platform ipc command [B-45](#)

debug platform ip dhcp command [B-37](#)

debug platform ip igmp snooping command [B-38](#)

debug platform ip multicast command [B-40](#)

debug platform ip unicast command [B-42](#)

debug platform ip wccp command [B-44](#)

debug platform led command [B-46](#)

debug platform matm command [B-47](#)

debug platform messaging application command [B-48](#)

debug platform phy command [B-50](#)

debug platform pm command [B-52](#)

debug platform port-asic command [B-54](#)

debug platform port-security command [B-55](#)

debug platform qos-acl-tcam command [B-56](#)

debug platform remote-commands command [B-57](#)

debug platform resource-manager command [B-58](#)

debug platform snmp command [B-59](#)

debug platform span command [B-60](#)

debug platform stack-manager command [B-61](#)

debug platform supervisor-asic command [B-62](#)

debug platform sw-bridge command [B-63](#)

debug platform tcam command [B-64](#)

debug platform udd command [B-67](#)

debug platform vlan command [B-68](#)

debug pm command [B-69](#)

debug port-security command [B-71](#)

debug qos-manager command [B-72](#)

debug spanning-tree backbonefast command [B-75](#)

debug spanning-tree bpdu command [B-76](#)

- debug spanning-tree bpd-opt command [B-77](#)
- debug spanning-tree command [B-73](#)
- debug spanning-tree mstp command [B-78](#)
- debug spanning-tree switch command [B-80](#)
- debug spanning-tree uplinkfast command [B-82](#)
- debug sw-vlan command [B-83](#)
- debug sw-vlan ifs command [B-85](#)
- debug sw-vlan notification command [B-86](#)
- debug sw-vlan vtp command [B-88](#)
- debug udd command [B-90](#)
- debug vqpc command [B-92](#)
- define interface-range command [2-68](#)
- delete (boot loader) command [A-6](#)
- delete command [2-70](#)
- deny (ARP access-list configuration) command [2-71](#)
- deny (IPv6) command [2-73](#)
- deny command [2-78](#)
- detect mechanism, causes [2-119](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-164](#)
 - enabling
 - on a VLAN [2-170](#)
 - option 82 [2-162, 2-164](#)
 - trust on an interface [2-168](#)
 - error recovery timer [2-121](#)
 - rate limiting [2-167](#)
- DHCP snooping binding database
 - binding file, configuring [2-160](#)
 - bindings
 - adding [2-158](#)
 - deleting [2-158](#)
 - displaying [2-455](#)
 - clearing database agent statistics [2-51](#)
 - database agent, configuring [2-160](#)
 - displaying
 - binding entries [2-455](#)
 - database agent status [2-457, 2-459](#)
 - renewing [2-355](#)
- dir (boot loader) command [A-7](#)
- directories, deleting [2-70](#)
- domain name, VTP [2-751, 2-755](#)
- dot1x auth-fail max-attempts [2-90](#)
- dot1x auth-fail vlan [2-92](#)
- dot1x command [2-88](#)
- dot1x control-direction command [2-94](#)
- dot1x critical global configuration command [2-96](#)
- dot1x critical interface configuration command [2-98](#)
- dot1x default command [2-100](#)
- dot1x fallback command [2-101](#)
- dot1x guest-vlan command [2-102](#)
- dot1x host-mode command [2-104](#)
- dot1x initialize command [2-105](#)
- dot1x mac-auth-bypass command [2-106](#)
- dot1x max-reauth-req command [2-108](#)
- dot1x max-req command [2-109](#)
- dot1x pae command [2-110](#)
- dot1x port-control command [2-111](#)
- dot1x re-authenticate command [2-113](#)
- dot1x reauthentication command [2-114](#)
- dot1x timeout command [2-115](#)
- dropping packets, with ACL matches [2-6](#)
- drop threshold, Layer 2 protocol tunneling [2-219](#)
- DSCP-to-CoS map [2-273](#)
- DSCP-to-DSCP-mutation map [2-273](#)
- DTP [2-683](#)
- DTP flap
 - error detection for [2-119](#)
 - error recovery timer [2-121](#)
- DTP negotiation [2-687](#)
- dual IPv4 and IPv6 templates [2-319](#)
- duplex command [2-117](#)
- dynamic-access ports
 - configuring [2-675](#)
 - restrictions [2-676](#)

dynamic ARP inspection

ARP ACLs

apply to a VLAN [2-144](#)define [2-20](#)deny packets [2-71](#)display [2-378](#)permit packets [2-317](#)

clear

log buffer [2-49](#)statistics [2-50](#)

display

ARP ACLs [2-378](#)configuration and operating state [2-450](#)log buffer [2-450](#)statistics [2-450](#)trust state and rate limit [2-450](#)enable per VLAN [2-154](#)error detection for [2-119](#)error recovery timer [2-121](#)

log buffer

clear [2-49](#)configure [2-148](#)display [2-450](#)rate-limit incoming ARP packets [2-146](#)

statistics

clear [2-50](#)display [2-450](#)trusted interface state [2-150](#)type of packet logged [2-155](#)validation checks [2-152](#)dynamic auto VLAN membership mode [2-682](#)dynamic desirable VLAN membership mode [2-682](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

Dynamic Trunking Protocol

See DTP

E

EAP-request/identity frame

maximum number to send [2-109](#)response time before retransmitting [2-115](#)encapsulation methods [2-702](#)environment variables, displaying [2-383](#)errdisable detect cause command [2-119](#)errdisable recovery command [2-121](#)error conditions, displaying [2-424](#)error disable detection [2-119](#)error-disabled interfaces, displaying [2-436](#)

EtherChannel

assigning Ethernet interface to channel group [2-37](#)creating port-channel logical interface [2-130](#)debug EtherChannel/PAgP, display [B-8](#)debug platform-specific events, display [B-33](#)displaying [2-427](#)

enabling Layer 2 protocol tunneling for

LACP [2-220](#)PAgP [2-220](#)UDLD [2-220](#)interface information, displaying [2-436](#)

LACP

clearing channel-group information [2-55, 2-56](#)debug messages, display [B-16](#)displaying [2-495](#)modes [2-37](#)port priority for hot-standby ports [2-223](#)restricting a protocol [2-41](#)system priority [2-225](#)load-distribution methods [2-335](#)

EtherChannel (continued)

PAGP

- aggregate-port learner [2-313](#)
- clearing channel-group information [2-59](#)
- debug messages, display [B-23](#)
- displaying [2-554](#)
- error detection for [2-119](#)
- error recovery timer [2-121](#)
- learn method [2-313](#)
- modes [2-37](#)
- physical-port learner [2-313](#)
- priority of interface for transmitted traffic [2-315](#)

Ethernet controller, internal register display [2-391, 2-398](#)

Ethernet Management port, debugging [B-9](#)

Ethernet statistics, collecting [2-357](#)

exception crashinfo command [2-123, 2-128](#)

exit command [2-740](#)

extended-range VLANs

- and allowed VLAN list [2-702](#)
- and pruning-eligible list [2-702](#)
- configuring [2-725](#)

extended system ID for STP [2-618](#)

F

fallback profile command [2-124](#)

fallback profiles, displaying [2-430](#)

fan information, displaying [2-420](#)

file name, VTP [2-751](#)

files, deleting [2-70](#)

flash_init (boot loader) command [A-9](#)

Flex Links

- configuring [2-677](#)
- displaying [2-436](#)

flowcontrol command [2-126](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-6](#)

forwarding results, display [C-9](#)

frame forwarding information, displaying [C-9](#)

front-end controller counter and status information [C-11](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-4](#)

H

hardware ACL statistics [2-374](#)

health monitoring diagnostic tests [2-81](#)

help (boot loader) command [A-12](#)

hierarchical policy maps [2-333](#)

host connection, port configuration [2-681](#)

host ports, private VLANs [2-685](#)

I

IEEE 802.1Q trunk ports and native VLANs [2-742](#)

IEEE 802.1Q tunnel ports

- configuring [2-682](#)
- displaying [2-410](#)
- limitations [2-683](#)

IEEE 802.1x

- and switchport modes [2-683](#)
- violation error recovery [2-121](#)
- See also port-based authentication

IGMP filters

- applying [2-173](#)
- debug messages, display [B-13](#)

IGMP groups, setting maximum [2-175](#)

IGMP maximum groups, debugging [B-14](#)

IGMP profiles

- creating [2-177](#)
- displaying [2-462](#)

IGMP snooping

- adding ports as a static member of a group [2-193](#)
- displaying [2-463, 2-468, 2-470](#)

IGMP snooping (continued)

- enabling [2-179](#)
- enabling the configurable-leave timer [2-181](#)
- enabling the Immediate-Leave feature [2-190](#)
- flooding query count [2-187](#)
- interface topology change notification behavior [2-189](#)
- multicast table [2-466](#)
- querier [2-183](#)
- query solicitation [2-187](#)
- report suppression [2-185](#)
- switch topology change notification behavior [2-187](#)

images

See software images

Immediate-Leave processing

- IGMP [2-190](#)
- IPv6 [2-215](#)
- MVR [2-309](#)

interface configuration mode [1-2, 1-4](#)**interface port-channel command** [2-130](#)**interface range command** [2-132](#)**interface-range macros** [2-68](#)**interfaces**

- assigning Ethernet interface to channel group [2-37](#)
- configuring [2-117](#)
- configuring multiple [2-132](#)
- creating port-channel logical [2-130](#)
- debug messages, display [B-12](#)
- disabling [2-597](#)
- displaying the MAC address table [2-521](#)
- restarting [2-597](#)

interface speed, configuring [2-655](#)**interface vlan command** [2-134](#)**internal registers, displaying** [2-391, 2-398, 2-401](#)**Internet Group Management Protocol**

See IGMP

ip access-group command [2-136](#)**ip address command** [2-139](#)**IP addresses, setting** [2-139](#)**IP address matching** [2-258](#)**ip admission command** [2-141](#)**ip admission name proxy http command** [2-142](#)**ip arp inspection filter vlan command** [2-144](#)**ip arp inspection limit command** [2-146](#)**ip arp inspection log-buffer command** [2-148](#)**ip arp inspection trust command** [2-150](#)**ip arp inspection validate command** [2-152](#)**ip arp inspection vlan command** [2-154](#)**ip arp inspection vlan logging command** [2-155](#)**IP DHCP snooping**

See DHCP snooping

ip dhcp snooping binding command [2-158](#)**ip dhcp snooping command** [2-157](#)**ip dhcp snooping database command** [2-160](#)**ip dhcp snooping information option allow-untrusted command** [2-164](#)**ip dhcp snooping information option command** [2-162](#)**ip dhcp snooping information option format remote-id command** [2-166](#)**ip dhcp snooping limit rate command** [2-167](#)**ip dhcp snooping trust command** [2-168](#)**ip dhcp snooping verify command** [2-169](#)**ip dhcp snooping vlan command** [2-170](#)**ip dhcp snooping vlan information option format-type circuit-id string command** [2-171](#)**ip igmp filter command** [2-173](#)**ip igmp max-groups command** [2-175](#)**ip igmp profile command** [2-177](#)**ip igmp snooping command** [2-179](#)**ip igmp snooping last-member-query-interval command** [2-181](#)**ip igmp snooping querier command** [2-183](#)**ip igmp snooping report-suppression command** [2-185](#)**ip igmp snooping tcn command** [2-187](#)**ip igmp snooping tcn flood command** [2-189](#)**ip igmp snooping vlan immediate-leave command** [2-190](#)**ip igmp snooping vlan mrouter command** [2-191](#)**ip igmp snooping vlan static command** [2-193](#)**IP multicast addresses** [2-306](#)

IP phones

auto-QoS configuration [2-22](#)

trusting packets sent from [2-299](#)

IP-precedence-to-DSCP map [2-273](#)

ip snap forwarding command [2-195](#)

ip source binding command [2-196](#)

IP source guard

disabling [2-200](#)

displaying

binding entries [2-472](#)

configuration [2-474](#)

dynamic binding entries only [2-455](#)

enabling [2-200](#)

static IP source bindings [2-196](#)

ip ssh command [2-198](#)

IPv6 access list, deny conditions [2-73](#)

ipv6 access-list command [2-201](#)

ipv6 mld snooping command [2-203](#)

ipv6 mld snooping last-listener-query count command [2-205](#)

ipv6 mld snooping last-listener-query-interval command [2-207](#)

ipv6 mld snooping listener-message-suppression command [2-209](#)

ipv6 mld snooping robustness-variable command [2-211](#)

ipv6 mld snooping tcn command [2-213](#)

ipv6 mld snooping vlan command [2-215](#)

IPv6 SDM template [2-358](#)

ipv6 traffic-filter command [2-217](#)

ip verify source command [2-200](#)

J

jumbo frames

See MTU

L

l2protocol-tunnel command [2-219](#)

l2protocol-tunnel cos command [2-222](#)

LACP

See EtherChannel

lacp port-priority command [2-223](#)

lacp system-priority command [2-225](#)

Layer 2 mode, enabling [2-673](#)

Layer 2 protocol ports, displaying [2-492](#)

Layer 2 protocol-tunnel

error detection for [2-119](#)

error recovery timer [2-121](#)

Layer 2 protocol tunnel counters [2-54](#)

Layer 2 protocol tunneling error recovery [2-220](#)

Layer 2 traceroute

IP addresses [2-716](#)

MAC addresses [2-713](#)

Layer 3 mode, enabling [2-673](#)

line configuration mode [1-3, 1-6](#)

Link Aggregation Control Protocol

See EtherChannel

link flap

error detection for [2-119](#)

error recovery timer [2-121](#)

link state group command [2-227](#)

link state track command [2-229](#)

load-distribution methods for EtherChannel [2-335](#)

location (global configuration) command [2-230](#)

location (interface configuration) command [2-232](#)

logging file command [2-234](#)

logical interface [2-130](#)

loopback error

detection for [2-119](#)

recovery timer [2-121](#)

loop guard, for spanning tree [2-620, 2-624](#)

M

- mac access-group command [2-236](#)
- MAC access-groups, displaying [2-509](#)
- MAC access list configuration mode [2-238](#)
- mac access-list extended command [2-238](#)
- MAC access lists [2-78](#)
- MAC addresses
 - displaying
 - aging time [2-515](#)
 - all [2-513](#)
 - dynamic [2-519](#)
 - MAC address-table move updates [2-523](#)
 - notification settings [2-525](#)
 - number of addresses in a VLAN [2-517](#)
 - per interface [2-521](#)
 - per VLAN [2-529](#)
 - static [2-527](#)
 - static and dynamic entries [2-511](#)
 - dynamic
 - aging time [2-240](#)
 - deleting [2-57](#)
 - displaying [2-519](#)
 - enabling MAC address notification [2-243](#)
 - enabling MAC address-table move update [2-241](#)
 - matching [2-258](#)
 - persistent stack [2-663](#)
 - static
 - adding and removing [2-245](#)
 - displaying [2-527](#)
 - dropping on an interface [2-246](#)
 - tables [2-513](#)
- MAC address notification, debugging [B-17](#)
- mac address-table aging-time [2-236](#), [2-258](#)
- mac address-table aging-time command [2-240](#)
- mac address-table move update command [2-241](#)
- mac address-table notification command [2-243](#)
- mac address-table static command [2-245](#)
- mac address-table static drop command [2-246](#)
- MAC frames
 - See MTU
- macro apply command [2-248](#)
- macro description command [2-251](#)
- macro global command [2-252](#)
- macro global description command [2-255](#)
- macro name command [2-256](#)
- macros
 - adding a description [2-251](#)
 - adding a global description [2-255](#)
 - applying [2-252](#)
 - creating [2-256](#)
 - displaying [2-556](#)
 - interface range [2-68](#), [2-132](#)
 - specifying parameter values [2-252](#)
 - tracing [2-252](#)
- maps
 - QoS
 - defining [2-273](#)
 - displaying [2-539](#)
 - VLAN
 - creating [2-737](#)
 - defining [2-258](#)
 - displaying [2-589](#)
- match (access-map configuration) command [2-258](#)
- match (class-map configuration) command [2-260](#)
- maximum transmission unit
 - See MTU
- mdix auto command [2-263](#)
- memory (boot loader) command [A-13](#)
- mkdir (boot loader) command [A-15](#)
- MLD snooping
 - configuring [2-209](#), [2-211](#)
 - configuring queries [2-205](#), [2-207](#)
 - configuring topology change notification [2-213](#)
 - displaying [2-482](#), [2-484](#), [2-486](#), [2-488](#)
 - enabling [2-203](#)
 - enabling on a VLAN [2-215](#)
- mls qos aggregate-policer command [2-267](#)

- mls qos command [2-265](#)
- mls qos cos command [2-269](#)
- mls qos dscp-mutation command [2-271](#)
- mls qos map command [2-273](#)
- mls qos queue-set output buffers command [2-277](#)
- mls qos queue-set output threshold command [2-279](#)
- mls qos rewrite ip dscp command [2-281](#)
- mls qos srr-queue input bandwidth command [2-283](#)
- mls qos srr-queue input buffers command [2-285](#)
- mls qos srr-queue input cos-map command [2-287](#)
- mls qos srr-queue input dscp-map command [2-289](#)
- mls qos srr-queue input priority-queue command [2-291](#)
- mls qos srr-queue input threshold command [2-293](#)
- mls qos srr-queue output cos-map command [2-295](#)
- mls qos srr-queue output dscp-map command [2-297](#)
- mls qos trust command [2-299](#)
- mls qos vlan-based command [2-301](#)
- mode, MVR [2-306](#)
- Mode button, and password recovery [2-361](#)
- modes, commands [1-2](#)
- monitor session command [2-302](#)
- more (boot loader) command [A-16](#)
- MSTP
 - displaying [2-569](#)
 - interoperability [2-63](#)
 - link type [2-622](#)
 - MST region
 - aborting changes [2-628](#)
 - applying changes [2-628](#)
 - configuration name [2-628](#)
 - configuration revision number [2-628](#)
 - current or pending display [2-628](#)
 - displaying [2-569](#)
 - MST configuration mode [2-628](#)
 - VLANs-to-instance mapping [2-628](#)
 - path cost [2-630](#)
 - protocol mode [2-626](#)
 - restart protocol migration process [2-63](#)

MSTP (continued)

- root port
 - loop guard [2-620](#)
 - preventing from becoming designated [2-620](#)
 - restricting which can be root [2-620](#)
 - root guard [2-620](#)
- root switch
 - affects of extended system ID [2-618](#)
 - hello-time [2-633, 2-640](#)
 - interval between BDPU messages [2-634](#)
 - interval between hello BPDU messages [2-633, 2-640](#)
 - max-age [2-634](#)
 - maximum hop count before discarding BPDU [2-635](#)
 - port priority for selection of [2-636](#)
 - primary or secondary [2-640](#)
 - switch priority [2-639](#)
- state changes
 - blocking to forwarding state [2-647](#)
 - enabling BPDU filtering [2-610, 2-644](#)
 - enabling BPDU guard [2-612, 2-644](#)
 - enabling Port Fast [2-644, 2-647](#)
 - forward-delay time [2-632](#)
 - length of listening and learning states [2-632](#)
 - rapid transition to forwarding [2-622](#)
 - shutting down Port Fast-enabled ports [2-644](#)
- state information display [2-568](#)
- MTU
 - configuring size [2-710](#)
 - displaying global setting [2-579](#)
- Multicast Listener Discovery
 - See MLD
- multicast group address, MVR [2-309](#)
- multicast groups, MVR [2-307](#)
- Multicast Listener Discovery
 - See MLD
- multicast router learning method [2-191](#)
- multicast router ports, configuring [2-191](#)

multicast router ports, IPv6 [2-215](#)
 multicast storm control [2-665](#)
 multicast VLAN, MVR [2-306](#)
 multicast VLAN registration
 See MVR
 multiple hosts on authorized port [2-104](#)
 Multiple Spanning Tree Protocol
 See MSTP
 MVR
 configuring [2-306](#)
 configuring interfaces [2-309](#)
 debug messages, display [B-21](#)
 displaying [2-548](#)
 displaying interface information [2-550](#)
 members, displaying [2-552](#)
 mvr (global configuration) command [2-306](#)
 mvr (interface configuration) command [2-309](#)
 mvr vlan group command [2-310](#)

N

native VLANs [2-702](#)
 native VLAN tagging [2-742](#)
 nonegotiate
 DTP messaging [2-687](#)
 non-IP protocols
 denying [2-78](#)
 forwarding [2-324](#)
 non-IP traffic access lists [2-238](#)
 non-IP traffic forwarding
 denying [2-78](#)
 permitting [2-324](#)
 non-stop forwarding [2-311](#)
 normal-range VLANs [2-725, 2-731](#)
 no vlan command [2-725, 2-735](#)
 nsf command [2-311](#)

O

online diagnostics
 configuring health monitoring diagnostic tests [2-81](#)
 displaying
 configured boot-up coverage level [2-405](#)
 current scheduled tasks [2-405](#)
 event logs [2-405](#)
 supported test suites [2-405](#)
 test ID [2-405](#)
 test results [2-405](#)
 test statistics [2-405](#)
 enabling
 scheduling [2-83](#)
 syslog messages [2-81](#)
 global configuration mode
 clearing health monitoring diagnostic test schedule [2-81](#)
 clearing test-based testing schedule [2-83](#)
 setting health monitoring diagnostic testing [2-81](#)
 setting test-based testing [2-83](#)
 setting up health monitoring diagnostic test schedule [2-81](#)
 setting up test-based testing [2-83](#)
 removing scheduling [2-83](#)
 scheduled switchover
 disabling [2-83](#)
 enabling [2-83](#)
 setting test interval [2-83](#)
 specifying health monitoring diagnostic tests [2-81](#)
 starting testing [2-85](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-313](#)
 pagp port-priority command [2-315](#)
 password, VTP [2-751, 2-755](#)

- password-recovery mechanism, enabling and disabling [2-361](#)
- permit (ARP access-list configuration) command [2-317](#)
- permit (IPv6) command [2-319](#)
- permit (MAC access-list configuration) command [2-324](#)
- per-VLAN spanning-tree plus
 - See STP
- physical-port learner [2-313](#)
- PID, displaying [2-449](#)
- PIM-DVMRP, as multicast router learning method [2-191](#)
- platform chassis-management command [2-327](#)
- police aggregate command [2-330](#)
- police command [2-328](#)
- policed-DSCP map [2-273](#)
- policy-map command [2-332](#)
- policy maps
 - applying to an interface [2-363, 2-369](#)
 - creating [2-332](#)
 - displaying [2-559](#)
 - hierarchical [2-333](#)
 - policers
 - displaying [2-532](#)
 - for a single class [2-328](#)
 - for multiple classes [2-267, 2-330](#)
 - policed-DSCP map [2-273](#)
 - traffic classification
 - defining the class [2-42](#)
 - defining trust states [2-718](#)
 - setting DSCP or IP precedence values [2-367](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-based authentication
 - AAA method list [2-3](#)
 - debug messages, display [B-5](#)
 - enabling guest VLAN supplicant [2-91, 2-101](#)
 - enabling IEEE 802.1x
 - globally [2-88](#)
 - per interface [2-111](#)
- port-based authentication (continued)
 - guest VLAN [2-102](#)
 - host modes [2-104](#)
 - IEEE 802.1x AAA accounting methods [2-1](#)
 - initialize an interface [2-105](#)
 - MAC authentication bypass [2-106](#)
 - manual control of authorization state [2-111](#)
 - multiple hosts on authorized port [2-104](#)
 - PAE as authenticator [2-110](#)
 - periodic re-authentication
 - enabling [2-114](#)
 - time between attempts [2-115](#)
 - quiet period between failed authentication exchanges [2-115](#)
 - re-authenticating IEEE 802.1x-enabled ports [2-113](#)
 - resetting configurable IEEE 802.1x parameters [2-100](#)
 - switch-to-authentication server retransmission time [2-115](#)
 - switch-to-client frame-retransmission number [2-108 to 2-109](#)
 - switch-to-client retransmission time [2-115](#)
- port-channel load-balance command [2-335](#)
- Port Fast, for spanning tree [2-647](#)
- port ranges, defining [2-66, 2-68](#)
- ports, debugging [B-69](#)
- ports, protected [2-700](#)
- port security
 - aging [2-694](#)
 - debug messages, display [B-71](#)
 - enabling [2-689](#)
 - violation error recovery [2-121](#)
- port trust states for QoS [2-299](#)
- port types, MVR [2-309](#)
- power information, displaying [2-420](#)
- priority-queue command [2-337](#)
- priority value, stack member [2-576, 2-668](#)
- private-vlan command [2-339](#)
- private-vlan mapping command [2-342](#)

private VLANs

- association [2-698](#)
- configuring [2-339](#)
- configuring ports [2-685](#)
- displaying [2-585](#)
- host ports [2-685](#)
- mapping
 - configuring [2-698](#)
 - displaying [2-436](#)
- promiscuous ports [2-685](#)

privileged EXEC mode [1-2, 1-3](#)product identification information, displaying [2-449](#)promiscuous ports, private VLANs [2-685](#)protected ports, displaying [2-442](#)

pruning

VLANs [2-702](#)

VTP

- displaying interface information [2-436](#)
- enabling [2-751, 2-755](#)

pruning-eligible VLAN list [2-704](#)

PVST+

See STP

Q

QoS

auto-QoS

- configuring [2-22](#)
- debug messages, display [B-2](#)
- displaying [2-379](#)

class maps

- creating [2-44](#)
- defining the match criteria [2-260](#)
- displaying [2-388](#)

defining the CoS value for an incoming packet [2-269](#)displaying configuration information [2-379, 2-531](#)DSCP transparency [2-281](#)

QoS (continued)

DSCP trusted ports

- applying DSCP-to-DSCP-mutation map to [2-271](#)
- defining DSCP-to-DSCP-mutation map [2-273](#)

egress queues

- allocating buffers [2-277](#)
- defining the CoS output queue threshold map [2-295](#)
- defining the DSCP output queue threshold map [2-297](#)
- displaying buffer allocations [2-535](#)
- displaying CoS output queue threshold map [2-539](#)
- displaying DSCP output queue threshold map [2-539](#)
- displaying queueing strategy [2-535](#)
- displaying queue-set settings [2-542](#)
- enabling bandwidth shaping and scheduling [2-659](#)
- enabling bandwidth sharing and scheduling [2-661](#)
- limiting the maximum output on a port [2-657](#)
- mapping a port to a queue-set [2-344](#)
- mapping CoS values to a queue and threshold [2-295](#)
- mapping DSCP values to a queue and threshold [2-297](#)
- setting maximum and reserved memory allocations [2-279](#)
- setting WTD thresholds [2-279](#)

enabling [2-265](#)

QoS (continued)

ingress queues

- allocating buffers [2-285](#)
- assigning SRR scheduling weights [2-283](#)
- defining the CoS input queue threshold map [2-287](#)
- defining the DSCP input queue threshold map [2-289](#)
- displaying buffer allocations [2-535](#)
- displaying CoS input queue threshold map [2-539](#)
- displaying DSCP input queue threshold map [2-539](#)
- displaying queueing strategy [2-535](#)
- displaying settings for [2-533](#)
- enabling the priority queue [2-291](#)
- mapping CoS values to a queue and threshold [2-287](#)
- mapping DSCP values to a queue and threshold [2-289](#)
- setting WTD thresholds [2-293](#)

maps

- defining [2-273](#), [2-287](#), [2-289](#), [2-295](#), [2-297](#)
- displaying [2-539](#)

policy maps

- applying an aggregate policer [2-330](#)
- applying to an interface [2-363](#), [2-369](#)
- creating [2-332](#)
- defining policers [2-267](#), [2-328](#)
- displaying policers [2-532](#)
- displaying policy maps [2-559](#)
- hierarchical [2-333](#)
- policed-DSCP map [2-273](#)
- setting DSCP or IP precedence values [2-367](#)
- traffic classifications [2-42](#)
- trust states [2-718](#)

port trust states [2-299](#)queues, enabling the expedite [2-337](#)**QoS (continued)**

statistics

- in-profile and out-of-profile packets [2-535](#)
 - packets enqueued or dropped [2-535](#)
 - sent and received CoS values [2-535](#)
 - sent and received DSCP values [2-535](#)
 - trusted boundary for IP phones [2-299](#)
 - VLAN-based [2-301](#)
- quality of service
- See QoS
- querytime, MVR [2-306](#)
- queue-set command [2-344](#)

R

- radius-server dead-criteria command [2-345](#)
- radius-server host command [2-347](#)
- rapid per-VLAN spanning-tree plus
 - See STP
- rapid PVST+
 - See STP
- re-authenticating IEEE 802.1x-enabled ports [2-113](#)
- re-authentication
 - periodic [2-114](#)
 - time between attempts [2-115](#)
- receiver ports, MVR [2-309](#)
- receiving flow-control packets [2-126](#)
- recovery mechanism
 - causes [2-121](#)
 - display [2-48](#), [2-386](#), [2-422](#), [2-425](#)
 - timer interval [2-121](#)
- reload command [2-349](#)
- remote command [2-351](#)
- remote-span command [2-353](#)
- Remote Switched Port Analyzer
 - See RSPAN
- rename (boot loader) command [A-17](#)
- renew ip dhcp snooping database command [2-355](#)
- reset (boot loader) command [A-18](#)

reset command [2-740](#)
 resource templates, displaying [2-564](#)
 restricted VLAN
 See dot1x auth-fail vlan
 rmdir (boot loader) command [A-19](#)
 rmon collection stats command [2-357](#)
 root guard, for spanning tree [2-620](#)
 routed ports
 IP addresses on [2-140](#)
 number supported [2-140](#)
 routing frames
 See MTU
 RSPAN
 configuring [2-302](#)
 displaying [2-545](#)
 filter RSPAN traffic [2-302](#)
 remote-span command [2-353](#)
 sessions
 add interfaces to [2-302](#)
 displaying [2-545](#)
 start new [2-302](#)

S

scheduled switchover
 disabling [2-83](#)
 enabling [2-83](#)
 SDM mismatch mode [2-359, 2-577](#)
 sdm prefer command [2-358](#)
 SDM templates
 allowed resources [2-359](#)
 and stacking [2-359](#)
 displaying [2-564](#)
 dual IPv4 and IPv6 [2-358](#)
 secure ports, limitations [2-691](#)
 sending flow-control packets [2-126](#)
 service password-recovery command [2-361](#)
 service-policy command [2-363](#)
 session command [2-366](#)
 set (boot loader) command [A-20](#)
 set command [2-367](#)
 setup command [2-369](#)
 setup express command [2-372](#)
 show access-lists command [2-374](#)
 show archive status command [2-377](#)
 show arp access-list command [2-378](#)
 show auto qos command [2-379](#)
 show boot command [2-383](#)
 show cable-diagnostics tdr command [2-386](#)
 show changes command [2-740](#)
 show class-map command [2-388](#)
 show controllers cpu-interface command [2-389](#)
 show controllers ethernet-controller command [2-391](#)
 show controllers ethernet-controller fastethernet command [2-398](#)
 show controllers team command [2-401](#)
 show controller utilization command [2-403](#)
 show current command [2-740](#)
 show dot1q-tunnel command [2-410](#)
 show dot1x command [2-411](#)
 show dtp [2-415](#)
 show eap command [2-417](#)
 show env command [2-420](#)
 show errdisable detect command [2-422](#)
 show errdisable flap-values command [2-424](#)
 show errdisable recovery command [2-425](#)
 show etherchannel command [2-427](#)
 show fallback profile command [2-430](#)
 show flowcontrol command [2-432](#)
 show idprom command [2-434](#)
 show interfaces command [2-436](#)
 show interfaces counters command [2-446](#)
 show inventory command [2-449](#)
 show ip arp inspection command [2-450](#)
 show ipc command [2-476](#)
 show ip dhcp snooping binding command [2-455](#)
 show ip dhcp snooping command [2-454](#)
 show ip dhcp snooping database command [2-457, 2-459](#)

- show ip igmp profile command [2-462](#)
- show ip igmp snooping address command [2-484](#)
- show ip igmp snooping command [2-463, 2-482](#)
- show ip igmp snooping groups command [2-466](#)
- show ip igmp snooping mrouter command [2-468, 2-486](#)
- show ip igmp snooping querier command [2-470, 2-488](#)
- show ip source binding command [2-472](#)
- show ipv6 access-list command [2-480](#)
- show ipv6 route updated [2-490](#)
- show ip verify source command [2-474](#)
- show l2protocol-tunnel command [2-492](#)
- show lacp command [2-495](#)
- show link state group command [2-499](#)
- show location [2-501](#)
- show location command [2-501](#)
- show logging command [2-504](#)
- show mac access-group command [2-509](#)
- show mac address-table address command [2-513](#)
- show mac address-table aging time command [2-515](#)
- show mac address-table command [2-511](#)
- show mac address-table count command [2-517](#)
- show mac address-table dynamic command [2-519](#)
- show mac address-table interface command [2-521](#)
- show mac address-table move update command [2-523](#)
- show mac address-table notification command [2-58, 2-525, B-19](#)
- show mac address-table static command [2-527](#)
- show mac address-table vlan command [2-529](#)
- show mls qos aggregate-policer command [2-532](#)
- show mls qos command [2-531](#)
- show mls qos input-queue command [2-533](#)
- show mls qos interface command [2-535](#)
- show mls qos maps command [2-539](#)
- show mls qos queue-set command [2-542](#)
- show mls qos vlan command [2-544](#)
- show monitor command [2-545](#)
- show mvr command [2-548](#)
- show mvr interface command [2-550](#)
- show mvr members command [2-552](#)
- show pagp command [2-554](#)
- show parser macro command [2-556](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform chassis command [C-4](#)
- show platform configuration command [C-6](#)
- show platform dl command [C-7](#)
- show platform etherchannel command [C-8](#)
- show platform forward command [C-9](#)
- show platform frontend-controller command [C-11](#)
- show platform igmp snooping command [C-12](#)
- show platform ipc trace command [C-20](#)
- show platform ip multicast command [C-14](#)
- show platform ip unicast command [C-15](#)
- show platform ipv6 unicast command [C-21](#)
- show platform ip wccp command [C-19](#)
- show platform layer4op command [C-23](#)
- show platform mac-address-table command [C-24](#)
- show platform messaging command [C-25](#)
- show platform monitor command [C-26](#)
- show platform mvr table command [C-27](#)
- show platform pm command [C-28](#)
- show platform port-asic command [C-30](#)
- show platform port-security command [C-35](#)
- show platform qos command [C-36](#)
- show platform resource-manager command [C-37](#)
- show platform snmp counters command [C-39](#)
- show platform spanning-tree command [C-40](#)
- show platform stack-manager command [C-42](#)
- show platform stp-instance command [C-41](#)
- show platform summary command [C-44](#)
- show platform tb command [C-45](#)
- show platform team command [C-47](#)
- show platform vlan command [C-50](#)
- show policy-map command [2-559](#)
- show port security command [2-561](#)
- show proposed command [2-740](#)
- show sdm prefer command [2-564](#)
- show setup express command [2-567](#)

- show spanning-tree command [2-568](#)
- show storm-control command [2-574](#)
- show switch command [2-576](#)
- show system mtu command [2-579](#)
- show trust command [2-718](#)
- show udd command [2-580](#)
- show version command [2-583](#)
- show vlan access-map command [2-589](#)
- show vlan command [2-585](#)
- show vlan command, fields [2-587](#)
- show vlan filter command [2-590](#)
- show vmcs command [2-591](#)
- show vtp command [2-593](#)
- shutdown command [2-597](#)
- shutdown threshold, Layer 2 protocol tunneling [2-219](#)
- shutdown vlan command [2-598](#)
- Smartports macros
 - See macros
- SNMP host, specifying [2-603](#)
- SNMP informs, enabling the sending of [2-599](#)
- snmp-server enable traps command [2-599](#)
- snmp-server host command [2-603](#)
- snmp trap mac-notification command [2-607](#)
- SNMP traps
 - enabling MAC address notification trap [2-607](#)
 - enabling the MAC address notification feature [2-243](#)
 - enabling the sending of [2-599](#)
- SoftPhone
 - See Cisco SoftPhone
- software images
 - copying [2-8](#)
 - deleting [2-70](#)
 - downloading [2-11](#)
 - upgrading [2-8, 2-11](#)
 - uploading [2-18](#)
- software version, displaying [2-583](#)
- source ports, MVR [2-309](#)

SPAN

- configuring [2-302](#)
- debug messages, display [B-20](#)
- displaying [2-545](#)
- filter SPAN traffic [2-302](#)
- sessions
 - add interfaces to [2-302](#)
 - displaying [2-545](#)
 - start new [2-302](#)
- spanning-tree backbonefast command [2-609](#)
- spanning-tree bpduguard command [2-610](#)
- spanning-tree bpduguard command [2-612](#)
- spanning-tree cost command [2-614](#)
- spanning-tree etherchannel command [2-616](#)
- spanning-tree extend system-id command [2-618](#)
- spanning-tree guard command [2-620](#)
- spanning-tree link-type command [2-622](#)
- spanning-tree loopguard default command [2-624](#)
- spanning-tree mode command [2-626](#)
- spanning-tree mst configuration command [2-628](#)
- spanning-tree mst cost command [2-630](#)
- spanning-tree mst forward-time command [2-632](#)
- spanning-tree mst hello-time command [2-633](#)
- spanning-tree mst max-age command [2-634](#)
- spanning-tree mst max-hops command [2-635](#)
- spanning-tree mst port-priority command [2-636](#)
- spanning-tree mst pre-standard command [2-638](#)
- spanning-tree mst priority command [2-639](#)
- spanning-tree mst root command [2-640](#)
- spanning-tree portfast (global configuration) command [2-644](#)
- spanning-tree portfast (interface configuration) command [2-647](#)
- spanning-tree port-priority command [2-642](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree transmit hold-count command [2-649](#)
- spanning-tree uplinkfast command [2-650](#)
- spanning-tree vlan command [2-652](#)

- speed command [2-655](#)
- srr-queue bandwidth limit command [2-657](#)
- srr-queue bandwidth shape command [2-659](#)
- srr-queue bandwidth share command [2-661](#)
- SSH, configuring version [2-198](#)
- stack-mac persistent timer command [2-663](#)
- stack member
 - access [2-366](#)
 - number [2-576, 2-671](#)
 - priority value [2-668](#)
 - provisioning [2-669](#)
 - reloading [2-349](#)
- stacks, switch
 - MAC address [2-663](#)
 - provisioning a new member [2-669](#)
 - reloading [2-349](#)
 - stack member access [2-366](#)
 - stack member number [2-576, 2-671](#)
 - stack member priority value [2-576, 2-668](#)
- static-access ports, configuring [2-675](#)
- statistics, Ethernet group [2-357](#)
- sticky learning, enabling [2-689](#)
- storm-control command [2-665](#)
- STP
 - BackboneFast [2-609](#)
 - counters, clearing [2-62](#)
 - debug messages, display
 - BackboneFast events [B-75](#)
 - MSTP [B-78](#)
 - optimized BPDUs handling [B-73](#)
 - spanning-tree activity [B-73](#)
 - switch shim [B-80](#)
 - transmitted and received BPDUs [B-76](#)
 - UplinkFast [B-82](#)
 - detection of indirect link failures [2-609](#)
 - enabling protocol tunneling for [2-219](#)
 - EtherChannel misconfiguration [2-616](#)
 - extended system ID [2-618](#)
 - path cost [2-614](#)
- STP (continued)
 - protocol modes [2-626](#)
 - root port
 - accelerating choice of new [2-650](#)
 - loop guard [2-620](#)
 - preventing from becoming designated [2-620](#)
 - restricting which can be root [2-620](#)
 - root guard [2-620](#)
 - UplinkFast [2-650](#)
 - root switch
 - affects of extended system ID [2-618, 2-653](#)
 - hello-time [2-652](#)
 - interval between BDPU messages [2-652](#)
 - interval between hello BPDU messages [2-652](#)
 - max-age [2-652](#)
 - port priority for selection of [2-642](#)
 - primary or secondary [2-652](#)
 - switch priority [2-652](#)
 - state changes
 - blocking to forwarding state [2-647](#)
 - enabling BPDU filtering [2-610, 2-644](#)
 - enabling BPDU guard [2-612, 2-644](#)
 - enabling Port Fast [2-644, 2-647](#)
 - enabling timer to recover from error state [2-121](#)
 - forward-delay time [2-652](#)
 - length of listening and learning states [2-652](#)
 - shutting down Port Fast-enabled ports [2-644](#)
 - state information display [2-568](#)
 - VLAN options [2-639, 2-652](#)
- SVIs, creating [2-134](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-673](#)
 - returning to interfaces [2-673](#)
- switchport access command [2-675](#)
- switchport backup interface command [2-677](#)
- switchport block command [2-680](#)
- switchport command [2-673](#)

switchport host command [2-681](#)
 switchport mode command [2-682](#)
 switchport mode private-vlan command [2-685](#)
 switchport nonegotiate command [2-687](#)
 switchport port-security aging command [2-694](#)
 switchport port-security command [2-689](#)
 switchport priority extend command [2-696](#)
 switchport private-vlan command [2-698](#)
 switchport protected command [2-700](#)
 switchports, displaying [2-436](#)
 switchport trunk command [2-702](#)
 switchport voice detect [2-705](#)
 switchport voice vlan command [2-706](#)
 switch priority command [2-668](#)
 switch provision command [2-669](#)
 switch renumber command [2-671](#)
 system env temperature threshold yellow command [2-708](#)
 system message logging, save message to flash [2-234](#)
 system mtu command [2-710](#)
 system resource templates [2-358](#)

T

tar files, creating, listing, and extracting [2-15](#)
 TDR, running [2-712](#)
 temperature information, displaying [2-420](#)
 templates, system resources [2-358](#)
 test cable-diagnostics tdr command [2-712](#)
 traceroute mac command [2-713](#)
 traceroute mac ip command [2-716](#)
 trunking, VLAN mode [2-682](#)
 trunk mode [2-682](#)
 trunk ports [2-682](#)
 trunks, to non-DTP device [2-683](#)
 trusted boundary for QoS [2-299](#)
 trusted port states for QoS [2-299](#)
 tunnel ports, Layer 2 protocol, displaying [2-492](#)
 type (boot loader) command [A-23](#)

U

UDLD

aggressive mode [2-720, 2-722](#)
 debug messages, display [B-90](#)
 enable globally [2-720](#)
 enable per interface [2-722](#)
 error recovery timer [2-121](#)
 message timer [2-720](#)
 normal mode [2-720, 2-722](#)
 reset a shutdown interface [2-724](#)
 status [2-580](#)

udld command [2-720](#)

udld port command [2-722](#)

udld reset command [2-724](#)

unicast storm control [2-665](#)

UniDirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-680](#)

unknown unicast traffic, preventing [2-680](#)

unset (boot loader) command [A-24](#)

upgrading

copying software images [2-8](#)

downloading software images [2-11](#)

software images, monitoring status of [2-377](#)

UplinkFast, for STP [2-650](#)

user EXEC mode [1-2, 1-3](#)

V

version (boot loader) command [A-26](#)

version mismatch mode [2-577](#)

vlan (global configuration) command [2-725](#)

vlan (VLAN configuration) command [2-731](#)

vlan access-map command [2-737](#)

VLAN access map configuration mode [2-737](#)

VLAN access maps

actions [2-6](#)

displaying [2-589](#)

VLAN-based QoS [2-301](#)

VLAN configuration

rules [2-728, 2-733](#)

saving [2-725, 2-735](#)

VLAN configuration mode

commands

VLAN [2-731](#)

VTP [2-755](#)

description [1-5](#)

entering [2-739](#)

summary [1-3](#)

vlan database command [2-739](#)

vlan dot1q tag native command [2-742](#)

vlan filter command [2-744](#)

VLAN filters, displaying [2-590](#)

VLAN ID range [2-725, 2-731](#)

VLAN maps

applying [2-744](#)

creating [2-737](#)

defining [2-258](#)

displaying [2-589](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-725](#)

configuring [2-725, 2-731](#)

debug messages, display

ISL [B-86](#)

VLAN IOS file system error tests [B-85](#)

VLAN manager activity [B-83](#)

VTP [B-88](#)

displaying configurations [2-585](#)

extended-range [2-725](#)

MAC addresses

displaying [2-529](#)

number of [2-517](#)

media types [2-728, 2-733](#)

normal-range [2-725, 2-731](#)

VLANs (continued)

private [2-685](#)

configuring [2-339](#)

displaying [2-585](#)

See also private VLANs

restarting [2-598](#)

saving the configuration [2-725](#)

shutting down [2-598](#)

SNMP traps for VTP [2-601, 2-604](#)

suspending [2-598](#)

variables [2-731](#)

VLAN Trunking Protocol

See VTP

VM mode [2-577](#)

VMPS

configuring servers [2-749](#)

displaying [2-591](#)

error recovery timer [2-121](#)

reconfirming dynamic VLAN assignments [2-746](#)

vmmps reconfirm (global configuration) command [2-747](#)

vmmps reconfirm (privileged EXEC) command [2-746](#)

vmmps retry command [2-748](#)

vmmps server command [2-749](#)

voice VLAN

configuring [2-705, 2-706](#)

setting port priority [2-696](#)

VQP

and dynamic-access ports [2-676](#)

clearing client statistics [2-64](#)

displaying information [2-591](#)

per-server retry count [2-748](#)

reconfirmation interval [2-747](#)

reconfirming dynamic VLAN assignments [2-746](#)

VTP

changing characteristics [2-751](#)

clearing pruning counters [2-65](#)

VTP (continued)

- configuring
 - domain name [2-751, 2-755](#)
 - file name [2-751](#)
 - mode [2-751, 2-755](#)
 - password [2-751, 2-755](#)
- counters display fields [2-594](#)
- displaying information [2-593](#)
- enabling
 - pruning [2-751, 2-755](#)
 - tunneling for [2-219](#)
 - Version 2 [2-751, 2-755](#)
- mode [2-751, 2-755](#)
- pruning [2-751, 2-755](#)
- saving the configuration [2-725, 2-735](#)
- statistics [2-593](#)
- status [2-593](#)
- status display fields [2-595](#)
- vtp (global configuration) command [2-751](#)
- vtp (VLAN configuration) command [2-755](#)

