



INDEX

A

- aaa accounting dot1x command [2-1](#)
- aaa authentication dot1x command [2-3](#)
- aaa authorization network command [2-5, 2-24, 2-30, 2-32, 2-34, 2-36, 2-38, 2-144, 2-311, 2-482, B-7, B-32](#)
- AAA methods [2-3](#)
- access control entries
 - See ACEs
- access control lists
 - See ACLs
- access groups
 - IP [2-194](#)
 - MAC, displaying [2-607](#)
- access list, IPv6 [2-268](#)
- access map configuration mode [2-337](#)
- access mode [2-799](#)
- access ports [2-799](#)
- ACEs [2-128, 2-414](#)
- ACLs
 - deny [2-126](#)
 - displaying [2-464](#)
 - for non-IP protocols [2-315](#)
 - IP [2-194](#)
 - matching [2-337](#)
 - on Layer 2 interfaces [2-194](#)
 - permit [2-412](#)
- action command [2-6](#)
- aggregate-port learner [2-401](#)
- allowed VLANs [2-819](#)
- archive copy-sw command [2-8](#)
- archive download-sw command [2-11](#)
- archive tar command [2-15](#)
- archive upload-sw command [2-18](#)
- arp (boot loader) command [A-2](#)
- arp access-list command [2-20](#)
- authentication command disable-port ignore [2-23](#)
- authentication control-direction command [2-24](#)
- authentication event command [2-26](#)
- authentication failed VLAN
 - See dot1x auth-fail vlan
- authentication fallback command [2-30](#)
- authentication host-mode command [2-32](#)
- authentication mac-move permit command [2-34](#)
- authentication open command [2-36](#)
- authentication order command [2-38](#)
- authentication periodic command [2-40](#)
- authentication port-control command [2-42](#)
- authentication priority command [2-44](#)
- authentication timer command [2-46](#)
- authentication violation command [2-48](#)
- auth-fail max-attempts
 - See dot1x auth-fail max-attempts
- auth-fail vlan
 - See dot1x auth-fail vlan
- auth open command [2-36](#)
- auth order command [2-38](#)
- authorization state of controlled port [2-161](#)
- auth timer command [2-46](#)
- autonegotiation of duplex mode [2-171](#)
- auto qos classify command [2-50](#)
- auto qos trust command [2-53](#)
- auto qos video command [2-56](#)
- auto qos voip command [2-59](#)

B

BackboneFast, for STP [2-721](#)

backup interfaces

- configuring [2-793](#)
- displaying [2-531](#)

boot (boot loader) command [A-3](#)

boot auto-copy-sw command [2-66](#)

boot auto-download-sw command [2-68](#)

boot config-file command [2-71](#)

boot enable-break command [2-72](#)

boot helper command [2-73](#)

boot helper-config file command [2-74](#)

booting

- Cisco IOS image [2-77](#)
- displaying environment variables [2-477](#)
- interrupting [2-72](#)
- manually [2-75](#)

boot loader

- accessing [A-1](#)
- booting
 - Cisco IOS image [A-3](#)
 - helper image [2-73](#)
- directories
 - creating [A-19](#)
 - displaying a list of [A-8](#)
 - removing [A-23](#)
- displaying
 - available commands [A-13](#)
 - memory heap utilization [A-14](#)
 - version [A-30](#)
- environment variables
 - described [A-24](#)
 - displaying settings [A-24](#)
 - location of [A-25](#)
 - setting [A-24](#)
 - unsetting [A-28](#)

files

- copying [A-6](#)
- deleting [A-7](#)
- displaying a list of [A-8](#)
- displaying the contents of [A-5, A-20, A-27](#)
- renaming [A-21](#)

file system

- formatting [A-11](#)
- initializing flash [A-10](#)
- running a consistency check [A-12](#)

prompt [A-1](#)

resetting the system [A-22](#)

boot manual command [2-75](#)

boot private-config-file command [2-76](#)

boot system command [2-77](#)

BPDU filtering, for spanning tree [2-722, 2-756](#)

BPDU guard, for spanning tree [2-724, 2-756](#)

broadcast storm control [2-777](#)

C

cat (boot loader) command [A-5](#)

CDP, enabling protocol tunneling for [2-294](#)

channel-group command [2-79](#)

channel-protocol command [2-83](#)

Cisco IP camera

- auto-QoS configuration [2-56](#)

Cisco SoftPhone

- auto-QoS configuration [2-59](#)
- trusting packets sent from [2-378](#)

Cisco Telepresence System

- auto-QoS configuration [2-56](#)

CISP

- See Client Information Signalling Protocol

cisp

- debug platform cisp command [B-32](#)

cisp enable command [2-84](#)

class command [2-85](#)

- class-map command [2-88](#)
- class maps
 - creating [2-88](#)
 - defining the match criteria [2-339](#)
 - displaying [2-483](#)
- class of service
 - See CoS
- clear dot1x command [2-90](#)
- clear eap command [2-91](#)
- clear errdisable interface [2-92](#)
- clear ip arp inspection log command [2-93](#)
- clear ip arp inspection statistics command [2-94](#)
- clear ipc command [2-99](#)
- clear ip dhcp snooping database command [2-95, 2-97](#)
- clear ipv6 dhcp conflict command [2-100](#)
- clear l2protocol-tunnel counters command [2-101](#)
- clear lacp command [2-102](#)
- clear logging command [2-103](#)
- clear mac address-table command [2-104, 2-105](#)
- clear nmsp statistics command [2-106](#)
- clear pagp command [2-107](#)
- clear port-security command [2-108](#)
- clear spanning-tree counters command [2-110](#)
- clear spanning-tree detected-protocols command [2-111](#)
- clear vmpls statistics command [2-112](#)
- clear vtp counters command [2-113](#)
- Client Information Signalling Protocol [2-84, 2-144, 2-482, B-7, B-32](#)
- command modes defined [1-2](#)
- configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-71, 2-76](#)
- configuring multiple interfaces [2-190](#)
- config-vlan mode
 - commands [2-843](#)
 - entering [2-842](#)
- copy (boot loader) command [A-6](#)
- copy logging onboard command [2-114](#)

- CoS
 - assigning default value to incoming packets [2-348](#)
 - assigning to Layer 2 protocol packets [2-297](#)
 - overriding the incoming value [2-348](#)
- CoS-to-DSCP map [2-352](#)
- CPU ASIC statistics, displaying [2-484](#)
- crashinfo files [2-181](#)
- critical VLAN [2-27](#)

D

- debug authentication [B-2](#)
- debug auto qos command [B-4](#)
- debug backup command [B-6](#)
- debug cisp command [B-7](#)
- debug dot1x command [B-8](#)
- debug dtp command [B-9](#)
- debug eap command [B-10](#)
- debug etherchannel command [B-11](#)
- debug fastethernet command [B-12](#)
- debug interface command [B-15](#)
- debug ip dhcp snooping command [B-13](#)
- debug ip igmp filter command [B-16](#)
- debug ip igmp max-groups command [B-17](#)
- debug ip igmp snooping command [B-18](#)
- debug ip verify source packet command [B-14](#)
- debug lacp command [B-19](#)
- debug lldp packets command [B-20](#)
- debug mac-notification command [B-21](#)
- debug matm command [B-22](#)
- debug matm move update command [B-23](#)
- debug monitor command [B-24](#)
- debug mvrdbg command [B-25](#)
- debug nmsp command [B-26](#)
- debug nvram command [B-27](#)
- debug pagp command [B-28](#)
- debug platform acl command [B-29](#)
- debug platform backup interface command [B-31](#)

- debug platform cisp command [B-32](#)
- debug platform cli-redirection main command [B-33](#)
- debug platform configuration command [B-34](#)
- debug platform cpu-queues command [B-35](#)
- debug platform device-manager command [B-37](#)
- debug platform dot1x command [B-38](#)
- debug platform etherchannel command [B-39](#)
- debug platform fallback-bridging command [B-40](#)
- debug platform forw-tcam command [B-41](#)
- debug platform ip arp inspection command [B-42](#)
- debug platform ipc command [B-51](#)
- debug platform ip dhcp command [B-43](#)
- debug platform ip igmp snooping command [B-44](#)
- debug platform ip multicast command [B-46](#)
- debug platform ip unicast command [B-48](#)
- debug platform ip wccp command [B-50](#)
- debug platform led command [B-52](#)
- debug platform matm command [B-53](#)
- debug platform messaging application command [B-54](#)
- debug platform phy command [B-56](#)
- debug platform pm command [B-58](#)
- debug platform port-asic command [B-60](#)
- debug platform port-security command [B-61](#)
- debug platform qos-acl-tcam command [B-62](#)
- debug platform remote-commands command [B-63](#)
- debug platform resource-manager command [B-64](#)
- debug platform snmp command [B-65](#)
- debug platform span command [B-66](#)
- debug platform stack-manager command [B-67](#)
- debug platform supervisor-asic command [B-68](#)
- debug platform sw-bridge command [B-69](#)
- debug platform tcam command [B-70](#)
- debug platform udd command [B-73](#)
- debug platform vlan command [B-74](#)
- debug pm command [B-75](#)
- debug port-security command [B-77](#)
- debug qos-manager command [B-78](#)
- debug spanning-tree backbonefast command [B-81](#)
- debug spanning-tree bpdu command [B-82](#)
- debug spanning-tree bpdu-opt command [B-83](#)
- debug spanning-tree command [B-79](#)
- debug spanning-tree mstp command [B-84](#)
- debug spanning-tree switch command [B-86](#)
- debug spanning-tree uplinkfast command [B-88](#)
- debug sw-vlan command [B-89](#)
- debug sw-vlan ifs command [B-91](#)
- debug sw-vlan notification command [B-92](#)
- debug sw-vlan vtp command [B-94](#)
- debug udd command [B-96](#)
- debug vqpc command [B-98](#)
- define interface-range command [2-116](#)
- delete (boot loader) command [A-7](#)
- delete command [2-118](#)
- deny (ARP access-list configuration) command [2-119](#)
- deny (IPv6) command [2-121](#)
- deny command [2-126](#)
- detect mechanism, causes [2-174](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-226](#)
 - enabling
 - on a VLAN [2-232](#)
 - option 82 [2-224, 2-226](#)
 - trust on an interface [2-230](#)
 - error recovery timer [2-178](#)
 - rate limiting [2-229](#)
- DHCP snooping binding database
 - binding file, configuring [2-222](#)
 - bindings
 - adding [2-220](#)
 - deleting [2-220](#)
 - displaying [2-552](#)
 - clearing database agent statistics [2-95, 2-97](#)
 - database agent, configuring [2-222](#)
 - displaying
 - binding entries [2-552](#)
 - database agent status [2-554, 2-556](#)
 - renewing [2-443](#)
- dir (boot loader) command [A-8](#)

- directories, deleting [2-118](#)
- domain name, VTP [2-861](#)
- dot1x auth-fail max-attempts [2-138](#)
- dot1x auth-fail vlan [2-140](#)
- dot1x command [2-136](#)
- dot1x control-direction command [2-142](#)
- dot1x credentials (global configuration) command [2-144](#)
- dot1x critical global configuration command [2-145](#)
- dot1x critical interface configuration command [2-147](#)
- dot1x default command [2-149](#)
- dot1x fallback command [2-150](#)
- dot1x guest-vlan command [2-151](#)
- dot1x host-mode command [2-153](#)
- dot1x initialize command [2-154](#)
- dot1x mac-auth-bypass command [2-155](#)
- dot1x max-reauth-req command [2-157](#)
- dot1x max-req command [2-159](#)
- dot1x pae command [2-160](#)
- dot1x port-control command [2-161](#)
- dot1x re-authenticate command [2-163](#)
- dot1x reauthentication command [2-164](#)
- dot1x supplicant force-multicast command [2-165](#)
- dot1x timeout command [2-166](#)
- dot1x violation-mode command [2-169](#)
- dropping packets, with ACL matches [2-6](#)
- drop threshold, Layer 2 protocol tunneling [2-294](#)
- DSCP-to-CoS map [2-352](#)
- DSCP-to-DSCP-mutation map [2-352](#)
- DTP [2-800](#)
- DTP flap
 - error detection for [2-174](#)
 - error recovery timer [2-178](#)
- DTP negotiation [2-804](#)
- dual IPv4 and IPv6 templates [2-407](#)
- duplex command [2-171](#)
- dynamic-access ports
 - configuring [2-789](#)
 - restrictions [2-790](#)
- dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [2-202](#)
 - define [2-20](#)
 - deny packets [2-119](#)
 - display [2-468](#)
 - permit packets [2-405](#)
 - clear
 - log buffer [2-93](#)
 - statistics [2-94](#)
 - display
 - ARP ACLs [2-468](#)
 - configuration and operating state [2-547](#)
 - log buffer [2-547](#)
 - statistics [2-547](#)
 - trust state and rate limit [2-547](#)
 - enable per VLAN [2-212](#)
 - error detection for [2-174](#)
 - error recovery timer [2-178](#)
 - log buffer
 - clear [2-93](#)
 - configure [2-206](#)
 - display [2-547](#)
 - rate-limit incoming ARP packets [2-204](#)
 - statistics
 - clear [2-94](#)
 - display [2-547](#)
 - trusted interface state [2-208](#)
 - type of packet logged [2-213](#)
 - validation checks [2-210](#)
- dynamic auto VLAN membership mode [2-799](#)
- dynamic desirable VLAN membership mode [2-799](#)
- Dynamic Host Configuration Protocol (DHCP)
 - See DHCP snooping
- Dynamic Trunking Protocol
 - See DTP

E

EAP-request/identity frame

- maximum number to send [2-159](#)
- response time before retransmitting [2-166](#)

encapsulation methods [2-819](#)

environment variables, displaying [2-477](#)

epm access-control open [2-173](#)

errdisable detect cause command [2-174](#)

errdisable detect cause small-frame comand [2-176](#)

errdisable recovery cause small-frame [2-180](#)

errdisable recovery command [2-178](#)

error conditions, displaying [2-519](#)

error disable detection [2-174](#)

error-disabled interfaces, displaying [2-531](#)

EtherChannel

assigning Ethernet interface to channel group [2-79](#)

creating port-channel logical interface [2-188](#)

debug EtherChannel/PAGP, display [B-11](#)

debug platform-specific events, display [B-39](#)

displaying [2-522](#)

enabling Layer 2 protocol tunneling for

LACP [2-295](#)

PAGP [2-295](#)

UDLD [2-295](#)

interface information, displaying [2-531](#)

LACP

clearing channel-group information [2-102, 2-103](#)

debug messages, display [B-19](#)

displaying [2-592](#)

modes [2-79](#)

port priority for hot-standby ports [2-298](#)

restricting a protocol [2-83](#)

system priority [2-300](#)

load-distribution methods [2-423](#)

PAGP

aggregate-port learner [2-401](#)

clearing channel-group information [2-107](#)

debug messages, display [B-28](#)

displaying [2-658](#)

error detection for [2-174](#)

error recovery timer [2-178](#)

learn method [2-401](#)

modes [2-79](#)

physical-port learner [2-401](#)

priority of interface for transmitted traffic [2-403](#)

Ethernet controller, internal register display [2-486, 2-493](#)

Ethernet Management port, debugging [B-12](#)

Ethernet statistics, collecting [2-447](#)

exception crashinfo command [2-181, 2-186](#)

extended-range VLANs

and allowed VLAN list [2-819](#)

and pruning-eligible list [2-819](#)

configuring [2-842](#)

extended system ID for STP [2-730](#)

F

fallback profile command [2-182](#)

fallback profiles, displaying [2-525](#)

fan information, displaying [2-515](#)

file name, VTP [2-861](#)

files, deleting [2-118](#)

flash_init (boot loader) command [A-10](#)

flexible authentication ordering [2-38](#)

Flex Links

configuring [2-793](#)

displaying [2-531](#)

flowcontrol command [2-184](#)

format (boot loader) command [A-11](#)

forwarding packets, with ACL matches [2-6](#)

forwarding results, display [C-9](#)

frame forwarding information, displaying [C-9](#)

front-end controller counter and status information [C-11](#)

fsck (boot loader) command [A-12](#)

G

global configuration mode [1-2, 1-4](#)

H

hardware ACL statistics [2-464](#)
 health monitoring diagnostic tests [2-129](#)
 help (boot loader) command [A-13](#)
 hierarchical policy maps [2-421](#)
 host connection, port configuration [2-798](#)
 host ports, private VLANs [2-802](#)

I

IEEE 802.1Q trunk ports and native VLANs [2-852](#)
 IEEE 802.1Q tunnel ports
 configuring [2-799](#)
 displaying [2-505](#)
 limitations [2-800](#)
 IEEE 802.1x
 and switchport modes [2-800](#)
 violation error recovery [2-178](#)
 See also port-based authentication
 IGMP filters
 applying [2-235](#)
 debug messages, display [B-16](#)
 IGMP groups, setting maximum [2-237](#)
 IGMP maximum groups, debugging [B-17](#)
 IGMP profiles
 creating [2-239](#)
 displaying [2-559](#)
 IGMP snooping
 adding ports as a static member of a group [2-255](#)
 displaying [2-560, 2-565, 2-567](#)
 enabling [2-241](#)
 enabling the configurable-leave timer [2-243](#)
 enabling the Immediate-Leave feature [2-252](#)
 flooding query count [2-249](#)

interface topology change notification behavior [2-251](#)
 multicast table [2-563](#)
 querier [2-245](#)
 query solicitation [2-249](#)
 report suppression [2-247](#)
 switch topology change notification behavior [2-249](#)
 images
 See software images
 Immediate-Leave processing
 IGMP [2-252](#)
 IPv6 [2-290](#)
 MVR [2-388](#)
 interface configuration mode [1-2, 1-4](#)
 interface port-channel command [2-188](#)
 interface range command [2-190](#)
 interface-range macros [2-116](#)
 interfaces
 assigning Ethernet interface to channel group [2-79](#)
 configuring [2-171](#)
 configuring multiple [2-190](#)
 creating port-channel logical [2-188](#)
 debug messages, display [B-15](#)
 disabling [2-707](#)
 displaying the MAC address table [2-619](#)
 restarting [2-707](#)
 interface speed, configuring [2-767](#)
 interface vlan command [2-192](#)
 internal registers, displaying [2-486, 2-493, 2-496](#)
 Internet Group Management Protocol
 See IGMP
 ip access-group command [2-194](#)
 ip address command [2-197](#)
 IP addresses, setting [2-197](#)
 IP address matching [2-337](#)
 ip admission command [2-199](#)
 ip admission name proxy http command [2-200](#)
 ip arp inspection filter vlan command [2-202](#)
 ip arp inspection limit command [2-204](#)
 ip arp inspection log-buffer command [2-206](#)

- ip arp inspection trust command [2-208](#)
 - ip arp inspection validate command [2-210](#)
 - ip arp inspection vlan command [2-212](#)
 - ip arp inspection vlan logging command [2-213](#)
 - ip device tracking command [2-215](#)
 - ip device tracking probe command [2-217](#)
 - IP DHCP snooping
 - See DHCP snooping
 - ip dhcp snooping binding command [2-220](#)
 - ip dhcp snooping command [2-219](#)
 - ip dhcp snooping database command [2-222](#)
 - ip dhcp snooping information option allow-untrusted command [2-226](#)
 - ip dhcp snooping information option command [2-224](#)
 - ip dhcp snooping information option format remote-id command [2-228](#)
 - ip dhcp snooping limit rate command [2-229](#)
 - ip dhcp snooping trust command [2-230](#)
 - ip dhcp snooping verify command [2-231](#)
 - ip dhcp snooping vlan command [2-232](#)
 - ip dhcp snooping vlan information option format-type circuit-id string command [2-233](#)
 - ip igmp filter command [2-235](#)
 - ip igmp max-groups command [2-237](#), [2-262](#), [2-264](#)
 - ip igmp profile command [2-239](#)
 - ip igmp snooping command [2-241](#)
 - ip igmp snooping last-member-query-interval command [2-243](#)
 - ip igmp snooping querier command [2-245](#)
 - ip igmp snooping report-suppression command [2-247](#)
 - ip igmp snooping tcn command [2-249](#)
 - ip igmp snooping tcn flood command [2-251](#)
 - ip igmp snooping vlan immediate-leave command [2-252](#)
 - ip igmp snooping vlan mrouter command [2-253](#)
 - ip igmp snooping vlan static command [2-255](#)
 - IP multicast addresses [2-385](#)
 - IP phones
 - auto-QoS configuration [2-59](#)
 - trusting packets sent from [2-378](#)
 - IP-precedence-to-DSCP map [2-352](#)
 - ip snap forwarding command [2-257](#)
 - ip source binding command [2-258](#)
 - IP source guard
 - disabling [2-266](#)
 - displaying
 - binding entries [2-569](#)
 - configuration [2-570](#)
 - dynamic binding entries only [2-552](#)
 - enabling [2-266](#)
 - static IP source bindings [2-258](#)
 - ip ssh command [2-260](#)
 - IPv6 access list, deny conditions [2-121](#)
 - ipv6 access-list command [2-268](#)
 - ipv6 address dhcp command [2-270](#)
 - ipv6 dhcp client request vendor command [2-271](#)
 - ipv6 dhcp ping packets command [2-272](#)
 - ipv6 dhcp pool command [2-274](#)
 - ipv6 dhcp server command [2-276](#)
 - ipv6 mld snooping command [2-278](#)
 - ipv6 mld snooping last-listener-query count command [2-280](#)
 - ipv6 mld snooping last-listener-query-interval command [2-282](#)
 - ipv6 mld snooping listener-message-suppression command [2-284](#)
 - ipv6 mld snooping robustness-variable command [2-286](#)
 - ipv6 mld snooping tcn command [2-288](#)
 - ipv6 mld snooping vlan command [2-290](#)
 - IPv6 SDM template [2-448](#)
 - ipv6 traffic-filter command [2-292](#)
 - ip verify source command [2-266](#)
-
- ## J
- jumbo frames
 - See MTU

L

- l2protocol-tunnel command [2-294](#)
- l2protocol-tunnel cos command [2-297](#)
- LACP
 - See EtherChannel
- lacp port-priority command [2-298](#)
- lacp system-priority command [2-300](#)
- Layer 2 mode, enabling [2-787](#)
- Layer 2 protocol ports, displaying [2-589](#)
- Layer 2 protocol-tunnel
 - error detection for [2-174](#)
 - error recovery timer [2-178](#)
- Layer 2 protocol tunnel counters [2-101](#)
- Layer 2 protocol tunneling error recovery [2-295](#)
- Layer 2 traceroute
 - IP addresses [2-833](#)
 - MAC addresses [2-830](#)
- Layer 3 mode, enabling [2-787](#)
- line configuration mode [1-3, 1-5](#)
- Link Aggregation Control Protocol
 - See EtherChannel
- link flap
 - error detection for [2-174](#)
 - error recovery timer [2-178](#)
- link state group command [2-302](#)
- link state track command [2-304](#)
- load-distribution methods for EtherChannel [2-423](#)
- location (global configuration) command [2-305](#)
- location (interface configuration) command [2-307](#)
- logging file command [2-309](#)
- logical interface [2-188](#)
- loopback error
 - detection for [2-174](#)
 - recovery timer [2-178](#)
- loop guard, for spanning tree [2-732, 2-736](#)

M

- mab request format attribute 32 command [2-311](#)
- mac access-group command [2-313](#)
- MAC access-groups, displaying [2-607](#)
- MAC access list configuration mode [2-315](#)
- mac access-list extended command [2-315](#)
- MAC access lists [2-126](#)
- MAC addresses
 - disabling MAC address learning per VLAN [2-318](#)
 - displaying
 - aging time [2-613](#)
 - all [2-611](#)
 - dynamic [2-617](#)
 - MAC address-table move updates [2-622](#)
 - notification settings [2-621, 2-624](#)
 - number of addresses in a VLAN [2-615](#)
 - per interface [2-619](#)
 - per VLAN [2-628](#)
 - static [2-626](#)
 - static and dynamic entries [2-609](#)
 - dynamic
 - aging time [2-317](#)
 - deleting [2-104](#)
 - displaying [2-617](#)
 - enabling MAC address notification [2-322](#)
 - enabling MAC address-table move update [2-320](#)
 - matching [2-337](#)
 - persistent stack [2-775](#)
 - static
 - adding and removing [2-324](#)
 - displaying [2-626](#)
 - dropping on an interface [2-325](#)
 - tables [2-611](#)
- MAC address notification, debugging [B-21](#)
- mac address-table aging-time [2-313, 2-337](#)
- mac address-table aging-time command [2-317](#)
- mac address-table learning command [2-318](#)
- mac address-table move update command [2-320](#)

- mac address-table notification command [2-322](#)
- mac address-table static command [2-324](#)
- mac address-table static drop command [2-325](#)
- MAC frames
 - See MTU
- macro apply command [2-327](#)
- macro description command [2-330](#)
- macro global command [2-331](#)
- macro global description command [2-334](#)
- macro name command [2-335](#)
- macros
 - adding a description [2-330](#)
 - adding a global description [2-334](#)
 - applying [2-331](#)
 - creating [2-335](#)
 - displaying [2-660](#)
 - interface range [2-116, 2-190](#)
 - specifying parameter values [2-331](#)
 - tracing [2-331](#)
- maps
 - QoS
 - defining [2-352](#)
 - displaying [2-638](#)
 - VLAN
 - creating [2-849](#)
 - defining [2-337](#)
 - displaying [2-697](#)
- match (access-map configuration) command [2-337](#)
- match (class-map configuration) command [2-339](#)
- maximum transmission unit
 - See MTU
- mdix auto command [2-342](#)
- memory (boot loader) command [A-14](#)
- mgmt_clr (boot loader) command [A-16](#)
- mgmt_init (boot loader) command [A-17, A-18](#)
- mkdir (boot loader) command [A-19](#)
- MLD snooping
 - configuring [2-284, 2-286](#)
 - configuring queries [2-280, 2-282](#)
 - configuring topology change notification [2-288](#)
 - displaying [2-579, 2-581, 2-583, 2-585](#)
 - enabling [2-278](#)
 - enabling on a VLAN [2-290](#)
- mls qos aggregate-policer command [2-346](#)
- mls qos command [2-344](#)
- mls qos cos command [2-348](#)
- mls qos dscp-mutation command [2-350](#)
- mls qos map command [2-352](#)
- mls qos queue-set output buffers command [2-356](#)
- mls qos queue-set output threshold command [2-358](#)
- mls qos rewrite ip dscp command [2-360](#)
- mls qos srr-queue input bandwidth command [2-362](#)
- mls qos srr-queue input buffers command [2-364](#)
- mls qos srr-queue input cos-map command [2-366](#)
- mls qos srr-queue input dscp-map command [2-368](#)
- mls qos srr-queue input priority-queue command [2-370](#)
- mls qos srr-queue input threshold command [2-372](#)
- mls qos srr-queue output cos-map command [2-374](#)
- mls qos srr-queue output dscp-map command [2-376](#)
- mls qos trust command [2-378](#)
- mls qos vlan-based command [2-380](#)
- mode, MVR [2-385](#)
- Mode button, and password recovery [2-451](#)
- modes, commands [1-2](#)
- monitor session command [2-381](#)
- more (boot loader) command [A-20](#)
- MSTP
 - displaying [2-674](#)
 - interoperability [2-111](#)
 - link type [2-734](#)
 - MST region
 - aborting changes [2-740](#)
 - applying changes [2-740](#)

MSTP (continued)

- configuration name [2-740](#)
- configuration revision number [2-740](#)
- current or pending display [2-740](#)
- displaying [2-674](#)
- MST configuration mode [2-740](#)
- VLANs-to-instance mapping [2-740](#)
- path cost [2-742](#)
- protocol mode [2-738](#)
- restart protocol migration process [2-111](#)
- root port
 - loop guard [2-732](#)
 - preventing from becoming designated [2-732](#)
 - restricting which can be root [2-732](#)
 - root guard [2-732](#)
- root switch
 - affects of extended system ID [2-730](#)
 - hello-time [2-745, 2-752](#)
 - interval between BPDU messages [2-746](#)
 - interval between hello BPDU messages [2-745, 2-752](#)
 - max-age [2-746](#)
 - maximum hop count before discarding BPDU [2-747](#)
 - port priority for selection of [2-748](#)
 - primary or secondary [2-752](#)
 - switch priority [2-751](#)
- state changes
 - blocking to forwarding state [2-759](#)
 - enabling BPDU filtering [2-722, 2-756](#)
 - enabling BPDU guard [2-724, 2-756](#)
 - enabling Port Fast [2-756, 2-759](#)
 - forward-delay time [2-744](#)
 - length of listening and learning states [2-744](#)
 - rapid transition to forwarding [2-734](#)
 - shutting down Port Fast-enabled ports [2-756](#)
- state information display [2-673](#)

MTU

- configuring size [2-827](#)
- displaying global setting [2-686](#)

Multicast Listener Discovery

See MLD

multicast group address, MVR [2-388](#)

multicast groups, MVR [2-386](#)

Multicast Listener Discovery

See MLD

multicast router learning method [2-253](#)

multicast router ports, configuring [2-253](#)

multicast router ports, IPv6 [2-290](#)

multicast storm control [2-777](#)

multicast VLAN, MVR [2-385](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-153](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

- configuring [2-385](#)
- configuring interfaces [2-388](#)
- debug messages, display [B-25](#)
- displaying [2-647](#)
- displaying interface information [2-649](#)
- members, displaying [2-651](#)
- mvr (global configuration) command [2-385](#)
- mvr (interface configuration) command [2-388](#)
- mvr vlan group command [2-389](#)

N

native VLANs [2-819](#)

native VLAN tagging [2-852](#)

network-policy (global configuration) command [2-391](#)

network-policy command [2-390](#)

network-policy profile (network-policy configuration)
command [2-392](#)

nmsp attachment suppress command [2-395](#)

nmsp command [2-394](#)

no authentication logging verbose [2-396](#)

no dot1x logging verbose [2-397](#)

no mab logging verbose [2-398](#)

nonegotiate

DTP messaging [2-804](#)

non-IP protocols

denying [2-126](#)

forwarding [2-412](#)

non-IP traffic access lists [2-315](#)

non-IP traffic forwarding

denying [2-126](#)

permitting [2-412](#)

non-stop forwarding [2-399](#)

normal-range VLANs [2-842](#), [2-848](#)

no vlan command [2-842](#)

nsf command [2-399](#)

O

online diagnostics

configuring health monitoring diagnostic tests [2-129](#)

displaying

configured boot-up coverage level [2-500](#)

current scheduled tasks [2-500](#)

event logs [2-500](#)

supported test suites [2-500](#)

test ID [2-500](#)

test results [2-500](#)

test statistics [2-500](#)

enabling

scheduling [2-131](#)

syslog messages [2-129](#)

global configuration mode

clearing health monitoring diagnostic test
schedule [2-129](#)

clearing test-based testing schedule [2-131](#)

setting health monitoring diagnostic
testing [2-129](#)

setting test-based testing [2-131](#)

setting up health monitoring diagnostic test
schedule [2-129](#)

setting up test-based testing [2-131](#)

removing scheduling [2-131](#)

scheduled switchover

disabling [2-131](#)

enabling [2-131](#)

setting test interval [2-131](#)

specifying health monitoring diagnostic tests [2-129](#)

starting testing [2-133](#)

P

PAgP

See EtherChannel

pagp learn-method command [2-401](#)

pagp port-priority command [2-403](#)

password, VTP [2-862](#)

password-recovery mechanism, enabling and
disabling [2-451](#)

permit (ARP access-list configuration) command [2-405](#)

permit (IPv6) command [2-407](#)

permit (MAC access-list configuration) command [2-412](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-401](#)

PID, displaying [2-546](#)

PIM-DVMRP, as multicast router learning method [2-253](#)

platform chassis-management command [2-415](#)

police aggregate command [2-418](#)

police command [2-416](#)

policed-DSCP map [2-352](#)

policy-map command [2-420](#)

- policy maps
 - applying to an interface [2-453, 2-459](#)
 - creating [2-420](#)
 - displaying [2-663](#)
 - hierarchical [2-421](#)
 - policers
 - displaying [2-631](#)
 - for a single class [2-416](#)
 - for multiple classes [2-346, 2-418](#)
 - policed-DSCP map [2-352](#)
 - traffic classification
 - defining the class [2-85](#)
 - defining trust states [2-835](#)
 - setting DSCP or IP precedence values [2-457](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-based authentication
 - AAA method list [2-3](#)
 - configuring violation modes [2-169](#)
 - debug messages, display [B-8](#)
 - enabling guest VLAN supplicant [2-139, 2-150](#)
 - enabling IEEE 802.1x
 - globally [2-136](#)
 - per interface [2-161](#)
 - guest VLAN [2-151](#)
 - host modes [2-153](#)
 - IEEE 802.1x AAA accounting methods [2-1](#)
 - initialize an interface [2-154](#)
 - MAC authentication bypass [2-155](#)
 - manual control of authorization state [2-161](#)
 - multiple hosts on authorized port [2-153](#)
 - PAE as authenticator [2-160](#)
 - periodic re-authentication
 - enabling [2-164](#)
 - time between attempts [2-166](#)
 - quiet period between failed authentication exchanges [2-166](#)
 - re-authenticating IEEE 802.1x-enabled ports [2-163](#)
 - resetting configurable IEEE 802.1x parameters [2-149](#)
 - switch-to-authentication server retransmission time [2-166](#)
 - switch-to-client frame-retransmission number [2-157 to 2-159](#)
 - switch-to-client retransmission time [2-166](#)
- port-channel load-balance command [2-423](#)
- Port Fast, for spanning tree [2-759](#)
- port ranges, defining [2-114, 2-116](#)
- ports, debugging [B-75](#)
- ports, protected [2-817](#)
- port security
 - aging [2-811](#)
 - debug messages, display [B-77](#)
 - enabling [2-806](#)
 - violation error recovery [2-178](#)
- port trust states for QoS [2-378](#)
- port types, MVR [2-388](#)
- power information, displaying [2-515](#)
- priority-queue command [2-425](#)
- priority value, stack member [2-681, 2-782](#)
- private-vlan command [2-427](#)
- private-vlan mapping command [2-430](#)
- private VLANs
 - association [2-815](#)
 - configuring [2-427](#)
 - configuring ports [2-802](#)
 - displaying [2-692](#)
 - host ports [2-802](#)
 - mapping
 - configuring [2-815](#)
 - displaying [2-531](#)
 - promiscuous ports [2-802](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-546](#)
- promiscuous ports, private VLANs [2-802](#)
- protected ports, displaying [2-537](#)

pruning

VLANs [2-819](#)

VTP

displaying interface information [2-531](#)enabling [2-862](#)pruning-eligible VLAN list [2-821](#)

PVST+

See STP

Q

QoS

auto-QoS

configuring [2-59](#)debug messages, display [B-4](#)displaying [2-473](#)

auto-QoS trust

configuring [2-53](#)

auto-QoS video

configuring [2-56](#)

class maps

creating [2-88](#)defining the match criteria [2-339](#)displaying [2-483](#)defining the CoS value for an incoming packet [2-348](#)displaying configuration information [2-473, 2-630](#)DSCP transparency [2-360](#)

DSCP trusted ports

applying DSCP-to-DSCP-mutation map to [2-350](#)defining DSCP-to-DSCP-mutation map [2-352](#)

egress queues

allocating buffers [2-356](#)defining the CoS output queue threshold map [2-374](#)defining the DSCP output queue threshold map [2-376](#)displaying buffer allocations [2-634](#)displaying CoS output queue threshold map [2-638](#)displaying DSCP output queue threshold map [2-638](#)displaying queueing strategy [2-634](#)displaying queue-set settings [2-641](#)enabling bandwidth shaping and scheduling [2-771](#)enabling bandwidth sharing and scheduling [2-773](#)limiting the maximum output on a port [2-769](#)mapping a port to a queue-set [2-432](#)mapping CoS values to a queue and threshold [2-374](#)mapping DSCP values to a queue and threshold [2-376](#)setting maximum and reserved memory allocations [2-358](#)setting WTD thresholds [2-358](#)enabling [2-344](#)

ingress queues

allocating buffers [2-364](#)assigning SRR scheduling weights [2-362](#)defining the CoS input queue threshold map [2-366](#)defining the DSCP input queue threshold map [2-368](#)displaying buffer allocations [2-634](#)displaying CoS input queue threshold map [2-638](#)displaying DSCP input queue threshold map [2-638](#)displaying queueing strategy [2-634](#)displaying settings for [2-632](#)enabling the priority queue [2-370](#)mapping CoS values to a queue and threshold [2-366](#)mapping DSCP values to a queue and threshold [2-368](#)setting WTD thresholds [2-372](#)

maps

defining [2-352, 2-366, 2-368, 2-374, 2-376](#)displaying [2-638](#)

QoS (continued)

policy maps

- applying an aggregate policer [2-418](#)
- applying to an interface [2-453, 2-459](#)
- creating [2-420](#)
- defining policers [2-346, 2-416](#)
- displaying policers [2-631](#)
- displaying policy maps [2-663](#)
- hierarchical [2-421](#)
- policed-DSCP map [2-352](#)
- setting DSCP or IP precedence values [2-457](#)
- traffic classifications [2-85](#)
- trust states [2-835](#)

port trust states [2-378](#)queues, enabling the expedite [2-425](#)

statistics

- in-profile and out-of-profile packets [2-634](#)
- packets enqueued or dropped [2-634](#)
- sent and received CoS values [2-634](#)
- sent and received DSCP values [2-634](#)

trusted boundary for IP phones [2-378](#)VLAN-based [2-380](#)

quality of service

See QoS

querytime, MVR [2-385](#)queue-set command [2-432](#)**R**radius-server dead-criteria command [2-433](#)radius-server host command [2-435](#)

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating IEEE 802.1x-enabled ports [2-163](#)

re-authentication

- periodic [2-164](#)
- time between attempts [2-166](#)

receiver ports, MVR [2-388](#)receiving flow-control packets [2-184](#)

recovery mechanism

- causes [2-178](#)
- display [2-92, 2-480, 2-517, 2-520](#)
- timer interval [2-178](#)

reload command [2-437](#)remote command [2-439](#)remote-span command [2-441](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-21](#)renew ip dhcp snooping database command [2-443](#)reset (boot loader) command [A-22](#)resource templates, displaying [2-668](#)

restricted VLAN

See dot1x auth-fail vlan

rmdir (boot loader) command [A-23](#)rmon collection stats command [2-447](#)root guard, for spanning tree [2-732](#)

routed ports

- IP addresses on [2-198](#)
- number supported [2-198](#)

routing frames

See MTU

RSPAN

- configuring [2-381](#)
- displaying [2-644](#)
- filter RSPAN traffic [2-381](#)
- remote-span command [2-441](#)
- sessions
 - add interfaces to [2-381](#)
 - displaying [2-644](#)
 - start new [2-381](#)

S

scheduled switchover

disabling [2-131](#)

enabling [2-131](#)

SDM mismatch mode [2-449, 2-682](#)

sdm prefer command [2-448](#)

SDM templates

allowed resources [2-449](#)

and stacking [2-449](#)

displaying [2-668](#)

dual IPv4 and IPv6 [2-448](#)

secure ports, limitations [2-808](#)

sending flow-control packets [2-184](#)

service password-recovery command [2-451](#)

service-policy command [2-453](#)

session command [2-456](#)

set (boot loader) command [A-24](#)

set command [2-457](#)

setup command [2-459](#)

setup express command [2-462](#)

show access-lists command [2-464](#)

show archive status command [2-467](#)

show arp access-list command [2-468](#)

show authentication command [2-469](#)

show auto qos command [2-473](#)

show boot command [2-477](#)

show cable-diagnostics tdr command [2-480](#)

show cisp command [2-482](#)

show class-map command [2-483](#)

show controllers cpu-interface command [2-484](#)

show controllers ethernet-controller command [2-486](#)

show controllers ethernet-controller fastethernet command [2-493](#)

show controllers team command [2-496](#)

show controller utilization command [2-498](#)

show dot1q-tunnel command [2-505](#)

show dot1x command [2-506](#)

show dtp [2-510](#)

show eap command [2-512](#)

show env command [2-515](#)

show errdisable detect command [2-517](#)

show errdisable flap-values command [2-519](#)

show errdisable recovery command [2-520](#)

show etherchannel command [2-522](#)

show fallback profile command [2-525](#)

show flowcontrol command [2-527](#)

show idprom command [2-529](#)

show interfaces command [2-531](#)

show interfaces counters command [2-543](#)

show inventory command [2-546](#)

show ip arp inspection command [2-547](#)

show ipc command [2-572](#)

show ip dhcp snooping binding command [2-552](#)

show ip dhcp snooping command [2-551](#)

show ip dhcp snooping database command [2-554, 2-556](#)

show ip igmp profile command [2-559](#)

show ip igmp snooping address command [2-581](#)

show ip igmp snooping command [2-560, 2-579](#)

show ip igmp snooping groups command [2-563](#)

show ip igmp snooping mrouter command [2-565, 2-583](#)

show ip igmp snooping querier command [2-567, 2-585](#)

show ip source binding command [2-569](#)

show ipv6 access-list command [2-576](#)

show ipv6 dhcp conflict command [2-578](#)

show ipv6 route updated [2-587](#)

show ip verify source command [2-570](#)

show l2protocol-tunnel command [2-589](#)

show lacp command [2-592](#)

show link state group command [2-596](#)

show lldp command [2-598](#)

show location [2-599](#)

show location command [2-599](#)

show logging command [2-602](#)

show mac access-group command [2-607](#)

show mac address-table address command [2-611](#)

show mac address-table aging time command [2-613](#)

show mac address-table command [2-609](#)

- show mac address-table count command [2-615](#)
- show mac address-table dynamic command [2-617](#)
- show mac address-table interface command [2-619](#)
- show mac address-table learning command [2-621](#)
- show mac address-table move update command [2-622](#)
- show mac address-table notification command [2-105](#), [2-624](#), [B-23](#)
- show mac address-table static command [2-626](#)
- show mac address-table vlan command [2-628](#)
- show mls qos aggregate-policer command [2-631](#)
- show mls qos command [2-630](#)
- show mls qos input-queue command [2-632](#)
- show mls qos interface command [2-634](#)
- show mls qos maps command [2-638](#)
- show mls qos queue-set command [2-641](#)
- show mls qos vlan command [2-643](#)
- show monitor command [2-644](#)
- show mvr command [2-647](#)
- show mvr interface command [2-649](#)
- show mvr members command [2-651](#)
- show network-policy profile command [2-653](#)
- show nmsp command [2-655](#)
- show pagp command [2-658](#)
- show parser macro command [2-660](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform chassis command [C-4](#)
- show platform configuration command [C-6](#)
- show platform dl command [C-7](#)
- show platform etherchannel command [C-8](#)
- show platform forward command [C-9](#)
- show platform frontend-controller command [C-11](#)
- show platform igmp snooping command [C-12](#)
- show platform ipc trace command [C-20](#)
- show platform ip multicast command [C-14](#)
- show platform ip unicast command [C-15](#)
- show platform ipv6 unicast command [C-21](#)
- show platform ip wccp command [C-19](#)
- show platform layer4op command [C-23](#)
- show platform mac-address-table command [C-24](#)
- show platform messaging command [C-25](#)
- show platform monitor command [C-26](#)
- show platform mvr table command [C-27](#)
- show platform pm command [C-28](#)
- show platform port-asic command [C-30](#)
- show platform port-security command [C-35](#)
- show platform qos command [C-36](#)
- show platform resource-manager command [C-37](#)
- show platform snmp counters command [C-39](#)
- show platform spanning-tree command [C-40](#)
- show platform stack-manager command [C-42](#)
- show platform stp-instance command [C-41](#)
- show platform summary command [C-46](#)
- show platform tb command [C-47](#)
- show platform team command [C-49](#)
- show platform vlan command [C-52](#)
- show policy-map command [2-663](#)
- show port security command [2-665](#)
- show sdm prefer command [2-668](#)
- show setup express command [2-672](#)
- show spanning-tree command [2-673](#)
- show storm-control command [2-679](#)
- show switch command [2-681](#)
- show system mtu command [2-686](#)
- show trust command [2-835](#)
- show uddl command [2-687](#)
- show version command [2-690](#)
- show vlan access-map command [2-697](#)
- show vlan command [2-692](#)
- show vlan command, fields [2-694](#)
- show vlan filter command [2-698](#)
- show vmps command [2-699](#)
- show vtp command [2-702](#)
- shutdown command [2-707](#)
- shutdown threshold, Layer 2 protocol tunneling [2-294](#)
- shutdown vlan command [2-708](#)
- small violation-rate command [2-709](#)

Smartports macros

See macros

SNMP host, specifying [2-715](#)

SNMP informs, enabling the sending of [2-711](#)

snmp-server enable traps command [2-711](#)

snmp-server host command [2-715](#)

snmp trap mac-notification command [2-719](#)

SNMP traps

enabling MAC address notification trap [2-719](#)

enabling the MAC address notification feature [2-322](#)

enabling the sending of [2-711](#)

SoftPhone

See Cisco SoftPhone

software images

copying [2-8](#)

deleting [2-118](#)

downloading [2-11](#)

upgrading [2-8, 2-11](#)

uploading [2-18](#)

software version, displaying [2-690](#)

source ports, MVR [2-388](#)

SPAN

configuring [2-381](#)

debug messages, display [B-24](#)

displaying [2-644](#)

filter SPAN traffic [2-381](#)

sessions

add interfaces to [2-381](#)

displaying [2-644](#)

start new [2-381](#)

spanning-tree backbonefast command [2-721](#)

spanning-tree bpduguard command [2-722](#)

spanning-tree bpduguard command [2-724](#)

spanning-tree cost command [2-726](#)

spanning-tree etherchannel command [2-728](#)

spanning-tree extend system-id command [2-730](#)

spanning-tree guard command [2-732](#)

spanning-tree link-type command [2-734](#)

spanning-tree loopguard default command [2-736](#)

spanning-tree mode command [2-738](#)

spanning-tree mst configuration command [2-740](#)

spanning-tree mst cost command [2-742](#)

spanning-tree mst forward-time command [2-744](#)

spanning-tree mst hello-time command [2-745](#)

spanning-tree mst max-age command [2-746](#)

spanning-tree mst max-hops command [2-747](#)

spanning-tree mst port-priority command [2-748](#)

spanning-tree mst pre-standard command [2-750](#)

spanning-tree mst priority command [2-751](#)

spanning-tree mst root command [2-752](#)

spanning-tree portfast (global configuration) command [2-756](#)

spanning-tree portfast (interface configuration) command [2-759](#)

spanning-tree port-priority command [2-754](#)

Spanning Tree Protocol

See STP

spanning-tree transmit hold-count command [2-761](#)

spanning-tree uplinkfast command [2-762](#)

spanning-tree vlan command [2-764](#)

speed command [2-767](#)

srr-queue bandwidth limit command [2-769](#)

srr-queue bandwidth shape command [2-771](#)

srr-queue bandwidth share command [2-773](#)

SSH, configuring version [2-260](#)

stack-mac persistent timer command [2-775](#)

stack member

access [2-456](#)

number [2-681, 2-785](#)

priority value [2-782](#)

provisioning [2-783](#)

reloading [2-437](#)

stacks, switch

disabling a member [2-780](#)

enabling a member [2-780](#)

MAC address [2-775](#)

provisioning a new member [2-783](#)

reloading [2-437](#)

- stacks, switch (continued)
 - stack member access [2-456](#)
 - stack member number [2-681, 2-785](#)
 - stack member priority value [2-681, 2-782](#)
- static-access ports, configuring [2-789](#)
- statistics, Ethernet group [2-447](#)
- sticky learning, enabling [2-806](#)
- storm-control command [2-777](#)
- STP
 - BackboneFast [2-721](#)
 - counters, clearing [2-110](#)
 - debug messages, display
 - BackboneFast events [B-81](#)
 - MSTP [B-84](#)
 - optimized BPDUs handling [B-83](#)
 - spanning-tree activity [B-79](#)
 - switch shim [B-86](#)
 - transmitted and received BPDUs [B-82](#)
 - UplinkFast [B-88](#)
 - detection of indirect link failures [2-721](#)
 - enabling protocol tunneling for [2-294](#)
 - EtherChannel misconfiguration [2-728](#)
 - extended system ID [2-730](#)
 - path cost [2-726](#)
 - protocol modes [2-738](#)
 - root port
 - accelerating choice of new [2-762](#)
 - loop guard [2-732](#)
 - preventing from becoming designated [2-732](#)
 - restricting which can be root [2-732](#)
 - root guard [2-732](#)
 - UplinkFast [2-762](#)
 - root switch
 - affects of extended system ID [2-730, 2-765](#)
 - hello-time [2-764](#)
 - interval between BPDU messages [2-764](#)
 - interval between hello BPDU messages [2-764](#)
 - max-age [2-764](#)
 - port priority for selection of [2-754](#)
 - primary or secondary [2-764](#)
 - switch priority [2-764](#)
 - state changes
 - blocking to forwarding state [2-759](#)
 - enabling BPDU filtering [2-722, 2-756](#)
 - enabling BPDU guard [2-724, 2-756](#)
 - enabling Port Fast [2-756, 2-759](#)
 - enabling timer to recover from error state [2-178](#)
 - forward-delay time [2-764](#)
 - length of listening and learning states [2-764](#)
 - shutting down Port Fast-enabled ports [2-756](#)
 - state information display [2-673](#)
 - VLAN options [2-751, 2-764](#)
- SVIs, creating [2-192](#)
- SVI status calculation [2-791](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-787](#)
 - returning to interfaces [2-787](#)
- switchport access command [2-789](#)
- switchport autostate exclude command [2-791](#)
- switchport backup interface command [2-793](#)
- switchport block command [2-796](#)
- switchport command [2-787](#)
- switchport host command [2-798](#)
- switchport mode command [2-799](#)
- switchport mode private-vlan command [2-802](#)
- switchport nonegotiate command [2-804](#)
- switchport port-security aging command [2-811](#)
- switchport port-security command [2-806](#)
- switchport priority extend command [2-813](#)
- switchport private-vlan command [2-815](#)
- switchport protected command [2-817](#)
- switchports, displaying [2-531](#)
- switchport trunk command [2-819](#)
- switchport voice detect [2-822](#)
- switchport voice vlan command [2-823](#)
- switch priority command [2-780, 2-782](#)

switch provision command [2-783](#)
 switch renumber command [2-785](#)
 system env temperature threshold yellow command [2-825](#)
 system message logging, save message to flash [2-309](#)
 system mtu command [2-827](#)
 system resource templates [2-448](#)

T

tar files, creating, listing, and extracting [2-15](#)
 TDR, running [2-829](#)
 temperature information, displaying [2-515](#)
 templates, system resources [2-448](#)
 test cable-diagnostics tdr command [2-829](#)
 traceroute mac command [2-830](#)
 traceroute mac ip command [2-833](#)
 trunking, VLAN mode [2-799](#)
 trunk mode [2-799](#)
 trunk ports [2-799](#)
 trunks, to non-DTP device [2-800](#)
 trusted boundary for QoS [2-378](#)
 trusted port states for QoS [2-378](#)
 tunnel ports, Layer 2 protocol, displaying [2-589](#)
 type (boot loader) command [A-27](#)

U

UDLD

aggressive mode [2-837, 2-839](#)
 debug messages, display [B-96](#)
 enable globally [2-837](#)
 enable per interface [2-839](#)
 error recovery timer [2-178](#)
 message timer [2-837](#)
 normal mode [2-837, 2-839](#)
 reset a shutdown interface [2-841](#)
 status [2-687](#)

udld command [2-837](#)

udld port command [2-839](#)
 udld reset command [2-841](#)
 unicast storm control [2-777](#)
 UniDirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-796](#)
 unknown unicast traffic, preventing [2-796](#)
 unset (boot loader) command [A-28](#)
 upgrading
 copying software images [2-8](#)
 downloading software images [2-11](#)
 software images, monitoring status of [2-467](#)
 UplinkFast, for STP [2-762](#)
 user EXEC mode [1-2, 1-3](#)

V

version (boot loader) command [A-30](#)
 version mismatch mode [2-682, C-43](#)
 vlan (global configuration) command [2-842](#)
 vlan (VLAN configuration) command [2-848](#)
 vlan access-map command [2-849](#)
 VLAN access map configuration mode [2-849](#)
 VLAN access maps
 actions [2-6](#)
 displaying [2-697](#)
 VLAN-based QoS [2-380](#)
 VLAN configuration
 rules [2-845](#)
 saving [2-842](#)
 VLAN configuration mode
 commands
 VLAN [2-848](#)
 VTP [2-867](#)
 description [1-4](#)
 entering [2-851](#)
 summary [1-3](#)
 vlan database command [2-851](#)
 vlan dot1q tag native command [2-852](#)

- vlan filter command [2-854](#)
- VLAN filters, displaying [2-698](#)
- VLAN ID range [2-842](#)
- VLAN maps
 - applying [2-854](#)
 - creating [2-849](#)
 - defining [2-337](#)
 - displaying [2-697](#)
- VLAN Query Protocol
 - See VQP
- VLANs
 - adding [2-842](#)
 - configuring [2-842, 2-848](#)
 - debug messages, display
 - ISL [B-92](#)
 - VLAN IOS file system error tests [B-91](#)
 - VLAN manager activity [B-89](#)
 - VTP [B-94](#)
 - displaying configurations [2-692](#)
 - extended-range [2-842](#)
 - MAC addresses
 - displaying [2-628](#)
 - number of [2-615](#)
 - media types [2-845](#)
 - normal-range [2-842, 2-848](#)
 - private [2-802](#)
 - configuring [2-427](#)
 - displaying [2-692](#)
 - See also private VLANs
 - restarting [2-708](#)
 - saving the configuration [2-842](#)
 - shutting down [2-708](#)
 - SNMP traps for VTP [2-713, 2-716](#)
 - suspending [2-708](#)
- VLAN Trunking Protocol
 - See VTP
- VM mode [2-682, C-43](#)
- VMPS
 - configuring servers [2-859](#)
 - displaying [2-699](#)
 - error recovery timer [2-178](#)
 - reconfirming dynamic VLAN assignments [2-856](#)
 - vmmps reconfirm (global configuration) command [2-857](#)
 - vmmps reconfirm (privileged EXEC) command [2-856](#)
 - vmmps retry command [2-858](#)
 - vmmps server command [2-859](#)
- voice VLAN
 - configuring [2-822, 2-823](#)
 - setting port priority [2-813](#)
- VQP
 - and dynamic-access ports [2-790](#)
 - clearing client statistics [2-112](#)
 - displaying information [2-699](#)
 - per-server retry count [2-858](#)
 - reconfirmation interval [2-857](#)
 - reconfirming dynamic VLAN assignments [2-856](#)
- VTP
 - changing characteristics [2-861](#)
 - clearing pruning counters [2-113](#)
 - configuring
 - domain name [2-861](#)
 - file name [2-861](#)
 - mode [2-861](#)
 - password [2-862](#)
 - counters display fields [2-703](#)
 - displaying information [2-702](#)
 - enabling
 - pruning [2-862](#)
 - tunneling for [2-294](#)
 - Version 2 [2-862](#)
 - enabling per port [2-866](#)
 - mode [2-861](#)
 - pruning [2-862](#)
 - saving the configuration [2-842](#)

VTP (continued)

- statistics [2-702](#)

- status [2-702](#)

- status display fields [2-705](#)

- vtp (global configuration) command [2-861](#)

- vtp (VLAN configuration) command [2-867](#)

- vtp interface configuration) command [2-866](#)

- vtp primary command [2-868](#)