



INDEX

A

- aaa accounting dot1x command [2-1](#)
- aaa authentication dot1x command [2-3](#)
- aaa authorization network command [2-5, 2-24, 2-30, 2-32, 2-34, 2-36, 2-38, 2-145, 2-313, B-7, B-32](#)
- AAA methods [2-3](#)
- access control entries
 - See ACEs
- access control lists
 - See ACLs
- access groups
 - IP [2-196](#)
- access list, IPv6 [2-270](#)
- access map configuration mode [2-339](#)
- access mode [2-783](#)
- access ports [2-783](#)
- ACEs [2-129, 2-416](#)
- ACLs
 - deny [2-127](#)
 - for non-IP protocols [2-317](#)
 - IP [2-196](#)
 - matching [2-339](#)
 - on Layer 2 interfaces [2-196](#)
 - permit [2-414](#)
- action command [2-6](#)
- aggregate-port learner [2-403](#)
- allowed VLANs [2-803](#)
- archive copy-sw command [2-8](#)
- archive download-sw command [2-11](#)
- archive tar command [2-15](#)
- archive upload-sw command [2-18](#)
- arp (boot loader) command [A-2](#)
- arp access-list command [2-20](#)
- authentication command disable-port ignore [2-23](#)
- authentication control-direction command [2-24](#)
- authentication event command [2-26](#)
- authentication failed VLAN
 - See dot1x auth-fail vlan
- authentication fallback command [2-30](#)
- authentication host-mode command [2-32](#)
- authentication mac-move permit command [2-34](#)
- authentication open command [2-36](#)
- authentication order command [2-38](#)
- authentication periodic command [2-40](#)
- authentication port-control command [2-42](#)
- authentication priority command [2-44](#)
- authentication timer command [2-46](#)
- authentication violation command [2-48](#)
- auth-fail max-attempts
 - See dot1x auth-fail max-attempts
- auth-fail vlan
 - See dot1x auth-fail vlan
- auth open command [2-36](#)
- auth order command [2-38](#)
- authorization state of controlled port [2-162](#)
- auth timer command [2-46](#)
- autonegotiation of duplex mode [2-173](#)
- auto qos classify command [2-50](#)
- auto qos trust command [2-53](#)
- auto qos video command [2-56](#)
- auto qos voip command [2-59](#)

B

BackboneFast, for STP [2-705](#)

backup interfaces

 configuring [2-777](#)

boot (boot loader) command [A-3](#)

boot auto-copy-sw command [2-66](#)

boot auto-download-sw command [2-68](#)

boot config-file command [2-71](#)

boot enable-break command [2-72](#)

boot helper command [2-73](#)

boot helper-config file command [2-74](#)

booting

 Cisco IOS image [2-77](#)

 interrupting [2-72](#)

 manually [2-75](#)

boot loader

 accessing [A-1](#)

 booting

 Cisco IOS image [A-3](#)

 helper image [2-73](#)

 directories

 creating [A-19](#)

 displaying a list of [A-8](#)

 removing [A-23](#)

 displaying

 available commands [A-13](#)

 memory heap utilization [A-14](#)

 version [A-30](#)

 environment variables

 described [A-24](#)

 displaying settings [A-24](#)

 location of [A-25](#)

 setting [A-24](#)

 unsetting [A-28](#)

 files

 copying [A-6](#)

 deleting [A-7](#)

 displaying a list of [A-8](#)

 displaying the contents of [A-5, A-20, A-27](#)

 renaming [A-21](#)

 file system

 formatting [A-11](#)

 initializing flash [A-10](#)

 running a consistency check [A-12](#)

 prompt [A-1](#)

 resetting the system [A-22](#)

boot manual command [2-75](#)

boot private-config-file command [2-76](#)

boot system command [2-77](#)

BPDU filtering, for spanning tree [2-706, 2-740](#)

BPDU guard, for spanning tree [2-708, 2-740](#)

broadcast storm control [2-761](#)

C

cat (boot loader) command [A-5](#)

CDP, enabling protocol tunneling for [2-296](#)

channel-group command [2-79](#)

channel-protocol command [2-83](#)

Cisco IP camera

 auto-QoS configuration [2-56](#)

Cisco SoftPhone

 auto-QoS configuration [2-59](#)

 trusting packets sent from [2-380](#)

Cisco Telepresence System

 auto-QoS configuration [2-56](#)

CISP

 See Client Information Signalling Protocol

cisp

 debug platform cisp command [B-32](#)

cisp enable command [2-84](#)

class command [2-85](#)

class-map command [2-88](#)

class maps

 creating [2-88](#)

 defining the match criteria [2-341](#)

class of service
 See CoS
 clear dot1x command [2-90](#)
 clear eap command [2-91](#)
 clear errdisable interface [2-92](#)
 clear ip arp inspection log command [2-93](#)
 clear ip arp inspection statistics command [2-94](#)
 clear ipc command [2-99](#)
 clear ip dhcp snooping database command [2-95, 2-97](#)
 clear ipv6 dhcp conflict command [2-100](#)
 clear l2protocol-tunnel counters command [2-101](#)
 clear lacp command [2-102](#)
 clear logging command [2-103](#)
 clear mac address-table command [2-104, 2-105](#)
 clear nmsp statistics command [2-106](#)
 clear pagp command [2-107](#)
 clear port-security command [2-108](#)
 clear psp counter [2-110](#)
 clear psp counter command [2-110](#)
 clear spanning-tree counters command [2-111](#)
 clear spanning-tree detected-protocols command [2-112](#)
 clear vmpls statistics command [2-113](#)
 clear vtp counters command [2-114](#)
 Client Information Signalling Protocol [2-84, 2-145, B-7, B-32](#)
 command modes defined [1-2](#)
 configuration files
 password recovery disable considerations [A-1](#)
 specifying the name [2-71, 2-76](#)
 configuring multiple interfaces [2-192](#)
 config-vlan mode
 commands [2-827](#)
 entering [2-826](#)
 copy (boot loader) command [A-6](#)
 copy logging onboard command [2-115](#)
 CoS
 assigning default value to incoming packets [2-350](#)
 assigning to Layer 2 protocol packets [2-299](#)
 overriding the incoming value [2-350](#)

CoS-to-DSCP map [2-354](#)

crashinfo files [2-183](#)

critical VLAN [2-27](#)

D

debug authentication [B-2](#)
 debug auto qos command [B-4](#)
 debug backup command [B-6](#)
 debug cisp command [B-7](#)
 debug dot1x command [B-8](#)
 debug dtp command [B-9](#)
 debug eap command [B-10](#)
 debug etherchannel command [B-11](#)
 debug fastethernet command [B-12](#)
 debug interface command [B-15](#)
 debug ip dhcp snooping command [B-13](#)
 debug ip igmp filter command [B-16](#)
 debug ip igmp max-groups command [B-17](#)
 debug ip igmp snooping command [B-18](#)
 debug ip verify source packet command [B-14](#)
 debug lacp command [B-19](#)
 debug lldp packets command [B-20](#)
 debug mac-notification command [B-21](#)
 debug matm command [B-22](#)
 debug matm move update command [B-23](#)
 debug monitor command [B-24](#)
 debug mvrdbg command [B-25](#)
 debug nmsp command [B-26](#)
 debug nvram command [B-27](#)
 debug pagp command [B-28](#)
 debug platform acl command [B-29](#)
 debug platform backup interface command [B-31](#)
 debug platform cisp command [B-32](#)
 debug platform cli-redirection main command [B-33](#)
 debug platform configuration command [B-34](#)
 debug platform cpu-queues command [B-35](#)
 debug platform device-manager command [B-37](#)
 debug platform dot1x command [B-38](#)

- debug platform etherchannel command [B-39](#)
- debug platform fallback-bridging command [B-40](#)
- debug platform ip arp inspection command [B-41](#)
- debug platform ipc command [B-50](#)
- debug platform ip dhcp command [B-42](#)
- debug platform ip igmp snooping command [B-43](#)
- debug platform ip multicast command [B-45](#)
- debug platform ip unicast command [B-47](#)
- debug platform ip wccp command [B-49](#)
- debug platform led command [B-51](#)
- debug platform matm command [B-52](#)
- debug platform messaging application command [B-53](#)
- debug platform phy command [B-54](#)
- debug platform pm command [B-56](#)
- debug platform port-asic command [B-58](#)
- debug platform port-security command [B-59](#)
- debug platform qos-acl-tcam command [B-60](#)
- debug platform remote-commands command [B-61](#)
- debug platform resource-manager command [B-62](#)
- debug platform snmp command [B-63](#)
- debug platform span command [B-64](#)
- debug platform stack-manager command [B-65](#)
- debug platform supervisor-asic command [B-66](#)
- debug platform sw-bridge command [B-67](#)
- debug platform tcam command [B-68](#)
- debug platform udd command [B-71](#)
- debug platform vlan command [B-72](#)
- debug pm command [B-73](#)
- debug port-security command [B-75](#)
- debug qos-manager command [B-76](#)
- debug spanning-tree backbonefast command [B-79](#)
- debug spanning-tree bpdu command [B-80](#)
- debug spanning-tree bpdu-opt command [B-81](#)
- debug spanning-tree command [B-77](#)
- debug spanning-tree mstp command [B-82](#)
- debug spanning-tree switch command [B-84](#)
- debug spanning-tree uplinkfast command [B-86](#)
- debug sw-vlan command [B-87](#)
- debug sw-vlan ifs command [B-89](#)
- debug sw-vlan notification command [B-90](#)
- debug sw-vlan vtp command [B-92](#)
- debug udd command [B-94](#)
- debug vqpc command [B-96](#)
- define interface-range command [2-117](#)
- delete (boot loader) command [A-7](#)
- delete command [2-119](#)
- deny (ARP access-list configuration) command [2-120](#)
- deny (IPv6) command [2-122](#)
- deny command [2-127](#)
- detect mechanism, causes [2-175](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-228](#)
 - enabling
 - on a VLAN [2-234](#)
 - option 82 [2-226, 2-228](#)
 - trust on an interface [2-232](#)
 - error recovery timer [2-179](#)
 - rate limiting [2-231](#)
- DHCP snooping binding database
 - binding file, configuring [2-224](#)
 - bindings
 - adding [2-222](#)
 - deleting [2-222](#)
 - clearing database agent statistics [2-95, 2-97](#)
 - database agent, configuring [2-224](#)
 - renewing [2-445](#)
- dir (boot loader) command [A-8](#)
- directories, deleting [2-119](#)
- domain name, VTP [2-842](#)
- dot1x auth-fail max-attempts [2-139](#)
- dot1x auth-fail vlan [2-141](#)
- dot1x command [2-137](#)
- dot1x control-direction command [2-143](#)
- dot1x credentials (global configuration) command [2-145](#)
- dot1x critical global configuration command [2-146](#)
- dot1x critical interface configuration command [2-148](#)
- dot1x default command [2-150](#)
- dot1x fallback command [2-151](#)

- dot1x guest-vlan command [2-152](#)
- dot1x host-mode command [2-154](#)
- dot1x initialize command [2-155](#)
- dot1x mac-auth-bypass command [2-156](#)
- dot1x max-reauth-req command [2-158](#)
- dot1x max-req command [2-160](#)
- dot1x pae command [2-161](#)
- dot1x port-control command [2-162](#)
- dot1x re-authenticate command [2-164](#)
- dot1x reauthentication command [2-165](#)
- dot1x supplicant force-multicast command [2-166](#)
- dot1x timeout command [2-167](#)
- dot1x violation-mode command [2-170](#)
- dropping packets, with ACL matches [2-6](#)
- drop threshold, Layer 2 protocol tunneling [2-296](#)
- DSCP-to-CoS map [2-354](#)
- DSCP-to-DSCP-mutation map [2-354](#)
- DTP [2-784](#)
- DTP flap
 - error detection for [2-175](#)
 - error recovery timer [2-179](#)
- DTP negotiation [2-788](#)
- dual IPv4 and IPv6 templates [2-409](#)
- duplex command [2-172](#)
- dynamic-access ports
 - configuring [2-773](#)
 - restrictions [2-774](#)
- dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [2-204](#)
 - define [2-20](#)
 - deny packets [2-120](#)
 - permit packets [2-407](#)
 - clear
 - log buffer [2-93](#)
 - statistics [2-94](#)
 - enable per VLAN [2-214](#)
 - error detection for [2-175](#)
 - error recovery timer [2-179](#)

- log buffer
 - clear [2-93](#)
 - configure [2-208](#)
- rate-limit incoming ARP packets [2-206](#)
- statistics
 - clear [2-94](#)
- trusted interface state [2-210](#)
- type of packet logged [2-215](#)
- validation checks [2-212](#)

- dynamic auto VLAN membership mode [2-783](#)
- dynamic desirable VLAN membership mode [2-783](#)
- Dynamic Host Configuration Protocol (DHCP)
 - See DHCP snooping
- Dynamic Trunking Protocol
 - See DTP

E

- EAP-request/identity frame
 - maximum number to send [2-160](#)
 - response time before retransmitting [2-167](#)
- encapsulation methods [2-803](#)
- epm access-control open [2-174](#)
- errdisable detect cause command [2-175](#)
- errdisable detect cause small-frame comand [2-177](#)
- errdisable recovery cause small-frame [2-182](#)
- errdisable recovery command [2-179](#)
- error disable detection [2-175](#)
- EtherChannel
 - assigning Ethernet interface to channel group [2-79](#)
 - creating port-channel logical interface [2-190](#)
 - debug EtherChannel/PAgP, display [B-11](#)
 - debug platform-specific events, display [B-39](#)
 - enabling Layer 2 protocol tunneling for
 - LACP [2-297](#)
 - PAgP [2-297](#)
 - UDLD [2-297](#)

EtherChannel (continued)

LACP

- clearing channel-group information [2-102, 2-103](#)
- debug messages, display [B-19](#)
- modes [2-79](#)
- port priority for hot-standby ports [2-300](#)
- restricting a protocol [2-83](#)
- system priority [2-302](#)

load-distribution methods [2-424](#)

PAgP

- aggregate-port learner [2-403](#)
- clearing channel-group information [2-107](#)
- debug messages, display [B-28](#)
- error detection for [2-175](#)
- error recovery timer [2-179](#)
- learn method [2-403](#)
- modes [2-79](#)
- physical-port learner [2-403](#)
- priority of interface for transmitted traffic [2-405](#)

Ethernet Management port, debugging [B-12](#)exception crashinfo command [2-183, 2-188](#)

extended-range VLANs

- and allowed VLAN list [2-803](#)
- and pruning-eligible list [2-803](#)
- configuring [2-826](#)

extended system ID for STP [2-714](#)

Ffallback profile command [2-184](#)fan information, displaying [2-517](#)file name, VTP [2-842](#)files, deleting [2-119](#)flash_init (boot loader) command [A-10](#)flexible authentication ordering [2-38](#)

Flex Links

- configuring [2-777](#)

flowcontrol command [2-186](#)format (boot loader) command [A-11](#)forwarding packets, with ACL matches [2-6](#)forwarding results, display [C-7](#)frame forwarding information, displaying [C-7](#)front-end controller counter and status information [C-9](#)fsck (boot loader) command [A-12](#)

Gglobal configuration mode [1-2, 1-4](#)

Hhealth monitoring diagnostic tests [2-130](#)help (boot loader) command [A-13](#)hierarchical policy maps [2-422](#)host connection, port configuration [2-782](#)host ports, private VLANs [2-786](#)

IIEEE 802.1Q trunk ports and native VLANs [2-833](#)

IEEE 802.1Q tunnel ports

- configuring [2-783](#)
- limitations [2-784](#)

IEEE 802.1x

- and switchport modes [2-784](#)
- violation error recovery [2-179](#)
- See also port-based authentication

IGMP filters

- applying [2-237](#)
- debug messages, display [B-16](#)

IGMP groups, setting maximum [2-239](#)IGMP maximum groups, debugging [B-17](#)

IGMP profiles

- creating [2-241](#)

- IGMP snooping
 - adding ports as a static member of a group [2-257](#)
 - enabling [2-243](#)
 - enabling the configurable-leave timer [2-245](#)
 - enabling the Immediate-Leave feature [2-254](#)
 - flooding query count [2-251](#)
 - interface topology change notification behavior [2-253](#)
 - querier [2-247](#)
 - query solicitation [2-251](#)
 - report suppression [2-249](#)
 - switch topology change notification behavior [2-251](#)
- images
 - See software images
- Immediate-Leave processing
 - IGMP [2-254](#)
 - IPv6 [2-292](#)
 - MVR [2-390](#)
- interface configuration mode [1-2, 1-4](#)
- interface port-channel command [2-190](#)
- interface range command [2-192](#)
- interface-range macros [2-117](#)
- interfaces
 - assigning Ethernet interface to channel group [2-79](#)
 - configuring [2-172](#)
 - configuring multiple [2-192](#)
 - creating port-channel logical [2-190](#)
 - debug messages, display [B-15](#)
 - disabling [2-691](#)
 - restarting [2-691](#)
- interface speed, configuring [2-751](#)
- interface vlan command [2-194](#)
- Internet Group Management Protocol
 - See IGMP
- invalid GBIC
 - error detection for [2-175](#)
 - error recovery timer [2-179](#)
- ip access-group command [2-196](#)
- ip address command [2-199](#)
- IP addresses, setting [2-199](#)
- IP address matching [2-339](#)
- ip admission command [2-201](#)
- ip admission name proxy http command [2-202](#)
- ip arp inspection filter vlan command [2-204](#)
- ip arp inspection limit command [2-206](#)
- ip arp inspection log-buffer command [2-208](#)
- ip arp inspection trust command [2-210](#)
- ip arp inspection validate command [2-212](#)
- ip arp inspection vlan command [2-214](#)
- ip arp inspection vlan logging command [2-215](#)
- ip device tracking command [2-217](#)
- ip device tracking probe command [2-219](#)
- IP DHCP snooping
 - See DHCP snooping
- ip dhcp snooping binding command [2-222](#)
- ip dhcp snooping command [2-221](#)
- ip dhcp snooping database command [2-224](#)
- ip dhcp snooping information option allow-untrusted command [2-228](#)
- ip dhcp snooping information option command [2-226](#)
- ip dhcp snooping information option format remote-id command [2-230](#)
- ip dhcp snooping limit rate command [2-231](#)
- ip dhcp snooping trust command [2-232](#)
- ip dhcp snooping verify command [2-233](#)
- ip dhcp snooping vlan command [2-234](#)
- ip dhcp snooping vlan information option format-type circuit-id string command [2-235](#)
- ip igmp filter command [2-237](#)
- ip igmp max-groups command [2-239, 2-264, 2-266](#)
- ip igmp profile command [2-241](#)
- ip igmp snooping command [2-243](#)
- ip igmp snooping last-member-query-interval command [2-245](#)
- ip igmp snooping querier command [2-247](#)
- ip igmp snooping report-suppression command [2-249](#)
- ip igmp snooping tcn command [2-251](#)
- ip igmp snooping tcn flood command [2-253](#)
- ip igmp snooping vlan immediate-leave command [2-254](#)
- ip igmp snooping vlan mrouter command [2-255](#)

ip igmp snooping vlan static command [2-257](#)

IP multicast addresses [2-387](#)

IP phones

 auto-QoS configuration [2-59](#)

 trusting packets sent from [2-380](#)

IP-precedence-to-DSCP map [2-354](#)

ip snap forwarding command [2-259](#)

ip source binding command [2-260](#)

IP source guard

 disabling [2-268](#)

 enabling [2-268](#)

 static IP source bindings [2-260](#)

ip ssh command [2-262](#)

IPv6 access list, deny conditions [2-122](#)

ipv6 access-list command [2-270](#)

ipv6 address dhcp command [2-272](#)

ipv6 dhcp client request vendor command [2-273](#)

ipv6 dhcp ping packets command [2-274](#)

ipv6 dhcp pool command [2-276](#)

ipv6 dhcp server command [2-278](#)

ipv6 mld snooping command [2-280](#)

ipv6 mld snooping last-listener-query count command [2-282](#)

ipv6 mld snooping last-listener-query-interval command [2-284](#)

ipv6 mld snooping listener-message-suppression command [2-286](#)

ipv6 mld snooping robustness-variable command [2-288](#)

ipv6 mld snooping tcn command [2-290](#)

ipv6 mld snooping vlan command [2-292](#)

ipv6 traffic-filter command [2-294](#)

ip verify source command [2-268](#)

L

l2protocol-tunnel command [2-296](#)

l2protocol-tunnel cos command [2-299](#)

LACP

 See EtherChannel

lacp port-priority command [2-300](#)

lacp system-priority command [2-302](#)

Layer 2 mode, enabling [2-771](#)

Layer 2 protocol-tunnel

 error detection for [2-175](#)

 error recovery timer [2-179](#)

Layer 2 protocol tunnel counters [2-101](#)

Layer 2 protocol tunneling error recovery [2-297](#)

Layer 2 traceroute

 IP addresses [2-817](#)

 MAC addresses [2-814](#)

Layer 3 mode, enabling [2-771](#)

line configuration mode [1-3, 1-5](#)

Link Aggregation Control Protocol

 See EtherChannel

link flap

 error detection for [2-175](#)

 error recovery timer [2-179](#)

link state group command [2-304](#)

link state track command [2-306](#)

load-distribution methods for EtherChannel [2-424](#)

location (global configuration) command [2-307](#)

location (interface configuration) command [2-309](#)

logging file command [2-311](#)

logical interface [2-190](#)

loopback error

 detection for [2-175](#)

 recovery timer [2-179](#)

loop guard, for spanning tree [2-716, 2-720](#)

M

mab request format attribute 32 command [2-313](#)

mac access-group command [2-315](#)

MAC access list configuration mode [2-317](#)

mac access-list extended command [2-317](#)

MAC access lists [2-127](#)

MAC addresses

- disabling MAC address learning per VLAN [2-320](#)

- dynamic

- aging time [2-319](#)

- deleting [2-104](#)

- enabling MAC address notification [2-324](#)

- enabling MAC address-table move update [2-322](#)

- matching [2-339](#)

- persistent stack [2-759](#)

- static

- adding and removing [2-326](#)

- dropping on an interface [2-327](#)

- MAC address notification, debugging [B-21](#)

- mac address-table aging-time [2-315, 2-339](#)

- mac address-table aging-time command [2-319](#)

- mac address-table learning command [2-320](#)

- mac address-table move update command [2-322](#)

- mac address-table notification command [2-324](#)

- mac address-table static command [2-326](#)

- mac address-table static drop command [2-327](#)

- macro apply command [2-329](#)

- macro description command [2-332](#)

- macro global command [2-333](#)

- macro global description command [2-336](#)

- macro name command [2-337](#)

- macros

- adding a description [2-332](#)

- adding a global description [2-336](#)

- applying [2-333](#)

- creating [2-337](#)

- interface range [2-117, 2-192](#)

- specifying parameter values [2-333](#)

- tracing [2-333](#)

- maps

- QoS

- defining [2-354](#)

- VLAN

- creating [2-831](#)

- defining [2-339](#)

- match (access-map configuration) command [2-339](#)

- match (class-map configuration) command [2-341](#)

- maximum transmission unit

- See MTU

- mdix auto command [2-344](#)

- memory (boot loader) command [A-14](#)

- mgmt_clr (boot loader) command [A-16](#)

- mgmt_init (boot loader) command [A-17, A-18](#)

- mkdir (boot loader) command [A-19](#)

- MLD snooping

- configuring [2-286, 2-288](#)

- configuring queries [2-282, 2-284](#)

- configuring topology change notification [2-290](#)

- enabling [2-280](#)

- enabling on a VLAN [2-292](#)

- mls qos aggregate-policer command [2-348](#)

- mls qos command [2-346](#)

- mls qos cos command [2-350](#)

- mls qos dscp-mutation command [2-352](#)

- mls qos map command [2-354](#)

- mls qos queue-set output buffers command [2-358](#)

- mls qos queue-set output threshold command [2-360](#)

- mls qos rewrite ip dscp command [2-362](#)

- mls qos srr-queue input bandwidth command [2-364](#)

- mls qos srr-queue input buffers command [2-366](#)

- mls qos-srr-queue input cos-map command [2-368](#)

- mls qos srr-queue input dscp-map command [2-370](#)

- mls qos srr-queue input priority-queue command [2-372](#)

- mls qos srr-queue input threshold command [2-374](#)

- mls qos-srr-queue output cos-map command [2-376](#)

- mls qos srr-queue output dscp-map command [2-378](#)

- mls qos trust command [2-380](#)

- mls qos vlan-based command [2-382](#)

- mode, MVR [2-387](#)

- modes, commands [1-2](#)

- monitor session command [2-383](#)

- more (boot loader) command [A-20](#)

MSTP

interoperability [2-112](#)

link type [2-718](#)

MST region

aborting changes [2-724](#)

applying changes [2-724](#)

configuration name [2-724](#)

configuration revision number [2-724](#)

current or pending display [2-724](#)

MST configuration mode [2-724](#)

VLANs-to-instance mapping [2-724](#)

path cost [2-726](#)

protocol mode [2-722](#)

restart protocol migration process [2-112](#)

root port

loop guard [2-716](#)

preventing from becoming designated [2-716](#)

restricting which can be root [2-716](#)

root guard [2-716](#)

root switch

affects of extended system ID [2-714](#)

hello-time [2-729, 2-736](#)

interval between BDPUs messages [2-730](#)

interval between hello BPDUs messages [2-729, 2-736](#)

max-age [2-730](#)

maximum hop count before discarding BPDUs [2-731](#)

port priority for selection of [2-732](#)

primary or secondary [2-736](#)

switch priority [2-735](#)

state changes

blocking to forwarding state [2-743](#)

enabling BPDUs filtering [2-706, 2-740](#)

enabling BPDUs guard [2-708, 2-740](#)

enabling Port Fast [2-740, 2-743](#)

forward-delay time [2-728](#)

length of listening and learning states [2-728](#)

rapid transition to forwarding [2-718](#)

shutting down Port Fast-enabled ports [2-740](#)

MTU

configuring size [2-811](#)

Multicast Listener Discovery

See MLD

multicast group address, MVR [2-390](#)

multicast groups, MVR [2-388](#)

multicast router learning method [2-255](#)

multicast router ports, configuring [2-255](#)

multicast router ports, IPv6 [2-292](#)

multicast storm control [2-761](#)

multicast VLAN, MVR [2-387](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-154](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

configuring [2-387](#)

configuring interfaces [2-390](#)

debug messages, display [B-25](#)

mvr (global configuration) command [2-387](#)

mvr (interface configuration) command [2-390](#)

mvr vlan group command [2-391](#)

N

native VLANs [2-803](#)

native VLAN tagging [2-833](#)

network-policy (global configuration) command [2-393](#)

network-policy command [2-392](#)

network-policy profile (network-policy configuration) command [2-394](#)

nmosp attachment suppress command [2-397](#)

nmosp command [2-396](#)

no authentication logging verbose [2-398](#)

no dot1x logging verbose [2-399](#)

no mab logging verbose [2-400](#)

nonegotiate

DTP messaging [2-788](#)

speed [2-751](#)

non-IP protocols

denying [2-127](#)

forwarding [2-414](#)

non-IP traffic access lists [2-317](#)

non-IP traffic forwarding

denying [2-127](#)

permitting [2-414](#)

non-stop forwarding [2-401](#)

normal-range VLANs [2-826](#)

no vlan command [2-826](#)

nsf command [2-401](#)

O

online diagnostics

configuring health monitoring diagnostic tests [2-130](#)

enabling

scheduling [2-132](#)

syslog messages [2-130](#)

global configuration mode

clearing health monitoring diagnostic test schedule [2-130](#)

clearing test-based testing schedule [2-132](#)

setting health monitoring diagnostic testing [2-130](#)

setting test-based testing [2-132](#)

setting up health monitoring diagnostic test schedule [2-130](#)

setting up test-based testing [2-132](#)

removing scheduling [2-132](#)

scheduled switchover

disabling [2-132](#)

enabling [2-132](#)

setting test interval [2-132](#)

specifying health monitoring diagnostic tests [2-130](#)

starting testing [2-134](#)

P

PAgP

See EtherChannel

pagp learn-method command [2-403](#)

pagp port-priority command [2-405](#)

password, VTP [2-843](#)

permit (ARP access-list configuration) command [2-407](#)

permit (IPv6) command [2-409](#)

permit (MAC access-list configuration) command [2-414](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-403](#)

PIM-DVMRP, as multicast router learning method [2-255](#)

police aggregate command [2-419](#)

police command [2-417](#)

policed-DSCP map [2-354](#)

policy-map command [2-421](#)

policy maps

creating [2-421](#)

hierarchical [2-422](#)

policers

for a single class [2-417](#)

for multiple classes [2-348, 2-419](#)

policed-DSCP map [2-354](#)

traffic classification

defining the class [2-85](#)

defining trust states [2-819](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

AAA method list [2-3](#)

configuring violation modes [2-170](#)

debug messages, display [B-8](#)

enabling guest VLAN supplicant [2-140, 2-151](#)

port-based authentication (continued)

enabling IEEE 802.1x

globally [2-137](#)per interface [2-162](#)guest VLAN [2-152](#)host modes [2-154](#)IEEE 802.1x AAA accounting methods [2-1](#)initialize an interface [2-155](#)MAC authentication bypass [2-156](#)manual control of authorization state [2-162](#)multiple hosts on authorized port [2-154](#)PAE as authenticator [2-161](#)

periodic re-authentication

enabling [2-165](#)time between attempts [2-167](#)quiet period between failed authentication
exchanges [2-167](#)re-authenticating IEEE 802.1x-enabled ports [2-164](#)resetting configurable IEEE 802.1x parameters [2-150](#)switch-to-authentication server retransmission
time [2-167](#)switch-to-client frame-retransmission
number [2-158 to 2-160](#)switch-to-client retransmission time [2-167](#)port-channel load-balance command [2-424](#)Port Fast, for spanning tree [2-743](#)port ranges, defining [2-115, 2-117](#)ports, debugging [B-73](#)ports, protected [2-801](#)

port security

aging [2-795](#)debug messages, display [B-75](#)enabling [2-790](#)violation error recovery [2-179](#)port trust states for QoS [2-380](#)port types, MVR [2-390](#)power information, displaying [2-517](#)priority-queue command [2-426](#)priority value, stack member [2-766](#)private-vlan command [2-428](#)private-vlan mapping command [2-431](#)

private VLANs

association [2-799](#)configuring [2-428](#)configuring ports [2-786](#)host ports [2-786](#)

mapping

configuring [2-799](#)promiscuous ports [2-786](#)privileged EXEC mode [1-2, 1-3](#)promiscuous ports, private VLANs [2-786](#)

pruning

VLANs [2-803](#)

VTP

enabling [2-843](#)pruning-eligible VLAN list [2-805](#)psp [2-433](#)psp command [2-433](#)

PVST+

See STP

Q**QoS**

auto-QoS

configuring [2-59](#)debug messages, display [B-4](#)

auto-QoS trust

configuring [2-53](#)

auto-QoS video

configuring [2-56](#)

class maps

creating [2-88](#)defining the match criteria [2-341](#)defining the CoS value for an incoming packet [2-350](#)DSCP transparency [2-362](#)

DSCP trusted ports

applying DSCP-to-DSCP-mutation map to [2-352](#)defining DSCP-to-DSCP-mutation map [2-354](#)

QoS (continued)

egress queues

- allocating buffers [2-358](#)
- defining the CoS output queue threshold map [2-376](#)
- defining the DSCP output queue threshold map [2-378](#)
- enabling bandwidth shaping and scheduling [2-755](#)
- enabling bandwidth sharing and scheduling [2-757](#)
- limiting the maximum output on a port [2-753](#)
- mapping a port to a queue-set [2-434](#)
- mapping CoS values to a queue and threshold [2-376](#)
- mapping DSCP values to a queue and threshold [2-378](#)
- setting maximum and reserved memory allocations [2-360](#)
- setting WTD thresholds [2-360](#)

enabling [2-346](#)

ingress queues

- allocating buffers [2-366](#)
- assigning SRR scheduling weights [2-364](#)
- defining the CoS input queue threshold map [2-368](#)
- defining the DSCP input queue threshold map [2-370](#)
- enabling the priority queue [2-372](#)
- mapping CoS values to a queue and threshold [2-368](#)
- mapping DSCP values to a queue and threshold [2-370](#)
- setting WTD thresholds [2-374](#)

maps

- defining [2-354, 2-368, 2-370, 2-376, 2-378](#)

policy maps

- applying an aggregate policer [2-419](#)
- creating [2-421](#)
- defining policers [2-348, 2-417](#)
- hierarchical [2-422](#)
- policed-DSCP map [2-354](#)

traffic classifications [2-85](#)trust states [2-819](#)port trust states [2-380](#)queues, enabling the expedite [2-426](#)trusted boundary for IP phones [2-380](#)VLAN-based [2-382](#)

quality of service

See QoS

querytime, MVR [2-387](#)queue-set command [2-434](#)

Rradius-server dead-criteria command [2-435](#)radius-server host command [2-437](#)

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating IEEE 802.1x-enabled ports [2-164](#)

re-authentication

periodic [2-165](#)time between attempts [2-167](#)receiver ports, MVR [2-390](#)receiving flow-control packets [2-186](#)

recovery mechanism

causes [2-179](#)display [2-92](#)timer interval [2-180](#)reload command [2-439](#)remote command [2-441](#)remote-span command [2-443](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-21](#)renew ip dhcp snooping database command [2-445](#)reset (boot loader) command [A-22](#)

restricted VLAN

See dot1x auth-fail vlan

rmdir (boot loader) command [A-23](#)
 rmon collection stats command [2-449](#)
 root guard, for spanning tree [2-716](#)
 routed ports
 IP addresses on [2-200](#)
 number supported [2-200](#)
 RSPAN
 configuring [2-383](#)
 filter RSPAN traffic [2-383](#)
 remote-span command [2-443](#)
 sessions
 add interfaces to [2-383](#)
 start new [2-383](#)

S

scheduled switchover
 disabling [2-132](#)
 enabling [2-132](#)
 sdm prefer command [2-450](#)
 SDM templates
 displaying [2-653](#)
 secure ports, limitations [2-792](#)
 sending flow-control packets [2-186](#)
 service password-recovery command [2-454](#)
 service-policy command [2-456](#)
 set (boot loader) command [A-24](#)
 set command [2-460](#)
 setup command [2-462](#)
 setup express command [2-465](#)
 show access-lists command [2-467](#)
 show archive status command [2-470](#)
 show arp access-list command [2-471](#)
 show authentication command [2-472](#)
 show auto qos command [2-476](#)
 show boot command [2-480](#)
 show cable-diagnostics tdr command [2-483](#)
 show cisp command [2-485](#)
 show class-map command [2-486](#)
 show controllers cpu-interface command [2-487](#)
 show controllers ethernet-controller command [2-489](#)
 show controllers ethernet-controller fastethernet command [2-496](#)
 show controllers team command [2-499](#)
 show controller utilization command [2-501](#)
 show dot1q-tunnel command [2-508](#)
 show dot1x command [2-509](#)
 show dtp [2-513](#)
 show eap command [2-515](#)
 show env command [2-517](#)
 show errdisable detect command [2-519](#)
 show errdisable flap-values command [2-521](#)
 show errdisable recovery command [2-522](#)
 show etherchannel command [2-524](#)
 show fallback profile command [2-527](#)
 show flowcontrol command [2-528](#)
 show idprom command [2-530](#)
 show interfaces command [2-532](#)
 show interfaces counters command [2-544](#)
 show inventory command [2-546](#)
 show ip arp inspection command [2-548](#)
 show ipc command [2-572](#)
 show ip dhcp snooping binding command [2-553](#)
 show ip dhcp snooping command [2-552](#)
 show ip dhcp snooping database command [2-555, 2-557](#)
 show ip igmp profile command [2-560](#)
 show ip igmp snooping address command [2-580](#)
 show ip igmp snooping command [2-561, 2-578](#)
 show ip igmp snooping groups command [2-564](#)
 show ip igmp snooping mrouter command [2-566, 2-582](#)
 show ip igmp snooping querier command [2-567](#)
 show ip source binding command [2-569](#)
 show ipv6 access-list command [2-575](#)
 show ipv6 dhcp conflict command [2-577](#)
 show ipv6 route updated [2-586](#)
 show ip verify source command [2-570](#)
 show l2protocol-tunnel command [2-588](#)
 show lacp command [2-590](#)

- show link state group command [2-594](#)
- show location command [2-596](#)
- show logging command [2-598](#)
- show mac address-table address command [2-606](#)
- show mac address-table command [2-604](#)
- show mac address-table count command [2-609](#)
- show mac address-table dynamic command [2-610](#)
- show mac address-table interface command [2-612](#)
- show mac address-table learning command [2-613](#)
- show mac address-table move update command [2-614](#)
- show mac address-table notification command [2-105](#), [2-615](#), [B-23](#)
- show mac address-table vlan command [2-619](#)
- show mls qos aggregate-policer command [2-622](#)
- show mls qos command [2-621](#)
- show mls qos input-queue command [2-623](#)
- show mls qos interface command [2-624](#)
- show mls qos maps command [2-627](#)
- show mls qos queue-set command [2-630](#)
- show mls qos vlan command [2-631](#)
- show monitor command [2-632](#)
- show network-policy profile command [2-639](#)
- show nmsp command [2-640](#)
- show pagp command [2-643](#)
- show parser macro command [2-645](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform configuration command [C-4](#)
- show platform dl command [C-5](#)
- show platform etherchannel command [C-6](#)
- show platform forward command [C-7](#)
- show platform frontend-controller command [C-9](#)
- show platform igmp snooping command [C-10](#)
- show platform ipc trace command [C-17](#)
- show platform ip multicast command [C-11](#)
- show platform ip unicast command [C-12](#)
- show platform ipv6 unicast command [C-18](#)
- show platform ip wccp command [C-16](#)
- show platform layer4op command [C-20](#)
- show platform mac-address-table command [C-21](#)
- show platform messaging command [C-22](#)
- show platform monitor command [C-23](#)
- show platform mvr table command [C-24](#)
- show platform pm command [C-25](#)
- show platform port-asic command [C-26](#)
- show platform port-security command [C-31](#)
- show platform qos command [C-32](#)
- show platform resource-manager command [C-33](#)
- show platform snmp counters command [C-35](#)
- show platform spanning-tree command [C-36](#)
- show platform stack-manager command [C-38](#)
- show platform stp-instance command [C-37](#)
- show platform tb command [C-42](#)
- show platform team command [C-44](#)
- show platform vlan command [C-47](#)
- show policy-map command [2-648](#)
- show port security command [2-649](#)
- show psp config [2-651](#)
- show psp config command [2-651](#)
- show psp statistics [2-652](#)
- show psp statistics command [2-652](#)
- show sdm prefer command [2-653](#)
- show setup express command [2-656](#)
- show spanning-tree command [2-657](#)
- show storm-control command [2-663](#)
- show switch command [2-665](#)
- show system mtu command [2-670](#)
- show trust command [2-819](#)
- show udld command [2-671](#)
- show version command [2-674](#)
- show vlan access-map command [2-680](#)
- show vlan command [2-676](#)
- show vlan filter command [2-681](#)
- show vmps command [2-682](#)
- show vtp command [2-684](#)
- shutdown command [2-691](#)
- shutdown threshold, Layer 2 protocol tunneling [2-296](#)
- shutdown vlan command [2-692](#)

- small violation-rate command [2-693](#)
- Smartports macros
 - See macros
- SNMP host, specifying [2-699](#)
- SNMP informs, enabling the sending of [2-695](#)
- snmp-server enable traps command [2-695](#)
- snmp-server host command [2-699](#)
- snmp trap mac-notification command [2-703](#)
- SNMP traps
 - enabling MAC address notification trap [2-703](#)
 - enabling the MAC address notification feature [2-324](#)
 - enabling the sending of [2-695](#)
- SoftPhone
 - See Cisco SoftPhone
- software images
 - copying [2-8](#)
 - deleting [2-119](#)
 - downloading [2-11](#)
 - upgrading [2-8, 2-11](#)
 - uploading [2-18](#)
- source ports, MVR [2-390](#)
- SPAN
 - configuring [2-383](#)
 - debug messages, display [B-24](#)
 - filter SPAN traffic [2-383](#)
 - sessions
 - add interfaces to [2-383](#)
 - start new [2-383](#)
- spanning-tree backbonefast command [2-705](#)
- spanning-tree bpdudfilter command [2-706](#)
- spanning-tree bpduguard command [2-708](#)
- spanning-tree cost command [2-710](#)
- spanning-tree etherchannel command [2-712](#)
- spanning-tree extend system-id command [2-714](#)
- spanning-tree guard command [2-716](#)
- spanning-tree link-type command [2-718](#)
- spanning-tree loopguard default command [2-720](#)
- spanning-tree mode command [2-722](#)
- spanning-tree mst configuration command [2-724](#)
- spanning-tree mst cost command [2-726](#)
- spanning-tree mst forward-time command [2-728](#)
- spanning-tree mst hello-time command [2-729](#)
- spanning-tree mst max-age command [2-730](#)
- spanning-tree mst max-hops command [2-731](#)
- spanning-tree mst port-priority command [2-732](#)
- spanning-tree mst pre-standard command [2-734](#)
- spanning-tree mst priority command [2-735](#)
- spanning-tree mst root command [2-736](#)
- spanning-tree portfast (global configuration) command [2-740](#)
- spanning-tree portfast (interface configuration) command [2-743](#)
- spanning-tree port-priority command [2-738](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree transmit hold-count command [2-745](#)
- spanning-tree uplinkfast command [2-746](#)
- spanning-tree vlan command [2-748](#)
- speed command [2-751](#)
- srr-queue bandwidth limit command [2-753](#)
- srr-queue bandwidth shape command [2-755](#)
- srr-queue bandwidth share command [2-757](#)
- SSH, configuring version [2-262](#)
- stack-mac persistent timer command [2-759](#)
- stack member
 - number [2-769](#)
 - priority value [2-766](#)
 - provisioning [2-767](#)
 - reloading [2-439](#)
- stacks, switch
 - disabling a member [2-764](#)
 - enabling a member [2-764](#)
 - MAC address [2-759](#)
 - provisioning a new member [2-767](#)
 - reloading [2-439](#)
 - stack member number [2-769](#)
 - stack member priority value [2-766](#)
- static-access ports, configuring [2-773](#)

- sticky learning, enabling [2-790](#)
- storm-control command [2-761](#)
- STP
 - BackboneFast [2-705](#)
 - counters, clearing [2-111](#)
 - debug messages, display
 - BackboneFast events [B-79](#)
 - MSTP [B-82](#)
 - optimized BPDUs handling [B-81](#)
 - spanning-tree activity [B-77](#)
 - switch shim [B-84](#)
 - transmitted and received BPDUs [B-80](#)
 - UplinkFast [B-86](#)
 - detection of indirect link failures [2-705](#)
 - enabling protocol tunneling for [2-296](#)
 - EtherChannel misconfiguration [2-712](#)
 - extended system ID [2-714](#)
 - path cost [2-710](#)
 - protocol modes [2-722](#)
 - root port
 - accelerating choice of new [2-746](#)
 - loop guard [2-716](#)
 - preventing from becoming designated [2-716](#)
 - restricting which can be root [2-716](#)
 - root guard [2-716](#)
 - UplinkFast [2-746](#)
 - root switch
 - affects of extended system ID [2-714, 2-749](#)
 - hello-time [2-748](#)
 - interval between BDPUs messages [2-748](#)
 - interval between hello BDPUs messages [2-748](#)
 - max-age [2-748](#)
 - port priority for selection of [2-738](#)
 - primary or secondary [2-748](#)
 - switch priority [2-748](#)
 - state changes
 - blocking to forwarding state [2-743](#)
 - enabling BPDU filtering [2-706, 2-740](#)
 - enabling BPDU guard [2-708, 2-740](#)
 - enabling Port Fast [2-740, 2-743](#)
 - enabling timer to recover from error state [2-179](#)
 - forward-delay time [2-748](#)
 - length of listening and learning states [2-748](#)
 - shutting down Port Fast-enabled ports [2-740](#)
 - VLAN options [2-735, 2-748](#)
 - SVIs, creating [2-194](#)
 - SVI status calculation [2-775](#)
 - Switched Port Analyzer
 - See SPAN
 - switching characteristics
 - modifying [2-771](#)
 - returning to interfaces [2-771](#)
 - switchport access command [2-773](#)
 - switchport autostate exclude command [2-775](#)
 - switchport backup interface command [2-777](#)
 - switchport block command [2-780](#)
 - switchport command [2-771](#)
 - switchport host command [2-782](#)
 - switchport mode command [2-783](#)
 - switchport mode private-vlan command [2-786](#)
 - switchport nonegotiate command [2-788](#)
 - switchport port-security aging command [2-795](#)
 - switchport port-security command [2-790](#)
 - switchport priority extend command [2-797](#)
 - switchport private-vlan command [2-799](#)
 - switchport protected command [2-801](#)
 - switchport trunk command [2-803](#)
 - switchport voice detect [2-806](#)
 - switchport voice vlan command [2-807](#)
 - switch priority command [2-764, 2-766](#)
 - switch provision command [2-767](#)
 - switch renumber command [2-769](#)
 - system env temperature threshold yellow command [2-809](#)
 - system message logging, save message to flash [2-311](#)
 - system mtu command [2-811](#)
 - system resource templates [2-450](#)

T

tar files, creating, listing, and extracting [2-15](#)

TDR, running [2-813](#)

temperature information, displaying [2-517](#)

templates, system resources [2-450](#)

test cable-diagnostics tdr command [2-813](#)

traceroute mac command [2-814](#)

traceroute mac ip command [2-817](#)

trunking, VLAN mode [2-783](#)

trunk mode [2-783](#)

trunk ports [2-783](#)

trunks, to non-DTP device [2-784](#)

trusted boundary for QoS [2-380](#)

trusted port states for QoS [2-380](#)

type (boot loader) command [A-27](#)

U
UDLD

- aggressive mode [2-821, 2-823](#)
- debug messages, display [B-94](#)
- enable globally [2-821](#)
- enable per interface [2-823](#)
- error recovery timer [2-179](#)
- message timer [2-821](#)
- normal mode [2-821, 2-823](#)
- reset a shutdown interface [2-825](#)

udld command [2-821](#)

udld port command [2-823](#)

udld reset command [2-825](#)

unicast storm control [2-761](#)

UniDirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-780](#)

unknown unicast traffic, preventing [2-780](#)

unset (boot loader) command [A-28](#)

upgrading

- copying software images [2-8](#)

- downloading software images [2-11](#)

UplinkFast, for STP [2-746](#)

user EXEC mode [1-2, 1-3](#)

V

version (boot loader) command [A-30](#)

version mismatch mode [C-39](#)

vlan (global configuration) command [2-826](#)

vlan access-map command [2-831](#)

VLAN access map configuration mode [2-831](#)

VLAN access maps

- actions [2-6](#)

VLAN-based QoS [2-382](#)

VLAN configuration

- rules [2-829](#)

- saving [2-826](#)

VLAN configuration mode

- description [1-4](#)

- summary [1-3](#)

vlan dot1q tag native command [2-833](#)

vlan filter command [2-835](#)

VLAN ID range [2-826](#)

VLAN maps

- applying [2-835](#)

- creating [2-831](#)

- defining [2-339](#)

VLAN Query Protocol

- See VQP

VLANs

- adding [2-826](#)

- configuring [2-826](#)

- debug messages, display

- ISL [B-90](#)

- VLAN IOS file system error tests [B-89](#)

- VLAN manager activity [B-87](#)

- VTP [B-92](#)

VLANs (continued)

- extended-range [2-826](#)

- media types [2-829](#)

- normal-range [2-826](#)

- private [2-786](#)

- configuring [2-428](#)

- See also private VLANs

- restarting [2-692](#)

- saving the configuration [2-826](#)

- shutting down [2-692](#)

- SNMP traps for VTP [2-697, 2-700](#)

- suspending [2-692](#)

VLAN Trunking Protocol

- See VTP

VM mode [C-39](#)

VMPS

- configuring servers [2-840](#)

- error recovery timer [2-180](#)

- reconfirming dynamic VLAN assignments [2-837](#)

- vmmps reconfirm (global configuration) command [2-838](#)

- vmmps reconfirm (privileged EXEC) command [2-837](#)

- vmmps retry command [2-839](#)

- vmmps server command [2-840](#)

voice VLAN

- configuring [2-806, 2-807](#)

- setting port priority [2-797](#)

VQP

- and dynamic-access ports [2-774](#)

- clearing client statistics [2-113](#)

- per-server retry count [2-839](#)

- reconfirmation interval [2-838](#)

- reconfirming dynamic VLAN assignments [2-837](#)

VTP

- changing characteristics [2-842](#)

- clearing pruning counters [2-114](#)

- configuring

- domain name [2-842](#)

- file name [2-842](#)

- mode [2-842](#)

- password [2-843](#)

- enabling

- pruning [2-843](#)

- tunneling for [2-296](#)

- Version 2 [2-843](#)

- enabling per port [2-847](#)

- mode [2-842](#)

- pruning [2-843](#)

- saving the configuration [2-826](#)

- vtp (global configuration) command [2-842](#)

- vtp interface configuration) command [2-847](#)

- vtp primary command [2-848](#)

